LinuxQMISDK-Lite

SLQS04.00.11

Generated by Doxygen 1.8.6

Mon Oct 30 2017 02:57:40

Contents

1 Welcome to the Sierra Wireless Linux QMI SDK API Reference Guide 1

1.1 Important Notice . . . 1
1.2 Limitation of Liability . . . 1
1.3 Patents . . . 1
1.4 Copyright . . . 2
1.5 Trademarks . . . 2
1.6 Contact Information . . . 2

2 Module Index 3

2.1 Modules . . . 3

3 Namespace Index 5

3.1 Namespace List . . . 5

4 Data Structure Index 7

4.1 Data Structures . . . 7

5 File Index 23

5.1 File List . . . 23

6 Module Documentation 25

6.1 QMI pack/unpack (lite-qmi) . . . 25
6.1.1 Detailed Description . . . 25
6.2 Streaming Download Protocol (lite-fw) . . . 26
6.2.1 Detailed Description . . . 26

7 Namespace Documentation 27

7.1 Tables Namespace Reference . . . 27
7.1.1 Detailed Description . . . 27

8 Data Structure Documentation 29

8.1 _litefw_FirmwareInfo_ Struct Reference . . . 29
8.1.1 Detailed Description . . . 29
8.1.2 Field Documentation . . . 29

8.1.2.1 szCarrier_str . . . 30
8.1.2.2 szCarrierPriversion_str . . . 30
8.1.2.3 szFwversion_str . . . 30
8.1.2.4 szModelid_str . . . 30
8.1.2.5 szPackageid_str . . . 30
8.1.2.6 szSku_str . . . 30
8.2 altSrcInfo_t Struct Reference . . . 30
8.2.1 Detailed Description . . . 30
8.2.2 Field Documentation . . . 31
8.2.2.1 coverage . . . 31
8.2.2.2 linkage . . . 31
8.2.2.3 source . . . 31
8.3 appStats Struct Reference . . . 31
8.3.1 Detailed Description . . . 31
8.3.2 Field Documentation . . . 33
8.3.2.1 aidLength . . . 33
8.3.2.2 aidVal . . . 33
8.3.2.3 appState . . . 33
8.3.2.4 appType . . . 33
8.3.2.5 persoFeature . . . 33
8.3.2.6 persoRetries . . . 33
8.3.2.7 persoState . . . 33
8.3.2.8 persoUnblockRetries . . . 34
8.3.2.9 pin1Retries . . . 34
8.3.2.10 pin1State . . . 34
8.3.2.11 pin2Retries . . . 34
8.3.2.12 pin2State . . . 34
8.3.2.13 puk1Retries . . . 34
8.3.2.14 puk2Retries . . . 34
8.3.2.15 univPin . . . 34
8.4 audio_RXAGCList Struct Reference . . . 34
8.4.1 Detailed Description . . . 34
8.4.2 Field Documentation . . . 34
8.4.2.1 pRXAIG . . . 35
8.4.2.2 pRXComprSlope . . . 35
8.4.2.3 pRXComprThres . . . 35
8.4.2.4 pRXExpSlope . . . 35
8.4.2.5 pRXExpThres . . . 35
8.4.2.6 pRXStaticGain . . . 35
8.5 audio_RXAVCList Struct Reference . . . 35

8.5.1 Detailed Description . . . 35
8.5.2 Field Documentation . . . 35
8.5.2.1 pAVRXAVCHeadroom . . . 35
8.5.2.2 pAVRXAVCSens . . . 35
8.6 audio_RXPCMIIRFltr Struct Reference . . . 35
8.6.1 Detailed Description . . . 35
8.6.2 Field Documentation . . . 37
8.6.2.1 pFlag . . . 37
8.6.2.2 pStage0Val . . . 37
8.6.2.3 pStage1Val . . . 37
8.6.2.4 pStage2Val . . . 37
8.6.2.5 pStage3Val . . . 37
8.6.2.6 pStage4Val . . . 37
8.6.2.7 pStageCnt . . . 37
8.7 audio_TXAGCList Struct Reference . . . 37
8.7.1 Detailed Description . . . 37
8.7.2 Field Documentation . . . 37
8.7.2.1 pTXAIG . . . 38
8.7.2.2 pTXComprSlope . . . 38
8.7.2.3 pTXComprThres . . . 38
8.7.2.4 pTXExpSlope . . . 38
8.7.2.5 pTXExpThres . . . 38
8.7.2.6 pTXStaticGain . . . 38
8.8 audio_TXPCMIIRFltr Struct Reference . . . 38
8.8.1 Detailed Description . . . 38
8.8.2 Field Documentation . . . 39
8.8.2.1 pFlag . . . 39
8.8.2.2 pStage0Val . . . 39
8.8.2.3 pStage1Val . . . 39
8.8.2.4 pStage2Val . . . 39
8.8.2.5 pStage3Val . . . 39
8.8.2.6 pStage4Val . . . 39
8.8.2.7 pStageCnt . . . 39
8.9 CarrierImage_t Struct Reference . . . 39
8.9.1 Detailed Description . . . 40
8.9.2 Field Documentation . . . 40
8.9.2.1 m_FwBuildId . . . 40
8.9.2.2 m_FwImageId . . . 40
8.9.2.3 m_nCarrierId . . . 40
8.9.2.4 m_nFolderId . . . 40

8.9.2.5 m_nStorage . . . 40
8.9.2.6 m_PriBuildId . . . 41
8.9.2.7 m_PriImageId . . . 41
8.10 cat_AlPhaIdentifierTlv Struct Reference . . . 41
8.10.1 Detailed Description . . . 41
8.10.2 Field Documentation . . . 41
8.10.2.1 AlphaID . . . 41
8.10.2.2 AlphaIDLength . . . 41
8.10.2.3 ReferenceID . . . 41
8.11 cat_commonEventTlv Struct Reference . . . 41
8.11.1 Detailed Description . . . 41
8.11.2 Field Documentation . . . 42
8.11.2.1 CatEvent . . . 42
8.11.2.2 EventID . . . 42
8.11.2.3 EventLength . . . 42
8.11.2.4 TlvPresent . . . 42
8.12 cat_currentCatEvent Union Reference . . . 42
8.12.1 Detailed Description . . . 42
8.12.2 Field Documentation . . . 42
8.12.2.1 CatAlphaIdtfr . . . 42
8.12.2.2 CatEndPS . . . 42
8.12.2.3 CatEventLst . . . 42
8.12.2.4 CatEvIDData . . . 42
8.12.2.5 CatRefresh . . . 42
8.13 cat_EndProactiveSessionTlv Struct Reference . . . 43
8.13.1 Detailed Description . . . 43
8.13.2 Field Documentation . . . 43
8.13.2.1 EndProactiveSession . . . 43
8.14 cat_EventIDDataTlv Struct Reference . . . 43
8.14.1 Detailed Description . . . 43
8.14.2 Field Documentation . . . 43
8.14.2.1 Data . . . 43
8.14.2.2 DataLength . . . 43
8.14.2.3 ReferenceID . . . 43
8.15 cat_EventListTlv Struct Reference . . . 43
8.15.1 Detailed Description . . . 44
8.15.2 Field Documentation . . . 44
8.15.2.1 SetupEventList . . . 44
8.16 cat_RefreshTlv Struct Reference . . . 44
8.16.1 Detailed Description . . . 44

8.16.2 Field Documentation . . . 44
8.16.2.1 RefreshMode . . . 44
8.16.2.2 RefreshStage . . . 44
8.17 cdmaSSInfo Struct Reference . . . 44
8.17.1 Detailed Description . . . 45
8.17.2 Field Documentation . . . 45
8.17.2.1 ecio . . . 45
8.17.2.2 rssi . . . 45
8.18 connectionStatus Struct Reference . . . 45
8.18.1 Detailed Description . . . 45
8.18.2 Field Documentation . . . 45
8.18.2.1 MDMCallDuration . . . 45
8.18.2.2 MDMConnStatus . . . 46
8.19 crashInfoParams Struct Reference . . . 46
8.19.1 Detailed Description . . . 46
8.19.2 Field Documentation . . . 46
8.19.2.1 crashInfo . . . 46
8.19.2.2 crashStatus . . . 46
8.20 crashInformation Struct Reference . . . 46
8.20.1 Detailed Description . . . 46
8.20.2 Field Documentation . . . 47
8.20.2.1 crashData . . . 47
8.20.2.2 crashId . . . 47
8.20.2.3 crashString . . . 47
8.20.2.4 crashStrlen . . . 47
8.20.2.5 gcdumpString . . . 47
8.20.2.6 gcdumpStrlen . . . 47
8.20.2.7 numCrashes . . . 47
8.21 currNetworkInfo Struct Reference . . . 47
8.21.1 Detailed Description . . . 47
8.21.2 Field Documentation . . . 49
8.21.2.1 NetworkType . . . 49
8.21.2.2 RATMask . . . 49
8.21.2.3 SOMask . . . 49
8.22 dms_ActivationStatusTlv Struct Reference . . . 49
8.22.1 Detailed Description . . . 49
8.22.2 Field Documentation . . . 50
8.22.2.1 activationStatus . . . 50
8.22.2.2 TlvPresent . . . 50
8.23 dms_OperatingModeTlv Struct Reference . . . 50

8.23.1 Detailed Description . . . 50
8.23.2 Field Documentation . . . 50
8.23.2.1 operatingMode . . . 51
8.23.2.2 TlvPresent . . . 51
8.24 DMScustSettingInfo Struct Reference . . . 51
8.24.1 Detailed Description . . . 51
8.24.2 Field Documentation . . . 51
8.24.2.1 cust_attr . . . 51
8.24.2.2 cust_id . . . 51
8.24.2.3 cust_value . . . 51
8.24.2.4 id_length . . . 51
8.24.2.5 value_length . . . 51
8.25 DMScustSettingList Struct Reference . . . 52
8.25.1 Detailed Description . . . 52
8.25.2 Field Documentation . . . 52
8.25.2.1 custSetting . . . 52
8.25.2.2 list_type . . . 52
8.25.2.3 num_instances . . . 52
8.26 DMSgetCustomFeatureV2 Struct Reference . . . 52
8.26.1 Detailed Description . . . 52
8.26.2 Field Documentation . . . 53
8.26.2.1 pCustSettingInfo . . . 53
8.26.2.2 pCustSettingList . . . 53
8.26.2.3 pGetCustomInput . . . 53
8.27 DMSgetCustomInput Struct Reference . . . 53
8.27.1 Detailed Description . . . 53
8.27.2 Field Documentation . . . 53
8.27.2.1 cust_id . . . 53
8.27.2.2 list_type . . . 53
8.28 dunchannelRate Struct Reference . . . 53
8.28.1 Detailed Description . . . 54
8.28.2 Field Documentation . . . 54
8.28.2.1 CurrChanRxRate . . . 54
8.28.2.2 CurrChanTxRate . . . 54
8.28.2.3 MaxChanRxRate . . . 54
8.28.2.4 MaxChanTxRate . . . 54
8.29 eriDataparams Struct Reference . . . 54
8.29.1 Detailed Description . . . 54
8.29.2 Field Documentation . . . 55
8.29.2.1 eriData . . . 55

8.29.2.2 eriDataLen . . . 55
8.30 eTWSPLMNInfoTlv Struct Reference . . . 55
8.30.1 Detailed Description . . . 55
8.30.2 Field Documentation . . . 55
8.30.2.1 ETWSPLMNInfo . . . 55
8.30.2.2 TlvPresent . . . 55
8.31 FMSImageElement Struct Reference . . . 55
8.31.1 Detailed Description . . . 55
8.31.2 Field Documentation . . . 56
8.31.2.1 buildId . . . 56
8.31.2.2 buildIdLength . . . 56
8.31.2.3 imageId . . . 56
8.31.2.4 imageType . . . 56
8.32 FMSImageIdElement Struct Reference . . . 56
8.32.1 Detailed Description . . . 56
8.32.2 Field Documentation . . . 57
8.32.2.1 buildID . . . 57
8.32.2.2 buildIDLength . . . 57
8.32.2.3 failureCount . . . 57
8.32.2.4 imageID . . . 57
8.32.2.5 storageIndex . . . 57
8.33 FMSImageIDEntries Struct Reference . . . 57
8.33.1 Detailed Description . . . 57
8.33.2 Field Documentation . . . 57
8.33.2.1 executingImage . . . 57
8.33.2.2 imageIDElement . . . 57
8.33.2.3 imageIDSize . . . 58
8.33.2.4 imageType . . . 58
8.33.2.5 maxImages . . . 58
8.34 FMSImageList Struct Reference . . . 58
8.34.1 Detailed Description . . . 58
8.34.2 Field Documentation . . . 58
8.34.2.1 imageIDEntries . . . 58
8.34.2.2 listSize . . . 58
8.35 FMSPrefImageList Struct Reference . . . 58
8.35.1 Detailed Description . . . 58
8.35.2 Field Documentation . . . 59
8.35.2.1 listEntries . . . 59
8.35.2.2 listSize . . . 59
8.36 hdrSSInfo Struct Reference . . . 59

8.36.1 Detailed Description . . . 59
8.36.2 Field Documentation . . . 59
8.36.2.1 ecio . . . 59
8.36.2.2 io . . . 60
8.36.2.3 rssi . . . 60
8.36.2.4 sinr . . . 60
8.37 image_info_t Struct Reference . . . 60
8.37.1 Detailed Description . . . 60
8.37.2 Field Documentation . . . 60
8.37.2.1 buildID . . . 60
8.37.2.2 buildIDLen . . . 60
8.37.2.3 imageType . . . 60
8.37.2.4 uniqueID . . . 60
8.38 ipv6_addr Struct Reference . . . 60
8.38.1 Field Documentation . . . 61
8.38.1.1 ipv6addr . . . 61
8.38.1.2 prefix . . . 61
8.39 ipv6AddressInfo Struct Reference . . . 61
8.39.1 Detailed Description . . . 61
8.39.2 Field Documentation . . . 61
8.39.2.1 IPAddressV6 . . . 61
8.39.2.2 IPV6PrefixLen . . . 61
8.40 LibPackGPRSRequestedQoS Struct Reference . . . 61
8.40.1 Detailed Description . . . 61
8.40.2 Field Documentation . . . 62
8.40.2.1 delayClass . . . 62
8.40.2.2 meanThroughputClass . . . 62
8.40.2.3 peakThroughputClass . . . 62
8.40.2.4 precedenceClass . . . 62
8.40.2.5 reliabilityClass . . . 62
8.41 LibpackProfile3GPP Struct Reference . . . 62
8.41.1 Detailed Description . . . 63
8.41.2 Field Documentation . . . 67
8.41.2.1 pAddrAllocPref . . . 67
8.41.2.2 pAPNClass . . . 67
8.41.2.3 pAPNDisabledFlag . . . 67
8.41.2.4 pAPNName . . . 68
8.41.2.5 pAPNnameSize . . . 68
8.41.2.6 pAuthenticationPref . . . 68
8.41.2.7 pGPRSMinimumQoS . . . 68

8.41.2.8 pGPRSRequestedQos . . . 68
8.41.2.9 pImCnFlag . . . 68
8.41.2.10 pIPv4AddrPref . . . 68
8.41.2.11 pIPv6AddPref . . . 68
8.41.2.12 pPassword . . . 68
8.41.2.13 pPasswordSize . . . 68
8.41.2.14 pPcscfAddrUsingDhcp . . . 68
8.41.2.15 pPcscfAddrUsingPCO . . . 68
8.41.2.16 pPDNInactivTimeout . . . 68
8.41.2.17 pPdpAccessConFlag . . . 68
8.41.2.18 pPdpContext . . . 68
8.41.2.19 pPdpDataCompType . . . 68
8.41.2.20 pPdpHdrCompType . . . 68
8.41.2.21 pPDPtype . . . 68
8.41.2.22 pPriDNSIPv4AddPref . . . 68
8.41.2.23 pPriDNSIPv6addpref . . . 68
8.41.2.24 pPrimaryID . . . 68
8.41.2.25 pProfilename . . . 68
8.41.2.26 pProfilenameSize . . . 68
8.41.2.27 pQosClassID . . . 68
8.41.2.28 pSecDNSIPv4AddPref . . . 68
8.41.2.29 pSecDNSIPv6addpref . . . 68
8.41.2.30 pSecondaryFlag . . . 68
8.41.2.31 pTFTID1Params . . . 68
8.41.2.32 pTFTID2Params . . . 69
8.41.2.33 pUMTSMinQoS . . . 69
8.41.2.34 pUMTSMinQosSigInd . . . 69
8.41.2.35 pUMTSReqQoS . . . 69
8.41.2.36 pUMTSReqQoSSigInd . . . 69
8.41.2.37 pUsername . . . 69
8.41.2.38 pUsernameSize . . . 69
8.42 LibpackProfile3GPP2 Struct Reference . . . 69
8.42.1 Detailed Description . . . 70
8.42.2 Field Documentation . . . 73
8.42.2.1 pAllowLinger . . . 73
8.42.2.2 pAPNClass3GPP2 . . . 73
8.42.2.3 pAPNEnabled3GPP2 . . . 73
8.42.2.4 pApnString . . . 73
8.42.2.5 pApnStringSize . . . 73
8.42.2.6 pAppPriority . . . 73

8.42.2.7 pAppType . . . 73
8.42.2.8 pAuthPassword . . . 73
8.42.2.9 pAuthPasswordSize . . . 73
8.42.2.10 pAuthProtocol . . . 73
8.42.2.11 pAuthRetryCount . . . 73
8.42.2.12 pAuthTimeout . . . 73
8.42.2.13 pDataMode . . . 73
8.42.2.14 pDataRate . . . 73
8.42.2.15 pIpcpAckTimeout . . . 74
8.42.2.16 pIpcpCreqRetryCount . . . 74
8.42.2.17 pIsPcscfAddressNedded . . . 74
8.42.2.18 pLcpAckTimeout . . . 74
8.42.2.19 pLcpCreqRetryCount . . . 74
8.42.2.20 pNegoDnsSrvrPref . . . 74
8.42.2.21 pPDNInactivTimeout3GPP2 . . . 74
8.42.2.22 pPdnType . . . 74
8.42.2.23 pPppSessCloseTimer1x . . . 74
8.42.2.24 pPppSessCloseTimerDO . . . 74
8.42.2.25 pPrimaryV4DnsAddress . . . 74
8.42.2.26 pPriV6DnsAddress . . . 74
8.42.2.27 pRATType . . . 74
8.42.2.28 pSecondaryV4DnsAddress . . . 74
8.42.2.29 pSecV6DnsAddress . . . 74
8.42.2.30 pUserId . . . 74
8.42.2.31 pUserIdSize . . . 74
8.43 LibPackprofile_3GPP Struct Reference . . . 74
8.43.1 Detailed Description . . . 75
8.43.2 Field Documentation . . . 79
8.43.2.1 pAddrAllocPref . . . 79
8.43.2.2 pAPNClass . . . 79
8.43.2.3 pAPNDisabledFlag . . . 79
8.43.2.4 pAPNName . . . 79
8.43.2.5 pAPNnameSize . . . 79
8.43.2.6 pAuthenticationPref . . . 79
8.43.2.7 pGPRSMinimumQoS . . . 79
8.43.2.8 pGPRSRequestedQos . . . 79
8.43.2.9 pImCnFlag . . . 79
8.43.2.10 pIPv4AddrPref . . . 79
8.43.2.11 pIPv6AddPref . . . 79
8.43.2.12 pPassword . . . 79

8.43.2.13 pPasswordSize . . . 79
8.43.2.14 pPcscfAddrUsingDhcp . . . 79
8.43.2.15 pPcscfAddrUsingPCO . . . 79
8.43.2.16 pPDNInactivTimeout . . . 79
8.43.2.17 pPdpAccessConFlag . . . 79
8.43.2.18 pPdpContext . . . 79
8.43.2.19 pPdpDataCompType . . . 79
8.43.2.20 pPdpHdrCompType . . . 79
8.43.2.21 pPDPtype . . . 79
8.43.2.22 pPriDNSIPv4AddPref . . . 79
8.43.2.23 pPriDNSIPv6addpref . . . 79
8.43.2.24 pPrimaryID . . . 80
8.43.2.25 pProfilename . . . 80
8.43.2.26 pProfilenameSize . . . 80
8.43.2.27 pQosClassID . . . 80
8.43.2.28 pSecDNSIPv4AddPref . . . 80
8.43.2.29 pSecDNSIPv6addpref . . . 80
8.43.2.30 pSecondaryFlag . . . 80
8.43.2.31 pTFTID1Params . . . 80
8.43.2.32 pTFTID2Params . . . 80
8.43.2.33 pUMTSMinQoS . . . 80
8.43.2.34 pUMTSMinQosSigInd . . . 80
8.43.2.35 pUMTSReqQoS . . . 80
8.43.2.36 pUMTSReqQoSSigInd . . . 80
8.43.2.37 pUsername . . . 80
8.43.2.38 pUsernameSize . . . 80
8.44 LibPackprofile_3GPP2 Struct Reference . . . 80
8.44.1 Detailed Description . . . 81
8.44.2 Field Documentation . . . 84
8.44.2.1 pAllowLinger . . . 84
8.44.2.2 pAPNClass3GPP2 . . . 84
8.44.2.3 pAPNEnabled3GPP2 . . . 84
8.44.2.4 pApnString . . . 84
8.44.2.5 pApnStringSize . . . 84
8.44.2.6 pAppPriority . . . 84
8.44.2.7 pAppType . . . 84
8.44.2.8 pAuthPassword . . . 84
8.44.2.9 pAuthPassword_tSize . . . 84
8.44.2.10 pAuthProtocol . . . 85
8.44.2.11 pAuthRetryCount . . . 85

8.44.2.12 pAuthTimeout . . . 85
8.44.2.13 pDataMode . . . 85
8.44.2.14 pDataRate . . . 85
8.44.2.15 pIpcpAckTimeout . . . 85
8.44.2.16 pIpcpCreqRetryCount . . . 85
8.44.2.17 pIsPcscfAddressNedded . . . 85
8.44.2.18 pLcpAckTimeout . . . 85
8.44.2.19 pLcpCreqRetryCount . . . 85
8.44.2.20 pNegoDnsSrvrPref . . . 85
8.44.2.21 pPDNInactivTimeout3GPP2 . . . 85
8.44.2.22 pPdnType . . . 85
8.44.2.23 pPppSessCloseTimer1x . . . 85
8.44.2.24 pPppSessCloseTimerDO . . . 85
8.44.2.25 pPrimaryV4DnsAddress . . . 85
8.44.2.26 pPriV6DnsAddress . . . 85
8.44.2.27 pRATType . . . 85
8.44.2.28 pSecondaryV4DnsAddress . . . 85
8.44.2.29 pSecV6DnsAddress . . . 85
8.44.2.30 pUserId . . . 85
8.44.2.31 pUserIdSize . . . 85
8.45 LibPackQosClassID Struct Reference . . . 85
8.45.1 Detailed Description . . . 86
8.45.2 Field Documentation . . . 86
8.45.2.1 gDlBitRate . . . 86
8.45.2.2 gUlBitRate . . . 86
8.45.2.3 maxDlBitRate . . . 86
8.45.2.4 maxUlBitRate . . . 86
8.45.2.5 QCI . . . 86
8.46 LibPackTFTIDParams Struct Reference . . . 86
8.46.1 Detailed Description . . . 87
8.46.2 Field Documentation . . . 87
8.46.2.1 destPortRangeEnd . . . 88
8.46.2.2 destPortRangeStart . . . 88
8.46.2.3 eValid . . . 88
8.46.2.4 filterId . . . 88
8.46.2.5 flowLabel . . . 88
8.46.2.6 IPSECSPI . . . 88
8.46.2.7 ipVersion . . . 88
8.46.2.8 nextHeader . . . 88
8.46.2.9 pSourceIP . . . 88

8.46.2.10 sourceIPMask . . . 88
8.46.2.11 srcPortRangeEnd . . . 88
8.46.2.12 srcPortRangeStart . . . 88
8.46.2.13 tosMask . . . 88
8.47 LibPackUMTSQoS Struct Reference . . . 88
8.47.1 Detailed Description . . . 88
8.47.2 Field Documentation . . . 90
8.47.2.1 deliveryErrSDU . . . 90
8.47.2.2 grntDownlinkBitrate . . . 90
8.47.2.3 grntUplinkBitrate . . . 90
8.47.2.4 maxDownlinkBitrate . . . 90
8.47.2.5 maxSDUSize . . . 90
8.47.2.6 maxUplinkBitrate . . . 90
8.47.2.7 qosDeliveryOrder . . . 91
8.47.2.8 resBerRatio . . . 91
8.47.2.9 sduErrorRatio . . . 91
8.47.2.10 trafficClass . . . 91
8.47.2.11 trafficPriority . . . 91
8.47.2.12 transferDelay . . . 91
8.48 LibPackUMTSReqQoSSigInd Struct Reference . . . 91
8.48.1 Detailed Description . . . 91
8.48.2 Field Documentation . . . 91
8.48.2.1 SigInd . . . 91
8.48.2.2 UMTSReqQoS . . . 91
8.49 loc_BdsSV Struct Reference . . . 91
8.49.1 Detailed Description . . . 91
8.49.2 Field Documentation . . . 92
8.49.2.1 id . . . 92
8.49.2.2 mask . . . 92
8.50 loc_BdsSVInfo Struct Reference . . . 92
8.50.1 Detailed Description . . . 92
8.50.2 Field Documentation . . . 92
8.50.2.1 len . . . 92
8.50.2.2 pSV . . . 92
8.51 loc_CellDb Struct Reference . . . 92
8.51.1 Detailed Description . . . 93
8.51.2 Field Documentation . . . 93
8.51.2.1 mask . . . 93
8.52 loc_ClkInfo Struct Reference . . . 93
8.52.1 Detailed Description . . . 93

8.52.2 Field Documentation . . . 94
8.52.2.1 mask . . . 94
8.53 loc_GnssData Struct Reference . . . 94
8.53.1 Detailed Description . . . 95
8.53.2 Field Documentation . . . 95
8.53.2.1 mask . . . 96
8.54 loc_gpsTime Struct Reference . . . 96
8.54.1 Detailed Description . . . 96
8.54.2 Field Documentation . . . 96
8.54.2.1 gpsTimeOfWeekMs . . . 96
8.54.2.2 gpsWeek . . . 96
8.55 loc_IPv4Info Struct Reference . . . 96
8.55.1 Detailed Description . . . 96
8.55.2 Field Documentation . . . 97
8.55.2.1 address . . . 97
8.55.2.2 port . . . 97
8.55.2.3 TlvPresent . . . 97
8.56 loc_IPv6Info Struct Reference . . . 97
8.56.1 Detailed Description . . . 97
8.56.2 Field Documentation . . . 97
8.56.2.1 address . . . 97
8.56.2.2 port . . . 97
8.56.2.3 TlvPresent . . . 97
8.57 loc_LocApplicationInfo Struct Reference . . . 97
8.57.1 Detailed Description . . . 98
8.57.2 Field Documentation . . . 98
8.57.2.1 appNameLength . . . 98
8.57.2.2 appProviderLength . . . 98
8.57.2.3 appVersionLength . . . 98
8.57.2.4 appVersionValid . . . 98
8.57.2.5 pAppName . . . 98
8.57.2.6 pAppProvider . . . 98
8.57.2.7 pAppVersion . . . 98
8.58 loc_precisionDilution Struct Reference . . . 98
8.58.1 Detailed Description . . . 99
8.58.2 Field Documentation . . . 99
8.58.2.1 HDOP . . . 99
8.58.2.2 PDOP . . . 99
8.58.2.3 VDOP . . . 99
8.59 loc_satelliteInfo Struct Reference . . . 99

8.59.1 Detailed Description . . . 99
8.59.2 Field Documentation . . . 101
8.59.2.1 azimuth . . . 101
8.59.2.2 elevation . . . 101
8.59.2.3 gnssSvId . . . 101
8.59.2.4 healthStatus . . . 101
8.59.2.5 snr . . . 101
8.59.2.6 svInfoMask . . . 101
8.59.2.7 svListLen . . . 101
8.59.2.8 svStatus . . . 101
8.59.2.9 system . . . 101
8.59.2.10 validMask . . . 101
8.60 loc_sensorDataUsage Struct Reference . . . 101
8.60.1 Detailed Description . . . 101
8.60.2 Field Documentation . . . 102
8.60.2.1 aidingIndicatorMask . . . 102
8.60.2.2 usageMask . . . 102
8.61 loc_SV Struct Reference . . . 102
8.61.1 Detailed Description . . . 102
8.61.2 Field Documentation . . . 103
8.61.2.1 id . . . 103
8.61.2.2 mask . . . 103
8.61.2.3 system . . . 103
8.62 loc_SVInfo Struct Reference . . . 103
8.62.1 Detailed Description . . . 103
8.62.2 Field Documentation . . . 103
8.62.2.1 len . . . 103
8.62.2.2 pSV . . . 103
8.63 loc_svUsedforFix Struct Reference . . . 103
8.63.1 Detailed Description . . . 104
8.63.2 Field Documentation . . . 104
8.63.2.1 gnssSvUsedList . . . 104
8.63.2.2 gnssSvUsedList_len . . . 104
8.64 loc_urlAddr Struct Reference . . . 104
8.64.1 Detailed Description . . . 104
8.64.2 Field Documentation . . . 104
8.64.2.1 address . . . 104
8.64.2.2 TlvPresent . . . 104
8.65 lteSSInfo Struct Reference . . . 105
8.65.1 Detailed Description . . . 105

8.65.2 Field Documentation . . . 105
8.65.2.1 rsrp . . . 105
8.65.2.2 rsrq . . . 105
8.65.2.3 rssi . . . 105
8.65.2.4 snr . . . 105
8.66 messageModeTlv Struct Reference . . . 105
8.66.1 Detailed Description . . . 106
8.66.2 Field Documentation . . . 106
8.66.2.1 MessageModeInfo . . . 106
8.66.2.2 TlvPresent . . . 106
8.67 nas_acqOrderPref Struct Reference . . . 106
8.67.1 Detailed Description . . . 106
8.67.2 Field Documentation . . . 106
8.67.2.1 acqOrdeLen . . . 106
8.67.2.2 pAcqOrder . . . 106
8.68 nas_ActPilotPNElement Struct Reference . . . 107
8.68.1 Detailed Description . . . 107
8.68.2 Field Documentation . . . 107
8.68.2.1 ActSetPilotPN . . . 107
8.68.2.2 ActSetPilotPNStrength . . . 107
8.69 nas_AddCDMASysInfo Struct Reference . . . 107
8.69.1 Detailed Description . . . 107
8.69.2 Field Documentation . . . 107
8.69.2.1 geoSysIdx . . . 107
8.69.2.2 regPrd . . . 108
8.70 nas_AddSysInfo Struct Reference . . . 108
8.70.1 Detailed Description . . . 108
8.70.2 Field Documentation . . . 108
8.70.2.1 cellBroadcastCap . . . 108
8.70.2.2 geoSysIdx . . . 108
8.71 nas_CallBarringSysInfo Struct Reference . . . 108
8.71.1 Detailed Description . . . 108
8.71.2 Field Documentation . . . 109
8.71.2.1 csBarStatus . . . 109
8.71.2.2 psBarStatus . . . 109
8.72 nas_callBarStatus Struct Reference . . . 109
8.72.1 Detailed Description . . . 109
8.72.2 Field Documentation . . . 110
8.72.2.1 csBarStatus . . . 110
8.72.2.2 psBarStatus . . . 110

8.73 nas_CDMAChannel Struct Reference . . . 110
8.73.1 Detailed Description . . . 110
8.73.2 Field Documentation . . . 110
8.73.2.1 priChA . . . 111
8.73.2.2 priChB . . . 111
8.73.2.3 secChA . . . 111
8.73.2.4 secChB . . . 111
8.74 nas_CDMAECIOThresh Struct Reference . . . 111
8.74.1 Detailed Description . . . 111
8.74.2 Field Documentation . . . 111
8.74.2.1 CDMAECIOThreshListLen . . . 111
8.74.2.2 pCDMAECIOThreshList . . . 111
8.75 nas_CDMAInfo Struct Reference . . . 111
8.75.1 Detailed Description . . . 111
8.75.2 Field Documentation . . . 112
8.75.2.1 baseId . . . 112
8.75.2.2 baseLat . . . 112
8.75.2.3 baseLong . . . 112
8.75.2.4 nid . . . 112
8.75.2.5 refpn . . . 112
8.75.2.6 sid . . . 112
8.76 nas_CDMARSSIThresh Struct Reference . . . 112
8.76.1 Detailed Description . . . 112
8.76.2 Field Documentation . . . 113
8.76.2.1 CDMARSSIThreshListLen . . . 113
8.76.2.2 pCDMARSSIThreshList . . . 113
8.77 nas_CDMASysInfo Struct Reference . . . 113
8.77.1 Detailed Description . . . 113
8.77.2 Field Documentation . . . 116
8.77.2.1 baseId . . . 116
8.77.2.2 baseLat . . . 116
8.77.2.3 baseLong . . . 116
8.77.2.4 bsInfoValid . . . 116
8.77.2.5 bsPRev . . . 116
8.77.2.6 bsPRevValid . . . 116
8.77.2.7 ccsSupported . . . 116
8.77.2.8 ccsSupportedValid . . . 116
8.77.2.9 cdmaSysIdValid . . . 116
8.77.2.10 isSysPrlMatch . . . 116
8.77.2.11 isSysPrlMatchValid . . . 116

8.77.2.12 MCC . . . 116
8.77.2.13 MNC . . . 116
8.77.2.14 networkID . . . 116
8.77.2.15 networkIdValid . . . 116
8.77.2.16 packetZone . . . 116
8.77.2.17 packetZoneValid . . . 116
8.77.2.18 pRevInUse . . . 116
8.77.2.19 pRevInUseValid . . . 116
8.77.2.20 sysInfoCDMA . . . 116
8.77.2.21 systemID . . . 117
8.78 nas_CDMASysInfoExt Struct Reference . . . 117
8.78.1 Detailed Description . . . 117
8.78.2 Field Documentation . . . 117
8.78.2.1 imsi_11_12 . . . 117
8.78.2.2 MCC . . . 117
8.79 nas_cellParams Struct Reference . . . 117
8.79.1 Detailed Description . . . 117
8.79.2 Field Documentation . . . 118
8.79.2.1 pci . . . 118
8.79.2.2 rsrp . . . 118
8.79.2.3 rsrq . . . 118
8.79.2.4 rssi . . . 118
8.79.2.5 srxlev . . . 118
8.80 nas_CommInfo Struct Reference . . . 118
8.80.1 Detailed Description . . . 118
8.80.2 Field Documentation . . . 119
8.80.2.1 imsRegState . . . 119
8.80.2.2 modemMode . . . 120
8.80.2.3 psState . . . 120
8.80.2.4 systemMode . . . 120
8.80.2.5 temperature . . . 120
8.81 nas_CSGID Struct Reference . . . 120
8.81.1 Detailed Description . . . 120
8.81.2 Field Documentation . . . 120
8.81.2.1 id . . . 120
8.81.2.2 mcc . . . 120
8.81.2.3 mnc . . . 121
8.81.2.4 mncPcsDigits . . . 121
8.81.2.5 rat . . . 121
8.82 nas_currentPLMN Struct Reference . . . 121

8.82.1 Detailed Description . . . 121
8.82.2 Field Documentation . . . 121
8.82.2.1 MCC . . . 121
8.82.2.2 MNC . . . 121
8.82.2.3 netDescr . . . 121
8.82.2.4 netDescrLength . . . 121
8.83 nas_dataSrvCapabilities Struct Reference . . . 122
8.83.1 Detailed Description . . . 122
8.83.2 Field Documentation . . . 122
8.83.2.1 dataCapabilities . . . 122
8.83.2.2 dataCapabilitiesLen . . . 122
8.84 nas_DataStatusDetail Struct Reference . . . 122
8.84.1 Detailed Description . . . 123
8.84.2 Field Documentation . . . 124
8.84.2.1 IPAddress . . . 124
8.84.2.2 LastErrCode . . . 124
8.85 nas_detailSvcInfo Struct Reference . . . 125
8.85.1 Detailed Description . . . 125
8.85.2 Field Documentation . . . 126
8.85.2.1 hdrHybrid . . . 126
8.85.2.2 hdrSrvStatus . . . 126
8.85.2.3 isSysForbidden . . . 126
8.85.2.4 srvCapability . . . 126
8.85.2.5 srvStatus . . . 126
8.86 nas_DeviceConfigDetail Struct Reference . . . 126
8.86.1 Detailed Description . . . 126
8.86.2 Field Documentation . . . 127
8.86.2.1 Chipset . . . 127
8.86.2.2 HWVersion . . . 127
8.86.2.3 QLIC . . . 127
8.86.2.4 Technology . . . 127
8.87 nas_dirNum Struct Reference . . . 127
8.87.1 Detailed Description . . . 127
8.87.2 Field Documentation . . . 127
8.87.2.1 dirNum . . . 127
8.87.2.2 dirNumLen . . . 127
8.88 nas_DRCParams Struct Reference . . . 127
8.88.1 Detailed Description . . . 128
8.88.2 Field Documentation . . . 128
8.88.2.1 DRCCover . . . 128

8.88.2.2 DRCValue . . . 128
8.89 nas_ecioListElement Struct Reference . . . 128
8.89.1 Detailed Description . . . 128
8.89.2 Field Documentation . . . 128
8.89.2.1 ecio . . . 129
8.89.2.2 radioIf . . . 129
8.90 nas_ECIOThresh Struct Reference . . . 129
8.90.1 Detailed Description . . . 129
8.90.2 Field Documentation . . . 129
8.90.2.1 ECIOThresListLen . . . 129
8.90.2.2 pECIOThresList . . . 129
8.91 nas_errorRateListElement Struct Reference . . . 129
8.91.1 Detailed Description . . . 129
8.91.2 Field Documentation . . . 130
8.91.2.1 errorRate . . . 130
8.91.2.2 radioIf . . . 130
8.92 nas_GERANInfo Struct Reference . . . 130
8.92.1 Detailed Description . . . 131
8.92.2 Field Documentation . . . 132
8.92.2.1 arfcn . . . 132
8.92.2.2 bsic . . . 132
8.92.2.3 cellID . . . 132
8.92.2.4 insNmrCellInfo . . . 132
8.92.2.5 lac . . . 132
8.92.2.6 nmrInst . . . 132
8.92.2.7 plmn . . . 132
8.92.2.8 rxLev . . . 132
8.92.2.9 timingAdvance . . . 132
8.93 nas_geranInstInfo Struct Reference . . . 132
8.93.1 Detailed Description . . . 132
8.93.2 Field Documentation . . . 132
8.93.2.1 geranArfcn . . . 132
8.93.2.2 geranBsicBcc . . . 133
8.93.2.3 geranBsicNcc . . . 133
8.93.2.4 geranRssi . . . 133
8.94 nas_gsmCellInfo Struct Reference . . . 133
8.94.1 Detailed Description . . . 133
8.94.2 Field Documentation . . . 133
8.94.2.1 arfcn . . . 134
8.94.2.2 band1900 . . . 134

8.94.2.3 bsicId . . . 134
8.94.2.4 cellIdValid . . . 134
8.94.2.5 rssi . . . 134
8.94.2.6 srxlev . . . 134
8.95 nas_GSMRSSIThresh Struct Reference . . . 134
8.95.1 Detailed Description . . . 134
8.95.2 Field Documentation . . . 134
8.95.2.1 GSMRSSIThreshListLen . . . 134
8.95.2.2 pGSMRSSIThreshList . . . 134
8.96 nas_GSMSrvStatusInfo Struct Reference . . . 134
8.96.1 Detailed Description . . . 134
8.96.2 Field Documentation . . . 135
8.96.2.1 isPrefDataPath . . . 135
8.96.2.2 srvStatus . . . 135
8.96.2.3 trueSrvStatus . . . 135
8.97 nas_GSMSysInfo Struct Reference . . . 135
8.97.1 Detailed Description . . . 136
8.97.2 Field Documentation . . . 137
8.97.2.1 cellId . . . 137
8.97.2.2 cellIdValid . . . 137
8.97.2.3 dtmSupp . . . 137
8.97.2.4 dtmSuppValid . . . 138
8.97.2.5 egprsSupp . . . 138
8.97.2.6 egprsSuppValid . . . 138
8.97.2.7 lac . . . 138
8.97.2.8 lacValid . . . 138
8.97.2.9 MCC . . . 138
8.97.2.10 MNC . . . 138
8.97.2.11 networkIdValid . . . 138
8.97.2.12 regRejectInfoValid . . . 138
8.97.2.13 rejCause . . . 138
8.97.2.14 rejectSrvDomain . . . 138
8.97.2.15 sysInfoGSM . . . 138
8.98 nas_HDRECIOThresh Struct Reference . . . 138
8.98.1 Detailed Description . . . 138
8.98.2 Field Documentation . . . 138
8.98.2.1 HDRECIOThreshListLen . . . 138
8.98.2.2 pHDRECIOThreshList . . . 138
8.99 nas_HDRIOThresh Struct Reference . . . 138
8.99.1 Detailed Description . . . 139

8.99.2 Field Documentation . . . 139
8.99.2.1 HDRIOThreshListLen . . . 139
8.99.2.2 pHDRIOThreshList . . . 139
8.100 nas_HDRRSSIThresh Struct Reference . . . 139
8.100.1 Detailed Description . . . 139
8.100.2 Field Documentation . . . 139
8.100.2.1 HDRRSSIThreshListLen . . . 139
8.100.2.2 pHDRRSSIThreshList . . . 140
8.101 nas_HDRSINRThresh Struct Reference . . . 140
8.101.1 Detailed Description . . . 140
8.101.2 Field Documentation . . . 140
8.101.2.1 HDRSINRThresListLen . . . 140
8.101.2.2 pHDRSINRThresList . . . 140
8.102 nas_HDRSINRThreshold Struct Reference . . . 140
8.102.1 Detailed Description . . . 140
8.102.2 Field Documentation . . . 141
8.102.2.1 HDRSINRThreshListLen . . . 141
8.102.2.2 pHDRSINRThreshList . . . 141
8.103 nas_HDRSysInfo Struct Reference . . . 141
8.103.1 Detailed Description . . . 141
8.103.2 Field Documentation . . . 143
8.103.2.1 hdrActiveProt . . . 143
8.103.2.2 hdrActiveProtValid . . . 143
8.103.2.3 hdrPersonality . . . 143
8.103.2.4 hdrPersonalityValid . . . 143
8.103.2.5 is856SysId . . . 143
8.103.2.6 is856SysIdValid . . . 143
8.103.2.7 isSysPrlMatch . . . 143
8.103.2.8 isSysPrlMatchValid . . . 143
8.103.2.9 sysInfoHDR . . . 143
8.104 nas_homeSIDNID Struct Reference . . . 143
8.104.1 Detailed Description . . . 143
8.104.2 Field Documentation . . . 143
8.104.2.1 numInstances . . . 143
8.104.2.2 SidNid . . . 143
8.105 nas_infoInterFreq Struct Reference . . . 143
8.105.1 Detailed Description . . . 144
8.105.2 Field Documentation . . . 144
8.105.2.1 cell_resel_priority . . . 144
8.105.2.2 cellInterFreqParams . . . 144

8.105.2.3 cells_len . . . 144
8.105.2.4 earfcn . . . 144
8.105.2.5 threshXHigh . . . 145
8.105.2.6 threshXLow . . . 145
8.106 nas_IOThresh Struct Reference . . . 145
8.106.1 Detailed Description . . . 145
8.106.2 Field Documentation . . . 145
8.106.2.1 IOThresListLen . . . 145
8.106.2.2 pIOThresList . . . 145
8.107 nas_lteEARFCN Struct Reference . . . 145
8.107.1 Detailed Description . . . 145
8.107.2 Field Documentation . . . 146
8.107.2.1 earfcn0 . . . 146
8.107.2.2 earfcn1 . . . 146
8.107.2.3 status . . . 146
8.108 nas_lteGsmCellInfo Struct Reference . . . 146
8.108.1 Detailed Description . . . 146
8.108.2 Field Documentation . . . 147
8.108.2.1 cellReselPriority . . . 147
8.108.2.2 cells_len . . . 147
8.108.2.3 GsmCellInfo . . . 147
8.108.2.4 nccPermitted . . . 147
8.108.2.5 threshGsmHigh . . . 147
8.108.2.6 threshGsmLow . . . 147
8.109 nas_LTEInfo Struct Reference . . . 147
8.109.1 Detailed Description . . . 147
8.109.2 Field Documentation . . . 149
8.109.2.1 band . . . 149
8.109.2.2 bandwidth . . . 149
8.109.2.3 emmConnState . . . 149
8.109.2.4 emmState . . . 149
8.109.2.5 emmSubState . . . 149
8.109.2.6 RXChan . . . 149
8.109.2.7 TXChan . . . 149
8.110 nas_LTEInfoInterfreq Struct Reference . . . 150
8.110.1 Detailed Description . . . 150
8.110.2 Field Documentation . . . 150
8.110.2.1 freqsLen . . . 150
8.110.2.2 InfoInterfreq . . . 150
8.110.2.3 ueInIdle . . . 150

8.111 nas_LTEInfoIntrafreq Struct Reference . . . 150
8.111.1 Detailed Description . . . 151
8.111.2 Field Documentation . . . 152
8.111.2.1 CellParams . . . 152
8.111.2.2 cellReselPriority . . . 152
8.111.2.3 cellsLen . . . 152
8.111.2.4 earfcn . . . 152
8.111.2.5 globalCellId . . . 152
8.111.2.6 plmn . . . 152
8.111.2.7 servingCellId . . . 152
8.111.2.8 sIntraSearch . . . 152
8.111.2.9 sNonIntraSearch . . . 152
8.111.2.10 tac . . . 152
8.111.2.11 threshServingLow . . . 152
8.111.2.12 ueInIdle . . . 152
8.112 nas_LTEInfoNeighboringGSM Struct Reference . . . 152
8.112.1 Detailed Description . . . 153
8.112.2 Field Documentation . . . 153
8.112.2.1 freqsLen . . . 153
8.112.2.2 LteGsmCellInfo . . . 153
8.112.2.3 ueInIdle . . . 153
8.113 nas_LTEInfoNeighboringWCDMA Struct Reference . . . 153
8.113.1 Detailed Description . . . 153
8.113.2 Field Documentation . . . 154
8.113.2.1 freqsLen . . . 154
8.113.2.2 LTEWCDMACellInfo . . . 154
8.113.2.3 ueInIdle . . . 154
8.114 nas_ltePCI Struct Reference . . . 154
8.114.1 Detailed Description . . . 154
8.114.2 Field Documentation . . . 154
8.114.2.1 earfcn . . . 154
8.114.2.2 pci . . . 154
8.114.2.3 status . . . 154
8.115 nas_lteRsrpinformation Struct Reference . . . 154
8.115.1 Detailed Description . . . 154
8.115.2 Field Documentation . . . 155
8.115.2.1 rsrplevel . . . 155
8.116 nas_LTERSRPThresh Struct Reference . . . 155
8.116.1 Detailed Description . . . 155
8.116.2 Field Documentation . . . 155

8.116.2.1 LTERSRPThreshListLen . . . 155
8.116.2.2 pLTERSRPThreshList . . . 155
8.117 nas_LTERSRQThresh Struct Reference . . . 155
8.117.1 Detailed Description . . . 155
8.117.2 Field Documentation . . . 156
8.117.2.1 LTERSRQThreshListLen . . . 156
8.117.2.2 pLTERSRQThreshList . . . 156
8.118 nas_LTERSSIThresh Struct Reference . . . 156
8.118.1 Detailed Description . . . 156
8.118.2 Field Documentation . . . 156
8.118.2.1 LTERSSIThreshListLen . . . 156
8.118.2.2 pLTERSSIThreshList . . . 156
8.119 nas_LTESigRptCfg Struct Reference . . . 156
8.119.1 Detailed Description . . . 157
8.119.2 Field Documentation . . . 157
8.119.2.1 avgPeriod . . . 157
8.119.2.2 rptRate . . . 157
8.120 nas_LTESigRptConfig Struct Reference . . . 157
8.120.1 Detailed Description . . . 157
8.120.2 Field Documentation . . . 158
8.120.2.1 avgPeriod . . . 158
8.120.2.2 rptRate . . . 158
8.121 nas_lteSnrinformation Struct Reference . . . 158
8.121.1 Detailed Description . . . 158
8.121.2 Field Documentation . . . 158
8.121.2.1 snrlevel . . . 159
8.122 nas_LTESNRThresh Struct Reference . . . 159
8.122.1 Detailed Description . . . 159
8.122.2 Field Documentation . . . 159
8.122.2.1 LTESNRThresListLen . . . 159
8.122.2.2 pLTESNRThresList . . . 159
8.123 nas_LTESNRThreshold Struct Reference . . . 159
8.123.1 Detailed Description . . . 159
8.123.2 Field Documentation . . . 160
8.123.2.1 LTESNRThreshListLen . . . 160
8.123.2.2 pLTESNRThreshList . . . 160
8.124 nas_LTESysInfo Struct Reference . . . 160
8.124.1 Detailed Description . . . 160
8.124.2 Field Documentation . . . 162
8.124.2.1 cellId . . . 162

8.124.2.2 cellIdValid . . . 162
8.124.2.3 lac . . . 162
8.124.2.4 lacValid . . . 162
8.124.2.5 MCC . . . 162
8.124.2.6 MNC . . . 162
8.124.2.7 networkIdValid . . . 162
8.124.2.8 regRejectInfoValid . . . 162
8.124.2.9 rejCause . . . 162
8.124.2.10 rejectSrvDomain . . . 162
8.124.2.11 sysInfoLTE . . . 162
8.124.2.12 tac . . . 162
8.124.2.13 tacValid . . . 162
8.125 nas_lteWcdmaCellInfo Struct Reference . . . 162
8.125.1 Detailed Description . . . 163
8.125.2 Field Documentation . . . 163
8.125.2.1 cellReselPriority . . . 163
8.125.2.2 cellsLen . . . 163
8.125.2.3 threshXhigh . . . 163
8.125.2.4 threshXlow . . . 163
8.125.2.5 uarfcn . . . 163
8.125.2.6 WCDMACellInfo . . . 163
8.126 nas_minBasedIMSI Struct Reference . . . 163
8.126.1 Detailed Description . . . 164
8.126.2 Field Documentation . . . 164
8.126.2.1 imsiM1112 . . . 164
8.126.2.2 imsiMS1 . . . 164
8.126.2.3 imsiMS2 . . . 164
8.126.2.4 mccM . . . 164
8.127 nas_MNRInfo Struct Reference . . . 164
8.127.1 Detailed Description . . . 164
8.127.2 Field Documentation . . . 165
8.127.2.1 mcc . . . 165
8.127.2.2 mnc . . . 165
8.127.2.3 rat . . . 165
8.128 nas_namName Struct Reference . . . 165
8.128.1 Detailed Description . . . 165
8.128.2 Field Documentation . . . 165
8.128.2.1 namName . . . 165
8.128.2.2 namNameLen . . . 165
8.129 nas_netSelectionPref Struct Reference . . . 165

8.129.1 Detailed Description . . . 166
8.129.2 Field Documentation . . . 166
8.129.2.1 mcc . . . 166
8.129.2.2 mnc . . . 166
8.129.2.3 netReg . . . 166
8.130 nas_NetworkStat1x Struct Reference . . . 166
8.130.1 Detailed Description . . . 166
8.130.2 Field Documentation . . . 168
8.130.2.1 ActSetCnt . . . 168
8.130.2.2 NeighborSetCnt . . . 168
8.130.2.3 pActPilotPNElements . . . 168
8.130.2.4 pNeighborSetPilotPN . . . 168
8.130.2.5 RX_EC_IO . . . 168
8.130.2.6 RX_PWR . . . 168
8.130.2.7 SO . . . 168
8.130.2.8 State . . . 168
8.130.2.9 TX_PWR . . . 168
8.131 nas_NetworkStatEVDO Struct Reference . . . 168
8.131.1 Detailed Description . . . 168
8.131.2 Field Documentation . . . 169
8.131.2.1 MACIndex . . . 170
8.131.2.2 PER . . . 170
8.131.2.3 PilotEnergy . . . 170
8.131.2.4 pSectorID . . . 170
8.131.2.5 RX_PWR . . . 170
8.131.2.6 SectorIDLen . . . 170
8.131.2.7 SNR . . . 170
8.131.2.8 State . . . 170
8.132 nas_nmrCellInfo Struct Reference . . . 170
8.132.1 Detailed Description . . . 170
8.132.2 Field Documentation . . . 171
8.132.2.1 nmrArfcn . . . 171
8.132.2.2 nmrBsic . . . 171
8.132.2.3 nmrCellID . . . 171
8.132.2.4 nmrLac . . . 171
8.132.2.5 nmrPlmn . . . 171
8.132.2.6 nmrRxLev . . . 171
8.133 nas_operatorNameString Struct Reference . . . 171
8.133.1 Detailed Description . . . 171
8.133.2 Field Documentation . . . 171

8.133.2.1 PLMNName . . . 171
8.134 nas_OperatorPLMNData Struct Reference . . . 171
8.134.1 Detailed Description . . . 172
8.134.2 Field Documentation . . . 172
8.134.2.1 lac1 . . . 172
8.134.2.2 lac2 . . . 172
8.134.2.3 mcc . . . 172
8.134.2.4 mnc . . . 172
8.134.2.5 PLMNRecID . . . 172
8.135 nas_operatorPLMNList Struct Reference . . . 172
8.135.1 Detailed Description . . . 173
8.135.2 Field Documentation . . . 173
8.135.2.1 numInstance . . . 173
8.135.2.2 PLMNData . . . 173
8.136 nas_PhyCaAggPcellInfo Struct Reference . . . 173
8.136.1 Detailed Description . . . 173
8.136.2 Field Documentation . . . 174
8.136.2.1 dl_bw_value . . . 174
8.136.2.2 freq . . . 174
8.136.2.3 iLTEbandValue . . . 174
8.136.2.4 pci . . . 174
8.136.2.5 TlvPresent . . . 174
8.137 nas_PhyCaAggScellDlBw Struct Reference . . . 174
8.137.1 Detailed Description . . . 174
8.137.2 Field Documentation . . . 174
8.137.2.1 dl_bw_value . . . 174
8.137.2.2 TlvPresent . . . 174
8.138 nas_PhyCaAggScellIndex Struct Reference . . . 174
8.138.1 Detailed Description . . . 174
8.138.2 Field Documentation . . . 175
8.138.2.1 scell_idx . . . 175
8.138.2.2 TlvPresent . . . 175
8.139 nas_PhyCaAggScellIndType Struct Reference . . . 175
8.139.1 Detailed Description . . . 175
8.139.2 Field Documentation . . . 175
8.139.2.1 freq . . . 175
8.139.2.2 pci . . . 175
8.139.2.3 scell_state . . . 175
8.139.2.4 TlvPresent . . . 175
8.140 nas_PhyCaAggScellInfo Struct Reference . . . 176

8.140.1 Detailed Description . . . 176
8.140.2 Field Documentation . . . 178
8.140.2.1 dl_bw_value . . . 178
8.140.2.2 freq . . . 178
8.140.2.3 iLTEbandValue . . . 178
8.140.2.4 pci . . . 178
8.140.2.5 scell_state . . . 178
8.140.2.6 TlvPresent . . . 178
8.141 nas_PilotSetData Struct Reference . . . 178
8.141.1 Detailed Description . . . 178
8.141.2 Field Documentation . . . 178
8.141.2.1 NumPilots . . . 178
8.141.2.2 pPilotSetInfo . . . 178
8.142 nas_PilotSetParams Struct Reference . . . 179
8.142.1 Detailed Description . . . 179
8.142.2 Field Documentation . . . 179
8.142.2.1 PilotPN . . . 179
8.142.2.2 PilotStrength . . . 179
8.142.2.3 PilotType . . . 179
8.143 nas_PLMNNetworkName Struct Reference . . . 179
8.143.1 Detailed Description . . . 179
8.143.2 Field Documentation . . . 180
8.143.2.1 numInstance . . . 180
8.143.2.2 PLMNNetName . . . 180
8.144 nas_PLMNNetworkNameData Struct Reference . . . 180
8.144.1 Detailed Description . . . 180
8.144.2 Field Documentation . . . 181
8.144.2.1 codingScheme . . . 181
8.144.2.2 countryInitials . . . 181
8.144.2.3 longName . . . 181
8.144.2.4 longNameLen . . . 181
8.144.2.5 longNameSpareBits . . . 181
8.144.2.6 shortName . . . 181
8.144.2.7 shortNameLen . . . 181
8.144.2.8 shortNameSpareBits . . . 181
8.145 nas_protocolSubtypeElement Struct Reference . . . 181
8.145.1 Detailed Description . . . 182
8.145.2 Field Documentation . . . 182
8.145.2.1 AccessMac . . . 183
8.145.2.2 AuthProt . . . 183

8.145.2.3 ControlMac . . . 183
8.145.2.4 EncryptProt . . . 183
8.145.2.5 ForwardMac . . . 183
8.145.2.6 IdleState . . . 183
8.145.2.7 KeyExchange . . . 183
8.145.2.8 MultDisc . . . 183
8.145.2.9 PhysicalLayer . . . 183
8.145.2.10 ReverseMac . . . 183
8.145.2.11 SecProt . . . 183
8.145.2.12 VirtStream . . . 183
8.146 nas_qaQmi3Gpp2TimeZone Struct Reference . . . 183
8.146.1 Detailed Description . . . 183
8.146.2 Field Documentation . . . 183
8.146.2.1 daylightSavings . . . 184
8.146.2.2 leapSeconds . . . 184
8.146.2.3 localTimeOffset . . . 184
8.147 nas_QmiNas3GppNetworkInfo Struct Reference . . . 184
8.147.1 Detailed Description . . . 184
8.147.2 Field Documentation . . . 185
8.147.2.1 Desription . . . 185
8.147.2.2 Forbidden . . . 185
8.147.2.3 InUse . . . 185
8.147.2.4 MCC . . . 185
8.147.2.5 MNC . . . 185
8.147.2.6 Preferred . . . 185
8.147.2.7 Roaming . . . 185
8.148 nas_QmiNas3GppNetworkRAT Struct Reference . . . 185
8.148.1 Detailed Description . . . 185
8.148.2 Field Documentation . . . 185
8.148.2.1 MCC . . . 186
8.148.2.2 MNC . . . 186
8.148.2.3 RAT . . . 186
8.149 nas_QmisNasPcsDigit Struct Reference . . . 186
8.149.1 Detailed Description . . . 186
8.149.2 Field Documentation . . . 186
8.149.2.1 includes_pcs_digit . . . 186
8.149.2.2 MCC . . . 186
8.149.2.3 MNC . . . 186
8.150 nas_RejectReasonTlv Struct Reference . . . 186
8.150.1 Detailed Description . . . 186

8.150.2 Field Documentation . . . 187
8.150.2.1 rejectCause . . . 187
8.150.2.2 serviceDomain . . . 187
8.150.2.3 TlvPresent . . . 187
8.151 nas_RFInfoTlv Struct Reference . . . 187
8.151.1 Detailed Description . . . 187
8.151.2 Field Documentation . . . 188
8.151.2.1 activeBandClass . . . 188
8.151.2.2 activeChannel . . . 188
8.151.2.3 radioInterface . . . 188
8.151.2.4 radioInterfaceSize . . . 188
8.151.2.5 TlvPresent . . . 188
8.152 nas_roamIndList Struct Reference . . . 188
8.152.1 Detailed Description . . . 188
8.152.2 Field Documentation . . . 189
8.152.2.1 numInstances . . . 189
8.152.2.2 radioInterface . . . 189
8.152.2.3 roamIndicator . . . 189
8.153 nas_RSRPThresh Struct Reference . . . 189
8.153.1 Detailed Description . . . 189
8.153.2 Field Documentation . . . 189
8.153.2.1 pRSRPThresList . . . 189
8.153.2.2 RSRPThresListLen . . . 189
8.154 nas_rsrqInformation Struct Reference . . . 189
8.154.1 Detailed Description . . . 189
8.154.2 Field Documentation . . . 190
8.154.2.1 radioIf . . . 190
8.154.2.2 rsrq . . . 190
8.155 nas_RSRQThresh Struct Reference . . . 190
8.155.1 Detailed Description . . . 190
8.155.2 Field Documentation . . . 190
8.155.2.1 pRSRQThresList . . . 190
8.155.2.2 RSRQThresListLen . . . 190
8.156 nas_RSSIThresh Struct Reference . . . 190
8.156.1 Detailed Description . . . 191
8.156.2 Field Documentation . . . 191
8.156.2.1 pRSSIThresList . . . 191
8.156.2.2 RSSIThresListLen . . . 191
8.157 nas_rxInfo Struct Reference . . . 191
8.157.1 Detailed Description . . . 191

8.157.2 Field Documentation . . . 192
8.157.2.1 ecio . . . 192
8.157.2.2 isRadioTuned . . . 192
8.157.2.3 phase . . . 192
8.157.2.4 rscp . . . 192
8.157.2.5 rsrp . . . 192
8.157.2.6 rxPower . . . 192
8.158 nas_RxSigInfo Struct Reference . . . 192
8.158.1 Detailed Description . . . 192
8.158.2 Field Documentation . . . 193
8.158.2.1 isRadioTuned . . . 193
8.158.2.2 rsrp . . . 193
8.158.2.3 rxChainIndex . . . 193
8.158.2.4 rxPower . . . 193
8.159 nas_rxSignalStrengthListElement Struct Reference . . . 193
8.159.1 Detailed Description . . . 193
8.159.2 Field Documentation . . . 194
8.159.2.1 radioIf . . . 194
8.159.2.2 rxSignalStrength . . . 194
8.160 nas_SccRxInfo Struct Reference . . . 194
8.160.1 Detailed Description . . . 194
8.160.2 Field Documentation . . . 195
8.160.2.1 numInstances . . . 195
8.160.2.2 rsrq . . . 195
8.160.2.3 sigInfo . . . 195
8.160.2.4 snr . . . 195
8.160.2.5 TlvPresent . . . 195
8.161 nas_serviceProviderName Struct Reference . . . 195
8.161.1 Detailed Description . . . 195
8.161.2 Field Documentation . . . 196
8.161.2.1 displayCondition . . . 196
8.161.2.2 spn . . . 196
8.161.2.3 spnLength . . . 196
8.162 nas_servSystem Struct Reference . . . 196
8.162.1 Detailed Description . . . 196
8.162.2 Field Documentation . . . 197
8.162.2.1 csAttachState . . . 197
8.162.2.2 numRadioInterfaces . . . 197
8.162.2.3 psAttachState . . . 197
8.162.2.4 radioInterface . . . 197

8.162.2.5 regState . . . 197
8.162.2.6 selNetwork . . . 197
8.163 nas_sidNid Struct Reference . . . 197
8.163.1 Detailed Description . . . 197
8.163.2 Field Documentation . . . 198
8.163.2.1 nid . . . 198
8.163.2.2 sid . . . 198
8.164 nas_SignalStrengthTlv Struct Reference . . . 198
8.164.1 Detailed Description . . . 198
8.164.2 Field Documentation . . . 198
8.164.2.1 radioInterface . . . 198
8.164.2.2 signalStrength . . . 198
8.164.2.3 TlvPresent . . . 198
8.165 nas_SLQSSignalStrengthsIndReq Struct Reference . . . 198
8.165.1 Detailed Description . . . 199
8.165.2 Field Documentation . . . 200
8.165.2.1 ecioDelta . . . 200
8.165.2.2 ecioThresholdList . . . 200
8.165.2.3 ecioThresholdListLen . . . 200
8.165.2.4 ioDelta . . . 200
8.165.2.5 lteRsrpDelta . . . 200
8.165.2.6 lteSnrDelta . . . 200
8.165.2.7 rsrqDelta . . . 200
8.165.2.8 rxSignalStrengthDelta . . . 200
8.165.2.9 sinrDelta . . . 200
8.165.2.10 sinrThresholdList . . . 200
8.165.2.11 sinrThresholdListLen . . . 200
8.166 nas_SLQSSignalStrengthsInformation Struct Reference . . . 200
8.166.1 Detailed Description . . . 200
8.166.2 Field Documentation . . . 201
8.166.2.1 ecioInfo . . . 201
8.166.2.2 errorRateInfo . . . 201
8.166.2.3 io . . . 201
8.166.2.4 lteRsrpinfo . . . 201
8.166.2.5 lteSnrinfo . . . 201
8.166.2.6 rsrqInfo . . . 201
8.166.2.7 rxSignalStrengthInfo . . . 201
8.166.2.8 sinr . . . 201
8.167 nas_SLQSSignalStrengthsTlv Struct Reference . . . 201
8.167.1 Detailed Description . . . 201

8.167.2 Field Documentation . . . 201
8.167.2.1 sSLQSSignalStrengthsInfo . . . 201
8.167.2.2 TlvPresent . . . 201
8.168 nas_SrvStatusInfo Struct Reference . . . 202
8.168.1 Detailed Description . . . 202
8.168.2 Field Documentation . . . 202
8.168.2.1 isPrefDataPath . . . 202
8.168.2.2 srvStatus . . . 202
8.169 nas_sysInfoCommon Struct Reference . . . 202
8.169.1 Detailed Description . . . 202
8.169.2 Field Documentation . . . 204
8.169.2.1 isSysForbidden . . . 204
8.169.2.2 isSysForbiddenValid . . . 204
8.169.2.3 roamStatus . . . 204
8.169.2.4 roamStatusValid . . . 204
8.169.2.5 srvCapability . . . 204
8.169.2.6 srvCapabilityValid . . . 204
8.169.2.7 srvDomain . . . 204
8.169.2.8 srvDomainValid . . . 204
8.170 nas_TDSCDMAECIOThresh Struct Reference . . . 205
8.170.1 Detailed Description . . . 205
8.170.2 Field Documentation . . . 205
8.170.2.1 pTDSCDMAECIOThreshList . . . 205
8.170.2.2 TDSCDMAECIOThreshListLen . . . 205
8.171 nas_TDSCDMARSCPThresh Struct Reference . . . 205
8.171.1 Detailed Description . . . 205
8.171.2 Field Documentation . . . 205
8.171.2.1 pTDSCDMARSCPThreshList . . . 205
8.171.2.2 TDSCDMARSCPThreshListLen . . . 206
8.172 nas_TDSCDMARSSIThresh Struct Reference . . . 206
8.172.1 Detailed Description . . . 206
8.172.2 Field Documentation . . . 206
8.172.2.1 pTDSCDMARSSIThreshList . . . 206
8.172.2.2 TDSCDMARSSIThreshListLen . . . 206
8.173 nas_TDSCDMASINRCONFThresh Struct Reference . . . 206
8.173.1 Detailed Description . . . 206
8.173.2 Field Documentation . . . 206
8.173.2.1 pTDSCDMASINRCONFThreshList . . . 207
8.173.2.2 TDSCDMASINRCONFThreshListLen . . . 207
8.174 nas_TDSCDMASINRThresh Struct Reference . . . 207

8.174.1 Detailed Description . . . 207
8.174.2 Field Documentation . . . 207
8.174.2.1 pTDSCDMASINRThreshList . . . 207
8.174.2.2 TDSCDMASINRThreshListLen . . . 207
8.175nas_timeInfo Struct Reference . . . 207
8.175.1 Detailed Description . . . 207
8.175.2 Field Documentation . . . 209
8.175.2.1 day . . . 209
8.175.2.2 dayLtSavingAdj . . . 209
8.175.2.3 dayOfWeek . . . 209
8.175.2.4 hour . . . 209
8.175.2.5 minute . . . 209
8.175.2.6 month . . . 209
8.175.2.7 radioInterface . . . 209
8.175.2.8 second . . . 209
8.175.2.9 timeZone . . . 209
8.175.2.10TlvPresent . . . 209
8.175.2.11year . . . 209
8.176nas_trueIMSI Struct Reference . . . 209
8.176.1 Detailed Description . . . 209
8.176.2 Field Documentation . . . 210
8.176.2.1 imsiT1112 . . . 210
8.176.2.2 imsiTaddrNum . . . 210
8.176.2.3 imsiTS1 . . . 210
8.176.2.4 imsiTS2 . . . 210
8.176.2.5 mccT . . . 210
8.177nas_txInfo Struct Reference . . . 210
8.177.1 Detailed Description . . . 210
8.177.2 Field Documentation . . . 210
8.177.2.1 isInTraffic . . . 210
8.177.2.2 txPower . . . 210
8.178nas_UMTSInfo Struct Reference . . . 210
8.178.1 Detailed Description . . . 211
8.178.2 Field Documentation . . . 212
8.178.2.1 cellID . . . 212
8.178.2.2 ecio . . . 212
8.178.2.3 geranInst . . . 212
8.178.2.4 GeranInstInfo . . . 212
8.178.2.5 lac . . . 212
8.178.2.6 plmn . . . 212

8.178.2.7 psc . . . 212
8.178.2.8 rscp . . . 212
8.178.2.9 uarfcn . . . 212
8.178.2.10umtsInst . . . 212
8.178.2.11UMTSInstInfo . . . 212
8.179nas_UMTSinstInfo Struct Reference . . . 212
8.179.1 Detailed Description . . . 212
8.179.2 Field Documentation . . . 213
8.179.2.1 umtsEcio . . . 213
8.179.2.2 umtsPsc . . . 213
8.179.2.3 umtsRscp . . . 213
8.179.2.4 umtsUarfcn . . . 213
8.180nas_umtsLTENbrCell Struct Reference . . . 213
8.180.1 Detailed Description . . . 213
8.180.2 Field Documentation . . . 214
8.180.2.1 cellIsTDD . . . 214
8.180.2.2 earfcn . . . 214
8.180.2.3 pci . . . 214
8.180.2.4 rsrp . . . 214
8.180.2.5 rsrq . . . 214
8.180.2.6 srxlev . . . 214
8.181nas_UniversalTime Struct Reference . . . 214
8.181.1 Detailed Description . . . 214
8.181.2 Field Documentation . . . 215
8.181.2.1 day . . . 215
8.181.2.2 dayOfWeek . . . 215
8.181.2.3 hour . . . 215
8.181.2.4 minute . . . 215
8.181.2.5 month . . . 215
8.181.2.6 second . . . 215
8.181.2.7 year . . . 215
8.182nas_wcdmaCellInfo Struct Reference . . . 215
8.182.1 Detailed Description . . . 215
8.182.2 Field Documentation . . . 216
8.182.2.1 cpich_ecno . . . 216
8.182.2.2 cpich_rscp . . . 216
8.182.2.3 psc . . . 216
8.182.2.4 srxlev . . . 216
8.183nas_WCDMAECIOThresh Struct Reference . . . 216
8.183.1 Detailed Description . . . 216

8.183.2 Field Documentation . . . 216
8.183.2.1 pWCDMAECIOThreshList . . . 216
8.183.2.2 WCDMAECIOThreshListLen . . . 216
8.184 nas_WCDMAInfoLTENeighborCell Struct Reference . . . 216
8.184.1 Detailed Description . . . 217
8.184.2 Field Documentation . . . 217
8.184.2.1 UMTSLTENbrCell . . . 217
8.184.2.2 umtsLTENbrCellLen . . . 217
8.184.2.3 wcdmaRRCState . . . 217
8.185 nas_WCDMARSSIThresh Struct Reference . . . 217
8.185.1 Detailed Description . . . 217
8.185.2 Field Documentation . . . 218
8.185.2.1 pWCDMARSSIThreshList . . . 218
8.185.2.2 WCDMARSSIThreshListLen . . . 218
8.186 nas_WCDMASysInfo Struct Reference . . . 218
8.186.1 Detailed Description . . . 218
8.186.2 Field Documentation . . . 220
8.186.2.1 cellId . . . 221
8.186.2.2 cellIdValid . . . 221
8.186.2.3 hsCallStatus . . . 221
8.186.2.4 hsCallStatusValid . . . 221
8.186.2.5 hsInd . . . 221
8.186.2.6 hsIndValid . . . 221
8.186.2.7 lac . . . 221
8.186.2.8 lacValid . . . 221
8.186.2.9 MCC . . . 221
8.186.2.10 MNC . . . 221
8.186.2.11 networkIdValid . . . 221
8.186.2.12 psc . . . 221
8.186.2.13 pscValid . . . 221
8.186.2.14 regRejectInfoValid . . . 221
8.186.2.15 rejCause . . . 221
8.186.2.16 rejectSrvDomain . . . 221
8.186.2.17 sysInfoWCDMA . . . 221
8.187 nas_wcdmaUARFCN Struct Reference . . . 221
8.187.1 Detailed Description . . . 221
8.187.2 Field Documentation . . . 222
8.187.2.1 status . . . 222
8.187.2.2 uarfcn . . . 222
8.188 NASBandPreferenceTlv Struct Reference . . . 222

8.188.1 Detailed Description . . . 222
8.188.2 Field Documentation . . . 222
8.188.2.1 band_pref . . . 222
8.188.2.2 TlvPresent . . . 222
8.189 NASEmergencyModeTlv Struct Reference . . . 222
8.189.1 Detailed Description . . . 222
8.189.2 Field Documentation . . . 222
8.189.2.1 EmerMode . . . 222
8.189.2.2 TlvPresent . . . 222
8.190 NasGetLTECphyCaInfo Struct Reference . . . 222
8.190.1 Detailed Description . . . 223
8.190.2 Field Documentation . . . 223
8.190.2.1 PhyCaAggPcellInfo . . . 223
8.190.2.2 PhyCaAggScellDlBw . . . 223
8.190.2.3 PhyCaAggScellIndex . . . 223
8.190.2.4 PhyCaAggScellIndType . . . 223
8.190.2.5 PhyCaAggScellInfo . . . 223
8.191 NASGWAcqOrderPrefTlv Struct Reference . . . 223
8.191.1 Detailed Description . . . 224
8.191.2 Field Documentation . . . 224
8.191.2.1 GWAcqOrderPref . . . 224
8.191.2.2 TlvPresent . . . 224
8.192 NASLTEBandPreferenceTlv Struct Reference . . . 224
8.192.1 Detailed Description . . . 224
8.192.2 Field Documentation . . . 224
8.192.2.1 LTEBandPref . . . 224
8.192.2.2 TlvPresent . . . 224
8.193 NASLteNasReleaseInfoTlv Struct Reference . . . 224
8.193.1 Detailed Description . . . 224
8.193.2 Field Documentation . . . 225
8.193.2.1 nas_major . . . 225
8.193.2.2 nas_minor . . . 225
8.193.2.3 nas_release . . . 225
8.193.2.4 TlvPresent . . . 225
8.194 NASModePreferenceTlv Struct Reference . . . 225
8.194.1 Detailed Description . . . 225
8.194.2 Field Documentation . . . 225
8.194.2.1 ModePref . . . 225
8.194.2.2 TlvPresent . . . 225
8.195 NASNetSelPreferenceTlv Struct Reference . . . 225

8.195.1 Detailed Description . . . 226
8.195.2 Field Documentation . . . 226
8.195.2.1 NetSelPref . . . 226
8.195.2.2 TlvPresent . . . 226
8.196 NASOTAMessageTlv Struct Reference . . . 226
8.196.1 Detailed Description . . . 226
8.196.2 Field Documentation . . . 226
8.196.2.1 data_buf . . . 226
8.196.2.2 data_len . . . 227
8.196.2.3 message_type . . . 227
8.196.2.4 TlvPresent . . . 227
8.197 NASPhyCaAggPcellInfo Struct Reference . . . 227
8.197.1 Detailed Description . . . 227
8.197.2 Field Documentation . . . 227
8.197.2.1 dl_bw_value . . . 227
8.197.2.2 freq . . . 227
8.197.2.3 iLTEbandValue . . . 227
8.197.2.4 pci . . . 227
8.197.2.5 TlvPresent . . . 227
8.198 NASPhyCaAggScellDlBw Struct Reference . . . 228
8.198.1 Detailed Description . . . 228
8.198.2 Field Documentation . . . 228
8.198.2.1 dl_bw_value . . . 228
8.198.2.2 TlvPresent . . . 228
8.199 NASPhyCaAggScellIndex Struct Reference . . . 228
8.199.1 Detailed Description . . . 228
8.199.2 Field Documentation . . . 228
8.199.2.1 scell_idx . . . 228
8.199.2.2 TlvPresent . . . 228
8.200 NASPhyCaAggScellIndType Struct Reference . . . 229
8.200.1 Detailed Description . . . 229
8.200.2 Field Documentation . . . 229
8.200.2.1 freq . . . 229
8.200.2.2 pci . . . 229
8.200.2.3 scell_state . . . 229
8.200.2.4 TlvPresent . . . 229
8.201 NASPhyCaAggScellInfo Struct Reference . . . 229
8.201.1 Detailed Description . . . 230
8.201.2 Field Documentation . . . 230
8.201.2.1 dl_bw_value . . . 230

8.201.2.2 freq . . . 230
8.201.2.3 iLTEbandValue . . . 230
8.201.2.4 pci . . . 230
8.201.2.5 scell_state . . . 230
8.201.2.6 TlvPresent . . . 230
8.202 NASPRLPreferenceTlv Struct Reference . . . 230
8.202.1 Detailed Description . . . 230
8.202.2 Field Documentation . . . 231
8.202.2.1 PRLPref . . . 231
8.202.2.2 TlvPresent . . . 231
8.203 NASQmiCbkNasSwiOTAMessageInd Struct Reference . . . 231
8.203.1 Detailed Description . . . 231
8.203.2 Field Documentation . . . 231
8.203.2.1 nasRelInfoTlv . . . 231
8.203.2.2 otaMsgTlv . . . 231
8.203.2.3 timeTlv . . . 231
8.204 NASQmiCbkNasSystemSelPrefInd Struct Reference . . . 231
8.204.1 Detailed Description . . . 232
8.204.2 Field Documentation . . . 232
8.204.2.1 BPTlv . . . 232
8.204.2.2 EMTlv . . . 232
8.204.2.3 GWAOPTlv . . . 232
8.204.2.4 LBPTlv . . . 232
8.204.2.5 MPTlv . . . 232
8.204.2.6 NSPTlv . . . 232
8.204.2.7 PRLPTlv . . . 233
8.204.2.8 RPTlv . . . 233
8.204.2.9 SDPTlv . . . 233
8.205 NASRoamPreferenceTlv Struct Reference . . . 233
8.205.1 Detailed Description . . . 233
8.205.2 Field Documentation . . . 233
8.205.2.1 RoamPref . . . 233
8.205.2.2 TlvPresent . . . 233
8.206 NASServDomainPrefTlv Struct Reference . . . 233
8.206.1 Detailed Description . . . 233
8.206.2 Field Documentation . . . 233
8.206.2.1 SrvDomainPref . . . 233
8.206.2.2 TlvPresent . . . 233
8.207 NASServingSystemInfo Struct Reference . . . 233
8.207.1 Detailed Description . . . 234

8.207.2 Field Documentation . . . 235
8.207.2.1 csAttachState . . . 235
8.207.2.2 hdrPersonality . . . 235
8.207.2.3 psAttachState . . . 235
8.207.2.4 radioInterfaceList . . . 235
8.207.2.5 radioInterfaceNo . . . 235
8.207.2.6 registrationState . . . 235
8.207.2.7 selectedNetwork . . . 235
8.208 NASTimeInfoTlv Struct Reference . . . 235
8.208.1 Detailed Description . . . 235
8.208.2 Field Documentation . . . 235
8.208.2.1 time . . . 235
8.208.2.2 TlvPresent . . . 235
8.209 newMTMessageTlv Struct Reference . . . 236
8.209.1 Detailed Description . . . 236
8.209.2 Field Documentation . . . 236
8.209.2.1 MTMessageInfo . . . 236
8.209.2.2 TlvPresent . . . 236
8.210 pack_audio_SLQSGetAudioPathConfig_t Struct Reference . . . 236
8.210.1 Detailed Description . . . 236
8.210.2 Field Documentation . . . 237
8.210.2.1 Item . . . 237
8.210.2.2 Profile . . . 237
8.211 pack_audio_SLQSGetAudioProfile_t Struct Reference . . . 237
8.211.1 Detailed Description . . . 237
8.211.2 Field Documentation . . . 237
8.211.2.1 Generator . . . 237
8.212 pack_audio_SLQSGetAudioVolTLBConfig_t Struct Reference . . . 238
8.212.1 Detailed Description . . . 238
8.212.2 Field Documentation . . . 238
8.212.2.1 Generator . . . 238
8.212.2.2 Item . . . 238
8.212.2.3 Profile . . . 238
8.212.2.4 Volume . . . 238
8.213 pack_audio_SLQSSetAudioPathConfig_t Struct Reference . . . 238
8.213.1 Detailed Description . . . 239
8.213.2 Field Documentation . . . 240
8.213.2.1 pCodecSTGain . . . 240
8.213.2.2 pDTMFTXGain . . . 240
8.213.2.3 pECMode . . . 240

8.213.2.4 pNSEnable . . . 240
8.213.2.5 Profile . . . 240
8.213.2.6 pRXAGCList . . . 240
8.213.2.7 pRXAVCAGCSwitch . . . 240
8.213.2.8 pRXAVCList . . . 240
8.213.2.9 pRXPCMIIRFltr . . . 240
8.213.2.10 pTXAGCList . . . 240
8.213.2.11 pTXAVCSwitch . . . 240
8.213.2.12 pTXGain . . . 240
8.213.2.13 pTXPCMIIRFltr . . . 240
8.214 pack_audio_SLQSSetAudioProfile_t Struct Reference . . . 240
8.214.1 Detailed Description . . . 241
8.214.2 Field Documentation . . . 241
8.214.2.1 EarMute . . . 241
8.214.2.2 Generator . . . 241
8.214.2.3 MicMute . . . 241
8.214.2.4 Profile . . . 241
8.214.2.5 Volume . . . 241
8.215 pack_audio_SLQSSetAudioVolTLBConfig_t Struct Reference . . . 242
8.215.1 Detailed Description . . . 242
8.215.2 Field Documentation . . . 242
8.215.2.1 Generator . . . 242
8.215.2.2 Item . . . 242
8.215.2.3 Profile . . . 242
8.215.2.4 Volume . . . 242
8.215.2.5 VolValue . . . 242
8.216 pack_cat_CATSendEnvelopeCommand_t Struct Reference . . . 242
8.216.1 Detailed Description . . . 243
8.216.2 Field Documentation . . . 243
8.216.2.1 cmdID . . . 243
8.216.2.2 dataLen . . . 243
8.216.2.3 pData . . . 243
8.217 pack_cat_CATSendTerminalResponse_t Struct Reference . . . 243
8.217.1 Detailed Description . . . 243
8.217.2 Field Documentation . . . 244
8.217.2.1 dataLen . . . 244
8.217.2.2 pData . . . 244
8.217.2.3 refID . . . 244
8.218 pack_cat_SetCATEventCallback_t Struct Reference . . . 244
8.218.1 Detailed Description . . . 244

8.218.2 Field Documentation . . . 244
8.218.2.1 eventMask . . . 244
8.219 pack_dms_ActivateAutomatic_t Struct Reference . . . 245
8.219.1 Detailed Description . . . 245
8.219.2 Field Documentation . . . 245
8.219.2.1 actCode . . . 245
8.220 pack_dms_GetCustFeaturesV2_t Struct Reference . . . 245
8.220.1 Detailed Description . . . 245
8.220.2 Field Documentation . . . 245
8.220.2.1 cust_id . . . 245
8.220.2.2 list_type . . . 245
8.220.2.3 Tlvresult . . . 246
8.221 pack_dms_ResetToFactoryDefaults_t Struct Reference . . . 246
8.221.1 Detailed Description . . . 246
8.221.2 Field Documentation . . . 246
8.221.2.1 spc . . . 246
8.222 pack_dms_SetActivationStatusCallback_t Struct Reference . . . 246
8.222.1 Detailed Description . . . 246
8.222.2 Field Documentation . . . 246
8.222.2.1 activationState . . . 246
8.223 pack_dms_SetCrashAction_t Struct Reference . . . 246
8.223.1 Detailed Description . . . 247
8.223.2 Field Documentation . . . 247
8.223.2.1 crashAction . . . 247
8.224 pack_dms_SetCustFeature_t Struct Reference . . . 247
8.224.1 Detailed Description . . . 247
8.224.2 Field Documentation . . . 249
8.224.2.1 DHCPRelayEnabled . . . 249
8.224.2.2 DisableIMSI . . . 249
8.224.2.3 GpsEnable . . . 249
8.224.2.4 GPSLPM . . . 249
8.224.2.5 GPSSel . . . 249
8.224.2.6 IPFamSupport . . . 249
8.224.2.7 IsVoiceEnabled . . . 249
8.224.2.8 RMAutoConnect . . . 249
8.224.2.9 SMSSupport . . . 249
8.225 pack_dms_SetCustFeaturesV2_t Struct Reference . . . 249
8.225.1 Detailed Description . . . 249
8.225.2 Field Documentation . . . 250
8.225.2.1 cust_id . . . 250

8.225.2.2 cust_value . . . 250
8.225.2.3 Tlvresult . . . 250
8.225.2.4 value_length . . . 250
8.226 pack_dms_SetEventReport_t Struct Reference . . . 250
8.226.1 Detailed Description . . . 250
8.226.2 Field Documentation . . . 250
8.226.2.1 mode . . . 250
8.227 pack_dms_SetPower_t Struct Reference . . . 250
8.227.1 Detailed Description . . . 250
8.227.2 Field Documentation . . . 251
8.227.2.1 mode . . . 251
8.227.2.2 Tlvresult . . . 251
8.228 pack_dms_SetUSBComp_t Struct Reference . . . 251
8.228.1 Detailed Description . . . 251
8.228.2 Field Documentation . . . 252
8.228.2.1 Tlvresult . . . 252
8.228.2.2 USBComp . . . 252
8.229 pack_dms_SLQSDmsSwiIndicationRegister_t Struct Reference . . . 252
8.229.1 Detailed Description . . . 252
8.229.2 Field Documentation . . . 252
8.229.2.1 resetInfoInd . . . 252
8.230 pack_dms_SLQSSwiGetCrashInfo_t Struct Reference . . . 252
8.230.1 Detailed Description . . . 252
8.230.2 Field Documentation . . . 252
8.230.2.1 clear . . . 253
8.231 pack_dms_SLQSSwiSetDyingGaspCfg_t Struct Reference . . . 253
8.231.1 Detailed Description . . . 253
8.231.2 Field Documentation . . . 253
8.231.2.1 pDestSMSContent . . . 253
8.231.2.2 pDestSMSNum . . . 253
8.232 pack_dms_SLQSSwiSetHostDevInfo_t Struct Reference . . . 253
8.232.1 Detailed Description . . . 253
8.232.2 Field Documentation . . . 254
8.232.2.1 manString . . . 254
8.232.2.2 modelString . . . 254
8.232.2.3 plasmaIDString . . . 254
8.232.2.4 swVerString . . . 254
8.233 pack_dms_SLQSSwiSetOSInfo_t Struct Reference . . . 254
8.233.1 Detailed Description . . . 254
8.233.2 Field Documentation . . . 254

8.233.2.1 nameString . . . 254
8.233.2.2 versionString . . . 254
8.234 pack_dms_UIMChangePIN_t Struct Reference . . . 254
8.234.1 Detailed Description . . . 255
8.234.2 Field Documentation . . . 255
8.234.2.1 id . . . 255
8.234.2.2 newValue . . . 255
8.234.2.3 oldValue . . . 255
8.235 pack_dms_UIMGetControlKeyStatus_t Struct Reference . . . 255
8.235.1 Detailed Description . . . 255
8.235.2 Field Documentation . . . 255
8.235.2.1 facility . . . 255
8.236 pack_dms_UIMGetICCID_t Struct Reference . . . 256
8.236.1 Detailed Description . . . 256
8.236.2 Field Documentation . . . 256
8.236.2.1 Tlvresult . . . 256
8.237 pack_dms_UIMSetControlKeyProtection_t Struct Reference . . . 256
8.237.1 Detailed Description . . . 256
8.237.2 Field Documentation . . . 257
8.237.2.1 facility . . . 257
8.237.2.2 facilityCk . . . 257
8.237.2.3 facilityState . . . 257
8.238 pack_dms_UIMSetPINProtection_t Struct Reference . . . 257
8.238.1 Detailed Description . . . 257
8.238.2 Field Documentation . . . 257
8.238.2.1 bEnable . . . 257
8.238.2.2 id . . . 257
8.238.2.3 value . . . 257
8.239 pack_dms_UIMUnblockControlKey_t Struct Reference . . . 257
8.239.1 Detailed Description . . . 257
8.239.2 Field Documentation . . . 258
8.239.2.1 facility . . . 258
8.239.2.2 facilityCk . . . 258
8.240 pack_dms_UIMUnblockPIN_t Struct Reference . . . 258
8.240.1 Detailed Description . . . 258
8.240.2 Field Documentation . . . 258
8.240.2.1 id . . . 258
8.240.2.2 newPin . . . 258
8.240.2.3 pukValue . . . 258
8.241 pack_dms_UIMVerifyPIN_t Struct Reference . . . 259

8.241.1 Detailed Description . . . 259
8.241.2 Field Documentation . . . 259
8.241.2.1 id . . . 259
8.241.2.2 value . . . 259
8.242 pack_fms_GetImagesPreference_t Struct Reference . . . 259
8.242.1 Detailed Description . . . 259
8.242.2 Field Documentation . . . 259
8.242.2.1 TlvResult . . . 259
8.243 pack_fms_GetStoredImages_t Struct Reference . . . 259
8.243.1 Detailed Description . . . 260
8.243.2 Field Documentation . . . 260
8.243.2.1 TlvResult . . . 260
8.244 pack_fms_SetImagesPreference_t Struct Reference . . . 260
8.244.1 Detailed Description . . . 260
8.244.2 Field Documentation . . . 261
8.244.2.1 bForceDownload . . . 261
8.244.2.2 imageListSize . . . 261
8.244.2.3 modemIndex . . . 261
8.244.2.4 pImageList . . . 261
8.244.2.5 TlvResult . . . 261
8.245 pack_ims_SLQSImsConfigIndicationRegister_t Struct Reference . . . 261
8.245.1 Detailed Description . . . 261
8.245.2 Field Documentation . . . 262
8.245.2.1 pRegMgrConfigEvents . . . 262
8.245.2.2 pSIPConfigEvents . . . 262
8.245.2.3 pSMSConfigEvents . . . 262
8.245.2.4 pUserConfigEvents . . . 262
8.245.2.5 pVoIPConfigEvents . . . 262
8.246 pack_ims_SLQSSetIMSSMSConfig_t Struct Reference . . . 262
8.246.1 Detailed Description . . . 262
8.246.2 Field Documentation . . . 263
8.246.2.1 pPhoneCtxtURI . . . 263
8.246.2.2 pPhoneCtxtURILen . . . 263
8.246.2.3 pSMSFormat . . . 263
8.246.2.4 pSMSOverIPNwInd . . . 263
8.247 pack_ims_SLQSSetIMSUserConfig_t Struct Reference . . . 263
8.247.1 Detailed Description . . . 263
8.247.2 Field Documentation . . . 263
8.247.2.1 pIMSDomain . . . 263
8.247.2.2 pIMSDomainLen . . . 263

8.248 pack_ims_SLQSSetIMSVoIPConfig_t Struct Reference . . . 263
8.248.1 Detailed Description . . . 264
8.248.2 Field Documentation . . . 266
8.248.2.1 pAmrMode . . . 266
8.248.2.2 pAmrOctetAligned . . . 266
8.248.2.3 pAmrWbEnable . . . 266
8.248.2.4 pAmrWBMode . . . 266
8.248.2.5 pAmrWBOctetAligned . . . 266
8.248.2.6 pMinSessionExpiryTimer . . . 266
8.248.2.7 pRingBackTimer . . . 266
8.248.2.8 pRingingTimer . . . 266
8.248.2.9 pRTPRTCPInactTimer . . . 266
8.248.2.10 pScrAmrEnable . . . 266
8.248.2.11 pScrAmrWbEnable . . . 266
8.248.2.12 pSessionExpiryTimer . . . 266
8.249 pack_ims_SLQSSetRegMgrConfig_t Struct Reference . . . 266
8.249.1 Detailed Description . . . 266
8.249.2 Field Documentation . . . 267
8.249.2.1 pCSCFPortName . . . 267
8.249.2.2 pCSCFPortNameLen . . . 267
8.249.2.3 pIMSTestMode . . . 267
8.249.2.4 pPriCSCFPort . . . 267
8.250 pack_ims_SLQSSetSIPConfig_t Struct Reference . . . 267
8.250.1 Detailed Description . . . 267
8.250.2 Field Documentation . . . 267
8.250.2.1 pSigCompEnabled . . . 268
8.250.2.2 pSIPLocalPort . . . 268
8.250.2.3 pSubscribeTimer . . . 268
8.250.2.4 pTimerSIPReg . . . 268
8.250.2.5 pTimerT1 . . . 268
8.250.2.6 pTimerT2 . . . 268
8.250.2.7 pTimerTf . . . 268
8.251 pack_imsa_SLQSRegisterIMSAIndication_t Struct Reference . . . 268
8.251.1 Detailed Description . . . 268
8.251.2 Field Documentation . . . 269
8.251.2.1 has_PdpStatusConfig . . . 269
8.251.2.2 has_RatHandoverStatusConfig . . . 269
8.251.2.3 has_RegStatusConfig . . . 269
8.251.2.4 has_ServiceStatusConfig . . . 269
8.251.2.5 PdpStatusConfig . . . 269

8.251.2.6 RatHandoverStatusConfig . . . 269
8.251.2.7 RegStatusConfig . . . 269
8.251.2.8 ServiceStatusConfig . . . 269
8.252 pack_loc_Delete_Assist_Data_t Struct Reference . . . 269
8.252.1 Detailed Description . . . 269
8.252.2 Field Documentation . . . 270
8.252.2.1 pBdsSVInfo . . . 270
8.252.2.2 pCellDb . . . 270
8.252.2.3 pClkInfo . . . 270
8.252.2.4 pGnssData . . . 270
8.252.2.5 pSVInfo . . . 270
8.252.2.6 TlvResult . . . 270
8.253 pack_loc_EventRegister_t Struct Reference . . . 270
8.253.1 Detailed Description . . . 270
8.253.2 Field Documentation . . . 272
8.253.2.1 eventRegister . . . 272
8.253.2.2 TlvResult . . . 272
8.254 pack_loc_SetExtPowerState_t Struct Reference . . . 272
8.254.1 Detailed Description . . . 272
8.254.2 Field Documentation . . . 272
8.254.2.1 extPowerState . . . 272
8.254.2.2 TlvResult . . . 272
8.255 pack_loc_SetOperationMode_t Struct Reference . . . 272
8.255.1 Detailed Description . . . 273
8.255.2 Field Documentation . . . 273
8.255.2.1 mode . . . 273
8.255.2.2 TlvResult . . . 273
8.256 pack_loc_SLQSLOCGetBestAvailPos_t Struct Reference . . . 273
8.256.1 Detailed Description . . . 273
8.256.2 Field Documentation . . . 273
8.256.2.1 TlvResult . . . 273
8.256.2.2 xid . . . 274
8.257 pack_loc_SLQSLOCGetServer_t Struct Reference . . . 274
8.257.1 Detailed Description . . . 274
8.257.2 Field Documentation . . . 274
8.257.2.1 has_serverAddrTypeMask . . . 274
8.257.2.2 serverAddrTypeMask . . . 274
8.257.2.3 serverType . . . 274
8.258 pack_loc_SLQSLOCInjectPosition_t Struct Reference . . . 274
8.258.1 Detailed Description . . . 275

8.258.2 Field Documentation . . . 278
8.258.2.1 altitudeSrcInfo . . . 278
8.258.2.2 altitudeWrtEllipsoid . . . 278
8.258.2.3 altitudeWrtMeanSeaLevel . . . 278
8.258.2.4 has_altitudeSrcInfo . . . 278
8.258.2.5 has_altitudeWrtEllipsoid . . . 278
8.258.2.6 has_altitudeWrtMeanSeaLevel . . . 278
8.258.2.7 has_horConfidence . . . 278
8.258.2.8 has_horReliability . . . 278
8.258.2.9 has_horUncCircular . . . 278
8.258.2.10 has_latitude . . . 278
8.258.2.11 has_longitude . . . 278
8.258.2.12 has_positionSrc . . . 278
8.258.2.13 has_rawHorConfidence . . . 278
8.258.2.14 has_rawHorUncCircular . . . 278
8.258.2.15 has_timestampAge . . . 278
8.258.2.16 has_timestampUtc . . . 278
8.258.2.17 has_vertConfidence . . . 278
8.258.2.18 has_vertRelicability . . . 279
8.258.2.19 has_vertUnc . . . 279
8.258.2.20 horConfidence . . . 279
8.258.2.21 horReliability . . . 279
8.258.2.22 horUncCircular . . . 279
8.258.2.23 latitude . . . 279
8.258.2.24 longitude . . . 279
8.258.2.25 positionSrc . . . 279
8.258.2.26 rawHorConfidence . . . 279
8.258.2.27 rawHorUncCircular . . . 279
8.258.2.28 timestampAge . . . 279
8.258.2.29 timestampUtc . . . 279
8.258.2.30 vertConfidence . . . 279
8.258.2.31 vertReliability . . . 279
8.258.2.32 vertUnc . . . 279
8.259 pack_loc_SLQSLOCInjectSensorData_t Struct Reference . . . 279
8.259.1 Detailed Description . . . 279
8.259.2 Field Documentation . . . 280
8.259.2.1 acceleroData . . . 280
8.259.2.2 acceleroTimeSrc . . . 280
8.259.2.3 accelTemp . . . 280
8.259.2.4 gyroData . . . 280

8.259.2.5 gyroTemp . . . 281
8.259.2.6 gyroTimeSrc . . . 281
8.259.2.7 has_acceleroTimeSrc . . . 281
8.259.2.8 has_accelTemp . . . 281
8.259.2.9 has_accleroData . . . 281
8.259.2.10 has_gyroData . . . 281
8.259.2.11 has_gyroTemp . . . 281
8.259.2.12 has_gyroTimeSrc . . . 281
8.259.2.13 has_opaqueId . . . 281
8.259.2.14 opaqueId . . . 281
8.260 pack_loc_SLQSLOCInjectUTCTime_t Struct Reference . . . 281
8.260.1 Detailed Description . . . 281
8.260.2 Field Documentation . . . 281
8.260.2.1 timeMsec . . . 281
8.260.2.2 timeUncMsec . . . 281
8.261 pack_loc_SLQSLOCSetCradleMountConfig_t Struct Reference . . . 281
8.261.1 Detailed Description . . . 282
8.261.2 Field Documentation . . . 282
8.261.2.1 confidence . . . 282
8.261.2.2 has_confidence . . . 282
8.261.2.3 state . . . 282
8.262 pack_loc_Start_t Struct Reference . . . 282
8.262.1 Detailed Description . . . 282
8.262.2 Field Documentation . . . 283
8.262.2.1 pApplicationInfo . . . 283
8.262.2.2 pConfigAltitudeAssumed . . . 284
8.262.2.3 pHorizontalAccuracyLvl . . . 284
8.262.2.4 pIntermediateReportState . . . 284
8.262.2.5 pMinIntervalTime . . . 284
8.262.2.6 pRecurrenceType . . . 284
8.262.2.7 SessionId . . . 284
8.262.2.8 Tlvresult . . . 284
8.263 pack_loc_Stop_t Struct Reference . . . 284
8.263.1 Detailed Description . . . 284
8.263.2 Field Documentation . . . 284
8.263.2.1 SessionId . . . 284
8.263.2.2 Tlvresult . . . 284
8.264 pack_nas_InitiateDomainAttach_t Struct Reference . . . 284
8.264.1 Detailed Description . . . 284
8.264.2 Field Documentation . . . 285

8.264.2.1 action . . . 285
8.265 pack_nas_SetACCOLC_t Struct Reference . . . 285
8.265.1 Detailed Description . . . 285
8.265.2 Field Documentation . . . 285
8.265.2.1 accolc . . . 285
8.265.2.2 spc . . . 285
8.266 pack_nas_SetCDMANetworkParameters_t Struct Reference . . . 285
8.266.1 Detailed Description . . . 285
8.266.2 Field Documentation . . . 286
8.266.2.1 pApplication . . . 286
8.266.2.2 pBroadcast . . . 286
8.266.2.3 pCustomSCP . . . 287
8.266.2.4 pForceRev0 . . . 287
8.266.2.5 pProtocol . . . 287
8.266.2.6 pRoaming . . . 287
8.266.2.7 pSPC . . . 287
8.267 pack_nas_SetNetworkPreference_t Struct Reference . . . 287
8.267.1 Detailed Description . . . 287
8.267.2 Field Documentation . . . 287
8.267.2.1 Duration . . . 287
8.267.2.2 TechnologyPref . . . 288
8.267.2.3 Tlvresult . . . 288
8.268 pack_nas_SLQSConfigSigInfo_t Struct Reference . . . 288
8.268.1 Detailed Description . . . 288
8.268.2 Field Documentation . . . 289
8.268.2.1 pECIOThresh . . . 289
8.268.2.2 pHDRSINRThresh . . . 289
8.268.2.3 pIOThresh . . . 289
8.268.2.4 pLTESigRptCfg . . . 289
8.268.2.5 pLTESNRThresh . . . 289
8.268.2.6 pRSRPThresh . . . 289
8.268.2.7 pRSRQThresh . . . 289
8.268.2.8 pRSSIThresh . . . 289
8.268.2.9 pTDSCDMASINRCONFThresh . . . 289
8.269 pack_nas_SLQSGetPLMNName_t Struct Reference . . . 289
8.269.1 Detailed Description . . . 289
8.269.2 Field Documentation . . . 290
8.269.2.1 mcc . . . 290
8.269.2.2 mnc . . . 290
8.269.2.3 pMncPcsStatus . . . 290

8.270 pack_nas_SLQSInitiateNetworkRegistration_t Struct Reference . . . 290
8.270.1 Detailed Description . . . 290
8.270.2 Field Documentation . . . 291
8.270.2.1 pChangeDuration . . . 291
8.270.2.2 pMncPcsDigitStatus . . . 291
8.270.2.3 pMNRInfo . . . 291
8.270.2.4 regAction . . . 291
8.271 pack_nas_SLQSNasConfigSigInfo2_t Struct Reference . . . 291
8.271.1 Detailed Description . . . 292
8.271.2 Field Documentation . . . 294
8.271.2.1 pCDMAECIODelta . . . 294
8.271.2.2 pCDMAECIOThresh . . . 294
8.271.2.3 pCDMARSSIDelta . . . 294
8.271.2.4 pCDMARSSIThresh . . . 294
8.271.2.5 pGSMRSSIDelta . . . 294
8.271.2.6 pGSMRSSIThresh . . . 294
8.271.2.7 pHDRECIODelta . . . 294
8.271.2.8 pHDRECIOThresh . . . 295
8.271.2.9 pHDRIODelta . . . 295
8.271.2.10 pHDRIOThresh . . . 295
8.271.2.11 pHDRRSSIDelta . . . 295
8.271.2.12 pHDRRSSIThresh . . . 295
8.271.2.13 pHDRSINRDelta . . . 295
8.271.2.14 pHDRSINRThresh . . . 295
8.271.2.15 pLTERSRPDelta . . . 295
8.271.2.16 pLTERSRPThresh . . . 295
8.271.2.17 pLTERSRQDelta . . . 295
8.271.2.18 pLTERSRQThresh . . . 295
8.271.2.19 pLTERSSIDelta . . . 295
8.271.2.20 pLTERSSIThresh . . . 295
8.271.2.21 pLTESigRptConfig . . . 295
8.271.2.22 pLTESNRDelta . . . 295
8.271.2.23 pLTESNRThresh . . . 295
8.271.2.24 pTDSCDMAECIODelta . . . 295
8.271.2.25 pTDSCDMAECIOThresh . . . 295
8.271.2.26 pTDSCDMARSCPDelta . . . 295
8.271.2.27 pTDSCDMARSCPThresh . . . 295
8.271.2.28 pTDSCDMARSSIDelta . . . 295
8.271.2.29 pTDSCDMARSSIThresh . . . 295
8.271.2.30 pTDSCDMASINRDelta . . . 295

8.271.2.31 pTDSCDMASINRThresh . . . 295
8.271.2.32 pWCDMAECIODelta . . . 295
8.271.2.33 pWCDMAECIOThresh . . . 295
8.271.2.34 pWCDMARSSIDelta . . . 295
8.271.2.35 pWCDMARSSIThresh . . . 295
8.272 pack_nas_SLQSNasGet3GPP2Subscription_t Struct Reference . . . 296
8.272.1 Detailed Description . . . 296
8.272.2 Field Documentation . . . 296
8.272.2.1 namID . . . 296
8.273 pack_nas_SLQSNasGetTxRxInfo_t Struct Reference . . . 296
8.273.1 Detailed Description . . . 296
8.273.2 Field Documentation . . . 296
8.273.2.1 radio_if . . . 296
8.274 pack_nas_SLQSNasIndicationRegisterExt_t Struct Reference . . . 296
8.274.1 Detailed Description . . . 297
8.274.2 Field Documentation . . . 299
8.274.2.1 pDDTMInd . . . 299
8.274.2.2 pDualStandByPrefInd . . . 299
8.274.2.3 pErrorRateInd . . . 299
8.274.2.4 pHDRNewUATIAssInd . . . 299
8.274.2.5 pHDRSessionCloseInd . . . 299
8.274.2.6 pLTECphyCa . . . 299
8.274.2.7 pManagedRoamingInd . . . 299
8.274.2.8 pNetworkRejectInd . . . 299
8.274.2.9 pNetworkTimeInd . . . 299
8.274.2.10 pServingSystemInd . . . 299
8.274.2.11 pSignalStrengthInd . . . 299
8.274.2.12 pSubscriptionInfoInd . . . 299
8.274.2.13 pSuppressSysInfoInd . . . 299
8.274.2.14 pSysInfoInd . . . 299
8.274.2.15 pSystemSelectionInd . . . 299
8.275 pack_nas_SLQSNASSeteDRXParams_t Struct Reference . . . 299
8.275.1 Detailed Description . . . 299
8.275.2 Field Documentation . . . 300
8.275.2.1 pCycleLen . . . 300
8.275.2.2 pEdrxEnable . . . 300
8.275.2.3 pPagingTimeWindow . . . 300
8.276 pack_nas_SLQSNasSwiIndicationRegister_t Struct Reference . . . 300
8.276.1 Detailed Description . . . 300
8.276.2 Field Documentation . . . 301

8.276.2.1 gsmUmtsDl . . . 301
8.276.2.2 gsmUmtsUl . . . 301
8.276.2.3 lteEmmDl . . . 301
8.276.2.4 lteEmmUl . . . 301
8.276.2.5 lteEsmDl . . . 301
8.276.2.6 lteEsmUl . . . 301
8.276.2.7 pRankIndicatorInd . . . 301
8.276.2.8 pTimer . . . 301
8.277 pack_nas_SLQSNASSwiSetChannelLock_t Struct Reference . . . 301
8.277.1 Detailed Description . . . 302
8.277.2 Field Documentation . . . 302
8.277.2.1 pLteEARFCN . . . 302
8.277.2.2 pLtePCI . . . 302
8.277.2.3 pWcdmaUARFCN . . . 302
8.278 pack_nas_SLQSSetBandPreference_t Struct Reference . . . 302
8.278.1 Detailed Description . . . 302
8.278.2 Field Documentation . . . 303
8.278.2.1 bandPref . . . 304
8.279 pack_nas_SLQSSetSignalStrengthsCallback_t Struct Reference . . . 304
8.279.1 Detailed Description . . . 304
8.279.2 Field Documentation . . . 304
8.279.2.1 bEnable . . . 304
8.279.2.2 pSigIndReq . . . 304
8.280 pack_nas_SLQSSetSysSelectionPref_t Struct Reference . . . 304
8.280.1 Detailed Description . . . 304
8.280.2 Field Documentation . . . 309
8.280.2.1 pAcqOrderPref . . . 309
8.280.2.2 pBandPref . . . 309
8.280.2.3 pChgDuration . . . 309
8.280.2.4 pCSGID . . . 309
8.280.2.5 pEmerMode . . . 309
8.280.2.6 pGWAcqOrderPref . . . 309
8.280.2.7 pLTEBandPref . . . 309
8.280.2.8 pMNCIncPCSDigStat . . . 309
8.280.2.9 pModePref . . . 309
8.280.2.10 pNetSelPref . . . 309
8.280.2.11 pPRLPref . . . 309
8.280.2.12 pRAT . . . 309
8.280.2.13 pRoamPref . . . 309
8.280.2.14 pSrvDomainPref . . . 309

8.280.2.15 pSrvRegRestriction . . . 310
8.280.2.16 pTdscdmaBandPref . . . 310
8.281 pack_nas_SLQSSwiPSDetach_t Struct Reference . . . 310
8.281.1 Detailed Description . . . 310
8.281.2 Field Documentation . . . 310
8.281.2.1 pDetachAction . . . 310
8.282 pack_pds_PDSInjectTimeReference_t Struct Reference . . . 310
8.282.1 Detailed Description . . . 310
8.282.2 Field Documentation . . . 310
8.282.2.1 systemDiscontinuities . . . 310
8.282.2.2 systemTime . . . 310
8.283 pack_pds_ResetPDSData_t Struct Reference . . . 311
8.283.1 Detailed Description . . . 311
8.283.2 Field Documentation . . . 311
8.283.2.1 pCellDataMask . . . 311
8.283.2.2 pGPSDataMask . . . 311
8.284 pack_pds_SetEventReportCallback_t Struct Reference . . . 311
8.284.1 Detailed Description . . . 312
8.284.2 Field Documentation . . . 312
8.284.2.1 posDataNmea . . . 312
8.284.2.2 rptPosData . . . 312
8.285 pack_pds_SetPDSDefaults_t Struct Reference . . . 312
8.285.1 Detailed Description . . . 312
8.285.2 Field Documentation . . . 313
8.285.2.1 accuracy . . . 313
8.285.2.2 interval . . . 313
8.285.2.3 operation . . . 313
8.285.2.4 timeout . . . 313
8.286 pack_pds_SetPDSState_t Struct Reference . . . 313
8.286.1 Detailed Description . . . 313
8.286.2 Field Documentation . . . 313
8.286.2.1 enable . . . 313
8.287 pack_pds_SetPortAutomaticTracking_t Struct Reference . . . 313
8.287.1 Detailed Description . . . 313
8.287.2 Field Documentation . . . 314
8.287.2.1 bAuto . . . 314
8.288 pack_pds_SetServiceAutomaticTracking_t Struct Reference . . . 314
8.288.1 Detailed Description . . . 314
8.288.2 Field Documentation . . . 314
8.288.2.1 bAuto . . . 314

8.289 pack_pds_SetXTRAAutomaticDownload_t Struct Reference . . . 314
8.289.1 Detailed Description . . . 314
8.289.2 Field Documentation . . . 315
8.289.2.1 bEnabled . . . 315
8.289.2.2 interval . . . 315
8.290 pack_pds_SetXTRANetwork_t Struct Reference . . . 315
8.290.1 Detailed Description . . . 315
8.290.2 Field Documentation . . . 315
8.290.2.1 preference . . . 315
8.291 pack_pds_SLQSGetAGPSConfig_t Struct Reference . . . 315
8.291.1 Detailed Description . . . 315
8.291.2 Field Documentation . . . 316
8.291.2.1 pNetworkMode . . . 316
8.292 pack_pds_SLQSPDSInjectAbsoluteTimeReference_t Struct Reference . . . 316
8.292.1 Detailed Description . . . 316
8.292.2 Field Documentation . . . 316
8.292.2.1 forceFlag . . . 316
8.292.2.2 timeBase . . . 316
8.292.2.3 timeMsec . . . 316
8.292.2.4 timeUncMsec . . . 316
8.293 pack_pds_SLQSPDSInjectPositionData_t Struct Reference . . . 316
8.293.1 Detailed Description . . . 317
8.293.2 Field Documentation . . . 318
8.293.2.1 pAltitudeWrtEllipsoid . . . 318
8.293.2.2 pAltitudeWrtSealevel . . . 318
8.293.2.3 pHorizontalConfidence . . . 318
8.293.2.4 pHorizontalUncCircular . . . 318
8.293.2.5 pLatitude . . . 318
8.293.2.6 pLongitude . . . 318
8.293.2.7 pPositionSource . . . 318
8.293.2.8 pTimeStamp . . . 318
8.293.2.9 pTimeType . . . 318
8.293.2.10 pVerticalConfidence . . . 318
8.293.2.11 pVerticalUnc . . . 318
8.294 pack_pds_SLQSSetAGPSConfig_t Struct Reference . . . 318
8.294.1 Detailed Description . . . 319
8.294.2 Field Documentation . . . 319
8.294.2.1 pNetworkMode . . . 319
8.294.2.2 pServerAddress . . . 319
8.294.2.3 pServerPort . . . 319

8.294.2.4 pServerURL . . . 319
8.294.2.5 pServerURLLength . . . 319
8.295 pack_pds_SLQSSetPositionMethodState_t Struct Reference . . . 319
8.295.1 Detailed Description . . . 319
8.295.2 Field Documentation . . . 320
8.295.2.1 pWifiState . . . 320
8.295.2.2 pXtraDataState . . . 320
8.295.2.3 pXtraTimeState . . . 320
8.296 pack_pds_StartPDSTrackingSessionExt_t Struct Reference . . . 320
8.296.1 Detailed Description . . . 320
8.296.2 Field Documentation . . . 321
8.296.2.1 fixAccuracy . . . 321
8.296.2.2 fixCount . . . 321
8.296.2.3 fixInterval . . . 321
8.296.2.4 fixTimeout . . . 321
8.296.2.5 sessionControl . . . 321
8.296.2.6 sessionOperation . . . 321
8.296.2.7 sessionServerOption . . . 321
8.296.2.8 sessionType . . . 321
8.297 pack_qmi_t Struct Reference . . . 321
8.297.1 Detailed Description . . . 322
8.297.2 Field Documentation . . . 322
8.297.2.1 msgid . . . 322
8.297.2.2 svc . . . 322
8.297.2.3 timeout . . . 322
8.297.2.4 xid . . . 322
8.298 pack_qos_BindDataPort_t Struct Reference . . . 322
8.298.1 Detailed Description . . . 322
8.298.2 Field Documentation . . . 322
8.298.2.1 pMuxID . . . 322
8.298.2.2 pPeripheralEndPointID . . . 322
8.298.2.3 pSIODataPort . . . 322
8.299 pack_qos_SLQSQosSwiReadApnExtraParams_t Struct Reference . . . 323
8.299.1 Detailed Description . . . 323
8.299.2 Field Documentation . . . 323
8.299.2.1 apnId . . . 323
8.300 pack_qos_SLQSQosSwiReadDataStats_t Struct Reference . . . 323
8.300.1 Detailed Description . . . 323
8.300.2 Field Documentation . . . 323
8.300.2.1 apnId . . . 323

8.301 pack_qos_SLQSSetQosEventCallback_t Struct Reference . . . 323
8.301.1 Detailed Description . . . 323
8.301.2 Field Documentation . . . 324
8.301.2.1 enable . . . 324
8.302 pack_rms_SetSMSWake_t Struct Reference . . . 324
8.302.1 Detailed Description . . . 324
8.302.2 Field Documentation . . . 324
8.302.2.1 enabled . . . 324
8.302.2.2 wake_mask . . . 324
8.303 pack_sar_SLQSSetRfSarState_t Struct Reference . . . 324
8.303.1 Detailed Description . . . 324
8.303.2 Field Documentation . . . 325
8.303.2.1 RfSarState . . . 325
8.304 pack_sms_SaveSMS_t Struct Reference . . . 325
8.304.1 Detailed Description . . . 325
8.304.2 Field Documentation . . . 326
8.304.2.1 messageFormat . . . 326
8.304.2.2 messageSize . . . 326
8.304.2.3 pMessage . . . 326
8.304.2.4 storageType . . . 326
8.305 pack_sms_SendSMS_t Struct Reference . . . 326
8.305.1 Detailed Description . . . 326
8.305.2 Field Documentation . . . 326
8.305.2.1 messageFormat . . . 326
8.305.2.2 messageSize . . . 326
8.305.2.3 pLinktimer . . . 326
8.305.2.4 pMessage . . . 326
8.306 pack_sms_SetNewSMSCallback_t Struct Reference . . . 326
8.306.1 Detailed Description . . . 327
8.306.2 Field Documentation . . . 327
8.306.2.1 status . . . 327
8.307 pack_sms_SetSMSCAddress_t Struct Reference . . . 327
8.307.1 Detailed Description . . . 327
8.307.2 Field Documentation . . . 327
8.307.2.1 pSMSCAddress . . . 327
8.307.2.2 pSMSCType . . . 327
8.308 pack_sms_SLQSDeleteSMS_t Struct Reference . . . 327
8.308.1 Detailed Description . . . 328
8.308.2 Field Documentation . . . 328
8.308.2.1 pMessageIndex . . . 328

8.308.2.2 pMessageMode . . . 328
8.308.2.3 pMessageTag . . . 328
8.308.2.4 storageType . . . 328
8.309 pack_sms_SLQSGetSMS_t Struct Reference . . . 328
8.309.1 Detailed Description . . . 328
8.309.2 Field Documentation . . . 329
8.309.2.1 messageIndex . . . 329
8.309.2.2 pMessageMode . . . 329
8.309.2.3 storageType . . . 329
8.310 pack_sms_SLQSGetSmsBroadcastConfig_t Struct Reference . . . 329
8.310.1 Detailed Description . . . 329
8.310.2 Field Documentation . . . 329
8.310.2.1 mode . . . 329
8.311 pack_sms_SLQSGetSMSList_t Struct Reference . . . 329
8.311.1 Detailed Description . . . 330
8.311.2 Field Documentation . . . 330
8.311.2.1 pMessageMode . . . 330
8.311.2.2 pRequestedTag . . . 330
8.311.2.3 storageType . . . 330
8.312 pack_sms_SLQSModifySMSStatus_t Struct Reference . . . 330
8.312.1 Detailed Description . . . 330
8.312.2 Field Documentation . . . 331
8.312.2.1 messageIndex . . . 331
8.312.2.2 messageTag . . . 331
8.312.2.3 pMessageMode . . . 331
8.312.2.4 storageType . . . 331
8.313 pack_sms_SLQSSendAsyncSMS_t Struct Reference . . . 331
8.313.1 Detailed Description . . . 331
8.313.2 Field Documentation . . . 331
8.313.2.1 pSendSmsParams . . . 331
8.314 pack_sms_SLQSSetIndicationRegister_t Struct Reference . . . 331
8.314.1 Detailed Description . . . 331
8.314.2 Field Documentation . . . 332
8.314.2.1 pSetIndicationRegReq . . . 332
8.315 pack_sms_SLQSSetSmsBroadcastActivation_t Struct Reference . . . 332
8.315.1 Detailed Description . . . 332
8.315.2 Field Documentation . . . 332
8.315.2.1 broadcastActivate . . . 332
8.315.2.2 mode . . . 332
8.316 pack_sms_SLQSSetSmsBroadcastConfig_t Struct Reference . . . 332

8.316.1 Detailed Description . . . 332
8.316.2 Field Documentation . . . 333
8.316.2.1 mode . . . 333
8.316.2.2 pBroadcastConfig . . . 333
8.316.2.3 pCDMABroadcastConfig . . . 333
8.317 pack_sms_SLQSSetSmsStorage_t Struct Reference . . . 333
8.317.1 Detailed Description . . . 333
8.317.2 Field Documentation . . . 333
8.317.2.1 smsStorage . . . 333
8.318 pack_sms_SLQSSmsGetMaxStorageSize_t Struct Reference . . . 333
8.318.1 Detailed Description . . . 334
8.318.2 Field Documentation . . . 334
8.318.2.1 pMaxStorageSizeReq . . . 334
8.319 pack_sms_SLQSSmsSetRoutes_t Struct Reference . . . 334
8.319.1 Detailed Description . . . 334
8.319.2 Field Documentation . . . 334
8.319.2.1 pSetRoutesReq . . . 334
8.320 pack_swiaudio_SLQSGetM2MAudioProfile_t Struct Reference . . . 334
8.320.1 Detailed Description . . . 334
8.320.2 Field Documentation . . . 335
8.320.2.1 pGenerator . . . 335
8.321 pack_swiaudio_SLQSGetM2MAudioVolume_t Struct Reference . . . 335
8.321.1 Detailed Description . . . 335
8.321.2 Field Documentation . . . 335
8.321.2.1 Generator . . . 335
8.321.2.2 Profile . . . 335
8.322 pack_swiaudio_SLQSGetM2MAVMute_t Struct Reference . . . 335
8.322.1 Detailed Description . . . 335
8.322.2 Field Documentation . . . 335
8.322.2.1 Profile . . . 336
8.323 pack_swiaudio_SLQSGetM2MSpkrGain_t Struct Reference . . . 336
8.323.1 Detailed Description . . . 336
8.323.2 Field Documentation . . . 336
8.323.2.1 Profile . . . 336
8.324 pack_swiaudio_SLQSSetM2MAudioAVCFG_t Struct Reference . . . 336
8.324.1 Detailed Description . . . 336
8.324.2 Field Documentation . . . 337
8.324.2.1 Device . . . 337
8.324.2.2 PIFACEId . . . 337
8.324.2.3 pPCMParams . . . 337

8.324.2.4 Profile . . . 337
8.325 pack_swiaudio_SLQSSetM2MAudioLPBK_t Struct Reference . . . 337
8.325.1 Detailed Description . . . 337
8.325.2 Field Documentation . . . 337
8.325.2.1 Enable . . . 337
8.326 pack_swiaudio_SLQSSetM2MAudioProfile_t Struct Reference . . . 337
8.326.1 Detailed Description . . . 338
8.326.2 Field Documentation . . . 338
8.326.2.1 pCwtMute . . . 338
8.326.2.2 pEarMute . . . 338
8.326.2.3 pGenerator . . . 338
8.326.2.4 pMicMute . . . 338
8.326.2.5 Profile . . . 338
8.326.2.6 pVolume . . . 338
8.327 pack_swiaudio_SLQSSetM2MAudioVolume_t Struct Reference . . . 338
8.327.1 Detailed Description . . . 339
8.327.2 Field Documentation . . . 339
8.327.2.1 Generator . . . 339
8.327.2.2 Level . . . 339
8.327.2.3 Profile . . . 339
8.328 pack_swiaudio_SLQSSetM2MAVMute_t Struct Reference . . . 339
8.328.1 Detailed Description . . . 339
8.328.2 Field Documentation . . . 340
8.328.2.1 EarMute . . . 340
8.328.2.2 MicMute . . . 340
8.328.2.3 pCwtMute . . . 340
8.328.2.4 Profile . . . 340
8.329 pack_swiaudio_SLQSSetM2MSpkrGain_t Struct Reference . . . 340
8.329.1 Detailed Description . . . 340
8.329.2 Field Documentation . . . 340
8.329.2.1 Profile . . . 340
8.329.2.2 Value . . . 340
8.330 pack_swiavms_SLQSAVMSSendSelection_t Struct Reference . . . 340
8.330.1 Detailed Description . . . 341
8.330.2 Field Documentation . . . 341
8.330.2.1 pClientPerformOperationFlag . . . 341
8.330.2.2 pDeferTime . . . 341
8.330.2.3 pPackageID . . . 341
8.330.2.4 pRejectReason . . . 341
8.330.2.5 selection . . . 341

8.331 pack_swiavms_SLQSAVMSSetSettings_t Struct Reference . . . 341
8.331.1 Detailed Description . . . 342
8.331.2 Field Documentation . . . 343
8.331.2.1 AutoConnect . . . 343
8.331.2.2 AutoReboot . . . 343
8.331.2.3 pAPNInfo . . . 343
8.331.2.4 pConnectionRetryTimers . . . 343
8.331.2.5 pFwAutoSDM . . . 343
8.331.2.6 pNotifStore . . . 343
8.331.2.7 pPeriodInfo . . . 343
8.331.2.8 pPollingTimer . . . 343
8.331.2.9 PromptFwDownload . . . 343
8.331.2.10 PromptFwUpdate . . . 343
8.332 pack_swiavms_SLQSAVMSStartSession_t Struct Reference . . . 343
8.332.1 Detailed Description . . . 343
8.332.2 Field Documentation . . . 343
8.332.2.1 sessionType . . . 343
8.333 pack_swiavms_SLQSAVMSStopSession_t Struct Reference . . . 344
8.333.1 Detailed Description . . . 344
8.333.2 Field Documentation . . . 344
8.333.2.1 sessionType . . . 344
8.334 pack_swiloc_SwiLocSetAutoStart_t Struct Reference . . . 344
8.334.1 Detailed Description . . . 344
8.334.2 Field Documentation . . . 345
8.334.2.1 fix_rate . . . 345
8.334.2.2 fix_type . . . 345
8.334.2.3 function . . . 345
8.334.2.4 max_dist . . . 345
8.334.2.5 max_time . . . 345
8.334.2.6 set_fix_rate . . . 346
8.334.2.7 set_fix_type . . . 346
8.334.2.8 set_function . . . 346
8.334.2.9 set_max_dist . . . 346
8.334.2.10 set_max_time . . . 346
8.335 pack_swioma_SLQSOMADMCancelSession_t Struct Reference . . . 346
8.335.1 Detailed Description . . . 346
8.335.2 Field Documentation . . . 346
8.335.2.1 sessionType . . . 346
8.336 pack_swioma_SLQSOMADMCancelSessionExt_t Struct Reference . . . 346
8.336.1 Detailed Description . . . 346

8.336.2 Field Documentation . . . 346
8.336.2.1 sessionType . . . 347
8.337 pack_swioma_SLQSOMADMGetSessionInfo_t Struct Reference . . . 347
8.337.1 Detailed Description . . . 347
8.337.2 Field Documentation . . . 347
8.337.2.1 SessionType . . . 347
8.338 pack_swioma_SLQSOMADMSendSelection_t Struct Reference . . . 347
8.338.1 Detailed Description . . . 347
8.338.2 Field Documentation . . . 348
8.338.2.1 pDeferTime . . . 348
8.338.2.2 pRejectReason . . . 348
8.338.2.3 selection . . . 348
8.339 pack_swioma_SLQSOMADMSendSelectionExt_t Struct Reference . . . 348
8.339.1 Detailed Description . . . 348
8.339.2 Field Documentation . . . 348
8.339.2.1 selection . . . 348
8.340 pack_swioma_SLQSOMADMSetSettings_t Struct Reference . . . 348
8.340.1 Detailed Description . . . 348
8.340.2 Field Documentation . . . 349
8.340.2.1 FOTAdownload . . . 349
8.340.2.2 FOTAUpdate . . . 349
8.340.2.3 pAutosdm . . . 349
8.340.2.4 pFwAutoCheck . . . 349
8.341 pack_swioma_SLQSOMADMSetSettingsExt_t Struct Reference . . . 349
8.341.1 Detailed Description . . . 349
8.341.2 Field Documentation . . . 350
8.341.2.1 FOTAdownload . . . 350
8.341.2.2 FOTAUpdate . . . 350
8.341.2.3 FUMOEnable . . . 350
8.341.2.4 OMADMEnable . . . 350
8.341.2.5 OMADMLogEnable . . . 350
8.341.2.6 PRLEnable . . . 350
8.342 pack_swioma_SLQSOMADMStartSession_t Struct Reference . . . 350
8.342.1 Detailed Description . . . 351
8.342.2 Field Documentation . . . 351
8.342.2.1 sessionType . . . 351
8.343 pack_swioma_SLQSOMADMStartSessionExt_t Struct Reference . . . 351
8.343.1 Detailed Description . . . 351
8.343.2 Field Documentation . . . 351
8.343.2.1 sessionType . . . 351

8.344pack_tmd_SLQSTmdDeRegNotMitigationLvl_t Struct Reference . . . 351
8.344.1 Detailed Description . . . 352
8.344.2 Field Documentation . . . 352
8.344.2.1 mitigationDevID . . . 352
8.344.2.2 mitigationDevIDLen . . . 352
8.345pack_tmd_SLQSTmdGetMitigationLvl_t Struct Reference . . . 352
8.345.1 Detailed Description . . . 352
8.345.2 Field Documentation . . . 352
8.345.2.1 mitigationDevID . . . 352
8.345.2.2 mitigationDevIDLen . . . 352
8.346pack_tmd_SLQSTmdRegNotMitigationLvl_t Struct Reference . . . 352
8.346.1 Detailed Description . . . 353
8.346.2 Field Documentation . . . 353
8.346.2.1 mitigationDevID . . . 353
8.346.2.2 mitigationDevIDLen . . . 353
8.347pack_uim_ChangePin_t Struct Reference . . . 353
8.347.1 Detailed Description . . . 353
8.347.2 Field Documentation . . . 354
8.347.2.1 changePIN . . . 354
8.347.2.2 EncryptedPIN1 . . . 354
8.347.2.3 pIndicationToken . . . 354
8.347.2.4 pKeyReferenceID . . . 354
8.347.2.5 sessionInfo . . . 354
8.347.2.6 Tlvresult . . . 354
8.348pack_uim_ReadTransparent_t Struct Reference . . . 354
8.348.1 Detailed Description . . . 354
8.348.2 Field Documentation . . . 355
8.348.2.1 fileIndex . . . 355
8.348.2.2 pEncryptData . . . 355
8.348.2.3 pIndicationToken . . . 355
8.348.2.4 readTransparent . . . 355
8.348.2.5 sessionInfo . . . 355
8.348.2.6 Tlvresult . . . 355
8.349pack_uim_SetPinProtection_t Struct Reference . . . 355
8.349.1 Detailed Description . . . 355
8.349.2 Field Documentation . . . 356
8.349.2.1 EncryptedPIN1 . . . 356
8.349.2.2 pIndicationToken . . . 356
8.349.2.3 pinProtection . . . 356
8.349.2.4 pKeyReferenceID . . . 356

8.349.2.5 sessionInfo . . . 356
8.349.2.6 TlvResult . . . 356
8.350 pack_uim_SLQSUIMAuthenticate_t Struct Reference . . . 356
8.350.1 Detailed Description . . . 356
8.350.2 Field Documentation . . . 357
8.350.2.1 authData . . . 357
8.350.2.2 pIndicationToken . . . 357
8.350.2.3 sessionInfo . . . 357
8.351 pack_uim_SLQSUIMDepersonalization_t Struct Reference . . . 357
8.351.1 Detailed Description . . . 357
8.351.2 Field Documentation . . . 357
8.351.2.1 depersonilisationInfo . . . 357
8.352 pack_uim_SLQSUIMEventRegister_t Struct Reference . . . 357
8.352.1 Detailed Description . . . 357
8.352.2 Field Documentation . . . 358
8.352.2.1 eventMask . . . 358
8.353 pack_uim_SLQSUIMGetConfiguration_t Struct Reference . . . 358
8.353.1 Detailed Description . . . 358
8.353.2 Field Documentation . . . 358
8.353.2.1 pConfigurationMask . . . 358
8.354 pack_uim_SLQSUIMGetFileAttributes_t Struct Reference . . . 358
8.354.1 Detailed Description . . . 358
8.354.2 Field Documentation . . . 359
8.354.2.1 fileIndex . . . 359
8.354.2.2 pIndicationToken . . . 359
8.354.2.3 sessionInfo . . . 359
8.355 pack_uim_SLQSUIMPowerDown_t Struct Reference . . . 359
8.355.1 Detailed Description . . . 359
8.355.2 Field Documentation . . . 359
8.355.2.1 slot . . . 359
8.356 pack_uim_SLQSUIMPowerUp_t Struct Reference . . . 359
8.356.1 Detailed Description . . . 360
8.356.2 Field Documentation . . . 360
8.356.2.1 pIgnoreHotSwapSwitch . . . 360
8.356.2.2 slot . . . 360
8.357 pack_uim_SLQSUIMRefreshComplete_t Struct Reference . . . 360
8.357.1 Detailed Description . . . 360
8.357.2 Field Documentation . . . 360
8.357.2.1 refreshComplete . . . 360
8.357.2.2 sessionInfo . . . 360

8.358 pack_uim_SLQSUIMRefreshGetLastEvent_t Struct Reference . . . 360
8.358.1 Detailed Description . . . 361
8.358.2 Field Documentation . . . 361
8.358.2.1 sessionInfo . . . 361
8.359 pack_uim_SLQSUIMRefreshOK_t Struct Reference . . . 361
8.359.1 Detailed Description . . . 361
8.359.2 Field Documentation . . . 361
8.359.2.1 OKtoRefresh . . . 361
8.359.2.2 sessionInfo . . . 361
8.360 pack_uim_SLQSUIMRefreshRegister_t Struct Reference . . . 361
8.360.1 Detailed Description . . . 362
8.360.2 Field Documentation . . . 362
8.360.2.1 regRefresh . . . 362
8.360.2.2 sessionInfo . . . 362
8.361 pack_uim_SLQSUIMSwitchSlot_t Struct Reference . . . 362
8.361.1 Detailed Description . . . 362
8.361.2 Field Documentation . . . 363
8.361.2.1 bLogicalSlot . . . 363
8.361.2.2 ulPhysicalSlot . . . 363
8.362 pack_uim_UnblockPin_t Struct Reference . . . 363
8.362.1 Detailed Description . . . 363
8.362.2 Field Documentation . . . 363
8.362.2.1 EncryptedPIN1 . . . 363
8.362.2.2 pIndicationToken . . . 363
8.362.2.3 pinProtection . . . 364
8.362.2.4 pKeyReferenceID . . . 364
8.362.2.5 sessionInfo . . . 364
8.362.2.6 Tlvresult . . . 364
8.363 pack_uim_VerifyPin_t Struct Reference . . . 364
8.363.1 Detailed Description . . . 364
8.363.2 Field Documentation . . . 365
8.363.2.1 pEncryptedPIN1 . . . 365
8.363.2.2 pIndicationToken . . . 365
8.363.2.3 pKeyReferenceID . . . 365
8.363.2.4 sessionInfo . . . 365
8.363.2.5 Tlvresult . . . 365
8.363.2.6 verifyPIN . . . 365
8.364 pack_voice_AnswerUSSD_t Struct Reference . . . 365
8.364.1 Detailed Description . . . 365
8.364.2 Field Documentation . . . 365

8.364.2.1 pInfo . . . 365
8.365 pack_voice_OriginateUSSD_t Struct Reference . . . 365
8.365.1 Detailed Description . . . 365
8.365.2 Field Documentation . . . 366
8.365.2.1 pInfo . . . 366
8.366 pack_voice_SLQSOriginateUSSD_t Struct Reference . . . 366
8.366.1 Detailed Description . . . 366
8.366.2 Field Documentation . . . 366
8.366.2.1 ussData . . . 366
8.366.2.2 ussDCS . . . 366
8.366.2.3 ussLen . . . 366
8.367 pack_voice_SLQSVoiceALSSelectLine_t Struct Reference . . . 366
8.367.1 Detailed Description . . . 366
8.367.2 Field Documentation . . . 367
8.367.2.1 lineValue . . . 367
8.368 pack_voice_SLQSVoiceALSSetLineSwitching_t Struct Reference . . . 367
8.368.1 Detailed Description . . . 367
8.368.2 Field Documentation . . . 367
8.368.2.1 switchOption . . . 367
8.369 pack_voice_SLQSVoiceAnswerCall_t Struct Reference . . . 367
8.369.1 Detailed Description . . . 367
8.369.2 Field Documentation . . . 367
8.369.2.1 pCallId . . . 368
8.370 pack_voice_SLQSVoiceBindSubscription_t Struct Reference . . . 368
8.370.1 Detailed Description . . . 368
8.370.2 Field Documentation . . . 368
8.370.2.1 subsType . . . 368
8.371 pack_voice_SLQSVoiceBurstDTMF_t Struct Reference . . . 368
8.371.1 Detailed Description . . . 368
8.371.2 Field Documentation . . . 368
8.371.2.1 BurstDTMFInfo . . . 368
8.371.2.2 pBurstDTMFLengths . . . 369
8.372 pack_voice_SLQSVoiceDialCall_t Struct Reference . . . 369
8.372.1 Detailed Description . . . 369
8.372.2 Field Documentation . . . 370
8.372.2.1 callNumber . . . 370
8.372.2.2 pCallPartySubAdd . . . 370
8.372.2.3 pCallType . . . 370
8.372.2.4 pCLIRType . . . 370
8.372.2.5 pCUGInfo . . . 370

8.372.2.6 pEmergencyCategory . . . 370
8.372.2.7 pSvcType . . . 370
8.372.2.8 pUUSInFo . . . 370
8.373pack_voice_SLQSVoiceEndCall_t Struct Reference . . . 370
8.373.1 Detailed Description . . . 371
8.373.2 Field Documentation . . . 371
8.373.2.1 pCallId . . . 371
8.374pack_voice_SLQSVoiceGetCallBarring_t Struct Reference . . . 371
8.374.1 Detailed Description . . . 371
8.374.2 Field Documentation . . . 371
8.374.2.1 pSvcClass . . . 371
8.374.2.2 reason . . . 372
8.375pack_voice_SLQSVoiceGetCallForwardingStatus_t Struct Reference . . . 372
8.375.1 Detailed Description . . . 372
8.375.2 Field Documentation . . . 372
8.375.2.1 pSvcClass . . . 372
8.375.2.2 Reason . . . 372
8.376pack_voice_SLQSVoiceGetCallInfo_t Struct Reference . . . 372
8.376.1 Detailed Description . . . 372
8.376.2 Field Documentation . . . 373
8.376.2.1 callID . . . 373
8.377pack_voice_SLQSVoiceGetCallWaiting_t Struct Reference . . . 373
8.377.1 Detailed Description . . . 373
8.377.2 Field Documentation . . . 373
8.377.2.1 pSvcClass . . . 373
8.378pack_voice_SLQSVoiceGetConfig_t Struct Reference . . . 373
8.378.1 Detailed Description . . . 373
8.378.2 Field Documentation . . . 374
8.378.2.1 pAirTimer . . . 374
8.378.2.2 pAMRStatus . . . 375
8.378.2.3 pAutoAnswer . . . 375
8.378.2.4 pNamID . . . 375
8.378.2.5 pPrefVoicePrivacy . . . 375
8.378.2.6 pPrefVoiceSO . . . 375
8.378.2.7 pRoamTimer . . . 375
8.378.2.8 pTTYMode . . . 375
8.378.2.9 pVoiceDomainPref . . . 375
8.379pack_voice_SLQSVoiceIndicationRegister_t Struct Reference . . . 375
8.379.1 Detailed Description . . . 375
8.379.2 Field Documentation . . . 376

8.379.2.1 pRegDTMFEvents . . . 376
8.379.2.2 pRegVoicePrivacyEvents . . . 376
8.379.2.3 pSuppsNotifEvents . . . 376
8.380 pack_voice_SLQSVoiceManageCalls_t Struct Reference . . . 376
8.380.1 Detailed Description . . . 376
8.380.2 Field Documentation . . . 377
8.380.2.1 pCallID . . . 377
8.380.2.2 SUPSType . . . 377
8.381 pack_voice_SLQSVoiceOrigUSSDNoWait_t Struct Reference . . . 377
8.381.1 Detailed Description . . . 377
8.381.2 Field Documentation . . . 377
8.381.2.1 USSInformation . . . 377
8.382 pack_voice_SLQSVoiceSendFlash_t Struct Reference . . . 377
8.382.1 Detailed Description . . . 377
8.382.2 Field Documentation . . . 378
8.382.2.1 pCallID . . . 378
8.382.2.2 pFlashPayLd . . . 378
8.382.2.3 pFlashType . . . 378
8.383 pack_voice_SLQSVoiceSetCallBarringPassword_t Struct Reference . . . 378
8.383.1 Detailed Description . . . 378
8.383.2 Field Documentation . . . 379
8.383.2.1 newPasswd . . . 379
8.383.2.2 newPasswdAgain . . . 379
8.383.2.3 oldPasswd . . . 379
8.383.2.4 Reason . . . 379
8.384 pack_voice_SLQSVoiceSetConfig_t Struct Reference . . . 379
8.384.1 Detailed Description . . . 379
8.384.2 Field Documentation . . . 380
8.384.2.1 pAirTimerConfig . . . 380
8.384.2.2 pAutoAnswer . . . 380
8.384.2.3 pPrefVoiceDomain . . . 380
8.384.2.4 pPrefVoiceSO . . . 380
8.384.2.5 pRoamTimerConfig . . . 380
8.384.2.6 pTTYMode . . . 380
8.385 pack_voice_SLQSVoiceSetPreferredPrivacy_t Struct Reference . . . 380
8.385.1 Detailed Description . . . 380
8.385.2 Field Documentation . . . 380
8.385.2.1 privacyPref . . . 380
8.386 pack_voice_SLQSVoiceSetSUPSService_t Struct Reference . . . 380
8.386.1 Detailed Description . . . 381

8.386.2 Field Documentation . . . 383
8.386.2.1 pCallBarringPasswd . . . 383
8.386.2.2 pCallForwardingNumber . . . 383
8.386.2.3 pCallFwdTypeAndPlan . . . 383
8.386.2.4 pServiceClass . . . 383
8.386.2.5 pTimerVal . . . 383
8.386.2.6 reason . . . 383
8.386.2.7 voiceSvc . . . 383
8.387 pack_voice_SLQSVoiceStartContDTMF_t Struct Reference . . . 383
8.387.1 Detailed Description . . . 383
8.387.2 Field Documentation . . . 383
8.387.2.1 DTMFdigit . . . 383
8.387.2.2 pCallID . . . 384
8.388 pack_voice_SLQSVoiceStopContDTMF_t Struct Reference . . . 384
8.388.1 Detailed Description . . . 384
8.388.2 Field Documentation . . . 384
8.388.2.1 callID . . . 384
8.389 pack_wds_DHCPv4ClientLeaseChange_t Struct Reference . . . 384
8.389.1 Detailed Description . . . 384
8.389.2 Field Documentation . . . 384
8.389.2.1 pEnableNotification . . . 384
8.390 pack_wds_GetDefaultProfile_t Struct Reference . . . 384
8.390.1 Detailed Description . . . 385
8.390.2 Field Documentation . . . 385
8.390.2.1 profiletype . . . 385
8.391 pack_wds_GetDefaultProfileNum_t Struct Reference . . . 385
8.391.1 Detailed Description . . . 385
8.391.2 Field Documentation . . . 385
8.391.2.1 family . . . 385
8.391.2.2 type . . . 385
8.392 pack_wds_GetDormancyState_t Struct Reference . . . 385
8.392.1 Detailed Description . . . 385
8.393 pack_wds_GetLastMobileIPError_t Struct Reference . . . 386
8.393.1 Detailed Description . . . 386
8.394 pack_wds_GetMobileIP_t Struct Reference . . . 386
8.394.1 Detailed Description . . . 386
8.395 pack_wds_GetMobileIPProfile_t Struct Reference . . . 386
8.395.1 Detailed Description . . . 386
8.395.2 Field Documentation . . . 386
8.395.2.1 index . . . 386

8.396 pack_wds_GetPacketStatistics_t Struct Reference . . . 387
8.396.1 Detailed Description . . . 387
8.396.2 Field Documentation . . . 387
8.396.2.1 pStatMask . . . 387
8.397 pack_wds_GetPacketStatus_t Struct Reference . . . 387
8.397.1 Detailed Description . . . 387
8.397.2 Field Documentation . . . 388
8.397.2.1 statmask . . . 388
8.398 pack_wds_GetSessionDuration_t Struct Reference . . . 388
8.398.1 Detailed Description . . . 388
8.399 pack_wds_RMSetTransferStatistics_t Struct Reference . . . 388
8.399.1 Detailed Description . . . 388
8.399.2 Field Documentation . . . 388
8.399.2.1 RmTrasnferStaticsReq . . . 388
8.400 pack_wds_SetAutoconnect_t Struct Reference . . . 388
8.400.1 Detailed Description . . . 388
8.400.2 Field Documentation . . . 389
8.400.2.1 acroamsetting . . . 389
8.400.2.2 acsetting . . . 389
8.401 pack_wds_SetDefaultProfile_t Struct Reference . . . 389
8.401.1 Detailed Description . . . 389
8.401.2 Field Documentation . . . 390
8.401.2.1 authentication . . . 390
8.401.2.2 ipAddress . . . 390
8.401.2.3 pApnname . . . 390
8.401.2.4 pdpType . . . 390
8.401.2.5 pName . . . 390
8.401.2.6 pPassword . . . 390
8.401.2.7 primaryDNS . . . 390
8.401.2.8 profileType . . . 391
8.401.2.9 pUsername . . . 391
8.401.2.10 secondaryDNS . . . 391
8.402 pack_wds_SetDefaultProfileNum_t Struct Reference . . . 391
8.402.1 Detailed Description . . . 391
8.402.2 Field Documentation . . . 391
8.402.2.1 family . . . 391
8.402.2.2 index . . . 391
8.402.2.3 type . . . 391
8.403 pack_wds_SetMobileIP_t Struct Reference . . . 391
8.403.1 Detailed Description . . . 391

8.403.2 Field Documentation . . . 392
8.403.2.1 mode . . . 392
8.404 pack_wds_SetMobileIPParameters_t Struct Reference . . . 392
8.404.1 Detailed Description . . . 392
8.404.2 Field Documentation . . . 393
8.404.2.1 pHA2002bis . . . 393
8.404.2.2 pHAAuthenticator . . . 393
8.404.2.3 pMode . . . 393
8.404.2.4 pReRegPeriod . . . 393
8.404.2.5 pReRegTraffic . . . 393
8.404.2.6 pRetryInterval . . . 393
8.404.2.7 pRetryLimit . . . 393
8.404.2.8 pSPC . . . 393
8.405 pack_wds_SetMobileIPProfile_t Struct Reference . . . 393
8.405.1 Detailed Description . . . 394
8.405.2 Field Documentation . . . 394
8.405.2.1 index . . . 394
8.405.2.2 pAAASPI . . . 394
8.405.2.3 pAddress . . . 394
8.405.2.4 pEnabled . . . 394
8.405.2.5 pHASPI . . . 394
8.405.2.6 pMNAAA . . . 395
8.405.2.7 pMNHA . . . 395
8.405.2.8 pNAI . . . 395
8.405.2.9 pPrimaryHA . . . 395
8.405.2.10 pRevTunneling . . . 395
8.405.2.11 pSecondaryHA . . . 395
8.405.2.12 spc . . . 395
8.406 pack_wds_SLQSCreateProfile_t Struct Reference . . . 395
8.406.1 Detailed Description . . . 395
8.406.2 Field Documentation . . . 395
8.406.2.1 pCurProfile . . . 395
8.406.2.2 pProfileId . . . 396
8.406.2.3 pProfileType . . . 396
8.407 pack_wds_SLQSDeleteProfile_t Struct Reference . . . 396
8.407.1 Detailed Description . . . 396
8.407.2 Field Documentation . . . 396
8.407.2.1 profileIndex . . . 396
8.407.2.2 profileType . . . 396
8.408 pack_wds_SLQSGetCurrDataSystemStat_t Struct Reference . . . 396

8.408.1 Detailed Description . . . 396
8.409pack_wds_SLQSGetDataBearerTechnology_t Struct Reference . . . 396
8.409.1 Detailed Description . . . 396
8.410pack_wds_SLQSGetDUNCallInfo_t Struct Reference . . . 397
8.410.1 Detailed Description . . . 397
8.410.2 Field Documentation . . . 398
8.410.2.1 Mask . . . 398
8.410.2.2 pReportChannelRate . . . 398
8.410.2.3 pReportConnStatus . . . 398
8.410.2.4 pReportDataBearerTech . . . 398
8.410.2.5 pReportDormStatus . . . 398
8.410.2.6 pTransferStatInd . . . 398
8.411pack_wds_SLQSGetProfileSettings_t Struct Reference . . . 398
8.411.1 Detailed Description . . . 398
8.411.2 Field Documentation . . . 399
8.411.2.1 ProfileId . . . 399
8.411.2.2 ProfileType . . . 399
8.412pack_wds_SLQSGetRuntimeSettings_t Struct Reference . . . 399
8.412.1 Detailed Description . . . 399
8.412.2 Field Documentation . . . 400
8.412.2.1 pReqSettings . . . 400
8.413pack_wds_SLQSModifyProfile_t Struct Reference . . . 400
8.413.1 Detailed Description . . . 400
8.413.2 Field Documentation . . . 401
8.413.2.1 curProfile . . . 401
8.413.2.2 pProfileId . . . 401
8.413.2.3 pProfileType . . . 401
8.414pack_wds_SLQSSet3GPPConfigItem_t Struct Reference . . . 401
8.414.1 Detailed Description . . . 401
8.414.2 Field Documentation . . . 402
8.414.2.1 LTEAttachProfileListLen . . . 402
8.414.2.2 p3gppRelease . . . 402
8.414.2.3 pDefaultPDNEnabled . . . 402
8.414.2.4 pLTEAttachProfile . . . 402
8.414.2.5 pLTEAttachProfileList . . . 402
8.414.2.6 pProfileList . . . 403
8.415pack_wds_SLQSSetIPFamilyPreference_t Struct Reference . . . 403
8.415.1 Detailed Description . . . 403
8.415.2 Field Documentation . . . 403
8.415.2.1 IPFamilyPreference . . . 403

8.416pack_wds_SLQSSetWdsEventCallback_t Struct Reference . . . 403
8.416.1 Detailed Description . . . 403
8.416.2 Field Documentation . . . 404
8.416.2.1 currentDataBearer . . . 404
8.416.2.2 dataBearer . . . 404
8.416.2.3 dataBearerTechExt . . . 404
8.416.2.4 dataSystemStatus . . . 404
8.416.2.5 dormancyStatus . . . 404
8.416.2.6 interval . . . 404
8.416.2.7 mobileIP . . . 404
8.416.2.8 transferStats . . . 404
8.417pack_wds_SLQSSGetDHCPv4ClientConfig_t Struct Reference . . . 404
8.417.1 Detailed Description . . . 404
8.417.2 Field Documentation . . . 404
8.417.2.1 pProfileId . . . 404
8.418pack_wds_SLQSSSetDHCPv4ClientConfig_t Struct Reference . . . 404
8.418.1 Detailed Description . . . 404
8.418.2 Field Documentation . . . 405
8.418.2.1 pHwConfig . . . 405
8.418.2.2 pProfileId . . . 405
8.418.2.3 pRequestOptionList . . . 405
8.419pack_wds_SLQSSSetLoopback_t Struct Reference . . . 405
8.419.1 Detailed Description . . . 405
8.419.2 Field Documentation . . . 405
8.419.2.1 loopbackMode . . . 405
8.419.2.2 loopbackMultiplier . . . 405
8.420pack_wds_SLQSStartDataSession_t Struct Reference . . . 405
8.420.1 Detailed Description . . . 406
8.420.2 Field Documentation . . . 406
8.420.2.1 pAuth . . . 406
8.420.2.2 pPass . . . 406
8.420.2.3 pprofileid3gpp . . . 406
8.420.2.4 pprofileid3gpp2 . . . 406
8.420.2.5 pTech . . . 406
8.420.2.6 pUser . . . 407
8.421pack_wds_SLQSStopDataSession_t Struct Reference . . . 407
8.421.1 Detailed Description . . . 407
8.421.2 Field Documentation . . . 407
8.421.2.1 psid . . . 407
8.422pack_wds_SLQSWdsSetEventReport_t Struct Reference . . . 407

8.422.1 Detailed Description . . . 407
8.422.2 Field Documentation . . . 408
8.422.2.1 pCurrChannelRateInd . . . 408
8.422.2.2 pCurrDataBearerTechInd . . . 408
8.422.2.3 pCurrPrefDataSysInd . . . 408
8.422.2.4 pDataBearerTechInd . . . 408
8.422.2.5 pDataCallStatusChangeInd . . . 408
8.422.2.6 pDataSystemStatusChangeInd . . . 409
8.422.2.7 pDormancyStatusInd . . . 409
8.422.2.8 pEVDOPageMonPerChangeInd . . . 409
8.422.2.9 pMIPStatusInd . . . 409
8.422.2.10 pTransferStatInd . . . 409
8.423 pack_wds_SLQSWdsSwiPDPRuntimeSettings_t Struct Reference . . . 409
8.423.1 Detailed Description . . . 409
8.423.2 Field Documentation . . . 409
8.423.2.1 contextId . . . 409
8.423.2.2 contextType . . . 409
8.424 PackCreateProfileOut Struct Reference . . . 409
8.424.1 Detailed Description . . . 409
8.424.2 Field Documentation . . . 410
8.424.2.1 ExtErrorCode . . . 410
8.424.2.2 ProfileIndex . . . 410
8.424.2.3 ProfileType . . . 410
8.425 packgetDyingGaspCfg Struct Reference . . . 410
8.425.1 Detailed Description . . . 410
8.425.2 Field Documentation . . . 410
8.425.2.1 pDestSMSContent . . . 410
8.425.2.2 pDestSMSNum . . . 410
8.426 packgetDyingGaspStatistics Struct Reference . . . 410
8.426.1 Detailed Description . . . 411
8.426.2 Field Documentation . . . 411
8.426.2.1 pSMSAttemptedFlag . . . 411
8.426.2.2 pTimeStamp . . . 411
8.427 PackSwiAvmsSetSettingsAPNInfo Struct Reference . . . 411
8.427.1 Detailed Description . . . 411
8.427.2 Field Documentation . . . 411
8.427.2.1 bAPNLength . . . 411
8.427.2.2 bPWDLength . . . 412
8.427.2.3 bUnameLength . . . 412
8.427.2.4 szAPN . . . 412

8.427.2.5 szPWD . . . 412
8.427.2.6 szUname . . . 412
8.428 PackSwiAvmsSetSettingsConnectionRetryTimers Struct Reference . . . 412
8.428.1 Detailed Description . . . 412
8.428.2 Field Documentation . . . 412
8.428.2.1 Timers . . . 412
8.429 PackSwiAvmsSetSettingsPeriodInfo Struct Reference . . . 413
8.429.1 Detailed Description . . . 413
8.429.2 Field Documentation . . . 413
8.429.2.1 ulMax . . . 413
8.429.2.2 ulMin . . . 413
8.430 PackSwiAVMSSettingsAPNInfo Struct Reference . . . 413
8.430.1 Detailed Description . . . 413
8.430.2 Field Documentation . . . 413
8.430.2.1 bAPNLength . . . 413
8.430.2.2 bPWDLength . . . 413
8.430.2.3 bUnameLength . . . 414
8.430.2.4 pAPN . . . 414
8.430.2.5 pPWD . . . 414
8.430.2.6 pUname . . . 414
8.431 PackSwiAVMSSettingsConnectionRetryTimers Struct Reference . . . 414
8.431.1 Detailed Description . . . 414
8.431.2 Field Documentation . . . 414
8.431.2.1 Timers . . . 414
8.432 PackSwiAVMSSettingsPeriodsInfo Struct Reference . . . 414
8.432.1 Detailed Description . . . 415
8.432.2 Field Documentation . . . 415
8.432.2.1 max . . . 415
8.432.2.2 min . . . 415
8.433 qmiSmsMessageList Struct Reference . . . 415
8.433.1 Detailed Description . . . 415
8.433.2 Field Documentation . . . 415
8.433.2.1 messageIndex . . . 415
8.433.2.2 messageTag . . . 415
8.434 qmiWDSDataBearerTechnology Struct Reference . . . 415
8.434.1 Detailed Description . . . 416
8.434.2 Field Documentation . . . 416
8.434.2.1 currentNetwork . . . 416
8.434.2.2 ratMask . . . 416
8.434.2.3 soMask . . . 416

8.435qmuxIPTable Struct Reference . . . 417
8.435.1 Field Documentation . . . 417
8.435.1.1 ipAddress . . . 417
8.435.1.2 ipv6Address . . . 417
8.435.1.3 muxID . . . 417
8.436qos_BindDataPortMuxID_t Struct Reference . . . 417
8.436.1 Detailed Description . . . 417
8.436.2 Field Documentation . . . 417
8.436.2.1 MuxID . . . 417
8.437qos_BindDataPortPeripheralEndPointID_t Struct Reference . . . 417
8.437.1 Detailed Description . . . 417
8.437.2 Field Documentation . . . 418
8.437.2.1 EndPointType . . . 418
8.437.2.2 IfaceID . . . 418
8.438qos_BindDataPortSIODataPort_t Struct Reference . . . 418
8.438.1 Detailed Description . . . 418
8.438.2 Field Documentation . . . 418
8.438.2.1 SIODataPort . . . 418
8.439RFBandInfoElements Struct Reference . . . 418
8.439.1 Detailed Description . . . 418
8.439.2 Field Documentation . . . 419
8.439.2.1 activeBandClass . . . 419
8.439.2.2 activeChannel . . . 419
8.439.2.3 radioInterface . . . 419
8.440rmTrasnferStaticsReq Struct Reference . . . 419
8.440.1 Detailed Description . . . 419
8.440.2 Field Documentation . . . 419
8.440.2.1 bResetStatistics . . . 419
8.440.2.2 ulMask . . . 420
8.441sensorData_t Struct Reference . . . 420
8.441.1 Detailed Description . . . 420
8.441.2 Field Documentation . . . 421
8.441.2.1 flags . . . 421
8.441.2.2 sensorDataLen . . . 421
8.441.2.3 timeOfFirstSample . . . 421
8.441.2.4 timeOffset . . . 421
8.441.2.5 xAxis . . . 421
8.441.2.6 yAxis . . . 421
8.441.2.7 zAxis . . . 421
8.442slot_t Struct Reference . . . 421

8.442.1 Detailed Description . . . 421
8.442.2 Field Documentation . . . 422
8.442.2.1 bICCID . . . 422
8.442.2.2 bICCIDLength . . . 422
8.442.2.3 bLogicalSlot . . . 422
8.442.2.4 uPhyCardStatus . . . 422
8.442.2.5 uPhySlotStatus . . . 422
8.443 slotInf Struct Reference . . . 422
8.443.1 Detailed Description . . . 422
8.443.2 Field Documentation . . . 423
8.443.2.1 AppStatus . . . 423
8.443.2.2 cardState . . . 424
8.443.2.3 errorState . . . 424
8.443.2.4 numApp . . . 424
8.443.2.5 upinRetries . . . 424
8.443.2.6 upinState . . . 424
8.443.2.7 upukRetries . . . 424
8.444 slots_t Struct Reference . . . 424
8.444.1 Detailed Description . . . 424
8.444.2 Field Documentation . . . 424
8.444.2.1 uimSlotStatus . . . 424
8.445 sms_BroadcastConfig Struct Reference . . . 424
8.445.1 Detailed Description . . . 424
8.445.2 Field Documentation . . . 425
8.445.2.1 fromServiceId . . . 425
8.445.2.2 selected . . . 425
8.445.2.3 toServiceId . . . 425
8.446 sms_CDMABroadcastConfig Struct Reference . . . 425
8.446.1 Detailed Description . . . 425
8.446.2 Field Documentation . . . 425
8.446.2.1 language . . . 425
8.446.2.2 selected . . . 425
8.446.2.3 serviceCategory . . . 425
8.447 sms_getIndicationReg Struct Reference . . . 425
8.447.1 Detailed Description . . . 426
8.447.2 Field Documentation . . . 426
8.447.2.1 pRegCallStatInfoEvt . . . 426
8.447.2.2 pRegTransLayerInfoEvt . . . 426
8.447.2.3 pRegTransNWRegInfoEvt . . . 426
8.448 sms_getMsgWaitingInfo Struct Reference . . . 426

8.448.1 Detailed Description . . . 427
8.448.2 Field Documentation . . . 427
8.448.2.1 msgWaitInfo . . . 427
8.448.2.2 numInstances . . . 427
8.449 sms_getTransLayerInfo Struct Reference . . . 427
8.449.1 Detailed Description . . . 427
8.449.2 Field Documentation . . . 427
8.449.2.1 pRegInd . . . 427
8.449.2.2 pTransLayerInfo . . . 428
8.450 sms_getTransNWRegInfo Struct Reference . . . 428
8.450.1 Detailed Description . . . 428
8.450.2 Field Documentation . . . 428
8.450.2.1 pRegStatus . . . 428
8.451 sms_maxStorageSizeReq Struct Reference . . . 428
8.451.1 Detailed Description . . . 428
8.451.2 Field Documentation . . . 429
8.451.2.1 pMessageMode . . . 429
8.451.2.2 storageType . . . 429
8.452 sms_maxStorageSizeResp Struct Reference . . . 429
8.452.1 Detailed Description . . . 429
8.452.2 Field Documentation . . . 429
8.452.2.1 freeSlots . . . 429
8.452.2.2 maxStorageSize . . . 429
8.453 sms_messageWaitingInfoContent Struct Reference . . . 429
8.453.1 Detailed Description . . . 429
8.453.2 Field Documentation . . . 430
8.453.2.1 activeInd . . . 430
8.453.2.2 msgCount . . . 430
8.453.2.3 msgType . . . 430
8.454 sms_msgProtocolResp Struct Reference . . . 430
8.454.1 Detailed Description . . . 430
8.454.2 Field Documentation . . . 430
8.454.2.1 msgProtocol . . . 430
8.455 sms_qaQmi3GPP2BroadcastCfgInfo Struct Reference . . . 430
8.455.1 Detailed Description . . . 431
8.455.2 Field Documentation . . . 431
8.455.2.1 activated_ind . . . 431
8.455.2.2 CDMABroadcastConfig . . . 431
8.455.2.3 num_instances . . . 431
8.456 sms_qaQmi3GPPBroadcastCfgInfo Struct Reference . . . 431

8.456.1 Detailed Description . . . 431
8.456.2 Field Documentation . . . 432
8.456.2.1 activated_ind . . . 432
8.456.2.2 broadcastConfig . . . 432
8.456.2.3 num_instances . . . 432
8.457 sms_routeEntry Struct Reference . . . 432
8.457.1 Detailed Description . . . 432
8.457.2 Field Documentation . . . 433
8.457.2.1 messageClass . . . 433
8.457.2.2 messageType . . . 433
8.457.2.3 receiptAction . . . 433
8.457.2.4 routeStorage . . . 433
8.458 sms_sendAsyncsmsParams Struct Reference . . . 433
8.458.1 Detailed Description . . . 434
8.458.2 Field Documentation . . . 435
8.458.2.1 messageFormat . . . 435
8.458.2.2 messageSize . . . 435
8.458.2.3 pFollowOnDC . . . 435
8.458.2.4 pForceOnDC . . . 435
8.458.2.5 pLinktimer . . . 435
8.458.2.6 pMessage . . . 435
8.458.2.7 pRetryMessage . . . 435
8.458.2.8 pRetryMessageId . . . 435
8.458.2.9 pServiceOption . . . 435
8.458.2.10 pSmsOnIms . . . 435
8.458.2.11 pUserData . . . 435
8.459 sms_setIndicationReg Struct Reference . . . 435
8.459.1 Detailed Description . . . 436
8.459.2 Field Documentation . . . 436
8.459.2.1 pRegCallStatInfoEvt . . . 436
8.459.2.2 pRegTransLayerInfoEvt . . . 436
8.459.2.3 pRegTransNWRegInfoEvt . . . 436
8.460 sms_setRoutesReq Struct Reference . . . 436
8.460.1 Detailed Description . . . 437
8.460.2 Field Documentation . . . 437
8.460.2.1 numOfRoutes . . . 437
8.460.2.2 pTransferStatusReport . . . 437
8.460.2.3 routeList . . . 437
8.461 sms_transLayerInfo Struct Reference . . . 437
8.461.1 Detailed Description . . . 437

8.461.2 Field Documentation . . . 437
8.461.2.1 TransCap . . . 437
8.461.2.2 TransType . . . 437
8.462 sMSCAddressInfo Struct Reference . . . 438
8.462.1 Detailed Description . . . 438
8.462.2 Field Documentation . . . 438
8.462.2.1 data . . . 438
8.462.2.2 length . . . 438
8.463 sMSCAddressTlv Struct Reference . . . 438
8.463.1 Detailed Description . . . 438
8.463.2 Field Documentation . . . 438
8.463.2.1 SMSCInfo . . . 438
8.463.2.2 TlvPresent . . . 438
8.464 sMSEtwsMessageInfo Struct Reference . . . 439
8.464.1 Detailed Description . . . 439
8.464.2 Field Documentation . . . 439
8.464.2.1 data . . . 439
8.464.2.2 length . . . 439
8.464.2.3 notificationType . . . 439
8.465 sMSEtwsMessageTlv Struct Reference . . . 439
8.465.1 Detailed Description . . . 439
8.465.2 Field Documentation . . . 440
8.465.2.1 EtwsMessageInfo . . . 440
8.465.2.2 TlvPresent . . . 440
8.466 sMSEtwsPlmnInfo Struct Reference . . . 440
8.466.1 Detailed Description . . . 440
8.466.2 Field Documentation . . . 440
8.466.2.1 mobileCountryCode . . . 440
8.466.2.2 mobileNetworkCode . . . 440
8.467 sMSMessageModeInfo Struct Reference . . . 440
8.467.1 Detailed Description . . . 440
8.467.2 Field Documentation . . . 440
8.467.2.1 messageMode . . . 440
8.468 sMSMTMessageInfo Struct Reference . . . 440
8.468.1 Detailed Description . . . 441
8.468.2 Field Documentation . . . 441
8.468.2.1 messageIndex . . . 441
8.468.2.2 storageType . . . 441
8.469 sMSOnIMSInfo Struct Reference . . . 441
8.469.1 Detailed Description . . . 441

8.469.2 Field Documentation . . . 441
8.469.2.1 smsOnIMS . . . 441
8.470 sMSOnIMSTlv Struct Reference . . . 441
8.470.1 Detailed Description . . . 441
8.470.2 Field Documentation . . . 442
8.470.2.1 IMSInfo . . . 442
8.470.2.2 TlvPresent . . . 442
8.471 sMSTransferRouteMTMessageInfo Struct Reference . . . 442
8.471.1 Detailed Description . . . 442
8.471.2 Field Documentation . . . 442
8.471.2.1 ackIndicator . . . 442
8.471.2.2 data . . . 443
8.471.2.3 format . . . 443
8.471.2.4 length . . . 443
8.471.2.5 transactionID . . . 443
8.472 swiaudio_PCMparams Struct Reference . . . 443
8.472.1 Detailed Description . . . 443
8.472.2 Field Documentation . . . 443
8.472.2.1 iFaceTab . . . 443
8.472.2.2 iFaceTabLen . . . 443
8.473 tdscdmaSigInfoExt Struct Reference . . . 443
8.473.1 Detailed Description . . . 443
8.473.2 Field Documentation . . . 444
8.473.2.1 ecio . . . 444
8.473.2.2 rscp . . . 444
8.473.2.3 rssi . . . 444
8.473.2.4 sinr . . . 444
8.474 tempData_t Struct Reference . . . 444
8.474.1 Detailed Description . . . 444
8.474.2 Field Documentation . . . 445
8.474.2.1 temperature . . . 445
8.474.2.2 temperatureDataLen . . . 445
8.474.2.3 timeOfFirstSample . . . 445
8.474.2.4 timeOffset . . . 445
8.474.2.5 timeSource . . . 445
8.475 tmd_mitigationDevList Struct Reference . . . 445
8.475.1 Detailed Description . . . 445
8.475.2 Field Documentation . . . 445
8.475.2.1 maxMitigationLevel . . . 446
8.475.2.2 mitigationDevId . . . 446

8.475.2.3 mitigationDevIdLen . . . 446
8.476 transferRouteMessageTlv Struct Reference . . . 446
8.476.1 Detailed Description . . . 446
8.476.2 Field Documentation . . . 446
8.476.2.1 TlvPresent . . . 446
8.476.2.2 TransferRouteMTMessageInfo . . . 446
8.477 uim_appStatus Struct Reference . . . 446
8.477.1 Detailed Description . . . 447
8.477.2 Field Documentation . . . 448
8.477.2.1 aidLength . . . 449
8.477.2.2 aidVal . . . 449
8.477.2.3 appState . . . 449
8.477.2.4 appType . . . 449
8.477.2.5 persoFeature . . . 449
8.477.2.6 persoRetries . . . 449
8.477.2.7 persoState . . . 449
8.477.2.8 persoUnblockRetries . . . 449
8.477.2.9 pin1Retries . . . 449
8.477.2.10 pin1State . . . 449
8.477.2.11 pin2Retries . . . 449
8.477.2.12 pin2State . . . 449
8.477.2.13 puk1Retries . . . 449
8.477.2.14 puk2Retries . . . 449
8.477.2.15 univPin . . . 449
8.478 uim_authenticateResult Struct Reference . . . 449
8.478.1 Detailed Description . . . 449
8.478.2 Field Documentation . . . 449
8.478.2.1 content . . . 449
8.478.2.2 contentLen . . . 450
8.479 uim_authenticationData Struct Reference . . . 450
8.479.1 Detailed Description . . . 450
8.479.2 Field Documentation . . . 450
8.479.2.1 context . . . 450
8.479.2.2 data . . . 450
8.479.2.3 dataLen . . . 451
8.480 uim_cardResult Struct Reference . . . 451
8.480.1 Detailed Description . . . 451
8.480.2 Field Documentation . . . 451
8.480.2.1 sw1 . . . 451
8.480.2.2 sw2 . . . 451

8.481 uim_cardStatus Struct Reference . . . 451
8.481.1 Detailed Description . . . 451
8.481.2 Field Documentation . . . 452
8.481.2.1 index1xPri . . . 452
8.481.2.2 index1xSec . . . 452
8.481.2.3 indexGwPri . . . 452
8.481.2.4 indexGwSec . . . 452
8.481.2.5 numSlot . . . 452
8.481.2.6 SlotInfo . . . 452
8.482 uim_changeUIMPIN Struct Reference . . . 452
8.482.1 Detailed Description . . . 453
8.482.2 Field Documentation . . . 453
8.482.2.1 oldPINLen . . . 453
8.482.2.2 oldPINVal . . . 453
8.482.2.3 pinID . . . 453
8.482.2.4 pinLen . . . 453
8.482.2.5 pinVal . . . 453
8.483 uim_depersonalizationInformation Struct Reference . . . 453
8.483.1 Detailed Description . . . 453
8.483.2 Field Documentation . . . 454
8.483.2.1 ckLen . . . 454
8.483.2.2 ckVal . . . 454
8.483.2.3 feature . . . 454
8.483.2.4 operation . . . 454
8.484 uim_encryptedPIN1 Struct Reference . . . 454
8.484.1 Detailed Description . . . 454
8.484.2 Field Documentation . . . 455
8.484.2.1 pin1Len . . . 455
8.484.2.2 pin1Val . . . 455
8.485 uim_fileAttributes Struct Reference . . . 455
8.485.1 Detailed Description . . . 455
8.485.2 Field Documentation . . . 458
8.485.2.1 fileID . . . 458
8.485.2.2 fileSize . . . 458
8.485.2.3 fileType . . . 458
8.485.2.4 rawLen . . . 458
8.485.2.5 rawValue . . . 458
8.485.2.6 recordCount . . . 458
8.485.2.7 recordSize . . . 458
8.485.2.8 secActivate . . . 458

8.485.2.9 secActivateMask . . . 458
8.485.2.10 secDeactivate . . . 458
8.485.2.11 secDeactivateMask . . . 458
8.485.2.12 secIncrease . . . 458
8.485.2.13 secIncreaseMask . . . 458
8.485.2.14 secRead . . . 458
8.485.2.15 secReadMask . . . 458
8.485.2.16 secWrite . . . 458
8.485.2.17 secWriteMask . . . 458
8.486 uim_fileInfo Struct Reference . . . 458
8.486.1 Detailed Description . . . 458
8.486.2 Field Documentation . . . 459
8.486.2.1 fileID . . . 459
8.486.2.2 path . . . 459
8.486.2.3 pathLen . . . 459
8.487 uim_hotSwapStatus Struct Reference . . . 459
8.487.1 Detailed Description . . . 459
8.487.2 Field Documentation . . . 459
8.487.2.1 hotSwap . . . 459
8.487.2.2 hotSwapLength . . . 459
8.488 uim_personalizationStatus Struct Reference . . . 459
8.488.1 Detailed Description . . . 460
8.488.2 Field Documentation . . . 460
8.488.2.1 feature . . . 460
8.488.2.2 numFeatures . . . 460
8.488.2.3 unblockLeft . . . 460
8.488.2.4 verifyLeft . . . 460
8.489 uim_readResult Struct Reference . . . 460
8.489.1 Detailed Description . . . 461
8.489.2 Field Documentation . . . 461
8.489.2.1 content . . . 461
8.489.2.2 contentLen . . . 461
8.490 uim_readTransparentInfo Struct Reference . . . 461
8.490.1 Detailed Description . . . 461
8.490.2 Field Documentation . . . 461
8.490.2.1 length . . . 461
8.490.2.2 offset . . . 461
8.491 uim_refreshevent Struct Reference . . . 461
8.491.1 Detailed Description . . . 462
8.491.2 Field Documentation . . . 463

8.491.2.1 aid . . . 463
8.491.2.2 aidLength . . . 463
8.491.2.3 arrfileInfo . . . 463
8.491.2.4 mode . . . 463
8.491.2.5 numOfFiles . . . 463
8.491.2.6 sessionType . . . 463
8.491.2.7 stage . . . 463
8.492 uim_registerRefresh Struct Reference . . . 463
8.492.1 Detailed Description . . . 463
8.492.2 Field Documentation . . . 464
8.492.2.1 arrfileInfo . . . 464
8.492.2.2 numFiles . . . 464
8.492.2.3 registerFlag . . . 464
8.492.2.4 voteForInit . . . 464
8.493 uim_remainingRetries Struct Reference . . . 464
8.493.1 Detailed Description . . . 464
8.493.2 Field Documentation . . . 464
8.493.2.1 unblockLeft . . . 464
8.493.2.2 verifyLeft . . . 465
8.494 uim_sessionInformation Struct Reference . . . 465
8.494.1 Detailed Description . . . 465
8.494.2 Field Documentation . . . 465
8.494.2.1 aid . . . 465
8.494.2.2 aidLength . . . 465
8.494.2.3 sessionType . . . 465
8.495 uim_setPINProtection Struct Reference . . . 465
8.495.1 Detailed Description . . . 466
8.495.2 Field Documentation . . . 466
8.495.2.1 pinID . . . 466
8.495.2.2 pinLength . . . 466
8.495.2.3 pinOperation . . . 466
8.495.2.4 pinValue . . . 466
8.496 uim_slotInfo Struct Reference . . . 466
8.496.1 Detailed Description . . . 467
8.496.2 Field Documentation . . . 468
8.496.2.1 AppStatus . . . 468
8.496.2.2 cardState . . . 468
8.496.2.3 errorState . . . 468
8.496.2.4 numApp . . . 468
8.496.2.5 upinRetries . . . 468

8.496.2.6 upinState . . . 468
8.496.2.7 upukRetries . . . 468
8.497 uim_UIMSessionInformation Struct Reference . . . 468
8.497.1 Detailed Description . . . 468
8.497.2 Field Documentation . . . 469
8.497.2.1 aid . . . 469
8.497.2.2 aidLength . . . 469
8.497.2.3 sessionType . . . 469
8.498 uim_unblockUIMPIN Struct Reference . . . 469
8.498.1 Detailed Description . . . 469
8.498.2 Field Documentation . . . 469
8.498.2.1 newPINLen . . . 469
8.498.2.2 newPINVal . . . 469
8.498.2.3 pinID . . . 469
8.498.2.4 pukLen . . . 470
8.498.2.5 pukVal . . . 470
8.499 uim_verifyUIMPIN Struct Reference . . . 470
8.499.1 Detailed Description . . . 470
8.499.2 Field Documentation . . . 470
8.499.2.1 pinID . . . 470
8.499.2.2 pinLen . . . 470
8.499.2.3 pinVal . . . 470
8.500 unpack_audio_SLQSGetAudioPathConfig_t Struct Reference . . . 470
8.500.1 Detailed Description . . . 471
8.500.2 Field Documentation . . . 472
8.500.2.1 pCodecSTGain . . . 472
8.500.2.2 pDTMFTXGain . . . 472
8.500.2.3 pECMode . . . 472
8.500.2.4 pMICGainSelect . . . 472
8.500.2.5 pNSEnable . . . 472
8.500.2.6 pRXAGCList . . . 472
8.500.2.7 pRXAVCAGCSwitch . . . 472
8.500.2.8 pRXAVCList . . . 472
8.500.2.9 pRXPCMIIRFltr . . . 472
8.500.2.10 pTXAGCList . . . 472
8.500.2.11 pTXAVCSwitch . . . 472
8.500.2.12 pTXGain . . . 472
8.500.2.13 pTXPCMIIRFltr . . . 472
8.501 unpack_audio_SLQSGetAudioProfile_t Struct Reference . . . 472
8.501.1 Detailed Description . . . 472

8.501.2 Field Documentation . . . 473
8.501.2.1 EarMute . . . 473
8.501.2.2 MicMute . . . 473
8.501.2.3 Profile . . . 473
8.501.2.4 Volume . . . 473
8.502 unpack_audio_SLQSGetAudioVolTLBConfig_t Struct Reference . . . 473
8.502.1 Detailed Description . . . 474
8.502.2 Field Documentation . . . 474
8.502.2.1 ResCode . . . 474
8.503 unpack_audio_SLQSSetAudioVolTLBConfig_t Struct Reference . . . 474
8.503.1 Detailed Description . . . 474
8.503.2 Field Documentation . . . 474
8.503.2.1 ResCode . . . 474
8.504 unpack_cat_SetCatEventCallback_ind_t Struct Reference . . . 474
8.504.1 Detailed Description . . . 474
8.504.2 Field Documentation . . . 474
8.504.2.1 CCETlv . . . 475
8.504.2.2 event_Index . . . 475
8.505 unpack_cat_SetCATEventCallback_t Struct Reference . . . 475
8.505.1 Detailed Description . . . 475
8.505.2 Field Documentation . . . 475
8.505.2.1 errorMask . . . 475
8.505.2.2 Tlvresult . . . 475
8.506 unpack_dms_GetActivationState_t Struct Reference . . . 475
8.506.1 Detailed Description . . . 476
8.506.2 Field Documentation . . . 476
8.506.2.1 state . . . 476
8.507 unpack_dms_GetBandCapability_t Struct Reference . . . 476
8.507.1 Detailed Description . . . 476
8.507.2 Field Documentation . . . 478
8.507.2.1 BandCapability . . . 478
8.507.2.2 Tlvresult . . . 478
8.508 unpack_dms_GetCrashAction_t Struct Reference . . . 478
8.508.1 Detailed Description . . . 478
8.508.2 Field Documentation . . . 478
8.508.2.1 DevCrashState . . . 478
8.508.2.2 Tlvresult . . . 478
8.509 unpack_dms_GetCustFeature_t Struct Reference . . . 478
8.509.1 Detailed Description . . . 479
8.509.2 Field Documentation . . . 480

8.509.2.1 DHCPRelayEnabled . . . 480
8.509.2.2 DisableIMSI . . . 480
8.509.2.3 GpsEnable . . . 480
8.509.2.4 GPSLPM . . . 480
8.509.2.5 GPSSel . . . 480
8.509.2.6 IPFamSupport . . . 480
8.509.2.7 IsVoiceEnabled . . . 481
8.509.2.8 RMAutoConnect . . . 481
8.509.2.9 SMSSupport . . . 481
8.509.2.10 Tlvresult . . . 481
8.510 unpack_dms_GetCustFeaturesV2_t Struct Reference . . . 481
8.510.1 Detailed Description . . . 481
8.510.2 Field Documentation . . . 481
8.510.2.1 GetCustomFeatureV2 . . . 481
8.510.2.2 Tlvresult . . . 481
8.511 unpack_dms_GetDeviceCap_t Struct Reference . . . 481
8.511.1 Detailed Description . . . 481
8.511.2 Field Documentation . . . 482
8.511.2.1 DataServiceCapability . . . 482
8.511.2.2 MaxRXChannelRate . . . 482
8.511.2.3 MaxTXChannelRate . . . 482
8.511.2.4 RadioIfaces . . . 482
8.511.2.5 RadioIfacesSize . . . 482
8.511.2.6 SimCapability . . . 482
8.511.2.7 Tlvresult . . . 482
8.512 unpack_dms_GetDeviceCapabilities_t Struct Reference . . . 482
8.512.1 Detailed Description . . . 483
8.512.2 Field Documentation . . . 483
8.512.2.1 dataServiceCaCapability . . . 483
8.512.2.2 maxRxChannelRate . . . 483
8.512.2.3 maxTxChannelRate . . . 484
8.512.2.4 RadioIfaces . . . 484
8.512.2.5 radioIfacesSize . . . 484
8.512.2.6 simCapability . . . 484
8.513 unpack_dms_GetDeviceHardwareRev_t Struct Reference . . . 484
8.513.1 Detailed Description . . . 484
8.513.2 Field Documentation . . . 484
8.513.2.1 String . . . 484
8.513.2.2 stringSize . . . 484
8.513.2.3 Tlvresult . . . 484

8.514 unpack_dms_GetDeviceMfr_t Struct Reference . . . 484
8.514.1 Detailed Description . . . 485
8.514.2 Field Documentation . . . 485
8.514.2.1 String . . . 485
8.514.2.2 stringSize . . . 485
8.514.2.3 Tlvresult . . . 485
8.515 unpack_dms_GetDeviceSerialNumbers_t Struct Reference . . . 485
8.515.1 Detailed Description . . . 485
8.515.2 Field Documentation . . . 486
8.515.2.1 esnSize . . . 486
8.515.2.2 ESNString . . . 486
8.515.2.3 imeiSize . . . 486
8.515.2.4 IMEIString . . . 486
8.515.2.5 imeiSvnSize . . . 486
8.515.2.6 ImeiSvnString . . . 486
8.515.2.7 meidSize . . . 486
8.515.2.8 MEIDString . . . 486
8.515.2.9 Tlvresult . . . 486
8.516 unpack_dms_GetFirmwareInfo_t Struct Reference . . . 486
8.516.1 Detailed Description . . . 487
8.516.2 Field Documentation . . . 488
8.516.2.1 appversion_str . . . 488
8.516.2.2 bootversion_str . . . 488
8.516.2.3 carrier_str . . . 488
8.516.2.4 cur_carr_name . . . 488
8.516.2.5 cur_carr_rev . . . 488
8.516.2.6 modelid_str . . . 488
8.516.2.7 packageid_str . . . 488
8.516.2.8 priversion_str . . . 488
8.516.2.9 sku_str . . . 488
8.516.2.10 Tlvresult . . . 488
8.517 unpack_dms_GetFirmwareRevision_t Struct Reference . . . 488
8.517.1 Detailed Description . . . 488
8.517.2 Field Documentation . . . 489
8.517.2.1 amssSize . . . 489
8.517.2.2 AMSSString . . . 489
8.517.2.3 PRIString . . . 489
8.517.2.4 Tlvresult . . . 489
8.518 unpack_dms_GetFirmwareRevisions_t Struct Reference . . . 489
8.518.1 Detailed Description . . . 489

8.518.2 Field Documentation . . . 490
8.518.2.1 amssSize . . . 490
8.518.2.2 AMSSString . . . 490
8.518.2.3 bootSize . . . 490
8.518.2.4 BootString . . . 490
8.518.2.5 priSize . . . 490
8.518.2.6 PRIString . . . 490
8.518.2.7 Tlvresult . . . 490
8.519 unpack_dms_GetFSN_t Struct Reference . . . 490
8.519.1 Detailed Description . . . 490
8.519.2 Field Documentation . . . 491
8.519.2.1 String . . . 491
8.519.2.2 Tlvresult . . . 491
8.520 unpack_dms_GetHardwareRevision_t Struct Reference . . . 491
8.520.1 Detailed Description . . . 491
8.520.2 Field Documentation . . . 491
8.520.2.1 hwVer . . . 491
8.521 unpack_dms_GetIMSI_t Struct Reference . . . 491
8.521.1 Detailed Description . . . 491
8.521.2 Field Documentation . . . 491
8.521.2.1 imsi . . . 491
8.521.2.2 Tlvresult . . . 491
8.522 unpack_dms_GetManufacturer_t Struct Reference . . . 492
8.522.1 Detailed Description . . . 492
8.522.2 Field Documentation . . . 492
8.522.2.1 manufacturer . . . 492
8.522.2.2 Tlvresult . . . 492
8.523 unpack_dms_GetModelID_t Struct Reference . . . 492
8.523.1 Detailed Description . . . 492
8.523.2 Field Documentation . . . 492
8.523.2.1 modelid . . . 492
8.523.2.2 Tlvresult . . . 492
8.524 unpack_dms_GetNetworkTime_t Struct Reference . . . 493
8.524.1 Detailed Description . . . 493
8.524.2 Field Documentation . . . 493
8.524.2.1 source . . . 493
8.524.2.2 timestamp . . . 493
8.524.2.3 Tlvresult . . . 493
8.525 unpack_dms_GetOfflineReason_t Struct Reference . . . 493
8.525.1 Detailed Description . . . 493

8.525.2 Field Documentation . . . 494
8.525.2.1 pbPlatform . . . 494
8.525.2.2 pReasonMask . . . 494
8.525.2.3 Tlvresult . . . 494
8.526 unpack_dms_GetPower_t Struct Reference . . . 494
8.526.1 Detailed Description . . . 494
8.526.2 Field Documentation . . . 495
8.526.2.1 HardwareControlledMode . . . 495
8.526.2.2 OfflineReason . . . 495
8.526.2.3 OperationMode . . . 495
8.526.2.4 Tlvresult . . . 495
8.527 unpack_dms_GetPRLVersion_t Struct Reference . . . 496
8.527.1 Detailed Description . . . 496
8.527.2 Field Documentation . . . 496
8.527.2.1 Tlvresult . . . 496
8.527.2.2 u16PRLVersion . . . 496
8.527.2.3 u8PRLPreference . . . 496
8.528 unpack_dms_GetSerialNumbers_t Struct Reference . . . 496
8.528.1 Detailed Description . . . 496
8.528.2 Field Documentation . . . 497
8.528.2.1 esn . . . 497
8.528.2.2 imei_no . . . 497
8.528.2.3 imeisv_svn . . . 497
8.528.2.4 meid . . . 497
8.529 unpack_dms_GetUSBComp_t Struct Reference . . . 497
8.529.1 Detailed Description . . . 497
8.529.2 Field Documentation . . . 499
8.529.2.1 NumSupUSBComps . . . 499
8.529.2.2 SupUSBComps . . . 499
8.529.2.3 Tlvresult . . . 499
8.529.2.4 USBComp . . . 499
8.530 unpack_dms_GetVoiceNumber_t Struct Reference . . . 499
8.530.1 Detailed Description . . . 500
8.530.2 Field Documentation . . . 500
8.530.2.1 MIN . . . 500
8.530.2.2 minSize . . . 500
8.530.2.3 Tlvresult . . . 500
8.530.2.4 VoiceNumber . . . 500
8.530.2.5 voiceNumberSize . . . 500
8.531 unpack_dms_ResetToFactoryDefaults_t Struct Reference . . . 500

8.531.1 Detailed Description . . . 500
8.531.2 Field Documentation . . . 501
8.531.2.1 TlvResult . . . 501
8.532 unpack_dms_SetActivationStatusCallback_t Struct Reference . . . 501
8.532.1 Detailed Description . . . 501
8.532.2 Field Documentation . . . 501
8.532.2.1 TlvResult . . . 501
8.533 unpack_dms_SetCrashAction_t Struct Reference . . . 501
8.533.1 Detailed Description . . . 501
8.533.2 Field Documentation . . . 501
8.533.2.1 notused . . . 501
8.534 unpack_dms_SetCustFeature_t Struct Reference . . . 501
8.534.1 Detailed Description . . . 502
8.534.2 Field Documentation . . . 502
8.534.2.1 TlvResult . . . 502
8.535 unpack_dms_SetCustFeaturesV2_t Struct Reference . . . 502
8.535.1 Detailed Description . . . 502
8.535.2 Field Documentation . . . 502
8.535.2.1 TlvResult . . . 502
8.536 unpack_dms_SetEventReport_ind_t Struct Reference . . . 502
8.536.1 Detailed Description . . . 502
8.536.2 Field Documentation . . . 503
8.536.2.1 ActivationStatusTlv . . . 503
8.536.2.2 OperatingModeTlv . . . 503
8.536.2.3 TlvResult . . . 503
8.537 unpack_dms_SetEventReport_t Struct Reference . . . 503
8.537.1 Detailed Description . . . 503
8.537.2 Field Documentation . . . 503
8.537.2.1 TlvResult . . . 503
8.538 unpack_dms_SetFirmwarePreference_t Struct Reference . . . 503
8.538.1 Detailed Description . . . 503
8.538.2 Field Documentation . . . 503
8.538.2.1 TlvResult . . . 504
8.539 unpack_dms_SetPower_t Struct Reference . . . 504
8.539.1 Detailed Description . . . 504
8.539.2 Field Documentation . . . 504
8.539.2.1 TlvResult . . . 504
8.540 unpack_dms_SetUSBComp_t Struct Reference . . . 504
8.540.1 Detailed Description . . . 504
8.540.2 Field Documentation . . . 504

8.540.2.1 TlvResult . . . 504
8.541 unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t Struct Reference . . . 504
8.541.1 Detailed Description . . . 505
8.541.2 Field Documentation . . . 505
8.541.2.1 source . . . 505
8.541.2.2 TlvResult . . . 505
8.541.2.3 type . . . 505
8.542 unpack_dms_SLQSDmsSwiGetResetInfo_t Struct Reference . . . 505
8.542.1 Detailed Description . . . 505
8.542.2 Field Documentation . . . 506
8.542.2.1 source . . . 506
8.542.2.2 TlvResult . . . 506
8.542.2.3 type . . . 506
8.543 unpack_dms_SLQSDmsSwiIndicationRegister_t Struct Reference . . . 506
8.543.1 Detailed Description . . . 506
8.543.2 Field Documentation . . . 507
8.543.2.1 TlvResult . . . 507
8.544 unpack_dms_SLQSGetBandCapability_t Struct Reference . . . 507
8.544.1 Detailed Description . . . 507
8.544.2 Field Documentation . . . 510
8.544.2.1 bandCapability . . . 510
8.544.2.2 is_LteBandCapability_Available . . . 510
8.544.2.3 is_TdsBandCapability_Available . . . 510
8.544.2.4 LteBandCapability . . . 510
8.544.2.5 TdsBandCapability . . . 510
8.545 unpack_dms_SLQSGetERIFile_t Struct Reference . . . 510
8.545.1 Detailed Description . . . 510
8.545.2 Field Documentation . . . 510
8.545.2.1 eriFile . . . 510
8.545.2.2 TlvResult . . . 510
8.546 unpack_dms_SLQSSwiClearDyingGaspStatistics_t Struct Reference . . . 510
8.546.1 Detailed Description . . . 511
8.546.2 Field Documentation . . . 511
8.546.2.1 TlvResult . . . 511
8.547 unpack_dms_SLQSSwiGetCrashInfo_t Struct Reference . . . 511
8.547.1 Detailed Description . . . 511
8.547.2 Field Documentation . . . 511
8.547.2.1 crashInfoParam . . . 511
8.547.2.2 TlvResult . . . 511
8.548 unpack_dms_SLQSSwiGetDyingGaspCfg_t Struct Reference . . . 511

8.548.1 Detailed Description . . . 512
8.548.2 Field Documentation . . . 512
8.548.2.1 pGetDyingGaspCfg . . . 512
8.548.2.2 Tlvresult . . . 512
8.549 unpack_dms_SLQSSwiGetDyingGaspStatistics_t Struct Reference . . . 512
8.549.1 Detailed Description . . . 512
8.549.2 Field Documentation . . . 512
8.549.2.1 pGetDyingGaspStatistics . . . 512
8.549.2.2 Tlvresult . . . 512
8.550 unpack_dms_SLQSSwiGetFirmwareCurr_t Struct Reference . . . 512
8.550.1 Detailed Description . . . 513
8.550.2 Field Documentation . . . 513
8.550.2.1 carrier . . . 513
8.550.2.2 fwvers . . . 513
8.550.2.3 numEntries . . . 513
8.550.2.4 pCurrImgInfo . . . 513
8.550.2.5 pkgver . . . 513
8.550.2.6 priver . . . 513
8.551 unpack_dms_SLQSSwiGetFwUpdateStatus_t Struct Reference . . . 514
8.551.1 Detailed Description . . . 514
8.551.2 Field Documentation . . . 515
8.551.2.1 imgType . . . 515
8.551.2.2 logString . . . 515
8.551.2.3 refData . . . 515
8.551.2.4 refString . . . 515
8.551.2.5 ResCode . . . 515
8.551.2.6 Tlvresult . . . 515
8.552 unpack_dms_SLQSSwiGetHostDevInfo_t Struct Reference . . . 515
8.552.1 Detailed Description . . . 515
8.552.2 Field Documentation . . . 516
8.552.2.1 manString . . . 516
8.552.2.2 modelString . . . 516
8.552.2.3 plasmaIDString . . . 516
8.552.2.4 swVerString . . . 516
8.552.2.5 Tlvresult . . . 516
8.553 unpack_dms_SLQSSwiGetOSInfo_t Struct Reference . . . 516
8.553.1 Detailed Description . . . 516
8.553.2 Field Documentation . . . 516
8.553.2.1 nameString . . . 517
8.553.2.2 Tlvresult . . . 517

8.553.2.3 versionString . . . 517
8.554 unpack_dms_SLQSSwiGetSerialNoExt_t Struct Reference . . . 517
8.554.1 Detailed Description . . . 517
8.554.2 Field Documentation . . . 517
8.554.2.1 meidString . . . 517
8.554.2.2 TlvResult . . . 517
8.555 unpack_dms_SLQSSwiSetDyingGaspCfg_t Struct Reference . . . 517
8.555.1 Detailed Description . . . 517
8.555.2 Field Documentation . . . 517
8.555.2.1 TlvResult . . . 518
8.556 unpack_dms_SLQSSwiSetHostDevInfo_t Struct Reference . . . 518
8.556.1 Detailed Description . . . 518
8.556.2 Field Documentation . . . 518
8.556.2.1 TlvResult . . . 518
8.557 unpack_dms_SLQSSwiSetOSInfo_t Struct Reference . . . 518
8.557.1 Detailed Description . . . 518
8.557.2 Field Documentation . . . 518
8.557.2.1 TlvResult . . . 518
8.558 unpack_dms_SLQSUIMGetState_t Struct Reference . . . 518
8.558.1 Detailed Description . . . 519
8.558.2 Field Documentation . . . 519
8.558.2.1 state . . . 519
8.558.2.2 TlvResult . . . 519
8.559 unpack_dms_UIMGetControlKeyStatus_t Struct Reference . . . 519
8.559.1 Detailed Description . . . 519
8.559.2 Field Documentation . . . 520
8.559.2.1 facilityState . . . 520
8.559.2.2 TlvResult . . . 520
8.559.2.3 unblockRetriesLeft . . . 520
8.559.2.4 verifyRetriesLeft . . . 520
8.560 unpack_dms_UIMGetICCID_t Struct Reference . . . 520
8.560.1 Detailed Description . . . 520
8.560.2 Field Documentation . . . 520
8.560.2.1 String . . . 520
8.560.2.2 stringSize . . . 520
8.560.2.3 TlvResult . . . 520
8.561 unpack_dms_UIMGetPINStatus_t Struct Reference . . . 520
8.561.1 Detailed Description . . . 521
8.561.2 Field Documentation . . . 522
8.561.2.1 p1Status . . . 522

8.561.2.2 p1UnblockRetriesLeft . . . 522
8.561.2.3 p1VerifyRetriesLeft . . . 522
8.561.2.4 p2Status . . . 522
8.561.2.5 p2UnblockRetriesLeft . . . 522
8.561.2.6 p2VerifyRetriesLeft . . . 522
8.561.2.7 TlvResult . . . 522
8.562 unpack_dms_UIMSetControlKeyProtection_t Struct Reference . . . 522
8.562.1 Detailed Description . . . 522
8.562.2 Field Documentation . . . 522
8.562.2.1 TlvResult . . . 522
8.562.2.2 verifyRetriesLeft . . . 522
8.563 unpack_dms_UIMSetPINProtection_t Struct Reference . . . 522
8.563.1 Detailed Description . . . 523
8.563.2 Field Documentation . . . 523
8.563.2.1 TlvResult . . . 523
8.563.2.2 unblockRetriesLeft . . . 523
8.563.2.3 verifyRetriesLeft . . . 523
8.564 unpack_dms_UIMUnblockControlKey_t Struct Reference . . . 523
8.564.1 Detailed Description . . . 523
8.564.2 Field Documentation . . . 524
8.564.2.1 TlvResult . . . 524
8.564.2.2 unblockRetriesLeft . . . 524
8.565 unpack_fms_GetImagesPreference_t Struct Reference . . . 524
8.565.1 Detailed Description . . . 524
8.565.2 Field Documentation . . . 524
8.565.2.1 ImageListSize . . . 524
8.565.2.2 pImageList . . . 524
8.565.2.3 TlvResult . . . 524
8.566 unpack_fms_GetStoredImages_t Struct Reference . . . 524
8.566.1 Detailed Description . . . 524
8.566.2 Field Documentation . . . 525
8.566.2.1 imageList . . . 525
8.566.2.2 imagelistSize . . . 525
8.566.2.3 TlvResult . . . 525
8.567 unpack_fms_SetImagesPreference_t Struct Reference . . . 525
8.567.1 Detailed Description . . . 525
8.567.2 Field Documentation . . . 525
8.567.2.1 ImageTypes . . . 525
8.567.2.2 ImageTypesSize . . . 525
8.567.2.3 TlvResult . . . 525

8.568 unpack_ims_SLQSGetIMSSMSConfig_t Struct Reference . . . 526
8.568.1 Detailed Description . . . 526
8.568.2 Field Documentation . . . 526
8.568.2.1 pPhoneCtxtURI . . . 526
8.568.2.2 pPhoneCtxtURILen . . . 526
8.568.2.3 pSettingResp . . . 526
8.568.2.4 pSMSFormat . . . 526
8.568.2.5 pSMSOverIPNwInd . . . 526
8.569 unpack_ims_SLQSGetIMSUserConfig_t Struct Reference . . . 526
8.569.1 Detailed Description . . . 527
8.569.2 Field Documentation . . . 527
8.569.2.1 pIMSDomain . . . 527
8.569.2.2 pIMSDomainLen . . . 527
8.569.2.3 pSettingResp . . . 527
8.570 unpack_ims_SLQSGetIMSVoIPConfig_t Struct Reference . . . 527
8.570.1 Detailed Description . . . 527
8.570.2 Field Documentation . . . 529
8.570.2.1 pAmrMode . . . 529
8.570.2.2 pAmrOctetAligned . . . 529
8.570.2.3 pAmrWbEnable . . . 529
8.570.2.4 pAmrWBMode . . . 529
8.570.2.5 pAmrWBOctetAligned . . . 529
8.570.2.6 pMinSessionExpiryTimer . . . 529
8.570.2.7 pRingBackTimer . . . 530
8.570.2.8 pRingingTimer . . . 530
8.570.2.9 pRTPRTCPInactTimer . . . 530
8.570.2.10 pScrAmrEnable . . . 530
8.570.2.11 pScrAmrWbEnable . . . 530
8.570.2.12 pSessionExpiryTimer . . . 530
8.570.2.13 pSettingResp . . . 530
8.571 unpack_ims_SLQSGetRegMgrConfig_t Struct Reference . . . 530
8.571.1 Detailed Description . . . 530
8.571.2 Field Documentation . . . 530
8.571.2.1 pIMSTestMode . . . 531
8.571.2.2 pPCSCFPort . . . 531
8.571.2.3 pPriCSCFPortName . . . 531
8.571.2.4 pPriCSCFPortNameLen . . . 531
8.571.2.5 pSettingResp . . . 531
8.572 unpack_ims_SLQSGetSIPConfig_t Struct Reference . . . 531
8.572.1 Detailed Description . . . 531

8.572.2 Field Documentation . . . 532
8.572.2.1 pSettingResp . . . 532
8.572.2.2 pSigCompEnabled . . . 532
8.572.2.3 pSIPLocalPort . . . 532
8.572.2.4 pSubscribeTimer . . . 532
8.572.2.5 pTimerSIPReg . . . 532
8.572.2.6 pTimerT1 . . . 532
8.572.2.7 pTimerT2 . . . 532
8.572.2.8 pTimerTf . . . 532
8.573 unpack_ims_SLQSSetIMSSMSConfig_t Struct Reference . . . 532
8.573.1 Detailed Description . . . 532
8.573.2 Field Documentation . . . 532
8.573.2.1 pSettingResp . . . 532
8.574 unpack_ims_SLQSSetIMSUserConfig_t Struct Reference . . . 532
8.574.1 Detailed Description . . . 532
8.574.2 Field Documentation . . . 533
8.574.2.1 pSettingResp . . . 533
8.575 unpack_ims_SLQSSetIMSVoIPConfig_t Struct Reference . . . 533
8.575.1 Detailed Description . . . 533
8.575.2 Field Documentation . . . 533
8.575.2.1 pSettingResp . . . 533
8.576 unpack_ims_SLQSSetRegMgrConfig_t Struct Reference . . . 533
8.576.1 Detailed Description . . . 533
8.576.2 Field Documentation . . . 533
8.576.2.1 pSettingResp . . . 533
8.577 unpack_ims_SLQSSetSIPConfig_t Struct Reference . . . 534
8.577.1 Detailed Description . . . 534
8.577.2 Field Documentation . . . 534
8.577.2.1 pSettingResp . . . 534
8.578 unpack_imsa_SLQSGetIMSARegStatus_t Struct Reference . . . 534
8.578.1 Detailed Description . . . 534
8.578.2 Field Documentation . . . 535
8.578.2.1 ImsRegErrCode . . . 535
8.578.2.2 ImsRegStatus . . . 535
8.578.2.3 NewImsRegStatus . . . 535
8.579 unpack_imsa_SLQSGetIMSAServiceStatus_t Struct Reference . . . 535
8.579.1 Detailed Description . . . 535
8.579.2 Field Documentation . . . 537
8.579.2.1 SmsServiceRat . . . 537
8.579.2.2 SmsServiceStatus . . . 537

8.579.2.3 UtServiceRat . . . 537
8.579.2.4 UtServiceStatus . . . 537
8.579.2.5 VoipServiceRat . . . 537
8.579.2.6 VoipServiceStatus . . . 537
8.579.2.7 VsServiceRat . . . 537
8.579.2.8 VsServiceStatus . . . 537
8.579.2.9 VtServiceRat . . . 537
8.579.2.10 VtServiceStatus . . . 537
8.580 unpack_loc_BestAvailPos_Ind_t Struct Reference . . . 537
8.580.1 Detailed Description . . . 538
8.580.2 Field Documentation . . . 542
8.580.2.1 pAltitudeWrtEllipsoid . . . 542
8.580.2.2 pAltitudeWrtMeanSeaLevel . . . 542
8.580.2.3 pGpsTime . . . 542
8.580.2.4 pHeading . . . 542
8.580.2.5 pHeadingUnc . . . 542
8.580.2.6 pHorCirConf . . . 542
8.580.2.7 pHorEllpConf . . . 542
8.580.2.8 pHorReliability . . . 542
8.580.2.9 pHorUncCircular . . . 542
8.580.2.10 pHorUncEllipseOrientAzimuth . . . 542
8.580.2.11 pHorUncEllipseSemiMajor . . . 542
8.580.2.12 pHorUncEllipseSemiMinor . . . 543
8.580.2.13 pLatitude . . . 543
8.580.2.14 pLongitude . . . 543
8.580.2.15 pMagneticDeviation . . . 543
8.580.2.16 pPrecisionDilution . . . 543
8.580.2.17 pSensorDataUsage . . . 543
8.580.2.18 pSpeedHorizontal . . . 543
8.580.2.19 pSpeedUnc . . . 543
8.580.2.20 pSpeedVertical . . . 543
8.580.2.21 pSpeedVerticalUnc . . . 543
8.580.2.22 pSvUsedforFix . . . 543
8.580.2.23 pTechnologyMask . . . 543
8.580.2.24 pTimeSrc . . . 543
8.580.2.25 pTimestampUtc . . . 543
8.580.2.26 pTimeUnc . . . 543
8.580.2.27 pVertConfidence . . . 543
8.580.2.28 pVertReliability . . . 543
8.580.2.29 pVertUnc . . . 543

8.580.2.30 pXid . . . 543
8.580.2.31 status . . . 543
8.580.2.32 TlvResult . . . 543
8.581 unpack_loc_Delete_Assist_Data_t Struct Reference . . . 543
8.581.1 Detailed Description . . . 543
8.581.2 Field Documentation . . . 544
8.581.2.1 TlvResult . . . 544
8.582 unpack_loc_DeleteAssistData_Ind_t Struct Reference . . . 544
8.582.1 Detailed Description . . . 544
8.582.2 Field Documentation . . . 544
8.582.2.1 status . . . 544
8.582.2.2 TlvResult . . . 545
8.583 unpack_loc_EngineState_Ind_t Struct Reference . . . 545
8.583.1 Detailed Description . . . 545
8.583.2 Field Documentation . . . 545
8.583.2.1 engineState . . . 545
8.583.2.2 TlvResult . . . 545
8.584 unpack_loc_EventNMEA_Ind_t Struct Reference . . . 545
8.584.1 Detailed Description . . . 545
8.584.2 Field Documentation . . . 546
8.584.2.1 NMEAData . . . 546
8.584.2.2 TlvResult . . . 546
8.585 unpack_loc_EventRegister_t Struct Reference . . . 546
8.585.1 Detailed Description . . . 546
8.585.2 Field Documentation . . . 546
8.585.2.1 TlvResult . . . 546
8.586 unpack_loc_GetServer_Ind_t Struct Reference . . . 546
8.586.1 Detailed Description . . . 546
8.586.2 Field Documentation . . . 547
8.586.2.1 pIPv4AddrInfo . . . 547
8.586.2.2 pIPv6AddrInfo . . . 547
8.586.2.3 pURL . . . 547
8.586.2.4 serverStatus . . . 547
8.586.2.5 serverType . . . 547
8.586.2.6 TlvResult . . . 548
8.587 unpack_loc_GnssSvInfo_Ind_t Struct Reference . . . 548
8.587.1 Detailed Description . . . 548
8.587.2 Field Documentation . . . 548
8.587.2.1 altitudeAssumed . . . 548
8.587.2.2 pSatelliteInfo . . . 548

8.587.2.3 TlvResult . . . 548
8.588 unpack_loc_PositionRpt_Ind_t Struct Reference . . . 548
8.588.1 Detailed Description . . . 549
8.588.2 Field Documentation . . . 554
8.588.2.1 pAltitudeAssumed . . . 554
8.588.2.2 pAltitudeWrtEllipsoid . . . 554
8.588.2.3 pAltitudeWrtMeanSeaLevel . . . 554
8.588.2.4 pFixId . . . 554
8.588.2.5 pGpsTime . . . 554
8.588.2.6 pHeading . . . 554
8.588.2.7 pHeadingUnc . . . 554
8.588.2.8 pHorConfidence . . . 554
8.588.2.9 pHorReliability . . . 554
8.588.2.10 pHorUncCircular . . . 554
8.588.2.11 pHorUncEllipseOrientAzimuth . . . 554
8.588.2.12 pHorUncEllipseSemiMajor . . . 554
8.588.2.13 pHorUncEllipseSemiMinor . . . 554
8.588.2.14 pLatitude . . . 554
8.588.2.15 pLeapSeconds . . . 554
8.588.2.16 pLongitude . . . 554
8.588.2.17 pMagneticDeviation . . . 554
8.588.2.18 pPrecisionDilution . . . 554
8.588.2.19 pSensorDataUsage . . . 554
8.588.2.20 pSpeedHorizontal . . . 554
8.588.2.21 pSpeedUnc . . . 554
8.588.2.22 pSpeedVertical . . . 554
8.588.2.23 pSvUsedforFix . . . 554
8.588.2.24 pTechnologyMask . . . 554
8.588.2.25 pTimeSrc . . . 554
8.588.2.26 pTimestampUtc . . . 555
8.588.2.27 pTimeUnc . . . 555
8.588.2.28 pVertConfidence . . . 555
8.588.2.29 pVertReliability . . . 555
8.588.2.30 pVertUnc . . . 555
8.588.2.31 sessionId . . . 555
8.588.2.32 sessionStatus . . . 555
8.588.2.33 TlvResult . . . 555
8.589 unpack_loc_SetExtPowerConfig_Ind_t Struct Reference . . . 555
8.589.1 Detailed Description . . . 555
8.589.2 Field Documentation . . . 555

8.589.2.1 status . . . 555
8.589.2.2 TlvResult . . . 556
8.590 unpack_loc_SetExtPowerState_t Struct Reference . . . 556
8.590.1 Detailed Description . . . 556
8.590.2 Field Documentation . . . 556
8.590.2.1 TlvResult . . . 556
8.591 unpack_loc_SetOperationMode_Ind_t Struct Reference . . . 556
8.591.1 Detailed Description . . . 556
8.591.2 Field Documentation . . . 557
8.591.2.1 status . . . 557
8.591.2.2 TlvResult . . . 557
8.592 unpack_loc_SetOperationMode_t Struct Reference . . . 557
8.592.1 Detailed Description . . . 557
8.592.2 Field Documentation . . . 557
8.592.2.1 TlvResult . . . 557
8.593 unpack_loc_SLQSLOCGetBestAvailPos_t Struct Reference . . . 557
8.593.1 Detailed Description . . . 557
8.593.2 Field Documentation . . . 557
8.593.2.1 TlvResult . . . 557
8.594 unpack_loc_Start_t Struct Reference . . . 558
8.594.1 Detailed Description . . . 558
8.594.2 Field Documentation . . . 558
8.594.2.1 TlvResult . . . 558
8.595 unpack_loc_Stop_t Struct Reference . . . 558
8.595.1 Detailed Description . . . 558
8.595.2 Field Documentation . . . 558
8.595.2.1 TlvResult . . . 558
8.596 unpack_nas_GetCDMANetworkParameters_t Struct Reference . . . 558
8.596.1 Detailed Description . . . 559
8.596.2 Field Documentation . . . 560
8.596.2.1 Application . . . 560
8.596.2.2 Broadcast . . . 560
8.596.2.3 CustomSCP . . . 560
8.596.2.4 ForceRev0 . . . 560
8.596.2.5 Protocol . . . 560
8.596.2.6 RegForeignNID . . . 560
8.596.2.7 RegForeignSID . . . 560
8.596.2.8 RegHomeSID . . . 560
8.596.2.9 Roaming . . . 560
8.596.2.10 SCI . . . 561

8.596.2.11 SCM . . . 561
8.597 unpack_nas_GetHomeNetwork3GPP2_t Struct Reference . . . 561
8.597.1 Detailed Description . . . 561
8.597.2 Field Documentation . . . 562
8.597.2.1 nameSize . . . 562
8.597.2.2 pMCC . . . 562
8.597.2.3 pMNC . . . 562
8.597.2.4 pName . . . 562
8.597.2.5 pNID . . . 563
8.597.2.6 pNw2DescDisp . . . 563
8.597.2.7 pNw2DescEnc . . . 563
8.597.2.8 pNw2DescLen . . . 563
8.597.2.9 pNw2MCC . . . 563
8.597.2.10 pNw2MNC . . . 563
8.597.2.11 pNw2Name . . . 563
8.597.2.12 pSID . . . 563
8.598 unpack_nas_GetHomeNetwork_t Struct Reference . . . 563
8.598.1 Detailed Description . . . 563
8.598.2 Field Documentation . . . 564
8.598.2.1 mcc . . . 564
8.598.2.2 mnc . . . 564
8.598.2.3 name . . . 564
8.598.2.4 nid . . . 564
8.598.2.5 sid . . . 564
8.599 unpack_nas_GetNetworkPreference_t Struct Reference . . . 564
8.599.1 Detailed Description . . . 564
8.599.2 Field Documentation . . . 565
8.599.2.1 ActiveTechPref . . . 565
8.599.2.2 Duration . . . 565
8.599.2.3 PersistentTechPref . . . 565
8.599.2.4 Tlvresult . . . 565
8.600 unpack_nas_GetRFInfo_t Struct Reference . . . 565
8.600.1 Detailed Description . . . 565
8.600.2 Field Documentation . . . 566
8.600.2.1 instancesSize . . . 566
8.600.2.2 RFBandInfoElements . . . 566
8.601 unpack_nas_GetServingNetwork_t Struct Reference . . . 566
8.601.1 Detailed Description . . . 566
8.601.2 Field Documentation . . . 568
8.601.2.1 CSDomain . . . 568

8.601.2.2 DataCaps . . . 568
8.601.2.3 DataCapsLen . . . 568
8.601.2.4 MCC . . . 568
8.601.2.5 MNC . . . 568
8.601.2.6 Name . . . 568
8.601.2.7 nameSize . . . 568
8.601.2.8 PSDomain . . . 568
8.601.2.9 RadioIfaces . . . 568
8.601.2.10 RadioIfacesSize . . . 568
8.601.2.11 RAN . . . 568
8.601.2.12 RegistrationState . . . 568
8.601.2.13 Roaming . . . 568
8.602 unpack_nas_GetServingNetworkCapabilities_t Struct Reference . . . 568
8.602.1 Detailed Description . . . 569
8.602.2 Field Documentation . . . 569
8.602.2.1 DataCaps . . . 569
8.602.2.2 DataCapsLen . . . 569
8.603 unpack_nas_GetSignalStrengths_t Struct Reference . . . 569
8.603.1 Detailed Description . . . 569
8.603.2 Field Documentation . . . 569
8.603.2.1 len . . . 570
8.603.2.2 radio . . . 570
8.603.2.3 rssi . . . 570
8.604 unpack_nas_PerformNetworkScan_t Struct Reference . . . 570
8.604.1 Detailed Description . . . 570
8.604.2 Field Documentation . . . 571
8.604.2.1 p3GppNetworkInfoInstances . . . 571
8.604.2.2 p3GppNetworkInstanceSize . . . 571
8.604.2.3 pPCSInstance . . . 571
8.604.2.4 pPCSInstanceSize . . . 571
8.604.2.5 pRATINstance . . . 571
8.604.2.6 pRATInstanceSize . . . 571
8.604.2.7 pScanResult . . . 571
8.605 unpack_nas_SetDataCapabilitiesCallback_ind_t Struct Reference . . . 571
8.605.1 Detailed Description . . . 571
8.605.2 Field Documentation . . . 571
8.605.2.1 dataCaps . . . 571
8.605.2.2 dataCapsSize . . . 571
8.606 unpack_nas_SetEventReportInd_t Struct Reference . . . 571
8.606.1 Detailed Description . . . 571

8.606.2 Field Documentation . . . 572
8.606.2.1 RFTlv . . . 572
8.606.2.2 RRTlv . . . 572
8.606.2.3 SLQSSSTlv . . . 572
8.606.2.4 SSTlv . . . 572
8.607 unpack_nas_SetNasLTECphyCaIndCallback_ind_t Struct Reference . . . 572
8.607.1 Detailed Description . . . 572
8.607.2 Field Documentation . . . 572
8.607.2.1 sPhyCaAggPcellInfo . . . 572
8.607.2.2 sPhyCaAggScellDlBw . . . 573
8.607.2.3 sPhyCaAggScellIndex . . . 573
8.607.2.4 sPhyCaAggScellIndType . . . 573
8.607.2.5 sPhyCaAggScellInfo . . . 573
8.608 unpack_nas_SetNetworkPreference_t Struct Reference . . . 573
8.608.1 Detailed Description . . . 573
8.608.2 Field Documentation . . . 573
8.608.2.1 Tlvresult . . . 573
8.609 unpack_nas_SetRoamingIndicatorCallback_ind_t Struct Reference . . . 573
8.609.1 Detailed Description . . . 573
8.609.2 Field Documentation . . . 573
8.609.2.1 roaming . . . 573
8.610 unpack_nas_SetServingSystemCallback_ind_t Struct Reference . . . 574
8.610.1 Detailed Description . . . 574
8.610.2 Field Documentation . . . 574
8.610.2.1 SSInfo . . . 574
8.610.2.2 Tlvresult . . . 574
8.611 unpack_nas_SLQSGetErrorRate_t Struct Reference . . . 574
8.611.1 Detailed Description . . . 574
8.611.2 Field Documentation . . . 575
8.611.2.1 pCDMAFrameErrRate . . . 575
8.611.2.2 pGSMBER . . . 575
8.611.2.3 pHDRPackErrRate . . . 575
8.611.2.4 pWCDMABER . . . 575
8.612 unpack_nas_SlqsGetLTECphyCAInfo_t Struct Reference . . . 575
8.612.1 Detailed Description . . . 575
8.612.2 Field Documentation . . . 576
8.612.2.1 LTECphyCaInfo . . . 576
8.612.2.2 Tlvresult . . . 576
8.613 unpack_nas_SLQSGetNetworkTime_t Struct Reference . . . 576
8.613.1 Detailed Description . . . 576

8.613.2 Field Documentation . . . 576
8.613.2.1 p3GPP2TimeInfo . . . 576
8.613.2.2 p3GPPTimeInfo . . . 576
8.614 unpack_nas_SLQSGetOperatorNameData_t Struct Reference . . . 576
8.614.1 Detailed Description . . . 576
8.614.2 Field Documentation . . . 577
8.614.2.1 pNITZInformation . . . 577
8.614.2.2 pOperatorNameString . . . 577
8.614.2.3 pOperatorPLMNList . . . 577
8.614.2.4 pPLMNNetworkName . . . 577
8.614.2.5 pSrvcProviderName . . . 577
8.615 unpack_nas_SLQSGetPLMNName_t Struct Reference . . . 577
8.615.1 Detailed Description . . . 578
8.615.2 Field Documentation . . . 579
8.615.2.1 longName . . . 579
8.615.2.2 longNameCI . . . 579
8.615.2.3 longNameEn . . . 579
8.615.2.4 longNameLen . . . 579
8.615.2.5 longNameSB . . . 579
8.615.2.6 shortName . . . 579
8.615.2.7 shortNameCI . . . 580
8.615.2.8 shortNameEn . . . 580
8.615.2.9 shortNameLen . . . 580
8.615.2.10 shortNameSB . . . 580
8.615.2.11 spn . . . 580
8.615.2.12 spnEncoding . . . 580
8.615.2.13 spnLength . . . 580
8.616 unpack_nas_SLQSGetServingSystem_t Struct Reference . . . 580
8.616.1 Detailed Description . . . 580
8.616.2 Field Documentation . . . 583
8.616.2.1 BasestationID . . . 583
8.616.2.2 BasestationLatitude . . . 583
8.616.2.3 BasestationLongitude . . . 583
8.616.2.4 CallBarStatus . . . 583
8.616.2.5 CDMA_P_Rev . . . 583
8.616.2.6 CDMASystemInfoExt . . . 583
8.616.2.7 CellID . . . 583
8.616.2.8 ConcSvcInfo . . . 583
8.616.2.9 CurrentPLMN . . . 583
8.616.2.10 DataSrvCapabilities . . . 583

8.616.2.11 DefaultRoamInd . . . 583
8.616.2.12 DetailedSvcInfo . . . 583
8.616.2.13 DTMInd . . . 583
8.616.2.14 Gpp2TimeZone . . . 583
8.616.2.15 GppNetworkDSTAdjustment . . . 583
8.616.2.16 GppTimeZone . . . 583
8.616.2.17 HdrPersonality . . . 583
8.616.2.18 Lac . . . 583
8.616.2.19 NetworkID . . . 584
8.616.2.20 PRLInd . . . 584
8.616.2.21 RoamIndicatorVal . . . 584
8.616.2.22 RoamingIndicatorList . . . 584
8.616.2.23 ServingSystem . . . 584
8.616.2.24 SystemID . . . 584
8.616.2.25 TrackAreaCode . . . 584
8.617 unpack_nas_SLQSGetSignalStrength_t Struct Reference . . . 584
8.617.1 Detailed Description . . . 584
8.617.2 Field Documentation . . . 586
8.617.2.1 ecioList . . . 586
8.617.2.2 ecioListLen . . . 586
8.617.2.3 errorRateList . . . 586
8.617.2.4 errorRateListLen . . . 586
8.617.2.5 Io . . . 586
8.617.2.6 ltersrp . . . 586
8.617.2.7 ltesnr . . . 586
8.617.2.8 rsrqInfo . . . 586
8.617.2.9 rxSignalStrengthList . . . 586
8.617.2.10 rxSignalStrengthListLen . . . 586
8.617.2.11 signalStrengthReqMask . . . 586
8.617.2.12 sinr . . . 586
8.618 unpack_nas_SLQSGetSysInfo_t Struct Reference . . . 586
8.618.1 Detailed Description . . . 587
8.618.2 Field Documentation . . . 589
8.618.2.1 pAddCDMASysInfo . . . 589
8.618.2.2 pAddGSMSysInfo . . . 589
8.618.2.3 pAddHDRSysInfo . . . 589
8.618.2.4 pAddLTESysInfo . . . 589
8.618.2.5 pAddWCDMASysInfo . . . 589
8.618.2.6 pCDMASrvStatusInfo . . . 589
8.618.2.7 pCDMASysInfo . . . 589

8.618.2.8 pGSMCallBarringSysInfo . . . 589
8.618.2.9 pGSMCipherDomainSysInfo . . . 589
8.618.2.10 pGSMSrvStatusInfo . . . 589
8.618.2.11 pGSMSysInfo . . . 589
8.618.2.12 pHDRSrvStatusInfo . . . 589
8.618.2.13 pHDRSysInfo . . . 589
8.618.2.14 pLTESrvStatusInfo . . . 589
8.618.2.15 pLTESysInfo . . . 589
8.618.2.16 pLTEVoiceSupportSysInfo . . . 589
8.618.2.17 pWCDMACallBarringSysInfo . . . 589
8.618.2.18 pWCDMACipherDomainSysInfo . . . 590
8.618.2.19 pWCDMASrvStatusInfo . . . 590
8.618.2.20 pWCDMASysInfo . . . 590
8.619 unpack_nas_SLQSGetSysSelectionPref_t Struct Reference . . . 590
8.619.1 Detailed Description . . . 590
8.619.2 Field Documentation . . . 594
8.619.2.1 pBandPref . . . 594
8.619.2.2 pEmerMode . . . 594
8.619.2.3 pGWAcqOrderPref . . . 594
8.619.2.4 pLTEBandPref . . . 594
8.619.2.5 pModePref . . . 594
8.619.2.6 pNetSelPref . . . 594
8.619.2.7 pPRLPref . . . 594
8.619.2.8 pRoamPref . . . 594
8.619.2.9 pSrvDomainPref . . . 594
8.620 unpack_nas_SLQSNasGet3GPP2Subscription_t Struct Reference . . . 594
8.620.1 Detailed Description . . . 595
8.620.2 Field Documentation . . . 595
8.620.2.1 pCDMAChannel . . . 595
8.620.2.2 pDirNum . . . 595
8.620.2.3 pHomeSIDNID . . . 595
8.620.2.4 pMinBasedIMSI . . . 595
8.620.2.5 pNAMNameInfo . . . 595
8.620.2.6 pTrueIMSI . . . 595
8.621 unpack_nas_SLQSNasGetCellLocationInfo_t Struct Reference . . . 595
8.621.1 Detailed Description . . . 596
8.621.2 Field Documentation . . . 596
8.621.2.1 pCDMAInfo . . . 596
8.621.2.2 pGERANInfo . . . 597
8.621.2.3 pLTEInfoInterfreq . . . 597

8.621.2.4 pLTEInfoIntrafreq . . . 597
8.621.2.5 pLTEInfoNeighboringGSM . . . 597
8.621.2.6 pLTEInfoNeighboringWCDMA . . . 597
8.621.2.7 pUMTSCellID . . . 597
8.621.2.8 pUMTSInfo . . . 597
8.621.2.9 pWCDMAInfoLTENeighborCell . . . 597
8.622 unpack_nas_SLQSNASGeteDRXParams_t Struct Reference . . . 597
8.622.1 Detailed Description . . . 597
8.622.2 Field Documentation . . . 597
8.622.2.1 pCycleLen . . . 597
8.622.2.2 pEdrxEnable . . . 597
8.622.2.3 pPagingTimeWindow . . . 597
8.623 unpack_nas_SLQSNasGetHDRColorCode_t Struct Reference . . . 598
8.623.1 Detailed Description . . . 598
8.623.2 Field Documentation . . . 598
8.623.2.1 pColorCode . . . 598
8.624 unpack_nas_SLQSNasGetSigInfo_t Struct Reference . . . 598
8.624.1 Detailed Description . . . 598
8.624.2 Field Documentation . . . 599
8.624.2.1 CDMASSInfo . . . 599
8.624.2.2 GSMSSInfo . . . 599
8.624.2.3 HDRSSInfo . . . 599
8.624.2.4 LTESSInfo . . . 599
8.624.2.5 WCDMASSInfo . . . 599
8.625 unpack_nas_SLQSNasGetTxRxInfo_t Struct Reference . . . 599
8.625.1 Detailed Description . . . 599
8.625.2 Field Documentation . . . 599
8.625.2.1 pRXChain0Info . . . 599
8.625.2.2 pRXChain1Info . . . 599
8.625.2.3 pTXInfo . . . 599
8.626 unpack_nas_SLQSNasNetworkTimeCallBack_ind_t Struct Reference . . . 600
8.626.1 Detailed Description . . . 600
8.626.2 Field Documentation . . . 600
8.626.2.1 pDayltSavAdj . . . 600
8.626.2.2 pRadioInterface . . . 600
8.626.2.3 pTimeZone . . . 600
8.626.2.4 universalTime . . . 600
8.627 unpack_nas_SLQSNasSigInfoCallback_ind_t Struct Reference . . . 601
8.627.1 Detailed Description . . . 601
8.627.2 Field Documentation . . . 601

8.627.2.1 pCDMASigInfo . . . 601
8.627.2.2 pGSMSigInfo . . . 602
8.627.2.3 pHDRSigInfo . . . 602
8.627.2.4 pLTESigInfo . . . 602
8.627.2.5 pRscp . . . 602
8.627.2.6 pTDSCDMASigInfoExt . . . 602
8.627.2.7 pWCDMASigInfo . . . 602
8.628 unpack_nas_SLQSNASSwiGetChannelLock_t Struct Reference . . . 602
8.628.1 Detailed Description . . . 602
8.628.2 Field Documentation . . . 602
8.628.2.1 pLteEARFCN . . . 602
8.628.2.2 pLtePCI . . . 602
8.628.2.3 pWcdmaUARFCN . . . 602
8.629 unpack_nas_SLQSNasSwiModemStatus_t Struct Reference . . . 602
8.629.1 Detailed Description . . . 603
8.629.2 Field Documentation . . . 603
8.629.2.1 commonInfo . . . 603
8.629.2.2 pLTEInfo . . . 603
8.630 unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t Struct Reference . . . 603
8.630.1 Detailed Description . . . 603
8.630.2 Field Documentation . . . 603
8.630.2.1 Info . . . 603
8.630.2.2 Tlvresult . . . 603
8.631 unpack_nas_SLQSNasTimerCallback_ind_t Struct Reference . . . 603
8.631.1 Detailed Description . . . 604
8.631.2 Field Documentation . . . 604
8.631.2.1 t3396_apn . . . 604
8.631.2.2 t3396_plmn_id . . . 604
8.631.2.3 t3396_val . . . 604
8.632 unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t Struct Reference . . . 604
8.632.1 Detailed Description . . . 604
8.632.2 Field Documentation . . . 604
8.632.2.1 Info . . . 604
8.632.2.2 Tlvresult . . . 604
8.633 unpack_nas_SLQSSwiGetHDRPersonality_t Struct Reference . . . 605
8.633.1 Detailed Description . . . 605
8.633.2 Field Documentation . . . 605
8.633.2.1 pCurrentPersonality . . . 605
8.633.2.2 pPersonalityListLength . . . 605
8.633.2.3 pProtocolSubtypeElement . . . 605

8.634 unpack_nas_SLQSSwiGetHDRProtSubtype_t Struct Reference . . . 605
8.634.1 Detailed Description . . . 605
8.634.2 Field Documentation . . . 606
8.634.2.1 pAppSubType . . . 606
8.634.2.2 pCurrentPrsnlty . . . 606
8.634.2.3 pPersonalityListLength . . . 606
8.634.2.4 pProtoSubTypElmnt . . . 606
8.635 unpack_nas_SLQSSwiGetHRPDStats_t Struct Reference . . . 606
8.635.1 Detailed Description . . . 606
8.635.2 Field Documentation . . . 607
8.635.2.1 pDRCParams . . . 607
8.635.2.2 pPilotSetData . . . 607
8.635.2.3 pUATI . . . 607
8.636 unpack_nas_SLQSSwiGetLteCQI_t Struct Reference . . . 607
8.636.1 Detailed Description . . . 607
8.636.2 Field Documentation . . . 607
8.636.2.1 CQIValueCW0 . . . 607
8.636.2.2 CQIValueCW1 . . . 608
8.636.2.3 ValidityCW0 . . . 608
8.636.2.4 ValidityCW1 . . . 608
8.637 unpack_nas_SLQSSwiGetLteSccRxInfo_t Struct Reference . . . 608
8.637.1 Detailed Description . . . 608
8.637.2 Field Documentation . . . 608
8.637.2.1 pSccRxInfo . . . 608
8.638 unpack_nas_SLQSSwiNetworkDebug_t Struct Reference . . . 608
8.638.1 Detailed Description . . . 608
8.638.2 Field Documentation . . . 609
8.638.2.1 pDataStatusDetail . . . 609
8.638.2.2 pDeviceConfigDetail . . . 609
8.638.2.3 pNetworkStat1x . . . 609
8.638.2.4 pNetworkStatEVDO . . . 609
8.638.2.5 pObjectVer . . . 609
8.639 unpack_nas_SLQSSysInfoCallback_ind_t Struct Reference . . . 609
8.639.1 Detailed Description . . . 610
8.639.2 Field Documentation . . . 611
8.639.2.1 pAddCDMASysInfo . . . 611
8.639.2.2 pAddGSMSysInfo . . . 611
8.639.2.3 pAddHDRSysInfo . . . 611
8.639.2.4 pAddLTESysInfo . . . 611
8.639.2.5 pAddWCDMASysInfo . . . 611

8.639.2.6 pCDMASrvStatusInfo . . . 611
8.639.2.7 pCDMASysInfo . . . 611
8.639.2.8 pGSMCallBarringSysInfo . . . 611
8.639.2.9 pGSMCipherDomainSysInfo . . . 611
8.639.2.10 pGSMSrvStatusInfo . . . 611
8.639.2.11 pGSMSysInfo . . . 612
8.639.2.12 pHDRSrvStatusInfo . . . 612
8.639.2.13 pHDRSysInfo . . . 612
8.639.2.14 pLTESrvStatusInfo . . . 612
8.639.2.15 pLTESysInfo . . . 612
8.639.2.16 pLTEVoiceSupportSysInfo . . . 612
8.639.2.17 pSysInfoNoChange . . . 612
8.639.2.18 pWCDMACallBarringSysInfo . . . 612
8.639.2.19 pWCDMACipherDomainSysInfo . . . 612
8.639.2.20 pWCDMASrvStatusInfo . . . 612
8.639.2.21 pWCDMASysInfo . . . 612
8.640 unpack_omaDmConfigTlv_t Struct Reference . . . 612
8.640.1 Detailed Description . . . 612
8.640.2 Field Documentation . . . 613
8.640.2.1 alertmsg . . . 613
8.640.2.2 alertmsglength . . . 613
8.640.2.3 state . . . 613
8.640.2.4 userInputReq . . . 613
8.640.2.5 userInputTimeout . . . 613
8.641 unpack_omaDmFotaTlv_t Struct Reference . . . 613
8.641.1 Detailed Description . . . 613
8.641.2 Field Documentation . . . 614
8.641.2.1 description . . . 614
8.641.2.2 descriptionlength . . . 614
8.641.2.3 fwdloadsize . . . 615
8.641.2.4 fwloadComplete . . . 615
8.641.2.5 namelength . . . 615
8.641.2.6 package_name . . . 615
8.641.2.7 sessionType . . . 615
8.641.2.8 severity . . . 615
8.641.2.9 state . . . 615
8.641.2.10 updateCompleteStatus . . . 615
8.641.2.11 userInputReq . . . 615
8.641.2.12 userInputTimeout . . . 615
8.641.2.13 version . . . 615

8.641.2.14 versionlength . . . 615
8.642 unpack_omaDmNotificationsTlv_t Struct Reference . . . 615
8.642.1 Detailed Description . . . 615
8.642.2 Field Documentation . . . 616
8.642.2.1 notification . . . 616
8.642.2.2 sessionStatus . . . 616
8.643 unpack_pds_GetPDSDefaults_t Struct Reference . . . 616
8.643.1 Detailed Description . . . 616
8.643.2 Field Documentation . . . 617
8.643.2.1 pAccuracy . . . 617
8.643.2.2 pInterval . . . 617
8.643.2.3 pOperation . . . 617
8.643.2.4 pTimeout . . . 617
8.644 unpack_pds_GetPDSState_t Struct Reference . . . 617
8.644.1 Detailed Description . . . 617
8.644.2 Field Documentation . . . 618
8.644.2.1 pEnabledStatus . . . 618
8.644.2.2 pTrackingStatus . . . 618
8.645 unpack_pds_GetPortAutomaticTracking_t Struct Reference . . . 618
8.645.1 Detailed Description . . . 618
8.645.2 Field Documentation . . . 618
8.645.2.1 pbAuto . . . 618
8.646 unpack_pds_GetServiceAutomaticTracking_t Struct Reference . . . 618
8.646.1 Detailed Description . . . 618
8.646.2 Field Documentation . . . 619
8.646.2.1 pbAuto . . . 619
8.647 unpack_pds_GetXTRAAutomaticDownload_t Struct Reference . . . 619
8.647.1 Detailed Description . . . 619
8.647.2 Field Documentation . . . 619
8.647.2.1 pbEnabled . . . 619
8.647.2.2 pInterval . . . 619
8.648 unpack_pds_GetXTRANetwork_t Struct Reference . . . 619
8.648.1 Detailed Description . . . 619
8.648.2 Field Documentation . . . 620
8.648.2.1 pPreference . . . 620
8.649 unpack_pds_GetXTRAValidity_t Struct Reference . . . 620
8.649.1 Detailed Description . . . 620
8.649.2 Field Documentation . . . 620
8.649.2.1 pDuration . . . 620
8.649.2.2 pGPSWeek . . . 620

8.649.2.3 pGPSWeekOffset . . . 620
8.650 unpack_pds_SetEventReport_Ind_t Struct Reference . . . 620
8.650.1 Detailed Description . . . 621
8.650.2 Field Documentation . . . 622
8.650.2.1 dLatitude . . . 622
8.650.2.2 dLongitude . . . 622
8.650.2.3 has_dLatitude . . . 622
8.650.2.4 has_dLongitude . . . 622
8.650.2.5 has_PositionDataNMEA . . . 622
8.650.2.6 has_posSrc . . . 622
8.650.2.7 has_SessionStatus . . . 622
8.650.2.8 PositionDataNMEA . . . 622
8.650.2.9 posSrc . . . 622
8.650.2.10 SessionStatus . . . 622
8.651 unpack_pds_SetPdsState_Ind_t Struct Reference . . . 622
8.651.1 Detailed Description . . . 622
8.651.2 Field Documentation . . . 623
8.651.2.1 EnabledStatus . . . 623
8.651.2.2 TlvPresent . . . 623
8.651.2.3 TrackingStatus . . . 623
8.652 unpack_pds_SLQSGetAGPSConfig_t Struct Reference . . . 623
8.652.1 Detailed Description . . . 623
8.652.2 Field Documentation . . . 624
8.652.2.1 pServerAddress . . . 624
8.652.2.2 pServerPort . . . 624
8.652.2.3 pServerURL . . . 624
8.652.2.4 pServerURLLength . . . 624
8.653 unpack_pds_SLQSGetGPSStateInfo_t Struct Reference . . . 624
8.653.1 Detailed Description . . . 624
8.653.2 Field Documentation . . . 627
8.653.2.1 Altitude . . . 627
8.653.2.2 EngineState . . . 627
8.653.2.3 glo_almanac_sv_msk . . . 627
8.653.2.4 glo_ephemeris_sv_msk . . . 627
8.653.2.5 glo_health_sv_msk . . . 627
8.653.2.6 glo_visible_sv_msk . . . 627
8.653.2.7 gps_almanac_sv_msk . . . 627
8.653.2.8 gps_ephemeris_sv_msk . . . 627
8.653.2.9 gps_health_sv_msk . . . 627
8.653.2.10 gps_visible_sv_msk . . . 627

8.653.2.11 HorizontalUncertainty . . . 627
8.653.2.12 ono_valid . . . 627
8.653.2.13 Latitude . . . 627
8.653.2.14 Longitude . . . 627
8.653.2.15 sbas_almanac_sv_msk . . . 627
8.653.2.16 sbas_ephemeris_sv_msk . . . 627
8.653.2.17 sbas_health_sv_msk . . . 627
8.653.2.18 sbas_visible_sv_msk . . . 627
8.653.2.19 Time_uncert_ms . . . 627
8.653.2.20 TimeStmp_gps_week . . . 627
8.653.2.21 TimeStmp_tow_ms . . . 627
8.653.2.22 ValidMask . . . 628
8.653.2.23 VerticalUncertainty . . . 628
8.653.2.24 xtra_start_gps_minutes . . . 628
8.653.2.25 xtra_start_gps_week . . . 628
8.653.2.26 xtra_valid_duration_hours . . . 628
8.654 unpack_qmi_t Struct Reference . . . 628
8.654.1 Detailed Description . . . 628
8.654.2 Field Documentation . . . 628
8.654.2.1 msgid . . . 628
8.654.2.2 type . . . 628
8.654.2.3 xid . . . 628
8.655 unpack_qos_dataRate_t Struct Reference . . . 628
8.655.1 Detailed Description . . . 628
8.655.2 Field Documentation . . . 629
8.655.2.1 dataRateMax . . . 629
8.655.2.2 guaranteedRate . . . 629
8.656 unpack_qos_IPv4Addr_t Struct Reference . . . 629
8.656.1 Detailed Description . . . 629
8.656.2 Field Documentation . . . 629
8.656.2.1 addr . . . 629
8.656.2.2 subnetMask . . . 629
8.657 unpack_qos_IPv6Addr_t Struct Reference . . . 629
8.657.1 Detailed Description . . . 629
8.657.2 Field Documentation . . . 629
8.657.2.1 addr . . . 630
8.657.2.2 prefixLen . . . 630
8.658 unpack_qos_IPv6TrafCls_t Struct Reference . . . 630
8.658.1 Detailed Description . . . 630
8.658.2 Field Documentation . . . 630

8.658.2.1 mask . . . 630
8.658.2.2 val . . . 630
8.659 unpack_qos_pktErrRate_t Struct Reference . . . 630
8.659.1 Detailed Description . . . 630
8.659.2 Field Documentation . . . 630
8.659.2.1 exponent . . . 630
8.659.2.2 multiplier . . . 631
8.660 unpack_qos_Port_t Struct Reference . . . 631
8.660.1 Detailed Description . . . 631
8.660.2 Field Documentation . . . 631
8.660.2.1 port . . . 631
8.660.2.2 range . . . 631
8.661 unpack_qos_QosFlowInfo_t Struct Reference . . . 631
8.661.1 Detailed Description . . . 631
8.661.2 Field Documentation . . . 632
8.661.2.1 BearerID . . . 632
8.661.2.2 is_RxQFlowGranted_Available . . . 632
8.661.2.3 is_TxQFlowGranted_Available . . . 632
8.661.2.4 NumRxFilters . . . 632
8.661.2.5 NumTxFilters . . . 632
8.661.2.6 QFlowState . . . 632
8.661.2.7 RxQFilter . . . 632
8.661.2.8 RxQFlowGranted . . . 632
8.661.2.9 TxQFilter . . . 632
8.661.2.10 TxQFlowGranted . . . 632
8.662 unpack_qos_QosFlowInfoState_t Struct Reference . . . 633
8.662.1 Detailed Description . . . 633
8.662.2 Field Documentation . . . 633
8.662.2.1 id . . . 633
8.662.2.2 isNewFlow . . . 633
8.662.2.3 state . . . 633
8.663 unpack_qos_SLQSQosGetNetworkStatus_t Struct Reference . . . 633
8.663.1 Detailed Description . . . 633
8.663.2 Field Documentation . . . 634
8.663.2.1 NWQoSStatus . . . 634
8.664 unpack_qos_SLQSQosSwiReadApnExtraParams_t Struct Reference . . . 634
8.664.1 Detailed Description . . . 634
8.664.2 Field Documentation . . . 634
8.664.2.1 ambr_dl . . . 635
8.664.2.2 ambr_dl_ext . . . 635

8.664.2.3 ambr_dl_ext2 . . . 635
8.664.2.4 ambr_ul . . . 635
8.664.2.5 ambr_ul_ext . . . 635
8.664.2.6 ambr_ul_ext2 . . . 635
8.664.2.7 apnId . . . 635
8.665 unpack_qos_SLQSQosSwiReadDataStats_t Struct Reference . . . 635
8.665.1 Detailed Description . . . 635
8.665.2 Field Documentation . . . 636
8.665.2.1 apnId . . . 636
8.665.2.2 numQosFlow . . . 636
8.665.2.3 qosFlow . . . 636
8.665.2.4 total_rx_bytes . . . 636
8.665.2.5 total_rx_pkt . . . 636
8.665.2.6 total_tx_bytes . . . 636
8.665.2.7 total_tx_bytes_drp . . . 636
8.665.2.8 total_tx_pkt . . . 636
8.665.2.9 total_tx_pkt_drp . . . 636
8.666 unpack_qos_SLQSSetQosEventCallback_ind_t Struct Reference . . . 636
8.666.1 Detailed Description . . . 636
8.666.2 Field Documentation . . . 637
8.666.2.1 NumFlows . . . 637
8.666.2.2 QosFlowInfo . . . 637
8.667 unpack_qos_SLQSSetQosNWStatusCallback_ind_t Struct Reference . . . 637
8.667.1 Detailed Description . . . 637
8.667.2 Field Documentation . . . 637
8.667.2.1 status . . . 637
8.668 unpack_qos_SLQSSetQosPriEventCallback_ind_t Struct Reference . . . 637
8.668.1 Detailed Description . . . 637
8.668.2 Field Documentation . . . 637
8.668.2.1 event . . . 637
8.669 unpack_qos_SLQSSetQosStatusCallback_ind_t Struct Reference . . . 638
8.669.1 Detailed Description . . . 638
8.669.2 Field Documentation . . . 639
8.669.2.1 event . . . 639
8.669.2.2 id . . . 639
8.669.2.3 reason . . . 639
8.669.2.4 status . . . 639
8.670 unpack_qos_swiQosFilter_t Struct Reference . . . 639
8.670.1 Detailed Description . . . 640
8.670.2 Field Documentation . . . 641

8.670.2.1 EspSpi . . . 641
8.670.2.2 Id . . . 641
8.670.2.3 index . . . 641
8.670.2.4 IPv4DstAddr . . . 641
8.670.2.5 IPv4SrcAddr . . . 641
8.670.2.6 IPv4Tos . . . 641
8.670.2.7 IPv6DstAddr . . . 642
8.670.2.8 IPv6Label . . . 642
8.670.2.9 IPv6SrcAddr . . . 642
8.670.2.10 IPv6TrafCls . . . 642
8.670.2.11 is_EspSpi_Available . . . 642
8.670.2.12 is_Id_Available . . . 642
8.670.2.13 is_IPv4DstAddr_Available . . . 642
8.670.2.14 is_IPv4SrcAddr_Available . . . 642
8.670.2.15 is_IPv4Tos_Available . . . 642
8.670.2.16 is_IPv6DstAddr_Available . . . 642
8.670.2.17 is_IPv6Label_Available . . . 642
8.670.2.18 is_IPv6SrcAddr_Available . . . 642
8.670.2.19 is_IPv6TrafCls_Available . . . 642
8.670.2.20 is_NxtHdrProto_Available . . . 642
8.670.2.21 is_Precedence_Available . . . 642
8.670.2.22 is_TCPDstPort_Available . . . 642
8.670.2.23 is_TCPSrcPort_Available . . . 642
8.670.2.24 is_TranDstPort_Available . . . 642
8.670.2.25 is_TranSrcPort_Available . . . 642
8.670.2.26 is_UDPDstPort_Available . . . 642
8.670.2.27 is_UDPSrcPort_Available . . . 642
8.670.2.28 NxtHdrProto . . . 642
8.670.2.29 Precedence . . . 642
8.670.2.30 TCPDstPort . . . 642
8.670.2.31 TCPSrcPort . . . 642
8.670.2.32 TranDstPort . . . 642
8.670.2.33 TranSrcPort . . . 642
8.670.2.34 UDPDstPort . . . 642
8.670.2.35 UDPSrcPort . . . 643
8.670.2.36 version . . . 643
8.671 unpack_qos_swiQosFlow_t Struct Reference . . . 643
8.671.1 Detailed Description . . . 643
8.671.2 Field Documentation . . . 645
8.671.2.1 DataRate . . . 645

8.671.2.2 index . . . 645
8.671.2.3 is_DataRate_Available . . . 646
8.671.2.4 is_Jitter_Available . . . 646
8.671.2.5 is_Latency_Available . . . 646
8.671.2.6 is_LteQci_Available . . . 646
8.671.2.7 is_MaxAllowedPktSz_Available . . . 646
8.671.2.8 is_MinPolicedPktSz_Available . . . 646
8.671.2.9 is_PktErrRate_Available . . . 646
8.671.2.10 is_ProfileId3GPP2_Available . . . 646
8.671.2.11 is_TokenBucket_Available . . . 646
8.671.2.12 is_TrafficClass_Available . . . 646
8.671.2.13 is_val_3GPP2Pri_Available . . . 646
8.671.2.14 is_val_3GPPImCn_Available . . . 646
8.671.2.15 is_val_3GPPResResidualBER_Available . . . 646
8.671.2.16 is_val_3GPPSigInd_Available . . . 646
8.671.2.17 is_val_3GPPTraHdlPri_Available . . . 646
8.671.2.18 Jitter . . . 646
8.671.2.19 Latency . . . 646
8.671.2.20 LteQci . . . 646
8.671.2.21 MaxAllowedPktSz . . . 646
8.671.2.22 MinPolicedPktSz . . . 646
8.671.2.23 PktErrRate . . . 646
8.671.2.24 ProfileId3GPP2 . . . 646
8.671.2.25 TokenBucket . . . 646
8.671.2.26 TrafficClass . . . 646
8.671.2.27 val_3GPP2Pri . . . 646
8.671.2.28 val_3GPPImCn . . . 646
8.671.2.29 val_3GPPResResidualBER . . . 646
8.671.2.30 val_3GPPSigInd . . . 646
8.671.2.31 val_3GPPTraHdlPri . . . 647
8.672 unpack_qos_tokenBucket_t Struct Reference . . . 647
8.672.1 Detailed Description . . . 647
8.672.2 Field Documentation . . . 647
8.672.2.1 bucketSz . . . 647
8.672.2.2 peakRate . . . 647
8.672.2.3 tokenRate . . . 647
8.673 unpack_qos_Tos_t Struct Reference . . . 647
8.673.1 Detailed Description . . . 647
8.673.2 Field Documentation . . . 648
8.673.2.1 mask . . . 648

8.673.2.2 val . . . 648
8.674 unpack_QosFlowStat_t Struct Reference . . . 648
8.674.1 Detailed Description . . . 648
8.674.2 Field Documentation . . . 648
8.674.2.1 bearerId . . . 648
8.674.2.2 tx_bytes . . . 648
8.674.2.3 tx_bytes_drp . . . 648
8.674.2.4 tx_pkt . . . 648
8.674.2.5 tx_pkt_drp . . . 648
8.675 unpack_rms_GetSMSWake_t Struct Reference . . . 648
8.675.1 Detailed Description . . . 649
8.675.2 Field Documentation . . . 649
8.675.2.1 enabled . . . 649
8.675.2.2 wake_mask . . . 649
8.676 unpack_RMTransferStatistics_ind_t Struct Reference . . . 649
8.676.1 Detailed Description . . . 649
8.676.2 Field Documentation . . . 650
8.676.2.1 RxDropConutTlv . . . 650
8.676.2.2 RxOkByteCountTlv . . . 650
8.676.2.3 RxOkConutTlv . . . 650
8.676.2.4 TxDropConutTlv . . . 650
8.676.2.5 TxOkByteCountTlv . . . 650
8.676.2.6 TxOkConutTlv . . . 650
8.677 unpack_sar_SLQSGetRfSarState_t Struct Reference . . . 650
8.677.1 Detailed Description . . . 650
8.677.2 Field Documentation . . . 651
8.677.2.1 pSarRFState . . . 651
8.678 unpack_sms_GetSMSCAddress_t Struct Reference . . . 651
8.678.1 Detailed Description . . . 651
8.678.2 Field Documentation . . . 651
8.678.2.1 addressSize . . . 651
8.678.2.2 pSMSCAddress . . . 651
8.678.2.3 pSMSCType . . . 651
8.678.2.4 typeSize . . . 651
8.679 unpack_sms_SaveSMS_t Struct Reference . . . 651
8.679.1 Detailed Description . . . 651
8.679.2 Field Documentation . . . 652
8.679.2.1 pMessageIndex . . . 652
8.680 unpack_sms_SendSMS_t Struct Reference . . . 652
8.680.1 Detailed Description . . . 652

8.680.2 Field Documentation . . . 652
8.680.2.1 messageFailureCode . . . 652
8.680.2.2 messageID . . . 652
8.681 unpack_sms_SetNewSMSCallback_ind_t Struct Reference . . . 652
8.681.1 Detailed Description . . . 652
8.681.2 Field Documentation . . . 653
8.681.2.1 ETWSPLMNTlv . . . 653
8.681.2.2 ETWSTlv . . . 653
8.681.2.3 IMSTlv . . . 653
8.681.2.4 MMTlv . . . 653
8.681.2.5 NewMMTlv . . . 653
8.681.2.6 SMSCTlv . . . 653
8.681.2.7 TRMessageTlv . . . 653
8.682 unpack_sms_SetNewSMSCallback_t Struct Reference . . . 653
8.682.1 Detailed Description . . . 653
8.683 unpack_sms_SLQSDeleteSMS_t Struct Reference . . . 654
8.683.1 Detailed Description . . . 654
8.684 unpack_sms_SLQSGetIndicationRegister_t Struct Reference . . . 654
8.684.1 Detailed Description . . . 654
8.684.2 Field Documentation . . . 654
8.684.2.1 pGetIndicationRegInfo . . . 654
8.685 unpack_sms_SLQSGetMessageWaiting_t Struct Reference . . . 654
8.685.1 Detailed Description . . . 654
8.685.2 Field Documentation . . . 655
8.685.2.1 pGetMsgWaitingInfoResp . . . 655
8.686 unpack_sms_SLQSGetSMS_t Struct Reference . . . 655
8.686.1 Detailed Description . . . 655
8.686.2 Field Documentation . . . 655
8.686.2.1 message . . . 655
8.686.2.2 messageFormat . . . 655
8.686.2.3 messageSize . . . 655
8.686.2.4 messageTag . . . 656
8.687 unpack_sms_SLQSGetSmsBroadcastConfig_t Struct Reference . . . 656
8.687.1 Detailed Description . . . 656
8.687.2 Field Documentation . . . 656
8.687.2.1 pBroadcastConfig . . . 656
8.687.2.2 pCDMABroadcastConfig . . . 656
8.688 unpack_sms_SLQSGetSMSList_t Struct Reference . . . 656
8.688.1 Detailed Description . . . 656
8.688.2 Field Documentation . . . 657

8.688.2.1 messageList . . . 657
8.688.2.2 messageListSize . . . 657
8.689 unpack_sms_SLQSGetTransLayerInfo_t Struct Reference . . . 657
8.689.1 Detailed Description . . . 657
8.689.2 Field Documentation . . . 657
8.689.2.1 pGetTransLayerInfo . . . 657
8.690 unpack_sms_SLQSGetTransNWRegInfo_t Struct Reference . . . 657
8.690.1 Detailed Description . . . 657
8.690.2 Field Documentation . . . 657
8.690.2.1 pGetTransNWRegInfo . . . 657
8.691 unpack_sms_SLQSModifySMSStatus_t Struct Reference . . . 657
8.691.1 Detailed Description . . . 658
8.692 unpack_sms_SLQSSmsGetMaxStorageSize_t Struct Reference . . . 658
8.692.1 Detailed Description . . . 658
8.692.2 Field Documentation . . . 658
8.692.2.1 pMaxStorageSizeResp . . . 658
8.693 unpack_sms_SLQSSmsGetMessageProtocol_t Struct Reference . . . 658
8.693.1 Detailed Description . . . 658
8.693.2 Field Documentation . . . 658
8.693.2.1 pMessageProtocol . . . 658
8.694 unpack_sms_SLQSSwiGetSMSStorage_t Struct Reference . . . 659
8.694.1 Detailed Description . . . 659
8.694.2 Field Documentation . . . 659
8.694.2.1 pSmsStorage . . . 659
8.695 unpack_sms_SLQSWmsMemoryFullCallBack_ind_t Struct Reference . . . 659
8.695.1 Detailed Description . . . 659
8.695.2 Field Documentation . . . 659
8.695.2.1 messageMode . . . 659
8.695.2.2 storageType . . . 660
8.696 unpack_swiaudio_SLQSGetM2MAudioProfile_t Struct Reference . . . 660
8.696.1 Detailed Description . . . 660
8.696.2 Field Documentation . . . 660
8.696.2.1 CwtMute . . . 660
8.696.2.2 EarMute . . . 660
8.696.2.3 Generator . . . 661
8.696.2.4 MicMute . . . 661
8.696.2.5 Profile . . . 661
8.696.2.6 Volume . . . 661
8.697 unpack_swiaudio_SLQSGetM2MAudioVolume_t Struct Reference . . . 661
8.697.1 Detailed Description . . . 661

8.697.2 Field Documentation . . . 661
8.697.2.1 Level . . . 661
8.698 unpack_swiaudio_SLQSGetM2MAVMute_t Struct Reference . . . 661
8.698.1 Detailed Description . . . 661
8.698.2 Field Documentation . . . 662
8.698.2.1 CwtMute . . . 662
8.698.2.2 EarMute . . . 662
8.698.2.3 MicMute . . . 662
8.699 unpack_swiaudio_SLQSGetM2MSpkrGain_t Struct Reference . . . 662
8.699.1 Detailed Description . . . 662
8.699.2 Field Documentation . . . 662
8.699.2.1 Value . . . 662
8.700 unpack_swiavms_SLQSAVMSEventReportInd_t Struct Reference . . . 662
8.700.1 Detailed Description . . . 663
8.700.2 Field Documentation . . . 663
8.700.2.1 pBinaryUpdateSessionInfo . . . 663
8.700.2.2 pConfig . . . 663
8.700.2.3 pConnectionRequest . . . 663
8.700.2.4 pDataSessionStatus . . . 663
8.700.2.5 pHTTPStatus . . . 663
8.700.2.6 pNotification . . . 664
8.700.2.7 pPackageID . . . 664
8.700.2.8 pRegStatus . . . 664
8.700.2.9 pSessionType . . . 664
8.700.2.10 pWAMSParaChanged . . . 664
8.700.2.11 resultcode . . . 664
8.701 unpack_swiavms_SLQSAVMSGetSettings_t Struct Reference . . . 664
8.701.1 Detailed Description . . . 664
8.701.2 Field Documentation . . . 665
8.701.2.1 AutoConnect . . . 665
8.701.2.2 AutoReboot . . . 665
8.701.2.3 FwAutoSDM . . . 665
8.701.2.4 FwPromptdownload . . . 665
8.701.2.5 FwPromptUpdate . . . 665
8.701.2.6 OMADMEnabled . . . 665
8.701.2.7 pAPNInfo . . . 665
8.701.2.8 pConnectionRetryTimers . . . 665
8.701.2.9 pNotificationStore . . . 665
8.701.2.10 pPeroidsInfo . . . 666
8.701.2.11 pPollingTimer . . . 666

8.701.2.12 resultcode . . . 666
8.702 unpack_swiavms_SLQSAVMSSendSelection_t Struct Reference . . . 666
8.702.1 Detailed Description . . . 666
8.702.2 Field Documentation . . . 666
8.702.2.1 resultcode . . . 666
8.703 unpack_swiavms_SLQSAVMSSessionGetInfo_t Struct Reference . . . 666
8.703.1 Detailed Description . . . 666
8.703.2 Field Documentation . . . 666
8.703.2.1 pBinaryUpdateSessionInfo . . . 666
8.703.2.2 pConfig . . . 666
8.703.2.3 pNotification . . . 666
8.703.2.4 pPackageID . . . 666
8.703.2.5 resultcode . . . 667
8.704 unpack_swiavms_SLQSAvmsSetEventReport_t Struct Reference . . . 667
8.704.1 Detailed Description . . . 667
8.704.2 Field Documentation . . . 667
8.704.2.1 resultcode . . . 667
8.705 unpack_swiavms_SLQSAVMSSetSettings_t Struct Reference . . . 667
8.705.1 Detailed Description . . . 667
8.705.2 Field Documentation . . . 667
8.705.2.1 resultcode . . . 667
8.706 unpack_swiavms_SLQSAVMSStartSession_t Struct Reference . . . 667
8.706.1 Detailed Description . . . 667
8.706.2 Field Documentation . . . 668
8.706.2.1 resultcode . . . 668
8.706.2.2 sessionResponse . . . 668
8.707 unpack_swiavms_SLQSAVMSStopSession_t Struct Reference . . . 668
8.707.1 Detailed Description . . . 668
8.707.2 Field Documentation . . . 668
8.707.2.1 resultcode . . . 668
8.708 unpack_swiloc_SwiLocGetAutoStart_t Struct Reference . . . 668
8.708.1 Detailed Description . . . 668
8.708.2 Field Documentation . . . 669
8.708.2.1 fix_rate . . . 669
8.708.2.2 fix_rate_reported . . . 670
8.708.2.3 fix_type . . . 670
8.708.2.4 fix_type_reported . . . 670
8.708.2.5 function . . . 670
8.708.2.6 function_reported . . . 670
8.708.2.7 max_dist . . . 670

8.708.2.8 max_dist_reported . . . 670
8.708.2.9 max_time . . . 670
8.708.2.10 max_time_reported . . . 670
8.709 unpack_swioma_SLQSOMADMAlertCallback_ind_t Struct Reference . . . 670
8.709.1 Detailed Description . . . 670
8.709.2 Field Documentation . . . 670
8.709.2.1 eventType . . . 670
8.709.2.2 SessionInfoConfig . . . 671
8.709.2.3 SessionInfoFota . . . 671
8.709.2.4 SessionInfoNotification . . . 671
8.710 unpack_swioma_SLQSOMADMGetSessionInfo_t Struct Reference . . . 671
8.710.1 Detailed Description . . . 671
8.710.2 Field Documentation . . . 673
8.710.2.1 Date . . . 673
8.710.2.2 DateLength . . . 673
8.710.2.3 PkgDescLength . . . 673
8.710.2.4 PkgDescription . . . 673
8.710.2.5 PkgName . . . 673
8.710.2.6 PkgNameLength . . . 673
8.710.2.7 RetryCount . . . 673
8.710.2.8 SessionState . . . 673
8.710.2.9 SessionType . . . 673
8.710.2.10 Severity . . . 673
8.710.2.11 Source . . . 673
8.710.2.12 SourceLength . . . 673
8.710.2.13 Status . . . 673
8.710.2.14 Time . . . 673
8.710.2.15 TimeLength . . . 673
8.710.2.16 UpdateCompleteStatus . . . 673
8.711 unpack_swioma_SLQSOMADMGetSettings_t Struct Reference . . . 673
8.711.1 Detailed Description . . . 673
8.711.2 Field Documentation . . . 674
8.711.2.1 Autosdm . . . 675
8.711.2.2 FOTAdownload . . . 675
8.711.2.3 FOTAUpdate . . . 675
8.711.2.4 FwAutoCheck . . . 675
8.711.2.5 OMADMEnabled . . . 675
8.712 unpack_swioma_SLQSOMADMStartSession_t Struct Reference . . . 675
8.712.1 Detailed Description . . . 675
8.712.2 Field Documentation . . . 675

8.712.2.1 FwAvailability . . . 675
8.713 unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t Struct Reference . . . 675
8.713.1 Detailed Description . . . 675
8.713.2 Field Documentation . . . 676
8.713.2.1 TlvResult . . . 676
8.714 unpack_tmd_SLQSTmdGetMitigationDevList_t Struct Reference . . . 676
8.714.1 Detailed Description . . . 676
8.714.2 Field Documentation . . . 676
8.714.2.1 MitigationDevList . . . 676
8.714.2.2 MitigationDevListLen . . . 676
8.714.2.3 TlvResult . . . 676
8.715 unpack_tmd_SLQSTmdGetMitigationLvl_t Struct Reference . . . 676
8.715.1 Detailed Description . . . 676
8.715.2 Field Documentation . . . 677
8.715.2.1 CurrentmitigationLvl . . . 677
8.715.2.2 ReqMitigationLvl . . . 677
8.715.2.3 TlvResult . . . 677
8.716 unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t Struct Reference . . . 677
8.716.1 Detailed Description . . . 677
8.716.2 Field Documentation . . . 677
8.716.2.1 deviceID . . . 677
8.716.2.2 deviceIdLen . . . 677
8.716.2.3 lvl . . . 677
8.717 unpack_tmd_SLQSTmdRegNotMitigationLvl_t Struct Reference . . . 678
8.717.1 Detailed Description . . . 678
8.717.2 Field Documentation . . . 678
8.717.2.1 TlvResult . . . 678
8.718 unpack_uim_ChangePin_t Struct Reference . . . 678
8.718.1 Detailed Description . . . 678
8.718.2 Field Documentation . . . 679
8.718.2.1 pEncryptedPIN1 . . . 679
8.718.2.2 pIndicationToken . . . 679
8.718.2.3 pRemainingRetries . . . 679
8.718.2.4 TlvResult . . . 679
8.719 unpack_uim_GetCardStatus_t Struct Reference . . . 679
8.719.1 Detailed Description . . . 679
8.719.2 Field Documentation . . . 679
8.719.2.1 pCardStatus . . . 679
8.719.2.2 pHotSwapStatus . . . 679
8.719.2.3 TlvResult . . . 679

8.720 unpack_uim_ReadTransparent_t Struct Reference . . . 679
8.720.1 Detailed Description . . . 680
8.720.2 Field Documentation . . . 680
8.720.2.1 pCardResult . . . 680
8.720.2.2 pEncryptedData . . . 680
8.720.2.3 pIndicationToken . . . 680
8.720.2.4 pReadResult . . . 680
8.720.2.5 Tlvresult . . . 680
8.721 unpack_uim_SetPinProtection_t Struct Reference . . . 680
8.721.1 Detailed Description . . . 681
8.721.2 Field Documentation . . . 681
8.721.2.1 pEncryptedPIN1 . . . 681
8.721.2.2 pIndicationToken . . . 681
8.721.2.3 pRemainingRetries . . . 681
8.721.2.4 Tlvresult . . . 681
8.722 unpack_uim_SetUimSlotStatusChangeCallback_ind_t Struct Reference . . . 681
8.722.1 Detailed Description . . . 681
8.722.2 Field Documentation . . . 682
8.722.2.1 bNumberOfPhySlots . . . 682
8.722.2.2 slotsstatusChange . . . 682
8.723 unpack_uim_SLQSUIMAuthenticate_t Struct Reference . . . 682
8.723.1 Detailed Description . . . 682
8.723.2 Field Documentation . . . 682
8.723.2.1 pAuthenticateResult . . . 682
8.723.2.2 pCardResult . . . 682
8.723.2.3 pIndicationToken . . . 682
8.724 unpack_uim_SLQSUIMDepersonalization_t Struct Reference . . . 682
8.724.1 Detailed Description . . . 683
8.724.2 Field Documentation . . . 683
8.724.2.1 pRemainingRetries . . . 683
8.725 unpack_uim_SLQSUIMEventRegister_t Struct Reference . . . 683
8.725.1 Detailed Description . . . 683
8.725.2 Field Documentation . . . 683
8.725.2.1 eventMask . . . 683
8.726 unpack_uim_SLQSUIMGetConfiguration_t Struct Reference . . . 683
8.726.1 Detailed Description . . . 683
8.726.2 Field Documentation . . . 684
8.726.2.1 pAutoSelection . . . 684
8.726.2.2 pHaltSubscription . . . 684
8.726.2.3 pPersonalizationStatus . . . 684

8.727 unpack_uim_SLQSUIMGetFileAttributes_t Struct Reference . . . 684
8.727.1 Detailed Description . . . 684
8.727.2 Field Documentation . . . 685
8.727.2.1 pCardResult . . . 685
8.727.2.2 pFileAttributes . . . 685
8.727.2.3 pIndicationToken . . . 685
8.728 unpack_uim_SLQSUIMGetSlotsStatus_t Struct Reference . . . 685
8.728.1 Detailed Description . . . 685
8.728.2 Field Documentation . . . 685
8.728.2.1 pNumberOfPhySlot . . . 685
8.728.2.2 pUimSlotsStatus . . . 685
8.729 unpack_uim_SLQSUIMRefreshGetLastEvent_t Struct Reference . . . 685
8.729.1 Detailed Description . . . 686
8.729.2 Field Documentation . . . 686
8.729.2.1 pRefreshEvent . . . 686
8.730 unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t Struct Reference . . . 686
8.730.1 Detailed Description . . . 686
8.730.2 Field Documentation . . . 686
8.730.2.1 pCardStatus . . . 686
8.731 unpack_uim_UnblockPin_t Struct Reference . . . 686
8.731.1 Detailed Description . . . 686
8.731.2 Field Documentation . . . 687
8.731.2.1 pEncryptedPIN1 . . . 687
8.731.2.2 pIndicationToken . . . 687
8.731.2.3 pRemainingRetries . . . 687
8.731.2.4 Tlvresult . . . 687
8.732 unpack_uim_VerifyPin_t Struct Reference . . . 687
8.732.1 Detailed Description . . . 687
8.732.2 Field Documentation . . . 688
8.732.2.1 pEncryptedPIN1 . . . 688
8.732.2.2 pIndicationToken . . . 688
8.732.2.3 pRemainingRetries . . . 688
8.732.2.4 Tlvresult . . . 688
8.733 unpack_voice_SLQSOriginateUSSD_t Struct Reference . . . 688
8.733.1 Detailed Description . . . 688
8.733.2 Field Documentation . . . 691
8.733.2.1 pAlphaIDInfo . . . 691
8.733.2.2 pCallId . . . 691
8.733.2.3 pCcResultType . . . 691
8.733.2.4 pCCSuppsType . . . 691

8.733.2.5 pfailureCause . . . 691
8.733.2.6 pUSSDInfo . . . 691
8.734 unpack_voice_SLQSVoiceAnswerCall_t Struct Reference . . . 691
8.734.1 Detailed Description . . . 691
8.734.2 Field Documentation . . . 692
8.734.2.1 pCallId . . . 692
8.735 unpack_voice_SLQSVoiceBurstDTMF_t Struct Reference . . . 692
8.735.1 Detailed Description . . . 692
8.735.2 Field Documentation . . . 692
8.735.2.1 pCallID . . . 692
8.736 unpack_voice_SLQSVoiceDialCall_t Struct Reference . . . 692
8.736.1 Detailed Description . . . 692
8.736.2 Field Documentation . . . 693
8.736.2.1 pAlphaIDInfo . . . 693
8.736.2.2 pCallID . . . 693
8.736.2.3 pCCResultType . . . 693
8.736.2.4 pCCSUPSType . . . 693
8.737 unpack_voice_SLQSVoiceEndCall_t Struct Reference . . . 693
8.737.1 Detailed Description . . . 693
8.737.2 Field Documentation . . . 694
8.737.2.1 pCallId . . . 694
8.738 unpack_voice_SLQSVoiceGetAllCallInfo_t Struct Reference . . . 694
8.738.1 Detailed Description . . . 694
8.738.2 Field Documentation . . . 696
8.738.2.1 pArrAlertingPattern . . . 696
8.738.2.2 pArrAlertingType . . . 696
8.738.2.3 pArrAlphaID . . . 696
8.738.2.4 pArrCalledPartyNum . . . 696
8.738.2.5 pArrCallEndReason . . . 696
8.738.2.6 pArrCallInfo . . . 696
8.738.2.7 pArrConnectPartyNum . . . 696
8.738.2.8 pArrDiagInfo . . . 696
8.738.2.9 pArrRedirPartyNum . . . 696
8.738.2.10 pArrRemotePartyName . . . 696
8.738.2.11 pArrRemotePartyNum . . . 696
8.738.2.12 pArrSvcOption . . . 696
8.738.2.13 pArrUUSInfo . . . 696
8.738.2.14 pOTASPStatus . . . 696
8.738.2.15 pVoicePrivacy . . . 696
8.739 unpack_voice_SLQSVoiceGetCallBarring_t Struct Reference . . . 696

8.739.1 Detailed Description . . . 697
8.739.2 Field Documentation . . . 698
8.739.2.1 pAlphaIDInfo . . . 698
8.739.2.2 pCallID . . . 698
8.739.2.3 pCCResType . . . 698
8.739.2.4 pCCSUPSType . . . 698
8.739.2.5 pFailCause . . . 698
8.739.2.6 pSvcClass . . . 698
8.740 unpack_voice_SLQSVoiceGetCallForwardingStatus_t Struct Reference . . . 698
8.740.1 Detailed Description . . . 698
8.740.2 Field Documentation . . . 699
8.740.2.1 pAlphaIDInfo . . . 699
8.740.2.2 pCallID . . . 699
8.740.2.3 pCCResType . . . 699
8.740.2.4 pCCSUPSType . . . 699
8.740.2.5 pFailCause . . . 699
8.740.2.6 pGetCallFWExtInfo . . . 699
8.740.2.7 pGetCallFWInfo . . . 699
8.741 unpack_voice_SLQSVoiceGetCallInfo_t Struct Reference . . . 699
8.741.1 Detailed Description . . . 700
8.741.2 Field Documentation . . . 702
8.741.2.1 pAlertingPattern . . . 702
8.741.2.2 pAlertType . . . 702
8.741.2.3 pAlphaIDInfo . . . 702
8.741.2.4 pCallInfo . . . 702
8.741.2.5 pConnectNumInfo . . . 702
8.741.2.6 pDiagInfo . . . 702
8.741.2.7 pOTASPStatus . . . 702
8.741.2.8 pRemotePartyName . . . 702
8.741.2.9 pRemotePartyNum . . . 702
8.741.2.10 pSrvOpt . . . 702
8.741.2.11 pUUSInfo . . . 702
8.741.2.12 pVoicePrivacy . . . 702
8.742 unpack_voice_SLQSVoiceGetCallWaiting_t Struct Reference . . . 703
8.742.1 Detailed Description . . . 703
8.742.2 Field Documentation . . . 704
8.742.2.1 pAlphaIDInfo . . . 704
8.742.2.2 pCallID . . . 704
8.742.2.3 pCCResType . . . 704
8.742.2.4 pCCSUPSType . . . 704

8.742.2.5 pFailCause . . . 704
8.742.2.6 pSvcClass . . . 704
8.743 unpack_voice_SLQSVoiceGetCLIP_t Struct Reference . . . 704
8.743.1 Detailed Description . . . 704
8.743.2 Field Documentation . . . 705
8.743.2.1 pAlphaIDInfo . . . 705
8.743.2.2 pCallID . . . 705
8.743.2.3 pCCResType . . . 705
8.743.2.4 pCCSUPSType . . . 705
8.743.2.5 pCLIPResp . . . 705
8.743.2.6 pFailCause . . . 705
8.744 unpack_voice_SLQSVoiceGetCLIR_t Struct Reference . . . 705
8.744.1 Detailed Description . . . 706
8.744.2 Field Documentation . . . 706
8.744.2.1 pAlphaIDInfo . . . 706
8.744.2.2 pCallID . . . 706
8.744.2.3 pCCResType . . . 707
8.744.2.4 pCCSUPSType . . . 707
8.744.2.5 pCLIRResp . . . 707
8.744.2.6 pFailCause . . . 707
8.745 unpack_voice_SLQSVoiceGetCNAP_t Struct Reference . . . 707
8.745.1 Detailed Description . . . 707
8.745.2 Field Documentation . . . 708
8.745.2.1 pAlphaIDInfo . . . 708
8.745.2.2 pCallID . . . 708
8.745.2.3 pCCResType . . . 708
8.745.2.4 pCCSUPSType . . . 708
8.745.2.5 pCNAPResp . . . 708
8.745.2.6 pFailCause . . . 708
8.746 unpack_voice_SLQSVoiceGetCOLP_t Struct Reference . . . 708
8.746.1 Detailed Description . . . 708
8.746.2 Field Documentation . . . 709
8.746.2.1 pAlphaIDInfo . . . 709
8.746.2.2 pCallID . . . 709
8.746.2.3 pCCResType . . . 709
8.746.2.4 pCCSUPSType . . . 709
8.746.2.5 pCOLPResp . . . 709
8.746.2.6 pFailCause . . . 709
8.747 unpack_voice_SLQSVoiceGetCOLR_t Struct Reference . . . 709
8.747.1 Detailed Description . . . 710

8.747.2 Field Documentation . . . 711
8.747.2.1 pAlphaIDInfo . . . 711
8.747.2.2 pCallID . . . 711
8.747.2.3 pCCResType . . . 711
8.747.2.4 pCCSUPSType . . . 711
8.747.2.5 pCOLRResp . . . 711
8.747.2.6 pFailCause . . . 711
8.748 unpack_voice_SLQSVoiceGetConfig_t Struct Reference . . . 711
8.748.1 Detailed Description . . . 711
8.748.2 Field Documentation . . . 713
8.748.2.1 pAirTimerCnt . . . 713
8.748.2.2 pAutoAnswerStat . . . 713
8.748.2.3 pCurAMRConfig . . . 713
8.748.2.4 pCurPrefVoiceSO . . . 713
8.748.2.5 pCurrTTYMode . . . 713
8.748.2.6 pCurVoiceDomainPref . . . 713
8.748.2.7 pCurVoicePrivacyPref . . . 713
8.748.2.8 pRoamTimerCnt . . . 713
8.749 unpack_voice_SLQSVoiceManageCalls_t Struct Reference . . . 713
8.749.1 Detailed Description . . . 713
8.749.2 Field Documentation . . . 713
8.749.2.1 pFailCause . . . 713
8.750 unpack_voice_SLQSVoiceSendFlash_t Struct Reference . . . 713
8.750.1 Detailed Description . . . 713
8.750.2 Field Documentation . . . 714
8.750.2.1 pCallID . . . 714
8.751 unpack_voice_SLQSVoiceSetCallBarringPassword_t Struct Reference . . . 714
8.751.1 Detailed Description . . . 714
8.751.2 Field Documentation . . . 715
8.751.2.1 pAlphaIDInfo . . . 715
8.751.2.2 pCallID . . . 715
8.751.2.3 pCCResType . . . 715
8.751.2.4 pCCSUPSType . . . 715
8.751.2.5 pFailCause . . . 715
8.752 unpack_voice_SLQSVoiceSetConfig_t Struct Reference . . . 715
8.752.1 Detailed Description . . . 715
8.752.2 Field Documentation . . . 716
8.752.2.1 pAirTimerStatus . . . 716
8.752.2.2 pAutoAnsStatus . . . 716
8.752.2.3 pPrefVoiceSOStatus . . . 717

8.752.2.4 pRoamTimerStatus . . . 717
8.752.2.5 pTTYConfigStatus . . . 717
8.752.2.6 pVoiceDomainPrefStatus . . . 717
8.753 unpack_voice_SLQSVoiceSetSUPSService_t Struct Reference . . . 717
8.753.1 Detailed Description . . . 717
8.753.2 Field Documentation . . . 718
8.753.2.1 pAlphaIDInfo . . . 718
8.753.2.2 pCallID . . . 718
8.753.2.3 pCCResultType . . . 718
8.753.2.4 pCCSUPSType . . . 718
8.753.2.5 pFailCause . . . 718
8.754 unpack_voice_SLQSVoiceStartContDTMF_t Struct Reference . . . 718
8.754.1 Detailed Description . . . 718
8.754.2 Field Documentation . . . 718
8.754.2.1 pCallID . . . 718
8.755 unpack_voice_SLQSVoiceStopContDTMF_t Struct Reference . . . 718
8.755.1 Detailed Description . . . 719
8.755.2 Field Documentation . . . 719
8.755.2.1 callID . . . 719
8.756 unpack_wds_DHCPv4ClientLease_ind_t Struct Reference . . . 719
8.756.1 Detailed Description . . . 719
8.756.2 Field Documentation . . . 719
8.756.2.1 DHCPv4LeaseOptTlv . . . 719
8.756.2.2 DHCPv4LeaseStateTlv . . . 719
8.756.2.3 IPv4AddrTlv . . . 719
8.756.2.4 ProfileIdTlv . . . 719
8.757 unpack_wds_GetAutoconnect_t Struct Reference . . . 719
8.757.1 Detailed Description . . . 720
8.757.2 Field Documentation . . . 720
8.757.2.1 psetting . . . 720
8.758 unpack_wds_GetByteTotals_t Struct Reference . . . 720
8.758.1 Detailed Description . . . 720
8.758.2 Field Documentation . . . 720
8.758.2.1 pRXTotalBytes . . . 720
8.758.2.2 pTXTotalBytes . . . 720
8.759 unpack_wds_GetConnectionRate_t Struct Reference . . . 720
8.759.1 Detailed Description . . . 721
8.759.2 Field Documentation . . . 721
8.759.2.1 currentChannelRXRate . . . 721
8.759.2.2 currentChannelTXRate . . . 721

8.759.2.3 maxChannelRXRate . . . 721
8.759.2.4 maxChannelTXRate . . . 721
8.760 unpack_wds_GetDataBearerTechnology_t Struct Reference . . . 721
8.760.1 Detailed Description . . . 721
8.760.2 Field Documentation . . . 722
8.760.2.1 pDataBearer . . . 722
8.761 unpack_wds_GetDefaultProfile_t Struct Reference . . . 722
8.761.1 Detailed Description . . . 722
8.761.2 Field Documentation . . . 724
8.761.2.1 apnname . . . 724
8.761.2.2 apnsize . . . 724
8.761.2.3 auth . . . 724
8.761.2.4 ipaddr . . . 724
8.761.2.5 ipaddrv6 . . . 724
8.761.2.6 name . . . 724
8.761.2.7 namesize . . . 724
8.761.2.8 pdptype . . . 724
8.761.2.9 pridns . . . 724
8.761.2.10 pridnsv6 . . . 724
8.761.2.11 secdns . . . 724
8.761.2.12 secdnsv6 . . . 724
8.761.2.13 username . . . 724
8.761.2.14 usersize . . . 724
8.762 unpack_wds_GetDefaultProfileNum_t Struct Reference . . . 724
8.762.1 Detailed Description . . . 725
8.762.2 Field Documentation . . . 725
8.762.2.1 index . . . 725
8.763 unpack_wds_GetDormancyState_t Struct Reference . . . 725
8.763.1 Detailed Description . . . 725
8.763.2 Field Documentation . . . 725
8.763.2.1 dormancyState . . . 725
8.764 unpack_wds_GetLastMobileIPError_t Struct Reference . . . 725
8.764.1 Detailed Description . . . 725
8.764.2 Field Documentation . . . 726
8.764.2.1 error . . . 726
8.765 unpack_wds_GetMobileIP_t Struct Reference . . . 726
8.765.1 Detailed Description . . . 726
8.765.2 Field Documentation . . . 726
8.765.2.1 mipMode . . . 726
8.766 unpack_wds_GetMobileIPProfile_t Struct Reference . . . 726

8.766.1 Detailed Description . . . 727
8.766.2 Field Documentation . . . 728
8.766.2.1 AAASPI . . . 728
8.766.2.2 AAAState . . . 728
8.766.2.3 address . . . 728
8.766.2.4 enabled . . . 728
8.766.2.5 HASPI . . . 728
8.766.2.6 HAState . . . 728
8.766.2.7 NAI . . . 728
8.766.2.8 naiSize . . . 728
8.766.2.9 primaryHA . . . 728
8.766.2.10 revTunneling . . . 728
8.766.2.11 secondaryHA . . . 728
8.767 unpack_wds_GetPacketStatistics_t Struct Reference . . . 728
8.767.1 Detailed Description . . . 728
8.767.2 Field Documentation . . . 730
8.767.2.1 pRXDroppedCount . . . 730
8.767.2.2 pRXOkBytesCount . . . 730
8.767.2.3 pRXOKBytesLastCall . . . 730
8.767.2.4 pRXPacketErrors . . . 730
8.767.2.5 pRXPacketOverflows . . . 730
8.767.2.6 pRXPacketSuccesses . . . 730
8.767.2.7 pTXDroppedCount . . . 730
8.767.2.8 pTXOkBytesCount . . . 730
8.767.2.9 pTXOKBytesLastCall . . . 730
8.767.2.10 pTXPacketErrors . . . 730
8.767.2.11 pTXPacketOverflows . . . 730
8.767.2.12 pTXPacketSuccesses . . . 730
8.768 unpack_wds_GetPacketStatus_t Struct Reference . . . 730
8.768.1 Detailed Description . . . 730
8.768.2 Field Documentation . . . 731
8.768.2.1 rXDroppedCount . . . 731
8.768.2.2 rXOkBytesCount . . . 732
8.768.2.3 rXOKBytesLastCall . . . 732
8.768.2.4 rXPacketErrors . . . 732
8.768.2.5 rXPacketOverflows . . . 732
8.768.2.6 rXPacketSuccesses . . . 732
8.768.2.7 tXDroppedCount . . . 732
8.768.2.8 tXOkBytesCount . . . 732
8.768.2.9 tXOKBytesLastCall . . . 732

8.768.2.10 TXPacketErrors . . . 732
8.768.2.11 TXPacketOverflows . . . 732
8.768.2.12 TXPacketSuccesses . . . 732
8.769 unpack_wds_GetSessionDuration_t Struct Reference . . . 732
8.769.1 Detailed Description . . . 732
8.769.2 Field Documentation . . . 732
8.769.2.1 callDuration . . . 732
8.770 unpack_wds_GetSessionState_t Struct Reference . . . 732
8.770.1 Detailed Description . . . 732
8.770.2 Field Documentation . . . 733
8.770.2.1 connectionStatus . . . 733
8.771 unpack_wds_RMSetTransferStatistics_t Struct Reference . . . 733
8.771.1 Detailed Description . . . 733
8.772 unpack_wds_SetMobileIPProfile_t Struct Reference . . . 733
8.772.1 Detailed Description . . . 733
8.773 unpack_wds_SLQSCreateProfile_t Struct Reference . . . 733
8.773.1 Detailed Description . . . 733
8.773.2 Field Documentation . . . 734
8.773.2.1 pCreateProfileOut . . . 734
8.773.2.2 pProfileID . . . 734
8.773.2.3 Tlvresult . . . 734
8.774 unpack_wds_SLQSDeleteProfile_t Struct Reference . . . 734
8.774.1 Detailed Description . . . 734
8.774.2 Field Documentation . . . 734
8.774.2.1 extendedErrorCode . . . 734
8.775 unpack_wds_SLQSGet3GPPConfigItem_t Struct Reference . . . 734
8.775.1 Detailed Description . . . 735
8.775.2 Field Documentation . . . 736
8.775.2.1 _3gppRelease . . . 736
8.775.2.2 defaultPDNEnabled . . . 736
8.775.2.3 LTEAttachProfile . . . 736
8.775.2.4 LTEAttachProfileList . . . 736
8.775.2.5 LTEAttachProfileListLen . . . 736
8.775.2.6 profileList . . . 736
8.776 unpack_wds_SLQSGetCurrDataSystemStat_t Struct Reference . . . 736
8.776.1 Detailed Description . . . 736
8.776.2 Field Documentation . . . 737
8.776.2.1 currNetworkInfo . . . 737
8.776.2.2 networkInfoLen . . . 737
8.776.2.3 prefNetwork . . . 737

8.777 unpack_wds_SLQSGetCurrentChannelRate_t Struct Reference . . . 737
8.777.1 Detailed Description . . . 737
8.777.2 Field Documentation . . . 737
8.777.2.1 current_channel_rx_rate . . . 737
8.777.2.2 current_channel_tx_rate . . . 738
8.777.2.3 max_channel_rx_rate . . . 738
8.777.2.4 max_channel_tx_rate . . . 738
8.778 unpack_wds_SLQSGetDataBearerTechnology_t Struct Reference . . . 738
8.778.1 Detailed Description . . . 738
8.778.2 Field Documentation . . . 738
8.778.2.1 curDataBearerTechnology . . . 738
8.778.2.2 dataBearerMask . . . 738
8.778.2.3 lastCallDataBearerTechnology . . . 738
8.779 unpack_wds_SLQSGetDUNCallInfo_t Struct Reference . . . 738
8.779.1 Detailed Description . . . 739
8.779.2 Field Documentation . . . 741
8.779.2.1 callEndReason . . . 741
8.779.2.2 channelRate . . . 741
8.779.2.3 connectionStatus . . . 741
8.779.2.4 dataBearerTech . . . 741
8.779.2.5 dormancyStatus . . . 741
8.779.2.6 lastCallDataBearerTech . . . 741
8.779.2.7 lastCallRXOKBytesCnt . . . 741
8.779.2.8 lastCallTXOKBytesCnt . . . 741
8.779.2.9 mdmCallDurationActive . . . 741
8.779.2.10 rxOKBytesCount . . . 741
8.779.2.11 txOKBytesCount . . . 741
8.780 unpack_wds_SLQSGetProfileSettings_t Struct Reference . . . 741
8.780.1 Detailed Description . . . 742
8.780.2 Field Documentation . . . 742
8.780.2.1 pProfileSettings . . . 742
8.780.2.2 ProfileType . . . 742
8.780.2.3 Tlvresult . . . 742
8.781 unpack_wds_SLQSGetRuntimeSettings_t Struct Reference . . . 742
8.781.1 Detailed Description . . . 743
8.781.2 Field Documentation . . . 744
8.781.2.1 APNName . . . 744
8.781.2.2 Authentication . . . 744
8.781.2.3 DomainList . . . 744
8.781.2.4 GPRSGrantedQoS . . . 744

8.781.2.5 GWAddressV4 . . . 744
8.781.2.6 IMCNflag . . . 744
8.781.2.7 IPFamilyPreference . . . 744
8.781.2.8 IPv4 . . . 744
8.781.2.9 IPV6AddrInfo . . . 744
8.781.2.10 IPV6GWAddrInfo . . . 744
8.781.2.11 Mtu . . . 744
8.781.2.12 PCSCFAddrPCO . . . 744
8.781.2.13 PCSCFFQDNAddrList . . . 744
8.781.2.14 PDPType . . . 745
8.781.2.15 PrimaryDNSV4 . . . 745
8.781.2.16 PrimaryDNSV6 . . . 745
8.781.2.17 ProfileID . . . 745
8.781.2.18 ProfileName . . . 745
8.781.2.19 SecondaryDNSV4 . . . 745
8.781.2.20 SecondaryDNSV6 . . . 745
8.781.2.21 ServerAddrList . . . 745
8.781.2.22 SubnetMaskV4 . . . 745
8.781.2.23 Technology . . . 745
8.781.2.24 UMTSGrantedQoS . . . 745
8.781.2.25 Username . . . 745
8.782 unpack_wds_SLQSModifyProfile_t Struct Reference . . . 745
8.782.1 Detailed Description . . . 745
8.782.2 Field Documentation . . . 745
8.782.2.1 pExtErrorCode . . . 745
8.783 unpack_wds_SLQSSetIPFamilyPreference_t Struct Reference . . . 745
8.783.1 Detailed Description . . . 746
8.783.2 Field Documentation . . . 746
8.783.2.1 Tlvresult . . . 746
8.784 unpack_wds_SLQSSetPacketSrvStatusCallback_t Struct Reference . . . 746
8.784.1 Detailed Description . . . 746
8.784.2 Field Documentation . . . 747
8.784.2.1 bearerID . . . 747
8.784.2.2 conn_status . . . 747
8.784.2.3 ipFamily . . . 747
8.784.2.4 reconfigReqd . . . 747
8.784.2.5 sessionEndReason . . . 747
8.784.2.6 techName . . . 748
8.784.2.7 verboseSessnEndReason . . . 748
8.784.2.8 verboseSessnEndReasonType . . . 748

8.785 unpack_wds_SLQSSetWdsEventCallback_ind_t Struct Reference . . . 748
8.785.1 Detailed Description . . . 748
8.785.2 Field Documentation . . . 749
8.785.2.1 currDBTechAvail . . . 749
8.785.2.2 currNWInfo . . . 749
8.785.2.3 dataSysStatAvail . . . 749
8.785.2.4 dBTechAvail . . . 749
8.785.2.5 dBtechExtAvail . . . 749
8.785.2.6 dBTechExtRatValue . . . 749
8.785.2.7 dBTechExtSoMask . . . 749
8.785.2.8 dBTechnology . . . 749
8.785.2.9 dBtechnologyExt . . . 749
8.785.2.10 dormancyStatAvail . . . 749
8.785.2.11 dormancyStatus . . . 749
8.785.2.12 mipstatAvail . . . 749
8.785.2.13 mipStatus . . . 749
8.785.2.14 netInfoLen . . . 749
8.785.2.15 prefNetwork . . . 749
8.785.2.16 ratMask . . . 749
8.785.2.17 rx_bytes . . . 749
8.785.2.18 rx_pkts . . . 749
8.785.2.19 soMask . . . 749
8.785.2.20 tx_bytes . . . 749
8.785.2.21 tx_pkts . . . 749
8.785.2.22 xferStatAvail . . . 749
8.786 unpack_wds_SLQSSGetDHCPv4ClientConfig_t Struct Reference . . . 750
8.786.1 Detailed Description . . . 750
8.786.2 Field Documentation . . . 750
8.786.2.1 pHwConfig . . . 750
8.786.2.2 pRequestOptionList . . . 750
8.787 unpack_wds_SLQSSGetLoopback_t Struct Reference . . . 750
8.787.1 Detailed Description . . . 750
8.787.2 Field Documentation . . . 751
8.787.2.1 ByteLoopbackMode . . . 751
8.787.2.2 ByteLoopbackMultiplier . . . 751
8.788 unpack_wds_SLQSStartDataSession_t Struct Reference . . . 751
8.788.1 Detailed Description . . . 751
8.788.2 Field Documentation . . . 751
8.788.2.1 pFailureReason . . . 751
8.788.2.2 psid . . . 751

8.788.2.3 pVerboseFailReasonType . . . 751
8.788.2.4 pVerboseFailureReason . . . 751
8.789 unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t Struct Reference . . . 751
8.789.1 Detailed Description . . . 752
8.789.2 Field Documentation . . . 753
8.789.2.1 apnName . . . 753
8.789.2.2 bearerId . . . 753
8.789.2.3 contextId . . . 753
8.789.2.4 ipv4Address . . . 753
8.789.2.5 ipv4GWAddress . . . 753
8.789.2.6 ipv6Address . . . 753
8.789.2.7 ipv6GWAddress . . . 753
8.789.2.8 prDNSIPv4Address . . . 754
8.789.2.9 prDNSIPv6Address . . . 754
8.789.2.10 prPCSCFIPv4Address . . . 754
8.789.2.11 prPCSCFIPv6Address . . . 754
8.789.2.12 seDNSIPv4Address . . . 754
8.789.2.13 seDNSIPv6Address . . . 754
8.789.2.14 sePCSCFIPv4Address . . . 754
8.789.2.15 sePCSCFIPv6Address . . . 754
8.790 UnPackGetProfileSettingOut Struct Reference . . . 754
8.790.1 Detailed Description . . . 754
8.790.2 Field Documentation . . . 754
8.790.2.1 curProfile . . . 754
8.790.2.2 pExtErrCode . . . 754
8.791 UnpackSwiAvmsEventReportBinaryUpdateSessionInfo Struct Reference . . . 754
8.791.1 Detailed Description . . . 755
8.791.2 Field Documentation . . . 756
8.791.2.1 bBinaryType . . . 756
8.791.2.2 bSerity . . . 756
8.791.2.3 bState . . . 756
8.791.2.4 bUserInputRequest . . . 756
8.791.2.5 szDescription . . . 756
8.791.2.6 szName . . . 756
8.791.2.7 szVersion . . . 756
8.791.2.8 TlvPresent . . . 756
8.791.2.9 ulPkgDownloadComplete . . . 756
8.791.2.10 ulPkgDownloadSize . . . 756
8.791.2.11 wDescriptionLength . . . 756
8.791.2.12 wNameLength . . . 756

8.791.2.13wUpdateCompeteStatus . . . 756
8.791.2.14wUserInputTimeout . . . 756
8.791.2.15wVersionLength . . . 756
8.792UnpackSwiAvmsEventReportConfig Struct Reference . . . 756
8.792.1 Detailed Description . . . 756
8.792.2 Field Documentation . . . 757
8.792.2.1 bState . . . 757
8.792.2.2 bUserInputRequest . . . 757
8.792.2.3 szAlertMsg . . . 757
8.792.2.4 TlvPresent . . . 757
8.792.2.5 wAlertMsgLength . . . 757
8.792.2.6 wUserInputTimeout . . . 757
8.793UnpackSwiAvmsEventReportConnectionRequest Struct Reference . . . 757
8.793.1 Detailed Description . . . 757
8.793.2 Field Documentation . . . 758
8.793.2.1 bUserInputRequest . . . 758
8.793.2.2 TlvPresent . . . 758
8.793.2.3 wUserInputTimeout . . . 758
8.794UnpackSwiAvmsEventReportDataSessionStatus Struct Reference . . . 758
8.794.1 Detailed Description . . . 758
8.794.2 Field Documentation . . . 758
8.794.2.1 bType . . . 758
8.794.2.2 TlvPresent . . . 758
8.794.2.3 wErrorCode . . . 758
8.795UnpackSwiAvmsEventReportHTTPStatus Struct Reference . . . 758
8.795.1 Detailed Description . . . 758
8.795.2 Field Documentation . . . 759
8.795.2.1 TlvPresent . . . 759
8.795.2.2 wHTTPStatus . . . 760
8.796UnpackSwiAvmsEventReportNotification Struct Reference . . . 760
8.796.1 Detailed Description . . . 760
8.796.2 Field Documentation . . . 760
8.796.2.1 bNotification . . . 761
8.796.2.2 TlvPresent . . . 761
8.796.2.3 wSessionStatus . . . 761
8.797UnpackSwiAvmsEventReportPackageID Struct Reference . . . 761
8.797.1 Detailed Description . . . 761
8.797.2 Field Documentation . . . 761
8.797.2.1 bPackageID . . . 761
8.797.2.2 TlvPresent . . . 761

8.798 UnpackSwiAvmsEventReportRegStatus Struct Reference . . . 761
8.798.1 Detailed Description . . . 761
8.798.2 Field Documentation . . . 761
8.798.2.1 bRegStatus . . . 761
8.798.2.2 TlvPresent . . . 762
8.799 UnpackSwiAvmsEventReportSessionType Struct Reference . . . 762
8.799.1 Detailed Description . . . 762
8.799.2 Field Documentation . . . 762
8.799.2.1 bType . . . 762
8.799.2.2 TlvPresent . . . 762
8.800 UnpackSwiAvmsEventReportWAMSParamChange Struct Reference . . . 762
8.800.1 Detailed Description . . . 762
8.800.2 Field Documentation . . . 763
8.800.2.1 TlvPresent . . . 763
8.800.2.2 wWamsChangeMask . . . 763
8.801 unpackWdsProfileParam Union Reference . . . 763
8.801.1 Detailed Description . . . 763
8.801.2 Field Documentation . . . 763
8.801.2.1 SlqsProfile3GPP . . . 763
8.801.2.2 SlqsProfile3GPP2 . . . 763
8.802 voice_airTimer Struct Reference . . . 763
8.802.1 Detailed Description . . . 763
8.802.2 Field Documentation . . . 764
8.802.2.1 airTimerValue . . . 764
8.802.2.2 namID . . . 764
8.803 voice_allCallsAlphaIDInfo Struct Reference . . . 764
8.803.1 Detailed Description . . . 764
8.803.2 Field Documentation . . . 764
8.803.2.1 AlphaIDInfo . . . 764
8.803.2.2 callID . . . 764
8.804 voice_allCallsDiagInfo Struct Reference . . . 764
8.804.1 Detailed Description . . . 764
8.804.2 Field Documentation . . . 765
8.804.2.1 callID . . . 765
8.804.2.2 DiagInfo . . . 765
8.805 voice_allCallsUUSInfo Struct Reference . . . 765
8.805.1 Detailed Description . . . 765
8.805.2 Field Documentation . . . 765
8.805.2.1 callID . . . 765
8.805.2.2 uusInfo . . . 765

8.806voice_alphaIDInfo Struct Reference . . . 765
8.806.1 Detailed Description . . . 765
8.806.2 Field Documentation . . . 766
8.806.2.1 alphaDcs . . . 766
8.806.2.2 alphaLen . . . 766
8.806.2.3 alphaText . . . 766
8.807voice_arrAlertingPattern Struct Reference . . . 766
8.807.1 Detailed Description . . . 766
8.807.2 Field Documentation . . . 767
8.807.2.1 alertingPattern . . . 767
8.807.2.2 callID . . . 767
8.807.2.3 numInstances . . . 767
8.808voice_arrAlertingType Struct Reference . . . 767
8.808.1 Detailed Description . . . 767
8.808.2 Field Documentation . . . 768
8.808.2.1 AlertingType . . . 768
8.808.2.2 callID . . . 768
8.808.2.3 numInstances . . . 768
8.809voice_arrAlphaID Struct Reference . . . 768
8.809.1 Detailed Description . . . 768
8.809.2 Field Documentation . . . 768
8.809.2.1 allCallsAlphaIDInfoArr . . . 768
8.809.2.2 numInstances . . . 768
8.810voice_arrCalledPartyNum Struct Reference . . . 768
8.810.1 Detailed Description . . . 769
8.810.2 Field Documentation . . . 769
8.810.2.1 CalledPartyNum . . . 769
8.810.2.2 numInstances . . . 769
8.811voice_arrCallEndReason Struct Reference . . . 769
8.811.1 Detailed Description . . . 769
8.811.2 Field Documentation . . . 769
8.811.2.1 callEndReason . . . 769
8.811.2.2 callID . . . 770
8.811.2.3 numInstances . . . 770
8.812voice_arrCallInfo Struct Reference . . . 770
8.812.1 Detailed Description . . . 770
8.812.2 Field Documentation . . . 770
8.812.2.1 getAllCallInfo . . . 770
8.812.2.2 numInstances . . . 770
8.813voice_arrConnectPartyNum Struct Reference . . . 770

8.813.1 Detailed Description . . . 770
8.813.2 Field Documentation . . . 771
8.813.2.1 ConnectedPartyNum . . . 771
8.813.2.2 numInstances . . . 771
8.814 voice_arrDiagInfo Struct Reference . . . 771
8.814.1 Detailed Description . . . 771
8.814.2 Field Documentation . . . 771
8.814.2.1 DiagInfo . . . 771
8.814.2.2 numInstances . . . 771
8.815 voice_arrRedirPartyNum Struct Reference . . . 771
8.815.1 Detailed Description . . . 771
8.815.2 Field Documentation . . . 772
8.815.2.1 numInstances . . . 772
8.815.2.2 RedirPartyNum . . . 772
8.816 voice_arrRemotePartyName Struct Reference . . . 772
8.816.1 Detailed Description . . . 772
8.816.2 Field Documentation . . . 772
8.816.2.1 GetAllCallRmtPtyName . . . 772
8.816.2.2 numInstances . . . 772
8.817 voice_arrRemotePartyNum Struct Reference . . . 772
8.817.1 Detailed Description . . . 772
8.817.2 Field Documentation . . . 773
8.817.2.1 numInstances . . . 773
8.817.2.2 RmtPtyNum . . . 773
8.818 voice_arrSvcOption Struct Reference . . . 773
8.818.1 Detailed Description . . . 773
8.818.2 Field Documentation . . . 773
8.818.2.1 callID . . . 773
8.818.2.2 numInstances . . . 773
8.818.2.3 srvOption . . . 773
8.819 voice_arrUUSInfo Struct Reference . . . 773
8.819.1 Detailed Description . . . 774
8.819.2 Field Documentation . . . 774
8.819.2.1 AllCallsUUSInfo . . . 774
8.819.2.2 numInstances . . . 774
8.820 voice_burstDTMFInfo Struct Reference . . . 774
8.820.1 Detailed Description . . . 774
8.820.2 Field Documentation . . . 775
8.820.2.1 digitCnt . . . 775
8.820.2.2 pCallID . . . 775

8.820.2.3 pDigitBuff . . . 775
8.821 voice_calledPartySubAdd Struct Reference . . . 775
8.821.1 Detailed Description . . . 775
8.821.2 Field Documentation . . . 775
8.821.2.1 extBit . . . 775
8.821.2.2 oddEvenInd . . . 775
8.821.2.3 subAddr . . . 775
8.821.2.4 subAddrLen . . . 776
8.821.2.5 subAddrType . . . 776
8.822 voice_callFwdTypeAndPlan Struct Reference . . . 776
8.822.1 Detailed Description . . . 776
8.822.2 Field Documentation . . . 776
8.822.2.1 numberPlan . . . 776
8.822.2.2 numberType . . . 776
8.823 voice_callFWExtInfo Struct Reference . . . 776
8.823.1 Detailed Description . . . 777
8.823.2 Field Documentation . . . 778
8.823.2.1 noReplyTimer . . . 778
8.823.2.2 number . . . 778
8.823.2.3 numLen . . . 778
8.823.2.4 numPlan . . . 778
8.823.2.5 numType . . . 778
8.823.2.6 PI . . . 778
8.823.2.7 SI . . . 778
8.823.2.8 SvcClass . . . 778
8.823.2.9 SvcStatus . . . 778
8.824 voice_callFWInfo Struct Reference . . . 778
8.824.1 Detailed Description . . . 779
8.824.2 Field Documentation . . . 779
8.824.2.1 noReplyTimer . . . 779
8.824.2.2 number . . . 779
8.824.2.3 numLen . . . 779
8.824.2.4 SvcClass . . . 779
8.824.2.5 SvcStatus . . . 779
8.825 voice_callInfo Struct Reference . . . 779
8.825.1 Detailed Description . . . 779
8.825.2 Field Documentation . . . 780
8.825.2.1 callID . . . 780
8.825.2.2 callState . . . 781
8.825.2.3 callType . . . 781

8.825.2.4 direction . . . 781
8.825.2.5 mode . . . 781
8.826 voice_ccSUPSType Struct Reference . . . 781
8.826.1 Detailed Description . . . 781
8.826.2 Field Documentation . . . 781
8.826.2.1 reason . . . 781
8.826.2.2 svcType . . . 781
8.827 voice_CLIPResp Struct Reference . . . 781
8.827.1 Detailed Description . . . 782
8.827.2 Field Documentation . . . 782
8.827.2.1 ActiveStatus . . . 782
8.827.2.2 ProvisionStatus . . . 782
8.828 voice_CLIRResp Struct Reference . . . 782
8.828.1 Detailed Description . . . 782
8.828.2 Field Documentation . . . 783
8.828.2.1 ActiveStatus . . . 783
8.828.2.2 ProvisionStatus . . . 783
8.829 voice_CNAPResp Struct Reference . . . 783
8.829.1 Detailed Description . . . 783
8.829.2 Field Documentation . . . 783
8.829.2.1 ActiveStatus . . . 783
8.829.2.2 ProvisionStatus . . . 783
8.830 voice_COLPResp Struct Reference . . . 784
8.830.1 Detailed Description . . . 784
8.830.2 Field Documentation . . . 784
8.830.2.1 ActiveStatus . . . 784
8.830.2.2 ProvisionStatus . . . 784
8.831 voice_COLRResp Struct Reference . . . 784
8.831.1 Detailed Description . . . 784
8.831.2 Field Documentation . . . 785
8.831.2.1 ActiveStatus . . . 785
8.831.2.2 ProvisionStatus . . . 785
8.832 voice_connectNumInfo Struct Reference . . . 785
8.832.1 Detailed Description . . . 785
8.832.2 Field Documentation . . . 786
8.832.2.1 callerID . . . 786
8.832.2.2 callerIDLen . . . 786
8.832.2.3 numPlan . . . 786
8.832.2.4 numPresInd . . . 787
8.832.2.5 numType . . . 787

8.832.2.6 screeningInd . . . 787
8.833 voice_CUGInfo Struct Reference . . . 787
8.833.1 Detailed Description . . . 787
8.833.2 Field Documentation . . . 787
8.833.2.1 CUGIndex . . . 787
8.833.2.2 SuppOA . . . 787
8.833.2.3 SuppPrefCUG . . . 787
8.834 voice_curAMRConfig Struct Reference . . . 787
8.834.1 Detailed Description . . . 787
8.834.2 Field Documentation . . . 788
8.834.2.1 gsmAmrStat . . . 788
8.834.2.2 wcdmaAmrStat . . . 788
8.835 voice_diagInfo Struct Reference . . . 788
8.835.1 Detailed Description . . . 788
8.835.2 Field Documentation . . . 788
8.835.2.1 diagInfoLen . . . 788
8.835.2.2 diagnosticInfo . . . 788
8.836 voice_DTMFLengths Struct Reference . . . 789
8.836.1 Detailed Description . . . 789
8.836.2 Field Documentation . . . 789
8.836.2.1 DTMFInterdigitInterval . . . 789
8.836.2.2 DTMFPulseWidth . . . 789
8.837 voice_getAllCallInformation Struct Reference . . . 789
8.837.1 Detailed Description . . . 789
8.837.2 Field Documentation . . . 790
8.837.2.1 ALS . . . 790
8.837.2.2 CallInfo . . . 790
8.837.2.3 isEmpty . . . 790
8.838 voice_getAllCallRmtPtyName Struct Reference . . . 790
8.838.1 Detailed Description . . . 790
8.838.2 Field Documentation . . . 790
8.838.2.1 callID . . . 790
8.838.2.2 RemotePartyName . . . 790
8.839 voice_getAllCallRmtPtyNum Struct Reference . . . 790
8.839.1 Detailed Description . . . 791
8.839.2 Field Documentation . . . 791
8.839.2.1 callID . . . 791
8.839.2.2 RemotePartyNum . . . 791
8.840 voice_getCallFWExtInfo Struct Reference . . . 791
8.840.1 Detailed Description . . . 791

8.840.2 Field Documentation . . . 791
8.840.2.1 CallFWExtInfo . . . 791
8.840.2.2 numInstances . . . 791
8.841 voice_getCallFWInfo Struct Reference . . . 792
8.841.1 Detailed Description . . . 792
8.841.2 Field Documentation . . . 792
8.841.2.1 CallFWInfo . . . 792
8.841.2.2 numInstances . . . 792
8.842 voice_peerNumberInfo Struct Reference . . . 792
8.842.1 Detailed Description . . . 792
8.842.2 Field Documentation . . . 794
8.842.2.1 callID . . . 794
8.842.2.2 number . . . 794
8.842.2.3 numLen . . . 794
8.842.2.4 numPI . . . 794
8.842.2.5 numPlan . . . 794
8.842.2.6 numSI . . . 794
8.842.2.7 numType . . . 794
8.843 voice_prefVoiceSO Struct Reference . . . 794
8.843.1 Detailed Description . . . 794
8.843.2 Field Documentation . . . 796
8.843.2.1 evrcCapability . . . 796
8.843.2.2 homeOrigVoiceSO . . . 796
8.843.2.3 homePageVoiceSO . . . 796
8.843.2.4 namID . . . 796
8.843.2.5 roamOrigVoiceSO . . . 796
8.844 voice_remotePartyName Struct Reference . . . 796
8.844.1 Detailed Description . . . 796
8.844.2 Field Documentation . . . 796
8.844.2.1 callerName . . . 797
8.844.2.2 codingScheme . . . 797
8.844.2.3 nameLen . . . 797
8.844.2.4 namePI . . . 797
8.845 voice_remotePartyNum Struct Reference . . . 797
8.845.1 Detailed Description . . . 797
8.845.2 Field Documentation . . . 797
8.845.2.1 numLen . . . 797
8.845.2.2 presentationInd . . . 797
8.845.2.3 remPartyNumber . . . 797
8.846 voice_roamTimer Struct Reference . . . 797

8.846.1 Detailed Description . . . 798
8.846.2 Field Documentation . . . 798
8.846.2.1 namID . . . 798
8.846.2.2 roamTimerValue . . . 798
8.847voice_USSInfo Struct Reference . . . 798
8.847.1 Detailed Description . . . 798
8.847.2 Field Documentation . . . 798
8.847.2.1 ussData . . . 799
8.847.2.2 ussDCS . . . 799
8.847.2.3 ussLen . . . 799
8.848voice_UUSInfo Struct Reference . . . 799
8.848.1 Detailed Description . . . 799
8.848.2 Field Documentation . . . 800
8.848.2.1 UUSData . . . 800
8.848.2.2 UUSDatalen . . . 800
8.848.2.3 UUSDcs . . . 800
8.848.2.4 UUSType . . . 800
8.849wds_currNetworkInfo Struct Reference . . . 800
8.849.1 Detailed Description . . . 800
8.849.2 Field Documentation . . . 801
8.849.2.1 NetworkType . . . 801
8.849.2.2 RATMask . . . 801
8.849.2.3 SOMask . . . 801
8.850wds_DataULongLongTlv Struct Reference . . . 801
8.850.1 Detailed Description . . . 801
8.850.2 Field Documentation . . . 801
8.850.2.1 TlvPresent . . . 802
8.850.2.2 ullData . . . 802
8.851wds_DataULongTlv Struct Reference . . . 802
8.851.1 Detailed Description . . . 802
8.851.2 Field Documentation . . . 802
8.851.2.1 TlvPresent . . . 802
8.851.2.2 ulData . . . 802
8.852wds_DHCPLeaseOptTlv Struct Reference . . . 802
8.852.1 Detailed Description . . . 802
8.852.2 Field Documentation . . . 802
8.852.2.1 numOpt . . . 802
8.852.2.2 optList . . . 802
8.852.2.3 optListData . . . 803
8.852.2.4 TlvPresent . . . 803

8.853 wds_DHCPLeaseStateTlv Struct Reference . . . 803
8.853.1 Detailed Description . . . 803
8.853.2 Field Documentation . . . 803
8.853.2.1 leaseState . . . 803
8.853.2.2 TlvPresent . . . 803
8.854 wds_DHCPOpt Struct Reference . . . 803
8.854.1 Detailed Description . . . 803
8.854.2 Field Documentation . . . 804
8.854.2.1 optCode . . . 804
8.854.2.2 optValLen . . . 804
8.854.2.3 pOptVal . . . 804
8.855 wds_DHCPProfileIdTlv Struct Reference . . . 804
8.855.1 Detailed Description . . . 804
8.855.2 Field Documentation . . . 804
8.855.2.1 profileId . . . 804
8.855.2.2 profileType . . . 804
8.855.2.3 TlvPresent . . . 804
8.856 wds_DHCPv4HWConfig Struct Reference . . . 804
8.856.1 Detailed Description . . . 805
8.856.2 Field Documentation . . . 805
8.856.2.1 chaddr . . . 805
8.856.2.2 chaddrLen . . . 805
8.856.2.3 hwType . . . 805
8.857 wds_DHCPv4Option Struct Reference . . . 805
8.857.1 Detailed Description . . . 805
8.857.2 Field Documentation . . . 805
8.857.2.1 optCode . . . 805
8.857.2.2 optVal . . . 806
8.857.2.3 optValLen . . . 806
8.858 wds_DHCPv4OptionList Struct Reference . . . 806
8.858.1 Detailed Description . . . 806
8.858.2 Field Documentation . . . 806
8.858.2.1 numOpt . . . 806
8.858.2.2 pOptList . . . 806
8.859 wds_DHCPv4ProfileId Struct Reference . . . 806
8.859.1 Detailed Description . . . 806
8.859.2 Field Documentation . . . 806
8.859.2.1 profileId . . . 807
8.859.2.2 profileType . . . 807
8.860 wds_Domain Struct Reference . . . 807

8.860.1 Detailed Description . . . 807
8.860.2 Field Documentation . . . 807
8.860.2.1 domainLen . . . 807
8.860.2.2 domainName . . . 807
8.861 wds_DomainNameList Struct Reference . . . 807
8.861.1 Detailed Description . . . 807
8.861.2 Field Documentation . . . 808
8.861.2.1 domain . . . 808
8.861.2.2 numInstances . . . 808
8.862 wds_GPRSQoS Struct Reference . . . 808
8.862.1 Detailed Description . . . 808
8.862.2 Field Documentation . . . 808
8.862.2.1 delayClass . . . 808
8.862.2.2 meanThroughputClass . . . 808
8.862.2.3 peakThroughputClass . . . 808
8.862.2.4 precedenceClass . . . 808
8.862.2.5 reliabilityClass . . . 808
8.863 wds_IPv4AdTlv Struct Reference . . . 809
8.863.1 Detailed Description . . . 809
8.863.2 Field Documentation . . . 809
8.863.2.1 IPv4Addr . . . 809
8.863.2.2 TlvPresent . . . 809
8.864 wds_IPV6AddressInfo Struct Reference . . . 809
8.864.1 Detailed Description . . . 809
8.864.2 Field Documentation . . . 809
8.864.2.1 IPAddressV6 . . . 809
8.864.2.2 IPV6PrefixLen . . . 809
8.865 wds_IPV6GWAddressInfo Struct Reference . . . 809
8.865.1 Detailed Description . . . 810
8.865.2 Field Documentation . . . 810
8.865.2.1 gwAddressV6 . . . 810
8.865.2.2 gwV6PrefixLen . . . 810
8.866 wds_PCSCFFQDNAddress Struct Reference . . . 810
8.866.1 Detailed Description . . . 810
8.866.2 Field Documentation . . . 810
8.866.2.1 fqdnAddr . . . 810
8.866.2.2 fqdnLen . . . 811
8.867 wds_PCSCFFQDNAddressList Struct Reference . . . 811
8.867.1 Detailed Description . . . 811
8.867.2 Field Documentation . . . 811

8.867.2.1 numInstances . . . 811
8.867.2.2 pcsfFQDNAddress . . . 811
8.868 wds_PCSCFIPv4ServerAddressList Struct Reference . . . 811
8.868.1 Detailed Description . . . 811
8.868.2 Field Documentation . . . 812
8.868.2.1 numInstances . . . 812
8.868.2.2 pscsfIPv4Addr . . . 812
8.869 wds_ProfileIdentifier Struct Reference . . . 812
8.869.1 Detailed Description . . . 812
8.869.2 Field Documentation . . . 812
8.869.2.1 profileIndex . . . 812
8.869.2.2 profileType . . . 812
8.870 wds_profileInfo Union Reference . . . 812
8.870.1 Detailed Description . . . 812
8.870.2 Field Documentation . . . 813
8.870.2.1 SlqsProfile3GPP . . . 813
8.870.2.2 SlqsProfile3GPP2 . . . 813
8.871 wds_transferStatInd Struct Reference . . . 813
8.871.1 Detailed Description . . . 813
8.871.2 Field Documentation . . . 813
8.871.2.1 StatsMask . . . 813
8.871.2.2 StatsPeriod . . . 813
8.872 wds_TrStatInd Struct Reference . . . 813
8.872.1 Detailed Description . . . 813
8.872.2 Field Documentation . . . 814
8.872.2.1 statsMask . . . 814
8.872.2.2 statsPeriod . . . 814
8.873 wds_UMTSMinQoS Struct Reference . . . 814
8.873.1 Detailed Description . . . 814
8.873.2 Field Documentation . . . 816
8.873.2.1 deliveryErrSDU . . . 816
8.873.2.2 grntDownlinkBitrate . . . 816
8.873.2.3 grntUplinkBitrate . . . 816
8.873.2.4 maxDownlinkBitrate . . . 816
8.873.2.5 maxSDUSize . . . 816
8.873.2.6 maxUplinkBitrate . . . 816
8.873.2.7 qosDeliveryOrder . . . 816
8.873.2.8 resBerRatio . . . 816
8.873.2.9 sduErrorRatio . . . 816
8.873.2.10 trafficClass . . . 816

8.873.2.11 trafficPriority . . . 816
8.873.2.12 transferDelay . . . 816
8.874 wdsDhcpv4HwConfig Struct Reference . . . 816
8.874.1 Detailed Description . . . 817
8.874.2 Field Documentation . . . 817
8.874.2.1 chaddr . . . 817
8.874.2.2 chaddrLen . . . 817
8.874.2.3 hwType . . . 817
8.875 wdsDhcpv4Option Struct Reference . . . 817
8.875.1 Detailed Description . . . 817
8.875.2 Field Documentation . . . 817
8.875.2.1 optCode . . . 818
8.875.2.2 optVal . . . 818
8.875.2.3 optValLen . . . 818
8.876 wdsDhcpv4OptionList Struct Reference . . . 818
8.876.1 Detailed Description . . . 818
8.876.2 Field Documentation . . . 818
8.876.2.1 numOpt . . . 818
8.876.2.2 pOptList . . . 818
8.877 wdsDhcpv4ProfileId Struct Reference . . . 818
8.877.1 Detailed Description . . . 818
8.877.2 Field Documentation . . . 819
8.877.2.1 profileId . . . 819
8.877.2.2 profileType . . . 819

9 File Documentation **821**

9.1 apdoxypages.c File Reference . . . 821
9.1.1 Detailed Description . . . 821
9.2 audio.h File Reference . . . 821
9.2.1 Function Documentation . . . 822
9.2.1.1 pack_audio_SLQSGetAudioPathConfig . . . 822
9.2.1.2 pack_audio_SLQSGetAudioProfile . . . 822
9.2.1.3 pack_audio_SLQSGetAudioVolTLBConfig . . . 823
9.2.1.4 pack_audio_SLQSSetAudioPathConfig . . . 823
9.2.1.5 pack_audio_SLQSSetAudioProfile . . . 824
9.2.1.6 pack_audio_SLQSSetAudioVolTLBConfig . . . 824
9.2.1.7 unpack_audio_SLQSGetAudioPathConfig . . . 825
9.2.1.8 unpack_audio_SLQSGetAudioProfile . . . 825
9.2.1.9 unpack_audio_SLQSGetAudioVolTLBConfig . . . 825
9.2.1.10 unpack_audio_SLQSSetAudioPathConfig . . . 826

9.2.1.11 unpack_audio_SLQSSetAudioProfile . . . 826
9.2.1.12 unpack_audio_SLQSSetAudioVolTLBConfig . . . 826
9.3 cat.h File Reference . . . 827
9.3.1 Macro Definition Documentation . . . 827
9.3.1.1 CAN_COMMON_EVENT_TLV_NUMBER . . . 827
9.3.1.2 CAT_EVENT_DATA_MAX_LENGTH . . . 827
9.3.2 Function Documentation . . . 827
9.3.2.1 pack_cat_CATSendEnvelopeCommand . . . 828
9.3.2.2 pack_cat_CATSendTerminalResponse . . . 828
9.3.2.3 pack_cat_SetCATEventCallback . . . 828
9.3.2.4 unpack_cat_CATSendEnvelopeCommand . . . 829
9.3.2.5 unpack_cat_CATSendTerminalResponse . . . 829
9.3.2.6 unpack_cat_SetCATEventCallback . . . 829
9.3.2.7 unpack_cat_SetCatEventCallback_ind . . . 830
9.4 common.h File Reference . . . 830
9.4.1 Macro Definition Documentation . . . 832
9.4.1.1 DEAULT_LOC_TIMEOUT_IN_SEC . . . 832
9.4.1.2 MINREQBKLEN . . . 832
9.4.1.3 MSGID_AND_LEN . . . 832
9.4.1.4 MSGID_DONT_CARE . . . 832
9.4.1.5 SDK_VALIDATE_INPUT_PACK_PARAM . . . 832
9.4.1.6 SDK_VALIDATE_INPUT_PACK_PARAM_AND_FILL_XID . . . 832
9.4.1.7 SDK_VALIDATE_INPUT_UNPACK_PARAM . . . 832
9.4.1.8 SDU_HDR_LEN . . . 833
9.4.1.9 UNUSEDPARAM . . . 833
9.4.2 Typedef Documentation . . . 833
9.4.2.1 logger . . . 833
9.4.3 Enumeration Type Documentation . . . 833
9.4.3.1 eLOG_LEVEL . . . 833
9.4.3.2 eQMI_SVC . . . 833
9.4.3.3 eTimeout . . . 834
9.4.3.4 msgtype . . . 834
9.4.4 Function Documentation . . . 834
9.4.4.1 fill_pack_ctx . . . 834
9.4.4.2 fill_sdu_hdr . . . 834
9.4.4.3 get_version . . . 834
9.4.4.4 helper_get_resp_ctx . . . 834
9.4.4.5 helper_get_xid . . . 835
9.4.4.6 helper_set_log_func . . . 835
9.4.4.7 helper_set_log_lvl . . . 835

9.4.4.8 liteqmi_GetVersion . . . 835
9.4.4.9 liteqmi_helper_decode7bitAsciiEncString . . . 835
9.4.4.10 liteqmi_log . . . 835
9.4.4.11 unpack_result_code_only . . . 835
9.4.5 Variable Documentation . . . 835
9.4.5.1 glog . . . 835
9.4.5.2 gloglvl . . . 835
9.5 dms.h File Reference . . . 835
9.5.1 Macro Definition Documentation . . . 842
9.5.1.1 ACT_CODE_MAX_SIZE . . . 842
9.5.1.2 CK_MAX_SIZE . . . 842
9.5.1.3 DMS_IMGDETAILS_LEN . . . 842
9.5.1.4 DMS_MAX_CUST_ID_LEN . . . 842
9.5.1.5 DMS_MAX_CUST_VALUE_LEN . . . 842
9.5.1.6 DMS_MAX_FWUPDATE_LOG_STR_SZ . . . 842
9.5.1.7 DMS_MAX_FWUPDATE_REF_STR_SZ . . . 842
9.5.1.8 DMS_MAX_RADIO_IFCS_SIZE . . . 842
9.5.1.9 DMS_PM_FACTORY . . . 842
9.5.1.10 DMS_PM_LOW . . . 842
9.5.1.11 DMS_PM_OFFLINE . . . 842
9.5.1.12 DMS_PM_ONLINE . . . 842
9.5.1.13 DMS_PM_PERSISTENT_LOW . . . 842
9.5.1.14 DMS_PM_RESET . . . 842
9.5.1.15 DMS_PM_SHUT_DOWN . . . 842
9.5.1.16 DMS_SET_REPORT_DISABLE . . . 842
9.5.1.17 DMS_SET_REPORT_ENABLE . . . 842
9.5.1.18 DMS_SLQSFWINFO_APPVERSION_SZ . . . 842
9.5.1.19 DMS_SLQSFWINFO_BOOTVERSION_SZ . . . 842
9.5.1.20 DMS_SLQSFWINFO_CARRIER_SZ . . . 842
9.5.1.21 DMS_SLQSFWINFO_CUR_CARR_NAME . . . 842
9.5.1.22 DMS_SLQSFWINFO_CUR_CARR_REV . . . 842
9.5.1.23 DMS_SLQSFWINFO_MODELID_SZ . . . 842
9.5.1.24 DMS_SLQSFWINFO_PACKAGEID_SZ . . . 842
9.5.1.25 DMS_SLQSFWINFO_PRIVERSION_SZ . . . 842
9.5.1.26 DMS_SLQSFWINFO_SKU_SZ . . . 842
9.5.1.27 DMS_SWI_SET_IND_DISABLE . . . 842
9.5.1.28 DMS_SWI_SET_IND_ENABLE . . . 843
9.5.1.29 DMS_UINT8_MAX_STRING_SZ . . . 843
9.5.1.30 DMS_VALID_FSN_LEN . . . 843
9.5.1.31 ERI_DATA_MAX_SIZE . . . 843

9.5.1.32 MAX_BUILD_ID_LEN . . . 843
9.5.1.33 MEID_MAX_SIZE . . . 843
9.5.1.34 SLQS_MAX_DYING_GASP_CFG_SMS_CONTENT_LENGTH . . . 843
9.5.1.35 SLQS_MAX_DYING_GASP_CFG_SMS_NUMBER_LENGTH . . . 843
9.5.1.36 SPC_SIZE . . . 843
9.5.1.37 UNIQUE_ID_LEN . . . 843
9.5.2 Function Documentation . . . 843
9.5.2.1 pack_dms_ActivateAutomatic . . . 843
9.5.2.2 pack_dms_GetActivationState . . . 843
9.5.2.3 pack_dms_GetBandCapability . . . 844
9.5.2.4 pack_dms_GetCrashAction . . . 844
9.5.2.5 pack_dms_GetCustFeature . . . 844
9.5.2.6 pack_dms_GetCustFeaturesV2 . . . 845
9.5.2.7 pack_dms_GetDeviceCap . . . 845
9.5.2.8 pack_dms_GetDeviceCapabilities . . . 846
9.5.2.9 pack_dms_GetDeviceHardwareRev . . . 846
9.5.2.10 pack_dms_GetDeviceMfr . . . 846
9.5.2.11 pack_dms_GetDeviceSerialNumbers . . . 847
9.5.2.12 pack_dms_GetFirmwareInfo . . . 847
9.5.2.13 pack_dms_GetFirmwareRevision . . . 847
9.5.2.14 pack_dms_GetFirmwareRevisions . . . 848
9.5.2.15 pack_dms_GetFSN . . . 848
9.5.2.16 pack_dms_GetHardwareRevision . . . 848
9.5.2.17 pack_dms_GetIMSI . . . 849
9.5.2.18 pack_dms_GetManufacturer . . . 849
9.5.2.19 pack_dms_GetModelID . . . 849
9.5.2.20 pack_dms_GetNetworkTime . . . 850
9.5.2.21 pack_dms_GetOfflineReason . . . 850
9.5.2.22 pack_dms_GetPower . . . 850
9.5.2.23 pack_dms_GetPRLVersion . . . 851
9.5.2.24 pack_dms_GetSerialNumbers . . . 851
9.5.2.25 pack_dms_GetUSBComp . . . 852
9.5.2.26 pack_dms_GetVoiceNumber . . . 852
9.5.2.27 pack_dms_ResetToFactoryDefaults . . . 852
9.5.2.28 pack_dms_SetActivationStatusCallback . . . 853
9.5.2.29 pack_dms_SetCrashAction . . . 853
9.5.2.30 pack_dms_SetCustFeature . . . 853
9.5.2.31 pack_dms_SetCustFeaturesV2 . . . 854
9.5.2.32 pack_dms_SetEventReport . . . 854
9.5.2.33 pack_dms_SetFirmwarePreference . . . 854

9.5.2.34 pack_dms_SetPower . . . 855
9.5.2.35 pack_dms_SetUSBComp . . . 855
9.5.2.36 pack_dms_SLQSDmsSwiGetResetInfo . . . 856
9.5.2.37 pack_dms_SLQSDmsSwiIndicationRegister . . . 856
9.5.2.38 pack_dms_SLQSGetBandCapability . . . 856
9.5.2.39 pack_dms_SLQSGetERIFile . . . 857
9.5.2.40 pack_dms_SLQSSwiClearDyingGaspStatistics . . . 857
9.5.2.41 pack_dms_SLQSSwiGetCrashInfo . . . 857
9.5.2.42 pack_dms_SLQSSwiGetDyingGaspCfg . . . 858
9.5.2.43 pack_dms_SLQSSwiGetDyingGaspStatistics . . . 858
9.5.2.44 pack_dms_SLQSSwiGetFirmwareCurr . . . 858
9.5.2.45 pack_dms_SLQSSwiGetFwUpdateStatus . . . 859
9.5.2.46 pack_dms_SLQSSwiGetHostDevInfo . . . 859
9.5.2.47 pack_dms_SLQSSwiGetOSInfo . . . 859
9.5.2.48 pack_dms_SLQSSwiGetSerialNoExt . . . 860
9.5.2.49 pack_dms_SLQSSwiSetDyingGaspCfg . . . 860
9.5.2.50 pack_dms_SLQSSwiSetHostDevInfo . . . 860
9.5.2.51 pack_dms_SLQSSwiSetOSInfo . . . 861
9.5.2.52 pack_dms_SLQSUIMGetState . . . 861
9.5.2.53 pack_dms_UIMChangePIN . . . 862
9.5.2.54 pack_dms_UIMGetControlKeyStatus . . . 862
9.5.2.55 pack_dms_UIMGetICCID . . . 862
9.5.2.56 pack_dms_UIMGetPINStatus . . . 863
9.5.2.57 pack_dms_UIMSetControlKeyProtection . . . 863
9.5.2.58 pack_dms_UIMSetPINProtection . . . 863
9.5.2.59 pack_dms_UIMUnblockControlKey . . . 864
9.5.2.60 pack_dms_UIMUnblockPIN . . . 864
9.5.2.61 pack_dms_UIMVerifyPIN . . . 865
9.5.2.62 pack_dms_ValidateSPC . . . 865
9.5.2.63 unpack_dms_ActivateAutomatic . . . 865
9.5.2.64 unpack_dms_GetActivationState . . . 866
9.5.2.65 unpack_dms_GetBandCapability . . . 866
9.5.2.66 unpack_dms_GetCrashAction . . . 866
9.5.2.67 unpack_dms_GetCustFeature . . . 867
9.5.2.68 unpack_dms_GetCustFeaturesV2 . . . 867
9.5.2.69 unpack_dms_GetDeviceCap . . . 867
9.5.2.70 unpack_dms_GetDeviceCapabilities . . . 868
9.5.2.71 unpack_dms_GetDeviceHardwareRev . . . 868
9.5.2.72 unpack_dms_GetDeviceMfr . . . 868
9.5.2.73 unpack_dms_GetDeviceSerialNumbers . . . 869

9.5.2.74 unpack_dms_GetFirmwareInfo . . . 869
9.5.2.75 unpack_dms_GetFirmwareRevision . . . 869
9.5.2.76 unpack_dms_GetFirmwareRevisions . . . 870
9.5.2.77 unpack_dms_GetFSN . . . 870
9.5.2.78 unpack_dms_GetHardwareRevision . . . 870
9.5.2.79 unpack_dms_GetIMSI . . . 871
9.5.2.80 unpack_dms_GetManufacturer . . . 871
9.5.2.81 unpack_dms_GetModelID . . . 871
9.5.2.82 unpack_dms_GetNetworkTime . . . 872
9.5.2.83 unpack_dms_GetOfflineReason . . . 872
9.5.2.84 unpack_dms_GetPower . . . 872
9.5.2.85 unpack_dms_GetPRLVersion . . . 873
9.5.2.86 unpack_dms_GetSerialNumbers . . . 873
9.5.2.87 unpack_dms_GetUSBComp . . . 873
9.5.2.88 unpack_dms_GetVoiceNumber . . . 874
9.5.2.89 unpack_dms_ResetToFactoryDefaults . . . 874
9.5.2.90 unpack_dms_SetActivationStatusCallback . . . 874
9.5.2.91 unpack_dms_SetCrashAction . . . 875
9.5.2.92 unpack_dms_SetCustFeature . . . 875
9.5.2.93 unpack_dms_SetCustFeaturesV2 . . . 875
9.5.2.94 unpack_dms_SetEventReport . . . 876
9.5.2.95 unpack_dms_SetEventReport_ind . . . 876
9.5.2.96 unpack_dms_SetFirmwarePreference . . . 877
9.5.2.97 unpack_dms_SetPower . . . 877
9.5.2.98 unpack_dms_SetUSBComp . . . 877
9.5.2.99 unpack_dms_SLQSDmsSwiGetResetInfo . . . 878
9.5.2.100 unpack_dms_SLQSDmsSwiGetResetInfo_Ind . . . 878
9.5.2.101 unpack_dms_SLQSDmsSwiIndicationRegister . . . 878
9.5.2.102 unpack_dms_SLQSGetBandCapability . . . 879
9.5.2.103 unpack_dms_SLQSGetERIFile . . . 879
9.5.2.104 unpack_dms_SLQSSwiClearDyingGaspStatistics . . . 879
9.5.2.105 unpack_dms_SLQSSwiGetCrashInfo . . . 880
9.5.2.106 unpack_dms_SLQSSwiGetDyingGaspCfg . . . 880
9.5.2.107 unpack_dms_SLQSSwiGetDyingGaspStatistics . . . 881
9.5.2.108 unpack_dms_SLQSSwiGetFirmwareCurr . . . 881
9.5.2.109 unpack_dms_SLQSSwiGetFwUpdateStatus . . . 881
9.5.2.110 unpack_dms_SLQSSwiGetHostDevInfo . . . 882
9.5.2.111 unpack_dms_SLQSSwiGetOSInfo . . . 882
9.5.2.112 unpack_dms_SLQSSwiGetSerialNoExt . . . 882
9.5.2.113 unpack_dms_SLQSSwiSetDyingGaspCfg . . . 883

9.5.2.114 unpack_dms_SLQSSwiSetHostDevInfo . . . 883
9.5.2.115 unpack_dms_SLQSSwiSetOSInfo . . . 883
9.5.2.116 unpack_dms_SLQSUIMGetState . . . 884
9.5.2.117 unpack_dms_UIMChangePIN . . . 884
9.5.2.118 unpack_dms_UIMGetControlKeyStatus . . . 884
9.5.2.119 unpack_dms_UIMGetICCID . . . 885
9.5.2.120 unpack_dms_UIMGetPINStatus . . . 885
9.5.2.121 unpack_dms_UIMSetControlKeyProtection . . . 885
9.5.2.122 unpack_dms_UIMSetPINProtection . . . 886
9.5.2.123 unpack_dms_UIMUnblockControlKey . . . 886
9.5.2.124 unpack_dms_UIMUnblockPIN . . . 887
9.5.2.125 unpack_dms_UIMVerifyPIN . . . 887
9.5.2.126 unpack_dms_ValidateSPC . . . 887
9.6 fms.h File Reference . . . 888
9.6.1 Macro Definition Documentation . . . 889
9.6.1.1 FMS_FW_PRI_BUILD_MATCH_LEN . . . 889
9.6.1.2 FMS_GOBI_LISTENTRIES_MAX . . . 889
9.6.1.3 FMS_GOBI_MBN_BUILD_ID_STR_LEN . . . 889
9.6.1.4 FMS_GOBI_MBN_IMG_ID_STR_LEN . . . 889
9.6.1.5 FMS_IMAGE_ID_BUILD_ID_LEN . . . 889
9.6.1.6 FMS_IMAGE_ID_IMG_ID_LEN . . . 889
9.6.1.7 FMS_IMAGE_ID_MAX_ENTRIES . . . 889
9.6.1.8 FMS_IMAGE_ID_PRI_IMGTYPE . . . 889
9.6.1.9 FMS_MAX_IMAGE_ID_ELEMENT . . . 889
9.6.1.10 FMS_MAX_IMAGE_PREFERENCE_IMAGE_SIZE . . . 889
9.6.2 Function Documentation . . . 889
9.6.2.1 GetValidFwPriCombinations . . . 889
9.6.2.2 pack_fms_GetImagesPreference . . . 889
9.6.2.3 pack_fms_GetStoredImages . . . 890
9.6.2.4 pack_fms_SetImagesPreference . . . 890
9.6.2.5 unpack_fms_GetImagesPreference . . . 890
9.6.2.6 unpack_fms_GetStoredImages . . . 890
9.6.2.7 unpack_fms_SetImagesPreference . . . 891
9.7 ims.h File Reference . . . 891
9.7.1 Function Documentation . . . 892
9.7.1.1 pack_ims_SLQSGetIMSSMSConfig . . . 892
9.7.1.2 pack_ims_SLQSGetIMSUserConfig . . . 892
9.7.1.3 pack_ims_SLQSGetIMSVoIPConfig . . . 893
9.7.1.4 pack_ims_SLQSGetRegMgrConfig . . . 893
9.7.1.5 pack_ims_SLQSGetSIPConfig . . . 894

9.7.1.6 pack_ims_SLQSImsConfigIndicationRegister . . . 894
9.7.1.7 pack_ims_SLQSSetIMSSMSConfig . . . 894
9.7.1.8 pack_ims_SLQSSetIMSUserConfig . . . 895
9.7.1.9 pack_ims_SLQSSetIMSVoIPConfig . . . 895
9.7.1.10 pack_ims_SLQSSetRegMgrConfig . . . 896
9.7.1.11 pack_ims_SLQSSetSIPConfig . . . 896
9.7.1.12 unpack_ims_SLQSGetIMSSMSConfig . . . 897
9.7.1.13 unpack_ims_SLQSGetIMSUserConfig . . . 897
9.7.1.14 unpack_ims_SLQSGetIMSVoIPConfig . . . 897
9.7.1.15 unpack_ims_SLQSGetRegMgrConfig . . . 898
9.7.1.16 unpack_ims_SLQSGetSIPConfig . . . 898
9.7.1.17 unpack_ims_SLQSImsConfigIndicationRegister . . . 898
9.7.1.18 unpack_ims_SLQSSetIMSSMSConfig . . . 899
9.7.1.19 unpack_ims_SLQSSetIMSUserConfig . . . 899
9.7.1.20 unpack_ims_SLQSSetIMSVoIPConfig . . . 899
9.7.1.21 unpack_ims_SLQSSetRegMgrConfig . . . 900
9.7.1.22 unpack_ims_SLQSSetSIPConfig . . . 900
9.8 imsa.h File Reference . . . 900
9.8.1 Function Documentation . . . 901
9.8.1.1 pack_imsa_SLQSGetIMSARegStatus . . . 901
9.8.1.2 pack_imsa_SLQSGetIMSAServiceStatus . . . 901
9.8.1.3 pack_imsa_SLQSRegisterIMSAIndication . . . 902
9.8.1.4 unpack_imsa_SLQSGetIMSARegStatus . . . 902
9.8.1.5 unpack_imsa_SLQSGetIMSAServiceStatus . . . 903
9.8.1.6 unpack_imsa_SLQSRegisterIMSAIndication . . . 903
9.9 lite-fw.h File Reference . . . 904
9.9.1 Detailed Description . . . 905
9.9.2 Macro Definition Documentation . . . 905
9.9.2.1 FIRMWARE_INFO_STRING_SIZE . . . 905
9.9.2.2 IMG_MASK_CLEAR . . . 905
9.9.2.3 IMG_MASK_GENERIC . . . 905
9.9.2.4 IMG_MASK_MDM . . . 905
9.9.2.5 IMG_MASK_PRI . . . 905
9.9.2.6 libSDP_BuildImagesPreferenceRequest . . . 905
9.9.2.7 libSDP_CalculateImageMask . . . 906
9.9.2.8 LIBSDP_CARRIER_PACKAGE_SKU . . . 906
9.9.2.9 libSDP_CheckValidFirmwareInfo . . . 906
9.9.2.10 libSDP_DownloadFW . . . 906
9.9.2.11 libSDP_ExtractFirmwareParametersByPath . . . 906
9.9.2.12 libSDP_getFileType . . . 906

9.9.2.13 libSDP_GetModelFamily . . . 906
9.9.2.14 libSDP_GetVersion . . . 906
9.9.2.15 libsdp_set_log_func . . . 906
9.9.2.16 libsdp_SetReadBlockSize . . . 906
9.9.2.17 LIBSDP_SKU_STRING_LENGTH . . . 906
9.9.2.18 LITEFW_CARRIER_PACKAGE_SKU . . . 906
9.9.2.19 LITEFW_SKU_STRING_LENGTH . . . 906
9.9.3 Typedef Documentation . . . 906
9.9.3.1 libSDP_FirmwareInfo . . . 906
9.9.3.2 libsdplogger . . . 906
9.9.3.3 litefw_FirmwareInfo . . . 906
9.9.3.4 litefwlogger . . . 907
9.9.4 Enumeration Type Documentation . . . 907
9.9.4.1 litefw_Fw_Type . . . 907
9.9.4.2 litefw_fwdwl_error_codes . . . 907
9.9.4.3 litefw_Models . . . 908
9.9.5 Function Documentation . . . 908
9.9.5.1 litefw_BuildImagesPreferenceRequest . . . 908
9.9.5.2 litefw_CalculateImageMask . . . 908
9.9.5.3 litefw_CheckValidFirmwareInfo . . . 908
9.9.5.4 litefw_DownloadFW . . . 909
9.9.5.5 litefw_ExtractFirmwareParametersByPath . . . 909
9.9.5.6 litefw_getFileType . . . 910
9.9.5.7 litefw_GetModelFamily . . . 910
9.9.5.8 litefw_GetVersion . . . 910
9.9.5.9 litefw_logsenable . . . 911
9.9.5.10 litefw_set_log_func . . . 911
9.9.5.11 litefw_SetReadBlockSize . . . 911
9.9.5.12 litefw_switch_9x07_to_downloadmode . . . 911
9.9.5.13 litefw_switch_to_BootHoldMode . . . 912
9.10 loc.h File Reference . . . 912
9.10.1 Macro Definition Documentation . . . 915
9.10.1.1 LOC_UINT8_MAX_STRING_SZ . . . 915
9.10.1.2 LOCEVENTMASKBATCHFULLNOTIFICATION . . . 915
9.10.1.3 LOCEVENTMASKENGINESTATE . . . 915
9.10.1.4 LOCEVENTMASKFIXSESSIONSTATE . . . 915
9.10.1.5 LOCEVENTMASKGEOFENCEBATCHBREACHNOTIFICATION . . . 915
9.10.1.6 LOCEVENTMASKGEOFENCEBREACHNOTIFICATION . . . 915
9.10.1.7 LOCEVENTMASKGEOFENCEGENALERT . . . 915
9.10.1.8 LOCEVENTMASKGNSSMEASUREMENTREPORT . . . 915

9.10.1.9 LOCEVENTMASKGNSSSVINFO . . . 915
9.10.1.10 LOCEVENTMASKINJECTPOSITIONREQ . . . 915
9.10.1.11 LOCEVENTMASKINJECTPREDICTEDORBITSREQ . . . 915
9.10.1.12 LOCEVENTMASKINJECTTIMEREQ . . . 916
9.10.1.13 LOCEVENTMASKINJECTWIFIAPDATAREQ . . . 916
9.10.1.14 LOCEVENTMASKINVALIDVALUE . . . 916
9.10.1.15 LOCEVENTMASKLIVEBATCHEDPOSITIONREPORT . . . 916
9.10.1.16 LOCEVENTMASKLOCATIONSERVERCONNECTIONREQ . . . 916
9.10.1.17 LOCEVENTMASKMOTIONDATACONTROL . . . 916
9.10.1.18 LOCEVENTMASKNIGEOFENCENOTIFICATION . . . 916
9.10.1.19 LOCEVENTMASKNINOTIFYVERIFYREQ . . . 916
9.10.1.20 LOCEVENTMASKNMEA . . . 916
9.10.1.21 LOCEVENTMASKPEDOMETERCONTROL . . . 916
9.10.1.22 LOCEVENTMASKPOSITIONREPORT . . . 916
9.10.1.23 LOCEVENTMASKSENSORSTREAMINGREADYSTATUS . . . 917
9.10.1.24 LOCEVENTMASKSETSPISTREAMINGREPORT . . . 917
9.10.1.25 LOCEVENTMASKTIMESYNCREQ . . . 917
9.10.1.26 LOCEVENTMASKVEHICLEDATAREADYSTATUS . . . 917
9.10.1.27 LOCEVENTMASKWIFIREQ . . . 917
9.10.1.28 MAX_LOC_NMEA_STR_LEN . . . 917
9.10.1.29 MAX_SENSOR_DATA_LEN . . . 917
9.10.1.30 MAX_TEMP_DATA_LEN . . . 917
9.10.2 Enumeration Type Documentation . . . 917
9.10.2.1 anonymous enum . . . 917
9.10.3 Function Documentation . . . 917
9.10.3.1 pack_loc_DeleteAssistData . . . 917
9.10.3.2 pack_loc_EventRegister . . . 918
9.10.3.3 pack_loc_SetExtPowerState . . . 918
9.10.3.4 pack_loc_SetOperationMode . . . 918
9.10.3.5 pack_loc_SLQSLOCGetBestAvailPos . . . 919
9.10.3.6 pack_loc_SLQSLOCGetServer . . . 919
9.10.3.7 pack_loc_SLQSLOCInjectPosition . . . 920
9.10.3.8 pack_loc_SLQSLOCInjectSensorData . . . 920
9.10.3.9 pack_loc_SLQSLOCInjectUTCTime . . . 920
9.10.3.10 pack_loc_SLQSLOCSetCradleMountConfig . . . 921
9.10.3.11 pack_loc_Start . . . 921
9.10.3.12 pack_loc_Stop . . . 921
9.10.3.13 unpack_loc_BestAvailPos_Ind . . . 922
9.10.3.14 unpack_loc_DeleteAssistData . . . 922
9.10.3.15 unpack_loc_DeleteAssistData_Ind . . . 923

9.10.3.16 unpack_loc_EngineState_Ind . . . 923
9.10.3.17 unpack_loc_EventNMEA_Ind . . . 923
9.10.3.18 unpack_loc_EventRegister . . . 924
9.10.3.19 unpack_loc_GetServer_Ind . . . 924
9.10.3.20 unpack_loc_GnssSvInfo_Ind . . . 924
9.10.3.21 unpack_loc_PositionRpt_Ind . . . 925
9.10.3.22 unpack_loc_SetExtPowerConfig_Ind . . . 925
9.10.3.23 unpack_loc_SetExtPowerState . . . 925
9.10.3.24 unpack_loc_SetOperationMode . . . 926
9.10.3.25 unpack_loc_SetOperationMode_Ind . . . 926
9.10.3.26 unpack_loc_SLQSLOCGetBestAvailPos . . . 926
9.10.3.27 unpack_loc_SLQSLOCGetServer . . . 927
9.10.3.28 unpack_loc_SLQSLOCInjectPosition . . . 927
9.10.3.29 unpack_loc_SLQSLOCInjectSensorData . . . 927
9.10.3.30 unpack_loc_SLQSLOCInjectUTCTime . . . 928
9.10.3.31 unpack_loc_SLQSLOCSetCradleMountConfig . . . 928
9.10.3.32 unpack_loc_Start . . . 928
9.10.3.33 unpack_loc_Stop . . . 929
9.11 nas.h File Reference . . . 929
9.11.1 Macro Definition Documentation . . . 937
9.11.1.1 NAS_IMSI_M_S1_LENGTH . . . 937
9.11.1.2 NAS_IMSI_M_S2_LENGTH . . . 937
9.11.1.3 NAS_MAX_DESCRIPTION_LENGTH . . . 937
9.11.1.4 NAS_MAX_NUM_NETWORKS . . . 937
9.11.1.5 NAS_MAX_SCC_RX_INFO_INSTANCES . . . 937
9.11.1.6 NAS_NAM_NAME_LENGTH . . . 937
9.11.1.7 NAS_OTA_MESSAGE_MAX_BUF_SIZE . . . 937
9.11.1.8 NAS_PLMN_LENGTH . . . 937
9.11.1.9 NAS_SERVING_SYSTEM_INFO_MAX_RADIO_INTERFACE_LIST . . . 937
9.11.2 Enumeration Type Documentation . . . 937
9.11.2.1 LITEQMI_NAS_LTE_CPHY_CA_BW_NRB . . . 937
9.11.2.2 LITEQMI_NAS_LTE_CPHY_SCELL_STATE . . . 937
9.11.2.3 NAS_LTE_CPHY_CA_BW_NRB_LITE . . . 938
9.11.2.4 NAS_LTE_CPHY_SCELL_STATE_LITE . . . 938
9.11.3 Function Documentation . . . 938
9.11.3.1 pack_nas_GetACCOLC . . . 938
9.11.3.2 pack_nas_GetANAAAAuthenticationStatus . . . 938
9.11.3.3 pack_nas_GetCDMANetworkParameters . . . 939
9.11.3.4 pack_nas_GetHomeNetwork . . . 939
9.11.3.5 pack_nas_GetHomeNetwork3GPP2 . . . 939

9.11.3.6 pack_nas_GetNetworkPreference . . . 940
9.11.3.7 pack_nas_GetRFInfo . . . 940
9.11.3.8 pack_nas_GetServingNetwork . . . 940
9.11.3.9 pack_nas_GetServingNetworkCapabilities . . . 940
9.11.3.10 pack_nas_GetSignalStrengths . . . 941
9.11.3.11 pack_nas_InitiateDomainAttach . . . 941
9.11.3.12 pack_nas_PerformNetworkScan . . . 941
9.11.3.13 pack_nas_SetACCOLC . . . 942
9.11.3.14 pack_nas_SetCDMANetworkParameters . . . 942
9.11.3.15 pack_nas_SetLURejectCallback . . . 943
9.11.3.16 pack_nas_SetNetworkPreference . . . 943
9.11.3.17 pack_nas_SetRFInfoCallback . . . 943
9.11.3.18 pack_nas_SLQSConfigSigInfo . . . 944
9.11.3.19 pack_nas_SLQSGetErrorRate . . . 944
9.11.3.20 pack_nas_SlqsGetLTECphyCAInfo . . . 944
9.11.3.21 pack_nas_SLQSGetNetworkTime . . . 944
9.11.3.22 pack_nas_SLQSGetOperatorNameData . . . 945
9.11.3.23 pack_nas_SLQSGetPLMNName . . . 945
9.11.3.24 pack_nas_SLQSGetServingSystem . . . 945
9.11.3.25 pack_nas_SLQSGetSignalStrength . . . 946
9.11.3.26 pack_nas_SLQSGetSysInfo . . . 946
9.11.3.27 pack_nas_SLQSGetSysSelectionPref . . . 947
9.11.3.28 pack_nas_SLQSInitiateNetworkRegistration . . . 947
9.11.3.29 pack_nas_SLQSNasConfigSigInfo2 . . . 947
9.11.3.30 pack_nas_SLQSNasGet3GPP2Subscription . . . 948
9.11.3.31 pack_nas_SLQSNasGetCellLocationInfo . . . 948
9.11.3.32 pack_nas_SLQSNASGeteDRXParams . . . 948
9.11.3.33 pack_nas_SLQSNasGetHDRColorCode . . . 949
9.11.3.34 pack_nas_SLQSNasGetSigInfo . . . 949
9.11.3.35 pack_nas_SLQSNasGetTxRxInfo . . . 949
9.11.3.36 pack_nas_SLQSNasIndicationRegisterExt . . . 950
9.11.3.37 pack_nas_SLQSNASSeteDRXParams . . . 950
9.11.3.38 pack_nas_SLQSNASSwiGetChannelLock . . . 951
9.11.3.39 pack_nas_SLQSNasSwiIndicationRegister . . . 951
9.11.3.40 pack_nas_SLQSNasSwiModemStatus . . . 951
9.11.3.41 pack_nas_SLQSNASSwiSetChannelLock . . . 952
9.11.3.42 pack_nas_SLQSSetBandPreference . . . 952
9.11.3.43 pack_nas_SLQSSetSignalStrengthsCallback . . . 952
9.11.3.44 pack_nas_SLQSSetSysSelectionPref . . . 953
9.11.3.45 pack_nas_SLQSSwiGetHDRPersonality . . . 953

9.11.3.46 pack_nas_SLQSSwiGetHDRProtSubtype . . . 953
9.11.3.47 pack_nas_SLQSSwiGetHRPDStats . . . 954
9.11.3.48 pack_nas_SLQSSwiGetLteCQI . . . 954
9.11.3.49 pack_nas_SLQSSwiGetLteSccRxInfo . . . 954
9.11.3.50 pack_nas_SLQSSwiNetworkDebug . . . 955
9.11.3.51 pack_nas_SLQSSwiPSDetach . . . 955
9.11.3.52 unpack_nas_GetACCOLC . . . 955
9.11.3.53 unpack_nas_GetANAAAAuthenticationStatus . . . 956
9.11.3.54 unpack_nas_GetCDMANetworkParameters . . . 956
9.11.3.55 unpack_nas_GetHomeNetwork . . . 957
9.11.3.56 unpack_nas_GetHomeNetwork3GPP2 . . . 957
9.11.3.57 unpack_nas_GetNetworkPreference . . . 957
9.11.3.58 unpack_nas_GetRFInfo . . . 958
9.11.3.59 unpack_nas_GetServingNetwork . . . 958
9.11.3.60 unpack_nas_GetServingNetworkCapabilities . . . 958
9.11.3.61 unpack_nas_GetSignalStrengths . . . 959
9.11.3.62 unpack_nas_InitiateDomainAttach . . . 959
9.11.3.63 unpack_nas_PerformNetworkScan . . . 959
9.11.3.64 unpack_nas_SetACCOLC . . . 960
9.11.3.65 unpack_nas_SetCDMANetworkParameters . . . 960
9.11.3.66 unpack_nas_SetDataCapabilitiesCallback_ind . . . 960
9.11.3.67 unpack_nas_SetEventReportInd . . . 961
9.11.3.68 unpack_nas_SetLURejectCallback . . . 961
9.11.3.69 unpack_nas_SetNasLTECphyCaIndCallback_ind . . . 961
9.11.3.70 unpack_nas_SetNetworkPreference . . . 962
9.11.3.71 unpack_nas_SetRFInfoCallback . . . 962
9.11.3.72 unpack_nas_SetRoamingIndicatorCallback_ind . . . 962
9.11.3.73 unpack_nas_SetServingSystemCallback_ind . . . 963
9.11.3.74 unpack_nas_SLQSConfigSigInfo . . . 963
9.11.3.75 unpack_nas_SLQSGetErrorRate . . . 963
9.11.3.76 unpack_nas_SlqsGetLTECphyCAInfo . . . 964
9.11.3.77 unpack_nas_SLQSGetNetworkTime . . . 964
9.11.3.78 unpack_nas_SLQSGetOperatorNameData . . . 965
9.11.3.79 unpack_nas_SLQSGetPLMNName . . . 965
9.11.3.80 unpack_nas_SLQSGetServingSystem . . . 965
9.11.3.81 unpack_nas_SLQSGetSignalStrength . . . 966
9.11.3.82 unpack_nas_SLQSGetSysInfo . . . 966
9.11.3.83 unpack_nas_SLQSGetSysSelectionPref . . . 966
9.11.3.84 unpack_nas_SLQSInitiateNetworkRegistration . . . 967
9.11.3.85 unpack_nas_SLQSNasConfigSigInfo2 . . . 967

9.11.3.86 unpack_nas_SLQSNasGet3GPP2Subscription . . . 967
9.11.3.87 unpack_nas_SLQSNasGetCellLocationInfo . . . 968
9.11.3.88 unpack_nas_SLQSNASGeteDRXParams . . . 968
9.11.3.89 unpack_nas_SLQSNasGetHDRColorCode . . . 969
9.11.3.90 unpack_nas_SLQSNasGetSigInfo . . . 969
9.11.3.91 unpack_nas_SLQSNasGetTxRxInfo . . . 969
9.11.3.92 unpack_nas_SLQSNasIndicationRegisterExt . . . 970
9.11.3.93 unpack_nas_SLQSNasNetworkTimeCallBack_ind . . . 970
9.11.3.94 unpack_nas_SLQSNASSeteDRXParams . . . 970
9.11.3.95 unpack_nas_SLQSNasSigInfoCallback_ind . . . 971
9.11.3.96 unpack_nas_SLQSNASSwiGetChannelLock . . . 971
9.11.3.97 unpack_nas_SLQSNasSwiIndicationRegister . . . 971
9.11.3.98 unpack_nas_SLQSNasSwiModemStatus . . . 972
9.11.3.99 unpack_nas_SLQSNasSwiOTAMessageCallback_ind . . . 972
9.11.3.100 unpack_nas_SLQSNASSwiSetChannelLock . . . 972
9.11.3.101 unpack_nas_SLQSNasSysInfoCallback_ind . . . 973
9.11.3.102 unpack_nas_SLQSNasTimerCallback_ind . . . 973
9.11.3.103 unpack_nas_SLQSSetBandPreference . . . 973
9.11.3.104 unpack_nas_SLQSSetSignalStrengthsCallback . . . 974
9.11.3.105 unpack_nas_SLQSSetSysSelectionPref . . . 974
9.11.3.106 unpack_nas_SLQSSetSysSelectionPrefCallBack_ind . . . 974
9.11.3.107 unpack_nas_SLQSSwiGetHDRPersonality . . . 975
9.11.3.108 unpack_nas_SLQSSwiGetHDRProtSubtype . . . 975
9.11.3.109 unpack_nas_SLQSSwiGetHRPDStats . . . 975
9.11.3.110 unpack_nas_SLQSSwiGetLteCQI . . . 976
9.11.3.111 unpack_nas_SLQSSwiGetLteSccRxInfo . . . 976
9.11.3.112 unpack_nas_SLQSSwiNetworkDebug . . . 976
9.11.3.113 unpack_nas_SLQSSwiPSDetach . . . 977
9.11.3.114 unpack_valid_nas_GetCDMANetworkParameters . . . 977
9.11.3.115 unpack_valid_nas_SLQSGetServingSystem . . . 977
9.11.3.116 unpack_valid_nas_SLQSGetSignalStrength . . . 978
9.11.3.117 unpack_valid_nas_SLQSNasGetSigInfo . . . 979
9.12 pds.h File Reference . . . 979
9.12.1 Function Documentation . . . 981
9.12.1.1 pack_pds_ForceXTRADownload . . . 981
9.12.1.2 pack_pds_GetPDSDefaults . . . 982
9.12.1.3 pack_pds_GetPDSState . . . 982
9.12.1.4 pack_pds_GetPortAutomaticTracking . . . 982
9.12.1.5 pack_pds_GetServiceAutomaticTracking . . . 983
9.12.1.6 pack_pds_GetXTRAAutomaticDownload . . . 983

9.12.1.7 pack_pds_GetXTRANetwork . . . 983
9.12.1.8 pack_pds_GetXTRAValidity . . . 984
9.12.1.9 pack_pds_PDSInjectTimeReference . . . 984
9.12.1.10 pack_pds_ResetPDSData . . . 984
9.12.1.11 pack_pds_SetEventReportCallback . . . 985
9.12.1.12 pack_pds_SetPDSDefaults . . . 985
9.12.1.13 pack_pds_SetPDSState . . . 985
9.12.1.14 pack_pds_SetPortAutomaticTracking . . . 986
9.12.1.15 pack_pds_SetServiceAutomaticTracking . . . 986
9.12.1.16 pack_pds_SetXTRAAutomaticDownload . . . 986
9.12.1.17 pack_pds_SetXTRANetwork . . . 987
9.12.1.18 pack_pds_SLQSGetAGPSConfig . . . 987
9.12.1.19 pack_pds_SLQSGetGPSStateInfo . . . 988
9.12.1.20 pack_pds_SLQSPDSDeterminePosition . . . 988
9.12.1.21 pack_pds_SLQSPDSInjectAbsoluteTimeReference . . . 988
9.12.1.22 pack_pds_SLQSPDSInjectPositionData . . . 989
9.12.1.23 pack_pds_SLQSSetAGPSConfig . . . 989
9.12.1.24 pack_pds_SLQSSetPositionMethodState . . . 989
9.12.1.25 pack_pds_StartPDSTrackingSessionExt . . . 990
9.12.1.26 pack_pds_StopPDSTrackingSession . . . 990
9.12.1.27 unpack_pds_ForceXTRADownload . . . 990
9.12.1.28 unpack_pds_GetPDSDefaults . . . 991
9.12.1.29 unpack_pds_GetPDSState . . . 991
9.12.1.30 unpack_pds_GetPortAutomaticTracking . . . 991
9.12.1.31 unpack_pds_GetServiceAutomaticTracking . . . 992
9.12.1.32 unpack_pds_GetXTRAAutomaticDownload . . . 992
9.12.1.33 unpack_pds_GetXTRANetwork . . . 992
9.12.1.34 unpack_pds_GetXTRAValidity . . . 993
9.12.1.35 unpack_pds_PDSInjectTimeReference . . . 993
9.12.1.36 unpack_pds_ResetPDSData . . . 993
9.12.1.37 unpack_pds_SetEventReport_Ind . . . 994
9.12.1.38 unpack_pds_SetEventReportCallback . . . 994
9.12.1.39 unpack_pds_SetPDSDefaults . . . 994
9.12.1.40 unpack_pds_SetPDSState . . . 995
9.12.1.41 unpack_pds_SetPdsState_Ind . . . 995
9.12.1.42 unpack_pds_SetPortAutomaticTracking . . . 995
9.12.1.43 unpack_pds_SetServiceAutomaticTracking . . . 996
9.12.1.44 unpack_pds_SetXTRAAutomaticDownload . . . 996
9.12.1.45 unpack_pds_SetXTRANetwork . . . 996
9.12.1.46 unpack_pds_SLQSGetAGPSConfig . . . 997

9.12.1.47 unpack_pds_SLQSGetGPSStateInfo . . . 997
9.12.1.48 unpack_pds_SLQSPDSDeterminePosition . . . 997
9.12.1.49 unpack_pds_SLQSPDSInjectAbsoluteTimeReference . . . 998
9.12.1.50 unpack_pds_SLQSPDSInjectPositionData . . . 998
9.12.1.51 unpack_pds_SLQSSetAGPSConfig . . . 998
9.12.1.52 unpack_pds_SLQSSetPositionMethodState . . . 999
9.12.1.53 unpack_pds_StartPDSTrackingSessionExt . . . 999
9.12.1.54 unpack_pds_StopPDSTrackingSession . . . 999
9.13 qaGobiApiTableBandClasses.h File Reference . . . 1000
9.13.1 Detailed Description . . . 1000
9.13.2 Band Classes (Value - Description) . . . 1000
9.13.2.1 LTE Bands . . . 1001
9.14 qaGobiApiTableCallControlReturnReasons.h File Reference . . . 1003
9.14.1 Detailed Description . . . 1003
9.14.2 S1 . . . 1003
9.15 qaGobiApiTableCallEndReasons.h File Reference . . . 1003
9.15.1 Detailed Description . . . 1003
9.15.2 Call end reason codes (Code - Reason) . . . 1004
9.15.2.1 Technology-agnostic call end reasons . . . 1004
9.15.2.2 EVDO CDMA 1xEV-DO . . . 1004
9.15.2.3 WCDMA/GSM call end reasons . . . 1005
9.15.2.4 EVDO CDMA 1xEV-DO . . . 1007
9.15.2.5 call end reason type . . . 1007
9.15.2.6 Mobile IP call end reasons (Type=1) . . . 1007
9.15.2.7 Internal call end reasons (Type=2) . . . 1009
9.15.2.8 Call Manager defined call end reasons (Type=3) . . . 1012
9.15.2.9 3GPP specification defined call end reasons (Type=6) . . . 1016
9.15.2.10 PPP call end reasons (Type=7) . . . 1018
9.15.2.11 EHRPD call end reasons (Type=8) . . . 1019
9.15.2.12 IPV6 call end reasons (Type=9) . . . 1020
9.16 qaGobiApiTableCarrierCodes.h File Reference . . . 1020
9.16.1 Detailed Description . . . 1020
9.16.2 Carrier Codes (Number - Carrier) . . . 1020
9.17 qaGobiApiTableCodingScheme.h File Reference . . . 1022
9.17.1 Detailed Description . . . 1022
9.17.2 S1 . . . 1022
9.17.2.1 Use of bits 3..0\n\n . . . 1022
9.17.3 Coding Group Bits 7..4(0001) . . . 1022
9.17.3.1 use of bits 3..0 . . . 1022
9.17.4 Coding Group Bits 7..4(0010) . . . 1023

9.17.4.1 use of bits 3..0 . . . 1023
9.17.5 Coding Group Bits 7..4(0011) . . . 1023
9.17.5.1 use of bits 3..0 . . . 1023
9.17.6 Coding Group Bits 7..4(01xx) . . . 1023
9.17.6.1 use of bits 3..0 . . . 1023
9.17.7 Coding Group Bits 7..4(1001) . . . 1024
9.17.7.1 Reserved coding groups . . . 1024
9.17.8 Coding Group Bits 7..4(1010..1101) . . . 1024
9.17.8.1 Reserved coding groups . . . 1024
9.17.9 Coding Group Bits 7..4(1110) . . . 1024
9.17.9.1 Defined by the WAP Forum . . . 1024
9.17.10 Coding Group Bits 7..4 (1111) . . . 1024
9.17.10.1 Data coding / message handling . . . 1024
9.17.11 Macro Definition Documentation . . . 1024
9.17.11.1 __GOBI_API_CODING_SCHEME_H__ . . . 1024
9.18 qaGobiApiTableGpsCapabilityCodes.h File Reference . . . 1024
9.18.1 Detailed Description . . . 1025
9.18.2 GPS capability (Value - Capability) . . . 1025
9.19 qaGobiApiTablePowerModes.h File Reference . . . 1025
9.19.1 Detailed Description . . . 1025
9.19.2 Power Modes (Value - Description) . . . 1025
9.20 qaGobiApiTableRadioInterfaces.h File Reference . . . 1026
9.20.1 Detailed Description . . . 1026
9.20.2 Radio interface . . . 1026
9.20.2.1 Technology (Value - Radio Interface Technology) . . . 1026
9.21 qaGobiApiTableRegionCodes.h File Reference . . . 1026
9.21.1 Detailed Description . . . 1026
9.21.2 Region Codes (Code - Region) . . . 1026
9.22 qaGobiApiTableServiceOptions.h File Reference . . . 1027
9.22.1 Detailed Description . . . 1027
9.22.2 Service Option codes (Code - Reason) . . . 1027
9.22.2.1 Description . . . 1027
9.23 qaGobiApiTableSupServiceInfoClasses.h File Reference . . . 1029
9.23.1 Detailed Description . . . 1029
9.23.2 Supplementary Service Information Classes (Value - Service Class) . . . 1029
9.24 qaGobiApiTableSwiAudio.h File Reference . . . 1029
9.24.1 Detailed Description . . . 1029
9.24.2 ACDB Device (Device ID - description) . . . 1030
9.24.3 Physical Interface (Device ID - description - Interface parameters) . . . 1030
9.25 qaGobiApiTableSwiOMADMSessionStatus.h File Reference . . . 1030

9.25.1 Detailed Description . . . 1030
9.25.2 OMA DM Session Status (Session Status - Meaning - Usage) . . . 1030
9.26 qaGobiApiTableSwiOMADMUpdateCompleteStatus.h File Reference . . . 1031
9.26.1 Detailed Description . . . 1031
9.26.2 OMA DM Update Complete Status (Update Complete Status - Meaning - Usage) . . . 1031
9.27 qaGobiApiTableVoiceCallEndReasons.h File Reference . . . 1032
9.27.1 Detailed Description . . . 1032
9.27.2 Voice Call and supplementary services end reason codes (Code - Reason) . . . 1033
9.27.2.1 General . . . 1033
9.27.2.2 service Errors . . . 1034
9.27.2.3 control cause values . . . 1035
9.27.2.4 reject causes . . . 1037
9.27.2.5 reject causes . . . 1037
9.27.2.6 reject causes . . . 1038
9.27.2.7 stratum reject causes . . . 1038
9.27.2.8 reject causes . . . 1038
9.27.2.9 IP end reasons . . . 1038
9.28 qmerrno.h File Reference . . . 1039
9.28.1 Enumeration Type Documentation . . . 1041
9.28.1.1 eQCWWANError . . . 1041
9.28.1.2 qm_wds_ds_profile_extended_err_codes . . . 1046
9.29 qos.h File Reference . . . 1046
9.29.1 Macro Definition Documentation . . . 1048
9.29.1.1 LITEQMI_MAX_QOS_FILTERS . . . 1048
9.29.1.2 LITEQMI_MAX_QOS_FLOW_PER_APN_STATS . . . 1048
9.29.1.3 LITEQMI_MAX_QOS_FLOWS . . . 1048
9.29.2 Function Documentation . . . 1048
9.29.2.1 pack_qos_BindDataPort . . . 1048
9.29.2.2 pack_qos_SLQSQosGetNetworkStatus . . . 1048
9.29.2.3 pack_qos_SLQSQosSwiReadApnExtraParams . . . 1049
9.29.2.4 pack_qos_SLQSQosSwiReadDataStats . . . 1050
9.29.2.5 pack_qos_SLQSSetQosEventCallback . . . 1050
9.29.2.6 unpack_qos_BindDataPort . . . 1051
9.29.2.7 unpack_qos_SLQSQosGetNetworkStatus . . . 1051
9.29.2.8 unpack_qos_SLQSQosSwiReadApnExtraParams . . . 1052
9.29.2.9 unpack_qos_SLQSQosSwiReadDataStats . . . 1052
9.29.2.10 unpack_qos_SLQSSetQosEventCallback . . . 1053
9.29.2.11 unpack_qos_SLQSSetQosEventCallback_ind . . . 1053
9.29.2.12 unpack_qos_SLQSSetQosNWStatusCallback_ind . . . 1054
9.29.2.13 unpack_qos_SLQSSetQosPriEventCallback_ind . . . 1054

9.29.2.14 unpack_qos_SLQSSetQosStatusCallback_ind . . . 1055
9.30 rms.h File Reference . . . 1056
9.30.1 Function Documentation . . . 1056
9.30.1.1 pack_rms_GetSMSWake . . . 1056
9.30.1.2 pack_rms_SetSMSWake . . . 1056
9.30.1.3 unpack_rms_GetSMSWake . . . 1057
9.30.1.4 unpack_rms_SetSMSWake . . . 1057
9.31 sar.h File Reference . . . 1057
9.31.1 Function Documentation . . . 1058
9.31.1.1 pack_sar_SLQSGetRfSarState . . . 1058
9.31.1.2 pack_sar_SLQSSetRfSarState . . . 1058
9.31.1.3 unpack_sar_SLQSGetRfSarState . . . 1058
9.31.1.4 unpack_sar_SLQSSetRfSarState . . . 1059
9.32 sms.h File Reference . . . 1059
9.32.1 Macro Definition Documentation . . . 1062
9.32.1.1 MAX_CDMA_ENC_MO_TXT_MSG_SIZE . . . 1062
9.32.1.2 MAX_MS_TRANSFER_ROUTE_MSG . . . 1062
9.32.1.3 MAX_MSC_ADDRESS_SIZE . . . 1062
9.32.1.4 MAX_MSE_TWS_MSG . . . 1062
9.32.1.5 MAX_SMS_LIST_SIZE . . . 1062
9.32.1.6 MAX_SMS_MESSAGE_SIZE . . . 1062
9.32.1.7 SMS_CONFIG_LEN . . . 1062
9.32.1.8 SMS_MAX_SMS_ROUTES . . . 1062
9.32.1.9 SMS_NUM_OF_SET . . . 1062
9.32.1.10 SMSC_TYPE_LEN . . . 1062
9.32.2 Enumeration Type Documentation . . . 1063
9.32.2.1 eqmiCbkSetStatus . . . 1063
9.32.3 Function Documentation . . . 1063
9.32.3.1 pack_sms_GetSMSCAddress . . . 1063
9.32.3.2 pack_sms_SaveSMS . . . 1063
9.32.3.3 pack_sms_SendSMS . . . 1063
9.32.3.4 pack_sms_SetNewSMSCallback . . . 1064
9.32.3.5 pack_sms_SetSMSCAddress . . . 1064
9.32.3.6 pack_sms_SLQSDeleteSMS . . . 1065
9.32.3.7 pack_sms_SLQSGetIndicationRegister . . . 1065
9.32.3.8 pack_sms_SLQSGetMessageWaiting . . . 1065
9.32.3.9 pack_sms_SLQSGetSMS . . . 1066
9.32.3.10 pack_sms_SLQSGetSmsBroadcastConfig . . . 1066
9.32.3.11 pack_sms_SLQSGetSMSList . . . 1066
9.32.3.12 pack_sms_SLQSGetTransLayerInfo . . . 1067

9.32.3.13 pack_sms_SLQSGetTransNWRegInfo . . . 1067
9.32.3.14 pack_sms_SLQSModifySMSStatus . . . 1067
9.32.3.15 pack_sms_SLQSSendAsyncSMS . . . 1068
9.32.3.16 pack_sms_SLQSSetIndicationRegister . . . 1068
9.32.3.17 pack_sms_SLQSSetSmsBroadcastActivation . . . 1068
9.32.3.18 pack_sms_SLQSSetSmsBroadcastConfig . . . 1069
9.32.3.19 pack_sms_SLQSSetSmsStorage . . . 1069
9.32.3.20 pack_sms_SLQSSmsGetMaxStorageSize . . . 1070
9.32.3.21 pack_sms_SLQSSmsGetMessageProtocol . . . 1070
9.32.3.22 pack_sms_SLQSSmsSetRoutes . . . 1070
9.32.3.23 pack_sms_SLQSSwiGetSMSStorage . . . 1071
9.32.3.24 unpack_sms_GetSMSCAddress . . . 1071
9.32.3.25 unpack_sms_SaveSMS . . . 1071
9.32.3.26 unpack_sms_SendSMS . . . 1072
9.32.3.27 unpack_sms_SetNewSMSCallback . . . 1072
9.32.3.28 unpack_sms_SetNewSMSCallback_ind . . . 1072
9.32.3.29 unpack_sms_SetSMSCAddress . . . 1073
9.32.3.30 unpack_sms_SLQSDeleteSMS . . . 1073
9.32.3.31 unpack_sms_SLQSGetIndicationRegister . . . 1073
9.32.3.32 unpack_sms_SLQSGetMessageWaiting . . . 1074
9.32.3.33 unpack_sms_SLQSGetSMS . . . 1074
9.32.3.34 unpack_sms_SLQSGetSmsBroadcastConfig . . . 1074
9.32.3.35 unpack_sms_SLQSGetSMSList . . . 1075
9.32.3.36 unpack_sms_SLQSGetTransLayerInfo . . . 1075
9.32.3.37 unpack_sms_SLQSGetTransNWRegInfo . . . 1075
9.32.3.38 unpack_sms_SLQSModifySMSStatus . . . 1076
9.32.3.39 unpack_sms_SLQSSendAsyncSMS . . . 1076
9.32.3.40 unpack_sms_SLQSSetIndicationRegister . . . 1076
9.32.3.41 unpack_sms_SLQSSetSmsBroadcastActivation . . . 1077
9.32.3.42 unpack_sms_SLQSSetSmsBroadcastConfig . . . 1077
9.32.3.43 unpack_sms_SLQSSetSmsStorage . . . 1077
9.32.3.44 unpack_sms_SLQSSmsGetMaxStorageSize . . . 1078
9.32.3.45 unpack_sms_SLQSSmsGetMessageProtocol . . . 1078
9.32.3.46 unpack_sms_SLQSSmsSetRoutes . . . 1078
9.32.3.47 unpack_sms_SLQSSwiGetSMSStorage . . . 1079
9.32.3.48 unpack_sms_SLQSWmsMemoryFullCallBack_ind . . . 1079
9.33 swiaudio.h File Reference . . . 1079
9.33.1 Macro Definition Documentation . . . 1081
9.33.1.1 SWIAUDIO_MAX_LEN_IFACE_TABLE . . . 1081
9.33.2 Function Documentation . . . 1081

9.33.2.1 pack_swiaudio_SLQSGetM2MAudioProfile . . . 1081
9.33.2.2 pack_swiaudio_SLQSGetM2MAudioVolume . . . 1081
9.33.2.3 pack_swiaudio_SLQSGetM2MAVMute . . . 1081
9.33.2.4 pack_swiaudio_SLQSGetM2MSpkrGain . . . 1082
9.33.2.5 pack_swiaudio_SLQSSetM2MAudioAVCFG . . . 1082
9.33.2.6 pack_swiaudio_SLQSSetM2MAudioLPBK . . . 1082
9.33.2.7 pack_swiaudio_SLQSSetM2MAudioNVDef . . . 1083
9.33.2.8 pack_swiaudio_SLQSSetM2MAudioProfile . . . 1083
9.33.2.9 pack_swiaudio_SLQSSetM2MAudioVolume . . . 1084
9.33.2.10 pack_swiaudio_SLQSSetM2MAVMute . . . 1084
9.33.2.11 pack_swiaudio_SLQSSetM2MSpkrGain . . . 1084
9.33.2.12 unpack_swiaudio_SLQSGetM2MAudioProfile . . . 1085
9.33.2.13 unpack_swiaudio_SLQSGetM2MAudioVolume . . . 1085
9.33.2.14 unpack_swiaudio_SLQSGetM2MAVMute . . . 1085
9.33.2.15 unpack_swiaudio_SLQSGetM2MSpkrGain . . . 1086
9.33.2.16 unpack_swiaudio_SLQSSetM2MAudioAVCFG . . . 1086
9.33.2.17 unpack_swiaudio_SLQSSetM2MAudioLPBK . . . 1086
9.33.2.18 unpack_swiaudio_SLQSSetM2MAudioNVDef . . . 1087
9.33.2.19 unpack_swiaudio_SLQSSetM2MAudioProfile . . . 1087
9.33.2.20 unpack_swiaudio_SLQSSetM2MAudioVolume . . . 1087
9.33.2.21 unpack_swiaudio_SLQSSetM2MAVMute . . . 1088
9.33.2.22 unpack_swiaudio_SLQSSetM2MSpkrGain . . . 1088
9.34 swiavms.h File Reference . . . 1088
9.34.1 Macro Definition Documentation . . . 1090
9.34.1.1 LITEQMI_MAX_SWIOMA_STR_LEN . . . 1090
9.34.1.2 MAX_AVMS_SETTINGS_RETRY_TIMER_NUMBER . . . 1090
9.34.1.3 MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_DESC_LENGTH . . . 1090
9.34.1.4 MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_NAME_LENGTH . . . 1090
9.34.1.5 MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_VERSION_LENGTH . . . 1090
9.34.1.6 MAX_PACK_SWI_AVMS_SESSIONGETINFO_CONFIG_ALERT_MSG_LENGTH . . . 1090
9.34.1.7 MAX_PACK_SWI_AVMS_SET_SETTING_APN_LENGTH . . . 1090
9.34.1.8 MAX_PACK_SWI_AVMS_SET_SETTING_CONNECTION_RETRY_TIMMERS . 1090
9.34.1.9 MAX_PACK_SWI_AVMS_SET_SETTING_PWD_LENGTH . . . 1090
9.34.1.10 MAX_PACK_SWI_AVMS_SET_SETTING_UNAME_LENGTH . . . 1090
9.34.2 Function Documentation . . . 1090
9.34.2.1 pack_swiavms_SLQSAVMSGetSettings . . . 1090
9.34.2.2 pack_swiavms_SLQSAVMSSendSelection . . . 1091

9.34.2.3 pack_swiavms_SLQSAVMSSessionGetInfo . . . 1091
9.34.2.4 pack_swiavms_SLQSAvmsSetEventReport . . . 1092
9.34.2.5 pack_swiavms_SLQSAVMSSetSettings . . . 1093
9.34.2.6 pack_swiavms_SLQSAVMSSetSettingsNoAutoRebootField . . . 1093
9.34.2.7 pack_swiavms_SLQSAVMSStartSession . . . 1094
9.34.2.8 pack_swiavms_SLQSAVMSStopSession . . . 1094
9.34.2.9 unpack_swiavms_SLQSAVMSEventReportInd . . . 1095
9.34.2.10 unpack_swiavms_SLQSAVMSGetSettings . . . 1096
9.34.2.11 unpack_swiavms_SLQSAVMSSendSelection . . . 1096
9.34.2.12 unpack_swiavms_SLQSAVMSSessionGetInfo . . . 1096
9.34.2.13 unpack_swiavms_SLQSAvmsSetEventReport . . . 1097
9.34.2.14 unpack_swiavms_SLQSAVMSSetSettings . . . 1097
9.34.2.15 unpack_swiavms_SLQSAVMSStartSession . . . 1098
9.34.2.16 unpack_swiavms_SLQSAVMSStopSession . . . 1098
9.35 SwiDataTypes.h File Reference . . . 1099
9.35.1 Detailed Description . . . 1099
9.35.2 Macro Definition Documentation . . . 1099
9.35.2.1 QMI_NO_LTE_FW_SUPPORT . . . 1099
9.35.2.2 QMI_TLV_PLACEHOLDER . . . 1099
9.35.2.3 SWI_API . . . 1099
9.35.2.4 UNUSEDPARAM . . . 1100
9.35.3 Typedef Documentation . . . 1100
9.35.3.1 BOOL . . . 1100
9.35.3.2 BYTE . . . 1100
9.35.3.3 CHAR . . . 1100
9.35.3.4 FLOAT . . . 1100
9.35.3.5 INT32 . . . 1100
9.35.3.6 INT8 . . . 1100
9.35.3.7 LPCSTR . . . 1100
9.35.3.8 SHORT . . . 1100
9.35.3.9 ULONG . . . 1100
9.35.3.10 ULONGLONG . . . 1100
9.35.3.11 USHORT . . . 1100
9.35.3.12 WORD . . . 1100
9.36 swiloc.h File Reference . . . 1100
9.36.1 Function Documentation . . . 1100
9.36.1.1 pack_swiloc_SwiLocGetAutoStart . . . 1100
9.36.1.2 pack_swiloc_SwiLocSetAutoStart . . . 1101
9.36.1.3 unpack_swiloc_SwiLocGetAutoStart . . . 1101
9.36.1.4 unpack_swiloc_SwiLocSetAutoStart . . . 1102

9.37 swioma.h File Reference . . . 1102
9.37.1 Macro Definition Documentation . . . 1103
9.37.1.1 LITEQMI_MAX_SWIOMA_STR_LEN . . . 1103
9.37.2 Function Documentation . . . 1103
9.37.2.1 pack_swioma_SLQSOMADMAlertCallback . . . 1103
9.37.2.2 pack_swioma_SLQSOMADMCancelSession . . . 1103
9.37.2.3 pack_swioma_SLQSOMADMGetSessionInfo . . . 1104
9.37.2.4 pack_swioma_SLQSOMADMGetSettings . . . 1105
9.37.2.5 pack_swioma_SLQSOMADMSendSelection . . . 1105
9.37.2.6 pack_swioma_SLQSOMADMSetSettings . . . 1106
9.37.2.7 pack_swioma_SLQSOMADMStartSession . . . 1107
9.37.2.8 unpack_swioma_SLQSOMADMAlertCallback . . . 1107
9.37.2.9 unpack_swioma_SLQSOMADMAlertCallback_ind . . . 1108
9.37.2.10 unpack_swioma_SLQSOMADMCancelSession . . . 1108
9.37.2.11 unpack_swioma_SLQSOMADMGetSessionInfo . . . 1109
9.37.2.12 unpack_swioma_SLQSOMADMGetSettings . . . 1109
9.37.2.13 unpack_swioma_SLQSOMADMSendSelection . . . 1110
9.37.2.14 unpack_swioma_SLQSOMADMSetSettings . . . 1110
9.37.2.15 unpack_swioma_SLQSOMADMStartSession . . . 1110
9.38 swiomaext.h File Reference . . . 1111
9.38.1 Macro Definition Documentation . . . 1111
9.38.1.1 LITEQMI_MAX_SWIOMA_STR_LEN . . . 1111
9.38.2 Function Documentation . . . 1111
9.38.2.1 pack_swioma_SLQSOMADMCancelSessionExt . . . 1111
9.38.2.2 pack_swioma_SLQSOMADMSendSelectionExt . . . 1112
9.38.2.3 pack_swioma_SLQSOMADMSetSettingsExt . . . 1113
9.38.2.4 pack_swioma_SLQSOMADMStartSessionExt . . . 1113
9.38.2.5 unpack_swioma_SLQSOMADMCancelSessionExt . . . 1114
9.38.2.6 unpack_swioma_SLQSOMADMSendSelectionExt . . . 1114
9.38.2.7 unpack_swioma_SLQSOMADMSetSettingsExt . . . 1115
9.38.2.8 unpack_swioma_SLQSOMADMStartSessionExt . . . 1115
9.39 SWIWWANCMAPI.h File Reference . . . 1115
9.40 tmd.h File Reference . . . 1115
9.40.1 Macro Definition Documentation . . . 1116
9.40.1.1 MAX_MITIGATION_DEV_ID_LEN . . . 1116
9.40.1.2 MAX_MITIGATION_DEV_LIST_LEN . . . 1116
9.40.1.3 TMD_MAX_DEV_LIST . . . 1116
9.40.2 Function Documentation . . . 1116
9.40.2.1 pack_tmd_SLQSTmdDeRegNotMitigationLvl . . . 1116
9.40.2.2 pack_tmd_SLQSTmdGetMitigationDevList . . . 1117

9.40.2.3 pack_tmd_SLQSTmdGetMitigationLvl . . . 1117
9.40.2.4 pack_tmd_SLQSTmdRegNotMitigationLvl . . . 1118
9.40.2.5 unpack_tmd_SLQSTmdDeRegNotMitigationLvl . . . 1118
9.40.2.6 unpack_tmd_SLQSTmdGetMitigationDevList . . . 1118
9.40.2.7 unpack_tmd_SLQSTmdGetMitigationLvl . . . 1119
9.40.2.8 unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind . . . 1119
9.40.2.9 unpack_tmd_SLQSTmdRegNotMitigationLvl . . . 1119
9.41 uim.h File Reference . . . 1120
9.41.1 Macro Definition Documentation . . . 1123
9.41.1.1 MAX_DESCRIPTION_LENGTH . . . 1123
9.41.1.2 MAX_ICCID_LENGTH . . . 1123
9.41.1.3 MAX_NO_OF_APPLICATIONS . . . 1123
9.41.1.4 MAX_NO_OF_SLOTS . . . 1123
9.41.1.5 MAX_SLOTS_STATUS . . . 1123
9.41.1.6 UIM_MAX_ACTIVE_PERS_FEATURES . . . 1123
9.41.1.7 UIM_MAX_CONTENT_LENGTH . . . 1123
9.41.1.8 UIM_MAX_DESCRIPTION_LENGTH . . . 1123
9.41.1.9 UIM_MAX_NO_OF_APPLICATIONS . . . 1123
9.41.1.10 UIM_MAX_NO_OF_SLOTS . . . 1123
9.41.1.11 UIM_UINT8_MAX_STRING_SZ . . . 1123
9.41.2 Function Documentation . . . 1123
9.41.2.1 pack_uim_ChangePin . . . 1123
9.41.2.2 pack_uim_GetCardStatus . . . 1123
9.41.2.3 pack_uim_ReadTransparent . . . 1124
9.41.2.4 pack_uim_SetPinProtection . . . 1124
9.41.2.5 pack_uim_SLQSUIMAuthenticate . . . 1124
9.41.2.6 pack_uim_SLQSUIMDepersonalization . . . 1125
9.41.2.7 pack_uim_SLQSUIMEventRegister . . . 1125
9.41.2.8 pack_uim_SLQSUIMGetConfiguration . . . 1126
9.41.2.9 pack_uim_SLQSUIMGetFileAttributes . . . 1126
9.41.2.10 pack_uim_SLQSUIMGetSlotsStatus . . . 1126
9.41.2.11 pack_uim_SLQSUIMPowerDown . . . 1127
9.41.2.12 pack_uim_SLQSUIMPowerUp . . . 1127
9.41.2.13 pack_uim_SLQSUIMRefreshComplete . . . 1127
9.41.2.14 pack_uim_SLQSUIMRefreshGetLastEvent . . . 1128
9.41.2.15 pack_uim_SLQSUIMRefreshOK . . . 1128
9.41.2.16 pack_uim_SLQSUIMRefreshRegister . . . 1128
9.41.2.17 pack_uim_SLQSUIMReset . . . 1129
9.41.2.18 pack_uim_SLQSUIMSwitchSlot . . . 1129
9.41.2.19 pack_uim_UnblockPin . . . 1130

9.41.2.20 pack_uim_VerifyPin . . . 1130
9.41.2.21 unpack_uim_ChangePin . . . 1130
9.41.2.22 unpack_uim_GetCardStatus . . . 1131
9.41.2.23 unpack_uim_ReadTransparent . . . 1131
9.41.2.24 unpack_uim_SetPinProtection . . . 1131
9.41.2.25 unpack_uim_SetUimSlotStatusChangeCallback_ind . . . 1132
9.41.2.26 unpack_uim_SLQSUIMAuthenticate . . . 1132
9.41.2.27 unpack_uim_SLQSUIMDepersonalization . . . 1132
9.41.2.28 unpack_uim_SLQSUIMEventRegister . . . 1133
9.41.2.29 unpack_uim_SLQSUIMGetConfiguration . . . 1133
9.41.2.30 unpack_uim_SLQSUIMGetFileAttributes . . . 1134
9.41.2.31 unpack_uim_SLQSUIMGetSlotsStatus . . . 1134
9.41.2.32 unpack_uim_SLQSUIMPowerDown . . . 1134
9.41.2.33 unpack_uim_SLQSUIMPowerUp . . . 1135
9.41.2.34 unpack_uim_SLQSUIMRefreshComplete . . . 1135
9.41.2.35 unpack_uim_SLQSUIMRefreshGetLastEvent . . . 1135
9.41.2.36 unpack_uim_SLQSUIMRefreshOK . . . 1136
9.41.2.37 unpack_uim_SLQSUIMRefreshRegister . . . 1136
9.41.2.38 unpack_uim_SLQSUIMReset . . . 1136
9.41.2.39 unpack_uim_SLQSUIMSetStatusChangeCallBack_ind . . . 1136
9.41.2.40 unpack_uim_SLQSUIMSwitchSlot . . . 1137
9.41.2.41 unpack_uim_UnblockPin . . . 1137
9.41.2.42 unpack_uim_VerifyPin . . . 1138
9.42 voice.h File Reference . . . 1138
9.42.1 Detailed Description . . . 1142
9.42.2 S1 . . . 1142
9.42.3 Macro Definition Documentation . . . 1142
9.42.3.1 BARRING_PASSWORD_LENGTH . . . 1142
9.42.3.2 MAX_VOICE_CALL_NO_LEN . . . 1142
9.42.3.3 MAX_VOICE_DESCRIPTION_LENGTH . . . 1142
9.42.3.4 MAXVOICEUSSDLENGTH . . . 1142
9.42.3.5 VOICE_MAX_NO_OF_CALLS . . . 1142
9.42.4 Enumeration Type Documentation . . . 1143
9.42.4.1 liteServiceClassInformation . . . 1143
9.42.5 Function Documentation . . . 1143
9.42.5.1 pack_voice_AnswerUSSD . . . 1143
9.42.5.2 pack_voice_CancelUSSD . . . 1143
9.42.5.3 pack_voice_OriginateUSSD . . . 1144
9.42.5.4 pack_voice_SLQSOriginateUSSD . . . 1144
9.42.5.5 pack_voice_SLQSVoiceALSSelectLine . . . 1144

9.42.5.6 pack_voice_SLQSVoiceALSSetLineSwitching . . . 1145
9.42.5.7 pack_voice_SLQSVoiceAnswerCall . . . 1145
9.42.5.8 pack_voice_SLQSVoiceBindSubscription . . . 1145
9.42.5.9 pack_voice_SLQSVoiceBurstDTMF . . . 1146
9.42.5.10 pack_voice_SLQSVoiceDialCall . . . 1146
9.42.5.11 pack_voice_SLQSVoiceEndCall . . . 1147
9.42.5.12 pack_voice_SLQSVoiceGetAllCallInfo . . . 1147
9.42.5.13 pack_voice_SLQSVoiceGetCallBarring . . . 1147
9.42.5.14 pack_voice_SLQSVoiceGetCallForwardingStatus . . . 1148
9.42.5.15 pack_voice_SLQSVoiceGetCallInfo . . . 1148
9.42.5.16 pack_voice_SLQSVoiceGetCallWaiting . . . 1148
9.42.5.17 pack_voice_SLQSVoiceGetCLIP . . . 1149
9.42.5.18 pack_voice_SLQSVoiceGetCLIR . . . 1149
9.42.5.19 pack_voice_SLQSVoiceGetCNAP . . . 1149
9.42.5.20 pack_voice_SLQSVoiceGetCOLP . . . 1150
9.42.5.21 pack_voice_SLQSVoiceGetCOLR . . . 1150
9.42.5.22 pack_voice_SLQSVoiceGetConfig . . . 1150
9.42.5.23 pack_voice_SLQSVoiceIndicationRegister . . . 1151
9.42.5.24 pack_voice_SLQSVoiceManageCalls . . . 1151
9.42.5.25 pack_voice_SLQSVoiceOrigUSSDNoWait . . . 1151
9.42.5.26 pack_voice_SLQSVoiceSendFlash . . . 1152
9.42.5.27 pack_voice_SLQSVoiceSetCallBarringPassword . . . 1152
9.42.5.28 pack_voice_SLQSVoiceSetConfig . . . 1153
9.42.5.29 pack_voice_SLQSVoiceSetPreferredPrivacy . . . 1153
9.42.5.30 pack_voice_SLQSVoiceSetSUPSService . . . 1153
9.42.5.31 pack_voice_SLQSVoiceStartContDTMF . . . 1154
9.42.5.32 pack_voice_SLQSVoiceStopContDTMF . . . 1154
9.42.5.33 unpack_voice_AnswerUSSD . . . 1154
9.42.5.34 unpack_voice_CancelUSSD . . . 1155
9.42.5.35 unpack_voice_OriginateUSSD . . . 1155
9.42.5.36 unpack_voice_SLQSOriginateUSSD . . . 1155
9.42.5.37 unpack_voice_SLQSVoiceALSSelectLine . . . 1156
9.42.5.38 unpack_voice_SLQSVoiceALSSetLineSwitching . . . 1156
9.42.5.39 unpack_voice_SLQSVoiceAnswerCall . . . 1156
9.42.5.40 unpack_voice_SLQSVoiceBindSubscription . . . 1157
9.42.5.41 unpack_voice_SLQSVoiceBurstDTMF . . . 1157
9.42.5.42 unpack_voice_SLQSVoiceDialCall . . . 1157
9.42.5.43 unpack_voice_SLQSVoiceEndCall . . . 1158
9.42.5.44 unpack_voice_SLQSVoiceGetAllCallInfo . . . 1158
9.42.5.45 unpack_voice_SLQSVoiceGetCallBarring . . . 1158

9.42.5.46 unpack_voice_SLQSVoiceGetCallForwardingStatus . . . 1159
9.42.5.47 unpack_voice_SLQSVoiceGetCallInfo . . . 1159
9.42.5.48 unpack_voice_SLQSVoiceGetCallWaiting . . . 1159
9.42.5.49 unpack_voice_SLQSVoiceGetCLIP . . . 1160
9.42.5.50 unpack_voice_SLQSVoiceGetCLIR . . . 1160
9.42.5.51 unpack_voice_SLQSVoiceGetCNAP . . . 1160
9.42.5.52 unpack_voice_SLQSVoiceGetCOLP . . . 1161
9.42.5.53 unpack_voice_SLQSVoiceGetCOLR . . . 1161
9.42.5.54 unpack_voice_SLQSVoiceGetConfig . . . 1161
9.42.5.55 unpack_voice_SLQSVoiceIndicationRegister . . . 1162
9.42.5.56 unpack_voice_SLQSVoiceManageCalls . . . 1162
9.42.5.57 unpack_voice_SLQSVoiceOrigUSSDNoWait . . . 1162
9.42.5.58 unpack_voice_SLQSVoiceSendFlash . . . 1163
9.42.5.59 unpack_voice_SLQSVoiceSetCallBarringPassword . . . 1163
9.42.5.60 unpack_voice_SLQSVoiceSetConfig . . . 1163
9.42.5.61 unpack_voice_SLQSVoiceSetPreferredPrivacy . . . 1164
9.42.5.62 unpack_voice_SLQSVoiceSetSUPSService . . . 1164
9.42.5.63 unpack_voice_SLQSVoiceStartContDTMF . . . 1164
9.42.5.64 unpack_voice_SLQSVoiceStopContDTMF . . . 1165
9.43 wds.h File Reference . . . 1165
9.43.1 Macro Definition Documentation . . . 1171
9.43.1.1 BYT_STAT_STAT_MASK . . . 1171
9.43.1.2 IPV6_ADDR_LEN . . . 1171
9.43.1.3 IPV6_ADDRESS_ARRAY_SIZE . . . 1171
9.43.1.4 MAX_WDS_3GPP_CONF_LTE_ATTACH_PROFILE_LIST_SIZE . . . 1171
9.43.1.5 PACK_WDS_IPV4 . . . 1171
9.43.1.6 PACK_WDS_IPV6 . . . 1171
9.43.1.7 WDS_DHCP_MAX_NUM_OPTIONS . . . 1171
9.43.1.8 WDS_DHCP_OPTION_DATA_BUF_SIZE . . . 1171
9.43.2 Typedef Documentation . . . 1171
9.43.2.1 UnpackQmiProfileInfo . . . 1171
9.43.3 Enumeration Type Documentation . . . 1172
9.43.3.1 liteQmiDataBearerMasks . . . 1172
9.43.4 Function Documentation . . . 1172
9.43.4.1 __attribute__ . . . 1172
9.43.4.2 pack_wds_DHCPv4ClientLeaseChange . . . 1172
9.43.4.3 pack_wds_GetAutoconnect . . . 1172
9.43.4.4 pack_wds_GetByteTotals . . . 1173
9.43.4.5 pack_wds_GetConnectionRate . . . 1173
9.43.4.6 pack_wds_GetDataBearerTechnology . . . 1174

9.43.4.7 pack_wds_GetDefaultProfile . . . 1174
9.43.4.8 pack_wds_GetDefaultProfileNum . . . 1174
9.43.4.9 pack_wds_GetDormancyState . . . 1175
9.43.4.10 pack_wds_GetLastMobileIPError . . . 1175
9.43.4.11 pack_wds_GetMobileIP . . . 1176
9.43.4.12 pack_wds_GetMobileIPProfile . . . 1176
9.43.4.13 pack_wds_GetPacketStatistics . . . 1176
9.43.4.14 pack_wds_GetPacketStatus . . . 1177
9.43.4.15 pack_wds_GetSessionDuration . . . 1177
9.43.4.16 pack_wds_GetSessionState . . . 1178
9.43.4.17 pack_wds_RMSetTransferStatistics . . . 1178
9.43.4.18 pack_wds_SetAutoconnect . . . 1178
9.43.4.19 pack_wds_SetDefaultProfile . . . 1179
9.43.4.20 pack_wds_SetDefaultProfileNum . . . 1179
9.43.4.21 pack_wds_SetMobileIP . . . 1180
9.43.4.22 pack_wds_SetMobileIPParameters . . . 1180
9.43.4.23 pack_wds_SetMobileIPProfile . . . 1181
9.43.4.24 pack_wds_SetMuxID . . . 1181
9.43.4.25 pack_wds_SLQSCreateProfile . . . 1181
9.43.4.26 pack_wds_SLQSDeleteProfile . . . 1182
9.43.4.27 pack_wds_SLQSGet3GPPConfigItem . . . 1182
9.43.4.28 pack_wds_SLQSGetCurrDataSystemStat . . . 1183
9.43.4.29 pack_wds_SLQSGetCurrentChannelRate . . . 1183
9.43.4.30 pack_wds_SLQSGetDataBearerTechnology . . . 1183
9.43.4.31 pack_wds_SLQSGetDUNCallInfo . . . 1184
9.43.4.32 pack_wds_SLQSGetProfileSettings . . . 1184
9.43.4.33 pack_wds_SLQSGetRuntimeSettings . . . 1185
9.43.4.34 pack_wds_SLQSModifyProfile . . . 1185
9.43.4.35 pack_wds_SLQSResetPacketStatics . . . 1186
9.43.4.36 pack_wds_SLQSSet3GPPConfigItem . . . 1186
9.43.4.37 pack_wds_SLQSSetIPFamilyPreference . . . 1187
9.43.4.38 pack_wds_SLQSSetWdsEventCallback . . . 1187
9.43.4.39 pack_wds_SLQSSGetDHCPv4ClientConfig . . . 1187
9.43.4.40 pack_wds_SLQSSGetLoopback . . . 1188
9.43.4.41 pack_wds_SLQSSSetDHCPv4ClientConfig . . . 1188
9.43.4.42 pack_wds_SLQSSSetLoopback . . . 1188
9.43.4.43 pack_wds_SLQSStartDataSession . . . 1189
9.43.4.44 pack_wds_SLQSStopDataSession . . . 1189
9.43.4.45 pack_wds_SLQSWdsGoActive . . . 1190
9.43.4.46 pack_wds_SLQSWdsGoDormant . . . 1190

9.43.4.47 pack_wds_SLQSWdsSetEventReport . . . 1191
9.43.4.48 pack_wds_SLQSWdsSwiPDPRuntimeSettings . . . 1191
9.43.4.49 unpack_wds_DHCPv4ClientLease_ind . . . 1191
9.43.4.50 unpack_wds_DHCPv4ClientLeaseChange . . . 1192
9.43.4.51 unpack_wds_GetAutoconnect . . . 1192
9.43.4.52 unpack_wds_GetByteTotals . . . 1192
9.43.4.53 unpack_wds_GetConnectionRate . . . 1193
9.43.4.54 unpack_wds_GetDataBearerTechnology . . . 1193
9.43.4.55 unpack_wds_GetDefaultProfile . . . 1194
9.43.4.56 unpack_wds_GetDefaultProfileNum . . . 1194
9.43.4.57 unpack_wds_GetDormancyState . . . 1194
9.43.4.58 unpack_wds_GetLastMobileIPError . . . 1195
9.43.4.59 unpack_wds_GetMobileIP . . . 1195
9.43.4.60 unpack_wds_GetMobileIPProfile . . . 1195
9.43.4.61 unpack_wds_GetPacketStatistics . . . 1196
9.43.4.62 unpack_wds_GetPacketStatus . . . 1196
9.43.4.63 unpack_wds_GetSessionDuration . . . 1196
9.43.4.64 unpack_wds_GetSessionState . . . 1197
9.43.4.65 unpack_wds_RMSetTransferStatistics . . . 1197
9.43.4.66 unpack_wds_RMTransferStatistics_ind . . . 1197
9.43.4.67 unpack_wds_SetAutoconnect . . . 1198
9.43.4.68 unpack_wds_SetDefaultProfile . . . 1198
9.43.4.69 unpack_wds_SetDefaultProfileNum . . . 1198
9.43.4.70 unpack_wds_SetMobileIP . . . 1199
9.43.4.71 unpack_wds_SetMobileIPParameters . . . 1199
9.43.4.72 unpack_wds_SetMobileIPProfile . . . 1199
9.43.4.73 unpack_wds_SetMuxID . . . 1200
9.43.4.74 unpack_wds_SLQSCreateProfile . . . 1200
9.43.4.75 unpack_wds_SLQSDeleteProfile . . . 1200
9.43.4.76 unpack_wds_SLQSGet3GPPConfigItem . . . 1201
9.43.4.77 unpack_wds_SLQSGetCurrDataSystemStat . . . 1201
9.43.4.78 unpack_wds_SLQSGetCurrentChannelRate . . . 1201
9.43.4.79 unpack_wds_SLQSGetDataBearerTechnology . . . 1202
9.43.4.80 unpack_wds_SLQSGetDUNCallInfo . . . 1202
9.43.4.81 unpack_wds_SLQSGetProfileSettings . . . 1202
9.43.4.82 unpack_wds_SLQSGetRuntimeSettings . . . 1203
9.43.4.83 unpack_wds_SLQSModifyProfile . . . 1203
9.43.4.84 unpack_wds_SLQSResetPacketStatics . . . 1203
9.43.4.85 unpack_wds_SLQSSet3GPPConfigItem . . . 1204
9.43.4.86 unpack_wds_SLQSSetIPFamilyPreference . . . 1204

9.43.4.87 unpack_wds_SLQSSetPacketSrvStatusCallback . . . 1204
9.43.4.88 unpack_wds_SLQSSetWdsEventCallback . . . 1205
9.43.4.89 unpack_wds_SLQSSetWdsEventCallback_ind . . . 1205
9.43.4.90 unpack_wds_SLQSSGetDHCPv4ClientConfig . . . 1205
9.43.4.91 unpack_wds_SLQSSGetLoopback . . . 1206
9.43.4.92 unpack_wds_SLQSSSetDHCPv4ClientConfig . . . 1206
9.43.4.93 unpack_wds_SLQSSSetLoopback . . . 1206
9.43.4.94 unpack_wds_SLQSStartDataSession . . . 1207
9.43.4.95 unpack_wds_SLQSStopDataSession . . . 1207
9.43.4.96 unpack_wds_SLQSWdsGoActive . . . 1207
9.43.4.97 unpack_wds_SLQSWdsGoDormant . . . 1208
9.43.4.98 unpack_wds_SLQSWdsSetEventReport . . . 1208
9.43.4.99 unpack_wds_SLQSWdsSwiPDPRuntimeSettings . . . 1208
9.43.5 Variable Documentation . . . 1208
9.43.5.1 __attribute__ . . . 1209
9.43.5.2 ipv6addr . . . 1209
9.43.5.3 prefix . . . 1209

Index **1210**

Chapter 1

Welcome to the Sierra Wireless Linux QMI SDK API Reference Guide

This API reference guide contains information about all the modules, in the Sierra Wireless Linux QMI SDK (SLQS). Use the tabs at the top of the page to navigate the reference guide.

- Modules tab – lists all the service modules and provides a link to the API header file in each module.
- References tab – links to reference material.

1.1 Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless modem are used in a normal manner with a well-constructed network, the Sierra Wireless modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless modem, or for failure of the Sierra Wireless modem to transmit or receive such data.

1.2 Limitation of Liability

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

1.3 Patents

Patents This product may contain technology developed by or for Sierra Wireless Inc. This product includes technology licensed from QUALCOMM® 3G. This product is manufactured or sold by Sierra Wireless Inc. or its affiliates

under one or more patents licensed from InterDigital Group.

1.4 Copyright

© 2011-2015 Sierra Wireless. All rights reserved.

1.5 Trademarks

AirCard® and Heart of the Wireless Machine® are registered trademarks of Sierra Wireless. Watcher® is a trademark of Sierra Wireless, registered in the European Community. Sierra Wireless, the Sierra Wireless logo, the red wave design, and the red-tipped antenna are trademarks of Sierra Wireless. Windows® is a registered trademark of Microsoft Corporation. QUALCOMM® is a registered trademark of QUALCOMM Incorporated. Used under license. Linux is a registered trademark of Linus Torvalds. Other trademarks are the property of the respective owners.

1.6 Contact Information

If you have any questions about the Sierra Wireless Linux SDK, contact your Sierra Wireless account manager.

Consult our website for up-to-date product descriptions, documentation, application notes, firmware upgrades, troubleshooting tips, and press releases: http://www.sierrawireless.com.

Chapter 2

Module Index

2.1 Modules

Here is a list of all modules:

QMI pack/unpack (lite-qmi) 25
Streaming Download Protocol (lite-fw) 26

Chapter 3

Namespace Index

3.1 Namespace List

Here is a list of all namespaces with brief descriptions:

Tables 27

Chapter 4

Data Structure Index

4.1 Data Structures

Here are the data structures with brief descriptions:

_litefw_FirmwareInfo_ . . . 29
altSrcInfo_t . . . 30
appStats . . . 31
audio_RXAGCList . . . 34
audio_RXAVCList . . . 35
audio_RXPCMIIRFltr . . . 35
audio_TXAGCList . . . 37
audio_TXPCMIIRFltr . . . 38
CarrierImage_t . . . 39
cat_AlPhaIdentifierTlv . . . 41
cat_commonEventTlv . . . 41
cat_currentCatEvent . . . 42
cat_EndProactiveSessionTlv . . . 43
cat_EventIDDataTlv . . . 43
cat_EventListTlv . . . 43
cat_RefreshTlv . . . 44
cdmaSSInfo . . . 44
connectionStatus . . . 45
crashInfoParams . . . 46
crashInformation . . . 46
currNetworkInfo . . . 47
dms_ActivationStatusTlv . . . 49
dms_OperatingModeTlv . . . 50
DMScustSettingInfo . . . 51
DMScustSettingList . . . 52
DMSgetCustomFeatureV2 . . . 52
DMSgetCustomInput . . . 53
dunchannelRate . . . 53
eriDataparams . . . 54
eTWSPLMNInfoTlv . . . 55
FMSImageElement . . . 55
FMSImageIdElement . . . 56
FMSImageIDEntries . . . 57
FMSImageList . . . 58
FMSPrefImageList . . . 58
hdrSSInfo . . . 59
image_info_t . . . 60
ipv6_addr . . . 60

ipv6AddressInfo . . . 61
LibPackGPRSRequestedQoS . . . 61
LibpackProfile3GPP . . . 62
LibpackProfile3GPP2 . . . 69
LibPackprofile_3GPP . . . 74
LibPackprofile_3GPP2 . . . 80
LibPackQosClassID . . . 85
LibPackTFTIDParams . . . 86
LibPackUMTSQoS . . . 88
LibPackUMTSReqQoSSigInd . . . 91
loc_BdsSV . . . 91
loc_BdsSVInfo . . . 92
loc_CellDb . . . 92
loc_ClkInfo . . . 93
loc_GnssData . . . 94
loc_gpsTime . . . 96
loc_IPv4Info . . . 96
loc_IPv6Info . . . 97
loc_LocApplicationInfo . . . 97
loc_precisionDilution . . . 98
loc_satelliteInfo . . . 99
loc_sensorDataUsage . . . 101
loc_SV . . . 102
loc_SVInfo . . . 103
loc_svUsedforFix . . . 103
loc_urlAddr . . . 104
lteSSInfo . . . 105
messageModeTlv . . . 105
nas_acqOrderPref . . . 106
nas_ActPilotPNElement . . . 107
nas_AddCDMASysInfo . . . 107
nas_AddSysInfo . . . 108
nas_CallBarringSysInfo . . . 108
nas_callBarStatus . . . 109
nas_CDMAChannel . . . 110
nas_CDMAECIOThresh . . . 111
nas_CDMAInfo . . . 111
nas_CDMARSSIThresh . . . 112
nas_CDMASysInfo . . . 113
nas_CDMASysInfoExt . . . 117
nas_cellParams . . . 117
nas_CommInfo . . . 118
nas_CSGID . . . 120
nas_currentPLMN . . . 121
nas_dataSrvCapabilities . . . 122
nas_DataStatusDetail . . . 122
nas_detailSvcInfo . . . 125
nas_DeviceConfigDetail . . . 126
nas_dirNum . . . 127
nas_DRCParams . . . 127
nas_ecioListElement . . . 128
nas_ECIOThresh . . . 129
nas_errorRateListElement . . . 129
nas_GERANInfo . . . 130
nas_geranInstInfo . . . 132
nas_gsmCellInfo . . . 133
nas_GSMRSSIThresh . . . 134
nas_GSMSrvStatusInfo . . . 134

nas_GSMSysInfo . . . 135
nas_HDRECIOThresh . . . 138
nas_HDRIOThresh . . . 138
nas_HDRRSSIThresh . . . 139
nas_HDRSINRThresh . . . 140
nas_HDRSINRThreshold . . . 140
nas_HDRSysInfo . . . 141
nas_homeSIDNID . . . 143
nas_infoInterFreq . . . 143
nas_IOThresh . . . 145
nas_lteEARFCN . . . 145
nas_lteGsmCellInfo . . . 146
nas_LTEInfo . . . 147
nas_LTEInfoInterfreq . . . 150
nas_LTEInfoIntrafreq . . . 150
nas_LTEInfoNeighboringGSM . . . 152
nas_LTEInfoNeighboringWCDMA . . . 153
nas_ltePCI . . . 154
nas_lteRsrpinformation . . . 154
nas_LTERSRPThresh . . . 155
nas_LTERSRQThresh . . . 155
nas_LTERSSIThresh . . . 156
nas_LTESigRptCfg . . . 156
nas_LTESigRptConfig . . . 157
nas_lteSnrinformation . . . 158
nas_LTESNRThresh . . . 159
nas_LTESNRThreshold . . . 159
nas_LTESysInfo . . . 160
nas_lteWcdmaCellInfo . . . 162
nas_minBasedIMSI . . . 163
nas_MNRInfo . . . 164
nas_namName . . . 165
nas_netSelectionPref . . . 165
nas_NetworkStat1x . . . 166
nas_NetworkStatEVDO . . . 168
nas_nmrCellInfo . . . 170
nas_operatorNameString . . . 171
nas_OperatorPLMNData . . . 171
nas_operatorPLMNList . . . 172
nas_PhyCaAggPcellInfo . . . 173
nas_PhyCaAggScellDlBw . . . 174
nas_PhyCaAggScellIndex . . . 174
nas_PhyCaAggScellIndType . . . 175
nas_PhyCaAggScellInfo . . . 176
nas_PilotSetData . . . 178
nas_PilotSetParams . . . 179
nas_PLMNNetworkName . . . 179
nas_PLMNNetworkNameData . . . 180
nas_protocolSubtypeElement . . . 181
nas_qaQmi3Gpp2TimeZone . . . 183
nas_QmiNas3GppNetworkInfo . . . 184
nas_QmiNas3GppNetworkRAT . . . 185
nas_QmisNasPcsDigit . . . 186
nas_RejectReasonTlv . . . 186
nas_RFInfoTlv . . . 187
nas_roamIndList . . . 188
nas_RSRPThresh . . . 189
nas_rsrqInformation . . . 189

nas_RSRQThresh . . . 190
nas_RSSIThresh . . . 190
nas_rxInfo . . . 191
nas_RxSigInfo . . . 192
nas_rxSignalStrengthListElement . . . 193
nas_SccRxInfo . . . 194
nas_serviceProviderName . . . 195
nas_servSystem . . . 196
nas_sidNid . . . 197
nas_SignalStrengthTlv . . . 198
nas_SLQSSignalStrengthsIndReq . . . 198
nas_SLQSSignalStrengthsInformation . . . 200
nas_SLQSSignalStrengthsTlv . . . 201
nas_SrvStatusInfo . . . 202
nas_sysInfoCommon . . . 202
nas_TDSCDMAECIOThresh . . . 205
nas_TDSCDMARSCPThresh . . . 205
nas_TDSCDMARSSIThresh . . . 206
nas_TDSCDMASINRCONFThresh . . . 206
nas_TDSCDMASINRThresh . . . 207
nas_timeInfo . . . 207
nas_trueIMSI . . . 209
nas_txInfo . . . 210
nas_UMTSInfo . . . 210
nas_UMTSinstInfo . . . 212
nas_umtsLTENbrCell . . . 213
nas_UniversalTime . . . 214
nas_wcdmaCellInfo . . . 215
nas_WCDMAECIOThresh . . . 216
nas_WCDMAInfoLTENeighborCell . . . 216
nas_WCDMARSSIThresh . . . 217
nas_WCDMASysInfo . . . 218
nas_wcdmaUARFCN . . . 221
NASBandPreferenceTlv . . . 222
NASEmergencyModeTlv . . . 222
NasGetLTECphyCaInfo . . . 222
NASGWAcqOrderPrefTlv . . . 223
NASLTEBandPreferenceTlv . . . 224
NASLteNasReleaseInfoTlv . . . 224
NASModePreferenceTlv . . . 225
NASNetSelPreferenceTlv . . . 225
NASOTAMessageTlv . . . 226
NASPhyCaAggPcellInfo . . . 227
NASPhyCaAggScellDlBw . . . 228
NASPhyCaAggScellIndex . . . 228
NASPhyCaAggScellIndType . . . 229
NASPhyCaAggScellInfo . . . 229
NASPRLPreferenceTlv . . . 230
NASQmiCbkNasSwiOTAMessageInd . . . 231
NASQmiCbkNasSystemSelPrefInd . . . 231
NASRoamPreferenceTlv . . . 233
NASServDomainPrefTlv . . . 233
NASServingSystemInfo . . . 233
NASTimeInfoTlv . . . 235
newMTMessageTlv . . . 236
pack_audio_SLQSGetAudioPathConfig_t . . . 236
pack_audio_SLQSGetAudioProfile_t . . . 237
pack_audio_SLQSGetAudioVolTLBConfig_t . . . 238

pack_audio_SLQSSetAudioPathConfig_t . . . 238
pack_audio_SLQSSetAudioProfile_t . . . 240
pack_audio_SLQSSetAudioVolTLBConfig_t . . . 242
pack_cat_CATSendEnvelopeCommand_t . . . 242
pack_cat_CATSendTerminalResponse_t . . . 243
pack_cat_SetCATEventCallback_t . . . 244
pack_dms_ActivateAutomatic_t . . . 245
pack_dms_GetCustFeaturesV2_t . . . 245
pack_dms_ResetToFactoryDefaults_t . . . 246
pack_dms_SetActivationStatusCallback_t . . . 246
pack_dms_SetCrashAction_t . . . 246
pack_dms_SetCustFeature_t . . . 247
pack_dms_SetCustFeaturesV2_t . . . 249
pack_dms_SetEventReport_t . . . 250
pack_dms_SetPower_t . . . 250
pack_dms_SetUSBComp_t . . . 251
pack_dms_SLQSDmsSwiIndicationRegister_t . . . 252
pack_dms_SLQSSwiGetCrashInfo_t . . . 252
pack_dms_SLQSSwiSetDyingGaspCfg_t . . . 253
pack_dms_SLQSSwiSetHostDevInfo_t . . . 253
pack_dms_SLQSSwiSetOSInfo_t . . . 254
pack_dms_UIMChangePIN_t . . . 254
pack_dms_UIMGetControlKeyStatus_t . . . 255
pack_dms_UIMGetICCID_t . . . 256
pack_dms_UIMSetControlKeyProtection_t . . . 256
pack_dms_UIMSetPINProtection_t . . . 257
pack_dms_UIMUnblockControlKey_t . . . 257
pack_dms_UIMUnblockPIN_t . . . 258
pack_dms_UIMVerifyPIN_t . . . 259
pack_fms_GetImagesPreference_t . . . 259
pack_fms_GetStoredImages_t . . . 259
pack_fms_SetImagesPreference_t . . . 260
pack_ims_SLQSImsConfigIndicationRegister_t . . . 261
pack_ims_SLQSSetIMSSMSConfig_t . . . 262
pack_ims_SLQSSetIMSUserConfig_t . . . 263
pack_ims_SLQSSetIMSVoIPConfig_t . . . 263
pack_ims_SLQSSetRegMgrConfig_t . . . 266
pack_ims_SLQSSetSIPConfig_t . . . 267
pack_imsa_SLQSRegisterIMSAIndication_t . . . 268
pack_loc_Delete_Assist_Data_t . . . 269
pack_loc_EventRegister_t . . . 270
pack_loc_SetExtPowerState_t . . . 272
pack_loc_SetOperationMode_t . . . 272
pack_loc_SLQSLOCGetBestAvailPos_t . . . 273
pack_loc_SLQSLOCGetServer_t . . . 274
pack_loc_SLQSLOCInjectPosition_t . . . 274
pack_loc_SLQSLOCInjectSensorData_t . . . 279
pack_loc_SLQSLOCInjectUTCTime_t . . . 281
pack_loc_SLQSLOCSetCradleMountConfig_t . . . 281
pack_loc_Start_t . . . 282
pack_loc_Stop_t . . . 284
pack_nas_InitiateDomainAttach_t . . . 284
pack_nas_SetACCOLC_t . . . 285
pack_nas_SetCDMANetworkParameters_t . . . 285
pack_nas_SetNetworkPreference_t . . . 287
pack_nas_SLQSConfigSigInfo_t . . . 288
pack_nas_SLQSGetPLMNName_t . . . 289
pack_nas_SLQSInitiateNetworkRegistration_t . . . 290

pack_nas_SLQSNasConfigSigInfo2_t . . . 291
pack_nas_SLQSNasGet3GPP2Subscription_t . . . 296
pack_nas_SLQSNasGetTxRxInfo_t . . . 296
pack_nas_SLQSNasIndicationRegisterExt_t . . . 296
pack_nas_SLQSNASSeteDRXParams_t . . . 299
pack_nas_SLQSNasSwiIndicationRegister_t . . . 300
pack_nas_SLQSNASSwiSetChannelLock_t . . . 301
pack_nas_SLQSSetBandPreference_t . . . 302
pack_nas_SLQSSetSignalStrengthsCallback_t . . . 304
pack_nas_SLQSSetSysSelectionPref_t . . . 304
pack_nas_SLQSSwiPSDetach_t . . . 310
pack_pds_PDSInjectTimeReference_t . . . 310
pack_pds_ResetPDSData_t . . . 311
pack_pds_SetEventReportCallback_t . . . 311
pack_pds_SetPDSDefaults_t . . . 312
pack_pds_SetPDSState_t . . . 313
pack_pds_SetPortAutomaticTracking_t . . . 313
pack_pds_SetServiceAutomaticTracking_t . . . 314
pack_pds_SetXTRAAutomaticDownload_t . . . 314
pack_pds_SetXTRANetwork_t . . . 315
pack_pds_SLQSGetAGPSConfig_t . . . 315
pack_pds_SLQSPDSInjectAbsoluteTimeReference_t . . . 316
pack_pds_SLQSPDSInjectPositionData_t . . . 316
pack_pds_SLQSSetAGPSConfig_t . . . 318
pack_pds_SLQSSetPositionMethodState_t . . . 319
pack_pds_StartPDSTrackingSessionExt_t . . . 320
pack_qmi_t . . . 321
pack_qos_BindDataPort_t . . . 322
pack_qos_SLQSQosSwiReadApnExtraParams_t . . . 323
pack_qos_SLQSQosSwiReadDataStats_t . . . 323
pack_qos_SLQSSetQosEventCallback_t . . . 323
pack_rms_SetSMSWake_t . . . 324
pack_sar_SLQSSetRfSarState_t . . . 324
pack_sms_SaveSMS_t . . . 325
pack_sms_SendSMS_t . . . 326
pack_sms_SetNewSMSCallback_t . . . 326
pack_sms_SetSMSCAddress_t . . . 327
pack_sms_SLQSDeleteSMS_t . . . 327
pack_sms_SLQSGetSMS_t . . . 328
pack_sms_SLQSGetSmsBroadcastConfig_t . . . 329
pack_sms_SLQSGetSMSList_t . . . 329
pack_sms_SLQSModifySMSStatus_t . . . 330
pack_sms_SLQSSendAsyncSMS_t . . . 331
pack_sms_SLQSSetIndicationRegister_t . . . 331
pack_sms_SLQSSetSmsBroadcastActivation_t . . . 332
pack_sms_SLQSSetSmsBroadcastConfig_t . . . 332
pack_sms_SLQSSetSmsStorage_t . . . 333
pack_sms_SLQSSmsGetMaxStorageSize_t . . . 333
pack_sms_SLQSSmsSetRoutes_t . . . 334
pack_swiaudio_SLQSGetM2MAudioProfile_t . . . 334
pack_swiaudio_SLQSGetM2MAudioVolume_t . . . 335
pack_swiaudio_SLQSGetM2MAVMute_t . . . 335
pack_swiaudio_SLQSGetM2MSpkrGain_t . . . 336
pack_swiaudio_SLQSSetM2MAudioAVCFG_t . . . 336
pack_swiaudio_SLQSSetM2MAudioLPBK_t . . . 337
pack_swiaudio_SLQSSetM2MAudioProfile_t . . . 337
pack_swiaudio_SLQSSetM2MAudioVolume_t . . . 338
pack_swiaudio_SLQSSetM2MAVMute_t . . . 339

pack_swiaudio_SLQSSetM2MSpkrGain_t . . . 340
pack_swiavms_SLQSAVMSSendSelection_t . . . 340
pack_swiavms_SLQSAVMSSetSettings_t . . . 341
pack_swiavms_SLQSAVMSStartSession_t . . . 343
pack_swiavms_SLQSAVMSStopSession_t . . . 344
pack_swiloc_SwiLocSetAutoStart_t . . . 344
pack_swioma_SLQSOMADMCancelSession_t . . . 346
pack_swioma_SLQSOMADMCancelSessionExt_t . . . 346
pack_swioma_SLQSOMADMGetSessionInfo_t . . . 347
pack_swioma_SLQSOMADMSendSelection_t . . . 347
pack_swioma_SLQSOMADMSendSelectionExt_t . . . 348
pack_swioma_SLQSOMADMSetSettings_t . . . 348
pack_swioma_SLQSOMADMSetSettingsExt_t . . . 349
pack_swioma_SLQSOMADMStartSession_t . . . 350
pack_swioma_SLQSOMADMStartSessionExt_t . . . 351
pack_tmd_SLQSTmdDeRegNotMitigationLvl_t . . . 351
pack_tmd_SLQSTmdGetMitigationLvl_t . . . 352
pack_tmd_SLQSTmdRegNotMitigationLvl_t . . . 352
pack_uim_ChangePin_t . . . 353
pack_uim_ReadTransparent_t . . . 354
pack_uim_SetPinProtection_t . . . 355
pack_uim_SLQSUIMAuthenticate_t . . . 356
pack_uim_SLQSUIMDepersonalization_t . . . 357
pack_uim_SLQSUIMEventRegister_t . . . 357
pack_uim_SLQSUIMGetConfiguration_t . . . 358
pack_uim_SLQSUIMGetFileAttributes_t . . . 358
pack_uim_SLQSUIMPowerDown_t . . . 359
pack_uim_SLQSUIMPowerUp_t . . . 359
pack_uim_SLQSUIMRefreshComplete_t . . . 360
pack_uim_SLQSUIMRefreshGetLastEvent_t . . . 360
pack_uim_SLQSUIMRefreshOK_t . . . 361
pack_uim_SLQSUIMRefreshRegister_t . . . 361
pack_uim_SLQSUIMSwitchSlot_t . . . 362
pack_uim_UnblockPin_t . . . 363
pack_uim_VerifyPin_t . . . 364
pack_voice_AnswerUSSD_t . . . 365
pack_voice_OriginateUSSD_t . . . 365
pack_voice_SLQSOriginateUSSD_t . . . 366
pack_voice_SLQSVoiceALSSelectLine_t . . . 366
pack_voice_SLQSVoiceALSSetLineSwitching_t . . . 367
pack_voice_SLQSVoiceAnswerCall_t . . . 367
pack_voice_SLQSVoiceBindSubscription_t . . . 368
pack_voice_SLQSVoiceBurstDTMF_t . . . 368
pack_voice_SLQSVoiceDialCall_t . . . 369
pack_voice_SLQSVoiceEndCall_t . . . 370
pack_voice_SLQSVoiceGetCallBarring_t . . . 371
pack_voice_SLQSVoiceGetCallForwardingStatus_t . . . 372
pack_voice_SLQSVoiceGetCallInfo_t . . . 372
pack_voice_SLQSVoiceGetCallWaiting_t . . . 373
pack_voice_SLQSVoiceGetConfig_t . . . 373
pack_voice_SLQSVoiceIndicationRegister_t . . . 375
pack_voice_SLQSVoiceManageCalls_t . . . 376
pack_voice_SLQSVoiceOrigUSSDNoWait_t . . . 377
pack_voice_SLQSVoiceSendFlash_t . . . 377
pack_voice_SLQSVoiceSetCallBarringPassword_t . . . 378
pack_voice_SLQSVoiceSetConfig_t . . . 379
pack_voice_SLQSVoiceSetPreferredPrivacy_t . . . 380
pack_voice_SLQSVoiceSetSUPSService_t . . . 380

pack_voice_SLQSVoiceStartContDTMF_t . . . 383
pack_voice_SLQSVoiceStopContDTMF_t . . . 384
pack_wds_DHCPv4ClientLeaseChange_t . . . 384
pack_wds_GetDefaultProfile_t . . . 384
pack_wds_GetDefaultProfileNum_t . . . 385
pack_wds_GetDormancyState_t . . . 385
pack_wds_GetLastMobileIPError_t . . . 386
pack_wds_GetMobileIP_t . . . 386
pack_wds_GetMobileIPProfile_t . . . 386
pack_wds_GetPacketStatistics_t . . . 387
pack_wds_GetPacketStatus_t . . . 387
pack_wds_GetSessionDuration_t . . . 388
pack_wds_RMSetTransferStatistics_t . . . 388
pack_wds_SetAutoconnect_t . . . 388
pack_wds_SetDefaultProfile_t . . . 389
pack_wds_SetDefaultProfileNum_t . . . 391
pack_wds_SetMobileIP_t . . . 391
pack_wds_SetMobileIPParameters_t . . . 392
pack_wds_SetMobileIPProfile_t . . . 393
pack_wds_SLQSCreateProfile_t . . . 395
pack_wds_SLQSDeleteProfile_t . . . 396
pack_wds_SLQSGetCurrDataSystemStat_t . . . 396
pack_wds_SLQSGetDataBearerTechnology_t . . . 396
pack_wds_SLQSGetDUNCallInfo_t . . . 397
pack_wds_SLQSGetProfileSettings_t . . . 398
pack_wds_SLQSGetRuntimeSettings_t . . . 399
pack_wds_SLQSModifyProfile_t . . . 400
pack_wds_SLQSSet3GPPConfigItem_t . . . 401
pack_wds_SLQSSetIPFamilyPreference_t . . . 403
pack_wds_SLQSSetWdsEventCallback_t . . . 403
pack_wds_SLQSSGetDHCPv4ClientConfig_t . . . 404
pack_wds_SLQSSSetDHCPv4ClientConfig_t . . . 404
pack_wds_SLQSSSetLoopback_t . . . 405
pack_wds_SLQSStartDataSession_t . . . 405
pack_wds_SLQSStopDataSession_t . . . 407
pack_wds_SLQSWdsSetEventReport_t . . . 407
pack_wds_SLQSWdsSwiPDPRuntimeSettings_t . . . 409
PackCreateProfileOut . . . 409
packgetDyingGaspCfg . . . 410
packgetDyingGaspStatistics . . . 410
PackSwiAvmsSetSettingsAPNInfo . . . 411
PackSwiAvmsSetSettingsConnectionRetryTimers . . . 412
PackSwiAvmsSetSettingsPeriodInfo . . . 413
PackSwiAVMSSettingsAPNInfo . . . 413
PackSwiAVMSSettingsConnectionRetryTimers . . . 414
PackSwiAVMSSettingsPeriodsInfo . . . 414
qmiSmsMessageList . . . 415
qmiWDSDataBearerTechnology . . . 415
qmuxIPTable . . . 417
qos_BindDataPortMuxID_t . . . 417
qos_BindDataPortPeripheralEndPointID_t . . . 417
qos_BindDataPortSIODataPort_t . . . 418
RFBandInfoElements . . . 418
rmTrasnferStaticsReq . . . 419
sensorData_t . . . 420
slot_t . . . 421
slotInf . . . 422
slots_t . . . 424

sms_BroadcastConfig . . . 424
sms_CDMABroadcastConfig . . . 425
sms_getIndicationReg . . . 425
sms_getMsgWaitingInfo . . . 426
sms_getTransLayerInfo . . . 427
sms_getTransNWRegInfo . . . 428
sms_maxStorageSizeReq . . . 428
sms_maxStorageSizeResp . . . 429
sms_messageWaitingInfoContent . . . 429
sms_msgProtocolResp . . . 430
sms_qaQmi3GPP2BroadcastCfgInfo . . . 430
sms_qaQmi3GPPBroadcastCfgInfo . . . 431
sms_routeEntry . . . 432
sms_sendAsyncsmsParams . . . 433
sms_setIndicationReg . . . 435
sms_setRoutesReq . . . 436
sms_transLayerInfo . . . 437
sMSCAddressInfo . . . 438
sMSCAddressTlv . . . 438
sMSEtwsMessageInfo . . . 439
sMSEtwsMessageTlv . . . 439
sMSEtwsPlmnInfo . . . 440
sMSMessageModeInfo . . . 440
sMSMTMessageInfo . . . 440
sMSOnIMSInfo . . . 441
sMSOnIMSTlv . . . 441
sMSTransferRouteMTMessageInfo . . . 442
swiaudio_PCMparams . . . 443
tdscdmaSigInfoExt . . . 443
tempData_t . . . 444
tmd_mitigationDevList . . . 445
transferRouteMessageTlv . . . 446
uim_appStatus . . . 446
uim_authenticateResult . . . 449
uim_authenticationData . . . 450
uim_cardResult . . . 451
uim_cardStatus . . . 451
uim_changeUIMPIN . . . 452
uim_depersonalizationInformation . . . 453
uim_encryptedPIN1 . . . 454
uim_fileAttributes . . . 455
uim_fileInfo . . . 458
uim_hotSwapStatus . . . 459
uim_personalizationStatus . . . 459
uim_readResult . . . 460
uim_readTransparentInfo . . . 461
uim_refreshevent . . . 461
uim_registerRefresh . . . 463
uim_remainingRetries . . . 464
uim_sessionInformation . . . 465
uim_setPINProtection . . . 465
uim_slotInfo . . . 466
uim_UIMSessionInformation . . . 468
uim_unblockUIMPIN . . . 469
uim_verifyUIMPIN . . . 470
unpack_audio_SLQSGetAudioPathConfig_t . . . 470
unpack_audio_SLQSGetAudioProfile_t . . . 472
unpack_audio_SLQSGetAudioVolTLBConfig_t . . . 473

unpack_audio_SLQSSetAudioVolTLBConfig_t . . . 474
unpack_cat_SetCatEventCallback_ind_t . . . 474
unpack_cat_SetCATEventCallback_t . . . 475
unpack_dms_GetActivationState_t . . . 475
unpack_dms_GetBandCapability_t . . . 476
unpack_dms_GetCrashAction_t . . . 478
unpack_dms_GetCustFeature_t . . . 478
unpack_dms_GetCustFeaturesV2_t . . . 481
unpack_dms_GetDeviceCap_t . . . 481
unpack_dms_GetDeviceCapabilities_t . . . 482
unpack_dms_GetDeviceHardwareRev_t . . . 484
unpack_dms_GetDeviceMfr_t . . . 484
unpack_dms_GetDeviceSerialNumbers_t . . . 485
unpack_dms_GetFirmwareInfo_t . . . 486
unpack_dms_GetFirmwareRevision_t . . . 488
unpack_dms_GetFirmwareRevisions_t . . . 489
unpack_dms_GetFSN_t . . . 490
unpack_dms_GetHardwareRevision_t . . . 491
unpack_dms_GetIMSI_t . . . 491
unpack_dms_GetManufacturer_t . . . 492
unpack_dms_GetModelID_t . . . 492
unpack_dms_GetNetworkTime_t . . . 493
unpack_dms_GetOfflineReason_t . . . 493
unpack_dms_GetPower_t . . . 494
unpack_dms_GetPRLVersion_t . . . 496
unpack_dms_GetSerialNumbers_t . . . 496
unpack_dms_GetUSBComp_t . . . 497
unpack_dms_GetVoiceNumber_t . . . 499
unpack_dms_ResetToFactoryDefaults_t . . . 500
unpack_dms_SetActivationStatusCallback_t . . . 501
unpack_dms_SetCrashAction_t . . . 501
unpack_dms_SetCustFeature_t . . . 501
unpack_dms_SetCustFeaturesV2_t . . . 502
unpack_dms_SetEventReport_ind_t . . . 502
unpack_dms_SetEventReport_t . . . 503
unpack_dms_SetFirmwarePreference_t . . . 503
unpack_dms_SetPower_t . . . 504
unpack_dms_SetUSBComp_t . . . 504
unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t . . . 504
unpack_dms_SLQSDmsSwiGetResetInfo_t . . . 505
unpack_dms_SLQSDmsSwiIndicationRegister_t . . . 506
unpack_dms_SLQSGetBandCapability_t . . . 507
unpack_dms_SLQSGetERIFile_t . . . 510
unpack_dms_SLQSSwiClearDyingGaspStatistics_t . . . 510
unpack_dms_SLQSSwiGetCrashInfo_t . . . 511
unpack_dms_SLQSSwiGetDyingGaspCfg_t . . . 511
unpack_dms_SLQSSwiGetDyingGaspStatistics_t . . . 512
unpack_dms_SLQSSwiGetFirmwareCurr_t . . . 512
unpack_dms_SLQSSwiGetFwUpdateStatus_t . . . 514
unpack_dms_SLQSSwiGetHostDevInfo_t . . . 515
unpack_dms_SLQSSwiGetOSInfo_t . . . 516
unpack_dms_SLQSSwiGetSerialNoExt_t . . . 517
unpack_dms_SLQSSwiSetDyingGaspCfg_t . . . 517
unpack_dms_SLQSSwiSetHostDevInfo_t . . . 518
unpack_dms_SLQSSwiSetOSInfo_t . . . 518
unpack_dms_SLQSUIMGetState_t . . . 518
unpack_dms_UIMGetControlKeyStatus_t . . . 519
unpack_dms_UIMGetICCID_t . . . 520

unpack_dms_UIMGetPINStatus_t . . . 520
unpack_dms_UIMSetControlKeyProtection_t . . . 522
unpack_dms_UIMSetPINProtection_t . . . 522
unpack_dms_UIMUnblockControlKey_t . . . 523
unpack_fms_GetImagesPreference_t . . . 524
unpack_fms_GetStoredImages_t . . . 524
unpack_fms_SetImagesPreference_t . . . 525
unpack_ims_SLQSGetIMSSMSConfig_t . . . 526
unpack_ims_SLQSGetIMSUserConfig_t . . . 526
unpack_ims_SLQSGetIMSVoIPConfig_t . . . 527
unpack_ims_SLQSGetRegMgrConfig_t . . . 530
unpack_ims_SLQSGetSIPConfig_t . . . 531
unpack_ims_SLQSSetIMSSMSConfig_t . . . 532
unpack_ims_SLQSSetIMSUserConfig_t . . . 532
unpack_ims_SLQSSetIMSVoIPConfig_t . . . 533
unpack_ims_SLQSSetRegMgrConfig_t . . . 533
unpack_ims_SLQSSetSIPConfig_t . . . 534
unpack_imsa_SLQSGetIMSARegStatus_t . . . 534
unpack_imsa_SLQSGetIMSAServiceStatus_t . . . 535
unpack_loc_BestAvailPos_Ind_t . . . 537
unpack_loc_Delete_Assist_Data_t . . . 543
unpack_loc_DeleteAssistData_Ind_t . . . 544
unpack_loc_EngineState_Ind_t . . . 545
unpack_loc_EventNMEA_Ind_t . . . 545
unpack_loc_EventRegister_t . . . 546
unpack_loc_GetServer_Ind_t . . . 546
unpack_loc_GnssSvInfo_Ind_t . . . 548
unpack_loc_PositionRpt_Ind_t . . . 548
unpack_loc_SetExtPowerConfig_Ind_t . . . 555
unpack_loc_SetExtPowerState_t . . . 556
unpack_loc_SetOperationMode_Ind_t . . . 556
unpack_loc_SetOperationMode_t . . . 557
unpack_loc_SLQSLOCGetBestAvailPos_t . . . 557
unpack_loc_Start_t . . . 558
unpack_loc_Stop_t . . . 558
unpack_nas_GetCDMANetworkParameters_t . . . 558
unpack_nas_GetHomeNetwork3GPP2_t . . . 561
unpack_nas_GetHomeNetwork_t . . . 563
unpack_nas_GetNetworkPreference_t . . . 564
unpack_nas_GetRFInfo_t . . . 565
unpack_nas_GetServingNetwork_t . . . 566
unpack_nas_GetServingNetworkCapabilities_t . . . 568
unpack_nas_GetSignalStrengths_t . . . 569
unpack_nas_PerformNetworkScan_t . . . 570
unpack_nas_SetDataCapabilitiesCallback_ind_t . . . 571
unpack_nas_SetEventReportInd_t . . . 571
unpack_nas_SetNasLTECphyCaIndCallback_ind_t . . . 572
unpack_nas_SetNetworkPreference_t . . . 573
unpack_nas_SetRoamingIndicatorCallback_ind_t . . . 573
unpack_nas_SetServingSystemCallback_ind_t . . . 574
unpack_nas_SLQSGetErrorRate_t . . . 574
unpack_nas_SlqsGetLTECphyCAInfo_t . . . 575
unpack_nas_SLQSGetNetworkTime_t . . . 576
unpack_nas_SLQSGetOperatorNameData_t . . . 576
unpack_nas_SLQSGetPLMNName_t . . . 577
unpack_nas_SLQSGetServingSystem_t . . . 580
unpack_nas_SLQSGetSignalStrength_t . . . 584
unpack_nas_SLQSGetSysInfo_t . . . 586

unpack_nas_SLQSGetSysSelectionPref_t . . . 590
unpack_nas_SLQSNasGet3GPP2Subscription_t . . . 594
unpack_nas_SLQSNasGetCellLocationInfo_t . . . 595
unpack_nas_SLQSNASGeteDRXParams_t . . . 597
unpack_nas_SLQSNasGetHDRColorCode_t . . . 598
unpack_nas_SLQSNasGetSigInfo_t . . . 598
unpack_nas_SLQSNasGetTxRxInfo_t . . . 599
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t . . . 600
unpack_nas_SLQSNasSigInfoCallback_ind_t . . . 601
unpack_nas_SLQSNASSwiGetChannelLock_t . . . 602
unpack_nas_SLQSNasSwiModemStatus_t . . . 602
unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t . . . 603
unpack_nas_SLQSNasTimerCallback_ind_t . . . 603
unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t . . . 604
unpack_nas_SLQSSwiGetHDRPersonality_t . . . 605
unpack_nas_SLQSSwiGetHDRProtSubtype_t . . . 605
unpack_nas_SLQSSwiGetHRPDStats_t . . . 606
unpack_nas_SLQSSwiGetLteCQI_t . . . 607
unpack_nas_SLQSSwiGetLteSccRxInfo_t . . . 608
unpack_nas_SLQSSwiNetworkDebug_t . . . 608
unpack_nas_SLQSSysInfoCallback_ind_t . . . 609
unpack_omaDmConfigTlv_t . . . 612
unpack_omaDmFotaTlv_t . . . 613
unpack_omaDmNotificationsTlv_t . . . 615
unpack_pds_GetPDSDefaults_t . . . 616
unpack_pds_GetPDSState_t . . . 617
unpack_pds_GetPortAutomaticTracking_t . . . 618
unpack_pds_GetServiceAutomaticTracking_t . . . 618
unpack_pds_GetXTRAAutomaticDownload_t . . . 619
unpack_pds_GetXTRANetwork_t . . . 619
unpack_pds_GetXTRAValidity_t . . . 620
unpack_pds_SetEventReport_Ind_t . . . 620
unpack_pds_SetPdsState_Ind_t . . . 622
unpack_pds_SLQSGetAGPSConfig_t . . . 623
unpack_pds_SLQSGetGPSStateInfo_t . . . 624
unpack_qmi_t . . . 628
unpack_qos_dataRate_t . . . 628
unpack_qos_IPv4Addr_t . . . 629
unpack_qos_IPv6Addr_t . . . 629
unpack_qos_IPv6TrafCls_t . . . 630
unpack_qos_pktErrRate_t . . . 630
unpack_qos_Port_t . . . 631
unpack_qos_QosFlowInfo_t . . . 631
unpack_qos_QosFlowInfoState_t . . . 633
unpack_qos_SLQSQosGetNetworkStatus_t . . . 633
unpack_qos_SLQSQosSwiReadApnExtraParams_t . . . 634
unpack_qos_SLQSQosSwiReadDataStats_t . . . 635
unpack_qos_SLQSSetQosEventCallback_ind_t . . . 636
unpack_qos_SLQSSetQosNWStatusCallback_ind_t . . . 637
unpack_qos_SLQSSetQosPriEventCallback_ind_t . . . 637
unpack_qos_SLQSSetQosStatusCallback_ind_t . . . 638
unpack_qos_swiQosFilter_t . . . 639
unpack_qos_swiQosFlow_t . . . 643
unpack_qos_tokenBucket_t . . . 647
unpack_qos_Tos_t . . . 647
unpack_QosFlowStat_t . . . 648
unpack_rms_GetSMSWake_t . . . 648
unpack_RMTransferStatistics_ind_t . . . 649

unpack_sar_SLQSGetRfSarState_t . . . 650
unpack_sms_GetSMSCAddress_t . . . 651
unpack_sms_SaveSMS_t . . . 651
unpack_sms_SendSMS_t . . . 652
unpack_sms_SetNewSMSCallback_ind_t . . . 652
unpack_sms_SetNewSMSCallback_t . . . 653
unpack_sms_SLQSDeleteSMS_t . . . 654
unpack_sms_SLQSGetIndicationRegister_t . . . 654
unpack_sms_SLQSGetMessageWaiting_t . . . 654
unpack_sms_SLQSGetSMS_t . . . 655
unpack_sms_SLQSGetSmsBroadcastConfig_t . . . 656
unpack_sms_SLQSGetSMSList_t . . . 656
unpack_sms_SLQSGetTransLayerInfo_t . . . 657
unpack_sms_SLQSGetTransNWRegInfo_t . . . 657
unpack_sms_SLQSModifySMSStatus_t . . . 657
unpack_sms_SLQSSmsGetMaxStorageSize_t . . . 658
unpack_sms_SLQSSmsGetMessageProtocol_t . . . 658
unpack_sms_SLQSSwiGetSMSStorage_t . . . 659
unpack_sms_SLQSWmsMemoryFullCallBack_ind_t . . . 659
unpack_swiaudio_SLQSGetM2MAudioProfile_t . . . 660
unpack_swiaudio_SLQSGetM2MAudioVolume_t . . . 661
unpack_swiaudio_SLQSGetM2MAVMute_t . . . 661
unpack_swiaudio_SLQSGetM2MSpkrGain_t . . . 662
unpack_swiavms_SLQSAVMSEventReportInd_t . . . 662
unpack_swiavms_SLQSAVMSGetSettings_t . . . 664
unpack_swiavms_SLQSAVMSSendSelection_t . . . 666
unpack_swiavms_SLQSAVMSSessionGetInfo_t . . . 666
unpack_swiavms_SLQSAvmsSetEventReport_t . . . 667
unpack_swiavms_SLQSAVMSSetSettings_t . . . 667
unpack_swiavms_SLQSAVMSStartSession_t . . . 667
unpack_swiavms_SLQSAVMSStopSession_t . . . 668
unpack_swiloc_SwiLocGetAutoStart_t . . . 668
unpack_swioma_SLQSOMADMAlertCallback_ind_t . . . 670
unpack_swioma_SLQSOMADMGetSessionInfo_t . . . 671
unpack_swioma_SLQSOMADMGetSettings_t . . . 673
unpack_swioma_SLQSOMADMStartSession_t . . . 675
unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t . . . 675
unpack_tmd_SLQSTmdGetMitigationDevList_t . . . 676
unpack_tmd_SLQSTmdGetMitigationLvl_t . . . 676
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t . . . 677
unpack_tmd_SLQSTmdRegNotMitigationLvl_t . . . 678
unpack_uim_ChangePin_t . . . 678
unpack_uim_GetCardStatus_t . . . 679
unpack_uim_ReadTransparent_t . . . 679
unpack_uim_SetPinProtection_t . . . 680
unpack_uim_SetUimSlotStatusChangeCallback_ind_t . . . 681
unpack_uim_SLQSUIMAuthenticate_t . . . 682
unpack_uim_SLQSUIMDepersonalization_t . . . 682
unpack_uim_SLQSUIMEventRegister_t . . . 683
unpack_uim_SLQSUIMGetConfiguration_t . . . 683
unpack_uim_SLQSUIMGetFileAttributes_t . . . 684
unpack_uim_SLQSUIMGetSlotsStatus_t . . . 685
unpack_uim_SLQSUIMRefreshGetLastEvent_t . . . 685
unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t . . . 686
unpack_uim_UnblockPin_t . . . 686
unpack_uim_VerifyPin_t . . . 687
unpack_voice_SLQSOriginateUSSD_t . . . 688
unpack_voice_SLQSVoiceAnswerCall_t . . . 691

unpack_voice_SLQSVoiceBurstDTMF_t . . . 692
unpack_voice_SLQSVoiceDialCall_t . . . 692
unpack_voice_SLQSVoiceEndCall_t . . . 693
unpack_voice_SLQSVoiceGetAllCallInfo_t . . . 694
unpack_voice_SLQSVoiceGetCallBarring_t . . . 696
unpack_voice_SLQSVoiceGetCallForwardingStatus_t . . . 698
unpack_voice_SLQSVoiceGetCallInfo_t . . . 699
unpack_voice_SLQSVoiceGetCallWaiting_t . . . 703
unpack_voice_SLQSVoiceGetCLIP_t . . . 704
unpack_voice_SLQSVoiceGetCLIR_t . . . 705
unpack_voice_SLQSVoiceGetCNAP_t . . . 707
unpack_voice_SLQSVoiceGetCOLP_t . . . 708
unpack_voice_SLQSVoiceGetCOLR_t . . . 709
unpack_voice_SLQSVoiceGetConfig_t . . . 711
unpack_voice_SLQSVoiceManageCalls_t . . . 713
unpack_voice_SLQSVoiceSendFlash_t . . . 713
unpack_voice_SLQSVoiceSetCallBarringPassword_t . . . 714
unpack_voice_SLQSVoiceSetConfig_t . . . 715
unpack_voice_SLQSVoiceSetSUPSService_t . . . 717
unpack_voice_SLQSVoiceStartContDTMF_t . . . 718
unpack_voice_SLQSVoiceStopContDTMF_t . . . 718
unpack_wds_DHCPv4ClientLease_ind_t . . . 719
unpack_wds_GetAutoconnect_t . . . 719
unpack_wds_GetByteTotals_t . . . 720
unpack_wds_GetConnectionRate_t . . . 720
unpack_wds_GetDataBearerTechnology_t . . . 721
unpack_wds_GetDefaultProfile_t . . . 722
unpack_wds_GetDefaultProfileNum_t . . . 724
unpack_wds_GetDormancyState_t . . . 725
unpack_wds_GetLastMobileIPError_t . . . 725
unpack_wds_GetMobileIP_t . . . 726
unpack_wds_GetMobileIPProfile_t . . . 726
unpack_wds_GetPacketStatistics_t . . . 728
unpack_wds_GetPacketStatus_t . . . 730
unpack_wds_GetSessionDuration_t . . . 732
unpack_wds_GetSessionState_t . . . 732
unpack_wds_RMSetTransferStatistics_t . . . 733
unpack_wds_SetMobileIPProfile_t . . . 733
unpack_wds_SLQSCreateProfile_t . . . 733
unpack_wds_SLQSDeleteProfile_t . . . 734
unpack_wds_SLQSGet3GPPConfigItem_t . . . 734
unpack_wds_SLQSGetCurrDataSystemStat_t . . . 736
unpack_wds_SLQSGetCurrentChannelRate_t . . . 737
unpack_wds_SLQSGetDataBearerTechnology_t . . . 738
unpack_wds_SLQSGetDUNCallInfo_t . . . 738
unpack_wds_SLQSGetProfileSettings_t . . . 741
unpack_wds_SLQSGetRuntimeSettings_t . . . 742
unpack_wds_SLQSModifyProfile_t . . . 745
unpack_wds_SLQSSetIPFamilyPreference_t . . . 745
unpack_wds_SLQSSetPacketSrvStatusCallback_t . . . 746
unpack_wds_SLQSSetWdsEventCallback_ind_t . . . 748
unpack_wds_SLQSSGetDHCPv4ClientConfig_t . . . 750
unpack_wds_SLQSSGetLoopback_t . . . 750
unpack_wds_SLQSStartDataSession_t . . . 751
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t . . . 751
UnPackGetProfileSettingOut . . . 754
UnpackSwiAvmsEventReportBinaryUpdateSessionInfo . . . 754
UnpackSwiAvmsEventReportConfig . . . 756

UnpackSwiAvmsEventReportConnectionRequest . . . 757
UnpackSwiAvmsEventReportDataSessionStatus . . . 758
UnpackSwiAvmsEventReportHTTPStatus . . . 758
UnpackSwiAvmsEventReportNotification . . . 760
UnpackSwiAvmsEventReportPackageID . . . 761
UnpackSwiAvmsEventReportRegStatus . . . 761
UnpackSwiAvmsEventReportSessionType . . . 762
UnpackSwiAvmsEventReportWAMSParamChange . . . 762
unpackWdsProfileParam . . . 763
voice_airTimer . . . 763
voice_allCallsAlphaIDInfo . . . 764
voice_allCallsDiagInfo . . . 764
voice_allCallsUUSInfo . . . 765
voice_alphaIDInfo . . . 765
voice_arrAlertingPattern . . . 766
voice_arrAlertingType . . . 767
voice_arrAlphaID . . . 768
voice_arrCalledPartyNum . . . 768
voice_arrCallEndReason . . . 769
voice_arrCallInfo . . . 770
voice_arrConnectPartyNum . . . 770
voice_arrDiagInfo . . . 771
voice_arrRedirPartyNum . . . 771
voice_arrRemotePartyName . . . 772
voice_arrRemotePartyNum . . . 772
voice_arrSvcOption . . . 773
voice_arrUUSInfo . . . 773
voice_burstDTMFInfo . . . 774
voice_calledPartySubAdd . . . 775
voice_callFwdTypeAndPlan . . . 776
voice_callFWExtInfo . . . 776
voice_callFWInfo . . . 778
voice_callInfo . . . 779
voice_ccSUPSType . . . 781
voice_CLIPResp . . . 781
voice_CLIRResp . . . 782
voice_CNAPResp . . . 783
voice_COLPResp . . . 784
voice_COLRResp . . . 784
voice_connectNumInfo . . . 785
voice_CUGInfo . . . 787
voice_curAMRConfig . . . 787
voice_diagInfo . . . 788
voice_DTMFLengths . . . 789
voice_getAllCallInformation . . . 789
voice_getAllCallRmtPtyName . . . 790
voice_getAllCallRmtPtyNum . . . 790
voice_getCallFWExtInfo . . . 791
voice_getCallFWInfo . . . 792
voice_peerNumberInfo . . . 792
voice_prefVoiceSO . . . 794
voice_remotePartyName . . . 796
voice_remotePartyNum . . . 797
voice_roamTimer . . . 797
voice_USSInfo . . . 798
voice_UUSInfo . . . 799
wds_currNetworkInfo . . . 800
wds_DataULongLongTlv . . . 801

wds_DataULongTlv . . . 802
wds_DHCPLeaseOptTlv . . . 802
wds_DHCPLeaseStateTlv . . . 803
wds_DHCPOpt . . . 803
wds_DHCPProfileIdTlv . . . 804
wds_DHCPv4HWConfig . . . 804
wds_DHCPv4Option . . . 805
wds_DHCPv4OptionList . . . 806
wds_DHCPv4ProfileId . . . 806
wds_Domain . . . 807
wds_DomainNameList . . . 807
wds_GPRSQoS . . . 808
wds_IPv4AdTlv . . . 809
wds_IPV6AddressInfo . . . 809
wds_IPV6GWAddressInfo . . . 809
wds_PCSCFFQDNAddress . . . 810
wds_PCSCFFQDNAddressList . . . 811
wds_PCSCFIPv4ServerAddressList . . . 811
wds_ProfileIdentifier . . . 812
wds_profileInfo . . . 812
wds_transferStatInd . . . 813
wds_TrStatInd . . . 813
wds_UMTSMinQoS . . . 814
wdsDhcpv4HwConfig . . . 816
wdsDhcpv4Option . . . 817
wdsDhcpv4OptionList . . . 818
wdsDhcpv4ProfileId . . . 818

Chapter 5

File Index

5.1 File List

Here is a list of all files with brief descriptions:

apdoxypages.c
Contains the module declaration for the Doxygen output. Also contains the content of the main page and related pages . . . 821
audio.h . . . 821
cat.h . . . 827
common.h . . . 830
dms.h . . . 835
fms.h . . . 888
ims.h . . . 891
imsa.h . . . 900
lite-fw.h . . . 904
loc.h . . . 912
nas.h . . . 929
pds.h . . . 979
qaGobiApiTableBandClasses.h
Network Access Service API Band Classes table . . . 1000
qaGobiApiTableCallControlReturnReasons.h
Call Control Return Reasons table . . . 1003
qaGobiApiTableCallEndReasons.h
Wireless Data Service Call End Reasons . . . 1003
qaGobiApiTableCarrierCodes.h
Carrier Codes table . . . 1020
qaGobiApiTableCodingScheme.h
Data Coding Scheme . . . 1022
qaGobiApiTableGpsCapabilityCodes.h
Position Determination Service API GPS Capability Codes . . . 1024
qaGobiApiTablePowerModes.h
Device Management Service API Power Modes table . . . 1025
qaGobiApiTableRadioInterfaces.h
Network Access Service API Radio Interfaces table . . . 1026
qaGobiApiTableRegionCodes.h
Region Codes table . . . 1026
qaGobiApiTableServiceOptions.h
Voice Service Options . . . 1027
qaGobiApiTableSupServiceInfoClasses.h
Voice Supplementary Service Information Classes . . . 1029
qaGobiApiTableSwiAudio.h
Swi Audio related tables . . . 1029

qaGobiApiTableSwiOMADMSessionStatus.h
Session Status table . . . 1030
qaGobiApiTableSwiOMADMUpdateCompleteStatus.h
Update Complete Status table . . . 1031
qaGobiApiTableVoiceCallEndReasons.h
Voice Service Call and supplementary services end reasons . . . 1032
qmerrno.h . . . 1039
qos.h . . . 1046
rms.h . . . 1056
sar.h . . . 1057
sms.h . . . 1059
swiaudio.h . . . 1079
swiavms.h . . . 1088
SwiDataTypes.h
SWI data types . . . 1099
swiloc.h . . . 1100
swioma.h . . . 1102
swiomaext.h . . . 1111
SWIWWANCMAPI.h . . . 1115
tmd.h . . . 1115
uim.h . . . 1120
voice.h . . . 1138
wds.h . . . 1165

Chapter 6

Module Documentation

6.1 QMI pack/unpack (lite-qmi)

Files

- file common.h
- file dms.h
- file loc.h
- file nas.h
- file qos.h
- file sms.h
- file swioma.h
- file uim.h
- file wds.h
- file fms.h
- file swiloc.h
- file pds.h
- file rms.h
- file sar.h
- file swiavms.h
- file voice.h
- file cat.h
- file imsa.h
- file tmd.h
- file swiomaext.h
- file audio.h
- file swiaudio.h
- file ims.h

6.1.1 Detailed Description

6.2 Streaming Download Protocol (lite-fw)

Files

- file lite-fw.h

6.2.1 Detailed Description

Chapter 7

Namespace Documentation

7.1 Tables Namespace Reference

7.1.1 Detailed Description

Tables referenced in the API function headers:

- Table 1 - Call End Reason Codes The reason a call (either in process or connected) was ended. qaGobiApiTableCallEndReasons.h
- Table 2 - Carrier codes List of carrier identification codes. qaGobiApiTableCarrierCodes.h
- Table 3 - Region codes List of region identification codes. qaGobiApiTableRegionCodes.h
- Table 4 - GPS capability codes List of GPS capability codes. qaGobiApiTableGpsCapabilityCodes.h
- Table 5 - Radio Interfaces List of radio interface technologies. qaGobiApiTableRadioInterfaces.h
- Table 6 - Band classes List of band classes. qaGobiApiTableBandClasses.h
- Table 7 - Power modes List of operating modes. qaGobiApiTablePowerModes.h
- Table 8 - Service Options List of Service Options. qaGobiApiTableServiceOptions.h
- Table 9 - Voice Call End Reason List of Voice Call End Reason. qaGobiApiTableVoiceCallEndReasons.h
- Table 10 - Data Coding Scheme List of Data Coding Scheme. qaGobiApiTableCodingScheme.h
- Table 11 - Call Control Return Reasons List of Voice Call Control Return Reasons. qaGobiApiTableCallControlReturnReasons.h
- Table 12 - Supplementary Service Information Classes List of Voice Supplementary Service Information Classes. qaGobiApiTableSupServiceInfoClasses.h
- Table 13 - Audio Calibration Data Base(ACDB) Device List of ACDB devices. qaGobiApiTableSwiAudio.h
- Table 14 - PIFACE List of physical interfaces. qaGobiApiTableSwiAudio.h

Chapter 8

Data Structure Documentation

8.1 _litefw_FirmwareInfo_ Struct Reference

Data Fields

- char szModelid_str [20]
- char szFwversion_str [20]
- char szSku_str [20]
- char szPackageid_str [20]
- char szCarrier_str [20]
- char szCarrierPriversion_str [20]

8.1.1 Detailed Description

This structure contains information of the response parameters associated with a Read Transparent API.

Parameters

szModelid_str	• Model Name String
szFwversion_str	• Firmware Version String.
szSku_str	• SKU String.
szPackageid_str	• Package ID String.
szCarrier_str	• Carrier String.
szCarrier-Priversion_str	• Carrier PRI Version String.

8.1.2 Field Documentation

8.1.2.1 char _litefw_FirmwareInfo_::szCarrier_str[20]

8.1.2.2 char _litefw_FirmwareInfo_::szCarrierPriversion_str[20]

8.1.2.3 char _litefw_FirmwareInfo_::szFwversion_str[20]

8.1.2.4 char _litefw_FirmwareInfo_::szModelid_str[20]

8.1.2.5 char _litefw_FirmwareInfo_::szPackageid_str[20]

8.1.2.6 char _litefw_FirmwareInfo_::szSku_str[20]

8.2 altSrcInfo_t Struct Reference

Data Fields

- uint32_t source
- uint32_t linkage
- uint32_t coverage

8.2.1 Detailed Description

This structure specifies information regarding the altitude source

Parameters

source	• Specifies the source of the altitude • Valid values – 0 - Source is unknown – 1 - GPS is the source – 2 - Cell ID provided the source – 3 - Source is enhanced cell ID – 4 - Wi-Fi is the source – 5 - Terrestrial source – 6 - Hybrid terrestrial source – 7 - Altitude database is the source – 8 - Barometric altimeter is the source – 9 - Other sources
linkage	• Specifies the dependency between the horizontal and altitude position components • Valid values – 0 - Not specified – 1 - Fully interdependent – 2 - Depends on latitude and longitude – 3 - Fully independent

coverage	• Specifies the region of uncertainty. • Valid values – 0 - Not specified – 1 - Altitude uncertainty is valid at the injected horizontal position coordinates only – 2 - Altitude uncertainty applies to the position of the device regardless of horizontal position

8.2.2 Field Documentation

8.2.2.1 uint32_t altSrcInfo_t::coverage

8.2.2.2 uint32_t altSrcInfo_t::linkage

8.2.2.3 uint32_t altSrcInfo_t::source

8.3 appStats Struct Reference

Data Fields

- uint8_t appType
- uint8_t appState
- uint8_t persoState
- uint8_t persoFeature
- uint8_t persoRetries
- uint8_t persoUnblockRetries
- uint8_t aidLength
- uint8_t aidVal [255]
- uint8_t univPin
- uint8_t pin1State
- uint8_t pin1Retries
- uint8_t puk1Retries
- uint8_t pin2State
- uint8_t pin2Retries
- uint8_t puk2Retries

8.3.1 Detailed Description

This structure contains Application Status Information loaded on the card.

Parameters

appType	• Indicates the type of the application. – 0 - Unknown – 1 - SIM card – 2 - USIM application – 3 - RUIM card – 4 - CSIM application – 5 - ISIM application • Other values are reserved for the future and are to be handled as "Unknown".

appState	• Indicates the state of the application. – 0 - Unknown – 1 - Detected – 2 - PIN1 or UPIN is required – 3 - PUK1 or PUK for UPIN is required – 4 - Personalization state must be checked – 5 - PIN1 is blocked – 6 - Illegal – 7 - Ready
persoState	• Indicates the state of the personalization for the application. – 0 - Unknown – 1 - Personalization operation is in progress – 2 - Ready – 3 - Personalization code is required – 4 - PUK for personalization code is required – 5 - Permanently blocked
persoFeature	• Indicates the personalization feature. • This applies only when a personalization code is required to deactivate or unblock personalization. – 0 - GW network personalization – 1 - GW network subset personalization – 2 - GW service provider personalization – 3 - GW corporate personalization – 4 - GW UIM personalization – 5 - 1X network type 1 personalization – 6 - 1X network type 2 personalization – 7 - 1X HRPD personalization – 8 - 1X service provider personalization – 9 - 1X corporate personalization – 10 - 1X RUIM personalization – 11 - Unknown
persoRetries	• Indicates the number of retries remaining to disable the personalization.
persoUnblock-Retries	• Indicates the number of retries remaining to unblock the personalization.
aidLength	• Number of sets of the following elements. i.e. aidVal • If zero(0) then no aidVal information exists.
aidVal[MAX_DE-SCRIPTION_LE-NGTH]	• Application identifier value.

univPin	• Indicates whether UPIN replaces PIN1. – 0 - PIN1 is used – 1 - UPIN replaces PIN1
pin1State	• Indicates the state of PIN1. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked
pin1Retries	• Indicates the number of retries remaining to verify PIN1.
puk1Retries	• Indicates the number of retries remaining to unblock PIN1.
pin2State	• Indicates the state of PIN2. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked
pin2Retries	• Indicates the number of retries remaining to verify PIN2.
puk2Retries	• Indicates the number of retries remaining to unblock PIN2.

8.3.2 Field Documentation

8.3.2.1 uint8_t appStats::aidLength

8.3.2.2 uint8_t appStats::aidVal[255]

8.3.2.3 uint8_t appStats::appState

8.3.2.4 uint8_t appStats::appType

8.3.2.5 uint8_t appStats::persoFeature

8.3.2.6 uint8_t appStats::persoRetries

8.3.2.7 uint8_t appStats::persoState

8.3.2.8 uint8_t appStats::persoUnblockRetries

8.3.2.9 uint8_t appStats::pin1Retries

8.3.2.10 uint8_t appStats::pin1State

8.3.2.11 uint8_t appStats::pin2Retries

8.3.2.12 uint8_t appStats::pin2State

8.3.2.13 uint8_t appStats::puk1Retries

8.3.2.14 uint8_t appStats::puk2Retries

8.3.2.15 uint8_t appStats::univPin

8.4 audio_RXAGCList Struct Reference

Data Fields

- uint16_t * pRXStaticGain
- uint16_t * pRXAIG
- uint16_t * pRXExpThres
- uint16_t * pRXExpSlope
- uint16_t * pRXComprThres
- uint16_t * pRXComprSlope

8.4.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig parameters related to AV_RXAGCLIST.

Parameters

pRXStaticGain	• RX pre-compressor static gain
pRXAIG	• RX pre-compressor gain selection flag
pRXExpThres	• RX expansion threshold
pRXExpSlope	• RX expansion slope
pRXComprThres	• RX compression threshold
pRXComprSlope	• RX compression slope

8.4.2 Field Documentation

8.4.2.1 uint16_t* audio_RXAGCList::pRXAIG

8.4.2.2 uint16_t* audio_RXAGCList::pRXComprSlope

8.4.2.3 uint16_t* audio_RXAGCList::pRXComprThres

8.4.2.4 uint16_t* audio_RXAGCList::pRXExpSlope

8.4.2.5 uint16_t* audio_RXAGCList::pRXExpThres

8.4.2.6 uint16_t* audio_RXAGCList::pRXStaticGain

8.5 audio_RXAVCList Struct Reference

Data Fields

- uint16_t * pAVRXAVCSens
- uint16_t * pAVRXAVCHeadroom

8.5.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig parameters related to AV_RXAVCLIST.

Parameters

pAVRXAVC-Sens	• AVC variation from nominal sensitivity
pAVRXAVC-Headroom	• AVC headroom

8.5.2 Field Documentation

8.5.2.1 uint16_t* audio_RXAVCList::pAVRXAVCHeadroom

8.5.2.2 uint16_t* audio_RXAVCList::pAVRXAVCSens

8.6 audio_RXPCMIIRFltr Struct Reference

Data Fields

- uint16_t * pFlag
- uint16_t * pStageCnt
- uint8_t * pStage0Val
- uint8_t * pStage1Val
- uint8_t * pStage2Val
- uint8_t * pStage3Val
- uint8_t * pStage4Val

8.6.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig parameters related to AV_RXPCMIIRFLTR.

Parameters

pFlag	• Flag – 0x0000 - IIR filter disable – 0xffff - IIR filter enable
pStageCnt	• Stage Count – 0-4
pStage0Val	• A 20 BYTE sized parameter indicating Stage 0 value – A1 – A2 – B0 – B1 – B2
pStage1Val	• A 20 BYTE sized parameter indicating Stage 1 value – A1 – A2 – B0 – B1 – B2
pStage2Val	• A 20 BYTE sized parameter indicating Stage 2 value – A1 – A2 – B0 – B1 – B2
pStage3Val	• A 20 BYTE sized parameter indicating Stage 3 value – A1 – A2 – B0 – B1 – B2
pStage4Val	• A 20 BYTE sized parameter indicating Stage 4 value – A1 – A2 – B0 – B1 – B2

8.6.2 Field Documentation

8.6.2.1 uint16_t* audio_RXPCMIIRFltr::pFlag

8.6.2.2 uint8_t* audio_RXPCMIIRFltr::pStage0Val

8.6.2.3 uint8_t* audio_RXPCMIIRFltr::pStage1Val

8.6.2.4 uint8_t* audio_RXPCMIIRFltr::pStage2Val

8.6.2.5 uint8_t* audio_RXPCMIIRFltr::pStage3Val

8.6.2.6 uint8_t* audio_RXPCMIIRFltr::pStage4Val

8.6.2.7 uint16_t* audio_RXPCMIIRFltr::pStageCnt

8.7 audio_TXAGCList Struct Reference

Data Fields

- uint16_t * pTXStaticGain
- uint16_t * pTXAIG
- uint16_t * pTXExpThres
- uint16_t * pTXExpSlope
- uint16_t * pTXComprThres
- uint16_t * pTXComprSlope

8.7.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig parameters related to AV_TXAGCLIST.

Parameters

pTXStaticGain	• TX pre-compressor static gain
pTXAIG	• TX pre-compressor gain selection flag
pTXExpThres	• TX expansion threshold
pTXExpSlope	• TX expansion slope
pTXComprThres	• TX compression threshold
pTXComprSlope	• TX compression slope

8.7.2 Field Documentation

8.7.2.1 uint16_t* audio_TXAGCList::pTXAIG

8.7.2.2 uint16_t* audio_TXAGCList::pTXComprSlope

8.7.2.3 uint16_t* audio_TXAGCList::pTXComprThres

8.7.2.4 uint16_t* audio_TXAGCList::pTXExpSlope

8.7.2.5 uint16_t* audio_TXAGCList::pTXExpThres

8.7.2.6 uint16_t* audio_TXAGCList::pTXStaticGain

8.8 audio_TXPCMIIRFltr Struct Reference

Data Fields

- uint16_t * pFlag
- uint16_t * pStageCnt
- uint8_t * pStage0Val
- uint8_t * pStage1Val
- uint8_t * pStage2Val
- uint8_t * pStage3Val
- uint8_t * pStage4Val

8.8.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig parameters related to AV_TXPCMIIRFLTR.

Parameters

pFlag	• Flag – 0x0000 - IIR filter disable – 0xffff - IIR filter enable
pStageCnt	• Stage Count – 0-4
pStage0Val	• A 20 BYTE sized parameter indicating Stage 0 value – A1 – A2 – B0 – B1 – B2

pStage1Val	• A 20 BYTE sized parameter indicating Stage 1 value – A1 – A2 – B0 – B1 – B2
pStage2Val	• A 20 BYTE sized parameter indicating Stage 2 value – A1 – A2 – B0 – B1 – B2
pStage3Val	• A 20 BYTE sized parameter indicating Stage 3 value – A1 – A2 – B0 – B1 – B2
pStage4Val	• A 20 BYTE sized parameter indicating Stage 4 value – A1 – A2 – B0 – B1 – B2

8.8.2 Field Documentation

8.8.2.1 uint16_t* audio_TXPCMIIRFltr::pFlag

8.8.2.2 uint8_t* audio_TXPCMIIRFltr::pStage0Val

8.8.2.3 uint8_t* audio_TXPCMIIRFltr::pStage1Val

8.8.2.4 uint8_t* audio_TXPCMIIRFltr::pStage2Val

8.8.2.5 uint8_t* audio_TXPCMIIRFltr::pStage3Val

8.8.2.6 uint8_t* audio_TXPCMIIRFltr::pStage4Val

8.8.2.7 uint16_t* audio_TXPCMIIRFltr::pStageCnt

8.9 CarrierImage_t Struct Reference

Data Fields

- uint32_t m_nCarrierId
- uint32_t m_nFolderId
- uint32_t m_nStorage
- uint8_t m_FwImageId [16]
- uint8_t m_FwBuildId [32]
- uint8_t m_PriImageId [16]
- uint8_t m_PriBuildId [32]

8.9.1 Detailed Description

This structure contains the Carrier Image parameters.

Parameters

m_nCarrierId	• Unique numeric carrier ID indicating the carrier that the following images belong to
m_nFolderId	• Unique numeric folder ID indicating the folder where the images should reside on the host storage.
m_nStorage	• Information of storage type • Values – 0 - Device – 1 - Host
m_FwImageId	• Firmware image ID
m_FwBuildId	• Firmware build ID
m_PriImageId	• PRI image ID
m_PriBuildId	• PRI build ID

8.9.2 Field Documentation

8.9.2.1 uint8_t CarrierImage_t::m_FwBuildId[32]

8.9.2.2 uint8_t CarrierImage_t::m_FwImageId[16]

8.9.2.3 uint32_t CarrierImage_t::m_nCarrierId

8.9.2.4 uint32_t CarrierImage_t::m_nFolderId

8.9.2.5 uint32_t CarrierImage_t::m_nStorage

8.9.2.6 uint8_t CarrierImage_t::m_PriBuildId[32]

8.9.2.7 uint8_t CarrierImage_t::m_PriImageId[16]

8.10 cat_AlPhaIdentifierTlv Struct Reference

Data Fields

- uint8_t ReferenceID
- uint16_t AlphaIDLength
- uint8_t AlphaID [255]

8.10.1 Detailed Description

structure used to store all Alpha Identifier parameters.

Parameters

ReferenceID	- proactive command type that included the alpha identifier - 0x01; sends SMS proactive command
AlphaIDLength	- length of AlphaID (in bytes)
AlphaID	- alpha identifier, encoded as in ETSI TS 102 223 [Section 8.2]

8.10.2 Field Documentation

8.10.2.1 uint8_t cat_AlPhaIdentifierTlv::AlphaID[255]

8.10.2.2 uint16_t cat_AlPhaIdentifierTlv::AlphaIDLength

8.10.2.3 uint8_t cat_AlPhaIdentifierTlv::ReferenceID

8.11 cat_commonEventTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t EventID
- uint16_t EventLength
- union cat_currentCatEvent CatEvent

8.11.1 Detailed Description

Structure used to store all Common CAT Event TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
EventID	- Event ID. Can be any of the following 16 - Display Text 17 - Get In-Key 18 - Get Input 19 - Setup Menu 20 - Select Item 21 - Send SMS - Alpha Identifier 22 - Setup Event List 23 - Setup Idle Mode Text 24 - Language Notification 25 - Refresh 26 - End Proactive Session
EventLength	- Length of pData (in Bytes)
CatEvent	- Structure to the Data specific to the CAT event ID

8.11.2 Field Documentation

8.11.2.1 union cat_currentCatEvent cat_commonEventTlv::CatEvent

8.11.2.2 uint8_t cat_commonEventTlv::EventID

8.11.2.3 uint16_t cat_commonEventTlv::EventLength

8.11.2.4 uint8_t cat_commonEventTlv::TlvPresent

8.12 cat_currentCatEvent Union Reference

Data Fields

- struct cat_EventIDDataTlv CatEvIDData
- struct cat_AlPhaIdentifierTlv CatAlphaIdtfr
- struct cat_EventListTlv CatEventLst
- struct cat_RefreshTlv CatRefresh
- struct cat_EndProactiveSessionTlv CatEndPS

8.12.1 Detailed Description

Union used to represent the current CAT Event Data. Choose the structure based on the EventID received.

- Use cat_EventIDDataTlv if the Event ID is any of the below.
  - 16
  - 17
  - 18
  - 19
  - 20
  - 23
  - 24
- Use cat_AlPhaIdentifierTlv if the Event ID is 21
- Use cat_EventListTlv if the Event ID is 22
- Use cat_RefreshTlv if the Event ID is 25
- Use cat_EndProactiveSessionTlv if the Event ID is 26

8.12.2 Field Documentation

8.12.2.1 struct cat_AlPhaIdentifierTlv cat_currentCatEvent::CatAlphaIdtfr

8.12.2.2 struct cat_EndProactiveSessionTlv cat_currentCatEvent::CatEndPS

8.12.2.3 struct cat_EventListTlv cat_currentCatEvent::CatEventLst

8.12.2.4 struct cat_EventIDDataTlv cat_currentCatEvent::CatEvIDData

8.12.2.5 struct cat_RefreshTlv cat_currentCatEvent::CatRefresh

8.13 cat_EndProactiveSessionTlv Struct Reference

Data Fields

- uint8_t EndProactiveSession

8.13.1 Detailed Description

structure used to store End Proactive Session event parameters.

Parameters

EndProactive-Session	- The proactive session end type values are: • 0x01 - End proactive session command type received from the card • 0x02 - End proactive session internal to ME

8.13.2 Field Documentation

8.13.2.1 uint8_t cat_EndProactiveSessionTlv::EndProactiveSession

8.14 cat_EventIDDataTlv Struct Reference

Data Fields

- uint32_t ReferenceID
- uint16_t DataLength
- uint8_t Data [255]

8.14.1 Detailed Description

structure used to store all Common CAT Event parameters.

Parameters

ReferenceID	- proactive command reference ID.
DataLength	- length of pData (in Bytes)
Data	- command specific to the CAT event ID, encoded as in ETSI TS 102 223 [Section 6.6.X]

8.14.2 Field Documentation

8.14.2.1 uint8_t cat_EventIDDataTlv::Data[255]

8.14.2.2 uint16_t cat_EventIDDataTlv::DataLength

8.14.2.3 uint32_t cat_EventIDDataTlv::ReferenceID

8.15 cat_EventListTlv Struct Reference

Data Fields

- uint32_t SetupEventList

8.15.1 Detailed Description

structure used to store all Event List parameters.

Parameters

SetupEventList	- Setup event list bit mask • 0x00000001 - User Activity Notify • 0x00000002 - Idle Screen Available • 0x00000004 - Lang Selection Notify Each set bit indicates the availability of the corresponding event in Setup Event list proactive command; all unlisted bits are reserved for future use and will be ignored

8.15.2 Field Documentation

8.15.2.1 uint32_t cat_EventListTlv::SetupEventList

8.16 cat_RefreshTlv Struct Reference

Data Fields

- uint16_t RefreshMode
- uint8_t RefreshStage

8.16.1 Detailed Description

structure used to store all Refresh Event parameters.

Parameters

RefreshMode	- The Refresh Event as in ETSI TS 102 223 [Section 8.6]
RefreshStage	- Stage of a refresh procedure • 0x01 - Refresh start • 0x02 - Refresh success • 0x03 - Refresh failed

8.16.2 Field Documentation

8.16.2.1 uint16_t cat_RefreshTlv::RefreshMode

8.16.2.2 uint8_t cat_RefreshTlv::RefreshStage

8.17 cdmaSSInfo Struct Reference

Data Fields

- int8_t rssi
- int16_t ecio

8.17.1 Detailed Description

This structure contains the parameters for CDMA/WCDMA Signal Strength Information

Parameters

rssi	• RSSI in dBm (signed value). • A value of -125 dBm or lower is used to indicate No Signal.
ecio	• ECIO value representing negative 0.5 dBm increments, i.e., 2 means -1 dBm (14 means -7 dBm, 63 means -31.5 dBm).

8.17.2 Field Documentation

8.17.2.1 int16_t cdmaSSInfo::ecio

8.17.2.2 int8_t cdmaSSInfo::rssi

8.18 connectionStatus Struct Reference

Data Fields

- uint8_t MDMConnStatus
- uint64_t MDMCallDuration

8.18.1 Detailed Description

This structure contains modem connection status

Parameters

MDMConn-Status	• Current link status – 0x01 - DISCONNECTED – 0x02 - CONNECTED – 0xff - Invalid data.
MDMCall-Duration	• Call duration in milliseconds. • If the modem connection status is connected, this represent the duration of the current DUN call. • If the modem connection status is disconnected, this represents the duration of the last DUN call since the device was powered up (zero, if no call has been made or if the last call was not DUN). – 0xffffffffffffffff - Invalid data.

8.18.2 Field Documentation

8.18.2.1 uint64_t connectionStatus::MDMCallDuration

8.18.2.2 uint8_t connectionStatus::MDMConnStatus

8.19 crashInfoParams Struct Reference

Data Fields

- uint8_t crashStatus
- crashInformation crashInfo

8.19.1 Detailed Description

This structure contains crash information parameters

Parameters

crashStatus[OUT]	• Device Crash Status • 0 - no crash • 1 - crash has occurred • 0xff - invalid data.
crashInfo[OUT]	• See crashInformation

8.19.2 Field Documentation

8.19.2.1 crashInformation crashInfoParams::crashInfo

8.19.2.2 uint8_t crashInfoParams::crashStatus

8.20 crashInformation Struct Reference

Data Fields

- uint16_t numCrashes
- uint32_t crashId
- uint32_t crashData
- uint16_t crashStrlen
- char crashString [255]
- uint16_t gcdumpStrlen
- char gcdumpString [1024]

8.20.1 Detailed Description

This structure contains crash information

Parameters

numCrashes[OUT]	• number of instances of the remaining fields

crashId[OUT]	• ramdom crash id assigned at crash
crashData	• crash data[OUT]
crashStrlen[IN/-OUT]	• length of the crashString field as an input, length of the crashString field returned by API as an OUTPUT
crashString	• crash string
gcdumpStrlen[O-UT]	• length of the gcdumpString field as an input, length of the gcdumpString field returned by API as an OUTPUT
gcdumpString[O-UT]	• gcdump string for the crash

8.20.2 Field Documentation

8.20.2.1 uint32_t crashInformation::crashData

8.20.2.2 uint32_t crashInformation::crashId

8.20.2.3 char crashInformation::crashString[255]

8.20.2.4 uint16_t crashInformation::crashStrlen

8.20.2.5 char crashInformation::gcdumpString[1024]

8.20.2.6 uint16_t crashInformation::gcdumpStrlen

8.20.2.7 uint16_t crashInformation::numCrashes

8.21 currNetworkInfo Struct Reference

Data Fields

- uint8_t NetworkType
- uint32_t RATMask
- uint32_t SOMask

8.21.1 Detailed Description

Network information structure

Parameters

NetworkType	• Values: – 0 - 3GPP – 1 - 3GPP2
RATMask	• Radio Access Technology (RAT) mask to indicate the type of technology. • Values: – 0 - Don't Care – 0x8000 - NULL Bearer • CDMA RAT mask values: – 0x01 - CDMA_1x – 0x02 - EVDO_REV0 – 0x04 - EVDO_REVA – 0x08 - EVDO_REVB – 0x10 - EHRPD – 0x20 - FMC • UMTS RAT mask values: – 0x01 - WCDMA – 0x02 - GPRS – 0x04 - HSDPA – 0x08 - HSUPA – 0x10 - EDGE – 0x20 - LTE – 0x40 - HSDPA+ – 0x80 - DC_HSDPA+ – 0x100 - 64_QAM – 0x200 - TDSCDMA

SOMask	• Service Option (SO) mask to indicate the service option or type of application. • Values: – 0 - Don't Care • CDMA 1x SO mask values: – 0x01 - CDMA_1X_IS95 – 0x02 - CDMA_1X_IS2000 – 0x04 - CDMA_1X_IS2000_REL_A • CDMA EV-DO Rev 0 SO mask values: – 0x01 - DPA • CDMA EV-DO Rev A SO mask values: – 0x01 - DPA – 0x02 - MFPA – 0x04 - EMPA – 0x08 - EMPA_EHRPD • CDMA EV-DO Rev B SO mask values: – 0x01 - DPA – 0x02 - MFPA – 0x04 - EMPA – 0x08 - EMPA_EHRPD – 0x10 - MMPA – 0x20 - MMPA_EHRPD

8.21.2 Field Documentation

8.21.2.1 uint8_t currNetworkInfo::NetworkType

8.21.2.2 uint32_t currNetworkInfo::RATMask

8.21.2.3 uint32_t currNetworkInfo::SOMask

8.22 dms_ActivationStatusTlv Struct Reference

Data Fields

- uint16_t TlvPresent
- uint32_t activationStatus

8.22.1 Detailed Description

Activation Status Tlv

Parameters

TlvPresent	• Tlv Present

activationStatus	• Service Activation Code – 0 - Service not activated – 1 - Service activated – 2 - Activation connecting – 3 - Activation connected – 4 - OTASP security authenticated – 5 - OTASP NAM downloaded – 6 - OTASP MDN downloaded – 7 - OTASP IMSI downloaded – 8 - OTASP PRL downloaded – 9 - OTASP SPC downloaded – 10 - OTASP settings committed

8.22.2 Field Documentation

8.22.2.1 uint32_t dms_ActivationStatusTlv::activationStatus

8.22.2.2 uint16_t dms_ActivationStatusTlv::TlvPresent

8.23 dms_OperatingModeTlv Struct Reference

Data Fields

- uint16_t TlvPresent
- uint32_t operatingMode

8.23.1 Detailed Description

Operating Mode Tlv

Parameters

TlvPresent	• Tlv Present
operatingMode	• 0 - Online • 1 - Low power • 2 - Factory test mode • 3 - Offline • 4 - Resetting • 5 - Shutting down • 6 - Persistent low power • 7 - Mode-only low power

8.23.2 Field Documentation

8.23.2.1 uint32_t dms_OperatingModeTlv::operatingMode

8.23.2.2 uint16_t dms_OperatingModeTlv::TlvPresent

8.24 DMScustSettingInfo Struct Reference

Data Fields

- uint16_t id_length
- uint8_t cust_id [64+1]
- uint16_t value_length
- uint8_t cust_value [8+1]
- uint16_t cust_attr

8.24.1 Detailed Description

This structure contains information about Customization Setting. This TLV is only applicable for 9x30 modules so far

Parameters

id_length	• length of cust_id field
cust_id	• Customization ID (Maximum 64 bytes) • NULL terminated ASCII string.
value_length	• length of cust_value field
cust_value	• Customization Setting Value (Maximum 8 bytes)
cust_attr	• Customization Setting attribute through QMI – bit 0: Values: * 0 - read only * 1 - read/write

8.24.2 Field Documentation

8.24.2.1 uint16_t DMScustSettingInfo::cust_attr

8.24.2.2 uint8_t DMScustSettingInfo::cust_id[64+1]

8.24.2.3 uint8_t DMScustSettingInfo::cust_value[8+1]

8.24.2.4 uint16_t DMScustSettingInfo::id_length

8.24.2.5 uint16_t DMScustSettingInfo::value_length

8.25 DMScustSettingList Struct Reference

Data Fields

- uint8_t list_type
- uint16_t num_instances
- DMScustSettingInfo custSetting [255+1]

8.25.1 Detailed Description

This structure contains the fields of TLV Customization Setting List. This TLV is only applicable for 9x30 modules so far

Parameters

list_type	• list type requested
num_instances	• number of instances of customization setting
custSetting	• See DMScustSettingInfo for more information

8.25.2 Field Documentation

8.25.2.1 DMScustSettingInfo DMScustSettingList::custSetting[255+1]

8.25.2.2 uint8_t DMScustSettingList::list_type

8.25.2.3 uint16_t DMScustSettingList::num_instances

8.26 DMSgetCustomFeatureV2 Struct Reference

Data Fields

- DMSgetCustomInput * pGetCustomInput
- DMScustSettingInfo * pCustSettingInfo
- DMScustSettingList * pCustSettingList

8.26.1 Detailed Description

This struture contains the TLV required to get the Customization Info and customization list.

Parameters

pGetCustom-Input[IN]	• See DMSgetCustomInput for more information
pCustSetting-Info[OUT]	• See DMScustSettingInfo for more information

pCustSetting-List[OUT]	• See DMScustSettingList for more information

8.26.2 Field Documentation

8.26.2.1 DMScustSettingInfo* DMSgetCustomFeatureV2::pCustSettingInfo

8.26.2.2 DMScustSettingList* DMSgetCustomFeatureV2::pCustSettingList

8.26.2.3 DMSgetCustomInput* DMSgetCustomFeatureV2::pGetCustomInput

8.27 DMSgetCustomInput Struct Reference

Data Fields

- uint8_t cust_id [64+1]
- uint8_t list_type

8.27.1 Detailed Description

This structure contains which customization id or the list type want to retrieve from modem. This TLV is only applicable for 9x30 modules so far

Parameters

cust_id	• Customization ID (Maximum 64 bytes) • NULL terminated ASCII string.
list_type	• list type requested

8.27.2 Field Documentation

8.27.2.1 uint8_t DMSgetCustomInput::cust_id[64+1]

8.27.2.2 uint8_t DMSgetCustomInput::list_type

8.28 dunchannelRate Struct Reference

Data Fields

- uint32_t CurrChanTxRate
- uint32_t CurrChanRxRate
- uint32_t MaxChanTxRate
- uint32_t MaxChanRxRate

8.28.1 Detailed Description

This structure contains Channel Rate

Parameters

CurrChanTxRate	• Instantaneous channel Tx rate in bits per second • 0xffffffff - Invalid data.
CurrChanRx-Rate	• Instantaneous channel Rx rate in bits per second • 0xffffffff - Invalid data.
MaxChanTxRate	• maximum Tx rate that can be assigned to the device by the serving system in bits per second • 0xffffffff - Invalid data.
MaxChanRx-Rate	• maximum Rx rate that can be assigned to the device by the serving system in bits per second • 0xffffffff - Invalid data.

8.28.2 Field Documentation

8.28.2.1 uint32_t dunchannelRate::CurrChanRxRate

8.28.2.2 uint32_t dunchannelRate::CurrChanTxRate

8.28.2.3 uint32_t dunchannelRate::MaxChanRxRate

8.28.2.4 uint32_t dunchannelRate::MaxChanTxRate

8.29 eriDataparams Struct Reference

Data Fields

- uint16_t eriDataLen
- uint8_t eriData [1024]

8.29.1 Detailed Description

This structure contains Extended Roaming Indicator(ERI) file parameters

Parameters

eriDataLen	• Upon input, the maximum number of bytes that file contents array can contain. • Upon successful output, actual number of bytes written to file contents array
eriData	• ERI data read from persistent storage(Max size is 1024)

8.29.2 Field Documentation

8.29.2.1 uint8_t eriDataparams::eriData[1024]

8.29.2.2 uint16_t eriDataparams::eriDataLen

8.30 eTWSPLMNInfoTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSEtwsPlmnInfo ETWSPLMNInfo

8.30.1 Detailed Description

This structure contains ETWS PLMN TLV information

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
ETWSPLMNInfo	• ETWS PLMN Information • See sMSEtwsPlmnInfo for more information

8.30.2 Field Documentation

8.30.2.1 sMSEtwsPlmnInfo eTWSPLMNInfoTlv::ETWSPLMNInfo

8.30.2.2 uint8_t eTWSPLMNInfoTlv::TlvPresent

8.31 FMSImageElement Struct Reference

Data Fields

- uint8_t imageType
- uint8_t imageId [16]
- uint8_t buildIdLength
- uint8_t buildId [100]

8.31.1 Detailed Description

This structure contains the Image Element information

Parameters

imageType	• Type of image 0 - Modem 1 - PRI
imageId	• Unique image identifier

buildIdLength	• Length of the build ID string (may be zero)
pBuildId	• Build ID ANSI string with length provided by the previous field

8.31.2 Field Documentation

8.31.2.1 uint8_t FMSImageElement::buildId[100]

8.31.2.2 uint8_t FMSImageElement::buildIdLength

8.31.2.3 uint8_t FMSImageElement::imageId[16]

8.31.2.4 uint8_t FMSImageElement::imageType

8.32 FMSImageIdElement Struct Reference

Data Fields

- uint8_t storageIndex
- uint8_t failureCount
- uint8_t imageID [16]
- uint8_t buildIDLength
- uint8_t buildID [100]

8.32.1 Detailed Description

This structure contains the Image ID list element Information

Parameters

storageIndex	• Index in storage where the image is located(a value of 0xFF indicates that the storage for this type of image is not relevant)
failureCount	• Number of consecutive write attempts to this storage index that have failed(a value of 0xFF indicates unspecified)
imageID	• Image unique identifier(max 16 chars.)
buildIDLength	• Length of the build ID string. If there is no build ID, this field will be 0 and no data will follow.
buildID	• String containing image build information(Max 100 characters)

8.32.2 Field Documentation

8.32.2.1 uint8_t FMSImageIdElement::buildID[100]

8.32.2.2 uint8_t FMSImageIdElement::buildIDLength

8.32.2.3 uint8_t FMSImageIdElement::failureCount

8.32.2.4 uint8_t FMSImageIdElement::imageID[16]

8.32.2.5 uint8_t FMSImageIdElement::storageIndex

8.33 FMSImageIDEntries Struct Reference

Data Fields

- uint8_t imageType
- uint8_t maxImages
- uint8_t executingImage
- uint8_t imageIDSize
- FMSImageIdElement imageIDElement [50]

8.33.1 Detailed Description

This structure contains the list entry Information

Parameters

imageType	• Type of image – 0 - Modem – 1 - PRI
maxImages	• Maximum number of images of this type that may be stored concurrently on the device
executingImage	• Index (into the next array) of image that is currently executing
imageIDSize	• The number of elements in the image ID list
imageIDElement	• Array of ImageIDElement Structure (Max 50 elements) • See FMSImageIdElement

8.33.2 Field Documentation

8.33.2.1 uint8_t FMSImageIDEntries::executingImage

8.33.2.2 FMSImageIdElement FMSImageIDEntries::imageIDElement[50]

8.33.2.3 uint8_t FMSImageIDEntries::imageIDSize

8.33.2.4 uint8_t FMSImageIDEntries::imageType

8.33.2.5 uint8_t FMSImageIDEntries::maxImages

8.34 FMSImageList Struct Reference

Data Fields

- uint8_t listSize
- FMSImageIDEntries imageIDEntries [2]

8.34.1 Detailed Description

This structure contains the Get Stored Images List

Parameters

listSize	• The number of elements in the image list
imageIDEntries	• Array of ImageIDEntries Structure (Max 2 entries)

8.34.2 Field Documentation

8.34.2.1 FMSImageIDEntries FMSImageList::imageIDEntries[2]

8.34.2.2 uint8_t FMSImageList::listSize

8.35 FMSPrefImageList Struct Reference

Data Fields

- uint8_t listSize
- FMSImageElement listEntries [2]

8.35.1 Detailed Description

This structure contains the Preference Image List information

Parameters

listSize	• The number of elements in the image list
pListEntries	• Array of Image entries with size provided by previous field • See FMSImageElement

8.35.2 Field Documentation

8.35.2.1 FMSImageElement FMSPrefImageList::listEntries[2]

8.35.2.2 uint8_t FMSPrefImageList::listSize

8.36 hdrSSInfo Struct Reference

Data Fields

- int8_t rssi
- int16_t ecio
- uint8_t sinr
- int32_t io

8.36.1 Detailed Description

This structure contains the parameters for HDR Signal Strength Information

Parameters

rssi	• RSSI in dBm (signed value). • A value of -125 dBm or lower is used to indicate No Signal.
ecio	• ECIO value representing negative 0.5 dBm increments, i.e., 2 means -1 dBm (14 means -7 dBm, 63 means -31.5 dBm).
sinr	• SINR level. • SINR is only applicable for 1xEV-DO. • Valid levels are 0 to 8, where the maximum value for: – 0 - SINR_LEVEL_0 is -9 dB – 1 - SINR_LEVEL_1 is -6 dB – 2 - SINR_LEVEL_2 is -4.5 dB – 3 - SINR_LEVEL_3 is -3 dB – 4 - SINR_LEVEL_4 is -2 dB – 5 - SINR_LEVEL_5 is +1 dB – 6 - SINR_LEVEL_6 is +3 dB – 7 - SINR_LEVEL_7 is +6 dB – 8 - SINR_LEVEL_8 is +9 dB – 0xFF - Not Available
io	• Received IO in dBm. • IO is only applicable for 1xEV-DO.

8.36.2 Field Documentation

8.36.2.1 int16_t hdrSSInfo::ecio

8.36.2.2 int32_t hdrSSInfo::io

8.36.2.3 int8_t hdrSSInfo::rssi

8.36.2.4 uint8_t hdrSSInfo::sinr

8.37 image_info_t Struct Reference

Data Fields

- uint8_t imageType
- uint8_t uniqueID [16]
- uint8_t buildIDLen
- uint8_t buildID [255]

8.37.1 Detailed Description

This structure is used to store image information

Parameters

imageType	• Image Type • Values: – 0 - FW – 1 - configuration
uniqueID	• Image Unique Identifier (ASCII characters)
buildIDLen	• Length of build ID string to follow • If set to zero, build ID string will be blank
buildID	• String containing image information(ASCII characters) • Maximum length of this string is 255 chars

8.37.2 Field Documentation

8.37.2.1 uint8_t image_info_t::buildID[255]

8.37.2.2 uint8_t image_info_t::buildIDLen

8.37.2.3 uint8_t image_info_t::imageType

8.37.2.4 uint8_t image_info_t::uniqueID[16]

8.38 ipv6_addr Struct Reference

Data Fields

- uint8_t ipv6addr [16]
- uint8_t prefix

8.38.1 Field Documentation

8.38.1.1 uint8_t ipv6_addr::ipv6addr[16]

8.38.1.2 uint8_t ipv6_addr::prefix

8.39 ipv6AddressInfo Struct Reference

Data Fields

- uint8_t IPV6PrefixLen
- uint16_t IPAddressV6 [8]

8.39.1 Detailed Description

This structure contains the IPv6 address information

Parameters

IPV6PrefixLen	Length of the received IPv6 address • 0xff - Invalid IPv6 address information.
IPAddressV6	IPv6 address(in network byte order)

8.39.2 Field Documentation

8.39.2.1 uint16_t ipv6AddressInfo::IPAddressV6[8]

8.39.2.2 uint8_t ipv6AddressInfo::IPV6PrefixLen

8.40 LibPackGPRSRequestedQoS Struct Reference

Data Fields

- uint32_t precedenceClass
- uint32_t delayClass
- uint32_t reliabilityClass
- uint32_t peakThroughputClass
- uint32_t meanThroughputClass

8.40.1 Detailed Description

This structure contains the GPRS Quality Of Service Information

Parameters

precedence-Class	• Precedence class
delayClass	• Delay class
reliabilityClass	• Reliability class
peak-Throughput-Class	• Peak throughput class
mean-Throughput-Class	• Mean throughput class

8.40.2 Field Documentation

8.40.2.1 uint32_t LibPackGPRSRequestedQoS::delayClass

8.40.2.2 uint32_t LibPackGPRSRequestedQoS::meanThroughputClass

8.40.2.3 uint32_t LibPackGPRSRequestedQoS::peakThroughputClass

8.40.2.4 uint32_t LibPackGPRSRequestedQoS::precedenceClass

8.40.2.5 uint32_t LibPackGPRSRequestedQoS::reliabilityClass

8.41 LibpackProfile3GPP Struct Reference

Data Fields

- uint8_t * pProfilename
- uint16_t * pProfilenameSize
- uint8_t * pPDPtype
- uint8_t * pPdpHdrCompType
- uint8_t * pPdpDataCompType
- uint8_t * pAPNName
- uint16_t * pAPNnameSize
- uint32_t * pPriDNSIPv4AddPref
- uint32_t * pSecDNSIPv4AddPref
- LibPackUMTSQoS * pUMTSReqQoS
- LibPackUMTSQoS * pUMTSMinQoS
- LibPackGPRSRequestedQoS * pGPRSRequestedQos
- LibPackGPRSRequestedQoS * pGPRSMinimumQoS
- uint8_t * pUsername
- uint16_t * pUsernameSize
- uint8_t * pPassword
- uint16_t * pPasswordSize
- uint8_t * pAuthenticationPref
- uint32_t * pIPv4AddrPref
- uint8_t * pPcscfAddrUsingPCO

- uint8_t * pPdpAccessConFlag
- uint8_t * pPcscfAddrUsingDhcp
- uint8_t * pImCnFlag
- LibPackTFTIDParams * pTFTID1Params
- LibPackTFTIDParams * pTFTID2Params
- uint8_t * pPdpContext
- uint8_t * pSecondaryFlag
- uint8_t * pPrimaryID
- uint16_t * pIPv6AddPref
- LibPackUMTSReqQoSSigInd * pUMTSReqQoSSigInd
- LibPackUMTSReqQoSSigInd * pUMTSMinQosSigInd
- uint16_t * pPriDNSIPv6addpref
- uint16_t * pSecDNSIPv6addpref
- uint8_t * pAddrAllocPref
- LibPackQosClassID * pQosClassID
- uint8_t * pAPNDisabledFlag
- uint32_t * pPDNInactivTimeout
- uint8_t * pAPNClass

8.41.1 Detailed Description

This structure contains Input parameters of unpack_wds_SLQSGetProfileSettings_t Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

pProfileName	• One or more uint8_ts describing the profile • NULL pointer - Invalid data.
pProfilename-Size;	• This parameter is an input parameter and should be initialised to the size of pProfileName field. Size of this parameter is 2 uint8_ts. • NULL pointer - Invalid data.
pPDPType	• Packet Data Protocol (PDP) type specifies the type of data payload exchanged over the air link when the packet data session is established with this profile – 0x00 - PDP-IP (IPv4) – 0x01 - PDP-PPP – 0x02 - PDP-IPV6 – 0x03 - PDP-IPV4V6 • NULL pointer - Invalid data.
pPdpHdrComp-Type	• PDP header compression type – 0 - PDP header compression is OFF – 1 - Manufacturer preferred compression – 2 - PDP header compression based on RFC 1144 – 3 - PDP header compression based on RFC 25074 PDP header compression based on RFC 3095 • NULL pointer - Invalid data.

pPdpDataCompType	• PDP data compression type – 0 - PDP data compression is OFF – 1 - Manufacturer preferred compression – 2 - V.42BIS data compression – 3 - V.44 data compression • NULL pointer - Invalid data.
pAPNName	• Access point name • NULL pointer - Invalid data.
pAPNnameSize;	• This parameter is an input parameter and should be initialised to the size of pAPNName field. Size of this parameter is 2 uint8_ts. • NULL pointer - Invalid data.
pPriDNSIPv4AddPref	• Primary DNS IPv4 Address Preference • NULL pointer - Invalid data.
pSecDNSIPv4AddPref	• Secondary DNS IPv4 Address Preference • NULL pointer - Invalid data.
pUMTSReqQoS	• UMTS Requested QoS • NULL pointer - Invalid data.
pUMTSMinQoS	• UMTS Minimum QoS • NULL pointer - Invalid data.
pGPRSRequestedQoS	• GPRS Requested QoS • NULL pointer - Invalid data.
pGPRSMinimumQoS	• GPRS Minimum QoS • NULL pointer - Invalid data.
pUsername	• User name • NULL pointer - Invalid data.
pUsernameSize;	• This parameter is an input parameter and should be initialised to the size of pUsername field. Size of this parameter is 2 uint8_ts. • NULL pointer - Invalid data.

pPassword	• Password • NULL pointer - Invalid data.
pPasswordSize;	• This parameter is an input parameter and should be initialised to the size of pPassword field. Size of this parameter is 2 uint8_ts. • NULL pointer - Invalid data.
pAuthentication-Pref	• Authentication Preference – Bit map that indicates the authentication algorithm preference * Bit 0 - PAP preference · 0 - PAP is never performed · 1 - PAP may be performed * Bit 1 - CHAP preference · 0 - CHAP is never performed · 1 - CHAP may be performed * If more than one bit is set, then the device decides which authentication procedure is performed while setting up the data session. For example, the device may have a policy to select the most secure authentication mechanism. • NULL pointer - Invalid data.
pIPv4AddrPref	• IPv4 Address Preference • NULL pointer - Invalid data.
pPcscfAddr-UsingPCO	• P-CSCF Address using PCO Flag – 1 - (TRUE) implies request PCSCF address using PCO – 0 - (FALSE) implies do not request By default, this value is 0 • NULL pointer - Invalid data.
pPdpAccess-ConFlag	• PDP access control flag – 0 - PDP access control none – 1 - PDP access control reject – 2 - PDP access control permission • NULL pointer - Invalid data.
pPcscfAddr-UsingDhcp	• P-CSCF address using DHCP – 1 - (TRUE) implies Request PCSCF address using DHCP – 0 - (FALSE) implies do not request By default, value is 0 • NULL pointer - Invalid data.

pImCnFlag	• IM CN flag – 1 - (TRUE) implies request IM CN flag for this profile – 0 - (FALSE) implies do not request IM CN flag for this profile • NULL pointer - Invalid data.
pTFTID1Params	• Traffic Flow Template • NULL pointer - Invalid data.
pTFTID2Params	• Traffic Flow Template • NULL pointer - Invalid data.
pPdpContext	• PDP context number • NULL pointer - Invalid data.
pSecondaryFlag	• PDP context secondary flag – 1 - (TRUE) implies this is secondary profile – 0 - (FALSE) implies this is not secondary profile • NULL pointer - Invalid data.
pPrimaryID	• PDP context primary ID • function SLQSGetProfileSettings() returns a default value 0xFF if this parameter is not returned by the device • NULL pointer - Invalid data.
pIPv6AddPref	• IPv6 address preference Preferred IPv6 address to be assigned to the TE; actual assigned address is negotiated with the network and may differ from this value; if not specified, the IPv6 address is obtained automatically from the network • NULL pointer - Invalid data.
pUMTSReqQoS-SigInd	• UMTS requested QoS with Signalling Indication flag • NULL pointer - Invalid data.
pUMTSMinQoS-SigInd	• UMTS minimum QoS with Signalling Indication flag • NULL pointer - Invalid data.
pPrimaryDNSI-Pv6addpref	• Primary DNS IPv6 address preference – The value may be used as a preference during negotiation with the network; if not specified, the wireless device will attempt to obtain the DNS address automatically from the network; the negotiated value is provided to the host via DHCP • NULL pointer - Invalid data.

pSecondaryDNSIPv6addpref	• Secondary DNS IPv6 address preference • NULL pointer - Invalid data.
paddrAllocationPref	• DHCP/NAS preference – This enumerated value may be used to indicate the address allocation preference * 0 - NAS signaling is used for address allocation * 1 - DHCP is used for address allocation • NULL pointer - Invalid data.
pQosClassID	• 3GPP LTE QoS parameters • NULL pointer - Invalid data.
pAPNDisabledFlag	• Optional 1 uint8_t Flag indicating if the APN is disabled/enabled • If set, the profile can not be used for making data calls • Any data call is failed locally • Values: – 0 - FALSE(default) – 1 - True • This parameter is currently read only and can be read by using the function SLQSGetProfileSettings(). • NULL pointer - Invalid data.
pPDNInactivTimeout	• Optional 4 uint8_ts indicating the duration of inactivity timer in seconds • If the PDP context/PDN connection is inactive for this duration i.e. No data Tx/Rx occurs, the PDP context/PDN connection is disconnected • Default value of zero indicates infinite value • This parameter is currently read only and can be read by using the function SLQSGetProfileSettings(). • NULL pointer - Invalid data.
pAPNClass	• Optional 1 uint8_t numeric identifier representing the APN in profile • Can be set and queried but is not used by the modem • This parameter is currently read only and can be read by using the function SLQSGetProfileSettings(). • NULL pointer - Invalid data.

8.41.2 Field Documentation

8.41.2.1 uint8_t* LibpackProfile3GPP::pAddrAllocPref

8.41.2.2 uint8_t* LibpackProfile3GPP::pAPNClass

8.41.2.3 uint8_t* LibpackProfile3GPP::pAPNDisabledFlag

8.41.2.4 uint8_t* LibpackProfile3GPP::pAPNName

8.41.2.5 uint16_t* LibpackProfile3GPP::pAPNnameSize

8.41.2.6 uint8_t* LibpackProfile3GPP::pAuthenticationPref

8.41.2.7 LibPackGPRSRequestedQoS* LibpackProfile3GPP::pGPRSMinimumQoS

8.41.2.8 LibPackGPRSRequestedQoS* LibpackProfile3GPP::pGPRSRequestedQos

8.41.2.9 uint8_t* LibpackProfile3GPP::pImCnFlag

8.41.2.10 uint32_t* LibpackProfile3GPP::pIPv4AddrPref

8.41.2.11 uint16_t* LibpackProfile3GPP::pIPv6AddPref

8.41.2.12 uint8_t* LibpackProfile3GPP::pPassword

8.41.2.13 uint16_t* LibpackProfile3GPP::pPasswordSize

8.41.2.14 uint8_t* LibpackProfile3GPP::pPcscfAddrUsingDhcp

8.41.2.15 uint8_t* LibpackProfile3GPP::pPcscfAddrUsingPCO

8.41.2.16 uint32_t* LibpackProfile3GPP::pPDNInactivTimeout

8.41.2.17 uint8_t* LibpackProfile3GPP::pPdpAccessConFlag

8.41.2.18 uint8_t* LibpackProfile3GPP::pPdpContext

8.41.2.19 uint8_t* LibpackProfile3GPP::pPdpDataCompType

8.41.2.20 uint8_t* LibpackProfile3GPP::pPdpHdrCompType

8.41.2.21 uint8_t* LibpackProfile3GPP::pPDPtype

8.41.2.22 uint32_t* LibpackProfile3GPP::pPriDNSIPv4AddPref

8.41.2.23 uint16_t* LibpackProfile3GPP::pPriDNSIPv6addpref

8.41.2.24 uint8_t* LibpackProfile3GPP::pPrimaryID

8.41.2.25 uint8_t* LibpackProfile3GPP::pProfilename

8.41.2.26 uint16_t* LibpackProfile3GPP::pProfilenameSize

8.41.2.27 LibPackQosClassID* LibpackProfile3GPP::pQosClassID

8.41.2.28 uint32_t* LibpackProfile3GPP::pSecDNSIPv4AddPref

8.41.2.29 uint16_t* LibpackProfile3GPP::pSecDNSIPv6addpref

8.41.2.30 uint8_t* LibpackProfile3GPP::pSecondaryFlag

8.41.2.31 LibPackTFTIDParams* LibpackProfile3GPP::pTFTID1Params

8.41.2.32 LibPackTFTIDParams* LibpackProfile3GPP::pTFTID2Params

8.41.2.33 LibPackUMTSQoS* LibpackProfile3GPP::pUMTSMinQoS

8.41.2.34 LibPackUMTSReqQoSSigInd* LibpackProfile3GPP::pUMTSMinQosSigInd

8.41.2.35 LibPackUMTSQoS* LibpackProfile3GPP::pUMTSReqQoS

8.41.2.36 LibPackUMTSReqQoSSigInd* LibpackProfile3GPP::pUMTSReqQoSSigInd

8.41.2.37 uint8_t* LibpackProfile3GPP::pUsername

8.41.2.38 uint16_t* LibpackProfile3GPP::pUsernameSize

8.42 LibpackProfile3GPP2 Struct Reference

Data Fields

- uint8_t * pNegoDnsSrvrPref
- uint32_t * pPppSessCloseTimerDO
- uint32_t * pPppSessCloseTimer1x
- uint8_t * pAllowLinger
- uint16_t * pLcpAckTimeout
- uint16_t * pIpcpAckTimeout
- uint16_t * pAuthTimeout
- uint8_t * pLcpCreqRetryCount
- uint8_t * pIpcpCreqRetryCount
- uint8_t * pAuthRetryCount
- uint8_t * pAuthProtocol
- uint8_t * pUserId
- uint16_t * pUserIdSize
- uint8_t * pAuthPassword
- uint16_t * pAuthPasswordSize
- uint8_t * pDataRate
- uint32_t * pAppType
- uint8_t * pDataMode
- uint8_t * pAppPriority
- uint8_t * pApnString
- uint16_t * pApnStringSize
- uint8_t * pPdnType
- uint8_t * pIsPcscfAddressNedded
- uint32_t * pPrimaryV4DnsAddress
- uint32_t * pSecondaryV4DnsAddress
- uint16_t * pPriV6DnsAddress
- uint16_t * pSecV6DnsAddress
- uint8_t * pRATType
- uint8_t * pAPNEnabled3GPP2
- uint32_t * pPDNInactivTimeout3GPP2
- uint8_t * pAPNClass3GPP2

8.42.1 Detailed Description

This structure contains the 3GPP2 profile parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

pNegoDnsSrvrPref	• Negotiate DNS Server Preference – 1 - (TRUE)implies request DNS addresses from the PDSN – 0 - (FALSE)implies do not request DNS addresses from the PDSN – Default value is 1 (TRUE)
pPppSessCloseTimerDO	• PPP Session Close Timer for DO – Timer value (in seconds) on DO indicating how long the PPP Session should linger before closing down
pPppSessCloseTimer1x	• PPP Session Close Timer for 1X – Timer value (in seconds) on 1X indicating how long the PPP session should linger before closing down
pAllowLinger	• Allow/disallow lingering of interface – 1 -(TRUE) implies allow lingering – 0 -(FALSE) implies do not allow lingering
pLcpAckTimeout	• LCP ACK Timeout – Value of LCP ACK Timeout in milliseconds
pIpcpAckTimeout	• IPCP ACK Timeout – Value of IPCP ACK Timeout in milliseconds
pAuthTimeout	• AUTH Timeout – Value of Authentication Timeout in milliseconds
pLcpCreqRetryCount	• LCP Configuration Request Retry Count
pIpcpCreqRetryCount	• IPCP Configuration Request Retry Count
pAuthRetryCount	• Authentication Retry Count value

pAuthProtocol	• Authentication Protocol – 1 - PAP – 2 - CHAP – 3 - PAP or CHAP
pUserId	• User ID to be used during data network authentication • maximum length allowed is 127 uint8_ts; • QMI_ERR_ARG_TOO_LONG will be returned if the storage on the wireless device is insufficient in size to hold the value.
pUserIdSize;	• This parameter is an input parameter and should be initialised to the size of pUserId field. Size of this parameter is 2 uint8_ts.
pAuthPassword	• Password to be used during data network authentication; • maximum length allowed is 127 uint8_ts • QMI_ERR_ARG_TOO_LONG will be returned if the storage on the wireless device is insufficient in size to hold the value.
pAuthPassword-Size;	• This parameter is an input parameter and should be initialised to the size of pAuthPassword field. Size of this parameter is 2 uint8_ts.
pDataRate	• Data Rate Requested – 0 - Low (Low speed Service Options (SO15) only) – 1 - Medium (SO33 + low R-SCH) – 2 - High (SO33 + high R-SCH) – Default is 2
pAppType	• Application Type: – 0x00000001 - Default Application Type – 0x00000020 - LBS Application Type – 0x00000040 - Tethered Application Type – This parameter is not used while creating/modifying a profile
pDataMode	• Data Mode to use: – 0 - CDMA or HDR (Hybrid 1X/1xEV-DO) – 1 - CDMA Only (1X only) – 2 - HDR Only (1xEV-DO only) – Default is 0

pAppPriority	• Application Priority – Numerical 1 uint8_t value defining the application priority; higher value implies higher priority – This parameter is not used while creating/modifying a profile
pApnString	• String representing the Access Point Name • maximum length allowed is 100 uint8_ts • QMI_ERR_ARG_TOO_LONG will be returned if the APN name is too long.
pApnStringSize;	• This parameter is an input parameter and should be initialised to the size of pApnString field. Size of this parameter is 2 uint8_ts.
pPdnType	• Packed Data Network Type Requested: – 0 - IPv4 PDN Type – 1 - IPv6 PDN Type – 2 - IPv4 or IPv6 PDN Type – 3 - Unspecified PDN Type (implying no preference)
pIsPcscf-AddressNedded	• This boolean value is used to control if PCSCF address is requested from PDSN – 1 -(TRUE) implies request for PCSCF value from the PDSN – 0 -(FALSE) implies do not request for PCSCF value from the PDSN
pPrimaryV4Dns-Address	• IPv4 Primary DNS address – The Primary IPv4 DNS address that can be statically assigned to the UE
pSecondaryV4-DnsAddress	• IPv4 Secondary DNS address – The Secondary IPv4 DNS address that can be statically assigned to the UE
pPriV6Dns-Address	• Primary IPv6 DNS address – The Primary IPv6 DNS address that can be statically assigned to the UE
pSecV6Dns-Address	• Secondary IPv6 DNS address – The Secondary IPv6 DNS address that can be statically assigned to the UE
pRATType	• Optional 1 uint8_t Flag indicating RAT Type • Values: – 1 - HRPD – 2 - EHRPD – 3 - HRPD_EHRPD • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().

pAPNEnabled3-GPP2	• Optional 1 uint8_t Flag indicating if the APN is disabled/enabled • If disabled, the profile can not be used for making data calls • Values: – 0 - Disabled – 1 - Enabled(default value) • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().
pPDNInactiv-Timeout3GPP2	• Optional 4 uint8_ts indicating the duration of inactivity timer in seconds • If the PDP context/PDN connection is inactive for this duration i.e. No data Tx/Rx occurs, the PDP context/PDN connection is disconnected • Default value of zero indicates infinite value • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().
pAPNClass3GP-P2	• Optional 1 uint8_t numeric identifier representing the APN in profile • Can be set and queried but is not used by the modem • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().

8.42.2 Field Documentation

8.42.2.1 uint8_t* LibpackProfile3GPP2::pAllowLinger

8.42.2.2 uint8_t* LibpackProfile3GPP2::pAPNClass3GPP2

8.42.2.3 uint8_t* LibpackProfile3GPP2::pAPNEnabled3GPP2

8.42.2.4 uint8_t* LibpackProfile3GPP2::pApnString

8.42.2.5 uint16_t* LibpackProfile3GPP2::pApnStringSize

8.42.2.6 uint8_t* LibpackProfile3GPP2::pAppPriority

8.42.2.7 uint32_t* LibpackProfile3GPP2::pAppType

8.42.2.8 uint8_t* LibpackProfile3GPP2::pAuthPassword

8.42.2.9 uint16_t* LibpackProfile3GPP2::pAuthPasswordSize

8.42.2.10 uint8_t* LibpackProfile3GPP2::pAuthProtocol

8.42.2.11 uint8_t* LibpackProfile3GPP2::pAuthRetryCount

8.42.2.12 uint16_t* LibpackProfile3GPP2::pAuthTimeout

8.42.2.13 uint8_t* LibpackProfile3GPP2::pDataMode

8.42.2.14 uint8_t* LibpackProfile3GPP2::pDataRate

8.42.2.15 uint16_t* LibpackProfile3GPP2::pIpcpAckTimeout

8.42.2.16 uint8_t* LibpackProfile3GPP2::pIpcpCreqRetryCount

8.42.2.17 uint8_t* LibpackProfile3GPP2::pIsPcscfAddressNedded

8.42.2.18 uint16_t* LibpackProfile3GPP2::pLcpAckTimeout

8.42.2.19 uint8_t* LibpackProfile3GPP2::pLcpCreqRetryCount

8.42.2.20 uint8_t* LibpackProfile3GPP2::pNegoDnsSrvrPref

8.42.2.21 uint32_t* LibpackProfile3GPP2::pPDNInactivTimeout3GPP2

8.42.2.22 uint8_t* LibpackProfile3GPP2::pPdnType

8.42.2.23 uint32_t* LibpackProfile3GPP2::pPppSessCloseTimer1x

8.42.2.24 uint32_t* LibpackProfile3GPP2::pPppSessCloseTimerDO

8.42.2.25 uint32_t* LibpackProfile3GPP2::pPrimaryV4DnsAddress

8.42.2.26 uint16_t* LibpackProfile3GPP2::pPriV6DnsAddress

8.42.2.27 uint8_t* LibpackProfile3GPP2::pRATType

8.42.2.28 uint32_t* LibpackProfile3GPP2::pSecondaryV4DnsAddress

8.42.2.29 uint16_t* LibpackProfile3GPP2::pSecV6DnsAddress

8.42.2.30 uint8_t* LibpackProfile3GPP2::pUserId

8.42.2.31 uint16_t* LibpackProfile3GPP2::pUserIdSize

8.43 LibPackprofile_3GPP Struct Reference

Data Fields

- uint8_t * pProfilename
- uint16_t * pProfilenameSize
- uint8_t * pPDPtype
- uint8_t * pPdpHdrCompType
- uint8_t * pPdpDataCompType
- uint8_t * pAPNName
- uint16_t * pAPNnameSize
- uint32_t * pPriDNSIPv4AddPref
- uint32_t * pSecDNSIPv4AddPref
- LibPackUMTSQoS * pUMTSReqQoS
- LibPackUMTSQoS * pUMTSMinQoS
- LibPackGPRSRequestedQoS * pGPRSRequestedQos
- LibPackGPRSRequestedQoS * pGPRSMinimumQoS
- uint8_t * pUsername
- uint16_t * pUsernameSize
- uint8_t * pPassword
- uint16_t * pPasswordSize

- uint8_t * pAuthenticationPref
- uint32_t * pIPv4AddrPref
- uint8_t * pPcscfAddrUsingPCO
- uint8_t * pPdpAccessConFlag
- uint8_t * pPcscfAddrUsingDhcp
- uint8_t * pImCnFlag
- LibPackTFTIDParams * pTFTID1Params
- LibPackTFTIDParams * pTFTID2Params
- uint8_t * pPdpContext
- uint8_t * pSecondaryFlag
- uint8_t * pPrimaryID
- uint16_t * pIPv6AddPref
- LibPackUMTSReqQoSSigInd * pUMTSReqQoSSigInd
- LibPackUMTSReqQoSSigInd * pUMTSMinQosSigInd
- uint16_t * pPriDNSIPv6addpref
- uint16_t * pSecDNSIPv6addpref
- uint8_t * pAddrAllocPref
- LibPackQosClassID * pQosClassID
- uint8_t * pAPNDisabledFlag
- uint32_t * pPDNInactivTimeout
- uint8_t * pAPNClass

8.43.1 Detailed Description

This structure contains Input/Output parameters of pack_wds_SLQSCreateProfile

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

pProfileName	• One or more bytes describing the profile
pProfilename-Size;	• This parameter is an input parameter and should be initialised to the size of pProfileName field. Size of this parameter is 2 bytes.
pPDPType	• Packet Data Protocol (PDP) type specifies the type of data payload exchanged over the air link when the packet data session is established with this profile – 0x00 - PDP-IP (IPv4) – 0x01 - PDP-PPP – 0x02 - PDP-IPV6 – 0x03 - PDP-IPV4V6
pPdpHdrComp-Type	• PDP header compression type – 0 - PDP header compression is OFF – 1 - Manufacturer preferred compression – 2 - PDP header compression based on RFC 1144 – 3 - PDP header compression based on RFC 25074 PDP header compression based on RFC 3095

pPdpDataCompType	• PDP data compression type – 0 - PDP data compression is OFF – 1 - Manufacturer preferred compression – 2 - V.42BIS data compression – 3 - V.44 data compression
pAPNName	• Access point name
pAPNnameSize;	• This parameter is an input parameter and should be initialised to the size of pAPNName field. Size of this parameter is 2 bytes.
pPriDNSIPv4AddPref	• Primary DNS IPv4 Address Preference
pSecDNSIPv4AddPref	• Secondary DNS IPv4 Address Preference
pUMTSReqQoS	• UMTS Requested QoS
pUMTSMinQoS	• UMTS Minimum QoS
pGPRSRequestedQoS	• GPRS Minimum QoS
pUsername	• User name
pUsernameSize;	• This parameter is an input parameter and should be initialised to the size of pUsername field. Size of this parameter is 2 bytes.
pPassword	• Password
pPasswordSize;	• This parameter is an input parameter and should be initialised to the size of pPassword field. Size of this parameter is 2 bytes.

pAuthentication-Pref	• Authentication Preference – Bit map that indicates the authentication algorithm preference * Bit 0 - PAP preference · 0 - PAP is never performed · 1 - PAP may be performed * Bit 1 - CHAP preference · 0 - CHAP is never performed · 1 - CHAP may be performed * If more than one bit is set, then the device decides which authentication procedure is performed while setting up the data session. For example, the device may have a policy to select the most secure authentication mechanism.
pIPv4AddrPref	• IPv4 Address Preference
pPcscfAddr-UsingPCO	• P-CSCF Address using PCO Flag – 1 - (TRUE) implies request PCSCF address using PCO – 0 - (FALSE) implies do not request By default, this value is 0
pPdpAccess-ConFlag	• PDP access control flag – 0 - PDP access control none – 1 - PDP access control reject – 2 - PDP access control permission
pPcscfAddr-UsingDhcp	• P-CSCF address using DHCP – 1 - (TRUE) implies Request PCSCF address using DHCP – 0 - (FALSE) implies do not request By default, value is 0
pImCnFlag	• IM CN flag – 1 - (TRUE) implies request IM CN flag for this profile – 0 - (FALSE) implies do not request IM CN flag for this profile
pTFTID1Params	• Traffic Flow Template
pTFTID2Params	• Traffic Flow Template
pPdpContext	• PDP context number
pSecondaryFlag	• PDP context secondary flag – 1 - (TRUE) implies this is secondary profile – 0 - (FALSE) implies this is not secondary profile

pPrimaryID	• PDP context primary ID • function SLQSGetProfileSettings() returns a default value 0xFF if this parameter is not returned by the device
pIPv6AddPref	• IPv6 address preference Preferred IPv6 address to be assigned to the TE; actual assigned address is negotiated with the network and may differ from this value; if not specified, the IPv6 address is obtained automatically from the network
pUMTSReqQoS-SigInd	• UMTS requested QoS with Signalling Indication flag
pUMTSMinQoS-SigInd	• UMTS minimum QoS with Signalling Indication flag
pPrimaryDNSI-Pv6addpref	• Primary DNS IPv6 address preference – The value may be used as a preference during negotiation with the network; if not specified, the wireless device will attempt to obtain the DNS address automatically from the network; the negotiated value is provided to the host via DHCP
pSecondaryDN-SIPv6addpref	• Secondary DNS IPv6 address preference
paddrAllocation-Pref	• DHCP/NAS preference – This enumerated value may be used to indicate the address allocation preference * 0 - NAS signaling is used for address allocation * 1 - DHCP is used for address allocation
pQosClassID	• 3GPP LTE QoS parameters
pAPNDisabled-Flag	• Optional 1 uint8_t Flag indicating if the APN is disabled/enabled • If set, the profile can not be used for making data calls • Any data call is failed locally • Values: – 0 - FALSE(default) – 1 - True • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().
pPDNInactiv-Timeout	• Optional 4 Bytes indicating the duration of inactivity timer in seconds • If the PDP context/PDN connection is inactive for this duration i.e. No data Tx/Rx occurs, the PDP context/PDN connection is disconnected • Default value of zero indicates infinite value • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().

pAPNClass	• Optional 1 uint8_t numeric identifier representing the APN in profile • Can be set and queried but is not used by the modem • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().

8.43.2 Field Documentation

8.43.2.1 uint8_t* LibPackprofile_3GPP::pAddrAllocPref

8.43.2.2 uint8_t* LibPackprofile_3GPP::pAPNClass

8.43.2.3 uint8_t* LibPackprofile_3GPP::pAPNDisabledFlag

8.43.2.4 uint8_t* LibPackprofile_3GPP::pAPNName

8.43.2.5 uint16_t* LibPackprofile_3GPP::pAPNnameSize

8.43.2.6 uint8_t* LibPackprofile_3GPP::pAuthenticationPref

8.43.2.7 LibPackGPRSRequestedQoS* LibPackprofile_3GPP::pGPRSMinimumQoS

8.43.2.8 LibPackGPRSRequestedQoS* LibPackprofile_3GPP::pGPRSRequestedQos

8.43.2.9 uint8_t* LibPackprofile_3GPP::pImCnFlag

8.43.2.10 uint32_t* LibPackprofile_3GPP::pIPv4AddrPref

8.43.2.11 uint16_t* LibPackprofile_3GPP::pIPv6AddPref

8.43.2.12 uint8_t* LibPackprofile_3GPP::pPassword

8.43.2.13 uint16_t* LibPackprofile_3GPP::pPasswordSize

8.43.2.14 uint8_t* LibPackprofile_3GPP::pPcscfAddrUsingDhcp

8.43.2.15 uint8_t* LibPackprofile_3GPP::pPcscfAddrUsingPCO

8.43.2.16 uint32_t* LibPackprofile_3GPP::pPDNInactivTimeout

8.43.2.17 uint8_t* LibPackprofile_3GPP::pPdpAccessConFlag

8.43.2.18 uint8_t* LibPackprofile_3GPP::pPdpContext

8.43.2.19 uint8_t* LibPackprofile_3GPP::pPdpDataCompType

8.43.2.20 uint8_t* LibPackprofile_3GPP::pPdpHdrCompType

8.43.2.21 uint8_t* LibPackprofile_3GPP::pPDPtype

8.43.2.22 uint32_t* LibPackprofile_3GPP::pPriDNSIPv4AddPref

8.43.2.23 uint16_t* LibPackprofile_3GPP::pPriDNSIPv6addpref

8.43.2.24 uint8_t* LibPackprofile_3GPP::pPrimaryID

8.43.2.25 uint8_t* LibPackprofile_3GPP::pProfilename

8.43.2.26 uint16_t* LibPackprofile_3GPP::pProfilenameSize

8.43.2.27 LibPackQosClassID* LibPackprofile_3GPP::pQosClassID

8.43.2.28 uint32_t* LibPackprofile_3GPP::pSecDNSIPv4AddPref

8.43.2.29 uint16_t* LibPackprofile_3GPP::pSecDNSIPv6addpref

8.43.2.30 uint8_t* LibPackprofile_3GPP::pSecondaryFlag

8.43.2.31 LibPackTFTIDParams* LibPackprofile_3GPP::pTFTID1Params

8.43.2.32 LibPackTFTIDParams* LibPackprofile_3GPP::pTFTID2Params

8.43.2.33 LibPackUMTSQoS* LibPackprofile_3GPP::pUMTSMinQoS

8.43.2.34 LibPackUMTSReqQoSSigInd* LibPackprofile_3GPP::pUMTSMinQosSigInd

8.43.2.35 LibPackUMTSQoS* LibPackprofile_3GPP::pUMTSReqQoS

8.43.2.36 LibPackUMTSReqQoSSigInd* LibPackprofile_3GPP::pUMTSReqQoSSigInd

8.43.2.37 uint8_t* LibPackprofile_3GPP::pUsername

8.43.2.38 uint16_t* LibPackprofile_3GPP::pUsernameSize

8.44 LibPackprofile_3GPP2 Struct Reference

Data Fields

- uint8_t * pNegoDnsSrvrPref
- uint32_t * pPppSessCloseTimerDO
- uint32_t * pPppSessCloseTimer1x
- uint8_t * pAllowLinger
- uint16_t * pLcpAckTimeout
- uint16_t * pIpcpAckTimeout
- uint16_t * pAuthTimeout
- uint8_t * pLcpCreqRetryCount
- uint8_t * pIpcpCreqRetryCount
- uint8_t * pAuthRetryCount
- uint8_t * pAuthProtocol
- uint8_t * pUserId
- uint16_t * pUserIdSize
- uint8_t * pAuthPassword
- uint16_t * pAuthPassword_tSize
- uint8_t * pDataRate
- uint32_t * pAppType
- uint8_t * pDataMode
- uint8_t * pAppPriority
- uint8_t * pApnString
- uint16_t * pApnStringSize

- uint8_t * pPdnType
- uint8_t * pIsPcscfAddressNedded
- uint32_t * pPrimaryV4DnsAddress
- uint32_t * pSecondaryV4DnsAddress
- uint16_t * pPriV6DnsAddress
- uint16_t * pSecV6DnsAddress
- uint8_t * pRATType
- uint8_t * pAPNEnabled3GPP2
- uint32_t * pPDNInactivTimeout3GPP2
- uint8_t * pAPNClass3GPP2

8.44.1 Detailed Description

This structure contains the 3GPP2 profile parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

pNegoDnsSrvr-Pref	• Negotiate DNS Server Preference – 1 - (TRUE)implies request DNS addresses from the PDSN – 0 - (FALSE)implies do not request DNS addresses from the PDSN – Default value is 1 (TRUE)
pPppSessClose-TimerDO	• PPP Session Close Timer for DO – Timer value (in seconds) on DO indicating how long the PPP Session should linger before closing down
pPppSessClose-Timer1x	• PPP Session Close Timer for 1X – Timer value (in seconds) on 1X indicating how long the PPP session should linger before closing down
pAllowLinger	• Allow/disallow lingering of interface – 1 -(TRUE) implies allow lingering – 0 -(FALSE) implies do not allow lingering
pLcpAckTimeout	• LCP ACK Timeout – Value of LCP ACK Timeout in milliseconds
pIpcpAck-Timeout	• IPCP ACK Timeout – Value of IPCP ACK Timeout in milliseconds
pAuthTimeout	• AUTH Timeout – Value of Authentication Timeout in milliseconds

pLcpCreqRetry-Count	• LCP Configuration Request Retry Count
pIpcpCreqRetry-Count	• IPCP Configuration Request Retry Count
pAuthRetry-Count	• Authentication Retry Count value
pAuthProtocol	• Authentication Protocol – 1 - PAP – 2 - CHAP – 3 - PAP or CHAP
pUserId	• User ID to be used during data network authentication • maximum length allowed is 127 bytes; • QMI_ERR_ARG_TOO_LONG will be returned if the storage on the wireless device is insufficient in size to hold the value.
pUserIdSize;	• This parameter is an input parameter and should be initialised to the size of pUserId field. Size of this parameter is 2 bytes.
pAuthPassword	• Password to be used during data network authentication; • maximum length allowed is 127 bytes • QMI_ERR_ARG_TOO_LONG will be returned if the storage on the wireless device is insufficient in size to hold the value.
pAuthPassword-Size;	• This parameter is an input parameter and should be initialised to the size of pAuthPassword field. Size of this parameter is 2 bytes.
pDataRate	• Data Rate Requested – 0 - Low (Low speed Service Options (SO15) only) – 1 - Medium (SO33 + low R-SCH) – 2 - High (SO33 + high R-SCH) – Default is 2
pAppType	• Application Type: – 0x00000001 - Default Application Type – 0x00000020 - LBS Application Type – 0x00000040 - Tethered Application Type – This parameter is not used while creating/modifying a profile

pDataMode	• Data Mode to use: – 0 - CDMA or HDR (Hybrid 1X/1xEV-DO) – 1 - CDMA Only (1X only) – 2 - HDR Only (1xEV-DO only) – Default is 0
pAppPriority	• Application Priority – Numerical 1 uint8_t value defining the application priority; higher value implies higher priority – This parameter is not used while creating/modifying a profile
pApnString	• String representing the Access Point Name • maximum length allowed is 100 bytes • QMI_ERR_ARG_TOO_LONG will be returned if the APN name is too long.
pApnStringSize;	• This parameter is an input parameter and should be initialised to the size of pApnString field. Size of this parameter is 2 bytes.
pPdnType	• Packed Data Network Type Requested: – 0 - IPv4 PDN Type – 1 - IPv6 PDN Type – 2 - IPv4 or IPv6 PDN Type – 3 - Unspecified PDN Type (implying no preference)
pIsPcscf-AddressNedded	• This boolean value is used to control if PCSCF address is requested from PDSN – 1 -(TRUE) implies request for PCSCF value from the PDSN – 0 -(FALSE) implies do not request for PCSCF value from the PDSN
pPrimaryV4Dns-Address	• IPv4 Primary DNS address – The Primary IPv4 DNS address that can be statically assigned to the UE
pSecondaryV4-DnsAddress	• IPv4 Secondary DNS address – The Secondary IPv4 DNS address that can be statically assigned to the UE
pPriV6Dns-Address	• Primary IPv6 DNS address – The Primary IPv6 DNS address that can be statically assigned to the UE
pSecV6Dns-Address	• Secondary IPv6 DNS address – The Secondary IPv6 DNS address that can be statically assigned to the UE

pRATType	• Optional 1 uint8_t Flag indicating RAT Type • Values: – 1 - HRPD – 2 - EHRPD – 3 - HRPD_EHRPD • This parameter is currently read only and can be read by using the function SLQSGetProfileSettings().
pAPNEnabled3GPP2	• Optional 1 uint8_t Flag indicating if the APN is disabled/enabled • If disabled, the profile can not be used for making data calls • Values: – 0 - Disabled – 1 - Enabled(default value) • This parameter is currently read only and can be read by using the function SLQSGetProfileSettings().
pPDNInactivTimeout3GPP2	• Optional 4 Bytes indicating the duration of inactivity timer in seconds • If the PDP context/PDN connection is inactive for this duration i.e. No data Tx/Rx occurs, the PDP context/PDN connection is disconnected • Default value of zero indicates infinite value • This parameter is currently read only and can be read by using the function SLQSGetProfileSettings().
pAPNClass3GPP2	• Optional 1 uint8_t numeric identifier representing the APN in profile • Can be set and queried but is not used by the modem • This parameter is currently read only and can be read by using the function SLQSGetProfileSettings().

8.44.2 Field Documentation

8.44.2.1 uint8_t* LibPackprofile_3GPP2::pAllowLinger

8.44.2.2 uint8_t* LibPackprofile_3GPP2::pAPNClass3GPP2

8.44.2.3 uint8_t* LibPackprofile_3GPP2::pAPNEnabled3GPP2

8.44.2.4 uint8_t* LibPackprofile_3GPP2::pApnString

8.44.2.5 uint16_t* LibPackprofile_3GPP2::pApnStringSize

8.44.2.6 uint8_t* LibPackprofile_3GPP2::pAppPriority

8.44.2.7 uint32_t* LibPackprofile_3GPP2::pAppType

8.44.2.8 uint8_t* LibPackprofile_3GPP2::pAuthPassword

8.44.2.9 uint16_t* LibPackprofile_3GPP2::pAuthPassword_tSize

8.44.2.10 uint8_t* LibPackprofile_3GPP2::pAuthProtocol

8.44.2.11 uint8_t* LibPackprofile_3GPP2::pAuthRetryCount

8.44.2.12 uint16_t* LibPackprofile_3GPP2::pAuthTimeout

8.44.2.13 uint8_t* LibPackprofile_3GPP2::pDataMode

8.44.2.14 uint8_t* LibPackprofile_3GPP2::pDataRate

8.44.2.15 uint16_t* LibPackprofile_3GPP2::pIpcpAckTimeout

8.44.2.16 uint8_t* LibPackprofile_3GPP2::pIpcpCreqRetryCount

8.44.2.17 uint8_t* LibPackprofile_3GPP2::pIsPcscfAddressNedded

8.44.2.18 uint16_t* LibPackprofile_3GPP2::pLcpAckTimeout

8.44.2.19 uint8_t* LibPackprofile_3GPP2::pLcpCreqRetryCount

8.44.2.20 uint8_t* LibPackprofile_3GPP2::pNegoDnsSrvrPref

8.44.2.21 uint32_t* LibPackprofile_3GPP2::pPDNInactivTimeout3GPP2

8.44.2.22 uint8_t* LibPackprofile_3GPP2::pPdnType

8.44.2.23 uint32_t* LibPackprofile_3GPP2::pPppSessCloseTimer1x

8.44.2.24 uint32_t* LibPackprofile_3GPP2::pPppSessCloseTimerDO

8.44.2.25 uint32_t* LibPackprofile_3GPP2::pPrimaryV4DnsAddress

8.44.2.26 uint16_t* LibPackprofile_3GPP2::pPriV6DnsAddress

8.44.2.27 uint8_t* LibPackprofile_3GPP2::pRATType

8.44.2.28 uint32_t* LibPackprofile_3GPP2::pSecondaryV4DnsAddress

8.44.2.29 uint16_t* LibPackprofile_3GPP2::pSecV6DnsAddress

8.44.2.30 uint8_t* LibPackprofile_3GPP2::pUserId

8.44.2.31 uint16_t* LibPackprofile_3GPP2::pUserIdSize

8.45 LibPackQosClassID Struct Reference

Data Fields

- uint8_t QCI
- uint8_t gDlBitRate
- uint32_t maxDlBitRate
- uint32_t gUlBitRate
- uint32_t maxUlBitRate

8.45.1 Detailed Description

This structure contains 3GPP LTE QoS parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

QCI	• QOS specified using the QOS Class Identifier (QOS) values QCI value 0 - Requests the network to assign the appropriate QCI value QCI values 1-4 - Associated with guaranteed bit rates QCI values 5-9 - Associated with non-guaranteed bit rates
gDlBitRate	• Guaranteed DL bit rate
maxDlBitRate	• Maximum DL bit rate
gUlBitRate	• Guaranteed UL bit rate
maxUlBitRate	• Maximum UL bit rate

8.45.2 Field Documentation

8.45.2.1 uint8_t LibPackQosClassID::gDlBitRate

8.45.2.2 uint32_t LibPackQosClassID::gUlBitRate

8.45.2.3 uint32_t LibPackQosClassID::maxDlBitRate

8.45.2.4 uint32_t LibPackQosClassID::maxUlBitRate

8.45.2.5 uint8_t LibPackQosClassID::QCI

8.46 LibPackTFTIDParams Struct Reference

Data Fields

- uint8_t filterId
- uint8_t eValid
- uint8_t ipVersion
- uint16_t * pSourceIP
- uint8_t sourceIPMask
- uint8_t nextHeader
- uint32_t destPortRangeStart
- uint16_t destPortRangeEnd
- uint16_t srcPortRangeStart
- uint16_t srcPortRangeEnd
- uint32_t IPSECSPI
- uint16_t tosMask
- uint32_t flowLabel

8.46.1 Detailed Description

This structure contains traffic flow template parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

filterId	• Filter identifier
eValid	• Evaluation precedence index
ipVersion	• IP version number – 4 - IPv4 – 6 - IPv6
pSourceIP	• Source IP address – IPv4 - Fill the first 4 uint8_ts – IPv6 - Fill all the 16 uint8_ts
sourceIPMask	• Mask value for the source address
nextHeader	• Next header/protocol value
destPortRange-Start	• Start value of the destination port range
destPortRange-End	• End value of the destination port range
srcPortRange-Start	• Start value of the source port range
srcPortRange-End	• End value of the source port range
IPSECSPI	• IPSEC security parameter index
tosMask	• TOS mask (Traffic class for IPv6)
flowLabel	• Flow label

8.46.2 Field Documentation

8.46.2.1 uint16_t LibPackTFTIDParams::destPortRangeEnd

8.46.2.2 uint32_t LibPackTFTIDParams::destPortRangeStart

8.46.2.3 uint8_t LibPackTFTIDParams::eValid

8.46.2.4 uint8_t LibPackTFTIDParams::filterId

8.46.2.5 uint32_t LibPackTFTIDParams::flowLabel

8.46.2.6 uint32_t LibPackTFTIDParams::IPSECSPI

8.46.2.7 uint8_t LibPackTFTIDParams::ipVersion

8.46.2.8 uint8_t LibPackTFTIDParams::nextHeader

8.46.2.9 uint16_t* LibPackTFTIDParams::pSourceIP

8.46.2.10 uint8_t LibPackTFTIDParams::sourceIPMask

8.46.2.11 uint16_t LibPackTFTIDParams::srcPortRangeEnd

8.46.2.12 uint16_t LibPackTFTIDParams::srcPortRangeStart

8.46.2.13 uint16_t LibPackTFTIDParams::tosMask

8.47 LibPackUMTSQoS Struct Reference

Data Fields

- uint8_t trafficClass
- uint32_t maxUplinkBitrate
- uint32_t maxDownlinkBitrate
- uint32_t grntUplinkBitrate
- uint32_t grntDownlinkBitrate
- uint8_t qosDeliveryOrder
- uint32_t maxSDUSize
- uint8_t sduErrorRatio
- uint8_t resBerRatio
- uint8_t deliveryErrSDU
- uint32_t transferDelay
- uint32_t trafficPriority

8.47.1 Detailed Description

This structure contains the UMTS Quality Of Service Information

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

trafficClass	• 0x00 - Subscribed • 0x01 - Conversational • 0x02 - Streaming • 0x03 - Interactive • 0x04 - Background • 0xff - Invalid UMTS Quality Of Service Information.
maxUplinkBitrate	• Maximum uplink bit rate in bits/sec
maxDownlink-Bitrate	• Maximum downlink bit rate in bits/sec
grntUplinkBitrate	• Guaranteed uplink bit rate in bits/sec
grntDownlink-Bitrate	• Guranteed downlink bit rate in bits/sec
qosDelivery-Order	- Qos delivery order • 0x00 - Subscribe • 0x01 - delivery order on • 0x02 - delivery order off
maxSDUSize	• Maximum SDU size
sduErrorRatio	- SDU error ratio • Target value for fraction of SDUs lost or detected as erroneous. • 0x00 - Subscribe • 0x01 - $1*10^{\wedge}(-2)$ • 0x02 - $7*10^{\wedge}(-3)$ • 0x03 - $1*10^{\wedge}(-3)$ • 0x04 - $1*10^{\wedge}(-4)$ • 0x05 - $1*10^{\wedge}(-5)$ • 0x06 - $1*10^{\wedge}(-6)$ • 0x07 - $1*10^{\wedge}(-1)$

resBerRatio	- Residual bit error ratio • Target value for undetected bit error ratio in in the delivered SDUs. • 0x00 - Subscribe • 0x01 - 5∗10^(-2) • 0x02 - 1∗10^(-2) • 0x03 - 5∗10^(-3) • 0x04 - 4∗10^(-3) • 0x05 - 1∗10^(-3) • 0x06 - 1∗10^(-4) • 0x07 - 1∗10^(-5) • 0x08 - 1∗10^(-6) • 0x09 - 1∗10^(-8)
deliveryErrSDU	- Delivery of erroneous SDUs • Indicates whether SDUs detected as erroneous shall be delivered or not. • 0x00 - Subscribe • 0x01 - 5∗10^(-2) • 0x02 - 1∗10^(-2) • 0x03 - 5∗10^(-3) • 0x04 - 4∗10^(-3) • 0x05 - 1∗10^(-3) • 0x06 - 1∗10^(-4) • 0x07 - 1∗10^(-5) • 0x08 - 1∗10^(-6) • 0x09 - 1∗10^(-8)
transferDelay	- Transfer delay (ms) • Indicates the targeted time between a request to transfer an SDU at one SAP to its delivery at the other SAP in milliseconds.
trafficPriority	- Transfer handling priority • Specifies the relative importance for handling of SDUs that belong to the UMTS bearer, compared to the SDUs of other bearers.

Check trafficClass before use.

8.47.2 Field Documentation

8.47.2.1 uint8_t LibPackUMTSQoS::deliveryErrSDU

8.47.2.2 uint32_t LibPackUMTSQoS::grntDownlinkBitrate

8.47.2.3 uint32_t LibPackUMTSQoS::grntUplinkBitrate

8.47.2.4 uint32_t LibPackUMTSQoS::maxDownlinkBitrate

8.47.2.5 uint32_t LibPackUMTSQoS::maxSDUSize

8.47.2.6 uint32_t LibPackUMTSQoS::maxUplinkBitrate

8.47.2.7 uint8_t LibPackUMTSQoS::qosDeliveryOrder

8.47.2.8 uint8_t LibPackUMTSQoS::resBerRatio

8.47.2.9 uint8_t LibPackUMTSQoS::sduErrorRatio

8.47.2.10 uint8_t LibPackUMTSQoS::trafficClass

8.47.2.11 uint32_t LibPackUMTSQoS::trafficPriority

8.47.2.12 uint32_t LibPackUMTSQoS::transferDelay

8.48 LibPackUMTSReqQoSSigInd Struct Reference

Data Fields

- LibPackUMTSQoS UMTSReqQoS
- uint8_t SigInd

8.48.1 Detailed Description

This structure contains UMTS requested QoS with Signaling Indication flag

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

UMTSReqQoS	• Contains the UMTS Quality Of Service Information • See LibPackUMTSQoS
SigInd	- Signaling Indication flag • TRUE - Signaling indication ON • FALSE - Signaling indication OFF

8.48.2 Field Documentation

8.48.2.1 uint8_t LibPackUMTSReqQoSSigInd::SigInd

8.48.2.2 LibPackUMTSQoS LibPackUMTSReqQoSSigInd::UMTSReqQoS

8.49 loc_BdsSV Struct Reference

Data Fields

- uint16_t id
- uint8_t mask

8.49.1 Detailed Description

This structure contains the BDS SV Info

Parameters

id	• SV ID of the satellite whose data is to be deleted. – Range for BDS: 201 to 237
mask	• Indicates if the ephemeris or almanac for a satellite is to be deleted • Valid values: – QMI_LOC_MASK_DELETE_EPHEMERIS (0x01) - Delete ephemeris for the satellite – QMI_LOC_MASK_DELETE_ALMANAC (0x02) - Delete almanac for the satellite

8.49.2 Field Documentation

8.49.2.1 uint16_t loc_BdsSV::id

8.49.2.2 uint8_t loc_BdsSV::mask

8.50 loc_BdsSVInfo Struct Reference

Data Fields

- uint8_t len
- loc_BdsSV * pSV

8.50.1 Detailed Description

This structure contains the number of sets of the BDS SVN Info

Parameters

len	• Number of sets of the following elements: – gnssSvId – deleteSvInfoMask
pSV	• Pointer to struct loc_BdsSV. See loc_BdsSV for more information

8.50.2 Field Documentation

8.50.2.1 uint8_t loc_BdsSVInfo::len

8.50.2.2 loc_BdsSV* loc_BdsSVInfo::pSV

8.51 loc_CellDb Struct Reference

Data Fields

- uint32_t mask

8.51.1 Detailed Description

This structure contains the cell database

Parameters

mask	• Mask for the cell database assistance data that is to be deleted • Valid values: – 0x00000001 - DELETE_CELLDB_POS – 0x00000002 - DELETE_CELLDB_LATEST_GPS_POS – 0x00000004 - DELETE_CELLDB_OTA_POS – 0x00000008 - DELETE_CELLDB_EXT_REF_POS – 0x00000010 - DELETE_CELLDB_TIMETAG – 0x00000020 - DELETE_CELLDB_CELLID – 0x00000040 - DELETE_CELLDB_CACHED_CELLID – 0x00000080 - DELETE_CELLDB_LAST_SRV_CELL – 0x00000100 - DELETE_CELLDB_CUR_SRV_CELL – 0x00000200 - DELETE_CELLDB_NEIGHBOR_INFO

8.51.2 Field Documentation

8.51.2.1 uint32_t loc_CellDb::mask

8.52 loc_ClkInfo Struct Reference

Data Fields

- uint32_t mask

8.52.1 Detailed Description

This structure contains the clock Info

Parameters

mask	• Mask for the clock information assistance data that is to be deleted • Valid bitmasks: – QMI_LOC_MASK_DELETE_CLOCK_INFO_TIME_EST (0x00000001) - Mask to delete time estimate from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_FREQ_EST (0x00000002) - Mask to delete frequency estimate from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_WEEK_NUMBER (0x00000004) - Mask to delete week number from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_RTC_TIME (0x00000008) - Mask to delete RTC time from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_TIME_TRANSFER (0x00000010) - Mask to delete time transfer from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GPSTIME_EST (0x00000020) - Mask to delete GPS time estimate from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GLOTIME_EST (0x00000040) - Mask to delete GLONASS time estimate from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GLODAY_NUMBER (0x00000080) - Mask to delete GLONASS day number from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GLO4YEAR_NUMBER (0x00000100) - Mask to delete GLONASS four year number from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GLO_RF_GRP_DELAY (0x00000200) - Mask to delete GLONASS RF GRP delay from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_DISABLE_TT (0x00000400) - Mask to delete disable TT from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GG_LEAPSEC (0x00000800) - Mask to delete a BDS time estimate from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GG_GGTB (0x00001000) - Mask to delete a BDS time estimate from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_BDSTIME_EST (0x00002000) - Mask to delete a BDS time estimate from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GB_GBTB (0x00004000) - Mask to delete Glonass-to-BDS time bias-related information from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_BG_BGTB (0x00008000) - Mask to delete BDS-to-GLONASS time bias-related information from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_BDSWEEK_NUMBER (0x00010000) - Mask to delete the BDS week number from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_BDS_RF_GRP_DELAY (0x00020000) - Mask to delete the BDS RF GRP delay from the clock information

8.52.2 Field Documentation

8.52.2.1 uint32_t loc_ClkInfo::mask

8.53 loc_GnssData Struct Reference

Data Fields

- uint64_t mask

8.53.1 Detailed Description

This structure contains the GNSS data

Parameters

mask	• Mask for the GNSS data that is to be deleted • Valid values: – QMI_LOC_MASK_DELETE_GPS_SVDIR (0x00000001) - Mask to delete GPS SVDIR – QMI_LOC_MASK_DELETE_GPS_SVSTEER (0x00000002) - Mask to delete GPS SVSTEER – QMI_LOC_MASK_DELETE_GPS_TIME (0x00000004) - Mask to delete GPS time – QMI_LOC_MASK_DELETE_GPS_ALM_CORR (0x00000008) - Mask to delete almanac correlation – QMI_LOC_MASK_DELETE_GLO_SVDIR (0x00000010) - Mask to delete GLONASS SVDIR – QMI_LOC_MASK_DELETE_GLO_SVSTEER (0x00000020) - Mask to delete GLONASS SVSTEER – QMI_LOC_MASK_DELETE_GLO_TIME (0x00000040) - Mask to delete GLONASS time – QMI_LOC_MASK_DELETE_GLO_ALM_CORR (0x00000080) - Mask to delete GLONASS almanac correlation – QMI_LOC_MASK_DELETE_SBAS_SVDIR (0x00000100) - Mask to delete SBAS SVDIR – QMI_LOC_MASK_DELETE_SBAS_SVSTEER (0x00000200) - Mask to delete SBAS SVSTEER – QMI_LOC_MASK_DELETE_POSITION (0x00000400) - Mask to delete position estimate – QMI_LOC_MASK_DELETE_TIME (0x00000800) - Mask to delete time estimate – QMI_LOC_MASK_DELETE_IONO (0x00001000) - Mask to delete IONO – QMI_LOC_MASK_DELETE_UTC (0x00002000) - Mask to delete UTC estimate – QMI_LOC_MASK_DELETE_HEALTH (0x00004000) - Mask to delete SV health record – QMI_LOC_MASK_DELETE_SADATA (0x00008000) - Mask to delete SADATA – QMI_LOC_MASK_DELETE_RTI (0x00010000) - Mask to delete RTI – QMI_LOC_MASK_DELETE_SV_NO_EXIST (0x00020000) - Mask to delete SV_NO_EXIST – QMI_LOC_MASK_DELETE_FREQ_BIAS_EST (0x00040000) - Mask to delete frequency bias estimate – QMI_LOC_MASK_DELETE_BDS_SVDIR (0x00080000) - Mask to delete BDS SVDIR – QMI_LOC_MASK_DELETE_BDS_SVSTEER (0x00100000) - Mask to delete BDS SVSTEER – QMI_LOC_MASK_DELETE_BDS_TIME (0x00200000) - Mask to delete BDS time – QMI_LOC_MASK_DELETE_BDS_ALM_CORR (0x00400000) - Mask to delete BDS almanac correlation – QMI_LOC_MASK_DELETE_GNSS_SV_BLACKLIST_GPS (0x00800000) - Mask to delete GNSS SV blacklist GPS – QMI_LOC_MASK_DELETE_GNSS_SV_BLACKLIST_GLO (0x01000000) - Mask to delete GNSS SV blacklist GLO – QMI_LOC_MASK_DELETE_GNSS_SV_BLACKLIST_BDS (0x02000000) - Mask to delete GNSS SV blacklist BDS

8.53.2 Field Documentation

8.53.2.1 uint64_t loc_GnssData::mask

8.54 loc_gpsTime Struct Reference

Data Fields

- uint16_t gpsWeek
- uint32_t gpsTimeOfWeekMs

8.54.1 Detailed Description

This structure contains GPS Time info.

Parameters

gpsWeek	• Current GPS week as calculated from midnight, Jan. 6, 1980. • Units - Weeks
gpsTimeOf-WeekMs	• Amount of time into the current GPS week. • Units - Milliseconds

8.54.2 Field Documentation

8.54.2.1 uint32_t loc_gpsTime::gpsTimeOfWeekMs

8.54.2.2 uint16_t loc_gpsTime::gpsWeek

8.55 loc_IPv4Info Struct Reference

Data Fields

- uint32_t address
- uint16_t port
- uint8_t TlvPresent

8.55.1 Detailed Description

This structure contains LOC Server IPV4 info field.

Parameters

address	• IPv4 address.
port	• IPv4 port.
TlvPresent	• Tlv Present or not

8.55.2 Field Documentation

8.55.2.1 uint32_t loc_IPv4Info::address

8.55.2.2 uint16_t loc_IPv4Info::port

8.55.2.3 uint8_t loc_IPv4Info::TlvPresent

8.56 loc_IPv6Info Struct Reference

Data Fields

- uint16_t address [8]
- uint32_t port
- uint8_t TlvPresent

8.56.1 Detailed Description

This structure contains LOC Get Server IPV6 info field.

Parameters

address	• IPv6 address. • Type - Array of unsigned integers • Maximum length of the array - 8
port	• IPv6 port.
TlvPresent	• Tlv Present or not

8.56.2 Field Documentation

8.56.2.1 uint16_t loc_IPv6Info::address[8]

8.56.2.2 uint32_t loc_IPv6Info::port

8.56.2.3 uint8_t loc_IPv6Info::TlvPresent

8.57 loc_LocApplicationInfo Struct Reference

Data Fields

- uint8_t appProviderLength
- uint8_t * pAppProvider
- uint8_t appNameLength
- uint8_t * pAppName
- uint8_t appVersionValid
- uint8_t appVersionLength
- uint8_t * pAppVersion

8.57.1 Detailed Description

This structure contains the Application Information

Parameters

appProvider-Length	• Length of the Application Provider
pAppProvider	• Application Provider • Depends upon the Length of application Provider
appNameLength	• Length of Application Name
pAppName	• Application Name • Depends upon the Length of application Name
appVersionValid	• Specifies whether the application version string contains a valid value • 0x00 (FALSE) Application version string is invalid • 0x01 (TRUE) Application version string is valid
appVersion-Length	• Length of Application Version
pAppVersion	• Application Version • Depends upon the Length of application Version

8.57.2 Field Documentation

8.57.2.1 uint8_t loc_LocApplicationInfo::appNameLength

8.57.2.2 uint8_t loc_LocApplicationInfo::appProviderLength

8.57.2.3 uint8_t loc_LocApplicationInfo::appVersionLength

8.57.2.4 uint8_t loc_LocApplicationInfo::appVersionValid

8.57.2.5 uint8_t* loc_LocApplicationInfo::pAppName

8.57.2.6 uint8_t* loc_LocApplicationInfo::pAppProvider

8.57.2.7 uint8_t* loc_LocApplicationInfo::pAppVersion

8.58 loc_precisionDilution Struct Reference

Data Fields

- uint32_t PDOP

- uint32_t HDOP
- uint32_t VDOP

8.58.1 Detailed Description

This structure contains Dilution of precision associated with this position.

Parameters

PDOP	• Position dilution of precision. • Range - 1 (highest accuracy) to 50 (lowest accuracy) • PDOP = square root of (Square of HDOP + Square of VDOP2)
HDOP	• Horizontal dilution of precision. • Range - 1 (highest accuracy) to 50 (lowest accuracy)
VDOP	• Vertical dilution of precision. • Range- 1 (highest accuracy) to 50 (lowest accuracy)

8.58.2 Field Documentation

8.58.2.1 uint32_t loc_precisionDilution::HDOP

8.58.2.2 uint32_t loc_precisionDilution::PDOP

8.58.2.3 uint32_t loc_precisionDilution::VDOP

8.59 loc_satelliteInfo Struct Reference

Data Fields

- uint8_t svListLen
- uint32_t validMask
- uint32_t system
- uint16_t gnssSvId
- uint8_t healthStatus
- uint32_t svStatus
- uint8_t svInfoMask
- float elevation
- float azimuth
- float snr

8.59.1 Detailed Description

Contain fields in struct loc_satelliteInfo

Parameters

svListLen	• number of sets of the following elements: – validMask – system – gnssSvid – healthStatus – svStatus – svInfoMask – elevation – azimuth – snr
validMask	• Bitmask indicating which of the fields in this TLV are valid. Valid bitmasks: – 0x00000001 - VALID_SYSTEM – 0x00000002 - VALID_GNSS_SVID – 0x00000004 - VALID_HEALTH_STATUS – 0x00000008 - VALID_PROCESS_STATUS – 0x00000010 - VALID_SVINFO_MASK – 0x00000020 - VALID_ELEVATION – 0x00000040 - VALID_AZIMUTH – 0x00000080 - VALID_SNR
system	• Indicates to which constellation this SV belongs. Valid values: – eQMI_LOC_SV_SYSTEM_GPS (1) - GPS satellite – eQMI_LOC_SV_SYSTEM_GALILEO (2) - GALILEO satellite – eQMI_LOC_SV_SYSTEM_SBAS (3) - SBAS satellite – eQMI_LOC_SV_SYSTEM_COMPASS (4) - COMPASS satellite – eQMI_LOC_SV_SYSTEM_GLONASS (5) - GLONASS satellite – eQMI_LOC_SV_SYSTEM_BDS (6) - BDS satellite
gnssSvId	• GNSS SV ID. The GPS and GLONASS SVs can be disambiguated using the system field. Range: – FOR GPS: 1 to 32 – FOR GLONASS: 1 to 32 – FOR SBAS: 120 to 151 – for BDS: 201 to 237
healthStatus	• health status. Range: 0 - 1 – 0 - unhealthy – 1 - healthy
svStatus	• SV process status. Valid values: – eQMI_LOC_SV_STATUS_IDLE (1) - SV is not being actively processed – eQMI_LOC_SV_STATUS_SEARCH (2) - The system is searching for this SV – eQMI_LOC_SV_STATUS_TRACK (3) - SV is being tracked

svInfoMask	• Indicates whether almanac and ephemeris information is available. Valid bitmasks: – 0x01 - SVINFO_HAS_EPHEMERIS – 0x02 - SVINFO_HAS_ALMANAC
elevation	• SV elevation angle. – Units: Degrees – Range: 0 to 90
azimuth	• SV azimuth angle. – Units: Degrees – Range: 0 to 360
snr	• SV signal-to-noise ratio – Units: dB-Hz

8.59.2 Field Documentation

8.59.2.1 float loc_satelliteInfo::azimuth

8.59.2.2 float loc_satelliteInfo::elevation

8.59.2.3 uint16_t loc_satelliteInfo::gnssSvId

8.59.2.4 uint8_t loc_satelliteInfo::healthStatus

8.59.2.5 float loc_satelliteInfo::snr

8.59.2.6 uint8_t loc_satelliteInfo::svInfoMask

8.59.2.7 uint8_t loc_satelliteInfo::svListLen

8.59.2.8 uint32_t loc_satelliteInfo::svStatus

8.59.2.9 uint32_t loc_satelliteInfo::system

8.59.2.10 uint32_t loc_satelliteInfo::validMask

8.60 loc_sensorDataUsage Struct Reference

Data Fields

- uint32_t usageMask
- uint32_t aidingIndicatorMask

8.60.1 Detailed Description

This structure contains Sensor Data Usage info.

Parameters

usageMask	• Specifies which sensors were used in calculating the position in the position report. – Value * 0x00000001 - Accelerometer used * 0x00000002 - Gyroscope used
aidingIndicator-Mask	• Specifies which results were aided by sensors. – Value * 0x00000001 - AIDED_HEADING * 0x00000002 - AIDED_SPEED * 0x00000004 - AIDED_POSITION * 0x00000008 - AIDED_VELOCITY

8.60.2 Field Documentation

8.60.2.1 uint32_t loc_sensorDataUsage::aidingIndicatorMask

8.60.2.2 uint32_t loc_sensorDataUsage::usageMask

8.61 loc_SV Struct Reference

Data Fields

- uint16_t id
- uint32_t system
- uint8_t mask

8.61.1 Detailed Description

This structure contains the Delete LOC SV Info

Parameters

id	• LOC SV ID of the satellite whose data is to be deleted • Range: – For GPS: 1 to 32 – For SBAS: 33 to 64 – For GLONASS: 65 to 96
system	• Indicates to which constellation this loc_SV belongs • Valid values: – eQMI_LOC_SV_SYSTEM_GPS (1) - GPS satellite – eQMI_LOC_SV_SYSTEM_GALILEO (2) - GALILEO satellite – eQMI_LOC_SV_SYSTEM_SBAS (3) - SBAS satellite – eQMI_LOC_SV_SYSTEM_COMPASS (4) - COMPASS satellite – eQMI_LOC_SV_SYSTEM_GLONASS (5) - GLONASS satellite – eQMI_LOC_SV_SYSTEM_BDS (6) - BDS satellite

mask	• Indicates if the ephemeris or almanac for a satellite is to be deleted • Valid values: – 0x01 - DELETE_EPHEMERIS – 0x02 - DELETE_ALMANAC

8.61.2 Field Documentation

8.61.2.1 uint16_t loc_SV::id

8.61.2.2 uint8_t loc_SV::mask

8.61.2.3 uint32_t loc_SV::system

8.62 loc_SVInfo Struct Reference

Data Fields

- uint8_t len
- loc_SV * pSV

8.62.1 Detailed Description

This structure contains the elements of Delete LOC SV Info

Parameters

len	• Number of sets of the following elements in struct loc_SV: – gnssSvId – system – deleteSvInfoMask
pSV	• Pointer to struct loc_SV. See loc_SV for more information

8.62.2 Field Documentation

8.62.2.1 uint8_t loc_SVInfo::len

8.62.2.2 loc_SV* loc_SVInfo::pSV

8.63 loc_svUsedforFix Struct Reference

Data Fields

- uint8_t gnssSvUsedList_len
- uint16_t gnssSvUsedList [255]

8.63.1 Detailed Description

This structure contains SVs Used to Calculate the Fix.

Parameters

gnssSvUsedList-_len	• Number of sets of gnssSvUsedList
pGnssSvUsed-List	• Entry in the list contains the SV ID of a satellite used for calculating this position report. • Following information is associated with each SV ID: – GPS - 1 to 32 – SBAS - 33 to 64 – GLONASS - 65 to 96 – QZSS - 193 to 197 – BDS - 201 to 237

8.63.2 Field Documentation

8.63.2.1 uint16_t loc_svUsedforFix::gnssSvUsedList[255]

8.63.2.2 uint8_t loc_svUsedforFix::gnssSvUsedList_len

8.64 loc_urlAddr Struct Reference

Data Fields

- char address [256]
- uint TlvPresent

8.64.1 Detailed Description

This structure contains LOC Get Server URL address field.

Parameters

address	• Uniform Resource Locator • Type - NULL terminated string • Maximum string length (including NULL terminator) 256
TlvPresent	• Tlv Present or not

8.64.2 Field Documentation

8.64.2.1 char loc_urlAddr::address[256]

8.64.2.2 uint loc_urlAddr::TlvPresent

8.65 lteSSInfo Struct Reference

Data Fields

- int8_t rssi
- int8_t rsrq
- int16_t rsrp
- int16_t snr

8.65.1 Detailed Description

This structure contains the parameters for LTE Signal Strength Information

Parameters

rssi	• RSSI in dBm (signed value). • A value of -125 dBm or lower is used to indicate No Signal. – For CDMA and UMTS, this indicates forward link pilot Ec – For GSM, this indicates received signal strength
rsrq	• RSRQ value in dB (signed integer value) as measured by L1. • Range: -3 to -20 (-3 means -3 dB, -20 means -20 dB).
rsrp	• Current RSRP in dBm as measured by L1. • Range: -44 to -140 (-44 means -44 dBm, -140 means -140 dBm).
snr	• SNR level as a scaled integer in units of 0.1 dB. e.g., -16 dB has a value of -160 and 24.6 dB has a value of 246,

8.65.2 Field Documentation

8.65.2.1 int16_t lteSSInfo::rsrp

8.65.2.2 int8_t lteSSInfo::rsrq

8.65.2.3 int8_t lteSSInfo::rssi

8.65.2.4 int16_t lteSSInfo::snr

8.66 messageModeTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSMessageModeInfo MessageModeInfo

8.66.1 Detailed Description

This structure contains message mode TLV information.

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
MessageMode-Info	• Message Mode • See sMSMessageModeInfo for more information

8.66.2 Field Documentation

8.66.2.1 sMSMessageModeInfo messageModeTlv::MessageModeInfo

8.66.2.2 uint8_t messageModeTlv::TlvPresent

8.67 nas_acqOrderPref Struct Reference

Data Fields

- uint8_t acqOrdeLen
- uint8_t * pAcqOrder

8.67.1 Detailed Description

Contain the Acquisition Order Preference.

Parameters

acqOrdeLen	• Number of sets of the following elements.
pAcqOrder	• Acquisition order preference to be set. Values: – 0x01 - NAS_RADIO_IF_CDMA_1X - cdma2000 1X – 0x02 - NAS_RADIO_IF_CDMA_1XEVDO - cdma2000 HRPD (1xEV-DO) – 0x04 - NAS_RADIO_IF_GSM - GSM – 0x05 - NAS_RADIO_IF_UMTS - UMTS – 0x08 - NAS_RADIO_IF_LTE - LTE – 0x09 - NAS_RADIO_IF_TDSCDMA - TD-SCDMA

8.67.2 Field Documentation

8.67.2.1 uint8_t nas_acqOrderPref::acqOrdeLen

8.67.2.2 uint8_t* nas_acqOrderPref::pAcqOrder

8.68 nas_ActPilotPNElement Struct Reference

Data Fields

- uint16_t ActSetPilotPN
- uint8_t ActSetPilotPNStrength

8.68.1 Detailed Description

This structure contains pilot PN Element.

Parameters

ActSetPilotPN	• Active Pilot PN
ActSetPilotPN-Strength	• Active Pilot PN strength

8.68.2 Field Documentation

8.68.2.1 uint16_t nas_ActPilotPNElement::ActSetPilotPN

8.68.2.2 uint8_t nas_ActPilotPNElement::ActSetPilotPNStrength

8.69 nas_AddCDMASysInfo Struct Reference

Data Fields

- uint16_t geoSysIdx
- uint16_t regPrd

8.69.1 Detailed Description

Structure for storing the Additional CDMA System Information.

Parameters

geoSysIdx	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used.
regPrd	• Registration period after the CDMA system is acquired. • When the CDMA registration period is not valid, 0xFFFF is used.

8.69.2 Field Documentation

8.69.2.1 uint16_t nas_AddCDMASysInfo::geoSysIdx

8.69.2.2 uint16_t nas_AddCDMASysInfo::regPrd

8.70 nas_AddSysInfo Struct Reference

Data Fields

- uint16_t geoSysIdx
- uint32_t cellBroadcastCap

8.70.1 Detailed Description

Structure for storing the Additional GSM and WCDMA System Information.

Parameters

geoSysIdx	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used.
cellBroadcast-Cap	• Cell broadcast capability of the serving system. • When the CDMA registration period is not valid, 0xFFFF is used. – NAS_CELL_BROADCAST_CAP_UNKNOWN - Cell broadcast support is unknown – NAS_CELL_BROADCAST_CAP_OFF - Cell broadcast is not supported – NAS_CELL_BROADCAST_CAP_ON - Cell broadcast is supported

8.70.2 Field Documentation

8.70.2.1 uint32_t nas_AddSysInfo::cellBroadcastCap

8.70.2.2 uint16_t nas_AddSysInfo::geoSysIdx

8.71 nas_CallBarringSysInfo Struct Reference

Data Fields

- uint32_t csBarStatus
- uint32_t psBarStatus

8.71.1 Detailed Description

Structure for storing the GSM and WCDMA Call Barring System Information.

Parameters

csBarStatus	• Call barring status for circuit-switched calls. – NAS_CELL_ACCESS_NORMAL_ONLY - Cell access is allowed for normal calls only – NAS_CELL_ACCESS_EMERGENCY_ONLY - Cell access is allowed for emergency calls only – NAS_CELL_ACCESS_NO_CALLS - Cell access is not allowed for any call type – NAS_CELL_ACCESS_ALL_CALLS - Cell access is allowed for all call types – NAS_CELL_ACCESS_UNKNOWN - Cell access type is unknown
psBarStatus	• Call barring status for packet-switched calls. – NAS_CELL_ACCESS_NORMAL_ONLY - Cell access is allowed for normal calls only – NAS_CELL_ACCESS_EMERGENCY_ONLY - Cell access is allowed for emergency calls only – NAS_CELL_ACCESS_NO_CALLS - Cell access is not allowed for any call type – NAS_CELL_ACCESS_ALL_CALLS - Cell access is allowed for all call types – NAS_CELL_ACCESS_UNKNOWN - Cell access type is unknown

8.71.2 Field Documentation

8.71.2.1 uint32_t nas_CallBarringSysInfo::csBarStatus

8.71.2.2 uint32_t nas_CallBarringSysInfo::psBarStatus

8.72 nas_callBarStatus Struct Reference

Data Fields

- uint32_t csBarStatus
- uint32_t psBarStatus

8.72.1 Detailed Description

This structure contains Call Barring Status.

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

csBarStatus	• Call Barring Status for circuit-switched calls. • Values: • NAS_CELL_ACCESS_NORMAL_ONLY - Cell access is allowed for normal calls only • NAS_CELL_ACCESS_EMERGENCY_ONLY - Cell access is allowed for emergency calls only • NAS_CELL_ACCESS_NO_CALLS - Cell access is not allowed for any call type • NAS_CELL_ACCESS_ALL_CALLS - Cell access is allowed for all call types • NAS_CELL_ACCESS_UNKNOWN - Cell access type is unknown

psBarStatus	• Call Barring Status for packet-switched calls. • Values: – NAS_CELL_ACCESS_NORMAL_ONLY - Cell access is allowed for normal calls only – NAS_CELL_ACCESS_EMERGENCY_ONLY - Cell access is allowed for emergency calls only – NAS_CELL_ACCESS_NO_CALLS - Cell access is not allowed for any call type – NAS_CELL_ACCESS_ALL_CALLS - Cell access is allowed for all call types – NAS_CELL_ACCESS_UNKNOWN - Cell access type is unknown

8.72.2 Field Documentation

8.72.2.1 uint32_t nas_callBarStatus::csBarStatus

8.72.2.2 uint32_t nas_callBarStatus::psBarStatus

8.73 nas_CDMAChannel Struct Reference

Data Fields

- uint16_t priChA
- uint16_t priChB
- uint16_t secChA
- uint16_t secChB

8.73.1 Detailed Description

This structure contains CDMA channel.

Parameters

priChA	• A Channel number for the primary carrier. – 0xFFFF - Not Available
priChB	• B Channel number for the primary carrier. – 0xFFFF - Not Available
secChA	• A Channel number for the secondary carrier. – 0xFFFF - Not Available
secChB	• B Channel number for the secondary carrier. – 0xFFFF - Not Available

8.73.2 Field Documentation

8.73.2.1 uint16_t nas_CDMAChannel::priChA

8.73.2.2 uint16_t nas_CDMAChannel::priChB

8.73.2.3 uint16_t nas_CDMAChannel::secChA

8.73.2.4 uint16_t nas_CDMAChannel::secChB

8.74 nas_CDMAECIOThresh Struct Reference

Data Fields

- uint8_t CDMAECIOThreshListLen
- int16_t * pCDMAECIOThreshList

8.74.1 Detailed Description

This structure contains CDMA ECIO threshold related parameters.

Parameters

CDMAECIO-ThreshListLen	• Length of the CDMA ECIO threshold list parameter to follow
pCDMAECIO-ThreshList	• Array of ECIO thresholds (in units of 0.1 dB) • Maximum of 32 values. Range for ECIO values: -31.5 to 0 (in dB)

8.74.2 Field Documentation

8.74.2.1 uint8_t nas_CDMAECIOThresh::CDMAECIOThreshListLen

8.74.2.2 int16_t* nas_CDMAECIOThresh::pCDMAECIOThreshList

8.75 nas_CDMAInfo Struct Reference

Data Fields

- uint16_t sid
- uint16_t nid
- uint16_t baseId
- uint16_t refpn
- uint32_t baseLat
- uint32_t baseLong

8.75.1 Detailed Description

This structure contains information about the CDMA Network.

Parameters

sid	• System ID. – 0xFFFF - Not Available
nid	• Network ID. – 0xFFFF - Not Available
baseId	• Base station ID. – 0xFFFF - Not Available
refpn	• Reference PN. – 0xFFFF - Not Available
baseLat	• Latitude of the current base station in units of 0.25 sec. – 0xFFFFFFFF - Not Available
baseLong	• Longitude of the current base station in units of 0.25 sec. – 0xFFFFFFFF - Not Available

8.75.2 Field Documentation

8.75.2.1 uint16_t nas_CDMAInfo::baseId

8.75.2.2 uint32_t nas_CDMAInfo::baseLat

8.75.2.3 uint32_t nas_CDMAInfo::baseLong

8.75.2.4 uint16_t nas_CDMAInfo::nid

8.75.2.5 uint16_t nas_CDMAInfo::refpn

8.75.2.6 uint16_t nas_CDMAInfo::sid

8.76 nas_CDMARSSIThresh Struct Reference

Data Fields

- uint8_t CDMARSSIThreshListLen
- int16_t * pCDMARSSIThreshList

8.76.1 Detailed Description

This structure contains CDMA RSSI threshold related parameters.

Parameters

CDMARSSI-ThreshListLen	• Length of the CDMARSSI threshold list parameter to follow
pCDMARSSI-ThreshList	• Array of RSSI thresholds (in units of 0.1 dBm) • maximum of 32 values. • Range for RSSI values:-105 to -21 (in dBm).

8.76.2 Field Documentation

8.76.2.1 uint8_t nas_CDMARSSIThresh::CDMARSSIThreshListLen

8.76.2.2 int16_t* nas_CDMARSSIThresh::pCDMARSSIThreshList

8.77 nas_CDMASysInfo Struct Reference

Data Fields

- nas_sysInfoCommon sysInfoCDMA
- uint8_t isSysPrlMatchValid
- uint8_t isSysPrlMatch
- uint8_t pRevInUseValid
- uint8_t pRevInUse
- uint8_t bsPRevValid
- uint8_t bsPRev
- uint8_t ccsSupportedValid
- uint8_t ccsSupported
- uint8_t cdmaSysIdValid
- uint16_t systemID
- uint16_t networkID
- uint8_t bsInfoValid
- uint16_t baseId
- uint32_t baseLat
- uint32_t baseLong
- uint8_t packetZoneValid
- uint16_t packetZone
- uint8_t networkIdValid
- uint8_t MCC [3]
- uint8_t MNC [3]

8.77.1 Detailed Description

Structure for storing the CDMA System Information.

Parameters

sysInfoCDMA	• See nas_sysInfoCommon for more information.

isSysPrlMatch-Valid	• Indicates whether the system PRL match is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
isSysPrlMatch	• Indicates whether the system is in a PRL. • Only applies to CDMA/HDR. – 0x00 - System is not in a PRL – 0x01 - System is in a PRL – 0xFF - Not Available • If the system is not in a PRL, roam_status carries the value from the default roaming indicator in the PRL. • If the system is in a PRL, roam_status is set to the value based on the standard specification.
pRevInUseValid	• Indicates whether the P_Rev in use is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
pRevInUse	• The lesser of the base station P_Rev and mobile P_Rev • Only applicable for CDMA. – 0xFF - Not Available
bsPRevValid	• Indicates whether the base station P_Rev is valid – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
bsPRev	• Base station P_Rev. • Only applicable for CDMA. – 0xFF - Not Available
ccsSupported-Valid	• Indicates whether the supported concurrent service is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
ccsSupported	• Whether concurrent service is supported. • Only applicable for CDMA. – 0x00 - Not supported – 0x01 - Supported – 0xFF - Not Available

cdmaSysIdValid	• Indicates whether the CDMA system ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
systemID	• System ID. – 0xFFFF - Not Available
networkID	• Network ID. – 0xFFFF - Not Available
bsInfoValid	• Indicates whether the base station information is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
baseLat	• Base station latitude in units of 0.25 sec. • Expressed as a two's complement signed number with positive numbers signifying North latitudes. – 0xFFFFFFFF - Not Available
baseLong	• Base station longitude in units of 0.25 sec. • Expressed as a two's complement signed number with positive numbers signifying East latitudes. – 0xFFFFFFFF - Not Available
packetZoneValid	• Indicates whether the packet zone is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
packetZone	• Packet zone (8-bit). – 0xFFFF indicates no packet zone. • Only applicable for CDMA.
networkIdValid	• Indicates whether the network ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available

MCC[NAS_PLMN_LENGTH]	• Mobile Country Code. • MCC digits in ASCII characters • MCC wildcard value is returned as {'3', 0xFF, 0xFF}.
MNC[NAS_PLMN_LENGTH]	• Mobile Network Code. • MNC digits in ASCII characters • An unused byte is set to 0xFF. • MNC wildcard value is returned as {'7', 0xFF, 0xFF}.

8.77.2 Field Documentation

8.77.2.1 uint16_t nas_CDMASysInfo::baseId

8.77.2.2 uint32_t nas_CDMASysInfo::baseLat

8.77.2.3 uint32_t nas_CDMASysInfo::baseLong

8.77.2.4 uint8_t nas_CDMASysInfo::bsInfoValid

8.77.2.5 uint8_t nas_CDMASysInfo::bsPRev

8.77.2.6 uint8_t nas_CDMASysInfo::bsPRevValid

8.77.2.7 uint8_t nas_CDMASysInfo::ccsSupported

8.77.2.8 uint8_t nas_CDMASysInfo::ccsSupportedValid

8.77.2.9 uint8_t nas_CDMASysInfo::cdmaSysIdValid

8.77.2.10 uint8_t nas_CDMASysInfo::isSysPrlMatch

8.77.2.11 uint8_t nas_CDMASysInfo::isSysPrlMatchValid

8.77.2.12 uint8_t nas_CDMASysInfo::MCC[3]

8.77.2.13 uint8_t nas_CDMASysInfo::MNC[3]

8.77.2.14 uint16_t nas_CDMASysInfo::networkID

8.77.2.15 uint8_t nas_CDMASysInfo::networkIdValid

8.77.2.16 uint16_t nas_CDMASysInfo::packetZone

8.77.2.17 uint8_t nas_CDMASysInfo::packetZoneValid

8.77.2.18 uint8_t nas_CDMASysInfo::pRevInUse

8.77.2.19 uint8_t nas_CDMASysInfo::pRevInUseValid

8.77.2.20 nas_sysInfoCommon nas_CDMASysInfo::sysInfoCDMA

8.77.2.21 uint16_t nas_CDMASysInfo::systemID

8.78 nas_CDMASysInfoExt Struct Reference

Data Fields

- uint16_t MCC
- uint8_t imsi_11_12

8.78.1 Detailed Description

This structure contains CDMA system information extension

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

MCC	• Mobile Country Code
imsi_11_12	• IMSI_11_12

8.78.2 Field Documentation

8.78.2.1 uint8_t nas_CDMASysInfoExt::imsi_11_12

8.78.2.2 uint16_t nas_CDMASysInfoExt::MCC

8.79 nas_cellParams Struct Reference

Data Fields

- uint16_t pci
- int16_t rsrq
- int16_t rsrp
- int16_t rssi
- int16_t srxlev

8.79.1 Detailed Description

This structure contains information about the Cell parameters.

Parameters

pci	• Physical cell ID. • Range: 0 to 503.

rsrq	• Current RSRQ in 1/10 dB as measured by L1. • Range: -20.0 dB to -3.0 dB.
rsrp	• Current RSRP in 1/10 dBm as measured by L1. • Range: -140.0 dBm to -44.0 dBm.
rssi	• Current RSSI in 1/10 dBm as measured by L1. • Range: -120.0 dBm to 0.
srxlev	• Cell selection Rx level (Srxlev) value. • Range: -128 to 128. • This field is only valid when ue_in_idle is TRUE.

8.79.2 Field Documentation

8.79.2.1 uint16_t nas_cellParams::pci

8.79.2.2 int16_t nas_cellParams::rsrp

8.79.2.3 int16_t nas_cellParams::rsrq

8.79.2.4 int16_t nas_cellParams::rssi

8.79.2.5 int16_t nas_cellParams::srxlev

8.80 nas_CommInfo Struct Reference

Data Fields

- int8_t temperature
- uint8_t modemMode
- uint8_t systemMode
- uint8_t imsRegState
- uint8_t psState

8.80.1 Detailed Description

Structure for storing the common information for the device.

Parameters

temperature	• Temperature. – 8-bit signed integer – 0xFF - Not Available.

modemMode	• Modem Operating Mode. – 0x00 - POWERING OFF – 0x01 - FACTORY TEST – 0x02 - OFFLINE – 0x03 - OFFLINE_AMPS – 0x04 - OFFLINE_CDMA – 0x05 - ONLINE – 0x06 - LOW POWER MODE – 0x07 - RESETTING – 0x08 - NETWORK TEST – 0x09 - OFFLINE REQUEST – 0x0A - PSEUDO ONLINE – 0x0B - RESETTING MODEM – 0xFF - Unknown
systemMode	• System Acquisition Mode. – 0x00 - No service – 0x01 - AMPS – 0x02 - CDMA – 0x03 - GSM – 0x04 - HDR – 0x05 - WCDMA – 0x06 - GPS – 0x08 - WLAN – 0x09 - LTE – 0xFF - Unknown
imsRegState	• IMS Registration State. – 0x00 - NO SRV – 0x01 - IN PROG – 0x02 - FAILED – 0x03 - LIMITED – 0x04 - FULL SRV – 0xFF - Unknown
psState	• PS Attach State. – 0x00 - Attached – 0x01 - Detached – 0xFF - Unknown

8.80.2 Field Documentation

8.80.2.1 uint8_t nas_CommInfo::imsRegState

8.80.2.2 uint8_t nas_CommInfo::modemMode

8.80.2.3 uint8_t nas_CommInfo::psState

8.80.2.4 uint8_t nas_CommInfo::systemMode

8.80.2.5 int8_t nas_CommInfo::temperature

8.81 nas_CSGID Struct Reference

Data Fields

- uint16_t mcc
- uint16_t mnc
- uint8_t mncPcsDigits
- uint32_t id
- uint8_t rat

8.81.1 Detailed Description

Contain the CSGID.

Parameters

mcc	• MCC value. Range 0 to 999
mnc	• MNC value. Range 0 to 999
mncPcsDigits	• TRUE - MNC is a three-digit value; e.g., a reported value of 90 corresponds to an MNC value of 090 • FALSE - MNC is a two-digit value; e.g., a reported value of 90 corresponds to an MNC value of 90
id	• Closed subscriber group identifier.
rat	• Radio interface technology of the CSG network. Values: – 0x04 - RADIO_IF_GSM - GSM – 0x05 - RADIO_IF_UMTS - UMTS – 0x08 - RADIO_IF_LTE - LTE – 0x09 - RADIO_IF_TDSCDMA - TDS

8.81.2 Field Documentation

8.81.2.1 uint32_t nas_CSGID::id

8.81.2.2 uint16_t nas_CSGID::mcc

8.81.2.3 uint16_t nas_CSGID::mnc

8.81.2.4 uint8_t nas_CSGID::mncPcsDigits

8.81.2.5 uint8_t nas_CSGID::rat

8.82 nas_currentPLMN Struct Reference

Data Fields

- uint16_t MCC
- uint16_t MNC
- uint8_t netDescrLength
- uint8_t netDescr [255]

8.82.1 Detailed Description

This structure contains the current PLMN parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

MCC	• mobile country code – A 16 bit representation of MCC – Range 0 to 999
MNC	• mobile network code – A 16 bit representation of MNC – Range 0 to 999
netDescrLength	• Length of Network description field • Defaults to zero
netDescr	• Network Description – optional string containing network name or description

8.82.2 Field Documentation

8.82.2.1 uint16_t nas_currentPLMN::MCC

8.82.2.2 uint16_t nas_currentPLMN::MNC

8.82.2.3 uint8_t nas_currentPLMN::netDescr[255]

8.82.2.4 uint8_t nas_currentPLMN::netDescrLength

8.83 nas_dataSrvCapabilities Struct Reference

Data Fields

- uint8_t dataCapabilitiesLen
- uint8_t dataCapabilities [32]

8.83.1 Detailed Description

This structure contains the data services capability

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

dataCapabilities-Len	• Length of data capabilities list • Defaults to zero
dataCapabilities	• List of data capabilities • Values: – 0x01 - GPRS – 0x02 - EDGE – 0x03 - HSDPA – 0x04 - HSUPA – 0x05 - WCDMA – 0x06 - CDMA – 0x07 - EV-DO Rev0 – 0x08 - EV-DO RevA – 0x09 - GSM – 0x0A - EV-DO Rev B – 0x0B - LTE – 0x0C - HSDPA+ – 0x0D - DC-HSDPA+

8.83.2 Field Documentation

8.83.2.1 uint8_t nas_dataSrvCapabilities::dataCapabilities[32]

8.83.2.2 uint8_t nas_dataSrvCapabilities::dataCapabilitiesLen

8.84 nas_DataStatusDetail Struct Reference

Data Fields

- uint32_t IPAddress
- uint8_t LastErrCode

8.84.1 Detailed Description

This structure contains data status detail

Parameters

IPAddress	• IP Address • 0xABCDEFGH - AB.CD.EF.GH • Example: – 0x12345678 - 18.52.86.120 0x12=18 0x34=52 0x56=86 0x78=120 • 0xFFFFFFFF - NA

LastErrCode	• MIP Error code – 0x00 - MIP_RRP_CODE_SUCCESS – 0x01 - MIP_RRP_CODE_SUCCESS_NO_SIM_BINDINGS – 0x40 - MIP_RRP_CODE_FAILURE_FA_REASON_UNSPECIFIED – 0x41 - MIP_RRP_CODE_FAILURE_FA_ADMIN_PROHIBITED – 0x42 - MIP_RRP_CODE_FAILURE_FA_INSUFFICIENT_RESOURCES – 0x43 - MIP_RRP_CODE_FAILURE_FA_MOBILE_NODE_FAILED_AUTH – 0x44 - MIP_RRP_CODE_FAILURE_FA_HA_FAILED_AUTH – 0x45 - MIP_RRP_CODE_FAILURE_FA_REQUESTED_LIFETIME_TOO_LONG – 0x46 - MIP_RRP_CODE_FAILURE_FA_MALFORMED_REQUEST – 0x47 - MIP_RRP_CODE_FAILURE_FA_MALFORMED_REPLY – 0x48 - MIP_RRP_CODE_FAILURE_FA_ENCAPSULATION_UNAVAILABLE – 0x49 - MIP_RRP_CODE_FAILURE_FA_VJHC_UNAVAILABLE – 0x4A - MIP_RRP_CODE_FAILURE_FA_CANT_REV_TUN – 0x4B - MIP_RRP_CODE_FAILURE_FA_MUST_REV_TUN – 0x4C - MIP_RRP_CODE_FAILURE_FA_BAD_TTL – 0x4D - MIP_RRP_CODE_FAILURE_INVALID_COA – 0x4F - MIP_RRP_CODE_FAILURE_FA_DELIVERY_STYLE_NOT_SUPPORTED – 0x59 - MIP_RRP_CODE_FAILURE_FA_VS_REASON – 0x61 - MIP_RRP_CODE_FAILURE_MISSING_NAI – 0x62 - MIP_RRP_CODE_FAILURE_MISSING_HA_ADDR – 0x63 - MIP_RRP_CODE_FAILURE_MISSING_HOMEADDR – 0x68 - MIP_RRP_CODE_FAILURE_UNKNOWN_CHALLENGE – 0x69 - MIP_RRP_CODE_FAILURE_MISSING_CHALLENGE – 0x6A - MIP_RRP_CODE_FAILURE_STALE_CHALLENGE – 0x6B - MIP_RRP_CODE_FAILURE_MISSING_MN_FA – 0x80 - MIP_RRP_CODE_FAILURE_HA_REASON_UNSPECIFIED – 0x81 - MIP_RRP_CODE_FAILURE_HA_ADMIN_PROHIBITED – 0x82 - MIP_RRP_CODE_FAILURE_HA_INSUFFICIENT_RESOURCES – 0x83 - MIP_RRP_CODE_FAILURE_HA_MOBILE_NODE_FAILED_AUTH – 0x84 - MIP_RRP_CODE_FAILURE_HA_FA_FAILED_AUTH – 0x85 - MIP_RRP_CODE_FAILURE_HA_REG_ID_MISMATCH – 0x86 - MIP_RRP_CODE_FAILURE_HA_MALFORMED_REQUEST – 0x88 - MIP_RRP_CODE_FAILURE_UNKNOWN_HA – 0x89 - MIP_RRP_CODE_FAILURE_HA_CANT_REV_TUN – 0x8A - MIP_RRP_CODE_FAILURE_HA_MUST_REV_TUN – 0x8B - MIP_RRP_CODE_FAILURE_HA_ENCAPSULATION_UNAVAILABLE – 0x8F - MIP_RRP_CODE_FAILURE_REDIRECTED_HA – 0x90 - MIP_RRP_CODE_FAILURE_HA_BAD_AAA_AUTH – 0xFF - NA

8.84.2 Field Documentation

8.84.2.1 uint32_t nas_DataStatusDetail::IPAddress

8.84.2.2 uint8_t nas_DataStatusDetail::LastErrCode

8.85 nas_detailSvcInfo Struct Reference

Data Fields

- uint8_t srvStatus
- uint8_t srvCapability
- uint8_t hdrSrvStatus
- uint8_t hdrHybrid
- uint8_t isSysForbidden

8.85.1 Detailed Description

This structure contains Detailed Service information

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

srvStatus	• Service status • Values: – 0x00 - No service – 0x01 - Limited service – 0x02 - Service available – 0x03 - Limited regional service – 0x04 - MS in power save or deep sleep
srvCapability	• System's service capability • Values: – 0x00 - No Service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - MS found the right system but not yet registered/attached
hdrSrvStatus	• HDR service status • Values: – 0x00 - No service – 0x01 - Limited service – 0x02 - Service available – 0x03 - Limited regional service – 0x04 - MS in power save or deep sleep
hdrHybrid	• HDR hybrid information • Values: – 0x00 - System is not hybrid – 0x01 - System is hybrid

isSysForbidden	• Forbidden system information • Values: – 0x00 - System is not a forbidden system – 0x01 - System is a forbidden system

8.85.2 Field Documentation

8.85.2.1 uint8_t nas_detailSvcInfo::hdrHybrid

8.85.2.2 uint8_t nas_detailSvcInfo::hdrSrvStatus

8.85.2.3 uint8_t nas_detailSvcInfo::isSysForbidden

8.85.2.4 uint8_t nas_detailSvcInfo::srvCapability

8.85.2.5 uint8_t nas_detailSvcInfo::srvStatus

8.86 nas_DeviceConfigDetail Struct Reference

Data Fields

- uint8_t Technology
- uint8_t QLIC
- uint8_t Chipset
- uint8_t HWVersion

8.86.1 Detailed Description

This structure contains device configure detail.

Parameters

Technology	• Current technology in use – 0x00 - 1x RTT – 0x01 - EVDO Rev 0 – 0x02 - EVDO Rev A – 0xFF - NA
QLIC	• Quasi Linear Interference Cancellation – 0x00 - Not supported – 0x01 - Supported
Chipset	• Qualcomm platform – 0x4E - MDM6200 – 0x4F - MDM6600 – 0xFF - NA

HWVersion	• Hardware version – 0x00 - BSHWREV0 – 0x01 - BSHWREV1 – 0x02 - BSHWREV2 – 0x03 - BSHWREV3 – 0x04 - BSHWREVMAX – 0xFF - BSHWREVUNKNOWN

8.86.2 Field Documentation

8.86.2.1 uint8_t nas_DeviceConfigDetail::Chipset

8.86.2.2 uint8_t nas_DeviceConfigDetail::HWVersion

8.86.2.3 uint8_t nas_DeviceConfigDetail::QLIC

8.86.2.4 uint8_t nas_DeviceConfigDetail::Technology

8.87 nas_dirNum Struct Reference

Data Fields

- uint8_t dirNumLen
- uint8_t dirNum [255]

8.87.1 Detailed Description

This structure contains the parameters for Directory Number Information

Parameters

dirNumLen	• Number of sets of the following elements: – dir_num • If zero(0), then no information follows.
dirNum	• Directory number in ASCII characters.

8.87.2 Field Documentation

8.87.2.1 uint8_t nas_dirNum::dirNum[255]

8.87.2.2 uint8_t nas_dirNum::dirNumLen

8.88 nas_DRCParams Struct Reference

Data Fields

- uint8_t DRCValue
- uint8_t DRCCover

8.88.1 Detailed Description

This structure contains DRC information.

Parameters

DRCValue	• Current Data Rate Channel
DRCCover	• Current Data Rate Channel cover

8.88.2 Field Documentation

8.88.2.1 uint8_t nas_DRCParams::DRCCover

8.88.2.2 uint8_t nas_DRCParams::DRCValue

8.89 nas_ecioListElement Struct Reference

Data Fields

- int16_t ecio
- uint8_t radioIf

8.89.1 Detailed Description

This structure contains the ECIO Information

Parameters

ecio	• ECIO value in dBm
radioIf	• Radio interface technology of the signal being measured – 0x00 – RADIO_IF_NO_SVC – None (no service) – 0x01 – RADIO_IF_CDMA_1X – cdma2000® 1X – 0x02 – RADIO_IF_CDMA_1XEVDO – cdma2000 HRPD (1xEV-DO) – 0x03 – RADIO_IF_AMPS – AMPS – 0x04 – RADIO_IF_GSM – GSM – 0x05 – RADIO_IF_UMTS – UMTS

8.89.2 Field Documentation

8.89.2.1 int16_t nas_ecioListElement::ecio

8.89.2.2 uint8_t nas_ecioListElement::radioIf

8.90 nas_ECIOThresh Struct Reference

Data Fields

- uint8_t ECIOThresListLen
- int16_t * pECIOThresList

8.90.1 Detailed Description

This sturcture contain ECIO threshold list.

Parameters

ECIOThresList-Len	• Length of the ECIO threshold list parameter to follow
pECIOThresList	• Sequence of thresholds delimiting ECIO event reporting bands • Every time a new ECIO value crosses a threshold value, an event report indication message with the new ECIO value is sent to the requesting control point. For this field – Each ECIO threshold value is a signed 2 byte value – Each ECIO threshold value increments in negative 0.5 dB, e.g., an ECIO threshold value of 2 means -1dB – Maximum number of threshold values is 16 – At least one value must be specified – Threshold values specified above are used for all RATs

8.90.2 Field Documentation

8.90.2.1 uint8_t nas_ECIOThresh::ECIOThresListLen

8.90.2.2 int16_t* nas_ECIOThresh::pECIOThresList

8.91 nas_errorRateListElement Struct Reference

Data Fields

- uint16_t errorRate
- uint8_t radioIf

8.91.1 Detailed Description

This structure contains the Error Rate Information

Parameters

errorRate	• Error rate value corresponds to the RAT that is currently registered. – For CDMA, the error rate reported is Frame Error Rate: * Valid error rate values between 1 and 10000 are returned to indicate percentage, e.g., a value of 300 means the error rate is 3% * A value of 0xFFFF indicates that the error rate is unknown or unavailable – For HDR, the error rate reported is Packet Error Rate: * Valid error rate values between 1 and 10000 are returned to indicate percentage, e.g., a value of 300 means the error rate is 3% * A value of 0xFFFF indicates that the error rate is unknown or unavailable – For GSM, the error rate reported is Bit Error Rate: * Valid values are 0, 100, 200, 300, 400, 500, 600, and 700 The reported value divided by 100 gives the error rate as an RxQual value, e.g.,a value of 300 represents an RxQual value of 3. * A value of 25500 indicates No Data – For WCDMA, the error rate reported is Block Error Rate (BLER): * Valid values are 1 to 10000 * The reported value divided by 100 provides the error rate in percentages, e.g., a value of 300 represents a BLER of 3%. * A value of 0 indicates No Data
radioIf	• Radio interface technology of the signal being measured – 0x00 – RADIO_IF_NO_SVC – None (no service) – 0x01 – RADIO_IF_CDMA_1X – cdma2000® 1X – 0x02 – RADIO_IF_CDMA_1XEVDO – cdma2000 HRPD (1xEV-DO) – 0x03 – RADIO_IF_AMPS – AMPS – 0x04 – RADIO_IF_GSM – GSM – 0x05 – RADIO_IF_UMTS – UMTS

8.91.2 Field Documentation

8.91.2.1 uint16_t nas_errorRateListElement::errorRate

8.91.2.2 uint8_t nas_errorRateListElement::radioIf

8.92 nas_GERANInfo Struct Reference

Data Fields

- uint32_t cellID
- uint8_t plmn [3]
- uint16_t lac
- uint16_t arfcn
- uint8_t bsic
- uint32_t timingAdvance
- uint16_t rxLev
- uint8_t nmrInst
- nas_nmrCellInfo insNmrCellInfo [255]

8.92.1 Detailed Description

This structure contains information about the GERAN Network.

Parameters

cellID	• Cell ID. • 0xFFFFFFFF indicates cell ID information is not present.
plmn[NAS_PLMN_LENGTH]	• MCC/MNC information coded as octet 3, 4, and 5. • This field is ignored when nmrCellID is not present.
lac	• Location area code. • This field is ignored when nmrCellID is not present. – 0xFFFF - Not Available
arfcn	• Absolute RF channel number. – 0xFFFF - Not Available
bsic	• Base station identity code. – 0xFF - Not Available
timingAdvance	• Measured delay (in bit periods; 1 bit period = 48/13 microsecond) of access burst transmission on RACH or PRACH to the expected signal from an MS at zero distance under static channel conditions. – 0xFFFFFFFF - Not Available
rxLev	• Serving Cell Rx measurement. • Values range between 0 and 63. • Mapped to a measured signal level: – Rxlev 0 is a signal strength less than -110 dBm – Rxlev 1 is -110 dBm to -109 dBm – Rxlev 2 is -109 dBm to -108 dBm – ... – Rxlev 62 is -49 dBm to -48 dBm – Rxlev 63 is greater than -48 dBm – 0xFFFF - Not Available
nmrInst	• Provides the number of set of instances which follow. • If 0(zero), then no information follows it.
insNmrCellInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_nmrCellInfo for more information.

8.92.2 Field Documentation

8.92.2.1 uint16_t nas_GERANInfo::arfcn

8.92.2.2 uint8_t nas_GERANInfo::bsic

8.92.2.3 uint32_t nas_GERANInfo::cellID

8.92.2.4 nas_nmrCellInfo nas_GERANInfo::insNmrCellInfo[255]

8.92.2.5 uint16_t nas_GERANInfo::lac

8.92.2.6 uint8_t nas_GERANInfo::nmrInst

8.92.2.7 uint8_t nas_GERANInfo::plmn[3]

8.92.2.8 uint16_t nas_GERANInfo::rxLev

8.92.2.9 uint32_t nas_GERANInfo::timingAdvance

8.93 nas_geranInstInfo Struct Reference

Data Fields

- uint16_t geranArfcn
- uint8_t geranBsicNcc
- uint8_t geranBsicBcc
- int16_t geranRssi

8.93.1 Detailed Description

This structure contains information about the GERAN Instances in UMTS Network.

Parameters

geranArfcn	• Absolute RF channel number.
geranBsicNcc	• Base station identity code network color code. • 0xFF indicates information is not present.
geranBsicBcc	• Base station identity code base station color code. • 0xFF indicates information is not present.
geranRssi	• Received signal strength indicator.

8.93.2 Field Documentation

8.93.2.1 uint16_t nas_geranInstInfo::geranArfcn

8.93.2.2 uint8_t nas_geranInstInfo::geranBsicBcc

8.93.2.3 uint8_t nas_geranInstInfo::geranBsicNcc

8.93.2.4 int16_t nas_geranInstInfo::geranRssi

8.94 nas_gsmCellInfo Struct Reference

Data Fields

- uint16_t arfcn
- uint8_t band1900
- uint8_t cellIdValid
- uint8_t bsicId
- int16_t rssi
- int16_t srxlev

8.94.1 Detailed Description

This structure contains information about the GSM Cell.

Parameters

arfcn	• GSM frequency being reported. • Range: 0 to 1023.
band1900	• Band indicator for the GSM ARFCN • This field is only valid if arfcn is in the overlapping region. • If TRUE and the cell is in the overlapping region, the ARFCN is on the 1900 band. • If FALSE, it is on the 1800 band.
cellIdValid	• Flag indicating whether the base station identity code ID is valid.
bsicId	• Base station identity code ID, including base station color code and network color code. • The lower 6 bits can be set to any value.
rssi	• Measured RSSI value in 1/10 dB. • Range: -200.0 dB to 0
srxlev	• Cell selection Rx level (Srxlev) value. • Range: -128 to 128. • This field is only valid when ue_in_idle is TRUE.

8.94.2 Field Documentation

8.94.2.1 uint16_t nas_gsmCellInfo::arfcn

8.94.2.2 uint8_t nas_gsmCellInfo::band1900

8.94.2.3 uint8_t nas_gsmCellInfo::bsicId

8.94.2.4 uint8_t nas_gsmCellInfo::cellIdValid

8.94.2.5 int16_t nas_gsmCellInfo::rssi

8.94.2.6 int16_t nas_gsmCellInfo::srxlev

8.95 nas_GSMRSSIThresh Struct Reference

Data Fields

- uint8_t GSMRSSIThreshListLen
- int16_t * pGSMRSSIThreshList

8.95.1 Detailed Description

This structure contains GSM RSSI threshold related parameters.

Parameters

GSMRSSI-ThreshListLen	• Length of the GSM RSSI threshold list parameter to follow
pGSMRSSI-ThreshList	• Array of RSSI thresholds (in units of 0.1 dBm) • Maximum of 32 values • Range for RSSI values: -111 to -48 (in dBm)

8.95.2 Field Documentation

8.95.2.1 uint8_t nas_GSMRSSIThresh::GSMRSSIThreshListLen

8.95.2.2 int16_t* nas_GSMRSSIThresh::pGSMRSSIThreshList

8.96 nas_GSMSrvStatusInfo Struct Reference

Data Fields

- uint8_t srvStatus
- uint8_t trueSrvStatus
- uint8_t isPrefDataPath

8.96.1 Detailed Description

Structure for storing the service status information for GSM, WCDMA and LTE networks.

Parameters

srvStatus	• Service status of the system. – 0x00 - No service – 0x01 - Limited service – 0x02 - Service – 0x03 - Limited regional service – 0x04 - Power save – 0xFF - Not Available
trueSrvStatus	• True service status of the system. • Not applicable to CDMA/HDR. – 0x00 - No service – 0x01 - Limited service – 0x02 - Service – 0x03 - Limited regional service – 0x04 - Power save – 0xFF - Not Available
isPrefDataPath	• Whether the RAT is the preferred data path. – 0x00 - Not preferred – 0x01 - Preferred – 0xFF - Not Available

8.96.2 Field Documentation

8.96.2.1 uint8_t nas_GSMSrvStatusInfo::isPrefDataPath

8.96.2.2 uint8_t nas_GSMSrvStatusInfo::srvStatus

8.96.2.3 uint8_t nas_GSMSrvStatusInfo::trueSrvStatus

8.97 nas_GSMSysInfo Struct Reference

Data Fields

- nas_sysInfoCommon sysInfoGSM
- uint8_t lacValid
- uint16_t lac
- uint8_t cellIdValid
- uint32_t cellId
- uint8_t regRejectInfoValid
- uint8_t rejectSrvDomain
- uint8_t rejCause
- uint8_t networkIdValid
- uint8_t MCC [3]
- uint8_t MNC [3]
- uint8_t egprsSuppValid
- uint8_t egprsSupp

- uint8_t dtmSuppValid
- uint8_t dtmSupp

8.97.1 Detailed Description

Structure for storing the GSM System Information.

Parameters

sysInfoGSM	• See nas_sysInfoCommon for more information.
lacValid	• Indicates whether the location area code is valid.. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
lac	• Location area code. • Only applies to 3GPP. – 0xFFFF - Not Available
cellIdValid	• Indicates whether the cell ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
cellId	• Cell ID. – 0xFFFFFFFF - Not Available
regRejectInfo-Valid	• Indicates whether the registration reject information is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
rejectSrvDomain	• Type of service domain in which the registration is rejected. – 0x00 - SYS_SRV_DOMAIN_NO_SRV - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - Camped – 0xFF - Not Available
rejCause	• Reject cause values sent are specified in [3GPP TS 24.008, Section 10.5.3.6 and 10.5.5.14] – 0xFF - Not Available

networkIdValid	• Indicates whether the network ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
MCC[NAS_PLMN_LENGTH]	• Mobile Country Code. • MCC digits in ASCII characters
MNC[NAS_PLMN_LENGTH]	• Mobile Network Code. • MNC digits in ASCII characters • An unused byte is set to 0xFF. • In case of two-digit MNC values, the third (unused) digit is set to 0xFF. For example, 15 (a two-digit MNC) is reported using the byte stream 0x31 0x35 0xFF.
egprsSuppValid	• Indicates whether the EGPRS support is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
egprsSupp	• EGPRS support indication. • Only applicable for GSM. – 0x00 - Not available – 0x01 - Available – 0xFF - Not Available
dtmSuppValid	• Indicates whether Dual Transfer mode support is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
dtmSupp	• Dual Transfer mode support indication. • Only applicable for GSM. – 0x00 - Not available – 0x01 - Available – 0xFF - Not Available

8.97.2 Field Documentation

8.97.2.1 uint32_t nas_GSMSysInfo::cellId

8.97.2.2 uint8_t nas_GSMSysInfo::cellIdValid

8.97.2.3 uint8_t nas_GSMSysInfo::dtmSupp

8.97.2.4 uint8_t nas_GSMSysInfo::dtmSuppValid

8.97.2.5 uint8_t nas_GSMSysInfo::egprsSupp

8.97.2.6 uint8_t nas_GSMSysInfo::egprsSuppValid

8.97.2.7 uint16_t nas_GSMSysInfo::lac

8.97.2.8 uint8_t nas_GSMSysInfo::lacValid

8.97.2.9 uint8_t nas_GSMSysInfo::MCC[3]

8.97.2.10 uint8_t nas_GSMSysInfo::MNC[3]

8.97.2.11 uint8_t nas_GSMSysInfo::networkIdValid

8.97.2.12 uint8_t nas_GSMSysInfo::regRejectInfoValid

8.97.2.13 uint8_t nas_GSMSysInfo::rejCause

8.97.2.14 uint8_t nas_GSMSysInfo::rejectSrvDomain

8.97.2.15 nas_sysInfoCommon nas_GSMSysInfo::sysInfoGSM

8.98 nas_HDRECIOThresh Struct Reference

Data Fields

- uint8_t HDRECIOThreshListLen
- int16_t * pHDRECIOThreshList

8.98.1 Detailed Description

This structure contains HDR ECIO threshold related parameters.

Parameters

HDRECIO-ThreshListLen	• Length of the HDR ECIO threshold list parameter to follow
pHDRECIO-ThreshList	• Array of ECIO thresholds (in units of 0.1 dB) • Maximum of 32 values • Range for ECIO values: -31.5 to 0 (in dB).

8.98.2 Field Documentation

8.98.2.1 uint8_t nas_HDRECIOThresh::HDRECIOThreshListLen

8.98.2.2 int16_t* nas_HDRECIOThresh::pHDRECIOThreshList

8.99 nas_HDRIOThresh Struct Reference

Data Fields

- uint8_t HDRIOThreshListLen
- int16_t * pHDRIOThreshList

8.99.1 Detailed Description

This structure contains HDR IO threshold related parameters.

Parameters

HDRIOThresh-ListLen	• Length of the HDR IO threshold list parameter to follow
pHDRIOThresh-List	• Array of IO thresholds (in units of 0.1 dBm) • Maximum of 32 values • Range for IO values: -128 to -13 (in dBm).

8.99.2 Field Documentation

8.99.2.1 uint8_t nas_HDRIOThresh::HDRIOThreshListLen

8.99.2.2 int16_t* nas_HDRIOThresh::pHDRIOThreshList

8.100 nas_HDRRSSIThresh Struct Reference

Data Fields

- uint8_t HDRRSSIThreshListLen
- int16_t * pHDRRSSIThreshList

8.100.1 Detailed Description

This structure contains HDR RSSI threshold related parameters.

Parameters

HDRRSSI-ThreshListLen	• Length of the HDR RSSI threshold list parameter to follow
pHDRRSSI-ThreshList	• Array of RSSI thresholds (in units of 0.1 dBm) • Maximum of 32 values. • Range for RSSI values: -118 to -13 (in dBm).

8.100.2 Field Documentation

8.100.2.1 uint8_t nas_HDRRSSIThresh::HDRRSSIThreshListLen

8.100.2.2 int16_t* nas_HDRRSSIThresh::pHDRRSSIThreshList

8.101 nas_HDRSINRThresh Struct Reference

Data Fields

- uint8_t HDRSINRThresListLen
- uint8_t * pHDRSINRThresList

8.101.1 Detailed Description

This structure contains HDR SINR threshold list.

Parameters

HDRSINRThresListLen	• Length of the HDR SINR threshold list parameter to follow
pHDRSINRThresList	• Sequence of thresholds delimiting SINR event reporting bands • Every time a new SINR value crosses a threshold value, an event report indication message with the new SINR value is sent to the requesting control point. For this field – SINR is reported only for HDR – Each SINR threshold value is an unsigned 1 byte value – Maximum number of threshold values is 16 – At least one value must be specified

8.101.2 Field Documentation

8.101.2.1 uint8_t nas_HDRSINRThresh::HDRSINRThresListLen

8.101.2.2 uint8_t* nas_HDRSINRThresh::pHDRSINRThresList

8.102 nas_HDRSINRThreshold Struct Reference

Data Fields

- uint8_t HDRSINRThreshListLen
- uint16_t * pHDRSINRThreshList

8.102.1 Detailed Description

This structure contains HDR SINR threshold related parameters.

Parameters

HDRSINRThreshListLen	• Length of the HDR ECIO threshold list parameter to follow

pHDRSINR-ThreshList	• Array of SINR level thresholds (in units of 1) • maximum of 32 values. • Valid levels are 0 to 8 – 0x00 - SINR_LEVEL_0 is -9 dB – 0x01 - SINR_LEVEL_1 is -6 dB – 0x02 - SINR_LEVEL_2 is -4.5 dB – 0x03 - SINR_LEVEL_3 is -3 dB – 0x04 - SINR_LEVEL_4 is -2 dB – 0x05 - SINR_LEVEL_5 is +1 dB – 0x06 - SINR_LEVEL_6 is +3 dB – 0x07 - SINR_LEVEL_7 is +6 dB – 0x08 - SINR_LEVEL_8 is +9 dB

8.102.2 Field Documentation

8.102.2.1 uint8_t nas_HDRSINRThreshold::HDRSINRThreshListLen

8.102.2.2 uint16_t* nas_HDRSINRThreshold::pHDRSINRThreshList

8.103 nas_HDRSysInfo Struct Reference

Data Fields

- nas_sysInfoCommon sysInfoHDR
- uint8_t isSysPrlMatchValid
- uint8_t isSysPrlMatch
- uint8_t hdrPersonalityValid
- uint8_t hdrPersonality
- uint8_t hdrActiveProtValid
- uint8_t hdrActiveProt
- uint8_t is856SysIdValid
- uint8_t is856SysId [16]

8.103.1 Detailed Description

Structure for storing the HDR System Information.

Parameters

sysInfoHDR	• See nas_sysInfoCommon for more information.
isSysPrlMatch-Valid	• Indicates whether the system PRL match is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available

isSysPrlMatch	• Indicates whether the system is in a PRL. • Only applies to CDMA/HDR. – 0x00 - System is not in a PRL – 0x01 - System is in a PRL – 0xFF - Not Available • If the system is not in a PRL, roam_status carries the value from the default roaming indicator in the PRL. • If the system is in a PRL, roam_status is set to the value based on the standard specification.
hdrPersonality-Valid	• Indicates whether the HDR personality is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
hdrPersonality	• HDR personality information. • Only applicable for HDR. – 0x00 - None – 0x02 - HRPD – 0x03 - eHRPD – 0xFF - Not Available
hdrActiveProt-Valid	• Indicates whether the HDR active protocol revision information is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
hdrActiveProt	• HDR active protocol revision information . • Only applicable for HDR. – 0x00 - None – 0x02 - HDR Rel 0 – 0x03 - HDR Rel A – 0x04 - HDR Rel B – 0xFF - Not Available
is856SysIdValid	• Indicates whether the IS-856 system ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
is856SysId[SLQ-S_SYSTEM_ID-_SIZE]	• IS-856 system ID. • Only applicable for HDR.

8.103.2 Field Documentation

8.103.2.1 uint8_t nas_HDRSysInfo::hdrActiveProt

8.103.2.2 uint8_t nas_HDRSysInfo::hdrActiveProtValid

8.103.2.3 uint8_t nas_HDRSysInfo::hdrPersonality

8.103.2.4 uint8_t nas_HDRSysInfo::hdrPersonalityValid

8.103.2.5 uint8_t nas_HDRSysInfo::is856SysId[16]

8.103.2.6 uint8_t nas_HDRSysInfo::is856SysIdValid

8.103.2.7 uint8_t nas_HDRSysInfo::isSysPrlMatch

8.103.2.8 uint8_t nas_HDRSysInfo::isSysPrlMatchValid

8.103.2.9 nas_sysInfoCommon nas_HDRSysInfo::sysInfoHDR

8.104 nas_homeSIDNID Struct Reference

Data Fields

- uint8_t numInstances
- nas_sidNid SidNid [255]

8.104.1 Detailed Description

This structure contains Home SID/NID

Parameters

numInstances	• Number of sets of the following elements: – sid – nid • If zero(0), then no information follows.
SidNid	• See nas_sidNid for more information

8.104.2 Field Documentation

8.104.2.1 uint8_t nas_homeSIDNID::numInstances

8.104.2.2 nas_sidNid nas_homeSIDNID::SidNid[255]

8.105 nas_infoInterFreq Struct Reference

Data Fields

- uint16_t earfcn
- uint8_t threshXLow
- uint8_t threshXHigh
- uint8_t cell_resel_priority
- uint8_t cells_len
- nas_cellParams cellInterFreqParams [255]

8.105.1 Detailed Description

This structure contains information about the inter-frequency.

Parameters

earfcn	• E-UTRA absolute radio frequency channel number of the serving cell. • Range: 0 to 65535.
threshXLow	• Cell Srxlev low threshold. • Range: 0 to 31. • When the serving cell does not exceed thresh_serving_low, the value of an evaluated cell must be smaller than this value to be considered for re-selection.
threshXHigh	• Cell Srxlev high threshold. • Range: 0 to 31. • When the serving cell exceeds thresh_serving_low, the value of an evaluated cell must be greater than this value to be considered for re-selection.
cell_resel_priority	• Cell re-selection priority • Range: 0 to 7. • This field is only valid when ue_in_idle is TRUE.
cells_len	• Provides the number of set of cell params.
cellInterFreqParams[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_cellParams for more information.

8.105.2 Field Documentation

8.105.2.1 uint8_t nas_infoInterFreq::cell_resel_priority

8.105.2.2 nas_cellParams nas_infoInterFreq::cellInterFreqParams[255]

8.105.2.3 uint8_t nas_infoInterFreq::cells_len

8.105.2.4 uint16_t nas_infoInterFreq::earfcn

8.105.2.5 uint8_t nas_infoInterFreq::threshXHigh

8.105.2.6 uint8_t nas_infoInterFreq::threshXLow

8.106 nas_IOThresh Struct Reference

Data Fields

- uint8_t IOThresListLen
- int32_t * pIOThresList

8.106.1 Detailed Description

This structure contains IO threshold list.

Parameters

IOThresListLen	• Length of the IO threshold list parameter to follow
pIOThresList	• Sequence of thresholds delimiting IO event reporting bands • Every time a new IO value crosses a threshold value, an event report indication message with the new IO value is sent to the requesting control point. For this field – IO is applicable only for HDR – Each IO threshold value is a signed 4 byte value – Maximum number of threshold values is 16 – At least one value must be specified

8.106.2 Field Documentation

8.106.2.1 uint8_t nas_IOThresh::IOThresListLen

8.106.2.2 int32_t* nas_IOThresh::pIOThresList

8.107 nas_lteEARFCN Struct Reference

Data Fields

- uint8_t status
- uint32_t earfcn0
- uint32_t earfcn1

8.107.1 Detailed Description

This structure contains LTE EARFCN infromation.

Parameters

status	• 0 - Disable • 1 - Enable
earfcn0	• Primary DL EARFCN to which the UE is locked
earfcn1	• Secondary DL EARFCN to which the UE is locked • Note : Make earfcn1 value equal to earfcn0 if only one EARFCN is desired.

8.107.2 Field Documentation

8.107.2.1 uint32_t nas_lteEARFCN::earfcn0

8.107.2.2 uint32_t nas_lteEARFCN::earfcn1

8.107.2.3 uint8_t nas_lteEARFCN::status

8.108 nas_lteGsmCellInfo Struct Reference

Data Fields

- uint8_t cellReselPriority
- uint8_t threshGsmHigh
- uint8_t threshGsmLow
- uint8_t nccPermitted
- uint8_t cells_len
- nas_gsmCellInfo GsmCellInfo [255]

8.108.1 Detailed Description

This structure contains information about the LTE GSM Cell.

Parameters

cellReselPriority	• Priority of this frequency group. • Range: 0 to 7. • This field is only valid when ue_in_idle is TRUE.
threshGsmHigh	• Reselection threshold for high priority layers. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE.
threshGsmLow	• Reselection threshold for low priority layers. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE.

nccPermitted	• Bitmask specifying whether a neighbor with a specific network color code is to be reported. • Range: 0 to 255. • Bit n set to 1 means a neighbor with NCC n must be included in the report. This flag is synonymous with a blacklist in other RATs. • This field is only valid when ue_in_idle is TRUE.
cells_len	• Provides the number of set of gsm cells.
GsmCellInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_gsmCellInfo for more information.

8.108.2 Field Documentation

8.108.2.1 uint8_t nas_lteGsmCellInfo::cellReselPriority

8.108.2.2 uint8_t nas_lteGsmCellInfo::cells_len

8.108.2.3 nas_gsmCellInfo nas_lteGsmCellInfo::GsmCellInfo[255]

8.108.2.4 uint8_t nas_lteGsmCellInfo::nccPermitted

8.108.2.5 uint8_t nas_lteGsmCellInfo::threshGsmHigh

8.108.2.6 uint8_t nas_lteGsmCellInfo::threshGsmLow

8.109 nas_LTEInfo Struct Reference

Data Fields

- uint8_t band
- uint8_t bandwidth
- uint16_t RXChan
- uint16_t TXChan
- uint8_t emmState
- uint8_t emmSubState
- uint8_t emmConnState

8.109.1 Detailed Description

Structure for storing the LTE information for the device.

Parameters

band	• LTE Band – 1 ∼ 40 (Band in decimal) – 0xFF - Invalid

bandwidth	• BandWidth. – 0x00 - 1.4 MHz – 0x01 - 3 MHz – 0x02 - 5 MHz – 0x03 - 10 MHz – 0x04 - 15 MHz – 0x05 - 20 MHz – 0x06 - Invalid – 0xFF - Unknown
RXChan	• RX channel number in decimal – 0xFFFF - Not Available
TXChan	• TX channel number in decimal – 0xFFFF - Not Available
emmState	• EMM State. – 0x00 - Deregistered – 0x01 - Reg Initiated – 0x02 - Registered – 0x03 - TAU Initiated – 0x04 - SR Initiated – 0x05 - Dereg Initiated – 0x06 - Invalid – 0xFF - Unknown

emmSubState	• EMM Sub State. – 0xFF - NOT Applicable • When EMM_state is 0x00: – 0x00 - No IMSI – 0x01 - PLMN Search – 0x02 - Attach Needed – 0x03 - No Cell – 0x04 - Attaching – 0x05 - Normal Service – 0x06 - Limited Service – 0x07 - Waiting for PDN • When EMM_state is 0x01: – 0x00 - Waiting for NW – 0x01 - Waiting for ESM • When EMM_state is 0x02: – 0x00 - Normal Service – 0x01 - Update Needed – 0x02 - Attempt Update – 0x03 - No Cell – 0x04 - PLMN Search – 0x05 - Limited Service – 0x06 - MM Update – 0x07 - IMSI Detach – 0x08 - Waiting for ESM
emmConnState	• EMM Connected Mode State. – 0x00 - RRC Idle – 0x01 - Waiting RRC Cfm – 0x02 - RRC Connected – 0x03 - RRC Releasing – 0xFF - Unknown

8.109.2 Field Documentation

8.109.2.1 uint8_t nas_LTEInfo::band

8.109.2.2 uint8_t nas_LTEInfo::bandwidth

8.109.2.3 uint8_t nas_LTEInfo::emmConnState

8.109.2.4 uint8_t nas_LTEInfo::emmState

8.109.2.5 uint8_t nas_LTEInfo::emmSubState

8.109.2.6 uint16_t nas_LTEInfo::RXChan

8.109.2.7 uint16_t nas_LTEInfo::TXChan

8.110 nas_LTEInfoInterfreq Struct Reference

Data Fields

- uint8_t ueInIdle
- uint8_t freqsLen
- nas_infoInterFreq InfoInterfreq [255]

8.110.1 Detailed Description

This structure contains information about the LTE Inter-Frequency Network.

Parameters

ueInIdle	• TRUE if the UE is in Idle mode, otherwise FALSE. – 0xFF - Not Available
freqsLen	• Provides the number of set of inter frequency information. • If 0(zero), then no information follows it.
InfoInterfreq[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_infoInterFreq for more information.

8.110.2 Field Documentation

8.110.2.1 uint8_t nas_LTEInfoInterfreq::freqsLen

8.110.2.2 nas_infoInterFreq nas_LTEInfoInterfreq::InfoInterfreq[255]

8.110.2.3 uint8_t nas_LTEInfoInterfreq::ueInIdle

8.111 nas_LTEInfoIntrafreq Struct Reference

Data Fields

- uint8_t ueInIdle
- uint8_t plmn [3]
- uint16_t tac
- uint32_t globalCellId
- uint16_t earfcn
- uint16_t servingCellId
- uint8_t cellReselPriority
- uint8_t sNonIntraSearch
- uint8_t threshServingLow
- uint8_t sIntraSearch
- uint8_t cellsLen
- nas_cellParams CellParams [255]

8.111.1 Detailed Description

This structure contains information about the LTE Intra-Frequency Network.

Parameters

ueInIdle	• TRUE if the UE is in Idle mode, otherwise FALSE. – 0xFF - Not Available
plmn[NAS_PLMN_LENGTH]	• PLMN ID coded as octet 3, 4, and 5.
tac	• Tracking area code. – 0xFFFF - Not Available
globalCellId	• Global cell ID in the system information block. – 0xFFFFFFFF - Not Available
earfcn	• E-UTRA absolute radio frequency channel number of the serving cell. • Range: 0 to 65535. – 0xFFFF - Not Available
servingCellId	• LTE serving cell ID. • Range: 0 to 503. • This is the cell ID of the serving cell and can be found in the cell list. – 0xFFFF - Not Available
cellReselPriority	• Priority for serving frequency. • Range: 0 to 7. • This field is only valid when ue_in_idle is TRUE. – 0xFF - Not Available
sNonIntraSearch	• S non-intra search threshold to control non-intrafrequency searches. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE. – 0xFF - Not Available
threshServingLow	• Serving cell low threshold. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE. – 0xFF - Not Available

sIntraSearch	• S Intra search threshold. • Range: 0 to 31. • The current cell measurement must fall below this threshold to consider intrafrequency for reselection. • This field is only valid when ue_in_idle is TRUE. – 0xFF - Not Available
cellsLen	• Provides the number of set of cell params. • If 0(zero), then no information follows it.
CellParams[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_cellParams for more information.

8.111.2 Field Documentation

8.111.2.1 nas_cellParams nas_LTEInfoIntrafreq::CellParams[255]

8.111.2.2 uint8_t nas_LTEInfoIntrafreq::cellReselPriority

8.111.2.3 uint8_t nas_LTEInfoIntrafreq::cellsLen

8.111.2.4 uint16_t nas_LTEInfoIntrafreq::earfcn

8.111.2.5 uint32_t nas_LTEInfoIntrafreq::globalCellId

8.111.2.6 uint8_t nas_LTEInfoIntrafreq::plmn[3]

8.111.2.7 uint16_t nas_LTEInfoIntrafreq::servingCellId

8.111.2.8 uint8_t nas_LTEInfoIntrafreq::sIntraSearch

8.111.2.9 uint8_t nas_LTEInfoIntrafreq::sNonIntraSearch

8.111.2.10 uint16_t nas_LTEInfoIntrafreq::tac

8.111.2.11 uint8_t nas_LTEInfoIntrafreq::threshServingLow

8.111.2.12 uint8_t nas_LTEInfoIntrafreq::ueInIdle

8.112 nas_LTEInfoNeighboringGSM Struct Reference

Data Fields

- uint8_t ueInIdle
- uint8_t freqsLen
- nas_lteGsmCellInfo LteGsmCellInfo [255]

8.112.1 Detailed Description

This structure contains information about the LTE Neighboring GSM Network.

Parameters

ueInIdle	• TRUE if the UE is in Idle mode, otherwise FALSE. – 0xFF - Not Available
freqsLen	• Provides the number of set of LTE GSM cell information. • If 0(zero), then no information follows it.
LteGsmCellInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_lteGsmCellInfo for more information.

8.112.2 Field Documentation

8.112.2.1 uint8_t nas_LTEInfoNeighboringGSM::freqsLen

8.112.2.2 nas_lteGsmCellInfo nas_LTEInfoNeighboringGSM::LteGsmCellInfo[255]

8.112.2.3 uint8_t nas_LTEInfoNeighboringGSM::ueInIdle

8.113 nas_LTEInfoNeighboringWCDMA Struct Reference

Data Fields

- uint8_t ueInIdle
- uint8_t freqsLen
- nas_lteWcdmaCellInfo LTEWCDMACellInfo [255]

8.113.1 Detailed Description

This structure contains information about the LTE Neighboring WCDMA Network.

Parameters

ueInIdle	• TRUE if the UE is in Idle mode, otherwise FALSE. – 0xFF - Not Available
freqsLen	• Provides the number of set of LTE WCDMA cell information. • If 0(zero), then no information follows it.
LTEWCDMACellInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_lteWcdmaCellInfo for more information.

8.113.2 Field Documentation

8.113.2.1 uint8_t nas_LTEInfoNeighboringWCDMA::freqsLen

8.113.2.2 nas_lteWcdmaCellInfo nas_LTEInfoNeighboringWCDMA::LTEWCDMACellInfo[255]

8.113.2.3 uint8_t nas_LTEInfoNeighboringWCDMA::ueInIdle

8.114 nas_ltePCI Struct Reference

Data Fields

- uint8_t status
- uint32_t earfcn
- uint32_t pci

8.114.1 Detailed Description

This structure contains LTE PCI infromation.

Parameters

status	• 0 - Disable • 1 - Enable
earfcn	• UARFCN to which UE is locked
pci	• PCI to which the UE is locked

8.114.2 Field Documentation

8.114.2.1 uint32_t nas_ltePCI::earfcn

8.114.2.2 uint32_t nas_ltePCI::pci

8.114.2.3 uint8_t nas_ltePCI::status

8.115 nas_lteRsrpinformation Struct Reference

Data Fields

- int16_t rsrplevel

8.115.1 Detailed Description

This structure contains the LTE RSRP Information

Parameters

rsrplevel	• LTE RSRP in dBm as a mesaured by L1. Range: -44 to -140(-44 means -44dBm, -140 means -140dBm).

8.115.2 Field Documentation

8.115.2.1 int16_t nas_lteRsrpinformation::rsrplevel

8.116 nas_LTERSRPThresh Struct Reference

Data Fields

- uint8_t LTERSRPThreshListLen
- int16_t * pLTERSRPThreshList

8.116.1 Detailed Description

This structure contains LTE RSRP threshold related parameters.

Parameters

LTERSRP-ThreshListLen	• Length of the LTE RSRP threshold list parameter to follow
pLTERSRP-ThreshList	• Array of RSRP thresholds (in units of 0.1 dBm) • Maximum of 32 values • Range for RSRP values: -140 to -44 (in dBm).

8.116.2 Field Documentation

8.116.2.1 uint8_t nas_LTERSRPThresh::LTERSRPThreshListLen

8.116.2.2 int16_t* nas_LTERSRPThresh::pLTERSRPThreshList

8.117 nas_LTERSRQThresh Struct Reference

Data Fields

- uint8_t LTERSRQThreshListLen
- int16_t * pLTERSRQThreshList

8.117.1 Detailed Description

This structure contains LTE RSRQ threshold related parameters.

Parameters

LTERSRQ-ThreshListLen	• Length of the LTE RSRQ threshold list parameter to follow
pLTERSRQ-ThreshList	• Array of RSRQ thresholds (in units of 0.1 dBm) • Maximum of 32 values. • Range for RSRQ values: -20 to -3 (in dBm)

8.117.2 Field Documentation

8.117.2.1 uint8_t nas_LTERSRQThresh::LTERSRQThreshListLen

8.117.2.2 int16_t* nas_LTERSRQThresh::pLTERSRQThreshList

8.118 nas_LTERSSIThresh Struct Reference

Data Fields

- uint8_t LTERSSIThreshListLen
- int16_t * pLTERSSIThreshList

8.118.1 Detailed Description

This structure contains LTE RSSI threshold related parameters.

Parameters

LTERSSI-ThreshListLen	• Length of the LTE RSSI threshold list parameter to follow
pLTERSSI-ThreshList	• Array of RSSI thresholds (in units of 0.1 dBm) • Maximum of 32 values. • Range for RSSI values: -120 to 0 (in dBm)

8.118.2 Field Documentation

8.118.2.1 uint8_t nas_LTERSSIThresh::LTERSSIThreshListLen

8.118.2.2 int16_t* nas_LTERSSIThresh::pLTERSSIThreshList

8.119 nas_LTESigRptCfg Struct Reference

Data Fields

- uint8_t rptRate
- uint8_t avgPeriod

8.119.1 Detailed Description

This structure contains LTE signal report config.

Parameters

rptRate	• Rate on how often the LTE signal must be checked for reporting • Values: – 0 - Report using the default configuration – 1 - Report every 1 sec – 2 - Report every 2 sec – 3 - Report every 3 sec – 4 - Report every 4 sec – 5 - Report every 5 sec
avgPeriod	• Averaging period to be used for the LTE signal • Values: – 0 - Average using the default configuration – 1 - Average over 1 sec – 2 - Average over 2 sec – 3 - Average over 3 sec – 4 - Average over 4 sec – 5 - Average over 5 sec – 6 - Average over 6 sec – 7 - Average over 7 sec – 8 - Average over 8 sec – 9 - Average over 9 sec – 10 - Average over 10 sec

8.119.2 Field Documentation

8.119.2.1 uint8_t nas_LTESigRptCfg::avgPeriod

8.119.2.2 uint8_t nas_LTESigRptCfg::rptRate

8.120 nas_LTESigRptConfig Struct Reference

Data Fields

- uint8_t rptRate
- uint8_t avgPeriod

8.120.1 Detailed Description

This structure contains LTE RSRP threshold related parameters.

Parameters

rptRate	• Rate on how often the LTE signal must be checked for reporting Values • 0 - Report using the default configuration • 1 - Report every 1 sec • 2 - Report every 2 sec • 3 - Report every 3 sec • 4 - Report every 4 sec • 5 - Report every 5 sec
avgPeriod	• Averaging period to be used for the LTE signal. • Values – 0 - Average using the default configuration – 1 - Average over 1 sec – 2 - Average over 2 sec – 3 - Average over 3 sec – 4 - Average over 4 sec – 5 - Average over 5 sec – 6 - Average over 6 sec – 7 - Average over 7 sec – 8 - Average over 8 sec – 9 - Average over 9 sec – 10 - Average over 10 sec

8.120.2 Field Documentation

8.120.2.1 uint8_t nas_LTESigRptConfig::avgPeriod

8.120.2.2 uint8_t nas_LTESigRptConfig::rptRate

8.121 nas_lteSnrinformation Struct Reference

Data Fields

- int16_t snrlevel

8.121.1 Detailed Description

This structure contains the LTE SNR Information

Parameters

snrlevel	• LTE SNR level as a scaled integer in units of 0.1dB e.g. -16dB has a value of -160 and 24.6dB has value of 246.

8.121.2 Field Documentation

8.121.2.1 int16_t nas_lteSnrinformation::snrlevel

8.122 nas_LTESNRThresh Struct Reference

Data Fields

- uint8_t LTESNRThresListLen
- int16_t * pLTESNRThresList

8.122.1 Detailed Description

This structure contains LTE SNR threshold list.

Parameters

LTESNRThres-ListLen	• Length of the LTE SNR threshold list parameter to follow
pLTESNRThres-List	• Sequence of thresholds delimiting SNR event reporting bands • Every time a SNR value crosses a threshold value, an event report indication message with the new SNR value is sent to the requesting control point. For this field – For LTE, each SNR threshold value is a signed 2 Byte value – Maximum number of threshold values is 16 – At least one value must be specified – SNR level as a scaled integer in units of 0.1 dB; e.g., -16 dB has a value of -160 and 24.6 dB has a value of 246

8.122.2 Field Documentation

8.122.2.1 uint8_t nas_LTESNRThresh::LTESNRThresListLen

8.122.2.2 int16_t* nas_LTESNRThresh::pLTESNRThresList

8.123 nas_LTESNRThreshold Struct Reference

Data Fields

- uint8_t LTESNRThreshListLen
- int16_t * pLTESNRThreshList

8.123.1 Detailed Description

This structure contains LTE SNR threshold related parameters.

Parameters

LTESNRThresh-ListLen	• Length of the LTE SNR threshold list parameter to follow

pLTESNR-ThreshList	• Array of SNR thresholds (in units of 0.1 dB) • Maximum of 32 values • Range for SNR values: -20 to 30 (in dB).

8.123.2 Field Documentation

8.123.2.1 uint8_t nas_LTESNRThreshold::LTESNRThreshListLen

8.123.2.2 int16_t* nas_LTESNRThreshold::pLTESNRThreshList

8.124 nas_LTESysInfo Struct Reference

Data Fields

- nas_sysInfoCommon sysInfoLTE
- uint8_t lacValid
- uint16_t lac
- uint8_t cellIdValid
- uint32_t cellId
- uint8_t regRejectInfoValid
- uint8_t rejectSrvDomain
- uint8_t rejCause
- uint8_t networkIdValid
- uint8_t MCC [3]
- uint8_t MNC [3]
- uint8_t tacValid
- uint16_t tac

8.124.1 Detailed Description

Structure for storing the LTE System Information.

Parameters

sysInfoLTE	• See nas_sysInfoCommon for more information.
lacValid	• Indicates whether the location area code is valid.. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
lac	• Location area code. • Only applies to 3GPP. – 0xFFFF - Not Available

cellIdValid	• Indicates whether the cell ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
cellId	• Cell ID. – 0xFFFFFFFF - Not Available
regRejectInfo-Valid	• Indicates whether the registration reject information is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
rejectSrvDomain	• Type of service domain in which the registration is rejected. – 0x00 - SYS_SRV_DOMAIN_NO_SRV - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - Camped – 0xFF - Not Available
rejCause	• Reject cause values sent are specified in [3GPP TS 24.008, Section 10.5.3.6]. and [3GPP TS 24.301, Section 9.9.3.9] – 0xFF - Not Available
networkIdValid	• Indicates whether the network ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
MCC[NAS_PLM-N_LENGTH]	• Mobile Country Code. • MCC digits in ASCII characters
MNC[NAS_PLM-N_LENGTH]	• Mobile Network Code. • MNC digits in ASCII characters • An unused byte is set to 0xFF. • In case of two-digit MNC values, the third (unused) digit is set to 0xFF. For example, 15 (a two-digit MNC) is reported using the byte stream 0x31 0x35 0xFF.

tacValid	• Indicates whether tracking area code is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
tac	• Tracking area code. • Only applicable for LTE. – 0xFFFF - Not Available

8.124.2 Field Documentation

8.124.2.1 uint32_t nas_LTESysInfo::cellId

8.124.2.2 uint8_t nas_LTESysInfo::cellIdValid

8.124.2.3 uint16_t nas_LTESysInfo::lac

8.124.2.4 uint8_t nas_LTESysInfo::lacValid

8.124.2.5 uint8_t nas_LTESysInfo::MCC[3]

8.124.2.6 uint8_t nas_LTESysInfo::MNC[3]

8.124.2.7 uint8_t nas_LTESysInfo::networkIdValid

8.124.2.8 uint8_t nas_LTESysInfo::regRejectInfoValid

8.124.2.9 uint8_t nas_LTESysInfo::rejCause

8.124.2.10 uint8_t nas_LTESysInfo::rejectSrvDomain

8.124.2.11 nas_sysInfoCommon nas_LTESysInfo::sysInfoLTE

8.124.2.12 uint16_t nas_LTESysInfo::tac

8.124.2.13 uint8_t nas_LTESysInfo::tacValid

8.125 nas_lteWcdmaCellInfo Struct Reference

Data Fields

- uint16_t uarfcn
- uint8_t cellReselPriority
- uint16_t threshXhigh
- uint16_t threshXlow
- uint8_t cellsLen
- nas_wcdmaCellInfo WCDMACellInfo [255]

8.125.1 Detailed Description

This structure contains information about the LTE WCDMA Cell.

Parameters

uarfcn	• WCDMA layer frequency. • Range: 0 to 16383.
cellReselPriority	• Cell re-selection priority. • Range: 0 to 7. • This field is only valid when ue_in_idle is TRUE.
threshXhigh	• Re-selection low threshold. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE.
threshXlow	• Re-selection high threshold. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE.
cellsLen	• Provides the number of set of WCDMA cells.
WCDMACellInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_wcdmaCellInfo for more information.

8.125.2 Field Documentation

8.125.2.1 uint8_t nas_lteWcdmaCellInfo::cellReselPriority

8.125.2.2 uint8_t nas_lteWcdmaCellInfo::cellsLen

8.125.2.3 uint16_t nas_lteWcdmaCellInfo::threshXhigh

8.125.2.4 uint16_t nas_lteWcdmaCellInfo::threshXlow

8.125.2.5 uint16_t nas_lteWcdmaCellInfo::uarfcn

8.125.2.6 nas_wcdmaCellInfo nas_lteWcdmaCellInfo::WCDMACellInfo[255]

8.126 nas_minBasedIMSI Struct Reference

Data Fields

- uint8_t mccM [3]
- uint16_t imsiM1112
- uint8_t imsiMS1 [7]

- uint8_t imsiMS2 [3]

8.126.1 Detailed Description

This structure contains MIN-based IMSI.

Parameters

mccM	• ASCII character representation of MCC_M
imsiM1112	• ASCII character representation of IMSI_M_11_12 value – 0xFFFF - Not Available
imsiMS1	• ASCII character representation of IMSI_M_S1 value
imsiMS2	• ASCII character representation of IMSI_M_S2 value

8.126.2 Field Documentation

8.126.2.1 uint16_t nas_minBasedIMSI::imsiM1112

8.126.2.2 uint8_t nas_minBasedIMSI::imsiMS1[7]

8.126.2.3 uint8_t nas_minBasedIMSI::imsiMS2[3]

8.126.2.4 uint8_t nas_minBasedIMSI::mccM[3]

8.127 nas_MNRInfo Struct Reference

Data Fields

- uint16_t mcc
- uint16_t mnc
- uint32_t rat

8.127.1 Detailed Description

Structure contains Manual Network Register Information parameters

Parameters

mcc	• A 16-bit integer representation of Mobile Country Code. Range - 0 to 999.
mnc	• A 16-bit integer representation of Mobile Network Code. Range - 0 to 999.

rat	• Radio access technology for which to register. – 0x04 - RADIO_IF_GSM – 0x05 - RADIO_IF_UMTS – 0x08 - RADIO_IF_LTE

8.127.2 Field Documentation

8.127.2.1 uint16_t nas_MNRInfo::mcc

8.127.2.2 uint16_t nas_MNRInfo::mnc

8.127.2.3 uint32_t nas_MNRInfo::rat

8.128 nas_namName Struct Reference

Data Fields

- uint8_t namNameLen
- uint8_t namName [12]

8.128.1 Detailed Description

This structure contains NAM Name.

Parameters

namNameLen	• Number of sets of the following elements: – nam_name • If zero(0), then no information follows.
namName	• Name information in ASCII. The maximum length of nam_name is 12.

8.128.2 Field Documentation

8.128.2.1 uint8_t nas_namName::namName[12]

8.128.2.2 uint8_t nas_namName::namNameLen

8.129 nas_netSelectionPref Struct Reference

Data Fields

- uint8_t netReg
- uint16_t mcc
- uint16_t mnc

8.129.1 Detailed Description

Contain the network selection preference.

Parameters

netReg	• specifies one of the following actions: – 0x00 - Automatic registration * Device registers according to its provisioning; mcc and mnc fields are ignored – 0x01 - Manual Registration * Device registers to specified network; mcc and mnc must contain valid values
mcc	• MCC value. Range 0 to 999
mnc	• MNC value. Range 0 to 999

8.129.2 Field Documentation

8.129.2.1 uint16_t nas_netSelectionPref::mcc

8.129.2.2 uint16_t nas_netSelectionPref::mnc

8.129.2.3 uint8_t nas_netSelectionPref::netReg

8.130 nas_NetworkStat1x Struct Reference

Data Fields

- uint8_t State
- uint16_t SO
- uint32_t RX_PWR
- uint16_t RX_EC_IO
- uint32_t TX_PWR
- uint8_t ActSetCnt
- nas_ActPilotPNElement * pActPilotPNElements
- uint8_t NeighborSetCnt
- uint16_t * pNeighborSetPilotPN

8.130.1 Detailed Description

This structure contains network stat 1x.

Parameters

State	• CDMA current access state – 0x01 - Searching – 0x02 - Idle – 0x03 - Traffic – Others - NA

SO	• CDMA service option – 0xFFFF - Not in a call – 0x0001 - Basic Variable Rate Voice Service(8kbps) – 0x0002 - Mobile Station Loopback(8kbps) – 0x0003 - Enhanced Variable Rate Codec(EVRC) Voice Service(8kbps) – 0x0006 - Short message Services(Rate Set 1) – 0x0009 - Mobile Station Loopback(13kbps) – 0x000E - Short Message Service (Rate Set 2) – 0x0011 - High Rate Voice Service(13kbps) – 0x0020 - Test Data Service Option(TDSO) – 0x0021 - cdma2000 High Speed Packet Data Service, Internet or ISO Protocol Stack – 0x0044 - EVRC-B Voice Service(8 kbps) – 0x0046 - EVRC-WB Voice Service(8 kbps) – 0x0049 - Voice Echo mode supports smart blanking(EVRC-NW) – 0x004B - Enhanced loopback – 0x8000 - Proprietary Service Option (Qualcomm Inc.)
RX_PWR	• RX Pwr(dBm) – 0xABCD00EF - -ABCD.EF dBm – ABCD00EF should be transferred to decimal while displaying – Example: 0x12340056 - -4660.86dBm 0x1234 = 4660, 0x0056 = 86 – 0xFFFFFFFF - NA
RX_EC_IO	• RX EC/IO(dB) – 0xABCD - -AB.CD dB – ABCD should be transferred to decimal while displaying – Example: 0x1234 - -18.52dB 0x12 = 18, 0x34 = 52 – 0xFFFF - NA
TX_PWR	• TX PWR(dBm) – 0xFFFFFFFF - NA – Others - display actual value in decimal – Example: 0x1234 - -4660dBm 0x1234 = 4660
ActSetCnt	• Count of active pilot PN elements • As input specifies number of sets of parameter pActPilotElements for which memory has been assigned • As output specifies the actual number of sets of parameter pActPilotElements returned by device
pActPilotPN-Elements	• See nas_ActPilotPNElement for more information

NeighborSetCnt	• Count of neighbor pilot PN elements • As input specifies number of sets of parameter pNeighborSetPilotPN for which memory has been assigned • As output specifies the actual number of sets of parameter pNeighborSetPilotPN returned by device
pNeighborSet-PilotPN	• Neighbor pilot PN

8.130.2 Field Documentation

8.130.2.1 uint8_t nas_NetworkStat1x::ActSetCnt

8.130.2.2 uint8_t nas_NetworkStat1x::NeighborSetCnt

8.130.2.3 nas_ActPilotPNElement* nas_NetworkStat1x::pActPilotPNElements

8.130.2.4 uint16_t* nas_NetworkStat1x::pNeighborSetPilotPN

8.130.2.5 uint16_t nas_NetworkStat1x::RX_EC_IO

8.130.2.6 uint32_t nas_NetworkStat1x::RX_PWR

8.130.2.7 uint16_t nas_NetworkStat1x::SO

8.130.2.8 uint8_t nas_NetworkStat1x::State

8.130.2.9 uint32_t nas_NetworkStat1x::TX_PWR

8.131 nas_NetworkStatEVDO Struct Reference

Data Fields

- uint8_t State
- uint8_t MACIndex
- uint8_t SectorIDLen
- uint16_t * pSectorID
- uint16_t RX_PWR
- uint16_t PER
- uint16_t PilotEnergy
- uint8_t SNR

8.131.1 Detailed Description

This structure contains network stat EVDO.

Parameters

State	• EVDO network access state – 0x00 - Sleep – 0x01 - Searching – 0x02 - Idle – 0x03 - Active – 0xFF - NA
MACIndex	• HDR Mac index – 0xFF - NA – Others - Display the actual value in decimal – Example: 0x12 - 18 0x12 = 18
SectorIDLen	(IN/OUT) • Sector ID length • As input specifies length of parameter pSectorID for which memory has been assigned • As output specifies the actual length of parameter pSectorID returned by device
pSectorID	• Sector ID
RX_PWR	• TX PWR(dBm) – 0xABCD - -ABCD dBm – ABCD should be transferred to decimal while displaying – Example: 0x1234 - -4660dBm 0x1234 = 4660 – 0xFFFF - NA
PER	• HDR Packet Error Rate – 0xFFFF - Unknown – Others - display the actual value in decimal – Example: 0x1234 - -4660dBm 0x1234 = 4660
PilotEnergy	• Pilt Energy (dB) – 0xFFFF - NA – 0xABCD should be transferred to decimal while displaying – Example: 0x1234 - -4660dBm 0x1234 = 4660
SNR	• Signal to Noise ratio (dB)

8.131.2 Field Documentation

8.131.2.1 uint8_t nas_NetworkStatEVDO::MACIndex

8.131.2.2 uint16_t nas_NetworkStatEVDO::PER

8.131.2.3 uint16_t nas_NetworkStatEVDO::PilotEnergy

8.131.2.4 uint16_t* nas_NetworkStatEVDO::pSectorID

8.131.2.5 uint16_t nas_NetworkStatEVDO::RX_PWR

8.131.2.6 uint8_t nas_NetworkStatEVDO::SectorIDLen

8.131.2.7 uint8_t nas_NetworkStatEVDO::SNR

8.131.2.8 uint8_t nas_NetworkStatEVDO::State

8.132 nas_nmrCellInfo Struct Reference

Data Fields

- uint32_t nmrCellID
- uint8_t nmrPlmn [3]
- uint16_t nmrLac
- uint16_t nmrArfcn
- uint8_t nmrBsic
- uint16_t nmrRxLev

8.132.1 Detailed Description

This structure contains information about the Network Measurement Report (NMR) Cell Information.

Parameters

nmrCellID	• Cell ID. • 0xFFFFFFFF indicates cell ID information is not present.
nmrPlmn[NAS_PLMN_LENGTH]	• MCC/MNC information coded as octet 3, 4, and 5. • This field is ignored when nmrCellID is not present.
nmrLac	• Location area code. • This field is ignored when nmrCellID is not present. – 0xFFFF - Not Available
nmrArfcn	• Absolute RF channel number. – 0xFFFF - Not Available
nmrBsic	• Base station identity code. – 0xFF - Not Available

nmrRxLev	• Cell Rx measurement. • Values range between 0 and 63. • Mapped to a measured signal level: – Rxlev 0 is a signal strength less than -110 dBm – Rxlev 1 is -110 dBm to -109 dBm – Rxlev 2 is -109 dBm to -108 dBm – ... – Rxlev 62 is -49 dBm to -48 dBm – Rxlev 63 is greater than -48 dBm – 0xFFFF - Not Available

8.132.2 Field Documentation

8.132.2.1 uint16_t nas_nmrCellInfo::nmrArfcn

8.132.2.2 uint8_t nas_nmrCellInfo::nmrBsic

8.132.2.3 uint32_t nas_nmrCellInfo::nmrCellID

8.132.2.4 uint16_t nas_nmrCellInfo::nmrLac

8.132.2.5 uint8_t nas_nmrCellInfo::nmrPlmn[3]

8.132.2.6 uint16_t nas_nmrCellInfo::nmrRxLev

8.133 nas_operatorNameString Struct Reference

Data Fields

- uint8_t PLMNName [255]

8.133.1 Detailed Description

This structure contains PLMN name.

Parameters

PLMNName	• PLMN name must be coded in a default 7-bit alphabet with b8 set to 0.

8.133.2 Field Documentation

8.133.2.1 uint8_t nas_operatorNameString::PLMNName[255]

8.134 nas_OperatorPLMNData Struct Reference

Data Fields

- uint8_t mcc [3]
- uint8_t mnc [3]
- uint16_t lac1
- uint16_t lac2
- uint8_t PLMNRecID

8.134.1 Detailed Description

This structure contains Operator PLMN.

Parameters

mcc	• MCC in ASCII string (a value of D in any of the digits is to be used to indicate a "wild" value for that corresponding digit).
mnc	• MNC in ASCII string (a value of D in any of the digits is to be used to indicate a "wild" value for that corresponding digit; digit 3 in MNC is optional and when not present, will be set as ASCII F).
lac1	• Location area code 1.
lac2	• Location area code 1.
PLMNRecID	• PLMN network name record identifier.

8.134.2 Field Documentation

8.134.2.1 uint16_t nas_OperatorPLMNData::lac1

8.134.2.2 uint16_t nas_OperatorPLMNData::lac2

8.134.2.3 uint8_t nas_OperatorPLMNData::mcc[3]

8.134.2.4 uint8_t nas_OperatorPLMNData::mnc[3]

8.134.2.5 uint8_t nas_OperatorPLMNData::PLMNRecID

8.135 nas_operatorPLMNList Struct Reference

Data Fields

- uint16_t numInstance
- nas_OperatorPLMNData PLMNData [255]

8.135.1 Detailed Description

This structure contains Operator PLMN List.

Parameters

numInstance	• Number of sets of the elements.
PLMNData	• Refer OperatorPLMNLData for details (Optional).

8.135.2 Field Documentation

8.135.2.1 uint16_t nas_operatorPLMNList::numInstance

8.135.2.2 nas_OperatorPLMNData nas_operatorPLMNList::PLMNData[255]

8.136 nas_PhyCaAggPcellInfo Struct Reference

Data Fields

- uint16_t pci
- uint16_t freq
- NAS_LTE_CPHY_CA_BW_NRB_LITE dl_bw_value
- uint16_t iLTEbandValue
- uint8_t TlvPresent

8.136.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Pcell Information.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
dl_bw_value	• Downlink Bandwidth Values. • See NAS_LTE_CPHY_CA_BW_NRB_LITE for more information.
scell_state	• Scell state Values. • See NAS_LTE_CPHY_SCELL_STATE_LITE for more information.
TlvPresent	• Tlv Present.

8.136.2 Field Documentation

8.136.2.1 NAS_LTE_CPHY_CA_BW_NRB_LITE nas_PhyCaAggPcellInfo::dl_bw_value

8.136.2.2 uint16_t nas_PhyCaAggPcellInfo::freq

8.136.2.3 uint16_t nas_PhyCaAggPcellInfo::iLTEbandValue

8.136.2.4 uint16_t nas_PhyCaAggPcellInfo::pci

8.136.2.5 uint8_t nas_PhyCaAggPcellInfo::TlvPresent

8.137 nas_PhyCaAggScellDlBw Struct Reference

Data Fields

- NAS_LTE_CPHY_CA_BW_NRB_LITE dl_bw_value
- uint8_t TlvPresent

8.137.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation Downlink Bandwidth of Scell.

Parameters

dl_bw_value	• Downlink Bandwidth Values. • See NAS_LTE_CPHY_CA_BW_NRB_LITE for more information.

8.137.2 Field Documentation

8.137.2.1 NAS_LTE_CPHY_CA_BW_NRB_LITE nas_PhyCaAggScellDlBw::dl_bw_value

8.137.2.2 uint8_t nas_PhyCaAggScellDlBw::TlvPresent

8.138 nas_PhyCaAggScellIndex Struct Reference

Data Fields

- uint8_t scell_idx
- uint8_t TlvPresent

8.138.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Index.

Parameters

scell_idx	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.

TlvPresent	• Tlv Present.

8.138.2 Field Documentation

8.138.2.1 uint8_t nas_PhyCaAggScellIndex::scell_idx

8.138.2.2 uint8_t nas_PhyCaAggScellIndex::TlvPresent

8.139 nas_PhyCaAggScellIndType Struct Reference

Data Fields

- uint16_t pci
- uint16_t freq
- NAS_LTE_CPHY_SCELL_STATE_LITE scell_state
- uint8_t TlvPresent

8.139.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Indicator Type.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
scell_state	• Scell state Values. • See NAS_LTE_CPHY_SCELL_STATE_LITE for more information.
TlvPresent	• Tlv Present.

8.139.2 Field Documentation

8.139.2.1 uint16_t nas_PhyCaAggScellIndType::freq

8.139.2.2 uint16_t nas_PhyCaAggScellIndType::pci

8.139.2.3 NAS_LTE_CPHY_SCELL_STATE_LITE nas_PhyCaAggScellIndType::scell_state

8.139.2.4 uint8_t nas_PhyCaAggScellIndType::TlvPresent

8.140 nas_PhyCaAggScellInfo Struct Reference

Data Fields

- uint16_t pci
- uint16_t freq
- NAS_LTE_CPHY_CA_BW_NRB_LITE dl_bw_value
- uint16_t iLTEbandValue
- NAS_LTE_CPHY_SCELL_STATE_LITE scell_state
- uint8_t TlvPresent

8.140.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Information.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
dl_bw_value	• Downlink Bandwidth Values. • See NAS_LTE_CPHY_CA_BW_NRB_LITE for more information.

iLTEbandValue	• Band value. • Range for LTE Band class 120 to 160. – 120 - LTE E-UTRA Operating Band 1 – 121 - LTE E-UTRA Operating Band 2 – 122 - LTE E-UTRA Operating Band 3 – 123 - LTE E-UTRA Operating Band 4 – 124 - LTE E-UTRA Operating Band 5 – 125 - LTE E-UTRA Operating Band 6 – 126 - LTE E-UTRA Operating Band 7 – 127 - LTE E-UTRA Operating Band 8 – 128 - LTE E-UTRA Operating Band 9 – 129 - LTE E-UTRA Operating Band 10 – 130 - LTE E-UTRA Operating Band 11 – 131 - LTE E-UTRA Operating Band 12 – 132 - LTE E-UTRA Operating Band 13 – 133 - LTE E-UTRA Operating Band 14 – 134 - LTE E-UTRA Operating Band 17 – 135 - LTE E-UTRA Operating Band 33 – 136 - LTE E-UTRA Operating Band 34 – 137 - LTE E-UTRA Operating Band 35 – 138 - LTE E-UTRA Operating Band 36 – 139 - LTE E-UTRA Operating Band 37 – 140 - LTE E-UTRA Operating Band 38 – 141 - LTE E-UTRA Operating Band 39 – 142 - LTE E-UTRA Operating Band 40 – 143 - LTE E-UTRA Operating Band 18 – 144 - LTE E-UTRA Operating Band 19 – 145 - LTE E-UTRA Operating Band 20 – 146 - LTE E-UTRA Operating Band 21 – 147 - LTE E-UTRA Operating Band 24 – 148 - LTE E-UTRA Operating Band 25 – 149 - LTE E-UTRA Operating Band 41 – 150 - LTE E-UTRA Operating Band 42 – 151 - LTE E-UTRA Operating Band 43 – 152 - LTE E-UTRA Operating Band 23 – 153 - LTE E-UTRA Operating Band 26 – 154 - LTE E-UTRA Operating Band 32 – 155 - LTE E-UTRA Operating Band 125 – 156 - LTE E-UTRA Operating Band 126 – 157 - LTE E-UTRA Operating Band 127 – 158 - LTE E-UTRA Operating Band 28 – 159 - LTE E-UTRA Operating Band 29 – 160 - LTE E-UTRA Operating Band 30
scell_state	• Scell state Values. • See NAS_LTE_CPHY_SCELL_STATE_LITE for more information.

TlvPresent	• Tlv Present.

8.140.2 Field Documentation

8.140.2.1 NAS_LTE_CPHY_CA_BW_NRB_LITE nas_PhyCaAggScellInfo::dl_bw_value

8.140.2.2 uint16_t nas_PhyCaAggScellInfo::freq

8.140.2.3 uint16_t nas_PhyCaAggScellInfo::iLTEbandValue

8.140.2.4 uint16_t nas_PhyCaAggScellInfo::pci

8.140.2.5 NAS_LTE_CPHY_SCELL_STATE_LITE nas_PhyCaAggScellInfo::scell_state

8.140.2.6 uint8_t nas_PhyCaAggScellInfo::TlvPresent

8.141 nas_PilotSetData Struct Reference

Data Fields

- uint8_t NumPilots
- nas_PilotSetParams * pPilotSetInfo

8.141.1 Detailed Description

This structure contains pilot sets data.

Parameters

NumPilots	• Number of Pilot Sets • As input specifies number of sets of parameter pPilotSetInfo for which memory has been assigned • As output specifies the actual number of sets of parameter pPilotSetInfo returned by device
pPilotSetInfo	• Pilot Set Parameters • See nas_PilotSetParams for more information.

note A buffer under sized error is returned if the number of sets of pPilotSetInfo returned by the device is greater than the value in NumPilots input parameter.

8.141.2 Field Documentation

8.141.2.1 uint8_t nas_PilotSetData::NumPilots

8.141.2.2 nas_PilotSetParams* nas_PilotSetData::pPilotSetInfo

8.142 nas_PilotSetParams Struct Reference

Data Fields

- uint32_t PilotType
- uint16_t PilotPN
- uint16_t PilotStrength

8.142.1 Detailed Description

This structure contains pilot sets parameters.

Parameters

PilotType	• 0x00 - NAS_HRPD_PILOT_CURR_ACT_PLT Current Active Pilot • 0x01 - NAS_HRPD_PILOT_NEIGHBOR_PLT Neighbor pilot information
PilotPN	• Pilot PN sequence offset index
PilotStrength	• Strength of the pilot (in dB)

8.142.2 Field Documentation

8.142.2.1 uint16_t nas_PilotSetParams::PilotPN

8.142.2.2 uint16_t nas_PilotSetParams::PilotStrength

8.142.2.3 uint32_t nas_PilotSetParams::PilotType

8.143 nas_PLMNNetworkName Struct Reference

Data Fields

- uint8_t numInstance
- nas_PLMNNetworkNameData PLMNNetName [255]

8.143.1 Detailed Description

This structure contains NITZ Information list.

Parameters

numInstance	• Number of sets of the elements.
PLMNNetName	• Refer nas_PLMNNetworkNameData for details (Optional).

8.143.2 Field Documentation

8.143.2.1 uint8_t nas_PLMNNetworkName::numInstance

8.143.2.2 nas_PLMNNetworkNameData nas_PLMNNetworkName::PLMNNetName[255]

8.144 nas_PLMNNetworkNameData Struct Reference

Data Fields

- uint8_t codingScheme
- uint8_t countryInitials
- uint8_t longNameSpareBits
- uint8_t shortNameSpareBits
- uint8_t longNameLen
- uint8_t longName [255]
- uint8_t shortNameLen
- uint8_t shortName [255]

8.144.1 Detailed Description

This structure contains NITZ Information.

Parameters

codingScheme	• Coding scheme: – 0 - CODING_SCHEME_CELL_BROADCAST_GSM - Cell broadcast data coding scheme, GSM default alphabet, language unspecified;defined in 3GPP TS 23.038. – 1 - CODING_SCHEME_UCS2 - UCS2 (16 bit);defined in ISO/IEC 10646
countryInitials	• Country's initials: – 0 - COUNTRY_INITIALS_DO_NOT_ADD - MS should not add the letters for the country's initials to the text string. – 1 - COUNTRY_INITIALS_ADD - MS should add the letters for the country's initials and a separator, e.g., a space, to the text string.
longNameSpare-Bits	• Long Name Spare Bits: – 1 - SPARE_BITS_8 - Bit 8 is spare and set to 0 in octet n – 2 - SPARE_BITS_7_TO_8 - Bits 7 and 8 are spare and set to 0 in octet n. – 3 - SPARE_BITS_6_TO_8 - Bits 6 to 8 (inclusive) are spare and set to 0 in octet n. – 4 - SPARE_BITS_5_TO_8 - Bits 5 to 8 (inclusive) are spare and set to 0 in octet n. – 5 - SPARE_BITS_4_TO_8 - Bits 4 to 8 (inclusive) are spare and set to 0 in octet n. – 6 - SPARE_BITS_3_TO_8 - Bits 3 to 8 (inclusive) are spare and set to 0 in octet n. – 7 - SPARE_BITS_2_TO_8 - Bits 2 to 8 (inclusive) are spare and set to 0 in octet n. – 0 - SPARE_BITS_UNKNOWN - Carries no information about the number of spare bits in octet n.

shortName-SpareBits	• Short Name Spare Bits: – 1 - SPARE_BITS_8 - Bit 8 is spare and set to 0 in octet n. – 2 - SPARE_BITS_7_TO_8 - Bits 7 and 8 are spare and set to 0 in octet n. – 3 - SPARE_BITS_6_TO_8 - Bits 6 to 8 (inclusive) are spare and set to 0 in octet n. – 4 - SPARE_BITS_5_TO_8 - Bits 5 to 8 (inclusive) are spare and set to 0 in octet n. – 5 - SPARE_BITS_4_TO_8 - Bits 4 to 8 (inclusive) are spare and set to 0 in octet n. – 6 - SPARE_BITS_3_TO_8 - Bits 3 to 8 (inclusive) are spare and set to 0 in octet n. – 7 - SPARE_BITS_2_TO_8 - Bits 2 to 8 (inclusive) are spare and set to 0 in octet n. – 0 - SPARE_BITS_UNKNOWN - Carries no information about the number of spare bits in octet n.
longNameLen	• It provides the length of long name.
longName	• Long name string in coding_scheme.
shortNameLen	• It provides the length of short name.
shortName	• Short name string in coding_scheme.

8.144.2 Field Documentation

8.144.2.1 uint8_t nas_PLMNNetworkNameData::codingScheme

8.144.2.2 uint8_t nas_PLMNNetworkNameData::countryInitials

8.144.2.3 uint8_t nas_PLMNNetworkNameData::longName[255]

8.144.2.4 uint8_t nas_PLMNNetworkNameData::longNameLen

8.144.2.5 uint8_t nas_PLMNNetworkNameData::longNameSpareBits

8.144.2.6 uint8_t nas_PLMNNetworkNameData::shortName[255]

8.144.2.7 uint8_t nas_PLMNNetworkNameData::shortNameLen

8.144.2.8 uint8_t nas_PLMNNetworkNameData::shortNameSpareBits

8.145 nas_protocolSubtypeElement Struct Reference

Data Fields

- uint16_t PhysicalLayer
- uint16_t ControlMac
- uint16_t AccessMac
- uint16_t ForwardMac
- uint16_t ReverseMac

- uint16_t KeyExchange
- uint16_t AuthProt
- uint16_t EncryptProt
- uint16_t SecProt
- uint16_t IdleState
- uint16_t MultDisc
- uint16_t VirtStream

8.145.1 Detailed Description

This structure contains protocol subtype element.

Parameters

PhysicalLayer	• Specifies Physical Layer Protocol subtype
ControlMac	• Specifies Control Channel MAC Protocol subtype
AccessMac	• Specifies Access Channel MAC Protocol subtype
ForwardMac	• Specifies Forward Traffic Channel MAC Protocol subtype
ReverseMac	• Specifies Reverse Traffic Channel MAC Protocol subtype
KeyExchange	• Specifies Key exchange Protocol subtype
AuthProt	• Specifies Authentication Protocol subtype
EncryptProt	• Specifies Encryption Protocol subtype
SecProt	• Specifies Security Protocol subtype
IdleState	• Specifies Idle state Protocol subtype
MultDisc	• Specifies Generic multimode capability discovery Protocol subtype
VirtStream	• Specifies Generic Virtual Stream Protocol subtype

8.145.2 Field Documentation

8.145.2.1 uint16_t nas_protocolSubtypeElement::AccessMac

8.145.2.2 uint16_t nas_protocolSubtypeElement::AuthProt

8.145.2.3 uint16_t nas_protocolSubtypeElement::ControlMac

8.145.2.4 uint16_t nas_protocolSubtypeElement::EncryptProt

8.145.2.5 uint16_t nas_protocolSubtypeElement::ForwardMac

8.145.2.6 uint16_t nas_protocolSubtypeElement::IdleState

8.145.2.7 uint16_t nas_protocolSubtypeElement::KeyExchange

8.145.2.8 uint16_t nas_protocolSubtypeElement::MultDisc

8.145.2.9 uint16_t nas_protocolSubtypeElement::PhysicalLayer

8.145.2.10 uint16_t nas_protocolSubtypeElement::ReverseMac

8.145.2.11 uint16_t nas_protocolSubtypeElement::SecProt

8.145.2.12 uint16_t nas_protocolSubtypeElement::VirtStream

8.146 nas_qaQmi3Gpp2TimeZone Struct Reference

Data Fields

- uint8_t leapSeconds
- uint8_t localTimeOffset
- uint8_t daylightSavings

8.146.1 Detailed Description

This structure contains the 3GPP2TimeZone parameters

Parameters

leapSeconds	• leap seconds - Number of leap seconds since the start of CDMA system time.
localTimeOffset	• Local Time Offset - Offset of system time in units of 30 minutes; the value in this field conveys as 8 bit 2's compliment number.
daylightSavings	• Day Light Savings Indicator – 0x00 - OFF (daylight savings not in effect) – 0x01 - ON (daylight savings in effect)

8.146.2 Field Documentation

8.146.2.1 uint8_t nas_qaQmi3Gpp2TimeZone::daylightSavings

8.146.2.2 uint8_t nas_qaQmi3Gpp2TimeZone::leapSeconds

8.146.2.3 uint8_t nas_qaQmi3Gpp2TimeZone::localTimeOffset

8.147 nas_QmiNas3GppNetworkInfo Struct Reference

Data Fields

- uint16_t MCC
- uint16_t MNC
- uint32_t InUse
- uint32_t Roaming
- uint32_t Forbidden
- uint32_t Preferred
- char Desription [255]

8.147.1 Detailed Description

Contain the 3GPP network information.

Parameters

MCC	• Mobile Country Code
MNC	• Mobile Network Code
InUse	• Is the Network the current serving Network – 0 - Unknown – 1 - Current serving network – 2 - Not current serving network, available
Roaming	• Home/Roam Status of the Network – 0 - Unknown – 1 - Home – 2 - Roam
Forbidden	• Is the Network in the forbidden network list – 0 - Unknown – 1 - Forbidden – 2 - Not Forbidden
Preferred	• Is the Network in the Preferred network list – 0 - Unknown – 1 - Preferred – 2 - Not Preferred

Description	• Network Name/Description • This is a NULL terminated string.

8.147.2 Field Documentation

8.147.2.1 char nas_QmiNas3GppNetworkInfo::Desription[255]

8.147.2.2 uint32_t nas_QmiNas3GppNetworkInfo::Forbidden

8.147.2.3 uint32_t nas_QmiNas3GppNetworkInfo::InUse

8.147.2.4 uint16_t nas_QmiNas3GppNetworkInfo::MCC

8.147.2.5 uint16_t nas_QmiNas3GppNetworkInfo::MNC

8.147.2.6 uint32_t nas_QmiNas3GppNetworkInfo::Preferred

8.147.2.7 uint32_t nas_QmiNas3GppNetworkInfo::Roaming

8.148 nas_QmiNas3GppNetworkRAT Struct Reference

Data Fields

- uint16_t MCC
- uint16_t MNC
- uint8_t RAT

8.148.1 Detailed Description

Contain the 3GPP radio access technology information.

Parameters

MCC	• Mobile Country Code
MNC	• Mobile Network Code
RAT	• Radio Access Technology – 0x04 - GERAN – 0x05 - UMTS – 0x08 - LTE – 0x09 - TD-SCDMA

8.148.2 Field Documentation

8.148.2.1 uint16_t nas_QmiNas3GppNetworkRAT::MCC

8.148.2.2 uint16_t nas_QmiNas3GppNetworkRAT::MNC

8.148.2.3 uint8_t nas_QmiNas3GppNetworkRAT::RAT

8.149 nas_QmisNasPcsDigit Struct Reference

Data Fields

- uint16_t MCC
- uint16_t MNC
- uint8_t includes_pcs_digit

8.149.1 Detailed Description

Contain the PCS Digit information

Parameters

MCC	• Mobile Country Code
MNC	• Mobile Network Code
includes_pcs_digit	• this field is use to interpret the length of corresponding MNC reported • 0x01 - MNC is a three-digit value • 0x00 - MNC is a two-digit value

8.149.2 Field Documentation

8.149.2.1 uint8_t nas_QmisNasPcsDigit::includes_pcs_digit

8.149.2.2 uint16_t nas_QmisNasPcsDigit::MCC

8.149.2.3 uint16_t nas_QmisNasPcsDigit::MNC

8.150 nas_RejectReasonTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t serviceDomain
- uint32_t rejectCause

8.150.1 Detailed Description

This structure contains paramaters reject reason.

Parameters

TlvPresent	indicating the presence of the TLV in the QMI ind
serviceDomain	service domain
rejectCause	cause of reject

8.150.2 Field Documentation

8.150.2.1 uint32_t nas_RejectReasonTlv::rejectCause

8.150.2.2 uint32_t nas_RejectReasonTlv::serviceDomain

8.150.2.3 uint8_t nas_RejectReasonTlv::TlvPresent

8.151 nas_RFInfoTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t radioInterfaceSize
- uint32_t radioInterface [255]
- uint32_t activeBandClass [255]
- uint32_t activeChannel [255]

8.151.1 Detailed Description

This structure contains paramaters RF Band Information List.

Parameters

TlvPresent	indicating the presence of the TLV in the QMI ind
radioInterface-Size	Number of sets of the following elements • radioInterface • activeBandClass • activeChannel
radioInterface	radio interface technology of the signal being measured • 0x01 - cdma2000 1X • 0x02 - cdma2000 HRPD (1xEV-DO) • 0x03 - AMPS • 0x04 - GSM • 0x05 - UMTS • 0x08 - LTE • 0x09 - TD-SCDMA
activeBandClass	active band class • 00 to 39 - CDMA band classes • 40 to 79 - GSM band classes • 80 to 91 - WCDMA band classes • 120 to 160 - LTE band classes • 200 to 205 - TD-SCDMA band classes

activeChannel	active channel • Active channel. If the channel is not relevant to the technology, a value of 0 is returned.

8.151.2 Field Documentation

8.151.2.1 uint32_t nas_RFInfoTlv::activeBandClass[255]

8.151.2.2 uint32_t nas_RFInfoTlv::activeChannel[255]

8.151.2.3 uint32_t nas_RFInfoTlv::radioInterface[255]

8.151.2.4 uint8_t nas_RFInfoTlv::radioInterfaceSize

8.151.2.5 uint8_t nas_RFInfoTlv::TlvPresent

8.152 nas_roamIndList Struct Reference

Data Fields

- uint8_t numInstances
- uint8_t radioInterface [32]
- uint8_t roamIndicator [32]

8.152.1 Detailed Description

This structure contains the Roaming Indicator List

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

numInstances	• number of sets of radio interface currently in use and roaming indicator – defaults to zero
radioInterface	• Radio Interface currently in use • Values: – 0x01 - RADIO_IF_CDMA_1X - cdma2000 1X – 0x02 - RADIO_IF_CDMA_1XEVDO - cdma2000 HRPD (1xEV-DO) – 0x03 - RADIO_IF_AMPS - AMPS – 0x04 - RADIO_IF_GSM - GSM – 0x05 - RADIO_IF_UMTS - UMTS – 0x08 - RADIO_IF_LTE - LTE
roamIndicator	• Roaming Indicator • Values: – 0x00 - Roaming – 0x01 - Home

8.152.2 Field Documentation

8.152.2.1 uint8_t nas_roamIndList::numInstances

8.152.2.2 uint8_t nas_roamIndList::radioInterface[32]

8.152.2.3 uint8_t nas_roamIndList::roamIndicator[32]

8.153 nas_RSRPThresh Struct Reference

Data Fields

- uint8_t RSRPThresListLen
- int16_t * pRSRPThresList

8.153.1 Detailed Description

This structure contains RSRP threshold list.

Parameters

RSRPThresList-Len	• Length of the RSRP threshold list parameter to follow
pRSRPThresList	• Sequence of thresholds delimiting current RSRP event reporting bands • Every time a new RSRP value crosses a specified threshold value, an event report indication message with the new RSRQ value is sent to the requesting control point. For this field – RSRP values are applicable only for LTE – RSRP values are measured in dBm, with a range of -44 dBm to -140 dBm – Each RSRP threshold value is a signed byte value – Maximum number of threshold values is 16 – At least one value must be specified

8.153.2 Field Documentation

8.153.2.1 int16_t* nas_RSRPThresh::pRSRPThresList

8.153.2.2 uint8_t nas_RSRPThresh::RSRPThresListLen

8.154 nas_rsrqInformation Struct Reference

Data Fields

- int8_t rsrq
- uint8_t radioIf

8.154.1 Detailed Description

This structure contains the RSRQ Information

Parameters

rsrq	• RSRQ value in dB (signed integer value); valid range is -3 to -20 (-3 means -3 dB, -20 means -20 dB)
radioIf	• Radio interface technology of the signal being measured – 0x08 – LTE

8.154.2 Field Documentation

8.154.2.1 uint8_t nas_rsrqInformation::radioIf

8.154.2.2 int8_t nas_rsrqInformation::rsrq

8.155 nas_RSRQThresh Struct Reference

Data Fields

- uint8_t RSRQThresListLen
- int8_t * pRSRQThresList

8.155.1 Detailed Description

This structure contains RSRQ threshold list.

Parameters

RSRQThresList-Len	• Length of the RSRQ threshold list parameter to follow
pRSRQThresList	• Sequence of thresholds delimiting current RSRQ event reporting bands • Every time a new RSRQ value crosses a threshold value, an event report indication message with the new RSRQ value is sent to the requesting control point. For this field – RSRQ values are applicable only for LTE – RSRQ values are measured in dBm, with a range of -20 dBm to -3 dBm – Each RSRQ threshold value is a signed byte value – Maximum number of threshold values is 16 – At least one value must be specified

8.155.2 Field Documentation

8.155.2.1 int8_t* nas_RSRQThresh::pRSRQThresList

8.155.2.2 uint8_t nas_RSRQThresh::RSRQThresListLen

8.156 nas_RSSIThresh Struct Reference

Data Fields

- uint8_t RSSIThresListLen
- int8_t * pRSSIThresList

8.156.1 Detailed Description

This sturcture contain RSSI threshold list.

Parameters

RSSIThresList-Len	• Length of the RSSI threshold list parameter to follow
pRSSIThresList	• RSSI in dBm(signed bytes) • A value of -125 dBm or lower is used to indicate No Signal • RSSI values have the following ranges (in dBm) – CDMA is -105 to -21 – HDR is -118 to -13 – GSM is -111 to -48 – WCDMA is -121 to 0 – LTE is -120 to 0 • Threshold values specified above are used for all RATs • The maximum number of threshold values is 16, each a signed byte value.

8.156.2 Field Documentation

8.156.2.1 int8_t* nas_RSSIThresh::pRSSIThresList

8.156.2.2 uint8_t nas_RSSIThresh::RSSIThresListLen

8.157 nas_rxInfo Struct Reference

Data Fields

- uint8_t isRadioTuned
- int32_t rxPower
- int32_t ecio
- int32_t rscp
- int32_t rsrp
- uint32_t phase

8.157.1 Detailed Description

This structure contains rx radio infomation.

Parameters

isRadioTuned	• Whether Rx is tuned to a channel: – 0x00 - Not tuned – 0x01 - Tuned – 0xFF - Not Available • If the radio is tuned, instantaneous values are set for the signal information fields below. • If the radio is not tuned, or is delayed or invalid, the values are set depending on each technology.
rx_pwr	• Rx power value in 1/10 dbm resolution.
ecio	• ECIO in 1/10 dbm; valid for CDMA, HDR, GSM, WCDMA, and LTE.
rscp	• Received signal code power in 1/10 dbm. • Valid for WCDMA.
rsrp	• Current reference signal received power in 1/10 dbm valid for LTE.
phase	• Phase in 1/100 degrees; valid for LTE. • When the phase is unknown, 0xFFFFFFFF is used.

8.157.2 Field Documentation

8.157.2.1 int32_t nas_rxInfo::ecio

8.157.2.2 uint8_t nas_rxInfo::isRadioTuned

8.157.2.3 uint32_t nas_rxInfo::phase

8.157.2.4 int32_t nas_rxInfo::rscp

8.157.2.5 int32_t nas_rxInfo::rsrp

8.157.2.6 int32_t nas_rxInfo::rxPower

8.158 nas_RxSigInfo Struct Reference

Data Fields

- uint8_t rxChainIndex
- uint8_t isRadioTuned
- int32_t rxPower
- int32_t rsrp

8.158.1 Detailed Description

This structure contains the parameters for Rx Signal Info.

Parameters

rxChainIndex	• Rx antenna path • Valid Values – 0 - Primary Rx – 1 - Diversity Rx
isRadioTuned	• Rx path is tuned to a channel or Not • Values – 0x00 - Not tuned – 0x01 - Tuned

Note

If the radio is tuned, the instantaneous values are set for the fields below. If the radio is not tuned, the values set below may be invalid.

Parameters

rxPower	• Rx power value in 1/10 dBm resolution
rsrp	• Current reference signal received power in 1/10 dBm resolution

8.158.2 Field Documentation

8.158.2.1 uint8_t nas_RxSigInfo::isRadioTuned

8.158.2.2 int32_t nas_RxSigInfo::rsrp

8.158.2.3 uint8_t nas_RxSigInfo::rxChainIndex

8.158.2.4 int32_t nas_RxSigInfo::rxPower

8.159 nas_rxSignalStrengthListElement Struct Reference

Data Fields

- int16_t rxSignalStrength
- uint8_t radioIf

8.159.1 Detailed Description

This structure contains the Received Signal Strength Information

Parameters

rxSignalStrength	• Received signal strength in dBm – For CDMA and UMTS, this indicates forward link pilotEc. – For GSM, the received signal strength. – For LTE, this indicates the total received wideband power observed by UE.
radioIf	• Radio interface technology of the signal being radio_if measured – 0x00 – RADIO_IF_NO_SVC – None (no service) – 0x01 – RADIO_IF_CDMA_1X – cdma2000® 1X – 0x02 – RADIO_IF_CDMA_1XEVDO – cdma2000 HRPD (1xEV-DO) – 0x03 – RADIO_IF_AMPS – AMPS – 0x04 – RADIO_IF_GSM – GSM – 0x05 – RADIO_IF_UMTS – UMTS – 0x08 – RADIO_IF_LTE – LTE

Note

First elemnet of the RSSI list always contains the current Signal strength and Radio Interface.

8.159.2 Field Documentation

8.159.2.1 uint8_t nas_rxSignalStrengthListElement::radioIf

8.159.2.2 int16_t nas_rxSignalStrengthListElement::rxSignalStrength

8.160 nas_SccRxInfo Struct Reference

Data Fields

- int32_t rsrq
- int16_t snr
- uint8_t numInstances
- nas_RxSigInfo sigInfo [255]
- uint8_t TlvPresent

8.160.1 Detailed Description

This structure contains information about the SccRxInfo parameters.

Parameters

rsrq	• Current reference signal • Receive quality in 1/10 dB resolution
snr	• Reference signal signal-to-noise ratio in dB. • Range -10 to 30

numInstances	• Number of sets of the following – rxChainIndex – isRadioTuned – rxPower – rsrp
sigInfo	• See nas_RxSigInfo for more information
TlvPresent	• Tlv Present.

8.160.2 Field Documentation

8.160.2.1 uint8_t nas_SccRxInfo::numInstances

8.160.2.2 int32_t nas_SccRxInfo::rsrq

8.160.2.3 nas_RxSigInfo nas_SccRxInfo::sigInfo[255]

8.160.2.4 int16_t nas_SccRxInfo::snr

8.160.2.5 uint8_t nas_SccRxInfo::TlvPresent

8.161 nas_serviceProviderName Struct Reference

Data Fields

- uint8_t displayCondition
- uint8_t spnLength
- uint8_t spn [255]

8.161.1 Detailed Description

This structure contains service provider name.

Parameters

displayCondition	• Display condition.
spnLength	• It provides length of spn.
spn	• Service provider name string must use: The SMS default 7-bit coded alphabet as defined in 3GPP TS 23.038 with bit 8 set to 9.

8.161.2 Field Documentation

8.161.2.1 uint8_t nas_serviceProviderName::displayCondition

8.161.2.2 uint8_t nas_serviceProviderName::spn[255]

8.161.2.3 uint8_t nas_serviceProviderName::spnLength

8.162 nas_servSystem Struct Reference

Data Fields

- uint8_t regState
- uint8_t csAttachState
- uint8_t psAttachState
- uint8_t selNetwork
- uint8_t numRadioInterfaces
- uint8_t radioInterface [32]

8.162.1 Detailed Description

This structure contains the Serving System parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

regState	• Registration state - Registration state of the mobile • Values: – 0 - Not Registered; mobile is not currently searching for a new network to provide service – 1 - Registered with a network – 2 - Not registered, but mobile is currently searching for a new network to provide service – 3 - Registration denied by visible network – 4 - Registration state is unknown
csAttachState	• CS Attach State - Circuit-switched domain attach state of the mobile • Values: – 0 - Unknown or not applicable – 1 - Attached – 2 - Detached
psAttachState	• PS Attach State - Packet-switched domain attach state of the mobile • Values: – 0 - Unknown or not applicable – 1 - Attached – 2 - Detached

selNetwork	• Selected Network - Type of selected radio access network • Values: – 0 - Unknown – 1 - 3GPP2 network – 2 - 3GPP network
numRadio-Interfaces	• In Use Radio Interfaces Number – Number of radio interfaces currently in use – defaults to zero
radioInterface	• Radio Interface currently in use • Values: – 0x00 - RADIO_IF_NO_SVC - None(no service) – 0x01 - RADIO_IF_CDMA_1X - cdma2000 1X – 0x02 - RADIO_IF_CDMA_1XEVDO - cdma2000 HRPD (1xEV-DO) – 0x03 - RADIO_IF_AMPS - AMPS – 0x04 - RADIO_IF_GSM - GSM – 0x05 - RADIO_IF_UMTS - UMTS – 0x08 - RADIO_IF_LTE - LTE

8.162.2 Field Documentation

8.162.2.1 uint8_t nas_servSystem::csAttachState

8.162.2.2 uint8_t nas_servSystem::numRadioInterfaces

8.162.2.3 uint8_t nas_servSystem::psAttachState

8.162.2.4 uint8_t nas_servSystem::radioInterface[32]

8.162.2.5 uint8_t nas_servSystem::regState

8.162.2.6 uint8_t nas_servSystem::selNetwork

8.163 nas_sidNid Struct Reference

Data Fields

- uint16_t nid
- uint16_t sid

8.163.1 Detailed Description

This structure contains the parameters for SidNid Information

Parameters

nid	• Network ID
sid	• System ID

8.163.2 Field Documentation

8.163.2.1 uint16_t nas_sidNid::nid

8.163.2.2 uint16_t nas_sidNid::sid

8.164 nas_SignalStrengthTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- int8_t signalStrength
- uint32_t radioInterface

8.164.1 Detailed Description

This structure contains paramaters Signal Strength.

Parameters

TlvPresent	indicating the presence of the TLV in the QMI ind
signalStrength	signal strength
radioInterface	radio interface technology of the signal being measured

8.164.2 Field Documentation

8.164.2.1 uint32_t nas_SignalStrengthTlv::radioInterface

8.164.2.2 int8_t nas_SignalStrengthTlv::signalStrength

8.164.2.3 uint8_t nas_SignalStrengthTlv::TlvPresent

8.165 nas_SLQSSignalStrengthsIndReq Struct Reference

Data Fields

- uint8_t rxSignalStrengthDelta
- uint8_t ecioDelta
- uint8_t ioDelta
- uint8_t sinrDelta
- uint8_t rsrqDelta
- uint8_t ecioThresholdListLen
- int16_t ecioThresholdList [10]
- uint8_t sinrThresholdListLen

- uint8_t sinrThresholdList [5]
- uint16_t lteSnrDelta
- uint8_t lteRsrpDelta

8.165.1 Detailed Description

Structure for storing the input parameters passed for SLQSSetSignalStrengthsCallback by the user.

Parameters

rxSignalStrengthDelta	• RSSI delta(in dBm) at which an event report indication, including the current RSSI, will be sent to the requesting control point.
ecioDelta	• ECIO delta at which an event report indication, ecioDelta including the current ECIO, will be sent to the requesting control point. • ECIO delta is an unsigned 1 byte value that increments in negative 0.5 dBm, e.g., ecio_delta of 2 means a change of -1 dBm.
ioDelta	• IO delta (in dBm) at which an event report indication, ioDelta including the current IO, will be sent to the requesting control point.
sinrDelta	• SINR delta level at which an event report indication, sinrDelta including the current SINR, will be sent to the requesting control point.
rsrqDelta	• RSRQ delta level at which an event report indication, including the current RSRQ, will be sent to the requesting control point.
ecioThresholdListLen	• Number of elements in the ECIO threshold list.
ecioThresholdList	• A sequence of thresholds delimiting EcIo event reporting bands. Every time a new EcIo value crosses a threshold value, an event report indication message with the new ECIO value is sent to the requesting control point. For this field: – Maximum number of threshold values is 10 – At least one value must be specified.
sinrThresholdListLen	• Number of elements in the SINR threshold list.
sinrThresholdList	• A sequence of thresholds delimiting SINR event reporting bands. Every time a new SINR value crosses a threshold value, an event report indication message with the new sinr value is sent to the requesting control point. For this field: – Maximum number of threshold values is 5 – At least one value must be specified.

ltesnrdelta	• LTE SNR delta level at which an event report indication, including the current SNR, will be sent to the requesting control point. LTE SNR delta level is an unsigned 2 byte value, representing the delta in units of 0.1 dB, e.g., lte_snr_delta of 3 means a change 0.3dB.
ltersrpdelta	-LTE RSRP delta level at which an event report -indication, including the current RSRP, will be sent -to the requesting control point. LTE RSRP delta -level is an unsigned 1 byte value, representing the -delta in dB.

8.165.2 Field Documentation

8.165.2.1 uint8_t nas_SLQSSignalStrengthsIndReq::ecioDelta

8.165.2.2 int16_t nas_SLQSSignalStrengthsIndReq::ecioThresholdList[10]

8.165.2.3 uint8_t nas_SLQSSignalStrengthsIndReq::ecioThresholdListLen

8.165.2.4 uint8_t nas_SLQSSignalStrengthsIndReq::ioDelta

8.165.2.5 uint8_t nas_SLQSSignalStrengthsIndReq::lteRsrpDelta

8.165.2.6 uint16_t nas_SLQSSignalStrengthsIndReq::lteSnrDelta

8.165.2.7 uint8_t nas_SLQSSignalStrengthsIndReq::rsrqDelta

8.165.2.8 uint8_t nas_SLQSSignalStrengthsIndReq::rxSignalStrengthDelta

8.165.2.9 uint8_t nas_SLQSSignalStrengthsIndReq::sinrDelta

8.165.2.10 uint8_t nas_SLQSSignalStrengthsIndReq::sinrThresholdList[5]

8.165.2.11 uint8_t nas_SLQSSignalStrengthsIndReq::sinrThresholdListLen

8.166 nas_SLQSSignalStrengthsInformation Struct Reference

Data Fields

- nas_rxSignalStrengthListElement rxSignalStrengthInfo
- nas_ecioListElement ecioInfo
- uint32_t io
- uint8_t sinr
- nas_errorRateListElement errorRateInfo
- nas_rsrqInformation rsrqInfo
- nas_lteSnrinformation lteSnrinfo
- nas_lteRsrpinformation lteRsrpinfo

8.166.1 Detailed Description

This structure contains paramaters signal strengths information.

Parameters

rxSignal-StrengthInfo	signal strength info list
ecioInfo	ecio info list
io	received IO in dBm; IO is only applicable for 1xEV-DO
sinr	SINR level
errorRateInfo	error rate info
rsrqInfo	rsrq info
lteSnrinfo	lte Snr information
lteRsrpinfo	lte rsrp info

8.166.2 Field Documentation

8.166.2.1 nas_ecioListElement nas_SLQSSignalStrengthsInformation::ecioInfo

8.166.2.2 nas_errorRateListElement nas_SLQSSignalStrengthsInformation::errorRateInfo

8.166.2.3 uint32_t nas_SLQSSignalStrengthsInformation::io

8.166.2.4 nas_lteRsrpinformation nas_SLQSSignalStrengthsInformation::lteRsrpinfo

8.166.2.5 nas_lteSnrinformation nas_SLQSSignalStrengthsInformation::lteSnrinfo

8.166.2.6 nas_rsrqInformation nas_SLQSSignalStrengthsInformation::rsrqInfo

8.166.2.7 nas_rxSignalStrengthListElement nas_SLQSSignalStrengthsInformation::rxSignalStrengthInfo

8.166.2.8 uint8_t nas_SLQSSignalStrengthsInformation::sinr

8.167 nas_SLQSSignalStrengthsTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- nas_SLQSSignalStrengthsInformation sSLQSSignalStrengthsInfo

8.167.1 Detailed Description

This structure contains paramaters SLQS Signal Strength.

Parameters

TlvPresent	indicating the presence of the TLV in the QMI ind
sSLQSSignal-StrengthsInfo	signal strength info

8.167.2 Field Documentation

8.167.2.1 nas_SLQSSignalStrengthsInformation nas_SLQSSignalStrengthsTlv::sSLQSSignalStrengthsInfo

8.167.2.2 uint8_t nas_SLQSSignalStrengthsTlv::TlvPresent

8.168 nas_SrvStatusInfo Struct Reference

Data Fields

- uint8_t srvStatus
- uint8_t isPrefDataPath

8.168.1 Detailed Description

Structure for storing the service status information for CDMA and HDR networks.

Parameters

srvStatus	• Service status of the system. – 0x00 - No service – 0x01 - Limited service – 0x02 - Service – 0x03 - Limited regional service – 0x04 - Power save – 0xFF - Not Available
isPrefDataPath	• Whether the RAT is the preferred data path. – 0x00 - Not preferred – 0x01 - Preferred – 0xFF - Not Available

8.168.2 Field Documentation

8.168.2.1 uint8_t nas_SrvStatusInfo::isPrefDataPath

8.168.2.2 uint8_t nas_SrvStatusInfo::srvStatus

8.169 nas_sysInfoCommon Struct Reference

Data Fields

- uint8_t srvDomainValid
- uint8_t srvDomain
- uint8_t srvCapabilityValid
- uint8_t srvCapability
- uint8_t roamStatusValid
- uint8_t roamStatus
- uint8_t isSysForbiddenValid
- uint8_t isSysForbidden

8.169.1 Detailed Description

Structure for storing the System Information common to CDMA, HDR, GSM, WCDMA and LTE networks.

Parameters

srvDomainValid	• Indicates whether the service domain is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
srvDomain	• Service domain registered on the system. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - Camped – 0xFF - Not Available
srvCapability-Valid	• Indicates whether the service capability is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
srvCapability	• Current system's service capability. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - Camped – 0xFF - Not Available
roamStatusValid	• Indicates whether the roaming status is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available

roamStatus	• Current roaming status. – 0x00 - Off – 0x01 - On – 0x02 - Blinking – 0x03 - Out of the neighborhood – 0x04 - Out of the building – 0x05 - Preferred system – 0x06 - Available system – 0x07 - Alliance partner – 0x08 - Premium partner – 0x09 - Full service – 0x0A - Partial service – 0x0B - Banner is on – 0x0C - Banner is off – 0x0D to 0x3F - Reserved for Standard Enhanced Roaming Indicator Numbers – 0x40 to 0x7F - Reserved for Non-Standard Enhanced Roaming Indicator Numbers – 0x40 to 0xFF - Reserved. – 0xFF - Not Available • Values from 0x02 onward are only applicable for 3GPP2
isSysForbidden-Valid	• Indicates whether the forbidden system is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
isSysForbidden	• Whether the system is forbidden. – 0x00 - Not forbidden – 0x01 - Forbidden – 0xFF - Not Available

8.169.2 Field Documentation

8.169.2.1 uint8_t nas_sysInfoCommon::isSysForbidden

8.169.2.2 uint8_t nas_sysInfoCommon::isSysForbiddenValid

8.169.2.3 uint8_t nas_sysInfoCommon::roamStatus

8.169.2.4 uint8_t nas_sysInfoCommon::roamStatusValid

8.169.2.5 uint8_t nas_sysInfoCommon::srvCapability

8.169.2.6 uint8_t nas_sysInfoCommon::srvCapabilityValid

8.169.2.7 uint8_t nas_sysInfoCommon::srvDomain

8.169.2.8 uint8_t nas_sysInfoCommon::srvDomainValid

8.170 nas_TDSCDMAECIOThresh Struct Reference

Data Fields

- uint8_t TDSCDMAECIOThreshListLen
- float * pTDSCDMAECIOThreshList

8.170.1 Detailed Description

This structure contains TDSCDMA ECIO threshold related parameters.

Parameters

TDSCDMAECIOThreshListLen	• Length of the TDSCDMA ECIO threshold list parameter to follow
pTDSCDMAECIOThreshList	• Array of ECIO thresholds (in dB) used by TD-SCDMA • Maximum of 32 values.

8.170.2 Field Documentation

8.170.2.1 float* nas_TDSCDMAECIOThresh::pTDSCDMAECIOThreshList

8.170.2.2 uint8_t nas_TDSCDMAECIOThresh::TDSCDMAECIOThreshListLen

8.171 nas_TDSCDMARSCPThresh Struct Reference

Data Fields

- uint8_t TDSCDMARSCPThreshListLen
- int16_t * pTDSCDMARSCPThreshList

8.171.1 Detailed Description

This structure contains TDSCDMA RSCP threshold related parameters.

Parameters

TDSCDMARSCPThreshListLen	• Length of the TDSCDMA RSCP threshold list parameter to follow
pTDSCDMARSCPThreshList	• Array of RSCP thresholds (in units of 0.1 dBm) • Maximum of 32 values • Range for RSCP values: -120 to -25 (in dBm).

8.171.2 Field Documentation

8.171.2.1 int16_t* nas_TDSCDMARSCPThresh::pTDSCDMARSCPThreshList

8.171.2.2 uint8_t nas_TDSCDMARSCPThresh::TDSCDMARSCPThreshListLen

8.172 nas_TDSCDMARSSIThresh Struct Reference

Data Fields

- uint8_t TDSCDMARSSIThreshListLen
- float * pTDSCDMARSSIThreshList

8.172.1 Detailed Description

This structure contains TDSCDMA RSSI threshold related parameters.

Parameters

TDSCDMARSSIThreshListLen	• Length of the TDSCDMA RSSI threshold list parameter to follow
pTDSCDMARSSIThreshList	• Array of RSSI thresholds (in dBm) used by TD-SCDMA • Maximum of 32 values.

8.172.2 Field Documentation

8.172.2.1 float* nas_TDSCDMARSSIThresh::pTDSCDMARSSIThreshList

8.172.2.2 uint8_t nas_TDSCDMARSSIThresh::TDSCDMARSSIThreshListLen

8.173 nas_TDSCDMASINRCONFThresh Struct Reference

Data Fields

- uint8_t TDSCDMASINRCONFThreshListLen
- float * pTDSCDMASINRCONFThreshList

8.173.1 Detailed Description

This structure contains TDSCDMA SINR threshold list.

Parameters

TDSCDMASINRCONFThreshListLen	• Length of the TDSCDMA SINR threshold list parameter to follow
pTDSCDMASINRCONFThreshList	• Array of SINR thresholds (in dB) used by TD-SCDMA • Maximum of 32 values

8.173.2 Field Documentation

8.173.2.1 float* nas_TDSCDMASINRCONFThresh::pTDSCDMASINRCONFThreshList

8.173.2.2 uint8_t nas_TDSCDMASINRCONFThresh::TDSCDMASINRCONFThreshListLen

8.174 nas_TDSCDMASINRThresh Struct Reference

Data Fields

- uint8_t TDSCDMASINRThreshListLen
- float * pTDSCDMASINRThreshList

8.174.1 Detailed Description

This structure contains TDSCDMA SINR threshold related parameters.

Parameters

TDSCDMASINRThreshListLen	• Length of the TDSCDMA SINR threshold list parameter to follow
pTDSCDMASINRThreshList	• Array of SINR thresholds (in dB) used by TD-SCDMA • Maximum of 32 values

8.174.2 Field Documentation

8.174.2.1 float* nas_TDSCDMASINRThresh::pTDSCDMASINRThreshList

8.174.2.2 uint8_t nas_TDSCDMASINRThresh::TDSCDMASINRThreshListLen

8.175 nas_timeInfo Struct Reference

Data Fields

- uint16_t year
- uint8_t month
- uint8_t day
- uint8_t hour
- uint8_t minute
- uint8_t second
- uint8_t dayOfWeek
- int8_t timeZone
- uint8_t dayLtSavingAdj
- uint8_t radioInterface
- uint8_t TlvPresent

8.175.1 Detailed Description

This structure contains the parameters for Network Time.

Parameters

year	• Year
month	• Month • 1 is January and 12 is December
day	• Day • Range - 1 to 31
hour	• Hour • Range - 0 to 59
minute	• Minute • Range - 0 to 59
second	• Second • Range - 0 to 59
dayOfWeek	• Day of the week • 0 is Monday and 6 is Sunday
timeZone	• Offset from Universal time • The difference between local time and Universal time, in increments of 15 min • Signed Value
dayLtSavingAdj	• Daylight saving adjustment in hours • Possible values - 0, 1, and 2. • This field is ignored if radio_if is NAS_RADIO_IF_CDMA_1XEVDO
radioInterface	• Radio interface from which the information comes • Values – 0x01 - NAS_RADIO_IF_CDMA_1X - cdma2000 1X – 0x02 - NAS_RADIO_IF_CDMA_1XEVDO - cdma2000 HRPD (1xEV-DO) – 0x04 - NAS_RADIO_IF_GSM - GSM – 0x05 - NAS_RADIO_IF_UMTS - UMTS – 0x08 - NAS_RADIO_IF_LTE - LTE – 0x09 - NAS_RADIO_IF_TDSCDMA -TD-SCDMA
TlvPresent	• Tlv Present.

8.175.2 Field Documentation

8.175.2.1 uint8_t nas_timeInfo::day

8.175.2.2 uint8_t nas_timeInfo::dayLtSavingAdj

8.175.2.3 uint8_t nas_timeInfo::dayOfWeek

8.175.2.4 uint8_t nas_timeInfo::hour

8.175.2.5 uint8_t nas_timeInfo::minute

8.175.2.6 uint8_t nas_timeInfo::month

8.175.2.7 uint8_t nas_timeInfo::radioInterface

8.175.2.8 uint8_t nas_timeInfo::second

8.175.2.9 int8_t nas_timeInfo::timeZone

8.175.2.10 uint8_t nas_timeInfo::TlvPresent

8.175.2.11 uint16_t nas_timeInfo::year

8.176 nas_trueIMSI Struct Reference

Data Fields

- uint8_t mccT [3]
- uint16_t imsiT1112
- uint8_t imsiTS1 [7]
- uint8_t imsiTS2 [3]
- uint8_t imsiTaddrNum

8.176.1 Detailed Description

This structure contains True IMSI.

Parameters

mccT	• ASCII character representation of MCC_T
imsiT1112	• ASCII character representation of IMSI_T_11_12 value – 0xFFFF - Not Available
imsiTS1	• ASCII character representation of IMSI_T_S1 value
imsiTS2	• ASCII character representation of IMSI_T_S2 value

imsiTaddrNum	• Value of IMSI_T_ADDR_NUM – 0xFF - Not Available

8.176.2 Field Documentation

8.176.2.1 uint16_t nas_truelMSI::imsiT1112

8.176.2.2 uint8_t nas_truelMSI::imsiTaddrNum

8.176.2.3 uint8_t nas_truelMSI::imsiTS1[7]

8.176.2.4 uint8_t nas_truelMSI::imsiTS2[3]

8.176.2.5 uint8_t nas_truelMSI::mccT[3]

8.177 nas_txInfo Struct Reference

Data Fields

- uint8_t isInTraffic
- int32_t txPower

8.177.1 Detailed Description

This structure contains tx radio infomation.

Parameters

isInTraffic	• Whether the device is in traffic. – 0x00 - not in traffic – 0x01 - in traffic • The txPower field is only meaningful when in the device is in traffic.
txPower	• Tx power value in 1/10 dbm.

8.177.2 Field Documentation

8.177.2.1 uint8_t nas_txInfo::isInTraffic

8.177.2.2 int32_t nas_txInfo::txPower

8.178 nas_UMTSInfo Struct Reference

Data Fields

- uint16_t cellID

- uint8_t plmn [3]
- uint16_t lac
- uint16_t uarfcn
- uint16_t psc
- int16_t rscp
- int16_t ecio
- uint8_t umtsInst
- nas_UMTSinstInfo UMTSInstInfo [255]
- uint8_t geranInst
- nas_geranInstInfo GeranInstInfo [255]

8.178.1 Detailed Description

This structure contains information about the UMTS Network.

Parameters

cellID	• Cell ID. • 0xFFFFFFFF indicates cell ID information is not present.
plmn[NAS_PLMN_LENGTH]	• MCC/MNC information coded as octet 3, 4, and 5. • This field is ignored when nmrCellID is not present.
lac	• Location area code. • This field is ignored when nmrCellID is not present. – 0xFFFF - Not Available
uarfcn	• UTRA absolute RF channel number. – 0xFFFF - Not Available
psc	• Primary scrambling code. – 0xFFFF - Not Available
rscp	• Received signal code power. – 0xFFFF - Not Available
ecio	• ECIO(Signal-to-Interference-ratio). – 0xFFFF - Not Available
umtsInst	• Provides the number of set of UMTS info instances. • If 0(zero), then no information follows it.
UMTSInstInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_UMTSinstInfo for more information.

geranInst	• Provides the number of set of GERAN info instances. • If 0(zero), then no information follows it.
GeranInstInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_geranInstInfo for more information.

8.178.2 Field Documentation

8.178.2.1 uint16_t nas_UMTSInfo::cellID

8.178.2.2 int16_t nas_UMTSInfo::ecio

8.178.2.3 uint8_t nas_UMTSInfo::geranInst

8.178.2.4 nas_geranInstInfo nas_UMTSInfo::GeranInstInfo[255]

8.178.2.5 uint16_t nas_UMTSInfo::lac

8.178.2.6 uint8_t nas_UMTSInfo::plmn[3]

8.178.2.7 uint16_t nas_UMTSInfo::psc

8.178.2.8 int16_t nas_UMTSInfo::rscp

8.178.2.9 uint16_t nas_UMTSInfo::uarfcn

8.178.2.10 uint8_t nas_UMTSInfo::umtsInst

8.178.2.11 nas_UMTSinstInfo nas_UMTSInfo::UMTSInstInfo[255]

8.179 nas_UMTSinstInfo Struct Reference

Data Fields

- uint16_t umtsUarfcn
- uint16_t umtsPsc
- int16_t umtsRscp
- int16_t umtsEcio

8.179.1 Detailed Description

This structure contains information about the UMTS Instances in UMTS Network.

Parameters

umtsUarfcn	• UTRA absolute RF channel number.
umtsPsc	• Primary scrambling code.

umtsRscp	• Received signal code power.
umtsEcio	• ECIO(Signal-to-Interference-ratio).

8.179.2 Field Documentation

8.179.2.1 int16_t nas_UMTSinstInfo::umtsEcio

8.179.2.2 uint16_t nas_UMTSinstInfo::umtsPsc

8.179.2.3 int16_t nas_UMTSinstInfo::umtsRscp

8.179.2.4 uint16_t nas_UMTSinstInfo::umtsUarfcn

8.180 nas_umtsLTENbrCell Struct Reference

Data Fields

- uint16_t earfcn
- uint16_t pci
- uint32_t rsrp
- uint32_t rsrq
- int16_t srxlev
- uint8_t cellIsTDD

8.180.1 Detailed Description

This structure contains information about the UMTS LTE neighbour Cell.

Parameters

earfcn	• E-UTRA absolute RF channel number of the detected cell.
pci	• Physical cell ID of the detected cell. • Range is defined in 3GPP TS 36.211
rsrp	• Current received signal strength indication (in dBm) of the detected cell.
rsrq	• Current reference signal received quality (in dB) of the detected cell.
srxlev	• Cell selection Rx level (Srxlev) value of the detected cell in linear scale. • This field is only valid when wcdma_rrc_state is not NAS_WCDMA_RRC_STATE_CEL_FACH or NAS_WCDMA_RRC_STATE_CELL_DCH.

cellIsTDD	• TRUE if the cell is TDD; FALSE if the cell is FDD.

8.180.2 Field Documentation

8.180.2.1 uint8_t nas_umtsLTENbrCell::cellIsTDD

8.180.2.2 uint16_t nas_umtsLTENbrCell::earfcn

8.180.2.3 uint16_t nas_umtsLTENbrCell::pci

8.180.2.4 uint32_t nas_umtsLTENbrCell::rsrp

8.180.2.5 uint32_t nas_umtsLTENbrCell::rsrq

8.180.2.6 int16_t nas_umtsLTENbrCell::srxlev

8.181 nas_UniversalTime Struct Reference

Data Fields

- uint16_t year
- uint8_t month
- uint8_t day
- uint8_t hour
- uint8_t minute
- uint8_t second
- uint8_t dayOfWeek

8.181.1 Detailed Description

This structure contains the parameters for Universal Time Information.

Parameters

year	• Year.
month	• Month. – 1 is January and 12 is December.
day	• Day. – Range 1 to 31.
hour	• Hour. – Range 0 to 59.

minute	• Minute. – Range 0 to 59.
second	• Second. – Range 0 to 59.
dayOfWeek	• Day of the Week. – 0 is Monday and 6 is Sunday.

8.181.2 Field Documentation

8.181.2.1 uint8_t nas_UniversalTime::day

8.181.2.2 uint8_t nas_UniversalTime::dayOfWeek

8.181.2.3 uint8_t nas_UniversalTime::hour

8.181.2.4 uint8_t nas_UniversalTime::minute

8.181.2.5 uint8_t nas_UniversalTime::month

8.181.2.6 uint8_t nas_UniversalTime::second

8.181.2.7 uint16_t nas_UniversalTime::year

8.182 nas_wcdmaCellInfo Struct Reference

Data Fields

- uint16_t psc
- int16_t cpich_rscp
- int16_t cpich_ecno
- int16_t srxlev

8.182.1 Detailed Description

This structure contains information about the WCDMA Cell.

Parameters

psc	• Primary scrambling code. • Range: 0 to 511.
cpich_rscp	• Absolute power level (in 1/10 dBm) of the common pilot channel as received by the UE. • Range: -120.0 dBm to -25.0 dBm

cpich_ecno	• CPICH Ec/No; ratio (in 1/10 dB) of the received energy per PN chip for the CPICH to the total received power spectral density at the UE antenna connector. • Range: -50.0 dB to 0.
srxlev	• Cell selection Rx level (Srxlev) value. • Range: -128 to 128. • This field is only valid when ue_in_idle is TRUE.

8.182.2 Field Documentation

8.182.2.1 int16_t nas_wcdmaCellInfo::cpich_ecno

8.182.2.2 int16_t nas_wcdmaCellInfo::cpich_rscp

8.182.2.3 uint16_t nas_wcdmaCellInfo::psc

8.182.2.4 int16_t nas_wcdmaCellInfo::srxlev

8.183 nas_WCDMAECIOThresh Struct Reference

Data Fields

- uint8_t WCDMAECIOThreshListLen
- int16_t * pWCDMAECIOThreshList

8.183.1 Detailed Description

This structure contains WCDMA ECIO threshold related parameters.

Parameters

WCDMAECIO-ThreshListLen	• Length of the WCDMA ECIO threshold list parameter to follow
pWCDMAECIO-ThreshList	• Array of ECIO thresholds (in units of 0.1 dB) • Maximum of 32 values • Range for ECIO values: -31.5 to 0 (in dB)

8.183.2 Field Documentation

8.183.2.1 int16_t* nas_WCDMAECIOThresh::pWCDMAECIOThreshList

8.183.2.2 uint8_t nas_WCDMAECIOThresh::WCDMAECIOThreshListLen

8.184 nas_WCDMAInfoLTENeighborCell Struct Reference

Data Fields

- uint32_t wcdmaRRCState
- uint8_t umtsLTENbrCellLen
- nas_umtsLTENbrCell UMTSLTENbrCell [255]

8.184.1 Detailed Description

This structure contains information about the WCDMA - LTE Neighboring Cell Info Set.

Parameters

wcdmaRRC-State	• WCDMA RRC states. • Defined in 3GPP TS 25.331 • Values: – 0x00 - NAS_WCDMA_RRC_STATE_DISCONNECTED ∗ WCDMA RRC State is IDLE – 0x01 - NAS_WCDMA_RRC_STATE_CELL_PCH ∗ WCDMA RRC state is CELL_PCH – 0x02 - NAS_WCDMA_RRC_STATE_URA_PCH ∗ WCDMA RRC state is URA_PCH – 0x03 - NAS_WCDMA_RRC_STATE_CELL_FACH ∗ WCDMA RRC state is CELL_FACH – 0x04 - NAS_WCDMA_RRC_STATE_CELL_DCH ∗ WCDMA RRC state is CELL_DCH
umtsLTENbr-CellLen	• Number of sets of UMTS LTE Neighbors.
UMTSLTENbr-Cell	• See nas_umtsLTENbrCell for more information.

8.184.2 Field Documentation

8.184.2.1 nas_umtsLTENbrCell nas_WCDMAInfoLTENeighborCell::UMTSLTENbrCell[255]

8.184.2.2 uint8_t nas_WCDMAInfoLTENeighborCell::umtsLTENbrCellLen

8.184.2.3 uint32_t nas_WCDMAInfoLTENeighborCell::wcdmaRRCState

8.185 nas_WCDMARSSIThresh Struct Reference

Data Fields

- uint8_t WCDMARSSIThreshListLen
- int16_t ∗ pWCDMARSSIThreshList

8.185.1 Detailed Description

This structure contains WCDMA RSSI threshold related parameters.

Parameters

WCDMARSSI-ThreshListLen	• Length of the WCDMA RSSI threshold list parameter to follow
pWCDMARSSI-ThreshList	• Array of RSSI thresholds (in units of 0.1 dBm) • Maximum of 32 values. • Range for RSSI values: -121 to 0 (in dBm)

8.185.2 Field Documentation

8.185.2.1 int16_t* nas_WCDMARSSIThresh::pWCDMARSSIThreshList

8.185.2.2 uint8_t nas_WCDMARSSIThresh::WCDMARSSIThreshListLen

8.186 nas_WCDMASysInfo Struct Reference

Data Fields

- nas_sysInfoCommon sysInfoWCDMA
- uint8_t lacValid
- uint16_t lac
- uint8_t cellIdValid
- uint32_t cellId
- uint8_t regRejectInfoValid
- uint8_t rejectSrvDomain
- uint8_t rejCause
- uint8_t networkIdValid
- uint8_t MCC [3]
- uint8_t MNC [3]
- uint8_t hsCallStatusValid
- uint8_t hsCallStatus
- uint8_t hsIndValid
- uint8_t hsInd
- uint8_t pscValid
- uint16_t psc

8.186.1 Detailed Description

Structure for storing the WCDMA System Information.

Parameters

sysInfoWCDMA	• See nas_sysInfoCommon for more information.
lacValid	• Indicates whether the location area code is valid.. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available

lac	• Location area code. • Only applies to 3GPP. – 0xFFFF - Not Available
cellIdValid	• Indicates whether the cell ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
cellId	• Cell ID. – 0xFFFFFFFF - Not Available
regRejectInfo-Valid	• Indicates whether the registration reject information is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
rejectSrvDomain	• Type of service domain in which the registration is rejected. – 0x00 - SYS_SRV_DOMAIN_NO_SRV - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - Camped – 0xFF - Not Available
rejCause	• Reject cause values sent are specified in [3GPP TS 24.008, Section 10.5.3.6]. – 0xFF - Not Available
networkIdValid	• Indicates whether the network ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
MCC[NAS_PLM-N_LENGTH]	• Mobile Country Code. • MCC digits in ASCII characters
MNC[NAS_PLM-N_LENGTH]	• Mobile Network Code. • MNC digits in ASCII characters • An unused byte is set to 0xFF. • In case of two-digit MNC values, the third (unused) digit is set to 0xFF. For example, 15 (a two-digit MNC) is reported using the byte stream 0x31 0x35 0xFF.

hsCallStatus-Valid	• Indicates whether the high-speed call status is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
hsCallStatus	• Call status on high speed. • Only applicable for WCDMA. – 0x00 - HSDPA and HSUPA are unsupported – 0x01 - HSDPA is supported – 0x02 - HSUPA is supported – 0x03 - HSDPA and HSUPA are supported – 0x04 - HSDPA+ is supported – 0x05 - HSDPA+ and HSUPA are supported – 0x06 - Dual-cell HSDPA+ is supported – 0x07 - Dual-cell HSDPA+ and HSUPA are supported – 0xFF - Not Available
hsIndValid	• Indicates whether high-speed service indication is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
hsInd	• High-speed service indication • Only applicable for WCDMA. – 0x00 - HSDPA and HSUPA are unsupported – 0x01 - HSDPA is supported – 0x02 - HSUPA is supported – 0x03 - HSDPA and HSUPA are supported – 0x04 - HSDPA+ is supported – 0x05 - HSDPA+ and HSUPA are supported – 0x06 - Dual-cell HSDPA+ is supported – 0x07 - Dual-cell HSDPA+ and HSUPA are supported – 0xFF - Not Available
pscValid	• Indicates whether primary scrambling code is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
psc	• Primary scrambling code. – 0xFFFF - Not Available

8.186.2 Field Documentation

8.186.2.1 uint32_t nas_WCDMASysInfo::cellId

8.186.2.2 uint8_t nas_WCDMASysInfo::cellIdValid

8.186.2.3 uint8_t nas_WCDMASysInfo::hsCallStatus

8.186.2.4 uint8_t nas_WCDMASysInfo::hsCallStatusValid

8.186.2.5 uint8_t nas_WCDMASysInfo::hsInd

8.186.2.6 uint8_t nas_WCDMASysInfo::hsIndValid

8.186.2.7 uint16_t nas_WCDMASysInfo::lac

8.186.2.8 uint8_t nas_WCDMASysInfo::lacValid

8.186.2.9 uint8_t nas_WCDMASysInfo::MCC[3]

8.186.2.10 uint8_t nas_WCDMASysInfo::MNC[3]

8.186.2.11 uint8_t nas_WCDMASysInfo::networkIdValid

8.186.2.12 uint16_t nas_WCDMASysInfo::psc

8.186.2.13 uint8_t nas_WCDMASysInfo::pscValid

8.186.2.14 uint8_t nas_WCDMASysInfo::regRejectInfoValid

8.186.2.15 uint8_t nas_WCDMASysInfo::rejCause

8.186.2.16 uint8_t nas_WCDMASysInfo::rejectSrvDomain

8.186.2.17 nas_sysInfoCommon nas_WCDMASysInfo::sysInfoWCDMA

8.187 nas_wcdmaUARFCN Struct Reference

Data Fields

- uint8_t status
- uint32_t uarfcn

8.187.1 Detailed Description

This structure contains WCDMA UARFCN infromation.

Parameters

status	• 0 - Disable • 1 - Enable
uarfcn	• UARFCN to which UE is locked

8.187.2 Field Documentation

8.187.2.1 uint8_t nas_wcdmaUARFCN::status

8.187.2.2 uint32_t nas_wcdmaUARFCN::uarfcn

8.188 NASBandPreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t band_pref

8.188.1 Detailed Description

Structure used to store all Band Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
band_pref	- Roaming Indication Value

8.188.2 Field Documentation

8.188.2.1 uint64_t NASBandPreferenceTlv::band_pref

8.188.2.2 uint8_t NASBandPreferenceTlv::TlvPresent

8.189 NASEmergencyModeTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t EmerMode

8.189.1 Detailed Description

Structure used to store Emergency Mode TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
EmerMode	- Emergency Mode Value

8.189.2 Field Documentation

8.189.2.1 uint8_t NASEmergencyModeTlv::EmerMode

8.189.2.2 uint8_t NASEmergencyModeTlv::TlvPresent

8.190 NasGetLTECphyCaInfo Struct Reference

Data Fields

- NASPhyCaAggScellIndType PhyCaAggScellIndType
- NASPhyCaAggScellDlBw PhyCaAggScellDlBw
- NASPhyCaAggScellInfo PhyCaAggScellInfo
- NASPhyCaAggPcellInfo PhyCaAggPcellInfo
- NASPhyCaAggScellIndex PhyCaAggScellIndex

8.190.1 Detailed Description

This structure contains the parameters for aggregation event information.

Parameters

PhyCaAggScell-IndType	• see NASPhyCaAggScellIndType
PhyCaAggScell-DlBw	• see NASPhyCaAggScellDlBw
PhyCaAggScell-Info	• see NASPhyCaAggScellInfo
PhyCaAggScell-IndType	• see NASPhyCaAggScellIndType
PhyCaAggPcell-Info	• see NASPhyCaAggPcellInfo
PhyCaAggScell-Index	• see NASPhyCaAggScellIndex

8.190.2 Field Documentation

8.190.2.1 NASPhyCaAggPcellInfo NasGetLTECphyCaInfo::PhyCaAggPcellInfo

8.190.2.2 NASPhyCaAggScellDlBw NasGetLTECphyCaInfo::PhyCaAggScellDlBw

8.190.2.3 NASPhyCaAggScellIndex NasGetLTECphyCaInfo::PhyCaAggScellIndex

8.190.2.4 NASPhyCaAggScellIndType NasGetLTECphyCaInfo::PhyCaAggScellIndType

8.190.2.5 NASPhyCaAggScellInfo NasGetLTECphyCaInfo::PhyCaAggScellInfo

8.191 NASGWAcqOrderPrefTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t GWAcqOrderPref

8.191.1 Detailed Description

Structure used to store GSM/WCDMA acquisition order preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
GWAcqOrder-Pref	- GSM/WCDMA acquisition order Preference Value

8.191.2 Field Documentation

8.191.2.1 uint32_t NASGWAcqOrderPrefTlv::GWAcqOrderPref

8.191.2.2 uint8_t NASGWAcqOrderPrefTlv::TlvPresent

8.192 NASLTEBandPreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t LTEBandPref

8.192.1 Detailed Description

Structure used to store LTE Band Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
LTEBandPref	- LTE Band Preference Value

8.192.2 Field Documentation

8.192.2.1 uint64_t NASLTEBandPreferenceTlv::LTEBandPref

8.192.2.2 uint8_t NASLTEBandPreferenceTlv::TlvPresent

8.193 NASLteNasReleaseInfoTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t nas_release
- uint8_t nas_major
- uint8_t nas_minor

8.193.1 Detailed Description

This structure contains LTE Nas Release Infomation

Parameters

Tlvresult	• unpack result
nas_release	• LTE NAS release
nas_major	• LTE NAS version major
nas_minor	• LTE NAS version minor

8.193.2 Field Documentation

8.193.2.1 uint8_t NASLteNasReleaseInfoTlv::nas_major

8.193.2.2 uint8_t NASLteNasReleaseInfoTlv::nas_minor

8.193.2.3 uint8_t NASLteNasReleaseInfoTlv::nas_release

8.193.2.4 uint8_t NASLteNasReleaseInfoTlv::TlvPresent

8.194 NASModePreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t ModePref

8.194.1 Detailed Description

Structure used to store Mode Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
ModePref	- Mode Preference Value

8.194.2 Field Documentation

8.194.2.1 uint16_t NASModePreferenceTlv::ModePref

8.194.2.2 uint8_t NASModePreferenceTlv::TlvPresent

8.195 NASNetSelPreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t NetSelPref

8.195.1 Detailed Description

Structure used to store Network Selection Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
NetSelPref	- Network Selection Preference Value

8.195.2 Field Documentation

8.195.2.1 uint8_t NASNetSelPreferenceTlv::NetSelPref

8.195.2.2 uint8_t NASNetSelPreferenceTlv::TlvPresent

8.196 NASOTAMessageTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t message_type
- uint16_t data_len
- uint8_t data_buf [2048]

8.196.1 Detailed Description

This structure contains OTA message

Parameters

Tlvresult	• unpack result
message_type	• message type – 0 - LTE ESM uplink – 1 - LTE ESM downlink – 2 - LTE EMM uplink – 3 - LTE EMM downlink – 4 - GSM/UMTS uplink – 5 - GSM/UMTS downlink
data_len	• OTA Message Content Length
data_buf	• OTA Message Content

8.196.2 Field Documentation

8.196.2.1 uint8_t NASOTAMessageTlv::data_buf[2048]

8.196.2.2 uint16_t NASOTAMessageTlv::data_len

8.196.2.3 uint32_t NASOTAMessageTlv::message_type

8.196.2.4 uint8_t NASOTAMessageTlv::TlvPresent

8.197 NASPhyCaAggPcellInfo Struct Reference

Data Fields

- uint32_t pci
- uint32_t freq
- LITEQMI_NAS_LTE_CPHY_CA_BW_NRB dl_bw_value
- uint32_t iLTEbandValue
- uint8_t TlvPresent

8.197.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Pcell Information.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
dl_bw_value	• Downlink Bandwidth Values. • See LITEQMI_NAS_LTE_CPHY_CA_BW_NRB for more information.
scell_state	• Scell state Values. • See LITEQMI_NAS_LTE_CPHY_SCELL_STATE for more information.
TlvPresent	• Tlv Present.

8.197.2 Field Documentation

8.197.2.1 LITEQMI_NAS_LTE_CPHY_CA_BW_NRB NASPhyCaAggPcellInfo::dl_bw_value

8.197.2.2 uint32_t NASPhyCaAggPcellInfo::freq

8.197.2.3 uint32_t NASPhyCaAggPcellInfo::iLTEbandValue

8.197.2.4 uint32_t NASPhyCaAggPcellInfo::pci

8.197.2.5 uint8_t NASPhyCaAggPcellInfo::TlvPresent

8.198 NASPhyCaAggScellDlBw Struct Reference

Data Fields

- LITEQMI_NAS_LTE_CPHY_CA_BW_NRB dl_bw_value
- uint8_t TlvPresent

8.198.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation Downlink Bandwidth of Scell.

Parameters

dl_bw_value	• Downlink Bandwidth Values. • See LITEQMI_NAS_LTE_CPHY_CA_BW_NRB for more information.

8.198.2 Field Documentation

8.198.2.1 LITEQMI_NAS_LTE_CPHY_CA_BW_NRB NASPhyCaAggScellDlBw::dl_bw_value

8.198.2.2 uint8_t NASPhyCaAggScellDlBw::TlvPresent

8.199 NASPhyCaAggScellIndex Struct Reference

Data Fields

- uint8_t scell_idx
- uint8_t TlvPresent

8.199.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Index.

Parameters

scell_idx	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
TlvPresent	• Tlv Present.

8.199.2 Field Documentation

8.199.2.1 uint8_t NASPhyCaAggScellIndex::scell_idx

8.199.2.2 uint8_t NASPhyCaAggScellIndex::TlvPresent

8.200 NASPhyCaAggScellIndType Struct Reference

Data Fields

- uint32_t pci
- uint32_t freq
- LITEQMI_NAS_LTE_CPHY_SCELL_STATE scell_state
- uint8_t TlvPresent

8.200.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Indeicator Type.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
scell_state	• Scell state Values. • See LITEQMI_NAS_LTE_CPHY_SCELL_STATE for more information.
TlvPresent	• Tlv Present.

8.200.2 Field Documentation

8.200.2.1 uint32_t NASPhyCaAggScellIndType::freq

8.200.2.2 uint32_t NASPhyCaAggScellIndType::pci

8.200.2.3 LITEQMI_NAS_LTE_CPHY_SCELL_STATE NASPhyCaAggScellIndType::scell_state

8.200.2.4 uint8_t NASPhyCaAggScellIndType::TlvPresent

8.201 NASPhyCaAggScellInfo Struct Reference

Data Fields

- uint32_t pci
- uint32_t freq
- LITEQMI_NAS_LTE_CPHY_CA_BW_NRB dl_bw_value
- uint32_t iLTEbandValue
- LITEQMI_NAS_LTE_CPHY_SCELL_STATE scell_state
- uint8_t TlvPresent

8.201.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Information.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
dl_bw_value	• Downlink Bandwidth Values. • See LITEQMI_NAS_LTE_CPHY_CA_BW_NRB for more information.
iLTEbandValue	• Band value. • Range for LTE Band class 120 to 160.
scell_state	• Scell state Values. • See LITEQMI_NAS_LTE_CPHY_SCELL_STATE for more information.
TlvPresent	• Tlv Present.

8.201.2 Field Documentation

8.201.2.1 LITEQMI_NAS_LTE_CPHY_CA_BW_NRB NASPhyCaAggScellInfo::dl_bw_value

8.201.2.2 uint32_t NASPhyCaAggScellInfo::freq

8.201.2.3 uint32_t NASPhyCaAggScellInfo::iLTEbandValue

8.201.2.4 uint32_t NASPhyCaAggScellInfo::pci

8.201.2.5 LITEQMI_NAS_LTE_CPHY_SCELL_STATE NASPhyCaAggScellInfo::scell_state

8.201.2.6 uint8_t NASPhyCaAggScellInfo::TlvPresent

8.202 NASPRLPreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t PRLPref

8.202.1 Detailed Description

Structure used to store CDMA PRL Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
PRLPref	- CDMA PRL Preference Value

8.202.2 Field Documentation

8.202.2.1 uint16_t NASPRLPreferenceTlv::PRLPref

8.202.2.2 uint8_t NASPRLPreferenceTlv::TlvPresent

8.203 NASQmiCbkNasSwiOTAMessageInd Struct Reference

Data Fields

- NASOTAMessageTlv otaMsgTlv
- NASLteNasReleaseInfoTlv nasRelInfoTlv
- NASTimeInfoTlv timeTlv

8.203.1 Detailed Description

This structure contains OTA message

Parameters

otaMsgTlv	• See NASOTAMessageTlv for more details
nasRelInfoTlv	• See NASLteNasReleaseInfoTlv for more details
timeTlv	• See NASTimeInfoTlv for more details

8.203.2 Field Documentation

8.203.2.1 NASLteNasReleaseInfoTlv NASQmiCbkNasSwiOTAMessageInd::nasRelInfoTlv

8.203.2.2 NASOTAMessageTlv NASQmiCbkNasSwiOTAMessageInd::otaMsgTlv

8.203.2.3 NASTimeInfoTlv NASQmiCbkNasSwiOTAMessageInd::timeTlv

8.204 NASQmiCbkNasSystemSelPrefInd Struct Reference

Data Fields

- NASEmergencyModeTlv EMTlv
- NASModePreferenceTlv MPTlv
- NASBandPreferenceTlv BPTlv
- NASPRLPreferenceTlv PRLPTlv
- NASRoamPreferenceTlv RPTlv
- NASLTEBandPreferenceTlv LBPTlv

- NASNetSelPreferenceTlv NSPTlv
- NASServDomainPrefTlv SDPTlv
- NASGWAcqOrderPrefTlv GWAOPTlv

8.204.1 Detailed Description

Structure used to store all QMI Notification parameters.

Parameters

EMTlv	- Emergency mode Tlv • See NASEmergencyModeTlv for more details
MPTlv	- Mode preference Tlv • See NASModePreferenceTlv for more details
BPTlv	- Band preference Tlv • See NASBandPreferenceTlv for more details
PRLPTlv	- PRL preference Tlv • See NASPRLPreferenceTlv for more details
RPTlv	- Roaming preference Tlv • See NASRoamPreferenceTlv for more details
LBPTlv	- LTE band preference Tlv • See NASLTEBandPreferenceTlv for more details
NSPTlv	- Network selection preference Tlv • See NASNetSelPreferenceTlv for more details
SDPTlv	- Service domain preference Tlv • See NASServDomainPrefTlv for more details
GWAOPTlv	- GSM WCDMA Acquisition Order Preference Tlv • See NASGWAcqOrderPrefTlv for more details

Note: None

8.204.2 Field Documentation

8.204.2.1 NASBandPreferenceTlv NASQmiCbkNasSystemSelPrefInd::BPTlv

8.204.2.2 NASEmergencyModeTlv NASQmiCbkNasSystemSelPrefInd::EMTlv

8.204.2.3 NASGWAcqOrderPrefTlv NASQmiCbkNasSystemSelPrefInd::GWAOPTlv

8.204.2.4 NASLTEBandPreferenceTlv NASQmiCbkNasSystemSelPrefInd::LBPTlv

8.204.2.5 NASModePreferenceTlv NASQmiCbkNasSystemSelPrefInd::MPTlv

8.204.2.6 NASNetSelPreferenceTlv NASQmiCbkNasSystemSelPrefInd::NSPTlv

8.204.2.7 NASPRLPreferenceTlv NASQmiCbkNasSystemSelPrefInd::PRLPTlv

8.204.2.8 NASRoamPreferenceTlv NASQmiCbkNasSystemSelPrefInd::RPTlv

8.204.2.9 NASServDomainPrefTlv NASQmiCbkNasSystemSelPrefInd::SDPTlv

8.205 NASRoamPreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t RoamPref

8.205.1 Detailed Description

Structure used to store Roaming Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
RoamPref	- Roaming Preference Value

8.205.2 Field Documentation

8.205.2.1 uint16_t NASRoamPreferenceTlv::RoamPref

8.205.2.2 uint8_t NASRoamPreferenceTlv::TlvPresent

8.206 NASServDomainPrefTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t SrvDomainPref

8.206.1 Detailed Description

Structure used to store Service domain preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
SrvDomainPref	- Service Domain Preference Value

8.206.2 Field Documentation

8.206.2.1 uint32_t NASServDomainPrefTlv::SrvDomainPref

8.206.2.2 uint8_t NASServDomainPrefTlv::TlvPresent

8.207 NASServingSystemInfo Struct Reference

Data Fields

- uint8_t registrationState
- uint8_t csAttachState
- uint8_t psAttachState
- uint8_t selectedNetwork
- uint8_t radioInterfaceNo
- uint8_t radioInterfaceList [255]
- uint8_t hdrPersonality

8.207.1 Detailed Description

This structure will hold the serving system parameters information

Parameters

registrationState	- Registration state of the mobile • 0 - QMI_NAS_NOT_REGISTERED Not registered;mobile is not currently searching for a new network to provide service • 1 - QMI_NAS_REGISTERED Registered with a network • 2 - QMI_NAS_NOT_REGISTERED_SEARCHING Not registered, but mobile is currently searching for a new network to provide service • 3 - QMI_NAS_REGISTRATION_DENIED Registration denied by the visible network • 4 - QMI_NAS_REGISTRATION_UNKNOWN Registration state is unknown
csAttachState	- Circuit Switch domain attach state of the mobile • 0 - Unknown or not applicable • 1 - Attached • 2 - Detached
psAttachState	- Packet domain attach state of the mobile • 0 - Unknown or not applicable • 1 - Attached • 2 - Detached
selectedNetwork	- Type of selected radio access network • 0x00 - Unknown • 0x01 - 3GPP2 network • 0x02 - 3GPP network
radioInterfaceNo	- Number of radio interfaces currently in use; this indicates how many radio_if identifiers follow this field
radioInterface-List	- Radio interface currently in use (each is 1 byte) • 0x00 - None (no service) • 0x01 - cdma2000 1X • 0x02 - cdma2000 HRPD (1xEV-DO) • 0x03 - AMPS • 0x04 - GSM • 0x05 - UMTS • 0x08 - LTE

hdrPersonality	- HDR personality information (valid only for EVDO) • 0x00 - Unknown • 0x01 - HRPD • 0x02 - eHRPD

Note: None

8.207.2 Field Documentation

8.207.2.1 uint8_t NASServingSystemInfo::csAttachState

8.207.2.2 uint8_t NASServingSystemInfo::hdrPersonality

8.207.2.3 uint8_t NASServingSystemInfo::psAttachState

8.207.2.4 uint8_t NASServingSystemInfo::radioInterfaceList[255]

8.207.2.5 uint8_t NASServingSystemInfo::radioInterfaceNo

8.207.2.6 uint8_t NASServingSystemInfo::registrationState

8.207.2.7 uint8_t NASServingSystemInfo::selectedNetwork

8.208 NASTimeInfoTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t time

8.208.1 Detailed Description

This structure contains LTE Nas time Infomation

Parameters

Tlvresult	• unpack result
time	• Seconds in local time since Jan. 6th 1980 00:00:00 UTC

8.208.2 Field Documentation

8.208.2.1 uint64_t NASTimeInfoTlv::time

8.208.2.2 uint8_t NASTimeInfoTlv::TlvPresent

8.209 newMTMessageTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSMTMessageInfo MTMessageInfo

8.209.1 Detailed Description

This structure contains MT message TLV information.

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
MTMessageInfo	• MT Message • See sMSMTMessageInfo for more information

8.209.2 Field Documentation

8.209.2.1 sMSMTMessageInfo newMTMessageTlv::MTMessageInfo

8.209.2.2 uint8_t newMTMessageTlv::TlvPresent

8.210 pack_audio_SLQSGetAudioPathConfig_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Item

8.210.1 Detailed Description

This structure contains the pack parameters for Get Audio Path Config.

Parameters

Profile	• Audio Profile – 0-9
Item	• Item – 0 - AV_EC – 1 - AV_NS – 2 - AV_TXVOL – 3 - AV_DTMFTXG – 4 - AV_CODECSTG – 5 - AV_TXPCMIIRFLTR – 6 - AV_RXPCMIIRFLTR – 7 - AV_MICGAIN – 8 - AV_RXAGC – 9 - AV_TXAGC – 10 - AV_RXAGCLIST – 11 - AV_RXAVCLIST – 12 - AV_TXAGCLIST

8.210.2 Field Documentation

8.210.2.1 uint8_t pack_audio_SLQSGetAudioPathConfig_t::Item

8.210.2.2 uint8_t pack_audio_SLQSGetAudioPathConfig_t::Profile

8.211 pack_audio_SLQSGetAudioProfile_t Struct Reference

Data Fields

- uint8_t Generator

8.211.1 Detailed Description

This structure contains the pack parameters to Get Audio Profile.

Parameters

Generator	• Audio Generator – 0 - Voice – 1 - Key Beep – 2 - MIDI

8.211.2 Field Documentation

8.211.2.1 uint8_t pack_audio_SLQSGetAudioProfile_t::Generator

8.212 pack_audio_SLQSGetAudioVolTLBConfig_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Generator
- uint8_t Volume
- uint8_t Item

8.212.1 Detailed Description

This structure contains the pack parameters for SLQSGetAudioVolTLBConfig.

Parameters

Profile	• Audio Profile – 0-9
Generator	• Audio Generator – 0-2
Volume	• Audio Volume Level – 0-7
Item	• Item – 13 - AV_RXVOLDB – 14 - AV_DTMFVOLDB – 15 - AV_PAD

8.212.2 Field Documentation

8.212.2.1 uint8_t pack_audio_SLQSGetAudioVolTLBConfig_t::Generator

8.212.2.2 uint8_t pack_audio_SLQSGetAudioVolTLBConfig_t::Item

8.212.2.3 uint8_t pack_audio_SLQSGetAudioVolTLBConfig_t::Profile

8.212.2.4 uint8_t pack_audio_SLQSGetAudioVolTLBConfig_t::Volume

8.213 pack_audio_SLQSSetAudioPathConfig_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t * pECMode
- uint8_t * pNSEnable
- uint16_t * pTXGain
- uint16_t * pDTMFTXGain

- uint16_t * pCodecSTGain
- audio_TXPCMIIRFltr * pTXPCMIIRFltr
- audio_RXPCMIIRFltr * pRXPCMIIRFltr
- uint8_t * pRXAVCAGCSwitch
- uint8_t * pTXAVCSwitch
- audio_RXAGCList * pRXAGCList
- audio_RXAVCList * pRXAVCList
- audio_TXAGCList * pTXAGCList

8.213.1 Detailed Description

This structure contains the pack parameters for SLQSSetAudioPathConfig .

Parameters

Profile	[Mandatory] • Audio Profile – 0-9
pECMode	[Optional] • AV_EC – 0 - Echo cancellation off – 1 - Handset echo mode – 2 - Headset mode – 3 - Car kit mode – 4 - Speaker Mode
pNSEnable	[Optional] • Noise Suppression – 0 - Noise suppression off – 1 - Noise suppression on
pTXGain	[Optional] • TX Voice volume – 0x0000 - 0xffff
pDTMFTXGain	[Optional] • AV_DTMFTXG – 0x0000 - 0xffff
pCodecSTGain	[Optional] • AV_CODECSTG – 0x0000 - 0xffff
pTXPCMIIRFltr	[Optional] • See audio_TXPCMIIRFltr for more information
pRXPCMIIRFltr	[Optional] • See audio_RXPCMIIRFltr for more information
pRXAVCAGC-Switch	[Optional] • RX AVC/AGC Switch

pTXAVCSwitch	[Optional] • TX AVC Switch
pRXAGCList	[Optional] • See audio_RXAGCList for more information
pRXAVCList	[Optional] • See audio_RXAVCList for more information
pTXAGCList	[Optional] • See audio_TXAGCList for more information

8.213.2 Field Documentation

8.213.2.1 uint16_t* pack_audio_SLQSSetAudioPathConfig_t::pCodecSTGain

8.213.2.2 uint16_t* pack_audio_SLQSSetAudioPathConfig_t::pDTMFTXGain

8.213.2.3 uint8_t* pack_audio_SLQSSetAudioPathConfig_t::pECMode

8.213.2.4 uint8_t* pack_audio_SLQSSetAudioPathConfig_t::pNSEnable

8.213.2.5 uint8_t pack_audio_SLQSSetAudioPathConfig_t::Profile

8.213.2.6 audio_RXAGCList* pack_audio_SLQSSetAudioPathConfig_t::pRXAGCList

8.213.2.7 uint8_t* pack_audio_SLQSSetAudioPathConfig_t::pRXAVCAGCSwitch

8.213.2.8 audio_RXAVCList* pack_audio_SLQSSetAudioPathConfig_t::pRXAVCList

8.213.2.9 audio_RXPCMIIRFltr* pack_audio_SLQSSetAudioPathConfig_t::pRXPCMIIRFltr

8.213.2.10 audio_TXAGCList* pack_audio_SLQSSetAudioPathConfig_t::pTXAGCList

8.213.2.11 uint8_t* pack_audio_SLQSSetAudioPathConfig_t::pTXAVCSwitch

8.213.2.12 uint16_t* pack_audio_SLQSSetAudioPathConfig_t::pTXGain

8.213.2.13 audio_TXPCMIIRFltr* pack_audio_SLQSSetAudioPathConfig_t::pTXPCMIIRFltr

8.214 pack_audio_SLQSSetAudioProfile_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t EarMute
- uint8_t MicMute
- uint8_t Generator
- uint8_t Volume

8.214.1 Detailed Description

This structure contains pack parameters to Set Audio Profile.

Parameters

Profile	• Audio Profile – 0 - Handset – 1 - Headset – 2 - Car Kit – 3 - Speaker phone – 4 - Auxiliary – 5 - TTY – 6 - Auxiliary external PCM – 7 - Primary external PCM – 8 - External slave PCM – 9 - I2S
EarMute	• Ear Mute Setting – 0 - unmuted – 1 - muted
MicMute	• MIC Mute Setting – 0 - unmuted – 1 - muted
Generator	• Audio Generator – 0 - Voice – 1 - Key Beep – 2 - MIDI
Volume	• Audio Volume Level – 0 to 7

8.214.2 Field Documentation

8.214.2.1 uint8_t pack_audio_SLQSSetAudioProfile_t::EarMute

8.214.2.2 uint8_t pack_audio_SLQSSetAudioProfile_t::Generator

8.214.2.3 uint8_t pack_audio_SLQSSetAudioProfile_t::MicMute

8.214.2.4 uint8_t pack_audio_SLQSSetAudioProfile_t::Profile

8.214.2.5 uint8_t pack_audio_SLQSSetAudioProfile_t::Volume

8.215 pack_audio_SLQSSetAudioVolTLBConfig_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Generator
- uint8_t Volume
- uint8_t Item
- uint16_t VolValue

8.215.1 Detailed Description

This structure contains the pack parameters for SLQSSetAudioVolTLBConfig.

Parameters

Profile	• Audio Profile – 0-9
Generator	• Audio Generator – 0-2
Volume	• Audio Volume Level – 0-7
Item	• Item – 13 - AV_RXVOLDB – 14 - AV_DTMFVOLDB – 15 - AV_PAD
Value	• Value to be set to the volume table

8.215.2 Field Documentation

8.215.2.1 uint8_t pack_audio_SLQSSetAudioVolTLBConfig_t::Generator

8.215.2.2 uint8_t pack_audio_SLQSSetAudioVolTLBConfig_t::Item

8.215.2.3 uint8_t pack_audio_SLQSSetAudioVolTLBConfig_t::Profile

8.215.2.4 uint8_t pack_audio_SLQSSetAudioVolTLBConfig_t::Volume

8.215.2.5 uint16_t pack_audio_SLQSSetAudioVolTLBConfig_t::VolValue

8.216 pack_cat_CATSendEnvelopeCommand_t Struct Reference

Data Fields

- uint32_t cmdID
- uint32_t dataLen
- uint8_t * pData

8.216.1 Detailed Description

Structure used to store envelope command data.

Parameters

cmdID	• Envelope command type – 0x01 - Menu Selection – 0x02 - Event DL User activity – 0x03 - Event DL Idle Screen Available – 0x04 - Event DL Language Selection
dataLen	• Length of pData in bytes
pData	• Encoded envelope data as defined in ETSI TS 102 223, section 7 [Smart Cards: Card Application Toolkit (CAT) – Release 4]

8.216.2 Field Documentation

8.216.2.1 uint32_t pack_cat_CATSendEnvelopeCommand_t::cmdID

8.216.2.2 uint32_t pack_cat_CATSendEnvelopeCommand_t::dataLen

8.216.2.3 uint8_t* pack_cat_CATSendEnvelopeCommand_t::pData

8.217 pack_cat_CATSendTerminalResponse_t Struct Reference

Data Fields

- uint32_t refID
- uint32_t dataLen
- uint8_t * pData

8.217.1 Detailed Description

Structure used to terminal response data.

Parameters

refID	• Proactive command reference ID. The value should be the same as indicated in the CAT event callback data for the relevant proactive command.

dataLen	• Terminal response data length
pData	• Terminal response for the relevant proactive command encoded as per ETSI TS 102 223, section 6.8 [Smart Cards: Card Application Toolkit (CAT) – Release 4]

8.217.2 Field Documentation

8.217.2.1 uint32_t pack_cat_CATSendTerminalResponse_t::dataLen

8.217.2.2 uint8_t* pack_cat_CATSendTerminalResponse_t::pData

8.217.2.3 uint32_t pack_cat_CATSendTerminalResponse_t::refID

8.218 pack_cat_SetCATEventCallback_t Struct Reference

Data Fields

- uint32_t eventMask

8.218.1 Detailed Description

This structure contains sEnables/disables the CAT event callback pack variable.

Parameters

eventMask	• bitmask of CAT events to register for – 0x00000001 - Display Text – 0x00000002 - Get In-Key – 0x00000004 - Get Input – 0x00000008 - Setup Menu – 0x00000010 - Select Item – 0x00000020 - Send SMS - Alpha Identifier – 0x00000040 - Setup Event: User Activity – 0x00000080 - Setup Event: Idle Screen Notify – 0x00000100 - Setup Event: Language Sel Notify – 0x00000200 - Setup Idle Mode Text – 0x00000400 - Language Notification – 0x00000800 - Refresh – 0x00001000 - End Proactive Session

8.218.2 Field Documentation

8.218.2.1 uint32_t pack_cat_SetCATEventCallback_t::eventMask

8.219 pack_dms_ActivateAutomatic_t Struct Reference

Data Fields

- uint8_t actCode [81]

8.219.1 Detailed Description

This structure contains UIM activate automation information

Parameters

actCode	• NULL-terminated string representing activation code (maximum string length of 12). • Specific carrier requirements may dictate actual activation code that is applicable, e.g., "∗22899"

8.219.2 Field Documentation

8.219.2.1 uint8_t pack_dms_ActivateAutomatic_t::actCode[81]

8.220 pack_dms_GetCustFeaturesV2_t Struct Reference

Data Fields

- uint8_t cust_id [64+1]
- uint8_t list_type
- uint16_t Tlvresult

8.220.1 Detailed Description

This structure contains which customization id or the list type want to retrieve from modem. This TLV is only applicable for 9x30 modules so far

Parameters

cust_id	• Customization ID (Maximum 64 bytes) • NULL terminated ASCII string.
list_type	• list type requested
Tlvresult	• Pack Result

8.220.2 Field Documentation

8.220.2.1 uint8_t pack_dms_GetCustFeaturesV2_t::cust_id[64+1]

8.220.2.2 uint8_t pack_dms_GetCustFeaturesV2_t::list_type

8.220.2.3 uint16_t pack_dms_GetCustFeaturesV2_t::Tlvresult

8.221 pack_dms_ResetToFactoryDefaults_t Struct Reference

Data Fields

- uint8_t spc [6]

8.221.1 Detailed Description

This structure contains UIM reset to factory default information

Parameters

spc[IN]	• Service programming code in ASCII format (digits 0 to 9 only)

8.221.2 Field Documentation

8.221.2.1 uint8_t pack_dms_ResetToFactoryDefaults_t::spc[6]

8.222 pack_dms_SetActivationStatusCallback_t Struct Reference

Data Fields

- uint8_t activationState

8.222.1 Detailed Description

This structure is used to store Set Service Activation Status callback parameter pack.

Parameters

activationState	• Service activation state. • Values – 0 - Do not report – 1 - Report activation state changes

8.222.2 Field Documentation

8.222.2.1 uint8_t pack_dms_SetActivationStatusCallback_t::activationState

8.223 pack_dms_SetCrashAction_t Struct Reference

Data Fields

- uint8_t crashAction

8.223.1 Detailed Description

This structure is used to store pack_dms_SetCrashAction parameters.

Parameters

crashAction	• 0 - USB Memory Download. Modem will reset after a crash and will stay in USB download mode with only DM port enumerated. • 1 - Reset. Modem will reset and come back in ONLINE mode. Minimal crash data will be available and can be extracted with at!gcdump? AT command • 2 - No Action

8.223.2 Field Documentation

8.223.2.1 uint8_t pack_dms_SetCrashAction_t::crashAction

8.224 pack_dms_SetCustFeature_t Struct Reference

Data Fields

- uint32_t GpsEnable
- uint8_t DisableIMSI
- uint16_t IPFamSupport
- uint8_t RMAutoConnect
- uint8_t GPSSel
- uint8_t SMSSupport
- uint8_t IsVoiceEnabled
- uint8_t DHCPRelayEnabled
- uint8_t GPSLPM

8.224.1 Detailed Description

This structure contains current settings of custom features pack parameters

Parameters

GpsEnable	• describes if GPS is enabled or disabled • values: – 0x00 - GPS is disabled – 0x01 - GPS is enabled
DisableIMSI	• optional 1 byte parameter • describes if IMSI display is enabled or disabled • values: – 0x00 - Allow display of IMSI – 0x01 - Do not display IMSI

IPFamSupport	• optional 2 byte BitMask • bitmask representing the IP families supported • values: – 0x01 - IPv4 – 0x02 - IPv6 – 0x04 - IPv4v6
RMAutoConnect	• optional 1 byte parameter • QMI Mode RM Net Auto Connect Support • values: – 0x00 - Not Supported – 0x01 - Supported
GPSSel	• optional 1 byte parameter • GPS Antenna Select • values: – 0x00 - Dedicated GPS Port – 0x01 - GPS Rx over AUX Port – 0x02 - GPS Rx over dedicated GPS port with no bias voltage applied
SMSSupport	• optional 1 byte parameter • SMS support • values: – 0x00 - Not supported – 0x01 - supported • Used to determine whether or not to hide SMS from user
IsVoiceEnabled	• optional 1 byte parameter • Voice support • values: – 0x00 - Enable voice on both AT and QMI interface (default) – 0x01 - Reserved – 0x02 - Disable voice on both AT and QMI interface
DHCPRelay-Enabled	• optional 1 byte parameter • DHCP Relay support • values: – 0x00 - Disable DHCP relay – 0x01 - Enable DHCP relay

GPSLPM	• optional 1 byte parameter • GPSLPM support • values: – 0x00 - Enable GPS in Low Power Mode – 0x01 - Disable GPS in Low Power Mode

8.224.2 Field Documentation

8.224.2.1 uint8_t pack_dms_SetCustFeature_t::DHCPRelayEnabled

8.224.2.2 uint8_t pack_dms_SetCustFeature_t::DisableIMSI

8.224.2.3 uint32_t pack_dms_SetCustFeature_t::GpsEnable

8.224.2.4 uint8_t pack_dms_SetCustFeature_t::GPSLPM

8.224.2.5 uint8_t pack_dms_SetCustFeature_t::GPSSel

8.224.2.6 uint16_t pack_dms_SetCustFeature_t::IPFamSupport

8.224.2.7 uint8_t pack_dms_SetCustFeature_t::IsVoiceEnabled

8.224.2.8 uint8_t pack_dms_SetCustFeature_t::RMAutoConnect

8.224.2.9 uint8_t pack_dms_SetCustFeature_t::SMSSupport

8.225 pack_dms_SetCustFeaturesV2_t Struct Reference

Data Fields

- uint8_t cust_id [64+1]
- uint16_t value_length
- uint8_t cust_value [8+1]
- uint16_t Tlvresult

8.225.1 Detailed Description

This structure contains customization settings set to modem pack

Parameters

cust_id	• Customization ID (Maximum 64 bytes) • NULL terminated ASCII string.
value_length	• length of cust_value field
cust_value	• Customization Setting Value (Maximum 8 bytes)

Tlvresult	• Pack Result

8.225.2 Field Documentation

8.225.2.1 uint8_t pack_dms_SetCustFeaturesV2_t::cust_id[64+1]

8.225.2.2 uint8_t pack_dms_SetCustFeaturesV2_t::cust_value[8+1]

8.225.2.3 uint16_t pack_dms_SetCustFeaturesV2_t::Tlvresult

8.225.2.4 uint16_t pack_dms_SetCustFeaturesV2_t::value_length

8.226 pack_dms_SetEventReport_t Struct Reference

Data Fields

- uint8_t mode

8.226.1 Detailed Description

This structure is used to store pack_dms_SetEventReport parameters.

Parameters

mode	• Operating Mode • 0 - reset • 1 - set • 2 - no change

8.226.2 Field Documentation

8.226.2.1 uint8_t pack_dms_SetEventReport_t::mode

8.227 pack_dms_SetPower_t Struct Reference

Data Fields

- uint32_t mode
- uint16_t Tlvresult

8.227.1 Detailed Description

Structure to store pack the operating mode of the device.

Parameters

mode	• Selected operating mode – See qaGobiApiTablePowerModes.h for power modes
TlvResult	• pack Tlv Result.

8.227.2 Field Documentation

8.227.2.1 uint32_t pack_dms_SetPower_t::mode

8.227.2.2 uint16_t pack_dms_SetPower_t::TlvResult

8.228 pack_dms_SetUSBComp_t Struct Reference

Data Fields

- uint8_t USBComp
- uint16_t TlvResult

8.228.1 Detailed Description

This structure is used to store USB composition information pack paramters

Parameters

USBComp	• Current USB Composition • Values: – 0..5 - Reserved (non-QMI) – 6 - DM NMEA AT QMI – 7 - DM NMEA AT QMI1 QMI2 QMI3 – 8 - DM NMEA AT MBIM – 9 - MBIM – 10 - NMEA MBIM – 11 - DM MBIM – 12 - DM NMEA MBIM 13-22 are combined compositions. One is for Win8 MBIM interfaces, another is for legacy QMI interfaces – 13 - 6 for QMI, 8 for MBIM – 14 - 6 for QMI, 9 for MBIM – 15 - 6 for QMI, 10 for MBIM – 16 - 6 for QMI, 11 for MBIM – 17 - 6 for QMI, 12 for MBIM – 18 - 7 for QMI, 8 for MBIM – 19 - 7 for QMI, 9 for MBIM – 20 - 7 for QMI, 10 for MBIM – 21 - 7 for QMI, 11 for MBIM – 22 - 7 for QMI, 12 for MBIM

Tlvresult	• pack Tlv Result.

8.228.2 Field Documentation

8.228.2.1 uint16_t pack_dms_SetUSBComp_t::Tlvresult

8.228.2.2 uint8_t pack_dms_SetUSBComp_t::USBComp

8.229 pack_dms_SLQSDmsSwiIndicationRegister_t Struct Reference

Data Fields

- uint8_t resetInfoInd

8.229.1 Detailed Description

This structure contains set registration state for different indication pack

Parameters

resetInfoInd[IN]	• Values – 0 - Disable – 1 - Enable

8.229.2 Field Documentation

8.229.2.1 uint8_t pack_dms_SLQSDmsSwiIndicationRegister_t::resetInfoInd

8.230 pack_dms_SLQSSwiGetCrashInfo_t Struct Reference

Data Fields

- uint8_t clear

8.230.1 Detailed Description

This structure contains pack_dms_SLQSSwiGetCrashInfo parameters

Parameters

clear	• 0 - do not clear crash data after response • 1 - clear crash data after response

8.230.2 Field Documentation

8.230.2.1 uint8_t pack_dms_SLQSSwiGetCrashInfo_t::clear

8.231 pack_dms_SLQSSwiSetDyingGaspCfg_t Struct Reference

Data Fields

- uint8_t * pDestSMSNum
- uint8_t * pDestSMSContent

8.231.1 Detailed Description

This structure is used to store pack_dms_SLQSSwiSetDyingGaspCfg parameters

Parameters

pDestSMSNum[IN]	• SMS Destination Number as string of 8 bit ASCII Characters Max 20 chars. • Optional parameter.
pDestSMSContent[IN]	• SMS COntent as a string of 8 bit ASCII text characters Max 160 chars. • Optional parameter.

8.231.2 Field Documentation

8.231.2.1 uint8_t* pack_dms_SLQSSwiSetDyingGaspCfg_t::pDestSMSContent

8.231.2.2 uint8_t* pack_dms_SLQSSwiSetDyingGaspCfg_t::pDestSMSNum

8.232 pack_dms_SLQSSwiSetHostDevInfo_t Struct Reference

Data Fields

- char manString [255]
- char modelString [255]
- char swVerString [255]
- char plasmaIDString [255]

8.232.1 Detailed Description

This structure contains SWI set host device info unpack information

Parameters

manString[IN]	• Host Device Manufacturer Name • Null terminated ASCII String
modelString[IN]	• Host Device Model String • Null terminated ASCII string.

swVerString[IN]	• Host Device Software Version String • Null terminated ASCII string
plasmaIDString[-IN]	• Host Device Plasma ID String • Null terminated alphanumeric ASCII string

8.232.2 Field Documentation

8.232.2.1 char pack_dms_SLQSSwiSetHostDevInfo_t::manString[255]

8.232.2.2 char pack_dms_SLQSSwiSetHostDevInfo_t::modelString[255]

8.232.2.3 char pack_dms_SLQSSwiSetHostDevInfo_t::plasmaIDString[255]

8.232.2.4 char pack_dms_SLQSSwiSetHostDevInfo_t::swVerString[255]

8.233 pack_dms_SLQSSwiSetOSInfo_t Struct Reference

Data Fields

- char nameString [255]
- char versionString [255]

8.233.1 Detailed Description

This structure contains SWI set host OS info pack information

Parameters

nameString[IN]	Host device manufacture String • NULL terminated ASCII string.
VersionString[IN]	Host device model String • NULL terminated ASCII string.

8.233.2 Field Documentation

8.233.2.1 char pack_dms_SLQSSwiSetOSInfo_t::nameString[255]

8.233.2.2 char pack_dms_SLQSSwiSetOSInfo_t::versionString[255]

8.234 pack_dms_UIMChangePIN_t Struct Reference

Data Fields

- uint8_t id
- uint8_t oldValue [255]

- uint8_t newValue [255]

8.234.1 Detailed Description

This structure contains UIM Unblock PIN Information

Parameters

id[IN]	• PIN ID – 1 (PIN1 / CHV1) – 2 (PIN2 / CHV2)
oldValue[IN]	• Old PIN value of PIN to change
newValue[IN]	• New PIN value of PIN to change

8.234.2 Field Documentation

8.234.2.1 uint8_t pack_dms_UIMChangePIN_t::id

8.234.2.2 uint8_t pack_dms_UIMChangePIN_t::newValue[255]

8.234.2.3 uint8_t pack_dms_UIMChangePIN_t::oldValue[255]

8.235 pack_dms_UIMGetControlKeyStatus_t Struct Reference

Data Fields

- uint8_t facility

8.235.1 Detailed Description

This structure contains UIM get control key status information

Parameters

facility[IN]	• MT or network facility – 0 - Network Personalization (PN) – 1 - Network Subset Personalization (PU) – 2 - Service Provider Personalization (PP) – 3 - Corporate Personalization (PC) – 4 - UIM Personalization (PF)

8.235.2 Field Documentation

8.235.2.1 uint8_t pack_dms_UIMGetControlKeyStatus_t::facility

8.236 pack_dms_UIMGetICCID_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.236.1 Detailed Description

This structure contains UIM Get ICCID pack

Parameters

Tlvresult	• Pack result.

8.236.2 Field Documentation

8.236.2.1 uint16_t pack_dms_UIMGetICCID_t::Tlvresult

8.237 pack_dms_UIMSetControlKeyProtection_t Struct Reference

Data Fields

- uint8_t facility
- uint8_t facilityState
- uint8_t facilityCk [8]

8.237.1 Detailed Description

This structure contains UIM Set control key protection information

Parameters

facility[IN]	• MT or network facility – 0 - Network Personalization (PN) – 1 - Network Subset Personalization (PU) – 2 - Service Provider Personalization (PP) – 3 - Corporate Personalization (PC) – 4 - UIM Personalization (PF)
facilityState[IN]	• UIM facility state – 0 - Deactivated – 1 - Activated – 2 - Blocked
facilityCk[IN]	• Facility depersonalization control key, string in ASCII text (maximum 8 bytes)

8.237.2 Field Documentation

8.237.2.1 uint8_t pack_dms_UIMSetControlKeyProtection_t::facility

8.237.2.2 uint8_t pack_dms_UIMSetControlKeyProtection_t::facilityCk[8]

8.237.2.3 uint8_t pack_dms_UIMSetControlKeyProtection_t::facilityState

8.238 pack_dms_UIMSetPINProtection_t Struct Reference

Data Fields

- uint8_t id
- uint8_t bEnable
- uint8_t value [255]

8.238.1 Detailed Description

This structure contains PIN Protection Information

Parameters

id[IN]	• PIN ID – 1 (PIN1 / CHV1) – 2 (PIN2 / CHV2)
bEnable[IN]	• Enable/disable PIN protection, 0 = Disable
pValue[IN]	• PIN value of the PIN to be enabled/disabled

8.238.2 Field Documentation

8.238.2.1 uint8_t pack_dms_UIMSetPINProtection_t::bEnable

8.238.2.2 uint8_t pack_dms_UIMSetPINProtection_t::id

8.238.2.3 uint8_t pack_dms_UIMSetPINProtection_t::value[255]

8.239 pack_dms_UIMUnblockControlKey_t Struct Reference

Data Fields

- uint8_t facility
- uint8_t facilityCk [8]

8.239.1 Detailed Description

This structure contains UIM unblock Control Key information

Parameters

facility[IN]	• MT or network facility – 0 - Network Personalization (PN) – 1 - Network Subset Personalization (PU) – 2 - Service Provider Personalization (PP) – 3 - Corporate Personalization (PC) – 4 - UIM Personalization (PF)
facilityCk[IN]	• Facility depersonalization control key, string in ASCII text (maximum 8 bytes)

8.239.2 Field Documentation

8.239.2.1 uint8_t pack_dms_UIMUnblockControlKey_t::facility

8.239.2.2 uint8_t pack_dms_UIMUnblockControlKey_t::facilityCk[8]

8.240 pack_dms_UIMUnblockPIN_t Struct Reference

Data Fields

- uint8_t id
- uint8_t pukValue [255]
- uint8_t newPin [255]

8.240.1 Detailed Description

This structure contains UIM Unblock PIN Information

Parameters

id[IN]	• PIN ID – 1 (PIN1 / CHV1) – 2 (PIN2 / CHV2)
pukValue[IN]	• PUK value of PIN to be unblocked
newPin[IN]	• New PIN value for the PIN to be unblocked

8.240.2 Field Documentation

8.240.2.1 uint8_t pack_dms_UIMUnblockPIN_t::id

8.240.2.2 uint8_t pack_dms_UIMUnblockPIN_t::newPin[255]

8.240.2.3 uint8_t pack_dms_UIMUnblockPIN_t::pukValue[255]

8.241 pack_dms_UIMVerifyPIN_t Struct Reference

Data Fields

- uint8_t id
- uint8_t value [255]

8.241.1 Detailed Description

This structure contains PIN Value Information

Parameters

id[IN]	• PIN ID – 1 (PIN1 / CHV1) – 2 (PIN2 / CHV2)
value[IN]	• PIN value of the PIN to be enabled/disabled

8.241.2 Field Documentation

8.241.2.1 uint8_t pack_dms_UIMVerifyPIN_t::id

8.241.2.2 uint8_t pack_dms_UIMVerifyPIN_t::value[255]

8.242 pack_fms_GetImagesPreference_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.242.1 Detailed Description

This structure contains the Get Image Preference information pack

Parameters

Tlvresult	• Pack result

8.242.2 Field Documentation

8.242.2.1 uint16_t pack_fms_GetImagesPreference_t::Tlvresult

8.243 pack_fms_GetStoredImages_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.243.1 Detailed Description

This structure contains the Get Stored Images pack

Parameters

Tlvresult	• Pack result

8.243.2 Field Documentation

8.243.2.1 uint16_t pack_fms_GetStoredImages_t::Tlvresult

8.244 pack_fms_SetImagesPreference_t Struct Reference

Data Fields

- uint32_t imageListSize
- FMSPrefImageList * pImageList
- uint32_t bForceDownload
- uint8_t modemindex
- uint16_t Tlvresult

8.244.1 Detailed Description

This structure contains the Set Images Preference pack

Parameters

imageListSize	• Image List Size
pImageList	• Image List • See FMSPrefImageList
bForceDownload	• 0 - Not Force Donwload. • 1 - Focrce Download.
modemindex	• Modem Index.
Tlvresult	• Unpack result

8.244.2 Field Documentation

8.244.2.1 uint32_t pack_fms_SetImagesPreference_t::bForceDownload

8.244.2.2 uint32_t pack_fms_SetImagesPreference_t::imageListSize

8.244.2.3 uint8_t pack_fms_SetImagesPreference_t::modemindex

8.244.2.4 FMSPrefImageList* pack_fms_SetImagesPreference_t::pImageList

8.244.2.5 uint16_t pack_fms_SetImagesPreference_t::Tlvresult

8.245 pack_ims_SLQSImsConfigIndicationRegister_t Struct Reference

Data Fields

- uint8_t * pSIPConfigEvents
- uint8_t * pRegMgrConfigEvents
- uint8_t * pSMSConfigEvents
- uint8_t * pUserConfigEvents
- uint8_t * pVoIPConfigEvents

8.245.1 Detailed Description

This structure contains parameters of IMS Config Indication Register

Parameters

pSIPConfig-Events(optional)	• Registration Indication For SIP Configuration Events. • When this registration is enabled, the device learns of SIP config events via the QMI_IMS_SIP-_CONFIG_IND indication. – 0x00 - Disable – 0x01 - Enable
pRegMgrConfig-Events(optional)	• Registration Indication For Registration Manager Configuration Events. • When this registration is enabled, the device learns of Reg Mgr config events via the QMI_IMS-_REG_MGR_CONFIG_IND indication. – 0x00 - Disable – 0x01 - Enable
pSMSConfig-Events(optional)	• Registration Indication For SMS Configuration Events. • When this registration is enabled, the device learns of SMS config events via the QMI_IMS_S-MS_CONFIG_IND indication. – 0x00 - Disable – 0x01 - Enable

pUserConfig-Events(optional)	• Registration Indication For User Configuration Events. • When this registration is enabled, the device learns of user config events via the QMI_IMS_USER_CONFIG_IND indication. – 0x00 - Disable – 0x01 - Enable
pVoIPConfig-Events(optional)	• Registration Indication For VoIP Configuration Events. • When this registration is enabled, the device learns of VOIP config events via the QMI_IMS_VOIP_CONFIG_IND indication. – 0x00 - Disable – 0x01 - Enable

Note

One of the optional parameter is mandatory to be present in the request.

8.245.2 Field Documentation

8.245.2.1 uint8_t* pack_ims_SLQSImsConfigIndicationRegister_t::pRegMgrConfigEvents

8.245.2.2 uint8_t* pack_ims_SLQSImsConfigIndicationRegister_t::pSIPConfigEvents

8.245.2.3 uint8_t* pack_ims_SLQSImsConfigIndicationRegister_t::pSMSConfigEvents

8.245.2.4 uint8_t* pack_ims_SLQSImsConfigIndicationRegister_t::pUserConfigEvents

8.245.2.5 uint8_t* pack_ims_SLQSImsConfigIndicationRegister_t::pVoIPConfigEvents

8.246 pack_ims_SLQSSetIMSSMSConfig_t Struct Reference

Data Fields

- uint8_t * pSMSFormat
- uint8_t * pSMSOverIPNwInd
- uint8_t * pPhoneCtxtURILen
- uint8_t * pPhoneCtxtURI

8.246.1 Detailed Description

This structure contains the SLQSSetIMSSMSConfig pack parameters.

Parameters

pSMSFormat	• SMS format – 0 - 3GPP – 1 - 3GPP2

pSMSOverIPNw-Ind	• SMS over IP Network Indication Flag – TRUE - Turn on mobile-originated SMS – FALSE - Turn off mobile-originated SMS
pPhoneCtxtURI-Len	• Length of Phone context Universal Resource Identifier to follow
pPhoneCtxtURI	• Phone context universal resource identifier • Length of this string must be specified in pPhoneCtxtURILen parameter

8.246.2 Field Documentation

8.246.2.1 uint8_t* pack_ims_SLQSSetIMSSMSConfig_t::pPhoneCtxtURI

8.246.2.2 uint8_t* pack_ims_SLQSSetIMSSMSConfig_t::pPhoneCtxtURILen

8.246.2.3 uint8_t* pack_ims_SLQSSetIMSSMSConfig_t::pSMSFormat

8.246.2.4 uint8_t* pack_ims_SLQSSetIMSSMSConfig_t::pSMSOverIPNwInd

8.247 pack_ims_SLQSSetIMSUserConfig_t Struct Reference

Data Fields

- uint8_t * pIMSDomainLen
- uint8_t * pIMSDomain

8.247.1 Detailed Description

This structure contains the SLQSSetIMSUserConfig pack parameters.

Parameters

pIMSDomainLen	• Length of IMS Domain Name to follow
pIMSDomain	• IMS domain name

8.247.2 Field Documentation

8.247.2.1 uint8_t* pack_ims_SLQSSetIMSUserConfig_t::pIMSDomain

8.247.2.2 uint8_t* pack_ims_SLQSSetIMSUserConfig_t::pIMSDomainLen

8.248 pack_ims_SLQSSetIMSVoIPConfig_t Struct Reference

Data Fields

- uint16_t * pSessionExpiryTimer
- uint16_t * pMinSessionExpiryTimer
- uint8_t * pAmrWbEnable
- uint8_t * pScrAmrEnable
- uint8_t * pScrAmrWbEnable
- uint8_t * pAmrMode
- uint16_t * pAmrWBMode
- uint8_t * pAmrOctetAligned
- uint8_t * pAmrWBOctetAligned
- uint16_t * pRingingTimer
- uint16_t * pRingBackTimer
- uint16_t * pRTPRTCPInactTimer

8.248.1 Detailed Description

This structure contains the SLQSSetIMSVoIPConfig pack parameters.

Parameters

pSessionExpiry-Timer	• Session duration, in seconds
pMinSession-ExpiryTimer	• Minimum allowed value for session expiry timer, in seconds
pAmrWbEnable	• Flag to enable/disable Adaptive Multirate Codec(AMR) WideBand(WB) audio • Values: – True - Enable – False - Disable
pScrAmrEnable	• Flag to enable/disable Source Control Rate(SCR) for AMR NarrowBand (NB) • Values: – True - Enable – False - Disable
pScrAmrWb-Enable	• Flag to enable/disable SCR for AMR WB Audio • Values: – True - Enable – False - Disable

pAmrMode	• BitMask for AMR NB modes allowed • Values: – 0x1 - 4.75 kbps – 0x2 - 5.15 kbps – 0x4 - 5.9 kbps – 0x8 - 6.17 kbps – 0x10 - 7.4 kbps – 0x20 - 7.95 kbps – 0x40 - 10.2 kbps – 0x80 - 12.2 kbps
pAmrWBMode	• BitMask for AMR WB modes allowed • Values: – 0x1 - 6.60 kbps – 0x2 - 8.85 kbps – 0x4 - 12.65 kbps – 0x8 - 14.25 kbps – 0x10 - 15.85 kbps – 0x20 - 18.25 kbps – 0x40 - 19.85 kbps – 0x80 - 23.05 kbps – 0x100 - 23.85 kbps
pAmrOctet-Aligned	• Flag to indicate if the octet is aligned for AMR NB Audio • Values: – True - Aligned – False - Not aligned, Bandwidth Efficient mode
pAmrWBOctet-Aligned	• Flag to indicate if the octet is aligned for AMR WB Audio • Values: – True - Aligned – False - Not aligned, Bandwidth Efficient mode
pRingingTimer	• Duration of ringing timer, in seconds. The ringing timer starts on the ringing event. If the call is not answered within the duration of this timer, the call is disconnected.
pRingBackTimer	• Duration of ringback timer, in seconds. The ringback timer starts on the ringback event. If the call is not answered within the duration of this timer, the call is disconnected.
pRTPRTCP-InactTimer	• Duration of RTP/RTCP inactivity timer, in seconds. If no RTP/RTCP packet is received prior to the expiry of this timer, the call is disconnected.

8.248.2 Field Documentation

8.248.2.1 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pAmrMode

8.248.2.2 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pAmrOctetAligned

8.248.2.3 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pAmrWbEnable

8.248.2.4 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pAmrWBMode

8.248.2.5 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pAmrWBOctetAligned

8.248.2.6 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pMinSessionExpiryTimer

8.248.2.7 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pRingBackTimer

8.248.2.8 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pRingingTimer

8.248.2.9 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pRTPRTCPInactTimer

8.248.2.10 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pScrAmrEnable

8.248.2.11 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pScrAmrWbEnable

8.248.2.12 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pSessionExpiryTimer

8.249 pack_ims_SLQSSetRegMgrConfig_t Struct Reference

Data Fields

- uint16_t * pPriCSCFPort
- uint8_t * pCSCFPortNameLen
- uint8_t * pCSCFPortName
- uint8_t * pIMSTestMode

8.249.1 Detailed Description

This structure contains the SLQSSetRegMgrConfig pack parameters.

Parameters

pPriCSCFPort	• Primary call session control function port
pCSCFPort-NameLen	• Length of the CSCF Port name parameter to follow
pCSCFPort-Name	• Call Session control port, fully qualified domain name • Length of this string must be specified in pCSCFPortNameLen parameter
pIMSTestMode	• IMS Test mode Enabled. – TRUE - Enable, no IMS registration – FALSE - Disable, IMS registration is initiated

8.249.2 Field Documentation

8.249.2.1 uint8_t* pack_ims_SLQSSetRegMgrConfig_t::pCSCFPortName

8.249.2.2 uint8_t* pack_ims_SLQSSetRegMgrConfig_t::pCSCFPortNameLen

8.249.2.3 uint8_t* pack_ims_SLQSSetRegMgrConfig_t::pIMSTestMode

8.249.2.4 uint16_t* pack_ims_SLQSSetRegMgrConfig_t::pPriCSCFPort

8.250 pack_ims_SLQSSetSIPConfig_t Struct Reference

Data Fields

- uint16_t * pSIPLocalPort
- uint32_t * pTimerSIPReg
- uint32_t * pSubscribeTimer
- uint32_t * pTimerT1
- uint32_t * pTimerT2
- uint32_t * pTimerTf
- uint8_t * pSigCompEnabled

8.250.1 Detailed Description

This structure contains the SLQSSetSIPConfig pack parameters.

Parameters

pSIPLocalPort	• Primary call session control function SIP port number
pTimerSIPReg	• Initial SIP registration duration from the User equipment, in seconds
pSubscribeTimer	• Duration of the subscription by the UE for IMS registration notifications, in seconds
pTimerT1	• RTT estimate, in milliseconds
pTimerT2	• The maximum retransmit interval for non-invite requests and invite responses, in milliseconds
pTimerTf	• Non-invite transaction timeout timer, in milliseconds
pSigComp-Enabled	• Sig Comp Status – TRUE - Enable – FALSE - Disable

8.250.2 Field Documentation

8.250.2.1 uint8_t* pack_ims_SLQSSetSIPConfig_t::pSigCompEnabled

8.250.2.2 uint16_t* pack_ims_SLQSSetSIPConfig_t::pSIPLocalPort

8.250.2.3 uint32_t* pack_ims_SLQSSetSIPConfig_t::pSubscribeTimer

8.250.2.4 uint32_t* pack_ims_SLQSSetSIPConfig_t::pTimerSIPReg

8.250.2.5 uint32_t* pack_ims_SLQSSetSIPConfig_t::pTimerT1

8.250.2.6 uint32_t* pack_ims_SLQSSetSIPConfig_t::pTimerT2

8.250.2.7 uint32_t* pack_ims_SLQSSetSIPConfig_t::pTimerTf

8.251 pack_imsa_SLQSRegisterIMSAIndication_t Struct Reference

Data Fields

- int has_RegStatusConfig
- uint8_t RegStatusConfig
- int has_ServiceStatusConfig
- uint8_t ServiceStatusConfig
- int has_RatHandoverStatusConfig
- uint8_t RatHandoverStatusConfig
- int has_PdpStatusConfig
- uint8_t PdpStatusConfig

8.251.1 Detailed Description

This structure contains parameters of IMSA Config Indication Register

Parameters

RegStatus-Config(optional)	• Register Indication For Registration status. • When this registration is enabled, the device learns of Registration status via the QMI_IMSA_-REGISTRATION_STATUS_IND indication. – 0x00 - Disable – 0x01 - Enable
ServiceStatus-Config(optional)	• Register Indication For Service status Events. • When this registration is enabled, the device learns of Service status via the QMI_IMSA_SER-VICE_STATUS_IND indication. – 0x00 - Disable – 0x01 - Enable
RatHandover-Status-Config(optional)	• Registration Indication For RAT handover status. • When this registration is enabled, the device learns of RAT handover status via the QMI_IMSA-_RAT_HANDOVER_STATUS_IND indication. – 0x00 - Disable – 0x01 - Enable

PdpStatus-Config(optional)	• PDP Status Configuration. – 0x00 - Disable – 0x01 - Enable

Note

One of the optional parameter is mandatory to be present in the request.

8.251.2 Field Documentation

8.251.2.1 int pack_imsa_SLQSRegisterIMSAIndication_t::has_PdpStatusConfig

8.251.2.2 int pack_imsa_SLQSRegisterIMSAIndication_t::has_RatHandoverStatusConfig

8.251.2.3 int pack_imsa_SLQSRegisterIMSAIndication_t::has_RegStatusConfig

8.251.2.4 int pack_imsa_SLQSRegisterIMSAIndication_t::has_ServiceStatusConfig

8.251.2.5 uint8_t pack_imsa_SLQSRegisterIMSAIndication_t::PdpStatusConfig

8.251.2.6 uint8_t pack_imsa_SLQSRegisterIMSAIndication_t::RatHandoverStatusConfig

8.251.2.7 uint8_t pack_imsa_SLQSRegisterIMSAIndication_t::RegStatusConfig

8.251.2.8 uint8_t pack_imsa_SLQSRegisterIMSAIndication_t::ServiceStatusConfig

8.252 pack_loc_Delete_Assist_Data_t Struct Reference

Data Fields

- loc_SVInfo * pSVInfo
- loc_GnssData * pGnssData
- loc_CellDb * pCellDb
- loc_ClkInfo * pClkInfo
- loc_BdsSVInfo * pBdsSVInfo
- uint16_t Tlvresult

8.252.1 Detailed Description

This structure contains LOC delete assist data pack

Parameters

pSVInfo	• Pointer to struct loc_SVInfo. See loc_SVInfo for more information
pGnssData	• Pointer to struct loc_GnssData. See loc_GnssData for more information
pCellDb	• Pointer to struct loc_CellDb. See loc_CellDb for more information

pClkInfo	• Pointer to struct loc_ClkInfo. See loc_ClkInfo for more information
pBdsSVInfo	• Pointer to struct loc_BdsSVInfo. See loc_BdsSVInfo for more information
Tlvresult	• Pack delete assist data request result.

8.252.2 Field Documentation

8.252.2.1 loc_BdsSVInfo* pack_loc_Delete_Assist_Data_t::pBdsSVInfo

8.252.2.2 loc_CellDb* pack_loc_Delete_Assist_Data_t::pCellDb

8.252.2.3 loc_ClkInfo* pack_loc_Delete_Assist_Data_t::pClkInfo

8.252.2.4 loc_GnssData* pack_loc_Delete_Assist_Data_t::pGnssData

8.252.2.5 loc_SVInfo* pack_loc_Delete_Assist_Data_t::pSVInfo

8.252.2.6 uint16_t pack_loc_Delete_Assist_Data_t::Tlvresult

8.253 pack_loc_EventRegister_t Struct Reference

Data Fields

- uint64_t eventRegister
- uint16_t Tlvresult

8.253.1 Detailed Description

This structure contains the Parameter for RegisterEvents

Parameters

eventRegister	• Specifies the events that the control point is interested in receiving. -Values – 0x00000001 - to receive position report event indications – 0x00000002 - to receive satellite report event indications.These reports are sent at a 1 Hz rate. – 0x00000004 - to receive NMEA reports for position and satellites in view.The report is at a 1 Hz rate. – 0x00000008 - to receive NI Notify/Verify request event indications – 0x00000010 - to receive time injection request event indications. – 0x00000020 - to receive predicted orbits request event indications. – 0x00000040 - to receive position injection request event indications. – 0x00000080 - to receive engine state report event indications. – 0x00000100 - to receive fix session status report event indications. – 0x00000200 - to receive Wi-Fi position request event indications. – 0x00000400 - to receive notifications from the location engine indicating its readiness to accept data from the sensors(accelerometer, gyroscope, etc.). – 0x00000800 - to receive time sync requests from the GPS engine. Time sync enables the GPS engine to synchronize its clock with the sensor processor's clock. – 0x00001000 - to receive Stationary Position Indicator (SPI) streaming report indications. – 0x00002000 - to receive location server requests. These requests are generated when the service wishes to establish a connection with a location server. – 0x00004000 - to receive notifications related to network-initiated Geofences. These events notify the client when a network-initiated Geofence is added, deleted, or edited. – 0x00008000 - to receive Geofence alerts. These alerts are generated to inform the client of the changes that may affect a Geofence, e.g., if GPS is turned off or if the network is unavailable. – 0x00010000 - to receive notifications when a Geofence is breached. These events are generated when a UE enters or leaves the perimeter of a Geofence. This breach report is for a single Geofence. – 0x00020000 - to register for pedometer control requests from the location engine. The location engine sends this event to control the injection of pedometer reports. – 0x00040000 - to register for motion data control requests from the location engine. The location engine sends this event to control the injection of motion data. – 0x00080000 - to receive notification when a batch is full. The location engine sends this event to notify of Batch Full for ongoing batching session. – 0x00100000 - to receive position report indications along with an ongoing batching session. The location engine sends this event to notify the batched position report while a batching session is ongoing. – 0x00200000 - to receive Wi-Fi Access Point (AP) data inject request event indications. – 0x00400000 - to receive notifications when a Geofence is breached. These events are generated when a UE enters or leaves the perimeter of a Geofence. This breach notification is for multiple Geofences. Breaches from multiple Geofences are all batched and sent in the same notification. – 0x00800000 - to receive notifications from the location engine indicating its readiness to accept vehicle data (vehicle accelerometer, vehicle angular rate, vehicle odometry, etc.). – 0x01000000 - to receive system clock and satellite measurement report events (system clock, SV time, Doppler, etc.). – 0x02000000 - to receive satellite position reports as polynomials.Reports are generated only for the GNSS satellite constellations that are enabled using QMI_LOC_SET_GNSS_-CONSTELL_REPORT_CONFIG.

Note

Multiple events can be registered by OR the individual masks and sending them in this TLV. All unused bits in this mask must be set to 0.

Parameters

TlvResult	• Pack result.

8.253.2 Field Documentation

8.253.2.1 uint64_t pack_loc_EventRegister_t::eventRegister

8.253.2.2 uint16_t pack_loc_EventRegister_t::TlvResult

8.254 pack_loc_SetExtPowerState_t Struct Reference

Data Fields

- uint32_t extPowerState
- uint16_t TlvResult

8.254.1 Detailed Description

This structure contains the Parameter External Power Source State pack.

Parameters

extPowerState	• Specifies the Power state; injected by the control point. • Values – 0 - Device is not connected to an external power source – 1 - Device is connected to an external power source – 2 - Unknown external power state
TlvResult	• Pack result.

8.254.2 Field Documentation

8.254.2.1 uint32_t pack_loc_SetExtPowerState_t::extPowerState

8.254.2.2 uint16_t pack_loc_SetExtPowerState_t::TlvResult

8.255 pack_loc_SetOperationMode_t Struct Reference

Data Fields

- uint32_t mode
- uint16_t TlvResult

8.255.1 Detailed Description

This structure contains Set Operation Mode pack

Parameters

mode	• Valid values: – eQMI_LOC_OPER_MODE_DEFAULT (1) - Use the default engine mode – eQMI_LOC_OPER_MODE_MSB (2) - Use the MS-based mode – eQMI_LOC_OPER_MODE_MSA (3) - Use the MS-assisted mode – eQMI_LOC_OPER_MODE_STANDALONE (4) - Use Standalone mode – eQMI_LOC_OPER_MODE_CELL_ID (5) - Use cell ID; this mode is only valid for GSM/UMTS networks – eQMI_LOC_OPER_MODE_WWAN (6) - Use WWAN measurements to calculate the position; if this mode is set, AFLT will be used for 1X networks and OTDOA will be used for LTE networks
Tlvresult	• Pack result.

8.255.2 Field Documentation

8.255.2.1 uint32_t pack_loc_SetOperationMode_t::mode

8.255.2.2 uint16_t pack_loc_SetOperationMode_t::Tlvresult

8.256 pack_loc_SLQSLOCGetBestAvailPos_t Struct Reference

Data Fields

- uint32_t xid
- uint16_t Tlvresult

8.256.1 Detailed Description

This structure contains Set Operation Mode pack

Parameters

xid	• Identifies the transaction. • The transaction ID is returned in the Get Best Available Position indication.
Tlvresult	• Pack result.

8.256.2 Field Documentation

8.256.2.1 uint16_t pack_loc_SLQSLOCGetBestAvailPos_t::Tlvresult

8.256.2.2 uint32_t pack_loc_SLQSLOCGetBestAvailPos_t::xid

8.257 pack_loc_SLQSLOCGetServer_t Struct Reference

Data Fields

- uint32_t serverType
- int has_serverAddrTypeMask
- uint8_t serverAddrTypeMask

8.257.1 Detailed Description

This structure contains parameters to Gets the location server. Please check has_<Param_Name> field for presence of optional parameters

Parameters

serverType	• Type of server. • Valid values – eQMI_LOC_SERVER_TYPE_CDMA_PDE (1) - Server type is CDMA PDE – eQMI_LOC_SERVER_TYPE_CDMA_MPC (2) - Server type is CDMA MPC – eQMI_LOC_SERVER_TYPE_UMTS_SLP (3) - Server type is UMTS SLP – eQMI_LOC_SERVER_TYPE_CUSTOM_PDE (4)- Server type is custom PDE
serverAddrTypeMask	• Optional parameter • Type of address the client wants. If unspecified, the indication will contain all the types of addresses it has for the specified server type. • Valid bitmasks – 0x01 - IPv4 – 0x02 - IPv6 – 0x04 - URL

8.257.2 Field Documentation

8.257.2.1 int pack_loc_SLQSLOCGetServer_t::has_serverAddrTypeMask

8.257.2.2 uint8_t pack_loc_SLQSLOCGetServer_t::serverAddrTypeMask

8.257.2.3 uint32_t pack_loc_SLQSLOCGetServer_t::serverType

8.258 pack_loc_SLQSLOCInjectPosition_t Struct Reference

Data Fields

- double latitude
- int has_latitude
- double longitude
- int has_longitude
- float horUncCircular

- int has_horUncCircular
- uint8_t horConfidence
- int has_horConfidence
- uint32_t horReliability
- int has_horReliability
- float altitudeWrtEllipsoid
- int has_altitudeWrtEllipsoid
- float altitudeWrtMeanSeaLevel
- int has_altitudeWrtMeanSeaLevel
- float vertUnc
- int has_vertUnc
- uint8_t vertConfidence
- int has_vertConfidence
- uint32_t vertReliability
- int has_vertRelicability
- altSrcInfo_t altitudeSrcInfo
- int has_altitudeSrcInfo
- uint64_t timestampUtc
- int has_timestampUtc
- uint32_t timestampAge
- int has_timestampAge
- uint32_t positionSrc
- int has_positionSrc
- float rawHorUncCircular
- int has_rawHorUncCircular
- uint8_t rawHorConfidence
- int has_rawHorConfidence

8.258.1 Detailed Description

This structure contains LOC Inject Position parameters Please check has_<Param_Name> field for presence of optional parameters

Parameters

latitude	• Optional parameter • Type - Floating point • Units - Degrees • Range - -90.0 to 90.0 • Positive values indicate northern latitude • Negative values indicate southern latitude • Note - This field must be specified together with pLongitude and pHorUncCircular.
longitude	• Optional parameter • Type - Floating point • Units - Degrees • Range - -180.0 to 180.0 • Positive values indicate eastern latitude • Negative values indicate western latitude • Note - This field must be specified together with pLatitude and pHorUncCircular.

horUncCircular	• Optional parameter • Horizontal position uncertainty. • Units - Meters • Note - This field must be specified together with pLatitude and pLongitude.
horConfidence	• Optional parameter • Horizontal confidence. • Units - Percent • Values – Valid Values - 1 to 99 – Invalid Values - 0, 101 to 255 – If 100 is received, reinterpret to 99 • Note - This field must be specified together with horizontal uncertainty. If not specified when pHorUncCircular is set, the default value is 50.
horReliability	• Optional parameter – Values * 0 - Location reliability is not set. * 1 - Location reliability is very low; use it at your own risk * 2 - Location reliability is low; little or no cross-checking is possible. * 3 - Location reliability is medium; limited cross-check passed * 4 - Location reliability is high; strong cross-check passed
altitudeWrt-Ellipsoid	• Optional parameter • Altitude With Respect to Ellipsoid. • Units - Meters • Values – Positive - height – Negative = depth
altitudeWrt-MeanSeaLevel	• Optional parameter • Altitude With Respect to Sea Level. • Units - Meters
vertUnc	• Optional parameter • Vertical uncertainty. • Units - Meters • Note - This is mandatory if either pAltitudeWrtEllipsoid or pAltitudeWrtMeanSeaLevel is specified.

vertConfidence	• Optional parameter • Vertical confidence. • Units - Percentage • Values – Valid Values - 0 to 99 – Invalid Values - 0, 100-256 – If 100 is received, reinterpret to 99 • Note - This field must be specified together with the vertical uncertainty. If not specified, the default value will be 50.
vertReliability	• Optional parameter – Values * 0 - Location reliability is not set. * 1 - Location reliability is very low; use it at your own risk. * 2 - Location reliability is low; little or no cross-checking is possible * 3 - Location reliability is medium; limited cross-check passed * 4 - Location reliability is high; strong cross-check passed
altitudeSrcInfo	• Optional parameter – Pointer to struct altitudeSrcInfo. See altitudeSrcInfo for more information
timestampUtc	• Optional parameter • UTC timestamp • Units - Milliseconds since Jan. 1, 1970
timestampAge	• Optional parameter • Position age, which is an estimate of how long ago this fix was made. • Units - Milliseconds
positionSrc	• Optional parameter • Source from which this position was obtained • Valid values – 0 - Position source is GNSS – 1 - Position source is Cell ID – 2 - Position source is Enhanced Cell ID – 3 - Position source is Wi-Fi – 4 - Position source is Terrestrial – 5 - Position source is GNSS Terrestrial Hybrid – 6 - Other sources • Note - If altitude is specified and the altitude source is not specified, the engine assumes that the altitude was obtained using the specified position source. – If both altitude and altitude source are specified, the engine assumes that only latitude and longitude were obtained using the specified position source.

rawHorUncCircular	• Optional parameter • Horizontal position uncertainty (circular) without any optimization. • Units - Meters
rawHorConfidence	• Optional parameter • Horizontal confidence associated with raw horizontal uncertainty • Units: Percent • Values – Valid values - 1 to 99 – Invalid values - 0, 101 to 255 – If 100 is received, reinterpret to 99 • Note - This field must be specified together with raw horizontal uncertainty. If not specified when rawHorUncCircular is set, the default value is 50.

8.258.2 Field Documentation

8.258.2.1 altSrcInfo_t pack_loc_SLQSLOCInjectPosition_t::altitudeSrcInfo

8.258.2.2 float pack_loc_SLQSLOCInjectPosition_t::altitudeWrtEllipsoid

8.258.2.3 float pack_loc_SLQSLOCInjectPosition_t::altitudeWrtMeanSeaLevel

8.258.2.4 int pack_loc_SLQSLOCInjectPosition_t::has_altitudeSrcInfo

8.258.2.5 int pack_loc_SLQSLOCInjectPosition_t::has_altitudeWrtEllipsoid

8.258.2.6 int pack_loc_SLQSLOCInjectPosition_t::has_altitudeWrtMeanSeaLevel

8.258.2.7 int pack_loc_SLQSLOCInjectPosition_t::has_horConfidence

8.258.2.8 int pack_loc_SLQSLOCInjectPosition_t::has_horReliability

8.258.2.9 int pack_loc_SLQSLOCInjectPosition_t::has_horUncCircular

8.258.2.10 int pack_loc_SLQSLOCInjectPosition_t::has_latitude

8.258.2.11 int pack_loc_SLQSLOCInjectPosition_t::has_longitude

8.258.2.12 int pack_loc_SLQSLOCInjectPosition_t::has_positionSrc

8.258.2.13 int pack_loc_SLQSLOCInjectPosition_t::has_rawHorConfidence

8.258.2.14 int pack_loc_SLQSLOCInjectPosition_t::has_rawHorUncCircular

8.258.2.15 int pack_loc_SLQSLOCInjectPosition_t::has_timestampAge

8.258.2.16 int pack_loc_SLQSLOCInjectPosition_t::has_timestampUtc

8.258.2.17 int pack_loc_SLQSLOCInjectPosition_t::has_vertConfidence

8.258.2.18 int pack_loc_SLQSLOCInjectPosition_t::has_vertRelicability

8.258.2.19 int pack_loc_SLQSLOCInjectPosition_t::has_vertUnc

8.258.2.20 uint8_t pack_loc_SLQSLOCInjectPosition_t::horConfidence

8.258.2.21 uint32_t pack_loc_SLQSLOCInjectPosition_t::horReliability

8.258.2.22 float pack_loc_SLQSLOCInjectPosition_t::horUncCircular

8.258.2.23 double pack_loc_SLQSLOCInjectPosition_t::latitude

8.258.2.24 double pack_loc_SLQSLOCInjectPosition_t::longitude

8.258.2.25 uint32_t pack_loc_SLQSLOCInjectPosition_t::positionSrc

8.258.2.26 uint8_t pack_loc_SLQSLOCInjectPosition_t::rawHorConfidence

8.258.2.27 float pack_loc_SLQSLOCInjectPosition_t::rawHorUncCircular

8.258.2.28 uint32_t pack_loc_SLQSLOCInjectPosition_t::timestampAge

8.258.2.29 uint64_t pack_loc_SLQSLOCInjectPosition_t::timestampUtc

8.258.2.30 uint8_t pack_loc_SLQSLOCInjectPosition_t::vertConfidence

8.258.2.31 uint32_t pack_loc_SLQSLOCInjectPosition_t::vertReliability

8.258.2.32 float pack_loc_SLQSLOCInjectPosition_t::vertUnc

8.259 pack_loc_SLQSLOCInjectSensorData_t Struct Reference

Data Fields

- int has_opaqueId
- uint32_t opaqueId
- int has_accleroData
- sensorData_t acceleroData
- int has_gyroData
- sensorData_t gyroData
- int has_acceleroTimeSrc
- uint32_t acceleroTimeSrc
- int has_gyroTimeSrc
- uint32_t gyroTimeSrc
- int has_accelTemp
- tempData_t accelTemp
- int has_gyroTemp
- tempData_t gyroTemp

8.259.1 Detailed Description

This structure contains parameters to inject sensor data into the GNSS location engine Please check has_<Param-_Name> field for presence of optional parameters

Parameters

opaqueId	• Opaque Identifier (Optional parameter) • An opaque identifier that is sent in by the client that will be echoed in the indication so the client can relate the indication to the request.
acceleroData	• 3-Axis Accelerometer Data (Optional parameter) • Pointer to struct sensorData. See sensorData_t for more information
gyroData	• 3-Axis Cyroscope Data (Optional parameter) • Pointer to struct sensorData. See sensorData_t for more information
acceleroTimeSrc	• 3-Axis Accelerometer Data Time Source (Optional parameter) • The location service uses this field to identify the time reference used in the accelerometer data time stamps. • If not specified, the location service assumes that the time source for the accelerometer data is unknown. • Valid values – 0 - Sensor time source is unspecified – 1 - Time source is common between the sensors and the location engine
gyroTimeSrc	• 3-Axis Gyroscope Data Time Source (Optional) • The location service uses this field to identify the time reference used in the gyroscope data time stamps. • If not specified, the location service assumes that the time source for the gyroscope data is unknown. • Valid values – 0 - Sensor time source is unspecified – 1 - Time source is common between the sensors and the location engine
accelTemp	• Accelerometer Temperature Data (Optional parameter) • Pointer to struct tempratureData. See tempData_t for more information
gyroTemp	• Gyroscope Temperature Data (Optional parameter) • Pointer to struct tempratureData. See tempData_t for more information

8.259.2 Field Documentation

8.259.2.1 sensorData_t pack_loc_SLQSLOCInjectSensorData_t::acceleroData

8.259.2.2 uint32_t pack_loc_SLQSLOCInjectSensorData_t::acceleroTimeSrc

8.259.2.3 tempData_t pack_loc_SLQSLOCInjectSensorData_t::accelTemp

8.259.2.4 sensorData_t pack_loc_SLQSLOCInjectSensorData_t::gyroData

8.259.2.5 tempData_t pack_loc_SLQSLOCInjectSensorData_t::gyroTemp

8.259.2.6 uint32_t pack_loc_SLQSLOCInjectSensorData_t::gyroTimeSrc

8.259.2.7 int pack_loc_SLQSLOCInjectSensorData_t::has_acceleroTimeSrc

8.259.2.8 int pack_loc_SLQSLOCInjectSensorData_t::has_accelTemp

8.259.2.9 int pack_loc_SLQSLOCInjectSensorData_t::has_accleroData

8.259.2.10 int pack_loc_SLQSLOCInjectSensorData_t::has_gyroData

8.259.2.11 int pack_loc_SLQSLOCInjectSensorData_t::has_gyroTemp

8.259.2.12 int pack_loc_SLQSLOCInjectSensorData_t::has_gyroTimeSrc

8.259.2.13 int pack_loc_SLQSLOCInjectSensorData_t::has_opaqueId

8.259.2.14 uint32_t pack_loc_SLQSLOCInjectSensorData_t::opaqueId

8.260 pack_loc_SLQSLOCInjectUTCTime_t Struct Reference

Data Fields

- uint64_t timeMsec
- uint32_t timeUncMsec

8.260.1 Detailed Description

This structure contains inject UTC time parameter.

Parameters

timeMsec	• The UTC time since Jan. 1, 1970
timeUncMsec	• The time Uncertainty

8.260.2 Field Documentation

8.260.2.1 uint64_t pack_loc_SLQSLOCInjectUTCTime_t::timeMsec

8.260.2.2 uint32_t pack_loc_SLQSLOCInjectUTCTime_t::timeUncMsec

8.261 pack_loc_SLQSLOCSetCradleMountConfig_t Struct Reference

Data Fields

- uint32_t state
- int has_confidence
- uint8_t confidence

8.261.1 Detailed Description

This structure contains parameters to set current cradle mount configuration Please check has_<Param_Name> field for presence of optional parameters

Parameters

state	• Cradle Mount State • Valid values: – 0 - Device is mounted on the cradle – 1 - Device is not mounted on the cradle – 2 - Unknown cradle mount state
confidence	• Cradle Mount Confidence (Optional) • Confidence in the Cradle Mount state expressed as a percentage. • Range - 0 to 100

8.261.2 Field Documentation

8.261.2.1 uint8_t pack_loc_SLQSLOCSetCradleMountConfig_t::confidence

8.261.2.2 int pack_loc_SLQSLOCSetCradleMountConfig_t::has_confidence

8.261.2.3 uint32_t pack_loc_SLQSLOCSetCradleMountConfig_t::state

8.262 pack_loc_Start_t Struct Reference

Data Fields

- uint8_t SessionId
- uint32_t * pRecurrenceType
- uint32_t * pHorizontalAccuracyLvl
- uint32_t * pIntermediateReportState
- uint32_t * pMinIntervalTime
- loc_LocApplicationInfo * pApplicationInfo
- uint32_t * pConfigAltitudeAssumed
- uint16_t Tlvresult

8.262.1 Detailed Description

This structure contains the LOC Start pack

Parameters

SessionId	• ID of the session as identified by the control point. • Range: 0 to 255

pRecurrence-Type	• Optional Parameter • Specifies the type of session in which the control point is interested. • Defaults to SINGLE. -Values – 1 - Request periodic position fixes – 2 - Request a single position fix
pHorizontal-AccuracyLvl	• Optional Parameter • Specifies the horizontal accuracy level required by the control point. • Defaults to LOW • Values – 1 - Low accuracy – 2 - Medium accuracy – 3 - High accuracy
pIntermediate-ReportState	• Optional Parameter • Specifies if the control point is interested in receiving intermediate reports. • ON by default. • Values – 1 - Intermediate reports are turned on – 2 - Intermediate reports are turned off
pMinInterval-Time	• Optional Parameter • Minimum time interval, specified by the control point, that must elapse between position reports. • Units - Milliseconds • Default - 1000 ms
LocApplication-Info	• Optional Parameter • LOC Application Parameters • See loc_LocApplicationInfo for more information
pConfigAltitude-Assumed	• Optional Parameter • Configuration for Altitude Assumed Info in GNSS SV Info Event • Defaults to ENABLED. • Values – 1 - Enable Altitude Assumed information in GNSS SV Info Event – 2 - Disable Altitude Assumed information in GNSS SV Info Event
Tlvresult	• Unpack result.

8.262.2 Field Documentation

8.262.2.1 loc_LocApplicationInfo* pack_loc_Start_t::pApplicationInfo

8.262.2.2 uint32_t* pack_loc_Start_t::pConfigAltitudeAssumed

8.262.2.3 uint32_t* pack_loc_Start_t::pHorizontalAccuracyLvl

8.262.2.4 uint32_t* pack_loc_Start_t::pIntermediateReportState

8.262.2.5 uint32_t* pack_loc_Start_t::pMinIntervalTime

8.262.2.6 uint32_t* pack_loc_Start_t::pRecurrenceType

8.262.2.7 uint8_t pack_loc_Start_t::SessionId

8.262.2.8 uint16_t pack_loc_Start_t::Tlvresult

8.263 pack_loc_Stop_t Struct Reference

Data Fields

- uint8_t SessionId
- uint16_t Tlvresult

8.263.1 Detailed Description

This structure contains Stop LOC pack

Parameters

sessionId	• ID of the session as identified by the control point. • Range: 0 to 255
Tlvresult	• Unpack result.

8.263.2 Field Documentation

8.263.2.1 uint8_t pack_loc_Stop_t::SessionId

8.263.2.2 uint16_t pack_loc_Stop_t::Tlvresult

8.264 pack_nas_InitiateDomainAttach_t Struct Reference

Data Fields

- uint32_t action

8.264.1 Detailed Description

Pack structure for Initiates a domain attach/detach of the device.

Parameters

action	• Domain action to attempt 1 - Attach 2 - Detach

8.264.2 Field Documentation

8.264.2.1 uint32_t pack_nas_InitiateDomainAttach_t::action

8.265 pack_nas_SetACCOLC_t Struct Reference

Data Fields

- int8_t spc [6]
- uint8_t accolc

8.265.1 Detailed Description

Sets the access overload class (ACCOLC)

Parameters

spc	• service programming code NULL-terminated string of six digit
accolc	• ACCOLC : Valid range is 0 to 15

8.265.2 Field Documentation

8.265.2.1 uint8_t pack_nas_SetACCOLC_t::accolc

8.265.2.2 int8_t pack_nas_SetACCOLC_t::spc[6]

8.266 pack_nas_SetCDMANetworkParameters_t Struct Reference

Data Fields

- char * pSPC
- uint8_t * pForceRev0
- uint8_t * pCustomSCP
- uint32_t * pProtocol
- uint32_t * pBroadcast
- uint32_t * pApplication
- uint32_t * pRoaming

8.266.1 Detailed Description

Pack structure to set CDMA Network parameters.

Parameters

pSPC	• Six digit service programming code (not necessary when only the roaming field is being set)
pForceRev0	• (Optional)Force CDMA 1x-EV-DO Rev. 0 mode – 0 - Disabled – 1 - Enabled Note: Enabled can only be specified if pCustomSCP state is set to Disabled
pCustomSCP	• (Optional)Use a custom config for CDMA 1x-EV-DO SCP – 0 - Disabled – 1 - Enabled Note: Enabled can only be specified if pForceRev0 is set to Disabled
pProtocol	• Protocol mask for custom SCP config – 0x00000001 - Subtype 2 Physical Layer – 0x00000002 - Enhanced CCMAC – 0x00000004 - Enhanced ACMAC – 0x00000008 - Enhanced FTCMAC – 0x00000010 - Subtype 3 RTCMAC – 0x00000020 - Subsystem 1 RTCMAC – 0x00000040 - Enhanced Idle – 0x00000080 - Generic Multimode Capable Disc Port – 0xFFFFFFFF - Unknown
pBroadcast	• Broadcast mask for custom SCP config – 0x00000001 - Generic broadcast enabled – 0xFFFFFFFF - Unknown
pApplication	• Application mask for custom SCP config – 0x00000001 - SN Multiflow Packet Application – 0x00000002 - SN Enhanced Multiflow Packet Application – 0xFFFFFFFF - Unknown
pRoaming	• Roaming preference – 0 - Automatic – 1 - Home Only – 2 - Affiliated Roaming Only – 3 - Home and Affiliated Roaming – 0xFFFFFFFF - Unknown

8.266.2 Field Documentation

8.266.2.1 uint32_t* pack_nas_SetCDMANetworkParameters_t::pApplication

8.266.2.2 uint32_t* pack_nas_SetCDMANetworkParameters_t::pBroadcast

8.266.2.3 uint8_t* pack_nas_SetCDMANetworkParameters_t::pCustomSCP

8.266.2.4 uint8_t* pack_nas_SetCDMANetworkParameters_t::pForceRev0

8.266.2.5 uint32_t* pack_nas_SetCDMANetworkParameters_t::pProtocol

8.266.2.6 uint32_t* pack_nas_SetCDMANetworkParameters_t::pRoaming

8.266.2.7 char* pack_nas_SetCDMANetworkParameters_t::pSPC

8.267 pack_nas_SetNetworkPreference_t Struct Reference

Data Fields

- uint32_t TechnologyPref
- uint32_t Duration
- uint16_t Tlvresult

8.267.1 Detailed Description

This structure contains pack set network preference parameters.

Parameters

TechnologyPref[-IN]	• Bitmask representing the radio technology preference set. • No bits set indicates to the device to automatically determine the technology to use • Values: – Bit 0 - Technology is 3GPP2 – Bit 1 - Technology is 3GPP • Any combination of the following may be returned: – Bit 2 - Analog - AMPS if 3GPP2, GSM if 3GPP – Bit 3 - Digital - CDMA if 3GPP2, WCDMA if 3GPP – Bit 4 - HDR – Bit 5 - LTE – Bits 6 to 15 - Reserved
Duration[IN]	• Duration of active preference – 0 - Permanent – 1 - Power cycle – 2 - Until the end of the next call or a power cycle – 3 - Until the end of the next call, a specified time, or a power cycle – 4 to 6 - Until the end of the next call
Tlvresult	• pack result

8.267.2 Field Documentation

8.267.2.1 uint32_t pack_nas_SetNetworkPreference_t::Duration

8.267.2.2 uint32_t pack_nas_SetNetworkPreference_t::TechnologyPref

8.267.2.3 uint16_t pack_nas_SetNetworkPreference_t::Tlvresult

8.268 pack_nas_SLQSConfigSigInfo_t Struct Reference

Data Fields

- nas_RSSIThresh * pRSSIThresh
- nas_ECIOThresh * pECIOThresh
- nas_HDRSINRThresh * pHDRSINRThresh
- nas_LTESNRThresh * pLTESNRThresh
- nas_IOThresh * pIOThresh
- nas_RSRQThresh * pRSRQThresh
- nas_RSRPThresh * pRSRPThresh
- nas_LTESigRptCfg * pLTESigRptCfg
- nas_TDSCDMASINRCONFThresh * pTDSCDMASINRCONFThresh

8.268.1 Detailed Description

Structure for ConfigSigInfo pack.

Parameters

pRSSIThresh	• RSSI threshold List • See nas_RSSIThresh for more details
pECIOThresh	• ECIO Threshold List • See nas_ECIOThresh for more details
pHDRSINR-Thresh	• HDR SINR Threshold List • See nas_HDRSINRThresh for more details
pLTESNR-Thresh	• LTE SNR Threshold List • See nas_LTESNRThresh for more details
pIOThresh	• IO Threshold List • See nas_IOThresh for more details
pRSRQThresh	• RSRQ Threshold List • See nas_RSRQThresh for more details
pRSRPThresh	• RSRP Threshold List • See nas_RSRPThresh for more details

pLTESigRptCfg	• LTE signal report config • See nas_LTESigRptCfg for more details
pTDSCDMASIN-RCONFThresh	• TD-SCDMA SINR Threshold List • See nas_TDSCDMASINRCONFThresh for more details

8.268.2 Field Documentation

8.268.2.1 nas_ECIOThresh∗ pack_nas_SLQSConfigSigInfo_t::pECIOThresh

8.268.2.2 nas_HDRSINRThresh∗ pack_nas_SLQSConfigSigInfo_t::pHDRSINRThresh

8.268.2.3 nas_IOThresh∗ pack_nas_SLQSConfigSigInfo_t::pIOThresh

8.268.2.4 nas_LTESigRptCfg∗ pack_nas_SLQSConfigSigInfo_t::pLTESigRptCfg

8.268.2.5 nas_LTESNRThresh∗ pack_nas_SLQSConfigSigInfo_t::pLTESNRThresh

8.268.2.6 nas_RSRPThresh∗ pack_nas_SLQSConfigSigInfo_t::pRSRPThresh

8.268.2.7 nas_RSRQThresh∗ pack_nas_SLQSConfigSigInfo_t::pRSRQThresh

8.268.2.8 nas_RSSIThresh∗ pack_nas_SLQSConfigSigInfo_t::pRSSIThresh

8.268.2.9 nas_TDSCDMASINRCONFThresh∗ pack_nas_SLQSConfigSigInfo_t::pTDSCDMASINRCONFThresh

8.269 pack_nas_SLQSGetPLMNName_t Struct Reference

Data Fields

- uint16_t mcc
- uint16_t mnc
- uint8_t ∗ pMncPcsStatus

8.269.1 Detailed Description

This structure contains pack get operator name for specificed network parameters.

Parameters

mcc	• A 16-bit integer representation of MCC. Range: 0 to 999
mnc	• A 16-bit integer representation of MNC. Range: 0 to 999

pMncPcsStatus	• MNC PCS Digit Include Status • Used to interpret the length of the corresponding MNC reported in the PLMN TLV(0x01). • Values – TRUE - MNC is a three-digit value. e.g. a reported value of 90 corresponds to an MNC value of 090 – FALSE - MNC is a two-digit value. e.g. a reported value of 90 corresponds to an MNC value of 90

Note

If pMncPcsStatus is not present, an MNC smaller than 100 is assumed to be a two-digit value, and an MNC greater than or equal to 100 is assumed to be a three digit value.

8.269.2 Field Documentation

8.269.2.1 uint16_t pack_nas_SLQSGetPLMNName_t::mcc

8.269.2.2 uint16_t pack_nas_SLQSGetPLMNName_t::mnc

8.269.2.3 uint8_t* pack_nas_SLQSGetPLMNName_t::pMncPcsStatus

8.270 pack_nas_SLQSInitiateNetworkRegistration_t Struct Reference

Data Fields

- uint32_t regAction
- nas_MNRInfo * pMNRInfo
- uint32_t * pChangeDuration
- uint8_t * pMncPcsDigitStatus

8.270.1 Detailed Description

This structure contains Initiate Network Registration request parameters

Parameters

regAction	• Specifies one of the following register actions : – AUTO_REGISTER - Device registers according to its provisioning and optional parameters supplied with the command are ignored. – MANUAL_REGISTER - Device registers to a specified network and the optional Manual Network Register Information parameter pMNRInfo must also be included for the command to process successfully and supported only for 3GPP.
pMNRInfo	[Optional] • Pointer to structure MNRInfo – See nas_MNRInfo for more information

pChange-Duration	[Optional] • Duration of the change. – 0x00 - Power cycle - Remains active until the next device power cycle – 0x01 - Permanent - Remains active through power cycles until changed by the client
pMncPcsDigit-Status	[Optional] • MNC PCS Digit Include Status – True - MNC is a 3-digit value. – False - MNC is a 2-digit value.

8.270.2 Field Documentation

8.270.2.1 uint32_t* pack_nas_SLQSInitiateNetworkRegistration_t::pChangeDuration

8.270.2.2 uint8_t* pack_nas_SLQSInitiateNetworkRegistration_t::pMncPcsDigitStatus

8.270.2.3 nas_MNRInfo* pack_nas_SLQSInitiateNetworkRegistration_t::pMNRInfo

8.270.2.4 uint32_t pack_nas_SLQSInitiateNetworkRegistration_t::regAction

8.271 pack_nas_SLQSNasConfigSigInfo2_t Struct Reference

Data Fields

- nas_CDMARSSIThresh * pCDMARSSIThresh
- uint16_t * pCDMARSSIDelta
- nas_CDMAECIOThresh * pCDMAECIOThresh
- uint16_t * pCDMAECIODelta
- nas_HDRRSSIThresh * pHDRRSSIThresh
- uint16_t * pHDRRSSIDelta
- nas_HDRECIOThresh * pHDRECIOThresh
- uint16_t * pHDRECIODelta
- nas_HDRSINRThreshold * pHDRSINRThresh
- uint16_t * pHDRSINRDelta
- nas_HDRIOThresh * pHDRIOThresh
- uint16_t * pHDRIODelta
- nas_GSMRSSIThresh * pGSMRSSIThresh
- uint16_t * pGSMRSSIDelta
- nas_WCDMARSSIThresh * pWCDMARSSIThresh
- uint16_t * pWCDMARSSIDelta
- nas_WCDMAECIOThresh * pWCDMAECIOThresh
- uint16_t * pWCDMAECIODelta
- nas_LTERSSIThresh * pLTERSSIThresh
- uint16_t * pLTERSSIDelta
- nas_LTESNRThreshold * pLTESNRThresh
- uint16_t * pLTESNRDelta
- nas_LTERSRQThresh * pLTERSRQThresh
- uint16_t * pLTERSRQDelta
- nas_LTERSRPThresh * pLTERSRPThresh
- uint16_t * pLTERSRPDelta
- nas_LTESigRptConfig * pLTESigRptConfig

- nas_TDSCDMARSCPThresh * pTDSCDMARSCPThresh
- uint16_t * pTDSCDMARSCPDelta
- nas_TDSCDMARSSIThresh * pTDSCDMARSSIThresh
- float * pTDSCDMARSSIDelta
- nas_TDSCDMAECIOThresh * pTDSCDMAECIOThresh
- float * pTDSCDMAECIODelta
- nas_TDSCDMASINRThresh * pTDSCDMASINRThresh
- float * pTDSCDMASINRDelta

8.271.1 Detailed Description

This structure contains pack set the signal strength reporting thresholds parameters.

Parameters

pCDMARSSI-Thresh	• CDMA RSSI threshold List
pCDMARSSI-Delta	• RSSI delta (in units of 0.1 dBm). • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pCDMAECIO-Thresh	• CDMA ECIO Threshold List
pCDMAECIO-Delta	• ECIO delta (in units of 0.1 dB). • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pHDRRSSI-Thresh	• HDR RSSI Threshold List
pHDRRSSIDelta	• RSSI delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pHDRECIO-Thresh	• HDR ECIO Threshold List
pHDRECIODelta	• ECIO delta (in units of 0.1 dB) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pHDRSINR-Thresh	• HDR SINR Threshold List
pHDRSINRDelta	• SINR delta (in units of 1 SINR level) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pHDRIOThresh	• HDR IO Threshold List

pHDRIODelta	• IO delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pGSMRSSI-Thresh	• GSM RSSI Threshold List • See nas_GSMRSSIThresh for more details
pGSMRSSIDelta	• RSSI delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pWCDMARSSI-Thresh	• WCDMA RSSI Threshold List • See nas_WCDMARSSIThresh for more details
pWCDMARSSI-Delta	• RSSI delta (in units of 0.1 dBm). • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pWCDMAECIO-Thresh	• WCDMA ECIO Threshold List
pWCDMAECIO-Delta	• ECIO delta (in units of 0.1 dB) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pLTERSSI-Thresh	• LTE RSSI Threshold List
pLTERSSIDelta	• RSSI delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pLTESNR-Thresh	• LTE SNR Threshold List
pLTESNRDelta	• SNR delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pLTERSRQ-Thresh	• LTE RSRQ Threshold List
pLTERSRQ-Delta	• RSRQ delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pLTERSRP-Thresh	• LTE RSRP Threshold List

pLTERSRPDelta	• RSRP delta (in units of 0.1 dBm). • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pLTESigRpt-Config	• LTE Signal Report Config
pTDSCDMARS-CPThresh	• TDSCDMA RSCP Threshold List
pTDSCDMARS-CPDelta	• RSCP delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pTDSCDMARS-SIThresh	• TDSCDMA RSSI Threshold List
pTDSCDMARS-SIDelta	• RSSI delta (in dBm) used by TD-SCDMA.
pTDSCDMAECI-OThresh	• TDSCDMA ECIO Threshold List
pTDSCDMAECI-ODelta	• ECIO delta (in dB) used by TD-SCDMA
pTDSCDMASIN-RThresh	• TDSCDMA SINR Threshold List
pTDSCDMASIN-RDelta	• SINR delta (in dB) used by TD-SCDMA.

Note

Mixture of threshold and delta values can be provided in the request. But for each type and RAT,only one of threshold list or delta value is to be provided.

8.271.2 Field Documentation

8.271.2.1 uint16_t* pack_nas_SLQSNasConfigSigInfo2_t::pCDMAECIODelta

8.271.2.2 nas_CDMAECIOThresh* pack_nas_SLQSNasConfigSigInfo2_t::pCDMAECIOThresh

8.271.2.3 uint16_t* pack_nas_SLQSNasConfigSigInfo2_t::pCDMARSSIDelta

8.271.2.4 nas_CDMARSSIThresh* pack_nas_SLQSNasConfigSigInfo2_t::pCDMARSSIThresh

8.271.2.5 uint16_t* pack_nas_SLQSNasConfigSigInfo2_t::pGSMRSSIDelta

8.271.2.6 nas_GSMRSSIThresh* pack_nas_SLQSNasConfigSigInfo2_t::pGSMRSSIThresh

8.271.2.7 uint16_t* pack_nas_SLQSNasConfigSigInfo2_t::pHDRECIODelta

8.271.2.8 **nas_HDRECIOThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRECIOThresh

8.271.2.9 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRIODelta

8.271.2.10 **nas_HDRIOThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRIOThresh

8.271.2.11 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRRSSIDelta

8.271.2.12 **nas_HDRRSSIThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRRSSIThresh

8.271.2.13 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRSINRDelta

8.271.2.14 **nas_HDRSINRThreshold*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRSINRThresh

8.271.2.15 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSRPDelta

8.271.2.16 **nas_LTERSRPThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSRPThresh

8.271.2.17 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSRQDelta

8.271.2.18 **nas_LTERSRQThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSRQThresh

8.271.2.19 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSSIDelta

8.271.2.20 **nas_LTERSSIThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSSIThresh

8.271.2.21 **nas_LTESigRptConfig*** pack_nas_SLQSNasConfigSigInfo2_t::pLTESigRptConfig

8.271.2.22 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pLTESNRDelta

8.271.2.23 **nas_LTESNRThreshold*** pack_nas_SLQSNasConfigSigInfo2_t::pLTESNRThresh

8.271.2.24 **float*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMAECIODelta

8.271.2.25 **nas_TDSCDMAECIOThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMAECIOThresh

8.271.2.26 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMARSCPDelta

8.271.2.27 **nas_TDSCDMARSCPThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMARSCPThresh

8.271.2.28 **float*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMARSSIDelta

8.271.2.29 **nas_TDSCDMARSSIThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMARSSIThresh

8.271.2.30 **float*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMASINRDelta

8.271.2.31 **nas_TDSCDMASINRThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMASINRThresh

8.271.2.32 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pWCDMAECIODelta

8.271.2.33 **nas_WCDMAECIOThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pWCDMAECIOThresh

8.271.2.34 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pWCDMARSSIDelta

8.271.2.35 **nas_WCDMARSSIThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pWCDMARSSIThresh

8.272 pack_nas_SLQSNasGet3GPP2Subscription_t Struct Reference

Data Fields

- uint8_t namID

8.272.1 Detailed Description

Structure for 3GPP2 Subscription pack.

Parameters

namID	[Mandatory] • NAM ID of the information to be retrieved. The index starts from 0. A nam_id of 0xFF is used to retrieve information of current NAM.

8.272.2 Field Documentation

8.272.2.1 uint8_t pack_nas_SLQSNasGet3GPP2Subscription_t::namID

8.273 pack_nas_SLQSNasGetTxRxInfo_t Struct Reference

Data Fields

- uint8_t radio_if

8.273.1 Detailed Description

Structure for TxRx Info pack

Parameters

radio_if	[Mandatory] • Radio interface technology of the signal being measured • Valid Values – 0x01 - NAS_RADIO_IF_CDMA_1X - CDMA – 0x02 - NAS_RADIO_IF_CDMA_1XEVDO - HDR – 0x04 - NAS_RADIO_IF_GSM - GSM – 0x05 - NAS_RADIO_IF_UMTS - UMTS – 0x08 - NAS_RADIO_IF_LTE - LTE

8.273.2 Field Documentation

8.273.2.1 uint8_t pack_nas_SLQSNasGetTxRxInfo_t::radio_if

8.274 pack_nas_SLQSNasIndicationRegisterExt_t Struct Reference

Data Fields

- uint8_t * pSystemSelectionInd
- uint8_t * pDDTMInd
- uint8_t * pServingSystemInd
- uint8_t * pDualStandByPrefInd
- uint8_t * pSubscriptionInfoInd
- uint8_t * pNetworkTimeInd
- uint8_t * pSysInfoInd
- uint8_t * pSignalStrengthInd
- uint8_t * pErrorRateInd
- uint8_t * pHDRNewUATIAssInd
- uint8_t * pHDRSessionCloseInd
- uint8_t * pManagedRoamingInd
- uint8_t * pNetworkRejectInd
- uint8_t * pSuppressSysInfoInd
- uint8_t * pLTECphyCa

8.274.1 Detailed Description

This structure contains pack indication register parameters.

Parameters

pSystemSelectionInd	[Optional] • System Selection Preference indication registration. The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pDDTMInd	[Optional] • DDTM (Data Dedicated Transmission Mode) indication registration. The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pServingSystemInd	[Optional] • Serving System indication registration. The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pDualStandByPrefInd	[Optional] • Dual Standby Preference indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pSubscriptionInfoInd	[Optional] • Subscription Information indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable

pNetworkTimeInd	[Optional] • Network Time indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pSysInfoInd	[Optional] • System Information indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pSignalStrengthInd	[Optional] • Signal Strength indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pErrorRateInd	[Optional] • Error Rate indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pHDRNewUATIAssInd	[Optional] • HDR New UATI Assigned indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pHDRSessionCloseInd	[Optional] • HDR Session Closed indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pManagedRoamingInd	[Optional] • Managed Roaming indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable
pNetworkRejectInd	[Optional] • Network reject information indication registration.The following callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pSuppressSysInfoInd	[Optional] • Controls the reporting of QMI_NAS_SYS_INFO_IND when only the reject_cause field has changed. Values: – 0x00 - Disable – 0x01 - Enable- 0x01 - Enable

pLTECphyCa	[Optional] • LTE Physical Carrier Aggregation Information.The following callbacks would not be invoked if the indication is disabled. – 0x00 - Disable (default value) – 0x01 - Enable

8.274.2 Field Documentation

8.274.2.1 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pDDTMInd

8.274.2.2 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pDualStandByPrefInd

8.274.2.3 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pErrorRateInd

8.274.2.4 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pHDRNewUATIAssInd

8.274.2.5 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pHDRSessionCloseInd

8.274.2.6 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pLTECphyCa

8.274.2.7 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pManagedRoamingInd

8.274.2.8 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pNetworkRejectInd

8.274.2.9 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pNetworkTimeInd

8.274.2.10 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pServingSystemInd

8.274.2.11 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pSignalStrengthInd

8.274.2.12 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pSubscriptionInfoInd

8.274.2.13 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pSuppressSysInfoInd

8.274.2.14 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pSysInfoInd

8.274.2.15 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pSystemSelectionInd

8.275 pack_nas_SLQSNASSeteDRXParams_t Struct Reference

Data Fields

- uint8_t * pEdrxEnable
- uint8_t * pCycleLen
- uint8_t * pPagingTimeWindow

8.275.1 Detailed Description

This structure contains the SLQSNASSeteDRXParams request parameters.

Parameters

pEdrxEnable	[Optional] • eDRX Enable • Values – 0x00 - Disable – 0x01 - Enable
pCycleLen	[Optional] • eDRX cycle length • Value to be set per 3GPP TS 24.008 Rel-13 Section 10.5.5.32
pPagingTime-Window	[Optional] • eDRX paging time window • Value to be set per 3GPP TS 24.008 Rel-13 Section 10.5.5.32

8.275.2 Field Documentation

8.275.2.1 uint8_t* pack_nas_SLQSNASSeteDRXParams_t::pCycleLen

8.275.2.2 uint8_t* pack_nas_SLQSNASSeteDRXParams_t::pEdrxEnable

8.275.2.3 uint8_t* pack_nas_SLQSNASSeteDRXParams_t::pPagingTimeWindow

8.276 pack_nas_SLQSNasSwiIndicationRegister_t Struct Reference

Data Fields

- uint8_t lteEsmUl
- uint8_t lteEsmDl
- uint8_t lteEmmUl
- uint8_t lteEmmDl
- uint8_t gsmUmtsUl
- uint8_t gsmUmtsDl
- uint8_t * pRankIndicatorInd
- uint8_t * pTimer

8.276.1 Detailed Description

This structure contains the OTA message indication.

Parameters

lteEsmUl	• 0 - do not report • 1 - report LTE ESM uplink messages
lteEsmDl	• 0 - do not report • 1 - report LTE ESM downlink messages

lteEmmUl	• 0 - do not report • 1 - report LTE EMM uplink messages
lteEmmDl	• 0 - do not report • 1 - report GSM/UMTS uplink messages
gsmUmtsUl	• 0 - do not report • 1 - report GSM/UMTS uplink messages
gsmUmtsDl	• 0 - do not report • 1 - report GSM/UMTS downlink messages
pRankIndicator-Ind	• 0 - do not report • 1 - report Rank Indicator messages
pTimer	• 0 - do not report • 1 - report Timer Indicator messages

8.276.2 Field Documentation

8.276.2.1 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::gsmUmtsDl

8.276.2.2 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::gsmUmtsUl

8.276.2.3 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::lteEmmDl

8.276.2.4 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::lteEmmUl

8.276.2.5 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::lteEsmDl

8.276.2.6 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::lteEsmUl

8.276.2.7 uint8_t* pack_nas_SLQSNasSwiIndicationRegister_t::pRankIndicatorInd

8.276.2.8 uint8_t* pack_nas_SLQSNasSwiIndicationRegister_t::pTimer

8.277 pack_nas_SLQSNASSwiSetChannelLock_t Struct Reference

Data Fields

- nas_wcdmaUARFCN * pWcdmaUARFCN
- nas_lteEARFCN * pLteEARFCN
- nas_ltePCI * pLtePCI

8.277.1 Detailed Description

Structure for ChannelLock pack.

Parameters

pWcdmaUARFCN	[Optional] • See nas_wcdmaUARFCN for more information
pLteEARFCN	[Optional] • See nas_lteEARFCN for more information
pLtePCI	[Optional] • See nas_ltePCI for more information

8.277.2 Field Documentation

8.277.2.1 nas_lteEARFCN∗ pack_nas_SLQSNASSwiSetChannelLock_t::pLteEARFCN

8.277.2.2 nas_ltePCI∗ pack_nas_SLQSNASSwiSetChannelLock_t::pLtePCI

8.277.2.3 nas_wcdmaUARFCN∗ pack_nas_SLQSNASSwiSetChannelLock_t::pWcdmaUARFCN

8.278 pack_nas_SLQSSetBandPreference_t Struct Reference

Data Fields

- uint64_t bandPref

8.278.1 Detailed Description

Provides information about the band preference.

Parameters

bandpreference	• Bit mask representing the band preference to be set. • Bit position meanings: – 0 - BC0_A - Band Class 0, A-System – 1 - BC0_B - Band Class 0, B-System, Band Class 0 AB , GSM 850 Band – 2 - BC1 - Band Class 1, all blocks – 3 - BC2 - Band Class 2 place holder – 4 - BC3 - Band Class 3, A-System – 5 - BC4 - Band Class 4, all blocks – 6 - BC5 - Band Class 5, all blocks – 7 - GSM_DCS_1800 - GSM DCS band – 8 - GSM_EGSM_900 - GSM Extended GSM (E-GSM) band – 9 - GSM_PGSM_900 - GSM Primary GSM (P-GSM) band – 10 - BC6 - Band Class 6 – 11 - BC7 - Band Class 7 – 12 - BC8 - Band Class 8 – 13 - BC9 - Band Class 9 – 14 - BC10 - Band Class 10 – 15 - BC11 - Band Class 11 – 16 - GSM_450 - GSM 450 band – 17 - GSM_480 - GSM 480 band – 18 - GSM_750 - GSM 750 band – 19 - GSM_850 - GSM 850 band – 20 - GSM_RGSM_900 - GSM Railways GSM Band – 21 - GSM_PCS_1900 - GSM PCS band – 22 - WCDMA_I_IMT_2000 - WCDMA EUROPE JAPAN and CHINA IMT 2100 band – 23 - WCDMA_II_PCS_1900 - WCDMA US PCS 1900 band – 24 - WCDMA_III_1700 - WCDMA EUROPE and CHINA DCS 1800 band – 25 - WCDMA_IV_1700 - WCDMA US 1700 band – 26 - WCDMA_V_850 - WCDMA US 850 band – 27 - WCDMA_VI_800 - WCDMA JAPAN 800 band – 28 - BC12 - Band Class 12 – 29 - BC14 - Band Class 14 – 30 - RESERVED_2 - Reserved 2 – 31 - BC15 - Band Class 15 – 32 - 47 - Reserved – 48 - WCDMA_VII_2600 - WCDMA EUROPE 2600 band – 49 - WCDMA_VIII_900 - WCDMA EUROPE and JAPAN 900 band – 50 - WCDMA_IX_1700 - WCDMA JAPAN 1700 band – 51 to 55 - Reserved – 56 - BBC16 - Band Class 16 – 57 - BC17 - Band Class 17 – 58 - BC18 - Band Class 18 – 59 - BC19 - Band Class 19 – 60 to 64 - Reserved

8.278.2 Field Documentation

8.278.2.1 uint64_t pack_nas_SLQSSetBandPreference_t::bandPref

8.279 pack_nas_SLQSSetSignalStrengthsCallback_t Struct Reference

Data Fields

- uint8_t bEnable
- nas_SLQSSignalStrengthsIndReq * pSigIndReq

8.279.1 Detailed Description

This structure contains paramaters pack set strength thresholds callback.

Parameters

bEnable	0/1 to disable/enable RSSI signal stregth indication
pSigIndReq	parameters to control signal strength indication

8.279.2 Field Documentation

8.279.2.1 uint8_t pack_nas_SLQSSetSignalStrengthsCallback_t::bEnable

8.279.2.2 nas_SLQSSignalStrengthsIndReq* pack_nas_SLQSSetSignalStrengthsCallback_t::pSigIndReq

8.280 pack_nas_SLQSSetSysSelectionPref_t Struct Reference

Data Fields

- uint8_t * pEmerMode
- uint16_t * pModePref
- uint64_t * pBandPref
- uint16_t * pPRLPref
- uint16_t * pRoamPref
- uint64_t * pLTEBandPref
- struct nas_netSelectionPref * pNetSelPref
- uint8_t * pChgDuration
- uint8_t * pMNCIncPCSDigStat
- uint32_t * pSrvDomainPref
- uint32_t * pGWAcqOrderPref
- uint64_t * pTdscdmaBandPref
- struct nas_acqOrderPref * pAcqOrderPref
- uint32_t * pSrvRegRestriction
- struct nas_CSGID * pCSGID
- unsigned char * pRAT

8.280.1 Detailed Description

Contain the system selection preferences.

Parameters

pEmerMode	• Optional parameter specifying the emergency Mode • Values: – 0 - OFF (normal) – 1 - ON (Emergency)
pModePref	• Optional parameter • Bit Mask indicating the radio technology mode preference • Bit values: – Bit 0 - cdma2000 1x – Bit 1 - cdma2000 HRPD(1xEV-DO) – Bit 2 - GSM – Bit 3 - UMTS – Bit 4 - LTE

pBandPref	• Optional parameter • Bit mask representing the band preference • Bit values: – Bit 0 - Band Class 0, A-System – Bit 1 - Band Class 0, B-System, Band Class 0 AB, GSM 850 Band – Bit 2 - Band Class 1, all blocks – Bit 3 - Band Class 2 place holder – Bit 4 - Band Class 3, A-System – Bit 5 - Band Class 4, all blocks – Bit 6 - Band Class 5, all blocks – Bit 7 - GSM_DCS_1800 band – Bit 8 - GSM Extended GSM (E-GSM) 900 band – Bit 9 - GSM Primary GSM (P-GSM) 900 band – Bit 10 - Band Class 6 – Bit 11 - Band Class 7 – Bit 12 - Band Class 8 – Bit 13 - Band Class 9 – Bit 14 - Band Class 10 – Bit 15 - Band Class 11 – Bit 16 - GSM 450 band – Bit 17 - GSM 480 band – Bit 18 - GSM 750 band – Bit 19 - GSM 850 band – Bit 20 - GSM Railways GSM 900 Band – Bit 21 - GSM PCS 1900 band – Bit 22 - WCDMA Europe, Japan, and China IMT 2100 band – Bit 23 - WCDMA U.S. PCS 1900 band – Bit 24 - WCDMA Europe and China DCS 1800 band – Bit 25 - WCDMA U.S. 1700 band – Bit 26 - WCDMA U.S. 850 band – Bit 27 - WCDMA Japan 800 band – Bit 28 - Band Class 12 – Bit 29 - Band Class 14 – Bit 30 - Reserved – Bit 31 - Band Class 15 – Bit 32 to 47 - Reserved – Bit 48 - WCDMA Europe 2600 band – Bit 49 - WCDMA Europe and Japan 900 band – Bit 50 - WCDMA Japan 1700 band – Bit 51 to 55 - Reserved – Bit 56 - Band Class 16 – Bit 57 - Band Class 17 – Bit 58 - Band Class 18 – Bit 59 - Band Class 19 – Bit 60 to 64 - Reserved

pPRLPref	• Optional parameter indicating the CDMA PRL Preference • Values: – 0x0001 - Acquire available system only on the A side – 0x0002 - Acquire available system only on the B side – 0x3FFF - Acquire any available systems
pRoamPref	• Optional parameter indicating the roaming Preference • Values: – 0x01 - Acquire only systems for which the roaming indicator is off – 0x02 - Acquire a system as long as its roaming indicator is not off – 0x03 - Acquire only systems for which the roaming indicator is off or solid on, i.e. not flashing; CDMA only – 0xFF - Acquire systems, regardless of their roaming indicator
pLTEBandPref	• Optional parameter • Bit mask representing the LTE band preference • Bit Values – Bit 0 - E-UTRA Operating Band 1 – Bit 1 - E-UTRA Operating Band 2 – Bit 2 - E-UTRA Operating Band 3 – Bit 3 - E-UTRA Operating Band 4 – Bit 4 - E-UTRA Operating Band 5 – Bit 5 - E-UTRA Operating Band 6 – Bit 6 - E-UTRA Operating Band 7 – Bit 7 - E-UTRA Operating Band 8 – Bit 8 - E-UTRA Operating Band 9 – Bit 9 - E-UTRA Operating Band 10 – Bit 10 - E-UTRA Operating Band 11 – Bit 11 - E-UTRA Operating Band 12 – Bit 12 - E-UTRA Operating Band 13 – Bit 13 - E-UTRA Operating Band 14 – Bit 16 - E-UTRA Operating Band 17 – Bit 17 - E-UTRA Operating Band 18 – Bit 18 - E-UTRA Operating Band 19 – Bit 19 - E-UTRA Operating Band 20 – Bit 20 - E-UTRA Operating Band 21 – Bit 32 - E-UTRA Operating Band 33 – Bit 33 - E-UTRA Operating Band 34 – Bit 34 - E-UTRA Operating Band 35 – Bit 35 - E-UTRA Operating Band 36 – Bit 36 - E-UTRA Operating Band 37 – Bit 37 - E-UTRA Operating Band 38 – Bit 38 - E-UTRA Operating Band 39 – Bit 39 - E-UTRA Operating Band 40 – All other bits are reserved

pNetSelPref	- netSelectionPref • Optional parameter for specifying Network Selection Preference • Modem selects networks based on this parameter(if present). • see nas_netSelectionPref for more information
pChgDuration	• Optional parameter specifying the duration of the change • Values: – 0x00 - Power cycle - Remains active until the next device power cycle – 0x01 - Permanent - Remains active through power cycles until changed by client – Device will use "0x01 - permanent" as default if this parameter is omitted
pMNCIncPCS-DigStat	• Optional parameter indicating if MNC includes PCS digit • Values: – TRUE - MNC is a 3 digit value; e.g., a reported value of 90 corresponds to an MNC value of 090 – FALSE - MNC is a 2-digit value; e.g., a reported value of 90 corresponds to an MNC value of 90
pSrvDomainPref	• Optional parameter indicating Service domain preference • Values: – 0x00 - Circuit switched only – 0x01 - Packet switched only – 0x02 - Circuit switched and packet switched – 0x03 - Packet switched attach – 0x04 - Packet switched detach
pGWAcqOrder-Pref	• Optional parameter indicating GSM/WCDMA Acquisition order Preference • Values: – 0x00 - Automatic – 0x01 - GSM then WCDMA – 0x02 - WCDMA then GSM
pTdscdmaBand-Pref	• Optional parameter indicating bitmask representing the TD-SCDMA band preference to be set. • Values: – 0x01 - TD-SCDMA Band A – 0x02 - TD-SCDMA Band B – 0x04 - TD-SCDMA Band C – 0x08 - TD-SCDMA Band D – 0x10 - TD-SCDMA Band E – 0x20 - TD-SCDMA Band F – All other bits are reserved
pAcqOrderPref	- acqOrderPref • Optional parameter for specifying Acquisition Order Preference • see nas_acqOrderPref for more information

pSrvReg-Restriction	• Optional parameter indicating Network Selection Registration Restriction Preference • Values: – 0x00 - Device follows the normal registration process – 0x01 - Device camps on the network according to its provisioning, but does not register – 0x02 - Device selects the network for limited service – All other values are reserved.
pCSGID	- CSGID • Optional parameter for specifying CSG ID • Either of pNetSelPref or pCSGID can be set. • see nas_CSGID for more information
pRAT	• Optional parameter Radio Access Technology order Preference • Values: – 0x04 - GSM – 0x05 - UMTS – 0x08 - LTE – 0x09 - TDSCDMA

8.280.2 Field Documentation

8.280.2.1 struct nas_acqOrderPref* pack_nas_SLQSSetSysSelectionPref_t::pAcqOrderPref

8.280.2.2 uint64_t* pack_nas_SLQSSetSysSelectionPref_t::pBandPref

8.280.2.3 uint8_t* pack_nas_SLQSSetSysSelectionPref_t::pChgDuration

8.280.2.4 struct nas_CSGID* pack_nas_SLQSSetSysSelectionPref_t::pCSGID

8.280.2.5 uint8_t* pack_nas_SLQSSetSysSelectionPref_t::pEmerMode

8.280.2.6 uint32_t* pack_nas_SLQSSetSysSelectionPref_t::pGWAcqOrderPref

8.280.2.7 uint64_t* pack_nas_SLQSSetSysSelectionPref_t::pLTEBandPref

8.280.2.8 uint8_t* pack_nas_SLQSSetSysSelectionPref_t::pMNCIncPCSDigStat

8.280.2.9 uint16_t* pack_nas_SLQSSetSysSelectionPref_t::pModePref

8.280.2.10 struct nas_netSelectionPref* pack_nas_SLQSSetSysSelectionPref_t::pNetSelPref

8.280.2.11 uint16_t* pack_nas_SLQSSetSysSelectionPref_t::pPRLPref

8.280.2.12 unsigned char* pack_nas_SLQSSetSysSelectionPref_t::pRAT

8.280.2.13 uint16_t* pack_nas_SLQSSetSysSelectionPref_t::pRoamPref

8.280.2.14 uint32_t* pack_nas_SLQSSetSysSelectionPref_t::pSrvDomainPref

8.280.2.15 uint32_t* pack_nas_SLQSSetSysSelectionPref_t::pSrvRegRestriction

8.280.2.16 uint64_t* pack_nas_SLQSSetSysSelectionPref_t::pTdscdmaBandPref

8.281 pack_nas_SLQSSwiPSDetach_t Struct Reference

Data Fields

- uint8_t * pDetachAction

8.281.1 Detailed Description

Structure for PS connection detach pack.

Parameters

pDetachAction[IN]	• Values – 2- Initiates an immediate packet domain detach.

8.281.2 Field Documentation

8.281.2.1 uint8_t* pack_nas_SLQSSwiPSDetach_t::pDetachAction

8.282 pack_pds_PDSInjectTimeReference_t Struct Reference

Data Fields

- uint64_t systemTime
- uint16_t systemDiscontinuities

8.282.1 Detailed Description

Structure contain the parameter for PDS Inject time.

Parameters

systemTime	• System time(milliseconds)
system-Discontinuities	• Number of system time discontinuities

8.282.2 Field Documentation

8.282.2.1 uint16_t pack_pds_PDSInjectTimeReference_t::systemDiscontinuities

8.282.2.2 uint64_t pack_pds_PDSInjectTimeReference_t::systemTime

8.283 pack_pds_ResetPDSData_t Struct Reference

Data Fields

- uint32_t * pGPSDataMask
- uint32_t * pCellDataMask

8.283.1 Detailed Description

Structure contain the parameter to Resets the specified PDS data.

Parameters

pGPSDataMask	• Bitmask of GPS data to clear (optional) – 0x00000001 - EPH – 0x00000002 - ALM – 0x00000004 - POS – 0x00000008 - TIME – 0x00000010 - IONO – 0x00000020 - UTC – 0x00000040 - HEALTH – 0x00000080 - SVDIR – 0x00000100 - SVSTEER – 0x00000200 - SADATA – 0x00000400 - RTI – 0x00000800 - ALM_CORR – 0x00001000 - FREQ_BIAS_EST
pCellDataMask	• Bitmask of cell data to clear (optional) – 0x00000001 - POS – 0x00000002 - LATEST_GPS_POS – 0x00000004 - OTA_POS – 0x00000008 - EXT_REF_POS – 0x00000010 - TIMETAG – 0x00000020 - CELLID – 0x00000040 - CACHED_CELLID – 0x00000080 - LAST_SRV_CELL – 0x00000100 - CUR_SRV_CELL – 0x00000200 - NEIGHBOR_INFO

8.283.2 Field Documentation

8.283.2.1 uint32_t* pack_pds_ResetPDSData_t::pCellDataMask

8.283.2.2 uint32_t* pack_pds_ResetPDSData_t::pGPSDataMask

8.284 pack_pds_SetEventReportCallback_t Struct Reference

Data Fields

- uint8_t posDataNmea
- uint8_t rptPosData

8.284.1 Detailed Description

Structure contain the parameter for the automatic tracking configuration for the NMEA COM port.

Parameters

posDataNmea	• Report new position data in NMEA format. • Values – 0x00 - Disable – 0x01 - Enable
rptPosData	• Report new position data in raw format. • Values – 0x00 - Disable – 0x01 - Enable

8.284.2 Field Documentation

8.284.2.1 uint8_t pack_pds_SetEventReportCallback_t::posDataNmea

8.284.2.2 uint8_t pack_pds_SetEventReportCallback_t::rptPosData

8.285 pack_pds_SetPDSDefaults_t Struct Reference

Data Fields

- uint32_t operation
- uint8_t timeout
- uint32_t interval
- uint32_t accuracy

8.285.1 Detailed Description

Structure containing session configuration parameters.

Parameters

operation	• Current session operating mode – 0 - Standalone – 1 - MS based – 2 - MS assisted
timeout	• Maximum amount of time (seconds) to work on each fix, maximum is 255

interval	• Interval (seconds) between fix requests
accuracy	• Preferred accuracy threshold (meters)

8.285.2 Field Documentation

8.285.2.1 uint32_t pack_pds_SetPDSDefaults_t::accuracy

8.285.2.2 uint32_t pack_pds_SetPDSDefaults_t::interval

8.285.2.3 uint32_t pack_pds_SetPDSDefaults_t::operation

8.285.2.4 uint8_t pack_pds_SetPDSDefaults_t::timeout

8.286 pack_pds_SetPDSState_t Struct Reference

Data Fields

- uint32_t enable

8.286.1 Detailed Description

Structure contain PDS state parameters.

Parameters

enable	• Desired PDS state – Zero - disable – Non-Zero - enable

8.286.2 Field Documentation

8.286.2.1 uint32_t pack_pds_SetPDSState_t::enable

8.287 pack_pds_SetPortAutomaticTracking_t Struct Reference

Data Fields

- uint32_t bAuto

8.287.1 Detailed Description

Structure contain the parameter for the automatic tracking configuration for the NMEA COM port.

Parameters

bAuto	• Enable automatic tracking for NMEA COM port – 0x00 - Disabled – 0x01 - Enabled

8.287.2 Field Documentation

8.287.2.1 uint32_t pack_pds_SetPortAutomaticTracking_t::bAuto

8.288 pack_pds_SetServiceAutomaticTracking_t Struct Reference

Data Fields

- uint32_t bAuto

8.288.1 Detailed Description

Structure contain the parameter to Sets the automatic tracking state.

Parameters

bAuto	• Automatic tracking session started for service – 0x00 - Disabled – 0x01 - Enabled

8.288.2 Field Documentation

8.288.2.1 uint32_t pack_pds_SetServiceAutomaticTracking_t::bAuto

8.289 pack_pds_SetXTRAAutomaticDownload_t Struct Reference

Data Fields

- uint32_t bEnabled
- uint16_t interval

8.289.1 Detailed Description

Structure contain the parameter to set the XTRA automatic database download configuration.

Parameters

bEnabled	• Automatic XTRA download status – 0 - Disabled – 1 - Enabled

interval	• Interval (hours) between XTRA downloads

8.289.2 Field Documentation

8.289.2.1 uint32_t pack_pds_SetXTRAAutomaticDownload_t::bEnabled

8.289.2.2 uint16_t pack_pds_SetXTRAAutomaticDownload_t::interval

8.290 pack_pds_SetXTRANetwork_t Struct Reference

Data Fields

- uint32_t preference

8.290.1 Detailed Description

Structure contain the parameter to Sets the XTRA WWAN network preference

Parameters

preference	• XTRA WWAN network preference – 0x00 - None (any available network) – 0x01 - Home-only, only when on home systems – 0x02 - Roam-only, only when on non-home systems

8.290.2 Field Documentation

8.290.2.1 uint32_t pack_pds_SetXTRANetwork_t::preference

8.291 pack_pds_SLQSGetAGPSConfig_t Struct Reference

Data Fields

- uint8_t * pNetworkMode

8.291.1 Detailed Description

Structure contain the parameter to PDS AGPS (MS-based) configuration pack.

Parameters

pNetworkMode	• Network Mode of AGPS Server [optional - should be present in Multimode Systems] – 0x00 - UMTS – 0x01 - CDMA

8.291.2 Field Documentation

8.291.2.1 uint8_t* pack_pds_SLQSGetAGPSConfig_t::pNetworkMode

8.292 pack_pds_SLQSPDSInjectAbsoluteTimeReference_t Struct Reference

Data Fields

- uint64_t timeMsec
- uint32_t timeUncMsec
- uint8_t timeBase
- uint8_t forceFlag

8.292.1 Detailed Description

Structure contain the parameter to Injects a absolute time reference.

Parameters

timeMsec	• Represents the number of milliseconds elapsed since either a GPS or UTC time base. If the time base is UTC, this value should NOT include leap seconds
timeUncMsec	• Time uncertainty in milliseconds
timeBase	• Time base – 0x00 - GPS (midnight, Jan 6, 1980) – 0x01 - UTC (midnight, Jan 1, 1970)
forceFlag	• Force acceptance of data

8.292.2 Field Documentation

8.292.2.1 uint8_t pack_pds_SLQSPDSInjectAbsoluteTimeReference_t::forceFlag

8.292.2.2 uint8_t pack_pds_SLQSPDSInjectAbsoluteTimeReference_t::timeBase

8.292.2.3 uint64_t pack_pds_SLQSPDSInjectAbsoluteTimeReference_t::timeMsec

8.292.2.4 uint32_t pack_pds_SLQSPDSInjectAbsoluteTimeReference_t::timeUncMsec

8.293 pack_pds_SLQSPDSInjectPositionData_t Struct Reference

Data Fields

- uint64_t * pTimeStamp
- uint64_t * pLatitude
- uint64_t * pLongitude
- uint32_t * pAltitudeWrtEllipsoid

- uint32_t * pAltitudeWrtSealevel
- uint32_t * pHorizontalUncCircular
- uint32_t * pVerticalUnc
- uint8_t * pHorizontalConfidence
- uint8_t * pVerticalConfidence
- uint8_t * pPositionSource
- uint8_t * pTimeType

8.293.1 Detailed Description

Position Data Parameters from the external source to be injected to PDS engine.

Parameters

pTimeStamp	• Timestamp of the injected position in msec. The time can be of type UTC, GPS, or Age and is defined in the pTimeType parameter. If the pTimeType is not present, the timestamp shall be assumed to be UTC time
pLatitude	• Latitude position referenced to the WGS-84 reference ellipsoid, counting positive angles north of the equator and negative angles south of the equator. Value (in decimal degrees) in the range from -90 degrees to +90 degrees.Value in double float format (refer toIEEE Std 754-1985)
pLongitude	• Longitude position referenced to the WGS-84 reference ellipsoid, counting positive angles east of the Greenwich Meridian and negative angles west of Greenwich meridian. Value (in decimal degrees) in the range from -180 degrees to +180 degrees.
pAltitudeWrt-Ellipsoid	• Height above the WGS-84 reference ellipsoid. Value conveys height (in meters). When injecting altitude information, the control point should include either this parameter or the pAltitudeWrt-Sealevel parameter. Value in single float format (refer to IEEE Std 754-1985)
pAltitudeWrt-Sealevel	• Height of MS above the mean sea level in units (in meters). When injecting altitude information, the control point should include either this parameter or the pAltitudeWrtEllipsoid parameter. Value in single float format (refer to IEEE Std 754-1985)
pHorizontalUnc-Circular	• Circular horizontal uncertainty (in meters). This parameter must be included if the latitude and longitude parameters are specified. Value in single float format (refer to IEEE Std 754-1985)
pVerticalUnc	• Vertical uncertainty (in meters). This parameter must be included if one of the altitude parameter are specified.Value in single float format (refer to IEEE Std 754-1985)
pHorizontal-Confidence	• Confidence value of the location horizontal uncertainty, specified as percentage, 1 to 100. This parameter must be included if the latitude and longitude parameters are specified.
pVertical-Confidence	• Confidence value of the location vertical uncertainty, specified as percentage, 1 to 100. This parameter must be included if one of the altitude paramters are specified.

pPositionSource	• Source of injected position: – 0x00 - Unknown – 0x01 - GPS – 0x02 - Cell ID – 0x03 - Enhanced cell ID – 0x04 - WiFi – 0x05 - Terrestrial – 0x06 - Terrestrial hybrid – 0x07 - Other
pTimeType	• Defines the time value set in the pTimeStamp parameter. – 0x00 - UTC Time: starting Jan 1, 1970 – 0x01 - GPS Time: starting Jan 6, 1980 – 0x02 - Age: Age of position information

8.293.2 Field Documentation

8.293.2.1 uint32_t* pack_pds_SLQSPDSInjectPositionData_t::pAltitudeWrtEllipsoid

8.293.2.2 uint32_t* pack_pds_SLQSPDSInjectPositionData_t::pAltitudeWrtSealevel

8.293.2.3 uint8_t* pack_pds_SLQSPDSInjectPositionData_t::pHorizontalConfidence

8.293.2.4 uint32_t* pack_pds_SLQSPDSInjectPositionData_t::pHorizontalUncCircular

8.293.2.5 uint64_t* pack_pds_SLQSPDSInjectPositionData_t::pLatitude

8.293.2.6 uint64_t* pack_pds_SLQSPDSInjectPositionData_t::pLongitude

8.293.2.7 uint8_t* pack_pds_SLQSPDSInjectPositionData_t::pPositionSource

8.293.2.8 uint64_t* pack_pds_SLQSPDSInjectPositionData_t::pTimeStamp

8.293.2.9 uint8_t* pack_pds_SLQSPDSInjectPositionData_t::pTimeType

8.293.2.10 uint8_t* pack_pds_SLQSPDSInjectPositionData_t::pVerticalConfidence

8.293.2.11 uint32_t* pack_pds_SLQSPDSInjectPositionData_t::pVerticalUnc

8.294 pack_pds_SLQSSetAGPSConfig_t Struct Reference

Data Fields

- uint32_t * pServerAddress
- uint32_t * pServerPort
- uint8_t * pServerURL
- uint8_t * pServerURLLength
- uint8_t * pNetworkMode

8.294.1 Detailed Description

Structure contain the parameter to Sets the PDS AGPS (MS-based) configuration.

Parameters

pServerAddress	• IPv4 address of AGPS server [optional]
pServerPort	• Port number of AGPS server [optional - should be present when pServerAddress is present]
pServerURL	• URL of the AGPS server [optional]
pServerURL-Length	• URL length of AGPS server [optional - should be present when pServerURL is present]
pNetworkMode	• Network Mode of AGPS Server [optional - should be present in Multimode Systems] – 0x00 - UMTS – 0x01 - CDMA

8.294.2 Field Documentation

8.294.2.1 uint8_t* pack_pds_SLQSSetAGPSConfig_t::pNetworkMode

8.294.2.2 uint32_t* pack_pds_SLQSSetAGPSConfig_t::pServerAddress

8.294.2.3 uint32_t* pack_pds_SLQSSetAGPSConfig_t::pServerPort

8.294.2.4 uint8_t* pack_pds_SLQSSetAGPSConfig_t::pServerURL

8.294.2.5 uint8_t* pack_pds_SLQSSetAGPSConfig_t::pServerURLLength

8.295 pack_pds_SLQSSetPositionMethodState_t Struct Reference

Data Fields

- uint8_t * pXtraTimeState
- uint8_t * pXtraDataState
- uint8_t * pWifiState

8.295.1 Detailed Description

Parameters to Set state of positioning method for a device.

Parameters

pXtraTimeState	• XTRA Time Position Method State. • Values: – 0x00 - Disable – 0x01 - Enable
pXtraDataState	• XTRA Data Position Method State. • Values: – 0x00 - Disable – 0x01 - Enable
Latitude	• WiFi Position Method State • Values: – 0x00 - Disable – 0x01 - Enable

8.295.2 Field Documentation

8.295.2.1 uint8_t* pack_pds_SLQSSetPositionMethodState_t::pWifiState

8.295.2.2 uint8_t* pack_pds_SLQSSetPositionMethodState_t::pXtraDataState

8.295.2.3 uint8_t* pack_pds_SLQSSetPositionMethodState_t::pXtraTimeState

8.296 pack_pds_StartPDSTrackingSessionExt_t Struct Reference

Data Fields

- uint8_t sessionControl
- uint8_t sessionType
- uint8_t sessionOperation
- uint8_t sessionServerOption
- uint8_t fixTimeout
- uint32_t fixInterval
- uint32_t fixCount
- uint32_t fixAccuracy

8.296.1 Detailed Description

Structure contain the parameter for PDS tracking session.

Parameters

sessionControl	• Control method: – 0x0 - Manual

sessionType	• Type: – 0x0 - New
session-Operation	• Operating mode: – 0x00 - Standalone – 0x01 - MS-based
sessionServer-Option	• Location server option: – 0x0 - Default
fixTimeout	• Maximum time to work on each fix (in seconds, max 255)
fixCount	• Count of position fix requests for this session (must be at least 1)
fixInterval	• interval between position fix requests (in seconds)
fixAccuracy	• Preferred accuracy threshold(in meters)

8.296.2 Field Documentation

8.296.2.1 uint32_t pack_pds_StartPDSTrackingSessionExt_t::fixAccuracy

8.296.2.2 uint32_t pack_pds_StartPDSTrackingSessionExt_t::fixCount

8.296.2.3 uint32_t pack_pds_StartPDSTrackingSessionExt_t::fixInterval

8.296.2.4 uint8_t pack_pds_StartPDSTrackingSessionExt_t::fixTimeout

8.296.2.5 uint8_t pack_pds_StartPDSTrackingSessionExt_t::sessionControl

8.296.2.6 uint8_t pack_pds_StartPDSTrackingSessionExt_t::sessionOperation

8.296.2.7 uint8_t pack_pds_StartPDSTrackingSessionExt_t::sessionServerOption

8.296.2.8 uint8_t pack_pds_StartPDSTrackingSessionExt_t::sessionType

8.297 pack_qmi_t Struct Reference

Data Fields

- uint16_t xid
- int timeout
- uint16_t msgid
- uint8_t svc

8.297.1 Detailed Description

qmi request context

Parameters

in	*xid*	transaction id
out	*timeout*	timeout recommended in seconds
out	*msgid*	message id
out	*svc*	qmi service

8.297.2 Field Documentation

8.297.2.1 uint16_t pack_qmi_t::msgid

8.297.2.2 uint8_t pack_qmi_t::svc

8.297.2.3 int pack_qmi_t::timeout

8.297.2.4 uint16_t pack_qmi_t::xid

8.298 pack_qos_BindDataPort_t Struct Reference

Data Fields

- qos_BindDataPortPeripheralEndPointID_t * pPeripheralEndPointID
- qos_BindDataPortMuxID_t * pMuxID
- qos_BindDataPortSIODataPort_t * pSIODataPort

8.298.1 Detailed Description

Structure that contains the request Binds a control point to a data port.

Parameters

pPeripheralEnd-PointID	• See qos_BindDataPortPeripheralEndPointID_t for more information.
pMuxID	• See qos_BindDataPortMuxID_t for more information.
pSIODataPort	• See qos_BindDataPortSIODataPort_t for more information.

8.298.2 Field Documentation

8.298.2.1 qos_BindDataPortMuxID_t* pack_qos_BindDataPort_t::pMuxID

8.298.2.2 qos_BindDataPortPeripheralEndPointID_t* pack_qos_BindDataPort_t::pPeripheralEndPointID

8.298.2.3 qos_BindDataPortSIODataPort_t* pack_qos_BindDataPort_t::pSIODataPort

8.299 pack_qos_SLQSQosSwiReadApnExtraParams_t Struct Reference

Data Fields

- uint32_t apnId

8.299.1 Detailed Description

Structure that contains the APN ID to obtain extra APN parameters

Parameters

apnId[IN]	• APN id

8.299.2 Field Documentation

8.299.2.1 uint32_t pack_qos_SLQSQosSwiReadApnExtraParams_t::apnId

8.300 pack_qos_SLQSQosSwiReadDataStats_t Struct Reference

Data Fields

- uint32_t apnId

8.300.1 Detailed Description

Structure that contains the APN ID to obtain data statistics

Parameters

apnId[IN]	• APN id

8.300.2 Field Documentation

8.300.2.1 uint32_t pack_qos_SLQSQosSwiReadDataStats_t::apnId

8.301 pack_qos_SLQSSetQosEventCallback_t Struct Reference

Data Fields

- uint8_t enable

8.301.1 Detailed Description

Structure that contains the APN ID to obtain data statistics

Parameters

in	*enable*	• 1 - Enable QoS event reporting • 0 - Disable QoS event reporting

8.301.2 Field Documentation

8.301.2.1 uint8_t pack_qos_SLQSSetQosEventCallback_t::enable

8.302 pack_rms_SetSMSWake_t Struct Reference

Data Fields

- uint32_t enabled
- uint32_t wake_mask

8.302.1 Detailed Description

Pack set SMS wake parameters

Parameters

enabled	• SMS wake functionality enabled – 0 - Disabled – 1 - Enabled
wake_mask	• SMS wake mask to search for incoming messages (only relevant when enabled)

8.302.2 Field Documentation

8.302.2.1 uint32_t pack_rms_SetSMSWake_t::enabled

8.302.2.2 uint32_t pack_rms_SetSMSWake_t::wake_mask

8.303 pack_sar_SLQSSetRfSarState_t Struct Reference

Data Fields

- uint32_t RfSarState

8.303.1 Detailed Description

This sturcture contain sets the specified RF SAR state parameter.

Parameters

RfSarState	• SAR RF State – QMI_SAR_RF_STATE_DEFAULT – QMI_SAR_RF_STATE_1 – QMI_SAR_RF_STATE_2 – QMI_SAR_RF_STATE_3 – QMI_SAR_RF_STATE_4 – QMI_SAR_RF_STATE_5 – QMI_SAR_RF_STATE_6 – QMI_SAR_RF_STATE_7 – QMI_SAR_RF_STATE_8

8.303.2 Field Documentation

8.303.2.1 uint32_t pack_sar_SLQSSetRfSarState_t::RfSarState

8.304 pack_sms_SaveSMS_t Struct Reference

Data Fields

- uint32_t storageType
- uint32_t messageFormat
- uint32_t messageSize
- uint8_t * pMessage

8.304.1 Detailed Description

Sutructure containing parameters to Save an SMS message to device memory

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
messageFormat	• Message format – 0 - CDMA (IS-637B) – 1 - 5 (Reserved) – 6 - GSM/WCDMA PP
messageSize	• The length of the message contents in bytes
pMessage	• The message contents

8.304.2 Field Documentation

8.304.2.1 uint32_t pack_sms_SaveSMS_t::messageFormat

8.304.2.2 uint32_t pack_sms_SaveSMS_t::messageSize

8.304.2.3 uint8_t* pack_sms_SaveSMS_t::pMessage

8.304.2.4 uint32_t pack_sms_SaveSMS_t::storageType

8.305 pack_sms_SendSMS_t Struct Reference

Data Fields

- uint32_t messageFormat
- uint32_t messageSize
- uint8_t * pMessage
- uint8_t * pLinktimer

8.305.1 Detailed Description

This structure contains pack send SMS parameters.

Parameters

messageFormat	• Message format – 0 - CDMA (IS-637B) – 1 - 5 (Reserved) – 6 - GSM/WCDMA PP
messageSize	• The length of the message contents in bytes
pLinktimer	• GW SMS link open for the specified number of second
pMessage	• The message contents in PDU format contains SMS header and payload message

8.305.2 Field Documentation

8.305.2.1 uint32_t pack_sms_SendSMS_t::messageFormat

8.305.2.2 uint32_t pack_sms_SendSMS_t::messageSize

8.305.2.3 uint8_t* pack_sms_SendSMS_t::pLinktimer

8.305.2.4 uint8_t* pack_sms_SendSMS_t::pMessage

8.306 pack_sms_SetNewSMSCallback_t Struct Reference

Data Fields

- enum eqmiCbkSetStatus status

8.306.1 Detailed Description

This strucure contains pack set new SMS callback parameters.

Parameters

status	callback parameter

8.306.2 Field Documentation

8.306.2.1 enum eqmiCbkSetStatus pack_sms_SetNewSMSCallback_t::status

8.307 pack_sms_SetSMSCAddress_t Struct Reference

Data Fields

- uint8_t * pSMSCAddress
- uint8_t * pSMSCType

8.307.1 Detailed Description

Structure to Set the SMS center address.

Parameters

SMSCAddress	• The SMS center address represented as a NULL terminated string
SMSCType	• The SMS center address type represented as a NULL terminated string (optional).

8.307.2 Field Documentation

8.307.2.1 uint8_t* pack_sms_SetSMSCAddress_t::pSMSCAddress

8.307.2.2 uint8_t* pack_sms_SetSMSCAddress_t::pSMSCType

8.308 pack_sms_SLQSDeleteSMS_t Struct Reference

Data Fields

- uint32_t storageType
- uint32_t * pMessageIndex
- uint32_t * pMessageTag
- uint8_t * pMessageMode

8.308.1 Detailed Description

This structure contains pack delete SMS parameters.

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
pMessageIndex	• (Optional) message index
pMessageTag	• (Optional) message tag – 0 - Read – 1 - Not read – 2 - Mobile originated and sent – 3 - Mobile originated but not yet sent
pMessageMode	• (Optional) message mode • this must be included if the device is capable of supporting more than one protocol • e.g. CDMA and GW – 0x00 - CDMA, LTE (if network type is CDMA) – 0x01 - GW, LTE (if network type is UMTS)

8.308.2 Field Documentation

8.308.2.1 uint32_t* pack_sms_SLQSDeleteSMS_t::pMessageIndex

8.308.2.2 uint8_t* pack_sms_SLQSDeleteSMS_t::pMessageMode

8.308.2.3 uint32_t* pack_sms_SLQSDeleteSMS_t::pMessageTag

8.308.2.4 uint32_t pack_sms_SLQSDeleteSMS_t::storageType

8.309 pack_sms_SLQSGetSMS_t Struct Reference

Data Fields

- uint32_t storageType
- uint32_t messageIndex
- uint8_t * pMessageMode

8.309.1 Detailed Description

This sturcture contains pack get SMS parameters.

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
messageIndex	• Message index
pMessageMode	• 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS)

8.309.2 Field Documentation

8.309.2.1 uint32_t pack_sms_SLQSGetSMS_t::messageIndex

8.309.2.2 uint8_t* pack_sms_SLQSGetSMS_t::pMessageMode

8.309.2.3 uint32_t pack_sms_SLQSGetSMS_t::storageType

8.310 pack_sms_SLQSGetSmsBroadcastConfig_t Struct Reference

Data Fields

- uint8_t mode

8.310.1 Detailed Description

This structure contains get SMS boardcast configure parameter.

Parameters

mode	• Mode – 0x00 - CDMA, LTE (if network type is CDMA) – 0x01 - GW, LTE (if network type is UMTS)

8.310.2 Field Documentation

8.310.2.1 uint8_t pack_sms_SLQSGetSmsBroadcastConfig_t::mode

8.311 pack_sms_SLQSGetSMSList_t Struct Reference

Data Fields

- uint32_t storageType
- uint32_t * pRequestedTag
- uint8_t * pMessageMode

8.311.1 Detailed Description

This structure contains pack get SMS list parameters.

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
requestedTag	• (Optional) Message tag – 0 - Read – 1 - Not read – 2 - Mobile originated and sent – 3 - Mobile originated but not yet sent
messageMode	• 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS)

8.311.2 Field Documentation

8.311.2.1 uint8_t* pack_sms_SLQSGetSMSList_t::pMessageMode

8.311.2.2 uint32_t* pack_sms_SLQSGetSMSList_t::pRequestedTag

8.311.2.3 uint32_t pack_sms_SLQSGetSMSList_t::storageType

8.312 pack_sms_SLQSModifySMSStatus_t Struct Reference

Data Fields

- uint32_t storageType
- uint32_t messageIndex
- uint32_t messageTag
- uint8_t * pMessageMode

8.312.1 Detailed Description

This structure contains pack modify SMS status parameters.

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
messageIndex	• Message index

messageTag	• Message tag – 0 - Read – 1 - Not read
pMessageMode	• 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS)

8.312.2 Field Documentation

8.312.2.1 uint32_t pack_sms_SLQSModifySMSStatus_t::messageIndex

8.312.2.2 uint32_t pack_sms_SLQSModifySMSStatus_t::messageTag

8.312.2.3 uint8_t* pack_sms_SLQSModifySMSStatus_t::pMessageMode

8.312.2.4 uint32_t pack_sms_SLQSModifySMSStatus_t::storageType

8.313 pack_sms_SLQSSendAsyncSMS_t Struct Reference

Data Fields

- sms_sendAsyncsmsParams * pSendSmsParams

8.313.1 Detailed Description

Structure contain Parameter to Send an SMS message for immediate over-the-air transmission

Parameters

pSendSms-Params	• structure containing the SMS parameters. Refer sms_sendasyncsmsparams

8.313.2 Field Documentation

8.313.2.1 sms_sendAsyncsmsParams* pack_sms_SLQSSendAsyncSMS_t::pSendSmsParams

8.314 pack_sms_SLQSSetIndicationRegister_t Struct Reference

Data Fields

- sms_setIndicationReg * pSetIndicationRegReq

8.314.1 Detailed Description

Structure contain Parameter that sets the registration state of different WMS indications.

Parameters

pSetIndication-Reg	• Pointer to structure of indicationRegReqParams – See sms_setIndicationReg for more information

8.314.2 Field Documentation

8.314.2.1 sms_setIndicationReg* pack_sms_SLQSSetIndicationRegister_t::pSetIndicationRegReq

8.315 pack_sms_SLQSSetSmsBroadcastActivation_t Struct Reference

Data Fields

- uint8_t mode
- uint8_t broadcastActivate

8.315.1 Detailed Description

Structure contain parameters that Enables or disables the reception of broadcast SMS messages.

Parameters

Mode	• Mode • 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS)
broadcast-Activate	• 0x00 - Disable broadcast • 0x01 - Activate broadcast

8.315.2 Field Documentation

8.315.2.1 uint8_t pack_sms_SLQSSetSmsBroadcastActivation_t::broadcastActivate

8.315.2.2 uint8_t pack_sms_SLQSSetSmsBroadcastActivation_t::mode

8.316 pack_sms_SLQSSetSmsBroadcastConfig_t Struct Reference

Data Fields

- uint8_t mode
- sms_qaQmi3GPPBroadcastCfgInfo * pBroadcastConfig
- sms_qaQmi3GPP2BroadcastCfgInfo * pCDMABroadcastConfig

8.316.1 Detailed Description

Structure containing parameters that provides the information about the SMS BroadcastConfiguration

Parameters

mode	• Mode – 0x00 - CDMA, LTE (if network type is CDMA) – 0x01 - GW, LTE (if network type is UMTS)
pBroadcast-Config	• The data for 3GPP Broadcast Information(Optional).
pCDMA-BroadcastConfig	• The data for 3GPP2 Broadcast Information(Optional).

8.316.2 Field Documentation

8.316.2.1 uint8_t pack_sms_SLQSSetSmsBroadcastConfig_t::mode

8.316.2.2 sms_qaQmi3GPPBroadcastCfgInfo* pack_sms_SLQSSetSmsBroadcastConfig_t::pBroadcastConfig

8.316.2.3 sms_qaQmi3GPP2BroadcastCfgInfo* pack_sms_SLQSSetSmsBroadcastConfig_t::pCDMABroadcastConfig

8.317 pack_sms_SLQSSetSmsStorage_t Struct Reference

Data Fields

- uint8_t smsStorage

8.317.1 Detailed Description

Structure contain Parameter to set the SMS Storage on the device

Parameters

smsStorage	• SMS Storage – 0x01 - device's permanent memory – 0x02 - UICC

8.317.2 Field Documentation

8.317.2.1 uint8_t pack_sms_SLQSSetSmsStorage_t::smsStorage

8.318 pack_sms_SLQSSmsGetMaxStorageSize_t Struct Reference

Data Fields

- sms_maxStorageSizeReq * pMaxStorageSizeReq

8.318.1 Detailed Description

This structure contains get maximum storage size.

Parameters

pMaxStorage-SizeReq	• Request parameters for SmsSLQSGetMaxStorageSize – See sms_maxStorageSizeReq for more information

8.318.2 Field Documentation

8.318.2.1 sms_maxStorageSizeReq∗ pack_sms_SLQSSmsGetMaxStorageSize_t::pMaxStorageSizeReq

8.319 pack_sms_SLQSSmsSetRoutes_t Struct Reference

Data Fields

- sms_setRoutesReq ∗ pSetRoutesReq

8.319.1 Detailed Description

Structure contain parameter that Sets the action performed on SMS message receipt for specified message routes. It also specifies the action performed on SMS receipt of status reports.

Parameters

pSetRoutesReq	• Pointer to structure of smsSetRoutesReq – See sms_setRoutesReq for more information

8.319.2 Field Documentation

8.319.2.1 sms_setRoutesReq∗ pack_sms_SLQSSmsSetRoutes_t::pSetRoutesReq

8.320 pack_swiaudio_SLQSGetM2MAudioProfile_t Struct Reference

Data Fields

- uint8_t ∗ pGenerator

8.320.1 Detailed Description

This structure contains the SLQSGetM2MAudioProfile pack parameters.

Parameters

p-Generator[optional]	• Generator – 0 - Voice

8.320.2 Field Documentation

8.320.2.1 uint8_t* pack_swiaudio_SLQSGetM2MAudioProfile_t::pGenerator

8.321 pack_swiaudio_SLQSGetM2MAudioVolume_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Generator

8.321.1 Detailed Description

This structure contains the SLQSGetM2MAudioVolume pack parameters.

Parameters

Profile	• Audio Profile – 0-5
Generator	• Generator – 0 - Voice

8.321.2 Field Documentation

8.321.2.1 uint8_t pack_swiaudio_SLQSGetM2MAudioVolume_t::Generator

8.321.2.2 uint8_t pack_swiaudio_SLQSGetM2MAudioVolume_t::Profile

8.322 pack_swiaudio_SLQSGetM2MAVMute_t Struct Reference

Data Fields

- uint8_t Profile

8.322.1 Detailed Description

This structure contains the SLQSGetM2MAVMute pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5

8.322.2 Field Documentation

8.322.2.1 uint8_t pack_swiaudio_SLQSGetM2MAVMute_t::Profile

8.323 pack_swiaudio_SLQSGetM2MSpkrGain_t Struct Reference

Data Fields

- uint8_t Profile

8.323.1 Detailed Description

This structure contains the SLQSGetM2MSpkrGain pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5

8.323.2 Field Documentation

8.323.2.1 uint8_t pack_swiaudio_SLQSGetM2MSpkrGain_t::Profile

8.324 pack_swiaudio_SLQSSetM2MAudioAVCFG_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Device
- uint8_t PIFACEId
- swiaudio_PCMparams * pPCMParams

8.324.1 Detailed Description

This structure contains the SLQSSetM2MAudioAVCFG pack parameters.

Parameters

Profile	• Audio Profile – 0-5
Device	• ACDB Device • See qaGobiApiTableSwiAudio.h for more information on ACDB Device
PIFACEId	• Physical Interface • See qaGobiApiTableSwiAudio.h for more information on physical interface

pPCMParams	• PCM parameters • See swiaudio_PCMparams for more information

8.324.2 Field Documentation

8.324.2.1 uint8_t pack_swiaudio_SLQSSetM2MAudioAVCFG_t::Device

8.324.2.2 uint8_t pack_swiaudio_SLQSSetM2MAudioAVCFG_t::PIFACEId

8.324.2.3 swiaudio_PCMparams* pack_swiaudio_SLQSSetM2MAudioAVCFG_t::pPCMParams

8.324.2.4 uint8_t pack_swiaudio_SLQSSetM2MAudioAVCFG_t::Profile

8.325 pack_swiaudio_SLQSSetM2MAudioLPBK_t Struct Reference

Data Fields

- uint8_t Enable

8.325.1 Detailed Description

This structure contains the SLQSSetM2MAudioLPBK pack parameters.

Parameters

Enable	• Operation to be performed – 0 - stop – 1 - VOCODER loop – 2 - internal codec loop

8.325.2 Field Documentation

8.325.2.1 uint8_t pack_swiaudio_SLQSSetM2MAudioLPBK_t::Enable

8.326 pack_swiaudio_SLQSSetM2MAudioProfile_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t * pEarMute
- uint8_t * pMicMute
- uint8_t * pGenerator
- uint8_t * pVolume
- uint8_t * pCwtMute

8.326.1 Detailed Description

This structure contains the SLQSSetM2MAudioProfile pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5
pEarMute	• Ear Mute – 0 - mute – 1 - unmute
pMicMute	• Mic Mute – 0 - mute – 1 - unmute
pGenerator	• Generator – 0 - voice
pVolume	• Set RX Volume level – 0-5
pCwtMute	• Call Waiting Tone Mute – 0 - Mute – 1 - UnMute

8.326.2 Field Documentation

8.326.2.1 uint8_t* pack_swiaudio_SLQSSetM2MAudioProfile_t::pCwtMute

8.326.2.2 uint8_t* pack_swiaudio_SLQSSetM2MAudioProfile_t::pEarMute

8.326.2.3 uint8_t* pack_swiaudio_SLQSSetM2MAudioProfile_t::pGenerator

8.326.2.4 uint8_t* pack_swiaudio_SLQSSetM2MAudioProfile_t::pMicMute

8.326.2.5 uint8_t pack_swiaudio_SLQSSetM2MAudioProfile_t::Profile

8.326.2.6 uint8_t* pack_swiaudio_SLQSSetM2MAudioProfile_t::pVolume

8.327 pack_swiaudio_SLQSSetM2MAudioVolume_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Generator

- uint8_t Level

8.327.1 Detailed Description

This structure contains the SLQSSetM2MAudioProfile pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5
Generator	• Generator – 0 - voice
Level	• Audio volume level – 0-5

8.327.2 Field Documentation

8.327.2.1 uint8_t pack_swiaudio_SLQSSetM2MAudioVolume_t::Generator

8.327.2.2 uint8_t pack_swiaudio_SLQSSetM2MAudioVolume_t::Level

8.327.2.3 uint8_t pack_swiaudio_SLQSSetM2MAudioVolume_t::Profile

8.328 pack_swiaudio_SLQSSetM2MAVMute_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t EarMute
- uint8_t MicMute
- uint8_t * pCwtMute

8.328.1 Detailed Description

This structure contains the SLQSSetM2MAVMute pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5
EarMute	• Ear Mute – 0-1

MicMute	• Mic Mute – 0-1
pCwtMute	[Optional] • Call Waiting Tone Mute – 0-1

8.328.2 Field Documentation

8.328.2.1 uint8_t pack_swiaudio_SLQSSetM2MAVMute_t::EarMute

8.328.2.2 uint8_t pack_swiaudio_SLQSSetM2MAVMute_t::MicMute

8.328.2.3 uint8_t* pack_swiaudio_SLQSSetM2MAVMute_t::pCwtMute

8.328.2.4 uint8_t pack_swiaudio_SLQSSetM2MAVMute_t::Profile

8.329 pack_swiaudio_SLQSSetM2MSpkrGain_t Struct Reference

Data Fields

- uint8_t Profile
- uint16_t Value

8.329.1 Detailed Description

This structure contains the SLQSSetM2MSpkrGain pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5
Value	• RX speakerphone gain – 0x0 - 0x7fff

8.329.2 Field Documentation

8.329.2.1 uint8_t pack_swiaudio_SLQSSetM2MSpkrGain_t::Profile

8.329.2.2 uint16_t pack_swiaudio_SLQSSetM2MSpkrGain_t::Value

8.330 pack_swiavms_SLQSAVMSSendSelection_t Struct Reference

Data Fields

- uint8_t selection
- uint32_t * pDeferTime
- uint8_t * pClientPerformOperationFlag
- uint8_t * pPackageID
- uint16_t * pRejectReason

8.330.1 Detailed Description

Structure containing the AVMS selection

Parameters

selection[IN]	• User Selection – 0x01 - Accept – 0x02 - Reject – 0x03 - Defer
pDeferTime[IN/-OPTIONAL]	• Defer time in minutes. A value of 0 will cause the prompt to be resent immediately.
pClientPerform-OperationFlag[I-N/OPTIONAL]	• Client operation flag after accept. – 0: if modem performs the operation (download or update) – 1: if client performs the operation (download or update)
pPackageID[IN/-OPTIONAL]	• Package ID.
pRejectReason[-IN/OPTIONAL]	• Reject Reason.

8.330.2 Field Documentation

8.330.2.1 uint8_t* pack_swiavms_SLQSAVMSSendSelection_t::pClientPerformOperationFlag

8.330.2.2 uint32_t* pack_swiavms_SLQSAVMSSendSelection_t::pDeferTime

8.330.2.3 uint8_t* pack_swiavms_SLQSAVMSSendSelection_t::pPackageID

8.330.2.4 uint16_t* pack_swiavms_SLQSAVMSSendSelection_t::pRejectReason

8.330.2.5 uint8_t pack_swiavms_SLQSAVMSSendSelection_t::selection

8.331 pack_swiavms_SLQSAVMSSetSettings_t Struct Reference

Data Fields

- uint8_t AutoConnect
- uint8_t AutoReboot

- uint8_t PromptFwDownload
- uint8_t PromptFwUpdate
- uint8_t * pFwAutoSDM
- uint32_t * pPollingTimer
- PackSwiAvmsSetSettingsConnectionRetryTimers * pConnectionRetryTimers
- PackSwiAvmsSetSettingsAPNInfo * pAPNInfo
- uint8_t * pNotifStore
- PackSwiAvmsSetSettingsPeriodInfo * pPeriodInfo

8.331.1 Detailed Description

Structure containing the AVMS settings to be set on the device This maps to structure SLQSAVMSSetSettings

Parameters

AutoConnect[IN]	• Auto Connect to AirVantage server – 0x00 - FALSE – 0x01 - TRUE
AutoReboot[IN]	• Automatic device reboot when the request is received from AirVantage server – 0x00 - FALSE – 0x01 - TRUE
PromptFwDownload[IN]	• Firmware Auto Download – 0x00 - FALSE – 0x01 - TRUE
PromptFwUpdate[IN]	• 1 byte parameter indicating FOTA Automatic update – 0x00 - Firmware autoupdate FALSE – 0x01 - Firmware autoupdate TRUE
pFwAutoSDM[IN/OPTIONAL]	• OMA Automatic UI Alert Response – 0x00 - DISABLED – 0x01 - ENABLED ACCEPT – 0x02 - ENABLED REJECT
pPollingTimer[IN/OPTIONAL]	• Polling timer to connect to AVMS server – 0-525600 (min) – 0:disabled
pConnectionRetryTimers[IN/OPTIONAL]	• See PackSwiAvmsSetSettingsConnectionRetryTimers for more information
pAPNInfo[IN/OPTIONAL]	• See PackSwiAvmsSetSettingsAPNInfo for more information

pNotifStore[IN/-OPTIONAL]	• See PackSwiAvmsSetSettingsAPNInfo for more information
pPeriodInfo[IN/-OPTIONAL]	• See PackSwiAvmsSetSettingsAPNInfo for more information

8.331.2 Field Documentation

8.331.2.1 uint8_t pack_swiavms_SLQSAVMSSetSettings_t::AutoConnect

8.331.2.2 uint8_t pack_swiavms_SLQSAVMSSetSettings_t::AutoReboot

8.331.2.3 PackSwiAvmsSetSettingsAPNInfo* pack_swiavms_SLQSAVMSSetSettings_t::pAPNInfo

8.331.2.4 PackSwiAvmsSetSettingsConnectionRetryTimers* pack_swiavms_SLQSAVMSSetSettings_t::pConnectionRetryTimers

8.331.2.5 uint8_t* pack_swiavms_SLQSAVMSSetSettings_t::pFwAutoSDM

8.331.2.6 uint8_t* pack_swiavms_SLQSAVMSSetSettings_t::pNotifStore

8.331.2.7 PackSwiAvmsSetSettingsPeriodInfo* pack_swiavms_SLQSAVMSSetSettings_t::pPeriodInfo

8.331.2.8 uint32_t* pack_swiavms_SLQSAVMSSetSettings_t::pPollingTimer

8.331.2.9 uint8_t pack_swiavms_SLQSAVMSSetSettings_t::PromptFwDownload

8.331.2.10 uint8_t pack_swiavms_SLQSAVMSSetSettings_t::PromptFwUpdate

8.332 pack_swiavms_SLQSAVMSStartSession_t Struct Reference

Data Fields

- uint8_t sessionType

8.332.1 Detailed Description

Structure that contains the session type request for AVMS start session command

Parameters

sessionType[IN]	• Session type – 0x01 - FOTA, to check availability of FW Update. This field is mandatory in OMA-DM case but not necessary in LWM2M one. To keep compatibility, this shall be used in LWM2M without any specific treatment.

8.332.2 Field Documentation

8.332.2.1 uint8_t pack_swiavms_SLQSAVMSStartSession_t::sessionType

8.333 pack_swiavms_SLQSAVMSStopSession_t Struct Reference

Data Fields

- uint8_t sessionType

8.333.1 Detailed Description

Structure that contains the session type for AVMS Stop session command

Parameters

sessionType	• Session type – 0x01 - FOTA, to suspend FOTA session. – 0xFF - Suspend ongoing FOTA session or stop any other active AVMS session.
resultcode	• Tlv Result Code

8.333.2 Field Documentation

8.333.2.1 uint8_t pack_swiavms_SLQSAVMSStopSession_t::sessionType

8.334 pack_swiloc_SwiLocSetAutoStart_t Struct Reference

Data Fields

- uint8_t function
- int set_function
- uint8_t fix_type
- int set_fix_type
- uint8_t max_time
- int set_max_time
- uint32_t max_dist
- int set_max_dist
- uint32_t fix_rate
- int set_fix_rate

8.334.1 Detailed Description

This structure contains SWI LOC Get Auto Start setting

Parameters

function	• Setting to indicate when modem should start an automatic GNSS fix – 0 - disabled – 1 - At bootup – 2 - When NMEA port is opened

set_function	• 0 - do not set to modem • l - set to modem
fix_type	• Type of GNSS fix: – 1 - Default Engine mode – 2 - MS-Based – 3 - MS-Assisted – 4 - Standalone
set_fix_type	• 0 - do not set to modem • l - set to modem
max_time	• Maximum time allowed for the receiver to get a fix in seconds • Valid range: 1-255
set_max_time	• 0 - do not set to modem • l - set to modem
max_dist	• Maximum uncertainty of a fix measured by distance in meters • Valid range: 1 - 4294967280
set_max_dist	• 0 - do not set to modem • l - set to modem
fix_rate	• Time between fixes in seconds • Valid range: 1–65535
set_fix_rate	• 0 - do not set to modem • l - set to modem

8.334.2 Field Documentation

8.334.2.1 uint32_t pack_swiloc_SwiLocSetAutoStart_t::fix_rate

8.334.2.2 uint8_t pack_swiloc_SwiLocSetAutoStart_t::fix_type

8.334.2.3 uint8_t pack_swiloc_SwiLocSetAutoStart_t::function

8.334.2.4 uint32_t pack_swiloc_SwiLocSetAutoStart_t::max_dist

8.334.2.5 uint8_t pack_swiloc_SwiLocSetAutoStart_t::max_time

8.334.2.6 int pack_swiloc_SwiLocSetAutoStart_t::set_fix_rate

8.334.2.7 int pack_swiloc_SwiLocSetAutoStart_t::set_fix_type

8.334.2.8 int pack_swiloc_SwiLocSetAutoStart_t::set_function

8.334.2.9 int pack_swiloc_SwiLocSetAutoStart_t::set_max_dist

8.334.2.10 int pack_swiloc_SwiLocSetAutoStart_t::set_max_time

8.335 pack_swioma_SLQSOMADMCancelSession_t Struct Reference

Data Fields

- uint32_t sessionType

8.335.1 Detailed Description

Structure that contains the session type for OMA cancel session command

Parameters

sessionType	[in] • Session type – 0x01 - FOTA, to check availability of FW Update – 0xFF - Cancel any active OMADM session

8.335.2 Field Documentation

8.335.2.1 uint32_t pack_swioma_SLQSOMADMCancelSession_t::sessionType

8.336 pack_swioma_SLQSOMADMCancelSessionExt_t Struct Reference

Data Fields

- uint32_t sessionType

8.336.1 Detailed Description

Structure that contains the session type for OMA cancel session command

Parameters

sessionType	[IN] • Session type – 0x01 - FOTA, to check availability of FW Update – 0xFF - Cancel any active OMADM session

8.336.2 Field Documentation

8.336.2.1 uint32_t pack_swioma_SLQSOMADMCancelSessionExt_t::sessionType

8.337 pack_swioma_SLQSOMADMGetSessionInfo_t Struct Reference

Data Fields

- uint32_t SessionType

8.337.1 Detailed Description

Structure that contains the session type for OMA get session info command

Parameters

SessionType	[in] • Session type – 0x01 - FOTA – 0xFF - Any active OMADM session. If no active sessions are available, then previous OMADM session info is returned

8.337.2 Field Documentation

8.337.2.1 uint32_t pack_swioma_SLQSOMADMGetSessionInfo_t::SessionType

8.338 pack_swioma_SLQSOMADMSendSelection_t Struct Reference

Data Fields

- uint32_t selection
- uint32_t * pDeferTime
- uint32_t * pRejectReason

8.338.1 Detailed Description

Structure containing the OMA DM selection

Parameters

selection	[in] • OMA-DM NIA Selection – 0x01 - Accept – 0x02 - Reject – 0x03 - Defer
pDeferTime	[in] • Defer time in minutes. A value of 0 will cause the prompt to be resent immediately. • This TLV is mandatory if selection is set to 0x03.

pRejectReason	[in] • Reject Reason • This TLV is processed if selection is set to 0x02. If it is not present, the reject reason 0 is used as default.

8.338.2 Field Documentation

8.338.2.1 uint32_t* pack_swioma_SLQSOMADMSendSelection_t::pDeferTime

8.338.2.2 uint32_t* pack_swioma_SLQSOMADMSendSelection_t::pRejectReason

8.338.2.3 uint32_t pack_swioma_SLQSOMADMSendSelection_t::selection

8.339 pack_swioma_SLQSOMADMSendSelectionExt_t Struct Reference

Data Fields

- uint32_t selection

8.339.1 Detailed Description

Structure containing the OMA DM selection

Parameters

selection	[IN] • OMA-DM NIA Selection – 0x01 - Accept – 0x02 - Reject – 0x03 - Defer

8.339.2 Field Documentation

8.339.2.1 uint32_t pack_swioma_SLQSOMADMSendSelectionExt_t::selection

8.340 pack_swioma_SLQSOMADMSetSettings_t Struct Reference

Data Fields

- uint8_t FOTAdownload
- uint8_t FOTAUpdate
- uint8_t * pAutosdm
- uint8_t * pFwAutoCheck

8.340.1 Detailed Description

Structure containing the OMA DM settings to be set on the device This maps to structure SLQSOMADMSettings-ReqParams3

Parameters

FOTAdownload	• 1 Byte parameter indicating support for FOTA Automatic download – 0x00 - Firmware autodownload FALSE – 0x01 - Firmware autodownload TRUE
FOTAUpdate	• 1 byte parameter indicating FOTA Automatic update – 0x00 - Firmware autoupdate FALSE – 0x01 - Firmware autoupdate TRUE
pAutosdm	• Optional 1 byte parameter indicating OMA Automatic UI Alert Response – 0x00 - Disabled – 0x01 - Enabled Accept – 0x02 - Enabled Reject
pFwAutoCheck	• Optional 1 byte parameter indicating OMA Automatic Check for Firmware Update on Power-Up Response – 0x00 - Disabled – 0x01 - Enabled

8.340.2 Field Documentation

8.340.2.1 uint8_t pack_swioma_SLQSOMADMSetSettings_t::FOTAdownload

8.340.2.2 uint8_t pack_swioma_SLQSOMADMSetSettings_t::FOTAUpdate

8.340.2.3 uint8_t* pack_swioma_SLQSOMADMSetSettings_t::pAutosdm

8.340.2.4 uint8_t* pack_swioma_SLQSOMADMSetSettings_t::pFwAutoCheck

8.341 pack_swioma_SLQSOMADMSetSettingsExt_t Struct Reference

Data Fields

- uint8_t FOTAdownload
- uint8_t FOTAUpdate
- uint8_t OMADMEnable
- uint8_t OMADMLogEnable
- uint8_t FUMOEnable
- uint8_t PRLEnable

8.341.1 Detailed Description

Structure containing the OMA DM settings to be set on the device This maps to structure SLQSOMADMSetSettings-Ext

Parameters

FOTAdownload	• 1 Byte parameter indicating support for FOTA Automatic download – 0x00 - Firmware autodownload FALSE – 0x01 - Firmware autodownload TRUE
FOTAUpdate	• 1 byte parameter indicating FOTA Automatic update – 0x00 - Firmware autoupdate FALSE – 0x01 - Firmware autoupdate TRUE
OMADMEnable	[IN] • 1 byte parameter indicating OMA DM – 0x00 - OMA DM Disabled – 0x01 - OMA DM Enabled
OMADMLog-Enable	[IN] • 1 byte parameter indicating OMA DM Logs – 0x00 - OMA DM Logs Disabled – 0x01 - OMA DM Logs Enabled
FUMOEnable	[IN] • 1 byte parameter indicating FUMO enabled – 0x00 - FUMO Disabled – 0x01 - FUMO enabled
PRLEnable	[IN] • 1 byte parameter indicating PRL Enabled – 0x00 - PRL Disabled – 0x01 - PRL Enabled – 0x02 - Launch a CI PRL – 0x03 - PRL Enabled and PRL automatic update every 45 days – 0x04 - PRL Enabled and PRL update ever 90 days

8.341.2 Field Documentation

8.341.2.1 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::FOTAdownload

8.341.2.2 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::FOTAUpdate

8.341.2.3 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::FUMOEnable

8.341.2.4 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::OMADMEnable

8.341.2.5 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::OMADMLogEnable

8.341.2.6 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::PRLEnable

8.342 pack_swioma_SLQSOMADMStartSession_t Struct Reference

Data Fields

- uint32_t sessionType

8.342.1 Detailed Description

Structure that contains the session type for OMA start session command

Parameters

sessionType[IN]	• Session type – 0x01 - FOTA, to check availability of FW Update – 0x02 - DM, to check availability of DM Update – 0x03 - PRL, to check availability of PRL Update

8.342.2 Field Documentation

8.342.2.1 uint32_t pack_swioma_SLQSOMADMStartSession_t::sessionType

8.343 pack_swioma_SLQSOMADMStartSessionExt_t Struct Reference

Data Fields

- uint32_t sessionType

8.343.1 Detailed Description

Structure that contains the session type for OMA start session command

Parameters

sessionType	[IN] • Session type – 0x01 - FOTA, to check availability of FW Update – 0x02 - DM, to check availability of DM Update – 0x03 - PRL, to check availability of PRL Update

8.343.2 Field Documentation

8.343.2.1 uint32_t pack_swioma_SLQSOMADMStartSessionExt_t::sessionType

8.344 pack_tmd_SLQSTmdDeRegNotMitigationLvl_t Struct Reference

Data Fields

- uint8_t mitigationDevIDLen
- char mitigationDevID [255]

8.344.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

mitigationDevID-Len	• Number of sets of the following elements – mitigation_dev_id
mitigationDevID	• Mitigation device ID

8.344.2 Field Documentation

8.344.2.1 char pack_tmd_SLQSTmdDeRegNotMitigationLvl_t::mitigationDevID[255]

8.344.2.2 uint8_t pack_tmd_SLQSTmdDeRegNotMitigationLvl_t::mitigationDevIDLen

8.345 pack_tmd_SLQSTmdGetMitigationLvl_t Struct Reference

Data Fields

- uint8_t mitigationDevIDLen
- char mitigationDevID [255]

8.345.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

mitigationDevID-Len	• Number of sets of the following elements – mitigation_dev_id
mitigationDevID	• Mitigation device ID

8.345.2 Field Documentation

8.345.2.1 char pack_tmd_SLQSTmdGetMitigationLvl_t::mitigationDevID[255]

8.345.2.2 uint8_t pack_tmd_SLQSTmdGetMitigationLvl_t::mitigationDevIDLen

8.346 pack_tmd_SLQSTmdRegNotMitigationLvl_t Struct Reference

Data Fields

- uint8_t mitigationDevIDLen
- char mitigationDevID [255]

8.346.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

mitigationDevID-Len	• Number of sets of the following elements – mitigation_dev_id
mitigationDevID	• Mitigation device ID

8.346.2 Field Documentation

8.346.2.1 char pack_tmd_SLQSTmdRegNotMitigationLvl_t::mitigationDevID[255]

8.346.2.2 uint8_t pack_tmd_SLQSTmdRegNotMitigationLvl_t::mitigationDevIDLen

8.347 pack_uim_ChangePin_t Struct Reference

Data Fields

- uim_encryptedPIN1 EncryptedPIN1
- uint32_t * pIndicationToken
- uint8_t * pKeyReferenceID
- uim_sessionInformation sessionInfo
- uim_changeUIMPIN changePIN
- uint16_t Tlvresult

8.347.1 Detailed Description

This structure contains information of the request parameters associated with a Change PIN API.

Parameters

sessionInfo	• See uim_sessionInformation for more information.
changePIN	• See uim_changeUIMPIN for more information.
pKeyReferenceI-D(optional)	• Indicates the PIN key reference ID. • Indicates the PIN key reference ID. Valid values are from 1 to 8, respectively, for application 1 to application 8. • This TLV is used only for PIN1 and PIN2 and is ignored in all other cases.

pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Valid Values – 0 - Result of operation in response. Indication will not be generated by the modem – Any other positive number - Result of operation in indication. Indication will have same token value set by this function

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.347.2 Field Documentation

8.347.2.1 uim_changeUIMPIN pack_uim_ChangePin_t::changePIN

8.347.2.2 uim_encryptedPIN1 pack_uim_ChangePin_t::EncryptedPIN1

8.347.2.3 uint32_t* pack_uim_ChangePin_t::pIndicationToken

8.347.2.4 uint8_t* pack_uim_ChangePin_t::pKeyReferenceID

8.347.2.5 uim_sessionInformation pack_uim_ChangePin_t::sessionInfo

8.347.2.6 uint16_t pack_uim_ChangePin_t::TlvResult

8.348 pack_uim_ReadTransparent_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo
- uim_fileInfo fileIndex
- uim_readTransparentInfo readTransparent
- uint32_t * pIndicationToken
- uint8_t * pEncryptData
- uint16_t TlvResult

8.348.1 Detailed Description

This structure contains information of the request parameters associated with a Read Transparent API.

Parameters

sessionInfo	• See uim_sessionInformation for more information.
fileIndex	• See uim_fileInfo for more information.
readTransparent	• See uim_readTransparentInfo for more information.

pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Valid Values – 0 - Result of operation in response. Indication will not be generated by the modem – Any other positive number - Result of operation in indication. Indication will have same token value set by this function
pEncrypt-Data(optional)	• Encrypt Data. • Indicates whether the data read from the card is to be encrypted.

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.348.2 Field Documentation

8.348.2.1 uim_fileInfo pack_uim_ReadTransparent_t::fileIndex

8.348.2.2 uint8_t* pack_uim_ReadTransparent_t::pEncryptData

8.348.2.3 uint32_t* pack_uim_ReadTransparent_t::pIndicationToken

8.348.2.4 uim_readTransparentInfo pack_uim_ReadTransparent_t::readTransparent

8.348.2.5 uim_sessionInformation pack_uim_ReadTransparent_t::sessionInfo

8.348.2.6 uint16_t pack_uim_ReadTransparent_t::TlvResult

8.349 pack_uim_SetPinProtection_t Struct Reference

Data Fields

- uim_encryptedPIN1 EncryptedPIN1
- uint32_t * pIndicationToken
- uint8_t * pKeyReferenceID
- uim_sessionInformation sessionInfo
- uim_setPINProtection pinProtection
- uint16_t TlvResult

8.349.1 Detailed Description

This structure contains information of the request parameters associated with a set pin protection API.

Parameters

sessionInfo	• See uim_sessionInformation for more information.

pinProtection	• See uim_setPINProtection for more information.
pKeyReferenceI-D(optional)	• Indicates the PIN key reference ID. • Indicates the PIN key reference ID. Valid values are from 1 to 8, respectively, for application 1 to application 8. • This TLV is used only for PIN1 and PIN2 and is ignored in all other cases.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Valid Values – 0 - Result of operation in response. Indication will not be generated by the modem – Any other positive number - Result of operation in indication. Indication will have same token value set by this function

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.349.2 Field Documentation

8.349.2.1 uim_encryptedPIN1 pack_uim_SetPinProtection_t::EncryptedPIN1

8.349.2.2 uint32_t* pack_uim_SetPinProtection_t::pIndicationToken

8.349.2.3 uim_setPINProtection pack_uim_SetPinProtection_t::pinProtection

8.349.2.4 uint8_t* pack_uim_SetPinProtection_t::pKeyReferenceID

8.349.2.5 uim_sessionInformation pack_uim_SetPinProtection_t::sessionInfo

8.349.2.6 uint16_t pack_uim_SetPinProtection_t::Tlvresult

8.350 pack_uim_SLQSUIMAuthenticate_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo
- uim_authenticationData authData
- uint32_t * pIndicationToken

8.350.1 Detailed Description

This structure contains information of the request parameters associated with a SLQSUIMAuthenticate.

Parameters

sessionInfo	• See uim_sessionInformation for more information.

authData	• See uim_authenticationData for more information.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication.

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.350.2 Field Documentation

8.350.2.1 uim_authenticationData pack_uim_SLQSUIMAuthenticate_t::authData

8.350.2.2 uint32_t* pack_uim_SLQSUIMAuthenticate_t::pIndicationToken

8.350.2.3 uim_sessionInformation pack_uim_SLQSUIMAuthenticate_t::sessionInfo

8.351 pack_uim_SLQSUIMDepersonalization_t Struct Reference

Data Fields

- uim_depersonalizationInformation depersonilisationInfo

8.351.1 Detailed Description

This structure contains information of the request parameters associated with a Depersonalization.

Parameters

depersonilisation-Info	• See uim_depersonalizationInformation for more information.

8.351.2 Field Documentation

8.351.2.1 uim_depersonalizationInformation pack_uim_SLQSUIMDepersonalization_t::depersonilisationInfo

8.352 pack_uim_SLQSUIMEventRegister_t Struct Reference

Data Fields

- uint32_t eventMask

8.352.1 Detailed Description

This structure contains pack event register parameter.

Parameters

eventMask	- bit 1 - card status • bit 4 - physical slot status

8.352.2 Field Documentation

8.352.2.1 uint32_t pack_uim_SLQSUIMEventRegister_t::eventMask

8.353 pack_uim_SLQSUIMGetConfiguration_t Struct Reference

Data Fields

- uint32_t * pConfigurationMask

8.353.1 Detailed Description

This structure contains information of the request parameters associated with Get Configuration to get the modem configuration for the UIM module

Parameters

pConfiguration-Mask(optional)	• Requested configurations – Bit 0 - Automatic selection – Bit 1 - Personalization status – Bit 2 - Halt subscription – All other bits are reserved for future use

Note

- if the TLV is missing, the service returns all configuration items in the response.

8.353.2 Field Documentation

8.353.2.1 uint32_t* pack_uim_SLQSUIMGetConfiguration_t::pConfigurationMask

8.354 pack_uim_SLQSUIMGetFileAttributes_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo
- uim_fileInfo fileIndex
- uint32_t * pIndicationToken

8.354.1 Detailed Description

This structure contains information of the request parameters associated with a Get File Attributes

Parameters

sessionInfo	• See uim_sessionInformation for more information.
fileIndex	• See uim_fileInfo for more information.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication.

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.354.2 Field Documentation

8.354.2.1 uim_fileInfo pack_uim_SLQSUIMGetFileAttributes_t::fileIndex

8.354.2.2 uint32_t* pack_uim_SLQSUIMGetFileAttributes_t::pIndicationToken

8.354.2.3 uim_sessionInformation pack_uim_SLQSUIMGetFileAttributes_t::sessionInfo

8.355 pack_uim_SLQSUIMPowerDown_t Struct Reference

Data Fields

- uint8_t slot

8.355.1 Detailed Description

This structure contains information of the request parameters associated with a Power Down.

Parameters

slot	• Indicates the slot to be used. – 1 - Slot 1 – 2 - Slot 2

8.355.2 Field Documentation

8.355.2.1 uint8_t pack_uim_SLQSUIMPowerDown_t::slot

8.356 pack_uim_SLQSUIMPowerUp_t Struct Reference

Data Fields

- uint8_t slot
- uint8_t * pIgnoreHotSwapSwitch

8.356.1 Detailed Description

This structure contains information of the request parameters associated with a Power Down.

Parameters

slot	• Indicates the slot to be used. – 1 - Slot 1 – 2 - Slot 2
pIgnoreHot-Swap-Switch(optional)	• Hot-swap switch status. – 0 - Checks the hot-swap switch status – 1 - Ignores the hot-swap switch status

8.356.2 Field Documentation

8.356.2.1 uint8_t* pack_uim_SLQSUIMPowerUp_t::pIgnoreHotSwapSwitch

8.356.2.2 uint8_t pack_uim_SLQSUIMPowerUp_t::slot

8.357 pack_uim_SLQSUIMRefreshComplete_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo
- uint8_t refreshComplete

8.357.1 Detailed Description

This structure contains information of the request parameters associated with a Refresh Complete event.

Parameters

sessionInfo(-Mandatory)	• See uim_sessionInformation for more information.
refresh-Complete(-Mandatory)	• Indicates whether the refresh was successful. Valid values: – 0 - Refresh was not completed successfully – 1 - Refresh was completed successfully

8.357.2 Field Documentation

8.357.2.1 uint8_t pack_uim_SLQSUIMRefreshComplete_t::refreshComplete

8.357.2.2 uim_sessionInformation pack_uim_SLQSUIMRefreshComplete_t::sessionInfo

8.358 pack_uim_SLQSUIMRefreshGetLastEvent_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo

8.358.1 Detailed Description

This structure contains information of the request parameters associated with a Refresh Get Last Event.

Parameters

sessionInfo(-Mandatory)	• See uim_sessionInformation for more information.

8.358.2 Field Documentation

8.358.2.1 uim_sessionInformation pack_uim_SLQSUIMRefreshGetLastEvent_t::sessionInfo

8.359 pack_uim_SLQSUIMRefreshOK_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo
- uint8_t OKtoRefresh

8.359.1 Detailed Description

This structure contains Parameters of the Session Information

Parameters

sessionInfo	• Session Information • See uim_sessionInformation for more information
OKtoRefresh	• Indicates whether a refresh is OK. Valid values: – 0 - Not OK to refresh – 1 - OK to refresh

8.359.2 Field Documentation

8.359.2.1 uint8_t pack_uim_SLQSUIMRefreshOK_t::OKtoRefresh

8.359.2.2 uim_sessionInformation pack_uim_SLQSUIMRefreshOK_t::sessionInfo

8.360 pack_uim_SLQSUIMRefreshRegister_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo

- uim_registerRefresh regRefresh

8.360.1 Detailed Description

This structure contains information of the request parameters associated with a Refresh Register.

Parameters

sessionInfo	• Session Information params • See uim_sessionInformation for more information
regRefresh	• Register Refresh parameters • See uim_registerRefresh for more information

8.360.2 Field Documentation

8.360.2.1 uim_registerRefresh pack_uim_SLQSUIMRefreshRegister_t::regRefresh

8.360.2.2 uim_sessionInformation pack_uim_SLQSUIMRefreshRegister_t::sessionInfo

8.361 pack_uim_SLQSUIMSwitchSlot_t Struct Reference

Data Fields

- uint8_t bLogicalSlot
- uint32_t ulPhysicalSlot

8.361.1 Detailed Description

This structure contains information of the request parameters associated with a Switch Slot.

Parameters

bLogicalSlot	• Indicates the slot to be used. – 1 - Slot 1 – 2 - Slot 2 – 3 - Slot 3 – 4 - Slot 4 – 5 - Slot 5
ulPhysicalSlot	• 1 - Slot 1 • 2 - Slot 2 • 3 - Slot 3 • 4 - Slot 4 • 5 - Slot 5

8.361.2 Field Documentation

8.361.2.1 uint8_t pack_uim_SLQSUIMSwitchSlot_t::bLogicalSlot

8.361.2.2 uint32_t pack_uim_SLQSUIMSwitchSlot_t::ulPhysicalSlot

8.362 pack_uim_UnblockPin_t Struct Reference

Data Fields

- uim_encryptedPIN1 EncryptedPIN1
- uint32_t * pIndicationToken
- uint8_t * pKeyReferenceID
- uim_sessionInformation sessionInfo
- uim_unblockUIMPIN pinProtection
- uint16_t TlvResult

8.362.1 Detailed Description

This structure contains information of the request parameters associated with a Unblock PIN API.

Parameters

EncryptedPIN1	• See uim_encryptedPIN1 for more information.
sessionInfo	• See uim_sessionInformation for more information.
pinProtection	• See uim_unblockUIMPIN for more information.
pKeyReferenceID(optional)	• Indicates the PIN key reference ID. • Indicates the PIN key reference ID. Valid values are from 1 to 8, respectively, for application 1 to application 8. • This TLV is used only for PIN1 and PIN2 and is ignored in all other cases.
pIndicationToken(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Valid Values – 0 - Result of operation in response. Indication will not be generated by the modem – Any other positive number - Result of operation in indication. Indication will have same token value set by this function

8.362.2 Field Documentation

8.362.2.1 uim_encryptedPIN1 pack_uim_UnblockPin_t::EncryptedPIN1

8.362.2.2 uint32_t* pack_uim_UnblockPin_t::pIndicationToken

8.362.2.3 uim_unblockUIMPIN pack_uim_UnblockPin_t::pinProtection

8.362.2.4 uint8_t* pack_uim_UnblockPin_t::pKeyReferenceID

8.362.2.5 uim_sessionInformation pack_uim_UnblockPin_t::sessionInfo

8.362.2.6 uint16_t pack_uim_UnblockPin_t::Tlvresult

8.363 pack_uim_VerifyPin_t Struct Reference

Data Fields

- uim_encryptedPIN1 * pEncryptedPIN1
- uint32_t * pIndicationToken
- uint8_t * pKeyReferenceID
- uim_sessionInformation sessionInfo
- uim_verifyUIMPIN verifyPIN
- uint16_t Tlvresult

8.363.1 Detailed Description

This structure contains information of the request parameters associated with a verify PIN API.

Parameters

sessionInfo	• See uim_sessionInformation for more information.
verifyPIN	• See uim_verifyUIMPIN for more information.
pEncryptedPIN1(optional)	• See uim_encryptedPIN1 for more information.
pKeyReferenceID(optional)	• Indicates the PIN key reference ID. • Indicates the PIN key reference ID. Valid values are from 1 to 8, respectively, for application 1 to application 8. • This TLV is used only for PIN1 and PIN2 and is ignored in all other cases.
pIndicationToken(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Valid Values – 0 - Result of operation in response. Indication will not be generated by the modem – Any other positive number - Result of operation in indication. Indication will have same token value set by this function

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.363.2 Field Documentation

8.363.2.1 uim_encryptedPIN1* pack_uim_VerifyPin_t::pEncryptedPIN1

8.363.2.2 uint32_t* pack_uim_VerifyPin_t::pIndicationToken

8.363.2.3 uint8_t* pack_uim_VerifyPin_t::pKeyReferenceID

8.363.2.4 uim_sessionInformation pack_uim_VerifyPin_t::sessionInfo

8.363.2.5 uint16_t pack_uim_VerifyPin_t::Tlvresult

8.363.2.6 uim_verifyUIMPIN pack_uim_VerifyPin_t::verifyPIN

8.364 pack_voice_AnswerUSSD_t Struct Reference

Data Fields

- uint8_t * pInfo

8.364.1 Detailed Description

This structure contains pack anser USSD parameter.

Parameters

pInfo	• USS information • See voice_USSInfo for more details

8.364.2 Field Documentation

8.364.2.1 uint8_t* pack_voice_AnswerUSSD_t::pInfo

8.365 pack_voice_OriginateUSSD_t Struct Reference

Data Fields

- uint8_t * pInfo

8.365.1 Detailed Description

This structure contains pack orginate USSD parameter.

Parameters

pInfo	• USS information • See voice_USSInfo for more details

8.365.2 Field Documentation

8.365.2.1 uint8_t* pack_voice_OriginateUSSD_t::pInfo

8.366 pack_voice_SLQSOriginateUSSD_t Struct Reference

Data Fields

- uint8_t ussDCS
- uint8_t ussLen
- uint8_t ussData [182]

8.366.1 Detailed Description

This structure contains USS Information

Parameters

ussDCS	• 1 - ASCII coding scheme • 2 - 8-BIT coding scheme • 3 - UCS2
ussLen	• Range 1 to 182
ussData	• Data encoded as per the DCS

8.366.2 Field Documentation

8.366.2.1 uint8_t pack_voice_SLQSOriginateUSSD_t::ussData[182]

8.366.2.2 uint8_t pack_voice_SLQSOriginateUSSD_t::ussDCS

8.366.2.3 uint8_t pack_voice_SLQSOriginateUSSD_t::ussLen

8.367 pack_voice_SLQSVoiceALSSelectLine_t Struct Reference

Data Fields

- uint8_t lineValue

8.367.1 Detailed Description

This structure contains ALS Select Line Information Parameters.

Parameters

lineValue	• ALS Line Value. – 0x00 - ALS_LINE1 - Line 1 (default) – 0x01 - ALS_LINE2 - Line 2

8.367.2 Field Documentation

8.367.2.1 uint8_t pack_voice_SLQSVoiceALSSelectLine_t::lineValue

8.368 pack_voice_SLQSVoiceALSSetLineSwitching_t Struct Reference

Data Fields

- uint8_t switchOption

8.368.1 Detailed Description

This structure contains ALS Set Line Switching Information Parameters.

Parameters

switchOption	• Switch Option. – 0x00 - VOICE_LINE_SWITCHING_NOT_ALLOWED - Line switching is not allowed – 0x01 - VOICE_LINE_SWITCHING_ALLOWED - Line switching is allowed

8.368.2 Field Documentation

8.368.2.1 uint8_t pack_voice_SLQSVoiceALSSetLineSwitching_t::switchOption

8.369 pack_voice_SLQSVoiceAnswerCall_t Struct Reference

Data Fields

- uint8_t * pCallId

8.369.1 Detailed Description

Contains the parameters passed for pack voice Answer Call.

Parameters

pCallId	• Unique call identifier for the call that must be answered.

8.369.2 Field Documentation

8.369.2.1 uint8_t* pack_voice_SLQSVoiceAnswerCall_t::pCallId

8.370 pack_voice_SLQSVoiceBindSubscription_t Struct Reference

Data Fields

- uint8_t subsType

8.370.1 Detailed Description

This structure contains Bind Subscription Information Parameters.

Parameters

subsType	• Subscription Type. – 0x00 - VOICE_SUBS_TYPE_PRIMARY - Primary – 0x01 - VOICE_SUBS_TYPE_SECONDARY - Secondary

8.370.2 Field Documentation

8.370.2.1 uint8_t pack_voice_SLQSVoiceBindSubscription_t::subsType

8.371 pack_voice_SLQSVoiceBurstDTMF_t Struct Reference

Data Fields

- voice_burstDTMFInfo BurstDTMFInfo
- voice_DTMFLengths * pBurstDTMFLengths

8.371.1 Detailed Description

This structure contains parameters of burst Dual-Tone Multifrequency (DTMF)

Parameters

BurstDTMFInfo	• Burst DTMF Information – See voice_burstDTMFInfo for more information
pBurstDTMF-Lengths	[optional] • DTMF Lengths – See voice_DTMFLengths for more information • NULL pointer - Invalid data.

8.371.2 Field Documentation

8.371.2.1 voice_burstDTMFInfo pack_voice_SLQSVoiceBurstDTMF_t::BurstDTMFInfo

8.371.2.2 voice_DTMFLengths* pack_voice_SLQSVoiceBurstDTMF_t::pBurstDTMFLengths

8.372 pack_voice_SLQSVoiceDialCall_t Struct Reference

Data Fields

- uint8_t callNumber [81]
- uint8_t * pCallType
- uint8_t * pCLIRType
- voice_UUSInfo * pUUSInFo
- voice_CUGInfo * pCUGInfo
- uint8_t * pEmergencyCategory
- voice_calledPartySubAdd * pCallPartySubAdd
- uint8_t * pSvcType

8.372.1 Detailed Description

This structure contains Voice Call Request Parameters

Parameters

callNumber[81]	• Number to be dialed in ASCII string, NULL terminated. • Length Range [1 to 81]
pCall-Type(optional)	• the type of call to be dialed. CALL_TYPE_VOICE is automatically selected if this parameter is not provided. When CALL_TYPE_NON_STD_OTASP is selected, the call is sent as a nonstandard OTASP call regardless of the digit string Call type values are: – 0x00 - CALL_TYPE_VOICE - Voice (automatic selection) – 0x01 - CALL_TYPE_VOICE_FORCED - Avoid modem call classification – 0x08 - CALL_TYPE_NON_STD_OTASP - Nonstandard OTASP* – 0x09 - CALL_TYPE_EMERGENCY - Emergency
pCLIR-Type(optional)	• CLIR type values are: – 0x01 - CLIR_SUPPRESSION - Suppression – 0x02 - CLIR_INVOCATION - Invocation
pUUSIn-Fo(optional)	• Pointer to structure of UUSInfo – See voice_UUSInfo for more information
pCUG-Info(optional)	• Pointer to structure of CUGInfo – See voice_CUGInfo for more information

pEmergency-Category(optional)	• Bit mask of emergency number categories. This is only applicable when the call type is set to Emergency. – Bit 0 - VOICE_EMER_CAT_POLICE_BIT - Police – Bit 1 - VOICE_EMER_CAT_AMBULANCE_BIT - Ambulance – Bit 2 - VOICE_EMER_CAT_FIRE_BRIGADE_BIT- Fire brigade – Bit 3 - VOICE_EMER_CAT_MARINE_GUARD_BIT - Marine guard – Bit 4 - VOICE_EMER_CAT_MOUNTAIN_RESCUE_BIT - Mountain rescue – Bit 5 - VOICE_EMER_CAT_MANUAL_ECALL_BIT - Manual emergency call – Bit 6 - VOICE_EMER_CAT_AUTO_ECALL_BIT - Automatic emergency call – Bit 7 - VOICE_EMER_CAT_SPARE_BIT - Spare bit
pCallPartySub-Add(optional)	• Pointer to structure of calledPartySubAdd – See voice_calledPartySubAdd for more information
pSvc-Type(optional)	• Service Type. – 0x01 - VOICE_DIAL_CALL_SRV_TYPE_AUTOMATIC - Automatic – 0x02 - VOICE_DIAL_CALL_SRV_TYPE_GSM - GSM – 0x03 - VOICE_DIAL_CALL_SRV_TYPE_WCDMA - WCDMA – 0x04 - VOICE_DIAL_CALL_SRV_TYPE_CDMA_AUTOMATIC - CDMA automatic – 0x05 - VOICE_DIAL_CALL_SRV_TYPE_GSM_WCDMA - GSM or WCDMA – 0x06 - VOICE_DIAL_CALL_SRV_TYPE_LTE -LTE

8.372.2 Field Documentation

8.372.2.1 uint8_t pack_voice_SLQSVoiceDialCall_t::callNumber[81]

8.372.2.2 voice_calledPartySubAdd* pack_voice_SLQSVoiceDialCall_t::pCallPartySubAdd

8.372.2.3 uint8_t* pack_voice_SLQSVoiceDialCall_t::pCallType

8.372.2.4 uint8_t* pack_voice_SLQSVoiceDialCall_t::pCLIRType

8.372.2.5 voice_CUGInfo* pack_voice_SLQSVoiceDialCall_t::pCUGInfo

8.372.2.6 uint8_t* pack_voice_SLQSVoiceDialCall_t::pEmergencyCategory

8.372.2.7 uint8_t* pack_voice_SLQSVoiceDialCall_t::pSvcType

8.372.2.8 voice_UUSInfo* pack_voice_SLQSVoiceDialCall_t::pUUSInFo

8.373 pack_voice_SLQSVoiceEndCall_t Struct Reference

Data Fields

- uint8_t * pCallId

8.373.1 Detailed Description

This structure contain pack voice end call parameter.

Parameters

pCallId	• Unique call identifier for the call that must be ended

8.373.2 Field Documentation

8.373.2.1 uint8_t* pack_voice_SLQSVoiceEndCall_t::pCallId

8.374 pack_voice_SLQSVoiceGetCallBarring_t Struct Reference

Data Fields

- uint8_t reason
- uint8_t * pSvcClass

8.374.1 Detailed Description

This structure contains Voice Get Call Barring Pack Parameters

Parameters

reason	• Call Barring Reason • Values: – 0x07 - QMI_VOICE_REASON_BARR_ALLOUTGOING - All outgoing – 0x08 - QMI_VOICE_REASON_BARR_OUTGOINGINT - Outgoing internal – 0x09 - QMI_VOICE_REASON_BARR_OUTGOINGINTEXTOHOME - Outgoing external to home – 0x0A - QMI_VOICE_REASON_BARR_ALLINCOMING - All incoming – 0x0B - QMI_VOICE_REASON_BARR_INCOMINGROAMING - Roaming incoming – 0x0C - QMI_VOICE_REASON_BARR_ALLBARRING - All calls are barred – 0x0D - QMI_VOICE_REASON_BARR_ALLOUTGOINGBARRING - All outgoing calls are barred – 0x0E - QMI_VOICE_REASON_BARR_ALLINCOMINGBARRING - All incoming calls are barred
pSvcClass	• Service class is a combination (sum) of information class constants (optional) • See qaGobiApiTableSupServiceInfoClasses.h for service classes. • Service Class is set to 0 if call waiting is not active for any of the information classes. • 0xFF,if Not Available

8.374.2 Field Documentation

8.374.2.1 uint8_t* pack_voice_SLQSVoiceGetCallBarring_t::pSvcClass

8.374.2.2 uint8_t pack_voice_SLQSVoiceGetCallBarring_t::reason

8.375 pack_voice_SLQSVoiceGetCallForwardingStatus_t Struct Reference

Data Fields

- uint8_t Reason
- uint8_t * pSvcClass

8.375.1 Detailed Description

This structure contains Voice Get Call Forwarding Status Pack Parameters

Parameters

Reason	• Call Forwarding Reason • Values: – 0x01 - QMI_VOICE_REASON_FWDREASON_UNCONDITIONAL - Unconditional call forwarding – 0x02 - QMI_VOICE_REASON_FWDREASON_MOBILEBUSY - Forward when the mobile is busy – 0x03 - QMI_VOICE_REASON_FWDREASON_NOREPLY - Forward when there is no reply – 0x04 - QMI_VOICE_REASON_FWDREASON_UNREACHABLE - Forward when the call is unreachable – 0x05 - QMI_VOICE_REASON_FWDREASON_ALLFORWARDING - All forwarding – 0x06 - QMI_VOICE_REASON_FWDREASON_ALLCONDITIONAL - All conditional forwarding
pSvc-Class(optional)	• Service Class is a combination (sum) of information class constants • See qaGobiApiTableSupServiceInfoClasses.h for service classes.

8.375.2 Field Documentation

8.375.2.1 uint8_t* pack_voice_SLQSVoiceGetCallForwardingStatus_t::pSvcClass

8.375.2.2 uint8_t pack_voice_SLQSVoiceGetCallForwardingStatus_t::Reason

8.376 pack_voice_SLQSVoiceGetCallInfo_t Struct Reference

Data Fields

- uint8_t callID

8.376.1 Detailed Description

This structure contains information of the request parameters associated with a call.

Parameters

callID	• Call identifier for the call queried for information.

8.376.2 Field Documentation

8.376.2.1 uint8_t pack_voice_SLQSVoiceGetCallInfo_t::callID

8.377 pack_voice_SLQSVoiceGetCallWaiting_t Struct Reference

Data Fields

- uint8_t * pSvcClass

8.377.1 Detailed Description

This structure contains Voice Get Call Waiting Response Parameters

Parameters

pSvcClass	• Service class is a combination (sum) of information class constants (optional) • See qaGobiApiTableSupServiceInfoClasses.h for service classes. • Service Class is set to 0 if call waiting is not active for any of the information classes. • 0xFF,if Not Available

8.377.2 Field Documentation

8.377.2.1 uint8_t* pack_voice_SLQSVoiceGetCallWaiting_t::pSvcClass

8.378 pack_voice_SLQSVoiceGetConfig_t Struct Reference

Data Fields

- uint8_t * pAutoAnswer
- uint8_t * pAirTimer
- uint8_t * pRoamTimer
- uint8_t * pTTYMode
- uint8_t * pPrefVoiceSO
- uint8_t * pAMRStatus
- uint8_t * pPrefVoicePrivacy
- uint8_t * pNamID
- uint8_t * pVoiceDomainPref

8.378.1 Detailed Description

This structure contains Voice Get Configuration Request Parameters

Parameters

pAuto-Answer(optional)	• Indicator to retrieve the Auto Answer Information. – 0x01 - Include auto answer information
pAir-Timer(optional)	• Indicator to retrieve the Air Timer Information. – 0x01 - Include air calls timer count information • Currently Not Supported.
pRoam-Timer(optional)	• Indicator to retrieve the Roam Timer Information. – 0x01 - Include roam calls timer information • Currently Not Supported.
pTTY-Mode(optional)	• Indicator to retrieve the TTY Mode Information. – 0x01 - Include TTY configuration status information
pPrefVoiceS-O(optional)	• Indicator to retrieve the Preferred Voice SO Information. – 0x01 - Include preferred voice configuration status information • Currently Not Supported.
pAMR-Status(optional)	• Indicator to retrieve the AMR Status Information. – 0x01 - Include AMR status information
pPrefVoice-Privacy(optional)	• Indicator to retrieve the Preferred Voice Privacy Information. – 0x01 - Include preferred voice privacy status information
pNamI-D(optional)	• Index of the Number Assignment Module Index (CDMA subscription) to be configured • Range: 0 to 3. • Some modems support only 1 or 2 NAMs. • The NAM Index is valid only when the request contains at least one of Air Timer, Roam Timer, and Preferred Voice SO. • If no nam_id value is specified in the request,the default value is 0.
pVoiceDomain-Pref(optional)	• Indicator to retrieve the Preferred Voice Domain Information. – 0x01 - Include voice domain preference information

Note

Using NULL for the pointers would make sure that the parameter is not returned.

8.378.2 Field Documentation

8.378.2.1 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pAirTimer

8.378.2.2 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pAMRStatus

8.378.2.3 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pAutoAnswer

8.378.2.4 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pNamID

8.378.2.5 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pPrefVoicePrivacy

8.378.2.6 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pPrefVoiceSO

8.378.2.7 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pRoamTimer

8.378.2.8 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pTTYMode

8.378.2.9 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pVoiceDomainPref

8.379 pack_voice_SLQSVoiceIndicationRegister_t Struct Reference

Data Fields

- uint8_t * pRegDTMFEvents
- uint8_t * pRegVoicePrivacyEvents
- uint8_t * pSuppsNotifEvents

8.379.1 Detailed Description

This structure contains parameters of Indication Register Information

Parameters

pRegDTMF-Events(optional)	• Registration Indication For DTMF Events. • When this registration is enabled, the device learns of DTMF events via the QMI_VOICE_DTMF_IND indication. – 0x00 - Disable – 0x01 - Enable
pRegVoice-Privacy-Events(optional)	• Registration Indication For Voice Privacy Events. • When this registration is enabled, the device learns of DTMF events via the QMI_VOICE_PRIVACY_IND indication. – 0x00 - Disable – 0x01 - Enable
pSuppsNotif-Events(optional)	• Registration Indication For Supplementary Service Notification Events. • When this registration is enabled, the device learns of DTMF events via the QMI_VOICE_SUPS_NOTIFICATION_IND indication. – 0x00 - Disable – 0x01 - Enable

Note

One of the optional parameter is mandatory to be present in the request.

8.379.2 Field Documentation

8.379.2.1 uint8_t* pack_voice_SLQSVoiceIndicationRegister_t::pRegDTMFEvents

8.379.2.2 uint8_t* pack_voice_SLQSVoiceIndicationRegister_t::pRegVoicePrivacyEvents

8.379.2.3 uint8_t* pack_voice_SLQSVoiceIndicationRegister_t::pSuppsNotifEvents

8.380 pack_voice_SLQSVoiceManageCalls_t Struct Reference

Data Fields

- uint8_t SUPSType
- uint8_t * pCallID

8.380.1 Detailed Description

This structure contains Manage Calls Information.

Parameters

SUPSType	• Supplementary service type during the call. – 0x01 - SUPS_TYPE_RELEASE_HELD_OR_WAITING * Release is held or waiting – 0x02 - SUPS_TYPE_RELEASE_ACTIVE_ACCEPT_HELD_OR_WAITING * Release is active and accepting held or waiting – 0x03 - SUPS_TYPE_HOLD_ACTIVE_ACCEPT_WAITING_OR_HELD * Hold is active and accepting waiting or held – 0x04 - SUPS_TYPE_HOLD_ALL_EXCEPT_SPECIFIED_CALL * Hold all calls except a specified one – 0x05 - SUPS_TYPE_MAKE_CONFERENCE_CALL * Make a conference call – 0x06 - SUPS_TYPE_EXPLICIT_CALL_TRANSFER * Explicit call transfer – 0x07 - SUPS_TYPE_CCBS_ACTIVATION * Activate completion of calls to busy subscriber – 0x08 - SUPS_TYPE_END_ALL_CALLS * End all calls – 0x09 - SUPS_TYPE_RELEASE_SPECIFIED_CALL * Release a specified call
pCallID[Optional]	• Applicable only for SUPSType 0x04, 0x07, and 0x09 • NULL pointer - Invalid data.

8.380.2 Field Documentation

8.380.2.1 uint8_t* pack_voice_SLQSVoiceManageCalls_t::pCallID

8.380.2.2 uint8_t pack_voice_SLQSVoiceManageCalls_t::SUPSType

8.381 pack_voice_SLQSVoiceOrigUSSDNoWait_t Struct Reference

Data Fields

- struct voice_USSInfo USSInformation

8.381.1 Detailed Description

This structure contains Orig USSD No Wait Information Parameters.

Parameters

USSInformation	• See voice_USSInfo for more information.

8.381.2 Field Documentation

8.381.2.1 struct voice_USSInfo pack_voice_SLQSVoiceOrigUSSDNoWait_t::USSInformation

8.382 pack_voice_SLQSVoiceSendFlash_t Struct Reference

Data Fields

- uint8_t * pCallID
- uint8_t * pFlashPayLd
- uint8_t * pFlashType

8.382.1 Detailed Description

This structure contains the flash information associated with a call.

Parameters

pCallID	• Unique call identifier associated with the current call.
pFlashPayLd(optional)	• Payload in ASCII to be sent in Flash. • Variable Length, NULL terminated.
pFlashType(optional)	• Flash type. – 0 - Simple Flash (default) – 1 - Activate answer hold – 2 - Deactivate answer hold

8.382.2 Field Documentation

8.382.2.1 uint8_t* pack_voice_SLQSVoiceSendFlash_t::pCallID

8.382.2.2 uint8_t* pack_voice_SLQSVoiceSendFlash_t::pFlashPayLd

8.382.2.3 uint8_t* pack_voice_SLQSVoiceSendFlash_t::pFlashType

8.383 pack_voice_SLQSVoiceSetCallBarringPassword_t Struct Reference

Data Fields

- uint8_t Reason
- uint8_t oldPasswd [4]
- uint8_t newPasswd [4]
- uint8_t newPasswdAgain [4]

8.383.1 Detailed Description

This structure contains Voice Set Call Barring Password Pack Parameters

Parameters

Reason	• Call Barring Reason • Values: – 0x07 - QMI_VOICE_REASON_BARR_ALLOUTGOING - All outgoing – 0x08 - QMI_VOICE_REASON_BARR_OUTGOINGINT - Outgoing internal – 0x09 - QMI_VOICE_REASON_BARR_OUTGOINGINTEXTOHOME - Outgoing external to home – 0x0A - QMI_VOICE_REASON_BARR_ALLINCOMING - All incoming – 0x0B - QMI_VOICE_REASON_BARR_INCOMINGROAMING - Roaming incoming – 0x0C - QMI_VOICE_REASON_BARR_ALLBARRING - All calls are barred – 0x0D - QMI_VOICE_REASON_BARR_ALLOUTGOINGBARRING - All outgoing calls are barred – 0x0E - QMI_VOICE_REASON_BARR_ALLINCOMINGBARRING - All incoming calls are barred
oldPasswd[BARRING_PASSWORD_LENGTH]	• Old password. – Password consists of 4 ASCII digits. – Range: 0000 to 9999.
newPasswd[BARRING_PASSWORD_LENGTH]	• New password. – Password consists of 4 ASCII digits. – Range: 0000 to 9999.
newPasswdAgain[BARRING_PASSWORD_LENGTH]	• New password Again. – Password consists of 4 ASCII digits. – Range: 0000 to 9999.

8.383.2 Field Documentation

8.383.2.1 uint8_t pack_voice_SLQSVoiceSetCallBarringPassword_t::newPasswd[4]

8.383.2.2 uint8_t pack_voice_SLQSVoiceSetCallBarringPassword_t::newPasswdAgain[4]

8.383.2.3 uint8_t pack_voice_SLQSVoiceSetCallBarringPassword_t::oldPasswd[4]

8.383.2.4 uint8_t pack_voice_SLQSVoiceSetCallBarringPassword_t::Reason

8.384 pack_voice_SLQSVoiceSetConfig_t Struct Reference

Data Fields

- uint8_t * pAutoAnswer
- voice_airTimer * pAirTimerConfig
- voice_roamTimer * pRoamTimerConfig
- uint8_t * pTTYMode
- voice_prefVoiceSO * pPrefVoiceSO
- uint8_t * pPrefVoiceDomain

8.384.1 Detailed Description

This structure contains information about the Set Configuration Request Parameters.

Parameters

pAutoAnswer	• Value specified is written to NV_AUTO_ANSWER_I. (optional) • Values: – 0x00 - Disable – 0x01 - Enable
pAirTimerConfig	• Value specified is written to NV_AIR_CNT_I. (optional) • See voice_airTimer for more information
pRoamTimer-Config	• Value specified is written to NV_ROAM_CNT_I. (optional) • See voice_roamTimer for more information
pTTYMode	• Value specified is written to NV_TTY_I. (optional) • Values: – 0x00 - TTY_MODE_FULL - Full – 0x01 - TTY_MODE_VCO - Voice carry over – 0x02 - TTY_MODE_HCO - Hearing carry over – 0x03 - TTY_MODE_OFF - Off
pPrefVoiceSO	• Value specified is written to NV_PREF_VOICE_SO_I. (optional) • See voice_prefVoiceSO for more information

pPrefVoice-Domain	• Preferred Voice-Domain. (optional) • Values: – 0x00 - VOICE_DOMAIN_PREF_CS_ONLY - Circuit-switched (CS) only – 0x01 - VOICE_DOMAIN_PREF_PS_ONLY - Packet-switched (PS) only – 0x02 - VOICE_DOMAIN_PREF_CS_PREF - CS is preferred, PS is secondary – 0x03 - VOICE_DOMAIN_PREF_PS_PREF - PS is preferred, CS is secondary

Note

One of the optional parameters must be present in the request.

8.384.2 Field Documentation

8.384.2.1 voice_airTimer* pack_voice_SLQSVoiceSetConfig_t::pAirTimerConfig

8.384.2.2 uint8_t* pack_voice_SLQSVoiceSetConfig_t::pAutoAnswer

8.384.2.3 uint8_t* pack_voice_SLQSVoiceSetConfig_t::pPrefVoiceDomain

8.384.2.4 voice_prefVoiceSO* pack_voice_SLQSVoiceSetConfig_t::pPrefVoiceSO

8.384.2.5 voice_roamTimer* pack_voice_SLQSVoiceSetConfig_t::pRoamTimerConfig

8.384.2.6 uint8_t* pack_voice_SLQSVoiceSetConfig_t::pTTYMode

8.385 pack_voice_SLQSVoiceSetPreferredPrivacy_t Struct Reference

Data Fields

- uint8_t privacyPref

8.385.1 Detailed Description

This structure contains the preferred voice privacy values.

Parameters

privacyPref	• Voice Privacy Preference – 0x00 - VOICE_PRIVACY_STANDARD - Standard privacy – 0x01 - VOICE_PRIVACY_ENHANCED - Enhanced privacy

8.385.2 Field Documentation

8.385.2.1 uint8_t pack_voice_SLQSVoiceSetPreferredPrivacy_t::privacyPref

8.386 pack_voice_SLQSVoiceSetSUPSService_t Struct Reference

Data Fields

- uint8_t voiceSvc
- uint8_t reason
- uint8_t * pServiceClass
- uint8_t * pCallBarringPasswd
- uint8_t * pCallForwardingNumber
- uint8_t * pTimerVal
- voice_callFwdTypeAndPlan * pCallFwdTypeAndPlan

8.386.1 Detailed Description

This structure contains Supplementary Service request parameters related to different features and their activation, deactivation, registration and erasure (applicable only for 3GPP)

Parameters

voiceSvc	• Manages all call-independent supplementary services, such as activation, deactivation, registration, and erasure (mandatory) – 0x01 - VOICE_SERVICE_ACTIVATE – 0x02 - VOICE_SERVICE_DEACTIVATE – 0x03 - VOICE_SERVICE_REGISTER – 0x04 - VOICE_SERVICE_ERASE

reason	• supplementary service reason values (mandatory) – 0x01 - QMI_VOICE_REASON_FWD_UNCONDITIONAL Unconditional call forwarding – 0x02 - QMI_VOICE_REASON_FWD_MOBILEBUSY Forward when the mobile is busy – 0x03 - QMI_VOICE_REASON_FWD_NOREPLY Forward when there is no reply – 0x04 - QMI_VOICE_REASON_FWD_UNREACHABLE Forward when the call is unreachable – 0x05 - QMI_VOICE_REASON_FWD_ALLFORWARDING All forwarding – 0x06 - QMI_VOICE_REASON_FWD_ALLCONDITIONAL All conditional forwarding – 0x07 - QMI_VOICE_REASON_BARR_ALLOUTGOING All outgoing calls are barred – 0x08 - QMI_VOICE_REASON_BARR_OUTGOINGINT Outgoing internal calls are barred – 0x09 - QMI_VOICE_REASON_BARR_OUTGOINGINTEXTOHOME Outgoing calls external to home are barred – 0x0A - QMI_VOICE_REASON_BARR_ALLINCOMING All incoming calls are barred – 0x0B - QMI_VOICE_REASON_BARR_INCOMINGROAMING Roaming incoming calls are barred – 0x0C - QMI_VOICE_REASON_BARR_ALLBARRING All calls are barred – 0x0D - QMI_VOICE_REASON_BARR_ALLOUTGOINGBARRING All outgoing calls are barred – 0x0E - QMI_VOICE_REASON_BARR_ALLINCOMINGBARRING All incoming calls are barred – 0x0F - QMI_VOICE_REASON_CALLWAITING Call waiting
pServiceClass	• Service class is a combination (sum) of information class constants (optional) – See liteServiceClassInformation for more information
pCallBarring-Passwd	• Password is required if call barring is provisioned using a password. Password consists of 4 ASCII digits. Range: 0000 to 9999 (optional)
pCallForwarding-Number	• Call forwarding number to be registered with the network. This has to be included in the request only when the service is set to VOICE_SERVICE_REGISTER. NULL terminated ASCII string. (optional)
pTimerVal	• Call forwarding no reply timer value in seconds. This has to be included in the request only when the service is set to VOICE_SERVICE_REGISTER and the reason is QMI_VOICE_REASON_FWD_NOREPLY. (optional) – Range: 5 to 30 in steps of 5

pCallFwdType-AndPlan	• Information about call forwarding type and plan. This parameter is ignored when the Call Forwarding Number is not included (optional) – See voice_callFwdTypeAndPlan for more information

8.386.2 Field Documentation

8.386.2.1 uint8_t* pack_voice_SLQSVoiceSetSUPSService_t::pCallBarringPasswd

8.386.2.2 uint8_t* pack_voice_SLQSVoiceSetSUPSService_t::pCallForwardingNumber

8.386.2.3 voice_callFwdTypeAndPlan* pack_voice_SLQSVoiceSetSUPSService_t::pCallFwdTypeAndPlan

8.386.2.4 uint8_t* pack_voice_SLQSVoiceSetSUPSService_t::pServiceClass

8.386.2.5 uint8_t* pack_voice_SLQSVoiceSetSUPSService_t::pTimerVal

8.386.2.6 uint8_t pack_voice_SLQSVoiceSetSUPSService_t::reason

8.386.2.7 uint8_t pack_voice_SLQSVoiceSetSUPSService_t::voiceSvc

8.387 pack_voice_SLQSVoiceStartContDTMF_t Struct Reference

Data Fields

- uint8_t * pCallID
- uint8_t DTMFdigit

8.387.1 Detailed Description

This structure contains parameters of continuous DTMF

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. Start continuous DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device
DTMFdigit	• DTMF digit in ASCII.

8.387.2 Field Documentation

8.387.2.1 uint8_t pack_voice_SLQSVoiceStartContDTMF_t::DTMFdigit

8.387.2.2 uint8_t* pack_voice_SLQSVoiceStartContDTMF_t::pCallID

8.388 pack_voice_SLQSVoiceStopContDTMF_t Struct Reference

Data Fields

- uint8_t callID

8.388.1 Detailed Description

This structure contains parameters of stop continuous DTMF

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. Stop continuous DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device

8.388.2 Field Documentation

8.388.2.1 uint8_t pack_voice_SLQSVoiceStopContDTMF_t::callID

8.389 pack_wds_DHCPv4ClientLeaseChange_t Struct Reference

Data Fields

- uint8_t * pEnableNotification

8.389.1 Detailed Description

WDS SWI DHCPv4 Client Lease Change Structure

Parameters

pEnable-Notification	• Enable Notification or not

8.389.2 Field Documentation

8.389.2.1 uint8_t* pack_wds_DHCPv4ClientLeaseChange_t::pEnableNotification

8.390 pack_wds_GetDefaultProfile_t Struct Reference

Data Fields

- uint32_t profiletype

8.390.1 Detailed Description

This structure contains pack get default profile information.

Parameters

profiletype	profile type • 0 - WDS_PROFILE_TYPE_3GPP (0x00) - 3GPP • 1 - WDS_PROFILE_TYPE_3GPP (0x01) - 3GPP2 • 2 - WDS_PROFILE_TYPE_EPC (0x02) - EPC

8.390.2 Field Documentation

8.390.2.1 uint32_t pack_wds_GetDefaultProfile_t::profiletype

8.391 pack_wds_GetDefaultProfileNum_t Struct Reference

Data Fields

- uint8_t type
- uint8_t family

8.391.1 Detailed Description

This structure contains pack Get Default Profile Number information.

Parameters

type	profile type • 0 - 3GPP • 1 - 3GPP2
family	profile family • 0 - Embedded • 1 - Tethered

8.391.2 Field Documentation

8.391.2.1 uint8_t pack_wds_GetDefaultProfileNum_t::family

8.391.2.2 uint8_t pack_wds_GetDefaultProfileNum_t::type

8.392 pack_wds_GetDormancyState_t Struct Reference

8.392.1 Detailed Description

This structure contains pack get dormancy state information.

Parameters

NULL	• this is a dummy structure

8.393 pack_wds_GetLastMobileIPError_t Struct Reference

8.393.1 Detailed Description

This structure contains pack get last mobile IP error information.

Parameters

NULL	• this is a dummy structure

8.394 pack_wds_GetMobileIP_t Struct Reference

8.394.1 Detailed Description

This structure contains pack get mobile IP information.

Parameters

NULL	• this is a dummy structure

8.395 pack_wds_GetMobileIPProfile_t Struct Reference

Data Fields

- uint8_t index

8.395.1 Detailed Description

This structure contains pack get mobile IP profile information.

Parameters

index	• Mobile IP profile ID

8.395.2 Field Documentation

8.395.2.1 uint8_t pack_wds_GetMobileIPProfile_t::index

8.396 pack_wds_GetPacketStatistics_t Struct Reference

Data Fields

- uint32_t * pStatMask

8.396.1 Detailed Description

This structure contains pack get packet statistics information.

Parameters

pStatMask	• Packet Statistics Mask – 0x00000001 - Tx packets OK – 0x00000002 - Rx packets OK – 0x00000004 - Tx packet errors – 0x00000008 - Rx packet errors – 0x00000010 - Tx overflows – 0x00000020 - Rx overflows – 0x00000040 - Tx bytes OK – 0x00000080 - Rx bytes OK

8.396.2 Field Documentation

8.396.2.1 uint32_t* pack_wds_GetPacketStatistics_t::pStatMask

8.397 pack_wds_GetPacketStatus_t Struct Reference

Data Fields

- uint32_t statmask

8.397.1 Detailed Description

This structure contains pack get packet status information.

Parameters

statmask	packet statistics mask • 0x00000001 - Tx packets OK • 0x00000002 - Rx packets OK • 0x00000004 - Tx packet errors • 0x00000008 - Rx packet errors • 0x00000010 - Tx overflows • 0x00000020 - Rx overflows • 0x00000040 - Tx bytes OK • 0x00000080 - Rx bytes OK • 0x00000100 - Tx packets dropped • 0x00000200 - Rx packets dropped

8.397.2 Field Documentation

8.397.2.1 uint32_t pack_wds_GetPacketStatus_t::statmask

8.398 pack_wds_GetSessionDuration_t Struct Reference

8.398.1 Detailed Description

This structure contains pack get session duration information.

Parameters

NULL	• this is a dummy structure

8.399 pack_wds_RMSetTransferStatistics_t Struct Reference

Data Fields

- rmTrasnferStaticsReq RmTrasnferStaticsReq

8.399.1 Detailed Description

This structure contains pack fetch current data system transfer statistics information.

Parameters

RmTrasnfer-StaticsReq[IN]	• See rmTrasnferStaticsReq for more information

8.399.2 Field Documentation

8.399.2.1 rmTrasnferStaticsReq pack_wds_RMSetTransferStatistics_t::RmTrasnferStaticsReq

8.400 pack_wds_SetAutoconnect_t Struct Reference

Data Fields

- uint8_t acsetting
- uint8_t acroamsetting

8.400.1 Detailed Description

auto connect data session parameters.

Parameters

acsetting	• Current autoconnect setting: – 0x00 - Autoconnect disabled – 0x01 - Autoconnect enabled – 0x02 - Autoconnect paused (resume on powercycle)
acroamsetting	• Current autoconnect roaming status – 0x00 - Autoconnect always allowed – 0x01 - Autoconnect while in home service area only

8.400.2 Field Documentation

8.400.2.1 uint8_t pack_wds_SetAutoconnect_t::acroamsetting

8.400.2.2 uint8_t pack_wds_SetAutoconnect_t::acsetting

8.401 pack_wds_SetDefaultProfile_t Struct Reference

Data Fields

- uint32_t profileType
- uint32_t pdpType
- uint32_t ipAddress
- uint32_t primaryDNS
- uint32_t secondaryDNS
- uint32_t authentication
- uint8_t * pName
- uint8_t * pUsername
- uint8_t * pApnname
- uint8_t * pPassword

8.401.1 Detailed Description

Writes the default profile settings to the device. The default profile is used to establish an autoconnect data session.

Parameters

profileType	• Type of profile – 0 - 3GPP – 1 - 3GPP2
pdpType	• Packet Data Protocol (PDP) type specifies the type of data payload exchanged over the air link when the packet data session is established with this profile (optional) – 0 - PDP-IP (IPv4) – 1 - PDP-PPP – 2 - PDP-IPv6 – 3 - PDP-IPv4v6

ipAddress	• Preferred IPv4 addr to be assigned to device (optional)
primaryDNS	• Primary DNS Ipv4 address preference (optional)
secondaryDNS	• Secondary DNS Ipv4 address preference (optional)
authentication	• Bitmap that indicates authentication algorithm preference (optional) – 0x00000001 - PAP preference * 0 - Never performed * 1 - May be performed – 0x00000002 - CHAP preference * 0 - Never performed * 1 - May be performed – All other bits are reserved and must be set to 0 – If more than 1 bit is set, then device decides which authentication procedure is performed while setting up data session e.g. the device may have a policy to select the most secure authentication mechanism.
pName	• profile Name (optional)
pUsername	• Username used during network authentication (optional)
pAPNName	• Access point name. NULL-terminated string parameter that is a logical name used to select GGSN and external packet data network (optional) • If value is NULL or omitted, then subscription default value will be requested.
pPassword	• Password used during network authentication (optional)

8.401.2 Field Documentation

8.401.2.1 uint32_t pack_wds_SetDefaultProfile_t::authentication

8.401.2.2 uint32_t pack_wds_SetDefaultProfile_t::ipAddress

8.401.2.3 uint8_t* pack_wds_SetDefaultProfile_t::pApnname

8.401.2.4 uint32_t pack_wds_SetDefaultProfile_t::pdpType

8.401.2.5 uint8_t* pack_wds_SetDefaultProfile_t::pName

8.401.2.6 uint8_t* pack_wds_SetDefaultProfile_t::pPassword

8.401.2.7 uint32_t pack_wds_SetDefaultProfile_t::primaryDNS

8.401.2.8 uint32_t pack_wds_SetDefaultProfile_t::profileType

8.401.2.9 uint8_t* pack_wds_SetDefaultProfile_t::pUsername

8.401.2.10 uint32_t pack_wds_SetDefaultProfile_t::secondaryDNS

8.402 pack_wds_SetDefaultProfileNum_t Struct Reference

Data Fields

- uint8_t type
- uint8_t family
- uint8_t index

8.402.1 Detailed Description

This structure to hold Set default profile number

Parameters

type	Identifies the technology type of the profile • 0 - 3GPP • 1 - 3GPP2
family	Identifies the family of profile • 0 - Embedded • 1 - Tethered
index	Profile number to be set as default profile.

8.402.2 Field Documentation

8.402.2.1 uint8_t pack_wds_SetDefaultProfileNum_t::family

8.402.2.2 uint8_t pack_wds_SetDefaultProfileNum_t::index

8.402.2.3 uint8_t pack_wds_SetDefaultProfileNum_t::type

8.403 pack_wds_SetMobileIP_t Struct Reference

Data Fields

- uint32_t mode

8.403.1 Detailed Description

This structure contains set mobile IP pack information.

Parameters

mode	• Mobile IP setting – 0 - Mobile IP off (simple IP only) – 1 - Mobile IP preferred – 2 - Mobile IP only

8.403.2 Field Documentation

8.403.2.1 uint32_t pack_wds_SetMobileIP_t::mode

8.404 pack_wds_SetMobileIPParameters_t Struct Reference

Data Fields

- char * pSPC
- uint32_t * pMode
- uint8_t * pRetryLimit
- uint8_t * pRetryInterval
- uint8_t * pReRegPeriod
- uint8_t * pReRegTraffic
- uint8_t * pHAAuthenticator
- uint8_t * pHA2002bis

8.404.1 Detailed Description

Mobile IP parameters information.

Parameters

pSPC	• NULL-terminated string representing six digit service programming code.
pMode	• Mode to be set (optional) – 0 - Mobile IP off (simple IP only) – 1 - Mobile IP preferred – 2 - Mobile IP only
pRetryLimit	• Registration retry attempt limit (optional)
pRetryInterval	• Registration retry attempt interval used to determine the time between registration attempts (optional)
pReRegPeriod	• Period (in minutes) to attempt re-registration before current registration expires (optional)

pReRegTraffic	• Re-registration only if traffic since last attempt (optional) – Zero - Disabled – NonZero - Enabled
pHA-Authenticator	• MH-HA authenticator calculator (optional) – Zero - Disabled – NonZero - Enabled
pHA2002bis	• MH-HA RFC 2002bis authentication instead of RFC2002 (optional) – Zero - Disabled – NonZero - Enabled

8.404.2 Field Documentation

8.404.2.1 uint8_t* pack_wds_SetMobileIPParameters_t::pHA2002bis

8.404.2.2 uint8_t* pack_wds_SetMobileIPParameters_t::pHAAuthenticator

8.404.2.3 uint32_t* pack_wds_SetMobileIPParameters_t::pMode

8.404.2.4 uint8_t* pack_wds_SetMobileIPParameters_t::pReRegPeriod

8.404.2.5 uint8_t* pack_wds_SetMobileIPParameters_t::pReRegTraffic

8.404.2.6 uint8_t* pack_wds_SetMobileIPParameters_t::pRetryInterval

8.404.2.7 uint8_t* pack_wds_SetMobileIPParameters_t::pRetryLimit

8.404.2.8 char* pack_wds_SetMobileIPParameters_t::pSPC

8.405 pack_wds_SetMobileIPProfile_t Struct Reference

Data Fields

- int8_t spc [10]
- uint8_t index
- uint8_t * pEnabled
- uint32_t * pAddress
- uint32_t * pPrimaryHA
- uint32_t * pSecondaryHA
- uint8_t * pRevTunneling
- int8_t * pNAI
- uint32_t * pHASPI
- uint32_t * pAAASPI
- int8_t * pMNHA
- int8_t * pMNAAA

8.405.1 Detailed Description

Sets the mobile IP parameters.

Parameters

spc	• Six digit service programming code string
index	• Index of the profile to modify
pEnabled	• (Optional) Enable profile? 0 - Disabled Nonzero - Enabled
pAddress	• (Optional) Home IPv4 address
pPrimaryHA	• (Optional) Primary home agent IPv4 address
pSecondaryHA	• (Optional) Secondary home agent IPv4 address
pRevTunneling	• (Optional) Enable reverse tunneling? 0 - Disabled Nonzero - Enabled
pNAI	• (Optional) Network access identifier string
pHASPI	• (Optional) Home agent security parameter index
pAAASPI	• (Optional) AAA server security parameter index
pMNHA	• (Optional) MN-HA key string
pMNAAA	• (Optional) MN-AAA key string

8.405.2 Field Documentation

8.405.2.1 uint8_t pack_wds_SetMobileIPProfile_t::index

8.405.2.2 uint32_t* pack_wds_SetMobileIPProfile_t::pAAASPI

8.405.2.3 uint32_t* pack_wds_SetMobileIPProfile_t::pAddress

8.405.2.4 uint8_t* pack_wds_SetMobileIPProfile_t::pEnabled

8.405.2.5 uint32_t* pack_wds_SetMobileIPProfile_t::pHASPI

8.405.2.6 int8_t* pack_wds_SetMobileIPProfile_t::pMNAAA

8.405.2.7 int8_t* pack_wds_SetMobileIPProfile_t::pMNHA

8.405.2.8 int8_t* pack_wds_SetMobileIPProfile_t::pNAI

8.405.2.9 uint32_t* pack_wds_SetMobileIPProfile_t::pPrimaryHA

8.405.2.10 uint8_t* pack_wds_SetMobileIPProfile_t::pRevTunneling

8.405.2.11 uint32_t* pack_wds_SetMobileIPProfile_t::pSecondaryHA

8.405.2.12 int8_t pack_wds_SetMobileIPProfile_t::spc[10]

8.406 pack_wds_SLQSCreateProfile_t Struct Reference

Data Fields

- uint8_t * pProfileId
- uint8_t * pProfileType
- wds_profileInfo * pCurProfile

8.406.1 Detailed Description

This structure contains pack create profile.

Parameters

pProfileId	• 1 to 16 for 3GPP profile (EM/MC73xx or earlier) • 1 to 24 for 3GPP profile (EM/MC74xx onwards) • 101 to 106 for 3GPP2 profile
pProfileType	• Identifies the technology type of the profile – 0x00 - 3GPP – 0x01 - 3GPP2 – NULL is not allowed
pCurProfile	• union of 3GPP and 3GPP2 profile • See wds_profileInfo

Note

- If profileID is NULL, 3GPP profile will be created and index will be assigned based on availability in device.
- If profileID is not NULL depending on pProfileType 3GPP/3GPP2 relevant profile will be created

8.406.2 Field Documentation

8.406.2.1 wds_profileInfo* pack_wds_SLQSCreateProfile_t::pCurProfile

8.406.2.2 uint8_t* pack_wds_SLQSCreateProfile_t::pProfileId

8.406.2.3 uint8_t* pack_wds_SLQSCreateProfile_t::pProfileType

8.407 pack_wds_SLQSDeleteProfile_t Struct Reference

Data Fields

- uint8_t profileType
- uint8_t profileIndex

8.407.1 Detailed Description

This structure contains the information about the profile to be deleted.

Parameters

profileType	• Identifies the type of profile – 0x00 - 3GPP • Note: Deletion of 3GPP2 profiles is not supported.
profileIndex	• Index of the configured profile to be deleted – Value between 1 - 16 (EM/MC73xx or earlier) – Value between 1 - 24 (EM/MC74xx onwards)

8.407.2 Field Documentation

8.407.2.1 uint8_t pack_wds_SLQSDeleteProfile_t::profileIndex

8.407.2.2 uint8_t pack_wds_SLQSDeleteProfile_t::profileType

8.408 pack_wds_SLQSGetCurrDataSystemStat_t Struct Reference

8.408.1 Detailed Description

This structure contains pack get current data system state information.

Parameters

NULL	• this is a dummy structure

8.409 pack_wds_SLQSGetDataBearerTechnology_t Struct Reference

8.409.1 Detailed Description

This structure contains pack get data bearer technology information.

Parameters

NULL	• this is a dummy structure

8.410 pack_wds_SLQSGetDUNCallInfo_t Struct Reference

Data Fields

- uint32_t Mask
- uint8_t * pReportConnStatus
- wds_transferStatInd * pTransferStatInd
- uint8_t * pReportDormStatus
- uint8_t * pReportDataBearerTech
- uint8_t * pReportChannelRate

8.410.1 Detailed Description

This structure contains the DUN Call Info Request parameters.

Parameters

Mask	• Mandatory parameter • Set the bits corresponding to the information requested to 1 • All other bits must be set to 0. • If any values are not available or applicable, the corresponding TLVs are not returned in the response. – Bit 0 - Connection Status – Bit 1 - Last call end reason – Bit 2 - Tx/Rx bytes OK – Bit 3 - Dormancy status – Bit 4 - Data bearer – Bit 5 - Channel rate – Bit 6 - Call active duration
pReportConn-Status	• Connect Status Indicator – 0 - Do not report – 1 - Report connection status and call end reason
pTransferStatInd	• See wds_transferStatInd for more information
pReportDorm-Status	• Dormancy Status Indicator – 0 - Do not report – 1 - Report traffic channel state of interface used for data connection

pReportData-BearerTech	• Current Data Bearer Technology Indicator – 0 - Do not report – 1 - Report radio interface used for data transfer when it changes
pReport-ChannelRate	• Channel Rate Indicator – 0 - Do not report – 1 - Report channel rate

8.410.2 Field Documentation

8.410.2.1 uint32_t pack_wds_SLQSGetDUNCallInfo_t::Mask

8.410.2.2 uint8_t* pack_wds_SLQSGetDUNCallInfo_t::pReportChannelRate

8.410.2.3 uint8_t* pack_wds_SLQSGetDUNCallInfo_t::pReportConnStatus

8.410.2.4 uint8_t* pack_wds_SLQSGetDUNCallInfo_t::pReportDataBearerTech

8.410.2.5 uint8_t* pack_wds_SLQSGetDUNCallInfo_t::pReportDormStatus

8.410.2.6 wds_transferStatInd* pack_wds_SLQSGetDUNCallInfo_t::pTransferStatInd

8.411 pack_wds_SLQSGetProfileSettings_t Struct Reference

Data Fields

- uint8_t ProfileId
- uint8_t ProfileType

8.411.1 Detailed Description

This structure contains pack get profile settings information.

Parameters

ProfileID	• 1 to 16 for 3GPP profile (EM/MC73xx or earlier) • 1 to 24 for 3GPP profile (EM/MC74xx onwards) • 101 to 106 for 3GPP2 profile
ProfileType	• Identifies the technology type of the profile – 0x00 - 3GPP – 0x01 - 3GPP2

Note

- If profileID is NULL, 3GPP profile will be fetched and index will be assigned based on availability in device.
- If profileID is not NULL depending on pProfileType 3GPP/3GPP2 relevant profile will be fetched

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

8.411.2 Field Documentation

8.411.2.1 uint8_t pack_wds_SLQSGetProfileSettings_t::ProfileId

8.411.2.2 uint8_t pack_wds_SLQSGetProfileSettings_t::ProfileType

8.412 pack_wds_SLQSGetRuntimeSettings_t Struct Reference

Data Fields

- uint32_t * pReqSettings

8.412.1 Detailed Description

This structure contains pack get runtime settings information

Parameters

pReqSettings	Requested Settings (Optional Parameter) • Set bits to 1, corresponding to requested information. All other bits must be set to 0. • If the values are not available, the corresponding TLVs are not returned in the response. • Absence of this mask TLV results in the device returning all of the available information corresponding to bits 0 through 12. • In cases where the information from bit 13 or greater is required, this TLV with all the necessary bits set must be present in the request. • Values – Bit 0 - Profile identifier – Bit 1 - Profile name – Bit 2 - PDP type – Bit 3 - APN name – Bit 4 - DNS address – Bit 5 - UMTS/GPRS granted QoS – Bit 6 - Username – Bit 7 - Authentication Protocol – Bit 8 - IP address – Bit 9 - Gateway info (address and subnet mask) – Bit 10 - PCSCF address using PCO flag – Bit 11 - PCSCF server address list – Bit 12 - PCSCF domain name list – Bit 13 - MTU – Bit 14 - domain name list – Bit 15 - IP family – Bit 16 - IM_CM flag – Bit 17 - Technology name – Bit 18 - Operator reserved PCO (Not Supported on MC/EM73xx)

8.412.2 Field Documentation

8.412.2.1 uint32_t* pack_wds_SLQSGetRuntimeSettings_t::pReqSettings

8.413 pack_wds_SLQSModifyProfile_t Struct Reference

Data Fields

- uint8_t * pProfileId
- uint8_t * pProfileType
- wds_profileInfo curProfile

8.413.1 Detailed Description

This structure contains pack modify profile information.

Parameters

pProfileId	• 1 to 16 for 3GPP profile (EM/MC73xx or earlier) • 1 to 24 for 3GPP profile (EM/MC74xx onwards) • 101 to 106 for 3GPP2 profile
pProfileType	• Identifies the technology type of the profile – 0x00 - 3GPP – 0x01 - 3GPP2 – NULL is not allowed
curProfile	• union of 3GPP and 3GPP2 profile • See wds_profileInfo

Note

- If profileID is NULL, 3GPP profile will be created and index will be assigned based on availability in device.
- If profileID is not NULL depending on pProfileType 3GPP/3GPP2 relevant profile will be created

8.413.2 Field Documentation

8.413.2.1 wds_profileInfo pack_wds_SLQSModifyProfile_t::curProfile

8.413.2.2 uint8_t* pack_wds_SLQSModifyProfile_t::pProfileId

8.413.2.3 uint8_t* pack_wds_SLQSModifyProfile_t::pProfileType

8.414 pack_wds_SLQSSet3GPPConfigItem_t Struct Reference

Data Fields

- uint16_t * pLTEAttachProfile
- uint16_t * pProfileList
- uint8_t * pDefaultPDNEnabled
- uint8_t * p3gppRelease
- uint16_t * pLTEAttachProfileList
- uint16_t LTEAttachProfileListLen

8.414.1 Detailed Description

This structure contains pack set 3GPP configuration item information.

Parameters

pLTEAttach-Profile	• Optional parameter • LTE Attach Profile – points to a single WORD Value indicating the attached LTE Profile – Optional parameter with possible values 1-16 (EM/MC73xx or earlier) • This setting is deprecated on MC/EM74xx

ProfileList	Profile List • an array of 4 profile configurations • Each element points to a single WORD value indicating profile • Optional parameter with possible values – 1 - 16 (MC/EM73xx and before) – 1 - 24 (MC/EM74xx and onwards) • function SLQSGet3GPPConfigItem() returns a default value 255 if no 3gpp configuration is present
pDefaultPDN-Enabled	• Optional parameter – 0 - disabled – 1 - enabled
p3gppRelease	3GPP release • Optional parameter – 0 - Release_99 – 1 - Release_5 – 2 - Release_6 – 3 - Release_7 – 4 - Release_8 • In 9x30 and onwards – 5 - Release 9 – 6 - Release 10 – 7 - Release 11
pLTEAttach-ProfileList	• pointer to WORD array indicating LTE Attach Profile List – Optional parameter – possible values: 1-24 – This setting is only supported for MC/EM74xx onwards – Please provide attach profiles in order of decreasing priority in this list.
LTEAttach-ProfileListLen	• Number of element in pLTEAttachProfileList – valid range: 1-24 – This setting is only supported for MC/EM74xx onwards

8.414.2 Field Documentation

8.414.2.1 uint16_t pack_wds_SLQSSet3GPPConfigItem_t::LTEAttachProfileListLen

8.414.2.2 uint8_t* pack_wds_SLQSSet3GPPConfigItem_t::p3gppRelease

8.414.2.3 uint8_t* pack_wds_SLQSSet3GPPConfigItem_t::pDefaultPDNEnabled

8.414.2.4 uint16_t* pack_wds_SLQSSet3GPPConfigItem_t::pLTEAttachProfile

8.414.2.5 uint16_t* pack_wds_SLQSSet3GPPConfigItem_t::pLTEAttachProfileList

8.414.2.6 uint16_t* pack_wds_SLQSSet3GPPConfigItem_t::pProfileList

8.415 pack_wds_SLQSSetIPFamilyPreference_t Struct Reference

Data Fields

- uint8_t IPFamilyPreference

8.415.1 Detailed Description

This structure contains pack set IP family preference information

Parameters

IPFamily-Preference	IP Family preference • PACK_WDS_IPV4 IP Version 4 • PACK_WDS_IPV6 IP Version 6

8.415.2 Field Documentation

8.415.2.1 uint8_t pack_wds_SLQSSetIPFamilyPreference_t::IPFamilyPreference

8.416 pack_wds_SLQSSetWdsEventCallback_t Struct Reference

Data Fields

- uint8_t dataBearer
- uint8_t dormancyStatus
- uint8_t mobileIP
- uint8_t transferStats
- uint8_t currentDataBearer
- uint8_t dataSystemStatus
- uint8_t dataBearerTechExt
- uint8_t interval

8.416.1 Detailed Description

This structure contains set WDS event callback information.

Parameters

dataBearer	data bearer
dormancyStatus	dormancy status
mobileIP	mobile IP
currentData-Bearer	current data bearer
dataSystem-Status	data system status
dataBearerTech-Ext	data Bearer Technology Extended
interval	interval

8.416.2 Field Documentation

8.416.2.1 uint8_t pack_wds_SLQSSetWdsEventCallback_t::currentDataBearer

8.416.2.2 uint8_t pack_wds_SLQSSetWdsEventCallback_t::dataBearer

8.416.2.3 uint8_t pack_wds_SLQSSetWdsEventCallback_t::dataBearerTechExt

8.416.2.4 uint8_t pack_wds_SLQSSetWdsEventCallback_t::dataSystemStatus

8.416.2.5 uint8_t pack_wds_SLQSSetWdsEventCallback_t::dormancyStatus

8.416.2.6 uint8_t pack_wds_SLQSSetWdsEventCallback_t::interval

8.416.2.7 uint8_t pack_wds_SLQSSetWdsEventCallback_t::mobileIP

8.416.2.8 uint8_t pack_wds_SLQSSetWdsEventCallback_t::transferStats

8.417 pack_wds_SLQSSGetDHCPv4ClientConfig_t Struct Reference

Data Fields

- wdsDhcpv4ProfileId * pProfileId

8.417.1 Detailed Description

This structure contain get DHCPv4 client configure.

Parameters

pProfileId	pointer to Profile Id structure • See wdsDhcpv4ProfileId

8.417.2 Field Documentation

8.417.2.1 wdsDhcpv4ProfileId* pack_wds_SLQSSGetDHCPv4ClientConfig_t::pProfileId

8.418 pack_wds_SLQSSSetDHCPv4ClientConfig_t Struct Reference

Data Fields

- wds_DHCPv4ProfileId * pProfileId
- wds_DHCPv4HWConfig * pHwConfig
- wds_DHCPv4OptionList * pRequestOptionList

8.418.1 Detailed Description

WDS SWI DHCPv4 Config Structure

Parameters

pProfileId	• pointer to Profile Id structure
pHWConfig	• pointer to HW Config structure
pRequestOption-List	• pointer to Option List structure to be sent in DHCP request

8.418.2 Field Documentation

8.418.2.1 wds_DHCPv4HWConfig∗ pack_wds_SLQSSSetDHCPv4ClientConfig_t::pHwConfig

8.418.2.2 wds_DHCPv4ProfileId∗ pack_wds_SLQSSSetDHCPv4ClientConfig_t::pProfileId

8.418.2.3 wds_DHCPv4OptionList∗ pack_wds_SLQSSSetDHCPv4ClientConfig_t::pRequestOptionList

8.419 pack_wds_SLQSSSetLoopback_t Struct Reference

Data Fields

- uint8_t loopbackMode
- uint8_t loopbackMultiplier

8.419.1 Detailed Description

This structure contains pack set loopback information.

Parameters

loopbackMode	• Loopback Mode. – 0 - Disable – 1 - Enable
loopback-Multiplier	• Loopback multiplier. Number of downlink bytes to send for each uplink byte.

8.419.2 Field Documentation

8.419.2.1 uint8_t pack_wds_SLQSSSetLoopback_t::loopbackMode

8.419.2.2 uint8_t pack_wds_SLQSSSetLoopback_t::loopbackMultiplier

8.420 pack_wds_SLQSStartDataSession_t Struct Reference

Data Fields

- uint8_t ∗ pTech

- uint32_t * pprofileid3gpp
- uint32_t * pprofileid3gpp2
- uint32_t * pAuth
- char * pUser
- char * pPass

8.420.1 Detailed Description

This structure contains pack Start Data Session Information.

Parameters

pTech	• Indicates the technology preference – 1 - UMTS – 2 - CDMA – 3 - eMBMS – 4 - Modem Link Label. Modem Link is an interface for transferring data between entities on AP and modem. • optional
pprofileid3gpp	• pointer to 3GPP profile id • optional
pprofileid3gpp2	• pointer to 3GPP2 profile id • optional
pAuth	• Authentication type, it can be PAP or CHAP • optional
pUser	• username for authentication process • optional
pPass	• password for authentication process • optional

8.420.2 Field Documentation

8.420.2.1 uint32_t* pack_wds_SLQSStartDataSession_t::pAuth

8.420.2.2 char* pack_wds_SLQSStartDataSession_t::pPass

8.420.2.3 uint32_t* pack_wds_SLQSStartDataSession_t::pprofileid3gpp

8.420.2.4 uint32_t* pack_wds_SLQSStartDataSession_t::pprofileid3gpp2

8.420.2.5 uint8_t* pack_wds_SLQSStartDataSession_t::pTech

8.420.2.6 char* pack_wds_SLQSStartDataSession_t::pUser

8.421 pack_wds_SLQSStopDataSession_t Struct Reference

Data Fields

- uint32_t * psid

8.421.1 Detailed Description

This structure contains pack stop data session information.

Parameters

psid	session id

8.421.2 Field Documentation

8.421.2.1 uint32_t* pack_wds_SLQSStopDataSession_t::psid

8.422 pack_wds_SLQSWdsSetEventReport_t Struct Reference

Data Fields

- uint8_t * pCurrChannelRateInd
- wds_TrStatInd * pTransferStatInd
- uint8_t * pDataBearerTechInd
- uint8_t * pDormancyStatusInd
- uint8_t * pMIPStatusInd
- uint8_t * pCurrDataBearerTechInd
- uint8_t * pDataCallStatusChangeInd
- uint8_t * pCurrPrefDataSysInd
- uint8_t * pEVDOPageMonPerChangeInd
- uint8_t * pDataSystemStatusChangeInd

8.422.1 Detailed Description

This structure contains the information about the Set Event Report Request parameters.

Parameters

pCurrChannel-RateInd	(optional) • Current Channel Rate Indicator. – 0 - Do not report – 1 - Report channel rate when it changes
pTransferStatInd	(optional) • See wds_TrStatInd for more information.
pDataBearer-TechInd	(optional) • Data Bearer Technology Indicator. – 0 - Do not report – 1 - Report radio interface used for data transfer when it changes

pDormancyStatusInd	(optional) • Dormancy Status indicator. – 0 - Do not report – 1 - Report traffic channel state of interface used for data connection
pMIPStatusInd	(optional) • MIP Status Indicator. – 0 - Do not report – 1 - Report MIP status
pCurrDataBearerTechInd	(optional) • Current Data Bearer Technology Indicator. – 0 - Do not report – 1 - Report current data bearer technology when it changes
pDataCallStatusChangeInd	(optional) • Data Call Status Change Indicator. – 0 - Do not report – 1 - Report data call status change when it changes
pCurrPrefDataSysInd	(optional) • Current Preferred Data System Indicator. – 0 - Do not report – 1 - Report preferred data system when it changes
pEVDOPageMonPerChangeInd	(optional) • EV-DO Page Monitor Period Change Indicator. – 0 - Do not report – 1 - Report EV-DO page monitor period change event
pDataSystemStatusChangeInd	(optional) • Data System Status Change Indicator. – 0 - Do not report – 1 - Report data system status change event

Note

At least one parameter should be present.

8.422.2 Field Documentation

8.422.2.1 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pCurrChannelRateInd

8.422.2.2 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pCurrDataBearerTechInd

8.422.2.3 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pCurrPrefDataSysInd

8.422.2.4 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pDataBearerTechInd

8.422.2.5 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pDataCallStatusChangeInd

8.422.2.6 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pDataSystemStatusChangeInd

8.422.2.7 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pDormancyStatusInd

8.422.2.8 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pEVDOPageMonPerChangeInd

8.422.2.9 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pMIPStatusInd

8.422.2.10 wds_TrStatInd* pack_wds_SLQSWdsSetEventReport_t::pTransferStatInd

8.423 pack_wds_SLQSWdsSwiPDPRuntimeSettings_t Struct Reference

Data Fields

- uint8_t contextId
- uint8_t contextType

8.423.1 Detailed Description

This structure contains the PDP Runtime Settings Request parameters.

Parameters

contextId	• Context Identifier
contextType	• Identifies technology type – 0 - 3GPP – 1 - 3GPP2

8.423.2 Field Documentation

8.423.2.1 uint8_t pack_wds_SLQSWdsSwiPDPRuntimeSettings_t::contextId

8.423.2.2 uint8_t pack_wds_SLQSWdsSwiPDPRuntimeSettings_t::contextType

8.424 PackCreateProfileOut Struct Reference

Data Fields

- uint8_t ProfileType
- uint8_t ProfileIndex
- uint16_t ExtErrorCode

8.424.1 Detailed Description

This structure contains out parameter Information

Parameters

ProfileType	• Identifies the type of profile 0x00 = 3GPP 0x01 = 3GPP2
ProfileIndex	• Index identifying the profile that was created
ExtErrorCode	• The extended error code received from DS Profile subsystem

8.424.2 Field Documentation

8.424.2.1 uint16_t PackCreateProfileOut::ExtErrorCode

8.424.2.2 uint8_t PackCreateProfileOut::ProfileIndex

8.424.2.3 uint8_t PackCreateProfileOut::ProfileType

8.425 packgetDyingGaspCfg Struct Reference

Data Fields

- uint8_t * pDestSMSNum
- uint8_t * pDestSMSContent

8.425.1 Detailed Description

This struture contains the TLV required to get the Dysing GASP Config.

Parameters

pDestSMSNum[IN]	• SMS Destination Number as string of 8 bit ASCII Characters Max 20 chars. • Optional parameter.
pDestSMSContent[IN]	• SMS COntent as a string of 8 bit ASCII text characters Max 160 chars. • Optional parameter.

8.425.2 Field Documentation

8.425.2.1 uint8_t* packgetDyingGaspCfg::pDestSMSContent

8.425.2.2 uint8_t* packgetDyingGaspCfg::pDestSMSNum

8.426 packgetDyingGaspStatistics Struct Reference

Data Fields

- uint32_t * pTimeStamp

- uint8_t * pSMSAttemptedFlag

8.426.1 Detailed Description

This structure contains Get Dysing GASP Statistics

Parameters

pTimeStamp[OUT]	• Timestamp of the last time power loss was detected and Dying Gasp feature was triggered. • UTC time in seconds since Jan 06, 1980 (GPS Epoch).
pSMSAttemptedFlag[OUT]	• Indicates whether device attempted to send SMS in the last power loss event. • 0 - SMS not attempted • 1 - SMS attempted • This only indicates device sent the SMS but does not guarantee network delivery.

8.426.2 Field Documentation

8.426.2.1 uint8_t* packgetDyingGaspStatistics::pSMSAttemptedFlag

8.426.2.2 uint32_t* packgetDyingGaspStatistics::pTimeStamp

8.427 PackSwiAvmsSetSettingsAPNInfo Struct Reference

Data Fields

- uint8_t bAPNLength
- uint8_t szAPN [49]
- uint8_t bUnameLength
- uint8_t szUname [29]
- uint8_t bPWDLength
- uint8_t szPWD [29]

8.427.1 Detailed Description

This structure contains pack set settings APN information.

Parameters

bAPNLength	APN Length.
szAPN	APN String.
bUnameLength	Username Length.
szUname	User Name String.
bPWDLength	Password Length.
szPWD	Password String.

8.427.2 Field Documentation

8.427.2.1 uint8_t PackSwiAvmsSetSettingsAPNInfo::bAPNLength

8.427.2.2 uint8_t PackSwiAvmsSetSettingsAPNInfo::bPWDLength

8.427.2.3 uint8_t PackSwiAvmsSetSettingsAPNInfo::bUnameLength

8.427.2.4 uint8_t PackSwiAvmsSetSettingsAPNInfo::szAPN[49]

8.427.2.5 uint8_t PackSwiAvmsSetSettingsAPNInfo::szPWD[29]

8.427.2.6 uint8_t PackSwiAvmsSetSettingsAPNInfo::szUname[29]

8.428 PackSwiAvmsSetSettingsConnectionRetryTimers Struct Reference

Data Fields

- uint16_t Timers [8]

8.428.1 Detailed Description

This structure contains the SLQSAVMSSetSettings Polling timer to connect to AVMS server.

Parameters

Timers[0]	- Timer 1. • 0-20160 (min) • 0:retry disabled
Timers[1]	- Timer 2. • 1-20160 (min)
Timers[2]	- Timer 3. • 1-20160 (min)
Timers[3]	- Timer 4. • 1-20160 (min)
Timers[4]	- Timer 5. • 1-20160 (min)
Timers[5]	- Timer 6. • 1-20160 (min)
Timers[6]	- Timer 7. • 1-20160 (min)
Timers[7]	- Timer 8. • 1-20160 (min)

8.428.2 Field Documentation

8.428.2.1 uint16_t PackSwiAvmsSetSettingsConnectionRetryTimers::Timers[8]

8.429 PackSwiAvmsSetSettingsPeriodInfo Struct Reference

Data Fields

- uint32_t ulMin
- uint32_t ulMax

8.429.1 Detailed Description

This structure contain pack set settings period information.

Parameters

ulMin	Min period in seconds.
ulMax	Max period in seconds.

8.429.2 Field Documentation

8.429.2.1 uint32_t PackSwiAvmsSetSettingsPeriodInfo::ulMax

8.429.2.2 uint32_t PackSwiAvmsSetSettingsPeriodInfo::ulMin

8.430 PackSwiAVMSSettingsAPNInfo Struct Reference

Data Fields

- uint8_t bAPNLength
- uint8_t * pAPN
- uint8_t bUnameLength
- uint8_t * pUname
- uint8_t bPWDLength
- uint8_t * pPWD

8.430.1 Detailed Description

This structure contains the SLQSAVMSGetSettings APN Info to connect to AVMS server.

Parameters

bAPNLength	- APN Length(Max 49).
szAPN	- APN.
bUnameLength	- User Name Length (Max 29).
szUname	- User Name.
bPWDLength	- Password Length (Max 29).
szPWD	- Password.

8.430.2 Field Documentation

8.430.2.1 uint8_t PackSwiAVMSSettingsAPNInfo::bAPNLength

8.430.2.2 uint8_t PackSwiAVMSSettingsAPNInfo::bPWDLength

8.430.2.3 uint8_t PackSwiAVMSSettingsAPNInfo::bUnameLength

8.430.2.4 uint8_t* PackSwiAVMSSettingsAPNInfo::pAPN

8.430.2.5 uint8_t* PackSwiAVMSSettingsAPNInfo::pPWD

8.430.2.6 uint8_t* PackSwiAVMSSettingsAPNInfo::pUname

8.431 PackSwiAVMSSettingsConnectionRetryTimers Struct Reference

Data Fields

- uint16_t Timers [8]

8.431.1 Detailed Description

This structure contains the SLQSAVMSGetSettings Polling timer to connect to AVMS server.

Parameters

Timers[0]	- Timer 1. • 0-20160 (min) • 0:retry disabled
Timers[1]	- Timer 2. • 1-20160 (min)
Timers[2]	- Timer 3. • 1-20160 (min)
Timers[3]	- Timer 4. • 1-20160 (min)
Timers[4]	- Timer 5. • 1-20160 (min)
Timers[5]	- Timer 6. • 1-20160 (min)
Timers[6]	- Timer 7. • 1-20160 (min)
Timers[7]	- Timer 8. • 1-20160 (min)

8.431.2 Field Documentation

8.431.2.1 uint16_t PackSwiAVMSSettingsConnectionRetryTimers::Timers[8]

8.432 PackSwiAVMSSettingsPeriodsInfo Struct Reference

Data Fields

- uint32_t min
- uint32_t max

8.432.1 Detailed Description

This structure contains the SLQSAVMSSettings Min/Max Period of an Observation.

Parameters

min	- Min period in seconds.
max	- Max period in seconds.

8.432.2 Field Documentation

8.432.2.1 uint32_t PackSwiAVMSSettingsPeriodsInfo::max

8.432.2.2 uint32_t PackSwiAVMSSettingsPeriodsInfo::min

8.433 qmiSmsMessageList Struct Reference

Data Fields

- uint32_t messageIndex
- uint32_t messageTag

8.433.1 Detailed Description

This structure contains SMS message list.

Parameters

messageIndex	• Message index of each matched message
messageTag	• Messagetag

8.433.2 Field Documentation

8.433.2.1 uint32_t qmiSmsMessageList::messageIndex

8.433.2.2 uint32_t qmiSmsMessageList::messageTag

8.434 qmiWDSDataBearerTechnology Struct Reference

Data Fields

- uint8_t currentNetwork
- uint32_t ratMask
- uint32_t soMask

8.434.1 Detailed Description

Structure to hold the current data bearer technology values

Parameters

currentNetwork[-OUT]	• current selected network – 0 - UNKNOWN – 1 - 3GPP2 – 2 - 3GPP – 0xff - Invalid data.
ratMask[OUT]	• Radio Access Technology (RAT) mask to indicate the type of technology (RAT mask value of zero indicates that this field is ignored) – 0x8000 - NULL Bearer – 0x0000 - DO_NOT_CARE CDMA RAT mask – 0x01 - CDMA_1X – 0x02 - EVDO_REV0 – 0x04 - EVDO_REVA UMTS RAT mask – 0x01 - WCDMA – 0x02 - GPRS – 0x04 - HSDPA – 0x08 - HSUPA – 0x10 - EDGE – 0x20 - LTE – 0x40 - HSDPA+ – 0x80 - DC_HSDPA+ – 0xffffffff - Invalid data.
soMask[OUT]	• Service Option (SO) mask to indicate the SO or type of application (SO mask value of zero indicates that this field is ignored) – 0x00 - DO_NOT_CARE CDMA 1X SO mask – 0x01 - CDMA_1X_IS95 – 0x02 - CDMA_1X_IS2000 – 0x04 - CDMA_1X_IS2000_REL_A CDMA EV-DO Rev A SO mask – 0x01 - EVDO_REVA_DPA – 0x02 - EVDO_REVA_MFPA – 0x04 - EVDO_REVA_EMPA – 0x08 - EVDO_REVA_EMPA_EHRPD – 0xffffffff - Invalid data.

8.434.2 Field Documentation

8.434.2.1 uint8_t qmiWDSDataBearerTechnology::currentNetwork

8.434.2.2 uint32_t qmiWDSDataBearerTechnology::ratMask

8.434.2.3 uint32_t qmiWDSDataBearerTechnology::soMask

8.435 qmuxIPTable Struct Reference

Data Fields

- uint8_t muxID
- uint32_t ipAddress
- ipv6_addr ipv6Address

8.435.1 Field Documentation

8.435.1.1 uint32_t qmuxIPTable::ipAddress

8.435.1.2 ipv6_addr qmuxIPTable::ipv6Address

8.435.1.3 uint8_t qmuxIPTable::muxID

8.436 qos_BindDataPortMuxID_t Struct Reference

Data Fields

- uint8_t MuxID

8.436.1 Detailed Description

Structure that contains the request Binds a control point to a data port Mux ID data.

Parameters

MuxID	Mux ID: • 0x80-0x8F : valid value

8.436.2 Field Documentation

8.436.2.1 uint8_t qos_BindDataPortMuxID_t::MuxID

8.437 qos_BindDataPortPeripheralEndPointID_t Struct Reference

Data Fields

- uint32_t EndPointType
- uint32_t IfaceID

8.437.1 Detailed Description

Structure that contains the request Binds a control point to a data port Periapheral End Point Type data.

Parameters

EndPointType	Peripheral end point type. Values: • 0 - Reserved • 1 - HSIC • 2 - HSUSB • 3 - PCIE • 4 - Embedded
IfaceID	Peripheral interface number.

8.437.2 Field Documentation

8.437.2.1 uint32_t qos_BindDataPortPeripheralEndPointID_t::EndPointType

8.437.2.2 uint32_t qos_BindDataPortPeripheralEndPointID_t::IfaceID

8.438 qos_BindDataPortSIODataPort_t Struct Reference

Data Fields

- uint16_t SIODataPort

8.438.1 Detailed Description

Structure that contains the request Binds a control point to a data port SIO Data Port data.

Parameters

u16SIODataPort	SIO Data Port to which the client binds

8.438.2 Field Documentation

8.438.2.1 uint16_t qos_BindDataPortSIODataPort_t::SIODataPort

8.439 RFBandInfoElements Struct Reference

Data Fields

- uint8_t radioInterface
- uint16_t activeBandClass
- uint16_t activeChannel

8.439.1 Detailed Description

This structure contains the RFBandInfo response parameters.

Parameters

radioInterface	• Radio interface technology – See Tables for Radio Interface

activeBandClass	• Active Band Class – See Tables for Band Classes
activeChannel	• Active channel (0 if channel is not relevant to the reported technology)

8.439.2 Field Documentation

8.439.2.1 uint16_t RFBandInfoElements::activeBandClass

8.439.2.2 uint16_t RFBandInfoElements::activeChannel

8.439.2.3 uint8_t RFBandInfoElements::radioInterface

8.440 rmTrasnferStaticsReq Struct Reference

Data Fields

- uint8_t bResetStatistics
- uint32_t ulMask

8.440.1 Detailed Description

RM Transfer Satistics Structure

Parameters

bResetStatistics	• Reset Statistics • Values: • 0 - Not Reset • Other - Reset
ulMask	• Enable/Disable RM Transfer Satatistics Indiscation Mask • Bit 0: Tx Packet Ok • Bit 1: Rx Packet Ok • Bit 2: Tx Bytes Ok • Bit 3: Rx Bytes Ok • Bit 4: Tx Packets Dropped • Bit 5: Rx Packets Dropped • Value: -0 - Disable -1 - Enable

8.440.2 Field Documentation

8.440.2.1 uint8_t rmTrasnferStaticsReq::bResetStatistics

8.440.2.2 uint32_t rmTrasnferStaticsReq::ulMask

8.441 sensorData_t Struct Reference

Data Fields

- uint32_t timeOfFirstSample
- uint8_t flags
- uint8_t sensorDataLen
- uint16_t timeOffset [64]
- uint32_t xAxis [64]
- uint32_t yAxis [64]
- uint32_t zAxis [64]

8.441.1 Detailed Description

This structure specifies information regarding the 3-Axis Sensor Data. Please check has_<Param_Name> field for presence of optional parameters

Parameters

timeOfFirst-Sample	• Denotes a full 32-bit time stamp of the first (oldest) sample in this message. • The time stamp is in the time reference scale that is used by the sensor time source. • Units - Milliseconds
flags	• Flags to indicate any deviation from the default measurement assumptions. • All unused bits in this field must be set to 0. • Valid bitmasks – 0x01 - Bitmask to specify that a sign reversal is required while interpreting the sensor data; only applies to the accelerometer samples – 0x02 - Bitmask to specify that the sensor time stamp is the same as the modem time stamp
sensorDataLen	• Number of sets of the following elements – timeOffset – xAxis – yAxis – zAxis
timeOffset	• Sample time offset • Units - Milliseconds
xAxis	• Sensor x-axis sample. • Units Accelerometer - Meters/seconds square • Units Gyroscope - Radians/second

yAxis	• Sensor Y-axis sample. • Units Accelerometer - Meters/seconds square • Units Gyroscope - Radians/second
xAxis	• Sensor Z-axis sample. • Units Accelerometer - Meters/seconds square • Units Gyroscope - Radians/second

8.441.2 Field Documentation

8.441.2.1 uint8_t sensorData_t::flags

8.441.2.2 uint8_t sensorData_t::sensorDataLen

8.441.2.3 uint32_t sensorData_t::timeOfFirstSample

8.441.2.4 uint16_t sensorData_t::timeOffset[64]

8.441.2.5 uint32_t sensorData_t::xAxis[64]

8.441.2.6 uint32_t sensorData_t::yAxis[64]

8.441.2.7 uint32_t sensorData_t::zAxis[64]

8.442 slot_t Struct Reference

Data Fields

- uint32_t uPhyCardStatus
- uint32_t uPhySlotStatus
- uint8_t bLogicalSlot
- uint8_t bICCIDLength
- uint8_t bICCID [255]

8.442.1 Detailed Description

This structure contains information of the response parameters associated with a Get Slots Status API.

Parameters

uPhyCardStatus	• State of the card in the Pyhsical Slot Status. – 0x00 - Unknown. – 0x01 - Absent. – 0x02 - Present.

uPhySlotStatus	• State of the Physical Slot status. – 0x00 Inactive. – 0x01 Activate.
bLogicalSlot	• Logical Slot associated with this physical slot. THis is valid if the physical slot is active. – 1 - Slot 1. – 2 - Slot 2. – 3 - Slot 3. – 4 - Slot 4. – 5 - Slot 5.
bLogicalSlot	• Number of sets the sets of ICCCID
bICCID[MAX_ICCID_LENGTH]	• Contains the ICCID of the card in the physical slot.

8.442.2 Field Documentation

8.442.2.1 uint8_t slot_t::bICCID[255]

8.442.2.2 uint8_t slot_t::bICCIDLength

8.442.2.3 uint8_t slot_t::bLogicalSlot

8.442.2.4 uint32_t slot_t::uPhyCardStatus

8.442.2.5 uint32_t slot_t::uPhySlotStatus

8.443 slotInf Struct Reference

Data Fields

- uint8_t cardState
- uint8_t upinState
- uint8_t upinRetries
- uint8_t upukRetries
- uint8_t errorState
- uint8_t numApp
- appStats AppStatus [10]

8.443.1 Detailed Description

This structure contains information about the SLOTS present.

Parameters

cardState	• Indicates the state of the card for each slot. – 0 - Absent – 1 - Present – 2 - Error
upinState	• Indicates the state of UPIN. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked – 0xFF - Not Available
upinRetries	• Indicates the number of retries remaining to verify the UPIN. • If 0xFF, information not available.
upukRetries	• Indicates the number of retries remaining to unblock the UPIN. • If 0xFF, information not available.
errorState	• Indicates the reason for the card error, and is valid only when the card state is Error – 0 - Unknown – 1 - Power down – 2 - Poll error – 3 - No ATR received – 4 - Volt mismatch – 5 - Parity error – 6 - Unknown; possibly removed – 7 - Card returned technical problems – 0xFF - Not Available • Other values are possible and reserved for future use. • When an unknown value is received, it is to be handled as "Unknown".
numApp	• Indicates the number of applications available on the card. • The following block is repeated for each application. i.e. AppStatus. • If zero(0) then no AppStatus information exists.
AppStatus[MAX_NO_OF_APPLICATIONS]	• See appStats for more information.

8.443.2 Field Documentation

8.443.2.1 appStats slotInf::AppStatus[10]

8.443.2.2 uint8_t slotInf::cardState

8.443.2.3 uint8_t slotInf::errorState

8.443.2.4 uint8_t slotInf::numApp

8.443.2.5 uint8_t slotInf::upinRetries

8.443.2.6 uint8_t slotInf::upinState

8.443.2.7 uint8_t slotInf::upukRetries

8.444 slots_t Struct Reference

Data Fields

- slot_t uimSlotStatus [255]

8.444.1 Detailed Description

This structure contains slots status.

Parameters

uimSlotStatus	• See slot_t

8.444.2 Field Documentation

8.444.2.1 slot_t slots_t::uimSlotStatus[255]

8.445 sms_BroadcastConfig Struct Reference

Data Fields

- uint16_t fromServiceId
- uint16_t toServiceId
- uint8_t selected

8.445.1 Detailed Description

This structure contains BroadcastConfig parameters

Parameters

fromServiceId	• Starting point of range of CBM message identifiers
toServiceId	• Ending point of range of CBM message identifiers

selected	• Range of CBM message identifiers indicated by from_service_id and to_service_id – 0x00 – Not selected – 0x01 – Selected

8.445.2 Field Documentation

8.445.2.1 uint16_t sms_BroadcastConfig::fromServiceId

8.445.2.2 uint8_t sms_BroadcastConfig::selected

8.445.2.3 uint16_t sms_BroadcastConfig::toServiceId

8.446 sms_CDMABroadcastConfig Struct Reference

Data Fields

- uint16_t serviceCategory
- uint16_t language
- uint8_t selected

8.446.1 Detailed Description

This structure contains CDMABroadcastConfig parameters

Parameters

serviceCategory	• Service category
language	• Language
selected	• Specified service_category and language – 0x00 – Not selected – 0x01 – Selected

8.446.2 Field Documentation

8.446.2.1 uint16_t sms_CDMABroadcastConfig::language

8.446.2.2 uint8_t sms_CDMABroadcastConfig::selected

8.446.2.3 uint16_t sms_CDMABroadcastConfig::serviceCategory

8.447 sms_getIndicationReg Struct Reference

Data Fields

- uint8_t * pRegTransLayerInfoEvt
- uint8_t * pRegTransNWRegInfoEvt
- uint8_t * pRegCallStatInfoEvt

8.447.1 Detailed Description

This structure contains Get Indication Register Response parameters

Parameters

pRegTransLayerInfoEvt	- • Optional parameter indicating registration status of transport layer information events • Values: – 0x00 - Disabled – 0x01 - Enabled • returns a default value 0xFF if this parameter is allocated memory in the structure and no response is received from the device.
pRegTransNWRegInfoEvt	- • Optional parameter indicating registration status of transport network registration information events • Values: – 0x00 - Disabled – 0x01 - Enabled • returns a default value 0xFF if this parameter is allocated memory in the structure and no response is received from the device.
pRegCallStatInfoEvt	- • Optional parameter indicating registration status of call status information events • Values: – 0x00 - Disabled – 0x01 - Enabled • returns a default value 0xFF if this parameter is allocated memory in the structure and no response is received from the device.

8.447.2 Field Documentation

8.447.2.1 uint8_t* sms_getIndicationReg::pRegCallStatInfoEvt

8.447.2.2 uint8_t* sms_getIndicationReg::pRegTransLayerInfoEvt

8.447.2.3 uint8_t* sms_getIndicationReg::pRegTransNWRegInfoEvt

8.448 sms_getMsgWaitingInfo Struct Reference

Data Fields

- uint8_t numInstances
- sms_messageWaitingInfoContent msgWaitInfo [0xFF]

8.448.1 Detailed Description

This structure contains Get Message Waiting Info Response parameters

Parameters

numInstances	• Number of sets of the elements in structure sms_messageWaitingInfoContent
pMsgWaitInfo	• Pointer to structure of sms_messageWaitingInfoContent. – See sms_messageWaitingInfoContent for more information.

8.448.2 Field Documentation

8.448.2.1 sms_messageWaitingInfoContent sms_getMsgWaitingInfo::msgWaitInfo[0xFF]

8.448.2.2 uint8_t sms_getMsgWaitingInfo::numInstances

8.449 sms_getTransLayerInfo Struct Reference

Data Fields

- uint8_t * pRegInd
- sms_transLayerInfo * pTransLayerInfo

8.449.1 Detailed Description

This structure contains Get Transport Layer Info Response parameters

Parameters

pRegInd	- • Optional parameter indicating if transport layer is registered • Values: – 0x00 - Transport layer is not registered – 0x01 - Transport layer is registered • returns a default value 0xFF if no response is received from the device. • NULL pointer - Invalid data.
pTransLayerInfo	• Pointer to structure of sms_transLayerInfo. – Optional parameter – See sms_transLayerInfo for more information • returns a default value 0xFF for parameter values if no response is received from the device. • NULL pointer - Invalid data.

8.449.2 Field Documentation

8.449.2.1 uint8_t* sms_getTransLayerInfo::pRegInd

8.449.2.2 sms_transLayerInfo* sms_getTransLayerInfo::pTransLayerInfo

8.450 sms_getTransNWRegInfo Struct Reference

Data Fields

- uint8_t * pRegStatus

8.450.1 Detailed Description

This structure contains transport network registration info parameter

Parameters

pRegStatus	- • Optional parameter indicating transport layer network registration status • Values: – 0x00 - No service – 0x01 - In progress – 0x02 - Failed – 0x03 - Limited Service – 0x04 - Full Service • returns a default value 0xFF if no response is received from the device.

8.450.2 Field Documentation

8.450.2.1 uint8_t* sms_getTransNWRegInfo::pRegStatus

8.451 sms_maxStorageSizeReq Struct Reference

Data Fields

- uint8_t storageType
- uint8_t * pMessageMode

8.451.1 Detailed Description

This structure contains get store max size request parameters

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
pMessage-Mode(optional	parameter) • 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS)

Note

The Message Mode TLV must be included if the device is capable of supporting more than one protocol

8.451.2 Field Documentation

8.451.2.1 uint8_t* sms_maxStorageSizeReq::pMessageMode

8.451.2.2 uint8_t sms_maxStorageSizeReq::storageType

8.452 sms_maxStorageSizeResp Struct Reference

Data Fields

- uint32_t maxStorageSize
- uint32_t freeSlots

8.452.1 Detailed Description

This structure contains get store max size response parameters

Parameters

maxStorageSize	- Memory Store Size
freeSlots	- Optional parameter indicating how much Memory is available - returns a default value 0xFFFFFFFF for parameter values if no response is received from the device.

8.452.2 Field Documentation

8.452.2.1 uint32_t sms_maxStorageSizeResp::freeSlots

8.452.2.2 uint32_t sms_maxStorageSizeResp::maxStorageSize

8.453 sms_messageWaitingInfoContent Struct Reference

Data Fields

- uint8_t msgType
- uint8_t activeInd
- uint8_t msgCount

8.453.1 Detailed Description

This structure contains message waiting information per instance

Parameters

msgType	• Message type – 0x00 - MWI_MESSAGE_TYPE_VOICMAIL - Voicemail – 0x01 - MWI_MESSAGE_TYPE_FAX - Fax – 0X02 - MWI_MESSAGE_TYPE_EMAIL - Email – 0x03 - MWI_MESSAGE_TYPE_OTHER - Other – 0x04 - MWI_MESSAGE_TYPE_VIDEOMAIL - Videomail
activeInd	• Indicates whether the indication is active – 0x00 - Inactive – 0x01 - Active
msgCount	• Number of messages

8.453.2 Field Documentation

8.453.2.1 uint8_t sms_messageWaitingInfoContent::activeInd

8.453.2.2 uint8_t sms_messageWaitingInfoContent::msgCount

8.453.2.3 uint8_t sms_messageWaitingInfoContent::msgType

8.454 sms_msgProtocolResp Struct Reference

Data Fields

- uint8_t msgProtocol

8.454.1 Detailed Description

This structure contains get message protocol response parameters

Parameters

msgProtocol	- • Message Protocol • Values: – 0x00 - MESSAGE_PROTOCOL_CDMA – 0x01 - MESSAGE_PROTOCOL_WCDMA

8.454.2 Field Documentation

8.454.2.1 uint8_t sms_msgProtocolResp::msgProtocol

8.455 sms_qaQmi3GPP2BroadcastCfgInfo Struct Reference

Data Fields

- uint8_t activated_ind
- uint16_t num_instances
- sms_CDMABroadcastConfig CDMABroadcastConfig [0x05]

8.455.1 Detailed Description

This structure contains the 3GPP2 Broadcast Configuration Information parameters

Parameters

activated_ind	• Broadcast SMS – 0x00 - Deactivated – 0x01 - Activated
num_instances	• Number of sets (N) of parameters Following each set describes one entry in the broadcast configuration table. – serviceCategory – language – selected
broadcastConfig	• A CDMABroadcastConfig structure array. • Further defined by the structure sms_CDMABroadcastConfig

8.455.2 Field Documentation

8.455.2.1 uint8_t sms_qaQmi3GPP2BroadcastCfgInfo::activated_ind

8.455.2.2 sms_CDMABroadcastConfig sms_qaQmi3GPP2BroadcastCfgInfo::CDMABroadcastConfig[0x05]

8.455.2.3 uint16_t sms_qaQmi3GPP2BroadcastCfgInfo::num_instances

8.456 sms_qaQmi3GPPBroadcastCfgInfo Struct Reference

Data Fields

- uint8_t activated_ind
- uint16_t num_instances
- sms_BroadcastConfig broadcastConfig [0x05]

8.456.1 Detailed Description

This structure contains the 3GPP Broadcast Configuration Information parameters

Parameters

activated_ind	• Broadcast SMS – 0x00 - Deactivated – 0x01 - Activated
num_instances	• Number of sets (N) of parameters Following each set describes one entry in the broadcast configuration table. – fromServiceId – toServiceId – selected
broadcastConfig	• A BroadcastConfig structure array. • Further defined by the structure sms_BroadcastConfig

8.456.2 Field Documentation

8.456.2.1 uint8_t sms_qaQmi3GPPBroadcastCfgInfo::activated_ind

8.456.2.2 sms_BroadcastConfig sms_qaQmi3GPPBroadcastCfgInfo::broadcastConfig[0x05]

8.456.2.3 uint16_t sms_qaQmi3GPPBroadcastCfgInfo::num_instances

8.457 sms_routeEntry Struct Reference

Data Fields

- uint8_t messageType
- uint8_t messageClass
- uint8_t routeStorage
- uint8_t receiptAction

8.457.1 Detailed Description

This structure contains SMS route entry details

Parameters

messageType	- • Message type matching this route • Values: – 0x00 - MESSAGE_TYPE_POINT_TO_POINT
messageClass	- • Message Class • Values: – 0x00 - MESSAGE_CLASS_0 – 0x01 - MESSAGE_CLASS_1 – 0x02 - MESSAGE_CLASS_2 – 0x03 - MESSAGE_CLASS_3 – 0x04 - MESSAGE_CLASS_NONE – 0x05 - MESSAGE_CLASS_CDMA
routeStorage	- • If the receiptAction is store where to store the message • Values: – 0x00 - STORAGE_TYPE_UIM – 0x01 - STORAGE_TYPE_NV – 0xFF - STORAGE_TYPE_NONE
receiptAction	- • Action to be taken on receipt of a message matching the specified type and class for this route • Values: – 0x00 - DISCARD (discarded without notification) – 0x01 - STORE AND NOTIFY (stored and notified to the registered clients) – 0x02 - TRANSFER ONLY (transferred to the client, client expected to send the ACK) – 0x03 - TRANSFER AND ACK (transferred to the client, device expected to send the ACK)

8.457.2 Field Documentation

8.457.2.1 uint8_t sms_routeEntry::messageClass

8.457.2.2 uint8_t sms_routeEntry::messageType

8.457.2.3 uint8_t sms_routeEntry::receiptAction

8.457.2.4 uint8_t sms_routeEntry::routeStorage

8.458 sms_sendAsyncsmsParams Struct Reference

Data Fields

- uint32_t messageFormat
- uint32_t messageSize
- uint8_t * pMessage
- uint8_t * pForceOnDC
- uint8_t * pServiceOption
- uint8_t * pFollowOnDC

- uint8_t * pLinktimer
- uint8_t * pSmsOnIms
- uint8_t * pRetryMessage
- uint32_t * pRetryMessageId
- uint32_t * pUserData

8.458.1 Detailed Description

This structure contains SMS parameters

Parameters

messageFormat	• Message format • Values: – 0 - CDMA (IS-637B) – 1 - 5 (Reserved) – 6 - GSM/WCDMA PP
messageSize	• The length of the message contents in bytes
pMessage	• The message contents
pForceOnDC	• Force the message to be sent on the CDMA dedicated channel. • Values: – 0x00 - Do not care about the channel on which the message is sent – 0x01 - Request to send the message over the dedicated channel
pServiceOption	• Service option: • Values: – 0x00 - SO_AUTO - AUTO (choose the best service option) – 0x06 - SO_6 - Service option 6 – 0x0E - SO_14 - Service option 14
pFollowOnDC	• Flag to request not to disconnect the CDMA dedicated channel after the send operation is complete. • This TLV can be included if more messages are expected to follow. • Values: – 0x01 - FOLLOW_ON_DC_ON - On (don't disconnect after send operation) Any value other than 0x01 is treated as an absence of this TLV.
pLinktimer	• Keeps the GW SMS link open for the specified number of seconds; can be enabled if more messages are expected to follow

pSmsOnIms	• Indicates whether the message is to be sent on IMS. • Values: – 0x00 - Message is not to be sent on IMS – 0x01 - Message is to be sent on IMS – 0x02 to 0xFF - Reserved
pRetryMessage	• Indicates this message is a retry message. • Values: – 0x01 - WMS_MESSAGE_IS_A_RETRY - Message is a retry message Note: Any value other than 0x01 in this field is treated as an absence of this TLV.
pRetryMessage-Id	• Message ID to be used in the retry message. • The message ID specified here is used instead of the messsage ID encoded in the raw message.
pUserData	• Enables the control point to associate the request with the corresponding indication. • The control point might send numerous requests. • This TLV will help the control point to identify the request for which the received indication belongs.

8.458.2 Field Documentation

8.458.2.1 uint32_t sms_sendAsyncsmsParams::messageFormat

8.458.2.2 uint32_t sms_sendAsyncsmsParams::messageSize

8.458.2.3 uint8_t* sms_sendAsyncsmsParams::pFollowOnDC

8.458.2.4 uint8_t* sms_sendAsyncsmsParams::pForceOnDC

8.458.2.5 uint8_t* sms_sendAsyncsmsParams::pLinktimer

8.458.2.6 uint8_t* sms_sendAsyncsmsParams::pMessage

8.458.2.7 uint8_t* sms_sendAsyncsmsParams::pRetryMessage

8.458.2.8 uint32_t* sms_sendAsyncsmsParams::pRetryMessageId

8.458.2.9 uint8_t* sms_sendAsyncsmsParams::pServiceOption

8.458.2.10 uint8_t* sms_sendAsyncsmsParams::pSmsOnIms

8.458.2.11 uint32_t* sms_sendAsyncsmsParams::pUserData

8.459 sms_setIndicationReg Struct Reference

Data Fields

- uint8_t * pRegTransLayerInfoEvt
- uint8_t * pRegTransNWRegInfoEvt
- uint8_t * pRegCallStatInfoEvt

8.459.1 Detailed Description

This structure contains Indication Register request parameters

Parameters

pRegTransLayerInfoEvt	- • Optional parameter indicating registration status of transport layer information events • Values: – 0x00 - Disabled – 0x01 - Enabled – NULL - No change - specifying NULL indicates that the device will continue to use the existing setting (disable/enable) which has been previously set for the device
pRegTransNWRegInfoEvt	- • Optional parameter indicating registration status of transport network registration information events • Values: – 0x00 - Disabled – 0x01 - Enabled – NULL - No change - specifying NULL indicates that the device will continue to use the existing setting (disable/enable) which has been previously set for the device
pRegCallStatInfoEvt	- • Optional parameter indicating registration status of call status information events • Values: – 0x00 - Disabled – 0x01 - Enabled – NULL - No change - specifying NULL indicates that the device will continue to use the existing setting (disable/enable) which has been previously set for the device

8.459.2 Field Documentation

8.459.2.1 uint8_t* sms_setIndicationReg::pRegCallStatInfoEvt

8.459.2.2 uint8_t* sms_setIndicationReg::pRegTransLayerInfoEvt

8.459.2.3 uint8_t* sms_setIndicationReg::pRegTransNWRegInfoEvt

8.460 sms_setRoutesReq Struct Reference

Data Fields

- uint16_t numOfRoutes
- sms_routeEntry routeList [0x0A]
- uint8_t * pTransferStatusReport

8.460.1 Detailed Description

This structure contains SMS route request parameters

Parameters

numOfRoutes	- • Number of sets of the following element
routeList	- • Array containing the set of sms_routeEntry
pTransferStatus-Report	- • 0x01 - Status report are transferred to the client (optional)

8.460.2 Field Documentation

8.460.2.1 uint16_t sms_setRoutesReq::numOfRoutes

8.460.2.2 uint8_t* sms_setRoutesReq::pTransferStatusReport

8.460.2.3 sms_routeEntry sms_setRoutesReq::routeList[0x0A]

8.461 sms_transLayerInfo Struct Reference

Data Fields

- uint8_t TransType
- uint8_t TransCap

8.461.1 Detailed Description

This structure contains Transport Layer Information

Parameters

TransType	• Transport Type – 0x00 - IMS
TransCap	• Transport Capability • Values: – 0x00 - CDMA – 0x01 - GW

8.461.2 Field Documentation

8.461.2.1 uint8_t sms_transLayerInfo::TransCap

8.461.2.2 uint8_t sms_transLayerInfo::TransType

8.462 sMSCAddressInfo Struct Reference

Data Fields

- uint8_t length
- uint8_t data [256]

8.462.1 Detailed Description

This structure contains SMSC information

Parameters

length	• Number of sets of following element
data	• SMSC address

8.462.2 Field Documentation

8.462.2.1 uint8_t sMSCAddressInfo::data[256]

8.462.2.2 uint8_t sMSCAddressInfo::length

8.463 sMSCAddressTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSCAddressInfo SMSCInfo

8.463.1 Detailed Description

This structure contains SMSC TLV information

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
SMSCInfo	• SMSC Address • See sMSCAddressInfo for more information

8.463.2 Field Documentation

8.463.2.1 sMSCAddressInfo sMSCAddressTlv::SMSCInfo

8.463.2.2 uint8_t sMSCAddressTlv::TlvPresent

8.464 sMSEtwsMessageInfo Struct Reference

Data Fields

- uint8_t notificationType
- uint16_t length
- uint8_t data [1254]

8.464.1 Detailed Description

This structure contains ETWS information

Parameters

notificationType	• Message mode 0x00 - Primary 0x01 - Secondary GSM 0x02 - Secondary UMTS
length	• Number of sets of following elements
data	• Raw message data

8.464.2 Field Documentation

8.464.2.1 uint8_t sMSEtwsMessageInfo::data[1254]

8.464.2.2 uint16_t sMSEtwsMessageInfo::length

8.464.2.3 uint8_t sMSEtwsMessageInfo::notificationType

8.465 sMSEtwsMessageTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSEtwsMessageInfo EtwsMessageInfo

8.465.1 Detailed Description

This structure contains ETWS TLV information

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
EtwsMessage-Info	• ETWS Message • See sMSEtwsMessageInfo for more information

8.465.2 Field Documentation

8.465.2.1 sMSEtwsMessageInfo sMSEtwsMessageTlv::EtwsMessageInfo

8.465.2.2 uint8_t sMSEtwsMessageTlv::TlvPresent

8.466 sMSEtwsPlmnInfo Struct Reference

Data Fields

- uint16_t mobileCountryCode
- uint16_t mobileNetworkCode

8.466.1 Detailed Description

This structure contains ETWS PLMN information

Parameters

mobileCountry-Code	• 16 bit representation of MCC value range : 0 -999
mobileNetwork-Code	• 16 bit representation of MNC value range : 0 -999

8.466.2 Field Documentation

8.466.2.1 uint16_t sMSEtwsPlmnInfo::mobileCountryCode

8.466.2.2 uint16_t sMSEtwsPlmnInfo::mobileNetworkCode

8.467 sMSMessageModeInfo Struct Reference

Data Fields

- uint8_t messageMode

8.467.1 Detailed Description

This structure contains message mode information.

Parameters

messageMode	Message Mode

8.467.2 Field Documentation

8.467.2.1 uint8_t sMSMessageModeInfo::messageMode

8.468 sMSMTMessageInfo Struct Reference

Data Fields

- uint32_t storageType
- uint32_t messageIndex

8.468.1 Detailed Description

This structure contains MT message information.

Parameters

storageType	memory storage 0x00-UIM 0x01-NV
messageIndex	MT Message index

8.468.2 Field Documentation

8.468.2.1 uint32_t sMSMTMessageInfo::messageIndex

8.468.2.2 uint32_t sMSMTMessageInfo::storageType

8.469 sMSOnIMSInfo Struct Reference

Data Fields

- uint8_t smsOnIMS

8.469.1 Detailed Description

This structure contains SMS on IMS information

Parameters

smsOnIMS	SMS on IMS

8.469.2 Field Documentation

8.469.2.1 uint8_t sMSOnIMSInfo::smsOnIMS

8.470 sMSOnIMSTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSOnIMSInfo IMSInfo

8.470.1 Detailed Description

This structure contains SMS on IMS TLV information.

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
IMSInfo	• SMS on IMS • See sMSOnIMSInfo for more information

8.470.2 Field Documentation

8.470.2.1 sMSOnIMSInfo sMSOnIMSTlv::IMSInfo

8.470.2.2 uint8_t sMSOnIMSTlv::TlvPresent

8.471 sMSTransferRouteMTMessageInfo Struct Reference

Data Fields

- uint8_t ackIndicator
- uint32_t transactionID
- uint8_t format
- uint16_t length
- uint8_t data [256]

8.471.1 Detailed Description

This structure contains Transfer route MT message information.

Parameters

ackIndicator	• Parameter to indicate if ACK must be sent by the control point 0x00 - Send ACK 0x01 - Do not send ACK
transactionID	• Transaction ID of the message
format	• Message format 0x00 - CDMA 0x02 - 0x05 - Reserved 0x06 - GW_PP 0x07 - GW_BC
length	• Length of the raw message. This length should not exceed the maximum WMS payload length of 256 bytes
data	• Raw message data

8.471.2 Field Documentation

8.471.2.1 uint8_t sMSTransferRouteMTMessageInfo::ackIndicator

8.471.2.2 uint8_t sMSTransferRouteMTMessageInfo::data[256]

8.471.2.3 uint8_t sMSTransferRouteMTMessageInfo::format

8.471.2.4 uint16_t sMSTransferRouteMTMessageInfo::length

8.471.2.5 uint32_t sMSTransferRouteMTMessageInfo::transactionID

8.472 swiaudio_PCMparams Struct Reference

Data Fields

- uint8_t iFaceTabLen
- uint8_t iFaceTab [255]

8.472.1 Detailed Description

This structure contains the PCM parameters.

Parameters

iFaceTabLen	• Number of sets of iface table
iFaceTab	• Physical Interface Parameters • See qaGobiApiTableSwiAudio.h for more information on physical interface parameters

8.472.2 Field Documentation

8.472.2.1 uint8_t swiaudio_PCMparams::iFaceTab[255]

8.472.2.2 uint8_t swiaudio_PCMparams::iFaceTabLen

8.473 tdscdmaSigInfoExt Struct Reference

Data Fields

- float rssi
- float rscp
- float ecio
- float sinr

8.473.1 Detailed Description

This structure contains the TDSCDMA Signal Strength Info Extended

Parameters

rssi	• Measured RSSI in dB

rscp[Optional]	• Measured RSCP in dBm
ecio[Optional]	• Measured ECIO in dBm.
sinr[Optional]	• Measured SINR in dB. -15 dB is sent to clients if the actual SINR is less than -15 dB

8.473.2 Field Documentation

8.473.2.1 float tdscdmaSigInfoExt::ecio

8.473.2.2 float tdscdmaSigInfoExt::rscp

8.473.2.3 float tdscdmaSigInfoExt::rssi

8.473.2.4 float tdscdmaSigInfoExt::sinr

8.474 tempData_t Struct Reference

Data Fields

- uint32_t timeSource
- uint32_t timeOfFirstSample
- uint8_t temperatureDataLen
- uint16_t timeOffset [64]
- uint32_t temperature [64]

8.474.1 Detailed Description

This structure specifies information regarding the Temperature Data. Please check has_<Param_Name> field for presence of optional parameters

Parameters

timeSource	• Time source of the sensor data • Valid values – 0 - Sensor time source is unspecified – 1 - Time source is common between the sensors and the location engine
timeOfFirst-Sample	• Denotes a full 32-bit time stamp of the first (oldest) sample in this message. • The time stamp is in the time reference scale that is used by the sensor time source. • Units - Milliseconds
temperature-DataLen	• Number of sets of the following elements – timeOffset – temperature

timeOffset	• Sample time offset • Units - Milliseconds
temperature	• Sensor temperature. • Type - Floating point • Units - Degrees Celsius • Range -50 to +100.00

8.474.2 Field Documentation

8.474.2.1 uint32_t tempData_t::temperature[64]

8.474.2.2 uint8_t tempData_t::temperatureDataLen

8.474.2.3 uint32_t tempData_t::timeOfFirstSample

8.474.2.4 uint16_t tempData_t::timeOffset[64]

8.474.2.5 uint32_t tempData_t::timeSource

8.475 tmd_mitigationDevList Struct Reference

Data Fields

- uint8_t mitigationDevIdLen
- char mitigationDevId [255]
- uint8_t maxMitigationLevel

8.475.1 Detailed Description

This structure contains mitigation devices list

Parameters

mitigationDevId-Len	• Number of sets of the following elements – mitigation_dev_id
mitigationDevId	• Mitigation device ID.
maxMitigation-Level	• Maximum valid mitigation level. • Valid range - 0 to max_mitigation_level.

8.475.2 Field Documentation

8.475.2.1 uint8_t tmd_mitigationDevList::maxMitigationLevel

8.475.2.2 char tmd_mitigationDevList::mitigationDevId[255]

8.475.2.3 uint8_t tmd_mitigationDevList::mitigationDevIdLen

8.476 transferRouteMessageTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSTransferRouteMTMessageInfo TransferRouteMTMessageInfo

8.476.1 Detailed Description

This structure contains Transfer route MT message TLV information.

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
TransferRouteMTMessageInfo	• Transfer Route MT Message • See sMSTransferRouteMTMessageInfo for more information

8.476.2 Field Documentation

8.476.2.1 uint8_t transferRouteMessageTlv::TlvPresent

8.476.2.2 sMSTransferRouteMTMessageInfo transferRouteMessageTlv::TransferRouteMTMessageInfo

8.477 uim_appStatus Struct Reference

Data Fields

- uint8_t appType
- uint8_t appState
- uint8_t persoState
- uint8_t persoFeature
- uint8_t persoRetries
- uint8_t persoUnblockRetries
- uint8_t aidLength
- uint8_t aidVal [255]
- uint8_t univPin
- uint8_t pin1State
- uint8_t pin1Retries
- uint8_t puk1Retries
- uint8_t pin2State
- uint8_t pin2Retries
- uint8_t puk2Retries

8.477.1 Detailed Description

This structure contains Application Status Information loaded on the card.

Parameters

appType	• Indicates the type of the application. – 0 - Unknown – 1 - SIM card – 2 - USIM application – 3 - RUIM card – 4 - CSIM application – 5 - ISIM application • Other values are reserved for the future and are to be handled as "Unknown".
appState	• Indicates the state of the application. – 0 - Unknown – 1 - Detected – 2 - PIN1 or UPIN is required – 3 - PUK1 or PUK for UPIN is required – 4 - Personalization state must be checked – 5 - PIN1 is blocked – 6 - Illegal – 7 - Ready
persoState	• Indicates the state of the personalization for the application. – 0 - Unknown – 1 - Personalization operation is in progress – 2 - Ready – 3 - Personalization code is required – 4 - PUK for personalization code is required – 5 - Permanently blocked
persoFeature	• Indicates the personalization feature. • This applies only when a personalization code is required to deactivate or unblock personalization. – 0 - GW network personalization – 1 - GW network subset personalization – 2 - GW service provider personalization – 3 - GW corporate personalization – 4 - GW UIM personalization – 5 - 1X network type 1 personalization – 6 - 1X network type 2 personalization – 7 - 1X HRPD personalization – 8 - 1X service provider personalization – 9 - 1X corporate personalization – 10 - 1X RUIM personalization – 11 - Unknown

persoRetries	• Indicates the number of retries remaining to disable the personalization.
persoUnblock-Retries	• Indicates the number of retries remaining to unblock the personalization.
aidLength	• Number of sets of the following elements. i.e. aidVal • If zero(0) then no aidVal information exists.
aidVal[MAX_DE-SCRIPTION_LE-NGTH]	• Application identifier value.
univPin	• Indicates whether UPIN replaces PIN1. – 0 - PIN1 is used – 1 - UPIN replaces PIN1
pin1State	• Indicates the state of PIN1. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked
pin1Retries	• Indicates the number of retries remaining to verify PIN1.
puk1Retries	• Indicates the number of retries remaining to unblock PIN1.
pin2State	• Indicates the state of PIN2. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked
pin2Retries	• Indicates the number of retries remaining to verify PIN2.
puk2Retries	• Indicates the number of retries remaining to unblock PIN2.

8.477.2 Field Documentation

8.477.2.1 uint8_t uim_appStatus::aidLength

8.477.2.2 uint8_t uim_appStatus::aidVal[255]

8.477.2.3 uint8_t uim_appStatus::appState

8.477.2.4 uint8_t uim_appStatus::appType

8.477.2.5 uint8_t uim_appStatus::persoFeature

8.477.2.6 uint8_t uim_appStatus::persoRetries

8.477.2.7 uint8_t uim_appStatus::persoState

8.477.2.8 uint8_t uim_appStatus::persoUnblockRetries

8.477.2.9 uint8_t uim_appStatus::pin1Retries

8.477.2.10 uint8_t uim_appStatus::pin1State

8.477.2.11 uint8_t uim_appStatus::pin2Retries

8.477.2.12 uint8_t uim_appStatus::pin2State

8.477.2.13 uint8_t uim_appStatus::puk1Retries

8.477.2.14 uint8_t uim_appStatus::puk2Retries

8.477.2.15 uint8_t uim_appStatus::univPin

8.478 uim_authenticateResult Struct Reference

Data Fields

- uint16_t contentLen
- uint8_t content [1024]

8.478.1 Detailed Description

This structure contains the information about the authenticate result.

Parameters

contentLen	• Length of the following elements i.e. content.
content[UIM_MAX_CONTENT_LENGTH]	• Authenticate data. • This value is a sequence of bytes returned from the card.

8.478.2 Field Documentation

8.478.2.1 uint8_t uim_authenticateResult::content[1024]

8.478.2.2 uint16_t uim_authenticateResult::contentLen

8.479 uim_authenticationData Struct Reference

Data Fields

- uint8_t context
- uint16_t dataLen
- uint8_t data [1024]

8.479.1 Detailed Description

This structure contains the Session Information.

Parameters

context	• Authenticate context. – 0 - Runs the GSM algorithm (valid only on a 2GSIM card) – 1 - Runs the CAVE algorithm (valid only on a RUIM card) – 2 - GSM security context (valid only on a USIM application) – 3 - 3G security context (valid only on a USIM application) – 4 - VGCS/VBS security context (valid only on aUSIM application) – 5 - GBA security context, Bootstrapping mode (valid only on a USIM or ISIM application) – 6 - GBA security context, NAF Derivation mode (valid only on a USIM or ISIM application) – 7 - MBMS security context, MSK Update mode (valid only on a USIM application) – 8 - MBMS security context, MTK Generation mode (valid only on a USIM application) – 9 - MBMS security context, MSK Deletion mode (valid only on a USIM application) – 10 - MBMS security context, MUK Deletion mode (valid only on a USIM application) – 11 - IMS AKA security context (valid only on aISIM application) – 12 - HTTP-digest security context (valid only onan ISIM application) – 13 - Compute IP authentication, CHAP (valid onlyon RUIM or CSIM) – 14 - Compute IP authentication, MN-HA authenticator (valid only on RUIM or CSIM) – 15 - Compute IP authentication, MIP-RRQ hash (valid only on RUIM or CSIM) – 16 - Compute IP authentication, MN-AAA authenticator (valid only on RUIM or CSIM) – 17 - Compute IP authentication, HRPD access authenticator (valid only on RUIM or CSIM) • Other values are possible and reserved for future use.
dataLen	• Length of the following elements i.e. data.
data[UIM_MAX-_DESCRIPTIO-N_LENGTH]	• Authenticate Data.

8.479.2 Field Documentation

8.479.2.1 uint8_t uim_authenticationData::context

8.479.2.2 uint8_t uim_authenticationData::data[1024]

8.479.2.3 uint16_t uim_authenticationData::dataLen

8.480 uim_cardResult Struct Reference

Data Fields

- uint8_t sw1
- uint8_t sw2

8.480.1 Detailed Description

This structure contains the information about the card result.

Parameters

sw1	• SW1 received from the card.
sw2	• SW2 received from the card.

8.480.2 Field Documentation

8.480.2.1 uint8_t uim_cardResult::sw1

8.480.2.2 uint8_t uim_cardResult::sw2

8.481 uim_cardStatus Struct Reference

Data Fields

- uint16_t indexGwPri
- uint16_t index1xPri
- uint16_t indexGwSec
- uint16_t index1xSec
- uint8_t numSlot
- uim_slotInfo SlotInfo [5]

8.481.1 Detailed Description

This structure contains Card Status Information.

Parameters

indexGwPri	• Index of the primary GW provisioning application. • The most significant byte indicates the slot (starting from 0), while the least significant byte indicates the application for that slot (starting from 0). • The value 0xFFFF identifies when the session does not exist.

index1xPri	• Index of the primary 1X provisioning application. • The most significant byte indicates the slot (starting from 0), while the least significant byte indicates the application for that slot (starting from 0). • The value 0xFFFF identifies when the session does not exist.
indexGwSec	• Index of the secondary GW provisioning application. • The most significant byte indicates the slot (starting from 0), while the least significant byte indicates the application for that slot (starting from 0). • The value 0xFFFF identifies when the session does not exist.
index1xSec	• Index of the secondary GW provisioning application. • The most significant byte indicates the slot (starting from 0), while the least significant byte indicates the application for that slot (starting from 0). • The value 0xFFFF identifies when the session does not exist.
numSlot	• Indicates the number of slots available on the device. • The following block is repeated for each slot. i.e. cardState • If zero(0) then no cardState information exists.
SlotInfo	• See uim_slotInfo for more information.

8.481.2 Field Documentation

8.481.2.1 uint16_t uim_cardStatus::index1xPri

8.481.2.2 uint16_t uim_cardStatus::index1xSec

8.481.2.3 uint16_t uim_cardStatus::indexGwPri

8.481.2.4 uint16_t uim_cardStatus::indexGwSec

8.481.2.5 uint8_t uim_cardStatus::numSlot

8.481.2.6 uim_slotInfo uim_cardStatus::SlotInfo[5]

8.482 uim_changeUIMPIN Struct Reference

Data Fields

- uint8_t pinID
- uint8_t oldPINLen
- uint8_t oldPINVal [255]
- uint8_t pinLen
- uint8_t pinVal [255]

8.482.1 Detailed Description

This structure contains the information about the pin parameters that need to be verified.

Parameters

pinID	• Indicates the PIN ID to be changed. – 1 - PIN1 (also called PIN) – 2 - PIN2 – 3 - Universal PIN – 4 - Hidden key
oldPINLen	• Length of the following elements i.e. old pin value.
oldPINVal[MAX_DESCRIPTION_LENGTH]	• Old PIN value. • This value is a sequence of ASCII characters.
pinLen	• Length of the following elements i.e. new pin value.
pinVal[MAX_DESCRIPTION_LENGTH]	• New PIN value. • This value is a sequence of ASCII characters.

8.482.2 Field Documentation

8.482.2.1 uint8_t uim_changeUIMPIN::oldPINLen

8.482.2.2 uint8_t uim_changeUIMPIN::oldPINVal[255]

8.482.2.3 uint8_t uim_changeUIMPIN::pinID

8.482.2.4 uint8_t uim_changeUIMPIN::pinLen

8.482.2.5 uint8_t uim_changeUIMPIN::pinVal[255]

8.483 uim_depersonalizationInformation Struct Reference

Data Fields

- uint8_t feature
- uint8_t operation
- uint8_t ckLen
- uint8_t ckVal [255]

8.483.1 Detailed Description

This structure contains the Depersonalization Information.

Parameters

feature	• Indicates the personalization feature to de-activate or unblock. – 0 - GW network personalization – 1 - GW network subset personalization – 2 - GW service provider personalization – 3 - GW corporate personalization – 4 - GW UIM personalization – 5 - 1X network type 1 personalization – 6 - 1X network type 2 personalization – 7 - 1X HRPD personalization – 8 - 1X service provider personalization – 9 - 1X corporate personalization – 10 - 1X RUIM personalization
operation	• Indicates the operation to perform. – 0 - Deactivate personalization. – 1 - Unblock personalization.
ckLen	• Length of the following elements i.e. control key value.
ckVal[MAX_DESCRIPTION_LENGTH]	• Control key value. • This value is a sequence of ASCII characters.

8.483.2 Field Documentation

8.483.2.1 uint8_t uim_depersonalizationInformation::ckLen

8.483.2.2 uint8_t uim_depersonalizationInformation::ckVal[255]

8.483.2.3 uint8_t uim_depersonalizationInformation::feature

8.483.2.4 uint8_t uim_depersonalizationInformation::operation

8.484 uim_encryptedPIN1 Struct Reference

Data Fields

- uint8_t pin1Len
- uint8_t pin1Val [255]

8.484.1 Detailed Description

This structure contains the encrypted PIN1 Information.

Parameters

pin1Len	• Number of sets of the following elements ie encrypted PIN1 value. • If zero(0), no information follows.
pin1Val	• Encrypted PIN1 value.

Note

This value is returned only when PIN1 is enabled successfully and the feature is supported.

8.484.2 Field Documentation

8.484.2.1 uint8_t uim_encryptedPIN1::pin1Len

8.484.2.2 uint8_t uim_encryptedPIN1::pin1Val[255]

8.485 uim_fileAttributes Struct Reference

Data Fields

- uint16_t fileSize
- uint16_t fileID
- uint8_t fileType
- uint16_t recordSize
- uint16_t recordCount
- uint8_t secRead
- uint16_t secReadMask
- uint8_t secWrite
- uint16_t secWriteMask
- uint8_t secIncrease
- uint16_t secIncreaseMask
- uint8_t secDeactivate
- uint16_t secDeactivateMask
- uint8_t secActivate
- uint16_t secActivateMask
- uint16_t rawLen
- uint8_t rawValue [255]

8.485.1 Detailed Description

This structure contains the information about the File Attributes.

Parameters

fileSize	• Indicates the size of the file.
fileID	• Indicates the ID of the file.

fileType	• Indicates the type of the file. – 0 - Transparent – 1 - Cyclic – 2 - Linear fixed – 3 - Dedicated file – 4 - Master file
recordSize	• Indicates the size of the records. • Only for cyclic and linear fixed files
recordCount	• Indicates the total no. of the records. • Only for linear fixed files
secRead	• Read security attributes. – 0 - Always – 1 - Never – 2 - AND condition – 3 - OR condition – 4 - Single condition
secReadMask	• Mask with read security attributes. • This field is valid only when required by security attributes. – Bit 0 - PIN1 – Bit 1 - PIN2 – Bit 2 - UPIN – Bit 3 - ADM
secWrite	• Write security attributes. – 0 - Always – 1 - Never – 2 - AND condition – 3 - OR condition – 4 - Single condition
secWriteMask	• Mask with write security attributes. • This field is valid only when required by security attributes. – Bit 0 - PIN1 – Bit 1 - PIN2 – Bit 2 - UPIN – Bit 3 - ADM

secIncrease	• Increase security attributes. – 0 - Always – 1 - Never – 2 - AND condition – 3 - OR condition – 4 - Single condition
secIncrease-Mask	• Mask with increase security attributes. • This field is valid only when required by security attributes. – Bit 0 - PIN1 – Bit 1 - PIN2 – Bit 2 - UPIN – Bit 3 - ADM
secDeactivate	• Deactivate security attributes. – 0 - Always – 1 - Never – 2 - AND condition – 3 - OR condition – 4 - Single condition
secDeactivate-Mask	• Mask with deactivate security attributes. • This field is valid only when required by security attributes. – Bit 0 - PIN1 – Bit 1 - PIN2 – Bit 2 - UPIN – Bit 3 - ADM
secActivate	• Activate security attributes. – 0 - Always – 1 - Never – 2 - AND condition – 3 - OR condition – 4 - Single condition
secActivateMask	• Mask with activate security attributes. • This field is valid only when required by security attributes. – Bit 0 - PIN1 – Bit 1 - PIN2 – Bit 2 - UPIN – Bit 3 - ADM
rawLen	• Length of the following elements i.e. raw value.

rawValue[MAX_-DESCRIPTION-_LENGTH]	• Raw value of file attributes.

8.485.2 Field Documentation

8.485.2.1 uint16_t uim_fileAttributes::fileID

8.485.2.2 uint16_t uim_fileAttributes::fileSize

8.485.2.3 uint8_t uim_fileAttributes::fileType

8.485.2.4 uint16_t uim_fileAttributes::rawLen

8.485.2.5 uint8_t uim_fileAttributes::rawValue[255]

8.485.2.6 uint16_t uim_fileAttributes::recordCount

8.485.2.7 uint16_t uim_fileAttributes::recordSize

8.485.2.8 uint8_t uim_fileAttributes::secActivate

8.485.2.9 uint16_t uim_fileAttributes::secActivateMask

8.485.2.10 uint8_t uim_fileAttributes::secDeactivate

8.485.2.11 uint16_t uim_fileAttributes::secDeactivateMask

8.485.2.12 uint8_t uim_fileAttributes::secIncrease

8.485.2.13 uint16_t uim_fileAttributes::secIncreaseMask

8.485.2.14 uint8_t uim_fileAttributes::secRead

8.485.2.15 uint16_t uim_fileAttributes::secReadMask

8.485.2.16 uint8_t uim_fileAttributes::secWrite

8.485.2.17 uint16_t uim_fileAttributes::secWriteMask

8.486 uim_fileInfo Struct Reference

Data Fields

- uint16_t fileID
- uint8_t pathLen
- uint16_t path [255]

8.486.1 Detailed Description

This structure contains paramaters for file Information

Parameters

fileID	• This is Identifier to SIM files; e.g. in UIM "6F07" is Identifier of IMSI File
pathLen	• Length of file Path
path	• Path value. This value must be the complete path of the file, which is a sequence block of 2 bytes (e.g., 0x3F00 0x7FFF) is for LTE (0x3F00 ,0x7F20) is for GSM.

8.486.2 Field Documentation

8.486.2.1 uint16_t uim_fileInfo::fileID

8.486.2.2 uint16_t uim_fileInfo::path[255]

8.486.2.3 uint8_t uim_fileInfo::pathLen

8.487 uim_hotSwapStatus Struct Reference

Data Fields

- uint8_t hotSwapLength
- uint8_t hotSwap [255]

8.487.1 Detailed Description

This structure contains Hot Swap Status Information.

Parameters

hotSwapLength	• Number of sets of the following elements. i.e. hot_swap
hotSwap	• Indicates the status of the hot-swap switch. – 0 - Hot-swap is not supported – 1 - Hot-swap is supported, but the status of the switch is not supported – 2 - Switch indicates that the card is present – 3 - Switch indicates that the card is not present

8.487.2 Field Documentation

8.487.2.1 uint8_t uim_hotSwapStatus::hotSwap[255]

8.487.2.2 uint8_t uim_hotSwapStatus::hotSwapLength

8.488 uim_personalizationStatus Struct Reference

Data Fields

- uint8_t numFeatures
- uint8_t feature [12]
- uint8_t verifyLeft [12]
- uint8_t unblockLeft [12]

8.488.1 Detailed Description

This structure contains the information about the card result.

Parameters

numFeatures	• Number of active personalization features. The following block is repeated for each feature.
feature	• Indicates the personalization feature to deactivate or unblock. Valid values: – 0 - GW network personalization – 1 - GW network subset personalization – 2 - GW service provider personalization – 3 - GW corporate personalization – 4 - GW UIM personalization – 5 - 1X network type 1 personalization – 6 - 1X network type 2 personalization – 7 - 1X HRPD personalization – 8 - 1X service provider personalization – 9 - 1X corporate personalization – 10 - 1X RUIM personalization
verifyLeft	• Number of the remaining attempts to verify the personalization feature.
unblockLeft	• Number of the remaining attempts to unblock the personalization feature.

8.488.2 Field Documentation

8.488.2.1 uint8_t uim_personalizationStatus::feature[12]

8.488.2.2 uint8_t uim_personalizationStatus::numFeatures

8.488.2.3 uint8_t uim_personalizationStatus::unblockLeft[12]

8.488.2.4 uint8_t uim_personalizationStatus::verifyLeft[12]

8.489 uim_readResult Struct Reference

Data Fields

- uint16_t contentLen
- uint8_t content [255]

8.489.1 Detailed Description

This structure contains the information for write operation.

Parameters

contentLen	• Number of sets of content.
content[255]	• Read content. • The content is the sequence of bytes as read from the card.

8.489.2 Field Documentation

8.489.2.1 uint8_t uim_readResult::content[255]

8.489.2.2 uint16_t uim_readResult::contentLen

8.490 uim_readTransparentInfo Struct Reference

Data Fields

- uint16_t offset
- uint16_t length

8.490.1 Detailed Description

This structure contains the information for read operation.

Parameters

offset	• Offset for the read operation.
length	• Length of the content to be read. • The value 0 is used to read the complete file.

8.490.2 Field Documentation

8.490.2.1 uint16_t uim_readTransparentInfo::length

8.490.2.2 uint16_t uim_readTransparentInfo::offset

8.491 uim_refreshevent Struct Reference

Data Fields

- uint8_t stage
- uint8_t mode

- uint8_t sessionType
- uint8_t aidLength
- uint8_t aid [255]
- uint16_t numOfFiles
- uim_fileInfo arrfileInfo [255]

8.491.1 Detailed Description

This structure contains information of parameters associated with the Refresh Event.

Parameters

stage	• Indicates the stage of the Refresh procedure. – 0 - Waiting for OK to refresh – 1 - Refresh started – 2 - Refresh ended successfully – 3 - Refresh failed
mode	• Indicates the Refresh mode. – 0 - Reset – 1 - Init – 2 - Init and FCN – 3 - FCN – 4 - Init and Full FCN – 5 - Application reset – 6 - 3G session reset
sessionType	• Indicates the session type. – 0 - Primary GW provisioning – 1 - Primary 1X provisioning – 2 - Secondary GW provisioning – 3 - Secondary 1X provisioning – 4 - Nonprovisioning on slot 1 – 5 - Nonprovisioning on slot 2 – 6 - Card on slot 1 – 7 - Card on slot 2 – 8 - Logical channel on slot 1 – 9 - Logical channel on slot 2
aidLength	• Number of sets of the following elements – Application Identifier
aid	• Application identifier value or channel ID. This value is required for non-provisioning and for logical channel session types. It is ignored in all other cases

numFiles	• Number of sets of the following elements: – file_id – path_len – path
arrfileInfo	• Array of file Information struct

8.491.2 Field Documentation

8.491.2.1 uint8_t uim_refreshevent::aid[255]

8.491.2.2 uint8_t uim_refreshevent::aidLength

8.491.2.3 uim_fileInfo uim_refreshevent::arrfileInfo[255]

8.491.2.4 uint8_t uim_refreshevent::mode

8.491.2.5 uint16_t uim_refreshevent::numOfFiles

8.491.2.6 uint8_t uim_refreshevent::sessionType

8.491.2.7 uint8_t uim_refreshevent::stage

8.492 uim_registerRefresh Struct Reference

Data Fields

- uint8_t registerFlag
- uint8_t voteForInit
- uint16_t numFiles
- uim_fileInfo arrfileInfo [255]

8.492.1 Detailed Description

This structure contains parameters of refresh Information

Parameters

registerFlag	• Flag that indicates whether to register or deregister for refresh indications. Valid values: – 0 - Deregister – 1 - Register
voteForInit	• Flag that indicates whether to vote for the init when there is a refresh. Valid values: – 0 - Client does not vote for initialization – 1 - Client votes for initialization

numFiles	• Number of sets of the following elements: – file_id – path_len – path
arrfileInfo	• Array of file Information structure. • See uim_fileInfo for more information

8.492.2 Field Documentation

8.492.2.1 uim_fileInfo uim_registerRefresh::arrfileInfo[255]

8.492.2.2 uint16_t uim_registerRefresh::numFiles

8.492.2.3 uint8_t uim_registerRefresh::registerFlag

8.492.2.4 uint8_t uim_registerRefresh::voteForInit

8.493 uim_remainingRetries Struct Reference

Data Fields

- uint8_t verifyLeft
- uint8_t unblockLeft

8.493.1 Detailed Description

This structure contains the information about the retries remaining.

Parameters

verifyLeft	• Number of remaining attempts to verify the PIN. • 0xFF, if unavailable.
unblockLeft	• Number of remaining attempts to unblock the PIN. • 0xFF, if unavailable.

Note

This value is returned only when the enable/disable operation has failed. This information is not sent for a hidden key PIN type.

8.493.2 Field Documentation

8.493.2.1 uint8_t uim_remainingRetries::unblockLeft

8.493.2.2 uint8_t uim_remainingRetries::verifyLeft

8.494 uim_sessionInformation Struct Reference

Data Fields

- uint8_t sessionType
- uint8_t aidLength
- uint8_t aid [255]

8.494.1 Detailed Description

This structure contains the Session Information.

Parameters

sessionType	• Indicates the session type. – 0 - Primary GW provisioning – 1 - Primary 1X provisioning – 2 - Secondary GW provisioning – 3 - Secondary 1X provisioning – 4 - Non-provisioning on slot 1 – 5 - Non-provisioning on slot 2 – 6 - Card on slot 1 – 7 - Card on slot 2 – 8 - Logical channel on slot 1 – 9 - Logical channel on slot 2
aidLength	• Length of the following elements i.e. Application Identifier.
aid	• Application identifier value or channel ID. • This value is required for non-provisioning and for logical channel session types. It is ignored in all other cases.

8.494.2 Field Documentation

8.494.2.1 uint8_t uim_sessionInformation::aid[255]

8.494.2.2 uint8_t uim_sessionInformation::aidLength

8.494.2.3 uint8_t uim_sessionInformation::sessionType

8.495 uim_setPINProtection Struct Reference

Data Fields

- uint8_t pinID
- uint8_t pinOperation

- uint8_t pinLength
- uint8_t pinValue [255]

8.495.1 Detailed Description

This structure contains the information about the pin protection parameters that need to be set.

Parameters

pinID	• Indicates the PIN ID to be enabled or disabled. – 1 - PIN1 (also called PIN) – 2 - PIN2 – 3 - Universal PIN – 4 - Hidden key
pinOperation	• Indicates whether the PIN is enabled or disabled. – 0 - Disable the PIN – 1 - Enable the PIN
pinLength	• Length of the following elements i.e. pin value.
pinValue[MAX_DESCRIPTION_LENGTH]	• PIN value. • This value is a sequence of ASCII characters.

8.495.2 Field Documentation

8.495.2.1 uint8_t uim_setPINProtection::pinID

8.495.2.2 uint8_t uim_setPINProtection::pinLength

8.495.2.3 uint8_t uim_setPINProtection::pinOperation

8.495.2.4 uint8_t uim_setPINProtection::pinValue[255]

8.496 uim_slotInfo Struct Reference

Data Fields

- uint8_t cardState
- uint8_t upinState
- uint8_t upinRetries
- uint8_t upukRetries
- uint8_t errorState
- uint8_t numApp
- uim_appStatus AppStatus [10]

8.496.1 Detailed Description

This structure contains information about the SLOTS present.

Parameters

cardState	• Indicates the state of the card for each slot. – 0 - Absent – 1 - Present – 2 - Error
upinState	• Indicates the state of UPIN. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked – 0xFF - Not Available
upinRetries	• Indicates the number of retries remaining to verify the UPIN. • If 0xFF, information not available.
upukRetries	• Indicates the number of retries remaining to unblock the UPIN. • If 0xFF, information not available.
errorState	• Indicates the reason for the card error, and is valid only when the card state is Error – 0 - Unknown – 1 - Power down – 2 - Poll error – 3 - No ATR received – 4 - Volt mismatch – 5 - Parity error – 6 - Unknown; possibly removed – 7 - Card returned technical problems – 0xFF - Not Available • Other values are possible and reserved for future use. • When an unknown value is received, it is to be handled as "Unknown".
numApp	• Indicates the number of applications available on the card. • The following block is repeated for each application. i.e. AppStatus. • If zero(0) then no AppStatus information exists.
AppStatus	• See uim_appStatus for more information.

8.496.2 Field Documentation

8.496.2.1 uim_appStatus uim_slotInfo::AppStatus[10]

8.496.2.2 uint8_t uim_slotInfo::cardState

8.496.2.3 uint8_t uim_slotInfo::errorState

8.496.2.4 uint8_t uim_slotInfo::numApp

8.496.2.5 uint8_t uim_slotInfo::upinRetries

8.496.2.6 uint8_t uim_slotInfo::upinState

8.496.2.7 uint8_t uim_slotInfo::upukRetries

8.497 uim_UIMSessionInformation Struct Reference

Data Fields

- uint8_t sessionType
- uint8_t aidLength
- uint8_t aid [255]

8.497.1 Detailed Description

This structure contains the Session Information.

Parameters

sessionType	• Indicates the session type. – 0 - Primary GW provisioning – 1 - Primary 1X provisioning – 2 - Secondary GW provisioning – 3 - Secondary 1X provisioning – 4 - Non-provisioning on slot 1 – 5 - Non-provisioning on slot 2 – 6 - Card on slot 1 – 7 - Card on slot 2 – 8 - Logical channel on slot 1 – 9 - Logical channel on slot 2
aidLength	• Length of the following elements i.e. Application Identifier.
aid	• Application identifier value or channel ID. • This value is required for non-provisioning and for logical channel session types. It is ignored in all other cases.

8.497.2 Field Documentation

8.497.2.1 uint8_t uim_UIMSessionInformation::aid[255]

8.497.2.2 uint8_t uim_UIMSessionInformation::aidLength

8.497.2.3 uint8_t uim_UIMSessionInformation::sessionType

8.498 uim_unblockUIMPIN Struct Reference

Data Fields

- uint8_t pinID
- uint8_t pukLen
- uint8_t pukVal [255]
- uint8_t newPINLen
- uint8_t newPINVal [255]

8.498.1 Detailed Description

This structure contains the information about the unblock pin parameters.

Parameters

pinID	• Indicates the PIN ID to be changed. – 1 - PIN1 (also called PIN) – 2 - PIN2 – 3 - Universal PIN
pukLen	• Length of the following elements i.e. puk value.
pukVal[UIM_MAX_DESCRIPTION_LENGTH]	• PIN Unlock Key value. • This value is a sequence of ASCII characters.
newPINLen	• Length of the following elements i.e. new pin value.
newPINVal[UIM_MAX_DESCRIPTION_LENGTH]	• New PIN value. • This value is a sequence of ASCII characters.

8.498.2 Field Documentation

8.498.2.1 uint8_t uim_unblockUIMPIN::newPINLen

8.498.2.2 uint8_t uim_unblockUIMPIN::newPINVal[255]

8.498.2.3 uint8_t uim_unblockUIMPIN::pinID

8.498.2.4 uint8_t uim_unblockUIMPIN::pukLen

8.498.2.5 uint8_t uim_unblockUIMPIN::pukVal[255]

8.499 uim_verifyUIMPIN Struct Reference

Data Fields

- uint8_t pinID
- uint8_t pinLen
- uint8_t pinVal [255]

8.499.1 Detailed Description

This structure contains the information about the pin parameters that need to be verified.

Parameters

pinID	• Indicates the PIN ID to be verified. – 1 - PIN1 (also called PIN) – 2 - PIN2 – 3 - Universal PIN – 4 - Hidden key
pinLen	• Length of the following elements i.e. pin value.
pinVal[MAX_DESCRIPTION_LENGTH]	• PIN value. • This value is a sequence of ASCII characters.

8.499.2 Field Documentation

8.499.2.1 uint8_t uim_verifyUIMPIN::pinID

8.499.2.2 uint8_t uim_verifyUIMPIN::pinLen

8.499.2.3 uint8_t uim_verifyUIMPIN::pinVal[255]

8.500 unpack_audio_SLQSGetAudioPathConfig_t Struct Reference

Data Fields

- uint8_t * pECMode
- uint8_t * pNSEnable
- uint16_t * pTXGain
- uint16_t * pDTMFTXGain
- uint16_t * pCodecSTGain
- audio_TXPCMIIRFltr * pTXPCMIIRFltr
- audio_RXPCMIIRFltr * pRXPCMIIRFltr
- uint8_t * pMICGainSelect

- uint8_t * pRXAVCAGCSwitch
- uint8_t * pTXAVCSwitch
- audio_RXAGCList * pRXAGCList
- audio_RXAVCList * pRXAVCList
- audio_TXAGCList * pTXAGCList

8.500.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig response parameters.

Parameters

pECMode	[Optional] • AV_EC – 0 - Echo cancellation off – 1 - Handset mode – 2 - Headset mode – 3 - Car kit mode – 4 - Speaker Mode
pNSEnable	[Optional] • AV_NS – 0 - Noise suppression off – 1 - Noise suppression on
pTXGain	[Optional] • AV_TXVOL – 0x0000 - 0xffff
pDTMFTXGain	[Optional] • AV_DTMFTXG – 0x0000 - 0xffff
pCodecSTGain	[Optional] • AV_CODECSTG – 0x0000 - 0xffff
pTXPCMIIRFltr	[Optional] • See audio_TXPCMIIRFltr for more information
pRXPCMIIRFltr	[Optional] • See audio_RXPCMIIRFltr for more information
pMICGainSelect	[Optional] • AV_MICGAIN
pRXAVCAGC-Switch	[Optional] • RX AVC/AGC Switch
pTXAVCSwitch	[Optional] • TX AVC Switch
pRXAGCList	[Optional] • See audio_RXAGCList for more information

pRXAVCList	[Optional] • See audio_RXAVCList for more information
pTXAGCList	[Optional] • See audio_TXAGCList for more information

8.500.2 Field Documentation

8.500.2.1 uint16_t* unpack_audio_SLQSGetAudioPathConfig_t::pCodecSTGain

8.500.2.2 uint16_t* unpack_audio_SLQSGetAudioPathConfig_t::pDTMFTXGain

8.500.2.3 uint8_t* unpack_audio_SLQSGetAudioPathConfig_t::pECMode

8.500.2.4 uint8_t* unpack_audio_SLQSGetAudioPathConfig_t::pMICGainSelect

8.500.2.5 uint8_t* unpack_audio_SLQSGetAudioPathConfig_t::pNSEnable

8.500.2.6 audio_RXAGCList* unpack_audio_SLQSGetAudioPathConfig_t::pRXAGCList

8.500.2.7 uint8_t* unpack_audio_SLQSGetAudioPathConfig_t::pRXAVCAGCSwitch

8.500.2.8 audio_RXAVCList* unpack_audio_SLQSGetAudioPathConfig_t::pRXAVCList

8.500.2.9 audio_RXPCMIIRFltr* unpack_audio_SLQSGetAudioPathConfig_t::pRXPCMIIRFltr

8.500.2.10 audio_TXAGCList* unpack_audio_SLQSGetAudioPathConfig_t::pTXAGCList

8.500.2.11 uint8_t* unpack_audio_SLQSGetAudioPathConfig_t::pTXAVCSwitch

8.500.2.12 uint16_t* unpack_audio_SLQSGetAudioPathConfig_t::pTXGain

8.500.2.13 audio_TXPCMIIRFltr* unpack_audio_SLQSGetAudioPathConfig_t::pTXPCMIIRFltr

8.501 unpack_audio_SLQSGetAudioProfile_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t EarMute
- uint8_t MicMute
- uint8_t Volume

8.501.1 Detailed Description

This structure contains the unpack parameters to Get Audio Profile.

Parameters

Profile	• Audio Profile – 0 - Handset – 1 - Headset – 2 - Car Kit – 3 - Speaker phone – 4 - Auxiliary – 5 - TTY – 6 - Auxiliary external PCM – 7 - Primary external PCM – 8 - External slave PCM – 9 - I2S – 0xff - Invalid data.
EarMute	• Ear Mute Setting – 0 - unmuted – 1 - muted – 0xff - Invalid data.
MicMute	• MIC Mute Setting – 0 - unmuted – 1 - muted – 0xff - Invalid data.
Volume	• Audio Volume Level – 0 to 7 – 0xff - Invalid data.

8.501.2 Field Documentation

8.501.2.1 uint8_t unpack_audio_SLQSGetAudioProfile_t::EarMute

8.501.2.2 uint8_t unpack_audio_SLQSGetAudioProfile_t::MicMute

8.501.2.3 uint8_t unpack_audio_SLQSGetAudioProfile_t::Profile

8.501.2.4 uint8_t unpack_audio_SLQSGetAudioProfile_t::Volume

8.502 unpack_audio_SLQSGetAudioVolTLBConfig_t Struct Reference

Data Fields

- uint16_t ResCode

8.502.1 Detailed Description

This structure contains the unpack parameters for SLQSGetAudioVolTLBConfig.

Parameters

ResCode	• Result of requested item

8.502.2 Field Documentation

8.502.2.1 uint16_t unpack_audio_SLQSGetAudioVolTLBConfig_t::ResCode

8.503 unpack_audio_SLQSSetAudioVolTLBConfig_t Struct Reference

Data Fields

- uint16_t ResCode

8.503.1 Detailed Description

This structure contains the unpack parameters for SLQSSetAudioVolTLBConfig.

Parameters

ResCode	• Result of requested item

8.503.2 Field Documentation

8.503.2.1 uint16_t unpack_audio_SLQSSetAudioVolTLBConfig_t::ResCode

8.504 unpack_cat_SetCatEventCallback_ind_t Struct Reference

Data Fields

- uint8_t event_Index
- struct cat_commonEventTlv CCETlv [11]

8.504.1 Detailed Description

Structure used to store all CAT Notification Parameters.

Parameters

event_Index	- Event Index
CCETlv	- CAT common event Tlv cat_commonEventTlv for more info.

8.504.2 Field Documentation

8.504.2.1 struct cat_commonEventTlv unpack_cat_SetCatEventCallback_ind_t::CCETlv[11]

8.504.2.2 uint8_t unpack_cat_SetCatEventCallback_ind_t::event_Index

8.505 unpack_cat_SetCATEventCallback_t Struct Reference

Data Fields

- uint32_t errorMask
- uint16_t Tlvresult

8.505.1 Detailed Description

This structure contains sEnables/disables the CAT event callback unpack variable.

Parameters

errorMask	• error bitmask. Each bit set indicates the proactive command that caused the error – 0x00000001 - Display Text – 0x00000002 - Get In-Key – 0x00000004 - Get Input – 0x00000008 - Setup Menu – 0x00000010 - Select Item – 0x00000020 - Send SMS - Alpha Identifier – 0x00000040 - Setup Event: User Activity – 0x00000080 - Setup Event: Idle Screen Notify – 0x00000100 - Setup Event: Language Sel Notify – 0x00000200 - Setup Idle Mode Text – 0x00000400 - Language Notification – 0x00000800 - Refresh – 0x00001000 - End Proactive Session
Tlvresult	• Unpack Result

8.505.2 Field Documentation

8.505.2.1 uint32_t unpack_cat_SetCATEventCallback_t::errorMask

8.505.2.2 uint16_t unpack_cat_SetCATEventCallback_t::Tlvresult

8.506 unpack_dms_GetActivationState_t Struct Reference

Data Fields

- uint8_t state

8.506.1 Detailed Description

This structure contains unpack_dms_GetActivationState parameters.

Parameters

state[OUT]	• Service Activation Code 0 - Service not activated 1 - Service activated 2 - Activation connecting 3 - Activation connected 4 - OTASP security authenticated 5 - OTASP NAM downloaded 6 - OTASP MDN downloaded 7 - OTASP IMSI downloaded 8 - OTASP PRL downloaded 9 - OTASP SPC downloaded 10 - OTASP settings committed 0xff - Invalid data.

8.506.2 Field Documentation

8.506.2.1 uint8_t unpack_dms_GetActivationState_t::state

8.507 unpack_dms_GetBandCapability_t Struct Reference

Data Fields

- uint32_t BandCapability
- uint16_t Tlvresult

8.507.1 Detailed Description

Structure to store the band capability of the device.

Parameters

BandCapability	Bitmask of bands supported by the device • Bit 0 - Band class 0, A-system • Bit 1 - Band class 0, B-system • Bit 2 - Band class 1, all blocks • Bit 3 - Band class 2 • Bit 4 - Band class 3, A-system • Bit 5 - Band class 4, all blocks • Bit 6 - Band class 5, all blocks • Bit 7 - GSM DCS band (1800) • Bit 8 - GSM Extended GSM (E-GSM) band (900) • Bit 9 - GSM Primary GSM (P-GSM) band (900) • Bit 10 - Band class 6 • Bit 11 - Band class 7 • Bit 12 - Band class 8 • Bit 13 - Band class 9 • Bit 14 - Band class 10 • Bit 15 - Band class 11 • Bit 16 - GSM 450 band • Bit 17 - GSM 480 band • Bit 18 - GSM 750 band • Bit 19 - GSM 850 band • Bit 20 - GSM railways GSM band (900) • Bit 21 - GSM PCS band (1900) • Bit 22 - WCDMA (Europe, Japan, and China) 2100 band • Bit 23 - WCDMA US PCS 1900 band • Bit 24 - WCDMA (Europe and China) DCS 1800 band • Bit 25 - WCDMA US 1700 band • Bit 26 - WCDMA US 850 band • Bit 27 - WCDMA Japan 800 band • Bit 28 - Band class 12 • Bit 29 - Band class 14 • Bit 30 - Reserved • Bit 31 - Band class 15 • Bits 32 through 47 - Reserved • Bit 48 - WCDMA Europe 2600 band • Bit 49 - WCDMA Europe and Japan 900 band • Bit 50 - WCDMA Japan 1700 band • Bits 51 through 55 - Reserved • Bit 56 - Band class 16 • Bit 57 - Band class 17 • Bit 58 - Band class 18 • Bit 59 - Band class 19
Tlvresult	• unpack Tlv Result. • eQCWWAN_ERR_NULL_TLV - Invalid Tlv Data.

8.507.2 Field Documentation

8.507.2.1 uint32_t unpack_dms_GetBandCapability_t::BandCapability

8.507.2.2 uint16_t unpack_dms_GetBandCapability_t::Tlvresult

8.508 unpack_dms_GetCrashAction_t Struct Reference

Data Fields

- uint8_t DevCrashState
- uint16_t Tlvresult

8.508.1 Detailed Description

This structure is used to store the Crash State from the device.

Parameters

DevCrashState	• Device Crash State • Values: – 0 - USB Memory Download Modem will reset after a crash and will stay in USB download mode with only ttyUSB0 enumerated. ramdump tool is to be used to recover the crash dump. Modem needs to be reset again to come back in ONLINE mode. – 1 - Reset Modem will reset and come back in ONLINE mode. Minimal crash data will be available and can be extracted with at!gcdump? AT command or SLQSSwiGetCrashInfo() SDK API – 2 - No action – 0xff - Invaild data.
Tlvresult	• unpack Tlv result

8.508.2 Field Documentation

8.508.2.1 uint8_t unpack_dms_GetCrashAction_t::DevCrashState

8.508.2.2 uint16_t unpack_dms_GetCrashAction_t::Tlvresult

8.509 unpack_dms_GetCustFeature_t Struct Reference

Data Fields

- uint32_t GpsEnable
- uint8_t DisableIMSI
- uint16_t IPFamSupport
- uint8_t RMAutoConnect
- uint8_t GPSSel
- uint8_t SMSSupport
- uint8_t IsVoiceEnabled
- uint8_t DHCPRelayEnabled

- uint8_t GPSLPM
- uint16_t Tlvresult

8.509.1 Detailed Description

This structure contains current settings of custom features

Parameters

GpsEnable	• describes if GPS is enabled or disabled • values: – 0x00 - GPS is disabled – 0x01 - GPS is enabled – 0xff - Invaild data.
DisableIMSI	• optional 1 byte parameter • describes if IMSI display is enabled or disabled • values: – 0x00 - Allow display of IMSI – 0x01 - Do not display IMSI – 0xff - Invaild data.
IPFamSupport	• optional 2 byte BitMask • bitmask representing the IP families supported • values: – 0x01 - IPv4 – 0x02 - IPv6 – 0x04 - IPv4v6 – 0xff - Invaild data.
RMAutoConnect	• optional 1 byte parameter • QMI Mode RM Net Auto Connect Support • values: – 0x00 - Not Supported – 0x01 - Supported – 0xff - Invaild data.
GPSSel	• optional 1 byte parameter • GPS Antenna Select • values: – 0x00 - Dedicated GPS Port – 0x01 - GPS Rx over AUX Port – 0x02 - GPS Rx over dedicated GPS port with no bias voltage applied – 0xff - Invaild data.

SMSSupport	• optional 1 byte parameter • SMS support • values: – 0x00 - Not supported – 0x01 - supported – 0xff - Invaild data. • Used to determine whether or not to hide SMS from user
IsVoiceEnabled	• optional 1 byte parameter • Voice support • values: – 0x00 - Enable voice on both AT and QMI interface (default) – 0x01 - Reserved – 0x02 - Disable voice on both AT and QMI interface – 0xff - Invaild data.
DHCPRelay-Enabled	• optional 1 byte parameter • DHCP Relay support • values: – 0x00 - Disable DHCP relay – 0x01 - Enable DHCP relay – 0xff - Invaild data.
GPSLPM	• optional 1 byte parameter • GPSLPM support • values: – 0x00 - Enable GPS in Low Power Mode – 0x01 - Disable GPS in Low Power Mode – 0xff - Invaild data.
Tlvresult	• unpack Tlv Result.

8.509.2 Field Documentation

8.509.2.1 uint8_t unpack_dms_GetCustFeature_t::DHCPRelayEnabled

8.509.2.2 uint8_t unpack_dms_GetCustFeature_t::DisableIMSI

8.509.2.3 uint32_t unpack_dms_GetCustFeature_t::GpsEnable

8.509.2.4 uint8_t unpack_dms_GetCustFeature_t::GPSLPM

8.509.2.5 uint8_t unpack_dms_GetCustFeature_t::GPSSel

8.509.2.6 uint16_t unpack_dms_GetCustFeature_t::IPFamSupport

8.509.2.7 uint8_t unpack_dms_GetCustFeature_t::IsVoiceEnabled

8.509.2.8 uint8_t unpack_dms_GetCustFeature_t::RMAutoConnect

8.509.2.9 uint8_t unpack_dms_GetCustFeature_t::SMSSupport

8.509.2.10 uint16_t unpack_dms_GetCustFeature_t::Tlvresult

8.510 unpack_dms_GetCustFeaturesV2_t Struct Reference

Data Fields

- DMSgetCustomFeatureV2 GetCustomFeatureV2
- uint16_t Tlvresult

8.510.1 Detailed Description

This structure contains customization settings set to modem unpack

Parameters

GetCustom-FeatureV2	• See DMSgetCustomFeatureV2 for more information
Tlvresult	• Unpack Result

8.510.2 Field Documentation

8.510.2.1 DMSgetCustomFeatureV2 unpack_dms_GetCustFeaturesV2_t::GetCustomFeatureV2

8.510.2.2 uint16_t unpack_dms_GetCustFeaturesV2_t::Tlvresult

8.511 unpack_dms_GetDeviceCap_t Struct Reference

Data Fields

- uint32_t MaxTXChannelRate
- uint32_t MaxRXChannelRate
- uint32_t DataServiceCapability
- uint32_t SimCapability
- uint32_t RadioIfacesSize
- uint8_t RadioIfaces [64]
- uint16_t Tlvresult

8.511.1 Detailed Description

Structure to store the device capabilities

Parameters

MaxTXChannel-Rate	• Maximum transmission rate (in bps) supported by the device • In multi-technology devices, this value will be the greatest rate among all supported technologies
MaxRXChannel-Rate	• Maximum reception rate (in bps) supported by the device • In multi-technology devices, this value will be the greatest rate among all supported technologies
DataService-Capability	• CS/PS data service capability – 0 - No data services supported – 1 - Only Circuit Switched (CS) services supported – 2 - Only Packet Switched (PS) services supported – 3 - Simultaneous CS and PS – 4 - Non-simultaneous CS and PS
SimCapability	Device SIM capability • 0 - SIM not supported • 1 - SIM supported
RadioIfacesSize	• Upon input, the maximum number of elements that the radio interface array can contain • Upon successful output, actual number of elements in the radio interface array
RadioIfaces	• Radio interface array. This is a structure of array containing the elements below. uint8_t RadioIfaces – See qaGobiApiTableRadioInterfaces.h for Radio Interfaces
Tlvresult	• Unpack Result • eQCWWAN_ERR_NULL_TLV - Invalid Tlv Data.

8.511.2 Field Documentation

8.511.2.1 uint32_t unpack_dms_GetDeviceCap_t::DataServiceCapability

8.511.2.2 uint32_t unpack_dms_GetDeviceCap_t::MaxRXChannelRate

8.511.2.3 uint32_t unpack_dms_GetDeviceCap_t::MaxTXChannelRate

8.511.2.4 uint8_t unpack_dms_GetDeviceCap_t::RadioIfaces[64]

8.511.2.5 uint32_t unpack_dms_GetDeviceCap_t::RadioIfacesSize

8.511.2.6 uint32_t unpack_dms_GetDeviceCap_t::SimCapability

8.511.2.7 uint16_t unpack_dms_GetDeviceCap_t::Tlvresult

8.512 unpack_dms_GetDeviceCapabilities_t Struct Reference

Data Fields

- uint32_t maxTxChannelRate
- uint32_t maxRxChannelRate
- uint32_t dataServiceCaCapability
- uint32_t simCapability
- uint32_t radioIfacesSize
- uint8_t RadioIfaces [255]

8.512.1 Detailed Description

Gets the device capabilities structure

Parameters

maxTxChannelRate	• Maximum transmission rate (in bps) supported by the device • In multi-technology devices, this value will be the greatest rate among all supported technologies
maxRxChannelRate	• Maximum reception rate (in bps) supported by the device • In multi-technology devices, this value will be the greatest rate among all supported technologies
dataServiceCaCapability	• CS/PS data service capability – 0 - No data services supported – 1 - Only Circuit Switched (CS) services supported – 2 - Only Packet Switched (PS) services supported – 3 - Simultaneous CS and PS – 4 - Non-simultaneous CS and PS
simCapability	• Device SIM capability – 0 - SIM not supported – 1 - SIM supported – 0xff - Invalid Device capablitityes Data.
radioIfacesSize	• Upon input, the maximum number of elements that the radio interface array can contain • Upon successful output, actual number of elements in the radio interface array
RadioIfaces[OUT]	• Radio interface array. This is a structure of array containing the elements below. – See qaGobiApiTableRadioInterfaces.h for Radio Interfaces

8.512.2 Field Documentation

8.512.2.1 uint32_t unpack_dms_GetDeviceCapabilities_t::dataServiceCaCapability

8.512.2.2 uint32_t unpack_dms_GetDeviceCapabilities_t::maxRxChannelRate

8.512.2.3 uint32_t unpack_dms_GetDeviceCapabilities_t::maxTxChannelRate

8.512.2.4 uint8_t unpack_dms_GetDeviceCapabilities_t::RadioIfaces[255]

8.512.2.5 uint32_t unpack_dms_GetDeviceCapabilities_t::radioIfacesSize

8.512.2.6 uint32_t unpack_dms_GetDeviceCapabilities_t::simCapability

8.513 unpack_dms_GetDeviceHardwareRev_t Struct Reference

Data Fields

- uint8_t stringSize
- char String [255]
- uint16_t Tlvresult

8.513.1 Detailed Description

Structure to store the hardware revision of the device

Parameters

stringSize	• The maximum number of characters (including NULL terminator) that the string array can contain
String	• NULL terminated Hardware Revision string • Maximum Length is 255 Bytes
Tlvresult	• Unpack Result • eQCWWAN_ERR_NULL_TLV - Invalid Tlv Data.

8.513.2 Field Documentation

8.513.2.1 char unpack_dms_GetDeviceHardwareRev_t::String[255]

8.513.2.2 uint8_t unpack_dms_GetDeviceHardwareRev_t::stringSize

8.513.2.3 uint16_t unpack_dms_GetDeviceHardwareRev_t::Tlvresult

8.514 unpack_dms_GetDeviceMfr_t Struct Reference

Data Fields

- uint8_t stringSize
- char String [255]
- uint16_t Tlvresult

8.514.1 Detailed Description

This structure is used to store unpack_dms_GetDeviceMfr parameters

Parameters

stringSize	• The maximum number of characters (including NULL terminator) that the string array can contain
String	• NULL terminated Device Manufacture string • Maximum Length is 255 Bytes
Tlvresult	• unpack Tlv result • eQCWWAN_ERR_NULL_TLV - Invalid Tlv Data.

8.514.2 Field Documentation

8.514.2.1 char unpack_dms_GetDeviceMfr_t::String[255]

8.514.2.2 uint8_t unpack_dms_GetDeviceMfr_t::stringSize

8.514.2.3 uint16_t unpack_dms_GetDeviceMfr_t::Tlvresult

8.515 unpack_dms_GetDeviceSerialNumbers_t Struct Reference

Data Fields

- uint8_t esnSize
- char ESNString [255]
- uint8_t imeiSize
- char IMEIString [255]
- uint8_t meidSize
- char MEIDString [255]
- uint8_t imeiSvnSize
- char ImeiSvnString [255]
- uint16_t Tlvresult

8.515.1 Detailed Description

This structure used to store unpack_dms_GetDeviceSerialNumbers parameters

Parameters

esnSize	• The maximum number of characters (including NULL terminator) that the ESN string array can contain
ESNString	• NULL-terminated ESN string. Empty string is returned when ESN is not supported/programmed • Maximum Length is 255 Bytes

imeiSize	• The maximum number of characters (including NULL terminator) that the IMEI string array can contain
IMEIString	• NULL terminated IMEI string. Empty string is returned when IMEI is not supported/programmed • Maximum Length is 255 Bytes
meidSize	• The maximum number of characters (including NULL terminator) that the MEID string array can contain
MEIDString	• NULL-terminated MEID string. Empty string is returned when MEID is not supported/programmed • Maximum Length is 255 Bytes
imeiSvnSize	• The maximum number of characters (including NULL terminator) that the IMEI SVN string array can contain.
ImeiSvnString	• NULL-terminated IMEI SVN string. Empty string is returned when IMEI SVN is not supported/programmed. • Maximum Length is 255 Bytes
Tlvresult	• unpack Tlv Result.

8.515.2 Field Documentation

8.515.2.1 uint8_t unpack_dms_GetDeviceSerialNumbers_t::esnSize

8.515.2.2 char unpack_dms_GetDeviceSerialNumbers_t::ESNString[255]

8.515.2.3 uint8_t unpack_dms_GetDeviceSerialNumbers_t::imeiSize

8.515.2.4 char unpack_dms_GetDeviceSerialNumbers_t::IMEIString[255]

8.515.2.5 uint8_t unpack_dms_GetDeviceSerialNumbers_t::imeiSvnSize

8.515.2.6 char unpack_dms_GetDeviceSerialNumbers_t::ImeiSvnString[255]

8.515.2.7 uint8_t unpack_dms_GetDeviceSerialNumbers_t::meidSize

8.515.2.8 char unpack_dms_GetDeviceSerialNumbers_t::MEIDString[255]

8.515.2.9 uint16_t unpack_dms_GetDeviceSerialNumbers_t::Tlvresult

8.516 unpack_dms_GetFirmwareInfo_t Struct Reference

Data Fields

- char modelid_str [20]
- char bootversion_str [85]
- char appversion_str [85]
- char sku_str [15]
- char packageid_str [85]
- char carrier_str [20]
- char priversion_str [16]
- char cur_carr_name [17]
- char cur_carr_rev [13]
- uint16_t Tlvresult

8.516.1 Detailed Description

This structure used to store unpack_dms_GetFirmwareInfo parameters

Parameters

modelid_str	- Mode ID String. • NULL-terminated Mode ID String. • Invalid data : index 0 equal 0x7F
bootversion_str	- Boot Version. • NULL-terminated Boot Version String. • Invalid data : index 0 equal 0x7F
appversion_str	- Application Version String. • NULL-terminated Application Version String. • Invalid data : index 0 equal 0x7F
sku_str	- SKU String. • NULL-terminated SKU String. • Invalid data : index 0 equal 0x7F
packageid_str	- Package ID String. • NULL-terminated Package ID String. • deprecated on EM/MC74xx(9x30) devices • Invalid data : index 0 equal 0x7F
carrier_str	- Carrier String. • NULL-terminated Carrier String. • Invalid data : index 0 equal 0x7F
priversion_str	- PRI Version String. • NULL-terminated PRI Version String. • Invalid data : index 0 equal 0x7F
cur_carr_name	- Current Carrier Name String. • NULL-terminated Current Carrier Name String. • Invalid data : index 0 equal 0x7F

cur_carr_rev	- Current Carrier Revision String. • NULL-terminated Current Carrier Revision String. • Invalid data : index 0 equal 0x7F
Tlvresult	- unpack Tlv Result.

8.516.2 Field Documentation

8.516.2.1 char unpack_dms_GetFirmwareInfo_t::appversion_str[85]

8.516.2.2 char unpack_dms_GetFirmwareInfo_t::bootversion_str[85]

8.516.2.3 char unpack_dms_GetFirmwareInfo_t::carrier_str[20]

8.516.2.4 char unpack_dms_GetFirmwareInfo_t::cur_carr_name[17]

8.516.2.5 char unpack_dms_GetFirmwareInfo_t::cur_carr_rev[13]

8.516.2.6 char unpack_dms_GetFirmwareInfo_t::modelid_str[20]

8.516.2.7 char unpack_dms_GetFirmwareInfo_t::packageid_str[85]

8.516.2.8 char unpack_dms_GetFirmwareInfo_t::priversion_str[16]

8.516.2.9 char unpack_dms_GetFirmwareInfo_t::sku_str[15]

8.516.2.10 uint16_t unpack_dms_GetFirmwareInfo_t::Tlvresult

8.517 unpack_dms_GetFirmwareRevision_t Struct Reference

Data Fields

- uint8_t amssSize
- char AMSSString [255]
- char PRIString [255]
- uint16_t Tlvresult

8.517.1 Detailed Description

This structure used to store unpack_dms_GetFirmwareRevision parameters

Parameters

amssSize	• Maximum number of characters (including NULL terminator) that the AMSS string array can contain.
AMSSString	• NULL-terminated AMSS revision string. • Maximum Length is 255 Bytes • Invalid data : index 0 equal 0x7F

PRIString[OUT]	• NULL-terminated PRI revision string. • Maximum Length is 255 Bytes • Invalid data : index 0 equal 0x7F
Tlvresult	• unpack Tlv Result.

8.517.2 Field Documentation

8.517.2.1 uint8_t unpack_dms_GetFirmwareRevision_t::amssSize

8.517.2.2 char unpack_dms_GetFirmwareRevision_t::AMSSString[255]

8.517.2.3 char unpack_dms_GetFirmwareRevision_t::PRIString[255]

8.517.2.4 uint16_t unpack_dms_GetFirmwareRevision_t::Tlvresult

8.518 unpack_dms_GetFirmwareRevisions_t Struct Reference

Data Fields

- uint8_t amssSize
- char AMSSString [255]
- uint8_t bootSize
- char BootString [255]
- uint8_t priSize
- char PRIString [255]
- uint16_t Tlvresult

8.518.1 Detailed Description

This structure used to store unpack_dms_GetFirmwareRevisions parameters

Parameters

amssSize	• Maximum number of characters (including NULL terminator) that the AMSS string array can contain
AMSSString	• NULL-terminated AMSS revision string • Maximum Length is 255 Bytes • Invalid data : index 0 equal 0x7F and amssSize is equal 0.
bootSize	• Maximum number of characters (including NULL terminator) that the boot string array can contain

BootString	• NULL-terminated boot code revision string • Maximum Length is 255 Bytes • Invalid data : index 0 equal 0x7F and bootSize is equal 0.
priSize	• Maximum number of characters (including NULL terminator) that the PRI string array can contain
PRIString	• NULL-terminated PRI revision string • Maximum Length is 255 Bytes • Invalid data : index 0 equal 0x7F and priSize is equal 0.
Tlvresult	• unpack Tlv Result

8.518.2 Field Documentation

8.518.2.1 uint8_t unpack_dms_GetFirmwareRevisions_t::amssSize

8.518.2.2 char unpack_dms_GetFirmwareRevisions_t::AMSSString[255]

8.518.2.3 uint8_t unpack_dms_GetFirmwareRevisions_t::bootSize

8.518.2.4 char unpack_dms_GetFirmwareRevisions_t::BootString[255]

8.518.2.5 uint8_t unpack_dms_GetFirmwareRevisions_t::priSize

8.518.2.6 char unpack_dms_GetFirmwareRevisions_t::PRIString[255]

8.518.2.7 uint16_t unpack_dms_GetFirmwareRevisions_t::Tlvresult

8.519 unpack_dms_GetFSN_t Struct Reference

Data Fields

- char String [255]
- uint16_t Tlvresult

8.519.1 Detailed Description

This structure used to store Factory Sequence Number parameter

Parameters

String	• Facorty Sequence Number • Maximum Length is 255 Bytes
Tlvresult	• Unpack Result 8 - eQCWWAN_ERR_NULL_TLV - Invalid Tlv Data.

8.519.2 Field Documentation

8.519.2.1 char unpack_dms_GetFSN_t::String[255]

8.519.2.2 uint16_t unpack_dms_GetFSN_t::Tlvresult

8.520 unpack_dms_GetHardwareRevision_t Struct Reference

Data Fields

- char hwVer [255]

8.520.1 Detailed Description

This structure used to store unpack_dms_GetHardwareRevision parameters

Parameters

hwVer	- Hardware version • NULL-terminated string • Maximum Length is 255 Bytes • Invalid data : index 0 equal 0x7F.

8.520.2 Field Documentation

8.520.2.1 char unpack_dms_GetHardwareRevision_t::hwVer[255]

8.521 unpack_dms_GetIMSI_t Struct Reference

Data Fields

- char imsi [255]
- uint16_t Tlvresult

8.521.1 Detailed Description

This structure used to store unpack_dms_GetIMSI parameters

Parameters

imsi	- IMSI no. • NULL-terminated String.
Tlvresult	- unpack Tlv Result.

8.521.2 Field Documentation

8.521.2.1 char unpack_dms_GetIMSI_t::imsi[255]

8.521.2.2 uint16_t unpack_dms_GetIMSI_t::Tlvresult

8.522 unpack_dms_GetManufacturer_t Struct Reference

Data Fields

- char manufacturer [255]
- uint16_t Tlvresult

8.522.1 Detailed Description

This structure is used to store device manufacturer information.

Parameters

manufacturer[OUT]	• NULL terminated string
Tlvresult	• Unpack Result • eQCWWAN_ERR_NULL_TLV - Invalid Tlv Data.

8.522.2 Field Documentation

8.522.2.1 char unpack_dms_GetManufacturer_t::manufacturer[255]

8.522.2.2 uint16_t unpack_dms_GetManufacturer_t::Tlvresult

8.523 unpack_dms_GetModelID_t Struct Reference

Data Fields

- char modelid [255]
- uint16_t Tlvresult

8.523.1 Detailed Description

This structure used to store unpack_dms_GetModelID parameters

Parameters

modelid	- Device model id. • NULL-terminated String.
Tlvresult	- unpack Tlv Result.

8.523.2 Field Documentation

8.523.2.1 char unpack_dms_GetModelID_t::modelid[255]

8.523.2.2 uint16_t unpack_dms_GetModelID_t::Tlvresult

8.524 unpack_dms_GetNetworkTime_t Struct Reference

Data Fields

- uint16_t source
- uint64_t timestamp
- uint16_t Tlvresult

8.524.1 Detailed Description

This structure used to store unpack_dms_GetNetworkTime parameters

Parameters

source	• Source of timestamp 0 - 32 kHz device clock 1 - CDMA network 2 - cdma2000 1xEV-DO network
timestamp	• Count of 1.25 ms that have elapsed from the start of GPS time (Jan 6, 1980)
Tlvresult	• Unpack Result • eQCWWAN_ERR_NULL_TLV - Invalid Tlv Data.

Note

The source of the timestamp provided specifies how the timestamp was determined. The first network time that is available will be returned. If no network time is available, the timestamp is taken from the 32 kHz slow-clock of the device.

8.524.2 Field Documentation

8.524.2.1 uint16_t unpack_dms_GetNetworkTime_t::source

8.524.2.2 uint64_t unpack_dms_GetNetworkTime_t::timestamp

8.524.2.3 uint16_t unpack_dms_GetNetworkTime_t::Tlvresult

8.525 unpack_dms_GetOfflineReason_t Struct Reference

Data Fields

- uint32_t * pReasonMask
- uint32_t * pbPlatform
- uint16_t Tlvresult

8.525.1 Detailed Description

This structure is used to store reason why the operating mode of the device is currently offline.

Parameters

pReasonMask[-OUT]	• Optional parameter • Bitmask of offline reasons – 0x00000001 - Host image configuration issue – 0x00000002 - PRI image configuration issue – 0x00000004 - PRI version incompatible – 0x00000008 - PRI copy issue – All others - Reserved – NULL pointer - Invalid data.
pbPlatform[OUT]	• Optional parameter • Is the device offline due to a platform restriction? – 0 - No – 1 - Yes – NULL pointer - Invalid data.
TlvResult	• Unpack Result

8.525.2 Field Documentation

8.525.2.1 uint32_t* unpack_dms_GetOfflineReason_t::pbPlatform

8.525.2.2 uint32_t* unpack_dms_GetOfflineReason_t::pReasonMask

8.525.2.3 uint16_t unpack_dms_GetOfflineReason_t::TlvResult

8.526 unpack_dms_GetPower_t Struct Reference

Data Fields

- uint32_t OperationMode
- uint32_t OfflineReason
- uint32_t HardwareControlledMode
- uint16_t TlvResult

8.526.1 Detailed Description

This structure used to store unpack_dms_GetPower parameters

Parameters

OperationMode	- operating mode. • 0 - Online (default). • 1 - Low power (airplane) mode. • 2 - Factory test mode. • 3 - Offline. • 4 - Reset. • 5 - Power off. • 6 - Persistent low power (airplane) mode. • 7 - Mode - only low power. • 0xff - Invalid data.

Note

Valid transitions for Power Modes

- Online to Low Power, Persistent low power, Factory test, Offline or Shut Down
- Low power to online, Persistent low power, Offline, or Shut Down
- Persistent low power to Online, Low power, Offline or Shut down
- Factory test to online
- Offline to Reset

Parameters

OfflineReason	- offline reason. • 0x0001 - Host image misconfiguration. • 0x0002 - PRI image misconfiguration. • 0x0004 - PRI version incompatible. • 0x0008 - Device memory is full,cannot copy PRI information. • 0xffff - Invalid data.
Hardware-ControlledMode	- hardware restricted mode. • 0x00 - FALSE. • 0x01 - TRUE. • 0xFF - Invalid data.
Tlvresult	- unpack Tlv Result. • eQCWWAN_ERR_NULL_TLV - Invalid Tlv Data.

8.526.2 Field Documentation

8.526.2.1 uint32_t unpack_dms_GetPower_t::HardwareControlledMode

8.526.2.2 uint32_t unpack_dms_GetPower_t::OfflineReason

8.526.2.3 uint32_t unpack_dms_GetPower_t::OperationMode

8.526.2.4 uint16_t unpack_dms_GetPower_t::Tlvresult

8.527 unpack_dms_GetPRLVersion_t Struct Reference

Data Fields

- uint8_t u8PRLPreference
- uint16_t u16PRLVersion
- uint16_t Tlvresult

8.527.1 Detailed Description

This structure used to store unpack_dms_GetPRLVersion parameters

Parameters

u8PRL-Preference	• PRL Preference – 0 - Unset – 1 - Set – 0xff invalid data.
u16PRLVersion	• PRL version of device. • 0xffff invalid data.
Tlvresult	• unpack Tlv Result

8.527.2 Field Documentation

8.527.2.1 uint16_t unpack_dms_GetPRLVersion_t::Tlvresult

8.527.2.2 uint16_t unpack_dms_GetPRLVersion_t::u16PRLVersion

8.527.2.3 uint8_t unpack_dms_GetPRLVersion_t::u8PRLPreference

8.528 unpack_dms_GetSerialNumbers_t Struct Reference

Data Fields

- char esn [255]
- char imei_no [255]
- char meid [255]
- char imeisv_svn [255]

8.528.1 Detailed Description

This structure used to store unpack_dms_GetSerialNumbers parameters

Parameters

esn	- Electronic Serial Number of the device. • NULL-terminated ESN string. Empty string is returned when ESN is not supported/programmed. • Invalid data : index 0 equal 0x7F.
imei_no	- International Mobile Equipment Identity of the device. • NULL terminated IMEI string. Empty string is returned when IMEI is not supported/programmed. • Invalid data : index 0 equal 0x7F.
meid	- Mobile Equipment Identifier of the device. • NULL-terminated MEID string. Empty string is returned when MEID is not supported/programmed. • Invalid data : index 0 equal 0x7F.
imeisv_svn	- NULL-terminated IMEI SVN string. Empty string is returned when IMEI SVN is not supported/programmed.imei software version revision. • Invalid data : index 0 equal 0x7F.

8.528.2 Field Documentation

8.528.2.1 char unpack_dms_GetSerialNumbers_t::esn[255]

8.528.2.2 char unpack_dms_GetSerialNumbers_t::imei_no[255]

8.528.2.3 char unpack_dms_GetSerialNumbers_t::imeisv_svn[255]

8.528.2.4 char unpack_dms_GetSerialNumbers_t::meid[255]

8.529 unpack_dms_GetUSBComp_t Struct Reference

Data Fields

- uint8_t USBComp [255]
- uint8_t NumSupUSBComps
- uint8_t SupUSBComps
- uint16_t Tlvresult

8.529.1 Detailed Description

This structure is used to store retrieved USB Composition

Parameters

USBComp	• Current USB Composition(optional parameter) • Values: – 0..5 - Reserved (non-QMI) – 6 - DM NMEA AT QMI – 7 - DM NMEA AT QMI1 QMI2 QMI3 – 8 - DM NMEA AT MBIM – 9 - MBIM – 10 - NMEA MBIM – 11 - DM MBIM – 12 - DM NMEA MBIM 13-22 are combined compositions. One is for Win8 MBIM interfaces, another is for legacy QMI interfaces – 13 - 6 for QMI, 8 for MBIM – 14 - 6 for QMI, 9 for MBIM – 15 - 6 for QMI, 10 for MBIM – 16 - 6 for QMI, 11 for MBIM – 17 - 6 for QMI, 12 for MBIM – 18 - 7 for QMI, 8 for MBIM – 19 - 7 for QMI, 9 for MBIM – 20 - 7 for QMI, 10 for MBIM – 21 - 7 for QMI, 11 for MBIM – 22 - 7 for QMI, 12 for MBIM
NumSupUSB-Comps	• Number of supported USB compositions in the parameter to follow • Range - 0-255 • Invalid data : USBComp index 0 equal 0x7F and NumSupUSBComps is equal 0.

SupUSBComps	• Optional parameter • List of supported USB compositions(1 Byte each - Max 255) • Total length is defined by pNumSupUSBComps parameter • Values: – 0..5 - Reserved (non-QMI) – 6 - DM NMEA AT QMI – 7 - DM NMEA AT QMI1 QMI2 QMI3 – 8 - DM NMEA AT MBIM – 9 - MBIM – 10 - NMEA MBIM – 11 - DM MBIM – 12 - DM NMEA MBIM 13-22 are combined compositions. One is for Win8 MBIM interfaces, another is for legacy QMI interfaces – 13 - 6 for QMI, 8 for MBIM – 14 - 6 for QMI, 9 for MBIM – 15 - 6 for QMI, 10 for MBIM – 16 - 6 for QMI, 11 for MBIM – 17 - 6 for QMI, 12 for MBIM – 18 - 7 for QMI, 8 for MBIM – 19 - 7 for QMI, 9 for MBIM – 20 - 7 for QMI, 10 for MBIM – 21 - 7 for QMI, 11 for MBIM – 22 - 7 for QMI, 12 for MBIM – 255 - invalid data.
Tlvresult	• unpack Tlv Result.

8.529.2 Field Documentation

8.529.2.1 uint8_t unpack_dms_GetUSBComp_t::NumSupUSBComps

8.529.2.2 uint8_t unpack_dms_GetUSBComp_t::SupUSBComps

8.529.2.3 uint16_t unpack_dms_GetUSBComp_t::Tlvresult

8.529.2.4 uint8_t unpack_dms_GetUSBComp_t::USBComp[255]

8.530 unpack_dms_GetVoiceNumber_t Struct Reference

Data Fields

- uint8_t voiceNumberSize
- char VoiceNumber [255]
- uint8_t minSize
- char MIN [255]
- uint16_t Tlvresult

8.530.1 Detailed Description

Structure to store the voice number in use by the device

Parameters

voiceNumber-Size	• Maximum number of characters (including NULL terminator) that the voice number array can contain.
VoiceNumber	• Voice number string: MDN or MS ISDN • Maximum Length is 255 Bytes • Invalid data : index 0 equal 0x7F and voiceNumberSize is equal 0.
minSize	• Maximum number of characters (including NULL terminator) that the MIN array can contain.
MIN	• Optional Parameter • MIN string: Empty string returned when MIN is not supported/ programmed. • Maximum Length is 255 Bytes • Invalid data : index 0 equal 0x7F and minSize is equal 0.
Tlvresult	• Unpack Result

8.530.2 Field Documentation

8.530.2.1 char unpack_dms_GetVoiceNumber_t::MIN[255]

8.530.2.2 uint8_t unpack_dms_GetVoiceNumber_t::minSize

8.530.2.3 uint16_t unpack_dms_GetVoiceNumber_t::Tlvresult

8.530.2.4 char unpack_dms_GetVoiceNumber_t::VoiceNumber[255]

8.530.2.5 uint8_t unpack_dms_GetVoiceNumber_t::voiceNumberSize

8.531 unpack_dms_ResetToFactoryDefaults_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.531.1 Detailed Description

This structure contains reset to factory default unpack

Parameters

Tlvresult	• Unpack Result

8.531.2 Field Documentation

8.531.2.1 uint16_t unpack_dms_ResetToFactoryDefaults_t::Tlvresult

8.532 unpack_dms_SetActivationStatusCallback_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.532.1 Detailed Description

This structure is used to store Set Service Activation Status callback parameter unpack.

Parameters

Tlvresult	• Unpack Result

8.532.2 Field Documentation

8.532.2.1 uint16_t unpack_dms_SetActivationStatusCallback_t::Tlvresult

8.533 unpack_dms_SetCrashAction_t Struct Reference

Data Fields

- uint8_t notused

8.533.1 Detailed Description

This structure is used to store unpack_dms_SetCrashAction parameters

Parameters

notused	• unpack Tlv result

8.533.2 Field Documentation

8.533.2.1 uint8_t unpack_dms_SetCrashAction_t::notused

8.534 unpack_dms_SetCustFeature_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.534.1 Detailed Description

This structure is used to store unpack_dms_SetCustFeature parameters

Parameters

Tlvresult	• unpack Tlv Result.

8.534.2 Field Documentation

8.534.2.1 uint16_t unpack_dms_SetCustFeature_t::Tlvresult

8.535 unpack_dms_SetCustFeaturesV2_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.535.1 Detailed Description

This structure contains customization settings set to modem unpack

Parameters

Tlvresult	• Unpack Result

8.535.2 Field Documentation

8.535.2.1 uint16_t unpack_dms_SetCustFeaturesV2_t::Tlvresult

8.536 unpack_dms_SetEventReport_ind_t Struct Reference

Data Fields

- dms_ActivationStatusTlv ActivationStatusTlv
- dms_OperatingModeTlv OperatingModeTlv
- uint16_t Tlvresult

8.536.1 Detailed Description

DMS Event Report indication structure

Parameters

ActivationStatus-Tlv	• See dms_ActivationStatusTlv
OperatingMode-Tlv	• See dms_OperatingModeTlv

Tlvresult	• Unpack Result

8.536.2 Field Documentation

8.536.2.1 dms_ActivationStatusTlv unpack_dms_SetEventReport_ind_t::ActivationStatusTlv

8.536.2.2 dms_OperatingModeTlv unpack_dms_SetEventReport_ind_t::OperatingModeTlv

8.536.2.3 uint16_t unpack_dms_SetEventReport_ind_t::Tlvresult

8.537 unpack_dms_SetEventReport_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.537.1 Detailed Description

This structure is used to store unpack_dms_SetEventReport parameters.

Parameters

Tlvresult	• unpack Tlv result

8.537.2 Field Documentation

8.537.2.1 uint16_t unpack_dms_SetEventReport_t::Tlvresult

8.538 unpack_dms_SetFirmwarePreference_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.538.1 Detailed Description

This structure is used to store unpack_dms_SetFirmwarePreference parameters

Parameters

Tlvresult	• unpack Tlv result

8.538.2 Field Documentation

8.538.2.1 uint16_t unpack_dms_SetFirmwarePreference_t::Tlvresult

8.539 unpack_dms_SetPower_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.539.1 Detailed Description

Structure to store unpack the operating mode of the device.

Parameters

Tlvresult	• unpack Tlv Result.

8.539.2 Field Documentation

8.539.2.1 uint16_t unpack_dms_SetPower_t::Tlvresult

8.540 unpack_dms_SetUSBComp_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.540.1 Detailed Description

This structure is used to store unpack USB composition information

Parameters

Tlvresult	• unpack Tlv Result.

8.540.2 Field Documentation

8.540.2.1 uint16_t unpack_dms_SetUSBComp_t::Tlvresult

8.541 unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t Struct Reference

Data Fields

- uint8_t type
- uint8_t source
- uint16_t Tlvresult

8.541.1 Detailed Description

This structure contains the TLV required to Get Reset Info.

Parameters

type[OUT]	• type of reset or power down, possible values listed below: – 0 - unknown – 1 - warm – 2 - hard – 3 - crash – 4 - power down
source[OUT]	• entity which initiated the reset or power down, possible values listed below: – 0 - unknown – 1 - user requested (AT!RESET, AT!BOOTHOLD, FW/PRI download - including host-initiated image switching) – 2 - hardware switch (W_DISABLE) – 3 - temperature critical – 4 - voltage critical – 5 - configuration update (SIM-based image switching, RMA reset, NVUPs which request a reset) – 6 - LWM2M (Light Weight M2M client (internal process for LWM2M)) – 7 - OMA-DM – 8 - FOTA
Tlvresult[OUT]	• Unpack Result 8 - eQCWWAN_ERR_NULL_TLV - Invalid Tlv Data.

8.541.2 Field Documentation

8.541.2.1 uint8_t unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t::source

8.541.2.2 uint16_t unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t::Tlvresult

8.541.2.3 uint8_t unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t::type

8.542 unpack_dms_SLQSDmsSwiGetResetInfo_t Struct Reference

Data Fields

- uint8_t type
- uint8_t source
- uint16_t Tlvresult

8.542.1 Detailed Description

This structure contains the TLV required to Get Reset Info.

Parameters

type[OUT]	• type of reset or power down, possible values listed below: – 0 - unknown – 1 - warm – 2 - hard – 3 - crash – 4 - power down – 255 - invalid data.
source[OUT]	• entity which initiated the reset or power down, possible values listed below: – 0 - unknown – 1 - user requested (AT!RESET, AT!BOOTHOLD, FW/PRI download - including host-initiated image switching) – 2 - hardware switch (W_DISABLE) – 3 - temperature critical – 4 - voltage critical – 5 - configuration update (SIM-based image switching, RMA reset, NVUPs which request a reset) – 6 - LWM2M (Light Weight M2M client (internal process for LWM2M)) – 7 - OMA-DM – 8 - FOTA – 255 - invalid data.
Tlvresult	• Unpack Result • eQCWWAN_ERR_NULL_TLV - Invalid Tlv Data.

8.542.2 Field Documentation

8.542.2.1 uint8_t unpack_dms_SLQSDmsSwiGetResetInfo_t::source

8.542.2.2 uint16_t unpack_dms_SLQSDmsSwiGetResetInfo_t::Tlvresult

8.542.2.3 uint8_t unpack_dms_SLQSDmsSwiGetResetInfo_t::type

8.543 unpack_dms_SLQSDmsSwiIndicationRegister_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.543.1 Detailed Description

This structure contains set registration state for different indication unpack

Parameters

Tlvresult	• Unpack Result

8.543.2 Field Documentation

8.543.2.1 uint16_t unpack_dms_SLQSDmsSwiIndicationRegister_t::TlvResult

8.544 unpack_dms_SLQSGetBandCapability_t Struct Reference

Data Fields

- uint64_t bandCapability
- int is_LteBandCapability_Available
- uint64_t LteBandCapability
- int is_TdsBandCapability_Available
- uint64_t TdsBandCapability

8.544.1 Detailed Description

This structure contains the Band Capabilities response.

Please check is_<Param_Name>_Available field for presence of optional parameters

Parameters

bandCapability[-OUT]	Bitmask of bands supported by the device • Bit 0 - Band class 0, A-system • Bit 1 - Band class 0, B-system • Bit 2 - Band class 1, all blocks • Bit 3 - Band class 2 • Bit 4 - Band class 3, A-system • Bit 5 - Band class 4, all blocks • Bit 6 - Band class 5, all blocks • Bit 7 - GSM DCS band (1800) • Bit 8 - GSM Extended GSM (E-GSM) band (900) • Bit 9 - GSM Primary GSM (P-GSM) band (900) • Bit 10 - Band class 6 • Bit 11 - Band class 7 • Bit 12 - Band class 8 • Bit 13 - Band class 9 • Bit 14 - Band class 10 • Bit 15 - Band class 11 • Bit 16 - GSM 450 band • Bit 17 - GSM 480 band • Bit 18 - GSM 750 band • Bit 19 - GSM 850 band • Bit 20 - GSM railways GSM band (900) • Bit 21 - GSM PCS band (1900) • Bit 22 - WCDMA (Europe, Japan, and China) 2100 band • Bit 23 - WCDMA US PCS 1900 band • Bit 24 - WCDMA (Europe and China) DCS 1800 band • Bit 25 - WCDMA US 1700 band • Bit 26 - WCDMA US 850 band • Bit 27 - WCDMA Japan 800 band • Bit 28 - Band class 12 • Bit 29 - Band class 14 • Bit 30 - Reserved • Bit 31 - Band class 15 • Bits 32 through 47 - Reserved • Bit 48 - WCDMA Europe 2600 band • Bit 49 - WCDMA Europe and Japan 900 band • Bit 50 - WCDMA Japan 1700 band • Bits 51 through 55 - Reserved • Bit 56 - Band class 16 • Bit 57 - Band class 17 • Bit 58 - Band class 18 • Bit 59 - Band class 19 • 0xffffffffffffffff - invalid data
is_LteBand-Capability_-Available[OUT]	LTE Band Capabilities Availability. • 0 : Unavailable. • 1 : Available.

LteBand-Capability[OUT]	Bitmask of LTE bands supported by the device • Bit 0 - LTE EUTRAN Band 1 UL:1920-1980; DL: 2110-2170 • Bit 1 - LTE EUTRAN Band 2 UL:1850-1910; DL: 1930-1990 • Bit 2 - LTE EUTRAN Band 3 UL:1710-1785; DL: 1805-1880 • Bit 3 - LTE EUTRAN Band 4 UL:1710-1755; DL: 2110-2155 • Bit 4 - LTE EUTRAN Band 5 UL: 824-849; DL: 869-894 • Bit 5 - LTE EUTRAN Band 6 UL: 830-840; DL: 875-885 • Bit 6 - LTE EUTRAN Band 7 UL:2500-2570; DL: 2620-2690 • Bit 7 - LTE EUTRAN Band 8 UL: 880-915; DL: 925-960 • Bit 8 - LTE EUTRAN Band 9 UL:1749.9-1784.9; DL: 1844.9-1879.9 • Bit 9 - LTE EUTRAN Band 10 UL:1710-1770; DL: 2110-2170 • Bit 10 - LTE EUTRAN Band 11 UL:1427.9-1452.9; DL: 1475.9-1500.9 • Bit 11 - LTE EUTRAN Band 12 UL:698-716; DL: 728-746 • Bit 12 - LTE EUTRAN Band 13 UL: 777-787; DL: 746-756 • Bit 13 - LTE EUTRAN Band 14 UL: 788-798; DL: 758-768 • Bits 14 and 15 - Reserved • Bit 16 - LTE EUTRAN Band 17 UL: 704-716; DL: 734-746 • Bit 17 - LTE EUTRAN Band 18 UL: 815-830; DL: 860-875 • Bit 18 - LTE EUTRAN Band 19 UL: 830-845; DL: 875-890 • Bit 19 - LTE EUTRAN Band 20 UL: 832-862; DL: 791-821 • Bit 20 - LTE EUTRAN Band 21 UL: 1447.9-1462.9; DL: 1495.9-1510.9 • Bit 21 - Reserved • Bit 22 - LTE EUTRAN Band 23 UL: 2000-2020; DL: 2180-2200 • Bit 23 - LTE EUTRAN Band 24 UL: 1626.5-1660.5; DL: 1525-1559 • Bit 24 - LTE EUTRAN Band 25 UL: 1850-1915; DL: 1930-1995 • Bit 25 - LTE EUTRAN Band 26 UL: 814-849; DL: 859-894 • Bit 26 - Reserved • Bit 27 - LTE EUTRAN Band 28 UL: 703-748; DL: 758-803 • Bit 28 - LTE EUTRAN Band 29 UL: 1850-1910 or 1710-1755; DL: 716-728 • Bits 29 through 31 - Reserved • Bit 32 - LTE EUTRAN Band 33 UL: 1900-1920; DL: 1900-1920 • Bit 33 - LTE EUTRAN Band 34 UL: 2010-2025; DL: 2010-2025 • Bit 34 - LTE EUTRAN Band 35 UL: 1850-1910; DL: 1850-1910 • Bit 35 - LTE EUTRAN Band 36 UL: 1930-1990; DL: 1930-1990 • Bit 36 - LTE EUTRAN Band 37 UL: 1910-1930; DL: 1910-1930 • Bit 37 - LTE EUTRAN Band 38 UL: 2570-2620; DL: 2570-2620 • Bit 38 - LTE EUTRAN Band 39 UL: 1880-1920; DL: 1880-1920 • Bit 39 - LTE EUTRAN Band 40 UL: 2300-2400; DL: 2300-2400 • Bit 40 - LTE EUTRAN Band 41 UL: 2496-2690; DL: 2496-2690 • Bit 41 - LTE EUTRAN Band 42 UL: 3400-3600; DL: 3400-3600 • Bit 42 - LTE EUTRAN Band 43 UL: 3600-3800; DL: 3600-3800 • Bits 43 through 64 - Reserved
is_TdsBand-Capability_-Available[OUT]	TDS Band Capabilities Availability. • 0 : Unavailable. • 1 : Available.

TdsBand-Capability[OUT]	Bitmask of TDS bands supported by the device. • Bit 0 - TDS Band A 1900 to 1920 MHz, 2010 to 2020 MHz • Bit 1 - TDS Band B 1850 to 1910 MHz, 1930 to 1990 MHz • Bit 2 - TDS Band C 1910 to 1930 MHz • Bit 3 - TDS Band D 2570 to 2620 MHz • Bit 4 - TDS Band E 2300 to 2400 MHz • Bit 5 - TDS Band F 1880 to 1920 MHz

8.544.2 Field Documentation

8.544.2.1 uint64_t unpack_dms_SLQSGetBandCapability_t::bandCapability

8.544.2.2 int unpack_dms_SLQSGetBandCapability_t::is_LteBandCapability_Available

8.544.2.3 int unpack_dms_SLQSGetBandCapability_t::is_TdsBandCapability_Available

8.544.2.4 uint64_t unpack_dms_SLQSGetBandCapability_t::LteBandCapability

8.544.2.5 uint64_t unpack_dms_SLQSGetBandCapability_t::TdsBandCapability

8.545 unpack_dms_SLQSGetERIFile_t Struct Reference

Data Fields

- uint16_t Tlvresult
- eriDataparams eriFile

8.545.1 Detailed Description

This structure contains Get ERI file unpack

Parameters

Tlvresult	• Unpack Result • eQCWWAN_ERR_NULL_TLV - Invalid TLV data.
eriFile	• Pointer to structure ERIFileparams • See eriDataparams for more information

8.545.2 Field Documentation

8.545.2.1 eriDataparams unpack_dms_SLQSGetERIFile_t::eriFile

8.545.2.2 uint16_t unpack_dms_SLQSGetERIFile_t::Tlvresult

8.546 unpack_dms_SLQSSwiClearDyingGaspStatistics_t Struct Reference

Data Fields

- uint16_t TlvResult

8.546.1 Detailed Description

This structure contains Clear Dying GASP unpack

Parameters

TlvResult	• Unpack Result

8.546.2 Field Documentation

8.546.2.1 uint16_t unpack_dms_SLQSSwiClearDyingGaspStatistics_t::TlvResult

8.547 unpack_dms_SLQSSwiGetCrashInfo_t Struct Reference

Data Fields

- uint16_t TlvResult
- crashInfoParams crashInfoParam

8.547.1 Detailed Description

This structure contains SWI get crash information unpack information

Parameters

TlvResult	• Unpack Result
crashInfoParam[-OUT]	• See crashInfoParams

8.547.2 Field Documentation

8.547.2.1 crashInfoParams unpack_dms_SLQSSwiGetCrashInfo_t::crashInfoParam

8.547.2.2 uint16_t unpack_dms_SLQSSwiGetCrashInfo_t::TlvResult

8.548 unpack_dms_SLQSSwiGetDyingGaspCfg_t Struct Reference

Data Fields

- packgetDyingGaspCfg * pGetDyingGaspCfg
- uint16_t TlvResult

8.548.1 Detailed Description

This structure contains Get Dying GASP Config unpack

Parameters

pGetDyingGasp-Cfg	• See packgetDyingGaspCfg • NULL pDestSMSNum for invalid data. • NULL pDestSMSContent for invalid data.
Tlvresult	• Unpack Result

8.548.2 Field Documentation

8.548.2.1 packgetDyingGaspCfg∗ unpack_dms_SLQSSwiGetDyingGaspCfg_t::pGetDyingGaspCfg

8.548.2.2 uint16_t unpack_dms_SLQSSwiGetDyingGaspCfg_t::Tlvresult

8.549 unpack_dms_SLQSSwiGetDyingGaspStatistics_t Struct Reference

Data Fields

- packgetDyingGaspStatistics ∗ pGetDyingGaspStatistics
- uint16_t Tlvresult

8.549.1 Detailed Description

This structure contains Get Dying GASP Statistics unpack.

Parameters

pGetDyingGasp-Statistics	• See packgetDyingGaspStatistics • NULL pTimeStamp for invalid Timestamp data. • NULL pSMSAttemptedFlag for invalid SMS attempted data.
Tlvresult	• Unpack Result

8.549.2 Field Documentation

8.549.2.1 packgetDyingGaspStatistics∗ unpack_dms_SLQSSwiGetDyingGaspStatistics_t::pGetDyingGaspStatistics

8.549.2.2 uint16_t unpack_dms_SLQSSwiGetDyingGaspStatistics_t::Tlvresult

8.550 unpack_dms_SLQSSwiGetFirmwareCurr_t Struct Reference

Data Fields

- uint8_t numEntries
- image_info_t * pCurrImgInfo
- char priver [16]
- char pkgver [16]
- char fwvers [16]
- char carrier [16]

8.550.1 Detailed Description

This structure is used to store unpack_dms_SLQSSwiGetFirmwareCurr parameters

Parameters

numEntries[IN/-OUT]	• Number of entries in the image list to follow • The size of the list pCurrImgInfo must be specified when calling the API
pCurrImgInfo[O-UT]	• Currently Active Image List
priver[OUT]	• PRI version of the currently running firmware • Invalid Data - index 0 equal 0x7F.
pkgver[OUT]	• Package version of the currently running firmware • Invalid Data - index 0 equal 0x7F.
fwvers[OUT]	• firmware version of the currently running firmware • Invalid Data - index 0 equal 0x7F.
carrier[OUT]	• Carrier string of the currently running firmware • Invalid Data - index 0 equal 0x7F.

8.550.2 Field Documentation

8.550.2.1 char unpack_dms_SLQSSwiGetFirmwareCurr_t::carrier[16]

8.550.2.2 char unpack_dms_SLQSSwiGetFirmwareCurr_t::fwvers[16]

8.550.2.3 uint8_t unpack_dms_SLQSSwiGetFirmwareCurr_t::numEntries

8.550.2.4 image_info_t* unpack_dms_SLQSSwiGetFirmwareCurr_t::pCurrImgInfo

8.550.2.5 char unpack_dms_SLQSSwiGetFirmwareCurr_t::pkgver[16]

8.550.2.6 char unpack_dms_SLQSSwiGetFirmwareCurr_t::priver[16]

8.551 unpack_dms_SLQSSwiGetFwUpdateStatus_t Struct Reference

Data Fields

- uint32_t ResCode
- uint8_t imgType
- uint32_t refData
- uint8_t refString [15]
- uint8_t logString [255]
- uint16_t Tlvresult

8.551.1 Detailed Description

This structure is used to store Firmware Update Status

Parameters

ResCode	• FW Update Result Code • Values: – 0x00000001 - Successful – 0x000000FF - Invalid Data. – 0xFFFFFFFF - Unknown (due to power off reset after firmware update) – 0x100000nn - File update errors while nn will be the exact error number: * 00 - General error – 0x200000nn - NVUP update errors while nn will be the exact error number: * 00 - General error – 0x40000nnn - FOTA update agent errors while nnn will be the exact error number: * 000 ∼ 0FF - Insignia defined error code * 100 ∼ 1FF - Sierra defined error code * See qaGobiApiTableFwDldErrorCodes.h for more detailed information – 0x800000nn - FDT/SSDP reported errors while nn will be the exact error number * See qaGobiApiTableFwDldErrorCodes.h for more detailed information
imgType	• Optional parameter • Firmware image type that failed the update • 0xff - Invalid Data.
refData	• Optional parameter • Failed image reference data • This is normally the offset of the image that caused the failure • 0xff - Invalid Data.
refString	• Optional parameter • Failed image reference string. This is normally the partition name of the image that caused the failure if applicable. • Invalid Data - index 0 equal 0xFF.

logString	• Optional parameter • Failed image reference string. This is normally the partition name of the image that caused the failure if applicable. • Invalid Data - index 0 equal 0xFF.
Tlvresult	• Unpack Result

8.551.2 Field Documentation

8.551.2.1 uint8_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::imgType

8.551.2.2 uint8_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::logString[255]

8.551.2.3 uint32_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::refData

8.551.2.4 uint8_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::refString[15]

8.551.2.5 uint32_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::ResCode

8.551.2.6 uint16_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::Tlvresult

8.552 unpack_dms_SLQSSwiGetHostDevInfo_t Struct Reference

Data Fields

- uint16_t Tlvresult
- char manString [255]
- char modelString [255]
- char swVerString [255]
- char plasmaIDString [255]

8.552.1 Detailed Description

This structure contains SWI get host device info unpack information

Parameters

Tlvresult	• unpack Result
manString[OUT]	• Host Device Manufacturer Name • Null terminated ASCII String • Invalid Data - index 0 equal 0x7F.
modelString[OUT]	• Host Device Model String • Null terminated ASCII String • Invalid Data - index 0 equal 0x7F.

swVerString[OUT]	• Host Device Software Version String • Null terminated ASCII string • Invalid Data - index 0 equal 0x7F.
plasmaIDString[OUT]	• Host Device Plasma ID String • Null terminated alphanumeric ASCII String. • Invalid Data - index 0 equal 0x7F.

8.552.2 Field Documentation

8.552.2.1 char unpack_dms_SLQSSwiGetHostDevInfo_t::manString[255]

8.552.2.2 char unpack_dms_SLQSSwiGetHostDevInfo_t::modelString[255]

8.552.2.3 char unpack_dms_SLQSSwiGetHostDevInfo_t::plasmaIDString[255]

8.552.2.4 char unpack_dms_SLQSSwiGetHostDevInfo_t::swVerString[255]

8.552.2.5 uint16_t unpack_dms_SLQSSwiGetHostDevInfo_t::Tlvresult

8.553 unpack_dms_SLQSSwiGetOSInfo_t Struct Reference

Data Fields

- uint16_t Tlvresult
- char nameString [255]
- char versionString [255]

8.553.1 Detailed Description

This structure contains SWI get host os info unpack information

Parameters

Tlvresult	• Unpack Result
nameString[OUT]	• Host operating system name • Invalid Data - index 0 equal 0xFF.
VersionString[OUT]	• Host operating system version • Invalid Data - index 0 equal 0xFF.

8.553.2 Field Documentation

8.553.2.1 char unpack_dms_SLQSSwiGetOSInfo_t::nameString[255]

8.553.2.2 uint16_t unpack_dms_SLQSSwiGetOSInfo_t::Tlvresult

8.553.2.3 char unpack_dms_SLQSSwiGetOSInfo_t::versionString[255]

8.554 unpack_dms_SLQSSwiGetSerialNoExt_t Struct Reference

Data Fields

- uint16_t Tlvresult
- char meidString [8]

8.554.1 Detailed Description

This structure contains SWI get device serial number extension unpack information

Parameters

Tlvresult	• pack Result
meidString[OUT]	• optional parameter, mobile equipment identifier • Invalid Data - index 0 equal 0x7F.

8.554.2 Field Documentation

8.554.2.1 char unpack_dms_SLQSSwiGetSerialNoExt_t::meidString[8]

8.554.2.2 uint16_t unpack_dms_SLQSSwiGetSerialNoExt_t::Tlvresult

8.555 unpack_dms_SLQSSwiSetDyingGaspCfg_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.555.1 Detailed Description

This structure contains set Dying GASP Config unpack

Parameters

Tlvresult	• Unpack Result

8.555.2 Field Documentation

8.555.2.1 uint16_t unpack_dms_SLQSSwiSetDyingGaspCfg_t::TlvResult

8.556 unpack_dms_SLQSSwiSetHostDevInfo_t Struct Reference

Data Fields

- uint16_t TlvResult

8.556.1 Detailed Description

This structure contains SWI set host dev info unpack

Parameters

TlvResult	• Unpack Result

8.556.2 Field Documentation

8.556.2.1 uint16_t unpack_dms_SLQSSwiSetHostDevInfo_t::TlvResult

8.557 unpack_dms_SLQSSwiSetOSInfo_t Struct Reference

Data Fields

- uint16_t TlvResult

8.557.1 Detailed Description

This structure contains SWI set host OS info unpack

Parameters

TlvResult	• Unpack Result

8.557.2 Field Documentation

8.557.2.1 uint16_t unpack_dms_SLQSSwiSetOSInfo_t::TlvResult

8.558 unpack_dms_SLQSUIMGetState_t Struct Reference

Data Fields

- uint8_t state
- uint16_t TlvResult

8.558.1 Detailed Description

This structure contains UIM get state unpack information

Parameters

state[OUT]	• UIM state
Tlvresult	• Unpack Result

8.558.2 Field Documentation

8.558.2.1 uint8_t unpack_dms_SLQSUIMGetState_t::state

8.558.2.2 uint16_t unpack_dms_SLQSUIMGetState_t::Tlvresult

8.559 unpack_dms_UIMGetControlKeyStatus_t Struct Reference

Data Fields

- uint8_t facilityState
- uint8_t verifyRetriesLeft
- uint8_t unblockRetriesLeft
- uint16_t Tlvresult

8.559.1 Detailed Description

This structure contains PIN retries status

Parameters

facilityState[OUT]	• Control key status – 0 - Deactivated – 1 - Activated – 2 - Blocked – 0xFF - Invalid Data.
verifyRetriesLeft[OUT]	• Optional parameter • Upon operational failure, this will indicate number of retries left, after which PIN will be blocked. • 0xFF - Invalid Data.
unblockRetriesLeft[OUT]	• Optional parameter • Upon operational failure, this will indicate number of unblock retries left, after which the PIN will be permanently blocked i.e. UIM is unusable. • 0xFF - Invalid Data.
Tlvresult	• Unpack Result

8.559.2 Field Documentation

8.559.2.1 uint8_t unpack_dms_UIMGetControlKeyStatus_t::facilityState

8.559.2.2 uint16_t unpack_dms_UIMGetControlKeyStatus_t::Tlvresult

8.559.2.3 uint8_t unpack_dms_UIMGetControlKeyStatus_t::unblockRetriesLeft

8.559.2.4 uint8_t unpack_dms_UIMGetControlKeyStatus_t::verifyRetriesLeft

8.560 unpack_dms_UIMGetICCID_t Struct Reference

Data Fields

- uint8_t stringSize
- uint8_t String [255]
- uint16_t Tlvresult

8.560.1 Detailed Description

This structure is used to store unpack_dms_UIMGetICCID parameters.

Parameters

stringSize	• Size of String.
String	• ICCID String. • Maximum Length is 255 Bytes
Tlvresult	• Unack result. 8 - eQCWWAN_ERR_NULL_TLV - Invalid Tlv Data.

8.560.2 Field Documentation

8.560.2.1 uint8_t unpack_dms_UIMGetICCID_t::String[255]

8.560.2.2 uint8_t unpack_dms_UIMGetICCID_t::stringSize

8.560.2.3 uint16_t unpack_dms_UIMGetICCID_t::Tlvresult

8.561 unpack_dms_UIMGetPINStatus_t Struct Reference

Data Fields

- uint8_t p1Status
- uint8_t p1VerifyRetriesLeft
- uint8_t p1UnblockRetriesLeft
- uint8_t p2Status
- uint8_t p2VerifyRetriesLeft
- uint8_t p2UnblockRetriesLeft

- uint16_t Tlvresult

8.561.1 Detailed Description

This structure contains Get PIN Status unpack information

Parameters

p1Status[OUT]	• PIN1 status(0xFFFFFFFF - Unknown) – 0 - PIN not initialized – 1 - PIN enabled, not verified – 2 - PIN enabled, verified – 3 - PIN disabled – 4 - PIN blocked – 5 - PIN permanently blocked – 0xFF - Invalid data.
p1VerifyRetries-Left[OUT]	• Optional parameter • Upon operational failure, this will indicate number of retries left of PIN1, after which PIN will be blocked. • 0xFF - Invalid data.
p1Unblock-RetriesLeft[OUT]	• Optional parameter • Upon operational failure, this will indicate number of unblock retries left of PIN1, after which the PIN will be permanently blocked i.e. UIM is unusable. • 0xFF - Invalid data.
p2Status[OUT]	• PIN2 status(0xFFFFFFFF - Unknown) – 0 - PIN not initialized – 1 - PIN enabled, not verified – 2 - PIN enabled, verified – 3 - PIN disabled – 4 - PIN blocked – 5 - PIN permanently blocked – 0xFF - Invalid data.
p2VerifyRetries-Left[OUT]	• Optional parameter • Upon operational failure, this will indicate number of retries left of PIN2, after which PIN will be blocked. • 0xFF - Invalid data.
p2Unblock-RetriesLeft[OUT]	• Optional parameter • Upon operational failure, this will indicate number of unblock retries left of PIN2, after which the PIN will be permanently blocked i.e. UIM is unusable. • 0xFF - Invalid data.

Tlvresult	• Unpack Result

8.561.2 Field Documentation

8.561.2.1 uint8_t unpack_dms_UIMGetPINStatus_t::p1Status

8.561.2.2 uint8_t unpack_dms_UIMGetPINStatus_t::p1UnblockRetriesLeft

8.561.2.3 uint8_t unpack_dms_UIMGetPINStatus_t::p1VerifyRetriesLeft

8.561.2.4 uint8_t unpack_dms_UIMGetPINStatus_t::p2Status

8.561.2.5 uint8_t unpack_dms_UIMGetPINStatus_t::p2UnblockRetriesLeft

8.561.2.6 uint8_t unpack_dms_UIMGetPINStatus_t::p2VerifyRetriesLeft

8.561.2.7 uint16_t unpack_dms_UIMGetPINStatus_t::Tlvresult

8.562 unpack_dms_UIMSetControlKeyProtection_t Struct Reference

Data Fields

- uint8_t verifyRetriesLeft
- uint16_t Tlvresult

8.562.1 Detailed Description

This structure contains UIM Set control key protection unpack information

Parameters

verifyRetries-Left[OUT]	• Optional parameter • number of retries left after which the control key is blocked
Tlvresult	• Unpack Result

8.562.2 Field Documentation

8.562.2.1 uint16_t unpack_dms_UIMSetControlKeyProtection_t::Tlvresult

8.562.2.2 uint8_t unpack_dms_UIMSetControlKeyProtection_t::verifyRetriesLeft

8.563 unpack_dms_UIMSetPINProtection_t Struct Reference

Data Fields

- uint8_t verifyRetriesLeft

- uint8_t unblockRetriesLeft
- uint16_t Tlvresult

8.563.1 Detailed Description

This structure contains PIN retries status

Parameters

verifyRetries-Left[OUT]	• Optional parameter • Upon operational failure, this will indicate number of retries left, after which PIN will be blocked. • 0xFF - Invalid data.
unblockRetries-Left[OUT]	• Optional parameter • Upon operational failure, this will indicate number of unblock retries left, after which the PIN will be permanently blocked i.e. UIM is unusable. • 0xFF - Invalid data.
Tlvresult[OUT]	• Unpack Result

8.563.2 Field Documentation

8.563.2.1 uint16_t unpack_dms_UIMSetPINProtection_t::Tlvresult

8.563.2.2 uint8_t unpack_dms_UIMSetPINProtection_t::unblockRetriesLeft

8.563.2.3 uint8_t unpack_dms_UIMSetPINProtection_t::verifyRetriesLeft

8.564 unpack_dms_UIMUnblockControlKey_t Struct Reference

Data Fields

- uint8_t unblockRetriesLeft
- uint16_t Tlvresult

8.564.1 Detailed Description

This structure contains UIM Set control key protection unpack information

Parameters

unblockRetries-Left[OUT]	• Optional parameter • number of unblock retries left after which the control key is permanently blocked • 0xff - Invalid data.
Tlvresult[OUT]	• Unpack Result

8.564.2 Field Documentation

8.564.2.1 uint16_t unpack_dms_UIMUnblockControlKey_t::Tlvresult

8.564.2.2 uint8_t unpack_dms_UIMUnblockControlKey_t::unblockRetriesLeft

8.565 unpack_fms_GetImagesPreference_t Struct Reference

Data Fields

- uint32_t ImageListSize
- FMSPrefImageList * pImageList
- uint16_t Tlvresult

8.565.1 Detailed Description

This structure contains the Get Image Preference information unpack

Parameters

listSize	• The number of elements in the image list
pListEntries	• Array of Image entries with size provided by previous field • See FMSImageElement
Tlvresult	• Unpack result

8.565.2 Field Documentation

8.565.2.1 uint32_t unpack_fms_GetImagesPreference_t::ImageListSize

8.565.2.2 FMSPrefImageList* unpack_fms_GetImagesPreference_t::pImageList

8.565.2.3 uint16_t unpack_fms_GetImagesPreference_t::Tlvresult

8.566 unpack_fms_GetStoredImages_t Struct Reference

Data Fields

- uint32_t imagelistSize
- FMSImageList imageList
- uint16_t Tlvresult

8.566.1 Detailed Description

This structure contains the Get Stored Images unpack

Parameters

listSize	• The number of elements in the image list
imageList	• Array of Image entries with size provided by previous field • See FMSImageElement
TlvResult	• Unpack result

8.566.2 Field Documentation

8.566.2.1 FMSImageList unpack_fms_GetStoredImages_t::imageList

8.566.2.2 uint32_t unpack_fms_GetStoredImages_t::imagelistSize

8.566.2.3 uint16_t unpack_fms_GetStoredImages_t::TlvResult

8.567 unpack_fms_SetImagesPreference_t Struct Reference

Data Fields

- uint32_t ImageTypesSize
- uint8_t ImageTypes [255]
- uint16_t TlvResult

8.567.1 Detailed Description

This structure contains the Set Images Preference unpack

Parameters

ImageTypesSize	• Image Type Size
ImageTypes	• Image Type
TlvResult	• Unpack result

8.567.2 Field Documentation

8.567.2.1 uint8_t unpack_fms_SetImagesPreference_t::ImageTypes[255]

8.567.2.2 uint32_t unpack_fms_SetImagesPreference_t::ImageTypesSize

8.567.2.3 uint16_t unpack_fms_SetImagesPreference_t::TlvResult

8.568 unpack_ims_SLQSGetIMSSMSConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- uint8_t * pSMSFormat
- uint8_t * pSMSOverIPNwInd
- uint8_t * pPhoneCtxtURILen
- uint8_t * pPhoneCtxtURI

8.568.1 Detailed Description

This structure contains the SLQSGetIMSSMSConfig unpack parameters.

Parameters

pSettingResp	• Settings Response
pSMSFormat	• SMS format – 0 - 3GPP – 1 - 3GPP2
pSMSOverIPNw-Ind	• SMS over IP Network Indication Flag – TRUE - Turn on mobile-originated SMS – FALSE - Turn off mobile-originated SMS
pPhoneCtxtURI-Len[IN/OUT]	• Size in bytes assigned to the Phone context Universal Resource Identifier to follow
pPhoneCtxtURI	• Phone context universal resource identifier • Length of this string must be specified in pPhoneCtxtURILen parameter

8.568.2 Field Documentation

8.568.2.1 uint8_t* unpack_ims_SLQSGetIMSSMSConfig_t::pPhoneCtxtURI

8.568.2.2 uint8_t* unpack_ims_SLQSGetIMSSMSConfig_t::pPhoneCtxtURILen

8.568.2.3 uint8_t* unpack_ims_SLQSGetIMSSMSConfig_t::pSettingResp

8.568.2.4 uint8_t* unpack_ims_SLQSGetIMSSMSConfig_t::pSMSFormat

8.568.2.5 uint8_t* unpack_ims_SLQSGetIMSSMSConfig_t::pSMSOverIPNwInd

8.569 unpack_ims_SLQSGetIMSUserConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- uint8_t * pIMSDomainLen
- uint8_t * pIMSDomain

8.569.1 Detailed Description

This structure contains the SLQSGetIMSUserConfig pack parameters.

Parameters

pSettingResp	• Settings Response
pIMSDomain-Len[IN/OUT]	• Length of IMS Domain Name to follow
pIMSDomain	• IMS domain name • Length of this string must be specified in pIMSDomainLen parameter

8.569.2 Field Documentation

8.569.2.1 uint8_t* unpack_ims_SLQSGetIMSUserConfig_t::pIMSDomain

8.569.2.2 uint8_t* unpack_ims_SLQSGetIMSUserConfig_t::pIMSDomainLen

8.569.2.3 uint8_t* unpack_ims_SLQSGetIMSUserConfig_t::pSettingResp

8.570 unpack_ims_SLQSGetIMSVoIPConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- uint16_t * pSessionExpiryTimer
- uint16_t * pMinSessionExpiryTimer
- uint8_t * pAmrWbEnable
- uint8_t * pScrAmrEnable
- uint8_t * pScrAmrWbEnable
- uint8_t * pAmrMode
- uint16_t * pAmrWBMode
- uint8_t * pAmrOctetAligned
- uint8_t * pAmrWBOctetAligned
- uint16_t * pRingingTimer
- uint16_t * pRingBackTimer
- uint16_t * pRTPRTCPInactTimer

8.570.1 Detailed Description

This structure contains the SLQSGetIMSVoIPConfig unpack parameters.

Parameters

pSettingResp	• Settings Response. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE
pSessionExpiry-Timer	• Session duration, in seconds
pMinSession-ExpiryTimer	• Minimum allowed value for session expiry timer, in seconds
pAmrWbEnable	• Flag to enable/disable Adaptive Multirate Codec(AMR) WideBand(WB) audio • Values: – True - Enable – False - Disable
pScrAmrEnable	• Flag to enable/disable Source Control Rate(SCR) for AMR NarrowBand (NB) • Values: – True - Enable – False - Disable
pScrAmrWb-Enable	• Flag to enable/disable SCR for AMR WB Audio • Values: – True - Enable – False - Disable
pAmrMode	• BitMask for AMR NB modes allowed • Values: – 0x1 - 4.75 kbps – 0x2 - 5.15 kbps – 0x4 - 5.9 kbps – 0x8 - 6.17 kbps – 0x10 - 7.4 kbps – 0x20 - 7.95 kbps – 0x40 - 10.2 kbps – 0x80 - 12.2 kbps

pAmrWBMode	• BitMask for AMR WB modes allowed • Values: – 0x1 - 6.60 kbps – 0x2 - 8.85 kbps – 0x4 - 12.65 kbps – 0x8 - 14.25 kbps – 0x10 - 15.85 kbps – 0x20 - 18.25 kbps – 0x40 - 19.85 kbps – 0x80 - 23.05 kbps – 0x100 - 23.85 kbps
pAmrOctet-Aligned	• Flag to indicate if the octet is aligned for AMR NB Audio • Values: – True - Aligned – False - Not aligned, Bandwidth Efficient mode
pAmrWBOctet-Aligned	• Flag to indicate if the octet is aligned for AMR WB Audio • Values: – True - Aligned – False - Not aligned, Bandwidth Efficient mode
pRingingTimer	• Duration of ringing timer, in seconds. The ringing timer starts on the ringing event. If the call is not answered within the duration of this timer, the call is disconnected.
pRingBackTimer	• Duration of ringback timer, in seconds. The ringback timer starts on the ringback event. If the call is not answered within the duration of this timer, the call is disconnected.
pRTPRTCP-InactTimer	• Duration of RTP/RTCP inactivity timer, in seconds. If no RTP/RTCP packet is received prior to the expiry of this timer, the call is disconnected.

8.570.2 Field Documentation

8.570.2.1 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pAmrMode

8.570.2.2 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pAmrOctetAligned

8.570.2.3 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pAmrWbEnable

8.570.2.4 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pAmrWBMode

8.570.2.5 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pAmrWBOctetAligned

8.570.2.6 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pMinSessionExpiryTimer

8.570.2.7 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pRingBackTimer

8.570.2.8 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pRingingTimer

8.570.2.9 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pRTPRTCPInactTimer

8.570.2.10 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pScrAmrEnable

8.570.2.11 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pScrAmrWbEnable

8.570.2.12 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pSessionExpiryTimer

8.570.2.13 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pSettingResp

8.571 unpack_ims_SLQSGetRegMgrConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- uint16_t * pPCSCFPort
- uint8_t * pPriCSCFPortNameLen
- uint8_t * pPriCSCFPortName
- uint8_t * pIMSTestMode

8.571.1 Detailed Description

This structure contains the SLQSGetRegMgrConfig unpack parameters.

Parameters

pSettingResp	• Settings Response
pPCSCFPort	• Proxy call session control function port
pPriCSCFPort-NameLen(IN/O-UT)	• Size in bytes assigned to the primary CSCF Port name parameter to follow
pPriCSCFPort-Name	• Call Session control port, fully qualified domain name • Length of this string must be specified in pPriCSCFPortNameLen parameter
pIMSTestMode	• IMS Test mode Enabled. – TRUE - Enabled – FALSE - Disabled

Note

pPriCSCFPortNameLen must be set to a valid value during API call to retrieve pPriCSCFPortName.

8.571.2 Field Documentation

8.571.2.1 uint8_t* unpack_ims_SLQSGetRegMgrConfig_t::pIMSTestMode

8.571.2.2 uint16_t* unpack_ims_SLQSGetRegMgrConfig_t::pPCSCFPort

8.571.2.3 uint8_t* unpack_ims_SLQSGetRegMgrConfig_t::pPriCSCFPortName

8.571.2.4 uint8_t* unpack_ims_SLQSGetRegMgrConfig_t::pPriCSCFPortNameLen

8.571.2.5 uint8_t* unpack_ims_SLQSGetRegMgrConfig_t::pSettingResp

8.572 unpack_ims_SLQSGetSIPConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- uint16_t * pSIPLocalPort
- uint32_t * pTimerSIPReg
- uint32_t * pSubscribeTimer
- uint32_t * pTimerT1
- uint32_t * pTimerT2
- uint32_t * pTimerTf
- uint8_t * pSigCompEnabled

8.572.1 Detailed Description

This structure contains the SLQSGetSIPConfig unpack parameters.

Parameters

pSettingResp	• Settings Response
pSIPLocalPort	• Primary call session control function SIP port number
pTimerSIPReg	• Initial SIP registration duration from the User equipment, in seconds
pSubscribeTimer	• Duration of the subscription by the UE for IMS registration notifications, in seconds
pTimerT1	• RTT estimate, in milliseconds
pTimerT2	• The maximum retransmit interval for non-invite requests and invite responses, in milliseconds
pTimerTf	• Non-invite transaction timeout timer, in milliseconds
pSigComp-Enabled	• Sig Comp Status – TRUE - Sig Comp Enabled – FALSE - Sig Comp Disabled

8.572.2 Field Documentation

8.572.2.1 uint8_t* unpack_ims_SLQSGetSIPConfig_t::pSettingResp

8.572.2.2 uint8_t* unpack_ims_SLQSGetSIPConfig_t::pSigCompEnabled

8.572.2.3 uint16_t* unpack_ims_SLQSGetSIPConfig_t::pSIPLocalPort

8.572.2.4 uint32_t* unpack_ims_SLQSGetSIPConfig_t::pSubscribeTimer

8.572.2.5 uint32_t* unpack_ims_SLQSGetSIPConfig_t::pTimerSIPReg

8.572.2.6 uint32_t* unpack_ims_SLQSGetSIPConfig_t::pTimerT1

8.572.2.7 uint32_t* unpack_ims_SLQSGetSIPConfig_t::pTimerT2

8.572.2.8 uint32_t* unpack_ims_SLQSGetSIPConfig_t::pTimerTf

8.573 unpack_ims_SLQSSetIMSSMSConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp

8.573.1 Detailed Description

This structure contains the SLQSSetIMSSMSConfig unpack parameters.

Parameters

pSettingResp	• Settings standard response type. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE

8.573.2 Field Documentation

8.573.2.1 uint8_t* unpack_ims_SLQSSetIMSSMSConfig_t::pSettingResp

8.574 unpack_ims_SLQSSetIMSUserConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp

8.574.1 Detailed Description

This structure contains the SLQSSetIMSUserConfig unpack parameters.

Parameters

pSettingResp	• Settings standard response type. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE

8.574.2 Field Documentation

8.574.2.1 uint8_t* unpack_ims_SLQSSetIMSUserConfig_t::pSettingResp

8.575 unpack_ims_SLQSSetIMSVoIPConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp

8.575.1 Detailed Description

This structure contains the SLQSSetIMSVoIPConfig unpack parameters.

Parameters

pSettingResp	• Settings standard response type. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE

8.575.2 Field Documentation

8.575.2.1 uint8_t* unpack_ims_SLQSSetIMSVoIPConfig_t::pSettingResp

8.576 unpack_ims_SLQSSetRegMgrConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp

8.576.1 Detailed Description

This structure contains the SLQSSetRegMgrConfig unpack parameters.

Parameters

pSettingResp	• Settings standard response type. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE

8.576.2 Field Documentation

8.576.2.1 uint8_t* unpack_ims_SLQSSetRegMgrConfig_t::pSettingResp

8.577 unpack_ims_SLQSSetSIPConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp

8.577.1 Detailed Description

This structure contains the SLQSSetSIPConfig unpack parameters.

Parameters

pSettingResp	• Settings standard response type. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE

8.577.2 Field Documentation

8.577.2.1 uint8_t* unpack_ims_SLQSSetSIPConfig_t::pSettingResp

8.578 unpack_imsa_SLQSGetIMSARegStatus_t Struct Reference

Data Fields

- uint8_t ImsRegStatus
- uint16_t ImsRegErrCode
- uint32_t NewImsRegStatus

8.578.1 Detailed Description

This structure contains response parameters of registration status.

Parameters

ImsRegStatus	• IMS Registration Status (Deprecated). • Values – TRUE - UE is registered on the IMS network – FALSE - UE is not registered on the IMS network – 0xff - not provided by modem
ImsRegErrCode	• IMS Registration Error Code. • An error code is returned when the IMS registration status is IMSA_STATUS_NOT_REGISTERED. -Values – 3xx - Redirection responses – 4xx - Client failure responses – 5xx - Server failure responses – 6xx - Global failure responses – 0xffff - not provided by modem

NewImsReg-Status	• New IMS Registration Status • Values – 0 - Not registered for IMS – 1 - Registering for IMS – 2 - Registered for IMS – 0xffffffff - not provided by modem

8.578.2 Field Documentation

8.578.2.1 uint16_t unpack_imsa_SLQSGetIMSARegStatus_t::ImsRegErrCode

8.578.2.2 uint8_t unpack_imsa_SLQSGetIMSARegStatus_t::ImsRegStatus

8.578.2.3 uint32_t unpack_imsa_SLQSGetIMSARegStatus_t::NewImsRegStatus

8.579 unpack_imsa_SLQSGetIMSAServiceStatus_t Struct Reference

Data Fields

- uint32_t SmsServiceStatus
- uint32_t VoipServiceStatus
- uint32_t VtServiceStatus
- uint32_t SmsServiceRat
- uint32_t VoipServiceRat
- uint32_t VtServiceRat
- uint32_t UtServiceStatus
- uint32_t UtServiceRat
- uint32_t VsServiceStatus
- uint32_t VsServiceRat

8.579.1 Detailed Description

This structure contains response parameters of service status for various IMS services.

Parameters

SmsService-Status	• SMS Service Status. • Values – 0 - IMS SMS service is not available – 1 - IMS SMS is in limited service – 2 - IMS SMS is in full service – 0xffffffff - not provided by modem
VoipSeriveStatus	• VoIP Service Status. -Values – 0 - IMS VoIP service is not available – 2 - IMS VoIP is in full service * 0xffffffff - not provided by modem

VtServiceStatus	• VT Service Status • Values – 0 - IMS VT service is not available – 2 - IMS VT is in full service – 0xffffffff - not provided by modem
SmsServiceRat	• SMS service RAT • Values – 0 - IMS service is registered on WLAN – 1 - IMS service is registered on WWAN – 2 - IMS service is registered on interworking WLAN – 0xffffffff - not provided by modem
VoipServiceRat	• VoIP service RAT. • Values – 0 - IMS service is registered on WLAN – 1 - IMS service is registered on WWAN – 2 - IMS service is registered on interworking WLAN – 0xffffffff - not provided by modem
VtServiceRat	• VT service RAT. • Values – 0 - IMS service is registered on WLAN – 1 - IMS service is registered on WWAN – 2 - IMS service is registered on interworking WLAN – 0xffffffff - not provided by modem
UtServiceStatus	• UT service Status. • Values – 0 - IMS UT service is not available – 2 - IMS UT is in full service – 0xffffffff - not provided by modem
UtServiceRat	• UT service RAT. • Values – 0 - IMS service is registered on WLAN – 1 - IMS service is registered on WWAN – 2 - IMS service is registered on interworking WLAN – 0xffffffff - not provided by modem

VsServiceStatus	• VS service Status. • Values – 0 - IMS UT service is not available – 2 - IMS UT is in full service – 0xffffffff - not provided by modem
VsServiceRat	• VS service RAT. • Values – 0 - IMS service is registered on WLAN – 1 - IMS service is registered on WWAN – 2 - IMS service is registered on interworking WLAN – 0xffffffff - not provided by modem

8.579.2 Field Documentation

8.579.2.1 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::SmsServiceRat

8.579.2.2 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::SmsServiceStatus

8.579.2.3 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::UtServiceRat

8.579.2.4 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::UtServiceStatus

8.579.2.5 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VoipServiceRat

8.579.2.6 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VoipServiceStatus

8.579.2.7 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VsServiceRat

8.579.2.8 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VsServiceStatus

8.579.2.9 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VtServiceRat

8.579.2.10 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VtServiceStatus

8.580 unpack_loc_BestAvailPos_Ind_t Struct Reference

Data Fields

- uint32_t status
- uint32_t * pXid
- uint64_t * pLatitude
- uint64_t * pLongitude
- uint32_t * pHorUncCircular
- uint32_t * pAltitudeWrtEllipsoid
- uint32_t * pVertUnc
- uint64_t * pTimestampUtc
- uint32_t * pTimeUnc
- uint32_t * pHorUncEllipseSemiMinor

- uint32_t * pHorUncEllipseSemiMajor
- uint32_t * pHorUncEllipseOrientAzimuth
- uint8_t * pHorCirConf
- uint8_t * pHorEllpConf
- uint32_t * pHorReliability
- uint32_t * pSpeedHorizontal
- uint32_t * pSpeedUnc
- uint32_t * pAltitudeWrtMeanSeaLevel
- uint8_t * pVertConfidence
- uint32_t * pVertReliability
- uint32_t * pSpeedVertical
- uint32_t * pSpeedVerticalUnc
- uint32_t * pHeading
- uint32_t * pHeadingUnc
- uint32_t * pMagneticDeviation
- uint32_t * pTechnologyMask
- loc_precisionDilution * pPrecisionDilution
- loc_gpsTime * pGpsTime
- uint32_t * pTimeSrc
- loc_sensorDataUsage * pSensorDataUsage
- loc_svUsedforFix * pSvUsedforFix
- uint16_t Tlvresult

8.580.1 Detailed Description

This structure contains Best Available Position

Parameters

status	• Valid values: – eQMI_LOC_SUCCESS (0) - Request was completed successfully – eQMI_LOC_GENERAL_FAILURE (1) - Request failed because of a general failure – eQMI_LOC_UNSUPPORTED (2) - Request failed because it is not supported – eQMI_LOC_INVALID_PARAMETER (3) - Request failed because it contained invalid parameters – eQMI_LOC_ENGINE_BUSY (4) - Request failed because the engine is busy – eQMI_LOC_PHONE_OFFLINE (5) - Request failed because the phone is offline – eQMI_LOC_TIMEOUT (6) - Request failed because it timed out – eQMI_LOC_CONFIG_NOT_SUPPORTED (7) - Request failed because an undefined configuration was requested – eQMI_LOC_INSUFFICIENT_MEMORY (8) - Request failed because the engine could not allocate sufficient memory for the request – eQMI_LOC_MAX_GEOFENCE_PROGRAMMED (9) - Request failed because the maximum number of Geofences are already programmed – eQMI_LOC_XTRA_VERSION_CHECK_FAILURE (10) - Location service failed because of an XTRA version-based file format check failure
xid	Transaction ID that was specified in the Get Best Available Position request.

pLatitude	• Latitude (specified in WGS84 datum) • Type - Floating point • Units - Degrees • Range - -90.0 to 90.0 • Positive values indicate northern latitude • Negative values indicate southern latitude
pLongitude	• Longitude (specified in WGS84 datum) • Type - Floating point • Units - Degrees • Range - -180.0 to 180.0 • Positive values indicate eastern latitude • Negative values indicate western latitude
pHorUncCircular	• Horizontal position uncertainty. • Units - Meters
pAltitudeWrt-Ellipsoid	• Altitude With Respect to WGS84 Ellipsoid. • Units - Meters • Range -500 to 15883
pVertUnc	• Vertical uncertainty. • Units - Meters
pTimestampUtc	• UTC timestamp • Units - Milliseconds since Jan. 1, 1970
pTimeUnc	• Time uncertainty. • Units - Milliseconds
pHorUncEllipse-SemiMinor	• Semi-minor axis of horizontal elliptical uncertainty. • Units - Meters
pHorUncEllipse-SemiMajor	• Semi-major axis of horizontal elliptical uncertainty. • Units: Meters
pHorUncEllipse-OrientAzimuth	• Elliptical horizontal uncertainty azimuth of orientation. • Units - Decimal degrees • Range - 0 to 180

pHorCirConf	• Horizontal circular uncertainty confidence • Units: Precent • Range: 0 to 99
pHorEllpConf	• Horizontal elliptical uncertainty confidence • Units: Precent • Range: 0 to 99
pHorReliability	• Values – 0 - Location reliability is not set. – 1 - Location reliability is very low; use it at your own risk – 2 - Location reliability is low; little or no cross-checking is possible. – 3 - Location reliability is medium; limited cross-check passed – 4 - Location reliability is high; strong cross-check passed
pSpeed-Horizontal	• Horizontal speed. • Units - Meters/second
pSpeedUnc	• 3-D Speed uncertainty. • Units - Meters/second.
pAltitudeWrt-MeanSeaLevel	• Altitude With Respect to Sea Level. • Units - Meters
pVertConfidence	• Vertical uncertainty confidence. • Units - Percentage • Range 0 to 99
pVertReliability	• Values – 0 - Location reliability is not set. – 1 - Location reliability is very low; use it at your own risk. – 2 - Location reliability is low; little or no cross-checking is possible – 3 - Location reliability is medium; limited cross-check passed – 4 - Location reliability is high; strong cross-check passed
pSpeedVertical	• Vertical speed. • Units - Meters/second
pSpeedVertical-Unc	• Veritical speed • Units: Meters/second

pHeading	• Heading. • Units - Degree • Range 0 to 359.999
pHeadingUnc	• Heading uncertainty. • Units - Degree • Range 0 to 359.999
pMagnetic-Deviation	• Difference between the bearing to true north and the bearing shown on a magnetic compass. The deviation is positive when the magnetic north is east of true north.
pTechnology-Mask	• Values – 0x00000001 - Satellites were used to generate the fix – 0x00000002 - Cell towers were used to generate the fix – 0x00000004 - Wi-Fi access points were used to generate the fix – 0x00000008 - Sensors were used to generate the fix – 0x00000010 - Reference Location was used to generate the fix – 0x00000020 - Coarse position injected into the location engine was used to generate the fix – 0x00000040 - AFLT was used to generate the fix – 0x00000080 - GNSS and network-provided measurements were used to generate the fix
-pPrecision-Dilution	• See loc_precisionDilution for more information
-pGpsTime	• See loc_gpsTime for more information

pTimeSrc	• Values – 0 - Invalid time. – 1 - Time is set by the 1X system. – 2 - Time is set by WCDMA/GSM time tagging. – 3 - Time is set by an external injection. – 4 - Time is set after decoding over-the-air GPS navigation data from one GPS satellite. – 5 - Time is set after decoding over-the-air GPS navigation data from multiple satellites. – 6 - Both time of the week and the GPS week number are known. – 7 - Time is set by the position engine after the fix is obtained – 8 - Time is set by the position engine after performing SFT, this is done when the clock time uncertainty is large. – 9 - Time is set after decoding GLO satellites. – 10- Time is set after transforming the GPS to GLO time – 11- Time is set by the sleep time tag provided by the WCDMA network. – 12- Time is set by the sleep time tag provided by the GSM network – 13- Source of the time is unknown – 14- Time is derived from the system clock (better known as the slow clock); GNSS time is maintained irrespective of the GNSS receiver state – 15- Time is set after decoding QZSS satellites. – 16- Time is set after decoding BDS satellites.
-pSensorData-Usage	• See loc_sensorDataUsage for more information
-pSvUsedforFix	• See loc_svUsedforFix for more information

8.580.2 Field Documentation

8.580.2.1 uint32_t* unpack_loc_BestAvailPos_Ind_t::pAltitudeWrtEllipsoid

8.580.2.2 uint32_t* unpack_loc_BestAvailPos_Ind_t::pAltitudeWrtMeanSeaLevel

8.580.2.3 loc_gpsTime* unpack_loc_BestAvailPos_Ind_t::pGpsTime

8.580.2.4 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHeading

8.580.2.5 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHeadingUnc

8.580.2.6 uint8_t* unpack_loc_BestAvailPos_Ind_t::pHorCirConf

8.580.2.7 uint8_t* unpack_loc_BestAvailPos_Ind_t::pHorEllpConf

8.580.2.8 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHorReliability

8.580.2.9 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHorUncCircular

8.580.2.10 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHorUncEllipseOrientAzimuth

8.580.2.11 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHorUncEllipseSemiMajor

8.580.2.12 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHorUncEllipseSemiMinor

8.580.2.13 uint64_t* unpack_loc_BestAvailPos_Ind_t::pLatitude

8.580.2.14 uint64_t* unpack_loc_BestAvailPos_Ind_t::pLongitude

8.580.2.15 uint32_t* unpack_loc_BestAvailPos_Ind_t::pMagneticDeviation

8.580.2.16 loc_precisionDilution* unpack_loc_BestAvailPos_Ind_t::pPrecisionDilution

8.580.2.17 loc_sensorDataUsage* unpack_loc_BestAvailPos_Ind_t::pSensorDataUsage

8.580.2.18 uint32_t* unpack_loc_BestAvailPos_Ind_t::pSpeedHorizontal

8.580.2.19 uint32_t* unpack_loc_BestAvailPos_Ind_t::pSpeedUnc

8.580.2.20 uint32_t* unpack_loc_BestAvailPos_Ind_t::pSpeedVertical

8.580.2.21 uint32_t* unpack_loc_BestAvailPos_Ind_t::pSpeedVerticalUnc

8.580.2.22 loc_svUsedforFix* unpack_loc_BestAvailPos_Ind_t::pSvUsedforFix

8.580.2.23 uint32_t* unpack_loc_BestAvailPos_Ind_t::pTechnologyMask

8.580.2.24 uint32_t* unpack_loc_BestAvailPos_Ind_t::pTimeSrc

8.580.2.25 uint64_t* unpack_loc_BestAvailPos_Ind_t::pTimestampUtc

8.580.2.26 uint32_t* unpack_loc_BestAvailPos_Ind_t::pTimeUnc

8.580.2.27 uint8_t* unpack_loc_BestAvailPos_Ind_t::pVertConfidence

8.580.2.28 uint32_t* unpack_loc_BestAvailPos_Ind_t::pVertReliability

8.580.2.29 uint32_t* unpack_loc_BestAvailPos_Ind_t::pVertUnc

8.580.2.30 uint32_t* unpack_loc_BestAvailPos_Ind_t::pXid

8.580.2.31 uint32_t unpack_loc_BestAvailPos_Ind_t::status

8.580.2.32 uint16_t unpack_loc_BestAvailPos_Ind_t::Tlvresult

8.581 unpack_loc_Delete_Assist_Data_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.581.1 Detailed Description

This structure contains LOC delete assist data unpack

Parameters

Tlvresult	• Unpack result.

8.581.2 Field Documentation

8.581.2.1 uint16_t unpack_loc_Delete_Assist_Data_t::Tlvresult

8.582 unpack_loc_DeleteAssistData_Ind_t Struct Reference

Data Fields

- uint32_t status
- uint16_t Tlvresult

8.582.1 Detailed Description

Contain the parameters passed for SetLocDeleteAssistDataCallback by the device.

Parameters

status	• Status of the Delete Assist Data request • Valid values: – eQMI_LOC_SUCCESS (0) - Request was completed successfully – eQMI_LOC_GENERAL_FAILURE (1) - Request failed because of a general failure – eQMI_LOC_UNSUPPORTED (2) - Request failed because it is not supported – eQMI_LOC_INVALID_PARAMETER (3) - Request failed because it contained invalid parameters – eQMI_LOC_ENGINE_BUSY (4) - Request failed because the engine is busy – eQMI_LOC_PHONE_OFFLINE (5) - Request failed because the phone is offline – eQMI_LOC_TIMEOUT (6) - Request failed because it timed out – eQMI_LOC_CONFIG_NOT_SUPPORTED (7) - Request failed because an undefined configuration was requested – eQMI_LOC_INSUFFICIENT_MEMORY (8) - Request failed because the engine could not allocate sufficient memory for the request – eQMI_LOC_MAX_GEOFENCE_PROGRAMMED (9) - Request failed because the maximum number of Geofences are already programmed – eQMI_LOC_XTRA_VERSION_CHECK_FAILURE (10) - Location service failed because of an XTRA version-based file format check failure – 0xffffffff - Invalid data.
Tlvresult	• unpack result

8.582.2 Field Documentation

8.582.2.1 uint32_t unpack_loc_DeleteAssistData_Ind_t::status

8.582.2.2 uint16_t unpack_loc_DeleteAssistData_Ind_t::TlvResult

8.583 unpack_loc_EngineState_Ind_t Struct Reference

Data Fields

- uint32_t engineState
- uint16_t TlvResult

8.583.1 Detailed Description

This structure contains LOC Engine State field.

Parameters

engineState	• Location engine state. • Valid values – 1 - Location engine is on – 2 - Loction engine is off • 0xffffffff - Invalid data.
TlvResult	• unpack result

8.583.2 Field Documentation

8.583.2.1 uint32_t unpack_loc_EngineState_Ind_t::engineState

8.583.2.2 uint16_t unpack_loc_EngineState_Ind_t::TlvResult

8.584 unpack_loc_EventNMEA_Ind_t Struct Reference

Data Fields

- char NMEAData [201]
- uint16_t TlvResult

8.584.1 Detailed Description

Contain the parameters passed for SetLocEventMaskNMEACallback by the device.

Parameters

NMEAData	• NMEA string • Type - NULL terminated string • Maximum string length (including NULL terminator) - 201
TlvResult	• unpack result

8.584.2 Field Documentation

8.584.2.1 char unpack_loc_EventNMEA_Ind_t::NMEAData[201]

8.584.2.2 uint16_t unpack_loc_EventNMEA_Ind_t::TlvResult

8.585 unpack_loc_EventRegister_t Struct Reference

Data Fields

- uint16_t TlvResult

8.585.1 Detailed Description

This structure contains Event Register unpack

Parameters

TlvResult	• Unpack result.

8.585.2 Field Documentation

8.585.2.1 uint16_t unpack_loc_EventRegister_t::TlvResult

8.586 unpack_loc_GetServer_Ind_t Struct Reference

Data Fields

- uint32_t serverStatus
- uint32_t serverType
- loc_IPv4Info * pIPv4AddrInfo
- loc_IPv6Info * pIPv6AddrInfo
- loc_urlAddr * pURL
- uint16_t TlvResult

8.586.1 Detailed Description

Contain the parameters passed for SetLocGetServerCallback by the device.

Parameters

serverStatus	• Status of the Get Server request. • Valid values – eQMI_LOC_SUCCESS (0) - Request was completed successfully – eQMI_LOC_GENERAL_FAILURE (1) - Request failed because of a general failure – eQMI_LOC_UNSUPPORTED (2) - Request failed because it is not supported – eQMI_LOC_INVALID_PARAMETER (3) - Request failed because it contained invalid parameters – eQMI_LOC_ENGINE_BUSY (4) - Request failed because the engine is busy – eQMI_LOC_PHONE_OFFLINE (5) - Request failed because the phone is offline – eQMI_LOC_TIMEOUT (6) - Request failed because it timed out – eQMI_LOC_CONFIG_NOT_SUPPORTED (7) - Request failed because an undefined configuration was requested – eQMI_LOC_INSUFFICIENT_MEMORY (8) - Request failed because the engine could not allocate sufficient memory for the request – eQMI_LOC_MAX_GEOFENCE_PROGRAMMED (9) - Request failed because the maximum number of Geofences are already programmed – eQMI_LOC_XTRA_VERSION_CHECK_FAILURE (10) - Location service failed because of an XTRA version-based file format check failure – 0xffffffff - Invalid data.
serverType	• Type of server. • Valid values – eQMI_LOC_SERVER_TYPE_CDMA_PDE (1) - Server type is CDMA PDE – eQMI_LOC_SERVER_TYPE_CDMA_MPC (2) - Server type is CDMA MPC – eQMI_LOC_SERVER_TYPE_UMTS_SLP (3) - Server type is UMTS SLP – eQMI_LOC_SERVER_TYPE_CUSTOM_PDE (4) - Server type is custom PDE – 0xffffffff - Invalid data.
pIPv4AddrInfo	• See loc_IPv4Info for more information.
pIPv6AddrInfo	• See loc_IPv6Info for more information.
pURL	• See loc_urlAddr for more information.

8.586.2 Field Documentation

8.586.2.1 loc_IPv4Info* unpack_loc_GetServer_Ind_t::pIPv4AddrInfo

8.586.2.2 loc_IPv6Info* unpack_loc_GetServer_Ind_t::pIPv6AddrInfo

8.586.2.3 loc_urlAddr* unpack_loc_GetServer_Ind_t::pURL

8.586.2.4 uint32_t unpack_loc_GetServer_Ind_t::serverStatus

8.586.2.5 uint32_t unpack_loc_GetServer_Ind_t::serverType

8.586.2.6 uint16_t unpack_loc_GetServer_Ind_t::Tlvresult

8.587 unpack_loc_GnssSvInfo_Ind_t Struct Reference

Data Fields

- uint8_t altitudeAssumed
- loc_satelliteInfo * pSatelliteInfo
- uint16_t Tlvresult

8.587.1 Detailed Description

Contain the parameters passed for SetLocGnssSvInfoCallback by the device.

Parameters

altitudeAssumed	• Indicates whether altitude is assumed or calculated – 0x00 (FALSE) - Valid altitude is calculated – 0x01 (TRUE) - Valid altitude is assumed; there may not be enough satellites to determine precise altitude – 0xff - Invalid data.
pSatelliteInfo	• See loc_satelliteInfo for more information. • NULL pointer - Invalid data.
Tlvresult	• unpack result

8.587.2 Field Documentation

8.587.2.1 uint8_t unpack_loc_GnssSvInfo_Ind_t::altitudeAssumed

8.587.2.2 loc_satelliteInfo* unpack_loc_GnssSvInfo_Ind_t::pSatelliteInfo

8.587.2.3 uint16_t unpack_loc_GnssSvInfo_Ind_t::Tlvresult

8.588 unpack_loc_PositionRpt_Ind_t Struct Reference

Data Fields

- uint32_t sessionStatus
- uint8_t sessionId
- uint64_t * pLatitude
- uint64_t * pLongitude
- uint32_t * pHorUncCircular
- uint32_t * pHorUncEllipseSemiMinor
- uint32_t * pHorUncEllipseSemiMajor
- uint32_t * pHorUncEllipseOrientAzimuth
- uint8_t * pHorConfidence
- uint32_t * pHorReliability

- uint32_t * pSpeedHorizontal
- uint32_t * pSpeedUnc
- uint32_t * pAltitudeWrtEllipsoid
- uint32_t * pAltitudeWrtMeanSeaLevel
- uint32_t * pVertUnc
- uint8_t * pVertConfidence
- uint32_t * pVertReliability
- uint32_t * pSpeedVertical
- uint32_t * pHeading
- uint32_t * pHeadingUnc
- uint32_t * pMagneticDeviation
- uint32_t * pTechnologyMask
- loc_precisionDilution * pPrecisionDilution
- uint64_t * pTimestampUtc
- uint8_t * pLeapSeconds
- loc_gpsTime * pGpsTime
- uint32_t * pTimeUnc
- uint32_t * pTimeSrc
- loc_sensorDataUsage * pSensorDataUsage
- uint32_t * pFixId
- loc_svUsedforFix * pSvUsedforFix
- uint8_t * pAltitudeAssumed
- uint16_t Tlvresult

8.588.1 Detailed Description

This structure contains Event Position Report Indication unpack

Parameters

sessionStatus	• Values – 0 - Session was successful – 1 - Session is still in progress; further position reports will be generated until either the fix criteria specified by the client are met or the client response timeout occurs. – 2 - Session failed.. – 3 - Fix request failed because the session timed out. – 4 - Fix request failed because the session was ended by the user. – 5 - Fix request failed due to bad parameters in the request. – 6 - Fix request failed because the phone is offline. – 7 - Fix request failed because the engine is locked – 0xffffffff - Invalid data.
sessionId	• ID of the session that was specified in the Start request • Range - 0 to 255

pLatitude	• Latitude (specified in WGS84 datum) • Type - Floating point • Units - Degrees • Range - -90.0 to 90.0 • Positive values indicate northern latitude • Negative values indicate southern latitude • NULL pointer - Invalid data.
pLongitude	• Longitude (specified in WGS84 datum) • Type - Floating point • Units - Degrees • Range - -180.0 to 180.0 • Positive values indicate eastern latitude • Negative values indicate western latitude • NULL pointer - Invalid data.
pHorUncCircular	• Horizontal position uncertainty. • Units - Meters • NULL pointer - Invalid data.
pHorUncEllipse-SemiMinor	• Semi-minor axis of horizontal elliptical uncertainty. • Units - Meters • NULL pointer - Invalid data.
pHorUncEllipse-SemiMajor	• Semi-major axis of horizontal elliptical uncertainty. • Units: Meters • NULL pointer - Invalid data.
pHorUncEllipse-OrientAzimuth	• Elliptical horizontal uncertainty azimuth of orientation. • Units - Decimal degrees • Range - 0 to 180 • NULL pointer - Invalid data.
pHorConfidence	• Horizontal uncertainty confidence. • If both elliptical and horizontal uncertainties are specified in this message, the confidence corresponds to the elliptical uncertainty. • Units - Percentage • Range 0-99 • NULL pointer - Invalid data.

pHorReliability	• Values – 0 - Location reliability is not set. – 1 - Location reliability is very low; use it at your own risk – 2 - Location reliability is low; little or no cross-checking is possible. – 3 - Location reliability is medium; limited cross-check passed – 4 - Location reliability is high; strong cross-check passed – NULL pointer - Invalid data.
pSpeed-Horizontal	• Horizontal speed. • Units - Meters/second • NULL pointer - Invalid data.
pSpeedUnc	• 3-D Speed uncertainty. • Units - Meters/second. • NULL pointer - Invalid data.
pAltitudeWrt-Ellipsoid	• Altitude With Respect to WGS84 Ellipsoid. • Units - Meters • Range -500 to 15883 • NULL pointer - Invalid data.
pAltitudeWrt-MeanSeaLevel	• Altitude With Respect to Sea Level. • Units - Meters • NULL pointer - Invalid data.
pVertUnc	• Vertical uncertainty. • Units - Meters • NULL pointer - Invalid data.
pVertConfidence	• Vertical uncertainty confidence. • Units - Percentage • Range 0 to 99 • NULL pointer - Invalid data.
pVertReliability	• Values – 0 - Location reliability is not set. – 1 - Location reliability is very low; use it at your own risk. – 2 - Location reliability is low; little or no cross-checking is possible – 3 - Location reliability is medium; limited cross-check passed – 4 - Location reliability is high; strong cross-check passed – NULL pointer - Invalid data.

pSpeedVertical	• Vertical speed. • Units - Meters/second • NULL pointer - Invalid data.
pHeading	• Heading. • Units - Degree • Range 0 to 359.999 • NULL pointer - Invalid data.
pHeadingUnc	• Heading uncertainty. • Units - Degree • Range 0 to 359.999 • NULL pointer - Invalid data.
pMagnetic-Deviation	• Difference between the bearing to true north and the bearing shown on a magnetic compass. The deviation is positive when the magnetic north is east of true north. • NULL pointer - Invalid data.
pTechnology-Mask	• Values – 0x00000001 - Satellites were used to generate the fix – 0x00000002 - Cell towers were used to generate the fix – 0x00000004 - Wi-Fi access points were used to generate the fix – 0x00000008 - Sensors were used to generate the fix – 0x00000010 - Reference Location was used to generate the fix – 0x00000020 - Coarse position injected into the location engine was used to generate the fix – 0x00000040 - AFLT was used to generate the fix – 0x00000080 - GNSS and network-provided measurements were used to generate the fix – NULL pointer - Invalid data.
-pPrecision-Dilution	• See loc_precisionDilution for more information • NULL pointer - Invalid data.
pTimestampUtc	• UTC timestamp • Units - Milliseconds since Jan. 1, 1970 • NULL pointer - Invalid data.
pLeapSeconds	• Leap second information. If leapSeconds is not available, timestampUtc is calculated based on a hard-coded value for leap seconds. • Units - Seconds • NULL pointer - Invalid data.

-pGpsTime	• See loc_gpsTime for more information • NULL pointer - Invalid data.
pTimeUnc	• Time uncertainty. • Units - Milliseconds • NULL pointer - Invalid data.
pTimeSrc	• Values – 0 - Invalid time. – 1 - Time is set by the 1X system. – 2 - Time is set by WCDMA/GSM time tagging. – 3 - Time is set by an external injection. – 4 - Time is set after decoding over-the-air GPS navigation data from one GPS satellite. – 5 - Time is set after decoding over-the-air GPS navigation data from multiple satellites. – 6 - Both time of the week and the GPS week number are known. – 7 - Time is set by the position engine after the fix is obtained – 8 - Time is set by the position engine after performing SFT, this is done when the clock time uncertainty is large. – 9 - Time is set after decoding GLO satellites. – 10- Time is set after transforming the GPS to GLO time – 11- Time is set by the sleep time tag provided by the WCDMA network. – 12- Time is set by the sleep time tag provided by the GSM network – 13- Source of the time is unknown – 14- Time is derived from the system clock (better known as the slow clock); GNSS time is maintained irrespective of the GNSS receiver state – 15- Time is set after decoding QZSS satellites. – 16- Time is set after decoding BDS satellites. – NULL pointer - Invalid data.
-pSensorData-Usage	• See loc_sensorDataUsage for more information – NULL pointer - Invalid data.
pFixId	• Fix count for the session. Starts with 0 and increments by one for each successive position report for a particular session. • NULL pointer - Invalid data.
-pSvUsedforFix	• See loc_svUsedforFix for more information – NULL pointer - Invalid data.
pAltitude-Assumed	• Indicates whether altitude is assumed or calculated.

- Value
  - 0x00 - Altitude is calculated

- 0x01 - Altitude is assumed
- NULL pointer - Invalid data.

8.588.2 Field Documentation

8.588.2.1 uint8_t* unpack_loc_PositionRpt_Ind_t::pAltitudeAssumed

8.588.2.2 uint32_t* unpack_loc_PositionRpt_Ind_t::pAltitudeWrtEllipsoid

8.588.2.3 uint32_t* unpack_loc_PositionRpt_Ind_t::pAltitudeWrtMeanSeaLevel

8.588.2.4 uint32_t* unpack_loc_PositionRpt_Ind_t::pFixId

8.588.2.5 loc_gpsTime* unpack_loc_PositionRpt_Ind_t::pGpsTime

8.588.2.6 uint32_t* unpack_loc_PositionRpt_Ind_t::pHeading

8.588.2.7 uint32_t* unpack_loc_PositionRpt_Ind_t::pHeadingUnc

8.588.2.8 uint8_t* unpack_loc_PositionRpt_Ind_t::pHorConfidence

8.588.2.9 uint32_t* unpack_loc_PositionRpt_Ind_t::pHorReliability

8.588.2.10 uint32_t* unpack_loc_PositionRpt_Ind_t::pHorUncCircular

8.588.2.11 uint32_t* unpack_loc_PositionRpt_Ind_t::pHorUncEllipseOrientAzimuth

8.588.2.12 uint32_t* unpack_loc_PositionRpt_Ind_t::pHorUncEllipseSemiMajor

8.588.2.13 uint32_t* unpack_loc_PositionRpt_Ind_t::pHorUncEllipseSemiMinor

8.588.2.14 uint64_t* unpack_loc_PositionRpt_Ind_t::pLatitude

8.588.2.15 uint8_t* unpack_loc_PositionRpt_Ind_t::pLeapSeconds

8.588.2.16 uint64_t* unpack_loc_PositionRpt_Ind_t::pLongitude

8.588.2.17 uint32_t* unpack_loc_PositionRpt_Ind_t::pMagneticDeviation

8.588.2.18 loc_precisionDilution* unpack_loc_PositionRpt_Ind_t::pPrecisionDilution

8.588.2.19 loc_sensorDataUsage* unpack_loc_PositionRpt_Ind_t::pSensorDataUsage

8.588.2.20 uint32_t* unpack_loc_PositionRpt_Ind_t::pSpeedHorizontal

8.588.2.21 uint32_t* unpack_loc_PositionRpt_Ind_t::pSpeedUnc

8.588.2.22 uint32_t* unpack_loc_PositionRpt_Ind_t::pSpeedVertical

8.588.2.23 loc_svUsedforFix* unpack_loc_PositionRpt_Ind_t::pSvUsedforFix

8.588.2.24 uint32_t* unpack_loc_PositionRpt_Ind_t::pTechnologyMask

8.588.2.25 uint32_t* unpack_loc_PositionRpt_Ind_t::pTimeSrc

8.588.2.26 uint64_t* unpack_loc_PositionRpt_Ind_t::pTimestampUtc

8.588.2.27 uint32_t* unpack_loc_PositionRpt_Ind_t::pTimeUnc

8.588.2.28 uint8_t* unpack_loc_PositionRpt_Ind_t::pVertConfidence

8.588.2.29 uint32_t* unpack_loc_PositionRpt_Ind_t::pVertReliability

8.588.2.30 uint32_t* unpack_loc_PositionRpt_Ind_t::pVertUnc

8.588.2.31 uint8_t unpack_loc_PositionRpt_Ind_t::sessionId

8.588.2.32 uint32_t unpack_loc_PositionRpt_Ind_t::sessionStatus

8.588.2.33 uint16_t unpack_loc_PositionRpt_Ind_t::Tlvresult

8.589 unpack_loc_SetExtPowerConfig_Ind_t Struct Reference

Data Fields

- uint32_t status
- uint16_t Tlvresult

8.589.1 Detailed Description

This structure contains LOC Set External Power Configure status field.

Parameters

status	• Valid values – 0 - Request was completed successfully – 1 - Request failed because of a general failure. – 2 - Request failed because it is not supported. – 3 - Request failed because it contained invalid parameters – 4 - Request failed because the engine is busy – 5 - Request failed because the phone is offline – 6 - Request failed because it timed out – 7 - Request failed because an undefined configuration was requested – 8 - engine could not allocate sufficient memory – 9 - Request failed because the maximum number of Geofences are already programmed – 10 -Location service failed because of an XTRA version-based file format check failure - 0xffffffff - Invalid data.
Tlvresult	• unpack result

8.589.2 Field Documentation

8.589.2.1 uint32_t unpack_loc_SetExtPowerConfig_Ind_t::status

8.589.2.2 uint16_t unpack_loc_SetExtPowerConfig_Ind_t::Tlvresult

8.590 unpack_loc_SetExtPowerState_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.590.1 Detailed Description

This structure contains Set Ext Power State unpack

Parameters

Tlvresult	• Unpack result.

8.590.2 Field Documentation

8.590.2.1 uint16_t unpack_loc_SetExtPowerState_t::Tlvresult

8.591 unpack_loc_SetOperationMode_Ind_t Struct Reference

Data Fields

- uint32_t status
- uint16_t Tlvresult

8.591.1 Detailed Description

This structure contains LOC Set External Power Configure status field.

Parameters

status	• Status of the Set Operation Mode request. • Valid values: – 0 - Request was completed successfully – 1 - Request failed because of a general failure – 2 - Request failed because it is not supported – 3 - Request failed because it contained invalid parameters – 4 - Request failed because the engine is busy – 5 - Request failed because the phone is offline – 6 - Request failed because it timed out – 7 - Request failed because an undefined configuration was requested – 8 - Request failed because the engine could not allocate sufficient memory for the request – 9 - Request failed because the maximum number of Geofences are already programmed – 10 - Location service failed because of an XTRA version-based file format check failure – 0xffffffff - Invalid data.

Tlvresult	• unpack result

8.591.2 Field Documentation

8.591.2.1 uint32_t unpack_loc_SetOperationMode_Ind_t::status

8.591.2.2 uint16_t unpack_loc_SetOperationMode_Ind_t::Tlvresult

8.592 unpack_loc_SetOperationMode_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.592.1 Detailed Description

This structure contains Set Operation Mode unpack

Parameters

Tlvresult	• Unpack result.

8.592.2 Field Documentation

8.592.2.1 uint16_t unpack_loc_SetOperationMode_t::Tlvresult

8.593 unpack_loc_SLQSLOCGetBestAvailPos_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.593.1 Detailed Description

This structure contains Set Operation Mode unpack

Parameters

Tlvresult	• Unpack result.

8.593.2 Field Documentation

8.593.2.1 uint16_t unpack_loc_SLQSLOCGetBestAvailPos_t::Tlvresult

8.594 unpack_loc_Start_t Struct Reference

Data Fields

- uint16_t TlvresultTlvresult

8.594.1 Detailed Description

This structure contains Start LOC unpack

Parameters

Tlvresult	• Unpack result.

8.594.2 Field Documentation

8.594.2.1 uint16_t unpack_loc_Start_t::Tlvresult

8.595 unpack_loc_Stop_t Struct Reference

Data Fields

- uint16_t TlvresultTlvresult

8.595.1 Detailed Description

This structure contains Stop LOC unpack

Parameters

Tlvresult	• Unpack result.

8.595.2 Field Documentation

8.595.2.1 uint16_t unpack_loc_Stop_t::Tlvresult

8.596 unpack_nas_GetCDMANetworkParameters_t Struct Reference

Data Fields

- uint8_t SCI
- uint8_t SCM
- uint8_t RegHomeSID
- uint8_t RegForeignSID
- uint8_t RegForeignNID
- uint8_t ForceRev0
- uint8_t CustomSCP
- uint32_t Protocol

- uint32_t Broadcast
- uint32_t Application
- uint32_t Roaming

8.596.1 Detailed Description

Gets the current CDMA network parameters

Parameters

SCI	• Slot cycle index – 0xFF-Unknown
SCM	• Station class mark – 0xFF-Unknown
RegHomeSID	• Register on home SID – 0 - Disabled – 1 - Enabled – 0xFF - Unknown
RegForeignSID	• Register on foreign SID – 0 - Disabled – 1 - Enabled – 0xFF - Unknown
RegForeignNID	• Register on foreign NID – 0 - Disabled – 1 - Enabled – 0xFF - Unknown
ForceRev0	• Force CDMA 1x-EV-DO Rev. 0 mode – 0 - Disabled – 1 - Enabled – 0xFF - Unknown
CustomSCP	• Use a custom config for CDMA 1x-EV-DO SCP – 0 - Disabled – 1 - Enabled – 0xFF - Unknown

Protocol	• Protocol mask for custom SCP config – 0x00000001 - Subtype 2 Physical Layer – 0x00000002 - Enhanced CCMAC – 0x00000004 - Enhanced ACMAC – 0x00000008 - Enhanced FTCMAC – 0x00000010 - Subtype 3 RTCMAC – 0x00000020 - Subsystem 1 RTCMAC – 0x00000040 - Enhanced Idle – 0x00000080 - Generic Multimode Capable Disc Port – 0xFFFFFFFF - Unknown
Broadcast	• Broadcast mask for custom SCP config – 0x00000001 - Generic broadcast enabled – 0xFFFFFFFF - Unknown
Application	• Application mask for custom SCP config – 0x00000001 - SN Multiflow Packet Application – 0x00000002 - SN Enhanced Multiflow Packet Application – 0xFFFFFFFF - Unknown
Roaming	• Roaming preference – 0 - Automatic – 1 - Home Only – 2 - Affiliated Roaming Only – 3 - Home and Affiliated Roaming – 0xFFFFFFFF - Unknown

8.596.2 Field Documentation

8.596.2.1 uint32_t unpack_nas_GetCDMANetworkParameters_t::Application

8.596.2.2 uint32_t unpack_nas_GetCDMANetworkParameters_t::Broadcast

8.596.2.3 uint8_t unpack_nas_GetCDMANetworkParameters_t::CustomSCP

8.596.2.4 uint8_t unpack_nas_GetCDMANetworkParameters_t::ForceRev0

8.596.2.5 uint32_t unpack_nas_GetCDMANetworkParameters_t::Protocol

8.596.2.6 uint8_t unpack_nas_GetCDMANetworkParameters_t::RegForeignNID

8.596.2.7 uint8_t unpack_nas_GetCDMANetworkParameters_t::RegForeignSID

8.596.2.8 uint8_t unpack_nas_GetCDMANetworkParameters_t::RegHomeSID

8.596.2.9 uint32_t unpack_nas_GetCDMANetworkParameters_t::Roaming

8.596.2.10 uint8_t unpack_nas_GetCDMANetworkParameters_t::SCI

8.596.2.11 uint8_t unpack_nas_GetCDMANetworkParameters_t::SCM

8.597 unpack_nas_GetHomeNetwork3GPP2_t Struct Reference

Data Fields

- uint16_t * pMCC
- uint16_t * pMNC
- uint8_t nameSize
- uint8_t * pName
- uint16_t * pSID
- uint16_t * pNID
- uint16_t * pNw2MCC
- uint16_t * pNw2MNC
- uint8_t * pNw2DescDisp
- uint8_t * pNw2DescEnc
- uint8_t * pNw2DescLen
- uint8_t * pNw2Name

8.597.1 Detailed Description

Structure for HomeNetwork3GPP2 unpack.

Parameters

pMCC	• Mobile country code (UMTS only). • NULL for invalid data
pMNC	• Mobile network code (UMTS only). • NULL for invalid data
nameSize	• Maximum number of characters (including NULL terminator) that network name array can contain (UMTS only).
pName	• Network name or description represented as a NULL terminated string (empty string returned when unknown) (UMTS only). • NULL for invalid data
pSID	• Home network system ID – 0xFFFF - Unknown. – Only applies to cdma2000 • NULL for invalid data

pNID	• Home network ID – 0xFFFF - Unknown. – Only applies to cdma2000 • NULL for invalid data
pNw2MCC	• Mobile country code (3GPP2 only). • Range : 0 to 999 • NULL for invalid data
pNw2MNC	• Mobile network code (3GPP2 only). • Range : 0 to 999 • NULL for invalid data
pNw2DescDisp	• Network Name Display (3GPP2 only). -Valid Value – 0x00 - Do not display – 0x01 - Display – 0xFF - Unknown • NULL for invalid data
pNw2DescEnc	• Encoding of the network description (3GPP2 only). • Valid Value – 0x00 - Octet, unspecified – 0x02 - 7-bit ASCII (liteqmi_helper_decode7bitAsciiEncString) – 0x04 - Unicode – 0x09 - GSM 7-bit default • NULL for invalid data
pNw2DescLen	• Network Description Length (3GPP2 only). • NULL for invalid data
pNw2Name	• Network Name (3GPP2 only). • NULL for invalid data

8.597.2 Field Documentation

8.597.2.1 uint8_t unpack_nas_GetHomeNetwork3GPP2_t::nameSize

8.597.2.2 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pMCC

8.597.2.3 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pMNC

8.597.2.4 uint8_t* unpack_nas_GetHomeNetwork3GPP2_t::pName

8.597.2.5 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pNID

8.597.2.6 uint8_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2DescDisp

8.597.2.7 uint8_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2DescEnc

8.597.2.8 uint8_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2DescLen

8.597.2.9 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2MCC

8.597.2.10 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2MNC

8.597.2.11 uint8_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2Name

8.597.2.12 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pSID

8.598 unpack_nas_GetHomeNetwork_t Struct Reference

Data Fields

- uint16_t mcc
- uint16_t mnc
- char name [255]
- uint16_t sid
- uint16_t nid

8.598.1 Detailed Description

This structure contains unpack get get home network parameters.

Parameters

mcc	• Mobile country code (UMTS only). • A 16-bit integer representation of MCC. Range: 0 to 999. • 0xFFFF - Invalid data.
mnc	• Mobile network code (UMTS only). • A 16-bit integer representation of MNC. Range: 0 to 999. • 0xFFFF - Invalid data.
name	• Network name or description represented as a NULL terminated string (empty string returned when unknown) (UMTS only).
sid	• Home network system ID – 0xFFFF - Unknown. – Only applies to cdma2000

nid	• Home network ID – 0xFFFF - Unknown. – Only applies to cdma2000

8.598.2 Field Documentation

8.598.2.1 uint16_t unpack_nas_GetHomeNetwork_t::mcc

8.598.2.2 uint16_t unpack_nas_GetHomeNetwork_t::mnc

8.598.2.3 char unpack_nas_GetHomeNetwork_t::name[255]

8.598.2.4 uint16_t unpack_nas_GetHomeNetwork_t::nid

8.598.2.5 uint16_t unpack_nas_GetHomeNetwork_t::sid

8.599 unpack_nas_GetNetworkPreference_t Struct Reference

Data Fields

- uint32_t ActiveTechPref
- uint32_t Duration
- uint32_t PersistentTechPref
- uint16_t Tlvresult

8.599.1 Detailed Description

Returns the network registration preference. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use unpack_nas_SLQSGetSys-SelectionPref() for new firmware versions and new modules

Parameters

TechnologyPref[-OUT]	• Bitmask representing the radio technology preference set. • No bits set indicates to the device to automatically determine the technology to use • Values: – Bit 0 - Technology is 3GPP2 – Bit 1 - Technology is 3GPP • Any combination of the following may be returned: – Bit 2 - Analog - AMPS if 3GPP2, GSM if 3GPP – Bit 3 - Digital - CDMA if 3GPP2, WCDMA if 3GPP – Bit 4 - HDR – Bit 5 - LTE – Bits 6 to 15 - Reserved – 0xffffffff - invalid data.

Duration[OUT]	• Duration of active preference – 0 - Permanent – 1 - Power cycle – 2 - Until the end of the next call or a power cycle – 3 - Until the end of the next call, a specified time, or a power cycle – 4 to 6 - Until the end of the next call – 0xffffffff - invalid data.
Persistent-TechnologyPref[-OUT]	• Bit field representing persistent radio technology preference – Same representation as the pTechnologyPref parameter • 0xffffffff - invalid data.
Tlvresult	• unpack result

8.599.2 Field Documentation

8.599.2.1 uint32_t unpack_nas_GetNetworkPreference_t::ActiveTechPref

8.599.2.2 uint32_t unpack_nas_GetNetworkPreference_t::Duration

8.599.2.3 uint32_t unpack_nas_GetNetworkPreference_t::PersistentTechPref

8.599.2.4 uint16_t unpack_nas_GetNetworkPreference_t::Tlvresult

8.600 unpack_nas_GetRFInfo_t Struct Reference

Data Fields

- uint8_t instancesSize
- RFBandInfoElements RFBandInfoElements [255]

8.600.1 Detailed Description

Structur to strore the RFInfoList

Parameters

instanceSize	• Upon input, maximum number of elements that the RF info instances array can contain. • Upon successful output, actual number of elements in RF info instances array.
RFBandInfo-Elements	• RF info instances array – See RFBandInfoElements for more information

8.600.2 Field Documentation

8.600.2.1 uint8_t unpack_nas_GetRFInfo_t::instancesSize

8.600.2.2 RFBandInfoElements unpack_nas_GetRFInfo_t::RFBandInfoElements[255]

8.601 unpack_nas_GetServingNetwork_t Struct Reference

Data Fields

- uint32_t RegistrationState
- uint32_t CSDomain
- uint32_t PSDomain
- uint32_t RAN
- uint8_t RadioIfacesSize
- uint8_t RadioIfaces [255]
- uint32_t Roaming
- uint16_t MCC
- uint16_t MNC
- uint8_t nameSize
- uint8_t Name [255]
- uint8_t DataCapsLen
- uint8_t DataCaps [255]

8.601.1 Detailed Description

This structure contains unpack get get serving network parameters.

Parameters

Registration-State	• Registration state: – 0 - Not registered – 1 - Registered – 2 - Searching/Not Registered – 3 - Registration Denied – 4 - Unknown
CSDomain	• Circuit switch domain status: – 0 - Unknown/Not Applicable – 1 - Attached – 2 - Detached
PSDomain	• Packet switch domain status – 0 - Unknown/Not Applicable – 1 - Attached – 2 - Detached

RAN	• Type of radio access network on which mobile is registered: – 0 - Unknown – 1 - cdma2000 network – 2 - UMTS network
RadioIfacesSize	• Upon input, maximum number of elements that the radio interface array contain. • Upon successful output, actual number of elements in the radio interface array.
RadioIfaces	• An array of Radio Interface Technology – See qaGobiApiTableRadioInterfaces.h for the Radio Interface Technologies
Roaming	• Roaming indicator • 0xffffffff - invaild data.
MCC	• Mobile country code • 0xffff - invalid dta.
MNC	• Mobile network code • 0xffff - invalid dta.
nameSize	• Maximum number of characters (including NULL terminator) that network name array can contain; applicable only for UMTS networks
Name	• Network name or description represented as a NULL terminated string; empty string is returned when unknown; applicable only for UMTS networks
DataCapsLen[IN/OUT]	• Upon input, the maximum number of elements the data capabilities array can contain. • Upon output, the actual number of elements in the data capabilities array.

DataCaps[OUT]	• Data capabilities array of unsigned long type – 1 - GPRS – 2 - EDGE – 3 - HSDPA – 4 - HSUPA – 5 - WCDMA – 6 - CDMA 1xRTT – 7 - CDMA 1xEV-DO Rev 0 – 8 - CDMA 1xEV-DO Rev. A – 9 - GSM – 10 - EVDO Rev. B – 11 - LTE – 12 - HSDPA Plus – 13 - Dual Carrier HSDPA Plus

8.601.2 Field Documentation

8.601.2.1 uint32_t unpack_nas_GetServingNetwork_t::CSDomain

8.601.2.2 uint8_t unpack_nas_GetServingNetwork_t::DataCaps[255]

8.601.2.3 uint8_t unpack_nas_GetServingNetwork_t::DataCapsLen

8.601.2.4 uint16_t unpack_nas_GetServingNetwork_t::MCC

8.601.2.5 uint16_t unpack_nas_GetServingNetwork_t::MNC

8.601.2.6 uint8_t unpack_nas_GetServingNetwork_t::Name[255]

8.601.2.7 uint8_t unpack_nas_GetServingNetwork_t::nameSize

8.601.2.8 uint32_t unpack_nas_GetServingNetwork_t::PSDomain

8.601.2.9 uint8_t unpack_nas_GetServingNetwork_t::RadioIfaces[255]

8.601.2.10 uint8_t unpack_nas_GetServingNetwork_t::RadioIfacesSize

8.601.2.11 uint32_t unpack_nas_GetServingNetwork_t::RAN

8.601.2.12 uint32_t unpack_nas_GetServingNetwork_t::RegistrationState

8.601.2.13 uint32_t unpack_nas_GetServingNetwork_t::Roaming

8.602 unpack_nas_GetServingNetworkCapabilities_t Struct Reference

Data Fields

- uint8_t DataCapsLen
- uint8_t DataCaps [255]

8.602.1 Detailed Description

This structure contains unpack get serving network capabilities parameters.

Parameters

DataCapsLen	• Upon input, the maximum number of elements the data capabilities array can contain. • Upon output, the actual number of elements in the data capabilities array.
DataCaps[OUT]	• Data capabilities array of unsigned long type – 1 - GPRS – 2 - EDGE – 3 - HSDPA – 4 - HSUPA – 5 - WCDMA – 6 - CDMA 1xRTT – 7 - CDMA 1xEV-DO Rev 0 – 8 - CDMA 1xEV-DO Rev. A – 9 - GSM – 10 - EVDO Rev. B – 11 - LTE – 12 - HSDPA Plus – 13 - Dual Carrier HSDPA Plus

8.602.2 Field Documentation

8.602.2.1 uint8_t unpack_nas_GetServingNetworkCapabilities_t::DataCaps[255]

8.602.2.2 uint8_t unpack_nas_GetServingNetworkCapabilities_t::DataCapsLen

8.603 unpack_nas_GetSignalStrengths_t Struct Reference

Data Fields

- uint32_t len
- signed char rssi [8]
- uint32_t radio [8]

8.603.1 Detailed Description

This structure contains unpack get signal strengths parameters.

Parameters

len	number of rssi & radio items following
rssi	signal strength array
radio	radio interface array

8.603.2 Field Documentation

8.603.2.1 uint32_t unpack_nas_GetSignalStrengths_t::len

8.603.2.2 uint32_t unpack_nas_GetSignalStrengths_t::radio[8]

8.603.2.3 signed char unpack_nas_GetSignalStrengths_t::rssi[8]

8.604 unpack_nas_PerformNetworkScan_t Struct Reference

Data Fields

- uint8_t * p3GppNetworkInstanceSize
- nas_QmiNas3GppNetworkInfo * p3GppNetworkInfoInstances
- uint8_t * pRATInstanceSize
- nas_QmiNas3GppNetworkRAT * pRATINstance
- uint8_t * pPCSInstanceSize
- nas_QmisNasPcsDigit * pPCSInstance
- uint32_t * pScanResult

8.604.1 Detailed Description

Contain the network scan information.

Parameters

p3GppNetwork-InstanceSize	• Upon input, maximum number of elements that the network info instance array can contain. • Upon successful output, the actual number of elements in the network info instance array.
p3GppNetwork-InfoInstances	• Network info instance array – See nas_QmiNas3GppNetworkInfo for more information
pRATInstance-Size	• Upon input, maximum number of elements that the RAT info instance array can contain. • Upon successful output, the actual number of elements in the RAT info instance array.
pRATINstance	• RAT info instance array – See nas_QmiNas3GppNetworkRAT for more information
pPCSInstance-Size	• Upon input, maximum number of elements that the PCS Digit info instance array can contain. • Upon successful output, the actual number of elements in the PCS Digit info instance array.
pPCSInstance	• PCS Digit info instance array – See nas_QmisNasPcsDigit for more information
pScanResult	• status of network scan • 0x00 - scan successful • 0x01 - scan was aborted • 0x02 - scan did not complete due to a radio link failure recovery in progress • 0xffffffff - invalid data.

8.604.2 Field Documentation

8.604.2.1 nas_QmiNas3GppNetworkInfo* unpack_nas_PerformNetworkScan_t::p3GppNetworkInfoInstances

8.604.2.2 uint8_t* unpack_nas_PerformNetworkScan_t::p3GppNetworkInstanceSize

8.604.2.3 nas_QmisNasPcsDigit* unpack_nas_PerformNetworkScan_t::pPCSInstance

8.604.2.4 uint8_t* unpack_nas_PerformNetworkScan_t::pPCSInstanceSize

8.604.2.5 nas_QmiNas3GppNetworkRAT* unpack_nas_PerformNetworkScan_t::pRATINstance

8.604.2.6 uint8_t* unpack_nas_PerformNetworkScan_t::pRATInstanceSize

8.604.2.7 uint32_t* unpack_nas_PerformNetworkScan_t::pScanResult

8.605 unpack_nas_SetDataCapabilitiesCallback_ind_t Struct Reference

Data Fields

- uint8_t dataCapsSize
- uint8_t dataCaps [255]

8.605.1 Detailed Description

This structure contains unpack set data capabilities callback indication parameters.

Parameters

dataCapsSize	Number of Data Capabilities
dataCaps	Data Capabilities

8.605.2 Field Documentation

8.605.2.1 uint8_t unpack_nas_SetDataCapabilitiesCallback_ind_t::dataCaps[255]

8.605.2.2 uint8_t unpack_nas_SetDataCapabilitiesCallback_ind_t::dataCapsSize

8.606 unpack_nas_SetEventReportInd_t Struct Reference

Data Fields

- nas_SignalStrengthTlv SSTlv
- nas_RFInfoTlv RFTlv
- nas_RejectReasonTlv RRTlv
- nas_SLQSSignalStrengthsTlv SLQSSSTlv

8.606.1 Detailed Description

This structure contains unpack set event report indication parameters.

Parameters

SSTlv	signal strength tlv
RFTlv	RF tlv
RRTlv	RR tlv
SLQSSSTlv	signal strength complete info tlv

8.606.2 Field Documentation

8.606.2.1 nas_RFInfoTlv unpack_nas_SetEventReportInd_t::RFTlv

8.606.2.2 nas_RejectReasonTlv unpack_nas_SetEventReportInd_t::RRTlv

8.606.2.3 nas_SLQSSignalStrengthsTlv unpack_nas_SetEventReportInd_t::SLQSSSTlv

8.606.2.4 nas_SignalStrengthTlv unpack_nas_SetEventReportInd_t::SSTlv

8.607 unpack_nas_SetNasLTECphyCaIndCallback_ind_t Struct Reference

Data Fields

- nas_PhyCaAggScellIndType sPhyCaAggScellIndType
- nas_PhyCaAggScellDlBw sPhyCaAggScellDlBw
- nas_PhyCaAggScellInfo sPhyCaAggScellInfo
- nas_PhyCaAggPcellInfo sPhyCaAggPcellInfo
- nas_PhyCaAggScellIndex sPhyCaAggScellIndex

8.607.1 Detailed Description

Structure for storing the LTE PHY CA indication parameters.

Parameters

pPhyCaAgg-ScellIndType	• See nas_PhyCaAggScellIndType for more information.
sPhyCaAgg-ScellDlBw	• See nas_PhyCaAggScellDlBw for more information.
sPhyCaAgg-ScellInfo	• See nas_PhyCaAggScellInfo for more information.
sPhyCaAgg-PcellInfo	• See nas_PhyCaAggPcellInfo for more information.
sPhyCaAgg-ScellIndex	• See nas_PhyCaAggScellIndex for more information.

8.607.2 Field Documentation

8.607.2.1 nas_PhyCaAggPcellInfo unpack_nas_SetNasLTECphyCaIndCallback_ind_t::sPhyCaAggPcellInfo

8.607.2.2 nas_PhyCaAggSceIIDlBw unpack_nas_SetNasLTECphyCaIndCallback_ind_t::sPhyCaAggSceIIDlBw

8.607.2.3 nas_PhyCaAggSceIIIndex unpack_nas_SetNasLTECphyCaIndCallback_ind_t::sPhyCaAggSceIIIndex

8.607.2.4 nas_PhyCaAggSceIIIndType unpack_nas_SetNasLTECphyCaIndCallback_ind_t::sPhyCaAggSceIIIndType

8.607.2.5 nas_PhyCaAggSceIIInfo unpack_nas_SetNasLTECphyCaIndCallback_ind_t::sPhyCaAggSceIIInfo

8.608 unpack_nas_SetNetworkPreference_t Struct Reference

Data Fields

- uint16_t TlvresultTlvresult

8.608.1 Detailed Description

This structure contains unpack set netwokr preference parameters.

Parameters

Tlvresult	• unpack result

8.608.2 Field Documentation

8.608.2.1 uint16_t unpack_nas_SetNetworkPreference_t::Tlvresult

8.609 unpack_nas_SetRoamingIndicatorCallback_ind_t Struct Reference

Data Fields

- uint8_t roaming

8.609.1 Detailed Description

This structure contains unpack set roaming indicator callback indication parameters.

Parameters

roaming	• Roaming Indication – 0 - Roaming – 1 - Home – 2 - Roaming partner – >2 - Operator defined values

8.609.2 Field Documentation

8.609.2.1 uint8_t unpack_nas_SetRoamingIndicatorCallback_ind_t::roaming

8.610 unpack_nas_SetServingSystemCallback_ind_t Struct Reference

Data Fields

- NASServingSystemInfo SSInfo
- uint16_t TlvResult

8.610.1 Detailed Description

This structure contains unpack set serving system callback indication parameters.

Parameters

SSInfo	• Serving system parameters information – See NASServingSystemInfo for more details
TlvResult	• unpack result

8.610.2 Field Documentation

8.610.2.1 NASServingSystemInfo unpack_nas_SetServingSystemCallback_ind_t::SSInfo

8.610.2.2 uint16_t unpack_nas_SetServingSystemCallback_ind_t::TlvResult

8.611 unpack_nas_SLQSGetErrorRate_t Struct Reference

Data Fields

- uint16_t * pCDMAFrameErrRate
- uint16_t * pHDRPackErrRate
- uint8_t * pGSMBER
- uint8_t * pWCDMABER

8.611.1 Detailed Description

Structure for Error Rate unpack parameters.

Parameters

pCDMAFrame-ErrRate	• CDMA Frame Error Rate • Valid error rate values between 1 and 10000 are returned to indicate the percentage, e.g., a value of 300 means the error rate is 3%. • A value of 0xFFFF indicates that the error rate is unknown/unavailable. • NULL for invalid data

pHDRPackErr-Rate	• HDR Packet Error Rate • Valid error rate values between 1 and 10000 are returned to indicate the percentage, e.g., a value of 300 means the error rate is 3%. • A value of 0xFFFF indicates that the error rate is unknown/unavailable. • NULL for invalid data
pGSMBER	• GSM Bit Error Rate • Valid error rate values between 1 and 100 are returned to indicate the percentage value. • A 0% block error rate (BLER) indicates No Data. • NULL for invalid data
pWCDMABER	• WCDMA Block Error Rate • Valid error rate values between 1 and 100 are returned to indicate the percentage value. • A value of 0xFF indicates that the error rate is unknown/unavailable. • NULL for invalid data

8.611.2 Field Documentation

8.611.2.1 uint16_t* unpack_nas_SLQSGetErrorRate_t::pCDMAFrameErrRate

8.611.2.2 uint8_t* unpack_nas_SLQSGetErrorRate_t::pGSMBER

8.611.2.3 uint16_t* unpack_nas_SLQSGetErrorRate_t::pHDRPackErrRate

8.611.2.4 uint8_t* unpack_nas_SLQSGetErrorRate_t::pWCDMABER

8.612 unpack_nas_SlqsGetLTECphyCAInfo_t Struct Reference

Data Fields

- NasGetLTECphyCaInfo LTECphyCaInfo
- uint16_t Tlvresult

8.612.1 Detailed Description

This structure contains unpack get carrier aggregation event information parameters.

Parameters

LTECphyCa	• Carrier aggregation event information – See NasGetLTECphyCaInfo for more details
Tlvresult	• unpack result

8.612.2 Field Documentation

8.612.2.1 NasGetLTECphyCaInfo unpack_nas_SlqsGetLTECphyCAInfo_t::LTECphyCaInfo

8.612.2.2 uint16_t unpack_nas_SlqsGetLTECphyCAInfo_t::TlvResult

8.613 unpack_nas_SLQSGetNetworkTime_t Struct Reference

Data Fields

- nas_timeInfo * p3GPP2TimeInfo
- nas_timeInfo * p3GPPTimeInfo

8.613.1 Detailed Description

This structure contains information about the GetNetworkTime response parameters.

Parameters

p3GPP2TimeInfo	[Optional] • See nas_timeInfo for more information • NULL for invalid data.
p3GPPTimeInfo	[Optional] • See nas_timeInfo for more information • NULL for invalid data.

8.613.2 Field Documentation

8.613.2.1 nas_timeInfo* unpack_nas_SLQSGetNetworkTime_t::p3GPP2TimeInfo

8.613.2.2 nas_timeInfo* unpack_nas_SLQSGetNetworkTime_t::p3GPPTimeInfo

8.614 unpack_nas_SLQSGetOperatorNameData_t Struct Reference

Data Fields

- nas_serviceProviderName * pSrvcProviderName
- nas_operatorPLMNList * pOperatorPLMNList
- nas_PLMNNetworkName * pPLMNNetworkName
- nas_operatorNameString * pOperatorNameString
- nas_PLMNNetworkNameData * pNITZInformation

8.614.1 Detailed Description

Structure for Operator Name unpack.

Parameters

pSrvcProvider-Name	• Refer nas_serviceProviderName for details (Optional). • Can provide NULL if this parameter is not required. • NULL for invalid data
pOperatorPLM-NList	• Refer nas_operatorPLMNList for details (Optional). • Can provide NULL if this parameter is not required. • NULL for invalid data
pPLMNNetwork-Name	• Refer nas_PLMNNetworkName for details (Optional). • Can provide NULL if this parameter is not required. • NULL for invalid data
pOperatorName-String	• Refer nas_operatorNameString for details (Optional). • Can provide NULL if this parameter is not required. • NULL for invalid data
pNITZ-Information	• Refer nas_PLMNNetworkNameData for details (Optional). • Can provide NULL if this parameter is not required. • NULL for invalid data

8.614.2 Field Documentation

8.614.2.1 nas_PLMNNetworkNameData∗ unpack_nas_SLQSGetOperatorNameData_t::pNITZInformation

8.614.2.2 nas_operatorNameString∗ unpack_nas_SLQSGetOperatorNameData_t::pOperatorNameString

8.614.2.3 nas_operatorPLMNList∗ unpack_nas_SLQSGetOperatorNameData_t::pOperatorPLMNList

8.614.2.4 nas_PLMNNetworkName∗ unpack_nas_SLQSGetOperatorNameData_t::pPLMNNetworkName

8.614.2.5 nas_serviceProviderName∗ unpack_nas_SLQSGetOperatorNameData_t::pSrvcProviderName

8.615 unpack_nas_SLQSGetPLMNName_t Struct Reference

Data Fields

- uint8_t spnEncoding
- uint8_t spnLength
- char spn [255]
- uint8_t shortNameEn
- uint8_t shortNameCI
- uint8_t shortNameSB
- char shortNameLen
- uint8_t shortName [255]
- uint8_t longNameEn
- uint8_t longNameCI

- uint8_t longNameSB
- uint8_t longNameLen
- char longName [255]

8.615.1 Detailed Description

This structure contains unpack get operator name for specificed network parameters.

Parameters

spnEncoding	• Coding scheme used for service provider name. This value is ignored if spn_len is zero Values: – 0x00 - SMS default 7-bit coded alphabet as defined in 3GPP TS 23.038 with bit 8 set to 0 – 0x01 - UCS2 (16 bit, little-endian) 3GPP TS 23.038 – Note: This value is ignored if spnLength is zero.
spnLength	• Length of SPN which follows • Note: This SPN value is ignored if spnLength is zero and spnEncoding is 0xff.
spn	• Service Provider name string
shortNameEn	• Coding scheme used for PLMN short name. This value is ignored if PLMN short name length is zero Values: – 0x00 - SMS default 7-bit coded alphabet as defined in 3GPP TS 23.038 with bit 8 set to 0 – 0x01 - UCS2 (16 bit, little-endian) 3GPP TS 23.038 – Note: This value is ignored if shortNameLen is zero.
shortNameCI	• Indicates whether the country initials are to be added to the shortName. This value is ignored if shortNameLen is zero. Values: – 0x00 - Do not add the letters for the countrys initials to the name – 0x01 - Add the countrys initials and a text string to the name – 0xFF - Not specified – Note: This value is ignored if shortNameLen is zero.
shortNameSB	• PLMN short name spare bits. This value is ignored if shortNameLen is zero. Values: – 0x01 - Bit 8 is spare and set to 0 in octet – 0x02 - Bits 7 and 8 are spare and set to 0 in octet n – 0x03 - Bits 6 to 8 (inclusive) are spare and set to 0 in octet n – 0x04 - Bits 5 to 8 (inclusive) are spare and set to 0 in octet n – 0x05 - Bits 4 to 8 (inclusive) are spare and set to 0 in octet n – 0x06 - Bits 3 to 8 (inclusive) are spare and set to 0 in octet n – 0x07 - Bits 2 to 8 (inclusive) are spare and set to 0 in octet n – 0x00 - Carries no information about the number of spare bits in octet n – Note: This value is ignored if shortNameLen is zero.
shortNameLen	• Length of shortName which follows • Note: This shortName value is ignored if shortNameLen is zero and shortNameEn is 0xff.

shortName	• PLMN short name
longNameEn	• Coding scheme used for PLMN long name. This value is ignored if PLMN long name length is zero Values: – 0x00 - SMS default 7-bit coded alphabet as defined in 3GPP TS 23.038 with bit 8 set to 0 – 0x01 - UCS2 (16 bit, little-endian) 3GPP TS 23.038 – Note: This value is ignored if shortNameLen is zero.
longNameCI	• Indicates whether the country initials are to be added to the longName. This value is ignored if longNameLen is zero. Values: – 0x00 - Do not add the letters for the countrys initials to the name – 0x01 - Add the countrys initials and a text string to the name – 0xFF - Not specified – Note: This value is ignored if shortNameLen is zero.
longNameSB	• PLMN long name spare bits. This value is ignored if longNameLen is zero. Values: – 0x01 - Bit 8 is spare and set to 0 in octet – 0x02 - Bits 7 and 8 are spare and set to 0 in octet n – 0x03 - Bits 6 to 8 (inclusive) are spare and set to 0 in octet n – 0x04 - Bits 5 to 8 (inclusive) are spare and set to 0 in octet n – 0x05 - Bits 4 to 8 (inclusive) are spare and set to 0 in octet n – 0x06 - Bits 3 to 8 (inclusive) are spare and set to 0 in octet n – 0x07 - Bits 2 to 8 (inclusive) are spare and set to 0 in octet n – 0x00 - Carries no information about the number of spare bits in octet n – Note: This value is ignored if shortNameLen is zero.
longNameLen	• Length of longName which follows • Note: This longName value is ignored if longNameLen is zero and longNameEn is 0xff.
longName	• PLMN long name

8.615.2 Field Documentation

8.615.2.1 char unpack_nas_SLQSGetPLMNName_t::longName[255]

8.615.2.2 uint8_t unpack_nas_SLQSGetPLMNName_t::longNameCI

8.615.2.3 uint8_t unpack_nas_SLQSGetPLMNName_t::longNameEn

8.615.2.4 uint8_t unpack_nas_SLQSGetPLMNName_t::longNameLen

8.615.2.5 uint8_t unpack_nas_SLQSGetPLMNName_t::longNameSB

8.615.2.6 uint8_t unpack_nas_SLQSGetPLMNName_t::shortName[255]

8.615.2.7 uint8_t unpack_nas_SLQSGetPLMNName_t::shortNameCI

8.615.2.8 uint8_t unpack_nas_SLQSGetPLMNName_t::shortNameEn

8.615.2.9 char unpack_nas_SLQSGetPLMNName_t::shortNameLen

8.615.2.10 uint8_t unpack_nas_SLQSGetPLMNName_t::shortNameSB

8.615.2.11 char unpack_nas_SLQSGetPLMNName_t::spn[255]

8.615.2.12 uint8_t unpack_nas_SLQSGetPLMNName_t::spnEncoding

8.615.2.13 uint8_t unpack_nas_SLQSGetPLMNName_t::spnLength

8.616 unpack_nas_SLQSGetServingSystem_t Struct Reference

Data Fields

- nas_servSystem ServingSystem
- uint8_t RoamIndicatorVal
- nas_dataSrvCapabilities DataSrvCapabilities
- nas_currentPLMN CurrentPLMN
- uint16_t SystemID
- uint16_t NetworkID
- uint16_t BasestationID
- uint32_t BasestationLatitude
- uint32_t BasestationLongitude
- nas_roamIndList RoamingIndicatorList
- uint8_t DefaultRoamInd
- nas_qaQmi3Gpp2TimeZone Gpp2TimeZone
- uint8_t CDMA_P_Rev
- uint8_t GppTimeZone
- uint8_t GppNetworkDSTAdjustment
- uint16_t Lac
- uint32_t CellID
- uint8_t ConcSvcInfo
- uint8_t PRLInd
- uint8_t DTMInd
- nas_detailSvcInfo DetailedSvcInfo
- nas_CDMASysInfoExt CDMASystemInfoExt
- uint8_t HdrPersonality
- uint16_t TrackAreaCode
- nas_callBarStatus CallBarStatus

8.616.1 Detailed Description

This structure contains the Serving System parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

ServingSystem	• Serving System • See nas_servSystem for more information
RoamIndicator-Val	• Optional parameter indicating Roaming Indicator value • Values: – 0x00 - Roaming – 0x01 - Home – 0x02 - Flashing – 0x03 and above - Operator defined values
DataSrv-Capabilities	• Optional parameter indicating Data services capability • See nas_dataSrvCapabilities for more information
CurrentPLMN	• Optional parameter indicating Current PLMN • See nas_currentPLMN for more information
SystemID	• Optional parameter indicating System ID
NetworkID	• Optional parameter indicating Network ID
BaseStationID	• Optional parameter indicating Base Station Identification Number
BaseStation-Latitude	• Optional parameter indicating Base station latitude in units of 0.25 sec,expressed as a two's complement signed number with positive numbers signifying North latitude
Basestation-Longitude	• Optional parameter indicating Base station longitude in units of 0.25 sec, expressed as a Two's complement signed number with positive numbers signifying East longitude
Roaming-IndicatorList	• Optional parameter indicating Roaming Indicator List • See nas_roamIndList for more information
DefaultRoamInd	• Optional parameter indicating Default Roaming Indicator • Values: – 0x00 - Roaming – 0x01 - Home
Gpp2TimeZone	• Optional parameter indicating 3GPP2 Time Zone • See nas_qaQmi3Gpp2TimeZone for more information

CDMA_P_Rev	• Optional parameter indicating CDMA P_Rev in use
GppTimeZone	• Optional parameter indicating Offset from Universal time, i.e., difference between local time and Universal time, in increments of 15 min. (signed value).
GppNetworkDS-TAdjustment	• Optional parameter indicating 3GPP network daylight saving adjustment • Values: – 0x00 - No adjustment for Daylight Saving Time – 0x01 - 1 hr adjustment for Daylight Saving Time – 0x02 - 2 hr adjustment for Daylight Saving Time
Lac	• Optional parameter indicating 3GPP Location Area Code
CellID	• Optional parameter indicating 3GPP Cell ID
ConcSvcInfo	• Optional parameter indicating 3GPP2 concurrent service Info • Values: – 0x00 - Concurrent service not available – 0x01 - Concurrent service available
PRLInd	• Optional parameter indicating 3GPP2 PRL Indicator • Values: – 0x00 - System not in PRL – 0x01 - System is in PRL
DTMInd	• Optional parameter indicating Dual Transfer Mode Indication(GSM Only) • Values: – 0x00 - DTM not supported – 0x01 - DTM supported
DetailedSvcInfo	• Optional parameter indicating Detailed service information • See nas_detailSvcInfo for more information
CDMASystem-InfoExt	• Optional parameter indicating CDMA System Info Ext • See nas_CDMASysInfoExt for more information

HdrPersonality	• Optional parameter indicating HDR Personality Information • Values: – 0x00 - Unknown – 0x01 - HRPD – 0x02 - eHRPD
TrackAreaCode	• Optional parameter indicating Tracking area code information for LTE
CallBarStatus	• Optional parameter indicating Call Barring Status • See nas_callBarStatus for more information

8.616.2 Field Documentation

8.616.2.1 uint16_t unpack_nas_SLQSGetServingSystem_t::BasestationID

8.616.2.2 uint32_t unpack_nas_SLQSGetServingSystem_t::BasestationLatitude

8.616.2.3 uint32_t unpack_nas_SLQSGetServingSystem_t::BasestationLongitude

8.616.2.4 nas_callBarStatus unpack_nas_SLQSGetServingSystem_t::CallBarStatus

8.616.2.5 uint8_t unpack_nas_SLQSGetServingSystem_t::CDMA_P_Rev

8.616.2.6 nas_CDMASysInfoExt unpack_nas_SLQSGetServingSystem_t::CDMASystemInfoExt

8.616.2.7 uint32_t unpack_nas_SLQSGetServingSystem_t::CellID

8.616.2.8 uint8_t unpack_nas_SLQSGetServingSystem_t::ConcSvcInfo

8.616.2.9 nas_currentPLMN unpack_nas_SLQSGetServingSystem_t::CurrentPLMN

8.616.2.10 nas_dataSrvCapabilities unpack_nas_SLQSGetServingSystem_t::DataSrvCapabilities

8.616.2.11 uint8_t unpack_nas_SLQSGetServingSystem_t::DefaultRoamInd

8.616.2.12 nas_detailSvcInfo unpack_nas_SLQSGetServingSystem_t::DetailedSvcInfo

8.616.2.13 uint8_t unpack_nas_SLQSGetServingSystem_t::DTMInd

8.616.2.14 nas_qaQmi3Gpp2TimeZone unpack_nas_SLQSGetServingSystem_t::Gpp2TimeZone

8.616.2.15 uint8_t unpack_nas_SLQSGetServingSystem_t::GppNetworkDSTAdjustment

8.616.2.16 uint8_t unpack_nas_SLQSGetServingSystem_t::GppTimeZone

8.616.2.17 uint8_t unpack_nas_SLQSGetServingSystem_t::HdrPersonality

8.616.2.18 uint16_t unpack_nas_SLQSGetServingSystem_t::Lac

8.616.2.19 uint16_t unpack_nas_SLQSGetServingSystem_t::NetworkID

8.616.2.20 uint8_t unpack_nas_SLQSGetServingSystem_t::PRLInd

8.616.2.21 uint8_t unpack_nas_SLQSGetServingSystem_t::RoamIndicatorVal

8.616.2.22 nas_roamIndList unpack_nas_SLQSGetServingSystem_t::RoamingIndicatorList

8.616.2.23 nas_servSystem unpack_nas_SLQSGetServingSystem_t::ServingSystem

8.616.2.24 uint16_t unpack_nas_SLQSGetServingSystem_t::SystemID

8.616.2.25 uint16_t unpack_nas_SLQSGetServingSystem_t::TrackAreaCode

8.617 unpack_nas_SLQSGetSignalStrength_t Struct Reference

Data Fields

- uint16_t signalStrengthReqMask
- uint16_t rxSignalStrengthListLen
- nas_rxSignalStrengthListElement rxSignalStrengthList [18]
- uint16_t ecioListLen
- nas_ecioListElement ecioList [18]
- int32_t Io
- uint8_t sinr
- uint16_t errorRateListLen
- nas_errorRateListElement errorRateList [18]
- nas_rsrqInformation rsrqInfo
- int16_t ltesnr
- int16_t ltersrp

8.617.1 Detailed Description

This structure contains the Signal Strength Information

Parameters

signalStrength-ReqMask	• Request Mask – Request additional signal information for: Bit 0 - RSSI Information bit Valid values are: 0 - Do Not Request Additional Info for RSSI 1 - Request Additional Info for RSSI Bit 1 - ECIO Information bit Valid values are: 0 - Do Not Request Additional Info for ECIO 1 - Request Additional Info for ECIO Bit 2 - IO Information bit Valid values are: 0 - Do Not Request Additional Info for IO 1 - Request Additional Info for IO Bit 3 - SINR Information bit Valid values are: 0 - Do Not Request Additional Info for SINR 1 - Request Additional Info for SINR Bit 4 - ERROR RATE Information bit Valid values are: 0 - Do Not Request Additional Info for Error Rate 1 - Request Additional Info for Error Rate Bit 5 - RSRQ Information bit Valid values are: 0 - Do Not Request Additional Info for RSRQ 1 - Request Additional Info for RSRQ Bit 6 - LTE SNR information bit Valid values are: 0 - Do not request additional information for LTE SNR 1 - Request additional information for LTE SNR Bit 7 - LTE RSRP Information bit Valid values are: 0 - Do not request additional information for LTE RSRP 1 - Request additional information for LTE RSRP
rxSignal-StrengthListLen	• Number of elements in Receive Signal Strength List
rxSignal-StrengthList	• See nas_rxSignalStrengthListElement for more information
ecioListLen	• Number of elements in ECIO List
ecioList	• See nas_ecioListElement for more information
Io	• Received Io in dBm; IO is only applicable for 1xEV-DO
sinr	• SINR level – SINR is only applicable for 1xEV-DO; valid levels are 0 to 8 where maximum value for 0 - SINR_LEVEL_0 is -9 dB 1 - SINR_LEVEL_1 is -6 dB 2 - SINR_LEVEL_2 is -4.5 dB 3 - SINR_LEVEL_3 is -3 dB 4 - SINR_LEVEL_4 is -2 dB 5 - SINR_LEVEL_5 is +1 dB 6 - SINR_LEVEL_6 is +3 dB 7 - SINR_LEVEL_7 is +6 dB 8 - SINR_LEVEL_8 is +9 dB

errorRateListLen	• Number of elements in Error Rate List
errorRateList	• See nas_errorRateListElement for more information
rsrqInfo	• See nas_rsrqInformation for more information
ltesnr	• LTE SNR level as a scaled integer in units of 0.1 dB; e.g., -16 dB has a value of -160 and 24.6 dB has a value of 246. LTE SNR is included only when the current serving system is LTE
ltersrp	• LTE SNR level as a scaled integer in units of 0.1 dB; e.g., -16 dB has a value of -160 and 24.6 dB has a value of 246. LTE SNR is included only when the current serving system is LTE

8.617.2 Field Documentation

8.617.2.1 nas_ecioListElement unpack_nas_SLQSGetSignalStrength_t::ecioList[18]

8.617.2.2 uint16_t unpack_nas_SLQSGetSignalStrength_t::ecioListLen

8.617.2.3 nas_errorRateListElement unpack_nas_SLQSGetSignalStrength_t::errorRateList[18]

8.617.2.4 uint16_t unpack_nas_SLQSGetSignalStrength_t::errorRateListLen

8.617.2.5 int32_t unpack_nas_SLQSGetSignalStrength_t::lo

8.617.2.6 int16_t unpack_nas_SLQSGetSignalStrength_t::ltersrp

8.617.2.7 int16_t unpack_nas_SLQSGetSignalStrength_t::ltesnr

8.617.2.8 nas_rsrqInformation unpack_nas_SLQSGetSignalStrength_t::rsrqInfo

8.617.2.9 nas_rxSignalStrengthListElement unpack_nas_SLQSGetSignalStrength_t::rxSignalStrengthList[18]

8.617.2.10 uint16_t unpack_nas_SLQSGetSignalStrength_t::rxSignalStrengthListLen

8.617.2.11 uint16_t unpack_nas_SLQSGetSignalStrength_t::signalStrengthReqMask

8.617.2.12 uint8_t unpack_nas_SLQSGetSignalStrength_t::sinr

8.618 unpack_nas_SLQSGetSysInfo_t Struct Reference

Data Fields

- nas_SrvStatusInfo * pCDMASrvStatusInfo
- nas_SrvStatusInfo * pHDRSrvStatusInfo
- nas_GSMSrvStatusInfo * pGSMSrvStatusInfo
- nas_GSMSrvStatusInfo * pWCDMASrvStatusInfo
- nas_GSMSrvStatusInfo * pLTESrvStatusInfo

- nas_CDMASysInfo * pCDMASysInfo
- nas_HDRSysInfo * pHDRSysInfo
- nas_GSMSysInfo * pGSMSysInfo
- nas_WCDMASysInfo * pWCDMASysInfo
- nas_LTESysInfo * pLTESysInfo
- nas_AddCDMASysInfo * pAddCDMASysInfo
- uint16_t * pAddHDRSysInfo
- nas_AddSysInfo * pAddGSMSysInfo
- nas_AddSysInfo * pAddWCDMASysInfo
- uint16_t * pAddLTESysInfo
- nas_CallBarringSysInfo * pGSMCallBarringSysInfo
- nas_CallBarringSysInfo * pWCDMACallBarringSysInfo
- uint8_t * pLTEVoiceSupportSysInfo
- uint8_t * pGSMCipherDomainSysInfo
- uint8_t * pWCDMACipherDomainSysInfo

8.618.1 Detailed Description

This structure contains unpack get system information parameters.

Parameters

pCDMASrvStatusInfo	• See nas_SrvStatusInfo for more information. • NULL Pointer for invalid data.
pHDRSrvStatusInfo	• See nas_SrvStatusInfo for more information. • NULL Pointer for invalid data.
pGSMSrvStatusInfo	• See nas_GSMSrvStatusInfo for more information. • NULL Pointer for invalid data.
pWCDMASrvStatusInfo	• See nas_GSMSrvStatusInfo for more information. • NULL Pointer for invalid data.
pLTESrvStatusInfo	• See nas_GSMSrvStatusInfo for more information. • NULL Pointer for invalid data.
pCDMASysInfo	• See nas_CDMASysInfo for more information. • NULL Pointer for invalid data.
pHDRSysInfo	• See nas_HDRSysInfo for more information. • NULL Pointer for invalid data.
pGSMSysInfo	• See nas_GSMSysInfo for more information. • NULL Pointer for invalid data.

pWCDMASysInfo	• See nas_WCDMASysInfo for more information. • NULL Pointer for invalid data.
pLTESysInfo	• See nas_LTESysInfo for more information. • NULL Pointer for invalid data.
pAddCDMASysInfo	• See nas_AddCDMASysInfo for more information. • NULL Pointer for invalid data.
pAddHDRSysInfo	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used. • NULL Pointer for invalid data.
pAddGSMSysInfo	• See nas_AddSysInfo for more information. • NULL Pointer for invalid data.
pAddWCDMASysInfo	• See nas_AddSysInfo for more information. • NULL Pointer for invalid data.
pAddLTESysInfo	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used. • NULL Pointer for invalid data.
pGSMCallBarringSysInfo	• See nas_CallBarringSysInfo for more information. • NULL Pointer for invalid data.
pWCDMACallBarringSysInfo	• See nas_CallBarringSysInfo for more information. • NULL Pointer for invalid data.
pLTEVoiceSupportSysInfo	• Indicates voice support status on LTE. – 0x00 - Voice is not supported – 0x01 - Voice is supported • NULL Pointer for invalid data.

pGSMCipher-DomainSysInfo	• Ciphering on the service domain. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched • NULL Pointer for invalid data.
pWCDMA-CipherDomain-SysInfo	• Ciphering on the service domain. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched • NULL Pointer for invalid data.

8.618.2 Field Documentation

8.618.2.1 nas_AddCDMASysInfo∗ unpack_nas_SLQSGetSysInfo_t::pAddCDMASysInfo

8.618.2.2 nas_AddSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pAddGSMSysInfo

8.618.2.3 uint16_t∗ unpack_nas_SLQSGetSysInfo_t::pAddHDRSysInfo

8.618.2.4 uint16_t∗ unpack_nas_SLQSGetSysInfo_t::pAddLTESysInfo

8.618.2.5 nas_AddSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pAddWCDMASysInfo

8.618.2.6 nas_SrvStatusInfo∗ unpack_nas_SLQSGetSysInfo_t::pCDMASrvStatusInfo

8.618.2.7 nas_CDMASysInfo∗ unpack_nas_SLQSGetSysInfo_t::pCDMASysInfo

8.618.2.8 nas_CallBarringSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pGSMCallBarringSysInfo

8.618.2.9 uint8_t∗ unpack_nas_SLQSGetSysInfo_t::pGSMCipherDomainSysInfo

8.618.2.10 nas_GSMSrvStatusInfo∗ unpack_nas_SLQSGetSysInfo_t::pGSMSrvStatusInfo

8.618.2.11 nas_GSMSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pGSMSysInfo

8.618.2.12 nas_SrvStatusInfo∗ unpack_nas_SLQSGetSysInfo_t::pHDRSrvStatusInfo

8.618.2.13 nas_HDRSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pHDRSysInfo

8.618.2.14 nas_GSMSrvStatusInfo∗ unpack_nas_SLQSGetSysInfo_t::pLTESrvStatusInfo

8.618.2.15 nas_LTESysInfo∗ unpack_nas_SLQSGetSysInfo_t::pLTESysInfo

8.618.2.16 uint8_t∗ unpack_nas_SLQSGetSysInfo_t::pLTEVoiceSupportSysInfo

8.618.2.17 nas_CallBarringSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pWCDMACallBarringSysInfo

8.618.2.18 uint8_t* unpack_nas_SLQSGetSysInfo_t::pWCDMACipherDomainSysInfo

8.618.2.19 nas_GSMSrvStatusInfo* unpack_nas_SLQSGetSysInfo_t::pWCDMASrvStatusInfo

8.618.2.20 nas_WCDMASysInfo* unpack_nas_SLQSGetSysInfo_t::pWCDMASysInfo

8.619 unpack_nas_SLQSGetSysSelectionPref_t Struct Reference

Data Fields

- uint8_t * pEmerMode
- uint16_t * pModePref
- uint64_t * pBandPref
- uint16_t * pPRLPref
- uint16_t * pRoamPref
- uint64_t * pLTEBandPref
- uint8_t * pNetSelPref
- uint32_t * pSrvDomainPref
- uint32_t * pGWAcqOrderPref

8.619.1 Detailed Description

This structure contains unpack get get system selection preferences parameters.

Parameters

pEmerMode	• Optional parameter specifying the emergency Mode • Values: – 0 - OFF (normal) – 1 - ON (Emergency) • NULL Pointer for invalid data.
pModePref	• Optional parameter • Bit Mask indicating the radio technology mode preference • Bit values: – Bit 0 - cdma2000 1x – Bit 1 - cdma2000 HRPD(1xEV-DO) – Bit 2 - GSM – Bit 3 - UMTS – Bit 4 - LTE • NULL Pointer for invalid data.

pBandPref	• Optional parameter • Bit mask representing the band preference • Bit values: – Bit 0 - Band Class 0, A-System – Bit 1 - Band Class 0, B-System, Band Class 0 AB, GSM 850 Band – Bit 2 - Band Class 1, all blocks – Bit 3 - Band Class 2 place holder – Bit 4 - Band Class 3, A-System – Bit 5 - Band Class 4, all blocks – Bit 6 - Band Class 5, all blocks – Bit 7 - GSM_DCS_1800 band – Bit 8 - GSM Extended GSM (E-GSM) 900 band – Bit 9 - GSM Primary GSM (P-GSM) 900 band – Bit 10 - Band Class 6 – Bit 11 - Band Class 7 – Bit 12 - Band Class 8 – Bit 13 - Band Class 9 – Bit 14 - Band Class 10 – Bit 15 - Band Class 11 – Bit 16 - GSM 450 band – Bit 17 - GSM 480 band – Bit 18 - GSM 750 band – Bit 19 - GSM 850 band – Bit 20 - GSM Railways GSM 900 Band – Bit 21 - GSM PCS 1900 band – Bit 22 - WCDMA Europe, Japan, and China IMT 2100 band – Bit 23 - WCDMA U.S. PCS 1900 band – Bit 24 - WCDMA Europe and China DCS 1800 band – Bit 25 - WCDMA U.S. 1700 band – Bit 26 - WCDMA U.S. 850 band – Bit 27 - WCDMA Japan 800 band – Bit 28 - Band Class 12 – Bit 29 - Band Class 14 – Bit 30 - Reserved – Bit 31 - Band Class 15 – Bit 32 to 47 - Reserved – Bit 48 - WCDMA Europe 2600 band – Bit 49 - WCDMA Europe and Japan 900 band – Bit 50 - WCDMA Japan 1700 band – Bit 51 to 55 - Reserved – Bit 56 - Band Class 16 – Bit 57 - Band Class 17 – Bit 58 - Band Class 18 – Bit 59 - Band Class 19 – Bit 60 to 64 - Reserved • NULL Pointer for invalid data.

pPRLPref	• Optional parameter indicating the CDMA PRL Preference • Values: – 0x0001 - Acquire available system only on the A side – 0x0002 - Acquire available system only on the B side – 0x3FFF - Acquire any available systems • NULL Pointer for invalid data.
pRoamPref	• Optional parameter indicating the roaming Preference • Values: – 0x01 - Acquire only systems for which the roaming indicator is off – 0x02 - Acquire a system as long as its roaming indicator is not off – 0x03 - Acquire only systems for which the roaming indicator is off or solid on, i.e. not flashing; CDMA only – 0xFF - Acquire systems, regardless of their roaming indicator • NULL Pointer for invalid data.

pLTEBandPref	• Optional parameter • Bit mask representing the LTE band preference • Bit Values – Bit 0 - E-UTRA Operating Band 1 – Bit 1 - E-UTRA Operating Band 2 – Bit 2 - E-UTRA Operating Band 3 – Bit 3 - E-UTRA Operating Band 4 – Bit 4 - E-UTRA Operating Band 5 – Bit 5 - E-UTRA Operating Band 6 – Bit 6 - E-UTRA Operating Band 7 – Bit 7 - E-UTRA Operating Band 8 – Bit 8 - E-UTRA Operating Band 9 – Bit 9 - E-UTRA Operating Band 10 – Bit 10 - E-UTRA Operating Band 11 – Bit 11 - E-UTRA Operating Band 12 – Bit 12 - E-UTRA Operating Band 13 – Bit 13 - E-UTRA Operating Band 14 – Bit 16 - E-UTRA Operating Band 17 – Bit 17 - E-UTRA Operating Band 18 – Bit 18 - E-UTRA Operating Band 19 – Bit 19 - E-UTRA Operating Band 20 – Bit 20 - E-UTRA Operating Band 21 – Bit 32 - E-UTRA Operating Band 33 – Bit 33 - E-UTRA Operating Band 34 – Bit 34 - E-UTRA Operating Band 35 – Bit 35 - E-UTRA Operating Band 36 – Bit 36 - E-UTRA Operating Band 37 – Bit 37 - E-UTRA Operating Band 38 – Bit 38 - E-UTRA Operating Band 39 – Bit 39 - E-UTRA Operating Band 40 – All other bits are reserved • NULL Pointer for invalid data.
pNetSelPref	• Optional parameter indicating network selection preference • Values: – 0x00 - Automatic network selection – 0x01 - Manual network selection. • NULL Pointer for invalid data.

pSrvDomainPref	• Optional parameter indicating Service domain preference • Values: – 0x00 - Circuit switched only – 0x01 - Packet switched only – 0x02 - Circuit switched and packet switched – 0x03 - Packet switched attach – 0x04 - Packet switched detach • NULL Pointer for invalid data.
pGWAcqOrder-Pref	• Optional parameter indicating GSM/WCDMA Acquisition order Preference • Values: – 0x00 - Automatic – 0x01 - GSM then WCDMA – 0x02 - WCDMA then GSM • NULL Pointer for invalid data.

8.619.2 Field Documentation

8.619.2.1 uint64_t* unpack_nas_SLQSGetSysSelectionPref_t::pBandPref

8.619.2.2 uint8_t* unpack_nas_SLQSGetSysSelectionPref_t::pEmerMode

8.619.2.3 uint32_t* unpack_nas_SLQSGetSysSelectionPref_t::pGWAcqOrderPref

8.619.2.4 uint64_t* unpack_nas_SLQSGetSysSelectionPref_t::pLTEBandPref

8.619.2.5 uint16_t* unpack_nas_SLQSGetSysSelectionPref_t::pModePref

8.619.2.6 uint8_t* unpack_nas_SLQSGetSysSelectionPref_t::pNetSelPref

8.619.2.7 uint16_t* unpack_nas_SLQSGetSysSelectionPref_t::pPRLPref

8.619.2.8 uint16_t* unpack_nas_SLQSGetSysSelectionPref_t::pRoamPref

8.619.2.9 uint32_t* unpack_nas_SLQSGetSysSelectionPref_t::pSrvDomainPref

8.620 unpack_nas_SLQSNasGet3GPP2Subscription_t Struct Reference

Data Fields

- nas_namName * pNAMNameInfo
- nas_dirNum * pDirNum
- nas_homeSIDNID * pHomeSIDNID
- nas_minBasedIMSI * pMinBasedIMSI
- nas_trueIMSI * pTrueIMSI
- nas_CDMAChannel * pCDMAChannel

8.620.1 Detailed Description

Structure for 3GPP2Subscription unpack.

Parameters

pNAMNameInfo	[Optional] • See nas_namName for more information • NULL for invalid data
pDirNum	[Optional] • See nas_dirNum for more information • NULL for invalid data
pHomeSIDNID	[Optional] • See nas_homeSIDNID for more information • NULL for invalid data
pMinBasedIMSI	[Optional] • See nas_minBasedIMSI for more information • NULL for invalid data
pTrueIMSI	[Optional] • See nas_trueIMSI for more information • NULL for invalid data
pCDMAChannel	[Optional] • See nas_CDMAChannel for more information • NULL for invalid data

8.620.2 Field Documentation

8.620.2.1 nas_CDMAChannel∗ unpack_nas_SLQSNasGet3GPP2Subscription_t::pCDMAChannel

8.620.2.2 nas_dirNum∗ unpack_nas_SLQSNasGet3GPP2Subscription_t::pDirNum

8.620.2.3 nas_homeSIDNID∗ unpack_nas_SLQSNasGet3GPP2Subscription_t::pHomeSIDNID

8.620.2.4 nas_minBasedIMSI∗ unpack_nas_SLQSNasGet3GPP2Subscription_t::pMinBasedIMSI

8.620.2.5 nas_namName∗ unpack_nas_SLQSNasGet3GPP2Subscription_t::pNAMNameInfo

8.620.2.6 nas_trueIMSI∗ unpack_nas_SLQSNasGet3GPP2Subscription_t::pTrueIMSI

8.621 unpack_nas_SLQSNasGetCellLocationInfo_t Struct Reference

Data Fields

- nas_GERANInfo ∗ pGERANInfo
- nas_UMTSInfo ∗ pUMTSInfo
- nas_CDMAInfo ∗ pCDMAInfo
- nas_LTEInfoIntrafreq ∗ pLTEInfoIntrafreq
- nas_LTEInfoInterfreq ∗ pLTEInfoInterfreq

- nas_LTEInfoNeighboringGSM * pLTEInfoNeighboringGSM
- nas_LTEInfoNeighboringWCDMA * pLTEInfoNeighboringWCDMA
- uint32_t * pUMTSCellID
- nas_WCDMAInfoLTENeighborCell * pWCDMAInfoLTENeighborCell

8.621.1 Detailed Description

This structure contains information about the Get Cell Location response parameters.

Parameters

pGERANInfo	• See nas_GERANInfo for more information. • NULL for invalid data
pUMTSInfo	• See nas_UMTSInfo for more information. • NULL for invalid data
pCDMAInfo	• See nas_CDMAInfo for more information. • NULL for invalid data
pLTEInfo-Intrafreq	• See nas_LTEInfoIntrafreq for more information. • NULL for invalid data
pLTEInfo-Interfreq	• See nas_LTEInfoInterfreq for more information. • NULL for invalid data
pLTEInfo-NeighboringGS-M	• See nas_LTEInfoNeighboringGSM for more information. • NULL for invalid data
pLTEInfo-NeighboringWC-DMA	• See nas_LTEInfoNeighboringWCDMA for more information. • NULL for invalid data
pUMTSCellID	• Cell ID. • 0xFFFFFFFF indicates cell ID information is not present. • NULL for invalid data
pWCDMAInfoLT-ENeighborCell	• See nas_WCDMAInfoLTENeighborCell for more information. • NULL for invalid data

8.621.2 Field Documentation

8.621.2.1 nas_CDMAInfo* unpack_nas_SLQSNasGetCellLocationInfo_t::pCDMAInfo

8.621.2.2 **nas_GERANInfo**∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pGERANInfo

8.621.2.3 **nas_LTEInfoInterfreq**∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pLTEInfoInterfreq

8.621.2.4 **nas_LTEInfoIntrafreq**∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pLTEInfoIntrafreq

8.621.2.5 **nas_LTEInfoNeighboringGSM**∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pLTEInfoNeighboringGSM

8.621.2.6 **nas_LTEInfoNeighboringWCDMA**∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pLTEInfoNeighboringWCDMA

8.621.2.7 **uint32_t**∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pUMTSCellID

8.621.2.8 **nas_UMTSInfo**∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pUMTSInfo

8.621.2.9 **nas_WCDMAInfoLTENeighborCell**∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pWCDMAInfoLTENeighborCell

8.622 unpack_nas_SLQSNASGeteDRXParams_t Struct Reference

Data Fields

- uint8_t ∗ pCycleLen
- uint8_t ∗ pPagingTimeWindow
- uint8_t ∗ pEdrxEnable

8.622.1 Detailed Description

This structure contains the SLQSNASGeteDRXParams unpack parameters.

Parameters

pCycleLen	[Optional] • eDRX cycle length • Value is per 3GPP TS 24.008 Rel-13 Section 10.5.5.32
pPagingTime-Window	[Optional] • eDRX paging time window • Value is per 3GPP TS 24.008 Rel-13 Section10.5.5.32
pEdrxEnable	[Optional] • eDRX Enable • Values – 0x00 - Disable – 0x01 - Enable

8.622.2 Field Documentation

8.622.2.1 **uint8_t**∗ unpack_nas_SLQSNASGeteDRXParams_t::pCycleLen

8.622.2.2 **uint8_t**∗ unpack_nas_SLQSNASGeteDRXParams_t::pEdrxEnable

8.622.2.3 **uint8_t**∗ unpack_nas_SLQSNASGeteDRXParams_t::pPagingTimeWindow

8.623 unpack_nas_SLQSNasGetHDRColorCode_t Struct Reference

Data Fields

- uint8_t * pColorCode

8.623.1 Detailed Description

Structure for storing the current preferred system selection settings for the device.

Parameters

pColorCode	[Optional] • Color code value • Color code corresponding to the sector to which the AT is sending the access probe • See 3GPP2 C.S0024-B V3.0, Section 7.11.6.2.1 for more information. – 0xFF - Not Available • NULL for invalid data

8.623.2 Field Documentation

8.623.2.1 uint8_t* unpack_nas_SLQSNasGetHDRColorCode_t::pColorCode

8.624 unpack_nas_SLQSNasGetSigInfo_t Struct Reference

Data Fields

- cdmaSSInfo CDMASSInfo
- hdrSSInfo HDRSSInfo
- int8_t GSMSSInfo
- cdmaSSInfo WCDMASSInfo
- lteSSInfo LTESSInfo

8.624.1 Detailed Description

This structure contains the SLQSNasGetSigInfo response parameters.

Parameters

CDMASSInfo	• See cdmaSSInfo for more information
HDRSSInfo	• See hdrSSInfo for more information
GSMSSInfo	• GSM signal strength is the RSSI in dBm (signed value). • A value of -125 dBm or lower is used to indicate No Signal.
WCDMASSInfo	• See cdmaSSInfo for more information

LTESSInfo	• See lteSSInfo for more information

8.624.2 Field Documentation

8.624.2.1 cdmaSSInfo unpack_nas_SLQSNasGetSigInfo_t::CDMASSInfo

8.624.2.2 int8_t unpack_nas_SLQSNasGetSigInfo_t::GSMSSInfo

8.624.2.3 hdrSSInfo unpack_nas_SLQSNasGetSigInfo_t::HDRSSInfo

8.624.2.4 lteSSInfo unpack_nas_SLQSNasGetSigInfo_t::LTESSInfo

8.624.2.5 cdmaSSInfo unpack_nas_SLQSNasGetSigInfo_t::WCDMASSInfo

8.625 unpack_nas_SLQSNasGetTxRxInfo_t Struct Reference

Data Fields

- nas_rxInfo * pRXChain0Info
- nas_rxInfo * pRXChain1Info
- nas_txInfo * pTXInfo

8.625.1 Detailed Description

Structure for TxRx Info unpack

Parameters

pRXChain0Info	[Optional] • See nas_rxInfo for more information. • NULL for invalid data.
pRXChain1Info	[Optional] • See nas_rxInfo for more information. • NULL for invalid data.
pTXInfo	[Optional] • See nas_txInfo for more information. • NULL for invalid data.

8.625.2 Field Documentation

8.625.2.1 nas_rxInfo* unpack_nas_SLQSNasGetTxRxInfo_t::pRXChain0Info

8.625.2.2 nas_rxInfo* unpack_nas_SLQSNasGetTxRxInfo_t::pRXChain1Info

8.625.2.3 nas_txInfo* unpack_nas_SLQSNasGetTxRxInfo_t::pTXInfo

8.626 unpack_nas_SLQSNasNetworkTimeCallBack_ind_t Struct Reference

Data Fields

- nas_UniversalTime universalTime
- uint8_t * pTimeZone
- uint8_t * pDayltSavAdj
- uint8_t * pRadioInterface

8.626.1 Detailed Description

Structure for storing the NAS Network Time indication parameters.

Parameters

universalTime	• See nas_UniversalTime for more information.
pTimeZone	• Time Zone. • Offset from Universal time, i.e., the difference between local time and Universal time, in increments of 15 min (signed value). • NULL for invalid data.
pDayltSavAdj	• Daylight Saving Adjustment. • Daylight saving adjustment in hr. – Possible values: 0, 1, and 2. • NULL for invalid data.
pRadioInterface	• Radio interface from which the information comes • Values – 0x01 - NAS_RADIO_IF_CDMA_1X - cdma2000 1X – 0x02 - NAS_RADIO_IF_CDMA_1XEVDO - cdma2000 HRPD (1xEV-DO) – 0x04 - NAS_RADIO_IF_GSM - GSM – 0x05 - NAS_RADIO_IF_UMTS - UMTS – 0x08 - NAS_RADIO_IF_LTE - LTE – 0x09 - NAS_RADIO_IF_TDSCDMA -TD-SCDMA • NULL for invalid data.

8.626.2 Field Documentation

8.626.2.1 uint8_t* unpack_nas_SLQSNasNetworkTimeCallBack_ind_t::pDayltSavAdj

8.626.2.2 uint8_t* unpack_nas_SLQSNasNetworkTimeCallBack_ind_t::pRadioInterface

8.626.2.3 uint8_t* unpack_nas_SLQSNasNetworkTimeCallBack_ind_t::pTimeZone

8.626.2.4 nas_UniversalTime unpack_nas_SLQSNasNetworkTimeCallBack_ind_t::universalTime

8.627 unpack_nas_SLQSNasSigInfoCallback_ind_t Struct Reference

Data Fields

- cdmaSSInfo * pCDMASigInfo
- hdrSSInfo * pHDRSigInfo
- int8_t * pGSMSigInfo
- cdmaSSInfo * pWCDMASigInfo
- lteSSInfo * pLTESigInfo
- int8_t * pRscp
- tdscdmaSigInfoExt * pTDSCDMASigInfoExt

8.627.1 Detailed Description

Structure for storing the nasSigInfo indication parameters.

Parameters

pCDMASigInfo	• See cdmaSSInfo for more information. • NULL Pointer for invalid data.
pHDRSigInfo	• See hdrSSInfo for more information. • NULL Pointer for invalid data.
pGSMSigInfo	• one byte value, GSM signal strength is the RSSI in dBm (signed value). A value of -125 dBm or lower is used to indicate No Signal • NULL Pointer for invalid data.
pWCDMASigInfo	• See cdmaSSInfo for more information. • NULL Pointer for invalid data.
pLTESigInfo	• See lteSSInfo for more information. • NULL Pointer for invalid data.
pRscp	• RSCP of the Primary Common Control Physical Channel (PCCPCH) in dBm. Measurement range: -120 dBm to -25 dBm. • NULL Pointer for invalid data.
pTDSCDMASig-InfoExt	• See tdscdmaSigInfoExt for more information. • NULL Pointer for invalid data.

8.627.2 Field Documentation

8.627.2.1 cdmaSSInfo* unpack_nas_SLQSNasSigInfoCallback_ind_t::pCDMASigInfo

8.627.2.2 int8_t* unpack_nas_SLQSNasSigInfoCallback_ind_t::pGSMSigInfo

8.627.2.3 hdrSSInfo* unpack_nas_SLQSNasSigInfoCallback_ind_t::pHDRSigInfo

8.627.2.4 lteSSInfo* unpack_nas_SLQSNasSigInfoCallback_ind_t::pLTESigInfo

8.627.2.5 int8_t* unpack_nas_SLQSNasSigInfoCallback_ind_t::pRscp

8.627.2.6 tdscdmaSigInfoExt* unpack_nas_SLQSNasSigInfoCallback_ind_t::pTDSCDMASigInfoExt

8.627.2.7 cdmaSSInfo* unpack_nas_SLQSNasSigInfoCallback_ind_t::pWCDMASigInfo

8.628 unpack_nas_SLQSNASSwiGetChannelLock_t Struct Reference

Data Fields

- nas_wcdmaUARFCN * pWcdmaUARFCN
- nas_lteEARFCN * pLteEARFCN
- nas_ltePCI * pLtePCI

8.628.1 Detailed Description

Structure for Get Channel Lock unpack.

Parameters

pWcdmaUARFCN	[Optional] • See nas_wcdmaUARFCN for more information • NULL for invalid data
pLteEARFCN	[Optional] • See nas_lteEARFCN for more information • NULL for invalid data
pLtePCI	[Optional] • See nas_ltePCI for more information • NULL for invalid data

8.628.2 Field Documentation

8.628.2.1 nas_lteEARFCN* unpack_nas_SLQSNASSwiGetChannelLock_t::pLteEARFCN

8.628.2.2 nas_ltePCI* unpack_nas_SLQSNASSwiGetChannelLock_t::pLtePCI

8.628.2.3 nas_wcdmaUARFCN* unpack_nas_SLQSNASSwiGetChannelLock_t::pWcdmaUARFCN

8.629 unpack_nas_SLQSNasSwiModemStatus_t Struct Reference

Data Fields

- nas_CommInfo commonInfo
- nas_LTEInfo * pLTEInfo

8.629.1 Detailed Description

Structure for storing the SLQS Nas Swi Modem Status response parameters.

Parameters

commonInfo	(mandatory) • See nas_CommInfo for more information
pLTEInfo	(optional) • See nas_LTEInfo for more information • NULL for invalid data.

8.629.2 Field Documentation

8.629.2.1 nas_CommInfo unpack_nas_SLQSNasSwiModemStatus_t::commonInfo

8.629.2.2 nas_LTEInfo* unpack_nas_SLQSNasSwiModemStatus_t::pLTEInfo

8.630 unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t Struct Reference

Data Fields

- NASQmiCbkNasSwiOTAMessageInd Info
- uint16_t TlvResult

8.630.1 Detailed Description

This structure contains unpack OTA message indication parameters.

Parameters

Info	• Structure used to store all QMI Notification Info. – See NASQmiCbkNasSwiOTAMessageInd for more details
TlvResult	• unpack result

8.630.2 Field Documentation

8.630.2.1 NASQmiCbkNasSwiOTAMessageInd unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t::Info

8.630.2.2 uint16_t unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t::TlvResult

8.631 unpack_nas_SLQSNasTimerCallback_ind_t Struct Reference

Data Fields

- char t3396_apn [101]
- uint8_t t3396_plmn_id [3]

- uint32_t t3396_val

8.631.1 Detailed Description

Structure for Network Timer indication parameters.

Parameters

t3396_apn	• apn
t3396_plmn_id	• plmn id
t3396_val	• timer value

8.631.2 Field Documentation

8.631.2.1 char unpack_nas_SLQSNasTimerCallback_ind_t::t3396_apn[101]

8.631.2.2 uint8_t unpack_nas_SLQSNasTimerCallback_ind_t::t3396_plmn_id[3]

8.631.2.3 uint32_t unpack_nas_SLQSNasTimerCallback_ind_t::t3396_val

8.632 unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t Struct Reference

Data Fields

- NASQmiCbkNasSystemSelPrefInd Info
- uint16_t Tlvresult

8.632.1 Detailed Description

This structure contains unpack set system selection preference callback indication parameters.

Parameters

Info	• Structure used to store all QMI Notification Info. – See NASQmiCbkNasSystemSelPrefInd for more details
Tlvresult	• unpack result

8.632.2 Field Documentation

8.632.2.1 NASQmiCbkNasSystemSelPrefInd unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t::Info

8.632.2.2 uint16_t unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t::Tlvresult

8.633 unpack_nas_SLQSSwiGetHDRPersonality_t Struct Reference

Data Fields

- uint16_t * pCurrentPersonality
- uint8_t * pPersonalityListLength
- nas_protocolSubtypeElement * pProtocolSubtypeElement

8.633.1 Detailed Description

Structure for HDRPersonality unpack.

Parameters

pCurrent-Personality[Out]	• Current active personality index. • NULL for invalid data
pPersonalityList-Length[In/Out]	• Number of Personality Protocol Subtype contains in this response. • maximum input value is 3 • NULL for invalid data
pProtocol-Subtype-Element[Out]	• See nas_protocolSubtypeElement for more information. • NULL for invalid data

8.633.2 Field Documentation

8.633.2.1 uint16_t* unpack_nas_SLQSSwiGetHDRPersonality_t::pCurrentPersonality

8.633.2.2 uint8_t* unpack_nas_SLQSSwiGetHDRPersonality_t::pPersonalityListLength

8.633.2.3 nas_protocolSubtypeElement* unpack_nas_SLQSSwiGetHDRPersonality_t::pProtocolSubtypeElement

8.634 unpack_nas_SLQSSwiGetHDRProtSubtype_t Struct Reference

Data Fields

- uint16_t * pCurrentPrsnlty
- uint8_t * pPersonalityListLength
- nas_protocolSubtypeElement * pProtoSubTypElmnt
- uint64_t * pAppSubType

8.634.1 Detailed Description

Structure for HDRProtSubtype unpack.

Parameters

pCurrent-Personality	• Current active personality index. • NULL for invalid data
pPersonalityList-Length	• Number of Personality Protocol Subtype contains in this response. • maximum input value is 4 • NULL for invalid data
pProtocol-SubtypeElement	• See nas_protocolSubtypeElement for more information. • NULL for invalid data
pAppSubType	• Stream application subtype • Application subtype for each stream • NULL for invalid data

8.634.2 Field Documentation

8.634.2.1 uint64_t* unpack_nas_SLQSSwiGetHDRProtSubtype_t::pAppSubType

8.634.2.2 uint16_t* unpack_nas_SLQSSwiGetHDRProtSubtype_t::pCurrentPrsnlty

8.634.2.3 uint8_t* unpack_nas_SLQSSwiGetHDRProtSubtype_t::pPersonalityListLength

8.634.2.4 nas_protocolSubtypeElement* unpack_nas_SLQSSwiGetHDRProtSubtype_t::pProtoSubTypElmnt

8.635 unpack_nas_SLQSSwiGetHRPDStats_t Struct Reference

Data Fields

- nas_DRCParams * pDRCParams
- uint8_t * pUATI
- nas_PilotSetData * pPilotSetData

8.635.1 Detailed Description

Structure for HRPD Stats unpack.

Parameters

pDRCParams	• See nas_DRCParams for more information. • NULL for invalid data
pUATI	• A 128-bit address that includes the access terminal identifier and subnet ID • Size must be 16 bytes • NULL for invalid data

pPilotSetData	• See nas_PilotSetData for more information. • NULL for invalid data

8.635.2 Field Documentation

8.635.2.1 nas_DRCParams* unpack_nas_SLQSSwiGetHRPDStats_t::pDRCParams

8.635.2.2 nas_PilotSetData* unpack_nas_SLQSSwiGetHRPDStats_t::pPilotSetData

8.635.2.3 uint8_t* unpack_nas_SLQSSwiGetHRPDStats_t::pUATI

8.636 unpack_nas_SLQSSwiGetLteCQI_t Struct Reference

Data Fields

- uint8_t ValidityCW0
- uint8_t CQIValueCW0
- uint8_t ValidityCW1
- uint8_t CQIValueCW1

8.636.1 Detailed Description

This structure contains paramaters unpack fetch CQI parameters for LTE data session.

Parameters

ValidityCW0[OUT]	• Values – 0- Invalid. – 1- Valid.
CQIValueCW0[OUT]	• Values – Range 0∼15
ValidityCW1[OUT]	• Values – 0- Invalid. – 1- Valid.
CQIValueCW1[OUT]	• Values – Range 0∼15

8.636.2 Field Documentation

8.636.2.1 uint8_t unpack_nas_SLQSSwiGetLteCQI_t::CQIValueCW0

8.636.2.2 uint8_t unpack_nas_SLQSSwiGetLteCQI_t::CQIValueCW1

8.636.2.3 uint8_t unpack_nas_SLQSSwiGetLteCQI_t::ValidityCW0

8.636.2.4 uint8_t unpack_nas_SLQSSwiGetLteCQI_t::ValidityCW1

8.637 unpack_nas_SLQSSwiGetLteSccRxInfo_t Struct Reference

Data Fields

- nas_SccRxInfo * pSccRxInfo

8.637.1 Detailed Description

This structure contains unpack get LTE Secondary carrier Rx signal level information parameters.

Parameters

pSccRxInfo	Secondary carrier Rx signal level info • See nas_SccRxInfo • NULL for invalid data

8.637.2 Field Documentation

8.637.2.1 nas_SccRxInfo* unpack_nas_SLQSSwiGetLteSccRxInfo_t::pSccRxInfo

8.638 unpack_nas_SLQSSwiNetworkDebug_t Struct Reference

Data Fields

- uint8_t * pObjectVer
- nas_NetworkStat1x * pNetworkStat1x
- nas_NetworkStatEVDO * pNetworkStatEVDO
- nas_DeviceConfigDetail * pDeviceConfigDetail
- nas_DataStatusDetail * pDataStatusDetail

8.638.1 Detailed Description

Structure for SwiNetworkDebug unpack.

Parameters

pObjectVer	• Object's version number for the host to handle – 0xFF - NA – Others - shows in decimal • NULL for invalid data
pNetworkStat1x	• See nas_NetworkStat1x for more information • NULL for invalid data

pNetworkStatEVDO	• See nas_NetworkStatEVDO for more information. • NULL for invalid data
pDeviceConfigDetail	• See nas_DeviceConfigDetail for more information. • NULL for invalid data
pDataStatusDetail	• See nas_DataStatusDetail for more information. • NULL for invalid data

8.638.2 Field Documentation

8.638.2.1 nas_DataStatusDetail∗ unpack_nas_SLQSSwiNetworkDebug_t::pDataStatusDetail

8.638.2.2 nas_DeviceConfigDetail∗ unpack_nas_SLQSSwiNetworkDebug_t::pDeviceConfigDetail

8.638.2.3 nas_NetworkStat1x∗ unpack_nas_SLQSSwiNetworkDebug_t::pNetworkStat1x

8.638.2.4 nas_NetworkStatEVDO∗ unpack_nas_SLQSSwiNetworkDebug_t::pNetworkStatEVDO

8.638.2.5 uint8_t∗ unpack_nas_SLQSSwiNetworkDebug_t::pObjectVer

8.639 unpack_nas_SLQSSysInfoCallback_ind_t Struct Reference

Data Fields

- nas_SrvStatusInfo ∗ pCDMASrvStatusInfo
- nas_SrvStatusInfo ∗ pHDRSrvStatusInfo
- nas_GSMSrvStatusInfo ∗ pGSMSrvStatusInfo
- nas_GSMSrvStatusInfo ∗ pWCDMASrvStatusInfo
- nas_GSMSrvStatusInfo ∗ pLTESrvStatusInfo
- nas_CDMASysInfo ∗ pCDMASysInfo
- nas_HDRSysInfo ∗ pHDRSysInfo
- nas_GSMSysInfo ∗ pGSMSysInfo
- nas_WCDMASysInfo ∗ pWCDMASysInfo
- nas_LTESysInfo ∗ pLTESysInfo
- nas_AddCDMASysInfo ∗ pAddCDMASysInfo
- uint16_t ∗ pAddHDRSysInfo
- nas_AddSysInfo ∗ pAddGSMSysInfo
- nas_AddSysInfo ∗ pAddWCDMASysInfo
- uint16_t ∗ pAddLTESysInfo
- nas_CallBarringSysInfo ∗ pGSMCallBarringSysInfo
- nas_CallBarringSysInfo ∗ pWCDMACallBarringSysInfo
- uint8_t ∗ pLTEVoiceSupportSysInfo
- uint8_t ∗ pGSMCipherDomainSysInfo
- uint8_t ∗ pWCDMACipherDomainSysInfo
- uint8_t ∗ pSysInfoNoChange

8.639.1 Detailed Description

This structure contains unpack system information callback indication parameters.

Parameters

pCDMASrvStatusInfo	• See nas_SrvStatusInfo for more information.
pHDRSrvStatusInfo	• See nas_SrvStatusInfo for more information.
pGSMSrvStatusInfo	• See nas_GSMSrvStatusInfo for more information.
pWCDMASrvStatusInfo	• See nas_GSMSrvStatusInfo for more information.
pLTESrvStatusInfo	• See nas_GSMSrvStatusInfo for more information.
pCDMASysInfo	• See nas_CDMASysInfo for more information.
pHDRSysInfo	• See nas_HDRSysInfo for more information.
pGSMSysInfo	• See nas_GSMSysInfo for more information.
pWCDMASysInfo	• See nas_WCDMASysInfo for more information.
pLTESysInfo	• See nas_LTESysInfo for more information.
pAddCDMASysInfo	• See nas_AddCDMASysInfo for more information.
pAddHDRSysInfo	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used.
pAddGSMSysInfo	• See nas_AddSysInfo for more information.
pAddWCDMASysInfo	• See nas_AddSysInfo for more information.
pAddLTESysInfo	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used.

pGSMCall-BarringSysInfo	• See nas_CallBarringSysInfo for more information.
pWCDMACall-BarringSysInfo	• See nas_CallBarringSysInfo for more information.
pLTEVoice-SupportSysInfo	• Indicates voice support status on LTE. – 0x00 - Voice is not supported – 0x01 - Voice is supported
pGSMCipher-DomainSysInfo	• Ciphering on the service domain. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched
pWCDMA-CipherDomain-SysInfo	• Ciphering on the service domain. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched
pSysInfoNo-Change	• System Info No Change. • Flag used to notify clients that a request to select a network ended with no change in the PLMN. – 0x01 - No change in system information

8.639.2 Field Documentation

8.639.2.1 nas_AddCDMASysInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pAddCDMASysInfo

8.639.2.2 nas_AddSysInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pAddGSMSysInfo

8.639.2.3 uint16_t∗ unpack_nas_SLQSSysInfoCallback_ind_t::pAddHDRSysInfo

8.639.2.4 uint16_t∗ unpack_nas_SLQSSysInfoCallback_ind_t::pAddLTESysInfo

8.639.2.5 nas_AddSysInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pAddWCDMASysInfo

8.639.2.6 nas_SrvStatusInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pCDMASrvStatusInfo

8.639.2.7 nas_CDMASysInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pCDMASysInfo

8.639.2.8 nas_CallBarringSysInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pGSMCallBarringSysInfo

8.639.2.9 uint8_t∗ unpack_nas_SLQSSysInfoCallback_ind_t::pGSMCipherDomainSysInfo

8.639.2.10 nas_GSMSrvStatusInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pGSMSrvStatusInfo

8.639.2.11 **nas_GSMSysInfo*** unpack_nas_SLQSSysInfoCallback_ind_t::pGSMSysInfo

8.639.2.12 **nas_SrvStatusInfo*** unpack_nas_SLQSSysInfoCallback_ind_t::pHDRSrvStatusInfo

8.639.2.13 **nas_HDRSysInfo*** unpack_nas_SLQSSysInfoCallback_ind_t::pHDRSysInfo

8.639.2.14 **nas_GSMSrvStatusInfo*** unpack_nas_SLQSSysInfoCallback_ind_t::pLTESrvStatusInfo

8.639.2.15 **nas_LTESysInfo*** unpack_nas_SLQSSysInfoCallback_ind_t::pLTESysInfo

8.639.2.16 **uint8_t*** unpack_nas_SLQSSysInfoCallback_ind_t::pLTEVoiceSupportSysInfo

8.639.2.17 **uint8_t*** unpack_nas_SLQSSysInfoCallback_ind_t::pSysInfoNoChange

8.639.2.18 **nas_CallBarringSysInfo*** unpack_nas_SLQSSysInfoCallback_ind_t::pWCDMACallBarringSysInfo

8.639.2.19 **uint8_t*** unpack_nas_SLQSSysInfoCallback_ind_t::pWCDMACipherDomainSysInfo

8.639.2.20 **nas_GSMSrvStatusInfo*** unpack_nas_SLQSSysInfoCallback_ind_t::pWCDMASrvStatusInfo

8.639.2.21 **nas_WCDMASysInfo*** unpack_nas_SLQSSysInfoCallback_ind_t::pWCDMASysInfo

8.640 unpack_omaDmConfigTlv_t Struct Reference

Data Fields

- uint8_t state
- uint8_t userInputReq
- uint16_t userInputTimeout
- uint16_t alertmsglength
- uint8_t alertmsg [256]

8.640.1 Detailed Description

This structure will hold the SwiOmaDmConfig session parameters information.

Parameters

state	• 0x01 - OMA-DM Read Request • 0x02 - OMA-DM Change Request • 0x03 - OMA-DM Config Complete
userInputReq	- Bit mask of available user inputs • 0x00 - No user input required.Informational indication • 0x01 - Accept • 0x02 - Reject
userInput-Timeout	• Timeout for user input in minutes. A value of 0 means no time-out
alertmsglength	• Length of Alert message string in bytes

alertmsg	• Alert message in UCS2 (Max 256 characters)

8.640.2 Field Documentation

8.640.2.1 uint8_t unpack_omaDmConfigTlv_t::alertmsg[256]

8.640.2.2 uint16_t unpack_omaDmConfigTlv_t::alertmsglength

8.640.2.3 uint8_t unpack_omaDmConfigTlv_t::state

8.640.2.4 uint8_t unpack_omaDmConfigTlv_t::userInputReq

8.640.2.5 uint16_t unpack_omaDmConfigTlv_t::userInputTimeout

8.641 unpack_omaDmFotaTlv_t Struct Reference

Data Fields

- uint8_t state
- uint8_t userInputReq
- uint16_t userInputTimeout
- uint32_t fwdloadsize
- uint32_t fwloadComplete
- uint16_t updateCompleteStatus
- uint8_t severity
- uint16_t versionlength
- uint8_t version [256]
- uint16_t namelength
- uint8_t package_name [256]
- uint16_t descriptionlength
- uint8_t description [256]
- uint8_t sessionType

8.641.1 Detailed Description

This structure will hold the SwiOmaDmFota session parameters information.

Parameters

state	• 0x01 - No Firmware available • 0x02 - Query Firmware Download • 0x03 - Firmware Downloading • 0x04 - Firmware downloaded • 0x05 - Query Firmware Update • 0x06 - Firmware updating • 0x07 - Firmware updated

userInputReq	- Bit mask of available user inputs • 0x00 - No user input required.Informational indication • 0x01 - Accept • 0x02 - Reject
userInput-Timeout	• Timeout for user input in minutes. A value of 0 means no time-out
fwdloadsize	• The size (in bytes) of the firmware update package
fwloadComplete	• The number of bytes downloaded. Need to determine how often to send this message for progress bar notification. Every 500ms or 5% increment.
update-CompleteStatus	• This field should be looked at only when the OMADM session is complete. • See qaGobiApiTableSwiOMADMUpdateCompleteStatus.h for update complete status.
severity	• 0x01 - Mandatory • 0x02 - Optional
versionlength	• Length of FW Version string in bytes
version	• FW Version string in ASCII (Max 256 characters)
namelength	• Length Package Name string in bytes
package_name	• Package Name in UCS2 (Max 256 characters)
descriptionlength	• Length of description in bytes
description	• Description of Update Package in USC2 (Max 256 characters)
sessionType	• 0x00 - Client initiated • 0x01 - Network initiated

8.641.2 Field Documentation

8.641.2.1 uint8_t unpack_omaDmFotaTlv_t::description[256]

8.641.2.2 uint16_t unpack_omaDmFotaTlv_t::descriptionlength

8.641.2.3 uint32_t unpack_omaDmFotaTlv_t::fwdloadsize

8.641.2.4 uint32_t unpack_omaDmFotaTlv_t::fwloadComplete

8.641.2.5 uint16_t unpack_omaDmFotaTlv_t::namelength

8.641.2.6 uint8_t unpack_omaDmFotaTlv_t::package_name[256]

8.641.2.7 uint8_t unpack_omaDmFotaTlv_t::sessionType

8.641.2.8 uint8_t unpack_omaDmFotaTlv_t::severity

8.641.2.9 uint8_t unpack_omaDmFotaTlv_t::state

8.641.2.10 uint16_t unpack_omaDmFotaTlv_t::updateCompleteStatus

8.641.2.11 uint8_t unpack_omaDmFotaTlv_t::userInputReq

8.641.2.12 uint16_t unpack_omaDmFotaTlv_t::userInputTimeout

8.641.2.13 uint8_t unpack_omaDmFotaTlv_t::version[256]

8.641.2.14 uint16_t unpack_omaDmFotaTlv_t::versionlength

8.642 unpack_omaDmNotificationsTlv_t Struct Reference

Data Fields

- uint8_t notification
- uint16_t sessionStatus

8.642.1 Detailed Description

This structure will hold the SwiOmaDmConfig session notification parameters information.

Parameters

notification	• 0x01 - GPS settings change • 0x02 - Device reset • 0x03 - Device factory reset • 0x04 - CI-DC Session start • 0x05 - CI-DC Session end • 0x06 - CI-PRL Session start • 0x07 - CI-PRL Session end • 0x08 - CI-FUMO Session start • 0x09 - CI-FUMO session end • 0x0A - HFA-DC Session start • 0x0B - HFA-DC Session end • 0x0C - HFA-PRL Session start • 0x0D - HFA-PRL Session end • 0x0E - HFA-FUMO Session start • 0x0F - HFA-FUMO session end • 0x10 - NI Session start • 0x11 - NI session end
sessionStatus	• This field will set to the session status for notifications that occur at the end of a session, zero for all other notifications • See qaGobiApiTableSwiOMADMSessionStatus.h for session completion code.

8.642.2 Field Documentation

8.642.2.1 uint8_t unpack_omaDmNotificationsTlv_t::notification

8.642.2.2 uint16_t unpack_omaDmNotificationsTlv_t::sessionStatus

8.643 unpack_pds_GetPDSDefaults_t Struct Reference

Data Fields

- uint32_t * pOperation
- uint8_t * pTimeout
- uint32_t * pInterval
- uint32_t * pAccuracy

8.643.1 Detailed Description

Structure contain session configuration parameters.

Parameters

pOperation	• Current session operating mode – 0 - Standalone – 1 - MS based – 2 - MS assisted • NULL pointer - Invalid data.
pTimeout	• Maximum amount of time (seconds) to work on each fix, maximum is 255 • NULL pointer - Invalid data.
pInterval	• Interval (seconds) between fix requests • NULL pointer - Invalid data.
pAccuracy	• Preferred accuracy threshold (meters) • NULL pointer - Invalid data.

8.643.2 Field Documentation

8.643.2.1 uint32_t* unpack_pds_GetPDSDefaults_t::pAccuracy

8.643.2.2 uint32_t* unpack_pds_GetPDSDefaults_t::pInterval

8.643.2.3 uint32_t* unpack_pds_GetPDSDefaults_t::pOperation

8.643.2.4 uint8_t* unpack_pds_GetPDSDefaults_t::pTimeout

8.644 unpack_pds_GetPDSState_t Struct Reference

Data Fields

- uint32_t * pEnabledStatus
- uint32_t * pTrackingStatus

8.644.1 Detailed Description

Structure contain parameters of current PDS state.

Parameters

pEnabledStatus	• Current PDS state – 0 - disable – 1 - enable • NULL pointer - Invalid data.

pTrackingStatus	• Current PDS tracking session state • Values: – 0x00 - Unknown – 0x01 - Inactive – 0x02 - Active • NULL pointer - Invalid data.

8.644.2 Field Documentation

8.644.2.1 uint32_t* unpack_pds_GetPDSState_t::pEnabledStatus

8.644.2.2 uint32_t* unpack_pds_GetPDSState_t::pTrackingStatus

8.645 unpack_pds_GetPortAutomaticTracking_t Struct Reference

Data Fields

- uint32_t * pbAuto

8.645.1 Detailed Description

Structure contain the parameter of automatic tracking configuration for the NMEA COM port.

Parameters

pbAuto	• Automatic tracking enabled for NMEA COM port – 0x00 - Disabled – 0x01 - Enabled

- NULL pointer - Invalid data.

8.645.2 Field Documentation

8.645.2.1 uint32_t* unpack_pds_GetPortAutomaticTracking_t::pbAuto

8.646 unpack_pds_GetServiceAutomaticTracking_t Struct Reference

Data Fields

- uint32_t * pbAuto

8.646.1 Detailed Description

Structure contain the parameter for automatic tracking state.

Parameters

pbAuto	• Automatic tracking session started for service – 0x00 - Disabled – 0x01 - Enabled • NULL pointer - Invalid data.

8.646.2 Field Documentation

8.646.2.1 uint32_t* unpack_pds_GetServiceAutomaticTracking_t::pbAuto

8.647 unpack_pds_GetXTRAAutomaticDownload_t Struct Reference

Data Fields

- uint32_t * pbEnabled
- uint16_t * pInterval

8.647.1 Detailed Description

Structure contain the parameter of automatic tracking configuration for the NMEA COM port.

Parameters

pbEnabled	• Automatic XTRA download status – 0 - Disabled – 1 - Enabled • NULL pointer - Invalid data.
pInterval	• Interval (hours) between XTRA downloads • NULL pointer - Invalid data.

8.647.2 Field Documentation

8.647.2.1 uint32_t* unpack_pds_GetXTRAAutomaticDownload_t::pbEnabled

8.647.2.2 uint16_t* unpack_pds_GetXTRAAutomaticDownload_t::pInterval

8.648 unpack_pds_GetXTRANetwork_t Struct Reference

Data Fields

- uint32_t * pPreference

8.648.1 Detailed Description

Structure contain the parameter for XTRA WWAN network preference

Parameters

pPreference	• XTRA WWAN network preference – 0x00 - None (any available network) – 0x01 - Home-only, only when on home systems – 0x02 - Roam-only, only when on non-home systems • NULL pointer - Invalid data.

8.648.2 Field Documentation

8.648.2.1 uint32_t* unpack_pds_GetXTRANetwork_t::pPreference

8.649 unpack_pds_GetXTRAValidity_t Struct Reference

Data Fields

- uint16_t * pGPSWeek
- uint16_t * pGPSWeekOffset
- uint16_t * pDuration

8.649.1 Detailed Description

Structure contain the parameter for XTRA database validity period

Parameters

pGPSWeek	• Starting GPS week of validity period • NULL pointer - Invalid data.
pGPSWeek-Offset	• Starting GPS week offset (minutes) of validity period • NULL pointer - Invalid data.
pDuration	• Length of validity period (hours) • NULL pointer - Invalid data.

8.649.2 Field Documentation

8.649.2.1 uint16_t* unpack_pds_GetXTRAValidity_t::pDuration

8.649.2.2 uint16_t* unpack_pds_GetXTRAValidity_t::pGPSWeek

8.649.2.3 uint16_t* unpack_pds_GetXTRAValidity_t::pGPSWeekOffset

8.650 unpack_pds_SetEventReport_Ind_t Struct Reference

Data Fields

- uint8_t has_PositionDataNMEA
- char PositionDataNMEA [200]
- uint8_t has_dLongitude
- double dLongitude
- uint8_t has_dLatitude
- double dLatitude
- uint8_t has_SessionStatus
- uint8_t SessionStatus
- uint8_t has_posSrc
- uint32_t posSrc

8.650.1 Detailed Description

Structure contain the parameter for the Set event report Indication. Please check has_<Param_Name> field for presence of optional parameters

Parameters

PositionDataNMEA	• Position Data NMEA. • String containing the position data in NMEA sentence format (maximum 200 bytes).
dLongitude	• Longitude position referenced to the WGS-84 reference ellipsoid, counting positive angles east of the Greenwich Meridian and negative angles west of the Greenwich Meridian. • Units - Decimal degrees • Range - -180 to +180 • Note - Value is in double float format
dLatitude	• Latitude position referenced to the WGS-84 reference ellipsoid, counting positive angles north of the equator and negative angles south of the equator. • Units: Decimal degrees • Range: -90 to +90 • Note - Value is in double float format
session_status	• Position Session Status • Status of current session. • Values – 0x00 - Success – 0x01 - In progress – 0x02 - General failure – 0x03 - Timeout – 0x04 - User ended the session – 0x05 - Bad parameter – 0x06 - Phone is offline – 0x07 - Engine is locked – 0x08 - E911 session in progress • Note - This TLV is always sent while a fix is being generated or if it halts due to an error. The Parsed Position Data TLV (0x13) is included if the session status is Success (0x00) or In Progress (0x01); otherwise this TLV is passed alone.

posSrc	• Position Source • This TLV is always sent with the Parsed Position Data TLV (0x13) when the latitude/longitude is marked as valid. Source of the position (bitmask). • Values – 0x00000001 - GPS – 0x00000002 – Cell ID – 0x00000004 – GLONASS – 0x00000008 – Network – 0x00000010 – External position injection

8.650.2 Field Documentation

8.650.2.1 double unpack_pds_SetEventReport_Ind_t::dLatitude

8.650.2.2 double unpack_pds_SetEventReport_Ind_t::dLongitude

8.650.2.3 uint8_t unpack_pds_SetEventReport_Ind_t::has_dLatitude

8.650.2.4 uint8_t unpack_pds_SetEventReport_Ind_t::has_dLongitude

8.650.2.5 uint8_t unpack_pds_SetEventReport_Ind_t::has_PositionDataNMEA

8.650.2.6 uint8_t unpack_pds_SetEventReport_Ind_t::has_posSrc

8.650.2.7 uint8_t unpack_pds_SetEventReport_Ind_t::has_SessionStatus

8.650.2.8 char unpack_pds_SetEventReport_Ind_t::PositionDataNMEA[200]

8.650.2.9 uint32_t unpack_pds_SetEventReport_Ind_t::posSrc

8.650.2.10 uint8_t unpack_pds_SetEventReport_Ind_t::SessionStatus

8.651 unpack_pds_SetPdsState_Ind_t Struct Reference

Data Fields

- uint16_t TlvPresent
- uint32_t EnabledStatus
- uint32_t TrackingStatus

8.651.1 Detailed Description

Structure contain the parameter for the Set PDS State Indication.

Parameters

EnabledStatus	• GPS service state. • Values – 0x00 - Disable – 0x01 - Enable
TrackingStatus	• Tracking session state. • Values – 0x00 - Unknown – 0x01 - Inactive – 0x02 - Active

8.651.2 Field Documentation

8.651.2.1 uint32_t unpack_pds_SetPdsState_Ind_t::EnabledStatus

8.651.2.2 uint16_t unpack_pds_SetPdsState_Ind_t::TlvPresent

8.651.2.3 uint32_t unpack_pds_SetPdsState_Ind_t::TrackingStatus

8.652 unpack_pds_SLQSGetAGPSConfig_t Struct Reference

Data Fields

- uint32_t * pServerAddress
- uint32_t * pServerPort
- uint8_t * pServerURL
- uint8_t * pServerURLLength

8.652.1 Detailed Description

Structure contain the parameter for PDS AGPS (MS-based) configuration unpack.

Parameters

pServerAddress	• IPv4 address of AGPS server. "0" if not set
pServerPort	• Port number of AGPS server. "0" if not set
pServerURL	• URL of the AGPS server. "0" if not set
pServerURL-Length	• URL length of AGPS server. "0" if not set

8.652.2 Field Documentation

8.652.2.1 uint32_t* unpack_pds_SLQSGetAGPSConfig_t::pServerAddress

8.652.2.2 uint32_t* unpack_pds_SLQSGetAGPSConfig_t::pServerPort

8.652.2.3 uint8_t* unpack_pds_SLQSGetAGPSConfig_t::pServerURL

8.652.2.4 uint8_t* unpack_pds_SLQSGetAGPSConfig_t::pServerURLLength

8.653 unpack_pds_SLQSGetGPSStateInfo_t Struct Reference

Data Fields

- uint8_t EngineState
- uint32_t ValidMask
- uint64_t Latitude
- uint64_t Longitude
- uint32_t HorizontalUncertainty
- uint32_t Altitude
- uint32_t VerticalUncertainty
- uint32_t TimeStmp_tow_ms
- uint16_t TimeStmp_gps_week
- uint32_t Time_uncert_ms
- uint8_t Iono_valid
- uint32_t gps_ephemeris_sv_msk
- uint32_t gps_almanac_sv_msk
- uint32_t gps_health_sv_msk
- uint32_t gps_visible_sv_msk
- uint32_t glo_ephemeris_sv_msk
- uint32_t glo_almanac_sv_msk
- uint32_t glo_health_sv_msk
- uint32_t glo_visible_sv_msk
- uint32_t sbas_ephemeris_sv_msk
- uint32_t sbas_almanac_sv_msk
- uint32_t sbas_health_sv_msk
- uint32_t sbas_visible_sv_msk
- uint16_t xtra_start_gps_week
- uint16_t xtra_start_gps_minutes
- uint16_t xtra_valid_duration_hours

8.653.1 Detailed Description

Structure contain the parameter for GPS state Info.

Parameters

EngineState	• Values: – 0 - OFF – 1 - ON • This field is always valid

ValidMask	• Mask of valid state information data. • Values: – 0x00000001 - Position(latitude/longitude/horizontal uncertainty) – 0x00000002 - Altitude and vertical uncertainty – 0x00000004 - Time ms – 0x00000008 - Time week number – 0x00000010 - Time uncertainty – 0x00000020 - Iono validity – 0x00000040 - GPS ephemeris – 0x00000080 - GPS almanac – 0x00000100 - GPS health – 0x00000200 - GPS visible SVs – 0x00000400 - GLONASS ephemeris – 0x00000800 - GLONASS almanac – 0x00001000 - GLONASS health – 0x00002000 - GLONASS visible SVs – 0x00004000 - SBAS ephemeris – 0x00008000 - SBAS almanac – 0x00010000 - SBAS health – 0x00020000 - SBAS visible SVs – 0x00040000 - XTRA information
Latitude	• Latitude position referenced to the WGS-84 reference ellipsoid, counting positive angles north of the equator and negative angles south of the equator. • Units: Decimal degrees • Range: -90 to +90 degrees. • Value is in double float format (refer to IEEE Std 754-1985)
Longitude	• Longitude position referenced to the WGS-84 reference ellipsoid, counting positive angles east of the Greenwich Meridian and negative angles west of Greenwich meridian. • Units: Decimal degrees • Range: -180 to +180 degrees • Value is in double float format (refer to IEEE Std 754-1985)
Horizontal-Uncertainty	• Circular horizontal uncertainty (in meters). The uncertainty is provided at 63 percent confidence. • Value is in single float format (refer to IEEE Std 754-1985)
Altitude	• Height above the WGS-84 reference ellipsoid. Value conveys height (in meters) plus 500 m • Range -500 to 15883 • Value in single float format (refer to IEEE Std 754-1985)
Vertical-Uncertainty	• Vertical uncertainty (in meters). The uncertainty is provided at 68 percent confidence. • Value in single float format (refer to IEEE Std 754-1985)

TimeStmp_tow_ms	• Time stamp in GPS time of week(in milliseconds)
TimeStmp_gps_week	• GPS week number
Time_uncert_ms	• Time uncertainty (in milliseconds). The uncertainty is provided at 99 percent confidence.
Iono_valid	• Iono validity. • Values: – 0 - Invalid – 1 - Valid
gps_ephemeris_sv_msk	• GPS SV mask for ephemeris; if the bit is set, ephemeris for that SV is available.
gps_almanac_sv_msk	• GPS SV mask for almanac; if the bit is set, almanac for that SV is available.
gps_health_sv_msk	• GPS SV mask for health; if the bit is set, health for that SV is available.
gps_visible_sv_msk	• GPS SV mask for visible Svs; if the bit is set, the SV is available.
glo_ephemeris_sv_msk	• GLONASS SV mask for ephemeris; if the bit is set, ephemeris for that SV is available.
glo_almanac_sv_msk	• GLONASS SV mask for almanac; if the bit is set, almanac for that SV is available.
glo_health_sv_msk	• GLONASS SV mask for health; if the bit is set, health for that SV is available.
glo_visible_sv_msk	• GLONASS SV mask for visible SVs; if the bit is set, the SV is available.
sbas_ephemeris_sv_msk	• SBAS SV mask for ephemeris; if the bit is set, ephemeris for that SV is available.
sbas_almanac_sv_msk	• SBAS SV mask for almanac; if the bit is set, almanac for that SV is available.
sbas_health_sv_msk	• SBAS SV mask for health; if the bit is set, health for that SV is available.
sbas_visible_sv_msk	• SBAS SV mask for visible SVs; if the bit is set, the SV is available.

xtra_start_gps_week	• Current XTRA information is valid starting from this GPS week number
xtra_start_gps_minutes	• Current XTRA information is valid starting from the GPS minutes with the GPS week
xtra_valid_duration_hours	• XTRA information is valid for this many hours starting from the specified GPS week/minutes

8.653.2 Field Documentation

8.653.2.1 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::Altitude

8.653.2.2 uint8_t unpack_pds_SLQSGetGPSStateInfo_t::EngineState

8.653.2.3 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::glo_almanac_sv_msk

8.653.2.4 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::glo_ephemeris_sv_msk

8.653.2.5 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::glo_health_sv_msk

8.653.2.6 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::glo_visible_sv_msk

8.653.2.7 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::gps_almanac_sv_msk

8.653.2.8 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::gps_ephemeris_sv_msk

8.653.2.9 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::gps_health_sv_msk

8.653.2.10 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::gps_visible_sv_msk

8.653.2.11 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::HorizontalUncertainty

8.653.2.12 uint8_t unpack_pds_SLQSGetGPSStateInfo_t::Iono_valid

8.653.2.13 uint64_t unpack_pds_SLQSGetGPSStateInfo_t::Latitude

8.653.2.14 uint64_t unpack_pds_SLQSGetGPSStateInfo_t::Longitude

8.653.2.15 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::sbas_almanac_sv_msk

8.653.2.16 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::sbas_ephemeris_sv_msk

8.653.2.17 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::sbas_health_sv_msk

8.653.2.18 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::sbas_visible_sv_msk

8.653.2.19 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::Time_uncert_ms

8.653.2.20 uint16_t unpack_pds_SLQSGetGPSStateInfo_t::TimeStmp_gps_week

8.653.2.21 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::TimeStmp_tow_ms

8.653.2.22 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::ValidMask

8.653.2.23 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::VerticalUncertainty

8.653.2.24 uint16_t unpack_pds_SLQSGetGPSStateInfo_t::xtra_start_gps_minutes

8.653.2.25 uint16_t unpack_pds_SLQSGetGPSStateInfo_t::xtra_start_gps_week

8.653.2.26 uint16_t unpack_pds_SLQSGetGPSStateInfo_t::xtra_valid_duration_hours

8.654 unpack_qmi_t Struct Reference

Data Fields

- enum msgtype type
- uint16_t msgid
- uint16_t xid

8.654.1 Detailed Description

qmi response context

Parameters

out	*type*	message type
out	*msgid*	message id
out	*xid*	transaction id

8.654.2 Field Documentation

8.654.2.1 uint16_t unpack_qmi_t::msgid

8.654.2.2 enum msgtype unpack_qmi_t::type

8.654.2.3 uint16_t unpack_qmi_t::xid

8.655 unpack_qos_dataRate_t Struct Reference

Data Fields

- uint32_t dataRateMax
- uint32_t guaranteedRate

8.655.1 Detailed Description

This structure contains the IP flow data rate min max

Parameters

dataRateMax	Maximum required data rate (bits per second)
guaranteedRate	Minimum guaranteed data rate (bits per second)

8.655.2 Field Documentation

8.655.2.1 uint32_t unpack_qos_dataRate_t::dataRateMax

8.655.2.2 uint32_t unpack_qos_dataRate_t::guaranteedRate

8.656 unpack_qos_IPv4Addr_t Struct Reference

Data Fields

- uint32_t addr
- uint32_t subnetMask

8.656.1 Detailed Description

This structure contains the IPv4 filter address

Parameters

addr	IPv4 address
subnetMask	A packet matches if: • (addr and subnetMask) == (IP pkt addr & subnetMask) Callers to set up a filter with a range of source addresses, if needed; subnet mask of all 1s (255.255.255.255) specifies a single address value

8.656.2 Field Documentation

8.656.2.1 uint32_t unpack_qos_IPv4Addr_t::addr

8.656.2.2 uint32_t unpack_qos_IPv4Addr_t::subnetMask

8.657 unpack_qos_IPv6Addr_t Struct Reference

Data Fields

- uint8_t addr [16]
- uint8_t prefixLen

8.657.1 Detailed Description

This structure contains the IPv6 filter address

Parameters

addr	IPv6 address (in network byte order); this is a 16-byte byte array (in Big-endian format)
prefixLen	IPv6 filter prefix length; can take a value between 0 and 128 Note: A packet matches if the IPv6 source address bytes until the prefix lengths are equal. Therefore prefix length can be used to set a filter with a range of source addresses. A prefix length of 128 specifies a single address value.

8.657.2 Field Documentation

8.657.2.1 uint8_t unpack_qos_IPv6Addr_t::addr[16]

8.657.2.2 uint8_t unpack_qos_IPv6Addr_t::prefixLen

8.658 unpack_qos_IPv6TrafCls_t Struct Reference

Data Fields

- uint8_t val
- uint8_t mask

8.658.1 Detailed Description

This structure contains the IPv6 filter traffic class

Parameters

val	The traffic class value
mask	The packet matches the traffic class filter if: (IPv6_filter_traffic_class_val and IPv6_filter_traffic_class_mask) == (Traffic class value in the IP packet & IPv6_filter_traffic_class_mask) Example: • IPv6_filter_tc_val = 00101000 • IPv6_filter_tc_mask = 11111100 Filter will compare only the first 6 bits in IPv6_filter_traffic_class with the first 6 bits in the traffic class field of the IP packet; first 6 bits in the traffic class field of the IP packet must be 001010 to match filter; last 2 bits can be anything, since they are ignored by filtering

8.658.2 Field Documentation

8.658.2.1 uint8_t unpack_qos_IPv6TrafCls_t::mask

8.658.2.2 uint8_t unpack_qos_IPv6TrafCls_t::val

8.659 unpack_qos_pktErrRate_t Struct Reference

Data Fields

- uint16_t multiplier
- uint16_t exponent

8.659.1 Detailed Description

This structure contains the IP flow packet error rate

Parameters

multiplier	Factor m in calculating packet error rate: E = m∗10∗∗(-p)
exponent	Factor p in calculating packet error rate (see above)

8.659.2 Field Documentation

8.659.2.1 uint16_t unpack_qos_pktErrRate_t::exponent

8.659.2.2 uint16_t unpack_qos_pktErrRate_t::multiplier

8.660 unpack_qos_Port_t Struct Reference

Data Fields

- uint16_t port
- uint16_t range

8.660.1 Detailed Description

This structure contains the Port Filter

Parameters

port	port value of the filter
range	range specifies the number of ports to be included in the filter starting from port; filter will match if port in the IP packet lies between port and (port + range) Range value of 0 implies that only one value of the port is valid, as specified by the port

8.660.2 Field Documentation

8.660.2.1 uint16_t unpack_qos_Port_t::port

8.660.2.2 uint16_t unpack_qos_Port_t::range

8.661 unpack_qos_QosFlowInfo_t Struct Reference

Data Fields

- unpack_qos_QosFlowInfoState_t QFlowState
- uint8_t is_TxQFlowGranted_Available
- unpack_qos_swiQosFlow_t TxQFlowGranted
- uint8_t is_RxQFlowGranted_Available
- unpack_qos_swiQosFlow_t RxQFlowGranted
- uint8_t NumTxFilters
- unpack_qos_swiQosFilter_t TxQFilter [25]
- uint8_t NumRxFilters
- unpack_qos_swiQosFilter_t RxQFilter [25]
- uint8_t BearerID

8.661.1 Detailed Description

Structure with QoS flow details.

Please check is_<Param_Name>_Available field for presence of optional parameters

Parameters

QFlowState	• QoS flow state information, please check unpack_qos_QosFlowInfoState_t for more information
is_TxQFlow-Granted_-Available	• TRUE if optional TxQFlowGranted is available

TxQFlow-Granted	• The Tx Qos flow granted, please check unpack_qos_swiQosFlow_t for more information
is_RxQFlow-Granted_-Available	• TRUE if optional RxQFlowGranted is available
RxQFlow-Granted	• The Rx Qos flow granted, please check unpack_qos_swiQosFlow_t for more information
NumTxFilters	• Number of Tx filters available
TxQFilter	• The Tx Qos filter, please check unpack_qos_swiQosFilter_t for more information • See LITEQMI_MAX_QOS_FILTERS for more information
NumRxFilters	• Number of Tx filters available
RxQFilter	• The Rx Qos filter, please check unpack_qos_swiQosFilter_t for more information • See LITEQMI_MAX_QOS_FILTERS for more information
BearerID	• The bearer ID • Bearer ID or Radio Link Protocol (RLP) ID of the activated flow. • Valid Values - 0 to 16 • 0xFF - Invalid value.

8.661.2 Field Documentation

8.661.2.1 uint8_t unpack_qos_QosFlowInfo_t::BearerID

8.661.2.2 uint8_t unpack_qos_QosFlowInfo_t::is_RxQFlowGranted_Available

8.661.2.3 uint8_t unpack_qos_QosFlowInfo_t::is_TxQFlowGranted_Available

8.661.2.4 uint8_t unpack_qos_QosFlowInfo_t::NumRxFilters

8.661.2.5 uint8_t unpack_qos_QosFlowInfo_t::NumTxFilters

8.661.2.6 unpack_qos_QosFlowInfoState_t unpack_qos_QosFlowInfo_t::QFlowState

8.661.2.7 unpack_qos_swiQosFilter_t unpack_qos_QosFlowInfo_t::RxQFilter[25]

8.661.2.8 unpack_qos_swiQosFlow_t unpack_qos_QosFlowInfo_t::RxQFlowGranted

8.661.2.9 unpack_qos_swiQosFilter_t unpack_qos_QosFlowInfo_t::TxQFilter[25]

8.661.2.10 unpack_qos_swiQosFlow_t unpack_qos_QosFlowInfo_t::TxQFlowGranted

8.662 unpack_qos_QosFlowInfoState_t Struct Reference

Data Fields

- uint32_t id
- uint8_t isNewFlow
- uint8_t state

8.662.1 Detailed Description

This structure contains QoS flow state

Parameters

id	QoS identifier
isNewFlow	• 1 - Newly added flow • 0 - Existing flow
state	This indicates that the flow that was added/modified/deleted: • 0x01 - Flow activated • 0x02 - Flow modified • 0x03 - Flow deleted • 0x04 - Flow suspended • 0x05 - Flow enabled • 0x06 - Flow disabled

8.662.2 Field Documentation

8.662.2.1 uint32_t unpack_qos_QosFlowInfoState_t::id

8.662.2.2 uint8_t unpack_qos_QosFlowInfoState_t::isNewFlow

8.662.2.3 uint8_t unpack_qos_QosFlowInfoState_t::state

8.663 unpack_qos_SLQSQosGetNetworkStatus_t Struct Reference

Data Fields

- uint8_t NWQoSStatus

8.663.1 Detailed Description

Structure that contains the response to get NW QoS status command

Parameters

NWQoSStatus	Network QoS support status • 0 - No QoS support in network • 1 - Network supports QoS • 0xff - Invalid Data.

8.663.2 Field Documentation

8.663.2.1 uint8_t unpack_qos_SLQSQosGetNetworkStatus_t::NWQoSStatus

8.664 unpack_qos_SLQSQosSwiReadApnExtraParams_t Struct Reference

Data Fields

- uint32_t apnId
- uint8_t ambr_ul
- uint8_t ambr_dl
- uint8_t ambr_ul_ext
- uint8_t ambr_dl_ext
- uint8_t ambr_ul_ext2
- uint8_t ambr_dl_ext2

8.664.1 Detailed Description

Structure that contains extra APN parameters

Parameters

apnId	• APN id • ID identifing the APN that the client would like to query the AMBR params
ambr_ul	• APN AMBR uplink • APN AMBR uplink values from 1 kbps to 8640 kbps
ambr_dl	• APN AMBR downlink • APN AMBR downlink values from 1 kbps to 8640 kbps
ambr_ul_ext	• Extended APN AMBR uplink • APN AMBR uplink values from 8700 kbps to 256 Mbps
ambr_dl_ext	• Extended APN AMBR downlink • APN AMBR downlink values from 8700 kbps to 256 Mbps
ambr_ul_ext2	• Second extended APN AMBR uplink • APN AMBR uplink values from 256 Mbps to 65280 Mbps
ambr_dl_ext2	• Second extended APN AMBR downlink • APN AMBR downlink values from 256 Mbps to 65280 Mbps

8.664.2 Field Documentation

8.664.2.1 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_dl

8.664.2.2 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_dl_ext

8.664.2.3 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_dl_ext2

8.664.2.4 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_ul

8.664.2.5 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_ul_ext

8.664.2.6 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_ul_ext2

8.664.2.7 uint32_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::apnId

8.665 unpack_qos_SLQSQosSwiReadDataStats_t Struct Reference

Data Fields

- uint32_t apnId
- uint32_t total_tx_pkt
- uint32_t total_tx_pkt_drp
- uint32_t total_rx_pkt
- uint64_t total_tx_bytes
- uint64_t total_tx_bytes_drp
- uint64_t total_rx_bytes
- uint32_t numQosFlow
- unpack_QosFlowStat_t qosFlow [10]

8.665.1 Detailed Description

Structure that contains APN data statistics

Parameters

apnId	• APN id • ID identifing the connected APN that the client would like to query the data statistic for
total_tx_pkt	• sum of all packets sent
total_tx_pkt_drp	• sum of all(TX) packets dropped
total_rx_pkt	• sum of all packets received
total_tx_bytes	• sum of all bytes sent
total_tx_bytes_drp	• sum of all(TX) bytes dropped

total_rx_bytes	• number of received bytes for the QoS flow ID
numQosFlow	• pointer to number of QoS flow Stat
qosFlow[LITEQMI_MAX_QOS_FLOW_PER_APN_STATS]	• Data statistic per QoS flow • See unpack_QosFlowStat_t for more information • See LITEQMI_MAX_QOS_FLOW_PER_APN_STATS for more information

8.665.2 Field Documentation

8.665.2.1 uint32_t unpack_qos_SLQSQosSwiReadDataStats_t::apnId

8.665.2.2 uint32_t unpack_qos_SLQSQosSwiReadDataStats_t::numQosFlow

8.665.2.3 unpack_QosFlowStat_t unpack_qos_SLQSQosSwiReadDataStats_t::qosFlow[10]

8.665.2.4 uint64_t unpack_qos_SLQSQosSwiReadDataStats_t::total_rx_bytes

8.665.2.5 uint32_t unpack_qos_SLQSQosSwiReadDataStats_t::total_rx_pkt

8.665.2.6 uint64_t unpack_qos_SLQSQosSwiReadDataStats_t::total_tx_bytes

8.665.2.7 uint64_t unpack_qos_SLQSQosSwiReadDataStats_t::total_tx_bytes_drp

8.665.2.8 uint32_t unpack_qos_SLQSQosSwiReadDataStats_t::total_tx_pkt

8.665.2.9 uint32_t unpack_qos_SLQSQosSwiReadDataStats_t::total_tx_pkt_drp

8.666 unpack_qos_SLQSSetQosEventCallback_ind_t Struct Reference

Data Fields

- uint8_t NumFlows
- unpack_qos_QosFlowInfo_t QosFlowInfo [8]

8.666.1 Detailed Description

Structure with QoS event details

Parameters

NumFlows	• Number of QoS flows available
QosFlowInfo	• The Qos flow details, please check unpack_qos_QosFlowInfo_t for more information • See LITEQMI_MAX_QOS_FLOWS for more information

8.666.2 Field Documentation

8.666.2.1 uint8_t unpack_qos_SLQSSetQosEventCallback_ind_t::NumFlows

8.666.2.2 unpack_qos_QosFlowInfo_t unpack_qos_SLQSSetQosEventCallback_ind_t::QosFlowInfo[8]

8.667 unpack_qos_SLQSSetQosNWStatusCallback_ind_t Struct Reference

Data Fields

- uint8_t status

8.667.1 Detailed Description

Structure with network's QoS status

Parameters

status	Network QoS support status • 0x00 - Current network does not support QoS • 0x01 - Current network supports QoS

Note

- Technology Supported: CDMA

8.667.2 Field Documentation

8.667.2.1 uint8_t unpack_qos_SLQSSetQosNWStatusCallback_ind_t::status

8.668 unpack_qos_SLQSSetQosPriEventCallback_ind_t Struct Reference

Data Fields

- uint16_t event

8.668.1 Detailed Description

Structure with QoS primary flow events

Parameters

event	Event which causes this indication: • 0x0001 - Primary flow QoS modify operation success • 0x0002 - Primary flow QoS modify operation failure

8.668.2 Field Documentation

8.668.2.1 uint16_t unpack_qos_SLQSSetQosPriEventCallback_ind_t::event

8.669 unpack_qos_SLQSSetQosStatusCallback_ind_t Struct Reference

Data Fields

- uint32_t id
- uint8_t status
- uint8_t event
- uint8_t reason

8.669.1 Detailed Description

Structure with QoS status indication details

Parameters

id	• Index identifying the QoS flow whose status is being reported
status	Current QoS flow status: • 0x01 - QMI_QOS_STATUS_ACTIVATED • 0x02 - QMI_QOS_STATUS_SUSPENDED • 0x03 - QMI_QOS_STATUS_GONE
event	• 0x01 - QMI_QOS_ACTIVATED_EV • 0x02 - QMI_QOS_SUSPENDED_EV • 0x03 - QMI_QOS_GONE_EV • 0x04 - QMI_QOS_MODIFY_ACCEPTED_EV • 0x05 - QMI_QOS_MODIFY_REJECTED_EV • 0x06 - QMI_QOS_INFO_CODE_UPDATED_EV

reason	• 0x01 - QMI_QOS_INVALID_PARAMS • 0x02 - QMI_QOS_INTERNAL_CALL_ENDED • 0x03 - QMI_QOS_INTERNAL_ERROR • 0x04 - QMI_QOS_INSUFFICIENT_LOCAL_Resources • 0x05 - QMI_QOS_TIMED_OUT_OPERATION • 0x06 - QMI_QOS_INTERNAL_UNKNOWN_CAUSE_CODE • 0x07 - QMI_QOS_INTERNAL_MODIFY_IN_PROGRESS • 0x08 - QMI_QOS_NOT_SUPPORTED • 0x09 - QMI_QOS_NOT_AVAILABLE • 0x0A - QMI_QOS_NOT_GUARANTEED • 0x0B - QMI_QOS_INSUFFICIENT_NETWORK_RESOURCES • 0x0C - QMI_QOS_AWARE_SYSTEM • 0x0D - QMI_QOS_UNAWARE_SYSTEM • 0x0E - QOS_REJECTED_OPERATION • 0x0F - QMI_QOS_WILL_GRANT_WHEN_QOS_RESUMED • 0x10 - QMI_QOS_NETWORK_CALL_ENDED • 0x11 - QMI_QOS_NETWORK_SERVICE_NOT_AVAILABLE • 0x12 - QMI_QOS_NETWORK_L2_LINK_RELEASED • 0x13 - QMI_QOS_NETWORK_L2_LINK_REESTAB_REJ • 0x14 - QMI_QOS_NETWORK_L2_LINK_REESTAB_IND • 0x15 - QMI_QOS_NETWORK_UNKNOWN_CAUSE_CODE • 0x16 - QMI_NETWORK_BUSY • 0xff - Invalid Data.

8.669.2 Field Documentation

8.669.2.1 uint8_t unpack_qos_SLQSSetQosStatusCallback_ind_t::event

8.669.2.2 uint32_t unpack_qos_SLQSSetQosStatusCallback_ind_t::id

8.669.2.3 uint8_t unpack_qos_SLQSSetQosStatusCallback_ind_t::reason

8.669.2.4 uint8_t unpack_qos_SLQSSetQosStatusCallback_ind_t::status

8.670 unpack_qos_swiQosFilter_t Struct Reference

Data Fields

- uint8_t index
- uint8_t version
- uint8_t is_IPv4SrcAddr_Available
- unpack_qos_IPv4Addr_t IPv4SrcAddr
- uint8_t is_IPv4DstAddr_Available
- unpack_qos_IPv4Addr_t IPv4DstAddr
- uint8_t is_NxtHdrProto_Available
- uint8_t NxtHdrProto
- uint8_t is_IPv4Tos_Available
- unpack_qos_Tos_t IPv4Tos
- uint8_t is_IPv6SrcAddr_Available

- unpack_qos_IPv6Addr_t IPv6SrcAddr
- uint8_t is_IPv6DstAddr_Available
- unpack_qos_IPv6Addr_t IPv6DstAddr
- uint8_t is_IPv6TrafCls_Available
- unpack_qos_IPv6TrafCls_t IPv6TrafCls
- uint8_t is_IPv6Label_Available
- uint32_t IPv6Label
- uint8_t is_TCPSrcPort_Available
- unpack_qos_Port_t TCPSrcPort
- uint8_t is_TCPDstPort_Available
- unpack_qos_Port_t TCPDstPort
- uint8_t is_UDPSrcPort_Available
- unpack_qos_Port_t UDPSrcPort
- uint8_t is_UDPDstPort_Available
- unpack_qos_Port_t UDPDstPort
- uint8_t is_EspSpi_Available
- uint32_t EspSpi
- uint8_t is_Precedence_Available
- uint16_t Precedence
- uint8_t is_Id_Available
- uint16_t Id
- uint8_t is_TranSrcPort_Available
- unpack_qos_Port_t TranSrcPort
- uint8_t is_TranDstPort_Available
- unpack_qos_Port_t TranDstPort

8.670.1 Detailed Description

This structure contains the QoS Filter Request.

Please check is_<Param_Name>_Available field for presence of optional parameters

Parameters

index	Mandatory parameter IP filter index Integer that uniquely identifies each filter instance This TLV must be present in the request
version	Mandatory parameter IP filter version Identifies whether the filter is associated with IPv4 or IPv6; value specified also implies that only TLVs defined for that IP version, i.e., TLVs with IPv4 or IPv6 in the name, can be specified • 0x04 - IPv4 • 0x06 - Ipv6
IPv4SrcAddr	IPv4 filter soruce address See unpack_qos_IPv4Addr_t for more information • Implemented only for unsolicited indication
IPv4DstAddr	IPv4 filter destination address See unpack_qos_IPv4Addr_t for more information • Implemented only for unsolicited indication
NxtHdrProto	IP filter next header protocol This TLV must be present if any non-IP filter TLV(s) are provided If this field is specified, only IP packets belonging to specified higher layer protocol are considered when filtering The following protocols may be specified: • 0x01 = ICMP • 0x06 = TCP • 0x11 = UDP • 0x32 = ESP Note: The next header protocol field will be set to 0xFD (TCP & UDP) if a TFT is received specifying a source or destination port number, but IP next header type is not specified.

IPv4Tos	IPv4 filter type of service See unpack_qos_Tos_t for more information
IPv6SrcAddr	IPv6 filter soruce address See unpack_qos_IPv6Addr_t for more information • Implemented only for unsolicited indication
IPv6DstAddr	IPv6 filter destination address See unpack_qos_IPv6Addr_t for more information • Implemented only for unsolicited indication
IPv6TrafCls	IPv6 filter traffic class See unpack_qos_IPv6TrafCls_t for more information
IPv6Label	IPv6 flow label Packet matches the IPv6 flow label filter if: (∗pIPv6Label == flow label in the IPv6 header) • Implemented only for unsolicited indication
TCPSrcPort	TCP filter source port filter See unpack_qos_Port_t for more information • Implemented only for unsolicited indication
TCPDstPort	TCP filter destination port filter See unpack_qos_Port_t for more information • Implemented only for unsolicited indication
UDPSrcPort	UDP filter source port filter See unpack_qos_Port_t for more information • Implemented only for unsolicited indication
UDPDstPort	UDP filter destination port filter See unpack_qos_Port_t for more information • Implemented only for unsolicited indication
EspSpi	ESP filter security policy index Security policy index to uniquely identify each IP flow for filtering encrypted packets for encapsulating security payload • Implemented only for unsolicited indication
Precedence	Filter Precedence Specifies the order in which filters are applied; lower numerical value has higher precedence Note: This TLV only applies to network-initiated QoS; QoS requests containing this TLV from control points will be ignored
Id	Filter ID Unique identifier for each filter;filter ID is assigned by the modem Note: This TLV only applies to network-initiated QoS; QoS requests containing this TLV from control points will be ignored
TranSrcPort	Transport protocolfilter source port See unpack_qos_Port_t for more information • Implemented only for unsolicited indication
UDPDstPort	Transport protocol filter destination port See unpack_qos_Port_t for more information • Implemented only for unsolicited indication

8.670.2 Field Documentation

8.670.2.1 uint32_t unpack_qos_swiQosFilter_t::EspSpi

8.670.2.2 uint16_t unpack_qos_swiQosFilter_t::Id

8.670.2.3 uint8_t unpack_qos_swiQosFilter_t::index

8.670.2.4 unpack_qos_IPv4Addr_t unpack_qos_swiQosFilter_t::IPv4DstAddr

8.670.2.5 unpack_qos_IPv4Addr_t unpack_qos_swiQosFilter_t::IPv4SrcAddr

8.670.2.6 unpack_qos_Tos_t unpack_qos_swiQosFilter_t::IPv4Tos

8.670.2.7 **unpack_qos_IPv6Addr_t** unpack_qos_swiQosFilter_t::IPv6DstAddr

8.670.2.8 uint32_t unpack_qos_swiQosFilter_t::IPv6Label

8.670.2.9 **unpack_qos_IPv6Addr_t** unpack_qos_swiQosFilter_t::IPv6SrcAddr

8.670.2.10 **unpack_qos_IPv6TrafCls_t** unpack_qos_swiQosFilter_t::IPv6TrafCls

8.670.2.11 uint8_t unpack_qos_swiQosFilter_t::is_EspSpi_Available

8.670.2.12 uint8_t unpack_qos_swiQosFilter_t::is_Id_Available

8.670.2.13 uint8_t unpack_qos_swiQosFilter_t::is_IPv4DstAddr_Available

8.670.2.14 uint8_t unpack_qos_swiQosFilter_t::is_IPv4SrcAddr_Available

8.670.2.15 uint8_t unpack_qos_swiQosFilter_t::is_IPv4Tos_Available

8.670.2.16 uint8_t unpack_qos_swiQosFilter_t::is_IPv6DstAddr_Available

8.670.2.17 uint8_t unpack_qos_swiQosFilter_t::is_IPv6Label_Available

8.670.2.18 uint8_t unpack_qos_swiQosFilter_t::is_IPv6SrcAddr_Available

8.670.2.19 uint8_t unpack_qos_swiQosFilter_t::is_IPv6TrafCls_Available

8.670.2.20 uint8_t unpack_qos_swiQosFilter_t::is_NxtHdrProto_Available

8.670.2.21 uint8_t unpack_qos_swiQosFilter_t::is_Precedence_Available

8.670.2.22 uint8_t unpack_qos_swiQosFilter_t::is_TCPDstPort_Available

8.670.2.23 uint8_t unpack_qos_swiQosFilter_t::is_TCPSrcPort_Available

8.670.2.24 uint8_t unpack_qos_swiQosFilter_t::is_TranDstPort_Available

8.670.2.25 uint8_t unpack_qos_swiQosFilter_t::is_TranSrcPort_Available

8.670.2.26 uint8_t unpack_qos_swiQosFilter_t::is_UDPDstPort_Available

8.670.2.27 uint8_t unpack_qos_swiQosFilter_t::is_UDPSrcPort_Available

8.670.2.28 uint8_t unpack_qos_swiQosFilter_t::NxtHdrProto

8.670.2.29 uint16_t unpack_qos_swiQosFilter_t::Precedence

8.670.2.30 **unpack_qos_Port_t** unpack_qos_swiQosFilter_t::TCPDstPort

8.670.2.31 **unpack_qos_Port_t** unpack_qos_swiQosFilter_t::TCPSrcPort

8.670.2.32 **unpack_qos_Port_t** unpack_qos_swiQosFilter_t::TranDstPort

8.670.2.33 **unpack_qos_Port_t** unpack_qos_swiQosFilter_t::TranSrcPort

8.670.2.34 **unpack_qos_Port_t** unpack_qos_swiQosFilter_t::UDPDstPort

8.670.2.35 unpack_qos_Port_t unpack_qos_swiQosFilter_t::UDPSrcPort

8.670.2.36 uint8_t unpack_qos_swiQosFilter_t::version

8.671 unpack_qos_swiQosFlow_t Struct Reference

Data Fields

- uint8_t index
- uint8_t is_ProfileId3GPP2_Available
- uint16_t ProfileId3GPP2
- uint8_t is_val_3GPP2Pri_Available
- uint8_t val_3GPP2Pri
- uint8_t is_TrafficClass_Available
- uint8_t TrafficClass
- uint8_t is_DataRate_Available
- unpack_qos_dataRate_t DataRate
- uint8_t is_TokenBucket_Available
- unpack_qos_tokenBucket_t TokenBucket
- uint8_t is_Latency_Available
- uint32_t Latency
- uint8_t is_Jitter_Available
- uint32_t Jitter
- uint8_t is_PktErrRate_Available
- unpack_qos_pktErrRate_t PktErrRate
- uint8_t is_MinPolicedPktSz_Available
- uint32_t MinPolicedPktSz
- uint8_t is_MaxAllowedPktSz_Available
- uint32_t MaxAllowedPktSz
- uint8_t is_val_3GPPResResidualBER_Available
- uint16_t val_3GPPResResidualBER
- uint8_t is_val_3GPPTraHdlPri_Available
- uint8_t val_3GPPTraHdlPri
- uint8_t is_val_3GPPImCn_Available
- uint8_t val_3GPPImCn
- uint8_t is_val_3GPPSigInd_Available
- uint8_t val_3GPPSigInd
- uint8_t is_LteQci_Available
- uint8_t LteQci

8.671.1 Detailed Description

This structure contains the QoS Flow Request.

Please check is_<Param_Name>_Available field for presence of optional parameters

Parameters

index	• Mandatory parameter • IP flow index • Integer that uniquely identifies each flow instance • Unique index must be assigned by the control point to every flow_spec instance

ProfileId3GPP2	• IP flow 3GPP2 profile ID • A profile ID is shorthand for a defined set of QoS flow parameters specified by the network; to be present while requesting QoS for a CDMA device
val_3GPP2Pri	• IP flow 3GPP2 flow priority • Flow priority used by the network in case of contention between flows with same QoS; this parameter applies for CDMA devices
TrafficClass	• IP flow traffic class • Integer that designates the requested traffic class: • 0 - Conversational • 1 - Streaming • 2 - Interactive • 3 - Background
DataRate	• IP flow data rate min max • See unpack_qos_dataRate_t for more information
TokenBucket	• IP flow data rate token bucket • See unpack_qos_tokenBucket_t for more information
Latency	• IP flow latency • Maximum delay (in milliseconds) that can be tolerated by an IP packet during transfer through the wireless link
Jitter	• IP flow jitter • Difference between the maximum and minimum latency (in milliseconds) that can be tolerated by an IP packet during the transfer through the wireless link
PktErrRate	• IP flow packet error rate • See unpack_qos_pktErrRate_t for more information
MinPolicedPktSz	• IP flow minimum policed packet size • Integer that defines the minimum packet size (in bytes) that will be policed for QoS guarantees; any IP packets that are smaller than the minimum specified policed size may not receive requested QoS
MaxAllowedPktSz	• IP flow maximum allowed packet size • Integer that defines the maximum packet size (in bytes) allowed in the IP flow; any IP packets greater in size than the maximum allowed packet size are not queued for transmission

val_3GPPRes-ResidualBER	• IP flow 3GPP residual bit error rate • residual_bit_error_rate • 0 = 5∗10-2 residual BER • 1 = 1∗10-2 residual BER • 2 = 5∗10-3 residual BER • 3 = 4∗10-3 residual BER • 4 = 1∗10-3 residual BER • 5 = 1∗10-4 residual BER • 6 = 1∗10-5 residual BER • 7 = 1∗10-6 residual BER • 8 = 6∗10-8 residual BER • Integer that indicates the undetected BER for each IP flow in the delivered packets; Tapplies only to 3GPP networks
val_3GPPTra-HdlPri	• 3GPP traffic handling priority • 0 - Relative traffic handling priority 1 • 1 - Relative traffic handling priority 2 • 2 - Relative traffic handling priority 3 • Defines the relative priority of the flow; applies only to 3GPP networks
val_3GPPImCn	• IP flow 3GPP IM CN flag • IM CN subsystem signaling flag: • 0x00 - FALSE • 0x01 - TRUE • This parameter applies only to 3GPP networks
val_3GPPSigInd	• IP flow 3GPP signaling indication • 0x00 - FALSE • 0x01 - TRUE • This parameter applies only to 3GPP networks
LteQci	• LTE QoS Class Identifier • QoS Class Identifier(QCI) is a required parameter to request QoS in LTE • QCI values: – QCI value 0 requests the network to assign the appropriate QCI value – QCI values 1-4 are associated with guaranteed bitrates – QCI values 5-9 are associated with nonguaranteed bitrates, so the values specified as guaranteed and maximum bitrates are ignored

8.671.2 Field Documentation

8.671.2.1 unpack_qos_dataRate_t unpack_qos_swiQosFlow_t::DataRate

8.671.2.2 uint8_t unpack_qos_swiQosFlow_t::index

8.671.2.3 uint8_t unpack_qos_swiQosFlow_t::is_DataRate_Available

8.671.2.4 uint8_t unpack_qos_swiQosFlow_t::is_Jitter_Available

8.671.2.5 uint8_t unpack_qos_swiQosFlow_t::is_Latency_Available

8.671.2.6 uint8_t unpack_qos_swiQosFlow_t::is_LteQci_Available

8.671.2.7 uint8_t unpack_qos_swiQosFlow_t::is_MaxAllowedPktSz_Available

8.671.2.8 uint8_t unpack_qos_swiQosFlow_t::is_MinPolicedPktSz_Available

8.671.2.9 uint8_t unpack_qos_swiQosFlow_t::is_PktErrRate_Available

8.671.2.10 uint8_t unpack_qos_swiQosFlow_t::is_ProfileId3GPP2_Available

8.671.2.11 uint8_t unpack_qos_swiQosFlow_t::is_TokenBucket_Available

8.671.2.12 uint8_t unpack_qos_swiQosFlow_t::is_TrafficClass_Available

8.671.2.13 uint8_t unpack_qos_swiQosFlow_t::is_val_3GPP2Pri_Available

8.671.2.14 uint8_t unpack_qos_swiQosFlow_t::is_val_3GPPImCn_Available

8.671.2.15 uint8_t unpack_qos_swiQosFlow_t::is_val_3GPPResResidualBER_Available

8.671.2.16 uint8_t unpack_qos_swiQosFlow_t::is_val_3GPPSigInd_Available

8.671.2.17 uint8_t unpack_qos_swiQosFlow_t::is_val_3GPPTraHdlPri_Available

8.671.2.18 uint32_t unpack_qos_swiQosFlow_t::Jitter

8.671.2.19 uint32_t unpack_qos_swiQosFlow_t::Latency

8.671.2.20 uint8_t unpack_qos_swiQosFlow_t::LteQci

8.671.2.21 uint32_t unpack_qos_swiQosFlow_t::MaxAllowedPktSz

8.671.2.22 uint32_t unpack_qos_swiQosFlow_t::MinPolicedPktSz

8.671.2.23 unpack_qos_pktErrRate_t unpack_qos_swiQosFlow_t::PktErrRate

8.671.2.24 uint16_t unpack_qos_swiQosFlow_t::ProfileId3GPP2

8.671.2.25 unpack_qos_tokenBucket_t unpack_qos_swiQosFlow_t::TokenBucket

8.671.2.26 uint8_t unpack_qos_swiQosFlow_t::TrafficClass

8.671.2.27 uint8_t unpack_qos_swiQosFlow_t::val_3GPP2Pri

8.671.2.28 uint8_t unpack_qos_swiQosFlow_t::val_3GPPImCn

8.671.2.29 uint16_t unpack_qos_swiQosFlow_t::val_3GPPResResidualBER

8.671.2.30 uint8_t unpack_qos_swiQosFlow_t::val_3GPPSigInd

8.671.2.31 uint8_t unpack_qos_swiQosFlow_t::val_3GPPTraHdlPri

8.672 unpack_qos_tokenBucket_t Struct Reference

Data Fields

- uint32_t peakRate
- uint32_t tokenRate
- uint32_t bucketSz

8.672.1 Detailed Description

This structure contains the TP flow data rate token bucket

Parameters

peakRate	Maximum rate at which data can be transmitted when the token bucket is full (bits per second)
tokenRate	Rate at which tokens will be put in the token bucket (bits per second); a token is required to be present in the bucket to send a byte of data
bucketSz	Maximum number of tokens that can be accumulated at any instance (bytes); controls the size of the burst that is allowed at any given time

8.672.2 Field Documentation

8.672.2.1 uint32_t unpack_qos_tokenBucket_t::bucketSz

8.672.2.2 uint32_t unpack_qos_tokenBucket_t::peakRate

8.672.2.3 uint32_t unpack_qos_tokenBucket_t::tokenRate

8.673 unpack_qos_Tos_t Struct Reference

Data Fields

- uint8_t val
- uint8_t mask

8.673.1 Detailed Description

This structure contains the IPv4 filter type of service

Parameters

val	Type of service value
mask	Packet matches the TOS filter if: (IPv4_filter_tos_val and IPv4_filter_tos_mask) == (TOS value in the IP packet & IPv4_filter_tos_mask) Example: • IPv4_filter_tos_val = 00101000 • IPv4_filter_tos_mask = 11111100 The filter will compare only the first 6 bits in the IPv4_filter_type_of_service with the first 6 bits in the TOS field of the IP packet. The first 6 bits in the TOS field of the IP packet must be 001010 to match the filter. The last 2 bits can be anything since they are ignored by filtering.

8.673.2 Field Documentation

8.673.2.1 uint8_t unpack_qos_Tos_t::mask

8.673.2.2 uint8_t unpack_qos_Tos_t::val

8.674 unpack_QosFlowStat_t Struct Reference

Data Fields

- uint32_t bearerId
- uint32_t tx_pkt
- uint32_t tx_pkt_drp
- uint64_t tx_bytes
- uint64_t tx_bytes_drp

8.674.1 Detailed Description

This structure contains the Data statistic per QoS flow

Parameters

bearerId	• Bearer ID
tx_pkt	• number of sent packets for the QoS flow ID
tx_pkt_drp	• number of dropped(TX) packets for the QoS flow ID
tx_bytes	• number of sent bytes for the QoS flow ID
tx_bytes_drp	• number of dropped(TX) bytes for the QoS flow ID

8.674.2 Field Documentation

8.674.2.1 uint32_t unpack_QosFlowStat_t::bearerId

8.674.2.2 uint64_t unpack_QosFlowStat_t::tx_bytes

8.674.2.3 uint64_t unpack_QosFlowStat_t::tx_bytes_drp

8.674.2.4 uint32_t unpack_QosFlowStat_t::tx_pkt

8.674.2.5 uint32_t unpack_QosFlowStat_t::tx_pkt_drp

8.675 unpack_rms_GetSMSWake_t Struct Reference

Data Fields

- uint32_t enabled
- uint32_t wake_mask

8.675.1 Detailed Description

Unpack get SMS wake parameters

Parameters

enabled	• SMS wake functionality enabled – 0 - Disabled – 1 - Enabled – 0xffffffff - invalid value.
wake_mask	• SMS wake mask to search for incoming messages (only relevant when enabled)

8.675.2 Field Documentation

8.675.2.1 uint32_t unpack_rms_GetSMSWake_t::enabled

8.675.2.2 uint32_t unpack_rms_GetSMSWake_t::wake_mask

8.676 unpack_RMTransferStatistics_ind_t Struct Reference

Data Fields

- wds_DataULongTlv TxOkConutTlv
- wds_DataULongTlv RxOkConutTlv
- wds_DataULongLongTlv TxOkByteCountTlv
- wds_DataULongLongTlv RxOkByteCountTlv
- wds_DataULongTlv TxDropConutTlv
- wds_DataULongTlv RxDropConutTlv

8.676.1 Detailed Description

WDS packet RM Transfer Statistics data structure for individual session

Parameters

TxOkConutTlv	• Tx Ok Packet Tlv Value.
RxOkConutTlv	• Rx Ok Packet Tlv Value.
TxOkByteCount-Tlv	• Tx Ok Byte Count Packet Tlv Value.

RxOkByteCount-Tlv	• Rx Ok Byte Count Packet Tlv Value.
TxDropConutTlv	• Tx Drop Count Packet Tlv Value.
RxDropConutTlv	• Rx Drop Count Packet Tlv Value.

8.676.2 Field Documentation

8.676.2.1 wds_DataULongTlv unpack_RMTransferStatistics_ind_t::RxDropConutTlv

8.676.2.2 wds_DataULongLongTlv unpack_RMTransferStatistics_ind_t::RxOkByteCountTlv

8.676.2.3 wds_DataULongTlv unpack_RMTransferStatistics_ind_t::RxOkConutTlv

8.676.2.4 wds_DataULongTlv unpack_RMTransferStatistics_ind_t::TxDropConutTlv

8.676.2.5 wds_DataULongLongTlv unpack_RMTransferStatistics_ind_t::TxOkByteCountTlv

8.676.2.6 wds_DataULongTlv unpack_RMTransferStatistics_ind_t::TxOkConutTlv

8.677 unpack_sar_SLQSGetRfSarState_t Struct Reference

Data Fields

- uint32_t * pSarRFState

8.677.1 Detailed Description

This structure contains unpack get RF SAR state parameter.

Parameters

pSarRFState	• SAR RF State – QMI_SAR_RF_STATE_DEFAULT – QMI_SAR_RF_STATE_1 – QMI_SAR_RF_STATE_2 – QMI_SAR_RF_STATE_3 – QMI_SAR_RF_STATE_4 – QMI_SAR_RF_STATE_5 – QMI_SAR_RF_STATE_6 – QMI_SAR_RF_STATE_7 – QMI_SAR_RF_STATE_8 • NULL pointer - Invalid data.

8.677.2 Field Documentation

8.677.2.1 uint32_t* unpack_sar_SLQSGetRfSarState_t::pSarRFState

8.678 unpack_sms_GetSMSCAddress_t Struct Reference

Data Fields

- uint8_t addressSize
- uint8_t * pSMSCAddress
- uint8_t typeSize
- uint8_t * pSMSCType

8.678.1 Detailed Description

Structure contains Gets the SMS center address parameters.

Parameters

addressSize	• The maximum number of characters (including NULL terminator) that the SMS center address array can contain.
pSMSCAddress	• The SMS center address represented as a NULL terminated string.
typeSize	• The maximum number of characters (including NULL terminator) that the SMS center address type array can contain.
pSMSCType	• The SMS center address type represented as a NULL terminated string.

8.678.2 Field Documentation

8.678.2.1 uint8_t unpack_sms_GetSMSCAddress_t::addressSize

8.678.2.2 uint8_t* unpack_sms_GetSMSCAddress_t::pSMSCAddress

8.678.2.3 uint8_t* unpack_sms_GetSMSCAddress_t::pSMSCType

8.678.2.4 uint8_t unpack_sms_GetSMSCAddress_t::typeSize

8.679 unpack_sms_SaveSMS_t Struct Reference

Data Fields

- uint32_t * pMessageIndex

8.679.1 Detailed Description

This structure contains unpack save SMS parameter.

Parameters

pMessageIndex	• The message index assigned by the device

8.679.2 Field Documentation

8.679.2.1 uint32_t* unpack_sms_SaveSMS_t::pMessageIndex

8.680 unpack_sms_SendSMS_t Struct Reference

Data Fields

- uint16_t messageID
- uint32_t messageFailureCode

8.680.1 Detailed Description

This structure contains unpack send SMS parameters.

Parameters

messageID	• WMS message ID
messageFailure-Code	• pointer to message failure code. If cause code is not provided, then value will be 0xFFFFFFFF

8.680.2 Field Documentation

8.680.2.1 uint32_t unpack_sms_SendSMS_t::messageFailureCode

8.680.2.2 uint16_t unpack_sms_SendSMS_t::messageID

8.681 unpack_sms_SetNewSMSCallback_ind_t Struct Reference

Data Fields

- newMTMessageTlv NewMMTlv
- transferRouteMessageTlv TRMessageTlv
- messageModeTlv MMTlv
- sMSEtwsMessageTlv ETWSTlv
- eTWSPLMNInfoTlv ETWSPLMNTlv
- sMSCAddressTlv SMSCTlv
- sMSOnIMSTlv IMSTlv

8.681.1 Detailed Description

This structure contains unpack new SMS callback indication.

Parameters

NewMMTlv	• MT message
TRMessageTlv	• Transfer Route MT Message • See transferRouteMessageTlv for more information
MMTlv	• Message mode • See messageModeTlv for more information
ETWSTlv	• ETWS Message • See sMSEtwsMessageTlv for more information
ETWSPLMNTlv	• ETWS PLMN Information • See eTWSPLMNInfoTlv for more information
SMSCTlv	• SMSC Address • See sMSCAddressTlv for more information
IMSTlv	• SMS on IMS • See sMSOnIMSTlv for more information

8.681.2 Field Documentation

8.681.2.1 eTWSPLMNInfoTlv unpack_sms_SetNewSMSCallback_ind_t::ETWSPLMNTlv

8.681.2.2 sMSEtwsMessageTlv unpack_sms_SetNewSMSCallback_ind_t::ETWSTlv

8.681.2.3 sMSOnIMSTlv unpack_sms_SetNewSMSCallback_ind_t::IMSTlv

8.681.2.4 messageModeTlv unpack_sms_SetNewSMSCallback_ind_t::MMTlv

8.681.2.5 newMTMessageTlv unpack_sms_SetNewSMSCallback_ind_t::NewMMTlv

8.681.2.6 sMSCAddressTlv unpack_sms_SetNewSMSCallback_ind_t::SMSCTlv

8.681.2.7 transferRouteMessageTlv unpack_sms_SetNewSMSCallback_ind_t::TRMessageTlv

8.682 unpack_sms_SetNewSMSCallback_t Struct Reference

8.682.1 Detailed Description

This structure contains unpack set new SMS callback.

Parameters

NULL	dummy prototype.

8.683 unpack_sms_SLQSDeleteSMS_t Struct Reference

8.683.1 Detailed Description

This structure contains unpack delete SMS parameters.

Parameters

NULL	unpack prototype.

8.684 unpack_sms_SLQSGetIndicationRegister_t Struct Reference

Data Fields

- sms_getIndicationReg * pGetIndicationRegInfo

8.684.1 Detailed Description

Structure containing Parameters that provides registration state of different WMS indications.

Parameters

pGetIndication-RegInfo	• Pointer to structure of getIndicationReg – See sms_getIndicationReg for more information

8.684.2 Field Documentation

8.684.2.1 sms_getIndicationReg* unpack_sms_SLQSGetIndicationRegister_t::pGetIndicationRegInfo

8.685 unpack_sms_SLQSGetMessageWaiting_t Struct Reference

Data Fields

- sms_getMsgWaitingInfo * pGetMsgWaitingInfoResp

8.685.1 Detailed Description

Structure contain Parameter that provide information about the message waiting information.

Parameters

pGetMsg-WaitingInfoResp	• Pointer to structure of getMsgWaitingInfoResp – See sms_getMsgWaitingInfo for more information • NULL pointer - Invalid data.

8.685.2 Field Documentation

8.685.2.1 sms_getMsgWaitingInfo* unpack_sms_SLQSGetMessageWaiting_t::pGetMsgWaitingInfoResp

8.686 unpack_sms_SLQSGetSMS_t Struct Reference

Data Fields

- uint32_t messageTag
- uint32_t messageFormat
- uint32_t messageSize
- uint8_t message [2048]

8.686.1 Detailed Description

This sturcture contains unpack get SMS parameters.

Parameters

messageTag	• Message tag – 0 - Read – 1 - Not read – 2 - Mobile originated and sent – 3 - Mobile originated but not yet sent
messageFormat	• Message format – 0 - CDMA (IS-637B) – 1 - 5 (Reserved) – 6 - GSM/WCDMA PP
messageSize	• Upon input the maximum number of bytes that can be written to the message array.

- Upon successful output the actual number of bytes written to the message array.

Parameters

message	• The message contents array

8.686.2 Field Documentation

8.686.2.1 uint8_t unpack_sms_SLQSGetSMS_t::message[2048]

8.686.2.2 uint32_t unpack_sms_SLQSGetSMS_t::messageFormat

8.686.2.3 uint32_t unpack_sms_SLQSGetSMS_t::messageSize

8.686.2.4 uint32_t unpack_sms_SLQSGetSMS_t::messageTag

8.687 unpack_sms_SLQSGetSmsBroadcastConfig_t Struct Reference

Data Fields

- sms_qaQmi3GPPBroadcastCfgInfo * pBroadcastConfig
- sms_qaQmi3GPP2BroadcastCfgInfo * pCDMABroadcastConfig

8.687.1 Detailed Description

Structure contain parameters that Provides Information about the SMS BroadcastConfiguration

Parameters

pBroadcast-Config	• The data for 3GPP Broadcast Information(Optional). • NULL pointer - Invalid data.
pCDMA-BroadcastConfig	• The data for 3GPP2 Broadcast Information(Optional). • NULL pointer - Invalid data.

8.687.2 Field Documentation

8.687.2.1 sms_qaQmi3GPPBroadcastCfgInfo* unpack_sms_SLQSGetSmsBroadcastConfig_t::pBroadcastConfig

8.687.2.2 sms_qaQmi3GPP2BroadcastCfgInfo* unpack_sms_SLQSGetSmsBroadcastConfig_t::pCDMABroadcastConfig

8.688 unpack_sms_SLQSGetSMSList_t Struct Reference

Data Fields

- uint32_t messageListSize
- qmiSmsMessageList messageList [255]

8.688.1 Detailed Description

This structure contains unpack get SMS list parameters.

Parameters

messageListSize	• Upon input the maximum number of elements that the message list array can contain. • Upon successful output the actual number of elements in the message list array.
messageList	• Message List • See qmiSmsMessageList for more information

8.688.2 Field Documentation

8.688.2.1 qmiSmsMessageList unpack_sms_SLQSGetSMSList_t::messageList[255]

8.688.2.2 uint32_t unpack_sms_SLQSGetSMSList_t::messageListSize

8.689 unpack_sms_SLQSGetTransLayerInfo_t Struct Reference

Data Fields

- sms_getTransLayerInfo * pGetTransLayerInfo

8.689.1 Detailed Description

Structure contain parameters that gives information about the transport layer.

Parameters

pGetTransLayer-Info	• Pointer to structure of getTransLayerInfo – See sms_getTransLayerInfo for more information

8.689.2 Field Documentation

8.689.2.1 sms_getTransLayerInfo* unpack_sms_SLQSGetTransLayerInfo_t::pGetTransLayerInfo

8.690 unpack_sms_SLQSGetTransNWRegInfo_t Struct Reference

Data Fields

- sms_getTransNWRegInfo * pGetTransNWRegInfo

8.690.1 Detailed Description

Structure containing parameters that provides transport layer network registration info.

Parameters

pGetTransNW-RegInfo	• Pointer to structure of getTransNWRegInfo – See sms_getTransNWRegInfo for more information

8.690.2 Field Documentation

8.690.2.1 sms_getTransNWRegInfo* unpack_sms_SLQSGetTransNWRegInfo_t::pGetTransNWRegInfo

8.691 unpack_sms_SLQSModifySMSStatus_t Struct Reference

8.691.1 Detailed Description

This structure contains unpack modify SMS status parameters.

Parameters

NULL	unpack prototype.

8.692 unpack_sms_SLQSSmsGetMaxStorageSize_t Struct Reference

Data Fields

- sms_maxStorageSizeResp * pMaxStorageSizeResp

8.692.1 Detailed Description

Structure contain parameters that provides the maximum number of messages that can be stored in the specified memory storage. Also it provides the number of slots currently available

Parameters

pMaxStorage-SizeResp	• Response parameters for SmsSLQSGetMaxStorageSize – See sms_maxStorageSizeResp for more information • NULL pointer - Invalid data.

8.692.2 Field Documentation

8.692.2.1 sms_maxStorageSizeResp* unpack_sms_SLQSSmsGetMaxStorageSize_t::pMaxStorageSizeResp

8.693 unpack_sms_SLQSSmsGetMessageProtocol_t Struct Reference

Data Fields

- sms_msgProtocolResp * pMessageProtocol

8.693.1 Detailed Description

Structure contain Parameters that get the message protocol currently in use for the WMS client.

Parameters

pMessage-Protocol	• Pointer to smsMsgprotocolResp – See sms_msgProtocolResp for more information

8.693.2 Field Documentation

8.693.2.1 sms_msgProtocolResp* unpack_sms_SLQSSmsGetMessageProtocol_t::pMessageProtocol

8.694 unpack_sms_SLQSSwiGetSMSStorage_t Struct Reference

Data Fields

- uint32_t * pSmsStorage

8.694.1 Detailed Description

Structure contain Parameters that return current SMS configuration that is applied to all incoming and outgoing messages.

Parameters

pSmsStorage	• Values: – 0x01 - device's permanent memory – 0x02 - UICC • NULL pointer - Invalid data.

8.694.2 Field Documentation

8.694.2.1 uint32_t* unpack_sms_SLQSSwiGetSMSStorage_t::pSmsStorage

8.695 unpack_sms_SLQSWmsMemoryFullCallBack_ind_t Struct Reference

Data Fields

- uint8_t storageType
- uint8_t messageMode

8.695.1 Detailed Description

This structure contains unpack SMS memory full callback indication.

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
messageMode	• 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS)

8.695.2 Field Documentation

8.695.2.1 uint8_t unpack_sms_SLQSWmsMemoryFullCallBack_ind_t::messageMode

8.695.2.2 uint8_t unpack_sms_SLQSWmsMemoryFullCallBack_ind_t::storageType

8.696 unpack_swiaudio_SLQSGetM2MAudioProfile_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t EarMute
- uint8_t MicMute
- uint8_t Generator
- uint8_t Volume
- uint8_t CwtMute

8.696.1 Detailed Description

This structure contains the SLQSGetM2MAudioProfile unpack parameters.

Parameters

Profile	• Audio Profile – 0-5
EarMute	• Ear Mute – 0 - Mute – 1 - Unmute
MicMute	• MIC Mute – 0 - Mute – 1 - Unmute
Generator	• Generator – 0 - Voice
Volume	• RX volume level – 0-5
CwtMute	• Call waiting tone Mute – 0 - Mute – 1 - Unmute

8.696.2 Field Documentation

8.696.2.1 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::CwtMute

8.696.2.2 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::EarMute

8.696.2.3 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::Generator

8.696.2.4 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::MicMute

8.696.2.5 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::Profile

8.696.2.6 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::Volume

8.697 unpack_swiaudio_SLQSGetM2MAudioVolume_t Struct Reference

Data Fields

- uint8_t Level

8.697.1 Detailed Description

This structure contains the SLQSGetM2MAudioVolume unpack parameters.

Parameters

Level	• The RX Volume Level – 0-5

8.697.2 Field Documentation

8.697.2.1 uint8_t unpack_swiaudio_SLQSGetM2MAudioVolume_t::Level

8.698 unpack_swiaudio_SLQSGetM2MAVMute_t Struct Reference

Data Fields

- uint8_t EarMute
- uint8_t MicMute
- uint8_t CwtMute

8.698.1 Detailed Description

This structure contains the SLQSGetM2MAVMute unpack parameters.

Parameters

pEarMute	• Ear Mute – 0-Mute – 1-UnMute
pMicMute	• Mic Mute – 0-Mute – 1-unmute

CwtMute	• Waiting tone Mute – 0-5

8.698.2 Field Documentation

8.698.2.1 uint8_t unpack_swiaudio_SLQSGetM2MAVMute_t::CwtMute

8.698.2.2 uint8_t unpack_swiaudio_SLQSGetM2MAVMute_t::EarMute

8.698.2.3 uint8_t unpack_swiaudio_SLQSGetM2MAVMute_t::MicMute

8.699 unpack_swiaudio_SLQSGetM2MSpkrGain_t Struct Reference

Data Fields

- uint16_t Value

8.699.1 Detailed Description

This structure contains the SLQSGetM2MSpkrGain unpack parameters.

Parameters

Value	• RX speakerphone gain – 0x0 - 0x7fff

8.699.2 Field Documentation

8.699.2.1 uint16_t unpack_swiaudio_SLQSGetM2MSpkrGain_t::Value

8.700 unpack_swiavms_SLQSAVMSEventReportInd_t Struct Reference

Data Fields

- UnpackSwiAvmsEventReportBinaryUpdateSessionInfo * pBinaryUpdateSessionInfo
- UnpackSwiAvmsEventReportConfig * pConfig
- UnpackSwiAvmsEventReportNotification * pNotification
- UnpackSwiAvmsEventReportPackageID * pPackageID
- UnpackSwiAvmsEventReportConnectionRequest * pConnectionRequest
- UnpackSwiAvmsEventReportWAMSParamChange * pWAMSParaChanged
- UnpackSwiAvmsEventReportRegStatus * pRegStatus
- UnpackSwiAvmsEventReportDataSessionStatus * pDataSessionStatus
- UnpackSwiAvmsEventReportSessionType * pSessionType
- UnpackSwiAvmsEventReportHTTPStatus * pHTTPStatus
- uint32_t resultcode

8.700.1 Detailed Description

Structure that contains the session type response for AVMS event report indication command

Parameters

pBinaryUpdateSessionInfo[OUT]	• See UnpackSwiAvmsEventReportBinaryUpdateSessionInfo for more information
pConfig[OUT]	• See UnpackSwiAvmsEventReportConfig for more information
pNotification[OUT]	• See UnpackSwiAvmsEventReportNotification for more information
pPackageID[OUT]	• See UnpackSwiAvmsEventReportPackageID for more information
pConnectionRequest[OUT]	• See UnpackSwiAvmsEventReportConnectionRequest for more information
pWAMSParaChanged[OUT]	• See UnpackSwiAvmsEventReportWAMSParamChange for more information
pRegStatus[OUT]	• See UnpackSwiAvmsEventReportRegStatus for more information
pDataSessionStatus[OUT]	• See UnpackSwiAvmsEventReportDataSessionStatus for more information
pSessionType[OUT]	• See UnpackSwiAvmsEventReportSessionType for more information
pWAMSParaChanged[OUT]	• See UnpackSwiAvmsEventReportWAMSParamChange for more information
pHTTPStatus[OUT]	• See UnpackSwiAvmsEventReportHTTPStatus for more information
resultcode	- Tlv Result Code.

8.700.2 Field Documentation

8.700.2.1 UnpackSwiAvmsEventReportBinaryUpdateSessionInfo∗ unpack_swiavms_SLQSAVMSEventReportInd_t::pBinaryUpdateSessionInfo

8.700.2.2 UnpackSwiAvmsEventReportConfig∗ unpack_swiavms_SLQSAVMSEventReportInd_t::pConfig

8.700.2.3 UnpackSwiAvmsEventReportConnectionRequest∗ unpack_swiavms_SLQSAVMSEventReportInd_t::pConnectionRequest

8.700.2.4 UnpackSwiAvmsEventReportDataSessionStatus∗ unpack_swiavms_SLQSAVMSEventReportInd_t::pDataSessionStatus

8.700.2.5 UnpackSwiAvmsEventReportHTTPStatus∗ unpack_swiavms_SLQSAVMSEventReportInd_t::pHTTPStatus

8.700.2.6 UnpackSwiAvmsEventReportNotification∗ unpack_swiavms_SLQSAVMSEventReportInd_t::pNotification

8.700.2.7 UnpackSwiAvmsEventReportPackageID∗ unpack_swiavms_SLQSAVMSEventReportInd_t::pPackageID

8.700.2.8 UnpackSwiAvmsEventReportRegStatus∗ unpack_swiavms_SLQSAVMSEventReportInd_t::pRegStatus

8.700.2.9 UnpackSwiAvmsEventReportSessionType∗ unpack_swiavms_SLQSAVMSEventReportInd_t::pSessionType

8.700.2.10 UnpackSwiAvmsEventReportWAMSParamChange∗ unpack_swiavms_SLQSAVMSEventReportInd_t::pWAMSParaChanged

8.700.2.11 uint32_t unpack_swiavms_SLQSAVMSEventReportInd_t::resultcode

8.701 unpack_swiavms_SLQSAVMSGetSettings_t Struct Reference

Data Fields

- uint32_t OMADMEnabled
- uint8_t AutoConnect
- uint8_t AutoReboot
- uint8_t FwPromptdownload
- uint8_t FwPromptUpdate
- uint8_t FwAutoSDM
- uint32_t ∗ pPollingTimer
- PackSwiAVMSSettingsConnectionRetryTimers ∗ pConnectionRetryTimers
- PackSwiAVMSSettingsAPNInfo ∗ pAPNInfo
- uint8_t ∗ pNotificationStore
- PackSwiAVMSSettingsPeriodsInfo ∗ pPeroidsInfo
- uint32_t resultcode

8.701.1 Detailed Description

Structure that contains the session type response for AVMS Set Settings command

Parameters

OMADMEnabled	- OMA DM Enabeld. • 0 - Disabled. • 1 - Enabled.
AutoConnect	- Auto Connect. • 0 - Disabeld. • 1 - Enabeld.
AutoReboot	- Auto Reboot. • 0 - Disabeld. • 1 - Enabeld.
Fw-Autodownload	- Firmware auto downalod. • 0 - Disabeld. • 1 - Enabeld.

FwAutoUpdate	- Firmware auto update. • 0 - Disabeld. • 1 - Enabeld.
FwAutoSDM	- OMA Automatic UI Alert Response. • 0 - Disabeld. • 1 - Enabeld.
pPollingTimer	- Polling timer to connect to AVMS server. • 0-525600 (min) • 0:disabled • NULL pointer - Invalid data.
pConnection-RetryTimers	- Connection Retry timers. • See PackSwiAVMSSettingsConnectionRetryTimers for more information. • NULL pointer - Invalid data.
pAPNInfo	- APN Information. • See PackSwiAVMSSettingsAPNInfo for more information. • NULL pointer - Invalid data.
pNotification-Store	- Notification Storing When Disabled or Offline. • 0 - Disabled. • 1 - Enabeld. • NULL pointer - Invalid data.
pPeroidsInfo	- Min and Max Period of an Observation. • See PackSwiAVMSSettingsPeriodsInfo for more information. • NULL pointer - Invalid data.
resultcode	- Tlv Result Code.

8.701.2 Field Documentation

8.701.2.1 uint8_t unpack_swiavms_SLQSAVMSGetSettings_t::AutoConnect

8.701.2.2 uint8_t unpack_swiavms_SLQSAVMSGetSettings_t::AutoReboot

8.701.2.3 uint8_t unpack_swiavms_SLQSAVMSGetSettings_t::FwAutoSDM

8.701.2.4 uint8_t unpack_swiavms_SLQSAVMSGetSettings_t::FwPromptdownload

8.701.2.5 uint8_t unpack_swiavms_SLQSAVMSGetSettings_t::FwPromptUpdate

8.701.2.6 uint32_t unpack_swiavms_SLQSAVMSGetSettings_t::OMADMEnabled

8.701.2.7 PackSwiAVMSSettingsAPNInfo* unpack_swiavms_SLQSAVMSGetSettings_t::pAPNInfo

8.701.2.8 PackSwiAVMSSettingsConnectionRetryTimers* unpack_swiavms_SLQSAVMSGetSettings_t::pConnection-RetryTimers

8.701.2.9 uint8_t* unpack_swiavms_SLQSAVMSGetSettings_t::pNotificationStore

8.701.2.10 PackSwiAVMSSettingsPeriodsInfo∗ unpack_swiavms_SLQSAVMSGetSettings_t::pPeroidsInfo

8.701.2.11 uint32_t∗ unpack_swiavms_SLQSAVMSGetSettings_t::pPollingTimer

8.701.2.12 uint32_t unpack_swiavms_SLQSAVMSGetSettings_t::resultcode

8.702 unpack_swiavms_SLQSAVMSSendSelection_t Struct Reference

Data Fields

- uint32_t resultcode

8.702.1 Detailed Description

Structure that contains the session type response for AVMS Selection command

Parameters

resultcode	- Tlv Result Code.

8.702.2 Field Documentation

8.702.2.1 uint32_t unpack_swiavms_SLQSAVMSSendSelection_t::resultcode

8.703 unpack_swiavms_SLQSAVMSSessionGetInfo_t Struct Reference

Data Fields

- UnpackSwiAvmsEventReportBinaryUpdateSessionInfo ∗ pBinaryUpdateSessionInfo
- UnpackSwiAvmsEventReportConfig ∗ pConfig
- UnpackSwiAvmsEventReportNotification ∗ pNotification
- UnpackSwiAvmsEventReportPackageID ∗ pPackageID
- uint32_t resultcode

8.703.1 Detailed Description

Structure that contains the session type response for AVMS get session info command

Parameters

resultcode	- Tlv Result Code.

8.703.2 Field Documentation

8.703.2.1 UnpackSwiAvmsEventReportBinaryUpdateSessionInfo∗ unpack_swiavms_SLQSAVMSSessionGetInfo_t-::pBinaryUpdateSessionInfo

8.703.2.2 UnpackSwiAvmsEventReportConfig∗ unpack_swiavms_SLQSAVMSSessionGetInfo_t::pConfig

8.703.2.3 UnpackSwiAvmsEventReportNotification∗ unpack_swiavms_SLQSAVMSSessionGetInfo_t::pNotification

8.703.2.4 UnpackSwiAvmsEventReportPackageID∗ unpack_swiavms_SLQSAVMSSessionGetInfo_t::pPackageID

8.703.2.5 uint32_t unpack_swiavms_SLQSAVMSSessionGetInfo_t::resultcode

8.704 unpack_swiavms_SLQSAvmsSetEventReport_t Struct Reference

Data Fields

- uint32_t resultcode

8.704.1 Detailed Description

Structure that contains the session type response for AVMS set event report command

Parameters

resultcode	- Tlv Result Code.

8.704.2 Field Documentation

8.704.2.1 uint32_t unpack_swiavms_SLQSAvmsSetEventReport_t::resultcode

8.705 unpack_swiavms_SLQSAVMSSetSettings_t Struct Reference

Data Fields

- uint32_t resultcode

8.705.1 Detailed Description

Structure that contains the session type response for AVMS Set Settings command

Parameters

resultcode	- Tlv Result Code.

8.705.2 Field Documentation

8.705.2.1 uint32_t unpack_swiavms_SLQSAVMSSetSettings_t::resultcode

8.706 unpack_swiavms_SLQSAVMSStartSession_t Struct Reference

Data Fields

- uint32_t sessionResponse
- uint32_t resultcode

8.706.1 Detailed Description

Structure that contains the session type response for AVMS start session command

Parameters

Session-Response	- OMA-DM availability CHECK for the requested item. • 0x00000001 - Available. • 0x00000002 - Not Available. • 0x00000003 - Check Timed Out. • 0xffffffff - Invalid data.
resultcode	- Tlv Result Code.

8.706.2 Field Documentation

8.706.2.1 uint32_t unpack_swiavms_SLQSAVMSStartSession_t::resultcode

8.706.2.2 uint32_t unpack_swiavms_SLQSAVMSStartSession_t::sessionResponse

8.707 unpack_swiavms_SLQSAVMSStopSession_t Struct Reference

Data Fields

- uint32_t resultcode

8.707.1 Detailed Description

Structure that contains the session type response for AVMS Stop session command

Parameters

resultcode	- Tlv Result Code.

8.707.2 Field Documentation

8.707.2.1 uint32_t unpack_swiavms_SLQSAVMSStopSession_t::resultcode

8.708 unpack_swiloc_SwiLocGetAutoStart_t Struct Reference

Data Fields

- uint8_t function
- int function_reported
- uint8_t fix_type
- int fix_type_reported
- uint8_t max_time
- int max_time_reported
- uint32_t max_dist
- int max_dist_reported
- uint32_t fix_rate
- int fix_rate_reported

8.708.1 Detailed Description

This structure contains SWI LOC Get Auto Start setting

Parameters

function	• Setting to indicate when modem should start an automatic GNSS fix – 0 - disabled – 1 - At bootup – 2 - When NMEA port is opened – 0xff - not reported by modem
function_reported	• 0 - not reported by modem • l - reported by modem
fix_type	• Type of GNSS fix: – 1 - Default Engine mode – 2 - MS-Based – 3 - MS-Assisted – 4 - Standalone
fix_type_reported	• 0 - not reported by modem • l - reported by modem
max_time	• Maximum time allowed for the receiver to get a fix in seconds • Valid range: 1-255
max_time_reported	• 0 - not reported by modem • l - reported by modem
max_dist	• Maximum uncertainty of a fix measured by distance in meters • Valid range: 1 - 4294967280
max_dist_reported	• 0 - not reported by modem • l - reported by modem
fix_rate	• Time between fixes in seconds • Valid range: 1–65535
fix_rate_reported	• 0 - not reported by modem • l - reported by modem

8.708.2 Field Documentation

8.708.2.1 uint32_t unpack_swiloc_SwiLocGetAutoStart_t::fix_rate

8.708.2.2 int unpack_swiloc_SwiLocGetAutoStart_t::fix_rate_reported

8.708.2.3 uint8_t unpack_swiloc_SwiLocGetAutoStart_t::fix_type

8.708.2.4 int unpack_swiloc_SwiLocGetAutoStart_t::fix_type_reported

8.708.2.5 uint8_t unpack_swiloc_SwiLocGetAutoStart_t::function

8.708.2.6 int unpack_swiloc_SwiLocGetAutoStart_t::function_reported

8.708.2.7 uint32_t unpack_swiloc_SwiLocGetAutoStart_t::max_dist

8.708.2.8 int unpack_swiloc_SwiLocGetAutoStart_t::max_dist_reported

8.708.2.9 uint8_t unpack_swiloc_SwiLocGetAutoStart_t::max_time

8.708.2.10 int unpack_swiloc_SwiLocGetAutoStart_t::max_time_reported

8.709 unpack_swioma_SLQSOMADMAlertCallback_ind_t Struct Reference

Data Fields

- uint32_t eventType
- unpack_omaDmFotaTlv_t SessionInfoFota
- unpack_omaDmConfigTlv_t SessionInfoConfig
- unpack_omaDmNotificationsTlv_t SessionInfoNotification

8.709.1 Detailed Description

Structure that contains OMA indication information based on eventType Strucutres for which the event is not valid will have values set to 0

Parameters

eventType	• 0x00 - SWIOMA-DM FOTA • 0x01 - SWIOMA-DM Config • 0x02 - SWIOMA-DM Notification • 0xff - indication missing event information.
SessionInfo-Fota[OUT]	• See unpack_omaDmFotaTlv_t for more information
SessionInfo-Config[OUT]	• See unpack_omaDmConfigTlv_t for more information
SessionInfo-Notification[OUT]	• See unpack_omaDmNotificationsTlv_t for more information

8.709.2 Field Documentation

8.709.2.1 uint32_t unpack_swioma_SLQSOMADMAlertCallback_ind_t::eventType

8.709.2.2 unpack_omaDmConfigTlv_t unpack_swioma_SLQSOMADMAlertCallback_ind_t::SessionInfoConfig

8.709.2.3 unpack_omaDmFotaTlv_t unpack_swioma_SLQSOMADMAlertCallback_ind_t::SessionInfoFota

8.709.2.4 unpack_omaDmNotificationsTlv_t unpack_swioma_SLQSOMADMAlertCallback_ind_t::SessionInfoNotification

8.710 unpack_swioma_SLQSOMADMGetSessionInfo_t Struct Reference

Data Fields

- uint8_t Status
- uint16_t UpdateCompleteStatus
- uint8_t Severity
- uint16_t SourceLength
- uint8_t Source [255]
- uint16_t PkgNameLength
- uint8_t PkgName [255]
- uint16_t PkgDescLength
- uint8_t PkgDescription [255]
- uint16_t DateLength
- uint8_t Date [255]
- uint16_t TimeLength
- uint8_t Time [255]
- uint8_t SessionType
- uint8_t SessionState
- uint16_t RetryCount

8.710.1 Detailed Description

Structure that contains the session type for OMA get session info unpack command Also used as input parameter to specify the size of variable parameters. (ref. notes)

Parameters

Status	• 1 Byte parameter indicating status – 0x01 - No Firmware available – 0x02 - Query Firmware Download – 0x03 - Firmware Downloading – 0x04 - Firmware Downloaded – 0x05 - Query Firmware Update – 0x06 - Firmware Updating – 0x07 - Firmware Updated – 0xff - Invalid Session information.
Update-CompleteStatus	• 2 byte parameter indicating Update Complete Status – See qaGobiApiTableSwiOMADMUpdateCompleteStatus.h Update Complete Status
Severity	• 1 byte parameter indicating severity – 0x01 - Mandatory – 0x02 - Optional

SourceLength	• 2 byte parameter indicating Length of Vendor Name String in Bytes.
Source	• Variable length parameter indicating Vendor Name in ASCII • See LITEQMI_MAX_SWIOMA_STR_LEN for more information
PkgNameLength	• 2 byte parameter indicating Length of Package Name String in Bytes.
PkgName	• Variable length parameter indicating Package Name in ASCII • See LITEQMI_MAX_SWIOMA_STR_LEN for more information
PkgDescLength	• 2 byte parameter indicating Length of Package Description String in Bytes.
PkgDescription	• Variable length parameter indicating Package Description in ASCII • See LITEQMI_MAX_SWIOMA_STR_LEN for more information
DateLength	• 2 byte parameter indicating Length of Package Description String in Bytes.
Date	• Variable length parameter indicating Package Description in ASCII • See LITEQMI_MAX_SWIOMA_STR_LEN for more information
TimeLength	• 2 byte parameter indicating Length of Time String in Bytes.
Time	• Variable length parameter indicating Time String in ASCII • See LITEQMI_MAX_SWIOMA_STR_LEN for more information
SessionType	• 1 byte parameter reflects the last session started for Sprint – 0x00 - No session since boot – 0x01 - Sprint CI-DC Session – 0x02 - Sprint CI-PRL Session – 0x03 - Sprint CI-FUMO Session – 0x04 - Sprint HFA-DC Session – 0x05 - Sprint HFA-PRL Session – 0x06 - Sprint HFA-FUMO Session – 0x07 - Sprint NI Session
SessionState	• 1 byte parameter indicating session state – 0x01 - idle – 0x02 - active – 0x03 - pending

RetryCount	• 1 byte parameter indicating retries left count – valid values 0 to 6

8.710.2 Field Documentation

8.710.2.1 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::Date[255]

8.710.2.2 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::DateLength

8.710.2.3 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::PkgDescLength

8.710.2.4 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::PkgDescription[255]

8.710.2.5 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::PkgName[255]

8.710.2.6 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::PkgNameLength

8.710.2.7 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::RetryCount

8.710.2.8 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::SessionState

8.710.2.9 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::SessionType

8.710.2.10 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::Severity

8.710.2.11 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::Source[255]

8.710.2.12 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::SourceLength

8.710.2.13 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::Status

8.710.2.14 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::Time[255]

8.710.2.15 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::TimeLength

8.710.2.16 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::UpdateCompleteStatus

8.711 unpack_swioma_SLQSOMADMGetSettings_t Struct Reference

Data Fields

- uint32_t OMADMEnabled
- uint8_t FOTAdownload
- uint8_t FOTAUpdate
- uint8_t Autosdm
- uint8_t FwAutoCheck

8.711.1 Detailed Description

Structure containing the OMA DM settings retrieved from the device

Parameters

OMADMEnabled	[out] • Optional 4 byte parameter indicating OMADM service enabled – 0x00000001 - Client-initiated device configuration – 0x00000002 - Network-initiated device configuration – 0x00000010 - Client-initiated FUMO – 0x00000020 - Network-initiated FUMO • function SLQSOMADMGetSettings2() returns a default value 0xFFFFFFFF in case this parameter is not returned by the modem.
FOTAdownload	[out] • Optional 1 Byte parameter indicating support for FOTA Automatic download – 0x00 - Host permission required before downloading – 0x01 - Automatically start downloading, no host permission required – 0x02 - Automatically start downloading, while not roaming – 0x03 - Automatically reject download – 0x04 - Automatically reject download with “Enterprise Reject Policy – 0xff - Invalid data.

• function SLQSOMADMGetSettings2() returns a default value 0xFF in case this parameter is not returned by the modem.

Parameters

FOTAUpdate	[out] • Optional 1 byte parameter indicating FOTA Automatic update – 0x00 - User permission required before updating firmware – 0x01 - No user permission required before updating firmware – 0x02 - User permission required, auto update on power up • function SLQSOMADMGetSettings2() returns a default value 0xFF in case this parameter is not returned by the modem.
Autosdm	[out] • Optional 1 byte parameter indicating OMA Automatic UI Alert Response – 0x00 - Disabled – 0x01 - Enabled Accept – 0x02 - Enabled Reject • function SLQSOMADMGetSettings2() returns a default value 0xFF in case this parameter is not returned by the modem.
FwAutoCheck	[out] • Optional 1 byte parameter indicating OMA Automatic Check for Firmware Update on Power-Up Response – 0x00 - Disabled – 0x01 - Enabled • function SLQSOMADMGetSettings2() returns a default value 0xFF in case this parameter is not returned by the modem.

8.711.2 Field Documentation

8.711.2.1 uint8_t unpack_swioma_SLQSOMADMGetSettings_t::Autosdm

8.711.2.2 uint8_t unpack_swioma_SLQSOMADMGetSettings_t::FOTAdownload

8.711.2.3 uint8_t unpack_swioma_SLQSOMADMGetSettings_t::FOTAUpdate

8.711.2.4 uint8_t unpack_swioma_SLQSOMADMGetSettings_t::FwAutoCheck

8.711.2.5 uint32_t unpack_swioma_SLQSOMADMGetSettings_t::OMADMEnabled

8.712 unpack_swioma_SLQSOMADMStartSession_t Struct Reference

Data Fields

- uint32_t FwAvailability

8.712.1 Detailed Description

Structure that contains the responses for OMA start session command

Parameters

FwAvailability	[out] • OMA-DM CHECK FW Available – 0x00000001 - FW Available. For CIDC and CIPRL, this value will be returned by the modem. CIDC and CIPRL are asynchronous OMADM sessions. – 0x00000002 - FW Not Available – 0x00000003 - FW Check Timed Out – 0xFFFFFFFF - Invalid data.

8.712.2 Field Documentation

8.712.2.1 uint32_t unpack_swioma_SLQSOMADMStartSession_t::FwAvailability

8.713 unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.713.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

Tlvresult	• Unpack Result

8.713.2 Field Documentation

8.713.2.1 uint16_t unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t::TlvResult

8.714 unpack_tmd_SLQSTmdGetMitigationDevList_t Struct Reference

Data Fields

- uint8_t MitigationDevListLen
- tmd_mitigationDevList MitigationDevList [255]
- uint16_t TlvResult

8.714.1 Detailed Description

This structure contains mitigation devices list from the remote endpoint

Parameters

MitigationDevListLen	• Mitigation Device List Length (Optional) • Number of sets of the following elements – MitigationDevList
pMitigationDevList	• Mitigation Device List (Optional) • See tmd_mitigationDevList for more information.
TlvResult	• Unpack Result

8.714.2 Field Documentation

8.714.2.1 tmd_mitigationDevList unpack_tmd_SLQSTmdGetMitigationDevList_t::MitigationDevList[255]

8.714.2.2 uint8_t unpack_tmd_SLQSTmdGetMitigationDevList_t::MitigationDevListLen

8.714.2.3 uint16_t unpack_tmd_SLQSTmdGetMitigationDevList_t::TlvResult

8.715 unpack_tmd_SLQSTmdGetMitigationLvl_t Struct Reference

Data Fields

- uint8_t CurrentmitigationLvl
- uint8_t ReqMitigationLvl
- uint16_t TlvResult

8.715.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

Currentmitigation-Lvl	• Current thermal mitigation level (Optional)
ReqMitigationLvl	• Requested Thermal Mitigation Level (Optional) • The requested thermal mitigation level from the client. The default is zero if the client has not previously set the mitigation level.
Tlvresult	• Unpack Result

8.715.2 Field Documentation

8.715.2.1 uint8_t unpack_tmd_SLQSTmdGetMitigationLvl_t::CurrentmitigationLvl

8.715.2.2 uint8_t unpack_tmd_SLQSTmdGetMitigationLvl_t::ReqMitigationLvl

8.715.2.3 uint16_t unpack_tmd_SLQSTmdGetMitigationLvl_t::Tlvresult

8.716 unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t Struct Reference

Data Fields

- uint8_t deviceIdLen
- char deviceID [255]
- uint8_t lvl

8.716.1 Detailed Description

Mitigation Level Report

Parameters

deviceIdLen	• Mitigation Device ID Length
deviceID	• Mitigation Device ID
lvl	• Current thermal mitigation level

8.716.2 Field Documentation

8.716.2.1 char unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t::deviceID[255]

8.716.2.2 uint8_t unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t::deviceIdLen

8.716.2.3 uint8_t unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t::lvl

8.717 unpack_tmd_SLQSTmdRegNotMitigationLvl_t Struct Reference

Data Fields

- uint16_t TlvResult

8.717.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

TlvResult	• Unpack Result

8.717.2 Field Documentation

8.717.2.1 uint16_t unpack_tmd_SLQSTmdRegNotMitigationLvl_t::TlvResult

8.718 unpack_uim_ChangePin_t Struct Reference

Data Fields

- uim_remainingRetries * pRemainingRetries
- uim_encryptedPIN1 * pEncryptedPIN1
- uint32_t * pIndicationToken
- uint16_t TlvResult

8.718.1 Detailed Description

This structure contains information of the response parameters associated with a set of PIN related API's.

Parameters

pRemaining-Retries(optional)	• See uim_remainingRetries for more information. • NULL pointer - Invalid data.
pEncryptedPI-N1(optional)	• See uim_encryptedPIN1 for more information. • NULL pointer - Invalid data.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result is provided in a subsequent indication. • 0xFFFFFFFF, if unavailable • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned.

8.718.2 Field Documentation

8.718.2.1 uim_encryptedPIN1* unpack_uim_ChangePin_t::pEncryptedPIN1

8.718.2.2 uint32_t* unpack_uim_ChangePin_t::pIndicationToken

8.718.2.3 uim_remainingRetries* unpack_uim_ChangePin_t::pRemainingRetries

8.718.2.4 uint16_t unpack_uim_ChangePin_t::Tlvresult

8.719 unpack_uim_GetCardStatus_t Struct Reference

Data Fields

- uim_cardStatus * pCardStatus
- uim_hotSwapStatus * pHotSwapStatus
- uint16_t Tlvresult

8.719.1 Detailed Description

This structure contains information of the response parameters associated with a Get Card Status API.

Parameters

pCard-Status(optional)	• See uim_cardStatus for more information. • NULL pointer - Invalid data.
pHotSwap-Status(optional)	• See uim_hotSwapStatus for more information. • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned.

8.719.2 Field Documentation

8.719.2.1 uim_cardStatus* unpack_uim_GetCardStatus_t::pCardStatus

8.719.2.2 uim_hotSwapStatus* unpack_uim_GetCardStatus_t::pHotSwapStatus

8.719.2.3 uint16_t unpack_uim_GetCardStatus_t::Tlvresult

8.720 unpack_uim_ReadTransparent_t Struct Reference

Data Fields

- uim_cardResult * pCardResult

- uim_readResult * pReadResult
- uint32_t * pIndicationToken
- uint8_t * pEncryptedData
- uint16_t TlvResult

8.720.1 Detailed Description

This structure contains information of the response parameters associated with a Read Transparent API.

Parameters

pCardResult	• See uim_cardResult for more information. • NULL pointer - Invalid data.
pReadResult	• See uim_readResult for more information. • NULL pointer - Invalid data.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • NULL pointer - Invalid data.
pEncrypted-Data(optional)	• Encrypted Data. • Indicates whether the data from the card passed in read_result is encrypted. • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.720.2 Field Documentation

8.720.2.1 uim_cardResult* unpack_uim_ReadTransparent_t::pCardResult

8.720.2.2 uint8_t* unpack_uim_ReadTransparent_t::pEncryptedData

8.720.2.3 uint32_t* unpack_uim_ReadTransparent_t::pIndicationToken

8.720.2.4 uim_readResult* unpack_uim_ReadTransparent_t::pReadResult

8.720.2.5 uint16_t unpack_uim_ReadTransparent_t::TlvResult

8.721 unpack_uim_SetPinProtection_t Struct Reference

Data Fields

- uim_remainingRetries * pRemainingRetries
- uim_encryptedPIN1 * pEncryptedPIN1
- uint32_t * pIndicationToken
- uint16_t TlvResult

8.721.1 Detailed Description

This structure contains information of the response parameters associated with a set of PIN related API's.

Parameters

pRemaining-Retries(optional)	• See uim_remainingRetries for more information. • NULL pointer - Invalid data.
pEncryptedPI-N1(optional)	• See uim_encryptedPIN1 for more information. • NULL pointer - Invalid data.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result is provided in a subsequent indication. • 0xFFFFFFFF, if unavailable • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned.

8.721.2 Field Documentation

8.721.2.1 uim_encryptedPIN1∗ unpack_uim_SetPinProtection_t::pEncryptedPIN1

8.721.2.2 uint32_t∗ unpack_uim_SetPinProtection_t::pIndicationToken

8.721.2.3 uim_remainingRetries∗ unpack_uim_SetPinProtection_t::pRemainingRetries

8.721.2.4 uint16_t unpack_uim_SetPinProtection_t::TlvResult

8.722 unpack_uim_SetUimSlotStatusChangeCallback_ind_t Struct Reference

Data Fields

- slots_t slotsstatusChange
- uint8_t bNumberOfPhySlots

8.722.1 Detailed Description

Structure consist of card status params

Parameters

slotsstatus-Change	• See slot_t for more information
bNumberOfPhy-Slots	• Number of Physical Slot(s) • 0xff - Invalid card slot status.

8.722.2 Field Documentation

8.722.2.1 uint8_t unpack_uim_SetUimSlotStatusChangeCallback_ind_t::bNumberOfPhySlots

8.722.2.2 slots_t unpack_uim_SetUimSlotStatusChangeCallback_ind_t::slotsstatusChange

8.723 unpack_uim_SLQSUIMAuthenticate_t Struct Reference

Data Fields

- uim_cardResult * pCardResult
- uim_authenticateResult * pAuthenticateResult
- uint32_t * pIndicationToken

8.723.1 Detailed Description

This structure contains information of the response parameters associated with a SLQSUIMAuthenticate.

Parameters

pCard-Result(optional)	• See uim_cardResult for more information. • NULL pointer - Invalid data.
pAuthenticate-Result(optional)	• See uim_authenticateResult for more information. • NULL pointer - Invalid data.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned.

8.723.2 Field Documentation

8.723.2.1 uim_authenticateResult* unpack_uim_SLQSUIMAuthenticate_t::pAuthenticateResult

8.723.2.2 uim_cardResult* unpack_uim_SLQSUIMAuthenticate_t::pCardResult

8.723.2.3 uint32_t* unpack_uim_SLQSUIMAuthenticate_t::pIndicationToken

8.724 unpack_uim_SLQSUIMDepersonalization_t Struct Reference

Data Fields

- uim_remainingRetries * pRemainingRetries

8.724.1 Detailed Description

This structure contains information of the response parameters associated with a Depersonalization.

Parameters

pRemaining-Retries(optional)	• See uim_remainingRetries for more information. • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned.

8.724.2 Field Documentation

8.724.2.1 uim_remainingRetries* unpack_uim_SLQSUIMDepersonalization_t::pRemainingRetries

8.725 unpack_uim_SLQSUIMEventRegister_t Struct Reference

Data Fields

- uint32_t eventMask

8.725.1 Detailed Description

This structure contains unpack event register parameter.

Parameters

eventMask	- bit 0 - card status • bit 1 - SAP connection • bit 4 - physical slot status • 0xffffffff - Invalid data.

8.725.2 Field Documentation

8.725.2.1 uint32_t unpack_uim_SLQSUIMEventRegister_t::eventMask

8.726 unpack_uim_SLQSUIMGetConfiguration_t Struct Reference

Data Fields

- uint8_t * pAutoSelection
- uim_personalizationStatus * pPersonalizationStatus
- uint8_t * pHaltSubscription

8.726.1 Detailed Description

This structure contains information of the response parameters associated with Get Configuration.

Parameters

pAuto-Selection(optional)	• Indicates whether the modem is configured to automatically select the provisioning sessions at powerup. • Valid values – 0 - Automatic provisioning is off – 1 - Automatic provisioning is on • NULL pointer - Invalid data.
p-Personalization-Status(optional)	• See uim_personalizationStatus for more information. • NULL pointer - Invalid data.
pHalt-Subscription(optional)	• Indicates if the modem is configured to publish the subscription after successful initialization. • Valid values – 0 - Modem proceeds with publishing the subscription – 1 - Modem does not publish the subscription • NULL pointer - Invalid data.

8.726.2 Field Documentation

8.726.2.1 uint8_t* unpack_uim_SLQSUIMGetConfiguration_t::pAutoSelection

8.726.2.2 uint8_t* unpack_uim_SLQSUIMGetConfiguration_t::pHaltSubscription

8.726.2.3 uim_personalizationStatus* unpack_uim_SLQSUIMGetConfiguration_t::pPersonalizationStatus

8.727 unpack_uim_SLQSUIMGetFileAttributes_t Struct Reference

Data Fields

- uim_cardResult * pCardResult
- uim_fileAttributes * pFileAttributes
- uint32_t * pIndicationToken

8.727.1 Detailed Description

This structure contains information of the response parameters associated with a Get File Attributes

Parameters

pCard-Result(optional)	• See uim_cardResult for more information. • NULL pointer - Invalid data.
pFile-Attributes(optional)	• See uim_fileAttributes for more information. • NULL pointer - Invalid data.

pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned.

8.727.2 Field Documentation

8.727.2.1 uim_cardResult∗ unpack_uim_SLQSUIMGetFileAttributes_t::pCardResult

8.727.2.2 uim_fileAttributes∗ unpack_uim_SLQSUIMGetFileAttributes_t::pFileAttributes

8.727.2.3 uint32_t∗ unpack_uim_SLQSUIMGetFileAttributes_t::pIndicationToken

8.728 unpack_uim_SLQSUIMGetSlotsStatus_t Struct Reference

Data Fields

- uint8_t ∗ pNumberOfPhySlot
- slots_t ∗ pUimSlotsStatus

8.728.1 Detailed Description

This structure contains information of the response parameters associated with a Get Slots Status API.

Parameters

pNumberOfPhy-Slot	• Number of sets of the Slot Status. • NULL pointer - Invalid data.
pUimSlotsStatus	• Slots Status See slots_t for more information..

8.728.2 Field Documentation

8.728.2.1 uint8_t∗ unpack_uim_SLQSUIMGetSlotsStatus_t::pNumberOfPhySlot

8.728.2.2 slots_t∗ unpack_uim_SLQSUIMGetSlotsStatus_t::pUimSlotsStatus

8.729 unpack_uim_SLQSUIMRefreshGetLastEvent_t Struct Reference

Data Fields

- uim_refreshevent ∗ pRefreshEvent

8.729.1 Detailed Description

This structure contains information of the response parameters associated with a Refresh Get Last Event.

Parameters

refreshEvent(-Optional)	• See uim_refreshevent for more information. • NULL pointer - Invalid data.

8.729.2 Field Documentation

8.729.2.1 uim_refreshevent* unpack_uim_SLQSUIMRefreshGetLastEvent_t::pRefreshEvent

8.730 unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t Struct Reference

Data Fields

- uim_cardStatus * pCardStatus

8.730.1 Detailed Description

This structure contains information about Status change callback.

Parameters

pCardStatus	Card Status • See uim_cardStatus for more information. • NULL pointer - Invalid data.

8.730.2 Field Documentation

8.730.2.1 uim_cardStatus* unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t::pCardStatus

8.731 unpack_uim_UnblockPin_t Struct Reference

Data Fields

- uim_remainingRetries * pRemainingRetries
- uim_encryptedPIN1 * pEncryptedPIN1
- uint32_t * pIndicationToken
- uint16_t Tlvresult

8.731.1 Detailed Description

This structure contains information of the response parameters associated with a set of PIN related API's.

Parameters

pRemaining-Retries(optional)	• See uim_remainingRetries for more information. • NULL pointer - Invalid data.
pEncryptedPI-N1(optional)	• See uim_encryptedPIN1 for more information. • NULL pointer - Invalid data.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result is provided in a subsequent indication. • 0xFFFFFFFF, if unavailable • NULL pointer - Invalid data.

8.731.2 Field Documentation

8.731.2.1 uim_encryptedPIN1∗ unpack_uim_UnblockPin_t::pEncryptedPIN1

8.731.2.2 uint32_t∗ unpack_uim_UnblockPin_t::pIndicationToken

8.731.2.3 uim_remainingRetries∗ unpack_uim_UnblockPin_t::pRemainingRetries

8.731.2.4 uint16_t unpack_uim_UnblockPin_t::Tlvresult

8.732 unpack_uim_VerifyPin_t Struct Reference

Data Fields

- uim_remainingRetries ∗ pRemainingRetries
- uim_encryptedPIN1 ∗ pEncryptedPIN1
- uint32_t ∗ pIndicationToken
- uint16_t Tlvresult

8.732.1 Detailed Description

This structure contains information of the response parameters associated with a set of PIN related API's.

Parameters

pRemaining-Retries(optional)	• See uim_remainingRetries for more information. • NULL pointer - Invalid data.
pEncryptedPI-N1(optional)	• See uim_encryptedPIN1 for more information. • NULL pointer - Invalid data.

pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result is provided in a subsequent indication. • 0xFFFFFFFF, if unavailable • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned.

8.732.2 Field Documentation

8.732.2.1 uim_encryptedPIN1∗ unpack_uim_VerifyPin_t::pEncryptedPIN1

8.732.2.2 uint32_t∗ unpack_uim_VerifyPin_t::pIndicationToken

8.732.2.3 uim_remainingRetries∗ unpack_uim_VerifyPin_t::pRemainingRetries

8.732.2.4 uint16_t unpack_uim_VerifyPin_t::Tlvresult

8.733 unpack_voice_SLQSOriginateUSSD_t Struct Reference

Data Fields

- uint16_t ∗ pfailureCause
- voice_alphaIDInfo ∗ pAlphaIDInfo
- struct voice_USSInfo ∗ pUSSDInfo
- uint8_t ∗ pCcResultType
- uint8_t ∗ pCallId
- voice_ccSUPSType ∗ pCCSuppsType

8.733.1 Detailed Description

This structure contains the parameters of USS response.

Parameters

pfailureCause

- Failure Cause.
- 0 - QMI_FAILURE_CAUSE_OFFLINE - Phone is offline
- 20 - QMI_FAILURE_CAUSE_CDMA_LOCK - Phone is CDMA locked until a power cycle; CDMA only
- 21 - QMI_FAILURE_CAUSE_NO_SRV - Phone has no service
- 22 - QMI_FAILURE_CAUSE_FADE - Call has ended abnormally
- 23 - QMI_FAILURE_CAUSE_INTERCEPT - Received intercept from the base station; originating only; CDMA only
- 24 - QMI_FAILURE_CAUSE_REORDER - Received reorder from the base station; originating only; CDMA only
- 25 - QMI_FAILURE_CAUSE_REL_NORMAL - Received release from the base station; no reason was given
- 26 - QMI_FAILURE_CAUSE_REL_SO_REJ - Received release from the base station; SO reject; CDMA only
- 27 - QMI_FAILURE_CAUSE_INCOM_CALL - Received incoming call from the base station
- 28 - QMI_FAILURE_CAUSE_ALERT_STOP - Received alert stop from the base station; incoming only; CDMA only
- 29 - QMI_FAILURE_CAUSE_CLIENT_END - Client ended the call
- 30 - QMI_FAILURE_CAUSE_ACTIVATION - Received end activation; OTASP call only; CDMA only
- 31 - QMI_FAILURE_CAUSE_MC_ABORT - MC aborted the origination/conversation; CDMA only
- 32 - QMI_FAILURE_CAUSE_MAX_ACCESS_PROBE - Maximum access probes were transmitted; CDMA only
- 33 - QMI_FAILURE_CAUSE_PSIST_N - Persistence test failure; FEATURE_JCDMA only; CDMA only
- 34 - QMI_FAILURE_CAUSE_UIM_NOT_PRESENT - R-UIM is not present
- 35 - QMI_FAILURE_CAUSE_ACC_IN_PROG - Access attempt is already in progress
- 36 - QMI_FAILURE_CAUSE_ACC_FAIL - Access failure for a reason other than the above
- 37 - QMI_FAILURE_CAUSE_RETRY_ORDER - Received retry order; originating only; IS 2000; CDMA only
- 38 - QMI_FAILURE_CAUSE_CCS_NOT_SUPPORTED_BYBS - Concurrent service is not supported by the base station
- 39 - QMI_FAILURE_CAUSE_NO_RESPONSE_FROM_BS - No response was received from the base station
- 40 - QMI_FAILURE_CAUSE_REJECTED_BY_BS - Call was rejected by the base station; CDMA only
- 41 - QMI_FAILURE_CAUSE_INCOMPATIBLE - Concurrent services requested were not compatible; CDMA only
- 42 - QMI_FAILURE_CAUSE_ACCESS_BLOCK - Access is blocked by the base station; CDMA only
- 43 - QMI_FAILURE_CAUSE_ALREADY_IN_TC - Corresponds to CM_CALL_ORIGERR_ALREADY_IN_TC
- 44 - QMI_FAILURE_CAUSE_EMERGENCY_FLASHED - Call is ended because an emergency call was flashed over this call; CDMA only
- 45 - QMI_FAILURE_CAUSE_USER_CALL_ORIGDURING_GPS - Used if CM is ending a GPS call in preference of a user call
- 46 - QMI_FAILURE_CAUSE_USER_CALL_ORIGDURING_SMS - Used if CM is ending an SMS call in preference of a user call
- 47 - QMI_FAILURE_CAUSE_USER_CALL_ORIGDURING_DATA - Used if CM is ending a data call in preference of an emergency call
- 48 - QMI_FAILURE_CAUSE_REDIR_OR_HANDOFF - Call was rejected because of a redirection or handoff
- 49 - QMI_FAILURE_CAUSE_ACCESS_BLOCK_ALL - Access is blocked by the base station for all mobiles; KDDI-specific; CDMA only
- 50 - QMI_FAILURE_CAUSE_OTASP_SPC_ERR - To support OTASP SPC Error indication
- 51 - QMI_FAILURE_CAUSE_IS707B_MAX_ACC - Maximum access probes for an IS-707B

AlphaIdentifier	• see voice_alphaIDInfo definition • NULL pointer - Invalid data.
pUSSDInfo	• USS Data from Network (See structure voice_USSInfo)

- NULL pointer - Invalid data.

Parameters

pCcResultType	• CC result code • NULL pointer - Invalid data.
pCallId	• Caller ID information • NULL pointer - Invalid data.
pCCSuppsType	• See structure 'voice_ccSUPSType' definition • NULL pointer - Invalid data.

8.733.2 Field Documentation

8.733.2.1 voice_alphaIDInfo* unpack_voice_SLQSOriginateUSSD_t::pAlphaIDInfo

8.733.2.2 uint8_t* unpack_voice_SLQSOriginateUSSD_t::pCallId

8.733.2.3 uint8_t* unpack_voice_SLQSOriginateUSSD_t::pCcResultType

8.733.2.4 voice_ccSUPSType* unpack_voice_SLQSOriginateUSSD_t::pCCSuppsType

8.733.2.5 uint16_t* unpack_voice_SLQSOriginateUSSD_t::pfailureCause

8.733.2.6 struct voice_USSInfo* unpack_voice_SLQSOriginateUSSD_t::pUSSDInfo

8.734 unpack_voice_SLQSVoiceAnswerCall_t Struct Reference

Data Fields

- uint8_t * pCallId

8.734.1 Detailed Description

Contains the parameters passed for pack voice Answer Call.

Parameters

pCallId	• Unique call identifier for the call that must be answered. • NULL pointer - Invalid data.

8.734.2 Field Documentation

8.734.2.1 uint8_t* unpack_voice_SLQSVoiceAnswerCall_t::pCallId

8.735 unpack_voice_SLQSVoiceBurstDTMF_t Struct Reference

Data Fields

- uint8_t * pCallID

8.735.1 Detailed Description

This structure contains Voice Burst DTMF Information for unpack.

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. A burst DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device • NULL pointer - Invalid data.

8.735.2 Field Documentation

8.735.2.1 uint8_t* unpack_voice_SLQSVoiceBurstDTMF_t::pCallID

8.736 unpack_voice_SLQSVoiceDialCall_t Struct Reference

Data Fields

- uint8_t * pCallID
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResultType
- voice_ccSUPSType * pCCSUPSType

8.736.1 Detailed Description

This structure contains Voice Call Response Parameters

Parameters

pCallID(optional)	• Unique call identifier for the dialed call • NULL pointer - Invalid data.
pAlphaID-Info(optional)	• Pointer to structure of alphaIDInfo – See voice_alphaIDInfo for more information • NULL pointer - Invalid data.
pCCResult-Type(optional)	• Call Control Result Type. – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – NULL pointer - Invalid data.
pCCSUPS-Type(optional)	• Pointer to structure of ccSUPSType • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • NULL pointer - Invalid data.

8.736.2 Field Documentation

8.736.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceDialCall_t::pAlphaIDInfo

8.736.2.2 uint8_t* unpack_voice_SLQSVoiceDialCall_t::pCallID

8.736.2.3 uint8_t* unpack_voice_SLQSVoiceDialCall_t::pCCResultType

8.736.2.4 voice_ccSUPSType* unpack_voice_SLQSVoiceDialCall_t::pCCSUPSType

8.737 unpack_voice_SLQSVoiceEndCall_t Struct Reference

Data Fields

- uint8_t * pCallId

8.737.1 Detailed Description

This structure contains unpack voice end call parameter.

Parameters

pCallId	• Unique call identifier for the call that must be ended • NULL pointer - Invalid data.

8.737.2 Field Documentation

8.737.2.1 uint8_t* unpack_voice_SLQSVoiceEndCall_t::pCallId

8.738 unpack_voice_SLQSVoiceGetAllCallInfo_t Struct Reference

Data Fields

- voice_arrCallInfo * pArrCallInfo
- voice_arrRemotePartyNum * pArrRemotePartyNum
- voice_arrRemotePartyName * pArrRemotePartyName
- voice_arrAlertingType * pArrAlertingType
- voice_arrUUSInfo * pArrUUSInfo
- voice_arrSvcOption * pArrSvcOption
- uint8_t * pOTASPStatus
- uint8_t * pVoicePrivacy
- voice_arrCallEndReason * pArrCallEndReason
- voice_arrAlphaID * pArrAlphaID
- voice_arrConnectPartyNum * pArrConnectPartyNum
- voice_arrDiagInfo * pArrDiagInfo
- voice_arrCalledPartyNum * pArrCalledPartyNum
- voice_arrRedirPartyNum * pArrRedirPartyNum
- voice_arrAlertingPattern * pArrAlertingPattern

8.738.1 Detailed Description

This structure contains information about the response parameters with all the calls originating or terminating from a particular device.

Parameters

pArrCallInfo(optional)	• See voice_arrCallInfo for more information. • NULL pointer - Invalid data.
pArrRemotePartyNum(optional)	• See voice_arrRemotePartyNum for more information. • NULL pointer - Invalid data.
pArrRemotePartyName(optional)	• See voice_arrRemotePartyName for more information. • NULL pointer - Invalid data.
pArrAlertingType(optional)	• See voice_arrAlertingType for more information. • NULL pointer - Invalid data.
pArrUUSInfo(optional)	• See voice_arrUUSInfo for more information. • NULL pointer - Invalid data.
pArrSvcOption(optional)	• See voice_arrSvcOption for more information. • NULL pointer - Invalid data.

pOTASP-Status(optional)	• OTASP status for the OTASP call. • Applicable only for 3GPP2 devices. – 0x00 - OTASP_STATUS_SPL_UNLOCKED - SPL unlocked; only for user-initiated OTASP – 0x01 - OTASP_STATUS_SPRC_RETRIES_EXCEEDED - SPC retries exceeded; only for user-initiated OTASP – 0x02 - OTASP_STATUS_AKEY_EXCHANGED - A-key exchanged; only for user-initiated OTASP – 0x03 - OTASP_STATUS_SSD_UPDATED - SSD updated; for both user-initiated OTASP and network-initiated OTASP (OTAPA) – 0x04 - OTASP_STATUS_NAM_DOWNLOADED - NAM downloaded; only for user-initiated OTASP – 0x05 - OTASP_STATUS_MDN_DOWNLOADED - MDN downloaded; only for user-initiated OTASP – 0x06 - OTASP_STATUS_IMSI_DOWNLOADED - IMSI downloaded; only for user-initiated OTASP – 0x07 - OTASP_STATUS_PRL_DOWNLOADED - PRL downloaded; only for user-initiated OTASP – 0x08 - OTASP_STATUS_COMMITTED - Commit successful; only for user-initiated OTASP – 0x09 - OTASP_STATUS_OTAPA_STARTED - OTAPA started; only for network-initiated OTASP (OTAPA) – 0x0A - OTASP_STATUS_OTAPA_STOPPED - OTAPA stopped; only for network-initiated OTASP (OTAPA) – 0x0B - OTASP_STATUS_OTAPA_ABORTED - OTAPA aborted; only for network-initiated OTASP (OTAPA) – 0x0C - OTASP_STATUS_OTAPA_COMMITTED - OTAPA committed; only for network-initiated OTASP (OTAPA) – 0xFF - Not Available • NULL pointer - Invalid data.
pVoice-Privacy(optional)	• Voice Privacy. • Values. – 0x00 - VOICE_PRIVACY_STANDARD - Standard privacy – 0x01 - VOICE_PRIVACY_ENHANCED - Enhanced privacy – 0xFF - Not Available • NULL pointer - Invalid data.
pArrCallEnd-Reason(optional)	• See voice_arrCallEndReason for more information. • NULL pointer - Invalid data.
pArrAlphaI-D(optional)	• See voice_arrAlphaID for more information. • NULL pointer - Invalid data.
pArrConnect-Party-Num(optional)	• See voice_arrConnectPartyNum for more information. • NULL pointer - Invalid data.

pArrDiag-Info(optional)	• See voice_arrDiagInfo for more information. • NULL pointer - Invalid data.
pArrCalledParty-Num(optional)	• See voice_arrCalledPartyNum for more information. • NULL pointer - Invalid data.
pArrRedirParty-Num(optional)	• See voice_arrRedirPartyNum for more information. • NULL pointer - Invalid data.
pArrAlerting-Pattern(optional)	• See voice_arrAlertingPattern for more information. • NULL pointer - Invalid data.

8.738.2 Field Documentation

8.738.2.1 voice_arrAlertingPattern∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrAlertingPattern

8.738.2.2 voice_arrAlertingType∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrAlertingType

8.738.2.3 voice_arrAlphaID∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrAlphaID

8.738.2.4 voice_arrCalledPartyNum∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrCalledPartyNum

8.738.2.5 voice_arrCallEndReason∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrCallEndReason

8.738.2.6 voice_arrCallInfo∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrCallInfo

8.738.2.7 voice_arrConnectPartyNum∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrConnectPartyNum

8.738.2.8 voice_arrDiagInfo∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrDiagInfo

8.738.2.9 voice_arrRedirPartyNum∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrRedirPartyNum

8.738.2.10 voice_arrRemotePartyName∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrRemotePartyName

8.738.2.11 voice_arrRemotePartyNum∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrRemotePartyNum

8.738.2.12 voice_arrSvcOption∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrSvcOption

8.738.2.13 voice_arrUUSInfo∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrUUSInfo

8.738.2.14 uint8_t∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pOTASPStatus

8.738.2.15 uint8_t∗ unpack_voice_SLQSVoiceGetAllCallInfo_t::pVoicePrivacy

8.739 unpack_voice_SLQSVoiceGetCallBarring_t Struct Reference

Data Fields

- uint8_t * pSvcClass
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType

8.739.1 Detailed Description

This structure contains Voice Get Call Barring Response Parameters

Parameters

pSvcClass	• Service class is a combination (sum) of information class constants (optional) • See qaGobiApiTableSupServiceInfoClasses.h for service classes. • Service Class is set to 0 if call waiting is not active for any of the information classes. • 0xFF,if Not Available • NULL pointer - Invalid data.
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • NULL pointer - Invalid data.
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • NULL pointer - Invalid data.
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • NULL pointer - Invalid data.
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • NULL pointer - Invalid data.
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned or has default value.

8.739.2 Field Documentation

8.739.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCallBarring_t::pAlphaIDInfo

8.739.2.2 uint8_t* unpack_voice_SLQSVoiceGetCallBarring_t::pCallID

8.739.2.3 uint8_t* unpack_voice_SLQSVoiceGetCallBarring_t::pCCResType

8.739.2.4 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCallBarring_t::pCCSUPSType

8.739.2.5 uint16_t* unpack_voice_SLQSVoiceGetCallBarring_t::pFailCause

8.739.2.6 uint8_t* unpack_voice_SLQSVoiceGetCallBarring_t::pSvcClass

8.740 unpack_voice_SLQSVoiceGetCallForwardingStatus_t Struct Reference

Data Fields

- voice_getCallFWInfo * pGetCallFWInfo
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType
- voice_getCallFWExtInfo * pGetCallFWExtInfo

8.740.1 Detailed Description

This structure contains Voice Get Call Forwarding Status Unpack Parameters

Parameters

pGetCallFWInfo	• Pointer to structure of getCallFWInfo (optional) – See voice_getCallFWInfo for more information • NULL pointer - Invalid data.
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • NULL pointer - Invalid data.
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • NULL pointer - Invalid data.

pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • NULL pointer - Invalid data.
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • NULL pointer - Invalid data.
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • NULL pointer - Invalid data.
pGetCallFWExt-Info	• Pointer to structure of getCallFWExtInfo (optional) – See voice_getCallFWExtInfo for more information • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned or has default value.

8.740.2 Field Documentation

8.740.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pAlphaIDInfo

8.740.2.2 uint8_t* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pCallID

8.740.2.3 uint8_t* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pCCResType

8.740.2.4 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pCCSUPSType

8.740.2.5 uint16_t* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pFailCause

8.740.2.6 voice_getCallFWExtInfo* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pGetCallFWExtInfo

8.740.2.7 voice_getCallFWInfo* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pGetCallFWInfo

8.741 unpack_voice_SLQSVoiceGetCallInfo_t Struct Reference

Data Fields

- voice_callInfo * pCallInfo
- voice_remotePartyNum * pRemotePartyNum

- uint16_t * pSrvOpt
- uint8_t * pVoicePrivacy
- uint8_t * pOTASPStatus
- voice_remotePartyName * pRemotePartyName
- voice_UUSInfo * pUUSInfo
- uint8_t * pAlertType
- voice_alphaIDInfo * pAlphaIDInfo
- voice_connectNumInfo * pConnectNumInfo
- voice_diagInfo * pDiagInfo
- uint32_t * pAlertingPattern

8.741.1 Detailed Description

This structure contains information of the unpack parameters associated with a call.

Parameters

pCall-Info(optional)	• See voice_callInfo for more information. • NULL pointer - Invalid data.
pRemoteParty-Num(optional)	• See voice_remotePartyNum for more information. • NULL pointer - Invalid data.
pSrvOpt	• Service option(optional) • Applicable only for 3GPP2 devices. • See Table8 qaGobiApiTableServiceOptions.h for standard service option number assignments. • NULL pointer - Invalid data.
pVoicePrivacy	• Voice Privacy.(optional) • Applicable only for 3GPP2 devices. • Values. – 0x00 - VOICE_PRIVACY_STANDARD - Standard privacy – 0x01 - VOICE_PRIVACY_ENHANCED - Enhanced privacy – 0xFF - Not Available • NULL pointer - Invalid data.

pOTASPStatus	• OTASP status for the OTASP call.(optional) • Applicable only for 3GPP2 devices. – 0x00 - OTASP_STATUS_SPL_UNLOCKED - SPL unlocked; only for user-initiated OTASP – 0x01 - OTASP_STATUS_SPRC_RETRIES_EXCEEDED - SPC retries exceeded; only for user-initiated OTASP – 0x02 - OTASP_STATUS_AKEY_EXCHANGED - A-key exchanged; only for user-initiated OTASP – 0x03 - OTASP_STATUS_SSD_UPDATED - SSD updated; for both user-initiated OTASP and network-initiated OTASP (OTAPA) – 0x04 - OTASP_STATUS_NAM_DOWNLOADED - NAM downloaded; only for user-initiated OTASP – 0x05 - OTASP_STATUS_MDN_DOWNLOADED - MDN downloaded; only for user-initiated OTASP – 0x06 - OTASP_STATUS_IMSI_DOWNLOADED - IMSI downloaded; only for user-initiated OTASP – 0x07 - OTASP_STATUS_PRL_DOWNLOADED - PRL downloaded; only for user-initiated OTASP – 0x08 - OTASP_STATUS_COMMITTED - Commit successful; only for user-initiated OTASP – 0x09 - OTASP_STATUS_OTAPA_STARTED - OTAPA started; only for network-initiated OTASP (OTAPA) – 0x0A - OTASP_STATUS_OTAPA_STOPPED - OTAPA stopped; only for network-initiated OTASP (OTAPA) – 0x0B - OTASP_STATUS_OTAPA_ABORTED - OTAPA aborted; only for network-initiated OTASP (OTAPA) – 0x0C - OTASP_STATUS_OTAPA_COMMITTED - OTAPA committed; only for network-initiated OTASP (OTAPA) – 0xFF - Not Available • NULL pointer - Invalid data.
pRemoteParty-Name(optional)	• Applicable only for 3GPP devices. • See voice_remotePartyName for more information. • NULL pointer - Invalid data.
pUUS-Info(optional)	• Applicable only for 3GPP devices. • See voice_UUSInfo for more information. • NULL pointer - Invalid data.
pAlert-Type(optional)	• Alerting type. • Applicable only for 3GPP devices. – 0x00 - ALERTING_LOCAL - Local – 0x01 - ALERTING_REMOTE - Remote – 0xFF - Not Available • NULL pointer - Invalid data.

pAlphaID-Info(optional)	• Applicable only for 3GPP devices. • See voice_alphaIDInfo for more information. • NULL pointer - Invalid data.
pConnectNum-Info(optional)	• See voice_connectNumInfo for more information. • NULL pointer - Invalid data.
pDiag-Info(optional)	• See voice_diagInfo for more information. • NULL pointer - Invalid data.
pAlertingPattern	• Alerting pattern.(optional) – 0x00 - QMI_VOICE_ALERTING_PATTERN_1 - Pattern 1 – 0x01 - QMI_VOICE_ALERTING_PATTERN_2 - Pattern 2 – 0x02 - QMI_VOICE_ALERTING_PATTERN_3 - Pattern 3 – 0x04 - QMI_VOICE_ALERTING_PATTERN_5 - Pattern 5 – 0x05 - QMI_VOICE_ALERTING_PATTERN_6 - Pattern 6 – 0x06 - QMI_VOICE_ALERTING_PATTERN_7 - Pattern 7 – 0x07 - QMI_VOICE_ALERTING_PATTERN_8 - Pattern 8 – 0x08 - QMI_VOICE_ALERTING_PATTERN_9 - Pattern 9 – 0xFF - Not Available • NULL pointer - Invalid data.

8.741.2 Field Documentation

8.741.2.1 uint32_t* unpack_voice_SLQSVoiceGetCallInfo_t::pAlertingPattern

8.741.2.2 uint8_t* unpack_voice_SLQSVoiceGetCallInfo_t::pAlertType

8.741.2.3 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCallInfo_t::pAlphaIDInfo

8.741.2.4 voice_callInfo* unpack_voice_SLQSVoiceGetCallInfo_t::pCallInfo

8.741.2.5 voice_connectNumInfo* unpack_voice_SLQSVoiceGetCallInfo_t::pConnectNumInfo

8.741.2.6 voice_diagInfo* unpack_voice_SLQSVoiceGetCallInfo_t::pDiagInfo

8.741.2.7 uint8_t* unpack_voice_SLQSVoiceGetCallInfo_t::pOTASPStatus

8.741.2.8 voice_remotePartyName* unpack_voice_SLQSVoiceGetCallInfo_t::pRemotePartyName

8.741.2.9 voice_remotePartyNum* unpack_voice_SLQSVoiceGetCallInfo_t::pRemotePartyNum

8.741.2.10 uint16_t* unpack_voice_SLQSVoiceGetCallInfo_t::pSrvOpt

8.741.2.11 voice_UUSInfo* unpack_voice_SLQSVoiceGetCallInfo_t::pUUSInfo

8.741.2.12 uint8_t* unpack_voice_SLQSVoiceGetCallInfo_t::pVoicePrivacy

8.742 unpack_voice_SLQSVoiceGetCallWaiting_t Struct Reference

Data Fields

- uint8_t * pSvcClass
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType

8.742.1 Detailed Description

This structure contains Voice Get Call Waiting Unpack Parameters

Parameters

pSvcClass	• Service class is a combination (sum) of information class constants (optional) • See qaGobiApiTableSupServiceInfoClasses.h for service classes. • Service Class is set to 0 if call waiting is not active for any of the information classes. • 0xFF,if Not Available • NULL pointer - Invalid data.
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • NULL pointer - Invalid data.
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • NULL pointer - Invalid data.
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • NULL pointer - Invalid data.
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • NULL pointer - Invalid data.

pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned or has default value.

8.742.2 Field Documentation

8.742.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCallWaiting_t::pAlphaIDInfo

8.742.2.2 uint8_t* unpack_voice_SLQSVoiceGetCallWaiting_t::pCallID

8.742.2.3 uint8_t* unpack_voice_SLQSVoiceGetCallWaiting_t::pCCResType

8.742.2.4 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCallWaiting_t::pCCSUPSType

8.742.2.5 uint16_t* unpack_voice_SLQSVoiceGetCallWaiting_t::pFailCause

8.742.2.6 uint8_t* unpack_voice_SLQSVoiceGetCallWaiting_t::pSvcClass

8.743 unpack_voice_SLQSVoiceGetCLIP_t Struct Reference

Data Fields

- voice_CLIPResp * pCLIPResp
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType

8.743.1 Detailed Description

This structure contains Voice Get Calling Line Identification Presentation(CLIP) Response Parameters

Parameters

pCLIPResp	• Pointer to structure of CLIPResp (optional) – See voice_CLIPResp for more information • NULL pointer - Invalid data.
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • NULL pointer - Invalid data.

pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • NULL pointer - Invalid data.
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • NULL pointer - Invalid data.
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned or has default value.

8.743.2 Field Documentation

8.743.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCLIP_t::pAlphaIDInfo

8.743.2.2 uint8_t* unpack_voice_SLQSVoiceGetCLIP_t::pCallID

8.743.2.3 uint8_t* unpack_voice_SLQSVoiceGetCLIP_t::pCCResType

8.743.2.4 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCLIP_t::pCCSUPSType

8.743.2.5 voice_CLIPResp* unpack_voice_SLQSVoiceGetCLIP_t::pCLIPResp

8.743.2.6 uint16_t* unpack_voice_SLQSVoiceGetCLIP_t::pFailCause

8.744 unpack_voice_SLQSVoiceGetCLIR_t Struct Reference

Data Fields

- voice_CLIRResp * pCLIRResp
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType

8.744.1 Detailed Description

This structure contains Voice Get Calling Line Identification Restriction (CLIR) Response Parameters

Parameters

pCLIRResp	• Pointer to structure of CLIRResp (optional) – See voice_CLIRResp for more information • NULL pointer - Invalid data.
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • NULL pointer - Invalid data.
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • NULL pointer - Invalid data.
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • NULL pointer - Invalid data.
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • NULL pointer - Invalid data.
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned or has default value.

8.744.2 Field Documentation

8.744.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCLIR_t::pAlphaIDInfo

8.744.2.2 uint8_t* unpack_voice_SLQSVoiceGetCLIR_t::pCallID

8.744.2.3 uint8_t* unpack_voice_SLQSVoiceGetCLIR_t::pCCResType

8.744.2.4 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCLIR_t::pCCSUPSType

8.744.2.5 voice_CLIRResp* unpack_voice_SLQSVoiceGetCLIR_t::pCLIRResp

8.744.2.6 uint16_t* unpack_voice_SLQSVoiceGetCLIR_t::pFailCause

8.745 unpack_voice_SLQSVoiceGetCNAP_t Struct Reference

Data Fields

- voice_CNAPResp * pCNAPResp
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType

8.745.1 Detailed Description

This structure contains Voice Get Calling Name Presentation(CNAP) Response Parameters

Parameters

pCNAPResp	• Pointer to structure of CNAPResp (optional) – See voice_CNAPResp for more information • NULL pointer - Invalid data.
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • NULL pointer - Invalid data.
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • NULL pointer - Invalid data.

pCCResType	• Call Control Result Type (optional)
	  – 0x00 - CC_RESULT_TYPE_VOICE - Voice
	  – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service
	  – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service
	  – 0xFF - Not Available
	• NULL pointer - Invalid data.

pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • NULL pointer - Invalid data.
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned or has default value.

8.745.2 Field Documentation

8.745.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCNAP_t::pAlphaIDInfo

8.745.2.2 uint8_t* unpack_voice_SLQSVoiceGetCNAP_t::pCallID

8.745.2.3 uint8_t* unpack_voice_SLQSVoiceGetCNAP_t::pCCResType

8.745.2.4 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCNAP_t::pCCSUPSType

8.745.2.5 voice_CNAPResp* unpack_voice_SLQSVoiceGetCNAP_t::pCNAPResp

8.745.2.6 uint16_t* unpack_voice_SLQSVoiceGetCNAP_t::pFailCause

8.746 unpack_voice_SLQSVoiceGetCOLP_t Struct Reference

Data Fields

- voice_COLPResp * pCOLPResp
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType

8.746.1 Detailed Description

This structure contains Voice Get Connected Line Identification Presentation(COLP) Response Parameters

Parameters

pCOLPResp	• Pointer to structure of COLPResp (optional) – See voice_COLPResp for more information • NULL pointer - Invalid data.

pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • NULL pointer - Invalid data.
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • NULL pointer - Invalid data.
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • NULL pointer - Invalid data.
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • NULL pointer - Invalid data.
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned or has default value.

8.746.2 Field Documentation

8.746.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCOLP_t::pAlphaIDInfo

8.746.2.2 uint8_t* unpack_voice_SLQSVoiceGetCOLP_t::pCallID

8.746.2.3 uint8_t* unpack_voice_SLQSVoiceGetCOLP_t::pCCResType

8.746.2.4 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCOLP_t::pCCSUPSType

8.746.2.5 voice_COLPResp* unpack_voice_SLQSVoiceGetCOLP_t::pCOLPResp

8.746.2.6 uint16_t* unpack_voice_SLQSVoiceGetCOLP_t::pFailCause

8.747 unpack_voice_SLQSVoiceGetCOLR_t Struct Reference

Data Fields

- voice_COLRResp * pCOLRResp
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType

8.747.1 Detailed Description

This structure contains Voice Get Connected Line Identification Restriction(COLR) Response Parameters

Parameters

pCOLRResp	• Pointer to structure of COLRResp (optional) – See voice_COLRResp for more information • NULL pointer - Invalid data.
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • NULL pointer - Invalid data.
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • NULL pointer - Invalid data.
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • NULL pointer - Invalid data.
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • NULL pointer - Invalid data.
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned or has default value.

8.747.2 Field Documentation

8.747.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCOLR_t::pAlphaIDInfo

8.747.2.2 uint8_t* unpack_voice_SLQSVoiceGetCOLR_t::pCallID

8.747.2.3 uint8_t* unpack_voice_SLQSVoiceGetCOLR_t::pCCResType

8.747.2.4 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCOLR_t::pCCSUPSType

8.747.2.5 voice_COLRResp* unpack_voice_SLQSVoiceGetCOLR_t::pCOLRResp

8.747.2.6 uint16_t* unpack_voice_SLQSVoiceGetCOLR_t::pFailCause

8.748 unpack_voice_SLQSVoiceGetConfig_t Struct Reference

Data Fields

- uint8_t * pAutoAnswerStat
- voice_airTimer * pAirTimerCnt
- voice_roamTimer * pRoamTimerCnt
- uint8_t * pCurrTTYMode
- voice_prefVoiceSO * pCurPrefVoiceSO
- voice_curAMRConfig * pCurAMRConfig
- uint8_t * pCurVoicePrivacyPref
- uint8_t * pCurVoiceDomainPref

8.748.1 Detailed Description

This structure contains Voice Get Configuration Response Parameters.

Parameters

pAutoAnswer-Stat(optional)	• Auto Answer Status • Value returned is read from NV_AUTO_ANSWER_I. – 0x00 - Disabled – 0x01 - Enabled – 0xFF - Not Available • NULL pointer - Invalid data.
pAirTimer-Cnt(optional)	• Air Timer Count • Value returned is read from NV_AIR_CNT_I. • See voice_airTimer for more information • NULL pointer - Invalid data.

pRoamTimer-Cnt(optional)	• Roam Timer Count • Value returned is read from NV_ROAM_CNT_I. • See voice_roamTimer for more information • NULL pointer - Invalid data.
pCurrTTY-Mode(optional)	• Current TTY Mode • Value returned is read from NV_TTY_I. – 0x00 - TTY_MODE_FULL - Full – 0x01 - TTY_MODE_VCO - Voice carry over – 0x02 - TTY_MODE_HCO - Hearing carry over – 0x03 - TTY_MODE_OFF - Off – 0xFF - Not Available • NULL pointer - Invalid data.
pCurPrefVoiceS-O(optional)	• Current Preferred Voice SO • Value returned is read from NV_PREF_VOICE_SO_I. • See voice_prefVoiceSO for more information • NULL pointer - Invalid data.
pCurAMR-Config(optional)	• Current Adaptive Multi-Rate Configuration. • Values returned are read from NV_GSM_ARM_CALL_CONFIG_I and NV_UMTS_AMR_CODEC_PREFERENCE_CONFIG_I. • See voice_curAMRConfig for more information • NULL pointer - Invalid data.
pCurVoice-Privacy-Pref(optional)	• Current Voice Privacy Preference • Value returned is read from NV_VOICE_PRIV_I. – 0x00 - Standard privacy – 0x01 - Enhanced privacy – 0xFF - Not Available • NULL pointer - Invalid data.
pCurVoice-Domain-Pref(optional)	• Current Voice Domain Preference. – 0x00 - Circuit-switched (CS) only – 0x01 - Packet-switched (PS) only – 0x02 - CS is preferred; PS is secondary – 0x03 - PS is preferred; CS is secondary – 0xFF - Not Available • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned or has default value.

8.748.2 Field Documentation

8.748.2.1 voice_airTimer* unpack_voice_SLQSVoiceGetConfig_t::pAirTimerCnt

8.748.2.2 uint8_t* unpack_voice_SLQSVoiceGetConfig_t::pAutoAnswerStat

8.748.2.3 voice_curAMRConfig* unpack_voice_SLQSVoiceGetConfig_t::pCurAMRConfig

8.748.2.4 voice_prefVoiceSO* unpack_voice_SLQSVoiceGetConfig_t::pCurPrefVoiceSO

8.748.2.5 uint8_t* unpack_voice_SLQSVoiceGetConfig_t::pCurrTTYMode

8.748.2.6 uint8_t* unpack_voice_SLQSVoiceGetConfig_t::pCurVoiceDomainPref

8.748.2.7 uint8_t* unpack_voice_SLQSVoiceGetConfig_t::pCurVoicePrivacyPref

8.748.2.8 voice_roamTimer* unpack_voice_SLQSVoiceGetConfig_t::pRoamTimerCnt

8.749 unpack_voice_SLQSVoiceManageCalls_t Struct Reference

Data Fields

- uint16_t * pFailCause

8.749.1 Detailed Description

This structure contains Failure cause Information. Populated when API Fails.

Parameters

pFailCause	• Supplementary service failure causes (optional, supply NULL if not required). • See Table8 qaGobiApiTableVoiceCallEndReasons.h for supplementary services failure cause – 0xFFFF is the value when the information is not received from device • NULL pointer - Invalid data.

8.749.2 Field Documentation

8.749.2.1 uint16_t* unpack_voice_SLQSVoiceManageCalls_t::pFailCause

8.750 unpack_voice_SLQSVoiceSendFlash_t Struct Reference

Data Fields

- uint8_t * pCallID

8.750.1 Detailed Description

This structure contains the flash information associated with a call.

Parameters

pCallID	• Unique call identifier associated with the current call. • NULL pointer - Invalid data.

8.750.2 Field Documentation

8.750.2.1 uint8_t* unpack_voice_SLQSVoiceSendFlash_t::pCallID

8.751 unpack_voice_SLQSVoiceSetCallBarringPassword_t Struct Reference

Data Fields

- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType

8.751.1 Detailed Description

This structure contains Voice Set Call Barring Password Unpack Parameters

Parameters

pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • NULL pointer - Invalid data.
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • NULL pointer - Invalid data.
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • NULL pointer - Invalid data.
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • NULL pointer - Invalid data.

pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • NULL pointer - Invalid data.

Note

Using NULL for the pointers would make sure that the parameter is not returned or has default value.

8.751.2 Field Documentation

8.751.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceSetCallBarringPassword_t::pAlphaIDInfo

8.751.2.2 uint8_t* unpack_voice_SLQSVoiceSetCallBarringPassword_t::pCallID

8.751.2.3 uint8_t* unpack_voice_SLQSVoiceSetCallBarringPassword_t::pCCResType

8.751.2.4 voice_ccSUPSType* unpack_voice_SLQSVoiceSetCallBarringPassword_t::pCCSUPSType

8.751.2.5 uint16_t* unpack_voice_SLQSVoiceSetCallBarringPassword_t::pFailCause

8.752 unpack_voice_SLQSVoiceSetConfig_t Struct Reference

Data Fields

- uint8_t * pAutoAnsStatus
- uint8_t * pAirTimerStatus
- uint8_t * pRoamTimerStatus
- uint8_t * pTTYConfigStatus
- uint8_t * pPrefVoiceSOStatus
- uint8_t * pVoiceDomainPrefStatus

8.752.1 Detailed Description

This structure contains information about the Set Configuration Response Parameters.

Parameters

pAutoAnsStatus	• Auto Answer Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. – NULL pointer - Invalid data.

pAirTimerStatus	• Air Timer Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. – NULL pointer - Invalid data.
pRoamTimer-Status	• Roam Timer Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. – NULL pointer - Invalid data.
pTTYConfig-Status	• TTY Config Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. – NULL pointer - Invalid data.
pPrefVoiceSO-Status	• Preferred Voice SO Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. – NULL pointer - Invalid data.
pVoiceDomain-PrefStatus	• Voice-Domain Preference Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. – NULL pointer - Invalid data.

Note

Parameters which are mentioned as NULL will be ignored.

8.752.2 Field Documentation

8.752.2.1 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pAirTimerStatus

8.752.2.2 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pAutoAnsStatus

8.752.2.3 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pPrefVoiceSOStatus

8.752.2.4 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pRoamTimerStatus

8.752.2.5 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pTTYConfigStatus

8.752.2.6 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pVoiceDomainPrefStatus

8.753 unpack_voice_SLQSVoiceSetSUPSService_t Struct Reference

Data Fields

- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResultType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType

8.753.1 Detailed Description

This structure contains Supplementary Service response parameters related to different features and their activation, deactivation, registration and erasure (applicable only for 3GPP)

Parameters

pFailCause	• Supplementary service failure causes (optional, supply NULL if not required). – 0xFFFF is the value when the information is not received from device – NULL pointer - Invalid data.
pAlphaIDInfo	• Pointer to structure of alphaIDInfo. The parameter used to pass the alpha (if any) given by the SIM/R-UIM after call control (optional, supply NULL if not required) – See voice_alphaIDInfo for more information – NULL pointer - Invalid data.
pCCResultType	• Call control result types (optional, supply NULL if not required) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - if the device does not provide this information – NULL pointer - Invalid data.
pCallID	• Unique call identifier for the dialed call (optional, supply NULL if not required) – 0x00 - if the device does not provide this information – NULL pointer - Invalid data.

pCCSUPSType	• Data is present when pCCResultType is present and is other than Voice. (optional, supply NULL if not required) – See voice_ccSUPSType for more information – NULL pointer - Invalid data.

8.753.2 Field Documentation

8.753.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceSetSUPSService_t::pAlphaIDInfo

8.753.2.2 uint8_t* unpack_voice_SLQSVoiceSetSUPSService_t::pCallID

8.753.2.3 uint8_t* unpack_voice_SLQSVoiceSetSUPSService_t::pCCResultType

8.753.2.4 voice_ccSUPSType* unpack_voice_SLQSVoiceSetSUPSService_t::pCCSUPSType

8.753.2.5 uint16_t* unpack_voice_SLQSVoiceSetSUPSService_t::pFailCause

8.754 unpack_voice_SLQSVoiceStartContDTMF_t Struct Reference

Data Fields

- uint8_t * pCallID

8.754.1 Detailed Description

This structure contains parameters of continuous DTMF

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. Start continuous DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device • NULL pointer - Invalid data.

8.754.2 Field Documentation

8.754.2.1 uint8_t* unpack_voice_SLQSVoiceStartContDTMF_t::pCallID

8.755 unpack_voice_SLQSVoiceStopContDTMF_t Struct Reference

Data Fields

- uint8_t callID

8.755.1 Detailed Description

This structure contains parameters of stop continuous DTMF

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. Stop continuous DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device

8.755.2 Field Documentation

8.755.2.1 uint8_t unpack_voice_SLQSVoiceStopContDTMF_t::callID

8.756 unpack_wds_DHCPv4ClientLease_ind_t Struct Reference

Data Fields

- wds_DHCPProfileIdTlv ProfileIdTlv
- wds_DHCPLeaseStateTlv DHCPv4LeaseStateTlv
- wds_IPv4AdTlv IPv4AddrTlv
- wds_DHCPLeaseOptTlv DHCPv4LeaseOptTlv

8.756.1 Detailed Description

This structure contains DHCP IPv4 client lease information

Parameters

ProfileIdTlv	profile identifier information, see wds_DHCPProfileIdTlv for more details
DHCPv4Lease-StateTlv	lease state, see wds_DHCPLeaseStateTlv for more details
IPv4AddrTlv	IPv4 address, see wds_IPv4AdTlv for more details
DHCPv4Lease-OptTlv	DHCP lease option, see wds_DHCPLeaseOptTlv for more details

8.756.2 Field Documentation

8.756.2.1 wds_DHCPLeaseOptTlv unpack_wds_DHCPv4ClientLease_ind_t::DHCPv4LeaseOptTlv

8.756.2.2 wds_DHCPLeaseStateTlv unpack_wds_DHCPv4ClientLease_ind_t::DHCPv4LeaseStateTlv

8.756.2.3 wds_IPv4AdTlv unpack_wds_DHCPv4ClientLease_ind_t::IPv4AddrTlv

8.756.2.4 wds_DHCPProfileIdTlv unpack_wds_DHCPv4ClientLease_ind_t::ProfileIdTlv

8.757 unpack_wds_GetAutoconnect_t Struct Reference

Data Fields

- uint32_t * psetting

8.757.1 Detailed Description

auto connect data session setting parameter.

Parameters

pSetting	• NDIS auto connect setting – 0 - Disabled – 1 - Enabled

8.757.2 Field Documentation

8.757.2.1 uint32_t* unpack_wds_GetAutoconnect_t::psetting

8.758 unpack_wds_GetByteTotals_t Struct Reference

Data Fields

- uint64_t * pTXTotalBytes
- uint64_t * pRXTotalBytes

8.758.1 Detailed Description

This structure contains unpack get byte totals information.

Parameters

pTXTotalBytes	• Bytes transmitted without error • NULL pointer - Invalid data.
pRXTotalBytes	• Bytes received without error • NULL pointer - Invalid data.

8.758.2 Field Documentation

8.758.2.1 uint64_t* unpack_wds_GetByteTotals_t::pRXTotalBytes

8.758.2.2 uint64_t* unpack_wds_GetByteTotals_t::pTXTotalBytes

8.759 unpack_wds_GetConnectionRate_t Struct Reference

Data Fields

- uint32_t currentChannelTXRate
- uint32_t currentChannelRXRate
- uint32_t maxChannelTXRate
- uint32_t maxChannelRXRate

8.759.1 Detailed Description

This structure contains unpack get connection rate information.

Parameters

currentChannelTXRate	• Current channel Tx rate (in bps)
currentChannelRXRate	• Current channel Rx rate (in bps)
maxChannelTXRate	• Maximum Tx rate (bps) that may be assigned to device by serving system.
maxChannelRXRate	• Maximum Rx rate (bps) that may be assigned to device by serving system.

8.759.2 Field Documentation

8.759.2.1 uint32_t unpack_wds_GetConnectionRate_t::currentChannelRXRate

8.759.2.2 uint32_t unpack_wds_GetConnectionRate_t::currentChannelTXRate

8.759.2.3 uint32_t unpack_wds_GetConnectionRate_t::maxChannelRXRate

8.759.2.4 uint32_t unpack_wds_GetConnectionRate_t::maxChannelTXRate

8.760 unpack_wds_GetDataBearerTechnology_t Struct Reference

Data Fields

- uint32_t * pDataBearer

8.760.1 Detailed Description

This structure contains unpack get data bearer technology information.

Parameters

pDataBearer[OUT]	• Data bearer technology – 0x01 - CDMA2000 1x – 0x02 - CDMA 1xEV-DO Rev 0 – 0x03 - GSM – 0x04 - UMTS – 0x05 - CDMA2000 HRPD (1xEV-DO Rev A) – 0x06 - EDGE – 0x07 - HSDPA AND WCDMA – 0x08 - WCDMA AND HSUPA – 0x09 - HSDPA AND HSUPA – 0x0A - LTE – 0x0B - CDMA2000 EHRPD – 0x0C - HSDPA+ and WCDMA – 0x0D - HSDPA+ and HSUPA – 0x0E - DC_HSDPA+ and WCDMA – 0x0F - DC_HSDPA+ and HSUPA – 0x10 - HSDPA+ and 64QAM – 0x11 - HSDPA+, 64QAM and HSUPA – 0x12 - TDSCDMA – 0x13 - TDSCDMA and HSDPA – 0xFF - Unknown

8.760.2 Field Documentation

8.760.2.1 uint32_t* unpack_wds_GetDataBearerTechnology_t::pDataBearer

8.761 unpack_wds_GetDefaultProfile_t Struct Reference

Data Fields

- uint32_t pdptype
- uint32_t ipaddr
- uint32_t pridns
- uint32_t secdns
- uint16_t ipaddrv6
- uint16_t pridnsv6
- uint16_t secdnsv6
- uint32_t auth
- uint8_t namesize
- int8_t name [255]
- uint8_t apnsize
- int8_t apnname [255]
- uint8_t usersize
- int8_t username [255]

8.761.1 Detailed Description

Reads the default profile settings from the device. The default profile is used to establish an auto connect data session.

Parameters

pdptype	• Packet Data Protocol (PDP) type specifies the type of data payload exchanged over the air link when the packet data session is established with this profile – 0 - PDP-IP (IPv4) – 1 - PDP-PPP – 2 - PDP-IPv6 – 3 - PDP-IPv4v6 – 0xff - Invalid data.
ipaddr	• Preferred IPv4 address to be assigned to device • 0xffffffff - Invalid data.
pridns	• Primary DNS IPv4 address preference • 0xffffffff - Invalid data.
secdns	• Secondary DNS IPv4 address preference • 0xffffffff - Invalid data.
ipaddrv6	• Preferred IPv6 address to be assigned to device • 0xffff - Invalid data.
pridnsv6	• Primary DNS Pv6 address preference • 0xffff - Invalid data.
secdnsv6	• Secondary DNS IPv6 address preference • 0xffff - Invalid data.
auth	• Bitmap that indicates authentication algorithm preference – 0x00000001 - PAP preference * 0 - Never performed * 1 - May be performed – 0x00000002 - CHAP preference * 0 - Never performed * 1 - May be performed – All other bits are reserved and must be set to 0 – If more than 1 bit is set, then device decides which authentication procedure is performed while setting up data session e.g. the device may have a policy to select the most secure authentication mechanism. – 0xffffffff - Invalid data.
namesize	• Maximum number of characters (including NULL terminator) that profile name array can contain. • 0xff - Invalid name data.

name	• Profile name
apnsize	• Maximum number of characters (including NULL terminator) that APN name array can contain • 0xff - Invalid apnname data.
apnname	• Access point name. NULL-terminated string parameter that is a logical name used to select GGSN and external packet data network. • If value is NULL or omitted, then subscription default value will be requested.
usersize	• Maximum number of characters (including NULL terminator) that username array can contain. • 0xff - Invalid username data.
username	• Username used during network authentication

8.761.2 Field Documentation

8.761.2.1 int8_t unpack_wds_GetDefaultProfile_t::apnname[255]

8.761.2.2 uint8_t unpack_wds_GetDefaultProfile_t::apnsize

8.761.2.3 uint32_t unpack_wds_GetDefaultProfile_t::auth

8.761.2.4 uint32_t unpack_wds_GetDefaultProfile_t::ipaddr

8.761.2.5 uint16_t unpack_wds_GetDefaultProfile_t::ipaddrv6

8.761.2.6 int8_t unpack_wds_GetDefaultProfile_t::name[255]

8.761.2.7 uint8_t unpack_wds_GetDefaultProfile_t::namesize

8.761.2.8 uint32_t unpack_wds_GetDefaultProfile_t::pdptype

8.761.2.9 uint32_t unpack_wds_GetDefaultProfile_t::pridns

8.761.2.10 uint16_t unpack_wds_GetDefaultProfile_t::pridnsv6

8.761.2.11 uint32_t unpack_wds_GetDefaultProfile_t::secdns

8.761.2.12 uint16_t unpack_wds_GetDefaultProfile_t::secdnsv6

8.761.2.13 int8_t unpack_wds_GetDefaultProfile_t::username[255]

8.761.2.14 uint8_t unpack_wds_GetDefaultProfile_t::usersize

8.762 unpack_wds_GetDefaultProfileNum_t Struct Reference

Data Fields

- uint8_t index

8.762.1 Detailed Description

This structure contains unpack Get Default Profile Number information.

Parameters

index	profile index

8.762.2 Field Documentation

8.762.2.1 uint8_t unpack_wds_GetDefaultProfileNum_t::index

8.763 unpack_wds_GetDormancyState_t Struct Reference

Data Fields

- uint32_t dormancyState

8.763.1 Detailed Description

This structure contains unpack get dormancy state information.

Parameters

dormancyState	• Dormancy state of current packet data session – 1 - Traffic channel dormant – 2 - Traffic channel active

8.763.2 Field Documentation

8.763.2.1 uint32_t unpack_wds_GetDormancyState_t::dormancyState

8.764 unpack_wds_GetLastMobileIPError_t Struct Reference

Data Fields

- uint32_t error

8.764.1 Detailed Description

structure to store last mobile IP error.

Parameters

error	• Status of last MIP call (or attempt) – Zero - Success – NonZero - Error code See qaGobiApiTableCallEndReasons.h for Mobile IP Error codes

8.764.2 Field Documentation

8.764.2.1 uint32_t unpack_wds_GetLastMobileIPError_t::error

8.765 unpack_wds_GetMobileIP_t Struct Reference

Data Fields

- uint32_t mipMode

8.765.1 Detailed Description

This structure contains unpack get mobile IP information.

Parameters

mipMode	• Mobile IP setting – 0 - Mobile IP off (simple IP only) – 1 - Mobile IP preferred – 2 - Mobile IP only

8.765.2 Field Documentation

8.765.2.1 uint32_t unpack_wds_GetMobileIP_t::mipMode

8.766 unpack_wds_GetMobileIPProfile_t Struct Reference

Data Fields

- uint8_t enabled
- uint32_t address
- uint32_t primaryHA
- uint32_t secondaryHA
- uint8_t revTunneling
- uint8_t naiSize
- int8_t NAI [255]
- uint32_t HASPI
- uint32_t AAASPI
- uint32_t HAState
- uint32_t AAAState

8.766.1 Detailed Description

This structure contains unpack get mobile IP profile information.

Parameters

enabled	• Profile enabled: – 0 - Disabled – 1 - Enabled – 0xFF - Invalid data.
address	• Home IPv4 address: – 0xFFFFFFFF - Invalid data.
primaryHA	• Primary home agent IPv4 address – 0xFFFFFFFF - Invalid data.
secondaryHA	• Secondary home agent IPv4 address – 0xFFFFFFFF - Invalid data.
revTunneling	• Reverse tunneling enabled – 0 - Disabled – 1 - Enabled – 0xFF - Invalid data.
naiSize	• The maximum number of characters (including NULL terminator) that the NAI array can contain. • 0xFF - Invalid data.
NAI	• Network access identifier string • 0xFF - Invalid data.
HASPI	• Home agent security parameter index • 0xFF - Invalid data.
AAASPI	• AAA server security parameter index – 0xFFFFFFFF - Unknown
HAState	• Home agent key state – 0 - Unset – 1 - Set, default value – 2 - Set, modified from default – 3 - 0xFFFFFFFF - Unknown

AAAState	• AAA key state – 0 - Unset – 1 - Set, default value – 2 - Set, modified from default – 3 - 0xFFFFFFFF - Unknown

8.766.2 Field Documentation

8.766.2.1 uint32_t unpack_wds_GetMobileIPProfile_t::AAASPI

8.766.2.2 uint32_t unpack_wds_GetMobileIPProfile_t::AAAState

8.766.2.3 uint32_t unpack_wds_GetMobileIPProfile_t::address

8.766.2.4 uint8_t unpack_wds_GetMobileIPProfile_t::enabled

8.766.2.5 uint32_t unpack_wds_GetMobileIPProfile_t::HASPI

8.766.2.6 uint32_t unpack_wds_GetMobileIPProfile_t::HAState

8.766.2.7 int8_t unpack_wds_GetMobileIPProfile_t::NAI[255]

8.766.2.8 uint8_t unpack_wds_GetMobileIPProfile_t::naiSize

8.766.2.9 uint32_t unpack_wds_GetMobileIPProfile_t::primaryHA

8.766.2.10 uint8_t unpack_wds_GetMobileIPProfile_t::revTunneling

8.766.2.11 uint32_t unpack_wds_GetMobileIPProfile_t::secondaryHA

8.767 unpack_wds_GetPacketStatistics_t Struct Reference

Data Fields

- uint32_t * pTXPacketSuccesses
- uint32_t * pRXPacketSuccesses
- uint32_t * pTXPacketErrors
- uint32_t * pRXPacketErrors
- uint32_t * pTXPacketOverflows
- uint32_t * pRXPacketOverflows
- uint64_t * pTXOkBytesCount
- uint64_t * pRXOkBytesCount
- uint64_t * pTXOKBytesLastCall
- uint64_t * pRXOKBytesLastCall
- uint32_t * pTXDroppedCount
- uint32_t * pRXDroppedCount

8.767.1 Detailed Description

This structure contains unpack get packet statistics information.

Parameters

pTXPacket-Successes	• No of transmitted Packets without error. • NULL pointer - Invalid data.
pRXPacket-Successes	• No of received Packets without error. • NULL pointer - Invalid data.
pTXPacketErrors	• Number of outgoing packets with framing errors. • NULL pointer - Invalid data.
pRXPacket-Errors	• Number of incoming packets with framing errors. • NULL pointer - Invalid data.
pTXPacket-Overflows	• Number of packets dropped because Tx buffer overflowed (out of memory). • NULL pointer - Invalid data.
pRXPacket-Overflows	• Number of packets dropped because Rx buffer overflowed (out of memory). • NULL pointer - Invalid data.
pTXOkBytes-Count	• Number of bytes transmitted without error. • NULL pointer - Invalid data.
pRXOkBytes-Count	• Number of bytes received without error. • NULL pointer - Invalid data.
pTXOKBytes-LastCall	• Number of bytes transmitted without error during the last data call (0 if no call was made earlier). Returned only if not in a call, and when the previous call was made using RmNet (for any devices that support • NULL pointer - Invalid data.
pRXOKBytes-LastCall	• Number of bytes received without error during the last data call (0 if no call was made earlier). Returned only if not in a call, and when the previous call was made using RmNet (for any devices that support • NULL pointer - Invalid data.
pTXDropped-Count	• Number of outgoing packets dropped. • NULL pointer - Invalid data.
pRXDropped-Count	• Number of incoming packets dropped. • NULL pointer - Invalid data.

8.767.2 Field Documentation

8.767.2.1 uint32_t* unpack_wds_GetPacketStatistics_t::pRXDroppedCount

8.767.2.2 uint64_t* unpack_wds_GetPacketStatistics_t::pRXOkBytesCount

8.767.2.3 uint64_t* unpack_wds_GetPacketStatistics_t::pRXOKBytesLastCall

8.767.2.4 uint32_t* unpack_wds_GetPacketStatistics_t::pRXPacketErrors

8.767.2.5 uint32_t* unpack_wds_GetPacketStatistics_t::pRXPacketOverflows

8.767.2.6 uint32_t* unpack_wds_GetPacketStatistics_t::pRXPacketSuccesses

8.767.2.7 uint32_t* unpack_wds_GetPacketStatistics_t::pTXDroppedCount

8.767.2.8 uint64_t* unpack_wds_GetPacketStatistics_t::pTXOkBytesCount

8.767.2.9 uint64_t* unpack_wds_GetPacketStatistics_t::pTXOKBytesLastCall

8.767.2.10 uint32_t* unpack_wds_GetPacketStatistics_t::pTXPacketErrors

8.767.2.11 uint32_t* unpack_wds_GetPacketStatistics_t::pTXPacketOverflows

8.767.2.12 uint32_t* unpack_wds_GetPacketStatistics_t::pTXPacketSuccesses

8.768 unpack_wds_GetPacketStatus_t Struct Reference

Data Fields

- uint32_t tXPacketSuccesses
- uint32_t rXPacketSuccesses
- uint32_t tXPacketErrors
- uint32_t rXPacketErrors
- uint32_t tXPacketOverflows
- uint32_t rXPacketOverflows
- uint64_t tXOkBytesCount
- uint64_t rXOkBytesCount
- uint64_t tXOKBytesLastCall
- uint64_t rXOKBytesLastCall
- uint32_t tXDroppedCount
- uint32_t rXDroppedCount

8.768.1 Detailed Description

Returns the packet data transfer statistics since the start of the current packet data.

Parameters

tXPacket-Successes	• No. of packets transmitted without error • 0xffffffff - Invalid data.

rXPacket-Successes	• No. of packets received without error • 0xffffffff - Invalid data.
tXPacketErrors	• No. of outgoing packets with framing errors • 0xffffffff - Invalid data.
rXPacketErrors	• No. of incoming packets with framing errors • 0xffffffff - Invalid data.
txPacket-Overflows	• Number of packets dropped because Tx buffer overflowed • 0xffffffff - Invalid data.
rxPacket-Overflows	• Number of packets dropped because Rx buffer overflowed • 0xffffffff - Invalid data.
txOkBytesCount	• No of bytes transmitted without error. • 0xffffffffffffffff - Invalid data.
rxOkBytesCount	• No of bytes received without error. • 0xffffffffffffffff - Invalid data.
txOKBytesLast-Call	• No of bytes transmitted without error during the last data call (0 if no call was made earlier). Returned only if not in a call, and when the previous call was made using RmNet (for any devices that support • 0xffffffffffffffff - Invalid data.
rxOKBytesLast-Call	• Number of bytes received without error during the last data call (0 if no call was made earlier). Returned only if not in a call, and when the previous call was made using RmNet (for any devices that support • 0xffffffffffffffff - Invalid data.
txDroppedCount	• Number of outgoing packets dropped. • 0xffffffff - Invalid data.
rxDroppedCount	• Number of incoming packets dropped. • 0xffffffff - Invalid data.

8.768.2 Field Documentation

8.768.2.1 uint32_t unpack_wds_GetPacketStatus_t::rXDroppedCount

8.768.2.2 uint64_t unpack_wds_GetPacketStatus_t::rXOkBytesCount

8.768.2.3 uint64_t unpack_wds_GetPacketStatus_t::rXOKBytesLastCall

8.768.2.4 uint32_t unpack_wds_GetPacketStatus_t::rXPacketErrors

8.768.2.5 uint32_t unpack_wds_GetPacketStatus_t::rXPacketOverflows

8.768.2.6 uint32_t unpack_wds_GetPacketStatus_t::rXPacketSuccesses

8.768.2.7 uint32_t unpack_wds_GetPacketStatus_t::tXDroppedCount

8.768.2.8 uint64_t unpack_wds_GetPacketStatus_t::tXOkBytesCount

8.768.2.9 uint64_t unpack_wds_GetPacketStatus_t::tXOKBytesLastCall

8.768.2.10 uint32_t unpack_wds_GetPacketStatus_t::tXPacketErrors

8.768.2.11 uint32_t unpack_wds_GetPacketStatus_t::tXPacketOverflows

8.768.2.12 uint32_t unpack_wds_GetPacketStatus_t::tXPacketSuccesses

8.769 unpack_wds_GetSessionDuration_t Struct Reference

Data Fields

- uint64_t callDuration

8.769.1 Detailed Description

This structure contains unpack get session duration information.

Parameters

callDuration	• Duration of the current packet session in milliseconds

8.769.2 Field Documentation

8.769.2.1 uint64_t unpack_wds_GetSessionDuration_t::callDuration

8.770 unpack_wds_GetSessionState_t Struct Reference

Data Fields

- uint32_t connectionStatus

8.770.1 Detailed Description

This structure contains unpack get session state information.

Parameters

connection-Status	- state of the current packet data session. • 1 - Disconnected. • 2 - Connected. • 3 - Suspended. • 4 - Authenticating.

8.770.2 Field Documentation

8.770.2.1 uint32_t unpack_wds_GetSessionState_t::connectionStatus

8.771 unpack_wds_RMSetTransferStatistics_t Struct Reference

8.771.1 Detailed Description

This structure contains unpack fetch current data system transfer statistics information.

Parameters

NULL	• this is a dummy structure

8.772 unpack_wds_SetMobileIPProfile_t Struct Reference

8.772.1 Detailed Description

This structure contains set mobile IP profile information.

Parameters

NULL	• this is a dummy structure

8.773 unpack_wds_SLQSCreateProfile_t Struct Reference

Data Fields

- PackCreateProfileOut * pCreateProfileOut
- uint8_t * pProfileID
- uint16_t Tlvresult

8.773.1 Detailed Description

This structure contains unpack create profile information.

Parameters

pCreateProfile-Out	• SLQS Create profile Information • See PackCreateProfileOut
pProfileID	• SLQS profile identifier information
TlvresuIt	• TLV present flag, TURE if presented, otherwise FALSE

8.773.2 Field Documentation

8.773.2.1 PackCreateProfileOut* unpack_wds_SLQSCreateProfile_t::pCreateProfileOut

8.773.2.2 uint8_t* unpack_wds_SLQSCreateProfile_t::pProfileID

8.773.2.3 uint16_t unpack_wds_SLQSCreateProfile_t::TlvresuIt

8.774 unpack_wds_SLQSDeleteProfile_t Struct Reference

Data Fields

- uint16_t extendedErrorCode

8.774.1 Detailed Description

This structure contains unpack delete profile information.

Parameters

extendedError-Code[OUT]	• The extended error code received from DS Profile subsystem of type eWDS_ERR_PROFILE_-REG_xxx. • Error code will only will be present if error code eQCWWAN_ERR_QMI_EXTENDED_INTERN-AL is returned by device. • See qm_wds_ds_profile_extended_err_codes enum in qmerrno.h for received error description. • 0xffff - Invalid data.

8.774.2 Field Documentation

8.774.2.1 uint16_t unpack_wds_SLQSDeleteProfile_t::extendedErrorCode

8.775 unpack_wds_SLQSGet3GPPConfigItem_t Struct Reference

Data Fields

- uint16_t LTEAttachProfile
- uint16_t profileList [5]
- uint8_t defaultPDNEnabled

- uint8_t _3gppRelease
- uint16_t LTEAttachProfileList [24]
- uint16_t LTEAttachProfileListLen

8.775.1 Detailed Description

This structure contains unpack get 3GPP configure item information.

Parameters

	LTEAttachProfile	• LTE Attach Profile – points to a single WORD Value indicating the attached LTE Profile – Optional parameter with possible values 1-16 (EM/MC73xx or earlier) • This setting is deprecated on MC/EM74xx • 0xffff - Invalid data.
	profileList	Profile List • an array of 4 profile configurations • Each element points to a single WORD value indicating profile • Optional parameter with possible values – 1 - 16 (MC/EM73xx and before) – 1 - 24 (MC/EM74xx and onwards) • function SLQSGet3GPPConfigItem() returns a default value 255 if no 3gpp configuration is present • 0xffff - Invalid data. • Note: the 5th entry is currently ignored, please set it to zero
out	*defaultPDN-Enabled*	• 0 - disabled • 1 - enabled • 0xff - Invalid data.
out	*_3gppRelease*	3GPP release • 0 - Release_99 • 1 - Release_5 • 2 - Release_6 • 3 - Release_7 • 4 - Release_8 • 5 - Release_9 (In 9x30 and toworads) • 6 - Release_10 (In 9x30 and toworads) • 7 - Release_11 (In 9x30 and toworads) • 0xff - Invalid data.
out	*LTEAttach-ProfileList*	• pointer to WORD array indiciating LTE Attach Profile List – Optional parameter – possible values: 1-24 – This setting is only supported for MC/EM74xx onwards – Please provide attach profiles in order of decreasing priority in this list.

in,out	*LTEAttach-ProfileListLen*	• Number of element in pLTEAttachProfileList – valid range: 1-24 – This setting is only supported for MC/EM74xx onwards • 0xffff - Invalid LTEAttachProfileList data.

8.775.2 Field Documentation

8.775.2.1 uint8_t unpack_wds_SLQSGet3GPPConfigItem_t::_3gppRelease

8.775.2.2 uint8_t unpack_wds_SLQSGet3GPPConfigItem_t::defaultPDNEnabled

8.775.2.3 uint16_t unpack_wds_SLQSGet3GPPConfigItem_t::LTEAttachProfile

8.775.2.4 uint16_t unpack_wds_SLQSGet3GPPConfigItem_t::LTEAttachProfileList[24]

8.775.2.5 uint16_t unpack_wds_SLQSGet3GPPConfigItem_t::LTEAttachProfileListLen

8.775.2.6 uint16_t unpack_wds_SLQSGet3GPPConfigItem_t::profileList[5]

8.776 unpack_wds_SLQSGetCurrDataSystemStat_t Struct Reference

Data Fields

- uint8_t prefNetwork
- uint8_t networkInfoLen
- currNetworkInfo currNetworkInfo [255]

8.776.1 Detailed Description

Data System Status

Parameters

prefNetwork	• Preferred Network • Values: – 0 - 3GPP – 1 - 3GPP2 – 0xff - Invalid data system status.
networkInfoLen	• As input parameter size assigned to next parameter i.e. network information • As output the actual number of network information elements returned by the device
currNetworkInfo	• Network information • See currNetworkInfo for more details

8.776.2 Field Documentation

8.776.2.1 currNetworkInfo unpack_wds_SLQSGetCurrDataSystemStat_t::currNetworkInfo[255]

8.776.2.2 uint8_t unpack_wds_SLQSGetCurrDataSystemStat_t::networkInfoLen

8.776.2.3 uint8_t unpack_wds_SLQSGetCurrDataSystemStat_t::prefNetwork

8.777 unpack_wds_SLQSGetCurrentChannelRate_t Struct Reference

Data Fields

- uint32_t current_channel_tx_rate
- uint32_t current_channel_rx_rate
- uint32_t max_channel_tx_rate
- uint32_t max_channel_rx_rate

8.777.1 Detailed Description

This structure contains unpack get current channel rate information.

Parameters

current_channel-_tx_rate	• Current Channel Tx Rate. • Instantaneous channel Tx rate in bits per second. • In 9x15, this is the total current channel rate for all PDNs combined. • In 9x30 and later, this is the channel rate for a specific PDN.
current_channel-_rx_rate	• Current Channel Rx Rate. • Instantaneous channel Rx rate in bits per second. • In 9x15, this is the total current channel rate for all PDNs combined. • In 9x30 and later, this is the channel rate for a specific PDN
max_channel_-tx_rate	• Max Channel Tx Rate. • Maximum total Tx rate that modem is able to support in current serving system in bits per second. • In 9x15, this is a default hard coded value for the current serving system.
max_channel_-rx_rate	• Max Channel Rx Rate. • Maximum total Rx rate that modem is able to support in current serving system in bits per second. • In 9x15, this is a default hard coded value for the current serving system.

8.777.2 Field Documentation

8.777.2.1 uint32_t unpack_wds_SLQSGetCurrentChannelRate_t::current_channel_rx_rate

8.777.2.2 uint32_t unpack_wds_SLQSGetCurrentChannelRate_t::current_channel_tx_rate

8.777.2.3 uint32_t unpack_wds_SLQSGetCurrentChannelRate_t::max_channel_rx_rate

8.777.2.4 uint32_t unpack_wds_SLQSGetCurrentChannelRate_t::max_channel_tx_rate

8.778 unpack_wds_SLQSGetDataBearerTechnology_t Struct Reference

Data Fields

- uint8_t dataBearerMask
- qmiWDSDataBearerTechnology curDataBearerTechnology
- qmiWDSDataBearerTechnology lastCallDataBearerTechnology

8.778.1 Detailed Description

Structure to hold the data bearer technology values

Parameters

dataBearerMask[OUT]	• This bit mask indicates if data bearer information for the current and/or last call has been received from the device. If a bit is set, then the information is available in the corresponding structure i.e. the one provided by the caller. Refer to liteQmiDataBearerMasks for bit-mask positions. • 0xff - Invalid data.
curDataBearerTechnology[OUT]	• current data bearer technology value. • See qmiWDSDataBearerTechnology – NULL if the parameter is not required
lastCallDataBearerTechnology[OUT]	• last call data bearer technology value. • See qmiWDSDataBearerTechnology – NULL if the parameter is not required

8.778.2 Field Documentation

8.778.2.1 qmiWDSDataBearerTechnology unpack_wds_SLQSGetDataBearerTechnology_t::curDataBearerTechnology

8.778.2.2 uint8_t unpack_wds_SLQSGetDataBearerTechnology_t::dataBearerMask

8.778.2.3 qmiWDSDataBearerTechnology unpack_wds_SLQSGetDataBearerTechnology_t::lastCallDataBearerTechnology

8.779 unpack_wds_SLQSGetDUNCallInfo_t Struct Reference

Data Fields

- connectionStatus connectionStatus
- uint16_t callEndReason

- uint64_t txOKBytesCount
- uint64_t rxOKBytesCount
- uint8_t dormancyStatus
- uint8_t dataBearerTech
- dunchannelRate channelRate
- uint64_t lastCallTXOKBytesCnt
- uint64_t lastCallRXOKBytesCnt
- uint64_t mdmCallDurationActive
- uint8_t lastCallDataBearerTech

8.779.1 Detailed Description

This structure contains the DUN Call Info response parameters

Parameters

connection-Status	• See connectionStatus for more information
callEndReason	• Last modem call end reason • See qaGobiApiTableCallEndReasons.h for Call End Reason • Only valid if the last call made was DUN, else zero is returned • 0xffff - Invalid data.
txOKBytesCount	• Number of bytes transmitted without error • Returned only if a data call is up • 0xffffffffffffffff - Invalid data.
rxOKBytesCount	• Number of bytes received without error • Returned only if a data call is up • 0xffffffffffffffff - Invalid data.
dormancyStatus	• Current traffic channel status • Returned if a data call is up – 0x01 - Traffic channel dormant – 0x02 - Traffic channel active – 0xff - Invalid data.

dataBearerTech	• Current data bearer technology • Returned only if a data call is up – 0x01 - cdma2000 1X – 0x02 - cdma2000 HRPD (1xEV-DO) – 0x03 - GSM – 0x04 - UMTS – 0x05 - cdma200 HRPD (1xEV-DO RevA) – 0x06 - EDGE – 0x07 - HSDPA and WCDMA – 0x08 - WCDMA and HSUPA – 0x09 - HSDPA and HSUPA – 0x0A - LTE – 0x0B - cdma2000 EHRPD – 0x0C - HSDPA+ and WCDMA – 0x0D - HSDPA+ and HSUPA – 0x0E - DC_HSDPA+ and WCDMA – 0x0F - DC_HSDPA+ and HSUPA – 0x10 - HSDPA+ and 64QAM – 0x11 - HSDPA+, 64QAM and HSUPA – 0x12 - TDSCDMA – 0x13 - TDSCDMA and HSDPA – 0xFF - Unknown
channelRate	• See dunchannelRate for more information
lastCallTXOK-BytesCnt	• Number of bytes transmitted without error during the last data call (0 if no call was made). • Return only if not in a call and the previous call was made using DUN. • 0xffffffffffffffff - Invalid data.
lastCallRXOK-BytesCnt	• Number of bytes transmitted without error during the last data call (0 if no call was made). • Return only if not in a call and the previous call was made using DUN. • 0xffffffffffffffff - Invalid data.
mdmCall-DurationActive	• Duration that the call is active in milliseconds • If the modem connection status is connected, this represents the active duration of the current DUN call • If the modem connection status is disconnected, this represents the duration of the last DUN call since the device was powered up (0 if no call has been made or if the last call was not DUN) • 0xffffffffffffffff - Invalid data.

lastCallData-BearerTech	• Last Call Data Bearer Technology • Returned only if not in a call and when the previous call was made using DUN – 0x01 - cdma2000 1X – 0x02 - cdma2000 HRPD (1xEV-DO) – 0x03 - GSM – 0x04 - UMTS – 0x05 - cdma200 HRPD (1xEV-DO Rev A) – 0x06 - EDGE – 0x07 - HSDPA and WCDMA – 0x08 - WCDMA and HSUPA – 0x09 - HSDPA and HSUPA – 0x0A - LTE – 0x0B - cdma2000 EHRPD – 0x0C - HSDPA+ and WCDMA – 0x0D - HSDPA+ and HSUPA – 0x0E - DC_HSDPA+ and WCDMA – 0x0F - DC_HSDPA+ and HSUPA – 0x10 - HSDPA+ and 64QAM – 0x11 - HSDPA+, 64QAM and HSUPA – 0x12 - TDSCDMA – 0x13 - TDSCDMA and HSDPA – 0xFF - Unknown

8.779.2 Field Documentation

8.779.2.1 uint16_t unpack_wds_SLQSGetDUNCallInfo_t::callEndReason

8.779.2.2 dunchannelRate unpack_wds_SLQSGetDUNCallInfo_t::channelRate

8.779.2.3 connectionStatus unpack_wds_SLQSGetDUNCallInfo_t::connectionStatus

8.779.2.4 uint8_t unpack_wds_SLQSGetDUNCallInfo_t::dataBearerTech

8.779.2.5 uint8_t unpack_wds_SLQSGetDUNCallInfo_t::dormancyStatus

8.779.2.6 uint8_t unpack_wds_SLQSGetDUNCallInfo_t::lastCallDataBearerTech

8.779.2.7 uint64_t unpack_wds_SLQSGetDUNCallInfo_t::lastCallRXOKBytesCnt

8.779.2.8 uint64_t unpack_wds_SLQSGetDUNCallInfo_t::lastCallTXOKBytesCnt

8.779.2.9 uint64_t unpack_wds_SLQSGetDUNCallInfo_t::mdmCallDurationActive

8.779.2.10 uint64_t unpack_wds_SLQSGetDUNCallInfo_t::rxOKBytesCount

8.779.2.11 uint64_t unpack_wds_SLQSGetDUNCallInfo_t::txOKBytesCount

8.780 unpack_wds_SLQSGetProfileSettings_t Struct Reference

Data Fields

- UnPackGetProfileSettingOut * pProfileSettings
- uint8_t ProfileType
- uint16_t Tlvresult

8.780.1 Detailed Description

This structure contains the profile setting information of parameter pOutput for API unpack_wds_SLQSGetProfile-Settings

Parameters

pProfileSettings	- Profile Settings
ProfileType	- Profile Type • 0 - Profile 3GPP • 1 - Profile 3GPP2
Tlvresult	- unpack Tlv Result.

8.780.2 Field Documentation

8.780.2.1 UnPackGetProfileSettingOut* unpack_wds_SLQSGetProfileSettings_t::pProfileSettings

8.780.2.2 uint8_t unpack_wds_SLQSGetProfileSettings_t::ProfileType

8.780.2.3 uint16_t unpack_wds_SLQSGetProfileSettings_t::Tlvresult

8.781 unpack_wds_SLQSGetRuntimeSettings_t Struct Reference

Data Fields

- uint32_t IPv4
- uint8_t ProfileName [128]
- uint32_t PDPType
- uint8_t APNName [128]
- uint32_t PrimaryDNSV4
- uint32_t SecondaryDNSV4
- LibPackUMTSQoS UMTSGrantedQoS
- struct wds_GPRSQoS GPRSGrantedQoS
- uint8_t Username [128]
- uint32_t Authentication
- struct wds_ProfileIdentifier ProfileID
- uint32_t GWAddressV4
- uint32_t SubnetMaskV4
- uint8_t PCSCFAddrPCO
- struct wds_PCSCFIPv4ServerAddressList ServerAddrList
- struct wds_PCSCFFQDNAddressList PCSCFFQDNAddrList
- uint16_t PrimaryDNSV6 [8]
- uint16_t SecondaryDNSV6 [8]
- uint32_t Mtu
- struct wds_DomainNameList DomainList
- uint8_t IPFamilyPreference

- uint8_t IMCNflag
- uint16_t Technology
- struct wds_IPV6AddressInfo IPV6AddrInfo
- struct wds_IPV6GWAddressInfo IPV6GWAddrInfo

8.781.1 Detailed Description

This structure contains unpack get runtime settings information.

Parameters

IPv4	ipv4 address • 0xff - Invalid data.
ProfileName	profile name • Invalid data when index 0 of ProfileName is equal 0xff.
PDPType	PDP type • 0xffffffff - Invalid data.
APNName	APN name • Invalid data when index 0 of APNName is equal 0xff.
PrimaryDNSV4	primary dns IPV4 • 0xffffffff - Invalid data.
SecondaryDNS-V4	secondary dns IPV4 • 0xffffffff - Invalid data.
UMTSGranted-QoS	UMTS Granted Qos
GPRSGranted-QoS	GPRS Granted QoS
Username	username for authentication process • Invalid data when index 0 of APNName is equal 0xff.
Authentication	authentication for authentication process • 0xffffffff - Invalid data.
ProfielID	profile ID
GWAddressV4	Gateway IPv4 • 0xffffffff - Invalid data.
SubnetMaskV4	Subnet mask IPV4 • 0xffffffff - Invalid data.
PCSCFAddrPC-O	PCSCF address PCO • 0xff - Invalid data.
ServerAddrList	PCSCF server address list IPV4
PCSCFFQDN-AddrList	PCSCF FQDN address list IPV4
PrimaryDNSV6	Primary DNS IPV6 • invaild when all array data are equal 0xffff

SecondryDNS-V6	Secondry DNS IPV6 • invaild when all array data are equal 0xffff
Mtu	Maximum Transfer Unit • 0xffffffff - Invalid data.
DomainList	domain list
IPFamily-Preference	ip family preference, it could be IPV4 or IPV6 • 0xff - Invalid data.
IMCNflag	IM control flag, value: TRUE or FALSE • 0xff - Invalid data.
Technology	technology on which current packet data session is in progress • Values: – 32767 - CDMA – 32764 - UMTS – 30592 - EPC – 30584 - modem link local – 0xffff - Invalid data.
IPV6AddrInfo	address information IPV6
IPV6GWAddr-Info	gateway address information IPV6

8.781.2 Field Documentation

8.781.2.1 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::APNName[128]

8.781.2.2 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::Authentication

8.781.2.3 struct wds_DomainNameList unpack_wds_SLQSGetRuntimeSettings_t::DomainList

8.781.2.4 struct wds_GPRSQoS unpack_wds_SLQSGetRuntimeSettings_t::GPRSGrantedQoS

8.781.2.5 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::GWAddressV4

8.781.2.6 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::IMCNflag

8.781.2.7 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::IPFamilyPreference

8.781.2.8 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::IPv4

8.781.2.9 struct wds_IPV6AddressInfo unpack_wds_SLQSGetRuntimeSettings_t::IPV6AddrInfo

8.781.2.10 struct wds_IPV6GWAddressInfo unpack_wds_SLQSGetRuntimeSettings_t::IPV6GWAddrInfo

8.781.2.11 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::Mtu

8.781.2.12 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::PCSCFAddrPCO

8.781.2.13 struct wds_PCSCFFQDNAddressList unpack_wds_SLQSGetRuntimeSettings_t::PCSCFFQDNAddrList

8.781.2.14 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::PDPType

8.781.2.15 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::PrimaryDNSV4

8.781.2.16 uint16_t unpack_wds_SLQSGetRuntimeSettings_t::PrimaryDNSV6[8]

8.781.2.17 struct wds_ProfileIdentifier unpack_wds_SLQSGetRuntimeSettings_t::ProfileID

8.781.2.18 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::ProfileName[128]

8.781.2.19 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::SecondaryDNSV4

8.781.2.20 uint16_t unpack_wds_SLQSGetRuntimeSettings_t::SecondaryDNSV6[8]

8.781.2.21 struct wds_PCSCFIPv4ServerAddressList unpack_wds_SLQSGetRuntimeSettings_t::ServerAddrList

8.781.2.22 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::SubnetMaskV4

8.781.2.23 uint16_t unpack_wds_SLQSGetRuntimeSettings_t::Technology

8.781.2.24 LibPackUMTSQoS unpack_wds_SLQSGetRuntimeSettings_t::UMTSGrantedQoS

8.781.2.25 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::Username[128]

8.782 unpack_wds_SLQSModifyProfile_t Struct Reference

Data Fields

- uint16_t * pExtErrorCode

8.782.1 Detailed Description

This structure contains out parameters for unpack_wds_SLQSModifyProfile

Parameters

pExtErrorCode	• The extended error code received from DS Profile subsystem of type eWDS_ERR_PROFILE_-REG_xxx. • Error code will only will be present if error code eQCWWAN_ERR_QMI_EXTENDED_INTERN-AL is returned by device. • See qm_wds_ds_profile_extended_err_codes enum in qmerrno.h for received error description. • NULL pointer - Invalid data.

8.782.2 Field Documentation

8.782.2.1 uint16_t* unpack_wds_SLQSModifyProfile_t::pExtErrorCode

8.783 unpack_wds_SLQSSetIPFamilyPreference_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.783.1 Detailed Description

This structure contains unpack Set IP family preference information

Parameters

Tlvresult	unpack result

8.783.2 Field Documentation

8.783.2.1 uint16_t unpack_wds_SLQSSetIPFamilyPreference_t::Tlvresult

8.784 unpack_wds_SLQSSetPacketSrvStatusCallback_t Struct Reference

Data Fields

- uint8_t conn_status
- uint8_t reconfigReqd
- uint16_t sessionEndReason
- uint16_t verboseSessnEndReasonType
- uint16_t verboseSessnEndReason
- uint8_t ipFamily
- uint16_t techName
- uint8_t bearerID

8.784.1 Detailed Description

This structure contains unpack set packet service status callback information.

Parameters

conn_status	connection status. • Current link status. Values: – 1 - DISCONNECTED – 2 - CONNECTED – 3 - SUSPENDED – 4 - AUTHENTICATING – 0xff Invalid data.
reconfigReqd	Indicates whether the network interface on the host needs to be reconfigured. • Values: – 0 - No need to reconfigure. – 1 - Reconfiguration required. – 0xff - Invalid data.
sessionEnd-Reason	Call End Reason • See qaGobiApiTableCallEndReasons.h for Call End Reason • 0xffff - invalid data.

verboseSessnEndReasonType	Verbose call end reason type • Call end reason type. Values: – 0 - Unspecified – 1 - Mobile IP – 2 - Internal – 3 - Call Manager defined – 6 - 3GPP Specification defined – 7 - PPP – 8 - EHRPD – 9 - IPv6 – 0xffff - invalid data.
verboseSessnEndReason	Reason the call ended (verbose) • See qaGobiApiTableCallEndReasons.h for Call End Reason • 0xffff - invalid data.
ipFamily	IP family of the packet data connection. • Values – 4 - IPv4 – 6 - IPv6 – 0xff - Invalid data.
techName	Technology name of the packet data connection. • Values – 32767 - CDMA – 32764 - UMTS – 30592 - EPC – 30590 - EMBMS – 30584 - Modem Link Local EPC is a logical interface to support LTE/eHRPD handoff. It is returned if the device supports IP session continuity. Modem Link Local is an interface for transferring data between entities on the AP and modem. – 0xffff - Invalid data.
bearerID	• bearer ID (3GPP) or RLP ID (3GPP2) of the packet data connection. • Valid Values - 0 to 16 • 0xFF - Invalid value.

8.784.2 Field Documentation

8.784.2.1 uint8_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::bearerID

8.784.2.2 uint8_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::conn_status

8.784.2.3 uint8_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::ipFamily

8.784.2.4 uint8_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::reconfigReqd

8.784.2.5 uint16_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::sessionEndReason

8.784.2.6 uint16_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::techName

8.784.2.7 uint16_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::verboseSessnEndReason

8.784.2.8 uint16_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::verboseSessnEndReasonType

8.785 unpack_wds_SLQSSetWdsEventCallback_ind_t Struct Reference

Data Fields

- uint8_t xferStatAvail
- uint64_t tx_bytes
- uint64_t rx_bytes
- uint64_t tx_pkts
- uint64_t rx_pkts
- uint8_t mipstatAvail
- uint32_t mipStatus
- uint8_t dBTechAvail
- uint32_t dBTechnology
- uint8_t dormancyStatAvail
- uint32_t dormancyStatus
- uint8_t currDBTechAvail
- uint32_t ratMask
- uint32_t soMask
- uint8_t dataSysStatAvail
- uint8_t prefNetwork
- uint8_t netInfoLen
- wds_currNetworkInfo currNWInfo [255]
- uint8_t dBtechExtAvail
- uint32_t dBtechnologyExt
- uint32_t dBTechExtRatValue
- uint64_t dBTechExtSoMask

8.785.1 Detailed Description

This structure contains unpack set WDS event callback information.

Parameters

xferStatAvail	transfer statistic available
tx_bytes	transmit bytes
rx_bytes	received bytes
tx_pkts	transmit packets
rx_pkts	received packets
mipstatAvail	Mobile IP status available
mipStatus	Mobile IP status
dBTechAvail	Data Bearer technology available
dBTechnology	Data Bearer technology
dormancyStat-Avail	Dormancy status available
dormancyStatus	Dormancy status
currDBTechAvail	Current Data Bearer technology available
ratMask	RAT mask to indicate type of technology
soMask	SO mask to indicate the service type
dataSysStatAvail	Data System Status available

prefNetwork	preferred network
currNWInfo	Current Network Info
dBtechExtAvail	Data bearer technology extended available
dBtechnologyExt	Data bearer technology Extended.
dBTechExtRatValue	Data bearer technology Extended RAT Value
dBTechExtSoMask	Data bearer technology Extended SO Mask

8.785.2 Field Documentation

8.785.2.1 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::currDBTechAvail

8.785.2.2 wds_currNetworkInfo unpack_wds_SLQSSetWdsEventCallback_ind_t::currNWInfo[255]

8.785.2.3 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dataSysStatAvail

8.785.2.4 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBTechAvail

8.785.2.5 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBtechExtAvail

8.785.2.6 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBTechExtRatValue

8.785.2.7 uint64_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBTechExtSoMask

8.785.2.8 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBTechnology

8.785.2.9 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBtechnologyExt

8.785.2.10 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dormancyStatAvail

8.785.2.11 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dormancyStatus

8.785.2.12 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::mipstatAvail

8.785.2.13 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::mipStatus

8.785.2.14 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::netInfoLen

8.785.2.15 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::prefNetwork

8.785.2.16 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::ratMask

8.785.2.17 uint64_t unpack_wds_SLQSSetWdsEventCallback_ind_t::rx_bytes

8.785.2.18 uint64_t unpack_wds_SLQSSetWdsEventCallback_ind_t::rx_pkts

8.785.2.19 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::soMask

8.785.2.20 uint64_t unpack_wds_SLQSSetWdsEventCallback_ind_t::tx_bytes

8.785.2.21 uint64_t unpack_wds_SLQSSetWdsEventCallback_ind_t::tx_pkts

8.785.2.22 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::xferStatAvail

8.786 unpack_wds_SLQSSGetDHCPv4ClientConfig_t Struct Reference

Data Fields

- wdsDhcpv4HwConfig * pHwConfig
- wdsDhcpv4OptionList * pRequestOptionList

8.786.1 Detailed Description

WDS SWI DHCPv4 Config Structure

Parameters

pHWConfig	• pointer to HW Config structure • See wdsDhcpv4HwConfig • NULL pointer - Invalid data.
pRequestOption-List	• pointer to Option List structure to be sent in DHCP request • See wdsDhcpv4OptionList • NULL pointer - Invalid data.

8.786.2 Field Documentation

8.786.2.1 wdsDhcpv4HwConfig* unpack_wds_SLQSSGetDHCPv4ClientConfig_t::pHwConfig

8.786.2.2 wdsDhcpv4OptionList* unpack_wds_SLQSSGetDHCPv4ClientConfig_t::pRequestOptionList

8.787 unpack_wds_SLQSSGetLoopback_t Struct Reference

Data Fields

- uint8_t ByteLoopbackMode
- uint8_t ByteLoopbackMultiplier

8.787.1 Detailed Description

This structure contains unpack Get loopback information.

Parameters

ByteLoopback-Mode	• Loopback Mode. – 0 - Disable – 1 - Enable – 0xff - Invalid data.
ByteLoopback-Multiplier	• Loopback multiplier. Number of downlink bytes to send for each uplink byte. • 0xff - Invalid data.

8.787.2 Field Documentation

8.787.2.1 uint8_t unpack_wds_SLQSSGetLoopback_t::ByteLoopbackMode

8.787.2.2 uint8_t unpack_wds_SLQSSGetLoopback_t::ByteLoopbackMultiplier

8.788 unpack_wds_SLQSStartDataSession_t Struct Reference

Data Fields

- uint32_t * psid
- uint32_t * pFailureReason
- uint32_t * pVerboseFailReasonType
- uint32_t * pVerboseFailureReason

8.788.1 Detailed Description

This structure contains unpack Start Data Session Information.

Parameters

psid	• Assigned session ID when starting a data session
pFailureReason	• Reason data session failed to be established • See qaGobiApiTableCallEndReasons.h for Call End Reason • NULL pointer - Invalid data.
pVerboseFail-ReasonType	• Parameter describing type of verbose failure reason • See qaGobiApiTableCallEndReasons.h for Call End Reason Type • NULL pointer - Invalid data.
pVerboseFailure-Reason	• Verbose reason explaining why call failed. Depends on verbFailReasonType parameter • See qaGobiApiTableCallEndReasons.h for Call End Reason • NULL pointer - Invalid data.

8.788.2 Field Documentation

8.788.2.1 uint32_t* unpack_wds_SLQSStartDataSession_t::pFailureReason

8.788.2.2 uint32_t* unpack_wds_SLQSStartDataSession_t::psid

8.788.2.3 uint32_t* unpack_wds_SLQSStartDataSession_t::pVerboseFailReasonType

8.788.2.4 uint32_t* unpack_wds_SLQSStartDataSession_t::pVerboseFailureReason

8.789 unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t Struct Reference

Data Fields

- uint8_t contextId
- uint8_t bearerId
- int8_t apnName [100]
- uint32_t ipv4Address
- uint32_t ipv4GWAddress
- uint32_t prDNSIPv4Address
- uint32_t seDNSIPv4Address
- ipv6AddressInfo ipv6Address
- ipv6AddressInfo ipv6GWAddress
- uint16_t prDNSIPv6Address [8]
- uint16_t seDNSIPv6Address [8]
- uint32_t prPCSCFIPv4Address
- uint32_t sePCSCFIPv4Address
- uint16_t prPCSCFIPv6Address [8]
- uint16_t sePCSCFIPv6Address [8]

8.789.1 Detailed Description

This structure contains the unpack parameters retrieved by the API unpack_wds_SLQSWdsSwiPDPRuntime-Settings

Parameters

contextId	(optional) • Context Identifier – 0xFF - Not Available
bearerId	(optional) • Bearer Identity • An EPS bearer identity uniquely identifies an EPS bearer for one UE accessing via E-UTRAN. The EPS Bearer Identity is allocated by the MME. – 0xFF - Not Available
apnName	(optional) • APN name associated with the context id – NULL terminated by default.
ipv4Address	(optional) • IPv4 Address – 0xFFFF - Not Available
ipv4GWAddress	(optional) • IPv4 Gateway Address – 0xFFFF - Not Available
prDNSIPv4-Address	(optional) • Primary DNS IPv4 Address – 0xFFFF - Not Available
seDNSIPv4-Address	(optional) • Secondary DNS IPv4 Address – 0xFFFF - Not Available

ipv6Address	(optional) • IPv6 Address • See ipv6AddressInfo for more information
ipv6GWAddress	(optional) • IPv6 Gateway Address • See ipv6AddressInfo for more information
prDNSIPv6-Address	(optional) • Primary IPv6 DNS Address(in network byte order) • This is an 8-element array of 16-bit numbers, each of which is in big-endian format • 0xffffffff - Invalid data.
seDNSIPv6-Address	(optional) • Secondary IPv6 DNS Address(in network byte order) • This is an 8-element array of 16-bit numbers, each of which is in big-endian format • 0xffffffff - Invalid data.
prPCSCFIPv4-Address	(optional) • Primary PCSCF IPv4 Address • 0xffffffff - Invalid data.
sePCSCFIPv4-Address	(optional) • Secondary PCSCF IPv4 Address • 0xffffffff - Invalid data.
prPCSCFIPv6-Address	(optional) • Primary PCSCF IPv6 Address • This is an 8-element array of 16-bit numbers, each of which is in big-endian format • 0xffff - Invalid data.
sePCSCFIPv6-Address	(optional) • Secondary PCSCF IPv6 Address • This is an 8-element array of 16-bit numbers, each of which is in big-endian format • 0xffff - Invalid data.

8.789.2 Field Documentation

8.789.2.1 int8_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::apnName[100]

8.789.2.2 uint8_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::bearerId

8.789.2.3 uint8_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::contextId

8.789.2.4 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::ipv4Address

8.789.2.5 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::ipv4GWAddress

8.789.2.6 ipv6AddressInfo unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::ipv6Address

8.789.2.7 ipv6AddressInfo unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::ipv6GWAddress

8.789.2.8 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::prDNSIPv4Address

8.789.2.9 uint16_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::prDNSIPv6Address[8]

8.789.2.10 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::prPCSCFIPv4Address

8.789.2.11 uint16_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::prPCSCFIPv6Address[8]

8.789.2.12 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::seDNSIPv4Address

8.789.2.13 uint16_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::seDNSIPv6Address[8]

8.789.2.14 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::sePCSCFIPv4Address

8.789.2.15 uint16_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::sePCSCFIPv6Address[8]

8.790 UnPackGetProfileSettingOut Struct Reference

Data Fields

- UnpackQmiProfileInfo curProfile
- uint16_t * pExtErrCode

8.790.1 Detailed Description

This structure contains the profile settings output

Parameters

curProfile	• Structure containing details of the current profile • See UnpackQmiProfileInfo
pExtErrCode	• pointer to a 2 byte extended error code • Error code will only will be present if error code eQCWWAN_ERR_QMI_EXTENDED_INTERNAL is returned by device. • See qm_wds_ds_profile_extended_err_codes enum in qmerrno.h for received error description.

8.790.2 Field Documentation

8.790.2.1 UnpackQmiProfileInfo UnPackGetProfileSettingOut::curProfile

8.790.2.2 uint16_t* UnPackGetProfileSettingOut::pExtErrCode

8.791 UnpackSwiAvmsEventReportBinaryUpdateSessionInfo Struct Reference

Data Fields

- uint8_t bBinaryType
- uint8_t bState
- uint8_t bUserInputRequest

- uint16_t wUserInputTimeout
- uint32_t ulPkgDownloadSize
- uint32_t ulPkgDownloadComplete
- uint16_t wUpdateCompeteStatus
- uint8_t bSerity
- uint16_t wVersionLength
- uint8_t szVersion [128]
- uint16_t wNameLength
- uint8_t szName [128]
- uint16_t wDescriptionLength
- uint8_t szDescription [1024]
- uint8_t TlvPresent

8.791.1 Detailed Description

This structure contains unpack event report binary update session information parameters.

Parameters

bBinaryType	: Type • 1 - Firmware. • 2 - User App. • 3 - Legato Framework.
bStat	: State • 0x01 - No binary update available. • 0x02 - Query binary Download. • 0x03 - Binary Downloading. • 0x04 - Binary downloaded. • 0x05 -Query Binary Update. • 0x06 - Binary updating. • 0x07 - Binary updated.
bUserInput-Request	Bit mask of available user inputs. • 0x00 - No user input required. Informational indication. • 0x01 - Accept. • 0x02 - Reject.
wUserInput-Timeout	Timeout for user input in minutes. A value of 0 means no time-out.
ulPkgDownload-Size	The size (in bytes) of the update package
ulPkgDownload-Complete	The number of bytes being downloaded. For downloading state, this value shall be $>$ 0 and incremented toward the pkg_dload_size. For other states, the value shall be 0 as it is meaningless.
wUpdate-CompeteStatus	Result code.This field should be looked at only when the AVMS session is complete.
bSerity	Serity. • 0x01 - Mandatory. • 0x02 - Optional.
wVersionLength	Length of FW Version string in bytes.
szVersion	FW Version string in ASCII.
wNameLength	Length Package Name string in bytes.
szName	Package Name in UCS2.

wDescription-Length	Length of description in bytes.
szDescription	Description of Update Package in USC2.
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.791.2 Field Documentation

8.791.2.1 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::bBinaryType

8.791.2.2 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::bSerity

8.791.2.3 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::bState

8.791.2.4 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::bUserInputRequest

8.791.2.5 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::szDescription[1024]

8.791.2.6 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::szName[128]

8.791.2.7 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::szVersion[128]

8.791.2.8 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::TlvPresent

8.791.2.9 uint32_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::ulPkgDownloadComplete

8.791.2.10 uint32_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::ulPkgDownloadSize

8.791.2.11 uint16_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::wDescriptionLength

8.791.2.12 uint16_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::wNameLength

8.791.2.13 uint16_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::wUpdateCompeteStatus

8.791.2.14 uint16_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::wUserInputTimeout

8.791.2.15 uint16_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::wVersionLength

8.792 UnpackSwiAvmsEventReportConfig Struct Reference

Data Fields

- uint8_t bState
- uint8_t bUserInputRequest
- uint16_t wUserInputTimeout
- uint16_t wAlertMsgLength
- uint8_t szAlertMsg [200]
- uint8_t TlvPresent

8.792.1 Detailed Description

This structure contains unpack event report configure parameters.

Parameters

bState	State. • 0x01 - AVMS Read Request. • 0x02 - AVMS Change Request. • 0x03 - AVMS Config Complete.
bUserInput-Request	Bit mask of available user inputs. • 0x00 - No user input required. Informational indication. • 0x01 - Accept. • 0x02 - Reject.
wUserInput-Timeout	Timeout for user input in seconds. A value of 0 means no time-out
wAlertMsg-Length	Length of Alert message string in bytes.
szAlertMsg	Alert message in UCS2.
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.792.2 Field Documentation

8.792.2.1 uint8_t UnpackSwiAvmsEventReportConfig::bState

8.792.2.2 uint8_t UnpackSwiAvmsEventReportConfig::bUserInputRequest

8.792.2.3 uint8_t UnpackSwiAvmsEventReportConfig::szAlertMsg[200]

8.792.2.4 uint8_t UnpackSwiAvmsEventReportConfig::TlvPresent

8.792.2.5 uint16_t UnpackSwiAvmsEventReportConfig::wAlertMsgLength

8.792.2.6 uint16_t UnpackSwiAvmsEventReportConfig::wUserInputTimeout

8.793 UnpackSwiAvmsEventReportConnectionRequest Struct Reference

Data Fields

- uint8_t bUserInputRequest
- uint16_t wUserInputTimeout
- uint8_t TlvPresent

8.793.1 Detailed Description

This structure contains unpack event report connection request parameters.

Parameters

bUserInput-Request	Bit mask of available user inputs. • 0x00 - No user input required. Informational indication. • 0x01 - Accept. • 0x02 - Reject.
bUserInput-Request	Timeout for user input in minutes. A value of 0 means no time-out.
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.793.2 Field Documentation

8.793.2.1 uint8_t UnpackSwiAvmsEventReportConnectionRequest::bUserInputRequest

8.793.2.2 uint8_t UnpackSwiAvmsEventReportConnectionRequest::TlvPresent

8.793.2.3 uint16_t UnpackSwiAvmsEventReportConnectionRequest::wUserInputTimeout

8.794 UnpackSwiAvmsEventReportDataSessionStatus Struct Reference

Data Fields

- uint8_t bType
- uint16_t wErrorCode
- uint8_t TlvPresent

8.794.1 Detailed Description

This structure contains unpack evnet report data session status parameters.

Parameters

bType	Notification type. • 0: Data session closed. • 1: Data session activated. • 2: Register made. -3: Data session error.
wErrorCode	LWM2M Session error code. • 0x0000: none
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.794.2 Field Documentation

8.794.2.1 uint8_t UnpackSwiAvmsEventReportDataSessionStatus::bType

8.794.2.2 uint8_t UnpackSwiAvmsEventReportDataSessionStatus::TlvPresent

8.794.2.3 uint16_t UnpackSwiAvmsEventReportDataSessionStatus::wErrorCode

8.795 UnpackSwiAvmsEventReportHTTPStatus Struct Reference

Data Fields

- uint16_t wHTTPStatus
- uint8_t TlvPresent

8.795.1 Detailed Description

This structure contains unpack event report HTTP status parameters.

Parameters

wHTTPStatus	See RFC 7231. • 100 - Continue • 101 - Switching Protocols • 200 - OK • 201 - Created • 202 - Accepted • 203 - Non-Authoritative Information • 204 - No Content • 205 - Reset Content • 206 - Partial Content • 300 - Multiple Choices • 301 - Moved Permanently • 302 - Found • 303 - See Other • 304 - Not Modified • 305 - Use Proxy • 307 - Temporary Redirect • 400 - Bad Request • 401 - Unauthorized • 402 - Payment Required • 403 - Forbidden • 404 - Not Found • 405 - Method Not Allowed • 406 - Not Acceptable • 407 - Proxy Authentication Required • 408 - Request Timeout • 409 - Conflict • 410 - Gone • 411 - Length Required • 412 - Precondition Failed • 413 - Payload Too Large • 414 - URI Too Long • 415 - Unsupported Media Type • 416 - Range Not Satisfiable • 417 - Expectation Failed • 426 - Upgrade Required • 500 - Internal Server Error • 501 - Not Implemented • 502 - Bad Gateway • 503 - Service Unavailable • 504 - Gateway Timeout • 505 - HTTP Version Not Supported
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.795.2 Field Documentation

8.795.2.1 uint8_t UnpackSwiAvmsEventReportHTTPStatus::TlvPresent

8.795.2.2 uint16_t UnpackSwiAvmsEventReportHTTPStatus::wHTTPStatus

8.796 UnpackSwiAvmsEventReportNotification Struct Reference

Data Fields

- uint8_t bNotification
- uint16_t wSessionStatus
- uint8_t TlvPresent

8.796.1 Detailed Description

This structure contains unpack event report notification parameters.

Parameters

bNotification	Notification. • 0x14 - Module starts sending data to server. • 0x15 - Authentication with the server. • 0x16 - session with the server is ended.
wSessionStatus	This field will set to the session status for notifications that occur at the end of a session, zero for all other notifications. • 0x0000: Successful: Session succeeded • 0x0001: Break: Session succeeded • 0x0002: Large Object Handled: Session succeeded • 0x0003: No status: Session succeeded • 0x0004: No more commands: Session succeeded • 0x0005: User cancel: Session cancelled • 0x0100-0x01FF: General errors • 0x0200-0x02FF: Syncml errors • 0x0300-0x03FF: Authentication errors • 0x0400-0x04FF: Protocol errors • 0x0500-0x05FF: Tree errors (DM Only) • 0x0600-0x06FF: Not applicable • 0x0700-0x07FF: Trigger errors • 0x0800-0x08FF: FUMO errors • 0x0900-0x09FF: Communication errors • 0x0A00-0x0AFF: Parsing errors • 0x0B00-0x0CFF: Not applicable • 0x7F00-0x7F12:Insignia errors • 0x7F13: Illegal text: Text received contains illegal characters • 0x7F14: Download failure: Failed to download FOTA image • 0x7F15: Empty session: Session ran successfully, but no information wasa updated • 0x7F16: Factory reset successful: Factory reset succeeded • 0x7F17: Factory reset fail: Factory reset failed
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.796.2 Field Documentation

8.796.2.1 uint8_t UnpackSwiAvmsEventReportNotification::bNotification

8.796.2.2 uint8_t UnpackSwiAvmsEventReportNotification::TlvPresent

8.796.2.3 uint16_t UnpackSwiAvmsEventReportNotification::wSessionStatus

8.797 UnpackSwiAvmsEventReportPackageID Struct Reference

Data Fields

- uint8_t bPackageID
- uint8_t TlvPresent

8.797.1 Detailed Description

This structure contains unpack event report package ID parameters.

Parameters

bPackageID	Package ID of the application binary that this AVMS_EVENT_ID notification is for.
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.797.2 Field Documentation

8.797.2.1 uint8_t UnpackSwiAvmsEventReportPackageID::bPackageID

8.797.2.2 uint8_t UnpackSwiAvmsEventReportPackageID::TlvPresent

8.798 UnpackSwiAvmsEventReportRegStatus Struct Reference

Data Fields

- uint8_t bRegStatus
- uint8_t TlvPresent

8.798.1 Detailed Description

This structure contains unpack event report registration status parameters.

Parameters

bRegStatus	LWM2M Registration status. • 0: Need Bootstrap. • 1: Bootstrap made. • 2: Register made. -3: Update made.
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.798.2 Field Documentation

8.798.2.1 uint8_t UnpackSwiAvmsEventReportRegStatus::bRegStatus

8.798.2.2 uint8_t UnpackSwiAvmsEventReportRegStatus::TlvPresent

8.799 UnpackSwiAvmsEventReportSessionType Struct Reference

Data Fields

- uint8_t bType
- uint8_t TlvPresent

8.799.1 Detailed Description

This structure contains unpack event report session type parameters.

Parameters

bType	Session Type. • 0: Bootstrap session. • 1. DM session
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.799.2 Field Documentation

8.799.2.1 uint8_t UnpackSwiAvmsEventReportSessionType::bType

8.799.2.2 uint8_t UnpackSwiAvmsEventReportSessionType::TlvPresent

8.800 UnpackSwiAvmsEventReportWAMSParamChange Struct Reference

Data Fields

- uint16_t wWamsChangeMask
- uint8_t TlvPresent

8.800.1 Detailed Description

This structure contains unpack event report WAMS parameter change parameters.

Parameters

wWamsChange-Mask	Mask of WAMS parameters changed. • By default set to 0xFF for all changes. • 0x01 - device_login • 0x02 - device_MD5_key • 0x04 - server_login • 0x08 - server_MD5_key • 0x10 - server_URL • 0x20 - Nonce • 0x40 - Application key
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.800.2 Field Documentation

8.800.2.1 uint8_t UnpackSwiAvmsEventReportWAMSParamChange::TlvPresent

8.800.2.2 uint16_t UnpackSwiAvmsEventReportWAMSParamChange::wWamsChangeMask

8.801 unpackWdsProfileParam Union Reference

Data Fields

- LibpackProfile3GPP SlqsProfile3GPP
- LibpackProfile3GPP2 SlqsProfile3GPP2

8.801.1 Detailed Description

This union WdsProfileParam consists of Profile3GPP and Profile3GPP2 out of which one will be used to create profile.

Parameters

SlqsProfile3GPP	3GPP profile • See LibpackProfile3GPP
SlqsProfile3GP-P2	3GPP2 profile • See LibpackProfile3GPP2

8.801.2 Field Documentation

8.801.2.1 LibpackProfile3GPP unpackWdsProfileParam::SlqsProfile3GPP

8.801.2.2 LibpackProfile3GPP2 unpackWdsProfileParam::SlqsProfile3GPP2

8.802 voice_airTimer Struct Reference

Data Fields

- uint8_t namID
- uint32_t airTimerValue

8.802.1 Detailed Description

This structure contains information about the Air Timer.

Parameters

namID	• Index of the NAM(Number Assignment Module) to be configured. • Range 0 to 3. • Some modems support only 1 or 2 NAMs. • 0xFF,if not available.

airTimerValue	• Time in minutes. • Cumulative air time is slammed. • 0xFFFFFFFF,if not available.

8.802.2 Field Documentation

8.802.2.1 uint32_t voice_airTimer::airTimerValue

8.802.2.2 uint8_t voice_airTimer::namID

8.803 voice_allCallsAlphaIDInfo Struct Reference

Data Fields

- uint8_t callID
- voice_alphaIDInfo AlphaIDInfo

8.803.1 Detailed Description

This structure contains information for Alpha Identifier for All Calls

Parameters

callID	• Unique call identifier for the call.
AlphaIDInfo	• See voice_alphaIDInfo for more information.

8.803.2 Field Documentation

8.803.2.1 voice_alphaIDInfo voice_allCallsAlphaIDInfo::AlphaIDInfo

8.803.2.2 uint8_t voice_allCallsAlphaIDInfo::callID

8.804 voice_allCallsDiagInfo Struct Reference

Data Fields

- uint8_t callID
- voice_diagInfo DiagInfo

8.804.1 Detailed Description

This structure contains Diagnostic Information for All Calls

Parameters

callID	• Unique call identifier for the call.
DiagInfo	• See voice_diagInfo for more information.

8.804.2 Field Documentation

8.804.2.1 uint8_t voice_allCallsDiagInfo::callID

8.804.2.2 voice_diagInfo voice_allCallsDiagInfo::DiagInfo

8.805 voice_allCallsUUSInfo Struct Reference

Data Fields

- uint8_t callID
- voice_UUSInfo uusInfo

8.805.1 Detailed Description

This structure contains information for User to User Signaling Service for All Calls.

Parameters

callID	• Unique call identifier for the call.
uusInfo	• See voice_UUSInfo for more information.

8.805.2 Field Documentation

8.805.2.1 uint8_t voice_allCallsUUSInfo::callID

8.805.2.2 voice_UUSInfo voice_allCallsUUSInfo::uusInfo

8.806 voice_alphaIDInfo Struct Reference

Data Fields

- uint8_t alphaDcs
- uint8_t alphaLen
- uint8_t alphaText [255]

8.806.1 Detailed Description

This structure contains information about the Alpha Identifier.

Parameters

alphaDcs	• Alpha coding scheme – 0x01 - GSM Default_Char – 0x02 - UCS2 – 0xFF - Not Available
alphaLen	• Number of sets of the following elements: – pAlpha_text • If zero(0) then no further information exists.
alphaText[MAX_VOICE_DESCRIPTION_LENGTH]	• Data encoded as per the alpha_dcs

8.806.2 Field Documentation

8.806.2.1 uint8_t voice_alphaIDInfo::alphaDcs

8.806.2.2 uint8_t voice_alphaIDInfo::alphaLen

8.806.2.3 uint8_t voice_alphaIDInfo::alphaText[255]

8.807 voice_arrAlertingPattern Struct Reference

Data Fields

- uint8_t numInstances
- uint8_t callID [20]
- uint32_t alertingPattern [20]

8.807.1 Detailed Description

This structure contains an array of Alerting Pattern.

Parameters

numInstances	• Number of callID, alertingPattern that follow. • If zero(0) then no further information exists.
callID[VOICE_MAX_NO_OF_CALLS]	• Array of Unique call identifier for the call.
alertingPattern[VOICE_MAX_NO_OF_CALLS]	• Array of Alerting pattern. – 0x00 - QMI_VOICE_ALERTING_PATTERN_1 - Pattern 1 – 0x01 - QMI_VOICE_ALERTING_PATTERN_2 - Pattern 2 – 0x02 - QMI_VOICE_ALERTING_PATTERN_3 - Pattern 3 – 0x04 - QMI_VOICE_ALERTING_PATTERN_5 - Pattern 5 – 0x05 - QMI_VOICE_ALERTING_PATTERN_6 - Pattern 6 – 0x06 - QMI_VOICE_ALERTING_PATTERN_7 - Pattern 7 – 0x07 - QMI_VOICE_ALERTING_PATTERN_8 - Pattern 8 – 0x08 - QMI_VOICE_ALERTING_PATTERN_9 - Pattern 9

8.807.2 Field Documentation

8.807.2.1 uint32_t voice_arrAlertingPattern::alertingPattern[20]

8.807.2.2 uint8_t voice_arrAlertingPattern::callID[20]

8.807.2.3 uint8_t voice_arrAlertingPattern::numInstances

8.808 voice_arrAlertingType Struct Reference

Data Fields

- uint8_t numInstances
- uint8_t callID [20]
- uint8_t AlertingType [20]

8.808.1 Detailed Description

This structure contains an array of Alerting Type.

Parameters

numInstances	• Number of callID, AlertingType that follow. • If zero(0) then no further information exists.
callID[VOICE_MAX_NO_OF_CALLS]	• Array of Unique call identifier for the call.

AlertingType[VOICE_MAX_NO_OF_CALLS]	• Array of Alerting type. – 0x00 - ALERTING_LOCAL - Local – 0x01 - ALERTING_REMOTE - Remote

8.808.2 Field Documentation

8.808.2.1 uint8_t voice_arrAlertingType::AlertingType[20]

8.808.2.2 uint8_t voice_arrAlertingType::callID[20]

8.808.2.3 uint8_t voice_arrAlertingType::numInstances

8.809 voice_arrAlphaID Struct Reference

Data Fields

- uint8_t numInstances
- voice_allCallsAlphaIDInfo allCallsAlphaIDInfoArr [20]

8.809.1 Detailed Description

This structure contains an array of Alpha ID Info

Parameters

numInstances	• Number of allCallsAlphaIDInfo that follow. • If zero(0) then no further information exists.
allCallsAlphaIDInfo[VOICE_MAX_NO_OF_CALLS]	• Array of allCallsAlphaIDInfo. • See voice_allCallsAlphaIDInfo for more information.

8.809.2 Field Documentation

8.809.2.1 voice_allCallsAlphaIDInfo voice_arrAlphaID::allCallsAlphaIDInfoArr[20]

8.809.2.2 uint8_t voice_arrAlphaID::numInstances

8.810 voice_arrCalledPartyNum Struct Reference

Data Fields

- uint8_t numInstances
- voice_peerNumberInfo CalledPartyNum [20]

8.810.1 Detailed Description

This structure contains an array of Called Party Numbers consisting of information of all the numbers which have been called from the device.

Parameters

numInstances	• Number of calledPartyNum that follow. • If zero(0) then no further information exists.
CalledPartyNum[VOICE_MAX_NO_OF_CALLS]	• Array of CalledPartyNum. • See voice_peerNumberInfo for more information.

8.810.2 Field Documentation

8.810.2.1 voice_peerNumberInfo voice_arrCalledPartyNum::CalledPartyNum[20]

8.810.2.2 uint8_t voice_arrCalledPartyNum::numInstances

8.811 voice_arrCallEndReason Struct Reference

Data Fields

- uint8_t numInstances
- uint8_t callID [20]
- uint16_t callEndReason [20]

8.811.1 Detailed Description

This structure contains an array of Call End Reasons.

Parameters

numInstances	• Number of callID, callEndReason that follow. • If zero(0) then no further information exists.
callID[VOICE_MAX_NO_OF_CALLS]	• Array of Unique call identifier for the call.
callEndReason[VOICE_MAX_NO_OF_CALLS]	• Array of Call End Reason . • See Table9 qaGobiApiTableVoiceCallEndReasons.h for a list of valid voice-related call end reasons

8.811.2 Field Documentation

8.811.2.1 uint16_t voice_arrCallEndReason::callEndReason[20]

8.811.2.2 uint8_t voice_arrCallEndReason::callID[20]

8.811.2.3 uint8_t voice_arrCallEndReason::numInstances

8.812 voice_arrCallInfo Struct Reference

Data Fields

- uint8_t numInstances
- voice_getAllCallInformation getAllCallInfo [20]

8.812.1 Detailed Description

This structure contains an array of Call Info

Parameters

numInstances	• Number of getAllCallInfo that follow. • If zero(0) then no further information exists.
getAllCallInfo[VOICE_MAX_NO_OF_CALLS]	• Array of CallInfo. • See voice_getAllCallInformation for more information.

8.812.2 Field Documentation

8.812.2.1 voice_getAllCallInformation voice_arrCallInfo::getAllCallInfo[20]

8.812.2.2 uint8_t voice_arrCallInfo::numInstances

8.813 voice_arrConnectPartyNum Struct Reference

Data Fields

- uint8_t numInstances
- voice_peerNumberInfo ConnectedPartyNum [20]

8.813.1 Detailed Description

This structure contains an array of Connected Party Numbers consisting of information regarding all the devices connected.

Parameters

numInstances	• Number of ConnectedPartyNum that follow. • If zero(0) then no further information exists.
ConnectedPartyNum[VOICE_MAX_NO_OF_CALLS]	• Array of ConnectedPartyNum. • See voice_peerNumberInfo for more information.

8.813.2 Field Documentation

8.813.2.1 voice_peerNumberInfo voice_arrConnectPartyNum::ConnectedPartyNum[20]

8.813.2.2 uint8_t voice_arrConnectPartyNum::numInstances

8.814 voice_arrDiagInfo Struct Reference

Data Fields

- uint8_t numInstances
- voice_allCallsDiagInfo DiagInfo [20]

8.814.1 Detailed Description

This structure contains an array of Diagnostic Information.

Parameters

numInstances	• Number of DiagInfo that follow. • If zero(0) then no further information exists.
DiagInfo[VOICE-_MAX_NO_OF-_CALLS]	• Array of DiagInfo. • See voice_allCallsDiagInfo for more information.

8.814.2 Field Documentation

8.814.2.1 voice_allCallsDiagInfo voice_arrDiagInfo::DiagInfo[20]

8.814.2.2 uint8_t voice_arrDiagInfo::numInstances

8.815 voice_arrRedirPartyNum Struct Reference

Data Fields

- uint8_t numInstances
- voice_peerNumberInfo RedirPartyNum [20]

8.815.1 Detailed Description

This structure contains an array of Redirecting Party Numbers consisting of information of all the numbers which have been redirected from the device.

Parameters

numInstances	• Number of redirPartyNum that follow. • If zero(0) then no further information exists.

RedirPartyNum[VOICE_MAX_NO_OF_CALLS]	• Array of RedirPartyNum. • See voice_peerNumberInfo for more information.

8.815.2 Field Documentation

8.815.2.1 uint8_t voice_arrRedirPartyNum::numInstances

8.815.2.2 voice_peerNumberInfo voice_arrRedirPartyNum::RedirPartyNum[20]

8.816 voice_arrRemotePartyName Struct Reference

Data Fields

- uint8_t numInstances
- voice_getAllCallRmtPtyName GetAllCallRmtPtyName [20]

8.816.1 Detailed Description

This structure contains an array of Remote Party Names

Parameters

numInstances	• Number of remotePartyName that follow. • If zero(0) then no further information exists.
GetAllCallRmtPtyName[MAX_NO_OF_CALLS]	• Array of remotePartyName. • See voice_getAllCallRmtPtyName for more information.

8.816.2 Field Documentation

8.816.2.1 voice_getAllCallRmtPtyName voice_arrRemotePartyName::GetAllCallRmtPtyName[20]

8.816.2.2 uint8_t voice_arrRemotePartyName::numInstances

8.817 voice_arrRemotePartyNum Struct Reference

Data Fields

- uint8_t numInstances
- voice_getAllCallRmtPtyNum RmtPtyNum [20]

8.817.1 Detailed Description

This structure contains an array of Remote Party Numbers

Parameters

numInstances	• Number of remotePartyNum that follow. • If zero(0) then no further information exists.
RmtPtyNum[VOICE_MAX_NO_OF_CALLS]	• Array of remotePartyNum. • See voice_getAllCallRmtPtyNum for more information.

8.817.2 Field Documentation

8.817.2.1 uint8_t voice_arrRemotePartyNum::numInstances

8.817.2.2 voice_getAllCallRmtPtyNum voice_arrRemotePartyNum::RmtPtyNum[20]

8.818 voice_arrSvcOption Struct Reference

Data Fields

- uint8_t numInstances
- uint8_t callID [20]
- uint16_t srvOption [20]

8.818.1 Detailed Description

This structure contains array an of Servicing option.

Parameters

numInstances	• Number of callID, srvOption that follow. • If zero(0) then no further information exists.
callID[VOICE_MAX_NO_OF_CALLS]	• Array of Unique call identifier for the call.
srvOption[VOICE_MAX_NO_OF_CALLS]	• Array of Service option. • See Table9 qaGobiApiTableServiceOptions.h for standard service option number assignments.

8.818.2 Field Documentation

8.818.2.1 uint8_t voice_arrSvcOption::callID[20]

8.818.2.2 uint8_t voice_arrSvcOption::numInstances

8.818.2.3 uint16_t voice_arrSvcOption::srvOption[20]

8.819 voice_arrUUSInfo Struct Reference

Data Fields

- uint8_t numInstances
- voice_allCallsUUSInfo AllCallsUUSInfo [20]

8.819.1 Detailed Description

This structure contains an array of User to User Signaling Service Information

Parameters

numInstances	• Number of allCallsUUSInfo that follow. • If zero(0) then no further information exists.
AllCallsUUSInfo[VOICE_MAX_NO_OF_CALLS]	• Array of allCallsUUSInfo. • See voice_allCallsUUSInfo for more information.

8.819.2 Field Documentation

8.819.2.1 voice_allCallsUUSInfo voice_arrUUSInfo::AllCallsUUSInfo[20]

8.819.2.2 uint8_t voice_arrUUSInfo::numInstances

8.820 voice_burstDTMFInfo Struct Reference

Data Fields

- uint8_t * pCallID
- uint8_t digitCnt
- uint8_t pDigitBuff [255]

8.820.1 Detailed Description

This structure contains Voice Burst DTMF Information

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. A burst DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device • NULL pointer - Invalid data.
digitCnt	• Length of DTMF digit buffer which follows
pDigitBuff[MAX_VOICE_DESCRIPTION_LENGTH]	• DTMF digit buffer in ASCII, NULL terminated

8.820.2 Field Documentation

8.820.2.1 uint8_t voice_burstDTMFInfo::digitCnt

8.820.2.2 uint8_t* voice_burstDTMFInfo::pCallID

8.820.2.3 uint8_t voice_burstDTMFInfo::pDigitBuff[255]

8.821 voice_calledPartySubAdd Struct Reference

Data Fields

- uint8_t extBit
- uint8_t subAddrType
- uint8_t oddEvenInd
- uint8_t subAddrLen
- uint8_t subAddr [255]

8.821.1 Detailed Description

This structure contains information about the Called Sub Party Addresses.

Parameters

extBit	• Extension bit.
subAddrType	• Subaddress type. – 0x00 - NSAP – 0x01 - USER
oddEvenInd	• Even/odd indicator. – 0x00 - Even number of address signals – 0x01 - Odd number of address signals
subAddrLen	• Number of sets of the following elements: – SubAddress
subAddr[MAX_VOICE_DESCRIPTION_LENGTH]	• Array of the SubAddress in BCD number format.

8.821.2 Field Documentation

8.821.2.1 uint8_t voice_calledPartySubAdd::extBit

8.821.2.2 uint8_t voice_calledPartySubAdd::oddEvenInd

8.821.2.3 uint8_t voice_calledPartySubAdd::subAddr[255]

8.821.2.4 uint8_t voice_calledPartySubAdd::subAddrLen

8.821.2.5 uint8_t voice_calledPartySubAdd::subAddrType

8.822 voice_callFwdTypeAndPlan Struct Reference

Data Fields

- uint8_t numberType
- uint8_t numberPlan

8.822.1 Detailed Description

This structure contains Supplementary Service request parameters related to different features and their activation, deactivation, registration and erasure (applicable only for 3GPP)

Parameters

numberType	• Call forwarding number type – 0x00 - QMI_VOICE_NUM_TYPE_UNKNOWN Unknown – 0x01 - QMI_VOICE_NUM_TYPE_INTERNATIONAL International – 0x02 - QMI_VOICE_NUM_TYPE_NATIONAL National – 0x03 - QMI_VOICE_NUM_TYPE_NETWORK_SPECIFIC Network-specific – 0x04 - QMI_VOICE_NUM_TYPE_SUBSCRIBER Subscriber – 0x05 - QMI_VOICE_NUM_TYPE_RESERVED Reserved – 0x06 - QMI_VOICE_NUM_TYPE_ABBREVIATED Abbreviated – 0x07 - QMI_VOICE_NUM_TYPE_RESERVED_EXTENSION Reserved extension
numberPlan	• Call forwarding number plan – 0x00 - QMI_VOICE_NUM_PLAN_UNKNOWN Unknown – 0x01 - QMI_VOICE_NUM_PLAN_ISDN ISDN – 0x03 - QMI_VOICE_NUM_PLAN_DATA Data – 0x04 - QMI_VOICE_NUM_PLAN_TELEX Telex – 0x08 - QMI_VOICE_NUM_PLAN_NATIONAL National – 0x09 - QMI_VOICE_NUM_PLAN_PRIVATE Private – 0x0B - QMI_VOICE_NUM_PLAN_RESERVED_CTS Reserved cordless telephony system – 0x0F - QMI_VOICE_NUM_PLAN_RESERVED_EXTENSION Reserved extension

8.822.2 Field Documentation

8.822.2.1 uint8_t voice_callFwdTypeAndPlan::numberPlan

8.822.2.2 uint8_t voice_callFwdTypeAndPlan::numberType

8.823 voice_callFWExtInfo Struct Reference

Data Fields

- uint8_t SvcStatus

- uint8_t SvcClass
- uint8_t noReplyTimer
- uint8_t PI
- uint8_t SI
- uint8_t numType
- uint8_t numPlan
- uint8_t numLen
- uint8_t number [255]

8.823.1 Detailed Description

This structure contains information for Get Call Forwarding Extended Information.

Parameters

SvcStatus	• Service status. Values: – 0x00 - SERVICE_STATUS_INACTIVE - Inactive – 0x01 - SERVICE_STATUS_ACTIVE - Active
SvcClass	• Service Class is a combination (sum) of information class constants • See qaGobiApiTableSupServiceInfoClasses.h for service classes.
noReplyTimer	• No reply timer value in seconds • A value of 0 indicates that no_reply_timer is ignored.
PI	• Presentation indicator; refer to [S1, Table 2.7.4.4-1] for valid values.
SI	• Number screening indicator. • Values: – 0x00 - QMI_VOICE_SI_USER_PROVIDED_NOT_SCREENED - Provided user is not screened – 0x01 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_PASSED - Provided user passed verification – 0x02 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_FAILED - Provided user failed verification – 0x03 - QMI_VOICE_SI_NETWORK_PROVIDED - Provided network
numType	• Number type. • Values: – 0x00 - QMI_VOICE_NUM_TYPE_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_TYPE_INTERNATIONAL - International – 0x02 - QMI_VOICE_NUM_TYPE_NATIONAL - National – 0x03 - QMI_VOICE_NUM_TYPE_NETWORK_SPECIFIC - Network-specific – 0x04 - QMI_VOICE_NUM_TYPE_SUBSCRIBER - Subscriber – 0x05 - QMI_VOICE_NUM_TYPE_RESERVED - Reserved – 0x06 - QMI_VOICE_NUM_TYPE_ABBREVIATED - Abbreviated – 0x07 - QMI_VOICE_NUM_TYPE_RESERVED_EXTENSION - Reserved extension

numPlan	• Number plan. • Values: – 0x00 - QMI_VOICE_NUM_PLAN_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_PLAN_ISDN - ISDN – 0x03 - QMI_VOICE_NUM_PLAN_DATA - Data – 0x04 - QMI_VOICE_NUM_PLAN_TELEX - Telex – 0x08 - QMI_VOICE_NUM_PLAN_NATIONAL - National – 0x09 - QMI_VOICE_NUM_PLAN_PRIVATE - Private – 0x0B - QMI_VOICE_NUM_PLAN_RESERVED_CTS - Reserved cordless telephony system – 0x0F - QMI_VOICE_NUM_PLAN_RESERVED_EXTENSION - Reserved extension
numLen	• Provides the length of number which follow.
number[255]	• number of numLen length, NULL terminated.

8.823.2 Field Documentation

8.823.2.1 uint8_t voice_callFWExtInfo::noReplyTimer

8.823.2.2 uint8_t voice_callFWExtInfo::number[255]

8.823.2.3 uint8_t voice_callFWExtInfo::numLen

8.823.2.4 uint8_t voice_callFWExtInfo::numPlan

8.823.2.5 uint8_t voice_callFWExtInfo::numType

8.823.2.6 uint8_t voice_callFWExtInfo::PI

8.823.2.7 uint8_t voice_callFWExtInfo::SI

8.823.2.8 uint8_t voice_callFWExtInfo::SvcClass

8.823.2.9 uint8_t voice_callFWExtInfo::SvcStatus

8.824 voice_callFWInfo Struct Reference

Data Fields

- uint8_t SvcStatus
- uint8_t SvcClass
- uint8_t numLen
- uint8_t number [255]
- uint8_t noReplyTimer

8.824.1 Detailed Description

This structure contains information for Get Call Forwarding Information.

Parameters

SvcStatus	• Service status. Values: – 0x00 - SERVICE_STATUS_INACTIVE - Inactive – 0x01 - SERVICE_STATUS_ACTIVE - Active
SvcClass	• Service Class is a combination (sum) of information class constants • See qaGobiApiTableSupServiceInfoClasses.h for service classes.
numLen	• Provides the length of number which follow.
number[255]	• number of numLen length, NULL terminated.
noReplyTimer	• No reply timer value in seconds • A value of 0 indicates that noReplyTimer is ignored.

8.824.2 Field Documentation

8.824.2.1 uint8_t voice_callFWInfo::noReplyTimer

8.824.2.2 uint8_t voice_callFWInfo::number[255]

8.824.2.3 uint8_t voice_callFWInfo::numLen

8.824.2.4 uint8_t voice_callFWInfo::SvcClass

8.824.2.5 uint8_t voice_callFWInfo::SvcStatus

8.825 voice_callInfo Struct Reference

Data Fields

- uint8_t callID
- uint8_t callState
- uint8_t callType
- uint8_t direction
- uint8_t mode

8.825.1 Detailed Description

This structure contains Information about call state changes. For example, when an incoming call is received, this structure is populated and indicate the incoming call information. When this incoming call is answered, the call status changes from INCOMING to CONVERSATION, which means a change in the call information and this structure is populated again with the changes and notified to/retrived by the user.

Parameters

callID	• Call identifier for the call queried for information. • If zero(0) then invalid.
callState	• Call state. – 0x01 - CALL_STATE_ORIGINATION - Origination – 0x02 - CALL_STATE_INCOMING - Incoming – 0x03 - CALL_STATE_CONVERSATION - Conversation – 0x04 - CALL_STATE_CC_IN_PROGRESS - Call is originating but waiting for call control to complete – 0x05 - CALL_STATE_ALERTING - Alerting – 0x06 - CALL_STATE_HOLD - Hold – 0x07 - CALL_STATE_WAITING - Waiting – 0x08 - CALL_STATE_DISCONNECTING - Disconnecting – 0x09 - CALL_STATE_END - End – 0x0A - CALL_STATE_SETUP - MT call is in Setup state in 3GPP – 0xFF - Not Available
callType	• Call type. – 0x00 - CALL_TYPE_VOICE - Voice – 0x02 - CALL_TYPE_VOICE_IP - Voice over IP – 0x06 - CALL_TYPE_OTAPA - OTAPA – 0x07 - CALL_TYPE_STD_OTASP - Standard OTASP – 0x08 - CALL_TYPE_NON_STD_OTASP - Nonstandard OTASP – 0x09 - CALL_TYPE_EMERGENCY - Emergency – 0xFF - Not Available
direction	• Direction. – 0x01 - CALL_DIRECTION_MO - MO call – 0x02 - CALL_DIRECTION_MT - MT call – 0xFF - Not Available
mode	• Mode. • If the mode field is "0x01 - CDMA",the optional Service Option, Voice Privacy, and OTASP Status (only for OTASP calls) TLVs are included in the response. – 0x01 - CALL_MODE_CDMA - CDMA – 0x02 - CALL_MODE_GSM - GSM – 0x03 - CALL_MODE_UMTS - UMTS – 0x04 - CALL_MODE_LTE - LTE – 0x05 - CALL_MODE_TDS - TD-SCDMA – 0xFF - Not Available

8.825.2 Field Documentation

8.825.2.1 uint8_t voice_callInfo::callID

8.825.2.2 uint8_t voice_callInfo::callState

8.825.2.3 uint8_t voice_callInfo::callType

8.825.2.4 uint8_t voice_callInfo::direction

8.825.2.5 uint8_t voice_callInfo::mode

8.826 voice_ccSUPSType Struct Reference

Data Fields

- uint8_t svcType
- uint8_t reason

8.826.1 Detailed Description

This structure contains information about the Call Control Supplementary Service Types

Parameters

svcType	• Service type. – 0x01 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_ACTIVATE - Activate – 0x02 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_DEACTIVATE - Deactivate – 0x03 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_REGISTER - Register – 0x04 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_ERASE - Erase – 0x05 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_INTERROGATE - Interrogate – 0x06 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_REGISTER_PASSWORD - Register password – 0x07 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_USSD - USSD – 0xFF - Not Available
reason	• Call control supplementary service result reason • Values: – See qaGobiApiTableCallControlReturnReasons.h for return reasons.

8.826.2 Field Documentation

8.826.2.1 uint8_t voice_ccSUPSType::reason

8.826.2.2 uint8_t voice_ccSUPSType::svcType

8.827 voice_CLIPResp Struct Reference

Data Fields

- uint8_t ActiveStatus
- uint8_t ProvisionStatus

8.827.1 Detailed Description

This structure contains information about the Calling Line Identification Presentation (CLIP) supplementary service responses.

Parameters

ActiveStatus	• Active status. • Values: – 0x00 - ACTIVE_STATUS_INACTIVE - Inactive – 0x01 - ACTIVE_STATUS_ACTIVE - Active – 0xFF - Not Available
ProvisionStatus	• Provisioned status. • Values: – 0x00 - PROVISION_STATUS_NOT_PROVISIONED - Not provisioned – 0x01 - PROVISION_STATUS_PROVISIONED - Provisioned – 0xFF - Not Available

8.827.2 Field Documentation

8.827.2.1 uint8_t voice_CLIPResp::ActiveStatus

8.827.2.2 uint8_t voice_CLIPResp::ProvisionStatus

8.828 voice_CLIRResp Struct Reference

Data Fields

- uint8_t ActiveStatus
- uint8_t ProvisionStatus

8.828.1 Detailed Description

This structure contains information about the Calling Line Identification Restriction (CLIR) supplementary service responses.

Parameters

ActiveStatus	• Active status. • Values: – 0x00 - ACTIVE_STATUS_INACTIVE - Inactive – 0x01 - ACTIVE_STATUS_ACTIVE - Active – 0xFF - Not Available

ProvisionStatus	• Provisioned status. • Values: – 0x00 - PROVISION_STATUS_NOT_PROVISIONED - Not provisioned – 0x01 - PROVISION_STATUS_PROVISIONED_PERMANENT - Permanently provisioned – 0x02 - PROVISION_STATUS_PRESENTATION_RESTRICTED - Restricted presentation – 0x03 - PROVISION_STATUS_PRESENTATION_ALLOWED - Allowed presentation – 0xFF - Not Available

8.828.2 Field Documentation

8.828.2.1 uint8_t voice_CLIRResp::ActiveStatus

8.828.2.2 uint8_t voice_CLIRResp::ProvisionStatus

8.829 voice_CNAPResp Struct Reference

Data Fields

- uint8_t ActiveStatus
- uint8_t ProvisionStatus

8.829.1 Detailed Description

This structure contains information about the Calling Name Presentation (CNAP) supplementary service responses.

Parameters

ActiveStatus	• Active status. • Values: – 0x00 - ACTIVE_STATUS_INACTIVE - Inactive – 0x01 - ACTIVE_STATUS_ACTIVE - Active – 0xFF - Not Available
ProvisionStatus	• Provisioned status. • Values: – 0x00 - PROVISION_STATUS_NOT_PROVISIONED - Not provisioned – 0x01 - PROVISION_STATUS_PROVISIONED - Provisioned – 0xFF - Not Available

8.829.2 Field Documentation

8.829.2.1 uint8_t voice_CNAPResp::ActiveStatus

8.829.2.2 uint8_t voice_CNAPResp::ProvisionStatus

8.830 voice_COLPResp Struct Reference

Data Fields

- uint8_t ActiveStatus
- uint8_t ProvisionStatus

8.830.1 Detailed Description

This structure contains information about the Connected Line Identification Presentation (COLP) supplementary service responses.

Parameters

ActiveStatus	• Active status. • Values: – 0x00 - ACTIVE_STATUS_INACTIVE - Inactive – 0x01 - ACTIVE_STATUS_ACTIVE - Active – 0xFF - Not Available
ProvisionStatus	• Provisioned status. • Values: – 0x00 - PROVISION_STATUS_NOT_PROVISIONED - Not provisioned – 0x01 - PROVISION_STATUS_PROVISIONED - Provisioned – 0xFF - Not Available

8.830.2 Field Documentation

8.830.2.1 uint8_t voice_COLPResp::ActiveStatus

8.830.2.2 uint8_t voice_COLPResp::ProvisionStatus

8.831 voice_COLRResp Struct Reference

Data Fields

- uint8_t ActiveStatus
- uint8_t ProvisionStatus

8.831.1 Detailed Description

This structure contains information about the Connected Line Identification Restriction (COLR) supplementary service responses.

Parameters

ActiveStatus	• Active status. • Values: – 0x00 - ACTIVE_STATUS_INACTIVE - Inactive – 0x01 - ACTIVE_STATUS_ACTIVE - Active – 0xFF - Not Available
ProvisionStatus	• Provisioned status. • Values: – 0x00 - PROVISION_STATUS_NOT_PROVISIONED - Not provisioned – 0x01 - PROVISION_STATUS_PROVISIONED - Provisioned – 0xFF - Not Available

8.831.2 Field Documentation

8.831.2.1 uint8_t voice_COLRResp::ActiveStatus

8.831.2.2 uint8_t voice_COLRResp::ProvisionStatus

8.832 voice_connectNumInfo Struct Reference

Data Fields

- uint8_t numPresInd
- uint8_t screeningInd
- uint8_t numType
- uint8_t numPlan
- uint8_t callerIDLen
- uint8_t callerID [81]

8.832.1 Detailed Description

This structure contains information about the numbers connected to a device. It contains information such as number type, eg International or Local.

Parameters

numPresInd	• Presentation indicator – 0x00 - PRESENTATION_ALLOWED - Allowed presentation – 0x01 - PRESENTATION_RESTRICTED - Restricted presentation – 0x02 - PRESENTATION_NUM_UNAVAILABLE - Unavailable presentation – 0x04 - PRESENTATION_PAYPHONE - Payphone presentation (GSM/UMTS specific) – 0xFF - Not Available

screeningInd	• Screening indicator. – 0x00 - QMI_VOICE_SI_USER_PROVIDED_NOT_SCREENED - Provided user is not screened – 0x01 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_PASSED - Provided user passed verification – 0x02 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_FAILED - Provided user failed verification – 0x03 - QMI_VOICE_SI_NETWORK_PROVIDED - Provided network – 0xFF - Not Available
numType	• Number type. – 0x00 - QMI_VOICE_NUM_TYPE_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_TYPE_INTERNATIONAL - International – 0x02 - QMI_VOICE_NUM_TYPE_NATIONAL - National – 0x03 - QMI_VOICE_NUM_TYPE_NETWORK_SPECIFIC - Network-specific – 0x04 - QMI_VOICE_NUM_TYPE_SUBSCRIBER - Subscriber – 0x05 - QMI_VOICE_NUM_TYPE_RESERVED - Reserved – 0x06 - QMI_VOICE_NUM_TYPE_ABBREVIATED - Abbreviated – 0x07 - QMI_VOICE_NUM_TYPE_RESERVED_EXTENSION - Reserved extension – 0xFF - Not Available
numPlan	• Number plan. – 0x00 - QMI_VOICE_NUM_PLAN_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_PLAN_ISDN - ISDN – 0x03 - QMI_VOICE_NUM_PLAN_DATA - Data – 0x04 - QMI_VOICE_NUM_PLAN_TELEX - Telex – 0x08 - QMI_VOICE_NUM_PLAN_NATIONAL - National – 0x09 - QMI_VOICE_NUM_PLAN_PRIVATE - Private – 0x0B - QMI_VOICE_NUM_PLAN_RESERVED_CTS - Reserved cordless telephony system – 0x0F - QMI_VOICE_NUM_PLAN_RESERVED_EXTENSION - Reserved extension – 0xFF - Not Available
callerIDLen	• Provides the length of caller ID which follow. • If zero(0) then no further information exists.
callerID[MAX_VOICE_CALL_NO_LEN]	• callerID of numLen length, NULL terminated.

8.832.2 Field Documentation

8.832.2.1 uint8_t voice_connectNumInfo::callerID[81]

8.832.2.2 uint8_t voice_connectNumInfo::callerIDLen

8.832.2.3 uint8_t voice_connectNumInfo::numPlan

8.832.2.4 uint8_t voice_connectNumInfo::numPresInd

8.832.2.5 uint8_t voice_connectNumInfo::numType

8.832.2.6 uint8_t voice_connectNumInfo::screeningInd

8.833 voice_CUGInfo Struct Reference

Data Fields

- uint16_t CUGIndex
- uint8_t SuppPrefCUG
- uint8_t SuppOA

8.833.1 Detailed Description

This structure contains Closed User Group Information

Parameters

CUGIndex	• Range 0x00... 0x7FFF
SuppPrefCUG	• Suppress preferential CUG – 0x00 - FALSE – 0x01 - TRUE
SuppOA	• Suppress OA subscription option – 0x00 - FALSE – 0x01 - TRUE

8.833.2 Field Documentation

8.833.2.1 uint16_t voice_CUGInfo::CUGIndex

8.833.2.2 uint8_t voice_CUGInfo::SuppOA

8.833.2.3 uint8_t voice_CUGInfo::SuppPrefCUG

8.834 voice_curAMRConfig Struct Reference

Data Fields

- uint8_t gsmAmrStat
- uint8_t wcdmaAmrStat

8.834.1 Detailed Description

This structure contains the Current Adaptive Multi Rate Configuration Information.

Parameters

gsmAmrStat	• GSM AMR Status – 0x00 - Disable – 0x01 - Enable – 0xFF - Not Available
wcdmaAmrStat	• WCDMA AMR Status • One or a combination of the following bitmask values: – Bit 0 - AMR codec advertised is not supported – Bit 1 - Controls WCDMA AMR wideband – Bit 2 - Controls GSM half rate AMR – Bit 3 - Controls GSM AMR wideband – Bit 4 - Controls GSM AMR narrowband • 0xFF, if not available

8.834.2 Field Documentation

8.834.2.1 uint8_t voice_curAMRConfig::gsmAmrStat

8.834.2.2 uint8_t voice_curAMRConfig::wcdmaAmrStat

8.835 voice_diagInfo Struct Reference

Data Fields

- uint8_t diagInfoLen
- uint8_t diagnosticInfo [255]

8.835.1 Detailed Description

This structure contains Diagnostic Information

Parameters

diagInfoLen	• Provides the length of information which follow. • If zero(0) then no further information exists.
diagnosticInfo[MAX_VOICE_DESCRIPTION_LENGTH]	• Diagnostic information.

8.835.2 Field Documentation

8.835.2.1 uint8_t voice_diagInfo::diagInfoLen

8.835.2.2 uint8_t voice_diagInfo::diagnosticInfo[255]

8.836 voice_DTMFLengths Struct Reference

Data Fields

- uint8_t DTMFPulseWidth
- uint8_t DTMFInterdigitInterval

8.836.1 Detailed Description

This structure contains Voice Burst DTMF pulse length information

Parameters

DTMFPulse-Width	• DTMF pulse width. Values: – 0x00 - DTMF_ONLENGTH_95MS - 95 ms – 0x01 - DTMF_ONLENGTH_150MS - 150 ms – 0x02 - DTMF_ONLENGTH_200MS - 200 ms – 0x03 - DTMF_ONLENGTH_250MS - 250 ms – 0x04 - DTMF_ONLENGTH_300MS - 300 ms – 0x05 - DTMF_ONLENGTH_350MS - 350 ms – 0x06 - DTMF_ONLENGTH_SMS SMS Tx special pulse width
DTMFInterdigit-Interval	• DTMF interdigit interval Values: – 0x00 - DTMF_OFFLENGTH_60MS - 60 ms – 0x01 - DTMF_OFFLENGTH_100MS - 100 ms – 0x02 - DTMF_OFFLENGTH_150MS - 150 ms – 0x03 - DTMF_OFFLENGTH_200MS - 200 ms

8.836.2 Field Documentation

8.836.2.1 uint8_t voice_DTMFLengths::DTMFInterdigitInterval

8.836.2.2 uint8_t voice_DTMFLengths::DTMFPulseWidth

8.837 voice_getAllCallInformation Struct Reference

Data Fields

- voice_callInfo CallInfo
- uint8_t isEmpty
- uint8_t ALS

8.837.1 Detailed Description

This structure contains information related to call state change.

Parameters

CallInfo	• See voice_callInfo for more information.
isEmpty	• Multiparty indicator. – 0x00 - False – 0x01 - True
ALS	• Alternate Line Service line indicator. • Feature for supporting two different phone numbers on the same mobile device. – 0x00 - ALS_LINE1 - Line 1 (default) – 0x01 - ALS_LINE2 - Line 2

8.837.2 Field Documentation

8.837.2.1 uint8_t voice_getAllCallInformation::ALS

8.837.2.2 voice_callInfo voice_getAllCallInformation::CallInfo

8.837.2.3 uint8_t voice_getAllCallInformation::isEmpty

8.838 voice_getAllCallRmtPtyName Struct Reference

Data Fields

- uint8_t callID
- voice_remotePartyName RemotePartyName

8.838.1 Detailed Description

This structure contains information for All Call Remote Party Names

Parameters

callID	• Unique call identifier for the call.
RemoteParty-Name	• See voice_remotePartyName for more information.

8.838.2 Field Documentation

8.838.2.1 uint8_t voice_getAllCallRmtPtyName::callID

8.838.2.2 voice_remotePartyName voice_getAllCallRmtPtyName::RemotePartyName

8.839 voice_getAllCallRmtPtyNum Struct Reference

Data Fields

- uint8_t callID
- voice_remotePartyNum RemotePartyNum

8.839.1 Detailed Description

This structure contains information for All Call Remote Party Numbers

Parameters

callID	• Unique call identifier for the call.
RemoteParty-Num	• See voice_remotePartyNum for more information.

8.839.2 Field Documentation

8.839.2.1 uint8_t voice_getAllCallRmtPtyNum::callID

8.839.2.2 voice_remotePartyNum voice_getAllCallRmtPtyNum::RemotePartyNum

8.840 voice_getCallFWExtInfo Struct Reference

Data Fields

- uint8_t numInstances
- voice_callFWExtInfo CallFWExtInfo [20]

8.840.1 Detailed Description

This structure contains an array of Call Forwarded Extended Information.

Parameters

numInstances	• Number of callFWExtInfo that follow. • If zero(0) then no further information exists.
CallFWExtInfo[-VOICE_MAX_N-O_OF_CALLS]	• Array of CallFWExtInfo. – See voice_callFWExtInfo for more information.

8.840.2 Field Documentation

8.840.2.1 voice_callFWExtInfo voice_getCallFWExtInfo::CallFWExtInfo[20]

8.840.2.2 uint8_t voice_getCallFWExtInfo::numInstances

8.841 voice_getCallFWInfo Struct Reference

Data Fields

- uint8_t numInstances
- voice_callFWInfo CallFWInfo [20]

8.841.1 Detailed Description

This structure contains an array of Call Forwarded Information.

Parameters

numInstances	• Number of callFWInfo that follow. • If zero(0) then no further information exists.
CallFWInfo[VOICE_MAX_NO_OF_CALLS]	• Array of callFWInfo. – See voice_callFWInfo for more information.

8.841.2 Field Documentation

8.841.2.1 voice_callFWInfo voice_getCallFWInfo::CallFWInfo[20]

8.841.2.2 uint8_t voice_getCallFWInfo::numInstances

8.842 voice_peerNumberInfo Struct Reference

Data Fields

- uint8_t callID
- uint8_t numPI
- uint8_t numSI
- uint8_t numType
- uint8_t numPlan
- uint8_t numLen
- uint8_t number [81]

8.842.1 Detailed Description

This structure contains information for Connected Peer Numbers.

Parameters

callID	• Unique call identifier for the call.
numPI	• Number presentation indicator. – 0x00 - PRESENTATION_ALLOWED - Allowed presentation – 0x01 - PRESENTATION_RESTRICTED - Restricted presentation – 0x02 - PRESENTATION_NUM_UNAVAILABLE - Unavailable presentation – 0x04 - PRESENTATION_PAYPHONE - Payphone presentation (GSM/UMTS specific) – 0xFF - Not Available
numSI	• Number screening indicator. – 0x00 - QMI_VOICE_SI_USER_PROVIDED_NOT_SCREENED - Provided user is not screened – 0x01 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_PASSED - Provided user passed verification – 0x02 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_FAILED - Provided user failed verification – 0x03 - QMI_VOICE_SI_NETWORK_PROVIDED - Provided network
numType	• Number type. – 0x00 - QMI_VOICE_NUM_TYPE_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_TYPE_INTERNATIONAL - International – 0x02 - QMI_VOICE_NUM_TYPE_NATIONAL - National – 0x03 - QMI_VOICE_NUM_TYPE_NETWORK_SPECIFIC - Network-specific – 0x04 - QMI_VOICE_NUM_TYPE_SUBSCRIBER - Subscriber – 0x05 - QMI_VOICE_NUM_TYPE_RESERVED - Reserved – 0x06 - QMI_VOICE_NUM_TYPE_ABBREVIATED - Abbreviated – 0x07 - QMI_VOICE_NUM_TYPE_RESERVED_EXTENSION - Reserved extension
numPlan	• Number plan. – 0x00 - QMI_VOICE_NUM_PLAN_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_PLAN_ISDN - ISDN – 0x03 - QMI_VOICE_NUM_PLAN_DATA - Data – 0x04 - QMI_VOICE_NUM_PLAN_TELEX - Telex – 0x08 - QMI_VOICE_NUM_PLAN_NATIONAL - National – 0x09 - QMI_VOICE_NUM_PLAN_PRIVATE - Private – 0x0B - QMI_VOICE_NUM_PLAN_RESERVED_CTS - Reserved cordless telephony system – 0x0F - QMI_VOICE_NUM_PLAN_RESERVED_EXTENSION - Reserved extension
numLen	• Provides the length of number which follow.
number[MAX_VOICE_CALL_NO_LEN]	• number of numLen length, NULL terminated.

8.842.2 Field Documentation

8.842.2.1 uint8_t voice_peerNumberInfo::callID

8.842.2.2 uint8_t voice_peerNumberInfo::number[81]

8.842.2.3 uint8_t voice_peerNumberInfo::numLen

8.842.2.4 uint8_t voice_peerNumberInfo::numPI

8.842.2.5 uint8_t voice_peerNumberInfo::numPlan

8.842.2.6 uint8_t voice_peerNumberInfo::numSI

8.842.2.7 uint8_t voice_peerNumberInfo::numType

8.843 voice_prefVoiceSO Struct Reference

Data Fields

- uint8_t namID
- uint8_t evrcCapability
- uint16_t homePageVoiceSO
- uint16_t homeOrigVoiceSO
- uint16_t roamOrigVoiceSO

8.843.1 Detailed Description

This structure contains information about the Preferred Voice Service Options.

Parameters

namID	• Index of the NAM(Number Assignment Module) to be configured. • Range 0 to 3. • Some modems support only 1 or 2 NAMs. • 0xFF,if not available.
evrcCapability	• EVRC capability. • Values: – 0x00 - Disable – 0x01 - Enable – 0xFF - Not Available

homePageVoiceSO	• Home page voice SO; most preferred CDMA SO to be requested from the network when receiving an incoming (MT) voice call within the home network. • Values: – 0x0000 - VOICE_SO_WILD - Any service option – 0x0001 - VOICE_SO_IS_96A - IS-96A – 0x0003 - VOICE_SO_EVRC - EVRC – 0x0011 - VOICE_SO_13K_IS733 - 13K_IS733 – 0x0038 - VOICE_SO_SELECTABLE_MODE_VOCODER - Selectable mode vocoder – 0x0044 - VOICE_SO_4GV_NARR0W_BAND - 4GV narrowband – 0x0046 - VOICE_SO_4GV_WIDE_BAND - 4GV wideband – 0x8000 - VOICE_SO_13K - 13K – 0x8001 - VOICE_SO_IS_96 - IS-96 – 0x8023 - VOICE_SO_WVRC - WVRC – 0xFFFF - Not Available
homeOrigVoiceSO	• Home origination voice SO; most preferred CDMA SO to be requested from the network when receiving an incoming (MT) voice call within the home network. • Values: – 0x0000 - VOICE_SO_WILD - Any service option – 0x0001 - VOICE_SO_IS_96A - IS-96A – 0x0003 - VOICE_SO_EVRC - EVRC – 0x0011 - VOICE_SO_13K_IS733 - 13K_IS733 – 0x0038 - VOICE_SO_SELECTABLE_MODE_VOCODER - Selectable mode vocoder – 0x0044 - VOICE_SO_4GV_NARR0W_BAND - 4GV narrowband – 0x0046 - VOICE_SO_4GV_WIDE_BAND - 4GV wideband – 0x8000 - VOICE_SO_13K - 13K – 0x8001 - VOICE_SO_IS_96 - IS-96 – 0x8023 - VOICE_SO_WVRC - WVRC – 0xFFFF - Not Available
roamOrigVoiceSO	• Roaming origination voice SO; most preferred CDMA SO to be requested from the network when receiving an incoming (MT) voice call within the home network. • Values: – 0x0000 - VOICE_SO_WILD - Any service option – 0x0001 - VOICE_SO_IS_96A - IS-96A – 0x0003 - VOICE_SO_EVRC - EVRC – 0x0011 - VOICE_SO_13K_IS733 - 13K_IS733 – 0x0038 - VOICE_SO_SELECTABLE_MODE_VOCODER - Selectable mode vocoder – 0x0044 - VOICE_SO_4GV_NARR0W_BAND - 4GV narrowband – 0x0046 - VOICE_SO_4GV_WIDE_BAND - 4GV wideband – 0x8000 - VOICE_SO_13K - 13K – 0x8001 - VOICE_SO_IS_96 - IS-96 – 0x8023 - VOICE_SO_WVRC - WVRC – 0xFFFF - Not Available

8.843.2 Field Documentation

8.843.2.1 uint8_t voice_prefVoiceSO::evrcCapability

8.843.2.2 uint16_t voice_prefVoiceSO::homeOrigVoiceSO

8.843.2.3 uint16_t voice_prefVoiceSO::homePageVoiceSO

8.843.2.4 uint8_t voice_prefVoiceSO::namID

8.843.2.5 uint16_t voice_prefVoiceSO::roamOrigVoiceSO

8.844 voice_remotePartyName Struct Reference

Data Fields

- uint8_t namePI
- uint8_t codingScheme
- uint8_t nameLen
- uint8_t callerName [255]

8.844.1 Detailed Description

This structure contains information about the names that are dialed from the device or from which a call is received on the device.

Parameters

namePI	• Name presentation indicator. – 0x00 - PRESENTATION_NAME_PRESENTATION_ALLOWED - Allowed presentation – 0x01 - PRESENTATION_NAME_PRESENTATION_RESTRICTED - Restricted presentation – 0x02 - PRESENTATION_NAME_UNAVAILABLE - Unavailable presentation – 0x03 - PRESENTATION_NAME_NAME_PRESENTATION_RESTRICTED - Restricted name presentation – 0xFF - Not Available
codingScheme	• Refer to Table10 qaGobiApiTableCodingScheme.h for coding schemes • 0xFF - Not Available
nameLen	• Provides the length of name which follow. • If zero(0) then no further information exists.
callerName[MAX_VOICE_DESCRIPTION_LENGTH]	• Name in ASCII, NULL ending.

8.844.2 Field Documentation

8.844.2.1 uint8_t voice_remotePartyName::callerName[255]

8.844.2.2 uint8_t voice_remotePartyName::codingScheme

8.844.2.3 uint8_t voice_remotePartyName::nameLen

8.844.2.4 uint8_t voice_remotePartyName::namePI

8.845 voice_remotePartyNum Struct Reference

Data Fields

- uint8_t presentationInd
- uint8_t numLen
- uint8_t remPartyNumber [81]

8.845.1 Detailed Description

This structure contains information about the numbers that are dialed from the device or from which a call is received on the device.

Parameters

presentationInd	• Presentation indicator. – 0x00 - PRESENTATION_ALLOWED - Allowed presentation – 0x01 - PRESENTATION_RESTRICTED - Restricted presentation – 0x02 - PRESENTATION_NUM_UNAVAILABLE - Unavailable presentation – 0x04 - PRESENTATION_PAYPHONE - Payphone presentation (GSM/UMTS specific) – 0xFF - Not Available
numLen	• Provides the length of number which follow. • If zero(0) then no further information exists.
remParty-Number[MAX_-CALL_NO_LEN]	• Array of numbers in ASCII, NULL ending.

8.845.2 Field Documentation

8.845.2.1 uint8_t voice_remotePartyNum::numLen

8.845.2.2 uint8_t voice_remotePartyNum::presentationInd

8.845.2.3 uint8_t voice_remotePartyNum::remPartyNumber[81]

8.846 voice_roamTimer Struct Reference

Data Fields

- uint8_t namID
- uint32_t roamTimerValue

8.846.1 Detailed Description

This structure contains information about the Roam Timer.

Parameters

namID	• Index of the NAM(Number Assignment Module) to be configured. • Range 0 to 3. • Some modems support only 1 or 2 NAMs. • 0xFF,if not available.
roamTimerValue	• Time in minutes. • Cumulative air time is slammed. • 0xFFFFFFFF,if not available.

8.846.2 Field Documentation

8.846.2.1 uint8_t voice_roamTimer::namID

8.846.2.2 uint32_t voice_roamTimer::roamTimerValue

8.847 voice_USSInfo Struct Reference

Data Fields

- uint8_t ussDCS
- uint8_t ussLen
- uint8_t ussData [182]

8.847.1 Detailed Description

This structure contains USS Information

Parameters

ussDCS	• 1 - ASCII coding scheme • 2 - 8-BIT coding scheme • 3 - UCS2
ussLen	• Range 1 to 182
ussData	• Data encoded as per the DCS

8.847.2 Field Documentation

8.847.2.1 uint8_t voice_USSInfo::ussData[182]

8.847.2.2 uint8_t voice_USSInfo::ussDCS

8.847.2.3 uint8_t voice_USSInfo::ussLen

8.848 voice_UUSInfo Struct Reference

Data Fields

- uint8_t UUSType
- uint8_t UUSDcs
- uint8_t UUSDatalen
- uint8_t UUSData [255]

8.848.1 Detailed Description

This structure contains User to User Signaling Service Information.

Parameters

UUSType	• UUS type values are: – 0x00 - UUS_DATA – 0x01 - UUS_TYPE1_IMPLICIT – 0x02 - UUS_TYPE1_REQUIRED – 0x03 - UUS_TYPE1_NOT_REQUIRED – 0x04 - UUS_TYPE2_REQUIRED – 0x05 - UUS_TYPE2_NOT_REQUIRED – 0x06 - UUS_TYPE3_REQUIRED – 0x07 - UUS_TYPE3_NOT_REQUIRED – 0xFF - Not Available
UUSDcs	• UUS data coding scheme values are: – 0x01 - UUS_DCS_USP – 0x02 - UUS_DCS_OHLP – 0x03 - UUS_DCS_X244 – 0x04 - UUS_DCS_SMCF – 0x05 - UUS_DCS_IA5 – 0x06 - UUS_DCS_RV12RD – 0x07 - UUS_DCS_Q931UNCCM – 0xFF - Not Available
UUSDatalen	• Number of sets of the following elements. – UUSData • If zero(0) then no further information exists.
UUSData[MAX_VOICE_DESCRIPTION_LENGTH]	• UUS data encoded as per coding scheme

8.848.2 Field Documentation

8.848.2.1 uint8_t voice_UUSInfo::UUSData[255]

8.848.2.2 uint8_t voice_UUSInfo::UUSDatalen

8.848.2.3 uint8_t voice_UUSInfo::UUSDcs

8.848.2.4 uint8_t voice_UUSInfo::UUSType

8.849 wds_currNetworkInfo Struct Reference

Data Fields

- uint8_t NetworkType
- uint32_t RATMask
- uint32_t SOMask

8.849.1 Detailed Description

Network information structure

Parameters

NetworkType	• Values: – 0 - 3GPP – 1 - 3GPP2
RATMask	• Radio Access Technology (RAT) mask to indicate the type of technology. • Values: – 0 - Don't Care – 0x8000 - NULL Bearer • CDMA RAT mask values: – 0x01 - CDMA_1x – 0x02 - EVDO_REV0 – 0x05 - HRPD – 0x0B - EHRPD • UMTS RAT mask values: – 0x03 - GPRS – 0x04 - WCDMA – 0x06 - EDGE – 0x07 - HSDPA and WCDMA – 0x08 - HSUPA and WCDMA – 0x08 - HSDPA and HSUPA – 0x0A - LTE – 0x0C - HSDPA+ and WCDMA – 0x0D - HSDPA+ and HSUPA – 0x0E - DC_HSDPA+ and WCDMA – 0x0F - DC_HSDPA+ and HSUPA

SOMask	• Service Option (SO) mask to indicate the service option or type of application. • Values: – 0 - Don't Care • CDMA 1x SO mask values: – 0x01 - CDMA_1X_IS95 – 0x02 - CDMA_1X_IS2000 – 0x04 - CDMA_1X_IS2000_REL_A • CDMA EV-DO Rev 0 SO mask values: – 0x01 - DPA • CDMA EV-DO Rev A SO mask values: – 0x01 - DPA – 0x02 - MFPA – 0x04 - EMPA – 0x08 - EMPA_EHRPD • CDMA EV-DO Rev B SO mask values: – 0x01 - DPA – 0x02 - MFPA – 0x04 - EMPA – 0x08 - EMPA_EHRPD – 0x10 - MMPA – 0x20 - MMPA_EHRPD

8.849.2 Field Documentation

8.849.2.1 uint8_t wds_currNetworkInfo::NetworkType

8.849.2.2 uint32_t wds_currNetworkInfo::RATMask

8.849.2.3 uint32_t wds_currNetworkInfo::SOMask

8.850 wds_DataULongLongTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t ullData

8.850.1 Detailed Description

This structure contains Data unsigned long long TLV data.

Parameters

TlvPresent	a flag indicates whether TLV presented or not
ullData	unsigend long long data in 64bit

8.850.2 Field Documentation

8.850.2.1 uint8_t wds_DataULongLongTlv::TlvPresent

8.850.2.2 uint64_t wds_DataULongLongTlv::ullData

8.851 wds_DataULongTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t ulData

8.851.1 Detailed Description

This structure contains Data unsigned long TLV data.

Parameters

TlvPresent	a flag indicates whether TLV presented or not
ulData	unsigend long data in 32bit

8.851.2 Field Documentation

8.851.2.1 uint8_t wds_DataULongTlv::TlvPresent

8.851.2.2 uint32_t wds_DataULongTlv::ulData

8.852 wds_DHCPLeaseOptTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t numOpt
- wds_DHCPOpt optList [30]
- uint8_t optListData [2048]

8.852.1 Detailed Description

DHCP lease option information

Parameters

TlvPresent	a flag indicates whether TLV presented or not
numOpt	number of sets of wds_DHCPOpt
optList	option list
optListData	option list data

8.852.2 Field Documentation

8.852.2.1 uint8_t wds_DHCPLeaseOptTlv::numOpt

8.852.2.2 wds_DHCPOpt wds_DHCPLeaseOptTlv::optList[30]

8.852.2.3 uint8_t wds_DHCPLeaseOptTlv::optListData[2048]

8.852.2.4 uint8_t wds_DHCPLeaseOptTlv::TlvPresent

8.853 wds_DHCPLeaseStateTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t leaseState

8.853.1 Detailed Description

DHCP lease state information

Parameters

TlvPresent	a flag indicates whether TLV presented or not
leaseState	lease state • 0 - active, newly acquired • 1 - active, renewed • 2 - active, renewing • 3 - active, rebinding • 4 - inactive, expired • 5 - inactive, renew refused • 6 - inactive, rebind refused • 7 - inactive, other

8.853.2 Field Documentation

8.853.2.1 uint8_t wds_DHCPLeaseStateTlv::leaseState

8.853.2.2 uint8_t wds_DHCPLeaseStateTlv::TlvPresent

8.854 wds_DHCPOpt Struct Reference

Data Fields

- uint8_t optCode
- uint8_t optValLen
- uint8_t * pOptVal

8.854.1 Detailed Description

DHCP option code information

Parameters

optCode	option code • values: – 0 - 255

optValLen	length of option code • values: – 0 - 255
pOptVal	option value

8.854.2 Field Documentation

8.854.2.1 uint8_t wds_DHCPOpt::optCode

8.854.2.2 uint8_t wds_DHCPOpt::optValLen

8.854.2.3 uint8_t* wds_DHCPOpt::pOptVal

8.855 wds_DHCPProfileIdTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t profileType
- uint8_t profileId

8.855.1 Detailed Description

DHCP profile id TLV information

Parameters

TlvPresent	a flag indicates whether TLV presented or not
profileType	identifying the type of the profile • 0 - 3GPP
profileId	index identifying the profile • 1-24 valid for 3GPP profile type (9x30 and onwards)

8.855.2 Field Documentation

8.855.2.1 uint8_t wds_DHCPProfileIdTlv::profileId

8.855.2.2 uint8_t wds_DHCPProfileIdTlv::profileType

8.855.2.3 uint8_t wds_DHCPProfileIdTlv::TlvPresent

8.856 wds_DHCPv4HWConfig Struct Reference

Data Fields

- uint8_t hwType
- uint8_t chaddrLen
- uint8_t chaddr [16]

8.856.1 Detailed Description

WDS SWI DHCPv4 HW Config Structure.

Parameters

hwType	• HW Type 1 - Ethernet 20 - Serial
chaddrlen	• chaddrlen
chaddr	• chaddr. Max size 16 bytes

8.856.2 Field Documentation

8.856.2.1 uint8_t wds_DHCPv4HWConfig::chaddr[16]

8.856.2.2 uint8_t wds_DHCPv4HWConfig::chaddrLen

8.856.2.3 uint8_t wds_DHCPv4HWConfig::hwType

8.857 wds_DHCPv4Option Struct Reference

Data Fields

- uint8_t optCode
- uint8_t optValLen
- uint8_t optVal [255]

8.857.1 Detailed Description

WDS SWI DHCPv4 Option Structure

Parameters

optCode	• Option code – 0 - 255
optValLen	• Option value length – 0 - 255
optVal	• Option value

8.857.2 Field Documentation

8.857.2.1 uint8_t wds_DHCPv4Option::optCode

8.857.2.2 uint8_t wds_DHCPv4Option::optVal[255]

8.857.2.3 uint8_t wds_DHCPv4Option::optValLen

8.858 wds_DHCPv4OptionList Struct Reference

Data Fields

- uint8_t numOpt
- wds_DHCPv4Option * pOptList

8.858.1 Detailed Description

WDS SWI DHCPv4 Option List Structure

Parameters

numOpt	• number of options – 0 - 255
pOptList	• pointer to list of DHCP Options

8.858.2 Field Documentation

8.858.2.1 uint8_t wds_DHCPv4OptionList::numOpt

8.858.2.2 wds_DHCPv4Option* wds_DHCPv4OptionList::pOptList

8.859 wds_DHCPv4ProfileId Struct Reference

Data Fields

- uint8_t profileType
- uint8_t profileId

8.859.1 Detailed Description

WDS SWI DHCPv4 Profile Identifier Structure

Parameters

profileType	• 0 for 3GPP
profileId	• 1 to 24 for 3GPP profile

8.859.2 Field Documentation

8.859.2.1 uint8_t wds_DHCPv4ProfileId::profileId

8.859.2.2 uint8_t wds_DHCPv4ProfileId::profileType

8.860 wds_Domain Struct Reference

Data Fields

- uint16_t domainLen
- uint8_t domainName [256]

8.860.1 Detailed Description

This structure contains the DomainName Information

Parameters

domainLen	• length of the recieved Domain name
domainName	• Domain name(Max 256 characters)

8.860.2 Field Documentation

8.860.2.1 uint16_t wds_Domain::domainLen

8.860.2.2 uint8_t wds_Domain::domainName[256]

8.861 wds_DomainNameList Struct Reference

Data Fields

- uint8_t numInstances
- struct wds_Domain domain [10]

8.861.1 Detailed Description

This structure contains the DomainNameList Information

Parameters

numInstances	• Number of Domain name receieved
domain	• Domain name information(Max 10 Domain names)

Note

Data invalid when numInstances equal 0xff.

8.861.2 Field Documentation

8.861.2.1 struct wds_Domain wds_DomainNameList::domain[10]

8.861.2.2 uint8_t wds_DomainNameList::numInstances

8.862 wds_GPRSQoS Struct Reference

Data Fields

- uint32_t precedenceClass
- uint32_t delayClass
- uint32_t reliabilityClass
- uint32_t peakThroughputClass
- uint32_t meanThroughputClass

8.862.1 Detailed Description

This structure contains the GPRS Quality Of Service Information

Parameters

precedence-Class	• Precedence class
delayClass	• Delay class
reliabilityClass	• Reliability class
peak-Throughput-Class	• Peak throughput class
mean-Throughput-Class	• Mean throughput class

Note

Data invalid when all parameters are equal to 0xffffffff.

8.862.2 Field Documentation

8.862.2.1 uint32_t wds_GPRSQoS::delayClass

8.862.2.2 uint32_t wds_GPRSQoS::meanThroughputClass

8.862.2.3 uint32_t wds_GPRSQoS::peakThroughputClass

8.862.2.4 uint32_t wds_GPRSQoS::precedenceClass

8.862.2.5 uint32_t wds_GPRSQoS::reliabilityClass

8.863 wds_IPv4AdTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t IPv4Addr

8.863.1 Detailed Description

IPv4 address TLV information

Parameters

TlvPresent	a flag indicates whether TLV presented or not
IPv4Addr	IPv4 address

8.863.2 Field Documentation

8.863.2.1 uint32_t wds_IPv4AdTlv::IPv4Addr

8.863.2.2 uint8_t wds_IPv4AdTlv::TlvPresent

8.864 wds_IPV6AddressInfo Struct Reference

Data Fields

- uint8_t IPV6PrefixLen
- uint16_t IPAddressV6 [8]

8.864.1 Detailed Description

This structure contains the IPV6 Address Information

Parameters

IPV6PrefixLen	• Length of the received IPv6 address in no. of bits; can take value between 0 and 128 – 0xFF - Not Available
IPAddressV6	• IPv6 address(in network byte order); This is an 8-element array of 16 bit numbers, each of which is in big endian format.

8.864.2 Field Documentation

8.864.2.1 uint16_t wds_IPV6AddressInfo::IPAddressV6[8]

8.864.2.2 uint8_t wds_IPV6AddressInfo::IPV6PrefixLen

8.865 wds_IPV6GWAddressInfo Struct Reference

Data Fields

- uint8_t gwV6PrefixLen
- uint16_t gwAddressV6 [8]

8.865.1 Detailed Description

This structure contains the IPV6 Gateway Address Information

Parameters

gwV6PrefixLen	• Length of the received IPv6 Gateway address in no. of bits; can take value between 0 and 128
IPAddressV6	• IPv6 Gateway address(in network byte order); This is an 8-element array of 16 bit numbers, each of which is in big endian format.

Note

Data invalid when IPV6PrefixLen equal 0xff.

8.865.2 Field Documentation

8.865.2.1 uint16_t wds_IPV6GWAddressInfo::gwAddressV6[8]

8.865.2.2 uint8_t wds_IPV6GWAddressInfo::gwV6PrefixLen

8.866 wds_PCSCFFQDNAddress Struct Reference

Data Fields

- uint16_t fqdnLen
- uint8_t fqdnAddr [256]

8.866.1 Detailed Description

This structure contains the PCSCFFQDNAddress Information

Parameters

fqdnLen	• length of the received FQDN address
fqdnAddr	• FQDN address(Max 256 characters)

8.866.2 Field Documentation

8.866.2.1 uint8_t wds_PCSCFFQDNAddress::fqdnAddr[256]

8.866.2.2 uint16_t wds_PCSCFFQDNAddress::fqdnLen

8.867 wds_PCSCFFQDNAddressList Struct Reference

Data Fields

- uint8_t numInstances
- struct wds_PCSCFFQDNAddress pcsfFQDNAddress [10]

8.867.1 Detailed Description

This structure contains the PCSCFFQDNAddressList Information

Parameters

numInstances	• Number of FQDN addresses received
pcsfFQDN-Address	• FQDN address information(Max 10 addresses)

Note

Data invalid when numInstances equal 0xff.

8.867.2 Field Documentation

8.867.2.1 uint8_t wds_PCSCFFQDNAddressList::numInstances

8.867.2.2 struct wds_PCSCFFQDNAddress wds_PCSCFFQDNAddressList::pcsfFQDNAddress[10]

8.868 wds_PCSCFIPv4ServerAddressList Struct Reference

Data Fields

- uint8_t numInstances
- uint32_t pscsfIPv4Addr [64]

8.868.1 Detailed Description

This structure contains the PCSCFIPv4ServerAddressList Information

Parameters

numInstances	• number of address following
pscsfIPv4Addr	• P-CSCF IPv4 server addresses(Max 16 address, 4 bytes each)

Note

Data invalid when numInstances equal 0xff and pscsfIPv4Addr equal to 0xffffffff.

8.868.2 Field Documentation

8.868.2.1 uint8_t wds_PCSCFIPv4ServerAddressList::numInstances

8.868.2.2 uint32_t wds_PCSCFIPv4ServerAddressList::pscsfIPv4Addr[64]

8.869 wds_ProfileIdentifier Struct Reference

Data Fields

- uint8_t profileType
- uint8_t profileIndex

8.869.1 Detailed Description

This structure contains the Profile Identifier Information

Parameters

profileType	• Identifies the type of profile 0x00 = 3GPP
profileIndex	• Index of profile whose settings were loaded prior to session parameter negotiation for the current call. If this TLV is not present, data call parameters are based on device default settings for each parameter

Note

Data invalid when all parameters are equal to 0xff.

8.869.2 Field Documentation

8.869.2.1 uint8_t wds_ProfileIdentifier::profileIndex

8.869.2.2 uint8_t wds_ProfileIdentifier::profileType

8.870 wds_profileInfo Union Reference

Data Fields

- LibPackprofile_3GPP SlqsProfile3GPP
- LibPackprofile_3GPP2 SlqsProfile3GPP2

8.870.1 Detailed Description

This union consist of profile_3GPP and profile_3GPP2 out of which one will be used to create profile.

Parameters

SlqsProfile3GPP	3GPP profile See LibPackprofile_3GPP
SlqsProfile3GP-P2	3GPP2 profile See LibPackprofile_3GPP2

8.870.2 Field Documentation

8.870.2.1 LibPackprofile_3GPP wds_profileInfo::SlqsProfile3GPP

8.870.2.2 LibPackprofile_3GPP2 wds_profileInfo::SlqsProfile3GPP2

8.871 wds_transferStatInd Struct Reference

Data Fields

- uint8_t StatsPeriod
- uint32_t StatsMask

8.871.1 Detailed Description

This structure contains the transfer statistic indication information

Parameters

StatsPeriod	Field Period between transfer statistic reports. • 0 - Do not report. • 1 - Other - Period between reports (in seconds).
StatsMask	requested statistic bit mask. • 0x00000040 - Tx bytes OK • 0x00000080 - Rx bytes OK

8.871.2 Field Documentation

8.871.2.1 uint32_t wds_transferStatInd::StatsMask

8.871.2.2 uint8_t wds_transferStatInd::StatsPeriod

8.872 wds_TrStatInd Struct Reference

Data Fields

- uint8_t statsPeriod
- uint32_t statsMask

8.872.1 Detailed Description

This structure contains the information about the Transfer Statistics Indicator parameters.

Parameters

statsPeriod	• Period between transfer statistics reports. – 0 - Do not report – Other - Period between reports (seconds)
statsMask	• Requested statistic bit mask. – 0x00000001 - Tx packets OK – 0x00000002 - Rx packets OK – 0x00000004 - Tx packet errors – 0x00000008 - Rx packet errors – 0x00000010 - Tx overflows – 0x00000020 - Rx overflows – 0x00000040 - Tx bytes OK – 0x00000080 - Rx bytes OK • Each bit set causes the corresponding optional information to be sent in SLQSWdsEventReport-CallBack. • All unlisted bits are reserved for future use and must be set to zero.

8.872.2 Field Documentation

8.872.2.1 uint32_t wds_TrStatInd::statsMask

8.872.2.2 uint8_t wds_TrStatInd::statsPeriod

8.873 wds_UMTSMinQoS Struct Reference

Data Fields

- uint8_t trafficClass
- uint32_t maxUplinkBitrate
- uint32_t maxDownlinkBitrate
- uint32_t grntUplinkBitrate
- uint32_t grntDownlinkBitrate
- uint8_t qosDeliveryOrder
- uint32_t maxSDUSize
- uint8_t sduErrorRatio
- uint8_t resBerRatio
- uint8_t deliveryErrSDU
- uint32_t transferDelay
- uint32_t trafficPriority

8.873.1 Detailed Description

This structure contains the UMTS Quality Of Service Information

Parameters

trafficClass	• 0x00 - Subscribed • 0x01 - Conversational • 0x02 - Streaming • 0x03 - Interactive • 0x04 - Background
maxUplinkBitrate	• Maximum uplink bit rate in bits/sec
maxDownlink-Bitrate	• Maximum downlink bit rate in bits/sec
grntUplinkBitrate	• Guaranteed uplink bit rate in bits/sec
grntDownlink-Bitrate	• Guaranteed downlink bit rate in bits/sec
qosDelivery-Order	- Qos delivery order • 0x00 - Subscribe • 0x01 - Delivery order on • 0x02 - Delivery order off
maxSDUSize	• Maximum SDU size
sduErrorRatio	- SDU error ratio • Target value for fraction of SDUs lost or detected as erroneous. • 0x00 - Subscribe • 0x01 - 1∗10^(-2) • 0x02 - 7∗10^(-3) • 0x03 - 1∗10^(-3) • 0x04 - 1∗10^(-4) • 0x05 - 1∗10^(-5) • 0x06 - 1∗10^(-6) • 0x07 - 1∗10^(-1)
resBerRatio	- Residual bit error ratio • Target value for undetected bit error ratio in in the delivered SDUs. • 0x00 - Subscribe • 0x01 - 5∗10^(-2) • 0x02 - 1∗10^(-2) • 0x03 - 5∗10^(-3) • 0x04 - 4∗10^(-3) • 0x05 - 1∗10^(-3) • 0x06 - 1∗10^(-4) • 0x07 - 1∗10^(-5) • 0x08 - 1∗10^(-6) • 0x09 - 1∗10^(-8)

deliveryErrSDU	- delivery of erroneous SDUs • Indicates whether SDUs detected as erroneous shall be delivered or not. • 0x00 - Subscribe • 0x01 - 5∗10^(-2) • 0x02 - 1∗10^(-2) • 0x03 - 5∗10^(-3) • 0x04 - 4∗10^(-3) • 0x05 - 1∗10^(-3) • 0x06 - 1∗10^(-4) • 0x07 - 1∗10^(-5) • 0x08 - 1∗10^(-6) • 0x09 - 1∗10^(-8)
transferDelay	- Transfer delay (ms) • Indicates the targeted time between a request to transfer an SDU at one SAP to its delivery at the other SAP in milliseconds.
trafficPriority	- Transfer handling priority • Specifies the relative importance for handling of SDUs that belong to the UMTS bearer, compared to the SDUs of other bearers.

8.873.2 Field Documentation

8.873.2.1 uint8_t wds_UMTSMinQoS::deliveryErrSDU

8.873.2.2 uint32_t wds_UMTSMinQoS::grntDownlinkBitrate

8.873.2.3 uint32_t wds_UMTSMinQoS::grntUplinkBitrate

8.873.2.4 uint32_t wds_UMTSMinQoS::maxDownlinkBitrate

8.873.2.5 uint32_t wds_UMTSMinQoS::maxSDUSize

8.873.2.6 uint32_t wds_UMTSMinQoS::maxUplinkBitrate

8.873.2.7 uint8_t wds_UMTSMinQoS::qosDeliveryOrder

8.873.2.8 uint8_t wds_UMTSMinQoS::resBerRatio

8.873.2.9 uint8_t wds_UMTSMinQoS::sduErrorRatio

8.873.2.10 uint8_t wds_UMTSMinQoS::trafficClass

8.873.2.11 uint32_t wds_UMTSMinQoS::trafficPriority

8.873.2.12 uint32_t wds_UMTSMinQoS::transferDelay

8.874 wdsDhcpv4HwConfig Struct Reference

Data Fields

- uint8_t hwType
- uint8_t chaddrLen
- uint8_t chaddr [16]

8.874.1 Detailed Description

Structure contain DHCP V4 Hardware Configuration.

Parameters

hwType	DHCP HW Type, examples: • 0 - Ethernet • 20 - Serial
chaddrLen	Length of chaddr field, examples: • 6 for Ethernet MAC address
chaddr	Client hardware address

8.874.2 Field Documentation

8.874.2.1 uint8_t wdsDhcpv4HwConfig::chaddr[16]

8.874.2.2 uint8_t wdsDhcpv4HwConfig::chaddrLen

8.874.2.3 uint8_t wdsDhcpv4HwConfig::hwType

8.875 wdsDhcpv4Option Struct Reference

Data Fields

- uint8_t optCode
- uint8_t optValLen
- uint8_t optVal [255]

8.875.1 Detailed Description

This structure contains DHCP V4 Option information.

Parameters

optCode	Option code • 0 - 255
optValLen	Option value length • 0 - 255
optVal	Option Value

8.875.2 Field Documentation

8.875.2.1 uint8_t wdsDhcpv4Option::optCode

8.875.2.2 uint8_t wdsDhcpv4Option::optVal[255]

8.875.2.3 uint8_t wdsDhcpv4Option::optValLen

8.876 wdsDhcpv4OptionList Struct Reference

Data Fields

- uint8_t numOpt
- wdsDhcpv4Option * pOptList

8.876.1 Detailed Description

Structure contain DHCP V4 Option List

Parameters

numOpt	number of options • 0 - 255
pOptList	pointer to list of DHCP Options • See wdsDhcpv4Option

8.876.2 Field Documentation

8.876.2.1 uint8_t wdsDhcpv4OptionList::numOpt

8.876.2.2 wdsDhcpv4Option* wdsDhcpv4OptionList::pOptList

8.877 wdsDhcpv4ProfileId Struct Reference

Data Fields

- uint8_t profileType
- uint8_t profileId

8.877.1 Detailed Description

This structure contains DHCP v4 ProfielID Information.

Parameters

profileType	profile type • 0 - 3GPP
profileId	profile index • index identifiying the profile 1-24 valid for 3GPP profile type (EM74xx and onwards)

8.877.2 Field Documentation

8.877.2.1 uint8_t wdsDhcpv4ProfileId::profileId

8.877.2.2 uint8_t wdsDhcpv4ProfileId::profileType

Chapter 9

File Documentation

9.1 apdoxypages.c File Reference

Contains the module declaration for the Doxygen output. Also contains the content of the main page and related pages.

Namespaces

- Tables

9.1.1 Detailed Description

Contains the module declaration for the Doxygen output. Also contains the content of the main page and related pages.

9.2 audio.h File Reference

Data Structures

- struct pack_audio_SLQSGetAudioProfile_t
- struct unpack_audio_SLQSGetAudioProfile_t
- struct pack_audio_SLQSSetAudioProfile_t
- struct pack_audio_SLQSGetAudioPathConfig_t
- struct audio_TXPCMIIRFltr
- struct audio_RXPCMIIRFltr
- struct audio_RXAGCList
- struct audio_RXAVCList
- struct audio_TXAGCList
- struct unpack_audio_SLQSGetAudioPathConfig_t
- struct pack_audio_SLQSSetAudioPathConfig_t
- struct pack_audio_SLQSGetAudioVolTLBConfig_t
- struct unpack_audio_SLQSGetAudioVolTLBConfig_t
- struct pack_audio_SLQSSetAudioVolTLBConfig_t
- struct unpack_audio_SLQSSetAudioVolTLBConfig_t

Functions

- int pack_audio_SLQSGetAudioProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSGetAudioProfile_t *pReqParam)
- int unpack_audio_SLQSGetAudioProfile (uint8_t *pResp, uint16_t respLen, unpack_audio_SLQSGetAudioProfile_t *pOutput)
- int pack_audio_SLQSSetAudioProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSSetAudioProfile_t *pReqParam)
- int unpack_audio_SLQSSetAudioProfile (uint8_t *pResp, uint16_t respLen)
- int pack_audio_SLQSGetAudioPathConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSGetAudioPathConfig_t *pReqParam)
- int unpack_audio_SLQSGetAudioPathConfig (uint8_t *pResp, uint16_t respLen, unpack_audio_SLQSGetAudioPathConfig_t *pOutput)
- int pack_audio_SLQSSetAudioPathConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSSetAudioPathConfig_t *pReqParam)
- int unpack_audio_SLQSSetAudioPathConfig (uint8_t *pResp, uint16_t respLen)
- int pack_audio_SLQSGetAudioVolTLBConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSGetAudioVolTLBConfig_t *pReqParam)
- int unpack_audio_SLQSGetAudioVolTLBConfig (uint8_t *pResp, uint16_t respLen, unpack_audio_SLQSGetAudioVolTLBConfig_t *pOutput)
- int pack_audio_SLQSSetAudioVolTLBConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSSetAudioVolTLBConfig_t *pReqParam)
- int unpack_audio_SLQSSetAudioVolTLBConfig (uint8_t *pResp, uint16_t respLen, unpack_audio_SLQSSetAudioVolTLBConfig_t *pOutput)

9.2.1 Function Documentation

9.2.1.1 int pack_audio_SLQSGetAudioPathConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSGetAudioPathConfig_t * *pReqParam*)

Gets the audio path configuration parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.2 int pack_audio_SLQSGetAudioProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSGetAudioProfile_t * *pReqParam*)

Gets get the profile content of the requested audio generator. pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.3 int pack_audio_SLQSGetAudioVolTLBConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSGetAudioVolTLBConfig_t * *pReqParam*)

Gets the audio VolTLB configuration parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.4 int pack_audio_SLQSSetAudioPathConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSSetAudioPathConfig_t * *pReqParam*)

sets the audio path configuration parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.5 int pack_audio_SLQSSetAudioProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSSetAudioProfile_t * *pReqParam*)

sets an audio profile pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.6 int pack_audio_SLQSSetAudioVoITLBConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSSetAudioVoITLBConfig_t * *pReqParam*)

Sets the audio VoITLB configuration parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.7 int unpack_audio_SLQSGetAudioPathConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_audio_SLQSGetAudioPathConfig_t * *pOutput*)

Gets the audio path configuration parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.2.1.8 int unpack_audio_SLQSGetAudioProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_audio_SLQSGetAudioProfile_t * *pOutput*)

Gets get the profile content of the requested audio generator unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.2.1.9 int unpack_audio_SLQSGetAudioVoITLBConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_audio_SLQSGetAudioVoITLBConfig_t * *pOutput*)

Gets the audio VoITLB configuration parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.2.1.10 int unpack_audio_SLQSSetAudioPathConfig (uint8_t * *pResp*, uint16_t *respLen*)

sets the audio path configuration parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.2.1.11 int unpack_audio_SLQSSetAudioProfile (uint8_t * *pResp*, uint16_t *respLen*)

sets an audio profile unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.2.1.12 int unpack_audio_SLQSSetAudioVolTLBConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_audio_SLQSSetAudioVolTLBConfig_t * *pOutput*)

Sets the audio VolTLB configuration parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3 cat.h File Reference

Data Structures

- struct pack_cat_SetCATEventCallback_t
- struct unpack_cat_SetCATEventCallback_t
- struct cat_EventIDDataTlv
- struct cat_AlPhaIdentifierTlv
- struct cat_EventListTlv
- struct cat_RefreshTlv
- struct cat_EndProactiveSessionTlv
- union cat_currentCatEvent
- struct cat_commonEventTlv
- struct unpack_cat_SetCatEventCallback_ind_t
- struct pack_cat_CATSendEnvelopeCommand_t
- struct pack_cat_CATSendTerminalResponse_t

Macros

- #define CAT_EVENT_DATA_MAX_LENGTH 255
- #define CAN_COMMON_EVENT_TLV_NUMBER 11

Functions

- int pack_cat_SetCATEventCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_cat_SetCATEventCallback_t *reqArg)
- int unpack_cat_SetCATEventCallback (uint8_t *pResp, uint16_t respLen, unpack_cat_SetCATEventCallback_t *pOutput)
- int unpack_cat_SetCatEventCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_cat_SetCatEventCallback_ind_t *pOutput)
- int pack_cat_CATSendEnvelopeCommand (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_cat_CATSendEnvelopeCommand_t *reqArg)
- int unpack_cat_CATSendEnvelopeCommand (uint8_t *pResp, uint16_t respLen)
- int pack_cat_CATSendTerminalResponse (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_cat_CATSendTerminalResponse_t *reqArg)
- int unpack_cat_CATSendTerminalResponse (uint8_t *pResp, uint16_t respLen)

9.3.1 Macro Definition Documentation

9.3.1.1 #define CAN_COMMON_EVENT_TLV_NUMBER 11

9.3.1.2 #define CAT_EVENT_DATA_MAX_LENGTH 255

9.3.2 Function Documentation

9.3.2.1 int pack_cat_CATSendEnvelopeCommand (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_cat_CATSendEnvelopeCommand_t * *reqArg*)

Sends the envelope command to the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.2.2 int pack_cat_CATSendTerminalResponse (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_cat_CATSendTerminalResponse_t * *reqArg*)

Sends the terminal response to the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter •

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.2.3 int pack_cat_SetCATEventCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_cat_SetCATEventCallback_t * *reqArg*)

Enables/disables the CAT event callback pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.2.4 int unpack_cat_CATSendEnvelopeCommand (uint8_t * *pResp*, uint16_t *respLen*)

Sends the envelope command to the device unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.2.5 int unpack_cat_CATSendTerminalResponse (uint8_t * *pResp*, uint16_t *respLen*)

Sends the terminal response to the device unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.2.6 int unpack_cat_SetCATEventCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_cat_SetCATEventCallback_t * *pOutput*)

Enables/disables the CAT event callback unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.2.7 int unpack_cat_SetCatEventCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_cat_SetCatEventCallback_ind_t * *pOutput*)

CAT event indication unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.4 common.h File Reference

Data Structures

- struct pack_qmi_t
- struct unpack_qmi_t

Macros

- #define SDU_HDR_LEN (3)
- #define MINREQBKLEN (2048)
- #define MSGID_AND_LEN (4)
- #define MSGID_DONT_CARE (0xffff)
- #define UNUSEDPARAM(x) (void)x
- #define DEAULT_LOC_TIMEOUT_IN_SEC 2
- #define SDK_VALIDATE_INPUT_PACK_PARAM(pCtx, pBuf, pLen)
- #define SDK_VALIDATE_INPUT_PACK_PARAM_AND_FILL_XID(pCtx, pBuf, pLen)
- #define SDK_VALIDATE_INPUT_UNPACK_PARAM(pResp, respLen, pOutput)

Typedefs

- typedef void(* logger)(uint8_t lvl, const char *buff)

Enumerations

- enum eLOG_LEVEL {
  eLOG_INFO,
  eLOG_DEBUG,
  eLOG_WARN,
  eLOG_FATAL }
- enum eTimeout {
  eTIMEOUT_2_S = 2000,
  eTIMEOUT_5_S = 5000,
  eTIMEOUT_8_S = 8000,
  eTIMEOUT_10_S = 10000,
  eTIMEOUT_20_S = 20000,
  eTIMEOUT_30_S = 30000,
  eTIMEOUT_60_S = 60000,
  eTIMEOUT_300_S = 300000,
  eTIMEOUT_DEFAULT = eTIMEOUT_8_S }
- enum eQMI_SVC {
  eCTL,
  eWDS,
  eDMS,
  eNAS =3,
  eQOS,
  eSMS =5,
  ePDS =0x06,
  eVOICE =0x09,
  eCAT =0x0A,
  eUIM =0x0B,
  eLOC =0x10,
  eSAR =0x11,
  eIMS =0x12,
  eTMD =0x18,
  eIMSA =0x21,
  eRMS =225,
  eSWIOMA =240,
  eAUDIO =241,
  eSWIM2MCMD =243,
  eSWIOMAEXT =244,
  eSWIAUDIO = 245,
  eSWILOC =246 }
- enum msgtype {
  eREQ =0,
  eRSP =2,
  eIND =4 }

Functions

- uint16_t helper_get_xid (uint8_t *qmi_resp)
- const char * helper_get_resp_ctx (uint8_t svc, uint8_t *pbuf, uint32_t len, unpack_qmi_t *pCtx)
- unsigned unpack_result_code_only (uint8_t *pMdmResp)
- int helper_set_log_func (logger func)
- void liteqmi_log (uint8_t lvl, const char *fmt,...)
- int helper_set_log_lvl (uint8_t lvl)
- void fill_sdu_hdr (pack_qmi_t *pCtx, uint8_t *pReqBuf)
- void fill_pack_ctx (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, uint8_t svc, int timeout)
- char * get_version ()
- char * liteqmi_GetVersion ()

- void liteqmi_helper_decode7bitAsciiEncString (uint8_t *encoded_str, uint8_t encoded_len, uint8_t *decoded_str)

Variables

- logger glog
- uint8_t gloglvl

9.4.1 Macro Definition Documentation

9.4.1.1 #define DEAULT_LOC_TIMEOUT_IN_SEC 2

9.4.1.2 #define MINREQBKLEN (2048)

9.4.1.3 #define MSGID_AND_LEN (4)

9.4.1.4 #define MSGID_DONT_CARE (0xffff)

9.4.1.5 #define SDK_VALIDATE_INPUT_PACK_PARAM(*pCtx, pBuf, pLen*)

Value:

```
if ((pCtx == NULL) || (pBuf == NULL) || (pLen == NULL) ) \
        {\
        liteqmi_log(eLOG_DEBUG,"[  pack] %s parameter NULL\n",__func__); \
        return eQCWWAN_ERR_INVALID_ARG; \
        }
```

9.4.1.6 #define SDK_VALIDATE_INPUT_PACK_PARAM_AND_FILL_XID(*pCtx, pBuf, pLen*)

Value:

```
if ((pCtx == NULL) || (pBuf == NULL) || (pLen == NULL) ) \
        {\
        liteqmi_log(eLOG_DEBUG,"[  pack] %s parameter NULL\n",__func__); \
        return eQCWWAN_ERR_INVALID_ARG; \
        } \
    if (pCtx->xid == 0) \
       return eQCWWAN_ERR_INVALID_XID; \
    pBuf[0] = eREQ; \
    pBuf[1] = pCtx->xid & 0xff; \
    pBuf[2] = pCtx->xid >> 8;
```

9.4.1.7 #define SDK_VALIDATE_INPUT_UNPACK_PARAM(*pResp, respLen, pOutput*)

Value:

```
if ((pResp == NULL) || (respLen == 0) || (pOutput == NULL) ) \
        {\
        liteqmi_log(eLOG_DEBUG,"[ unpack] %s parameter NULL or invalid\n",
      __func__); \
        return eQCWWAN_ERR_INVALID_ARG; \
        }
```

9.4.1.8 #define SDU_HDR_LEN (3)

9.4.1.9 #define UNUSEDPARAM(x) (void)x

9.4.2 Typedef Documentation

9.4.2.1 typedef void(∗ logger)(uint8_t lvl, const char ∗buff)

9.4.3 Enumeration Type Documentation

9.4.3.1 enum eLOG_LEVEL

log levels

Enumerator

eLOG_INFO

eLOG_DEBUG

eLOG_WARN

eLOG_FATAL

9.4.3.2 enum eQMI_SVC

qmi service

Enumerator

eCTL

eWDS

eDMS

eNAS

eQOS

eSMS

ePDS

eVOICE

eCAT

eUIM

eLOC

eSAR

eIMS

eTMD

eIMSA

eRMS

eSWIOMA

eAUDIO

eSWIM2MCMD

eSWIOMAEXT

eSWIAUDIO

eSWILOC

9.4.3.3 enum eTimeout

eTimeout

Enumerator

eTIMEOUT_2_S

eTIMEOUT_5_S

eTIMEOUT_8_S

eTIMEOUT_10_S

eTIMEOUT_20_S

eTIMEOUT_30_S

eTIMEOUT_60_S

eTIMEOUT_300_S

eTIMEOUT_DEFAULT

9.4.3.4 enum msgtype

qmi message type

Enumerator

eREQ

eRSP

eIND

9.4.4 Function Documentation

9.4.4.1 void fill_pack_ctx (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen,* uint8_t *svc,* int *timeout*)

9.4.4.2 void fill_sdu_hdr (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf*)

9.4.4.3 char* get_version ( )

Returns

version string

9.4.4.4 const char* helper_get_resp_ctx (uint8_t *svc,* uint8_t * *pbuf,* uint32_t *len,* unpack_qmi_t * *pCtx*)

extract msgid/xid/type from modem reply

Parameters

in	*svc*	qmi service
in	*pbuf*	qmi response/indication
in	*len*	response/indication length
out	*pCtx*	unpacked context

Returns

qmi message string

9.4.4.5 uint16_t helper_get_xid (uint8_t * *qmi_resp*)

9.4.4.6 int helper_set_log_func (logger *func*)

set log function

9.4.4.7 int helper_set_log_lvl (uint8_t *lvl*)

set log level

9.4.4.8 char* liteqmi_GetVersion ( )

Returns

version string

9.4.4.9 void liteqmi_helper_decode7bitAsciiEncString (uint8_t * *encoded_str,* uint8_t *encoded_len,* uint8_t * *decoded_str*)

decode 7bit encoded string

Parameters

in	*encoded_str*	7 bit encoded ASCII
in	*encoded_len*	encoded length
out	*decoded_str*	decoded ASCII string

9.4.4.10 void liteqmi_log (uint8_t *lvl,* const char * *fmt,* ...)

9.4.4.11 unsigned unpack_result_code_only (uint8_t * *pMdmResp*)

common handler for unpacking response with TLV type 0x02 only

9.4.5 Variable Documentation

9.4.5.1 logger glog

9.4.5.2 uint8_t gloglvl

9.5 dms.h File Reference

Data Structures

- struct unpack_dms_GetModelID_t
- struct unpack_dms_GetIMSI_t
- struct unpack_dms_GetFirmwareInfo_t
- struct unpack_dms_GetPower_t
- struct unpack_dms_GetSerialNumbers_t
- struct unpack_dms_GetHardwareRevision_t
- struct unpack_dms_SLQSGetBandCapability_t
- struct unpack_dms_GetDeviceCapabilities_t
- struct unpack_dms_GetFirmwareRevisions_t
- struct unpack_dms_GetFirmwareRevision_t

- struct unpack_dms_GetDeviceSerialNumbers_t
- struct unpack_dms_GetPRLVersion_t
- struct unpack_dms_GetNetworkTime_t
- struct unpack_dms_GetVoiceNumber_t
- struct unpack_dms_GetDeviceHardwareRev_t
- struct unpack_dms_GetFSN_t
- struct unpack_dms_GetDeviceCap_t
- struct pack_dms_SetPower_t
- struct unpack_dms_SetPower_t
- struct unpack_dms_GetBandCapability_t
- struct unpack_dms_GetUSBComp_t
- struct pack_dms_SetUSBComp_t
- struct unpack_dms_SetUSBComp_t
- struct pack_dms_SetCustFeature_t
- struct unpack_dms_SetCustFeature_t
- struct unpack_dms_GetCustFeature_t
- struct unpack_dms_SetFirmwarePreference_t
- struct unpack_dms_GetCrashAction_t
- struct pack_dms_SetCrashAction_t
- struct unpack_dms_SetCrashAction_t
- struct unpack_dms_GetDeviceMfr_t
- struct pack_dms_SetEventReport_t
- struct unpack_dms_SetEventReport_t
- struct dms_OperatingModeTlv
- struct dms_ActivationStatusTlv
- struct unpack_dms_SetEventReport_ind_t
- struct pack_dms_UIMGetICCID_t
- struct unpack_dms_UIMGetICCID_t
- struct pack_dms_SetCustFeaturesV2_t
- struct unpack_dms_SetCustFeaturesV2_t
- struct pack_dms_GetCustFeaturesV2_t
- struct DMSgetCustomInput
- struct DMScustSettingInfo
- struct DMScustSettingList
- struct DMSgetCustomFeatureV2
- struct unpack_dms_GetCustFeaturesV2_t
- struct unpack_dms_GetActivationState_t
- struct image_info_t
- struct unpack_dms_SLQSSwiGetFirmwareCurr_t
- struct pack_dms_SLQSSwiSetDyingGaspCfg_t
- struct unpack_dms_SLQSSwiSetDyingGaspCfg_t
- struct unpack_dms_SLQSSwiClearDyingGaspStatistics_t
- struct packgetDyingGaspStatistics
- struct unpack_dms_SLQSSwiGetDyingGaspStatistics_t
- struct packgetDyingGaspCfg
- struct unpack_dms_SLQSSwiGetDyingGaspCfg_t
- struct unpack_dms_SLQSDmsSwiGetResetInfo_t
- struct unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t
- struct pack_dms_SLQSDmsSwiIndicationRegister_t
- struct unpack_dms_SLQSDmsSwiIndicationRegister_t
- struct unpack_dms_SLQSSwiGetFwUpdateStatus_t
- struct unpack_dms_GetManufacturer_t
- struct unpack_dms_GetOfflineReason_t
- struct pack_dms_SetActivationStatusCallback_t
- struct unpack_dms_SetActivationStatusCallback_t

- struct pack_dms_UIMSetPINProtection_t
- struct unpack_dms_UIMSetPINProtection_t
- struct pack_dms_UIMUnblockPIN_t
- struct pack_dms_UIMVerifyPIN_t
- struct pack_dms_UIMChangePIN_t
- struct pack_dms_UIMGetControlKeyStatus_t
- struct unpack_dms_UIMGetControlKeyStatus_t
- struct unpack_dms_UIMGetPINStatus_t
- struct pack_dms_UIMSetControlKeyProtection_t
- struct unpack_dms_UIMSetControlKeyProtection_t
- struct pack_dms_UIMUnblockControlKey_t
- struct unpack_dms_UIMUnblockControlKey_t
- struct pack_dms_ResetToFactoryDefaults_t
- struct unpack_dms_ResetToFactoryDefaults_t
- struct pack_dms_ActivateAutomatic_t
- struct eriDataparams
- struct unpack_dms_SLQSGetERIFile_t
- struct unpack_dms_SLQSUIMGetState_t
- struct pack_dms_SLQSSwiGetCrashInfo_t
- struct crashInformation
- struct crashInfoParams
- struct unpack_dms_SLQSSwiGetCrashInfo_t
- struct unpack_dms_SLQSSwiGetHostDevInfo_t
- struct pack_dms_SLQSSwiSetHostDevInfo_t
- struct unpack_dms_SLQSSwiSetHostDevInfo_t
- struct unpack_dms_SLQSSwiGetOSInfo_t
- struct pack_dms_SLQSSwiSetOSInfo_t
- struct unpack_dms_SLQSSwiSetOSInfo_t
- struct unpack_dms_SLQSSwiGetSerialNoExt_t

Macros

- #define DMS_UINT8_MAX_STRING_SZ 255
- #define DMS_MAX_CUST_ID_LEN 64
- #define DMS_MAX_CUST_VALUE_LEN 8
- #define DMS_IMGDETAILS_LEN 16
- #define DMS_MAX_FWUPDATE_LOG_STR_SZ 255
- #define DMS_MAX_FWUPDATE_REF_STR_SZ 15
- #define DMS_VALID_FSN_LEN 14
- #define DMS_MAX_RADIO_IFCS_SIZE 64
- #define DMS_SLQSFWINFO_MODELID_SZ 20
- #define DMS_SLQSFWINFO_BOOTVERSION_SZ 85
- #define DMS_SLQSFWINFO_APPVERSION_SZ 85
- #define DMS_SLQSFWINFO_SKU_SZ 15
- #define DMS_SLQSFWINFO_PACKAGEID_SZ 85
- #define DMS_SLQSFWINFO_CARRIER_SZ 20
- #define DMS_SLQSFWINFO_PRIVERSION_SZ 16
- #define DMS_SLQSFWINFO_CUR_CARR_NAME 17
- #define DMS_SLQSFWINFO_CUR_CARR_REV 13
- #define MAX_BUILD_ID_LEN 255
- #define UNIQUE_ID_LEN 16
- #define SLQS_MAX_DYING_GASP_CFG_SMS_CONTENT_LENGTH 160
- #define SLQS_MAX_DYING_GASP_CFG_SMS_NUMBER_LENGTH 20
- #define SPC_SIZE 6

- #define CK_MAX_SIZE 8
- #define ACT_CODE_MAX_SIZE 81
- #define ERI_DATA_MAX_SIZE 1024
- #define MEID_MAX_SIZE 8
- #define DMS_PM_ONLINE 0x00 /* Online */
- #define DMS_PM_LOW 0x01 /* Low Power */
- #define DMS_PM_FACTORY 0x02 /* Factory Test Mode */
- #define DMS_PM_OFFLINE 0x03 /* Offline */
- #define DMS_PM_RESET 0x04 /* Reset */
- #define DMS_PM_SHUT_DOWN 0x05 /* Shut Down */
- #define DMS_PM_PERSISTENT_LOW 0x06 /* Persistent Low Power */
- #define DMS_SET_REPORT_ENABLE 1
- #define DMS_SET_REPORT_DISABLE 0
- #define DMS_SWI_SET_IND_ENABLE 1
- #define DMS_SWI_SET_IND_DISABLE 0

Functions

- int pack_dms_GetIMSI (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetIMSI (uint8_t *pResp, uint16_t respLen, unpack_dms_GetIMSI_t *pOutput)
- int pack_dms_GetModelID (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetModelID (uint8_t *pResp, uint16_t respLen, unpack_dms_GetModelID_t *pOutput)
- int pack_dms_GetFirmwareInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetFirmwareInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_GetFirmwareInfo_t *pOutput)
- int pack_dms_GetPower (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetPower (uint8_t *pResp, uint16_t respLen, unpack_dms_GetPower_t *pOutput)
- int pack_dms_GetSerialNumbers (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetSerialNumbers (uint8_t *pResp, uint16_t respLen, unpack_dms_GetSerialNumbers_t *pOutput)
- int pack_dms_GetHardwareRevision (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetHardwareRevision (uint8_t *pResp, uint16_t respLen, unpack_dms_GetHardwareRevision_t *pOutput)
- int pack_dms_SLQSGetBandCapability (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_SLQSGetBandCapability (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSGetBandCapability_t *pOutput)
- int pack_dms_GetDeviceCapabilities (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetDeviceCapabilities (uint8_t *pResp, uint16_t respLen, unpack_dms_GetDeviceCapabilities_t *pOutput)
- int pack_dms_GetFirmwareRevisions (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetFirmwareRevisions (uint8_t *pResp, uint16_t respLen, unpack_dms_GetFirmwareRevisions_t *pOutput)
- int pack_dms_GetFirmwareRevision (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetFirmwareRevision (uint8_t *pResp, uint16_t respLen, unpack_dms_GetFirmwareRevision_t *pOutput)
- int pack_dms_GetDeviceSerialNumbers (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetDeviceSerialNumbers (uint8_t *pResp, uint16_t respLen, unpack_dms_GetDeviceSerialNumbers_t *pOutput)
- int pack_dms_GetPRLVersion (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetPRLVersion (uint8_t *pResp, uint16_t respLen, unpack_dms_GetPRLVersion_t *pOutput)
- int pack_dms_GetNetworkTime (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetNetworkTime (uint8_t *pResp, uint16_t respLen, unpack_dms_GetNetworkTime_t *pOutput)
- int pack_dms_GetVoiceNumber (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)

- int unpack_dms_GetVoiceNumber (uint8_t *pResp, uint16_t respLen, unpack_dms_GetVoiceNumber_t *pOutput)
- int pack_dms_GetDeviceHardwareRev (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetDeviceHardwareRev (uint8_t *pResp, uint16_t respLen, unpack_dms_GetDeviceHardwareRev_t *pOutput)
- int pack_dms_GetFSN (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetFSN (uint8_t *pResp, uint16_t respLen, unpack_dms_GetFSN_t *pOutput)
- int pack_dms_GetDeviceCap (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetDeviceCap (uint8_t *pResp, uint16_t respLen, unpack_dms_GetDeviceCap_t *pOutput)
- int pack_dms_SetPower (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetPower_t *reqArg)
- int unpack_dms_SetPower (uint8_t *pResp, uint16_t respLen, unpack_dms_SetPower_t *pOutput)
- int pack_dms_GetBandCapability (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetBandCapability (uint8_t *pResp, uint16_t respLen, unpack_dms_GetBandCapability_t *pOutput)
- int pack_dms_GetUSBComp (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetUSBComp (uint8_t *pResp, uint16_t respLen, unpack_dms_GetUSBComp_t *pOutput)
- int pack_dms_SetUSBComp (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetUSBComp_t *reqArg)
- int unpack_dms_SetUSBComp (uint8_t *pResp, uint16_t respLen, unpack_dms_SetUSBComp_t *pOutput)
- int pack_dms_SetCustFeature (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetCustFeature_t *reqArg)
- int unpack_dms_SetCustFeature (uint8_t *pResp, uint16_t respLen, unpack_dms_SetCustFeature_t *pOutput)
- int pack_dms_GetCustFeature (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetCustFeature (uint8_t *pResp, uint16_t respLen, unpack_dms_GetCustFeature_t *pOutput)
- int pack_dms_SetFirmwarePreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_SetFirmwarePreference (uint8_t *pResp, uint16_t respLen, unpack_dms_SetFirmwarePreference_t *pOutput)
- int pack_dms_GetCrashAction (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetCrashAction (uint8_t *pResp, uint16_t respLen, unpack_dms_GetCrashAction_t *pOutput)
- int pack_dms_SetCrashAction (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetCrashAction_t reqArg)
- int unpack_dms_SetCrashAction (uint8_t *pResp, uint16_t respLen, unpack_dms_SetCrashAction_t *pOutput)
- int pack_dms_GetDeviceMfr (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetDeviceMfr (uint8_t *pResp, uint16_t respLen, unpack_dms_GetDeviceMfr_t *pOutput)
- int pack_dms_SetEventReport (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetEventReport_t *reqArg)
- int unpack_dms_SetEventReport (uint8_t *pResp, uint16_t respLen, unpack_dms_SetEventReport_t *pOutput)
- int unpack_dms_SetEventReport_ind (uint8_t *pResp, uint16_t respLen, unpack_dms_SetEventReport_ind_t *pOutput)
- int pack_dms_UIMGetICCID (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMGetICCID_t *reqArg)
- int unpack_dms_UIMGetICCID (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMGetICCID_t *pOutput)
- int pack_dms_SetCustFeaturesV2 (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetCustFeaturesV2_t *reqArg)
- int unpack_dms_SetCustFeaturesV2 (uint8_t *pResp, uint16_t respLen, unpack_dms_SetCustFeaturesV2_t *pOutput)
- int pack_dms_GetCustFeaturesV2 (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_GetCustFeaturesV2_t *reqArg)
- int unpack_dms_GetCustFeaturesV2 (uint8_t *pResp, uint16_t respLen, unpack_dms_GetCustFeaturesV2_t *pOutput)

- int pack_dms_GetActivationState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_GetActivationState (uint8_t *pResp, uint16_t respLen, unpack_dms_GetActivationState_t *pOutput)
- int pack_dms_SLQSSwiGetFirmwareCurr (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetFirmwareCurr (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetFirmwareCurr_t *pOutput)
- int pack_dms_SLQSSwiSetDyingGaspCfg (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SLQSSwiSetDyingGaspCfg_t *reqArg)
- int unpack_dms_SLQSSwiSetDyingGaspCfg (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiSetDyingGaspCfg_t *pOutput)
- int pack_dms_SLQSSwiClearDyingGaspStatistics (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiClearDyingGaspStatistics (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiClearDyingGaspStatistics_t *pOutput)
- int pack_dms_SLQSSwiGetDyingGaspStatistics (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetDyingGaspStatistics (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetDyingGaspStatistics_t *pOutput)
- int pack_dms_SLQSSwiGetDyingGaspCfg (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetDyingGaspCfg (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetDyingGaspCfg_t *pOutput)
- int pack_dms_SLQSDmsSwiGetResetInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSDmsSwiGetResetInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSDmsSwiGetResetInfo_t *pOutput)
- int unpack_dms_SLQSDmsSwiGetResetInfo_Ind (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t *pOutput)
- int pack_dms_SLQSDmsSwiIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SLQSDmsSwiIndicationRegister_t *reqArg)
- int unpack_dms_SLQSDmsSwiIndicationRegister (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSDmsSwiIndicationRegister_t *pOutput)
- int pack_dms_SLQSSwiGetFwUpdateStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetFwUpdateStatus (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetFwUpdateStatus_t *pOutput)
- int pack_dms_GetManufacturer (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_GetManufacturer (uint8_t *pResp, uint16_t respLen, unpack_dms_GetManufacturer_t *pOutput)
- int pack_dms_GetOfflineReason (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_GetOfflineReason (uint8_t *pResp, uint16_t respLen, unpack_dms_GetOfflineReason_t *pOutput)
- int pack_dms_SetActivationStatusCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetActivationStatusCallback_t *reqArg)
- int unpack_dms_SetActivationStatusCallback (uint8_t *pResp, uint16_t respLen, unpack_dms_SetActivationStatusCallback_t *pOutput)
- int pack_dms_UIMSetPINProtection (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMSetPINProtection_t *pReq)
- int unpack_dms_UIMSetPINProtection (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMSetPINProtection_t *pOutput)
- int pack_dms_UIMUnblockPIN (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMUnblockPIN_t *pReq)
- int unpack_dms_UIMUnblockPIN (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMSetPINProtection_t *pOutput)
- int pack_dms_UIMVerifyPIN (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMVerifyPIN_t *pReq)
- int unpack_dms_UIMVerifyPIN (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMSetPINProtection_t *pOutput)
- int pack_dms_UIMChangePIN (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMChangePIN_t *pReq)

- int unpack_dms_UIMChangePIN (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMSetPINProtection_t *pOutput)
- int pack_dms_UIMGetControlKeyStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMGetControlKeyStatus_t *pReq)
- int unpack_dms_UIMGetControlKeyStatus (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMGetControlKeyStatus_t *pOutput)
- int pack_dms_UIMGetPINStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_UIMGetPINStatus (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMGetPINStatus_t *pOutput)
- int pack_dms_UIMSetControlKeyProtection (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMSetControlKeyProtection_t *pReq)
- int unpack_dms_UIMSetControlKeyProtection (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMSetControlKeyProtection_t *pOutput)
- int pack_dms_UIMUnblockControlKey (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMUnblockControlKey_t *pReq)
- int unpack_dms_UIMUnblockControlKey (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMUnblockControlKey_t *pOutput)
- int pack_dms_ResetToFactoryDefaults (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_ResetToFactoryDefaults_t *pReq)
- int unpack_dms_ResetToFactoryDefaults (uint8_t *pResp, uint16_t respLen, unpack_dms_ResetToFactoryDefaults_t *pOutput)
- int pack_dms_ValidateSPC (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_ResetToFactoryDefaults_t *pReq)
- int unpack_dms_ValidateSPC (uint8_t *pResp, uint16_t respLen, unpack_dms_ResetToFactoryDefaults_t *pOutput)
- int pack_dms_ActivateAutomatic (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_ActivateAutomatic_t *pReq)
- int unpack_dms_ActivateAutomatic (uint8_t *pResp, uint16_t respLen, unpack_dms_ResetToFactoryDefaults_t *pOutput)
- int pack_dms_SLQSGetERIFile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSGetERIFile (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSGetERIFile_t *pOutput)
- int pack_dms_SLQSUIMGetState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSUIMGetState (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSUIMGetState_t *pOutput)
- int pack_dms_SLQSSwiGetCrashInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SLQSSwiGetCrashInfo_t *pReq)
- int unpack_dms_SLQSSwiGetCrashInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetCrashInfo_t *pOutput)
- int pack_dms_SLQSSwiGetHostDevInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetHostDevInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetHostDevInfo_t *pOutput)
- int pack_dms_SLQSSwiSetHostDevInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SLQSSwiSetHostDevInfo_t *pReq)
- int unpack_dms_SLQSSwiSetHostDevInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiSetHostDevInfo_t *pOutput)
- int pack_dms_SLQSSwiGetOSInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetOSInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetOSInfo_t *pOutput)
- int pack_dms_SLQSSwiSetOSInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SLQSSwiSetOSInfo_t *pReq)
- int unpack_dms_SLQSSwiSetOSInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiSetOSInfo_t *pOutput)
- int pack_dms_SLQSSwiGetSerialNoExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetSerialNoExt (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetSerialNoExt_t *pOutput)

9.5.1 Macro Definition Documentation

9.5.1.1 #define ACT_CODE_MAX_SIZE 81

9.5.1.2 #define CK_MAX_SIZE 8

9.5.1.3 #define DMS_IMGDETAILS_LEN 16

9.5.1.4 #define DMS_MAX_CUST_ID_LEN 64

9.5.1.5 #define DMS_MAX_CUST_VALUE_LEN 8

9.5.1.6 #define DMS_MAX_FWUPDATE_LOG_STR_SZ 255

9.5.1.7 #define DMS_MAX_FWUPDATE_REF_STR_SZ 15

9.5.1.8 #define DMS_MAX_RADIO_IFCS_SIZE 64

9.5.1.9 #define DMS_PM_FACTORY 0x02 /∗ Factory Test Mode ∗/

9.5.1.10 #define DMS_PM_LOW 0x01 /∗ Low Power ∗/

9.5.1.11 #define DMS_PM_OFFLINE 0x03 /∗ Offline ∗/

9.5.1.12 #define DMS_PM_ONLINE 0x00 /∗ Online ∗/

9.5.1.13 #define DMS_PM_PERSISTENT_LOW 0x06 /∗ Persistent Low Power ∗/

9.5.1.14 #define DMS_PM_RESET 0x04 /∗ Reset ∗/

9.5.1.15 #define DMS_PM_SHUT_DOWN 0x05 /∗ Shut Down ∗/

9.5.1.16 #define DMS_SET_REPORT_DISABLE 0

9.5.1.17 #define DMS_SET_REPORT_ENABLE 1

9.5.1.18 #define DMS_SLQSFWINFO_APPVERSION_SZ 85

9.5.1.19 #define DMS_SLQSFWINFO_BOOTVERSION_SZ 85

9.5.1.20 #define DMS_SLQSFWINFO_CARRIER_SZ 20

9.5.1.21 #define DMS_SLQSFWINFO_CUR_CARR_NAME 17

9.5.1.22 #define DMS_SLQSFWINFO_CUR_CARR_REV 13

9.5.1.23 #define DMS_SLQSFWINFO_MODELID_SZ 20

9.5.1.24 #define DMS_SLQSFWINFO_PACKAGEID_SZ 85

9.5.1.25 #define DMS_SLQSFWINFO_PRIVERSION_SZ 16

9.5.1.26 #define DMS_SLQSFWINFO_SKU_SZ 15

9.5.1.27 #define DMS_SWI_SET_IND_DISABLE 0

9.5.1.28 #define DMS_SWI_SET_IND_ENABLE 1

9.5.1.29 #define DMS_UINT8_MAX_STRING_SZ 255

9.5.1.30 #define DMS_VALID_FSN_LEN 14

9.5.1.31 #define ERI_DATA_MAX_SIZE 1024

9.5.1.32 #define MAX_BUILD_ID_LEN 255

9.5.1.33 #define MEID_MAX_SIZE 8

9.5.1.34 #define SLQS_MAX_DYING_GASP_CFG_SMS_CONTENT_LENGTH 160

9.5.1.35 #define SLQS_MAX_DYING_GASP_CFG_SMS_NUMBER_LENGTH 20

9.5.1.36 #define SPC_SIZE 6

9.5.1.37 #define UNIQUE_ID_LEN 16

9.5.2 Function Documentation

9.5.2.1 int pack_dms_ActivateAutomatic (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_ActivateAutomatic_t * *pReq*)

Requests the device to perform automatic service activation pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.2 int pack_dms_GetActivationState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get Activation State pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.3 int pack_dms_GetBandCapability (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Band Capability pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.4 int pack_dms_GetCrashAction (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Crash Action pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.5 int pack_dms_GetCustFeature (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Custom Feature pack. This API is deprecated for EM74xx/MC74xx, please use pack_dms_GetCustFeatures-V2() instead for EM74xx/MC74xx.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.6 int pack_dms_GetCustFeaturesV2 (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_GetCustFeaturesV2_t * *reqArg*)

Get Custom Feature pack This function queries the modem for a list of supported features. This function is for firmware version 2.0 and newer. Currently supported Customization features:

- GPIOSARENABLE
- GPSSEL
- IMSWITCHHIDE
- IPV6ENABLE
- WAKEHOSTEN

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.7 int pack_dms_GetDeviceCap (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Device Capabilities pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.8 int pack_dms_GetDeviceCapabilities (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get device capability pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.9 int pack_dms_GetDeviceHardwareRev (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Hardware Revision of the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.10 int pack_dms_GetDeviceMfr (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Device Manufacture Name pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.11 int pack_dms_GetDeviceSerialNumbers (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Device Serial Number pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.12 int pack_dms_GetFirmwareInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get firmware info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.13 int pack_dms_GetFirmwareRevision (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Firmware Revision pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.14 int pack_dms_GetFirmwareRevisions (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Firmware Revisions pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.15 int pack_dms_GetFSN (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get FSN pack. This API get the Factory Sequence Number of the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.16 int pack_dms_GetHardwareRevision (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get hardware revision of the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.17 int pack_dms_GetIMSI (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get IMSI pack. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_-xx_xx and all EM74xx firmware versions. Please use pack_uim_ReadTransparent()(EF ID: 3F00 7F20 6F07 for 2G card and 3F00 7FFF 6F07 for 3G card) instead for new firmware versions and new modules.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.18 int pack_dms_GetManufacturer (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get device manufacturer information pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.19 int pack_dms_GetModelID (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get model id pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.20 int pack_dms_GetNetworkTime (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Network Time pack Returns the current time of the device based on the value supported by the network.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.21 int pack_dms_GetOfflineReason (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get operating mode offline reason pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.22 int pack_dms_GetPower (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get operating mode of the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.23 int pack_dms_GetPRLVersion (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get PRL Versions pack. Return version of the active Preferred Roaming List (PRL) in use by the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.24 int pack_dms_GetSerialNumbers (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get serial numbers pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.25 int pack_dms_GetUSBComp (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get USB Comp pack This API queries the modem's USB interface configuration and supported configuration parameters.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.26 int pack_dms_GetVoiceNumber (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Voice Number pack. Returns the voice number in use by the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.27 int pack_dms_ResetToFactoryDefaults (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_ResetToFactoryDefaults_t * *pReq*)

Resets to default factory settings of the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.28 int pack_dms_SetActivationStatusCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetActivationStatusCallback_t * *reqArg*)

Set activation status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.29 int pack_dms_SetCrashAction (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetCrashAction_t *reqArg*)

Set Crash Action pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.30 int pack_dms_SetCustFeature (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetCustFeature_t * *reqArg*)

Set Custom Feature pack. This API is deprecated for EM74xx/MC74xx, please use pack_dms_SetCustFeatures-V2() instead for EM74xx/MC74xx.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.31 int pack_dms_SetCustFeaturesV2 (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetCustFeaturesV2_t * *reqArg*)

Set Cust Features pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.32 int pack_dms_SetEventReport (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetEventReport_t * *reqArg*)

Set Event Report pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.33 int pack_dms_SetFirmwarePreference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Set Firmware Preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.34 int pack_dms_SetPower (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetPower_t * *reqArg*)

Set Power pack Sets the operating mode of the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.35 int pack_dms_SetUSBComp (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetUSBComp_t * *reqArg*)

Set USB Comp pack This API is used to change the modem's USB interface configuration thus allowing a device to have multiple USB compositions. Devices will, by default, be configured to support a minimal set of interfaces to reduce end user modem installation time. Developers and some customers, however, require access to a custom set of interfaces. A reset is required for any change in the USB composition to take effect.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.36 int pack_dms_SLQSDmsSwiGetResetInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get reset info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.37 int pack_dms_SLQSDmsSwiIndicationRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SLQSDmsSwiIndicationRegister_t * *reqArg*)

Set the registration state for different indication pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

support EM/MC74xx onwards

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.38 int pack_dms_SLQSGetBandCapability (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get band capability of the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.39 int pack_dms_SLQSGetERIFile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To set UIM Get ERI file pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.40 int pack_dms_SLQSSwiClearDyingGaspStatistics (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Clear Dying GASP Statistics pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.41 int pack_dms_SLQSSwiGetCrashInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SLQSSwiGetCrashInfo_t * *pReq*)

To Get the Crash Information from the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.42 int pack_dms_SLQSSwiGetDyingGaspCfg (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get Dying GASP Config pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.43 int pack_dms_SLQSSwiGetDyingGaspStatistics (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get Dying GASP Statistics pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.44 int pack_dms_SLQSSwiGetFirmwareCurr (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get currently active image pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.45 int pack_dms_SLQSSwiGetFwUpdateStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get Firmware Update status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.46 int pack_dms_SLQSSwiGetHostDevInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get host dev information pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.47 int pack_dms_SLQSSwiGetOSInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To Get Host OS Info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.48 int pack_dms_SLQSSwiGetSerialNoExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get serial number extension pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.49 int pack_dms_SLQSSwiSetDyingGaspCfg (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SLQSSwiSetDyingGaspCfg_t * *reqArg*)

Set Dying GASP Config pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.50 int pack_dms_SLQSSwiSetHostDevInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SLQSSwiSetHostDevInfo_t * *pReq*)

To set Host Dev Info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.51 int pack_dms_SLQSSwiSetOSInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SLQSSwiSetOSInfo_t * *pReq*)

To set Host OS Info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.52 int pack_dms_SLQSUIMGetState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Returns the UIM state pack. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use API unpack_uim_GetCardStatus/ unpack_uim_GetCardStatus for new firmware versions and new modules

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.53 int pack_dms_UIMChangePIN (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMChangePIN_t * *pReq*)

To set UIM change PIN pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.54 int pack_dms_UIMGetControlKeyStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMGetControlKeyStatus_t * *pReq*)

To set UIM Get Control Key Status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.55 int pack_dms_UIMGetICCID (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMGetICCID_t * *reqArg*)

Packs the UIMGetICCID response message to a user-provided response structure. This API is deprecated on MC73xx/EM73xx modules. Since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use pack_uim_ReadTransparent()(EF ID: 3F00 2FE2) instead for new firmware versions and new modules.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.56 int pack_dms_UIMGetPINStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To set UIM Get PIN Status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.57 int pack_dms_UIMSetControlKeyProtection (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMSetControlKeyProtection_t * *pReq*)

To set UIM Set Control Key Protection pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.58 int pack_dms_UIMSetPINProtection (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMSetPINProtection_t * *pReq*)

To set UIM PIN protection pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.59 int pack_dms_UIMUnblockControlKey (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMUnblockControlKey_t * *pReq*)

To set UIM Unblock Control Key pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.60 int pack_dms_UIMUnblockPIN (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMUnblockPIN_t * *pReq*)

To set UIM unblock PIN pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.61 int pack_dms_UIMVerifyPIN (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMVerifyPIN_t * *pReq*)

To set UIM verify PIN pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.62 int pack_dms_ValidateSPC (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_ResetToFactoryDefaults_t * *pReq*)

Requests the device to perform automatic service activation pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.63 int unpack_dms_ActivateAutomatic (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_ResetToFactory-Defaults_t * *pOutput*)

Requests the device to perform automatic service activation unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.64 int unpack_dms_GetActivationState (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetActivationState_t * *pOutput*)

Get Activation State unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.65 int unpack_dms_GetBandCapability (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetBandCapability_t * *pOutput*)

Get Band Capabilities unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.66 int unpack_dms_GetCrashAction (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetCrashAction_t * *pOutput*)

Get Crash Action unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.67 int unpack_dms_GetCustFeature (uint8_t * *pResp*, uint16_t *respLen*, **unpack_dms_GetCustFeature_t** * *pOutput*)

Get Custom Feature unpack. This API is deprecated for EM74xx/MC74xx, please use unpack_dms_GetCustFeaturesV2() instead for EM74xx/MC74xx.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.68 int unpack_dms_GetCustFeaturesV2 (uint8_t * *pResp*, uint16_t *respLen*, **unpack_dms_GetCustFeaturesV2_t** * *pOutput*)

Get Custom Feature unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.69 int unpack_dms_GetDeviceCap (uint8_t * *pResp*, uint16_t *respLen*, **unpack_dms_GetDeviceCap_t** * *pOutput*)

Get Device Capabilities unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.70 int unpack_dms_GetDeviceCapabilities (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetDeviceCapabilities_t * *pOutput*)

Get device capability unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.71 int unpack_dms_GetDeviceHardwareRev (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetDeviceHardwareRev_t * *pOutput*)

Get Hardware Revision of the device unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.72 int unpack_dms_GetDeviceMfr (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetDeviceMfr_t * *pOutput*)

Get Device Manufacture Name unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.73 int unpack_dms_GetDeviceSerialNumbers (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetDeviceSerialNumbers_t * *pOutput*)

Get Device Serial Number unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.74 int unpack_dms_GetFirmwareInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetFirmwareInfo_t * *pOutput*)

Get firmware info unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.75 int unpack_dms_GetFirmwareRevision (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetFirmwareRevision_t * *pOutput*)

Get Firmware Revision unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.76 int unpack_dms_GetFirmwareRevisions (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetFirmwareRevisions_t * *pOutput*)

Get Firmware Revisions unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.77 int unpack_dms_GetFSN (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetFSN_t * *pOutput*)

Get FSN unpack This API get the Factory Sequence Number of the device.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.78 int unpack_dms_GetHardwareRevision (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetHardwareRevision_t * *pOutput*)

Get hardware revision of the device unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.79 int unpack_dms_GetIMSI (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetIMSI_t * *pOutput*)

Get IMSI unpack. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx-_xx_xx and all EM74xx firmware versions. Please use unpack_uim_ReadTransparent()(EF ID: 3F00 7F20 6F07 for 2G card and 3F00 7FFF 6F07 for 3G card) instead for new firmware versions and new modules.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.80 int unpack_dms_GetManufacturer (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetManufacturer_t * *pOutput*)

To get device manufacturer information unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.81 int unpack_dms_GetModelID (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetModelID_t * *pOutput*)

Get model id unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.82 int unpack_dms_GetNetworkTime (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetNetworkTime_t * *pOutput*)

Get Network Time unpack. Returns the current time of the device based on the value supported by the network.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.83 int unpack_dms_GetOfflineReason (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetOfflineReason_t * *pOutput*)

To get operating mode offline reason unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.84 int unpack_dms_GetPower (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetPower_t * *pOutput*)

Get operating mode of the device unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.85 int unpack_dms_GetPRLVersion (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetPRLVersion_t * *pOutput*)

Get PRL Versions unpack Return version of the active Preferred Roaming List (PRL) in use by the device.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.86 int unpack_dms_GetSerialNumbers (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetSerialNumbers_t * *pOutput*)

Get serial numbers unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.87 int unpack_dms_GetUSBComp (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetUSBComp_t * *pOutput*)

Get USB Comp unpack This API queries the modem's USB interface configuration and supported configuration parameters.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.88 int unpack_dms_GetVoiceNumber (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetVoiceNumber_t * *pOutput*)

Get Voice Number unpack Returns the voice number in use by the device.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.89 int unpack_dms_ResetToFactoryDefaults (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_ResetToFactory-Defaults_t * *pOutput*)

Resets to default factory settings of the device unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.90 int unpack_dms_SetActivationStatusCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetActivationStatusCallback_t * *pOutput*)

Set Activation status unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.91 int unpack_dms_SetCrashAction (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetCrashAction_t * *pOutput*)

Set Crash Action unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response. Not used

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.92 int unpack_dms_SetCustFeature (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetCustFeature_t * *pOutput*)

Set Custom Feature unpack. This API is deprecated for EM74xx/MC74xx, please use unpack_dms_SetCustFeaturesV2() instead for EM74xx/MC74xx.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.93 int unpack_dms_SetCustFeaturesV2 (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetCustFeaturesV2_t * *pOutput*)

Set Cust features unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.94 int unpack_dms_SetEventReport (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetEventReport_t * *pOutput*)

Set Event Report unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.95 int unpack_dms_SetEventReport_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetEventReport_ind_t * *pOutput*)

Event Report Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.96 int unpack_dms_SetFirmwarePreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetFirmwarePreference_t * *pOutput*)

Set Firmware Preference unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.97 int unpack_dms_SetPower (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetPower_t * *pOutput*)

Set Power unpack. Sets the operating mode of the device.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.98 int unpack_dms_SetUSBComp (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetUSBComp_t * *pOutput*)

Set USB Comp unpack This API is used to change the modem's USB interface configuration thus allowing a device to have multiple USB compositions. Devices will, by default, be configured to support a minimal set of interfaces to reduce end user modem installation time. Developers and some customers, however, require access to a custom set of interfaces. A reset is required for any change in the USB composition to take effect.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.99 int unpack_dms_SLQSDmsSwiGetResetInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSDmsSwiGetResetInfo_t * *pOutput*)

To get reset info unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.100 int unpack_dms_SLQSDmsSwiGetResetInfo_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t * *pOutput*)

DMS reset info Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

support EM/MC74xx onwards

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.101 int unpack_dms_SLQSDmsSwiIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSDmsSwiIndicationRegister_t * *pOutput*)

Set the registration state for different indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

support EM/MC74xx onwards

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.102 int unpack_dms_SLQSGetBandCapability (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSGetBandCapability_t * *pOutput*)

Get band capability of the device unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.103 int unpack_dms_SLQSGetERIFile (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSGetERIFile_t * *pOutput*)

To get UIM Get ERI file unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.104 int unpack_dms_SLQSSwiClearDyingGaspStatistics (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiClearDyingGaspStatistics_t * *pOutput*)

Clear Dying GASP Statistics unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.105 int unpack_dms_SLQSSwiGetCrashInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetCrashInfo_t * *pOutput*)

To Get the Crash Information from the device unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.106 int unpack_dms_SLQSSwiGetDyingGaspCfg (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetDyingGaspCfg_t * *pOutput*)

Get Dying GASP Config unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.107 int unpack_dms_SLQSSwiGetDyingGaspStatistics (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetDyingGaspStatistics_t * *pOutput*)

Get Dying GASP Statistics unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.108 int unpack_dms_SLQSSwiGetFirmwareCurr (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetFirmwareCurr_t * *pOutput*)

Get currently active image unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.109 int unpack_dms_SLQSSwiGetFwUpdateStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetFwUpdateStatus_t * *pOutput*)

To get Firmware Update status unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.110 int unpack_dms_SLQSSwiGetHostDevInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetHostDevInfo_t * *pOutput*)

To get host dev information unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.111 int unpack_dms_SLQSSwiGetOSInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetOSInfo_t * *pOutput*)

To get Host OS Info unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.112 int unpack_dms_SLQSSwiGetSerialNoExt (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetSerialNoExt_t * *pOutput*)

To get serial number extension unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.113 int unpack_dms_SLQSSwiSetDyingGaspCfg (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiSetDyingGaspCfg_t * *pOutput*)

Set Dying GASP Config unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.114 int unpack_dms_SLQSSwiSetHostDevInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiSetHostDevInfo_t * *pOutput*)

To set Host Dev Info unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.115 int unpack_dms_SLQSSwiSetOSInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiSetOSInfo_t * *pOutput*)

To set Host OS Info unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.116 int unpack_dms_SLQSUIMGetState (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSUIMGetState_t * *pOutput*)

Returns the UIM state unpack. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use API unpack_uim_GetCardStatus / unpack_uim_GetCardStatus for new firmware versions and new modules

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.117 int unpack_dms_UIMChangePIN (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMSetPINProtection_t * *pOutput*)

To get UIM change PIN unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.118 int unpack_dms_UIMGetControlKeyStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMGetControlKeyStatus_t * *pOutput*)

To get UIM Get ControlKeyStatus unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.119 int unpack_dms_UIMGetICCID (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMGetICCID_t * *pOutput*)

Unpacks the UIMGetICCID response message to a user-provided response structure.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.120 int unpack_dms_UIMGetPINStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMGetPINStatus_t * *pOutput*)

To get UIM Get PIN Status unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.121 int unpack_dms_UIMSetControlKeyProtection (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMSetControlKeyProtection_t * *pOutput*)

To get UIM Set Control Key Protection unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.122 int unpack_dms_UIMSetPINProtection (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMSetPINProtection_t * *pOutput*)

To get UIM Set PIN protection unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.123 int unpack_dms_UIMUnblockControlKey (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMUnblockControlKey_t * *pOutput*)

To get UIM Unblock Control Key unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.124 int unpack_dms_UIMUnblockPIN (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMSetPINProtection_t * *pOutput*)

To get UIM unblock PIN unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.125 int unpack_dms_UIMVerifyPIN (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMSetPINProtection_t * *pOutput*)

To get UIM verify PIN unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.126 int unpack_dms_ValidateSPC (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_ResetToFactoryDefaults_t * *pOutput*)

Requests the device to perform automatic service activation unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.6 fms.h File Reference

Data Structures

- struct CarrierImage_t
- struct pack_fms_GetImagesPreference_t
- struct FMSImageElement
- struct FMSPrefImageList
- struct unpack_fms_GetImagesPreference_t
- struct pack_fms_GetStoredImages_t
- struct FMSImageIdElement
- struct FMSImageIDEntries
- struct FMSImageList
- struct unpack_fms_GetStoredImages_t
- struct pack_fms_SetImagesPreference_t
- struct unpack_fms_SetImagesPreference_t

Macros

- #define FMS_GOBI_MBN_IMG_ID_STR_LEN 16
- #define FMS_GOBI_MBN_BUILD_ID_STR_LEN 100
- #define FMS_GOBI_LISTENTRIES_MAX 2
- #define FMS_MAX_IMAGE_PREFERENCE_IMAGE_SIZE 255
- #define FMS_MAX_IMAGE_ID_ELEMENT 50
- #define FMS_IMAGE_ID_MAX_ENTRIES 2
- #define FMS_FW_PRI_BUILD_MATCH_LEN 11
- #define FMS_IMAGE_ID_IMG_ID_LEN 16
- #define FMS_IMAGE_ID_BUILD_ID_LEN 32
- #define FMS_IMAGE_ID_PRI_IMGTYPE 0x01

Functions

- int pack_fms_GetImagesPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_fms_GetImagesPreference_t *reqArg)
- int unpack_fms_GetImagesPreference (uint8_t *pResp, uint16_t respLen, unpack_fms_GetImagesPreference_t *pOutput)
- int pack_fms_GetStoredImages (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_fms_GetStoredImages_t *reqArg)
- int unpack_fms_GetStoredImages (uint8_t *pResp, uint16_t respLen, unpack_fms_GetStoredImages_t *pOutput)
- int pack_fms_SetImagesPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_fms_SetImagesPreference_t *reqArg)
- int unpack_fms_SetImagesPreference (uint8_t *pResp, uint16_t respLen, unpack_fms_SetImagesPreference_t *pOutput)
- uint32_t GetValidFwPriCombinations (FMSImageList *pStoredImageList, uint32_t *pValidCombinationSize, CarrierImage_t *pValidCombinations)

9.6.1 Macro Definition Documentation

9.6.1.1 #define FMS_FW_PRI_BUILD_MATCH_LEN 11

9.6.1.2 #define FMS_GOBI_LISTENTRIES_MAX 2

9.6.1.3 #define FMS_GOBI_MBN_BUILD_ID_STR_LEN 100

9.6.1.4 #define FMS_GOBI_MBN_IMG_ID_STR_LEN 16

9.6.1.5 #define FMS_IMAGE_ID_BUILD_ID_LEN 32

9.6.1.6 #define FMS_IMAGE_ID_IMG_ID_LEN 16

9.6.1.7 #define FMS_IMAGE_ID_MAX_ENTRIES 2

9.6.1.8 #define FMS_IMAGE_ID_PRI_IMGTYPE 0x01

9.6.1.9 #define FMS_MAX_IMAGE_ID_ELEMENT 50

9.6.1.10 #define FMS_MAX_IMAGE_PREFERENCE_IMAGE_SIZE 255

9.6.2 Function Documentation

9.6.2.1 uint32_t GetValidFwPriCombinations (FMSImageList * *pStoredImageList*, uint32_t * *pValidCombinationSize*, CarrierImage_t * *pValidCombinations*)

This API distills valid Firmware/PRI combinations from GetStoredImages result

Parameters

in	*pStoredImage-List*	• image list returned from GetStoredImages • See FMSImageList
in,out	*pValid-CombinationSize*	• number of combination passed in and returned
out	*pValid-Combinations*	• valid combinations returned • See CarrierImage_t

Returns

- eQCWWAN_ERR_INVALID_ARG - Invalid parameters
- eQCWWAN_ERR_BUFFER_SZ - No enough element to store combinatons returned

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.6.2.2 int pack_fms_GetImagesPreference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_fms_GetImagesPreference_t * *reqArg*)

Get Images Preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

9.6.2.3 int pack_fms_GetStoredImages (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_fms_GetStoredImages_t * *reqArg*)

Get Images Preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

9.6.2.4 int pack_fms_SetImagesPreference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_fms_SetImagesPreference_t * *reqArg*)

Set Images Preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

9.6.2.5 int unpack_fms_GetImagesPreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_fms_GetImagesPreference_t * *pOutput*)

Get Images Preference unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

9.6.2.6 int unpack_fms_GetStoredImages (uint8_t * *pResp*, uint16_t *respLen*, unpack_fms_GetStoredImages_t * *pOutput*)

Get Images Preference unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

9.6.2.7 int unpack_fms_SetImagesPreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_fms_SetImagesPreference_t * *pOutput*)

Set Images Preference unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

9.7 ims.h File Reference

Data Structures

- struct pack_ims_SLQSSetSIPConfig_t
- struct unpack_ims_SLQSSetSIPConfig_t
- struct pack_ims_SLQSSetRegMgrConfig_t
- struct unpack_ims_SLQSSetRegMgrConfig_t
- struct pack_ims_SLQSSetIMSSMSConfig_t
- struct unpack_ims_SLQSSetIMSSMSConfig_t
- struct pack_ims_SLQSSetIMSUserConfig_t
- struct unpack_ims_SLQSSetIMSUserConfig_t
- struct pack_ims_SLQSSetIMSVoIPConfig_t
- struct unpack_ims_SLQSSetIMSVoIPConfig_t
- struct unpack_ims_SLQSGetSIPConfig_t
- struct unpack_ims_SLQSGetRegMgrConfig_t
- struct unpack_ims_SLQSGetIMSSMSConfig_t
- struct unpack_ims_SLQSGetIMSUserConfig_t
- struct unpack_ims_SLQSGetIMSVoIPConfig_t
- struct pack_ims_SLQSImsConfigIndicationRegister_t

Functions

- int pack_ims_SLQSSetSIPConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSSetSIPConfig_t *pReqParam)
- int unpack_ims_SLQSSetSIPConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSetSIPConfig_t *pOutput)
- int pack_ims_SLQSSetRegMgrConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSSetRegMgrConfig_t *pReqParam)
- int unpack_ims_SLQSSetRegMgrConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSetRegMgrConfig_t *pOutput)
- int pack_ims_SLQSSetIMSSMSConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSSetIMSSMSConfig_t *pReqParam)
- int unpack_ims_SLQSSetIMSSMSConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSetIMSSMSConfig_t *pOutput)
- int pack_ims_SLQSSetIMSUserConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSSetIMSUserConfig_t *pReqParam)
- int unpack_ims_SLQSSetIMSUserConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSetIMSUserConfig_t *pOutput)
- int pack_ims_SLQSSetIMSVoIPConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSSetIMSVoIPConfig_t *pReqParam)
- int unpack_ims_SLQSSetIMSVoIPConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSetIMSVoIPConfig_t *pOutput)

- int pack_ims_SLQSGetSIPConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_ims_SLQSGetSIPConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSGetSIPConfig_t *pOutput)
- int pack_ims_SLQSGetRegMgrConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_ims_SLQSGetRegMgrConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSGetRegMgrConfig_t *pOutput)
- int pack_ims_SLQSGetIMSSMSConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_ims_SLQSGetIMSSMSConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSGetIMSSMSConfig_t *pOutput)
- int pack_ims_SLQSGetIMSUserConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_ims_SLQSGetIMSUserConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSGetIMSUserConfig_t *pOutput)
- int pack_ims_SLQSGetIMSVoIPConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_ims_SLQSGetIMSVoIPConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSGetIMSVoIPConfig_t *pOutput)
- int pack_ims_SLQSImsConfigIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSImsConfigIndicationRegister_t *pReqParam)
- int unpack_ims_SLQSImsConfigIndicationRegister (uint8_t *pResp, uint16_t respLen)

9.7.1 Function Documentation

9.7.1.1 int pack_ims_SLQSGetIMSSMSConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Retrieves the SMS configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.1.2 int pack_ims_SLQSGetIMSUserConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Retrieves the IMS User configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.1.3 int pack_ims_SLQSGetIMSVoIPConfig (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen*)

Retrieves the IMS VoIP configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.1.4 int pack_ims_SLQSGetRegMgrConfig (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen*)

Retrieves the Session Initiation Protocol(SIP) configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.1.5 int pack_ims_SLQSGetSIPConfig (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen*)

Retrieves the Session Initiation Protocol(SIP) configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.1.6 int pack_ims_SLQSImsConfigIndicationRegister (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen,* pack_ims_SLQSImsConfigIndicationRegister_t * *pReqParam*)

Sets the registration state for different QMI_IMS indications for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

```
- This function is used by a device to register/deregister for different
  QMI IMS indications.
- The device's registration state variables that control registration
  for indications will be modified to reflect the settings indicated in the
  request message.
- At least one optional parameter must be present in the request.
```

9.7.1.7 int pack_ims_SLQSSetIMSSMSConfig (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen,* pack_ims_SLQSSetIMSSMSConfig_t * *pReqParam*)

Sets the IMS SMS configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.1.8 int pack_ims_SLQSSetIMSUserConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_ims_SLQSSetIMSUserConfig_t * *pReqParam*)

Sets the IMS user configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.1.9 int pack_ims_SLQSSetIMSVoIPConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_ims_SLQSSetIMSVoIPConfig_t * *pReqParam*)

Sets the IMS Voice over Internet Protocol (VoIP) configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.1.10 int pack_ims_SLQSSetRegMgrConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_ims_SLQSSetRegMgrConfig_t * *pReqParam*)

Sets the IMS registration manager configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.1.11 int pack_ims_SLQSSetSIPConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_ims_SLQSSetSIPConfig_t * *pReqParam*)

Sets the IMS Session Initiation Protocol(SIP) configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.1.12 int unpack_ims_SLQSGetIMSSMSConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSGetIMSSMSConfig_t * *pOutput*)

Retrieves the SMS configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.1.13 int unpack_ims_SLQSGetIMSUserConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSGetIMSUserConfig_t * *pOutput*)

Retrieves the IMS User configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.1.14 int unpack_ims_SLQSGetIMSVoIPConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSGetIMSVoIPConfig_t * *pOutput*)

Retrieves the IMS VoIP configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.1.15 int unpack_ims_SLQSGetRegMgrConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSGetRegMgrConfig_t * *pOutput*)

Retrieves the Session Initiation Protocol(SIP) configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.1.16 int unpack_ims_SLQSGetSIPConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSGetSIPConfig_t * *pOutput*)

Retrieves the Session Initiation Protocol(SIP) configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.1.17 int unpack_ims_SLQSImsConfigIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*)

Sets the registration state for different QMI_IMS indications for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.1.18 int unpack_ims_SLQSSetIMSSMSConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSetIMSSMSConfig_t * *pOutput*)

Sets the IMS SMS configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.1.19 int unpack_ims_SLQSSetIMSUserConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSetIMSUserConfig_t * *pOutput*)

Sets the IMS user configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.1.20 int unpack_ims_SLQSSetIMSVoIPConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSetIMSVoIPConfig_t * *pOutput*)

Sets the IMS Voice over Internet Protocol (VoIP) configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.1.21 int unpack_ims_SLQSSetRegMgrConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSetRegMgrConfig_t * *pOutput*)

Sets the IMS registration manager configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.1.22 int unpack_ims_SLQSSetSIPConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSetSIPConfig_t * *pOutput*)

Sets the IMS Session Initiation Protocol(SIP) configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8 imsa.h File Reference

Data Structures

- struct pack_imsa_SLQSRegisterIMSAIndication_t
- struct unpack_imsa_SLQSGetIMSARegStatus_t
- struct unpack_imsa_SLQSGetIMSAServiceStatus_t

Functions

- int pack_imsa_SLQSRegisterIMSAIndication (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_imsa_SLQSRegisterIMSAIndication_t *reqParam)
- int unpack_imsa_SLQSRegisterIMSAIndication (uint8_t *pResp, uint16_t respLen)
- int pack_imsa_SLQSGetIMSARegStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_imsa_SLQSGetIMSARegStatus (uint8_t *pResp, uint16_t respLen, unpack_imsa_SLQSGetIMSARegStatus_t *pOutput)
- int pack_imsa_SLQSGetIMSAServiceStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_imsa_SLQSGetIMSAServiceStatus (uint8_t *pResp, uint16_t respLen, unpack_imsa_SLQSGetIMSAServiceStatus_t *pOutput)

9.8.1 Function Documentation

9.8.1.1 int pack_imsa_SLQSGetIMSARegStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack Get IMSA Registration Status command.

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.1.2 int pack_imsa_SLQSGetIMSAServiceStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack Get IMSA Service Status command

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.1.3 int pack_imsa_SLQSRegisterIMSAIndication (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_imsa_SLQSRegisterIMSAIndication_t * *reqParam*)

Function to pack Register IMSA Indication command

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[IN] • See pack_imsa_SLQSRegisterIMSAIndication_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.1.4 int unpack_imsa_SLQSGetIMSARegStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_imsa_SLQSGetIMSA-RegStatus_t * *pOutput*)

Function to unpack Get IMSA Registration Status response from modem. *

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem
pOutput	[OUT] • See unpack_imsa_SLQSGetIMSARegStatus_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.1.5 int unpack_imsa_SLQSGetIMSAServiceStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_imsa_SLQSGetIMSAServiceStatus_t * *pOutput*)

Function to unpack Get IMSA Service Status response from modem

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem
pOutput	[OUT] • See unpack_imsa_SLQSGetIMSAServiceStatus_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.1.6 int unpack_imsa_SLQSRegisterIMSAIndication (uint8_t * *pResp*, uint16_t *respLen*)

Function to unpack Register IMSA Indication response from modem

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.9 lite-fw.h File Reference

Data Structures

- struct _litefw_FirmwareInfo_

Macros

- #define IMG_MASK_MDM (1<<0)
- #define IMG_MASK_PRI (1<<1)
- #define IMG_MASK_CLEAR (0x000)
- #define IMG_MASK_GENERIC (0xFFFF)
- #define LITEFW_CARRIER_PACKAGE_SKU "9999999"
- #define LITEFW_SKU_STRING_LENGTH 7
- #define FIRMWARE_INFO_STRING_SIZE 20
- #define libSDP_GetVersion litefw_GetVersion
- #define libSDP_CalculateImageMask litefw_CalculateImageMask
- #define libSDP_getFileType litefw_getFileType
- #define libSDP_ExtractFirmwareParametersByPath litefw_ExtractFirmwareParametersByPath
- #define libSDP_GetModelFamily litefw_GetModelFamily
- #define libSDP_CheckValidFirmwareInfo litefw_CheckValidFirmwareInfo
- #define libSDP_BuildImagesPreferenceRequest litefw_BuildImagesPreferenceRequest
- #define libSDP_DownloadFW litefw_DownloadFW
- #define libsdp_set_log_func litefw_set_log_func
- #define libsdp_SetReadBlockSize litefw_SetReadBlockSize
- #define LIBSDP_CARRIER_PACKAGE_SKU LITEFW_CARRIER_PACKAGE_SKU
- #define LIBSDP_SKU_STRING_LENGTH LITEFW_SKU_STRING_LENGTH

Typedefs

- typedef struct _litefw_FirmwareInfo_ litefw_FirmwareInfo
- typedef void(* litefwlogger)(uint8_t lvl, const char *buff)
- typedef litefw_FirmwareInfo libSDP_FirmwareInfo
- typedef litefwlogger libsdplogger

Enumerations

- enum litefw_fwdwl_error_codes {
  eSDP_FWDWL_SUCCESS = 0,
  eSDP_FWDWL_ERR_GENERAL = 100,
  eSDP_FWDWL_ERR_SDK,
  eSDP_FWDWL_ERR_SET_CBK,
  eSDP_FWDWL_ERR_PATH_TOO_LONG,
  eSDP_FWDWL_ERR_PATH_NOT_SPECIFIED,
  eSDP_FWDWL_ERR_FW_UPGRADE,
  eSDP_FWDWL_ERR_INVALID_DEV,
  eSDP_FWDWL_ERR_INVALID_PATH,
  eSDP_FWDWL_ERR_TIMEOUT,
  eSDP_FWDWL_ERR_FAIL,
  eSDP_FWDWL_ERR_PRI_FAIL,
  eSDP_FWDWL_ERR_FW_VERSION_FAIL,
  eSDP_FWDWL_ERR_END }

- enum litefw_Fw_Type {
  eFW_TYPE_MBN_GOBI,
  eFW_TYPE_MBN,
  eFW_TYPE_CWE,
  eFW_TYPE_NVU,
  eFW_TYPE_SPK,
  eFW_TYPE_INVALID,
  eFW_TYPE_CWE_NVU }
- enum litefw_Models {
  eModel_Unknown =-1,
  eModel_9X15 =0,
  eModel_WP9X15 =1,
  eModel_9X30 =2,
  eModel_9x07 =3 }

Functions

- void litefw_logsenable (int log_en)
- int litefw_ExtractFirmwareParametersByPath (char *pImagePath, litefw_FirmwareInfo *info)
- int litefw_BuildImagesPreferenceRequest (litefw_FirmwareInfo info, pack_fms_SetImagesPreference_t *pack)
- int litefw_CalculateImageMask (unpack_fms_SetImagesPreference_t SetPrefRspFromModem)
- int litefw_getFileType (char *szPath)
- unsigned int litefw_DownloadFW (char *pImagePath, char *szTTYPath, int iFWImageType, int image_mask, int iModelFamily)
- int litefw_GetModelFamily (char *pModelString)
- int litefw_CheckValidFirmwareInfo (litefw_FirmwareInfo info)
- char * litefw_GetVersion ()
- int litefw_set_log_func (litefwlogger func)
- void litefw_SetReadBlockSize (unsigned long lBlockSize)
- int litefw_switch_9x07_to_downloadmode (char *szTTYPath)
- int litefw_switch_to_BootHoldMode (char *szTTYPath)

9.9.1 Detailed Description

Filename: lite-fw.h

Purpose: Global definitions used inside the SDK

Copyright: © 2016 Sierra Wireless Inc., all rights reserved

9.9.2 Macro Definition Documentation

9.9.2.1 #define FIRMWARE_INFO_STRING_SIZE 20

9.9.2.2 #define IMG_MASK_CLEAR (0x000)

9.9.2.3 #define IMG_MASK_GENERIC (0xFFFF)

9.9.2.4 #define IMG_MASK_MDM (1<<0)

9.9.2.5 #define IMG_MASK_PRI (1<<1)

9.9.2.6 #define libSDP_BuildImagesPreferenceRequest litefw_BuildImagesPreferenceRequest

9.9.2.7 #define libSDP_CalculateImageMask litefw_CalculateImageMask

9.9.2.8 #define LIBSDP_CARRIER_PACKAGE_SKU LITEFW_CARRIER_PACKAGE_SKU

9.9.2.9 #define libSDP_CheckValidFirmwareInfo litefw_CheckValidFirmwareInfo

9.9.2.10 #define libSDP_DownloadFW litefw_DownloadFW

9.9.2.11 #define libSDP_ExtractFirmwareParametersByPath litefw_ExtractFirmwareParametersByPath

9.9.2.12 #define libSDP_getFileType litefw_getFileType

9.9.2.13 #define libSDP_GetModelFamily litefw_GetModelFamily

9.9.2.14 #define libSDP_GetVersion litefw_GetVersion

9.9.2.15 #define libsdp_set_log_func litefw_set_log_func

9.9.2.16 #define libsdp_SetReadBlockSize litefw_SetReadBlockSize

9.9.2.17 #define LIBSDP_SKU_STRING_LENGTH LITEFW_SKU_STRING_LENGTH

9.9.2.18 #define LITEFW_CARRIER_PACKAGE_SKU "9999999"

9.9.2.19 #define LITEFW_SKU_STRING_LENGTH 7

9.9.3 Typedef Documentation

9.9.3.1 typedef litefw_FirmwareInfo libSDP_FirmwareInfo

9.9.3.2 typedef litefwlogger libsdplogger

9.9.3.3 typedef struct _litefw_FirmwareInfo_ litefw_FirmwareInfo

This structure contains information of the response parameters associated with a Read Transparent API.

Parameters

szModelid_str	• Model Name String
szFwversion_str	• Firmware Version String.
szSku_str	• SKU String.
szPackageid_str	• Package ID String.
szCarrier_str	• Carrier String.
szCarrier-Priversion_str	• Carrier PRI Version String.

9.9.3.4 typedef void(∗ litefwlogger)(uint8_t lvl, const char ∗buff)

This Custom Log prototype.

Parameters

in	*lvl*	• Log level.
in	*buff*	• Log String.

Returns

none

9.9.4 Enumeration Type Documentation

9.9.4.1 enum litefw_Fw_Type

Enumerator

eFW_TYPE_MBN_GOBI

eFW_TYPE_MBN

eFW_TYPE_CWE

eFW_TYPE_NVU

eFW_TYPE_SPK

eFW_TYPE_INVALID

eFW_TYPE_CWE_NVU

9.9.4.2 enum litefw_fwdwl_error_codes

Enumerator

eSDP_FWDWL_SUCCESS

eSDP_FWDWL_ERR_GENERAL

eSDP_FWDWL_ERR_SDK

eSDP_FWDWL_ERR_SET_CBK

eSDP_FWDWL_ERR_PATH_TOO_LONG

eSDP_FWDWL_ERR_PATH_NOT_SPECIFIED

eSDP_FWDWL_ERR_FW_UPGRADE

eSDP_FWDWL_ERR_INVALID_DEV

eSDP_FWDWL_ERR_INVALID_PATH

eSDP_FWDWL_ERR_TIMEOUT

eSDP_FWDWL_ERR_FAIL

eSDP_FWDWL_ERR_PRI_FAIL

eSDP_FWDWL_ERR_FW_VERSION_FAIL

eSDP_FWDWL_ERR_END

9.9.4.3 enum litefw_Models

Enumerator

eModel_Unknown

eModel_9X15

eModel_WP9X15

eModel_9X30

eModel_9x07

9.9.5 Function Documentation

9.9.5.1 int litefw_BuildImagesPreferenceRequest (litefw_FirmwareInfo *info*, pack_fms_SetImagesPreference_t * *pack*)

This API Build Image Preference Request Using Firmware Information.

Parameters

in	*info*	• See litefw_FirmwareInfo for more information.
out	*pack*	• See pack_fms_SetImagesPreference_t for more information.

Returns

0 on success, litefw_fwdwl_error_codes error value otherwise

See Also

See litefw_fwdwl_error_codes for error values

9.9.5.2 int litefw_CalculateImageMask (unpack_fms_SetImagesPreference_t *SetPrefRspFromModem*)

This API Calculate Image Mask for Firmware Download.

Parameters

in	*SetPrefRsp-FromModem*	• See unpack_fms_SetImagesPreference_t for more information.

Returns

Image Mask

- IMG_MASK_MDM | IMG_MASK_PRI

9.9.5.3 int litefw_CheckValidFirmwareInfo (litefw_FirmwareInfo *info*)

This API Check Valid Firmware Information to build Image Prefernce Request.

Parameters

in	*info*	• See litefw_FirmwareInfo for more information.

Returns

0 on success, -1 error value otherwise

9.9.5.4 unsigned int litefw_DownloadFW (char * *pImagePath*, char * *szTTYPath*, int *iFWImageType*, int *image_mask*, int *iModelFamily*)

This API Download Firmware.

Parameters

in	*pImagePath*	• Firmware Folder Path.
in	*szTTYPath*	• QDL Device Path.
in	*iFWImageType*	• Firmware Type. • See litefw_Fw_Type
in	*image_mask*	• Image Mask. – IMG_MASK_MDM | IMG_MASK_PRI
in	*iModelFamily*	• Modem Family. • See litefw_Models

Returns

0 on success, litefw_fwdwl_error_codes error value otherwise

See Also

See litefw_fwdwl_error_codes for error values

9.9.5.5 int litefw_ExtractFirmwareParametersByPath (char * *pImagePath*, litefw_FirmwareInfo * *info*)

This API Extrace Firmware Parameters From Path.

Parameters

in	*pImagePath*	• Firmware Folder Path.
out	*info*	• See litefw_FirmwareInfo for more information.

Returns

0 on success, litefw_fwdwl_error_codes error value otherwise

See Also

See litefw_fwdwl_error_codes for error values

9.9.5.6 int litefw_getFileType (char * *szPath*)

This API Get File Type By Path

Parameters

in	*szPath*	• See litefw_FirmwareInfo for more information.

Returns

eFW_TYPE_INVALID on error, litefw_Fw_Type value otherwise

See Also

See litefw_Fw_Type for values

9.9.5.7 int litefw_GetModelFamily (char * *pModelString*)

This API Get Model Famliy from a model string.

Parameters

in	*pModelString*	• Model String.

Returns

eModel_Unknown on Error, litefw_Models value otherwise

See Also

See litefw_Models for values

9.9.5.8 char* litefw_GetVersion ( )

This API Get Lib SDP Version.

Returns

Version String

9.9.5.9 void litefw_logsenable (int *log_en*)

This function enable/disable lite firmware debug logs.

Parameters

in	*log_en*	• Logs enable/disable flag.

9.9.5.10 int litefw_set_log_func (litefwlogger *func*)

This API Set Custom Log function.

Parameters

in	*func*	• See litefwlogger for more information.

Returns

none

9.9.5.11 void litefw_SetReadBlockSize (unsigned long *lBlockSize*)

This API Set Read BlockSize.

Parameters

in	*lBlockSize*	• Firmware Read Block Size.

Returns

none

9.9.5.12 int litefw_switch_9x07_to_downloadmode (char * *szTTYPath*)

This API switch 9x07 modem to download mode.

Parameters

in	*szTTYPath*	• QDL Device Path.

Returns

0 on success, -1 error value otherwise

9.9.5.13 int litefw_switch_to_BootHoldMode (char * *szTTYPath*)

This API switch modem to boot hold modem via QDL port.

Parameters

in	*szTTYPath*	• QDL Device Path.

Returns

0 on success, -1 error value otherwise

9.10 loc.h File Reference

Data Structures

- struct loc_LocApplicationInfo
- struct loc_SV
- struct loc_SVInfo
- struct loc_GnssData
- struct loc_CellDb
- struct loc_ClkInfo
- struct loc_BdsSV
- struct loc_BdsSVInfo
- struct pack_loc_EventRegister_t
- struct unpack_loc_EventRegister_t
- struct pack_loc_SetExtPowerState_t
- struct unpack_loc_SetExtPowerState_t
- struct pack_loc_Start_t
- struct unpack_loc_Start_t
- struct pack_loc_Stop_t
- struct unpack_loc_Stop_t
- struct pack_loc_SetOperationMode_t
- struct unpack_loc_SetOperationMode_t
- struct pack_loc_Delete_Assist_Data_t
- struct unpack_loc_Delete_Assist_Data_t
- struct loc_precisionDilution
- struct loc_sensorDataUsage
- struct loc_svUsedforFix
- struct loc_gpsTime
- struct unpack_loc_PositionRpt_Ind_t
- struct unpack_loc_EngineState_Ind_t
- struct unpack_loc_SetExtPowerConfig_Ind_t
- struct unpack_loc_SLQSLOCGetBestAvailPos_t
- struct pack_loc_SLQSLOCGetBestAvailPos_t
- struct unpack_loc_BestAvailPos_Ind_t
- struct unpack_loc_SetOperationMode_Ind_t
- struct unpack_loc_DeleteAssistData_Ind_t
- struct loc_satelliteInfo
- struct unpack_loc_GnssSvInfo_Ind_t
- struct pack_loc_SLQSLOCInjectUTCTime_t
- struct altSrcInfo_t

- struct pack_loc_SLQSLOCInjectPosition_t
- struct pack_loc_SLQSLOCSetCradleMountConfig_t
- struct sensorData_t
- struct tempData_t
- struct pack_loc_SLQSLOCInjectSensorData_t
- struct unpack_loc_EventNMEA_Ind_t
- struct pack_loc_SLQSLOCGetServer_t
- struct loc_IPv4Info
- struct loc_IPv6Info
- struct loc_urlAddr
- struct unpack_loc_GetServer_Ind_t

Macros

- #define LOC_UINT8_MAX_STRING_SZ 255
- #define LOCEVENTMASKPOSITIONREPORT 0x00000001
- #define LOCEVENTMASKGNSSSVINFO 0x00000002
- #define LOCEVENTMASKNMEA 0x00000004
- #define LOCEVENTMASKNINOTIFYVERIFYREQ 0x00000008
- #define LOCEVENTMASKINJECTTIMEREQ 0x00000010
- #define LOCEVENTMASKINJECTPREDICTEDORBITSREQ 0x00000020
- #define LOCEVENTMASKINJECTPOSITIONREQ 0x00000040
- #define LOCEVENTMASKENGINESTATE 0x00000080
- #define LOCEVENTMASKFIXSESSIONSTATE 0x00000100
- #define LOCEVENTMASKWIFIREQ 0x00000200
- #define LOCEVENTMASKSENSORSTREAMINGREADYSTATUS 0x00000400
- #define LOCEVENTMASKTIMESYNCREQ 0x00000800
- #define LOCEVENTMASKSETSPISTREAMINGREPORT 0x00001000
- #define LOCEVENTMASKLOCATIONSERVERCONNECTIONREQ 0x00002000
- #define LOCEVENTMASKNIGEOFENCENOTIFICATION 0x00004000
- #define LOCEVENTMASKGEOFENCEGENALERT 0x00008000
- #define LOCEVENTMASKGEOFENCEBREACHNOTIFICATION 0x00010000
- #define LOCEVENTMASKPEDOMETERCONTROL 0x00020000
- #define LOCEVENTMASKMOTIONDATACONTROL 0x00040000
- #define LOCEVENTMASKBATCHFULLNOTIFICATION 0x00080000
- #define LOCEVENTMASKLIVEBATCHEDPOSITIONREPORT 0x00100000
- #define LOCEVENTMASKINJECTWIFIAPDATAREQ 0x00200000
- #define LOCEVENTMASKGEOFENCEBATCHBREACHNOTIFICATION 0x00400000
- #define LOCEVENTMASKVEHICLEDATAREADYSTATUS 0x00800000
- #define LOCEVENTMASKGNSSMEASUREMENTREPORT 0x01000000
- #define LOCEVENTMASKINVALIDVALUE 0xFFFFFFFF
- #define MAX_SENSOR_DATA_LEN 64
- #define MAX_TEMP_DATA_LEN 64
- #define MAX_LOC_NMEA_STR_LEN 201

Enumerations

- enum {
  eQMI_LOC_SESS_STATUS_SUCCESS =0,
  eQMI_LOC_SESS_STATUS_IN_PROGRESS =1,
  eQMI_LOC_SESS_STATUS_FAILURE =2,
  eQMI_LOC_SESS_STATUS_TIMEOUT =3 }

Functions

- int pack_loc_EventRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_EventRegister_t *reqArg)
- int unpack_loc_EventRegister (uint8_t *pResp, uint16_t respLen, unpack_loc_EventRegister_t *pOutput)
- int pack_loc_SetExtPowerState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SetExtPowerState_t *reqArg)
- int unpack_loc_SetExtPowerState (uint8_t *pResp, uint16_t respLen, unpack_loc_SetExtPowerState_t *pOutput)
- int pack_loc_Start (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_Start_t *reqArg)
- int unpack_loc_Start (uint8_t *pResp, uint16_t respLen, unpack_loc_Start_t *pOutput)
- int pack_loc_Stop (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_Stop_t *reqArg)
- int unpack_loc_Stop (uint8_t *pResp, uint16_t respLen, unpack_loc_Stop_t *pOutput)
- int pack_loc_SetOperationMode (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SetOperationMode_t *reqArg)
- int unpack_loc_SetOperationMode (uint8_t *pResp, uint16_t respLen, unpack_loc_SetOperationMode_t *pOutput)
- int pack_loc_DeleteAssistData (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_Delete_Assist_Data_t *reqArg)
- int unpack_loc_DeleteAssistData (uint8_t *pResp, uint16_t respLen, unpack_loc_Delete_Assist_Data_t *pOutput)
- int unpack_loc_PositionRpt_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_PositionRpt_Ind_t *pOutput)
- int unpack_loc_EngineState_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_EngineState_Ind_t *pOutput)
- int unpack_loc_SetExtPowerConfig_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_SetExtPowerConfig_Ind_t *pOutput)
- int pack_loc_SLQSLOCGetBestAvailPos (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCGetBestAvailPos_t *reqArg)
- int unpack_loc_SLQSLOCGetBestAvailPos (uint8_t *pResp, uint16_t respLen, unpack_loc_SLQSLOCGetBestAvailPos_t *pOutput)
- int unpack_loc_BestAvailPos_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_BestAvailPos_Ind_t *pOutput)
- int unpack_loc_SetOperationMode_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_SetOperationMode_Ind_t *pOutput)
- int unpack_loc_DeleteAssistData_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_DeleteAssistData_Ind_t *pOutput)
- int unpack_loc_GnssSvInfo_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_GnssSvInfo_Ind_t *pOutput)
- int pack_loc_SLQSLOCInjectUTCTime (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCInjectUTCTime_t *reqArg)
- int unpack_loc_SLQSLOCInjectUTCTime (uint8_t *pResp, uint16_t respLen)
- int pack_loc_SLQSLOCInjectPosition (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCInjectPosition_t *reqArg)
- int unpack_loc_SLQSLOCInjectPosition (uint8_t *pResp, uint16_t respLen)
- int pack_loc_SLQSLOCSetCradleMountConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCSetCradleMountConfig_t *reqArg)
- int unpack_loc_SLQSLOCSetCradleMountConfig (uint8_t *pResp, uint16_t respLen)
- int pack_loc_SLQSLOCInjectSensorData (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCInjectSensorData_t *reqArg)
- int unpack_loc_SLQSLOCInjectSensorData (uint8_t *pResp, uint16_t respLen)
- int unpack_loc_EventNMEA_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_EventNMEA_Ind_t *pOutput)
- int pack_loc_SLQSLOCGetServer (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCGetServer_t *reqArg)
- int unpack_loc_SLQSLOCGetServer (uint8_t *pResp, uint16_t respLen)
- int unpack_loc_GetServer_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_GetServer_Ind_t *pOutput)

9.10.1 Macro Definition Documentation

9.10.1.1 #define LOC_UINT8_MAX_STRING_SZ 255

9.10.1.2 #define LOCEVENTMASKBATCHFULLNOTIFICATION 0x00080000

The control point must enable this mask to receive notification when a batch is full. The location engine sends this event to notify of Batch Full for ongoing batching session.

9.10.1.3 #define LOCEVENTMASKENGINESTATE 0x00000080

The control point must enable this mask to receive engine state report event indications.

9.10.1.4 #define LOCEVENTMASKFIXSESSIONSTATE 0x00000100

The control point must enable this mask to receive fix session status report event indications.

9.10.1.5 #define LOCEVENTMASKGEOFENCEBATCHBREACHNOTIFICATION 0x00400000

The control point must enable this mask to receive notifications when a Geofence is breached. These events are generated when a UE enters or leaves the perimeter of a Geofence. This breach notification is for multiple Geofences. Breaches from multiple Geofences are all batched and sent in the same notification.

9.10.1.6 #define LOCEVENTMASKGEOFENCEBREACHNOTIFICATION 0x00010000

The control point must enable this mask to receive notifications when a Geofence is breached. These events are generated when a UE enters or leaves the perimeter of a Geofence. This breach report is for a single Geofence.

9.10.1.7 #define LOCEVENTMASKGEOFENCEGENALERT 0x00008000

The control point must enable this mask to receive Geofence alerts. These alerts are generated to inform the client of the changes that may affect a Geofence, for example, if GPS is turned off or if the network is unavailable.

9.10.1.8 #define LOCEVENTMASKGNSSMEASUREMENTREPORT 0x01000000

The control point must enable this mask to receive system clock and satellite measurement report events (system clock, SV time, Doppler, etc.). Reports are generated only for the GNSS satellite constellations that are enabled using QMI_LOC_SET_GNSS_ CONSTELL_REPORT_CONFIG(Not yet supported).

9.10.1.9 #define LOCEVENTMASKGNSSSVINFO 0x00000002

The control point must enable this mask to receive satellite report event indications. These reports are sent at a 1 Hz rate.

9.10.1.10 #define LOCEVENTMASKINJECTPOSITIONREQ 0x00000040

The control point must enable this mask to receive position injection request event indications.

9.10.1.11 #define LOCEVENTMASKINJECTPREDICTEDORBITSREQ 0x00000020

The control point must enable this mask to receive predicted orbits request event indications.

9.10.1.12 #define LOCEVENTMASKINJECTTIMEREQ 0x00000010

The control point must enable this mask to receive time injection request event indications.

9.10.1.13 #define LOCEVENTMASKINJECTWIFIAPDATAREQ 0x00200000

The control point must enable this mask to receive Wi-Fi Access Point (AP) data inject request event indications.

9.10.1.14 #define LOCEVENTMASKINVALIDVALUE 0xFFFFFFFF

Invalid Event Mask

9.10.1.15 #define LOCEVENTMASKLIVEBATCHEDPOSITIONREPORT 0x00100000

The control point must enable this mask to receive position report indications along with an ongoing batching session. The location engine sends this event to notify the batched position report while a batching session is ongoing.

9.10.1.16 #define LOCEVENTMASKLOCATIONSERVERCONNECTIONREQ 0x00002000

The control point must enable this mask to receive location server requests. These requests are generated when the service wishes to establish a connection with a location server.

9.10.1.17 #define LOCEVENTMASKMOTIONDATACONTROL 0x00040000

The control point must enable this mask to register for motion data control requests from the location engine. The location engine sends this event to control the injection of motion data.

9.10.1.18 #define LOCEVENTMASKNIGEOFENCENOTIFICATION 0x00004000

The control point must enable this mask to receive notifications related to network-initiated Geofences. These events notify the client when a network-initiated Geofence is added, deleted, or edited.

9.10.1.19 #define LOCEVENTMASKNINOTIFYVERIFYREQ 0x00000008

The control point must enable this mask to receive NI Notify/Verify request event indications.

9.10.1.20 #define LOCEVENTMASKNMEA 0x00000004

The control point must enable this mask to receive NMEA reports for position and satellites in view. The report is at a 1 Hz rate.

9.10.1.21 #define LOCEVENTMASKPEDOMETERCONTROL 0x00020000

The control point must enable this mask to register for pedometer control requests from the location engine. The location engine sends this event to control the injection of pedometer reports.

9.10.1.22 #define LOCEVENTMASKPOSITIONREPORT 0x00000001

The control point must enable this mask to receive position report event indications.

9.10.1.23 #define LOCEVENTMASKSENSORSTREAMINGREADYSTATUS 0x00000400

The control point must enable this mask to receive notifications from the location engine indicating its readiness to accept data from the sensors (accelerometer, gyroscope, etc.).

9.10.1.24 #define LOCEVENTMASKSETSPISTREAMINGREPORT 0x00001000

The control point must enable this mask to receive Stationary Position Indicator (SPI) streaming report indications.

9.10.1.25 #define LOCEVENTMASKTIMESYNCREQ 0x00000800

The control point must enable this mask to receive time sync requests from the GPS engine. Time sync enables the GPS engine to synchronize its clock with the sensor processor's clock.

9.10.1.26 #define LOCEVENTMASKVEHICLEDATAREADYSTATUS 0x00800000

The control point must enable this mask to receive notifications from the location engine indicating its readiness to accept vehicle data (vehicle accelerometer, vehicle angular rate, vehicle odometry, etc.).

9.10.1.27 #define LOCEVENTMASKWIFIREQ 0x00000200

The control point must enable this mask to receive Wi-Fi position request event indications.

9.10.1.28 #define MAX_LOC_NMEA_STR_LEN 201

9.10.1.29 #define MAX_SENSOR_DATA_LEN 64

9.10.1.30 #define MAX_TEMP_DATA_LEN 64

9.10.2 Enumeration Type Documentation

9.10.2.1 anonymous enum

Enumerator

eQMI_LOC_SESS_STATUS_SUCCESS

eQMI_LOC_SESS_STATUS_IN_PROGRESS

eQMI_LOC_SESS_STATUS_FAILURE

eQMI_LOC_SESS_STATUS_TIMEOUT

9.10.3 Function Documentation

9.10.3.1 int pack_loc_DeleteAssistData (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_Delete_Assist_Data_t * *reqArg*)

Delete Assistant Data pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.2 int pack_loc_EventRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_EventRegister_t * *reqArg*)

Event Register pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.3 int pack_loc_SetExtPowerState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SetExtPowerState_t * *reqArg*)

Set Ext Power State pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.4 int pack_loc_SetOperationMode (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SetOperationMode_t * *reqArg*)

Set Operation Mode pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.5 int pack_loc_SLQSLOCGetBestAvailPos (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCGetBestAvailPos_t * *reqArg*)

Get Best Avail position pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.6 int pack_loc_SLQSLOCGetServer (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCGetServer_t * *reqArg*)

Pack get server.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

The request is acknowledged through the response, but the SUCCESS/FAILURE status is sent through unpack_loc_GetServer_Ind callback If successful, the callback also contains the A-GPS server address.

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.7 int pack_loc_SLQSLOCInjectPosition (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCInjectPosition_t * *reqArg*)

Pack inject position.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.8 int pack_loc_SLQSLOCInjectSensorData (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCInjectSensorData_t * *reqArg*)

Pack inject sensor data.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.9 int pack_loc_SLQSLOCInjectUTCTime (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCInjectUTCTime_t * *reqArg*)

Pack inject UTC time.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.10 int pack_loc_SLQSLOCSetCradleMountConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCSetCradleMountConfig_t * *reqArg*)

Pack set cradle mount configure.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.11 int pack_loc_Start (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_Start_t * *reqArg*)

LOC Start pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.12 int pack_loc_Stop (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_Stop_t * *reqArg*)

Loc Stop pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.13 int unpack_loc_BestAvailPos_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_BestAvailPos_Ind_t * *pOutput*)

Loc Best Avial position Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.14 int unpack_loc_DeleteAssistData (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_Delete_Assist_Data_t * *pOutput*)

Delete Assistant Data unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.15 int unpack_loc_DeleteAssistData_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_DeleteAssistData_Ind_t * *pOutput*)

Unpack the status of delete the location engine assistance data

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.16 int unpack_loc_EngineState_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_EngineState_Ind_t * *pOutput*)

Loc Engine State Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.17 int unpack_loc_EventNMEA_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_EventNMEA_Ind_t * *pOutput*)

Unpack the NMEA Event Indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.18 int unpack_loc_EventRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_EventRegister_t * *pOutput*)

Event Register unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.19 int unpack_loc_GetServer_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_GetServer_Ind_t * *pOutput*)

Unpack the Get Server Indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.20 int unpack_loc_GnssSvInfo_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_GnssSvInfo_Ind_t * *pOutput*)

Unpack the GNSS SV Info Indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.21 int unpack_loc_PositionRpt_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_PositionRpt_Ind_t * *pOutput*)

Loc Position Report Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.22 int unpack_loc_SetExtPowerConfig_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SetExtPowerConfig_Ind_t * *pOutput*)

Loc Set External Power Configure Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.23 int unpack_loc_SetExtPowerState (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SetExtPowerState_t * *pOutput*)

Set Ext Power State unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.24 int unpack_loc_SetOperationMode (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SetOperationMode_t * *pOutput*)

Set Operation Mode unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.25 int unpack_loc_SetOperationMode_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SetOperationMode_Ind_t * *pOutput*)

Unpack the engine to use the specified operation mode.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.26 int unpack_loc_SLQSLOCGetBestAvailPos (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SLQSLOCGetBestAvailPos_t * *pOutput*)

Get Best Avail position unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.27 int unpack_loc_SLQSLOCGetServer (uint8_t * *pResp*, uint16_t *respLen*)

Unpack get server.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.28 int unpack_loc_SLQSLOCInjectPosition (uint8_t * *pResp*, uint16_t *respLen*)

Unpack inject position.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.29 int unpack_loc_SLQSLOCInjectSensorData (uint8_t * *pResp*, uint16_t *respLen*)

Unpack inject sensor data.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.30 int unpack_loc_SLQSLOCInjectUTCTime (uint8_t * *pResp*, uint16_t *respLen*)

Unpack inject UTC time.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.31 int unpack_loc_SLQSLOCSetCradleMountConfig (uint8_t * *pResp*, uint16_t *respLen*)

Unpack set cradle mount configure.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.32 int unpack_loc_Start (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_Start_t * *pOutput*)

Loc Start unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.3.33 int unpack_loc_Stop (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_Stop_t * *pOutput*)

Loc Stop unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11 nas.h File Reference

Data Structures

- struct unpack_nas_GetSignalStrengths_t
- struct unpack_nas_SLQSGetSysSelectionPref_t
- struct nas_netSelectionPref
- struct nas_acqOrderPref
- struct nas_CSGID
- struct pack_nas_SLQSSetSysSelectionPref_t
- struct pack_nas_SLQSSetBandPreference_t
- struct pack_nas_SLQSNasIndicationRegisterExt_t
- struct RFBandInfoElements
- struct unpack_nas_GetRFInfo_t
- struct cdmaSSInfo
- struct hdrSSInfo
- struct lteSSInfo
- struct tdscdmaSigInfoExt
- struct unpack_nas_SLQSNasGetSigInfo_t
- struct unpack_nas_SLQSNasSigInfoCallback_ind_t
- struct unpack_nas_GetHomeNetwork_t
- struct nas_SrvStatusInfo
- struct nas_GSMSrvStatusInfo
- struct nas_sysInfoCommon
- struct nas_CDMASysInfo
- struct nas_HDRSysInfo
- struct nas_GSMSysInfo
- struct nas_WCDMASysInfo

- struct nas_LTESysInfo
- struct nas_AddCDMASysInfo
- struct nas_AddSysInfo
- struct nas_CallBarringSysInfo
- struct unpack_nas_SLQSGetSysInfo_t
- struct unpack_nas_SLQSSysInfoCallback_ind_t
- struct unpack_nas_GetServingNetwork_t
- struct unpack_nas_GetServingNetworkCapabilities_t
- struct nas_QmiNas3GppNetworkInfo
- struct nas_QmiNas3GppNetworkRAT
- struct nas_QmisNasPcsDigit
- struct unpack_nas_PerformNetworkScan_t
- struct unpack_nas_SLQSSwiGetLteCQI_t
- struct nas_CommInfo
- struct nas_LTEInfo
- struct unpack_nas_SLQSNasSwiModemStatus_t
- struct nas_servSystem
- struct nas_dataSrvCapabilities
- struct nas_currentPLMN
- struct nas_roamIndList
- struct nas_qaQmi3Gpp2TimeZone
- struct nas_detailSvcInfo
- struct nas_CDMASysInfoExt
- struct nas_callBarStatus
- struct unpack_nas_SLQSGetServingSystem_t
- struct nas_rxSignalStrengthListElement
- struct nas_ecioListElement
- struct nas_errorRateListElement
- struct nas_rsrqInformation
- struct nas_lteSnrinformation
- struct nas_lteRsrpinformation
- struct unpack_nas_SLQSGetSignalStrength_t
- struct nas_SLQSSignalStrengthsIndReq
- struct pack_nas_SLQSSetSignalStrengthsCallback_t
- struct nas_SLQSSignalStrengthsInformation
- struct nas_RejectReasonTlv
- struct nas_SignalStrengthTlv
- struct nas_RFInfoTlv
- struct nas_SLQSSignalStrengthsTlv
- struct unpack_nas_SetEventReportInd_t
- struct unpack_nas_GetCDMANetworkParameters_t
- struct pack_nas_SetACCOLC_t
- struct nas_CDMARSSIThresh
- struct nas_CDMAECIOThresh
- struct nas_HDRRSSIThresh
- struct nas_HDRECIOThresh
- struct nas_HDRSINRThreshold
- struct nas_HDRIOThresh
- struct nas_GSMRSSIThresh
- struct nas_WCDMARSSIThresh
- struct nas_WCDMAECIOThresh
- struct nas_LTERSSIThresh
- struct nas_LTESNRThreshold
- struct nas_LTERSRQThresh
- struct nas_LTERSRPThresh

- struct nas_LTESigRptConfig
- struct nas_TDSCDMARSCPThresh
- struct nas_TDSCDMARSSIThresh
- struct nas_TDSCDMAECIOThresh
- struct nas_TDSCDMASINRThresh
- struct pack_nas_SLQSNasConfigSigInfo2_t
- struct unpack_nas_SetDataCapabilitiesCallback_ind_t
- struct unpack_nas_GetNetworkPreference_t
- struct pack_nas_SetNetworkPreference_t
- struct unpack_nas_SetNetworkPreference_t
- struct unpack_nas_SetRoamingIndicatorCallback_ind_t
- struct NASServingSystemInfo
- struct unpack_nas_SetServingSystemCallback_ind_t
- struct NASPhyCaAggScellIndType
- struct NASPhyCaAggScellDlBw
- struct NASPhyCaAggScellInfo
- struct NASPhyCaAggPcellInfo
- struct NASPhyCaAggScellIndex
- struct NasGetLTECphyCaInfo
- struct unpack_nas_SlqsGetLTECphyCAInfo_t
- struct NASEmergencyModeTlv
- struct NASModePreferenceTlv
- struct NASBandPreferenceTlv
- struct NASPRLPreferenceTlv
- struct NASRoamPreferenceTlv
- struct NASLTEBandPreferenceTlv
- struct NASNetSelPreferenceTlv
- struct NASServDomainPrefTlv
- struct NASGWAcqOrderPrefTlv
- struct NASQmiCbkNasSystemSelPrefInd
- struct unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t
- struct NASOTAMessageTlv
- struct NASLteNasReleaseInfoTlv
- struct NASTimeInfoTlv
- struct NASQmiCbkNasSwiOTAMessageInd
- struct unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t
- struct nas_MNRInfo
- struct pack_nas_SLQSInitiateNetworkRegistration_t
- struct pack_nas_SLQSNasSwiIndicationRegister_t
- struct pack_nas_SLQSGetPLMNName_t
- struct unpack_nas_SLQSGetPLMNName_t
- struct nas_nmrCellInfo
- struct nas_GERANInfo
- struct nas_geranInstInfo
- struct nas_UMTSinstInfo
- struct nas_UMTSInfo
- struct nas_CDMAInfo
- struct nas_cellParams
- struct nas_LTEInfoIntrafreq
- struct nas_infoInterFreq
- struct nas_LTEInfoInterfreq
- struct nas_gsmCellInfo
- struct nas_lteGsmCellInfo
- struct nas_LTEInfoNeighboringGSM
- struct nas_wcdmaCellInfo

- struct nas_lteWcdmaCellInfo
- struct nas_LTEInfoNeighboringWCDMA
- struct nas_umtsLTENbrCell
- struct nas_WCDMAInfoLTENeighborCell
- struct unpack_nas_SLQSNasGetCellLocationInfo_t
- struct nas_timeInfo
- struct unpack_nas_SLQSGetNetworkTime_t
- struct nas_UniversalTime
- struct unpack_nas_SLQSNasNetworkTimeCallBack_ind_t
- struct nas_PhyCaAggScellIndType
- struct nas_PhyCaAggScellDlBw
- struct nas_PhyCaAggScellInfo
- struct nas_PhyCaAggPcellInfo
- struct nas_PhyCaAggScellIndex
- struct unpack_nas_SetNasLTECphyCaIndCallback_ind_t
- struct nas_RxSigInfo
- struct nas_SccRxInfo
- struct unpack_nas_SLQSSwiGetLteSccRxInfo_t
- struct unpack_nas_SLQSNasTimerCallback_ind_t
- struct pack_nas_InitiateDomainAttach_t
- struct pack_nas_SetCDMANetworkParameters_t
- struct unpack_nas_SLQSNasGetHDRColorCode_t
- struct pack_nas_SLQSNasGetTxRxInfo_t
- struct nas_rxInfo
- struct nas_txInfo
- struct unpack_nas_SLQSNasGetTxRxInfo_t
- struct nas_OperatorPLMNData
- struct nas_operatorPLMNList
- struct nas_serviceProviderName
- struct nas_PLMNNetworkNameData
- struct nas_PLMNNetworkName
- struct nas_operatorNameString
- struct unpack_nas_SLQSGetOperatorNameData_t
- struct pack_nas_SLQSNasGet3GPP2Subscription_t
- struct nas_namName
- struct nas_dirNum
- struct nas_sidNid
- struct nas_homeSIDNID
- struct nas_minBasedIMSI
- struct nas_trueIMSI
- struct nas_CDMAChannel
- struct unpack_nas_SLQSNasGet3GPP2Subscription_t
- struct nas_protocolSubtypeElement
- struct unpack_nas_SLQSSwiGetHDRPersonality_t
- struct unpack_nas_SLQSSwiGetHDRProtSubtype_t
- struct pack_nas_SLQSSwiPSDetach_t
- struct unpack_nas_SLQSGetErrorRate_t
- struct nas_DRCParams
- struct nas_PilotSetParams
- struct nas_PilotSetData
- struct unpack_nas_SLQSSwiGetHRPDStats_t
- struct nas_ActPilotPNElement
- struct nas_NetworkStat1x
- struct nas_NetworkStatEVDO
- struct nas_DeviceConfigDetail

- struct nas_DataStatusDetail
- struct unpack_nas_SLQSSwiNetworkDebug_t
- struct nas_RSSIThresh
- struct nas_ECIOThresh
- struct nas_HDRSINRThresh
- struct nas_LTESNRThresh
- struct nas_IOThresh
- struct nas_RSRQThresh
- struct nas_RSRPThresh
- struct nas_LTESigRptCfg
- struct nas_TDSCDMASINRCONFThresh
- struct pack_nas_SLQSConfigSigInfo_t
- struct unpack_nas_GetHomeNetwork3GPP2_t
- struct nas_wcdmaUARFCN
- struct nas_lteEARFCN
- struct nas_ltePCI
- struct pack_nas_SLQSNASSwiSetChannelLock_t
- struct unpack_nas_SLQSNASSwiGetChannelLock_t
- struct unpack_nas_SLQSNASGeteDRXParams_t
- struct pack_nas_SLQSNASSeteDRXParams_t

Macros

- #define NAS_OTA_MESSAGE_MAX_BUF_SIZE 2048
- #define NAS_MAX_NUM_NETWORKS 30
- #define NAS_MAX_DESCRIPTION_LENGTH 255
- #define NAS_PLMN_LENGTH 3
- #define NAS_MAX_SCC_RX_INFO_INSTANCES 255
- #define NAS_NAM_NAME_LENGTH 12
- #define NAS_IMSI_M_S1_LENGTH 7
- #define NAS_IMSI_M_S2_LENGTH 3
- #define NAS_SERVING_SYSTEM_INFO_MAX_RADIO_INTERFACE_LIST 255

Enumerations

- enum LITEQMI_NAS_LTE_CPHY_SCELL_STATE {
  eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_DECONFIGURED =0x00,
  eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED =0x01,
  eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED =0x02 }
- enum LITEQMI_NAS_LTE_CPHY_CA_BW_NRB {
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_6 =0x00,
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_15 =0x01,
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_25 =0x02,
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_50 =0x03,
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_75 =0x04,
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_100 =0x05 }
- enum NAS_LTE_CPHY_CA_BW_NRB_LITE {
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_6 =0x00,
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_15 =0x01,
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_25 =0x02,
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_50 =0x03,
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_75 =0x04,
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_100 =0x05 }
- enum NAS_LTE_CPHY_SCELL_STATE_LITE {
  eNAS_LTE_CPHY_SCELL_STATE_DECONFIGURED_LITE =0x00,
  eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED_LITE =0x01,
  eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED_LITE =0x02 }

Functions

- int unpack_nas_GetSignalStrengths (uint8_t *pResp, uint16_t respLen, unpack_nas_GetSignalStrengths_t *pOutput)
- int pack_nas_GetSignalStrengths (pack_qmi_t *pCtx, uint8_t *pReq, uint16_t *pLen)
- int pack_nas_SLQSGetSysSelectionPref (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetSysSelectionPref (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetSysSelectionPref_t *pOutput)
- int pack_nas_SLQSSetSysSelectionPref (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSSetSysSelectionPref_t *pReqParam)
- int unpack_nas_SLQSSetSysSelectionPref (uint8_t *pResp, uint16_t respLen)
- int pack_nas_SLQSSetBandPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSSetBandPreference_t *pReqParam)
- int unpack_nas_SLQSSetBandPreference (uint8_t *pResp, uint16_t respLen)
- int pack_nas_SLQSNasIndicationRegisterExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNasIndicationRegisterExt_t *pReqParam)
- int unpack_nas_SLQSNasIndicationRegisterExt (uint8_t *pResp, uint16_t respLen)
- int pack_nas_GetRFInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetRFInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_GetRFInfo_t *pOutput)
- int pack_nas_SLQSNasGetSigInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNasGetSigInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasGetSigInfo_t *pOutput)
- int unpack_valid_nas_SLQSNasGetSigInfo (uint8_t *pResp, uint8_t u8Info)
- int unpack_nas_SLQSNasSigInfoCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasSigInfoCallback_ind_t *pOutput)
- int unpack_nas_GetHomeNetwork (uint8_t *pResp, uint16_t respLen, unpack_nas_GetHomeNetwork_t *pOutput)
- int pack_nas_GetHomeNetwork (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int pack_nas_SLQSGetSysInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetSysInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetSysInfo_t *pOutput)
- int unpack_nas_SLQSNasSysInfoCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSysInfoCallback_ind_t *pOutput)
- int pack_nas_GetServingNetwork (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetServingNetwork (uint8_t *pResp, uint16_t respLen, unpack_nas_GetServingNetwork_t *pOutput)
- int pack_nas_GetServingNetworkCapabilities (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetServingNetworkCapabilities (uint8_t *pResp, uint16_t respLen, unpack_nas_GetServingNetworkCapabilities_t *pOutput)
- int pack_nas_PerformNetworkScan (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_PerformNetworkScan (uint8_t *pResp, uint16_t respLen, unpack_nas_PerformNetworkScan_t *pOutput)
- int pack_nas_SLQSSwiGetLteCQI (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSSwiGetLteCQI (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiGetLteCQI_t *pOutput)
- int pack_nas_SLQSNasSwiModemStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNasSwiModemStatus (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasSwiModemStatus_t *pOutput)
- int pack_nas_SLQSGetServingSystem (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetServingSystem (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetServingSystem_t *pOutput)
- int unpack_valid_nas_SLQSGetServingSystem (uint8_t *pResp, uint8_t u8Info)
- int pack_nas_SLQSGetSignalStrength (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, uint16_t reqMask)
- int unpack_nas_SLQSGetSignalStrength (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetSignalStrength_t *pOutput)

- int unpack_valid_nas_SLQSGetSignalStrength (uint8_t *pResp, uint8_t u8Info)
- int pack_nas_SLQSSetSignalStrengthsCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSSetSignalStrengthsCallback_t *pReqParam)
- int unpack_nas_SLQSSetSignalStrengthsCallback (uint8_t *pResp, uint16_t respLen)
- int pack_nas_SetRFInfoCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, uint8_t *pBenable)
- int unpack_nas_SetRFInfoCallback (uint8_t *pResp, uint16_t respLen)
- int pack_nas_SetLURejectCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, uint8_t *pBenable)
- int unpack_nas_SetLURejectCallback (uint8_t *pResp, uint16_t respLen)
- int unpack_nas_SetEventReportInd (uint8_t *pResp, uint16_t respLen, unpack_nas_SetEventReportInd_t *pOutput)
- int pack_nas_GetCDMANetworkParameters (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetCDMANetworkParameters (uint8_t *pResp, uint16_t respLen, unpack_nas_GetCDMANetworkParameters_t *pOutput)
- int unpack_valid_nas_GetCDMANetworkParameters (uint8_t *pResp, uint8_t u8Info)
- int pack_nas_GetANAAAAuthenticationStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetANAAAAuthenticationStatus (uint8_t *pResp, uint16_t respLen, uint32_t *pAuthStatus)
- int pack_nas_GetACCOLC (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetACCOLC (uint8_t *pResp, uint16_t respLen, uint8_t *pAccolc)
- int pack_nas_SetACCOLC (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SetACCOLC_t reqParam)
- int unpack_nas_SetACCOLC (uint8_t *pResp, uint16_t respLen)
- int pack_nas_SLQSNasConfigSigInfo2 (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNasConfigSigInfo2_t *pReqParam)
- int unpack_nas_SLQSNasConfigSigInfo2 (uint8_t *pResp, uint16_t respLen)
- int unpack_nas_SetDataCapabilitiesCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SetDataCapabilitiesCallback_ind_t *pOutput)
- int pack_nas_GetNetworkPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetNetworkPreference (uint8_t *pResp, uint16_t respLen, unpack_nas_GetNetworkPreference_t *pOutput)
- int pack_nas_SetNetworkPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SetNetworkPreference_t *reqArg)
- int unpack_nas_SetNetworkPreference (uint8_t *pResp, uint16_t respLen, unpack_nas_SetNetworkPreference_t *pOutput)
- int unpack_nas_SetRoamingIndicatorCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SetRoamingIndicatorCallback_ind_t *pOutput)
- int unpack_nas_SetServingSystemCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SetServingSystemCallback_ind_t *pOutput)
- int pack_nas_SlqsGetLTECphyCAInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SlqsGetLTECphyCAInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SlqsGetLTECphyCAInfo_t *pOutput)
- int unpack_nas_SLQSSetSysSelectionPrefCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t *pOutput)
- int unpack_nas_SLQSNasSwiOTAMessageCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t *pOutput)
- int pack_nas_SLQSInitiateNetworkRegistration (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSInitiateNetworkRegistration_t *pReqParam)
- int unpack_nas_SLQSInitiateNetworkRegistration (uint8_t *pResp, uint16_t respLen)
- int pack_nas_SLQSNasSwiIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNasSwiIndicationRegister_t *pReqParam)
- int unpack_nas_SLQSNasSwiIndicationRegister (uint8_t *pResp, uint16_t respLen)
- int pack_nas_SLQSGetPLMNName (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSGetPLMNName_t *reqArg)
- int unpack_nas_SLQSGetPLMNName (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetPLMNName_t *pOutput)
- int pack_nas_SLQSNasGetCellLocationInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)

- int unpack_nas_SLQSNasGetCellLocationInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasGetCellLocationInfo_t *pOutput)
- int pack_nas_SLQSGetNetworkTime (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetNetworkTime (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetNetworkTime_t *pOutput)
- int unpack_nas_SLQSNasNetworkTimeCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasNetworkTimeCallBack_ind_t *pOutput)
- int unpack_nas_SetNasLTECphyCaIndCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SetNasLTECphyCaIndCallback_ind_t *pOutput)
- int pack_nas_SLQSSwiGetLteSccRxInfo (pack_qmi_t *pCtx, uint8_t *pReq, uint16_t *pLen)
- int unpack_nas_SLQSSwiGetLteSccRxInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiGetLteSccRxInfo_t *pOutput)
- int unpack_nas_SLQSNasTimerCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasTimerCallback_ind_t *pOutput)
- int pack_nas_InitiateDomainAttach (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_InitiateDomainAttach_t *pReqParam)
- int unpack_nas_InitiateDomainAttach (uint8_t *pResp, uint16_t respLen)
- int pack_nas_SetCDMANetworkParameters (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SetCDMANetworkParameters_t *pReqParam)
- int unpack_nas_SetCDMANetworkParameters (uint8_t *pResp, uint16_t respLen)
- int pack_nas_SLQSNasGetHDRColorCode (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNasGetHDRColorCode (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasGetHDRColorCode_t *pOutput)
- int pack_nas_SLQSNasGetTxRxInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNasGetTxRxInfo_t *reqArg)
- int unpack_nas_SLQSNasGetTxRxInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasGetTxRxInfo_t *pOutput)
- int pack_nas_SLQSGetOperatorNameData (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetOperatorNameData (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetOperatorNameData_t *pOutput)
- int pack_nas_SLQSNasGet3GPP2Subscription (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNasGet3GPP2Subscription_t *reqArg)
- int unpack_nas_SLQSNasGet3GPP2Subscription (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasGet3GPP2Subscription_t *pOutput)
- int pack_nas_SLQSSwiGetHDRPersonality (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSSwiGetHDRPersonality (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiGetHDRPersonality_t *pOutput)
- int pack_nas_SLQSSwiGetHDRProtSubtype (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSSwiGetHDRProtSubtype (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiGetHDRProtSubtype_t *pOutput)
- int pack_nas_SLQSSwiPSDetach (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSSwiPSDetach_t *pReqParam)
- int unpack_nas_SLQSSwiPSDetach (uint8_t *pResp, uint16_t respLen)
- int pack_nas_SLQSGetErrorRate (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetErrorRate (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetErrorRate_t *pOutput)
- int pack_nas_SLQSSwiGetHRPDStats (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSSwiGetHRPDStats (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiGetHRPDStats_t *pOutput)
- int pack_nas_SLQSSwiNetworkDebug (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSSwiNetworkDebug (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiNetworkDebug_t *pOutput)
- int pack_nas_SLQSConfigSigInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSConfigSigInfo_t *pReqParam)
- int unpack_nas_SLQSConfigSigInfo (uint8_t *pResp, uint16_t respLen)
- int pack_nas_GetHomeNetwork3GPP2 (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)

- int unpack_nas_GetHomeNetwork3GPP2 (uint8_t *pResp, uint16_t respLen, unpack_nas_GetHomeNetwork3GPP2_t *pOutput)
- int pack_nas_SLQSNASSwiSetChannelLock (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNASSwiSetChannelLock_t *pReqParam)
- int unpack_nas_SLQSNASSwiSetChannelLock (uint8_t *pResp, uint16_t respLen)
- int pack_nas_SLQSNASSwiGetChannelLock (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNASSwiGetChannelLock (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNASSwiGetChannelLock_t *pOutput)
- int pack_nas_SLQSNASGeteDRXParams (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNASGeteDRXParams (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNASGeteDRXParams_t *pOutput)
- int pack_nas_SLQSNASSeteDRXParams (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNASSeteDRXParams_t *pReqParam)
- int unpack_nas_SLQSNASSeteDRXParams (uint8_t *pResp, uint16_t respLen)

9.11.1 Macro Definition Documentation

9.11.1.1 #define NAS_IMSI_M_S1_LENGTH 7

9.11.1.2 #define NAS_IMSI_M_S2_LENGTH 3

9.11.1.3 #define NAS_MAX_DESCRIPTION_LENGTH 255

9.11.1.4 #define NAS_MAX_NUM_NETWORKS 30

9.11.1.5 #define NAS_MAX_SCC_RX_INFO_INSTANCES 255

9.11.1.6 #define NAS_NAM_NAME_LENGTH 12

9.11.1.7 #define NAS_OTA_MESSAGE_MAX_BUF_SIZE 2048

9.11.1.8 #define NAS_PLMN_LENGTH 3

9.11.1.9 #define NAS_SERVING_SYSTEM_INFO_MAX_RADIO_INTERFACE_LIST 255

9.11.2 Enumeration Type Documentation

9.11.2.1 enum LITEQMI_NAS_LTE_CPHY_CA_BW_NRB

Enumerator

eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_6
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_15
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_25
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_50
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_75
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_100

9.11.2.2 enum LITEQMI_NAS_LTE_CPHY_SCELL_STATE

Enumerator

eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_DECONFIGURED
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED

9.11.2.3 enum NAS_LTE_CPHY_CA_BW_NRB_LITE

Enumerator

eNAS_LTE_CPHY_CA_BW_NRB_LITE_6

eNAS_LTE_CPHY_CA_BW_NRB_LITE_15

eNAS_LTE_CPHY_CA_BW_NRB_LITE_25

eNAS_LTE_CPHY_CA_BW_NRB_LITE_50

eNAS_LTE_CPHY_CA_BW_NRB_LITE_75

eNAS_LTE_CPHY_CA_BW_NRB_LITE_100

9.11.2.4 enum NAS_LTE_CPHY_SCELL_STATE_LITE

Enumerator

eNAS_LTE_CPHY_SCELL_STATE_DECONFIGURED_LITE

eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED_LITE

eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED_LITE

9.11.3 Function Documentation

9.11.3.1 int pack_nas_GetACCOLC (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Retrieves information about the access overload class (ACCOLC) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.2 int pack_nas_GetANAAAAuthenticationStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

AN-AAA authentication status of the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.3 int pack_nas_GetCDMANetworkParameters (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get CDMA Network Parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.4 int pack_nas_GetHomeNetwork (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get home network pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.5 int pack_nas_GetHomeNetwork3GPP2 (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get Home Network 3GPP2 Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.6 int pack_nas_GetNetworkPreference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the network registration preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

9.11.3.7 int pack_nas_GetRFInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get rf info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.8 int pack_nas_GetServingNetwork (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack provides information about the system that provides service to the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.9 int pack_nas_GetServingNetworkCapabilities (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack returns information regarding the data capabilities of the system that currently provides service to the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.10 int pack_nas_GetSignalStrengths (pack_qmi_t * *pCtx*, uint8_t * *pReq*, uint16_t * *pLen*)

get signal strengths pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReq*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.11 int pack_nas_InitiateDomainAttach (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_InitiateDomainAttach_t * *pReqParam*)

Initiates a domain attach/detach of the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.12 int pack_nas_PerformNetworkScan (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack performs scan for available networks and scans for RAT info as well.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.13 int pack_nas_SetACCOLC (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SetACCOLC_t *reqParam*)

Pack Sets the access overload class (ACCOLC)

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.14 int pack_nas_SetCDMANetworkParameters (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SetCDMANetworkParameters_t * *pReqParam*)

CDMA Network Parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.15 int pack_nas_SetLURejectCallback (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, uint8_t * pBenable)

Pack set registration reject Callback

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pBenable*	0/1 value to disable/enable indication respectively

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.16 int pack_nas_SetNetworkPreference (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_nas_SetNetworkPreference_t * reqArg)

Sets the network registration preference. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use pack_nas_SLQSSetSysSelectionPref() for new firmware versions and new modules

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

9.11.3.17 int pack_nas_SetRFInfoCallback (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, uint8_t * pBenable)

Pack Set RF Band Information callback.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pBenable*	0/1 value to disable/enable indication respectively

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.18 int pack_nas_SLQSConfigSigInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSConfigSigInfo_t * *pReqParam*)

Config Sig Info Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.19 int pack_nas_SLQSGetErrorRate (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get Error Rate Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.20 int pack_nas_SlqsGetLTECphyCAInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack get carrier aggregation event information.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

9.11.3.21 int pack_nas_SLQSGetNetworkTime (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack Get Network Time.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.22 int pack_nas_SLQSGetOperatorNameData (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Operator Name Data Parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.23 int pack_nas_SLQSGetPLMNName (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSGetPLMNName_t * *reqArg*)

Pack get operator name for specificed network.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.24 int pack_nas_SLQSGetServingSystem (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack queries information regarding the system that currently provides service.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.25 int pack_nas_SLQSGetSignalStrength (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, uint16_t *reqMask*)

Queries the current signal strength as measured by the device. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use unpack_nas_SLQSNasGetSigInfo() for new firmware versions and new modules

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqMask*	request mask for fetching extra signal info

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.26 int pack_nas_SLQSGetSysInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack get system information.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.27 int pack_nas_SLQSGetSysSelectionPref (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Queries the different system selection preferences of the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.28 int pack_nas_SLQSInitiateNetworkRegistration (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_nas_SLQSInitiateNetworkRegistration_t * pReqParam)

Pack initiates a network registration.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.29 int pack_nas_SLQSNasConfigSigInfo2 (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_nas_SLQSNasConfigSigInfo2_t * pReqParam)

Pack sets the signal strength reporting thresholds

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.30 int pack_nas_SLQSNasGet3GPP2Subscription (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSNasGet3GPP2Subscription_t * *reqArg*)

3GPP2 Subscription Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.31 int pack_nas_SLQSNasGetCellLocationInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack retrieves cell location-related information.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.32 int pack_nas_SLQSNASGeteDRXParams (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get eDRX Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.33 int pack_nas_SLQSNasGetHDRColorCode (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

HDR Color Code Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.34 int pack_nas_SLQSNasGetSigInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get sig info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.35 int pack_nas_SLQSNasGetTxRxInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSNasGetTxRxInfo_t * *reqArg*)

Get Tx Rx Info Parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.36 int pack_nas_SLQSNasIndicationRegisterExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSNasIndicationRegisterExt_t * *pReqParam*)

Pack used to Registers/De-registers for different NAS (Network access service) indications.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

This function is used by a control point to register/deregister for different QMI_NAS indications. The control point's registration state variables, controlling registration for indications, are modified to reflect the settings indicated in the parameters that are present in the request message. At least one optional parameter must be present in the request.

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.37 int pack_nas_SLQSNASSeteDRXParams (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSNASSeteDRXParams_t * *pReqParam*)

Set eDRX Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.38 int pack_nas_SLQSNASSwiGetChannelLock (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Get Channel Lock Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.39 int pack_nas_SLQSNasSwiIndicationRegister (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_nas_SLQSNasSwiIndicationRegister_t * pReqParam)

Pack sets the registration state for different QMI_NAS SWI indications.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.40 int pack_nas_SLQSNasSwiModemStatus (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

This function requests the device to return the current status of modem.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.41 int pack_nas_SLQSNASSwiSetChannelLock (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSNASSwiSetChannelLock_t * *pReqParam*)

Set Channel Lock Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.42 int pack_nas_SLQSSetBandPreference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSSetBandPreference_t * *pReqParam*)

Pack sets the different system selection preferences of the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.43 int pack_nas_SLQSSetSignalStrengthsCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSSetSignalStrengthsCallback_t * *pReqParam*)

Pack set signal strength thresholds callback.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.44 int pack_nas_SLQSSetSysSelectionPref (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSSetSysSelectionPref_t * *pReqParam*)

Sets the different system selection preferences of the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values4780

9.11.3.45 int pack_nas_SLQSSwiGetHDRPersonality (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

HDR Personality Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.46 int pack_nas_SLQSSwiGetHDRProtSubtype (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

HDR Protocol Sub type Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.47 int pack_nas_SLQSSwiGetHRPDStats (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

HRPD Stats Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.48 int pack_nas_SLQSSwiGetLteCQI (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack fetch CQI parameters for LTE data session.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.49 int pack_nas_SLQSSwiGetLteSccRxInfo (pack_qmi_t * *pCtx*, uint8_t * *pReq*, uint16_t * *pLen*)

get LTE Secondary carrier Rx signal level information pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReq*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.50 int pack_nas_SLQSSwiNetworkDebug (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Network Debug Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.51 int pack_nas_SLQSSwiPSDetach (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSSwiPSDetach_t * *pReqParam*)

PS Connection Detach Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.52 int unpack_nas_GetACCOLC (uint8_t * *pResp*, uint16_t *respLen*, uint8_t * *pAccolc*)

Retrieves information about the access overload class (ACCOLC) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pAccolc*	An 8-bit integer representation of the ACCOLC. • Range: 0 to 15 (0x00 to 0x0F). • 0xFF invalid data.

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.53 int unpack_nas_GetANAAAAuthenticationStatus (uint8_t * *pResp*, uint16_t *respLen*, uint32_t * *pAuthStatus*)

AN-AAA authentication status of the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pAuthStatus*	AN-AAA Authentication Status. Status of the last AN-AAA authentication request, if any, for the current 1xEV-DO session. • 0 - AAA_STATUS_FAILED - Authentication failed • 1 - AAA_STATUS_SUCCESS - Authentication success • 2 - AAA_STATUS_NO_REQUEST - No authentication requested • 0xffffffff - invalid data.

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.54 int unpack_nas_GetCDMANetworkParameters (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetCDMANetworkParameters_t * *pOutput*)

Get CDMA Network Parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	qmi output parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.55 int unpack_nas_GetHomeNetwork (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetHomeNetwork_t * *pOutput*)

Retrieves information about the home network of the device unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.56 int unpack_nas_GetHomeNetwork3GPP2 (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetHomeNetwork3GPP2_t * *pOutput*)

Get Home Network 3GPP2 Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.57 int unpack_nas_GetNetworkPreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetNetwork-Preference_t * *pOutput*)

Gets the network registration preference unpack

Parameters

in	*pResp*	qmi resp from modem
in	*respLen*	qmi resp length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.58 int unpack_nas_GetRFInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetRFInfo_t * *pOutput*)

get rf info unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.59 int unpack_nas_GetServingNetwork (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetServingNetwork_t * *pOutput*)

Unpack provides information about the system that provides service to the device. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use API unpack_nas_SLQSGetSysInfo() for new firmware versions and new modules

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.60 int unpack_nas_GetServingNetworkCapabilities (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetServingNetworkCapabilities_t * *pOutput*)

Unpack returns information regarding the data capabilities of the system that currently provides service to the device.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.61 int unpack_nas_GetSignalStrengths (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetSignalStrengths_t * *pOutput*)

Returns the available signal strengths (in dBm) as measured by the device in an array. This will also provides the corresponding radio interfaces in an array.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.62 int unpack_nas_InitiateDomainAttach (uint8_t * *pResp*, uint16_t *respLen*)

Initiates a domain attach/detach of the device unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.63 int unpack_nas_PerformNetworkScan (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_PerformNetwork-Scan_t * *pOutput*)

Unpack performs scan for available networks and scans for RAT info as well.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.64 int unpack_nas_SetACCOLC (uint8_t * *pResp*, uint16_t *respLen*)

Unpack Sets the access overload class (ACCOLC)

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.65 int unpack_nas_SetCDMANetworkParameters (uint8_t * *pResp*, uint16_t *respLen*)

CDMA Network Parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.66 int unpack_nas_SetDataCapabilitiesCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetDataCapabilitiesCallback_ind_t * *pOutput*)

Data Capabilities indication unpack

Parameters

in	*pResp*	qmi indication from modem
in	*respLen*	qmi indication length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.67 int unpack_nas_SetEventReportInd (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetEventReportInd_t * *pOutput*)

Unpack set event report indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.68 int unpack_nas_SetLURejectCallback (uint8_t * *pResp*, uint16_t *respLen*)

Unpack set registration reject Callback

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.69 int unpack_nas_SetNasLTECphyCaIndCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetNasLTECphyCaIndCallback_ind_t * *pOutput*)

Unpack set LTE PHY CA indication callback.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	sig info indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.70 int unpack_nas_SetNetworkPreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetNetworkPreference_t * *pOutput*)

Sets the network registration preference unpack

Parameters

in	*pResp*	qmi resp from modem
in	*respLen*	qmi resp length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.71 int unpack_nas_SetRFInfoCallback (uint8_t * *pResp*, uint16_t *respLen*)

Unack Set RF Band Information callback.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.72 int unpack_nas_SetRoamingIndicatorCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetRoamingIndicatorCallback_ind_t * *pOutput*)

Roaming indication unpack

Parameters

in	*pResp*	qmi indication from modem
in	*respLen*	qmi indication length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.73 int unpack_nas_SetServingSystemCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetServingSystemCallback_ind_t * *pOutput*)

Set Serving system indication unpack

Parameters

in	*pResp*	qmi indication from modem
in	*respLen*	qmi indication length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.74 int unpack_nas_SLQSConfigSigInfo (uint8_t * *pResp*, uint16_t *respLen*)

Config Sig Info Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.75 int unpack_nas_SLQSGetErrorRate (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetErrorRate_t * *pOutput*)

Get Error Rate Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.76 int unpack_nas_SlqsGetLTECphyCAInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SlqsGetLTECphyCAInfo_t * *pOutput*)

Unack get carrier aggregation event information.

Parameters

in	*pResp*	qmi resp from modem
in	*respLen*	qmi resp length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.77 int unpack_nas_SLQSGetNetworkTime (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetNetworkTime_t * *pOutput*)

Unpack get network time.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.78 int unpack_nas_SLQSGetOperatorNameData (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetOperatorNameData_t * *pOutput*)

Operator Name Data Parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.79 int unpack_nas_SLQSGetPLMNName (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetPLMNName_t * *pOutput*)

unpack get operator name for specificed network.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.80 int unpack_nas_SLQSGetServingSystem (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetServingSystem_t * *pOutput*)

Unack queries information regarding the system that currently provides service.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.81 int unpack_nas_SLQSGetSignalStrength (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetSignalStrength_t * *pOutput*)

Unpack get signal strength.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.82 int unpack_nas_SLQSGetSysInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetSysInfo_t * *pOutput*)

Provides the system information. This API is preferred when trying to get the service status info and serving system info. The function unpack_nas_SLQSGetServingSystem_t() reports similar NAS information, but it is deprecated. Please refer to the header description of unpack_nas_SLQSGetServingSystem_t() for more information.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

This API queries current serving system information, including registration information and system property. The registration information for all RATs specified in the mode capability setting are included regardless of registration status. The RAT-specific system property are included only for RATs that are specified in the mode capability setting and which are not in either No Service or Power Save modes.

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.83 int unpack_nas_SLQSGetSysSelectionPref (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetSysSelectionPref_t * *pOutput*)

Queries the different system selection preferences of the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.84 int unpack_nas_SLQSInitiateNetworkRegistration (uint8_t * *pResp*, uint16_t *respLen*)

Unpack initiates a network registration.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.85 int unpack_nas_SLQSNasConfigSigInfo2 (uint8_t * *pResp*, uint16_t *respLen*)

Unpack sets the signal strength reporting thresholds

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.86 int unpack_nas_SLQSNasGet3GPP2Subscription (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasGet3GPP2Subscription_t * *pOutput*)

3GPP2 Subscription Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.87 int unpack_nas_SLQSNasGetCellLocationInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasGetCellLocationInfo_t * *pOutput*)

Unpack retrieves cell location-related information.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.88 int unpack_nas_SLQSNASGeteDRXParams (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNASGeteDRXParams_t * *pOutput*)

Get eDRX Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.89 int unpack_nas_SLQSNasGetHDRColorCode (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasGetHDRColorCode_t * *pOutput*)

HDR Color Code Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.90 int unpack_nas_SLQSNasGetSigInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasGetSigInfo_t * *pOutput*)

get sig info unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

This command queries the signal strength information for currently active RATs. Information is reported only if the corresponding RATs have signal strength values to be reported. If no signal strength information is available for any RAT, the response message contains only the mandatory response message

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.91 int unpack_nas_SLQSNasGetTxRxInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasGetTxRxInfo_t * *pOutput*)

Get Tx Rx Info Parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.92 int unpack_nas_SLQSNasIndicationRegisterExt (uint8_t * *pResp*, uint16_t *respLen*)

Unpack used to Registers/De-registers for different NAS (Network access service) indications.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.93 int unpack_nas_SLQSNasNetworkTimeCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasNetworkTimeCallBack_ind_t * *pOutput*)

Unpack Network time callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	sig info indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.94 int unpack_nas_SLQSNASSeteDRXParams (uint8_t * *pResp*, uint16_t *respLen*)

Set eDRX Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.95 int unpack_nas_SLQSNasSigInfoCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasSigInfoCallback_ind_t * *pOutput*)

Unpack Signal Information callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	sig info indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.96 int unpack_nas_SLQSNASSwiGetChannelLock (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNASSwiGetChannelLock_t * *pOutput*)

Get Channel Lock Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.97 int unpack_nas_SLQSNasSwiIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*)

unpack sets the registration state for different QMI_NAS SWI indications.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.98 int unpack_nas_SLQSNasSwiModemStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasSwiModemStatus_t * *pOutput*)

This function requests the device to return the current status of modem.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.99 int unpack_nas_SLQSNasSwiOTAMessageCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t * *pOutput*)

OTA message indication unpack

Parameters

in	*pResp*	qmi indication from modem
in	*respLen*	qmi indication length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.100 int unpack_nas_SLQSNASSwiSetChannelLock (uint8_t * *pResp*, uint16_t *respLen*)

Set Channel Lock Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.101 int unpack_nas_SLQSNasSysInfoCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSysInfoCallback_ind_t * *pOutput*)

Unpack system information callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.102 int unpack_nas_SLQSNasTimerCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasTimerCallback_ind_t * *pOutput*)

Unpack timer callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	network timer indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.103 int unpack_nas_SLQSSetBandPreference (uint8_t * *pResp*, uint16_t *respLen*)

Unpack sets the different system selection preferences of the device.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

9.11.3.104 int unpack_nas_SLQSSetSignalStrengthsCallback (uint8_t * *pResp*, uint16_t *respLen*)

Unpack set signal strength thresholds callback.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.105 int unpack_nas_SLQSSetSysSelectionPref (uint8_t * *pResp*, uint16_t *respLen*)

Sets the different system selection preferences of the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.106 int unpack_nas_SLQSSetSysSelectionPrefCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t * *pOutput*)

System Selection Preference indication unpack

Parameters

in	*pResp*	qmi indication from modem
in	*respLen*	qmi indication length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.107 int unpack_nas_SLQSSwiGetHDRPersonality (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiGetHDRPersonality_t * *pOutput*)

HDR Personality Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.108 int unpack_nas_SLQSSwiGetHDRProtSubtype (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiGetHDRProtSubtype_t * *pOutput*)

HDR Protocol Sub type Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.109 int unpack_nas_SLQSSwiGetHRPDStats (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiGetHRPDStats_t * *pOutput*)

HRPD Stats Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.110 int unpack_nas_SLQSSwiGetLteCQI (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiGetLteCQI_t * *pOutput*)

Unack fetch CQI parameters for LTE data session.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.111 int unpack_nas_SLQSSwiGetLteSccRxInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiGetLteSccRxInfo_t * *pOutput*)

get LTE Secondary carrier Rx signal level information unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.112 int unpack_nas_SLQSSwiNetworkDebug (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiNetworkDebug_t * *pOutput*)

Network Debug Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.113 int unpack_nas_SLQSSwiPSDetach (uint8_t * *pResp*, uint16_t *respLen*)

PS Connection Detach Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.114 int unpack_valid_nas_GetCDMANetworkParameters (uint8_t * *pResp*, uint8_t *u8Info*)

valid CDMA Network Parameters

Parameters

in	*pResp*	qmi response from modem
in	*u8Info*	value to check unpack_nas_GetCDMANetworkParameters_t param valid. • 0 - SCI • 1 - SCM • 2 - RegHomeSID, RegForeignSID and RegForeignNID • 3 - ForceRev0 • 4 - CustomSCP, Protocol ,Broadcast and Application • 5 - Roaming

Returns

eQCWWAN_ERR_NONE on signal info valid, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.115 int unpack_valid_nas_SLQSGetServingSystem (uint8_t * *pResp*, uint8_t *u8Info*)

valid queries information regarding the system that currently provides service

Parameters

in	*pResp*	qmi response from modem
in	*u8Info*	value to check unpack_nas_SLQSGetServingSystem_t param valid. • 0 - RoamIndicatorVal • 1 - DataSrvCapabilities • 2 - CurrentPLMN • 3 - SystemID and NetworkID • 4 - BaseStationID, BaseStationLatitude and BasestationLongitude • 5 - RoamingIndicatorList • 6 - DefaultRoamInd • 7 - Gpp2TimeZone • 8 - CDMA_P_Rev • 9 - GppTimeZone • 10 - GppNetworkDSTAdjustment • 11 - Lac • 12 - CellID • 13 - ConcSvcInfo • 14 - PRLInd • 15 - DTMInd • 16 - DetailedSvcInfo • 17 - CDMASystemInfoExt • 18 - HdrPersonality • 19 - TrackAreaCode • 20 - CallBarStatus

Returns

eQCWWAN_ERR_NONE on signal info valid, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.116 int unpack_valid_nas_SLQSGetSignalStrength (uint8_t * *pResp*, uint8_t *u8Info*)

valid queries information regarding the system that currently provides service

Parameters

in	*pResp*	qmi response from modem
in	*u8Info*	value to check unpack_nas_SLQSGetSignalStrength_t param valid. • 0 - rxSignalStrengthList and rxSignalStrengthListLen • 1 - ecioList and ecioListLen • 2 - Io • 3 - sinr • 4 - errorRateListLen, errorRateList • 5 - rsrqInfo • 6 - ltesnr • 7 - ltersrp

Returns

eQCWWAN_ERR_NONE on signal info valid, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.3.117 int unpack_valid_nas_SLQSNasGetSigInfo (uint8_t * *pResp*, uint8_t *u8Info*)

valid get sig info

Parameters

in	*pResp*	qmi response from modem
in	*u8Info*	value to check unpack_nas_SLQSNasGetSigInfo_t param valid. • 0 - CDMASSInfo • 1 - HDRSSInfo. • 2 - GSMSSInfo. • 3 - WCDMASSInfo. • 4 - LTESSInfo.

Returns

eQCWWAN_ERR_NONE on signal info valid, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12 pds.h File Reference

Data Structures

- struct unpack_pds_GetPDSState_t
- struct pack_pds_SetPDSState_t
- struct unpack_pds_GetPDSDefaults_t
- struct pack_pds_SetPDSDefaults_t
- struct unpack_pds_GetPortAutomaticTracking_t
- struct pack_pds_SetPortAutomaticTracking_t
- struct pack_pds_StartPDSTrackingSessionExt_t
- struct pack_pds_PDSInjectTimeReference_t
- struct unpack_pds_GetXTRAAutomaticDownload_t
- struct pack_pds_SetXTRAAutomaticDownload_t
- struct unpack_pds_GetXTRANetwork_t
- struct pack_pds_SetXTRANetwork_t
- struct unpack_pds_GetXTRAValidity_t
- struct unpack_pds_GetServiceAutomaticTracking_t
- struct pack_pds_SetServiceAutomaticTracking_t
- struct pack_pds_ResetPDSData_t
- struct pack_pds_SLQSSetAGPSConfig_t
- struct pack_pds_SLQSPDSInjectAbsoluteTimeReference_t

- struct pack_pds_SLQSGetAGPSConfig_t
- struct unpack_pds_SLQSGetAGPSConfig_t
- struct pack_pds_SLQSPDSInjectPositionData_t
- struct unpack_pds_SLQSGetGPSStateInfo_t
- struct pack_pds_SLQSSetPositionMethodState_t
- struct pack_pds_SetEventReportCallback_t
- struct unpack_pds_SetEventReport_Ind_t
- struct unpack_pds_SetPdsState_Ind_t

Functions

- int pack_pds_GetPDSState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetPDSState (uint8_t *pResp, uint16_t respLen, unpack_pds_GetPDSState_t *pOutput)
- int pack_pds_SetPDSState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetPDSState_t *pReqParam)
- int unpack_pds_SetPDSState (uint8_t *pResp, uint16_t respLen)
- int pack_pds_GetPDSDefaults (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetPDSDefaults (uint8_t *pResp, uint16_t respLen, unpack_pds_GetPDSDefaults_t *pOutput)
- int pack_pds_SetPDSDefaults (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetPDSDefaults_t *pReqParam)
- int unpack_pds_SetPDSDefaults (uint8_t *pResp, uint16_t respLen)
- int pack_pds_GetPortAutomaticTracking (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetPortAutomaticTracking (uint8_t *pResp, uint16_t respLen, unpack_pds_GetPortAutomaticTracking_t *pOutput)
- int pack_pds_SetPortAutomaticTracking (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetPortAutomaticTracking_t *pReqParam)
- int unpack_pds_SetPortAutomaticTracking (uint8_t *pResp, uint16_t respLen)
- int pack_pds_StartPDSTrackingSessionExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_StartPDSTrackingSessionExt_t *pReqParam)
- int unpack_pds_StartPDSTrackingSessionExt (uint8_t *pResp, uint16_t respLen)
- int pack_pds_StopPDSTrackingSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_StopPDSTrackingSession (uint8_t *pResp, uint16_t respLen)
- int pack_pds_PDSInjectTimeReference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_PDSInjectTimeReference_t *pReqParam)
- int unpack_pds_PDSInjectTimeReference (uint8_t *pResp, uint16_t respLen)
- int pack_pds_GetXTRAAutomaticDownload (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetXTRAAutomaticDownload (uint8_t *pResp, uint16_t respLen, unpack_pds_GetXTRAAutomaticDownload_t *pOutput)
- int pack_pds_SetXTRAAutomaticDownload (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetXTRAAutomaticDownload_t *pReqParam)
- int unpack_pds_SetXTRAAutomaticDownload (uint8_t *pResp, uint16_t respLen)
- int pack_pds_GetXTRANetwork (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetXTRANetwork (uint8_t *pResp, uint16_t respLen, unpack_pds_GetXTRANetwork_t *pOutput)
- int pack_pds_SetXTRANetwork (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetXTRANetwork_t *pReqParam)
- int unpack_pds_SetXTRANetwork (uint8_t *pResp, uint16_t respLen)
- int pack_pds_GetXTRAValidity (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetXTRAValidity (uint8_t *pResp, uint16_t respLen, unpack_pds_GetXTRAValidity_t *pOutput)
- int pack_pds_ForceXTRADownload (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_ForceXTRADownload (uint8_t *pResp, uint16_t respLen)
- int pack_pds_GetServiceAutomaticTracking (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)

- int unpack_pds_GetServiceAutomaticTracking (uint8_t *pResp, uint16_t respLen, unpack_pds_GetServiceAutomaticTracking_t *pOutput)
- int pack_pds_SetServiceAutomaticTracking (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetServiceAutomaticTracking_t *pReqParam)
- int unpack_pds_SetServiceAutomaticTracking (uint8_t *pResp, uint16_t respLen)
- int pack_pds_ResetPDSData (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_ResetPDSData_t *pReqParam)
- int unpack_pds_ResetPDSData (uint8_t *pResp, uint16_t respLen)
- int pack_pds_SLQSSetAGPSConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SLQSSetAGPSConfig_t *pReqParam)
- int unpack_pds_SLQSSetAGPSConfig (uint8_t *pResp, uint16_t respLen)
- int pack_pds_SLQSPDSInjectAbsoluteTimeReference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SLQSPDSInjectAbsoluteTimeReference_t *pReqParam)
- int unpack_pds_SLQSPDSInjectAbsoluteTimeReference (uint8_t *pResp, uint16_t respLen)
- int pack_pds_SLQSGetAGPSConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SLQSGetAGPSConfig_t *pReqParam)
- int unpack_pds_SLQSGetAGPSConfig (uint8_t *pResp, uint16_t respLen, unpack_pds_SLQSGetAGPSConfig_t *pOutput)
- int pack_pds_SLQSPDSInjectPositionData (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SLQSPDSInjectPositionData_t *pReqParam)
- int unpack_pds_SLQSPDSInjectPositionData (uint8_t *pResp, uint16_t respLen)
- int pack_pds_SLQSPDSDeterminePosition (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_SLQSPDSDeterminePosition (uint8_t *pResp, uint16_t respLen)
- int pack_pds_SLQSGetGPSStateInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_SLQSGetGPSStateInfo (uint8_t *pResp, uint16_t respLen, unpack_pds_SLQSGetGPSStateInfo_t *pOutput)
- int pack_pds_SLQSSetPositionMethodState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SLQSSetPositionMethodState_t *pReqParam)
- int unpack_pds_SLQSSetPositionMethodState (uint8_t *pResp, uint16_t respLen)
- int pack_pds_SetEventReportCallback (pack_qmi_t *pCtx, uint8_t *pReq, uint16_t *pLen, pack_pds_SetEventReportCallback_t *pReqParam)
- int unpack_pds_SetEventReportCallback (uint8_t *pResp, uint16_t respLen)
- int unpack_pds_SetEventReport_Ind (uint8_t *pResp, uint16_t respLen, unpack_pds_SetEventReport_Ind_t *pOutput)
- int unpack_pds_SetPdsState_Ind (uint8_t *pResp, uint16_t respLen, unpack_pds_SetPdsState_Ind_t *pOutput)

9.12.1 Function Documentation

9.12.1.1 int pack_pds_ForceXTRADownload (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Forces the XTRA database to be downloaded to the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.2 int pack_pds_GetPDSDefaults (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Get the default tracking session configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.3 int pack_pds_GetPDSState (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Get current PDS state pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.4 int pack_pds_GetPortAutomaticTracking (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Returns the automatic tracking configuration for the NMEA COM port pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.5 int pack_pds_GetServiceAutomaticTracking (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen*)

automatic tracking state for the service pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.6 int pack_pds_GetXTRAAutomaticDownload (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen*)

XTRA automatic database download configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.7 int pack_pds_GetXTRANetwork (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen*)

XTRA WWAN network preference parameter pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.8 int pack_pds_GetXTRAValidity (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

XTRA database validity period parameter pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.9 int pack_pds_PDSInjectTimeReference (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_pds_PDSInjectTimeReference_t * pReqParam)

Inject system time parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.10 int pack_pds_ResetPDSData (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_pds_ResetPDSData_t * pReqParam)

Resets the specified PDS data pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.11 int pack_pds_SetEventReportCallback (pack_qmi_t * *pCtx*, uint8_t * *pReq*, uint16_t * *pLen*, pack_pds_SetEventReportCallback_t * *pReqParam*)

Enables/disables the PDS Event report callback function pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReq*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.12 int pack_pds_SetPDSDefaults (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetPDSDefaults_t * *pReqParam*)

Sets the default tracking session configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.13 int pack_pds_SetPDSState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetPDSState_t * *pReqParam*)

Sets the PDS state pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.14 int pack_pds_SetPortAutomaticTracking (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetPortAutomaticTracking_t * *pReqParam*)

Sets the automatic tracking configuration for the NMEA COM port pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.15 int pack_pds_SetServiceAutomaticTracking (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetServiceAutomaticTracking_t * *pReqParam*)

Sets the automatic tracking state for the service pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.16 int pack_pds_SetXTRAAutomaticDownload (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetXTRAAutomaticDownload_t * *pReqParam*)

Sets the XTRA automatic database download configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.17 int pack_pds_SetXTRANetwork (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetXTRANetwork_t * *pReqParam*)

Sets the XTRA WWAN network preference pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.18 int pack_pds_SLQSGetAGPSConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SLQSGetAGPSConfig_t * *pReqParam*)

Gets the PDS AGPS (MS-based) configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.19 int pack_pds_SLQSGetGPSStateInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Queries the MSM GPS server for receiver state information pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.20 int pack_pds_SLQSPDSDeterminePosition (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Requests the MSM GPS service to obtain the current position for manually controlled tracking sessions pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.21 int pack_pds_SLQSPDSInjectAbsoluteTimeReference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SLQSPDSInjectAbsoluteTimeReference_t * *pReqParam*)

Injects a absolute time reference into the PDS engine pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.22 int pack_pds_SLQSPDSInjectPositionData (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SLQSPDSInjectPositionData_t * *pReqParam*)

Injects position data into the PDS engine pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.23 int pack_pds_SLQSSetAGPSConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SLQSSetAGPSConfig_t * *pReqParam*)

Sets the PDS AGPS (MS-based) configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.24 int pack_pds_SLQSSetPositionMethodState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SLQSSetPositionMethodState_t * *pReqParam*)

Sets the state of positioning methods for the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.25 int pack_pds_StartPDSTrackingSessionExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_StartPDSTrackingSessionExt_t * *pReqParam*)

Starts a PDS tracking session pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.26 int pack_pds_StopPDSTrackingSession (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Stops a PDS tracking session pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.27 int unpack_pds_ForceXTRADownload (uint8_t * *pResp*, uint16_t *respLen*)

Forces the XTRA database to be downloaded to the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.28 int unpack_pds_GetPDSDefaults (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetPDSDefaults_t * *pOutput*)

Get the default tracking session configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.29 int unpack_pds_GetPDSState (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetPDSState_t * *pOutput*)

Get current PDS state unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.30 int unpack_pds_GetPortAutomaticTracking (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetPortAutomaticTracking_t * *pOutput*)

Returns the automatic tracking configuration for the NMEA COM port unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.31 int unpack_pds_GetServiceAutomaticTracking (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetServiceAutomaticTracking_t * *pOutput*)

automatic tracking state for the service unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.32 int unpack_pds_GetXTRAAutomaticDownload (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetXTRAAutomaticDownload_t * *pOutput*)

XTRA automatic database download configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.33 int unpack_pds_GetXTRANetwork (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetXTRANetwork_t * *pOutput*)

XTRA WWAN network preference parameter unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.34 int unpack_pds_GetXTRAValidity (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetXTRAValidity_t * *pOutput*)

XTRA database validity period parameter unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.35 int unpack_pds_PDSInjectTimeReference (uint8_t * *pResp*, uint16_t *respLen*)

Inject system time parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.36 int unpack_pds_ResetPDSData (uint8_t * *pResp*, uint16_t *respLen*)

Resets the specified PDS data unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.37 int unpack_pds_SetEventReport_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SetEventReport_Ind_t * *pOutput*)

PDS Event Report Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.38 int unpack_pds_SetEventReportCallback (uint8_t * *pResp*, uint16_t *respLen*)

Enables/disables the PDS Event report callback function unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.39 int unpack_pds_SetPDSDefaults (uint8_t * *pResp*, uint16_t *respLen*)

Sets the default tracking session configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.40 int unpack_pds_SetPDSState (uint8_t * *pResp*, uint16_t *respLen*)

Sets the PDS state unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.41 int unpack_pds_SetPdsState_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SetPdsState_Ind_t * *pOutput*)

PDS State Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.42 int unpack_pds_SetPortAutomaticTracking (uint8_t * *pResp*, uint16_t *respLen*)

Sets the automatic tracking configuration for the NMEA COM port unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.43 int unpack_pds_SetServiceAutomaticTracking (uint8_t * *pResp*, uint16_t *respLen*)

Sets the automatic tracking state for the service unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.44 int unpack_pds_SetXTRAAutomaticDownload (uint8_t * *pResp*, uint16_t *respLen*)

Sets the XTRA automatic database download configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.45 int unpack_pds_SetXTRANetwork (uint8_t * *pResp*, uint16_t *respLen*)

Sets the XTRA WWAN network preference unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.46 int unpack_pds_SLQSGetAGPSConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SLQSGetAGPSConfig_t * *pOutput*)

Gets the PDS AGPS (MS-based) configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.47 int unpack_pds_SLQSGetGPSStateInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SLQSGetGPSStateInfo_t * *pOutput*)

Queries the MSM GPS server for receiver state information unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.48 int unpack_pds_SLQSPDSDeterminePosition (uint8_t * *pResp*, uint16_t *respLen*)

Requests the MSM GPS service to obtain the current position for manually controlled tracking sessions unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.49 int unpack_pds_SLQSPDSInjectAbsoluteTimeReference (uint8_t * *pResp*, uint16_t *respLen*)

Injects a absolute time reference into the PDS engine unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.50 int unpack_pds_SLQSPDSInjectPositionData (uint8_t * *pResp*, uint16_t *respLen*)

Injects position data into the PDS engine unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.51 int unpack_pds_SLQSSetAGPSConfig (uint8_t * *pResp*, uint16_t *respLen*)

Sets the PDS AGPS (MS-based) configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.52 int unpack_pds_SLQSSetPositionMethodState (uint8_t * *pResp*, uint16_t *respLen*)

Sets the state of positioning methods for the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.53 int unpack_pds_StartPDSTrackingSessionExt (uint8_t * *pResp*, uint16_t *respLen*)

Starts a PDS tracking session unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.1.54 int unpack_pds_StopPDSTrackingSession (uint8_t * *pResp*, uint16_t *respLen*)

Stops a PDS tracking session unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.13 qaGobiApiTableBandClasses.h File Reference

Network Access Service API Band Classes table.

9.13.1 Detailed Description

Network Access Service API Band Classes table.

9.13.2 Band Classes (Value - Description)

- 0 - CDMA Band Class 0
- 1 - CDMA Band Class 1
- 3 - CDMA Band Class 3
- 4 - CDMA Band Class 4
- 5 - CDMA Band Class 5
- 6 - CDMA Band Class 6
- 7 - CDMA Band Class 7
- 8 - CDMA Band Class 8
- 9 - CDMA Band Class 9
- 10 - CDMA Band Class 10
- 11 - CDMA Band Class 11
- 12 - CDMA Band Class 12
- 13 - CDMA Band Class 13
- 14 - CDMA Band Class 14
- 15 - CDMA Band Class 15
- 16 - CDMA Band Class 16
- 17 - CDMA Band Class 17
- 18 - CDMA Band Class 18
- 19 - CDMA Band Class 19
- 40 - GSM 450
- 41 - GSM 480
- 42 - GSM 750
- 43 - GSM 850

- 44 - GSM 900 (Extended)
- 45 - GSM 900 (Primary)
- 46 - GSM 900 (Railways)
- 47 - GSM 1800
- 48 - GSM 1900
- 80 - WCDMA 2100
- 81 - WCDMA PCS 1900
- 82 - WCDMA DCS 1800
- 83 - WCDMA 1700 (US)
- 84 - WCDMA 850
- 85 - WCDMA 800
- 86 - WCDMA 2600
- 87 - WCDMA 900
- 88 - WCDMA 1700 (Japan)
- 90 - WCDMA 1500 band (Japan)
- 91 - WCDMA 850 band (Japan)
- < Reserved 89, 92-109 for WCDMA band classes>
- 110 - WLAN US 2400 MHz
- 111 - WLAN JAPAN 2400 MHz
- 112 - WLAN EUROPEAN 2400 MHz
- 113 - WLAN FRANCE 2400 MHz
- 114 - WLAN SPAIN 2400 MHz
- 115 - WLAN US 5000 MHz band
- 116 - WLAN JAPAN 5000 MHz
- 117 - WLAN EUROPEAN 5000 MHz
- 118 - WLAN FRANCE 5000 MHz
- 119 - WLAN SPAIN 5000 MHz

9.13.2.1 LTE Bands

- 28 - LTE Band Class 28
- 39 - LTE Band Class 39
- 40 - LTE Band Class 40
- 41 - LTE Band Class 41
- 120 - FDD UL:1920-1980; DL:2110-2170; E-UTRA Operating Band 1
- 121 - FDD UL:1850-1910; DL:1930-1990; E-UTRA Operating Band 2
- 122 - FDD UL:1710-1785; DL:1805-1880; E-UTRA Operating Band 3

- 123 - FDD UL:1710-1755; DL:2110-2155; E-UTRA Operating Band 4
- 124 - FDD UL: 824- 849; DL: 869- 894; E-UTRA Operating Band 5
- 125 - FDD UL: 830- 840; DL: 875- 885; E-UTRA Operating Band 6
- 126 - FDD UL:2500-2570; DL:2620-2690; E-UTRA Operating Band 7
- 127 - FDD UL: 880- 915; DL: 925- 960; E-UTRA Operating Band 8
- 128 - FDD UL:1749.9-1784.9; DL:1844.9-1879.9; E-UTRA Operating Band 9
- 129 - FDD UL:1710-1770; DL:2110-2170; E-UTRA Operating Band 10
- 130 - FDD UL:1427.9-1452.9; DL:1475.9-1500.9; E-UTRA Operating Band 11
- 131 - FDD UL:698-716; DL:728-746; E-UTRA Operating Band 12
- 132 - FDD UL: 777- 787; DL: 746-756; E-UTRA Operating Band 13
- 133 - FDD UL: 788- 798; DL: 758-768; E-UTRA Operating Band 14
- 134 - FDD UL: 704-716; DL: 734-746; E-UTRA Operating Band 17
- 135 - TDD LTE UL: 1900-1920; DL: 1900-1920; E-UTRA Operating Band 33
- 136 - TDD LTE UL: 2010-2025; DL: 2010-2025; E-UTRA Operating Band 34
- 137 - TDD LTE UL: 1850-1910; DL: 1850-1910; E-UTRA Operating Band 35
- 138 - TDD LTE UL: 1930-1990; DL: 1930-1990; E-UTRA Operating Band 36
- 139 - TDD LTE UL: 1910-1930; DL: 1910-1930; E-UTRA Operating Band 37
- 140 - TDD LTE UL: 2570-2620; DL: 2570-2620; E-UTRA Operating Band 38
- 141 - TDD LTE UL: 1880-1920; DL: 1880-1920; E-UTRA Operating Band 39
- 142 - TDD LTE UL: 2300-2400; DL: 2300-2400; E-UTRA Operating Band 40
- 143 - FDD LTE UL: 815-830; DL: 860-875; E-UTRA Operating Band 18
- 144 - FDD LTE UL: 830-845; DL: 875-890; E-UTRA Operating Band 19
- 145 - FDD LTE UL: 832-862; DL: 791-821; E-UTRA Operating Band 20
- 146 - FDD LTE UL: 1447.9-1462.9; DL: 1495.9-1510.9; E-UTRA Operating Band 21
- 147 - FDD LTE UL: 1626.5-1660.5; DL: 1525-1559; E-UTRA Operating Band 24
- 148 - FDD LTE UL: 1850-19195; DL: 1930-1995; E-UTRA Operating Band 25
- 149 - TDD LTE UL: 2496-2690; DL: 2496-2690; E-UTRA Operating Band 41
- 150 - TDD LTE UL: 3400-3600; DL: 3400-3600; E-UTRA Operating Band 42
- 151 - TDD LTE UL: 3600-3800; DL: 3600-3800; E-UTRA Operating Band 43
- 200 - TD-SCDMA Band A
- 201 - TD-SCDMA Band B
- 202 - TD-SCDMA Band C
- 203 - TD-SCDMA Band D
- 204 - TD-SCDMA Band E
- 205 - TD-SCDMA Band F

Copyright: © 2011 Sierra Wireless, Inc. all rights reserved

9.14 qaGobiApiTableCallControlReturnReasons.h File Reference

Call Control Return Reasons table.

9.14.1 Detailed Description

Call Control Return Reasons table.

9.14.2 S1

- 0x01 - QMI_VOICE_REASON_FWD_UNCONDITIONAL - Unconditional call forwarding
- 0x02 - QMI_VOICE_REASON_FWD_MOBILEBUSY - Forward when the mobile is busy
- 0x03 - QMI_VOICE_REASON_FWD_NOREPLY - Forward when there is no reply
- 0x04 - QMI_VOICE_REASON_FWD_UNREACHABLE - Forward when the call is unreachable
- 0x05 - QMI_VOICE_REASON_FWD_ALLFORWARDING - All forwarding
- 0x06 - QMI_VOICE_REASON_FWD_ALLCONDITIONAL - All conditional forwarding
- 0x07 - QMI_VOICE_REASON_BARR_ALLOUTGOING - All outgoing
- 0x08 - QMI_VOICE_REASON_BARR_OUTGOINGINT - Outgoing internal
- 0x09 - QMI_VOICE_REASON_BARR_OUTGOINGINTEXTOHOME - Outgoing external to home
- 0x0A - QMI_VOICE_REASON_BARR_ALLINCOMING - All incoming
- 0x0B - QMI_VOICE_REASON_BARR_INCOMINGROAMING - Roaming incoming
- 0x0C - QMI_VOICE_REASON_BARR_ALLBARRING - All calls are barred
- 0x0D - QMI_VOICE_REASON_BARR_ALLOUTGOINGBARRING - All outgoing calls are barred
- 0x0E - QMI_VOICE_REASON_BARR_ALLINCOMINGBARRING - All incoming calls are barred
- 0x0F - QMI_VOICE_REASON_CALLWAITING - Call waiting
- 0x10 - VOICE_CC_SUPS_RESULT_REASON_CLIP - CLIP
- 0x11 - VOICE_CC_SUPS_RESULT_REASON_CLIR - CLIR
- 0x12 - VOICE_CC_SUPS_RESULT_REASON_COLP - COLP
- 0x13 - VOICE_CC_SUPS_RESULT_REASON_COLR - COLR
- 0x14 - VOICE_CC_SUPS_RESULT_REASON_CNAP - CNAP
- 0xFF - Not Available

Copyright: © 2012 Sierra Wireless, Inc. all rights reserved

9.15 qaGobiApiTableCallEndReasons.h File Reference

Wireless Data Service Call End Reasons.

9.15.1 Detailed Description

Wireless Data Service Call End Reasons.

9.15.2 Call end reason codes (Code - Reason)

9.15.2.1 Technology-agnostic call end reasons

- 1 - Reason unspecified, check the verbose call end reason
- 2 - Client ended the call
- 3 - Device has no service
- 4 - Call ended abnormally
- 5 - Received release from base station; no reason given
- 6 - Access attempt already in progress; SD2.0 only
- 7 - Access failure for reason other than the above
- 8 - Call rejected because of redirection or handoff
- 9 - Call failed because close is in progress
- 10 - Authentication failed, 3GPP equivalent ESM(EPS Session Management) cause code value 29, User authentication failed
- 11 - Call ended because of internal call end. This error code is returned when data call is brought down due to some unknown error, such as not specific to any RAT
- 12 - Call ended because of internal error. This error code is returned when data call is brought down due to some unspecified internal error, such as NULL pointer
- 13 - Internal unknown cause code

9.15.2.2 EVDO CDMA 1xEV-DO

- 500 - Device is CDMA-locked until power cycle
- 501 - Received intercept from base station; origination only
- 502 - Received reorder from base station; origination only
- 503 - Received release from base station; service option reject
- 504 - Received incoming call from base station
- 505 - Received alert stop from base station; incoming only
- 506 - Received end activation; OTASP call only
- 507 - Max access probes transmitted
- 508 - Concurrent service is not supported by base station
- 509 - No response received from base station
- 510 - Call rejected by the base station; CDMA only
- 511 - Concurrent services requested were not compatible; CDMA only
- 512 - Corresponds to CM CALL ORIG ERR ALREADY IN TC
- 513 - Used if Call manager subsystem is ending a GPS call in favor of a user call
- 514 - Used if Call manager subsystem is ending a SMS call in favor of a user call
- 515 - CDMA Only; Device has no service

9.15.2.3 WCDMA/GSM call end reasons

- 1000 - Call origination request failed; WCDMA/GSM Only
- 1001 - Client rejected the incoming call; WCDMA/GSM Only
- 1002 - Device has no UMTS service; WCDMA/GSM Only
- 1003 - Network ended the call, look in cc call; WCDMA/GSM Only
- 1004 - LLC(Logical Link Control) or SNDCP(Sub Network Dependent Convergence Protocol) failure
- 1005 - Insufficient resources, 3GPP equivalent ESM(EPS Session Management) cause code value 26, Insufficient resources
- 1006 - Service option temporarily out of order, 3GPP equivalent ESM(EPS Session Management) cause code value 34, Service option temporarily out of order
- 1007 - PTI already used, 3GPP equivalent ESM(EPS Session Management) cause code value 35, PTI(-Procedure Transaction Identity) already in use
- 1008 - Regular PDP context deactivation, 3GPP equivalent ESM(EPS Session Management) cause code value 36, Regular deactivation
- 1009 - Network failure, 3GPP equivalent ESM(EPS Session Management) cause code value 38, Network failure
- 1010 - Reactivation requested, 3GPP equivalent ESM(EPS Session Management) cause code value 39, Reactivation requested
- 1011 - Protocol error, unspecified, 3GPP equivalent ESM(EPS Session Management) cause code value 111, Protocol error, unspecified
- 1012 - Operator determined barring, 3GPP equivalent ESM(EPS Session Management) cause code value 8, Operator Determined Barring
- 1013 - Unknown or missing Access Point Name (APN), 3GPP equivalent ESM(EPS Session Management) cause code value 27, Missing or unknown APN
- 1014 - Unknown PDP address or PDP type, 3GPP equivalent ESM(EPS Session Management) cause code value 28, Unknown PDN type
- 1015 - Activation rejected by GGSN, 3GPP equivalent ESM(EPS Session Management) cause code value 30, Requested rejected by Serving GW or PDN GW
- 1016 - Activation rejected, unspecified, 3GPP equivalent ESM(EPS Session Management) cause code value 31, Request rejected, unspecified
- 1017 - Service option not supported, 3GPP equivalent ESM(EPS Session Management) cause code value 32, Service option not supported
- 1018 - Requested service option not subscribed, 3GPP equivalent ESM(EPS Session Management) cause code value 33, Requested service option not subscribed
- 1019 - EPS Quality of Service (QoS) not accepted, 3GPP equivalent ESM(EPS Session Management) cause code value 37, EPS QoS not accepted
- 1020 - Semantic error in the TFT operation, 3GPP equivalent ESM(EPS Session Management) cause code value 41, Semantic error in the TFT operation
- 1021 - Syntactical error in the TFT operation, 3GPP equivalent ESM(EPS Session Management) cause code value 42, Syntactical error in the TFT operation
- 1022 - Unknown PDP context, 3GPP equivalent ESM(EPS Session Management) cause code value 43, Invalid EPS bearer identity

- 1023 - Semantic errors in packet filter(s), 3GPP equivalent ESM(EPS Session Management) cause code value 44, Semantic errors in packet filter(s)
- 1024 - Syntactical error in packet filter(s), 3GPP equivalent ESM(EPS Session Management) cause code value 45, Syntactical errors in packet filter(s)
- 1025 - PDP context without TFT already activated, 3GPP equivalent ESM(EPS Session Management) cause code value 46, Unused
- 1026 - Invalid transaction identifier value, 3GPP equivalent ESM(EPS Session Management) cause code value 81, Invalid PTI value
- 1027 - Semantically incorrect message, 3GPP equivalent ESM(EPS Session Management) cause code value 95, Semantically incorrect message
- 1028 - Invalid mandatory information, 3GPP equivalent ESM(EPS Session Management) cause code value 96, Invalid mandatory information
- 1029 - Message type non-existent or not implemented, 3GPP equivalent ESM(EPS Session Management) cause code value 97, Message type non-existent or not implemented
- 1030 - Message not compatible with state, 3GPP equivalent ESM(EPS Session Management) cause code value 98, Message type not compatible with the protocol state
- 1031 - Information element nonexistent or not implemented, 3GPP equivalent ESM(EPS Session Management) cause code value 99, Information element non-existent or not implemented
- 1032 - Conditional information element error, 3GPP equivalent ESM(EPS Session Management) cause code value 100, Conditional IE error
- 1033 - Message not compatible with protocol state, 3GPP equivalent ESM(EPS Session Management) cause code value 101, Message not compatible with the protocol state
- 1034 - APN restriction value incompatible with active PDP context, 3GPP equivalent ESM(EPS Session Management) cause code value 112, APN restriction value incompatible with
  - active EPS bearer context
- 1035 - No GPRS context present
- 1036 - Requested feature not supported, 3GPP equivalent ESM(EPS Session Management) cause code value 40, Feature not supported
- 1037 - Illegal MS, 3GPP equivalent EMM(EPS Mobility Management) cause code value 3, Illegal UE (MS)
- 1038 - Illegal ME, 3GPP equivalent EMM(EPS Mobility Management) cause code value 6, Illegal ME. This error code is sent to the MS if the ME used is not acceptable
  - to the network, e.g. blacklisted
- 1039 - GPRS and non GPRS services not allowed
- 1040 - GPRS services not allowed
- 1041 - MS identity not derived by the network, 3GPP equivalent EMM(EPS Mobility Management) cause code value 9, UE (MS) Identify cannot be derived by the network
- 1042 - Implicitly detached, 3GPP equivalent EMM(EPS Mobility Management) cause code value 10, Implicitly Detached
- 1043 - PLMN not allowed, 3GPP equivalent EMM(EPS Mobility Management) cause code value 11, PLMN not allowed
- 1044 - LA not allowed, this cause is sent to the MS if it requests location updating in a location area where the HPLMN determines that the MS, by subscription, is not allowed to operate.
- 1045 - GPRS services not allowed in PLMN

- 1046 - PDP duplicate
- 1047 - UE radio access technology change
- 1048 - app preempted
- 1049 - Congestion, This cause is sent if the service request or LOCATION UPDATING REQUEST message cannot be actioned because of congestion (e.g. congestion of the MSC or SGSN or GGSN or PDN Gateway; no channel; facility busy/congested etc.).
- 1050 - No PDP context activated
- 1051 - Access class DSAC rejection

9.15.2.4 EVDO CDMA 1xEV-DO

- 1500 - Abort connection setup due to the reception of a Connection Deny message with deny code set to either general or network busy.
- 1501 - Abort connection setup due to the reception of a Connection Deny message with deny code set to either billing or authentication failure.
- 1502 - Change HDR system due to redirection or PRL not preferred
- 1503 - Exit HDR due to redirection or PRL not preferred
- 1504 - No HDR session
- 1505 - Used if Call manager is ending an HDR call origination in favor of a GPS fix
- 1506 - Connection setup timeout
- 1507 - Call manager released HDR call so 1x call can continue

9.15.2.5 call end reason type

- 1 - Mobile IP
- 2 - Internal
- 3 - Call Manager defined
- 6 - 3GPP specification defined
- 7 - PPP
- 8 - EHRPD
- 9 - IPv6

9.15.2.6 Mobile IP call end reasons (Type=1)

- 64 - MIP(Mobile IP) FA(Foreign Agent) ERR REASON UNSPECIFIED, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration with unspecified reason
- 65 - MIP(Mobile IP) FA(Foreign Agent) ERR ADMINISTRATIVELY PROHIBITED, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent administratively prohibited MIP registration
- 66 - MIP(Mobile IP) FA(Foreign Agent) ERR INSUFFICIENT RESOURCES, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to insufficient resources

- 67 - MIP(Mobile IP) FA(Foreign Agent) ERR MOBILE NODE AUTHENTICATION FAILURE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because MN-AAA authenticator was wrong
- 68 - MIP(Mobile IP) FA(Foreign Agent) ERR HA AUTHENTICATION FAILURE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because of home agent authentication failure
- 69 - MIP(Mobile IP) FA(Foreign Agent) ERR REQUESTED LIFETIME TOO LONG, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because requested lifetime is too long
- 70 - MIP(Mobile IP) FA(Foreign Agent) ERR MALFORMED REQUEST, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to malformed request
- 71 - MIP(Mobile IP) FA(Foreign Agent) ERR MALFORMED REPLY, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to malformed reply
- 72 - MIP(Mobile IP) FA(Foreign Agent) ERR ENCAPSULATION UNAVAILABLE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because requested encapsulation is unavailable
- 73 - MIP(Mobile IP) FA(Foreign Agent) ERR VJHC UNAVAILABLE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because VJ Header Compression is unavailable
- 74 - MIP(Mobile IP) FA(Foreign Agent) ERR REVERSE TUNNEL UNAVAILABLE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because reverse tunnel is unavailable
- 75 - MIP(Mobile IP) FA(Foreign Agent) ERR REVERSE TUNNEL IS MANDATORY AND T BIT NOT SET, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because reverse tunnel is mandatory but not requested by device
- 79 - MIP(Mobile IP) FA(Foreign Agent) ERR DELIVERY STYLE NOT SUPPORTED, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because delivery style is not supported
- 97 - MIP(Mobile IP) FA(Foreign Agent) ERR MISSING NAI, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to missing NAI
- 98 - MIP(Mobile IP) FA(Foreign Agent) ERR MISSING HA, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to missing Home Agent
- 99 - MIP(Mobile IP) FA(Foreign Agent) ERR MISSING HOME ADDR, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to missing Home Address
- 104 - MIP(Mobile IP) FA(Foreign Agent) ERR UNKNOWN CHALLENGE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to unknown challenge
- 105 - MIP(Mobile IP) FA(Foreign Agent) ERR MISSING CHALLENGE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to missing challenge
- 106 - MIP(Mobile IP) FA(Foreign Agent) ERR STALE CHALLENGE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to stale challenge
- 128 - MIP(Mobile IP) FA(Home Agent) ERR REASON UNSPECIFIED, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration with unspecified reason

- 129 - MIP(Mobile IP) FA(Home Agent) ERR ADMINISTRATIVELY PROHIBITED, this error code is returned when the data call bring up fails in MIP setup phase since home agent administratively prohibited MIP registration
- 130 - MIP(Mobile IP) FA(Home Agent) ERR INSUFFICIENT RESOURCES, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to insufficient resources
- 131 - MIP(Mobile IP) FA(Home Agent) ERR MOBILE NODE AUTHENTICATION FAILURE, this error code is returned when the data call bring up fails in MIP setup phase since home agent fails authentication because MN-HA authenticator was wrong
- 132 - MIP(Mobile IP) FA(Home Agent) ERR FA AUTHENTICATION FAILURE, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to FA authentication failure
- 133 - MIP(Mobile IP) FA(Home Agent) ERR REGISTRATION ID MISMATCH, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to registration id mismatch
- 134 - MIP(Mobile IP) FA(Home Agent) ERR MALFORMED REQUEST, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to malformed request
- 136 - MIP(Mobile IP) FA(Home Agent) ERR UNKNOWN HA ADDR, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to unknown Home Agent address. This code is returned by a home agent when the mobile node is performing dynamic home agent address resolution as described in RFC 3220 (IP Mobility Support for IPV4) Sections 3.6.1.1 and 3.6.1.2
- 137 - MIP(Mobile IP) FA(Home Agent) ERR REVERSE TUNNEL UNAVAILABLE, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration because reverse tunnel is unavailable
- 138 - MIP(Mobile IP) FA(Home Agent) ERR REVERSE TUNNEL IS MANDATORY AND T BIT NOT SET, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration because reverse tunnel is mandatory but not requested by device
- 139 - MIP(Mobile IP) FA(Home Agent) ERR ENCAPSULATION UNAVAILABLE, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to encapsulation unavailable
- 65536 - MIP ERR REASON UNKNOWN

9.15.2.7 Internal call end reasons (Type=2)

- 200 - INTERNAL MIN, internal error table offset value, no meaningful message to the error.
- 201 - INTERNAL ERROR, this error code is returned when data call is brought down due to some unspecified internal error
- 202 - CALL ENDED
- 203 - INTERNAL UNKNOWN CAUSE CODE, this error code is returned when data call is brought down due to some unknown error
- 204 - UNKNOWN CAUSE CODE, this error code is returned when data call is brought down due to some unknown error
- 205 - CLOSE IN PROGRESS
- 206 - NETWORK INITIATED TERMINATION
- 207 - APP PREEMPTED

- 208 - ERR PDN IPV4 CALL DISALLOWED, this error code is returned when V4 PDN is in throttled state due to network providing only V6 address during the previous VSNCP bring up (subs_limited_to_v6). The time for which the IPv4 PDN is throttled is determined by the IPv4 throttling timers maintained in the profile
- 209 - ERR PDN IPV4 CALL THROTTLED, this error code is returned when V4 PDN is in throttled state due to previous VSNCP bring up failure(s). The time for which the IPv4 PDN is throttled is determined by the IPv4 throttling timers maintained in the profile
- 210 - ERR PDN IPV6 CALL DISALLOWED, this error code is returned when V6 PDN is in throttled state due to network providing only V4 address during the previous VSNCP bring up (subs_limited_to_v4). The time for which the IPv6 PDN is throttled is determined by the IPv6 throttling timers maintained in the profile
- 211 - ERR PDN IPV6 CALL THROTTLED, this error code is returned when V6 PDN is in throttled state due to previous VSNCP bring up failure(s). The time for which the IPv6 PDN is throttled is determined by the IPv6 throttling timers maintained in the profile
- 212 - MODEM RESTART
- 213 - PDP PPP NOT SUPPORTED
- 214 - UNPREFERRED RAT, this error code is returned when data call is brought down since the RAT on which the data call is attempted/connected is no longer the preferred RAT
- 215 - PHYS LINK CLOSE IN PROGRESS, this error code is returned when data call bring up is rejected because physical link is in the process of cleanup
- 216 - APN PENDING HANDOVER, this error code is returned when interface bring up is attempted for an APN that is yet to be handed over to target RAT
- 217 - PROFILE BEARER INCOMPATIBLE
- 218 - MMGSDI CARD EVT, this error code is returned when data call is brought down because card got refreshed/removed
- 219 - LPM OR PWR DOWN, this error code is returned when data call is brought down because device is going into lower power mode or powering down
- 220 - APN DISABLED, this error code is returned when APN is disabled in card
- 221 - MPIT EXPIRED, this error code is returned when data call is brought down because maximum PPP inactivity timer expired
- 222 - IPV6 ADDR TRANSFER FAILED
- 223 - TRAT SWAP FAILED
- 224 - EHRPD TO HRPD FALLBACK, this error code is returned when data call is brought down because device falls back from eHRPD to HRPD (not because of OOS on eHRPD but due to operator/spec driven eHRPD to HRPD fallback requirements)
- 225 - MANDATORY APN DISABLED, this error code is returned when any mandatory APN is disabled, and MinApnList Disallow call config item is set to TRUE in device
- 226 - MIP CONFIG FAILURE, this error code is returned when UE is in MIP Only config (QCMIP=2) but MIP config fails on call bring up due to incorrect provisioning
- 227 - INTERNAL_PDN_INACTIVITY_TIMER_EXPIRED, this error code is returned when PDN inactivity timer expired due to no data transmission in a configurable duration of time
- 228 - MAX_V4_CONNECTIONS, this error code is returned when IPv4 data call bring up is rejected because the UE already maintains the allotted maximum number of IPv4 data connections
- 229 - MAX_V6_CONNECTIONS, this error code is returned when IPv6 data call bring up is rejected because the UE already maintains the allotted maximum number of IPv6 data connections

- 230 - APN_MISMATCH, this error code is returned when New PDN bring up is rejected during interface selection because the UE has already allotted the available interfaces for other PDNs
- 231 - IP_VERSION_MISMATCH, this error code is returned when New call bring up is rejected because the existing data call IP type does not match the requested IP type
- 232 - DUN_CALL_DISALLOWED, this error code is returned when DUN call bring up is rejected because the UE is in eHRPD RAT
- 233 - INVALID_PROFILE, this error code is returned when Call bring up was requested with an invalid profile
- 234 - INTERNAL_EPC_NONEPC_TRANSITION, this error code is returned when Data call is rejected or brought down because the UE is in transition between EPC and non-EPC RAT
- 235 - INVALID_PROFILE_ID, this error code is returned when Call bring up was requested with an invalid profile ID
- 236 - INTERNAL_CALL_ALREADY_PRESENT, this error code is returned when a data call with the same policy is already connected or in the process of bring up on another RmNet instance
- 237 - IFACE_IN_USE, this error code is returned when the current IFACE is in use
- 238 - IP_PDP_MISMATCH, this error code is returned when a PPP call is attempted on a PDP profile
- 239 - APN_DISALLOWED_ON_ROAMING, this error code is returned when PDN connection to the APN is disallowed on the roaming network. The DS generates DS_SYS_EVENT_3GPP_ROAMING_DISALLOWED_INFO to inform clients of the APNs that must deregister and disconnect (if the PDN is up) while the UE is on the roaming network. Clients must deregister or disconnect if the APN name corresponding to the client is listed in this system event. Clients can register again if the APN name corresponding to the client is not listed in this system event.
- 240 - APN_PARAM_CHANGE, this error code is returned when Failure to reestablish the PDN with the changed parameters; when APN-related parameters are changed, the PDN associated with the parameters must be brought down and reestablished with the changed parameters
- 241 - IFACE_IN_USE_CFG_MATCH, this error code is returned when the IFACE is already in use with a matching configuration
- 242 - NULL_APN_DISALLOWED, this error code is returned when a PDN is attempted to be brought up with a NULL APN and when a NULL APN is not supported
- 243 - THERMAL_MITIGATION, this error code is returned when the thermal level increases and causes calls to be torn down when normal mode of operation is not allowed
- 244 - SUBS_ID_MISMATCH, this error code is returned when a new call bring up is rejected due to a mismatch between the subs_id in the profile and the subs_id in the ACL policy information
- 245 - DATA_SETTINGS_DISABLED, this error code is returned when the PDN connection to a given APN is disallowed because data is disabled from the device user interface (UI) settings
- 246 - DATA_ROAMING_SETTINGS_DISABLED, this error code is returned when the PDN Connection to a given APN is disallowed because data roaming is disabled from the device UI settings and the UE is roaming
- 247 - APN_FORMAT_INVALID, this error code is returned when the APN specified in the policy does not follow the format specified in the 3GPP Specification
- 248 - DDS_CALL_ABORT, this error code is returned when a DDS switch occurs; the data call is brought down with the DDS abort reason
- 249 - VALIDATION_FAILURE, this error code is returned when a data call is brought down due to an internal validation failure

9.15.2.8 Call Manager defined call end reasons (Type=3)

- 500 - CDMA LOCK, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to device in CDMA locked state
- 501 - INTERCEPT, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since it received an intercept order from the base station
- 502 - REORDER, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) due to receiving a reorder from base station
- 503 - REL SO REJ, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to receiving a release from base station with reason: SO Reject
- 504 - INCOM CALL, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since it received an incoming call from base station
- 505 - ALERT STOP, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to RL/FL fade (or) receiving call release from base stations
- 506 - ACTIVATION, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to channel acquisition failures. This indicates that device has failed acquiring all the channels in the PRL
- 507 - MAX ACCESS PROBE, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) due maximum access probes transmitted
- 508 - CCS NOT SUPPORTED BY BS, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since concurrent service is not supported by base station
- 509 - NO RESPONSE FROM BS, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since there is no response received from base station
- 510 - REJECTED BY BS, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) due to base station rejecting the call
- 511 - INCOMPATIBLE, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since concurrent services requested were not compatible
- 512 - ALREADY IN TC, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since traffic channel is already up for voice calls
- 513 - USER CAL ORIG DURING GPS
- 514 - USER CAL ORIG DURING SMS, this error code is returned when data call is brought down because traffic channel request got rejected since SMS is ongoing
- 515 - NO CDMA SRV, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device does not have CDMA service
- 516 - MC ABORT, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since MC aborted the origination/conversation
- 517 - PSIST NG, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to persistence test failure
- 518 - UIM NOT PRESENT, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to RUIM not present
- 519 - RETRY ORDER, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) due to receiving a retry order from base station
- 520 - ACCESS BLOCK, this error code is returned when data call is brought down because traffic channel rejected/released due to Access blocked by base station

- 521 - ACCESS BLOCK ALL, this error code is returned when data call is brought down because traffic channel rejected due to Access blocked by the base station for all mobile devices
- 522 - IS707B MAX ACC, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) due maximum access probes for IS-707B call
- 523 - THERMAL EMERGENCY, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) to put device in thermal emergency
- 524 - CALL ORIG THROTTLED, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since call origination is throttled by DCTM module
- 535 - USER CALL ORIGINATE DURING VOICE CALL, this error code is returned when data call is brought down because traffic channel got released by CM(Call Manager) in favor of voice call or SMS when concurrent voice and data are not supported
- 1000 - CONFERENCE FAILED
- 1001 - INCOMING REJECTED
- 1002 - NO GATEWAY SERVICE
- 1003 - NO GPRS CONTEXT
- 1004 - ILLEGAL MS, This cause is sent to the MS when the network refuses service to the MS either because an identity of the MS is not acceptable to the network or because the MS does not pass the authentication check, i.e. the SRES received from the MS is different from that generated by the network
- 1005 - ILLEGAL ME, This cause is sent to the MS if the ME used is not acceptable to the network, e.g. blacklisted
- 1006 - GPRS SERVICES AND NON GPRS SERVICES NOT ALLOWED
- 1007 - GPRS SERVICES NOT ALLOWED
- 1008 - MS IDENTITY CANNOT BE DERIVED BY THE NETWORK
- 1009 - IMPLICITLY DETACHED, this error code is sent to the MS either if the network has implicitly detached the MS, e.g. some while after the Mobile reachable timer has expired, or if the GMM context data related to the subscription does not exist in the SGSN e.g. because of a SGSN restart.
- 1010 - PLMN NOT ALLOWED, this error code is sent to the MS if it requests location updating in a PLMN where the MS, by subscription or due to operator determined barring is not allowed to operate
- 1011 - LOCAL AREA NOT ALLOWED
- 1012 - GPRS SERVICES NOT ALLOWED IN THIS PLMN
- 1013 - PDP DUPLICATE
- 1014 - USER EQUIPMENT RADIO ACCESS TECHNOLOGY CHANGE
- 1015 - CONGESTION
- 1016 - NO PDP CONEXT ACTIVATED
- 1017 - ACCESS CLASS DSAC REJECTION
- 1018 - PDP ACTIVATE MAX RETRY FAILED
- 1019 - RAB FAILURE
- 1020 - EPS SERVICE NOT ALLOWED
- 1021 - TRACKING AREA NOT ALLOWED
- 1022 - ROAMING NOT ALLOWED IN THIS TRACKING AREA

- 1023 - NO SUITABLE CELLS IN TRACKING AREA
- 1024 - NOT AUTHORIZED FOR THIS CLOSED SUBSCRIBER GROUP
- 1025 - ESM UNKNOWN EPS BEARER CONTEXT
- 1026 - DRB RELEASED AT RRC
- 1027 - NAS SIG CONN RELEASED
- 1028 - EPS MOBILITY MANAGEMENT DETACHED
- 1029 - EPS MOBILITY MANAGEMENT ATTACH FAILED
- 1030 - EPS MOBILITY MANAGEMENT ATTACH STARTED
- 1031 - LTE NAS SERVICE REQ FAILED
- 1032 - ESM(EPS Session Management) ACTIVE DEDICATED BEARER REACTIVATED BY NW
- 1033 - ESM(EPS Session Management) LOWER LAYER FAILURE
- 1034 - ESM(EPS Session Management) SYNC UP WITH NW
- 1035 - ESM(EPS Session Management) NW ACTIVATED DED BEARER WITH ID OF DEF BEARER
- 1036 - ESM(EPS Session Management) BAD OTA MESSAGE
- 1037 - ESM DS REJECTED THE CALL
- 1038 - ESM(EPS Session Management) CONTEXT TRANSFERRED DUE TO IRAT
- 1039 - DS EXPLICIT DEACT
- 1040 - ESM(EPS Session Management) LOCAL CAUSE NONE
- 1041 - LTE NAS SERVICE REQ FAILED NO THROTTLE
- 1042 - ACL FAILURE, This error code should rarely triggered and reported to the application
- 1043 - LTE NAS SERVICE REQ FAILED DS DISALLOW
- 1044 - EMM(EPS Mobility Management) T3417 EXPIRED
- 1045 - EMM(EPS Mobility Management) T3417 EXT EXPIRED
- 1046 - LRRC(LTE Radio Resource Control) UL DATA CNF FAILURE TXN - Light Radio Resource Controller Uplink data confirmation failure
- 1047 - LRRC(LTE Radio Resource Control) UL DATA CNF FAILURE HO
- 1048 - LRRC(LTE Radio Resource Control) UL DATA CNF FAILURE CONN REL
- 1049 - LRRC(LTE Radio Resource Control) UL DATA CNF FAILURE RLF
- 1050 - LRRC(LTE Radio Resource Control) UL DATA CNF FAILURE CTRL NOT CONN
- 1051 - LRRC(LTE Radio Resource Control) CONN EST FAILURE
- 1052 - LRRC(LTE Radio Resource Control) CONN EST FAILURE ABORTED
- 1053 - LRRC(LTE Radio Resource Control) CONN EST FAILURE ACCESS BARRED
- 1054 - LRRC(LTE Radio Resource Control) CONN EST FAILURE CELL RESEL
- 1055 - LRRC(LTE Radio Resource Control) CONN EST FAILURE CONFIG FAILURE
- 1056 - LRRC(LTE Radio Resource Control) CONN EST FAILURE TIMER EXPIRED
- 1057 - LRRC(LTE Radio Resource Control) CONN EST FAILURE LINK FAILURE

- 1058 - LRRC(LTE Radio Resource Control) CONN EST FAILURE NOT CAMPED
- 1059 - LRRC(LTE Radio Resource Control) CONN EST FAILURE SI FAILURE
- 1060 - LRRC(LTE Radio Resource Control) CONN EST FAILURE CONN REJECT
- 1061 - LRRC(LTE Radio Resource Control) CONN REL NORMAL
- 1062 - LRRC(LTE Radio Resource Control) CONN REL RLF
- 1063 - LRRC(LTE Radio Resource Control) CONN REL CRE FAILURE
- 1064 - LRRC(LTE Radio Resource Control) CONN REL OOS DURING CRE
- 1065 - LRRC(LTE Radio Resource Control) CONN REL ABORTED
- 1066 - LRRC(LTE Radio Resource Control) CONN REL SIB READ ERROR
- 1067 - DETACH WITH REATTACH LTE NW DETACH
- 1068 - DETACH WITH OUT REATTACH LTE NW DETACH
- 1069 - ESM(EPS Session Management) PROC TIME OUT
- 1070 - MESSAGE EXCEED MAX L2 LIMIT
- 1500 - CD GEN OR BUSY, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to the reception of a Connection Deny message with a deny code of general or network busy
- 1501 - CD BILL OR AUTH, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to the reception of a Connection Deny message with a deny code of billing failure or authentication failure
- 1502 - CHG HDR, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since there is a change to HDR system due to redirection or PRL not preferred
- 1503 - EXIT HDR, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device exited HDR due to redirection or PRL not preferred
- 1504 - HDR NO SESSION, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device does not have a HDR session
- 1505 - HDR ORIG DURING GPS FIX, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since it is ending an HDR call origination in favor of a GPS fix
- 1506 - HDR CS TIMEOUT, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since connection setup on HDR system timed out
- 1507 - HDR RELEASED BY CM, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) when it wants to release a HDR call so a 1X call can continue
- 1508 - COLLOC ACQ FAIL, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) when device failed to acquire co-located HDR for origination
- 1509 - OTASP COMMIT IN PROG, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since an OTASP commit is in progress
- 1510 - NO HYBR HDR SRV, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device has no Hybrid HDR service
- 1511 - HDR NO LOCK GRANTED, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since HDR module could not get the RF lock

- 1512 - HOLD OTHER IN PROG, this error code is returned when data call is brought down by CM(Call Manager) because DBM or SMS is in progress
- 1513 - HDR FADE, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since HDR module released the call due to fade
- 1514 - HDR ACC FAIL, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to HDR system Access Failure
- 2000 - CLIENT END, this error code is returned when client ends the data call
- 2001 - NO SRV, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since device has no service
- 2002 - FADE, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device lost the system due to fade
- 2003 - REL NORMAL, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to receiving a release from base station with no reason
- 2004 - ACC IN PROG, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to Access attempt already in progress
- 2005 - ACC FAIL, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to Access Failure
- 2006 - REDIR OR HANDOFF, this error code is returned when data call is brought down because device is in the process of redirecting/handing off to a different target system
- 2500 - OFFLINE, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device went offline
- 2501 - EMERGENCY MODE, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since device is operating in Emergency mode
- 2502 - PHONE IN USE, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device is in use (e.g voice call)
- 2503 - INVALID MODE, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since the device's operational mode is different from the mode requested in the traffic channel bring up
- 2504 - INVALID SIM STATE, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since the SIM was marked by network as invalid for circuit and/or packet service domain
- 2505 - NO COLLOC HDR, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since there is no collocated HDR
- 2506 - CALL CONTROL REJECTED, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since Call control module rejected the request

9.15.2.9 3GPP specification defined call end reasons (Type=6)

- 8 - OPERATOR DETERMINED BARRING, this reason code is posted by the MME(Mobility Management Entity) to indicate operator has barred the UE
- 25 - LLC SNDCP FAILURE, PDP context deactivation initiated by the MS or by the Network
- 26 - INSUFFICIENT RESOURCES, this reason is posted to indicate that the network cannot provide the requested service due to insufficient resources
- 27 - MISSING OR UNKNOWN APN, the APN was required and not specified or APN could not be resolved. In LTE mode of operation, this is a PDN throttling cause code, meaning the UE may endup throttling further requests to the same APN

- 28 - UNKNOWN PDN TYPE, the reason is posted by the network to indicate that the PDN type was not recognized
- 29 - AUTH FAILED, the reason is posted when authentication fails. In LTE mode of operation, this is a PDN throttling cause code, meaning the UE may end up throttling further requests to the same APN
- 30 - GGSN REJECT, the reason is posted when the request was rejected by Serving GW or PDN GW. In LTE mode of operation, this is a PDN throttling cause code, meaning the UE may end up throttling further requests to the same APN
- 31 - ACTIVATION REJECT, the reason is posted when the request is rejected by the network due to unspecified reasons
- 32 - OPTION NOT SUPPORTED, the reason is posted when UE requested a service not supported by the PLMN
- 33 - OPTION UNSUBSCRIBED, This cause is sent when the MS requests a service option for which it has no subscription
- 34 - OPTION TEMP OOO, service option temporarily out of order, this reason is posted when the network is temporarily out of resources to service the request
- 35 - PTI ALREADY USED, the reason is posted to indicate that PTI (Procedure Transaction Identifier) used in the request is already active via another UE requested procedure
- 36 - REGULAR DEACTIVATION, this reason is posted by the network to initiate a regular release of bearer resources
- 37 - EPS QOS NOT ACCEPTED, this reason is posted by the network to indicate that the QoS requested by the UE could not be accepted
- 38 - NETWORK FAILURE, this reason is posted when an error occurs in the network
- 39 - UMTS REACTIVATION REQ, this reason is posted by the network to request for bearer reactivation. This code may be posted during network congestion
- 40 - FEATURE NOT SUPPORTED, Unsuccessful MBMS context activation requested by the network
- 41 - TFT SEMANTIC ERROR, the reason is posted by the network to indicate semantic error(s) in specifying TFT operation included in the request
- 42 - TFT SYNTAX ERROR, the reason is posted by the network to indicate syntactic error(s) in specifying TFT operation included in the request
- 43 - UNKNOWN PDP CONTEXT, the reason is posted when the bearer identity (or linked bearer identity) in the request is invalid (or inactive)
- 44 - FILTER SEMANTIC ERROR, the reason is posted by the network to indicate semantic error(s) in specifying packet filter(s) associated with a TFT
- 45 - FILTER SYNTAX ERROR, the reason is posted by the network to indicate syntactic error(s) in specifying packet filter(s) associated with a TFT
- 46 - PDP WITHOUT ACTIVE TFT, the reason is posted by the network when UW requested more than one PDP connection without TFT
- 50 - IPV4 ONLY ALLOWED, 3GPP equivalent ESM(EPS Session Management) cause code value 50, PDN type IPv4 only allowed.
- 51 - IPV6 ONLY ALLOWED, 3GPP equivalent ESM(EPS Session Management) cause code value 51, PDN type IPv6 only allowed
- 52 - SINGLE ADDRESS BEARER ONLY, 3GPP equivalent ESM(EPS Session Management) cause code value 52, Single address bearers only allowed. The reason is posted when the network supports single address bearers only, meaning dual IP bearers are not supported

- 53 - ESM INFORMATION NOT RECEIVED, 3GPP equivalent ESM(EPS Session Management) cause code value 53, ESM information not received. The reason is posted by the network to indicate that the PDN connection request was rejected because ESM information was not received
- 54 - PND CONNECTION DOES NOT EXIST, 3GPP equivalent ESM(EPS Session Management) cause code value 54, PDN connection does not exist The reason is posted by the network during handover from a non-3GPP network to indicate that the MME does not have any information regarding the requested PDN connection
- 55 - MULTIPLE CONNECTION TO SAME PDN NOT ALLOWED, 3GPP equivalent ESM(EPS Session Management) cause code value 55, Multiple PDN connections for a given APN not allowed. The reason is posted by the network to indicate that the UE is already connected to the requested APN via another PDN/PDN connection
- 81 - INVALID TRANSACTION ID, the reason is posted by the network to indicate that the PTI used in the request is unassigned or reserved
- 95 - MESSAGE INCORRECT SEMANTIC, the reason is posted by the network to indicate receipt of an invalid message
- 96 - INVALID MANDATORY INFO, the reason is posted by the network to indicate receipt of a message with semantic error in a mandatory information element
- 97 - MESSAGE TYPE UNSUPPORTED, the reason is posted by the network to indicate receipt of a message that is either undefined or defined but not implemented by the equipment sending this ESM cause
- 98 - MSG TYPE NONCOMPATIBLE STATE, the reason is posted by the network to indicate receipt of a message type that cannot be handled in the current network protocol state
- 99 - UNKNOWN INFO ELEMENT, the reason is posted by the network to indicate receipt of a message that includes and information element that is either not defined or defined but not implemented by the equipment sending the ESM cause
- 100 - CONDITIONAL IE ERROR, the reason is posted by the network to indicate receipt of a message that includes a syntactically incorrect information element. This message is ignored by the network.
- 101 - MSG AND PROTOCOL STATE UNCOMPATIBLE, the reason is posted by the network to indicate receipt of a message that cannot be handled in the current network protocol state
- 111 - PROTOCOL ERROR, the reason is posted by the network to indicate a protocol error when no other error applies
- 112 - APN TYPE CONFLICT
- 113 - INVALID PROXY-CALL SESSION CONTROL FUNCTION ADDRESS

9.15.2.10 PPP call end reasons (Type=7)

- 1 - TIMEOUT, this error code is returned when the data call bring up fails in PPP setup due to timeout (For e.g: LCP Conf Ack not received from network)
- 2 - AUTH FAILURE, this error code is returned when the data call bring up fails in PPP setup due to authentication failure
- 3 - OPTION MISMATCH, this error code is returned when the data call bring up fails in PPP setup due option mismatch (e.g: Authentication is required, but not negotiated with network during LCP phase)
- 31 - PAP FAILURE, this error code is returned when the data call bring up fails in PPP setup due to PAP failure
- 32 - CHAP FAILURE, this error code is returned when the data call bring up fails in PPP setup due to CHAP failure
- 33 - CLOSE IN PROGRESS, this error code is returned when the data call bring up fails in PPP setup since PPP is in the process of cleaning the previous PPP session
- -1 - UNKNOWN, this error code is unused

9.15.2.11 EHRPD call end reasons (Type=8)

- 1 - SUBS LIMITED TO V4, this error code is returned when the V6 interface bring up fails because network provided only V4 address for the upcoming PDN
- 2 - SUBS LIMITED TO V6, this error code is returned when the V4 interface bring up fails because network provided only V6 address for the upcoming PDN
- 4 - VSNCP(Vendor Specific Network Control Protocol) TIMEOUT, this error code is returned when the data call bring up fails in VSNCP phase due to VSNCP timeout error
- 5 - VSNCP(Vendor Specific Network Control Protocol) FAILURE, this error code is returned when VSNCP configuration failed during call bring up
- 6 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I GEN ERROR, this error code is returned when the data call bring up fails in VSNCP phase due to general error
- 7 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I UNAUTH APN, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason requested APN is unauthorized
- 8 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I PDN LIMIT EXCEED, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason PDN limit exceeded
- 9 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I NO PDN GW, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason no PDN gateway
- 10 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I PDN GW UNREACH, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason PDN gateway unreachable
- 11 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I PDN GW REJ, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason PDN gateway reject
- 12 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I INSUFF PARAM, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason insufficient parameter
- 13 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I RESOURCE UNAVAIL, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason resource unavailable
- 14 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I ADMIN PROHIBIT, this error code is returned when the data call bring up fails in SNCP phase since network rejected VSNCP config request with reason admin prohibited
- 15 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I PDN ID IN USE, this error code is returned when the data call bring up fails in VSNCP phase because network rejected with reason PDN ID IN USE (or) All existing PDNs are brought down with this end reason because one of the PDN bring up got rejected by network with reason PDN ID IN USE
- 16 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I SUBSCR LIMITATION, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason subscriber limitation
- 17 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I PDN EXISTS FOR THIS APN, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason PDN exists for this APN

9.15.2.12 IPV6 call end reasons (Type=9)

- 1 - PREFIX UNAVAILABLE, this error code is returned when V6 data call is brought down because device failed to get the prefix from network
- 2 - IPV6 ERR HRPD IPV6 DISABLED, this error code is returned when V6 data call bring up is rejected because IPV6 is disabled in 1X/HRPD mode
- 3 - IPV6 DISABLED, this error code is returned when IPv6 data call bring up is rejected because NV1896 (IPV6 enable) is disabled

Copyright: © 2011-2013 Sierra Wireless, Inc. all rights reserved

9.16 qaGobiApiTableCarrierCodes.h File Reference

Carrier Codes table.

9.16.1 Detailed Description

Carrier Codes table.

9.16.2 Carrier Codes (Number - Carrier)

- 0 - no carrier specified
- 1 - Generic
- 2 - Telstra
- 4 - AT&T
- 5 - Verizon
- 11 - Sprint
- 12 - Telefonica
- 101 - Verizon
- 102 - Sprint
- 103 - Alltel
- 104 - Bell Mobility
- 105 - Telus
- 106 - U.S. Cellular
- 107 - Telstra
- 108 - China Unicom
- 109 - Telecom New Zealand
- 110 - SK Telecom
- 111 - Reliance Communications
- 112 - Tata Communications
- 113 - MetroPCS Communications

- 114 - Leap Wireless
- 115 - KDDI
- 116 - Grupo Iusacell
- 117 - China Telecom
- 118 - Open Mobile Handset
- 176 - Rogers
- 177 - NetIndex
- 178 - DNA
- 179 - Big Pond
- 201 - AT&T
- 202 - Vodafone
- 203 - T-Mobile
- 204 - Orange
- 205 - Telefonica
- 206 - Telecom Italia
- 207 - 3
- 208 - O2
- 209 - SFR
- 210 - Swisscom AG
- 211 - China Mobile
- 212 - Telstra
- 213 - Singapore Telecommunications
- 214 - Reliance Telecommunications
- 215 - Bharti Airtel
- 216 - NTT docomo
- 217 - E Mobile
- 218 - Softbank
- 219 - Korea Telecom Freetel
- 220 - SK Telecom
- 221 - Telenor
- 222 - NetCom Norway
- 223 - TeliaSonera
- 224 - América Móvil
- 225 - Brasil Vivo
- 0xFFFFFFFF - Unknown

Copyright: © 2011-2014 Sierra Wireless, Inc. all rights reserved

9.17 qaGobiApiTableCodingScheme.h File Reference

Data Coding Scheme.

Macros

- #define __GOBI_API_CODING_SCHEME_H__

9.17.1 Detailed Description

Data Coding Scheme.

9.17.2 S1

9.17.2.1 Use of bits 3..0\n\n

- Language using the GSM 7 bit default alphabet Bits 3..0
  indicate the language:
  0000 German
  0001 English
  0010 Italian
  0011 French
  0100 Spanish
  0101 Dutch
  0110 Swedish
  0111 Danish
  1000 Portuguese
  1001 Finnish
  1010 Norwegian
  1011 Greek
  1100 Turkish
  1101 Hungarian
  1110 Polish
  1111 Language unspecified

9.17.3 Coding Group Bits 7..4(0001)

9.17.3.1 use of bits 3..0

- 0000 GSM 7 bit default alphabet; message preceded by language indication.
  The first 3 characters of the message are a two-character representation of the language encoded according to ISO 639 [12], followed by a CR character. The CR character is then followed by 90 characters of text.
- 0001 UCS2; message preceded by language indication
  The message starts with a two GSM 7-bit default alphabet character representation of the language encoded according to ISO 639. This is padded

to the octet boundary with two bits set to 0 and then followed by 40 characters
of UCS2-encoded message.
An MS not supporting UCS2 coding will present the two character language
identifier followed by improperly interpreted user data.

9.17.4 Coding Group Bits 7..4(0010)

9.17.4.1 use of bits 3..0

- 0000 Czech
  0001 Hebrew
  0010 Arabic
  0011 Russian
  0100 Icelandic
  0101..1111 Reserved for other languages using the GSM 7 bit
  default alphabet, with unspecified handling at the MS

9.17.5 Coding Group Bits 7..4(0011)

9.17.5.1 use of bits 3..0

- 0000..1111 Reserved for other languages using the GSM 7 bit
  default alphabet, with unspecified handling at the MS

9.17.6 Coding Group Bits 7..4(01xx)

9.17.6.1 use of bits 3..0

- General Data Coding indication
  - Bits 5..0 indicate the following:
  - Bit 5, if set to 0, indicates the text is uncompressed
  - Bit 5, if set to 1, indicates the text is compressed using the compression algorithm defined in 3GPP TS 23.042
  - Bit 4, if set to 0, indicates that bits 1 to 0 are reserved and have no message class meaning
  - Bit 4, if set to 1, indicates that bits 1 to 0 have a message class meaning: Bit 1 Bit 0 Message Class:
    0 0 Class 0
    0 1 Class 1 Default meaning: ME-specific.
    1 0 Class 2 (U)SIM specific message.
    1 1 Class 3 Default meaning: TE-specific (see 3GPP TS 27.005)
    Bits 3 and 2 indicate the character set being used, as follows:
    Bit 3 Bit 2 Character set:
    0 0 GSM 7 bit default alphabet
    0 1 8 bit data
    1 0 UCS2 (16 bit) [10]
    1 1 Reserved

9.17.7 Coding Group Bits 7..4(1001)

9.17.7.1 Reserved coding groups

- Message with User Data Header (UDH) structure:
  Bit 1 Bit 0 Message Class:
  0 0 Class 0
  0 1 Class 1 Default meaning: ME-specific.
  1 0 Class 2 (U)SIM specific message.
  1 1 Class 3 Default meaning: TE-specific (see 3GPP TS 27.005 [8])
  Bits 3 and 2 indicate the alphabet being used, as follows:
  Bit 3 Bit 2 Alphabet:
  0 0 GSM 7 bit default alphabet
  0 1 8 bit data
  1 0 USC2 (16 bit) [10]
  1 1 Reserved

9.17.8 Coding Group Bits 7..4(1010..1101)

9.17.8.1 Reserved coding groups

9.17.9 Coding Group Bits 7..4(1110)

9.17.9.1 Defined by the WAP Forum

9.17.10 Coding Group Bits 7..4 (1111)

9.17.10.1 Data coding / message handling

- Bit 3 is reserved, set to 0.
  Bit 2 Message coding:
  0 GSM 7 bit default alphabet
  1 8 bit data
  Bit 1 Bit 0 Message Class:
  0 0 No message class.
  0 1 Class 1 user defined.
  1 0 Class 2 user defined.
  1 1 Class 3
  default meaning: TE specific(3GPP TS 27.005)
  Copyright: © 2012 Sierra Wireless, Inc. all rights reserved

9.17.11 Macro Definition Documentation

9.17.11.1 #define __GOBI_API_CODING_SCHEME_H__

9.18 qaGobiApiTableGpsCapabilityCodes.h File Reference

Position Determination Service API GPS Capability Codes.

9.18.1 Detailed Description

Position Determination Service API GPS Capability Codes.

9.18.2 GPS capability (Value - Capability)

- 0 - None
- 1 - Standalone
- 2 - Assisted (including XTRA and implying standalone is also supported)
- 3 - Assisted (without XTRA and implying standalone is also supported)
- 0xFFFFFFFF - Unknown

Copyright: © 2011 Sierra Wireless, Inc. all rights reserved

9.19 qaGobiApiTablePowerModes.h File Reference

Device Management Service API Power Modes table.

9.19.1 Detailed Description

Device Management Service API Power Modes table.

9.19.2 Power Modes (Value - Description)

- 0 - Online (default)
- 1 - Low power (airplane) mode
- 2 - Factory test mode
- 3 - Offline
- 4 - Reset
- 5 - Power off
- 6 - Persistent low power (airplane) mode
- 7 - Mode - only low power

Valid transitions for Power Modes

- Online to Low Power, Persistent low power, Factory test, Offline or Shut Down
- Low power to online, Persistent low power, Offline, or Shut Down
- Persistent low power to Online, Low power, Offline or Shut down
- Factory test to online
- Offline to Reset

Copyright: © 2011 Sierra Wireless, Inc. all rights reserved

9.20 qaGobiApiTableRadioInterfaces.h File Reference

Network Access Service API Radio Interfaces table.

9.20.1 Detailed Description

Network Access Service API Radio Interfaces table.

9.20.2 Radio interface

9.20.2.1 Technology (Value - Radio Interface Technology)

- 0 - No service
- 1 - CDMA 1xRTT
- 2 - CDMA 1xEV-DO
- 3 - AMPS (Unsupported)
- 4 - GSM
- 5 - UMTS
- 6 - WLAN
- 7 - GPS
- 8 - LTE

Copyright: © 2011 Sierra Wireless, Inc. all rights reserved

9.21 qaGobiApiTableRegionCodes.h File Reference

Region Codes table.

9.21.1 Detailed Description

Region Codes table.

9.21.2 Region Codes (Code - Region)

- 0 - North America
- 1 - Latin America
- 2 - Europe
- 3 - Asia
- 4 - Australia
- 5 - Global
- 0xFFFFFFFF - Unknown

Copyright: © 2011 Sierra Wireless, Inc. all rights reserved

9.22 qaGobiApiTableServiceOptions.h File Reference

Voice Service Options.

9.22.1 Detailed Description

Voice Service Options.

9.22.2 Service Option codes (Code - Reason)

9.22.2.1 Description

- 0x0001 - Basic variable rate voice service (8 kbps)
- 0x0002 - Mobile station loopback (8 kbps)
- 0x0003 - Enhanced variable rate voice service (8 kbps)
- 0x0004 - Asynchronous data service (9.6 kbps)
- 0x0005 - Group 3 facsimile (9.6 kbps)
- 0x0006 - Short message service (rate set 1)
- 0x0007 - Packet data service: Internet or ISO Protocol stack (9.6 kbps)
- 0x0008 - Packet data service: CDPD Protocol stack (9.6 kbps)
- 0x0009 - Mobile station loopback (13 kbps)
- 0x000A - transparent service
- 0x000B - III nontransparent service
- 0x000C - Asynchronous data service (14.4 or 9.6 kbps)
- 0x000D - Group 3 facsimile (14.4 or 9.6 kbps)
- 0x000E - Short message service (rate set 2)
- 0x000F - Packet data service: Internet or ISO Protocol stack (14.4 kbps)
- 0x0010 - Packet data service: CDPD Protocol stack (14.4 kbps)
- 0x0011 - High-rate voice service (13 kbps)
- 0x0012 - Over-the-air parameter administration (rate set 1)
- 0x0013 - Over-the-air parameter administration (rate set 2)
- 0x0014 - Group 3 analog facsimile (rate set 1)
- 0x0015 - Group 3 analog facsimile (rate set 2)
- 0x0016 - High-speed packet data service: Internet or ISO Protocol stack (RS1 forward, RS1 reverse)
- 0x0017 - High-speed packet data service: Internet or ISO Protocol stack (RS1 forward, RS2 reverse)
- 0x0018 - High-speed packet data service: Internet or ISO Protocol stack (RS2 forward, RS1 reverse)
- 0x0019 - High-speed packet data service: Internet or ISO Protocol stack (RS2 forward, RS2 reverse)
- 0x001A - High-speed packet data service: CDPD Protocol stack (RS1 forward, RS1 reverse)
- 0x001B - High-speed packet data service: CDPD Protocol stack (RS1 forward, RS2 reverse)

- 0x001C - High-speed packet data service: CDPD Protocol stack (RS2 forward, RS1 reverse)
- 0x001D - High-speed packet data service: CDPD Protocol stack (RS2 forward, RS2 reverse)
- 0x001E - RATE_SET_1 Supplemental channel loopback test for rate set 1
- 0x001F - RATE_SET_2 Supplemental channel loopback test for rate set 2
- 0x0020 - Test Data Service Option (TDSO)
- 0x0021 - cdma2000 high-speed packet data service, Internet or ISO Protocol stack
- 0x0022 - cdma2000 high-speed packet data service, CDPD Protocol
- 0x0023 - Location services, rate set 1 (9.6 kbps)
- 0x0024 - Location services, rate set 2 (14.4 kbps)
- 0x0025 - ISDN interworking service (64 kbps)
- 0x0026 - GSM voice
- 0x0027 - GSM circuit data
- 0x0028 - GSM packet data
- 0x0029 - GSM short message service
- 0x0036 - Markov Service Option (MSO)
- 0x0037 - Loopback Service Option (LSO)
- 0x0038 - Selectable mode vocoder
- 0x0039 - 32 kbps circuit video conferencing
- 0x003A - CONFERENCING 64 kbps circuit video conferencing
- 0x003B - HRPD packet data service, which when used in paging over the 1X air interface, a page response is not required
- 0x003C - Link Layer Assisted Robust Header Compression (LLA ROHC) - header removal
- 0x003D - LLA ROHC - Header Compression
- 0x003E - Source-controlled Variable-Rate Multimode Wideband (VMR-WB) speech codec rate set 2
- 0x003F - Source-controlled VMR-WB speech codec rate set 1
- 0x0040 - HRPD auxiliary packet data service instance
- 0x0041 - cdma2000/GPRS interworking
- 0x0042 - ISO_PROTOCOL_SO_66 cdma2000 high-speed packet data service, Internet or ISO Protocol stack
- 0x0043 - HRPD packet data IP service where higher layer protocol is IP or ROHC
- 0x0044 - Enhanced variable rate voice service (EVRC-B)
- 0x0045 - HRPD packet data service, which when used in paging over the 1X air interface, a page response is required
- 0x0046 - Enhanced variable rate voice service (EVRC-WB)
- 0x1004 - Asynchronous data service, Revision 1 (9.6 or 14.4 kbps)
- 0x1005 - Group 3 facsimile, Revision 1 (9.6 or 14.4 kbps)
- 0x1007 - Packet data service: Internet or ISO Protocol stack, Revision 1 (9.6 or 14.4 kbps)
- 0x1008 - Packet data service: CDPD Protocol stack, Revision 1 (9.6 or 14.4 kbps)

- 0x7FF8 - Identifies service reference identifier 0
- 0x7FF9 - Identifies service reference identifier 1
- 0x7FFA - Identifies service reference identifier 2
- 0x7FFB - Identifies service reference identifier 3
- 0x7FFC - Identifies service reference identifier 4
- 0x7FFD - Identifies service reference identifier 5
- 0x7FFE - Identifies service reference identifier 6
- 0x7FFF - Identifies service reference identifier 7

Copyright: © 2012 Sierra Wireless, Inc. all rights reserved

9.23 qaGobiApiTableSupServiceInfoClasses.h File Reference

Voice Supplementary Service Information Classes.

9.23.1 Detailed Description

Voice Supplementary Service Information Classes.

9.23.2 Supplementary Service Information Classes (Value - Service Class)

- 0X00 - CLASS_NONE
- 0X01 - CLASS_VOICE
- 0X02 - CLASS_DATA
- 0X04 - CLASS_FAX
- 0X08 - CLASS_SMS
- 0X10 - CLASS_DATACIRCUITSYNC
- 0X20 - CLASS_DATACIRCUITASYNC
- 0X40 - CLASS_PACKETACCESS
- 0X80 - CLASS_PADACCESS

Copyright: © 2012 Sierra Wireless, Inc. all rights reserved

9.24 qaGobiApiTableSwiAudio.h File Reference

Swi Audio related tables.

9.24.1 Detailed Description

Swi Audio related tables.

9.24.2 ACDB Device (Device ID - description)

- 0 - Vehicle HF
- 1 - Handset
- 2 - TTY
- 3 - USB
- 4 - NA

9.24.3 Physical Interface (Device ID - description - Interface parameters)

- 0 - PCM - Mode: 0-slave, 1-master, 2-Auxiliary PCM; Rate: 0-8k, 1-16k; Format: 0-linear, 1-u-law, 2-A-law; Padding: 0-disable, 1-enable; Bits-frame: 0-8BPF, 1-16BPF, 2-32BPF, 3-64BPF, 4-128BPF, 5-256BPF;
- 1 - I2S - None
- 2 - Analog(with internal codec) - None
- 3 - USB - None

Copyright: © 2013 Sierra Wireless, Inc. all rights reserved

9.25 qaGobiApiTableSwiOMADMSessionStatus.h File Reference

Session Status table.

9.25.1 Detailed Description

Session Status table.

9.25.2 OMA DM Session Status (Session Status - Meaning - Usage)

- 0x0000 - Successful - Session succeeded
- 0x0001 - Break - Session succeeded
- 0x0002 - Large Object Handled - Session succeeded
- 0x0003 - No status - Session succeeded
- 0x0004 - No more commands - Session succeeded
- 0x0005 - User cancel - Session cancelled
- 0x0100-0x01FF - General errors
- 0x0200-0x02FF - Syncml errors
- 0x0300-0x03FF - Authentication errors
- 0x0400-0x04FF - Protocol errors
- 0x0500-0x05FF - Tree errors (DM Only)
- 0x0600-0x06FF - Not applicable
- 0x0700-0x07FF - Trigger errors

- 0x0800-0x08FF - FUMO errors
- 0x0900-0x09FF - Communication errors
- 0x0A00-0x0AFF - Parsing errors
- 0x0B00-0x0CFF - Not applicable
- 0x7F00-0x7F12 - Insignia errors
- 0x7F13 - Illegal text - Text received contains illegal characters
- 0x7F14 - Download failure - Failed to download FOTA image
- 0x7F15 - Empty session - Session ran successfully, but no information was updated
- 0x7F16 - Factory reset successful - Factory reset succeeded
- 0x7F17 - Factory reset fail - Factory reset failed

Copyright: © 2017 Sierra Wireless, Inc. all rights reserved

9.26 qaGobiApiTableSwiOMADMUpdateCompleteStatus.h File Reference

Update Complete Status table.

9.26.1 Detailed Description

Update Complete Status table.

9.26.2 OMA DM Update Complete Status (Update Complete Status - Meaning - Usage)

- 200 - Successful - The request has succeeded
- 250-299 - Successful(vendor specified) - successful operation with vendor specified ResultCode
- 400 - Management Client Error - Management Client error - based on User or Device behavior
- 401 - User Cancelled - User chose not to accept the operation when prompted
- 402 - Corrupted Firmware Update Package - Corrupted firmware update package did not store correctly. Detected for example, by mismatch CRCs between actual and expected
- 403 - Firmware UpdatePackage(Device Mismatch) - Wrong firmware update package delivered to device based on current device characteristics
- 404 - Failed Firmware Update Package Validation - Failure to positively validate digital signature of firmware update package
- 405 - Firmware Update Package Not acceptable - firmware update package is not acceptable
- 406 - Alternate Download Authentication Failure - authentication required but authentication failure was encountered when downloading firmware update package
- 407 - Alternate Download Request Timeout - client has encountered a timeout when downloading firmware update package
- 408 - Not Implemented - the device does not support the requested operation
- 409 - Undefined Error - indicates failure not defined by any other error code
- 410 - Firmware Update Failed - firmware update operation failed in device

- 411 - Malformed or Bad URL - the URL provided for alternate download is bad
- 412 - Alternate Download Server Unavailable - the alternate download server is unavailable or does not respond
- 450 - Client Error (OMADM General) - Vendor defined client error
- 451 - Client Error (OMADM SyncML) - Vendor defined client error
- 452 - Client Error (OMADM Auth) - Vendor defined client error
- 453 - Client Error (OMADM Protocol)- Vendor defined client error
- 454 - Client Error (OMADM Tree) - Vendor defined client error
- 455 - Client Error (OMADM DStore) - Vendor defined client error
- 456 - Client Error (OMADM Trigger) - Vendor defined client error
- 457 - Client Error (OMADM Fumo) - Vendor defined client error
- 458 - Client Error (OMADM Comms) - Vendor defined client error
- 459 - Client Error (OMADM Parse) - Vendor defined client error
- 460 - Client Error (OMADM TNDS) - Vendor defined client error
- 461 - Client Error (OMADM SCM) - Vendor defined client error
- 462 - Client Error (OMADM Impl) - Vendor defined client error
- 463-499 - Client Error (Vendor Specified) - client error encountered for operation with vendor specified result code
- 500 - Alternate Download Server Error - Alternate download server error encountered
- 501 - Download fails due to device out of memory - The download fails due to insufficient memory in the device to save the firmware update package
- 502 - Firmware update fails due to device out of memory - The update fails because there isn't sufficient memory to update the device
- 503 - Download fails due to network issues - The download fails due to network/transport level errors
- 550-599 - Alternate Download Server Error (vendor specified)- Alternate download server error encountered for operation with vendor specified result code

Copyright: © 2013 Sierra Wireless, Inc. all rights reserved

9.27 qaGobiApiTableVoiceCallEndReasons.h File Reference

Voice Service Call and supplementary services end reasons.

9.27.1 Detailed Description

Voice Service Call and supplementary services end reasons.

9.27.2 Voice Call and supplementary services end reason codes (Code - Reason)

9.27.2.1 General

- 0 - Phone is offline
- 20 - Phone is CDMA locked until a power cycle; CDMA only
- 21 - Phone has no service, this is for backward compatibility
- 22 - Call has ended abnormally; CDMA only
- 23 - Received intercept from the base station; originating only; CDMA only
- 24 - Received reorder from the base station; originating only; CDMA only
- 25 - Received release from the base station; no reason was given
- 26 - Received release from the base station; SO reject; CDMA only
- 27 - Received incoming call from the base station
- 28 - Received alert stop from the base station; incoming only; CDMA only
- 29 - Client ended the call
- 30 - Received end activation; OTASP call only; CDMA only
- 31 - MC aborted the origination/conversation; CDMA only
- 32 - Maximum access probes were transmitted; CDMA only
- 33 - Persistence test failure; FEATURE_JCDMA only; CDMA only
- 34 - R-UIM is not present
- 35 - Access attempt is already in progress
- 36 - Access failure for a reason other than the above
- 37 - Received retry order; originating only; IS 2000; CDMA only
- 38 - BYBS Concurrent service is not supported by the base station
- 39 - No response was received from the base station
- 40 - Call was rejected by the base station; CDMA only
- 41 - Concurrent services requested were not compatible; CDMA only
- 42 - Access is blocked by the base station; CDMA only
- 43 - Corresponds to CM_CALL_ORIG_ ERR_ALREADY_IN_TC
- 44 - Call is ended because an emergency call is flashed over this call; CDMA only
- 45 - Used if CM is ending a GPS call in preference of a user call
- 46 - Used if CM is ending an SMS call in preference of a user call
- 47 - Used if CM is ending a data call in preference of an emergency call
- 48 - Call was rejected because of a redirection or handoff
- 49 - Access is blocked by the base station for all mobiles; KDDI-specific; CDMA only
- 50 - To support OTASP SPC Error indication
- 51 - Maximum access probes for an IS-707B call; CDMA only

- 52 - Base station reject order
- 53 - Base station retry order
- 54 - Timer T42 is expired
- 55 - Timer T40 is expired
- 56 - Service initialization failure - Traffic Channel Initialization
- 57 - Timer T50m is expired - Traffic Channel Initialization
- 58 - Timer T51m is expired - Traffic Channel Initialization
- 59 - Acknowledgement timeout due to 12 retransmissions
- 60 - Bad forward link or timer T5M is expired
- 61 - Transceiver Resource Manager request failed
- 62 - Timer T41 is expired
- 100 - WCDMA/GSM/TDS only; call end LL cause, Received a reason for ending the call from the lower layer
- 101 - WCDMA/GSM only; Call origination request failed
- 102 - WCDMA/GSM only; client rejected an incoming call
- 103 - WCDMA/GSM only; client rejected a setup indication
- 104 - WCDMA/GSM only; network ended the call
- 105 - WCDMA/GSM only
- 106 - GWM/WCDMA only; phone has no service
- 107 - 1X only; phone has no service
- 108 - Full service is unavailable
- 109 - Indicates resources are not available to handle a new MO/MT PS call

9.27.2.2 service Errors

- 110 - Unknown subscriber
- 111 - Illegal subscriber
- 112 - Bearer service not provisioned
- 113 - Tele service not provisioned
- 114 - Illegal equipment
- 115 - Call barred
- 116 - Illegal ss operation
- 117 - Ss error status
- 118 - Ss not available
- 119 - Ss subscription violation
- 120 - Ss incompatibility
- 121 - Facility not supported
- 122 - Absent subscriber

- 123 - Short term denial
- 124 - Long term denial
- 125 - System failure
- 126 - Data missing
- 127 - Unexpected data value
- 128 - Pwd registration failure
- 129 - Negative pwd check
- 130 - Num of pwd attempts violation
- 131 - Position method failure
- 132 - Unknown alphabet
- 133 - Ussd busy
- 134 - Rejected by user
- 135 - Rejected by network
- 136 - Deflection to served subscriber
- 137 - Special service code
- 138 - Invalid deflected to number
- 139 - Mpty participants exceeded
- 140 - Resources not available

9.27.2.3 control cause values

- 141 - Unassigned number
- 142 - No route to destination
- 143 - Channel unacceptable
- 144 - Operator determined barring
- 145 - Normal call clearing
- 146 - User busy sEE [s3, aNNEX h]
- 147 - No user responding sEE [s3, aNNEX h]
- 148 - User alerting no answer
- 149 - Call rejected sEE [s3, aNNEX h]
- 150 - Number changed sEE [s3, aNNEX h]
- 151 - Preemption sEE [s3, aNNEX h]
- 152 - Destination out of order
- 153 - Invalid number format
- 154 - Facility rejected
- 155 - Resp to status enquiry
- 156 - Normal unspecified

- 157 - No circuit or channel available
- 158 - Network out of order
- 159 - Temporary failure
- 160 - Switching equipment congestion
- 161 - Access information discarded
- 162 - Requested circuit or channel not available
- 163 - Resources unavailable or unspecified
- 164 - Qos unavailable
- 165 - Requested facility not subscribed
- 166 - Incoming calls barred within cug
- 167 - Bearer capability not auth
- 168 - Bearer capability unavailable
- 169 - Service option not available
- 170 - Acm limit exceeded
- 171 - Bearer service not implemented
- 172 - Requested facility not implemented
- 173 - Only digital information bearer available
- 174 - Service or option not implemented
- 175 - Invalid transaction identifier
- 176 - USER NOT MEMBER OF CUG
- 177 - Incompatible destination
- 178 - Invalid transit nw selection
- 179 - Semantically incorrect message
- 180 - Invalid mandatory information
- 181 - Message type non implemented
- 182 - Message type not compatible with protocol statE
- 183 - Information element non existent
- 184 - Conditonal ie error
- 185 - Message not compatible with protocol state
- 186 - Recovery on timer expired
- 187 - Protocol error unspecified
- 188 - Interworking unspecified
- 189 - Outgoing calls barred within cug
- 190 - No cug selection
- 191 - Unknown cug index
- 192 - Cug index incompatible

- 193 - Cug call failure unspecified
- 194 - Clir not subscribed
- 195 - Ccbs possible sEE
- 196 - Ccbs not possible

9.27.2.4 reject causes

- 197 - Imsi unknown in hlr
- 198 - Illegal ms
- 199 - Imsi unknown in vlr
- 200 - Imei not accepted
- 201 - Illegal me sEE
- 202 - Plmn not allowed
- 203 - Location area not allowed
- 204 - Roaming not allowed in this location area
- 205 - No suitable cells in location area
- 206 - Network failure sEE
- 207 - mac failure sEE
- 208 - Synch failure
- 209 - Network congestion
- 210 - GSM authentication unacceptable
- 211 - Service not subscribed
- 212 - Service temporarily out of order
- 213 - Call cannot be identified
- 214 - Incorrect semantics in message
- 215 - Mandatory information invalid
- 216 - Call failed due to other access stratum failures
- 217 - SIM is invalid
- 218 - Invalid call state
- 219 - Access class is blocked
- 220 - No resources are in the protocol stack to allow the call
- 221 - Invalid user data was received

9.27.2.5 reject causes

- 222 - Timer T3230 is expired
- 223 - No cell is available
- 224 - Abort message was received
- 225 - Radio link was lost due to other lower layer causes

9.27.2.6 reject causes

- 226 - Timer T303 is expired
- 227 - CNM MM release is pending

9.27.2.7 stratum reject causes

- 228 - Access stratum RR release indication
- 229 - Access stratum random access failure
- 230 - RRC_REL_IND Access stratum RRC release indication
- 231 - Access stratum close session indication
- 232 - Access stratum open session failure
- 233 - Access stratum low level failure
- 234 - Access stratum low level failure redial is not allowed
- 235 - Access stratum low level immediate retry
- 236 - Access stratum abort radio is unavailable

9.27.2.8 reject causes

- 237 - Service option is not supported

9.27.2.9 IP end reasons

- 300 - Received SIP 400 bad request;waiting for INVITE response
- 301 - Received SIP 400 bad request;waiting for INVITE response
- 302 - Received SIP 404 not found; call failed; called party does not exist
- 303 - Received SIP 415 unsupported media type; call failed; called party does not support media
- 304 - Received SIP 480 temporarily unavailable; call failed; called party is not in the LTE area
- 305 - No network response; call failed
- 306 - No network response; unable to put call on hold
- 307 - Moved to eHRPD; call failed or dropped; not in the LTE area
- 308 - Upgrade/downgrade rejected (200 OK with the current call SDP)
- 309 - Received 403 call forbidden; waiting for INVITE response
- 310 - Generic timeout; did not receive a response from the server or other end
- 311 - Reported on the MO side for generic internal software errors; user can try again if the call still exists
- 312 - Reported on the MT side if the upgrade timer has been cancelled or cannot complete the request for some reason after notifying the user of a re-invite request
- 313 - Call origination is rejected due to a Service-Specific Access Control (SSAC) barring
- 314 - Phone was put in thermal emergency
- 315 - 1XCSFB call ended because of a soft failure
- 316 - 1XCSFB call ended because of a hard failure

Copyright: © 2012 Sierra Wireless, Inc. all rights reserved

9.28 qmerrno.h File Reference

Enumerations

- enum eQCWWANError {
  eQCWWAN_ERR_ENUM_BEGIN = -1,
  eQCWWAN_ERR_NONE,
  eQCWWAN_ERR_GENERAL,
  eQCWWAN_ERR_INTERNAL,
  eQCWWAN_ERR_MEMORY,
  eQCWWAN_ERR_INVALID_ARG,
  eQCWWAN_ERR_BUFFER_SZ,
  eQCWWAN_ERR_NO_DEVICE,
  eQCWWAN_ERR_INVALID_DEVID,
  eQCWWAN_ERR_NO_CONNECTION,
  eQCWWAN_ERR_QMI_IFACE,
  eQCWWAN_ERR_QMI_CONNECT,
  eQCWWAN_ERR_QMI_REQ_SCH,
  eQCWWAN_ERR_QMI_REQ,
  eQCWWAN_ERR_QMI_RSP,
  eQCWWAN_ERR_QMI_REQ_TO,
  eQCWWAN_ERR_QMI_RSP_TO,
  eQCWWAN_ERR_MALFORMED_QMI_RSP,
  eQCWWAN_ERR_INVALID_QMI_RSP,
  eQCWWAN_ERR_INVALID_FILE,
  eQCWWAN_ERR_FILE_OPEN,
  eQCWWAN_ERR_FILE_COPY,
  eQCWWAN_ERR_OFFLINE = 27,
  eQCWWAN_ERR_RESET,
  eQCWWAN_ERR_NO_SIGNAL,
  eQCWWAN_ERR_MULTIPLE_DEVICES,
  eQCWWAN_ERR_DRIVER,
  eQCWWAN_ERR_NO_CANCELABLE_OP,
  eQCWWAN_ERR_CANCEL_OP,
  eQCWWAN_ERR_API_MUTEX_TIMEOUT,
  eQCWWAN_ERR_PDU_GENERATION,
  eQCWWAN_ERR_INVALID_XID,
  eQCWWAN_ERR_MULTIPLE_SMS_UNSUPPORTED,
  eQCWWAN_ERR_ENUM_END,
  eQCWWAN_ERR_QMI_OFFSET = 1000,
  eQCWWAN_ERR_QMI_MALFORMED_MSG = 1001,
  eQCWWAN_ERR_QMI_NO_MEMORY,
  eQCWWAN_ERR_QMI_INTERNAL,
  eQCWWAN_ERR_QMI_ABORTED,
  eQCWWAN_ERR_QMI_CLIENT_IDS_EXHAUSTED,
  eQCWWAN_ERR_QMI_UNABORTABLE_TRANSACTION,
  eQCWWAN_ERR_QMI_INVALID_CLIENT_ID,
  eQCWWAN_ERR_QMI_NO_THRESHOLDS,
  eQCWWAN_ERR_QMI_INVALID_HANDLE,
  eQCWWAN_ERR_QMI_INVALID_PROFILE,
  eQCWWAN_ERR_QMI_INVALID_PINID,
  eQCWWAN_ERR_QMI_INCORRECT_PIN,
  eQCWWAN_ERR_QMI_NO_NETWORK_FOUND,
  eQCWWAN_ERR_QMI_CALL_FAILED,
  eQCWWAN_ERR_QMI_OUT_OF_CALL,
  eQCWWAN_ERR_QMI_NOT_PROVISIONED,
  eQCWWAN_ERR_QMI_MISSING_ARG,
  eQCWWAN_ERR_QMI_ARG_TOO_LONG = 1019,
  eQCWWAN_ERR_QMI_INVALID_TX_ID = 1022,
  eQCWWAN_ERR_QMI_DEVICE_IN_USE,
  eQCWWAN_ERR_QMI_OP_NETWORK_UNSUPPORTED,
  eQCWWAN_ERR_QMI_OP_DEVICE_UNSUPPORTED,
  eQCWWAN_ERR_QMI_NO_EFFECT,
  eQCWWAN_ERR_QMI_NO_FREE_PROFILE,
  eQCWWAN_ERR_QMI_INVALID_PDP_TYPE,
  eQCWWAN_ERR_QMI_INVALID_TECH_PREF,
  eQCWWAN_ERR_QMI_INVALID_PROFILE_TYPE,

eQCWWAN_ERR_QMI_WIDTH = 0xFFFF }
- enum qm_wds_ds_profile_extended_err_codes {
  eWDS_ERR_PROFILE_REG_RESULT_FAIL = 1,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_HNDL,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_OP,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_TYPE,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_NUM,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_IDENT,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_LIB_NOT_INITED,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_LEN_INVALID,
  eWDS_ERR_PROFILE_REG_RESULT_LIST_END,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_SUBS_ID,
  eWDS_ERR_PROFILE_REG_INVAL_PROFILE_FAMILY,
  eWDS_ERR_PROFILE_REG_3GPP_INVAL_PROFILE_FAMILY = 1001,
  eWDS_ERR_PROFILE_REG_3GPP_ACCESS_ERR,
  eWDS_ERR_PROFILE_REG_3GPP_CONTEXT_NOT_DEFINED,
  eWDS_ERR_PROFILE_REG_3GPP_VALID_FLAG_NOT_SET,
  eWDS_ERR_PROFILE_REG_3GPP_READ_ONLY_FLAG_SET,
  eWDS_ERR_PROFILE_REG_3GPP_ERR_OUT_OF_PROFILES,
  eWDS_ERR_PROFILE_REG_3GPP2_ERR_INVALID_IDENT_FOR_PROFILE = 1101,
  eWDS_ERR_PROFILE_REG_END }

9.28.1 Enumeration Type Documentation

9.28.1.1 enum eQCWWANError

QMI Error Code Enumeration

Enumerator

eQCWWAN_ERR_ENUM_BEGIN

eQCWWAN_ERR_NONE 00 - Success

eQCWWAN_ERR_GENERAL 01 - General error

eQCWWAN_ERR_INTERNAL 02 - Internal error

eQCWWAN_ERR_MEMORY 03 - Memory error

eQCWWAN_ERR_INVALID_ARG 04 - Invalid argument

eQCWWAN_ERR_BUFFER_SZ 05 - Buffer too small

eQCWWAN_ERR_NO_DEVICE 06 - Unable to detect WWAN device

eQCWWAN_ERR_INVALID_DEVID 07 - Invalid WWAN device ID

eQCWWAN_ERR_NO_CONNECTION 08 - No connection to WWAN device

eQCWWAN_ERR_QMI_IFACE 09 - Unable to obtain QMI interace

eQCWWAN_ERR_QMI_CONNECT 10 - Unable to connect to QMI interface

eQCWWAN_ERR_QMI_REQ_SCH 11 - Unable to schedule QMI request

eQCWWAN_ERR_QMI_REQ 12 - Error sending QMI request

eQCWWAN_ERR_QMI_RSP 13 - Error receiving QMI response

eQCWWAN_ERR_QMI_REQ_TO 14 - Timeout while sending QMI request

eQCWWAN_ERR_QMI_RSP_TO 15 - Timeout while receiving QMI response

eQCWWAN_ERR_MALFORMED_QMI_RSP 16 - Malformed QMI response received

eQCWWAN_ERR_INVALID_QMI_RSP 17 - Invalid QMI response received

eQCWWAN_ERR_INVALID_FILE 18 - Invalid file path

eQCWWAN_ERR_FILE_OPEN 19 - Unable to open file

eQCWWAN_ERR_FILE_COPY 20 - Unable to copy file

eQCWWAN_ERR_OFFLINE 27 - Unable to set WWAN device offline

eQCWWAN_ERR_RESET 28 - Unable to reset WWAN device

eQCWWAN_ERR_NO_SIGNAL 29 - No available signal

eQCWWAN_ERR_MULTIPLE_DEVICES 30 - Multiple WWAN devices detected

eQCWWAN_ERR_DRIVER 31 - Error interfacing to driver

eQCWWAN_ERR_NO_CANCELABLE_OP 32 - No cancelable operation is pending

eQCWWAN_ERR_CANCEL_OP 33- Error canceling outstanding operation

eQCWWAN_ERR_API_MUTEX_TIMEOUT 34- api mutex lock timeout

eQCWWAN_ERR_PDU_GENERATION 35- PDU generation error

eQCWWAN_ERR_INVALID_XID 36- Invalid transaction id

eQCWWAN_ERR_MULTIPLE_SMS_UNSUPPORTED 37- Unsupported multiple SMS

eQCWWAN_ERR_ENUM_END End of SLQS SDK specific error codes

eQCWWAN_ERR_QMI_OFFSET 1000 - This is not an error code but the offset from which mapped QMI error codes start from

eQCWWAN_ERR_QMI_MALFORMED_MSG 1001 - Malformed or Corrupted QMI msg

eQCWWAN_ERR_QMI_NO_MEMORY 1002 - Device could not allocate memory for QMI Resp

eQCWWAN_ERR_QMI_INTERNAL 1003 - Unexpected error occurred during processing

eQCWWAN_ERR_QMI_ABORTED 1004 - Processing aborted

eQCWWAN_ERR_QMI_CLIENT_IDS_EXHAUSTED 1005 - QMI client IDs have been exhausted

eQCWWAN_ERR_QMI_UNABORTABLE_TRANSACTION 1006 - Unable to abort QMI transaction

eQCWWAN_ERR_QMI_INVALID_CLIENT_ID 1007 - Invalid QMI client ID

eQCWWAN_ERR_QMI_NO_THRESHOLDS 1008 - No thresholds were provided

eQCWWAN_ERR_QMI_INVALID_HANDLE 1009 - Invalid Handle provided in the QMI request

eQCWWAN_ERR_QMI_INVALID_PROFILE 1010 - Profile specified is invalid

eQCWWAN_ERR_QMI_INVALID_PINID 1011 - Invalid PIN ID specified

eQCWWAN_ERR_QMI_INCORRECT_PIN 1012 - Incorrect PIN ID specified

eQCWWAN_ERR_QMI_NO_NETWORK_FOUND 1013 - No network found

eQCWWAN_ERR_QMI_CALL_FAILED 1014 - Call failed

eQCWWAN_ERR_QMI_OUT_OF_CALL 1015 - Device is not in a call

eQCWWAN_ERR_QMI_NOT_PROVISIONED 1016 - Requested information element not provisioned on device

eQCWWAN_ERR_QMI_MISSING_ARG 1017 - Mandatory QMI TLV not provided

eQCWWAN_ERR_QMI_ARG_TOO_LONG 1019 - Arg passed in QMI TLV larger than available storage in device

eQCWWAN_ERR_QMI_INVALID_TX_ID 1022 - Invalid TX ID specified

eQCWWAN_ERR_QMI_DEVICE_IN_USE 1023 - Device currently in a call

eQCWWAN_ERR_QMI_OP_NETWORK_UNSUPPORTED 1024 - The selected operation is not supported by the network

eQCWWAN_ERR_QMI_OP_DEVICE_UNSUPPORTED 1025 - The selected operation is not supported by the device

eQCWWAN_ERR_QMI_NO_EFFECT 1026 - Requested operation would have no effect

eQCWWAN_ERR_QMI_NO_FREE_PROFILE 1027 - No space for a profile is available

eQCWWAN_ERR_QMI_INVALID_PDP_TYPE 1028 - Invalid PDP type specified

eQCWWAN_ERR_QMI_INVALID_TECH_PREF 1029 - Invalid technology preference specified

eQCWWAN_ERR_QMI_INVALID_PROFILE_TYPE 1030 - Invalid profile type specified

eQCWWAN_ERR_QMI_INVALID_SERVICE_TYPE 1031 - Invalid service type specified

eQCWWAN_ERR_QMI_INVALID_REGISTER_ACTION 1032 - Invalid register action specified

eQCWWAN_ERR_QMI_INVALID_PS_ATTACH_ACTION 1033 - Invalid PS attach/detach action specified

eQCWWAN_ERR_QMI_AUTHENTICATION_FAILED 1034 - Authentication of supplied information element failed

eQCWWAN_ERR_QMI_PIN_BLOCKED 1035 - PIN is blocked; an unblock operation needs to be issued

eQCWWAN_ERR_QMI_PIN_PERM_BLOCKED 1036 - PIN is permanently blocked; the UIM is unusable

eQCWWAN_ERR_QMI_SIM_NOT_INITIALIZED 1037 - UIM initialization has not completed

eQCWWAN_ERR_QMI_MAX_QOS_REQUESTS_IN_USE 1038 - Max QOS requests are used

eQCWWAN_ERR_QMI_INCORRECT_FLOW_FILTER 1039 - The Flow filter is incorrect

eQCWWAN_ERR_QMI_NETWORK_QOS_UNAWARE 1040 - Network unaware of the QOS requested

eQCWWAN_ERR_QMI_INVALID_ID 1041 - Invalid QOS ID

eQCWWAN_ERR_QMI_INVALID_QOS_ID 1041 - Invalid QOS ID

eQCWWAN_ERR_QMI_REQUESTED_NUM_UNSUPPORTED 1042 - The request number is not supported

eQCWWAN_ERR_QMI_INTERFACE_NOT_FOUND 1043 - Unable to find the interface

eQCWWAN_ERR_QMI_FLOW_SUSPENDED 1044- Flow suspended

eQCWWAN_ERR_QMI_INVALID_DATA_FORMAT 1045 - Data format is invalid

eQCWWAN_ERR_QMI_GENERAL 1046 - General error

eQCWWAN_ERR_QMI_UNKNOWN 1047 - Unknown error

eQCWWAN_ERR_QMI_INVALID_ARG 1048 - A specified argument is invalid

eQCWWAN_ERR_QMI_INVALID_INDEX 1049 - A specified index is invalid

eQCWWAN_ERR_QMI_NO_ENTRY 1050 - No information element exists at specified memory designation

eQCWWAN_ERR_QMI_DEVICE_STORAGE_FULL 1051 - The memory storage specified in the request is full

eQCWWAN_ERR_QMI_DEVICE_NOT_READY 1052 - Device not in a ready state

eQCWWAN_ERR_QMI_NETWORK_NOT_READY 1053 - Network not in a ready state

eQCWWAN_ERR_QMI_CAUSE_CODE 1054 - Error provided in SMS cause code

eQCWWAN_ERR_QMI_MESSAGE_NOT_SENT 1055 - The message could not be sent

eQCWWAN_ERR_QMI_MESSAGE_DELIVERY_FAILURE 1056 - The message could not be delivered

eQCWWAN_ERR_QMI_INVALID_MESSAGE_ID 1057 - The message ID specified for the message is invalid

eQCWWAN_ERR_QMI_ENCODING 1058 - The message is not encoded properly

eQCWWAN_ERR_QMI_AUTHENTICATION_LOCK 1059 - Maximum number of authentication failures has been reached

eQCWWAN_ERR_QMI_INVALID_TRANSITION 1060 - Operating mode transition from the current mode is invalid

eQCWWAN_ERR_QMI_NOT_A_MCAST_IFACE 1061 - The intercace is not muticast

eQCWWAN_ERR_QMI_MAX_MCAST_REQUESTS_IN_USE 1062 - Maximum requests in use

eQCWWAN_ERR_QMI_INVALID_MCAST_HANDLE 1063 - Invalid muticast handle

eQCWWAN_ERR_QMI_INVALID_IP_FAMILY_PREF 1064 - Invalid IP family preference

eQCWWAN_ERR_QMI_SESSION_INACTIVE 1065 - No tracking session has been started

eQCWWAN_ERR_QMI_SESSION_INVALID 1066 - Current session does not allow this operation

eQCWWAN_ERR_QMI_SESSION_OWNERSHIP 1067 - Current tracking session not started by this QMI control point

eQCWWAN_ERR_QMI_INSUFFICIENT_RESOURCES 1068 - Device GPS service resources insufficient for request

eQCWWAN_ERR_QMI_DISABLED 1069 - Device GPS service disabled

eQCWWAN_ERR_QMI_INVALID_OPERATION 1070 - Invalid operation specified

eQCWWAN_ERR_QMI_INVALID_QMI_CMD 1071 - Invalid/unknown QMI command specified

eQCWWAN_ERR_QMI_TPDU_TYPE 1072 - Message contains TPDU type that cannot be read as raw message

eQCWWAN_ERR_QMI_SMSC_ADDR 1073 - The SMSC address specified is invalid

eQCWWAN_ERR_QMI_INFO_UNAVAILABLE 1074 - Information element is unavailable at this point

eQCWWAN_ERR_QMI_SEGMENT_TOO_LONG 1075 - Segment size too large

eQCWWAN_ERR_QMI_SEGMENT_ORDER 1076 - Segment order is incorrect

eQCWWAN_ERR_QMI_BUNDLING_NOT_SUPPORTED 1077 - Bundling not supported

eQCWWAN_ERR_QMI_OP_PARTIAL_FAILURE 1078 - The operation failed partially

eQCWWAN_ERR_QMI_POLICY_MISMATCH 1079 - Policy mismatch

eQCWWAN_ERR_QMI_SIM_FILE_NOT_FOUND 1080 - SIM file not found

eQCWWAN_ERR_QMI_EXTENDED_INTERNAL 1081 - Extended internal error

eQCWWAN_ERR_QMI_ACCESS_DENIED 1082 - Access to a required entity is not available

eQCWWAN_ERR_QMI_HARDWARE_RESTRICTED 1083 - Selected operating mode is invalid with current hardware setting

eQCWWAN_ERR_QMI_ACK_NOT_SENT 1084 - ACK not sent

eQCWWAN_ERR_QMI_INJECT_TIMEOUT 1084 - Inject a timeout for the request

eQCWWAN_ERR_QMI_INCOMPATIBLE_STATE 1090 - Incompatible state

eQCWWAN_ERR_QMI_FDN_RESTRICT 1091 - FDN Restrict

eQCWWAN_ERR_QMI_SUPS_FAILURE_CAUSE 1092 - SUPS failure cause

eQCWWAN_ERR_QMI_NO_RADIO 1093 - No Radio

eQCWWAN_ERR_QMI_NOT_SUPPORTED 1094 - Not Supported

eQCWWAN_ERR_QMI_NO_SUBSCRIPTION 1095 - No Subscription

eQCWWAN_ERR_QMI_CARD_CALL_CONTROL_FAILED 1096 - Card call control failed

eQCWWAN_ERR_QMI_NETWORK_ABORTED 1097 - Network Aborted

eQCWWAN_ERR_QMI_MSG_BLOCKED 1098 - Open Error

eQCWWAN_ERR_QMI_MAX Error - End of QMI specific defines

eQCWWAN_ERR_SWICM_START **Vendor defines - Connection Manager error codes**

eQCWWAN_ERR_SWICM_NOT_IMPLEMENTED 0xE001 - The API is yet to be implemented

eQCWWAN_ERR_SWICM_QMI_SVC_NOT_SUPPORTED 0xE002 - The service is not supported

eQCWWAN_ERR_SWICM_QMI_CLNT_NOT_SUPPORTED 0xE003 - The client is not supported

eQCWWAN_ERR_SWICM_TIMEOUT 0xE004 - API Timeout

eQCWWAN_ERR_SWICM_SOCKET_IN_USE 0xE005 - The communication socket is in use

eQCWWAN_ERR_SWICM_AM_VERS_ERROR 0xE006 - SLQS API and SDK version mismatch

eQCWWAN_ERR_SWICM_FAILED_TO_KILL_SDK_PROCESS 0xE007 - Failed to kill SDK process

eQCWWAN_ERR_SWICM_CALL_IN_PROGRESS 0xE008 - Call in progress

eQCWWAN_ERR_SWICM_V4DWN_V6DWN 0xE009 - IPV4 and IPV6 is down

eQCWWAN_ERR_SWICM_V4DWN_V6UP 0xE00A - IPV4 is down and IPV6 is up

eQCWWAN_ERR_SWICM_V4UP_V6DWN 0xE00B - IPV4 is up and IPV6 is down

eQCWWAN_ERR_SWICM_V4UP_V6UP 0xE00C - IPV4 and IPV6 is up

eQCWWAN_ERR_SWICM_INVALID_SESSION_ID 0xE00D - Invalid V4 Session ID

eQCWWAN_ERR_SWICM_INVALID_V4_SESSION_ID 0xE00E - Invalid V4 Session ID

eQCWWAN_ERR_SWICM_INVALID_V6_SESSION_ID 0xE00F - Invalid V6 Session ID

eQCWWAN_ERR_SWICM_SM_NO_AVAILABLE_SESSIONS 0xE010 - No available Session Manager slots for additional data sessions

eQCWWAN_ERR_SWICM_END 0xE011 - End of connection manager specific codes

eQCWWAN_ERR_SWISMS_START **Vendor defines - SMS Error codes**

eQCWWAN_ERR_SWISMS_MSG_LEN_TOO_LONG 0xE101 - SMS message length is long

eQCWWAN_ERR_SWISMS_MSG_CORRUPTED 0xE102 - The SMS message is corrupted (encoding wrong)

eQCWWAN_ERR_SWISMS_SMSC_NUM_CORRUPTED 0xE103 - The SMS number is corrupted (incorrect number)

eQCWWAN_ERR_SWISMS_BEARER_DATA_NOT_FOUND 0xE104 - The SMS bearer data is not available

eQCWWAN_ERR_SWISM_END

eQCWWAN_ERR_SWIIM_START **Vendor defines - Image Management error codes**

eQCWWAN_ERR_SWIIM_INVALID_PATH 0xE801 - Invalid directory path

eQCWWAN_ERR_SWIIM_OPENING_DIR 0xE802 - Unable to open the directory

eQCWWAN_ERR_SWIIM_FILE_NOT_FOUND 0xE803 - No Firmware image present in the path

eQCWWAN_ERR_SWIIM_OPENING_FILE 0xE804 - Unable to open the file

eQCWWAN_ERR_SWIIM_CORRUPTED_FW_IMAGE 0xE805 - Firmware image is corrupted

eQCWWAN_ERR_SWIIM_FIRMWARE_NOT_DOWNLOADED 0xE806 - No Firmware image download needed

eQCWWAN_ERR_SWIIM_FW_UPDATE_FAIL 0xE807 - Firmware update failed

eQCWWAN_ERR_SWIIM_FW_PREFERENCE_MISMATCH 0xE808 - Update success but pri/fw preference mismatch

eQCWWAN_ERR_SWIIM_FW_UPDATE_SUCCESS 0xE809 - Update successful

eQCWWAN_ERR_SWIIM_FW_ENTER_DOWNLOAD_MODE 0xE80A - Enter Download Mode

eQCWWAN_ERR_SWIIM_FW_FLASH_COMPLETE 0xE80B - File transfer to modem complete

eQCWWAN_ERR_SWIIM_FW_WAIT_FOR_REBOOT 0xE80C - Wait for modem to reboot

eQCWWAN_ERR_SWIIM_INVALID_CRASH_STATE 0xE80D - Invalid Crash State for Firmware Download

eQCWWAN_ERR_SWIIM_FW_SAME_AS_CURRENT_ACTIVE_IMAGE 0xE80E - Same as current active image

eQCWWAN_ERR_SWIIM_FW_INVALID_SLOT_INDEX 0xE80F - invalid slot index

eQCWWAN_ERR_SWIIM_END

eQCWWAN_ERR_SWIDCS_START **Vendor defines - Device Connectivity error codes**

eQCWWAN_ERR_SWIDCS_IOCTL_ERR 0xE901 - IO Control error

eQCWWAN_ERR_SWIDCS_FILEIO_ERR 0xE902 - file open/read/write error

eQCWWAN_ERR_SWIDCS_DEVNODE_NOT_FOUND 0xE903 - The device is not found

eQCWWAN_ERR_SWIDCS_APP_DISCONNECTED 0xE904 - Application is disconnected from SDK

eQCWWAN_ERR_SWIDCS_END

eQCWWAN_ERR_QMI_CAT_START **QMI errors related to CAT**

eQCWWAN_ERR_QMI_EVENT_REG_FAILED 62441 - CAT event registration failed

eQCWWAN_ERR_QMI_INVALID_TERMINAL_RSP 62442 - Invalid terminal response

eQCWWAN_ERR_QMI_INVALID_ENVELOPE_CMD 62443 - Invalid envelope command

eQCWWAN_ERR_QMI_CARD_BUSY_RSP 62444 - Card busy response for envelope command

eQCWWAN_ERR_QMI_ENVELOPE_CMD_FAILURE 62445 - Envelope command failure

eQCWWAN_ERR_QMI_CAT_END

eQCWWAN_ERR_NULL_TLV

eQCWWAN_ERR_QMI_WIDTH 0xFFFF - Not an error, represent the end of QMI errors

9.28.1.2 enum qm_wds_ds_profile_extended_err_codes

WDS DS profile extented error codes

Enumerator

eWDS_ERR_PROFILE_REG_RESULT_FAIL 1 - General Failure

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_HNDL 2 - The request contains an invalid profile handle

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_OP 3 - An invalid operation was requested.

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_TYPE 4 - The request contains an invalid technology type

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_NUM 5 - The request contains an invalid profile number

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_IDENT 6 - The request contains an invalid profile identifier

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL 7 - The request contains an invalid argument other than profile number and profile identifier received.

eWDS_ERR_PROFILE_REG_RESULT_ERR_LIB_NOT_INITED 8 - Profile registry has not been initialized yet

eWDS_ERR_PROFILE_REG_RESULT_ERR_LEN_INVALID 9 - The request contains a parameter with invalid length.

eWDS_ERR_PROFILE_REG_RESULT_LIST_END 10 - End of the profile list was reached while searching for the requested profile.

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_SUBS_ID 11 - The request contains an invalid subscrition identifier.

eWDS_ERR_PROFILE_REG_INVAL_PROFILE_FAMILY 12 - The request contains an invalid profile family.

eWDS_ERR_PROFILE_REG_3GPP_INVAL_PROFILE_FAMILY 1001 - The request contains an invalid 3GPP profile family.

eWDS_ERR_PROFILE_REG_3GPP_ACCESS_ERR 1002 - An error was encountered while accessing the 3GPP profiles.

eWDS_ERR_PROFILE_REG_3GPP_CONTEXT_NOT_DEFINED 1003 - The given 3GPP profile doesn't have a valid context.

eWDS_ERR_PROFILE_REG_3GPP_VALID_FLAG_NOT_SET 1004 - The given 3GPP profile is marked invalid.

eWDS_ERR_PROFILE_REG_3GPP_READ_ONLY_FLAG_SET 1005 - The given 3GPP profile is marked read-only.

eWDS_ERR_PROFILE_REG_3GPP_ERR_OUT_OF_PROFILES 1006 - Creation of a new 3GPP profile failed because the limit of 16 profiles has already been reached.

eWDS_ERR_PROFILE_REG_3GPP2_ERR_INVALID_IDENT_FOR_PROFILE 1101 - An invalid profile identifier was received as part of the 3GPP2 profile modification request.

eWDS_ERR_PROFILE_REG_END

9.29 qos.h File Reference

Data Structures

- struct unpack_qos_SLQSQosGetNetworkStatus_t
- struct pack_qos_SLQSQosSwiReadApnExtraParams_t
- struct unpack_qos_SLQSQosSwiReadApnExtraParams_t

- struct pack_qos_SLQSQosSwiReadDataStats_t
- struct unpack_QosFlowStat_t
- struct unpack_qos_SLQSQosSwiReadDataStats_t
- struct unpack_qos_SLQSSetQosNWStatusCallback_ind_t
- struct unpack_qos_SLQSSetQosStatusCallback_ind_t
- struct unpack_qos_SLQSSetQosPriEventCallback_ind_t
- struct pack_qos_SLQSSetQosEventCallback_t
- struct unpack_qos_QosFlowInfoState_t
- struct unpack_qos_dataRate_t
- struct unpack_qos_tokenBucket_t
- struct unpack_qos_pktErrRate_t
- struct unpack_qos_swiQosFlow_t
- struct unpack_qos_IPv4Addr_t
- struct unpack_qos_Tos_t
- struct unpack_qos_IPv6Addr_t
- struct unpack_qos_IPv6TrafCls_t
- struct unpack_qos_Port_t
- struct unpack_qos_swiQosFilter_t
- struct unpack_qos_QosFlowInfo_t
- struct unpack_qos_SLQSSetQosEventCallback_ind_t
- struct qos_BindDataPortPeripheralEndPointID_t
- struct qos_BindDataPortMuxID_t
- struct qos_BindDataPortSIODataPort_t
- struct pack_qos_BindDataPort_t

Macros

- #define LITEQMI_MAX_QOS_FLOW_PER_APN_STATS 10
- #define LITEQMI_MAX_QOS_FILTERS 25
- #define LITEQMI_MAX_QOS_FLOWS 8

Functions

- int pack_qos_SLQSQosGetNetworkStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_qos_SLQSQosGetNetworkStatus (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSQosGetNetworkStatus_t *pOutput)
- int pack_qos_SLQSQosSwiReadApnExtraParams (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_qos_SLQSQosSwiReadApnExtraParams_t reqParam)
- int unpack_qos_SLQSQosSwiReadApnExtraParams (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSQosSwiReadApnExtraParams_t *pOutput)
- int pack_qos_SLQSQosSwiReadDataStats (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_qos_SLQSQosSwiReadDataStats_t reqParam)
- int unpack_qos_SLQSQosSwiReadDataStats (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSQosSwiReadDataStats_t *pOutput)
- int unpack_qos_SLQSSetQosNWStatusCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSSetQosNWStatusCallback_ind_t *pOutput)
- int unpack_qos_SLQSSetQosStatusCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSSetQosStatusCallback_ind_t *pOutput)
- int unpack_qos_SLQSSetQosPriEventCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSSetQosPriEventCallback_ind_t *pOutput)
- int pack_qos_SLQSSetQosEventCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_qos_SLQSSetQosEventCallback_t reqParam)
- int unpack_qos_SLQSSetQosEventCallback (uint8_t *pResp, uint16_t respLen)

- int unpack_qos_SLQSSetQosEventCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSSetQosEventCallback_ind_t *pOutput)
- int pack_qos_BindDataPort (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_qos_BindDataPort_t req)
- int unpack_qos_BindDataPort (uint8_t *pResp, uint16_t respLen)

9.29.1 Macro Definition Documentation

9.29.1.1 #define LITEQMI_MAX_QOS_FILTERS 25

9.29.1.2 #define LITEQMI_MAX_QOS_FLOW_PER_APN_STATS 10

9.29.1.3 #define LITEQMI_MAX_QOS_FLOWS 8

9.29.2 Function Documentation

9.29.2.1 int pack_qos_BindDataPort (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_qos_BindDataPort_t *req*)

Function to pack command to Binds a control point to a data port. This maps to PkQmiQosBindDataPort

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Timeout: 2 seconds

9.29.2.2 int pack_qos_SLQSQosGetNetworkStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack command to retrieve QoS status of the network. This maps to SLQSQosGetNetworkStatus

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Timeout: 2 seconds
- Technology Supported: CDMA
- PDN Specific: No

9.29.2.3 int pack_qos_SLQSQosSwiReadApnExtraParams (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_qos_SLQSQosSwiReadApnExtraParams_t *reqParam*)

Function to pack QMI command to query extra APN parameters This maps to SLQSQosSwiReadApnExtraParams

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_qos_SLQSQosSwiReadApnExtraParams_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Timeout: 2 seconds
  - PDN Specific: Yes

9.29.2.4 int pack_qos_SLQSQosSwiReadDataStats (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_qos_SLQSQosSwiReadDataStats_t *reqParam*)

Function to pack QMI command to query APN data statistics This maps to SLQSQosSwiReadDataStats

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_qos_SLQSQosSwiReadDataStats_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Timeout: 2 seconds
  - PDN Specific: Yes

9.29.2.5 int pack_qos_SLQSSetQosEventCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_qos_SLQSSetQosEventCallback_t *reqParam*)

Function to pack QMI command to enable QoS event indications This maps to SLQSSetQosEventCallback

Parameters

out	*pCtx*	• See pack_qmi_t for more information

in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_qos_SLQSSetQosEventCallback_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Timeout: 2 seconds
  - PDN Specific: Yes

9.29.2.6 int unpack_qos_BindDataPort (uint8_t * *pResp*, uint16_t *respLen*)

Function to unpack the response to Binds a control point to a data port. This maps to UpkQmiQosBindDataPort

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.29.2.7 int unpack_qos_SLQSQosGetNetworkStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSQosGetNetworkStatus_t * *pOutput*)

Function to unpack the response to get NW QoS status command This maps to SLQSQosGetNetworkStatus

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSQosGetNetworkStatus_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.29.2.8 int unpack_qos_SLQSQosSwiReadApnExtraParams (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSQosSwiReadApnExtraParams_t * *pOutput*)

Function to unpack the response to get NW QoS status command This maps to SLQSQosSwiReadApnExtraParams

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSQosSwiReadApnExtraParams_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.29.2.9 int unpack_qos_SLQSQosSwiReadDataStats (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSQosSwiReadDataStats_t * *pOutput*)

Function to unpack APN data statistics response This maps to SLQSQosSwiReadDataStats

Parameters

in	*pResp*	• Response from modem

in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSQosSwiReadDataStats_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.29.2.10 int unpack_qos_SLQSSetQosEventCallback (uint8_t * *pResp*, uint16_t *respLen*)

Function to unpack enable QoS event indications command's response This maps to SLQSSetQosEventCallback

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.29.2.11 int unpack_qos_SLQSSetQosEventCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSSetQosEventCallback_ind_t * *pOutput*)

Function to unpack QoS event indications This maps to SLQSSetQosEventCallback

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSSetQosEventCallback_ind_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- This is a broadcast notification that is sent to the registered QoS service
- No explicit function to register for this indication is needed
- Please use eQMI_QOS_NETWORK_STATUS_IND indication to identify this event from QOS service read function

9.29.2.12 int unpack_qos_SLQSSetQosNWStatusCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, **unpack_qos_SLQSSetQosNWStatusCallback_ind_t** * *pOutput*)

Function to unpack QoS NW status indication. This maps to SLQSSetQosNWStatusCallback

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSSetQosNWStatusCallback_ind_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Technology Supported: CDMA
- This is a broadcast notification that is sent to the registered QoS service
- No explicit function to register for this indication is needed
- Please use eQMI_QOS_NETWORK_STATUS_IND indication to identify this event from QOS service read function

9.29.2.13 int unpack_qos_SLQSSetQosPriEventCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, **unpack_qos_SLQSSetQosPriEventCallback_ind_t** * *pOutput*)

Function to unpack QoS primary flow events. This maps to SLQSSetQosPriEventCallback

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSSetQosPriEventCallback_ind_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- This is a broadcast notification that is sent to the registered QoS service
- No explicit function to register for this indication is needed
- Please use eQMI_QOS_PRIMARY_QOS_EVENT_IND indication to identify this event from QOS service read function
- This is only generated when the primary flow is modified by the host

9.29.2.14 int unpack_qos_SLQSSetQosStatusCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSSetQosStatusCallback_ind_t * *pOutput*)

Function to unpack QoS status indications. This maps to SLQSSetQosStatusCallback

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSSetQosStatusCallback_ind_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- This is a broadcast notification that is sent to the registered QoS service
- No explicit function to register for this indication is needed
- Please use eQMI_QOS_FLOW_STATUS_IND indication to identify this event from QOS service read function

9.30 rms.h File Reference

Data Structures

- struct unpack_rms_GetSMSWake_t
- struct pack_rms_SetSMSWake_t

Functions

- int pack_rms_GetSMSWake (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_rms_GetSMSWake (uint8_t *pResp, uint16_t respLen, unpack_rms_GetSMSWake_t *pOutput)
- int pack_rms_SetSMSWake (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_rms_SetSMSWake_t *reqArg)
- int unpack_rms_SetSMSWake (uint8_t *pResp, uint16_t respLen)

9.30.1 Function Documentation

9.30.1.1 int pack_rms_GetSMSWake (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen*)

Get SMS Wake pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.30.1.2 int pack_rms_SetSMSWake (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen,* pack_rms_SetSMSWake_t * *reqArg*)

Set SMS Wake pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.30.1.3 int unpack_rms_GetSMSWake (uint8_t * *pResp*, uint16_t *respLen*, unpack_rms_GetSMSWake_t * *pOutput*)

Get SMS Wake unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.30.1.4 int unpack_rms_SetSMSWake (uint8_t * *pResp*, uint16_t *respLen*)

Set SMS Wake unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.31 sar.h File Reference

Data Structures

- struct unpack_sar_SLQSGetRfSarState_t
- struct pack_sar_SLQSSetRfSarState_t

Functions

- int pack_sar_SLQSGetRfSarState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)

- int unpack_sar_SLQSGetRfSarState (uint8_t *pResp, uint16_t respLen, unpack_sar_SLQSGetRfSarState_t *pOutput)
- int pack_sar_SLQSSetRfSarState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sar_SLQSSetRfSarState_t *reqArg)
- int unpack_sar_SLQSSetRfSarState (uint8_t *pResp, uint16_t respLen)

9.31.1 Function Documentation

9.31.1.1 int pack_sar_SLQSGetRfSarState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the specified RF SAR state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.31.1.2 int pack_sar_SLQSSetRfSarState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sar_SLQSSetRfSarState_t * *reqArg*)

Sets the specified RF SAR state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.31.1.3 int unpack_sar_SLQSGetRfSarState (uint8_t * *pResp*, uint16_t *respLen*, unpack_sar_SLQSGetRfSarState_t * *pOutput*)

Gets the specified RF SAR state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.31.1.4 int unpack_sar_SLQSSetRfSarState (uint8_t * *pResp*, uint16_t *respLen*)

Sets the specified RF SAR state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32 sms.h File Reference

Data Structures

- struct pack_sms_SLQSGetSMS_t
- struct unpack_sms_SLQSGetSMS_t
- struct pack_sms_SLQSGetSMSList_t
- struct qmiSmsMessageList
- struct unpack_sms_SLQSGetSMSList_t
- struct pack_sms_SLQSModifySMSStatus_t
- struct unpack_sms_SLQSModifySMSStatus_t
- struct pack_sms_SLQSDeleteSMS_t
- struct unpack_sms_SLQSDeleteSMS_t
- struct pack_sms_SendSMS_t
- struct unpack_sms_SendSMS_t
- struct pack_sms_SetNewSMSCallback_t
- struct unpack_sms_SetNewSMSCallback_t
- struct sMSMTMessageInfo
- struct newMTMessageTlv
- struct sMSTransferRouteMTMessageInfo
- struct transferRouteMessageTlv
- struct sMSMessageModeInfo
- struct messageModeTlv
- struct sMSEtwsMessageInfo
- struct sMSEtwsMessageTlv
- struct sMSEtwsPlmnInfo
- struct eTWSPLMNInfoTlv
- struct sMSCAddressInfo
- struct sMSCAddressTlv

- struct sMSOnIMSInfo
- struct sMSOnIMSTlv
- struct unpack_sms_SetNewSMSCallback_ind_t
- struct unpack_sms_SLQSWmsMemoryFullCallBack_ind_t
- struct unpack_sms_GetSMSCAddress_t
- struct pack_sms_SetSMSCAddress_t
- struct pack_sms_SaveSMS_t
- struct unpack_sms_SaveSMS_t
- struct sms_BroadcastConfig
- struct sms_qaQmi3GPPBroadcastCfgInfo
- struct sms_CDMABroadcastConfig
- struct sms_qaQmi3GPP2BroadcastCfgInfo
- struct unpack_sms_SLQSGetSmsBroadcastConfig_t
- struct pack_sms_SLQSGetSmsBroadcastConfig_t
- struct pack_sms_SLQSSetSmsBroadcastConfig_t
- struct pack_sms_SLQSSetSmsBroadcastActivation_t
- struct sms_transLayerInfo
- struct sms_getTransLayerInfo
- struct unpack_sms_SLQSGetTransLayerInfo_t
- struct sms_getTransNWRegInfo
- struct unpack_sms_SLQSGetTransNWRegInfo_t
- struct sms_getIndicationReg
- struct unpack_sms_SLQSGetIndicationRegister_t
- struct sms_setIndicationReg
- struct pack_sms_SLQSSetIndicationRegister_t
- struct sms_routeEntry
- struct sms_setRoutesReq
- struct pack_sms_SLQSSmsSetRoutes_t
- struct sms_msgProtocolResp
- struct unpack_sms_SLQSSmsGetMessageProtocol_t
- struct sms_maxStorageSizeReq
- struct sms_maxStorageSizeResp
- struct pack_sms_SLQSSmsGetMaxStorageSize_t
- struct unpack_sms_SLQSSmsGetMaxStorageSize_t
- struct sms_messageWaitingInfoContent
- struct sms_getMsgWaitingInfo
- struct unpack_sms_SLQSGetMessageWaiting_t
- struct sms_sendAsyncsmsParams
- struct pack_sms_SLQSSendAsyncSMS_t
- struct pack_sms_SLQSSetSmsStorage_t
- struct unpack_sms_SLQSSwiGetSMSStorage_t

Macros

- #define MAX_SMS_MESSAGE_SIZE 2048
- #define MAX_SMS_LIST_SIZE 255
- #define MAX_MS_TRANSFER_ROUTE_MSG 256
- #define MAX_MSE_TWS_MSG 1254
- #define MAX_MSC_ADDRESS_SIZE 256
- #define MAX_CDMA_ENC_MO_TXT_MSG_SIZE 255
- #define SMSC_TYPE_LEN 0x03
- #define SMS_CONFIG_LEN 0x05
- #define SMS_MAX_SMS_ROUTES 0x0A
- #define SMS_NUM_OF_SET 0xFF

Enumerations

- enum eqmiCbkSetStatus {
  LITEQMI_QMI_CBK_PARAM_RESET = 0,
  LITEQMI_QMI_CBK_PARAM_SET = 1,
  LITEQMI_QMI_CBK_PARAM_NOCHANGE }

Functions

- int pack_sms_SLQSGetSMS (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSGetSMS_t *reqParam)
- int unpack_sms_SLQSGetSMS (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetSMS_t *pOutput)
- int pack_sms_SLQSGetSMSList (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSGetSMSList_t *reqParam)
- int unpack_sms_SLQSGetSMSList (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetSMSList_t *pOutput)
- int pack_sms_SLQSModifySMSStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSModifySMSStatus_t *reqParam)
- int unpack_sms_SLQSModifySMSStatus (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSModifySMSStatus_t *pOutput)
- int pack_sms_SLQSDeleteSMS (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSDeleteSMS_t *reqParam)
- int unpack_sms_SLQSDeleteSMS (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSDeleteSMS_t *pOutput)
- int pack_sms_SendSMS (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SendSMS_t *reqParam)
- int unpack_sms_SendSMS (uint8_t *pResp, uint16_t respLen, unpack_sms_SendSMS_t *pOutput)
- int pack_sms_SetNewSMSCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SetNewSMSCallback_t reqParam)
- int unpack_sms_SetNewSMSCallback (uint8_t *pResp, uint16_t respLen, unpack_sms_SetNewSMSCallback_t *Output)
- int unpack_sms_SetNewSMSCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_sms_SetNewSMSCallback_ind_t *pOutput)
- int unpack_sms_SLQSWmsMemoryFullCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSWmsMemoryFullCallBack_ind_t *pOutput)
- int pack_sms_GetSMSCAddress (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_GetSMSCAddress (uint8_t *pResp, uint16_t respLen, unpack_sms_GetSMSCAddress_t *pOutput)
- int pack_sms_SetSMSCAddress (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SetSMSCAddress_t *reqParam)
- int unpack_sms_SetSMSCAddress (uint8_t *pResp, uint16_t respLen)
- int pack_sms_SaveSMS (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SaveSMS_t *reqParam)
- int unpack_sms_SaveSMS (uint8_t *pResp, uint16_t respLen, unpack_sms_SaveSMS_t *pOutput)
- int pack_sms_SLQSGetSmsBroadcastConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSGetSmsBroadcastConfig_t *reqParam)
- int unpack_sms_SLQSGetSmsBroadcastConfig (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetSmsBroadcastConfig_t *pOutput)
- int pack_sms_SLQSSetSmsBroadcastConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSetSmsBroadcastConfig_t *reqParam)
- int unpack_sms_SLQSSetSmsBroadcastConfig (uint8_t *pResp, uint16_t respLen)
- int pack_sms_SLQSSetSmsBroadcastActivation (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSetSmsBroadcastActivation_t *reqParam)
- int unpack_sms_SLQSSetSmsBroadcastActivation (uint8_t *pResp, uint16_t respLen)
- int pack_sms_SLQSGetTransLayerInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)

- int unpack_sms_SLQSGetTransLayerInfo (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetTransLayerInfo_t *pOutput)
- int pack_sms_SLQSGetTransNWRegInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_SLQSGetTransNWRegInfo (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetTransNWRegInfo_t *pOutput)
- int pack_sms_SLQSGetIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_SLQSGetIndicationRegister (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetIndicationRegister_t *pOutput)
- int pack_sms_SLQSSetIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSetIndicationRegister_t *reqParam)
- int unpack_sms_SLQSSetIndicationRegister (uint8_t *pResp, uint16_t respLen)
- int pack_sms_SLQSSmsSetRoutes (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSmsSetRoutes_t *reqParam)
- int unpack_sms_SLQSSmsSetRoutes (uint8_t *pResp, uint16_t respLen)
- int pack_sms_SLQSSmsGetMessageProtocol (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_SLQSSmsGetMessageProtocol (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSmsGetMessageProtocol_t *pOutput)
- int pack_sms_SLQSSmsGetMaxStorageSize (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSmsGetMaxStorageSize_t *reqParam)
- int unpack_sms_SLQSSmsGetMaxStorageSize (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSmsGetMaxStorageSize_t *pOutput)
- int pack_sms_SLQSGetMessageWaiting (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_SLQSGetMessageWaiting (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetMessageWaiting_t *pOutput)
- int pack_sms_SLQSSendAsyncSMS (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSendAsyncSMS_t *reqParam)
- int unpack_sms_SLQSSendAsyncSMS (uint8_t *pResp, uint16_t respLen)
- int pack_sms_SLQSSetSmsStorage (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSetSmsStorage_t *reqParam)
- int unpack_sms_SLQSSetSmsStorage (uint8_t *pResp, uint16_t respLen)
- int pack_sms_SLQSSwiGetSMSStorage (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_SLQSSwiGetSMSStorage (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSwiGetSMSStorage_t *pOutput)

9.32.1 Macro Definition Documentation

9.32.1.1 #define MAX_CDMA_ENC_MO_TXT_MSG_SIZE 255

9.32.1.2 #define MAX_MS_TRANSFER_ROUTE_MSG 256

9.32.1.3 #define MAX_MSC_ADDRESS_SIZE 256

9.32.1.4 #define MAX_MSE_TWS_MSG 1254

9.32.1.5 #define MAX_SMS_LIST_SIZE 255

9.32.1.6 #define MAX_SMS_MESSAGE_SIZE 2048

9.32.1.7 #define SMS_CONFIG_LEN 0x05

9.32.1.8 #define SMS_MAX_SMS_ROUTES 0x0A

9.32.1.9 #define SMS_NUM_OF_SET 0xFF

9.32.1.10 #define SMSC_TYPE_LEN 0x03

9.32.2 Enumeration Type Documentation

9.32.2.1 enum eqmiCbkSetStatus

Enumerator

LITEQMI_QMI_CBK_PARAM_RESET

LITEQMI_QMI_CBK_PARAM_SET

LITEQMI_QMI_CBK_PARAM_NOCHANGE

9.32.3 Function Documentation

9.32.3.1 int pack_sms_GetSMSCAddress (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the SMS center address pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.2 int pack_sms_SaveSMS (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SaveSMS_t * *reqParam*)

Saves an SMS message to device memory pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.3 int pack_sms_SendSMS (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SendSMS_t * *reqParam*)

send sms list pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.4 int pack_sms_SetNewSMSCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SetNewSMSCallback_t *reqParam*)

set new sms callback pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.5 int pack_sms_SetSMSCAddress (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SetSMSCAddress_t * *reqParam*)

Set the SMS center address pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.6 int pack_sms_SLQSDeleteSMS (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSDeleteSMS_t * *reqParam*)

delete sms pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.7 int pack_sms_SLQSGetIndicationRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets registration state of different WMS indications pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.8 int pack_sms_SLQSGetMessageWaiting (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the message waiting information pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.9 int pack_sms_SLQSGetSMS (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSGetSMS_t * *reqParam*)

get sms pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.10 int pack_sms_SLQSGetSmsBroadcastConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSGetSmsBroadcastConfig_t * *reqParam*)

Provides Information about the SMS BroadcastConfiguration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.11 int pack_sms_SLQSGetSMSList (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSGetSMSList_t * *reqParam*)

get sms list pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.12 int pack_sms_SLQSGetTransLayerInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets information about the transport layer pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.13 int pack_sms_SLQSGetTransNWRegInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets transport layer network registration info pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.14 int pack_sms_SLQSModifySMSStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSModifySMSStatus_t * *reqParam*)

modify sms status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.15 int pack_sms_SLQSSendAsyncSMS (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSendAsyncSMS_t * *reqParam*)

Sends an SMS message for immediate over-the-air transmission pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.16 int pack_sms_SLQSSetIndicationRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSetIndicationRegister_t * *reqParam*)

Sets the registration state of different WMS indications pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.17 int pack_sms_SLQSSetSmsBroadcastActivation (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSetSmsBroadcastActivation_t * *reqParam*)

Enables or disables the reception of broadcast SMS messages pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.18 int pack_sms_SLQSSetSmsBroadcastConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSetSmsBroadcastConfig_t * *reqParam*)

Sets the information about the SMS BroadcastConfiguration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.19 int pack_sms_SLQSSetSmsStorage (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSetSmsStorage_t * *reqParam*)

Sets the SMS Storage on the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.20 int pack_sms_SLQSSmsGetMaxStorageSize (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_sms_SLQSSmsGetMaxStorageSize_t * reqParam)

Get the maximum number of messages that can be stored in the specified memory storage. Also it provides the number of slots currently available pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.21 int pack_sms_SLQSSmsGetMessageProtocol (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Gets the message protocol currently in use for the WMS client pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.22 int pack_sms_SLQSSmsSetRoutes (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_sms_SLQSSmsSetRoutes_t * reqParam)

Sets the action performed on SMS message receipt for specified message routes. It also specifies the action performed on SMS receipt of status reports pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.23 int pack_sms_SLQSSwiGetSMSStorage (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the current SMS configuration that is applied to all incoming and outgoing messages pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.24 int unpack_sms_GetSMSCAddress (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_GetSMSCAddress_t * *pOutput*)

Gets the SMS center address unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.25 int unpack_sms_SaveSMS (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SaveSMS_t * *pOutput*)

Saves an SMS message to device memory unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.26 int unpack_sms_SendSMS (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SendSMS_t * *pOutput*)

send sms unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.27 int unpack_sms_SetNewSMSCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SetNewSMS-Callback_t * *Output*)

set new sms callback unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*Output*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.28 int unpack_sms_SetNewSMSCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SetNewSMSCallback_ind_t * *pOutput*)

set new sms callback indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.29 int unpack_sms_SetSMSCAddress (uint8_t * *pResp*, uint16_t *respLen*)

Set the SMS center address unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.30 int unpack_sms_SLQSDeleteSMS (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSDeleteSMS_t * *pOutput*)

delete sms unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.31 int unpack_sms_SLQSGetIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetIndicationRegister_t * *pOutput*)

Gets registration state of different WMS indications unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.32 int unpack_sms_SLQSGetMessageWaiting (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetMessageWaiting_t * *pOutput*)

Gets the message waiting information unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.33 int unpack_sms_SLQSGetSMS (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetSMS_t * *pOutput*)

get sms unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.34 int unpack_sms_SLQSGetSmsBroadcastConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetSmsBroadcastConfig_t * *pOutput*)

Provides Information about the SMS BroadcastConfiguration unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.35 int unpack_sms_SLQSGetSMSList (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetSMSList_t * *pOutput*)

get sms list unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.36 int unpack_sms_SLQSGetTransLayerInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetTransLayerInfo_t * *pOutput*)

Gets information about the transport layer unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.37 int unpack_sms_SLQSGetTransNWRegInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetTransNWRegInfo_t * *pOutput*)

Gets transport layer network registration info unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.38 int unpack_sms_SLQSModifySMSStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSModifySMSStatus_t * *pOutput*)

modify sms status unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.39 int unpack_sms_SLQSSendAsyncSMS (uint8_t * *pResp*, uint16_t *respLen*)

Sends an SMS message for immediate over-the-air transmission unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.40 int unpack_sms_SLQSSetIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*)

Sets the registration state of different WMS indications unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.41 int unpack_sms_SLQSSetSmsBroadcastActivation (uint8_t * *pResp*, uint16_t *respLen*)

Enables or disables the reception of broadcast SMS messages unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.42 int unpack_sms_SLQSSetSmsBroadcastConfig (uint8_t * *pResp*, uint16_t *respLen*)

Sets the information about the SMS BroadcastConfiguration unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.43 int unpack_sms_SLQSSetSmsStorage (uint8_t * *pResp*, uint16_t *respLen*)

Sets the SMS Storage on the device unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.44 int unpack_sms_SLQSSmsGetMaxStorageSize (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSmsGetMaxStorageSize_t * *pOutput*)

Get the maximum number of messages that can be stored in the specified memory storage. Also it provides the number of slots currently available unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.45 int unpack_sms_SLQSSmsGetMessageProtocol (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSmsGetMessageProtocol_t * *pOutput*)

Gets the message protocol currently in use for the WMS client unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.46 int unpack_sms_SLQSSmsSetRoutes (uint8_t * *pResp*, uint16_t *respLen*)

Sets the action performed on SMS message receipt for specified message routes. It also specifies the action performed on SMS receipt of status reports unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.47 int unpack_sms_SLQSSwiGetSMSStorage (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSwiGetSMSStorage_t * *pOutput*)

Gets the current SMS configuration that is applied to all incoming and outgoing messages unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.48 int unpack_sms_SLQSWmsMemoryFullCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSWmsMemoryFullCallBack_ind_t * *pOutput*)

sms full callback indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33 swiaudio.h File Reference

Data Structures

- struct pack_swiaudio_SLQSGetM2MAudioProfile_t
- struct unpack_swiaudio_SLQSGetM2MAudioProfile_t
- struct pack_swiaudio_SLQSSetM2MAudioProfile_t

- struct pack_swiaudio_SLQSGetM2MAudioVolume_t
- struct unpack_swiaudio_SLQSGetM2MAudioVolume_t
- struct pack_swiaudio_SLQSSetM2MAudioVolume_t
- struct swiaudio_PCMparams
- struct pack_swiaudio_SLQSSetM2MAudioAVCFG_t
- struct pack_swiaudio_SLQSSetM2MAudioLPBK_t
- struct pack_swiaudio_SLQSGetM2MSpkrGain_t
- struct unpack_swiaudio_SLQSGetM2MSpkrGain_t
- struct pack_swiaudio_SLQSSetM2MSpkrGain_t
- struct pack_swiaudio_SLQSGetM2MAVMute_t
- struct unpack_swiaudio_SLQSGetM2MAVMute_t
- struct pack_swiaudio_SLQSSetM2MAVMute_t

Macros

- #define SWIAUDIO_MAX_LEN_IFACE_TABLE 255

Functions

- int pack_swiaudio_SLQSGetM2MAudioProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSGetM2MAudioProfile_t *pReqParam)
- int unpack_swiaudio_SLQSGetM2MAudioProfile (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSGetM2MAudioProfile_t *pOutput)
- int pack_swiaudio_SLQSSetM2MAudioProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MAudioProfile_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MAudioProfile (uint8_t *pResp, uint16_t respLen)
- int pack_swiaudio_SLQSGetM2MAudioVolume (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSGetM2MAudioVolume_t *pReqParam)
- int unpack_swiaudio_SLQSGetM2MAudioVolume (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSGetM2MAudioVolume_t *pOutput)
- int pack_swiaudio_SLQSSetM2MAudioVolume (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MAudioVolume_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MAudioVolume (uint8_t *pResp, uint16_t respLen)
- int pack_swiaudio_SLQSSetM2MAudioAVCFG (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MAudioAVCFG_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MAudioAVCFG (uint8_t *pResp, uint16_t respLen)
- int pack_swiaudio_SLQSSetM2MAudioLPBK (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MAudioLPBK_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MAudioLPBK (uint8_t *pResp, uint16_t respLen)
- int pack_swiaudio_SLQSSetM2MAudioNVDef (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swiaudio_SLQSSetM2MAudioNVDef (uint8_t *pResp, uint16_t respLen)
- int pack_swiaudio_SLQSGetM2MSpkrGain (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSGetM2MSpkrGain_t *pReqParam)
- int unpack_swiaudio_SLQSGetM2MSpkrGain (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSGetM2MSpkrGain_t *pOutput)
- int pack_swiaudio_SLQSSetM2MSpkrGain (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MSpkrGain_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MSpkrGain (uint8_t *pResp, uint16_t respLen)
- int pack_swiaudio_SLQSGetM2MAVMute (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSGetM2MAVMute_t *pReqParam)
- int unpack_swiaudio_SLQSGetM2MAVMute (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSGetM2MAVMute_t *pOutput)
- int pack_swiaudio_SLQSSetM2MAVMute (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MAVMute_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MAVMute (uint8_t *pResp, uint16_t respLen)

9.33.1 Macro Definition Documentation

9.33.1.1 #define SWIAUDIO_MAX_LEN_IFACE_TABLE 255

9.33.2 Function Documentation

9.33.2.1 int pack_swiaudio_SLQSGetM2MAudioProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSGetM2MAudioProfile_t * *pReqParam*)

Gets the profile content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.2 int pack_swiaudio_SLQSGetM2MAudioVolume (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSGetM2MAudioVolume_t * *pReqParam*)

Gets the Volume content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.3 int pack_swiaudio_SLQSGetM2MAVMute (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSGetM2MAVMute_t * *pReqParam*)

Gets the AV Mute content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.4 int pack_swiaudio_SLQSGetM2MSpkrGain (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSGetM2MSpkrGain_t * *pReqParam*)

Gets the SPKRGAIN content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.5 int pack_swiaudio_SLQSSetM2MAudioAVCFG (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MAudioAVCFG_t * *pReqParam*)

Sets the AVCFG content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.6 int pack_swiaudio_SLQSSetM2MAudioLPBK (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MAudioLPBK_t * *pReqParam*)

Sets the LPBK content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.7 int pack_swiaudio_SLQSSetM2MAudioNVDef (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Sets the NVDef content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.8 int pack_swiaudio_SLQSSetM2MAudioProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MAudioProfile_t * *pReqParam*)

sets an audio profile content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.9 int pack_swiaudio_SLQSSetM2MAudioVolume (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MAudioVolume_t * *pReqParam*)

Sets the Volume content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.10 int pack_swiaudio_SLQSSetM2MAVMute (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MAVMute_t * *pReqParam*)

Sets the AV Mute content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.11 int pack_swiaudio_SLQSSetM2MSpkrGain (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MSpkrGain_t * *pReqParam*)

Sets the SPKRGAIN content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.12 int unpack_swiaudio_SLQSGetM2MAudioProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSGetM2MAudioProfile_t * *pOutput*)

Gets the profile content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.13 int unpack_swiaudio_SLQSGetM2MAudioVolume (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSGetM2MAudioVolume_t * *pOutput*)

Gets the Volume content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.14 int unpack_swiaudio_SLQSGetM2MAVMute (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSGetM2MAVMute_t * *pOutput*)

Gets the AV Mute content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.15 int unpack_swiaudio_SLQSGetM2MSpkrGain (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSGetM2MSpkrGain_t * *pOutput*)

Gets the SPKRGAIN content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.16 int unpack_swiaudio_SLQSSetM2MAudioAVCFG (uint8_t * *pResp*, uint16_t *respLen*)

Sets the AVCFG content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.17 int unpack_swiaudio_SLQSSetM2MAudioLPBK (uint8_t * *pResp*, uint16_t *respLen*)

Sets the LPBK content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.18 int unpack_swiaudio_SLQSSetM2MAudioNVDef (uint8_t * *pResp*, uint16_t *respLen*)

Sets the NVDef content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.19 int unpack_swiaudio_SLQSSetM2MAudioProfile (uint8_t * *pResp*, uint16_t *respLen*)

sets an audio profile content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.20 int unpack_swiaudio_SLQSSetM2MAudioVolume (uint8_t * *pResp*, uint16_t *respLen*)

Sets the Volume content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.21 int unpack_swiaudio_SLQSSetM2MAVMute (uint8_t * *pResp*, uint16_t *respLen*)

Sets the AV Mute content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.2.22 int unpack_swiaudio_SLQSSetM2MSpkrGain (uint8_t * *pResp*, uint16_t *respLen*)

Sets the SPKRGAIN content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34 swiavms.h File Reference

Data Structures

- struct pack_swiavms_SLQSAVMSStartSession_t
- struct unpack_swiavms_SLQSAVMSStartSession_t
- struct pack_swiavms_SLQSAVMSStopSession_t
- struct unpack_swiavms_SLQSAVMSStopSession_t
- struct PackSwiAvmsSetSettingsPeriodInfo
- struct PackSwiAvmsSetSettingsAPNInfo
- struct PackSwiAvmsSetSettingsConnectionRetryTimers

- struct pack_swiavms_SLQSAVMSSetSettings_t
- struct unpack_swiavms_SLQSAVMSSetSettings_t
- struct PackSwiAVMSSettingsAPNInfo
- struct PackSwiAVMSSettingsConnectionRetryTimers
- struct PackSwiAVMSSettingsPeriodsInfo
- struct unpack_swiavms_SLQSAVMSGetSettings_t
- struct pack_swiavms_SLQSAVMSSendSelection_t
- struct unpack_swiavms_SLQSAVMSSendSelection_t
- struct unpack_swiavms_SLQSAvmsSetEventReport_t
- struct UnpackSwiAvmsEventReportBinaryUpdateSessionInfo
- struct UnpackSwiAvmsEventReportConfig
- struct UnpackSwiAvmsEventReportNotification
- struct UnpackSwiAvmsEventReportConnectionRequest
- struct UnpackSwiAvmsEventReportWAMSParamChange
- struct UnpackSwiAvmsEventReportPackageID
- struct UnpackSwiAvmsEventReportRegStatus
- struct UnpackSwiAvmsEventReportDataSessionStatus
- struct UnpackSwiAvmsEventReportSessionType
- struct UnpackSwiAvmsEventReportHTTPStatus
- struct unpack_swiavms_SLQSAVMSSessionGetInfo_t
- struct unpack_swiavms_SLQSAVMSEventReportInd_t

Macros

- #define LITEQMI_MAX_SWIOMA_STR_LEN 255
- #define MAX_PACK_SWI_AVMS_SET_SETTING_APN_LENGTH 49
- #define MAX_PACK_SWI_AVMS_SET_SETTING_UNAME_LENGTH 29
- #define MAX_PACK_SWI_AVMS_SET_SETTING_PWD_LENGTH 29
- #define MAX_PACK_SWI_AVMS_SET_SETTING_CONNECTION_RETRY_TIMMERS 8
- #define MAX_AVMS_SETTINGS_RETRY_TIMER_NUMBER 8
- #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_VERSION_LENGTH 128
- #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_NAME_LENGTH 128
- #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_DESC_LENGTH 1024
- #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_CONFIG_ALERT_MSG_LENGTH 200

Functions

- int pack_swiavms_SLQSAVMSStartSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiavms_SLQSAVMSStartSession_t reqParam)
- int unpack_swiavms_SLQSAVMSStartSession (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSStartSession_t *pResponse)
- int pack_swiavms_SLQSAVMSStopSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiavms_SLQSAVMSStopSession_t reqParam)
- int unpack_swiavms_SLQSAVMSStopSession (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSStopSession_t *pResponse)
- int pack_swiavms_SLQSAVMSSetSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiavms_SLQSAVMSSetSettings_t reqParam)
- int unpack_swiavms_SLQSAVMSSetSettings (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSSetSettings_t *pResponse)
- int pack_swiavms_SLQSAVMSSetSettingsNoAutoRebootField (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiavms_SLQSAVMSSetSettings_t reqParam)

- int pack_swiavms_SLQSAVMSGetSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swiavms_SLQSAVMSGetSettings (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSGetSettings_t *pResponse)
- int pack_swiavms_SLQSAVMSSendSelection (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiavms_SLQSAVMSSendSelection_t reqParam)
- int unpack_swiavms_SLQSAVMSSendSelection (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSSendSelection_t *pResponse)
- int pack_swiavms_SLQSAvmsSetEventReport (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swiavms_SLQSAvmsSetEventReport (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAvmsSetEventReport_t *pResponse)
- int pack_swiavms_SLQSAVMSSessionGetInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swiavms_SLQSAVMSSessionGetInfo (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSSessionGetInfo_t *pResponse)
- int unpack_swiavms_SLQSAVMSEventReportInd (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSEventReportInd_t *pResponse)

9.34.1 Macro Definition Documentation

9.34.1.1 #define LITEQMI_MAX_SWIOMA_STR_LEN 255

9.34.1.2 #define MAX_AVMS_SETTINGS_RETRY_TIMER_NUMBER 8

9.34.1.3 #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_DESC_LENGTH 1024

9.34.1.4 #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_NAME_LENGTH 128

9.34.1.5 #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_VERSION_LENGTH 128

9.34.1.6 #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_CONFIG_ALERT_MSG_LENGTH 200

9.34.1.7 #define MAX_PACK_SWI_AVMS_SET_SETTING_APN_LENGTH 49

9.34.1.8 #define MAX_PACK_SWI_AVMS_SET_SETTING_CONNECTION_RETRY_TIMMERS 8

9.34.1.9 #define MAX_PACK_SWI_AVMS_SET_SETTING_PWD_LENGTH 29

9.34.1.10 #define MAX_PACK_SWI_AVMS_SET_SETTING_UNAME_LENGTH 29

9.34.2 Function Documentation

9.34.2.1 int pack_swiavms_SLQSAVMSGetSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack AVMS Get settings command This maps to SLQSAVMSSetSettings

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.2 int pack_swiavms_SLQSAVMSSendSelection (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiavms_SLQSAVMSSendSelection_t *reqParam*)

Function to pack AVMS send selection command This maps to SLQSAVMSSendSelection

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_swiavms_SLQSAVMSSendSelection_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.3 int pack_swiavms_SLQSAVMSSessionGetInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack AVMS get session info command This maps to SLQSAVMSSessionGetInfo

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.4 int pack_swiavms_SLQSAvmsSetEventReport (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack AVMS set event report command This maps to SLQSAVMSSetEventReport

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.5 int pack_swiavms_SLQSAVMSSetSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiavms_SLQSAVMSSetSettings_t *reqParam*)

Function to pack AVMS Set settings command This maps to SLQSAVMSSetSettings

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_swiavms_SLQSAVMSSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.6 int pack_swiavms_SLQSAVMSSetSettingsNoAutoRebootField (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiavms_SLQSAVMSSetSettings_t *reqParam*)

Function to pack AVMS Set settings without Auto Reobot field command This maps to SLQSAVMSSetSettings-IgnoreAutoReboot

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_swiavms_SLQSAVMSSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.7 int pack_swiavms_SLQSAVMSStartSession (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiavms_SLQSAVMSStartSession_t *reqParam*)

Function to pack Start AVMS session command This maps to SLQSAVMSStartSession

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_swiavms_SLQSAVMSStartSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.8 int pack_swiavms_SLQSAVMSStopSession (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiavms_SLQSAVMSStopSession_t *reqParam*)

Function to pack cancel AVMS session command This maps to SLQSAVMSStopSession

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_swiavms_SLQSAVMSStopSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.9 int unpack_swiavms_SLQSAVMSEventReportInd (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSEventReportInd_t * *pResponse*)

Function to unpack AVMS event report Indication command This maps to SLQSAVMSSetEventReport

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSEventReportInd_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.10 int unpack_swiavms_SLQSAVMSGetSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSGetSettings_t * *pResponse*)

Function to unpack AVMS set settings command This maps to SLQSAVMSGetSettings

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.11 int unpack_swiavms_SLQSAVMSSendSelection (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSSendSelection_t * *pResponse*)

Function to unpack AVMS send selection command This maps to SLQSAVMSSendSelection

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSSendSelection_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.12 int unpack_swiavms_SLQSAVMSSessionGetInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSSessionGetInfo_t * *pResponse*)

Function to unpack AVMS event report Indication command This maps to SLQSAVMSSetEventReport

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSSessionGetInfo_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.13 int unpack_swiavms_SLQSAvmsSetEventReport (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAvmsSetEventReport_t * *pResponse*)

Function to unpack AVMS set event report command This maps to SLQSAVMSSetEventReport

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAvmsSetEventReport_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.14 int unpack_swiavms_SLQSAVMSSetSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSSetSettings_t * *pResponse*)

Function to unpack AVMS Set settings command This maps to SLQSAVMSSetSettings

Parameters

in	*pResp*	• Response from modem

in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.15 int unpack_swiavms_SLQSAVMSStartSession (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSStartSession_t * *pResponse*)

Function to unpack Start AVMS session response from modem This maps to SLQSAVMSStartSession

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSStartSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.16 int unpack_swiavms_SLQSAVMSStopSession (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSStopSession_t * *pResponse*)

Function to pack stop AVMS session command This maps to SLQSAVMSStopSession

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem

out	*pResponse*	• See unpack_swiavms_SLQSAVMSStopSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.35 SwiDataTypes.h File Reference

SWI data types.

Macros

- #define SWI_API
- #define QMI_NO_LTE_FW_SUPPORT 0
- #define QMI_TLV_PLACEHOLDER 0x8F
- #define UNUSEDPARAM(x) (void)x

Typedefs

- typedef unsigned int ULONG
- typedef unsigned long long ULONGLONG
- typedef signed char INT8
- typedef unsigned char BYTE
- typedef char CHAR
- typedef unsigned short WORD
- typedef unsigned short USHORT
- typedef const char * LPCSTR
- typedef int BOOL
- typedef signed short SHORT
- typedef signed int INT32
- typedef float FLOAT

9.35.1 Detailed Description

SWI data types.

9.35.2 Macro Definition Documentation

9.35.2.1 #define QMI_NO_LTE_FW_SUPPORT 0

9.35.2.2 #define QMI_TLV_PLACEHOLDER 0x8F

9.35.2.3 #define SWI_API

9.35.2.4 #define UNUSEDPARAM(x) (void)x

Macro used to avoid “unused variable” compiler warnings generated due to the inclusion of the "-Wextra" flag in our make files.

9.35.3 Typedef Documentation

9.35.3.1 typedef int BOOL

9.35.3.2 typedef unsigned char BYTE

9.35.3.3 typedef char CHAR

9.35.3.4 typedef float FLOAT

9.35.3.5 typedef signed int INT32

9.35.3.6 typedef signed char INT8

9.35.3.7 typedef const char* LPCSTR

9.35.3.8 typedef signed short SHORT

9.35.3.9 typedef unsigned int ULONG

9.35.3.10 typedef unsigned long long ULONGLONG

9.35.3.11 typedef unsigned short USHORT

9.35.3.12 typedef unsigned short WORD

9.36 swiloc.h File Reference

Data Structures

- struct unpack_swiloc_SwiLocGetAutoStart_t
- struct pack_swiloc_SwiLocSetAutoStart_t

Functions

- int pack_swiloc_SwiLocGetAutoStart (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swiloc_SwiLocGetAutoStart (uint8_t *pResp, uint16_t respLen, unpack_swiloc_SwiLocGetAutoStart_t *pOutput)
- int pack_swiloc_SwiLocSetAutoStart (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiloc_SwiLocSetAutoStart_t *reqArg)
- int unpack_swiloc_SwiLocSetAutoStart (uint8_t *pResp, uint16_t respLen)

9.36.1 Function Documentation

9.36.1.1 int pack_swiloc_SwiLocGetAutoStart (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Get Auto Start pack

Parameters

in	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.1.2 int pack_swiloc_SwiLocSetAutoStart (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiloc_SwiLocSetAutoStart_t * *reqArg*)

Set Auto Start pack

Parameters

in	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.1.3 int unpack_swiloc_SwiLocGetAutoStart (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiloc_SwiLocGetAutoStart_t * *pOutput*)

Get Auto Start unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.1.4 int unpack_swiloc_SwiLocSetAutoStart (uint8_t * *pResp*, uint16_t *respLen*)

Set Auto Start unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.37 swioma.h File Reference

Data Structures

- struct pack_swioma_SLQSOMADMStartSession_t
- struct unpack_swioma_SLQSOMADMStartSession_t
- struct pack_swioma_SLQSOMADMCancelSession_t
- struct unpack_swioma_SLQSOMADMGetSettings_t
- struct pack_swioma_SLQSOMADMSetSettings_t
- struct pack_swioma_SLQSOMADMSendSelection_t
- struct pack_swioma_SLQSOMADMGetSessionInfo_t
- struct unpack_swioma_SLQSOMADMGetSessionInfo_t
- struct unpack_omaDmFotaTlv_t
- struct unpack_omaDmConfigTlv_t
- struct unpack_omaDmNotificationsTlv_t
- struct unpack_swioma_SLQSOMADMAlertCallback_ind_t

Macros

- #define LITEQMI_MAX_SWIOMA_STR_LEN 255

Functions

- int pack_swioma_SLQSOMADMStartSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMStartSession_t reqParam)
- int unpack_swioma_SLQSOMADMStartSession (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMStartSession_t *pOutput)
- int pack_swioma_SLQSOMADMCancelSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMCancelSession_t reqParam)
- int unpack_swioma_SLQSOMADMCancelSession (uint8_t *pResp, uint16_t respLen)
- int pack_swioma_SLQSOMADMGetSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swioma_SLQSOMADMGetSettings (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMGetSettings_t *pOutput)
- int pack_swioma_SLQSOMADMSetSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMSetSettings_t reqParam)
- int unpack_swioma_SLQSOMADMSetSettings (uint8_t *pResp, uint16_t respLen)

- int pack_swioma_SLQSOMADMSendSelection (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMSendSelection_t reqParam)
- int unpack_swioma_SLQSOMADMSendSelection (uint8_t *pResp, uint16_t respLen)
- int pack_swioma_SLQSOMADMGetSessionInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMGetSessionInfo_t reqParam)
- int unpack_swioma_SLQSOMADMGetSessionInfo (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMGetSessionInfo_t *pOutput)
- int pack_swioma_SLQSOMADMAlertCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swioma_SLQSOMADMAlertCallback (uint8_t *pResp, uint16_t respLen)
- int unpack_swioma_SLQSOMADMAlertCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMAlertCallback_ind_t *pOutput)

9.37.1 Macro Definition Documentation

9.37.1.1 #define LITEQMI_MAX_SWIOMA_STR_LEN 255

9.37.2 Function Documentation

9.37.2.1 int pack_swioma_SLQSOMADMAlertCallback (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen*)

Function to pack QMI command to enable the SWIOMADM network-initiated alert callback function. This maps to SetSLQSOMADMAlertCallback

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.37.2.2 int pack_swioma_SLQSOMADMCancelSession (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen,* pack_swioma_SLQSOMADMCancelSession_t *reqParam*)

Function to pack cancel OMA-DM session command This maps to SLQSOMADMCancelSession

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On output, number of bytes actually packed
reqParam	[in] • See pack_swioma_SLQSOMADMCancelSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.37.2.3 int pack_swioma_SLQSOMADMGetSessionInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMGetSessionInfo_t *reqParam*)

Function to pack QMI command to return information related to the current (or previous if no session is active) OMA-DM session. This maps to SLQSOMADMGetSessionInfo

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[in] • See pack_swioma_SLQSOMADMGetSessionInfo_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.37.2.4 int pack_swioma_SLQSOMADMGetSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack command to retrieve the OMA-DM settings from the device. This maps to SLQSOMADMGetSettings2

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On output, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.37.2.5 int pack_swioma_SLQSOMADMSendSelection (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMSendSelection_t *reqParam*)

Function to pack OMA-DM send selection command This maps to SLQSOMADMSendSelection2

Parameters

pCtx	[out] • See pack_qmi_t for more information

pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[in] • See pack_swioma_SLQSOMADMSendSelection_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.37.2.6 int pack_swioma_SLQSOMADMSetSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMSetSettings_t *reqParam*)

Function to pack OMA-DM set settings command This maps to SLQSOMADMSetSettings3

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[in] • See pack_swioma_SLQSOMADMSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.37.2.7 int pack_swioma_SLQSOMADMStartSession (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMStartSession_t *reqParam*)

Function to pack Start OMA-DM session command This maps to SLQSOMADMStartSession2

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[in] • See pack_swioma_SLQSOMADMStartSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.37.2.8 int unpack_swioma_SLQSOMADMAlertCallback (uint8_t * *pResp*, uint16_t *respLen*)

Function to unpack response of QMI command to enable the SWIOMADM network-initiated alert callback function. This maps to SetSLQSOMADMAlertCallback

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Please use eQMI_SWIOMA_EVENT_IND indication to identify this event from SWIOMA service read function

9.37.2.9 int unpack_swioma_SLQSOMADMAlertCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMAlertCallback_ind_t * *pOutput*)

Function to unpack SWIOMADM alert indications This maps to SetSLQSOMADMAlertCallback

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem
pOutput	[out] • See unpack_swioma_SLQSOMADMAlertCallback_ind_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.37.2.10 int unpack_swioma_SLQSOMADMCancelSession (uint8_t * *pResp*, uint16_t *respLen*)

Function to pack cancel OMA-DM session command This maps to SLQSOMADMCancelSession

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.37.2.11 int unpack_swioma_SLQSOMADMGetSessionInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMGetSessionInfo_t * *pOutput*)

Function to unpack information related to the current (or previous if no session is active) OMA-DM session. This maps to SLQSOMADMGetSessionInfo

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem
pOutput	[out] • See unpack_swioma_SLQSOMADMGetSessionInfo_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.37.2.12 int unpack_swioma_SLQSOMADMGetSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMGetSettings_t * *pOutput*)

Function to unpack OMA-DM get settings response from modem This maps to SLQSOMADMGetSettings2

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem
pOutput	[out] • See unpack_swioma_SLQSOMADMGetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.37.2.13 int unpack_swioma_SLQSOMADMSendSelection (uint8_t * *pResp*, uint16_t *respLen*)

Function to unpack OMA-DM send selection command This maps to SLQSOMADMSendSelection2

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.37.2.14 int unpack_swioma_SLQSOMADMSetSettings (uint8_t * *pResp*, uint16_t *respLen*)

Function to unpack OMA-DM set settings command This maps to SLQSOMADMSetSettings3

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.37.2.15 int unpack_swioma_SLQSOMADMStartSession (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMStartSession_t * *pOutput*)

Function to unpack Start OMA-DM session response from modem This maps to SLQSOMADMStartSession2

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem

pOutput	[out] • See unpack_swioma_SLQSOMADMStartSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.38 swiomaext.h File Reference

Data Structures

- struct pack_swioma_SLQSOMADMStartSessionExt_t
- struct pack_swioma_SLQSOMADMCancelSessionExt_t
- struct pack_swioma_SLQSOMADMSetSettingsExt_t
- struct pack_swioma_SLQSOMADMSendSelectionExt_t

Macros

- #define LITEQMI_MAX_SWIOMA_STR_LEN 255

Functions

- int pack_swioma_SLQSOMADMStartSessionExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMStartSessionExt_t reqParam)
- int unpack_swioma_SLQSOMADMStartSessionExt (uint8_t *pResp, uint16_t respLen)
- int pack_swioma_SLQSOMADMCancelSessionExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMCancelSessionExt_t reqParam)
- int unpack_swioma_SLQSOMADMCancelSessionExt (uint8_t *pResp, uint16_t respLen)
- int pack_swioma_SLQSOMADMSetSettingsExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMSetSettingsExt_t reqParam)
- int unpack_swioma_SLQSOMADMSetSettingsExt (uint8_t *pResp, uint16_t respLen)
- int pack_swioma_SLQSOMADMSendSelectionExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMSendSelectionExt_t reqParam)
- int unpack_swioma_SLQSOMADMSendSelectionExt (uint8_t *pResp, uint16_t respLen)

9.38.1 Macro Definition Documentation

9.38.1.1 #define LITEQMI_MAX_SWIOMA_STR_LEN 255

9.38.2 Function Documentation

9.38.2.1 int pack_swioma_SLQSOMADMCancelSessionExt (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen,* pack_swioma_SLQSOMADMCancelSessionExt_t *reqParam*)

Function to pack cancel OMA-DM session command This maps to SLQSOMADMCancelSessionExt

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[IN] • See pack_swioma_SLQSOMADMCancelSessionExt_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.38.2.2 int pack_swioma_SLQSOMADMSendSelectionExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMSendSelectionExt_t *reqParam*)

Function to pack OMA-DM send selection command This maps to SLQSOMADMSendSelectionExt

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[IN] • See pack_swioma_SLQSOMADMSendSelectionExt_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.38.2.3 int pack_swioma_SLQSOMADMSetSettingsExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMSetSettingsExt_t *reqParam*)

Function to pack OMA-DM set settings command This maps to SLQSOMADMSetSettingsExt

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[IN] • See pack_swioma_SLQSOMADMSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.38.2.4 int pack_swioma_SLQSOMADMStartSessionExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMStartSessionExt_t *reqParam*)

Function to pack Start OMA-DM session command This maps to SLQSOMADMStartSessionExt

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes

pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[IN] • See pack_swioma_SLQSOMADMStartSessionExt_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.38.2.5 int unpack_swioma_SLQSOMADMCancelSessionExt (uint8_t * *pResp,* uint16_t *respLen*)

Function to pack cancel OMA-DM session command This maps to SLQSOMADMCancelSessionExt

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.38.2.6 int unpack_swioma_SLQSOMADMSendSelectionExt (uint8_t * *pResp,* uint16_t *respLen*)

Function to unpack OMA-DM send selection command This maps to SLQSOMADMSendSelectionExt

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.38.2.7 int unpack_swioma_SLQSOMADMSetSettingsExt (uint8_t * *pResp*, uint16_t *respLen*)

Function to unpack OMA-DM set settings command This maps to SLQSOMADMSetSettingsExt

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.38.2.8 int unpack_swioma_SLQSOMADMStartSessionExt (uint8_t * *pResp*, uint16_t *respLen*)

Function to unpack Start OMA-DM session response from modem This maps to SLQSOMADMStartSessionExt

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.39 SWIWWANCMAPI.h File Reference

9.40 tmd.h File Reference

Data Structures

- struct tmd_mitigationDevList
- struct unpack_tmd_SLQSTmdGetMitigationDevList_t
- struct pack_tmd_SLQSTmdGetMitigationLvl_t
- struct unpack_tmd_SLQSTmdGetMitigationLvl_t
- struct pack_tmd_SLQSTmdRegNotMitigationLvl_t
- struct unpack_tmd_SLQSTmdRegNotMitigationLvl_t
- struct pack_tmd_SLQSTmdDeRegNotMitigationLvl_t
- struct unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t
- struct unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t

Macros

- #define TMD_MAX_DEV_LIST 255
- #define MAX_MITIGATION_DEV_LIST_LEN 255
- #define MAX_MITIGATION_DEV_ID_LEN 255

Functions

- int pack_tmd_SLQSTmdGetMitigationDevList (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_tmd_SLQSTmdGetMitigationDevList (uint8_t *pResp, uint16_t respLen, unpack_tmd_SLQSTmdGetMitigationDevList_t *pOutput)
- int pack_tmd_SLQSTmdGetMitigationLvl (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_tmd_SLQSTmdGetMitigationLvl_t *reqArg)
- int unpack_tmd_SLQSTmdGetMitigationLvl (uint8_t *pResp, uint16_t respLen, unpack_tmd_SLQSTmdGetMitigationLvl_t *pOutput)
- int pack_tmd_SLQSTmdRegNotMitigationLvl (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_tmd_SLQSTmdRegNotMitigationLvl_t *reqArg)
- int unpack_tmd_SLQSTmdRegNotMitigationLvl (uint8_t *pResp, uint16_t respLen, unpack_tmd_SLQSTmdRegNotMitigationLvl_t *pOutput)
- int pack_tmd_SLQSTmdDeRegNotMitigationLvl (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_tmd_SLQSTmdDeRegNotMitigationLvl_t *reqArg)
- int unpack_tmd_SLQSTmdDeRegNotMitigationLvl (uint8_t *pResp, uint16_t respLen, unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t *pOutput)
- int unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t *pOutput)

9.40.1 Macro Definition Documentation

9.40.1.1 #define MAX_MITIGATION_DEV_ID_LEN 255

9.40.1.2 #define MAX_MITIGATION_DEV_LIST_LEN 255

9.40.1.3 #define TMD_MAX_DEV_LIST 255

9.40.2 Function Documentation

9.40.2.1 int pack_tmd_SLQSTmdDeRegNotMitigationLvl (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_tmd_SLQSTmdDeRegNotMitigationLvl_t * *reqArg*)

To DeRegister notification mitigation level pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*reqArg*	request argument.

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.40.2.2 int pack_tmd_SLQSTmdGetMitigationDevList (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get mitigation device list pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.40.2.3 int pack_tmd_SLQSTmdGetMitigationLvl (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_tmd_SLQSTmdGetMitigationLvl_t * *reqArg*)

To get mitigation level pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*reqArg*	request argument.

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.40.2.4 int pack_tmd_SLQSTmdRegNotMitigationLvl (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_tmd_SLQSTmdRegNotMitigationLvl_t * *reqArg*)

To Register notification mitigation level pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*reqArg*	request argument.

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.40.2.5 int unpack_tmd_SLQSTmdDeRegNotMitigationLvl (uint8_t * *pResp*, uint16_t *respLen*, unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t * *pOutput*)

To De-Register notification mitigation level unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.40.2.6 int unpack_tmd_SLQSTmdGetMitigationDevList (uint8_t * *pResp*, uint16_t *respLen*, unpack_tmd_SLQSTmdGetMitigationDevList_t * *pOutput*)

To mitigation device list unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.40.2.7 int unpack_tmd_SLQSTmdGetMitigationLvl (uint8_t * *pResp*, uint16_t *respLen*, unpack_tmd_SLQSTmdGetMitigationLvl_t * *pOutput*)

To get mitigation level unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.40.2.8 int unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t * *pOutput*)

Mitigiation Level Report Indication unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.40.2.9 int unpack_tmd_SLQSTmdRegNotMitigationLvl (uint8_t * *pResp*, uint16_t *respLen*, unpack_tmd_SLQSTmdRegNotMitigationLvl_t * *pOutput*)

To Register notification mitigation level unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41 uim.h File Reference

Data Structures

- struct uim_appStatus
- struct uim_slotInfo
- struct uim_cardStatus
- struct uim_hotSwapStatus
- struct unpack_uim_GetCardStatus_t
- struct uim_encryptedPIN1
- struct uim_remainingRetries
- struct uim_sessionInformation
- struct uim_verifyUIMPIN
- struct uim_unblockUIMPIN
- struct uim_cardResult
- struct uim_setPINProtection
- struct uim_changeUIMPIN
- struct uim_fileInfo
- struct uim_UIMSessionInformation
- struct uim_readTransparentInfo
- struct uim_readResult
- struct pack_uim_VerifyPin_t
- struct unpack_uim_VerifyPin_t
- struct pack_uim_UnblockPin_t
- struct unpack_uim_UnblockPin_t
- struct pack_uim_SetPinProtection_t
- struct unpack_uim_SetPinProtection_t
- struct pack_uim_ChangePin_t
- struct unpack_uim_ChangePin_t
- struct pack_uim_ReadTransparent_t
- struct unpack_uim_ReadTransparent_t
- struct pack_uim_SLQSUIMEventRegister_t
- struct unpack_uim_SLQSUIMEventRegister_t
- struct appStats
- struct slotInf
- struct unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t
- struct slot_t
- struct slots_t
- struct unpack_uim_SLQSUIMGetSlotsStatus_t
- struct pack_uim_SLQSUIMSwitchSlot_t
- struct unpack_uim_SetUimSlotStatusChangeCallback_ind_t
- struct pack_uim_SLQSUIMPowerUp_t
- struct pack_uim_SLQSUIMPowerDown_t
- struct pack_uim_SLQSUIMRefreshOK_t
- struct uim_registerRefresh
- struct pack_uim_SLQSUIMRefreshRegister_t

- struct pack_uim_SLQSUIMRefreshComplete_t
- struct uim_refreshevent
- struct pack_uim_SLQSUIMRefreshGetLastEvent_t
- struct unpack_uim_SLQSUIMRefreshGetLastEvent_t
- struct pack_uim_SLQSUIMGetFileAttributes_t
- struct uim_fileAttributes
- struct unpack_uim_SLQSUIMGetFileAttributes_t
- struct uim_depersonalizationInformation
- struct pack_uim_SLQSUIMDepersonalization_t
- struct unpack_uim_SLQSUIMDepersonalization_t
- struct uim_authenticationData
- struct pack_uim_SLQSUIMAuthenticate_t
- struct uim_authenticateResult
- struct unpack_uim_SLQSUIMAuthenticate_t
- struct uim_personalizationStatus
- struct pack_uim_SLQSUIMGetConfiguration_t
- struct unpack_uim_SLQSUIMGetConfiguration_t

Macros

- #define UIM_UINT8_MAX_STRING_SZ 255
- #define UIM_MAX_DESCRIPTION_LENGTH 255
- #define UIM_MAX_NO_OF_SLOTS 5
- #define UIM_MAX_NO_OF_APPLICATIONS 10
- #define MAX_NO_OF_SLOTS 5
- #define MAX_NO_OF_APPLICATIONS 10
- #define MAX_DESCRIPTION_LENGTH 255
- #define MAX_SLOTS_STATUS 255
- #define MAX_ICCID_LENGTH 255
- #define UIM_MAX_CONTENT_LENGTH 1024
- #define UIM_MAX_ACTIVE_PERS_FEATURES 12

Functions

- int pack_uim_GetCardStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_uim_GetCardStatus (uint8_t *pResp, uint16_t respLen, unpack_uim_GetCardStatus_t *pOutput)
- int pack_uim_VerifyPin (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_VerifyPin_t *reqArg)
- int unpack_uim_VerifyPin (uint8_t *pResp, uint16_t respLen, unpack_uim_VerifyPin_t *pOutput)
- int pack_uim_UnblockPin (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_UnblockPin_t *reqArg)
- int unpack_uim_UnblockPin (uint8_t *pResp, uint16_t respLen, unpack_uim_UnblockPin_t *pOutput)
- int pack_uim_SetPinProtection (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SetPinProtection_t *reqArg)
- int unpack_uim_SetPinProtection (uint8_t *pResp, uint16_t respLen, unpack_uim_SetPinProtection_t *pOutput)
- int pack_uim_ChangePin (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_ChangePin_t *reqArg)
- int unpack_uim_ChangePin (uint8_t *pResp, uint16_t respLen, unpack_uim_ChangePin_t *pOutput)
- int pack_uim_ReadTransparent (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_ReadTransparent_t *reqArg)
- int unpack_uim_ReadTransparent (uint8_t *pResp, uint16_t respLen, unpack_uim_ReadTransparent_t *pOutput)

- int pack_uim_SLQSUIMEventRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMEventRegister_t *reqArg)
- int unpack_uim_SLQSUIMEventRegister (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMEventRegister_t *pOutput)
- int unpack_uim_SLQSUIMSetStatusChangeCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t *pOutput)
- int pack_uim_SLQSUIMGetSlotsStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_uim_SLQSUIMGetSlotsStatus (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMGetSlotsStatus_t *pOutput)
- int pack_uim_SLQSUIMSwitchSlot (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMSwitchSlot_t *reqArg)
- int unpack_uim_SLQSUIMSwitchSlot (uint8_t *pResp, uint16_t respLen)
- int unpack_uim_SetUimSlotStatusChangeCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_uim_SetUimSlotStatusChangeCallback_ind_t *pOutput)
- int pack_uim_SLQSUIMPowerUp (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMPowerUp_t *reqArg)
- int unpack_uim_SLQSUIMPowerUp (uint8_t *pResp, uint16_t respLen)
- int pack_uim_SLQSUIMPowerDown (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMPowerDown_t *reqArg)
- int unpack_uim_SLQSUIMPowerDown (uint8_t *pResp, uint16_t respLen)
- int pack_uim_SLQSUIMReset (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_uim_SLQSUIMReset (uint8_t *pResp, uint16_t respLen)
- int pack_uim_SLQSUIMRefreshOK (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMRefreshOK_t *reqArg)
- int unpack_uim_SLQSUIMRefreshOK (uint8_t *pResp, uint16_t respLen)
- int pack_uim_SLQSUIMRefreshRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMRefreshRegister_t *reqArg)
- int unpack_uim_SLQSUIMRefreshRegister (uint8_t *pResp, uint16_t respLen)
- int pack_uim_SLQSUIMRefreshComplete (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMRefreshComplete_t *reqArg)
- int unpack_uim_SLQSUIMRefreshComplete (uint8_t *pResp, uint16_t respLen)
- int pack_uim_SLQSUIMRefreshGetLastEvent (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMRefreshGetLastEvent_t *reqArg)
- int unpack_uim_SLQSUIMRefreshGetLastEvent (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMRefreshGetLastEvent_t *pOutput)
- int pack_uim_SLQSUIMGetFileAttributes (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMGetFileAttributes_t *reqArg)
- int unpack_uim_SLQSUIMGetFileAttributes (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMGetFileAttributes_t *pOutput)
- int pack_uim_SLQSUIMDepersonalization (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMDepersonalization_t *reqArg)
- int unpack_uim_SLQSUIMDepersonalization (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMDepersonalization_t *pOutput)
- int pack_uim_SLQSUIMAuthenticate (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMAuthenticate_t *reqArg)
- int unpack_uim_SLQSUIMAuthenticate (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMAuthenticate_t *pOutput)
- int pack_uim_SLQSUIMGetConfiguration (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMGetConfiguration_t *reqArg)
- int unpack_uim_SLQSUIMGetConfiguration (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMGetConfiguration_t *pOutput)

9.41.1 Macro Definition Documentation

9.41.1.1 #define MAX_DESCRIPTION_LENGTH 255

9.41.1.2 #define MAX_ICCID_LENGTH 255

9.41.1.3 #define MAX_NO_OF_APPLICATIONS 10

9.41.1.4 #define MAX_NO_OF_SLOTS 5

9.41.1.5 #define MAX_SLOTS_STATUS 255

9.41.1.6 #define UIM_MAX_ACTIVE_PERS_FEATURES 12

9.41.1.7 #define UIM_MAX_CONTENT_LENGTH 1024

9.41.1.8 #define UIM_MAX_DESCRIPTION_LENGTH 255

9.41.1.9 #define UIM_MAX_NO_OF_APPLICATIONS 10

9.41.1.10 #define UIM_MAX_NO_OF_SLOTS 5

9.41.1.11 #define UIM_UINT8_MAX_STRING_SZ 255

9.41.2 Function Documentation

9.41.2.1 int pack_uim_ChangePin (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_ChangePin_t * *reqArg*)

Change Pin pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.2 int pack_uim_GetCardStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Card Status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.3 int pack_uim_ReadTransparent (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_ReadTransparent_t * *reqArg*)

SLQS ReadTransparent pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.4 int pack_uim_SetPinProtection (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SetPinProtection_t * *reqArg*)

Set Pin Protection pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.5 int pack_uim_SLQSUIMAuthenticate (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMAuthenticate_t * *reqArg*)

Send a security command to the card pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.6 int pack_uim_SLQSUIMDepersonalization (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMDepersonalization_t * *reqArg*)

De-activates or unblocks the personalization on the phone pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.7 int pack_uim_SLQSUIMEventRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMEventRegister_t * *reqArg*)

UIM Status Change callback enable pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.8 int pack_uim_SLQSUIMGetConfiguration (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMGetConfiguration_t * *reqArg*)

Gets the modem configuration for the UIM module pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.9 int pack_uim_SLQSUIMGetFileAttributes (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMGetFileAttributes_t * *reqArg*)

Retrieves the file attributes for any EF(Elementary File) or DF(Dedicated File) in the card and provides access by the path pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.10 int pack_uim_SLQSUIMGetSlotsStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack get slots status.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.11 int pack_uim_SLQSUIMPowerDown (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMPowerDown_t * *reqArg*)

Powers down the card pack

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.12 int pack_uim_SLQSUIMPowerUp (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMPowerUp_t * *reqArg*)

Powers up the card pack

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.13 int pack_uim_SLQSUIMRefreshComplete (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMRefreshComplete_t * *reqArg*)

Enables the terminal response to be sent to the card When the client finished Refresh procedure pack

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.14 int pack_uim_SLQSUIMRefreshGetLastEvent (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMRefreshGetLastEvent_t * *reqArg*)

Retrieve the last refresh event pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.15 int pack_uim_SLQSUIMRefreshOK (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMRefreshOK_t * *reqArg*)

Enables the client to indicate whether it is OK to start the Refresh procedure pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.16 int pack_uim_SLQSUIMRefreshRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMRefreshRegister_t * *reqArg*)

Registers for file change notifications triggered by the card pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.17 int pack_uim_SLQSUIMReset (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Resets the issuing control points state kept by the service pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.18 int pack_uim_SLQSUIMSwitchSlot (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMSwitchSlot_t * *reqArg*)

switch slot pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.19 int pack_uim_UnblockPin (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_UnblockPin_t * *reqArg*)

Unblock Pin pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.20 int pack_uim_VerifyPin (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_VerifyPin_t * *reqArg*)

Verify Pin Status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.21 int unpack_uim_ChangePin (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_ChangePin_t * *pOutput*)

Change Pin unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.22 int unpack_uim_GetCardStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_GetCardStatus_t * *pOutput*)

Get Card Status unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.23 int unpack_uim_ReadTransparent (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_ReadTransparent_t * *pOutput*)

SLQS ReadTransparent unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.24 int unpack_uim_SetPinProtection (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SetPinProtection_t * *pOutput*)

Set Pin Protection unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.25 int unpack_uim_SetUimSlotStatusChangeCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SetUimSlotStatusChangeCallback_ind_t * *pOutput*)

UIM Slot Status Change indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

use pack_uim_SLQSUIMEventRegister to subscribe

9.41.2.26 int unpack_uim_SLQSUIMAuthenticate (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMAuthenticate_t * *pOutput*)

Unpack the status code received from the card when card responded to the read request

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.27 int unpack_uim_SLQSUIMDepersonalization (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMDepersonalization_t * *pOutput*)

De-activates or unblocks the personalization on the phone unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.28 int unpack_uim_SLQSUIMEventRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMEvent-Register_t * *pOutput*)

UIM Status Change callback enable unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.29 int unpack_uim_SLQSUIMGetConfiguration (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMGetConfiguration_t * *pOutput*)

Gets the modem configuration for the UIM module unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.30 int unpack_uim_SLQSUIMGetFileAttributes (uint8_t * *pResp*, uint16_t *respLen*, **unpack_uim_SLQSUIMGetFileAttributes_t** * *pOutput*)

Retrieves the file attributes for any EF(Elementary File) or DF(Dedicated File) in the card and provides access by the path unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.31 int unpack_uim_SLQSUIMGetSlotsStatus (uint8_t * *pResp*, uint16_t *respLen*, **unpack_uim_SLQSUIMGetSlotsStatus_t** * *pOutput*)

get slot status unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.32 int unpack_uim_SLQSUIMPowerDown (uint8_t * *pResp*, uint16_t *respLen*)

Powers down the card unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.33 int unpack_uim_SLQSUIMPowerUp (uint8_t * *pResp*, uint16_t *respLen*)

Powers up the card unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.34 int unpack_uim_SLQSUIMRefreshComplete (uint8_t * *pResp*, uint16_t *respLen*)

Enables the terminal response to be sent to the card When the client finished Refresh procedure unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.35 int unpack_uim_SLQSUIMRefreshGetLastEvent (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMRefreshGetLastEvent_t * *pOutput*)

Retrieve the last refresh event unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.36 int unpack_uim_SLQSUIMRefreshOK (uint8_t * *pResp*, uint16_t *respLen*)

Enables the client to indicate whether it is OK to start the Refresh procedure unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.37 int unpack_uim_SLQSUIMRefreshRegister (uint8_t * *pResp*, uint16_t *respLen*)

Registers for file change notifications triggered by the card unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.38 int unpack_uim_SLQSUIMReset (uint8_t * *pResp*, uint16_t *respLen*)

Resets the issuing control points state kept by the service unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.39 int unpack_uim_SLQSUIMSetStatusChangeCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t * *pOutput*)

UIM Status Change indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

use pack_uim_SLQSUIMEventRegister to subscribe

9.41.2.40 int unpack_uim_SLQSUIMSwitchSlot (uint8_t * *pResp*, uint16_t *respLen*)

switch slot unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.41 int unpack_uim_UnblockPin (uint8_t * *pResp*, uint16_t *respLen*, **unpack_uim_UnblockPin_t** * *pOutput*)

Unblock Pin unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.41.2.42 int unpack_uim_VerifyPin (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_VerifyPin_t * *pOutput*)

Verify Pin unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42 voice.h File Reference

Data Structures

- struct voice_USSInfo
- struct pack_voice_OriginateUSSD_t
- struct pack_voice_AnswerUSSD_t
- struct voice_UUSInfo
- struct voice_CUGInfo
- struct voice_calledPartySubAdd
- struct pack_voice_SLQSVoiceDialCall_t
- struct voice_alphaIDInfo
- struct voice_ccSUPSType
- struct unpack_voice_SLQSVoiceDialCall_t
- struct pack_voice_SLQSVoiceEndCall_t
- struct unpack_voice_SLQSVoiceEndCall_t
- struct voice_callFwdTypeAndPlan
- struct pack_voice_SLQSVoiceSetSUPSService_t
- struct unpack_voice_SLQSVoiceSetSUPSService_t
- struct voice_airTimer
- struct voice_roamTimer
- struct voice_prefVoiceSO
- struct pack_voice_SLQSVoiceSetConfig_t
- struct unpack_voice_SLQSVoiceSetConfig_t
- struct pack_voice_SLQSVoiceAnswerCall_t
- struct unpack_voice_SLQSVoiceAnswerCall_t
- struct voice_CLIRResp
- struct unpack_voice_SLQSVoiceGetCLIR_t
- struct voice_CLIPResp
- struct unpack_voice_SLQSVoiceGetCLIP_t
- struct pack_voice_SLQSVoiceGetCallWaiting_t
- struct unpack_voice_SLQSVoiceGetCallWaiting_t
- struct pack_voice_SLQSVoiceGetCallBarring_t
- struct unpack_voice_SLQSVoiceGetCallBarring_t
- struct pack_voice_SLQSVoiceGetCallForwardingStatus_t
- struct voice_callFWInfo

- struct voice_callFWExtInfo
- struct voice_getCallFWInfo
- struct voice_getCallFWExtInfo
- struct unpack_voice_SLQSVoiceGetCallForwardingStatus_t
- struct pack_voice_SLQSVoiceSetCallBarringPassword_t
- struct unpack_voice_SLQSVoiceSetCallBarringPassword_t
- struct pack_voice_SLQSVoiceGetCallInfo_t
- struct voice_callInfo
- struct voice_remotePartyNum
- struct voice_remotePartyName
- struct voice_connectNumInfo
- struct voice_diagInfo
- struct unpack_voice_SLQSVoiceGetCallInfo_t
- struct voice_getAllCallInformation
- struct voice_getAllCallRmtPtyNum
- struct voice_getAllCallRmtPtyName
- struct voice_allCallsUUSInfo
- struct voice_allCallsAlphaIDInfo
- struct voice_allCallsDiagInfo
- struct voice_peerNumberInfo
- struct voice_arrCallInfo
- struct voice_arrRemotePartyNum
- struct voice_arrRemotePartyName
- struct voice_arrAlertingType
- struct voice_arrUUSInfo
- struct voice_arrSvcOption
- struct voice_arrCallEndReason
- struct voice_arrAlphaID
- struct voice_arrConnectPartyNum
- struct voice_arrDiagInfo
- struct voice_arrCalledPartyNum
- struct voice_arrRedirPartyNum
- struct voice_arrAlertingPattern
- struct unpack_voice_SLQSVoiceGetAllCallInfo_t
- struct pack_voice_SLQSVoiceManageCalls_t
- struct unpack_voice_SLQSVoiceManageCalls_t
- struct voice_burstDTMFInfo
- struct voice_DTMFLengths
- struct pack_voice_SLQSVoiceBurstDTMF_t
- struct unpack_voice_SLQSVoiceBurstDTMF_t
- struct pack_voice_SLQSVoiceStartContDTMF_t
- struct unpack_voice_SLQSVoiceStartContDTMF_t
- struct pack_voice_SLQSVoiceStopContDTMF_t
- struct unpack_voice_SLQSVoiceStopContDTMF_t
- struct pack_voice_SLQSVoiceSendFlash_t
- struct unpack_voice_SLQSVoiceSendFlash_t
- struct pack_voice_SLQSVoiceSetPreferredPrivacy_t
- struct pack_voice_SLQSVoiceIndicationRegister_t
- struct pack_voice_SLQSVoiceGetConfig_t
- struct voice_curAMRConfig
- struct unpack_voice_SLQSVoiceGetConfig_t
- struct pack_voice_SLQSVoiceOrigUSSDNoWait_t
- struct pack_voice_SLQSVoiceBindSubscription_t
- struct pack_voice_SLQSVoiceALSSetLineSwitching_t
- struct pack_voice_SLQSVoiceALSSelectLine_t

- struct voice_COLPResp
- struct unpack_voice_SLQSVoiceGetCOLP_t
- struct voice_COLRResp
- struct unpack_voice_SLQSVoiceGetCOLR_t
- struct voice_CNAPResp
- struct unpack_voice_SLQSVoiceGetCNAP_t
- struct pack_voice_SLQSOriginateUSSD_t
- struct unpack_voice_SLQSOriginateUSSD_t

Macros

- #define MAXVOICEUSSDLENGTH 182
- #define MAX_VOICE_CALL_NO_LEN 81
- #define MAX_VOICE_DESCRIPTION_LENGTH 255
- #define VOICE_MAX_NO_OF_CALLS 20
- #define BARRING_PASSWORD_LENGTH 4

Enumerations

- enum liteServiceClassInformation {
  LITE_VOICE_SUPS_SRV_CLASS_NONE = 0x00,
  LITE_VOICE_SUPS_SRV_CLASS_VOICE = 0x01,
  LITE_VOICE_SUPS_SRV_CLASS_DATA = 0x02,
  LITE_VOICE_SUPS_SRV_CLASS_FAX = 0x04,
  LITE_VOICE_SUPS_SRV_CLASS_SMS = 0x08,
  LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITSYNC = 0x10,
  LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITASYNC = 0x20,
  LITE_VOICE_SUPS_SRV_CLASS_PACKETACCESS = 0x40,
  LITE_VOICE_SUPS_SRV_CLASS_PADACCESS = 0x80 }

Functions

- int pack_voice_OriginateUSSD (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_OriginateUSSD_t *reqArg)
- int unpack_voice_OriginateUSSD (uint8_t *pResp, uint16_t respLen)
- int pack_voice_AnswerUSSD (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_AnswerUSSD_t *reqArg)
- int unpack_voice_AnswerUSSD (uint8_t *pResp, uint16_t respLen)
- int pack_voice_CancelUSSD (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_CancelUSSD (uint8_t *pResp, uint16_t respLen)
- int pack_voice_SLQSVoiceDialCall (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceDialCall_t *pReq)
- int unpack_voice_SLQSVoiceDialCall (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceDialCall_t *pOutput)
- int pack_voice_SLQSVoiceEndCall (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceEndCall_t *pReq)
- int unpack_voice_SLQSVoiceEndCall (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceEndCall_t *pOutput)
- int pack_voice_SLQSVoiceSetSUPSService (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceSetSUPSService_t *pReq)
- int unpack_voice_SLQSVoiceSetSUPSService (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceSetSUPSService_t *pOutput)
- int pack_voice_SLQSVoiceSetConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceSetConfig_t *pReq)

- int unpack_voice_SLQSVoiceSetConfig (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceSetConfig_t *pOutput)
- int pack_voice_SLQSVoiceAnswerCall (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceAnswerCall_t *pReq)
- int unpack_voice_SLQSVoiceAnswerCall (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceAnswerCall_t *pOutput)
- int pack_voice_SLQSVoiceGetCLIR (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetCLIR (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCLIR_t *pOutput)
- int pack_voice_SLQSVoiceGetCLIP (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetCLIP (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCLIP_t *pOutput)
- int pack_voice_SLQSVoiceGetCallWaiting (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceGetCallWaiting_t *pReq)
- int unpack_voice_SLQSVoiceGetCallWaiting (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCallWaiting_t *pOutput)
- int pack_voice_SLQSVoiceGetCallBarring (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceGetCallBarring_t *pReq)
- int unpack_voice_SLQSVoiceGetCallBarring (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCallBarring_t *pOutput)
- int pack_voice_SLQSVoiceGetCallForwardingStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceGetCallForwardingStatus_t *pReq)
- int unpack_voice_SLQSVoiceGetCallForwardingStatus (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCallForwardingStatus_t *pOutput)
- int pack_voice_SLQSVoiceSetCallBarringPassword (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceSetCallBarringPassword_t *pReq)
- int unpack_voice_SLQSVoiceSetCallBarringPassword (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceSetCallBarringPassword_t *pOutput)
- int pack_voice_SLQSVoiceGetCallInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceGetCallInfo_t *pReq)
- int unpack_voice_SLQSVoiceGetCallInfo (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCallInfo_t *pOutput)
- int pack_voice_SLQSVoiceGetAllCallInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetAllCallInfo (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetAllCallInfo_t *pOutput)
- int pack_voice_SLQSVoiceManageCalls (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceManageCalls_t *pReq)
- int unpack_voice_SLQSVoiceManageCalls (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceManageCalls_t *pOutput)
- int pack_voice_SLQSVoiceBurstDTMF (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceBurstDTMF_t *pReq)
- int unpack_voice_SLQSVoiceBurstDTMF (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceBurstDTMF_t *pOutput)
- int pack_voice_SLQSVoiceStartContDTMF (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceStartContDTMF_t *pReq)
- int unpack_voice_SLQSVoiceStartContDTMF (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceStartContDTMF_t *pOutput)
- int pack_voice_SLQSVoiceStopContDTMF (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceStopContDTMF_t *pReq)
- int unpack_voice_SLQSVoiceStopContDTMF (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceStopContDTMF_t *pOutput)
- int pack_voice_SLQSVoiceSendFlash (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceSendFlash_t *pReq)
- int unpack_voice_SLQSVoiceSendFlash (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceSendFlash_t *pOutput)
- int pack_voice_SLQSVoiceSetPreferredPrivacy (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceSetPreferredPrivacy_t *reqArg)

- int unpack_voice_SLQSVoiceSetPreferredPrivacy (uint8_t *pResp, uint16_t respLen)
- int pack_voice_SLQSVoiceIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceIndicationRegister_t *reqArg)
- int unpack_voice_SLQSVoiceIndicationRegister (uint8_t *pResp, uint16_t respLen)
- int pack_voice_SLQSVoiceGetConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceGetConfig_t *reqArg)
- int unpack_voice_SLQSVoiceGetConfig (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetConfig_t *pOutput)
- int pack_voice_SLQSVoiceOrigUSSDNoWait (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceOrigUSSDNoWait_t *reqArg)
- int unpack_voice_SLQSVoiceOrigUSSDNoWait (uint8_t *pResp, uint16_t respLen)
- int pack_voice_SLQSVoiceBindSubscription (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceBindSubscription_t *reqArg)
- int unpack_voice_SLQSVoiceBindSubscription (uint8_t *pResp, uint16_t respLen)
- int pack_voice_SLQSVoiceALSSetLineSwitching (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceALSSetLineSwitching_t *reqArg)
- int unpack_voice_SLQSVoiceALSSetLineSwitching (uint8_t *pResp, uint16_t respLen)
- int pack_voice_SLQSVoiceALSSelectLine (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceALSSelectLine_t *reqArg)
- int unpack_voice_SLQSVoiceALSSelectLine (uint8_t *pResp, uint16_t respLen)
- int pack_voice_SLQSVoiceGetCOLP (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetCOLP (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCOLP_t *pOutput)
- int pack_voice_SLQSVoiceGetCOLR (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetCOLR (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCOLR_t *pOutput)
- int pack_voice_SLQSVoiceGetCNAP (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetCNAP (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCNAP_t *pOutput)
- int pack_voice_SLQSOriginateUSSD (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSOriginateUSSD_t *reqArg)
- int unpack_voice_SLQSOriginateUSSD (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSOriginateUSSD_t *pOutput)

9.42.1 Detailed Description

9.42.2 S1

- 3GPP Mobile Radio Interface Layer 3 Specification : Core Network Protocols; Stage 3 (Release 7)
- 3GPP TS 24.008 V7.0.0 (2005-06)

9.42.3 Macro Definition Documentation

9.42.3.1 #define BARRING_PASSWORD_LENGTH 4

9.42.3.2 #define MAX_VOICE_CALL_NO_LEN 81

9.42.3.3 #define MAX_VOICE_DESCRIPTION_LENGTH 255

9.42.3.4 #define MAXVOICEUSSDLENGTH 182

9.42.3.5 #define VOICE_MAX_NO_OF_CALLS 20

9.42.4 Enumeration Type Documentation

9.42.4.1 enum liteServiceClassInformation

Service Class information

Enumerator

LITE_VOICE_SUPS_SRV_CLASS_NONE

LITE_VOICE_SUPS_SRV_CLASS_VOICE

LITE_VOICE_SUPS_SRV_CLASS_DATA

LITE_VOICE_SUPS_SRV_CLASS_FAX

LITE_VOICE_SUPS_SRV_CLASS_SMS

LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITSYNC

LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITASYNC

LITE_VOICE_SUPS_SRV_CLASS_PACKETACCESS

LITE_VOICE_SUPS_SRV_CLASS_PADACCESS

9.42.5 Function Documentation

9.42.5.1 int pack_voice_AnswerUSSD (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_AnswerUSSD_t * *reqArg*)

Responds to a USSD request from the network pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.2 int pack_voice_CancelUSSD (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Cancels an in-progress USSD operation pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.3 int pack_voice_OriginateUSSD (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_OriginateUSSD_t * *reqArg*)

Initiates a USSD operation pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.4 int pack_voice_SLQSOriginateUSSD (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSOriginateUSSD_t * *reqArg*)

Initiates a USSD session pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.5 int pack_voice_SLQSVoiceALSSelectLine (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceALSSelectLine_t * *reqArg*)

allows the user to select the preferred line pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.6 int pack_voice_SLQSVoiceALSSetLineSwitching (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceALSSetLineSwitching_t * *reqArg*)

sets the line switch setting on the card pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.7 int pack_voice_SLQSVoiceAnswerCall (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceAnswerCall_t * *pReq*)

Answers an incoming voice call pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.8 int pack_voice_SLQSVoiceBindSubscription (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceBindSubscription_t * *reqArg*)

binds a subscription type to a specific voice client ID pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.9 int pack_voice_SLQSVoiceBurstDTMF (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceBurstDTMF_t * *pReq*)

Sends a burst Dual-Tone Multi frequency (DTMF) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.10 int pack_voice_SLQSVoiceDialCall (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceDialCall_t * *pReq*)

Originates a voice call (MO call) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.11 int pack_voice_SLQSVoiceEndCall (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_voice_SLQSVoiceEndCall_t * pReq)

Ends a voice call pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.12 int pack_voice_SLQSVoiceGetAllCallInfo (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

information associated with all the calls originating or terminating pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.13 int pack_voice_SLQSVoiceGetCallBarring (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_voice_SLQSVoiceGetCallBarring_t * pReq)

Status of Call Barring Supplementary Service pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.14 int pack_voice_SLQSVoiceGetCallForwardingStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceGetCallForwardingStatus_t * *pReq*)

Status of Call Forwarding Supplementary Service pack

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.15 int pack_voice_SLQSVoiceGetCallInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceGetCallInfo_t * *pReq*)

information associated with a call pack

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.16 int pack_voice_SLQSVoiceGetCallWaiting (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceGetCallWaiting_t * *pReq*)

Status of Call Waiting Supplementary Service pack

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.17 int pack_voice_SLQSVoiceGetCLIP (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

status of the Calling Line Identification Presentation (CLIP) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.18 int pack_voice_SLQSVoiceGetCLIR (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

status of the Calling Line Identification Restriction (CLIR) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.19 int pack_voice_SLQSVoiceGetCNAP (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

status of the Calling Name Presentation(CNAP) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.20 int pack_voice_SLQSVoiceGetCOLP (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

status of the Connected Line Identification Presentation pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.21 int pack_voice_SLQSVoiceGetCOLR (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

status of the Connected Line Identification Restriction pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.22 int pack_voice_SLQSVoiceGetConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceGetConfig_t * *reqArg*)

retrieves various configuration parameters that control the modem behavior pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.23 int pack_voice_SLQSVoiceIndicationRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceIndicationRegister_t * *reqArg*)

Sets the registration state for different QMI_VOICE indications pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.24 int pack_voice_SLQSVoiceManageCalls (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceManageCalls_t * *pReq*)

Manages the calls by using the supplementary service pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.25 int pack_voice_SLQSVoiceOrigUSSDNoWait (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceOrigUSSDNoWait_t * *reqArg*)

initiates a USSD operation No Wait pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.26 int pack_voice_SLQSVoiceSendFlash (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceSendFlash_t * *pReq*)

sends a simple flash message pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.27 int pack_voice_SLQSVoiceSetCallBarringPassword (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceSetCallBarringPassword_t * *pReq*)

Sets a Call Barring Password pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.28 int pack_voice_SLQSVoiceSetConfig (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_voice_SLQSVoiceSetConfig_t * pReq)

configuration parameters that control the modem behavior pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.29 int pack_voice_SLQSVoiceSetPreferredPrivacy (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_voice_SLQSVoiceSetPreferredPrivacy_t * reqArg)

sets the voice privacy preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.30 int pack_voice_SLQSVoiceSetSUPSService (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_voice_SLQSVoiceSetSUPSService_t * pReq)

call-independent supplementary services pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.31 int pack_voice_SLQSVoiceStartContDTMF (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceStartContDTMF_t * *pReq*)

Starts a continuous DTMF pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.32 int pack_voice_SLQSVoiceStopContDTMF (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceStopContDTMF_t * *pReq*)

Stops a continuous DTMF pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.33 int unpack_voice_AnswerUSSD (uint8_t * *pResp*, uint16_t *respLen*)

Responds to a USSD request from the network unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.34 int unpack_voice_CancelUSSD (uint8_t * *pResp*, uint16_t *respLen*)

Cancels an in-progress USSD operation unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.35 int unpack_voice_OriginateUSSD (uint8_t * *pResp*, uint16_t *respLen*)

Initiates a USSD operation unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.36 int unpack_voice_SLQSOriginateUSSD (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSOriginateUSSD_t * *pOutput*)

Initiates a USSD session unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.37 int unpack_voice_SLQSVoiceALSSelectLine (uint8_t * *pResp*, uint16_t *respLen*)

allows the user to select the preferred line unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.38 int unpack_voice_SLQSVoiceALSSetLineSwitching (uint8_t * *pResp*, uint16_t *respLen*)

sets the line switch setting on the card unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.39 int unpack_voice_SLQSVoiceAnswerCall (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceAnswerCall_t * *pOutput*)

Answers an incoming voice call unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.40 int unpack_voice_SLQSVoiceBindSubscription (uint8_t * *pResp*, uint16_t *respLen*)

binds a subscription type to a specific voice client ID unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.41 int unpack_voice_SLQSVoiceBurstDTMF (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceBurstDTMF_t * *pOutput*)

Sends a burst Dual-Tone Multi frequency (DTMF) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.42 int unpack_voice_SLQSVoiceDialCall (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceDialCall_t * *pOutput*)

Originates a voice call (MO call) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.43 int unpack_voice_SLQSVoiceEndCall (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceEndCall_t * *pOutput*)

Ends a voice call unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.44 int unpack_voice_SLQSVoiceGetAllCallInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetAllCallInfo_t * *pOutput*)

information associated with all the calls originating or terminating unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.45 int unpack_voice_SLQSVoiceGetCallBarring (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCallBarring_t * *pOutput*)

Status of Call Barring Supplementary Service unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.46 int unpack_voice_SLQSVoiceGetCallForwardingStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCallForwardingStatus_t * *pOutput*)

Status of Call Forwarding Supplementary Service unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.47 int unpack_voice_SLQSVoiceGetCallInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCallInfo_t * *pOutput*)

information associated with a call unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.48 int unpack_voice_SLQSVoiceGetCallWaiting (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCallWaiting_t * *pOutput*)

Status of Call Waiting Supplementary Service unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.49 int unpack_voice_SLQSVoiceGetCLIP (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCLIP_t * *pOutput*)

status of the Calling Line Identification Presentation (CLIP) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.50 int unpack_voice_SLQSVoiceGetCLIR (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCLIR_t * *pOutput*)

status of the Calling Line Identification Restriction (CLIR) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.51 int unpack_voice_SLQSVoiceGetCNAP (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCNAP_t * *pOutput*)

status of the Calling Name Presentation(CNAP) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.52 int unpack_voice_SLQSVoiceGetCOLP (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCOLP_t * *pOutput*)

status of the Connected Line Identification Presentation unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.53 int unpack_voice_SLQSVoiceGetCOLR (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCOLR_t * *pOutput*)

status of the Connected Line Identification Restriction unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.54 int unpack_voice_SLQSVoiceGetConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetConfig_t * *pOutput*)

retrieves various configuration parameters that control the modem behavior unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.55 int unpack_voice_SLQSVoiceIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*)

Sets the registration state for different QMI_VOICE indications unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.56 int unpack_voice_SLQSVoiceManageCalls (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceManageCalls_t * *pOutput*)

Manages the calls by using the supplementary service unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.57 int unpack_voice_SLQSVoiceOrigUSSDNoWait (uint8_t * *pResp*, uint16_t *respLen*)

initiates a USSD operation No Wait unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.58 int unpack_voice_SLQSVoiceSendFlash (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceSendFlash_t * *pOutput*)

sends a simple flash message unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.59 int unpack_voice_SLQSVoiceSetCallBarringPassword (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceSetCallBarringPassword_t * *pOutput*)

Sets a Call Barring Password unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.60 int unpack_voice_SLQSVoiceSetConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceSetConfig_t * *pOutput*)

configuration parameters that control the modem behavior unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.61 int unpack_voice_SLQSVoiceSetPreferredPrivacy (uint8_t * *pResp*, uint16_t *respLen*)

sets the voice privacy preference unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.62 int unpack_voice_SLQSVoiceSetSUPSService (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceSetSUPSService_t * *pOutput*)

call-independent supplementary services unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.63 int unpack_voice_SLQSVoiceStartContDTMF (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceStartContDTMF_t * *pOutput*)

Starts a continuous DTMF unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.5.64 int unpack_voice_SLQSVoiceStopContDTMF (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceStopContDTMF_t * *pOutput*)

Stops a continuous DTMF unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

return eQCWWAN_ERR_NULL_TLV then callID value is invalid.

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43 wds.h File Reference

Data Structures

- struct LibPackQosClassID
- struct LibPackTFTIDParams
- struct LibPackGPRSRequestedQoS
- struct LibPackUMTSQoS
- struct LibPackUMTSReqQoSSigInd
- struct pack_wds_SLQSStartDataSession_t
- struct unpack_wds_SLQSStartDataSession_t
- struct unpack_wds_SLQSSetPacketSrvStatusCallback_t
- struct pack_wds_SLQSStopDataSession_t
- struct wds_ProfileIdentifier
- struct wds_GPRSQoS
- struct wds_PCSCFIPv4ServerAddressList
- struct wds_PCSCFFQDNAddress
- struct wds_PCSCFFQDNAddressList
- struct wds_Domain
- struct wds_DomainNameList
- struct wds_IPV6AddressInfo
- struct wds_IPV6GWAddressInfo
- struct unpack_wds_SLQSGetRuntimeSettings_t

- struct wds_currNetworkInfo
- struct unpack_wds_SLQSSetWdsEventCallback_ind_t
- struct pack_wds_SLQSSetWdsEventCallback_t
- struct pack_wds_SLQSGetRuntimeSettings_t
- struct wds_UMTSMinQoS
- struct LibPackprofile_3GPP
- struct LibPackprofile_3GPP2
- union wds_profileInfo
- struct pack_wds_SLQSCreateProfile_t
- struct PackCreateProfileOut
- struct unpack_wds_SLQSCreateProfile_t
- struct pack_wds_SLQSModifyProfile_t
- struct unpack_wds_SLQSModifyProfile_t
- struct pack_wds_SLQSGetProfileSettings_t
- struct LibpackProfile3GPP
- struct LibpackProfile3GPP2
- union unpackWdsProfileParam
- struct UnPackGetProfileSettingOut
- struct unpack_wds_SLQSGetProfileSettings_t
- struct unpack_wds_GetSessionState_t
- struct pack_wds_GetDefaultProfile_t
- struct unpack_wds_GetDefaultProfile_t
- struct unpack_wds_GetConnectionRate_t
- struct pack_wds_GetPacketStatus_t
- struct unpack_wds_GetPacketStatus_t
- struct unpack_wds_GetSessionDuration_t
- struct pack_wds_GetSessionDuration_t
- struct unpack_wds_GetDormancyState_t
- struct pack_wds_GetDormancyState_t
- struct pack_wds_SLQSDeleteProfile_t
- struct unpack_wds_SLQSDeleteProfile_t
- struct pack_wds_SetDefaultProfile_t
- struct unpack_wds_SLQSGet3GPPConfigItem_t
- struct pack_wds_SLQSSet3GPPConfigItem_t
- struct unpack_wds_GetMobileIP_t
- struct pack_wds_GetMobileIP_t
- struct pack_wds_GetMobileIPProfile_t
- struct unpack_wds_GetMobileIPProfile_t
- struct currNetworkInfo
- struct unpack_wds_SLQSGetCurrDataSystemStat_t
- struct pack_wds_SLQSGetCurrDataSystemStat_t
- struct unpack_wds_GetLastMobileIPError_t
- struct pack_wds_GetLastMobileIPError_t
- struct rmTrasnferStaticsReq
- struct pack_wds_RMSetTransferStatistics_t
- struct unpack_wds_RMSetTransferStatistics_t
- struct pack_wds_SetMobileIPProfile_t
- struct unpack_wds_SetMobileIPProfile_t
- struct pack_wds_SLQSWdsSwiPDPRuntimeSettings_t
- struct ipv6AddressInfo
- struct unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t
- struct wds_transferStatInd
- struct pack_wds_SLQSGetDUNCallInfo_t
- struct connectionStatus
- struct dunchannelRate

- struct unpack_wds_SLQSGetDUNCallInfo_t
- struct qmiWDSDataBearerTechnology
- struct unpack_wds_SLQSGetDataBearerTechnology_t
- struct pack_wds_SLQSGetDataBearerTechnology_t
- struct pack_wds_SLQSSetIPFamilyPreference_t
- struct unpack_wds_SLQSSetIPFamilyPreference_t
- struct pack_wds_SetDefaultProfileNum_t
- struct pack_wds_GetDefaultProfileNum_t
- struct unpack_wds_GetDefaultProfileNum_t
- struct wdsDhcpv4ProfileId
- struct wdsDhcpv4HwConfig
- struct wdsDhcpv4Option
- struct wdsDhcpv4OptionList
- struct pack_wds_SLQSSGetDHCPv4ClientConfig_t
- struct unpack_wds_SLQSSGetDHCPv4ClientConfig_t
- struct pack_wds_GetPacketStatistics_t
- struct unpack_wds_GetPacketStatistics_t
- struct unpack_wds_GetByteTotals_t
- struct unpack_wds_SLQSGetCurrentChannelRate_t
- struct unpack_wds_SLQSSGetLoopback_t
- struct pack_wds_SLQSSSetLoopback_t
- struct wds_DataULongTlv
- struct wds_DataULongLongTlv
- struct unpack_RMTransferStatistics_ind_t
- struct pack_wds_DHCPv4ClientLeaseChange_t
- struct wds_DHCPProfileIdTlv
- struct wds_DHCPLeaseStateTlv
- struct wds_IPv4AdTlv
- struct wds_DHCPOpt
- struct wds_DHCPLeaseOptTlv
- struct unpack_wds_DHCPv4ClientLease_ind_t
- struct pack_wds_SetMobileIP_t
- struct pack_wds_SetMobileIPParameters_t
- struct pack_wds_SetAutoconnect_t
- struct unpack_wds_GetAutoconnect_t
- struct wds_TrStatInd
- struct pack_wds_SLQSWdsSetEventReport_t
- struct wds_DHCPv4ProfileId
- struct wds_DHCPv4HWConfig
- struct wds_DHCPv4Option
- struct wds_DHCPv4OptionList
- struct pack_wds_SLQSSSetDHCPv4ClientConfig_t
- struct unpack_wds_GetDataBearerTechnology_t
- struct ipv6_addr
- struct qmuxIPTable

Macros

- #define IPV6_ADDRESS_ARRAY_SIZE 8
- #define MAX_WDS_3GPP_CONF_LTE_ATTACH_PROFILE_LIST_SIZE 24
- #define PACK_WDS_IPV4 4
- #define PACK_WDS_IPV6 6
- #define BYT_STAT_STAT_MASK 0X000000C0
- #define WDS_DHCP_MAX_NUM_OPTIONS 30
- #define WDS_DHCP_OPTION_DATA_BUF_SIZE 2048 /∗ current max size of raw message in SDK process is 2048 ∗/
- #define IPV6_ADDR_LEN 16

Typedefs

- typedef union unpackWdsProfileParam UnpackQmiProfileInfo

Enumerations

- enum liteQmiDataBearerMasks {
  QMI_LITE_WDS_CURRENT_CALL_DB_MASK = 0x01,
  QMI_LITE_WDS_LAST_CALL_DB_MASK = 0x02 }

Functions

- int pack_wds_SLQSStartDataSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSStartDataSession_t *reqArg)
- int unpack_wds_SLQSStartDataSession (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSStartDataSession_t *pOutput)
- int unpack_wds_SLQSSetPacketSrvStatusCallback (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSetPacketSrvStatusCallback_t *pOutput)
- int pack_wds_SLQSStopDataSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSStopDataSession_t *reqArg)
- int unpack_wds_SLQSStopDataSession (uint8_t *pResp, uint16_t respLen)
- int unpack_wds_SLQSGetRuntimeSettings (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetRuntimeSettings_t *pOutput)
- int unpack_wds_SLQSSetWdsEventCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSetWdsEventCallback_ind_t *pOutput)
- int unpack_wds_SLQSSetWdsEventCallback (uint8_t *pResp, uint16_t respLen)
- int pack_wds_SLQSSetWdsEventCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSetWdsEventCallback_t *reqArg)
- int pack_wds_SLQSGetRuntimeSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSGetRuntimeSettings_t *reqArg)
- int pack_wds_SLQSCreateProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSCreateProfile_t *reqArg)
- int unpack_wds_SLQSCreateProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSCreateProfile_t *pOutput)
- int pack_wds_SLQSModifyProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSModifyProfile_t *reqArg)
- int unpack_wds_SLQSModifyProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSModifyProfile_t *pOutput)
- int pack_wds_SLQSGetProfileSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSGetProfileSettings_t *reqArg)
- int unpack_wds_SLQSGetProfileSettings (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetProfileSettings_t *pOutput)
- int pack_wds_GetSessionState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_GetSessionState (uint8_t *pResp, uint16_t respLen, unpack_wds_GetSessionState_t *pOutput)
- int pack_wds_GetDefaultProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetDefaultProfile_t *reqParam)
- int unpack_wds_GetDefaultProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_GetDefaultProfile_t *pOutput)
- int pack_wds_GetConnectionRate (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_GetConnectionRate (uint8_t *pResp, uint16_t respLen, unpack_wds_GetConnectionRate_t *pOutput)
- int pack_wds_GetPacketStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetPacketStatus_t *reqParam)

- int unpack_wds_GetPacketStatus (uint8_t *pResp, uint16_t respLen, unpack_wds_GetPacketStatus_t *pOutput)
- int pack_wds_GetSessionDuration (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetSessionDuration_t *reqParam)
- int unpack_wds_GetSessionDuration (uint8_t *pResp, uint16_t respLen, unpack_wds_GetSessionDuration_t *pOutput)
- int pack_wds_GetDormancyState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetDormancyState_t *reqParam)
- int unpack_wds_GetDormancyState (uint8_t *pResp, uint16_t respLen, unpack_wds_GetDormancyState_t *pOutput)
- int pack_wds_SLQSDeleteProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSDeleteProfile_t *reqParam)
- int unpack_wds_SLQSDeleteProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSDeleteProfile_t *pOutput)
- int pack_wds_SetDefaultProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetDefaultProfile_t *reqParam)
- int unpack_wds_SetDefaultProfile (uint8_t *pResp, uint16_t respLen)
- int pack_wds_SLQSGet3GPPConfigItem (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSGet3GPPConfigItem (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGet3GPPConfigItem_t *pOutput)
- int pack_wds_SLQSSet3GPPConfigItem (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSet3GPPConfigItem_t *reqParam)
- int unpack_wds_SLQSSet3GPPConfigItem (uint8_t *pResp, uint16_t respLen)
- int pack_wds_GetMobileIP (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetMobileIP_t *pReqParam)
- int unpack_wds_GetMobileIP (uint8_t *pResp, uint16_t respLen, unpack_wds_GetMobileIP_t *pOutput)
- int pack_wds_GetMobileIPProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetMobileIPProfile_t *reqParam)
- int unpack_wds_GetMobileIPProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_GetMobileIPProfile_t *pOutput)
- int pack_wds_SLQSGetCurrDataSystemStat (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSGetCurrDataSystemStat_t *pReqParam)
- int unpack_wds_SLQSGetCurrDataSystemStat (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetCurrDataSystemStat_t *pOutput)
- int pack_wds_GetLastMobileIPError (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetLastMobileIPError_t *pReqParam)
- int unpack_wds_GetLastMobileIPError (uint8_t *pResp, uint16_t respLen, unpack_wds_GetLastMobileIPError_t *pOutput)
- int pack_wds_RMSetTransferStatistics (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_RMSetTransferStatistics_t *reqParam)
- int unpack_wds_RMSetTransferStatistics (uint8_t *pResp, uint16_t respLen, unpack_wds_RMSetTransferStatistics_t *pOutput)
- int pack_wds_SetMobileIPProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetMobileIPProfile_t *reqParam)
- int unpack_wds_SetMobileIPProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_SetMobileIPProfile_t *pOutput)
- int pack_wds_SLQSWdsSwiPDPRuntimeSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSWdsSwiPDPRuntimeSettings_t *reqParam)
- int unpack_wds_SLQSWdsSwiPDPRuntimeSettings (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t *pOutput)
- int pack_wds_SLQSGetDUNCallInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSGetDUNCallInfo_t *reqParam)
- int unpack_wds_SLQSGetDUNCallInfo (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetDUNCallInfo_t *pOutput)
- int pack_wds_SLQSGetDataBearerTechnology (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSGetDataBearerTechnology_t *pReqParam)

- int unpack_wds_SLQSGetDataBearerTechnology (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetDataBearerTechnology_t *pOutput)
- int pack_wds_SLQSSetIPFamilyPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSetIPFamilyPreference_t *pReqParam)
- int unpack_wds_SLQSSetIPFamilyPreference (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSetIPFamilyPreference_t *pOutput)
- int pack_wds_SetDefaultProfileNum (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetDefaultProfileNum_t *pReqParam)
- int unpack_wds_SetDefaultProfileNum (uint8_t *pResp, uint16_t respLen)
- int pack_wds_GetDefaultProfileNum (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetDefaultProfileNum_t *pReqParam)
- int unpack_wds_GetDefaultProfileNum (uint8_t *pResp, uint16_t respLen, unpack_wds_GetDefaultProfileNum_t *pOutput)
- int pack_wds_SLQSSGetDHCPv4ClientConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSGetDHCPv4ClientConfig_t *pReq)
- int unpack_wds_SLQSSGetDHCPv4ClientConfig (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSGetDHCPv4ClientConfig_t *pOutput)
- int pack_wds_GetPacketStatistics (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetPacketStatistics_t *pReq)
- int unpack_wds_GetPacketStatistics (uint8_t *pResp, uint16_t respLen, unpack_wds_GetPacketStatistics_t *pOutput)
- int pack_wds_GetByteTotals (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_GetByteTotals (uint8_t *pResp, uint16_t respLen, unpack_wds_GetByteTotals_t *pOutput)
- int pack_wds_SLQSGetCurrentChannelRate (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSGetCurrentChannelRate (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetCurrentChannelRate_t *pOutput)
- int pack_wds_SLQSSGetLoopback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSSGetLoopback (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSGetLoopback_t *pOutput)
- int pack_wds_SLQSSSetLoopback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSSetLoopback_t *reqArg)
- int unpack_wds_SLQSSSetLoopback (uint8_t *pResp, uint16_t respLen)
- int unpack_wds_RMTransferStatistics_ind (uint8_t *pResp, uint16_t respLen, unpack_RMTransferStatistics_ind_t *pOutput)
- int pack_wds_DHCPv4ClientLeaseChange (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_DHCPv4ClientLeaseChange_t *reqArg)
- int unpack_wds_DHCPv4ClientLeaseChange (uint8_t *pResp, uint16_t respLen)
- int unpack_wds_DHCPv4ClientLease_ind (uint8_t *pResp, uint16_t respLen, unpack_wds_DHCPv4ClientLease_ind_t *pOutput)
- int pack_wds_SetMobileIP (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetMobileIP_t *reqArg)
- int unpack_wds_SetMobileIP (uint8_t *pResp, uint16_t respLen)
- int pack_wds_SetMobileIPParameters (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetMobileIPParameters_t *reqArg)
- int unpack_wds_SetMobileIPParameters (uint8_t *pResp, uint16_t respLen)
- int pack_wds_SetAutoconnect (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetAutoconnect_t *reqArg)
- int unpack_wds_SetAutoconnect (uint8_t *pResp, uint16_t respLen)
- int pack_wds_GetAutoconnect (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_GetAutoconnect (uint8_t *pResp, uint16_t respLen, unpack_wds_GetAutoconnect_t *pOutput)
- int pack_wds_SLQSWdsSetEventReport (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSWdsSetEventReport_t *reqArg)
- int unpack_wds_SLQSWdsSetEventReport (uint8_t *pResp, uint16_t respLen)
- int pack_wds_SLQSWdsGoDormant (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSWdsGoDormant (uint8_t *pResp, uint16_t respLen)

- int pack_wds_SLQSWdsGoActive (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSWdsGoActive (uint8_t *pResp, uint16_t respLen)
- int pack_wds_SLQSResetPacketStatics (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSResetPacketStatics (uint8_t *pResp, uint16_t respLen)
- int pack_wds_SLQSSSetDHCPv4ClientConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSSetDHCPv4ClientConfig_t *reqArg)
- int unpack_wds_SLQSSSetDHCPv4ClientConfig (uint8_t *pResp, uint16_t respLen)
- int pack_wds_GetDataBearerTechnology (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_GetDataBearerTechnology (uint8_t *pResp, uint16_t respLen, unpack_wds_GetDataBearerTechnology_t *pOutput)
- int pack_wds_SetMuxID (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, uint8_t *pMuxID)
- int unpack_wds_SetMuxID (uint8_t *pResp, uint16_t respLen)
- struct ipv6_addr __attribute__ ((__packed__)) ipv6_addr

Variables

- typedef __attribute__
- uint8_t ipv6addr [16]
- uint8_t prefix

9.43.1 Macro Definition Documentation

9.43.1.1 #define BYT_STAT_STAT_MASK 0X000000C0

9.43.1.2 #define IPV6_ADDR_LEN 16

9.43.1.3 #define IPV6_ADDRESS_ARRAY_SIZE 8

9.43.1.4 #define MAX_WDS_3GPP_CONF_LTE_ATTACH_PROFILE_LIST_SIZE 24

9.43.1.5 #define PACK_WDS_IPV4 4

9.43.1.6 #define PACK_WDS_IPV6 6

9.43.1.7 #define WDS_DHCP_MAX_NUM_OPTIONS 30

9.43.1.8 #define WDS_DHCP_OPTION_DATA_BUF_SIZE 2048 /* current max size of raw message in SDK process is 2048 */

9.43.2 Typedef Documentation

9.43.2.1 typedef union unpackWdsProfileParam UnpackQmiProfileInfo

This union WdsProfileParam consists of Profile3GPP and Profile3GPP2 out of which one will be used to create profile.

Parameters

SlqsProfile3GPP	3GPP profile • See LibpackProfile3GPP
SlqsProfile3GPP2	3GPP2 profile • See LibpackProfile3GPP2

9.43.3 Enumeration Type Documentation

9.43.3.1 enum liteQmiDataBearerMasks

Bit mask values to indicate the presence of data bearer information for the current and last data calls

Enumerator

QMI_LITE_WDS_CURRENT_CALL_DB_MASK

QMI_LITE_WDS_LAST_CALL_DB_MASK

9.43.4 Function Documentation

9.43.4.1 struct ipv6_addr __attribute__ ((__packed__))

9.43.4.2 int pack_wds_DHCPv4ClientLeaseChange (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_DHCPv4ClientLeaseChange_t * *reqArg*)

DHCPv4 lease state changes pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.3 int pack_wds_GetAutoconnect (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets auto connect data session setting pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.4 int pack_wds_GetByteTotals (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get Rx/Tx byte counts since the start of the last packet data session pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.5 int pack_wds_GetConnectionRate (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get connection rate pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.43.4.6 int pack_wds_GetDataBearerTechnology (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get current data bearer technology pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.7 int pack_wds_GetDefaultProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetDefaultProfile_t * *reqParam*)

get default profile pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.8 int pack_wds_GetDefaultProfileNum (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetDefaultProfileNum_t * *pReqParam*)

get default profile number pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.9 int pack_wds_GetDormancyState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetDormancyState_t * *reqParam*)

get dormancy state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.43.4.10 int pack_wds_GetLastMobileIPError (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetLastMobileIPError_t * *pReqParam*)

get current data system pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.43.4.11 int pack_wds_GetMobileIP (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetMobileIP_t * *pReqParam*)

get mobile ip mode pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.43.4.12 int pack_wds_GetMobileIPProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetMobileIPProfile_t * *reqParam*)

get mobile ip profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.13 int pack_wds_GetPacketStatistics (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetPacketStatistics_t * *pReq*)

gets current packet transfer counter values pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.14 int pack_wds_GetPacketStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetPacketStatus_t * *reqParam*)

get packet status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.15 int pack_wds_GetSessionDuration (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetSessionDuration_t * *reqParam*)

get session duration pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.43.4.16 int pack_wds_GetSessionState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get session state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.17 int pack_wds_RMSetTransferStatistics (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_RMSetTransferStatistics_t * *reqParam*)

RM set transfer statistics pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Note

PDN Specific: No

9.43.4.18 int pack_wds_SetAutoconnect (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetAutoconnect_t * *reqArg*)

Auto connect data session parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.19 int pack_wds_SetDefaultProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetDefaultProfile_t * *reqParam*)

set default profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.20 int pack_wds_SetDefaultProfileNum (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetDefaultProfileNum_t * *pReqParam*)

set default profile number pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.21 int pack_wds_SetMobileIP (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetMobileIP_t * *reqArg*)

Sets the current mobile IP setting pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.22 int pack_wds_SetMobileIPParameters (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetMobileIPParameters_t * *reqArg*)

Sets the specified mobile IP parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.23 int pack_wds_SetMobileIPProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetMobileIPProfile_t * *reqParam*)

set mobile ip profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.24 int pack_wds_SetMuxID (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, uint8_t * *pMuxID*)

Set MUX ID pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pMuxID*	MUX ID. • 0x80 to 0x88

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.25 int pack_wds_SLQSCreateProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSCreateProfile_t * *reqArg*)

Create Profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.26 int pack_wds_SLQSDeleteProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSDeleteProfile_t * *reqParam*)

delete stored profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.27 int pack_wds_SLQSGet3GPPConfigItem (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get 3Gpp config items pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.28 int pack_wds_SLQSGetCurrDataSystemStat (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSGetCurrDataSystemStat_t * *pReqParam*)

get current data system pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.29 int pack_wds_SLQSGetCurrentChannelRate (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get current Tx/Rx channel bitrate of the current packet data pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.30 int pack_wds_SLQSGetDataBearerTechnology (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSGetDataBearerTechnology_t * *pReqParam*)

get data bearer technology pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.31 int pack_wds_SLQSGetDUNCallInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSGetDUNCallInfo_t * *reqParam*)

get dun call info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.32 int pack_wds_SLQSGetProfileSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSGetProfileSettings_t * *reqArg*)

Get Profile Settings pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.33 int pack_wds_SLQSGetRuntimeSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSGetRuntimeSettings_t * *reqArg*)

get runtime settings pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.34 int pack_wds_SLQSModifyProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSModifyProfile_t * *reqArg*)

Modify Profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.35 int pack_wds_SLQSResetPacketStatics (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Reset packet data transfer statistics pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.36 int pack_wds_SLQSSet3GPPConfigItem (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSSet3GPPConfigItem_t * *reqParam*)

set 3Gpp config items pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.37 int pack_wds_SLQSSetIPFamilyPreference (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_wds_SLQSSetIPFamilyPreference_t * pReqParam)

Set IP Family Preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.38 int pack_wds_SLQSSetWdsEventCallback (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_wds_SLQSSetWdsEventCallback_t * reqArg)

set event callback pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.43.4.39 int pack_wds_SLQSSGetDHCPv4ClientConfig (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_wds_SLQSSGetDHCPv4ClientConfig_t * pReq)

get DHCPv4 Client Config pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.40 int pack_wds_SLQSSGetLoopback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get the value of loopback mode and multiplier pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.41 int pack_wds_SLQSSSetDHCPv4ClientConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSSSetDHCPv4ClientConfig_t * *reqArg*)

Gets the DHCP Client V4 Configuration pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

see qmerrno.h for eQCWWAN_xxx error values

9.43.4.42 int pack_wds_SLQSSSetLoopback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSSSetLoopback_t * *reqArg*)

Enable/disable Data Loopback Mode and set the value of loopback multiplier pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.43 int pack_wds_SLQSStartDataSession (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSStartDataSession_t * *reqArg*)

Start data session

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.44 int pack_wds_SLQSStopDataSession (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSStopDataSession_t * *reqArg*)

stop data session pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.45 int pack_wds_SLQSWdsGoActive (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the device into Active state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.46 int pack_wds_SLQSWdsGoDormant (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the device into dormant state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.47 int pack_wds_SLQSWdsSetEventReport (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_wds_SLQSWdsSetEventReport_t * reqArg)

Sets the event report parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.48 int pack_wds_SLQSWdsSwiPDPRuntimeSettings (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_wds_SLQSWdsSwiPDPRuntimeSettings_t * reqParam)

swi pdp runtime settings pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.43.4.49 int unpack_wds_DHCPv4ClientLease_ind (uint8_t * pResp, uint16_t respLen, unpack_wds_DHCPv4ClientLease_ind_t * pOutput)

DHCP lease state has changed indication unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.50 int unpack_wds_DHCPv4ClientLeaseChange (uint8_t * *pResp*, uint16_t *respLen*)

DHCPv4 lease state changes unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.51 int unpack_wds_GetAutoconnect (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetAutoconnect_t * *pOutput*)

Gets auto connect data session setting unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.52 int unpack_wds_GetByteTotals (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetByteTotals_t * *pOutput*)

get Rx/Tx byte counts since the start of the last packet data session unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.53 int unpack_wds_GetConnectionRate (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetConnectionRate_t * *pOutput*)

get connection rate unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.54 int unpack_wds_GetDataBearerTechnology (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetDataBearerTechnology_t * *pOutput*)

get current data bearer technology unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.55 int unpack_wds_GetDefaultProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetDefaultProfile_t * *pOutput*)

get default profile unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.56 int unpack_wds_GetDefaultProfileNum (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetDefaultProfileNum_t * *pOutput*)

get default profile number unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.57 int unpack_wds_GetDormancyState (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetDormancyState_t * *pOutput*)

get dormancy state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.58 int unpack_wds_GetLastMobileIPError (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetLastMobileIP-Error_t * *pOutput*)

get current data system unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.59 int unpack_wds_GetMobileIP (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetMobileIP_t * *pOutput*)

get mobile ip mode unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.60 int unpack_wds_GetMobileIPProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetMobileIPProfile_t * *pOutput*)

get mobile ip profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.61 int unpack_wds_GetPacketStatistics (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetPacketStatistics_t * *pOutput*)

gets current packet transfer counter values unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.62 int unpack_wds_GetPacketStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetPacketStatus_t * *pOutput*)

get packet status unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.63 int unpack_wds_GetSessionDuration (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetSessionDuration_t * *pOutput*)

get session duration unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.64 int unpack_wds_GetSessionState (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetSessionState_t * *pOutput*)

get session state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.65 int unpack_wds_RMSetTransferStatistics (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_RMSetTransferStatistics_t * *pOutput*)

RM set transfer statistics unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.66 int unpack_wds_RMTransferStatistics_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_RMTransferStatistics_ind_t * *pOutput*)

RM transfer statistics indication unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.67 int unpack_wds_SetAutoconnect (uint8_t * *pResp*, uint16_t *respLen*)

Auto connect data session parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.68 int unpack_wds_SetDefaultProfile (uint8_t * *pResp*, uint16_t *respLen*)

set default profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.69 int unpack_wds_SetDefaultProfileNum (uint8_t * *pResp*, uint16_t *respLen*)

set default profile number unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.70 int unpack_wds_SetMobileIP (uint8_t * *pResp*, uint16_t *respLen*)

Sets the current mobile IP setting unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.71 int unpack_wds_SetMobileIPParameters (uint8_t * *pResp*, uint16_t *respLen*)

Sets the specified mobile IP parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.72 int unpack_wds_SetMobileIPProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SetMobileIPProfile_t * *pOutput*)

set mobile ip profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.73 int unpack_wds_SetMuxID (uint8_t * *pResp*, uint16_t *respLen*)

Set MUX ID unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.74 int unpack_wds_SLQSCreateProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSCreateProfile_t * *pOutput*)

Create Profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response structure to fill

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.75 int unpack_wds_SLQSDeleteProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSDeleteProfile_t * *pOutput*)

delete stored profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.76 int unpack_wds_SLQSGet3GPPConfigItem (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGet3GPPConfigItem_t * *pOutput*)

get 3GPP config items unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.77 int unpack_wds_SLQSGetCurrDataSystemStat (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetCurrDataSystemStat_t * *pOutput*)

get current data system unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.78 int unpack_wds_SLQSGetCurrentChannelRate (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetCurrentChannelRate_t * *pOutput*)

get current Tx/Rx channel bitrate of the current packet data unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.79 int unpack_wds_SLQSGetDataBearerTechnology (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetDataBearerTechnology_t * *pOutput*)

get data bearer technology unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.80 int unpack_wds_SLQSGetDUNCallInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetDUNCallInfo_t * *pOutput*)

get dun call info unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.81 int unpack_wds_SLQSGetProfileSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetProfileSettings_t * *pOutput*)

get session state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response structure to fill

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.82 int unpack_wds_SLQSGetRuntimeSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetRuntimeSettings_t * *pOutput*)

get runtime settings unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.83 int unpack_wds_SLQSModifyProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSModifyProfile_t * *pOutput*)

Modify Profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response structure to fill

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.84 int unpack_wds_SLQSResetPacketStatics (uint8_t * *pResp*, uint16_t *respLen*)

Reset packet data transfer statistics unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.85 int unpack_wds_SLQSSet3GPPConfigItem (uint8_t * *pResp*, uint16_t *respLen*)

set 3GPP config items unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

9.43.4.86 int unpack_wds_SLQSSetIPFamilyPreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSetIPFamilyPreference_t * *pOutput*)

Set IP Family Preference unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.87 int unpack_wds_SLQSSetPacketSrvStatusCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSetPacketSrvStatusCallback_t * *pOutput*)

set packet srv status callback unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.88 int unpack_wds_SLQSSetWdsEventCallback (uint8_t * *pResp*, uint16_t *respLen*)

set event callback unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.89 int unpack_wds_SLQSSetWdsEventCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSetWdsEventCallback_ind_t * *pOutput*)

set event callback unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.90 int unpack_wds_SLQSSGetDHCPv4ClientConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSGetDHCPv4ClientConfig_t * *pOutput*)

get DHCPv4 Client Config unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.91 int unpack_wds_SLQSSGetLoopback (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSGetLoopback_t * *pOutput*)

get the value of loopback mode and multiplier unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.92 int unpack_wds_SLQSSSetDHCPv4ClientConfig (uint8_t * *pResp*, uint16_t *respLen*)

Gets the DHCP Client V4 Configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.93 int unpack_wds_SLQSSSetLoopback (uint8_t * *pResp*, uint16_t *respLen*)

Enable/disable Data Loopback Mode and set the value of loopback multiplier unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.94 int unpack_wds_SLQSStartDataSession (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSStartDataSession_t * *pOutput*)

start data session unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.95 int unpack_wds_SLQSStopDataSession (uint8_t * *pResp*, uint16_t *respLen*)

stop data session unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.96 int unpack_wds_SLQSWdsGoActive (uint8_t * *pResp*, uint16_t *respLen*)

Gets the device into Active state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.97 int unpack_wds_SLQSWdsGoDormant (uint8_t * *pResp*, uint16_t *respLen*)

Gets the device into dormant state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.98 int unpack_wds_SLQSWdsSetEventReport (uint8_t * *pResp*, uint16_t *respLen*)

Sets the event report parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.4.99 int unpack_wds_SLQSWdsSwiPDPRuntimeSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t * *pOutput*)

get current data system unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.5 Variable Documentation

9.43.5.1 typedef __attribute__

9.43.5.2 uint8_t ipv6addr[16]

9.43.5.3 uint8_t prefix

Index

_3gppRelease
  unpack_wds_SLQSGet3GPPConfigItem_t, 736
__attribute__
  wds.h, 1172, 1208
_litefw_FirmwareInfo_, 29
  szCarrier_str, 29
  szCarrierPriversion_str, 30
  szFwversion_str, 30
  szModelid_str, 30
  szPackageid_str, 30
  szSku_str, 30

AAASPI
  unpack_wds_GetMobileIPProfile_t, 728
AAAState
  unpack_wds_GetMobileIPProfile_t, 728
ACT_CODE_MAX_SIZE
  dms.h, 842
ALS
  voice_getAllCallInformation, 790
AMSSString
  unpack_dms_GetFirmwareRevision_t, 489
  unpack_dms_GetFirmwareRevisions_t, 490
APNName
  unpack_wds_SLQSGetRuntimeSettings_t, 744
accelTemp
  pack_loc_SLQSLOCInjectSensorData_t, 280
acceleroData
  pack_loc_SLQSLOCInjectSensorData_t, 280
acceleroTimeSrc
  pack_loc_SLQSLOCInjectSensorData_t, 280
AccessMac
  nas_protocolSubtypeElement, 182
accolc
  pack_nas_SetACCOLC_t, 285
accuracy
  pack_pds_SetPDSDefaults_t, 313
ackIndicator
  sMSTransferRouteMTMessageInfo, 442
acqOrdeLen
  nas_acqOrderPref, 106
acroamsetting
  pack_wds_SetAutoconnect_t, 389
acsetting
  pack_wds_SetAutoconnect_t, 389
actCode
  pack_dms_ActivateAutomatic_t, 245
ActSetCnt
  nas_NetworkStat1x, 168
ActSetPilotPN
  nas_ActPilotPNElement, 107
ActSetPilotPNStrength
  nas_ActPilotPNElement, 107
action
  pack_nas_InitiateDomainAttach_t, 285
activated_ind
  sms_qaQmi3GPP2BroadcastCfgInfo, 431
  sms_qaQmi3GPPBroadcastCfgInfo, 432
activationState
  pack_dms_SetActivationStatusCallback_t, 246
activationStatus
  dms_ActivationStatusTlv, 50
ActivationStatusTlv
  unpack_dms_SetEventReport_ind_t, 503
activeBandClass
  nas_RFInfoTlv, 188
  RFBandInfoElements, 419
activeChannel
  nas_RFInfoTlv, 188
  RFBandInfoElements, 419
activeInd
  sms_messageWaitingInfoContent, 430
ActiveStatus
  voice_CLIPResp, 782
  voice_CLIRResp, 783
  voice_CNAPResp, 783
  voice_COLPResp, 784
  voice_COLRResp, 785
ActiveTechPref
  unpack_nas_GetNetworkPreference_t, 565
addr
  unpack_qos_IPv4Addr_t, 629
  unpack_qos_IPv6Addr_t, 629
address
  loc_IPv4Info, 97
  loc_IPv6Info, 97
  loc_urlAddr, 104
  unpack_wds_GetMobileIPProfile_t, 728
addressSize
  unpack_sms_GetSMSCAddress_t, 651
aid
  uim_refreshevent, 463
  uim_sessionInformation, 465
  uim_UIMSessionInformation, 469
aidLength
  appStats, 33
  uim_appStatus, 448
  uim_refreshevent, 463
  uim_sessionInformation, 465

uim_UIMSessionInformation, 469
aidVal
appStats, 33
uim_appStatus, 449
aidingIndicatorMask
loc_sensorDataUsage, 102
airTimerValue
voice_airTimer, 764
alertingPattern
voice_arrAlertingPattern, 767
AlertingType
voice_arrAlertingType, 768
alertmsg
unpack_omaDmConfigTlv_t, 613
alertmsglength
unpack_omaDmConfigTlv_t, 613
allCallsAlphaIDInfoArr
voice_arrAlphaID, 768
AllCallsUUSInfo
voice_arrUUSInfo, 774
alphaDcs
voice_alphaIDInfo, 766
AlphaID
cat_AlPhaIdentifierTlv, 41
AlphaIDInfo
voice_allCallsAlphaIDInfo, 764
AlphaIDLength
cat_AlPhaIdentifierTlv, 41
alphaLen
voice_alphaIDInfo, 766
alphaText
voice_alphaIDInfo, 766
altSrcInfo_t, 30
coverage, 31
linkage, 31
source, 31
Altitude
unpack_pds_SLQSGetGPSStateInfo_t, 627
altitudeAssumed
unpack_loc_GnssSvInfo_Ind_t, 548
altitudeSrcInfo
pack_loc_SLQSLOCInjectPosition_t, 278
altitudeWrtEllipsoid
pack_loc_SLQSLOCInjectPosition_t, 278
altitudeWrtMeanSeaLevel
pack_loc_SLQSLOCInjectPosition_t, 278
ambr_dl
unpack_qos_SLQSQosSwiReadApnExtraParams_t, 634
ambr_dl_ext
unpack_qos_SLQSQosSwiReadApnExtraParams_t, 635
ambr_dl_ext2
unpack_qos_SLQSQosSwiReadApnExtraParams_t, 635
ambr_ul
unpack_qos_SLQSQosSwiReadApnExtraParams_t, 635
ambr_ul_ext
unpack_qos_SLQSQosSwiReadApnExtraParams_t, 635
ambr_ul_ext2
unpack_qos_SLQSQosSwiReadApnExtraParams_t, 635
amssSize
unpack_dms_GetFirmwareRevision_t, 489
unpack_dms_GetFirmwareRevisions_t, 490
apdoxypages.c, 821
apnId
pack_qos_SLQSQosSwiReadApnExtraParams_t, 323
pack_qos_SLQSQosSwiReadDataStats_t, 323
unpack_qos_SLQSQosSwiReadApnExtraParams_t, 635
unpack_qos_SLQSQosSwiReadDataStats_t, 636
apnName
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 753
apnname
unpack_wds_GetDefaultProfile_t, 724
apnsize
unpack_wds_GetDefaultProfile_t, 724
appNameLength
loc_LocApplicationInfo, 98
appProviderLength
loc_LocApplicationInfo, 98
appState
appStats, 33
uim_appStatus, 449
appStats, 31
aidLength, 33
aidVal, 33
appState, 33
appType, 33
persoFeature, 33
persoRetries, 33
persoState, 33
persoUnblockRetries, 33
pin1Retries, 34
pin1State, 34
pin2Retries, 34
pin2State, 34
puk1Retries, 34
puk2Retries, 34
univPin, 34
AppStatus
slotInf, 423
uim_slotInfo, 468
appType
appStats, 33
uim_appStatus, 449
appVersionLength
loc_LocApplicationInfo, 98
appVersionValid
loc_LocApplicationInfo, 98
Application

unpack_nas_GetCDMANetworkParameters_t, 560
appversion_str
unpack_dms_GetFirmwareInfo_t, 488
arfcn
nas_GERANInfo, 132
nas_gsmCellInfo, 133
arrfileInfo
uim_refreshevent, 463
uim_registerRefresh, 464
audio.h, 821
pack_audio_SLQSGetAudioPathConfig, 822
pack_audio_SLQSGetAudioProfile, 822
pack_audio_SLQSGetAudioVolTLBConfig, 823
pack_audio_SLQSSetAudioPathConfig, 823
pack_audio_SLQSSetAudioProfile, 824
pack_audio_SLQSSetAudioVolTLBConfig, 824
unpack_audio_SLQSGetAudioPathConfig, 825
unpack_audio_SLQSGetAudioProfile, 825
unpack_audio_SLQSGetAudioVolTLBConfig, 825
unpack_audio_SLQSSetAudioPathConfig, 826
unpack_audio_SLQSSetAudioProfile, 826
unpack_audio_SLQSSetAudioVolTLBConfig, 826
audio_RXAGCList, 34
pRXAIG, 34
pRXComprSlope, 35
pRXComprThres, 35
pRXExpSlope, 35
pRXExpThres, 35
pRXStaticGain, 35
audio_RXAVCList, 35
pAVRXAVCHeadroom, 35
pAVRXAVCSens, 35
audio_RXPCMIIRFltr, 35
pFlag, 37
pStage0Val, 37
pStage1Val, 37
pStage2Val, 37
pStage3Val, 37
pStage4Val, 37
pStageCnt, 37
audio_TXAGCList, 37
pTXAIG, 37
pTXComprSlope, 38
pTXComprThres, 38
pTXExpSlope, 38
pTXExpThres, 38
pTXStaticGain, 38
audio_TXPCMIIRFltr, 38
pFlag, 39
pStage0Val, 39
pStage1Val, 39
pStage2Val, 39
pStage3Val, 39
pStage4Val, 39
pStageCnt, 39
auth
unpack_wds_GetDefaultProfile_t, 724
authData
pack_uim_SLQSUIMAuthenticate_t, 357
AuthProt
nas_protocolSubtypeElement, 183
Authentication
unpack_wds_SLQSGetRuntimeSettings_t, 744
authentication
pack_wds_SetDefaultProfile_t, 390
AutoConnect
pack_swiavms_SLQSAVMSSetSettings_t, 343
unpack_swiavms_SLQSAVMSGetSettings_t, 665
AutoReboot
pack_swiavms_SLQSAVMSSetSettings_t, 343
unpack_swiavms_SLQSAVMSGetSettings_t, 665
Autosdm
unpack_swioma_SLQSOMADMGetSettings_t, 674
avgPeriod
nas_LTESigRptCfg, 157
nas_LTESigRptConfig, 158
azimuth
loc_satelliteInfo, 101

bAPNLength
PackSwiAvmsSetSettingsAPNInfo, 411
PackSwiAVMSSettingsAPNInfo, 413
bAuto
pack_pds_SetPortAutomaticTracking_t, 314
pack_pds_SetServiceAutomaticTracking_t, 314
bBinaryType
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 756
bEnable
pack_dms_UIMSetPINProtection_t, 257
pack_nas_SLQSSetSignalStrengthsCallback_t, 304
bEnabled
pack_pds_SetXTRAAutomaticDownload_t, 315
bForceDownload
pack_fms_SetImagesPreference_t, 261
bICCID
slot_t, 422
bICCIDLength
slot_t, 422
bLogicalSlot
pack_uim_SLQSUIMSwitchSlot_t, 363
slot_t, 422
bNotification
UnpackSwiAvmsEventReportNotification, 760
bNumberOfPhySlots
unpack_uim_SetUimSlotStatusChangeCallback_-ind_t, 682
BOOL
SwiDataTypes.h, 1100
BPTlv
NASQmiCbkNasSystemSelPrefInd, 232
bPWDLength
PackSwiAvmsSetSettingsAPNInfo, 411
PackSwiAVMSSettingsAPNInfo, 413
bPackageID
UnpackSwiAvmsEventReportPackageID, 761

bRegStatus
UnpackSwiAvmsEventReportRegStatus, 761
bResetStatistics
rmTrasnferStaticsReq, 419
bSerity
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 756
bState
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 756
UnpackSwiAvmsEventReportConfig, 757
bType
UnpackSwiAvmsEventReportDataSessionStatus, 758
UnpackSwiAvmsEventReportSessionType, 762
bUnameLength
PackSwiAvmsSetSettingsAPNInfo, 412
PackSwiAVMSSettingsAPNInfo, 413
bUserInputRequest
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 756
UnpackSwiAvmsEventReportConfig, 757
UnpackSwiAvmsEventReportConnectionRequest, 758
BYT_STAT_STAT_MASK
wds.h, 1171
BYTE
SwiDataTypes.h, 1100
band
nas_LTEInfo, 149
band1900
nas_gsmCellInfo, 134
band_pref
NASBandPreferenceTlv, 222
BandCapability
unpack_dms_GetBandCapability_t, 478
bandCapability
unpack_dms_SLQSGetBandCapability_t, 510
bandPref
pack_nas_SLQSSetBandPreference_t, 303
bandwidth
nas_LTEInfo, 149
baseId
nas_CDMAInfo, 112
nas_CDMASysInfo, 116
baseLat
nas_CDMAInfo, 112
nas_CDMASysInfo, 116
baseLong
nas_CDMAInfo, 112
nas_CDMASysInfo, 116
BasestationID
unpack_nas_SLQSGetServingSystem_t, 583
BasestationLatitude
unpack_nas_SLQSGetServingSystem_t, 583
BasestationLongitude
unpack_nas_SLQSGetServingSystem_t, 583
BearerID
unpack_qos_QosFlowInfo_t, 632
bearerID
unpack_wds_SLQSSetPacketSrvStatusCallback_-t, 747
bearerId
unpack_QosFlowStat_t, 648
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 753
bootSize
unpack_dms_GetFirmwareRevisions_t, 490
BootString
unpack_dms_GetFirmwareRevisions_t, 490
bootversion_str
unpack_dms_GetFirmwareInfo_t, 488
Broadcast
unpack_nas_GetCDMANetworkParameters_t, 560
broadcastActivate
pack_sms_SLQSSetSmsBroadcastActivation_t, 332
broadcastConfig
sms_qaQmi3GPPBroadcastCfgInfo, 432
bsInfoValid
nas_CDMASysInfo, 116
bsPRev
nas_CDMASysInfo, 116
bsPRevValid
nas_CDMASysInfo, 116
bsic
nas_GERANInfo, 132
bsicId
nas_gsmCellInfo, 134
bucketSz
unpack_qos_tokenBucket_t, 647
buildID
FMSImageIdElement, 57
image_info_t, 60
buildIDLen
image_info_t, 60
buildIDLength
FMSImageIdElement, 57
buildId
FMSImageElement, 56
buildIdLength
FMSImageElement, 56
BurstDTMFInfo
pack_voice_SLQSVoiceBurstDTMF_t, 368
ByteLoopbackMode
unpack_wds_SLQSSGetLoopback_t, 751
ByteLoopbackMultiplier
unpack_wds_SLQSSGetLoopback_t, 751

CCETlv
unpack_cat_SetCatEventCallback_ind_t, 474
CDMA_P_Rev
unpack_nas_SLQSGetServingSystem_t, 583
CDMABroadcastConfig
sms_qaQmi3GPP2BroadcastCfgInfo, 431
CDMAECIOThreshListLen
nas_CDMAECIOThresh, 111

CDMARSSIThreshListLen
nas_CDMARSSIThresh, 113
CDMASSInfo
unpack_nas_SLQSNasGetSigInfo_t, 599
CDMASystemInfoExt
unpack_nas_SLQSGetServingSystem_t, 583
CHAR
SwiDataTypes.h, 1100
CK_MAX_SIZE
dms.h, 842
CQIValueCW0
unpack_nas_SLQSSwiGetLteCQI_t, 607
CQIValueCW1
unpack_nas_SLQSSwiGetLteCQI_t, 607
CSDomain
unpack_nas_GetServingNetwork_t, 568
CUGIndex
voice_CUGInfo, 787
CallBarStatus
unpack_nas_SLQSGetServingSystem_t, 583
callDuration
unpack_wds_GetSessionDuration_t, 732
callEndReason
unpack_wds_SLQSGetDUNCallInfo_t, 741
voice_arrCallEndReason, 769
CallFWExtInfo
voice_getCallFWExtInfo, 791
CallFWInfo
voice_getCallFWInfo, 792
callID
pack_voice_SLQSVoiceGetCallInfo_t, 373
pack_voice_SLQSVoiceStopContDTMF_t, 384
unpack_voice_SLQSVoiceStopContDTMF_t, 719
voice_allCallsAlphaIDInfo, 764
voice_allCallsDiagInfo, 765
voice_allCallsUUSInfo, 765
voice_arrAlertingPattern, 767
voice_arrAlertingType, 768
voice_arrCallEndReason, 769
voice_arrSvcOption, 773
voice_callInfo, 780
voice_getAllCallRmtPtyName, 790
voice_getAllCallRmtPtyNum, 791
voice_peerNumberInfo, 794
callNumber
pack_voice_SLQSVoiceDialCall_t, 370
callState
voice_callInfo, 780
callType
voice_callInfo, 781
CalledPartyNum
voice_arrCalledPartyNum, 769
callerID
voice_connectNumInfo, 786
callerIDLen
voice_connectNumInfo, 786
callerName
voice_remotePartyName, 796
Callinfo
voice_getAllCallInformation, 790
cardState
slotInf, 423
uim_slotInfo, 468
carrier
unpack_dms_SLQSSwiGetFirmwareCurr_t, 513
carrier_str
unpack_dms_GetFirmwareInfo_t, 488
CarrierImage_t, 39
m_FwBuildId, 40
m_FwImageId, 40
m_PriBuildId, 40
m_PriImageId, 41
m_nCarrierId, 40
m_nFolderId, 40
m_nStorage, 40
cat.h, 827
pack_cat_CATSendEnvelopeCommand, 827
pack_cat_CATSendTerminalResponse, 828
pack_cat_SetCATEventCallback, 828
unpack_cat_CATSendEnvelopeCommand, 829
unpack_cat_CATSendTerminalResponse, 829
unpack_cat_SetCATEventCallback, 829
unpack_cat_SetCatEventCallback_ind, 830
cat_AlPhaIdentifierTlv, 41
AlphaID, 41
AlphaIDLength, 41
ReferenceID, 41
cat_EndProactiveSessionTlv, 43
EndProactiveSession, 43
cat_EventIDDataTlv, 43
Data, 43
DataLength, 43
ReferenceID, 43
cat_EventListTlv, 43
SetupEventList, 44
cat_RefreshTlv, 44
RefreshMode, 44
RefreshStage, 44
cat_commonEventTlv, 41
CatEvent, 42
EventID, 42
EventLength, 42
TlvPresent, 42
cat_currentCatEvent, 42
CatAlphaIdtfr, 42
CatEndPS, 42
CatEvIDData, 42
CatEventLst, 42
CatRefresh, 42
CatAlphaIdtfr
cat_currentCatEvent, 42
CatEndPS
cat_currentCatEvent, 42
CatEvIDData
cat_currentCatEvent, 42
CatEvent

cat_commonEventTlv, 42
CatEventLst
cat_currentCatEvent, 42
CatRefresh
cat_currentCatEvent, 42
ccsSupported
nas_CDMASysInfo, 116
ccsSupportedValid
nas_CDMASysInfo, 116
cdmaSSInfo, 44
ecio, 45
rssi, 45
cdmaSysIdValid
nas_CDMASysInfo, 116
cell_resel_priority
nas_infoInterFreq, 144
cellBroadcastCap
nas_AddSysInfo, 108
CellID
unpack_nas_SLQSGetServingSystem_t, 583
cellID
nas_GERANInfo, 132
nas_UMTSInfo, 212
cellId
nas_GSMSysInfo, 137
nas_LTESysInfo, 162
nas_WCDMASysInfo, 220
cellIdValid
nas_gsmCellInfo, 134
nas_GSMSysInfo, 137
nas_LTESysInfo, 162
nas_WCDMASysInfo, 221
cellInterFreqParams
nas_infoInterFreq, 144
cellIsTDD
nas_umtsLTENbrCell, 214
CellParams
nas_LTEInfoIntrafreq, 152
cellReselPriority
nas_lteGsmCellInfo, 147
nas_LTEInfoIntrafreq, 152
nas_lteWcdmaCellInfo, 163
cells_len
nas_infoInterFreq, 144
nas_lteGsmCellInfo, 147
cellsLen
nas_LTEInfoIntrafreq, 152
nas_lteWcdmaCellInfo, 163
chaddr
wds_DHCPv4HWConfig, 805
wdsDhcpv4HwConfig, 817
chaddrLen
wds_DHCPv4HWConfig, 805
wdsDhcpv4HwConfig, 817
changePIN
pack_uim_ChangePin_t, 354
channelRate
unpack_wds_SLQSGetDUNCallInfo_t, 741
Chipset
nas_DeviceConfigDetail, 127
ckLen
uim_depersonalizationInformation, 454
ckVal
uim_depersonalizationInformation, 454
clear
pack_dms_SLQSSwiGetCrashInfo_t, 252
cmdID
pack_cat_CATSendEnvelopeCommand_t, 243
codingScheme
nas_PLMNNetworkNameData, 181
voice_remotePartyName, 797
common.h
eAUDIO, 833
eCAT, 833
eCTL, 833
eDMS, 833
eIMS, 833
eIMSA, 833
eIND, 834
eLOC, 833
eLOG_DEBUG, 833
eLOG_FATAL, 833
eLOG_INFO, 833
eLOG_WARN, 833
eNAS, 833
ePDS, 833
eQOS, 833
eREQ, 834
eRMS, 833
eRSP, 834
eSAR, 833
eSMS, 833
eSWIAUDIO, 833
eSWILOC, 833
eSWIM2MCMD, 833
eSWIOMA, 833
eSWIOMAEXT, 833
eTIMEOUT_10_S, 834
eTIMEOUT_20_S, 834
eTIMEOUT_2_S, 834
eTIMEOUT_300_S, 834
eTIMEOUT_30_S, 834
eTIMEOUT_5_S, 834
eTIMEOUT_60_S, 834
eTIMEOUT_8_S, 834
eTIMEOUT_DEFAULT, 834
eTMD, 833
eUIM, 833
eVOICE, 833
eWDS, 833
common.h, 830
eLOG_LEVEL, 833
eQMI_SVC, 833
eTimeout, 833
fill_pack_ctx, 834
fill_sdu_hdr, 834

get_version, 834
glog, 835
gloglvl, 835
helper_get_resp_ctx, 834
helper_get_xid, 834
helper_set_log_func, 835
helper_set_log_lvl, 835
liteqmi_GetVersion, 835
liteqmi_helper_decode7bitAsciiEncString, 835
liteqmi_log, 835
logger, 833
MINREQBKLEN, 832
MSGID_AND_LEN, 832
MSGID_DONT_CARE, 832
msgtype, 834
SDU_HDR_LEN, 832
UNUSEDPARAM, 833
unpack_result_code_only, 835
commonInfo
unpack_nas_SLQSNasSwiModemStatus_t, 603
ConcSvcInfo
unpack_nas_SLQSGetServingSystem_t, 583
confidence
pack_loc_SLQSLOCSetCradleMountConfig_t, 282
conn_status
unpack_wds_SLQSSetPacketSrvStatusCallback_t, 747
ConnectedPartyNum
voice_arrConnectPartyNum, 771
connectionStatus, 45
MDMCallDuration, 45
MDMConnStatus, 45
unpack_wds_GetSessionState_t, 733
unpack_wds_SLQSGetDUNCallInfo_t, 741
content
uim_authenticateResult, 449
uim_readResult, 461
contentLen
uim_authenticateResult, 449
uim_readResult, 461
context
uim_authenticationData, 450
contextId
pack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 409
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 753
contextType
pack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 409
ControlMac
nas_protocolSubtypeElement, 183
countryInitials
nas_PLMNNetworkNameData, 181
coverage
altSrcInfo_t, 31
cpich_ecno
nas_wcdmaCellInfo, 216
cpich_rscp
nas_wcdmaCellInfo, 216
crashAction
pack_dms_SetCrashAction_t, 247
crashData
crashInformation, 47
crashId
crashInformation, 47
crashInfo
crashInfoParams, 46
crashInfoParam
unpack_dms_SLQSSwiGetCrashInfo_t, 511
crashInfoParams, 46
crashInfo, 46
crashStatus, 46
crashInformation, 46
crashData, 47
crashId, 47
crashString, 47
crashStrlen, 47
gcdumpString, 47
gcdumpStrlen, 47
numCrashes, 47
crashStatus
crashInfoParams, 46
crashString
crashInformation, 47
crashStrlen
crashInformation, 47
csAttachState
nas_servSystem, 197
NASServingSystemInfo, 235
csBarStatus
nas_CallBarringSysInfo, 109
nas_callBarStatus, 110
cur_carr_name
unpack_dms_GetFirmwareInfo_t, 488
cur_carr_rev
unpack_dms_GetFirmwareInfo_t, 488
curDataBearerTechnology
unpack_wds_SLQSGetDataBearerTechnology_t, 738
curProfile
pack_wds_SLQSModifyProfile_t, 401
UnPackGetProfileSettingOut, 754
CurrChanRxRate
dunchannelRate, 54
CurrChanTxRate
dunchannelRate, 54
currDBTechAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
currNWInfo
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
currNetworkInfo, 47
NetworkType, 49
RATMask, 49

SOMask, 49
unpack_wds_SLQSGetCurrDataSystemStat_t, 737
current_channel_rx_rate
unpack_wds_SLQSGetCurrentChannelRate_t, 737
current_channel_tx_rate
unpack_wds_SLQSGetCurrentChannelRate_t, 737
currentChannelRXRate
unpack_wds_GetConnectionRate_t, 721
currentChannelTXRate
unpack_wds_GetConnectionRate_t, 721
currentDataBearer
pack_wds_SLQSSetWdsEventCallback_t, 404
currentNetwork
qmiWDSDataBearerTechnology, 416
CurrentPLMN
unpack_nas_SLQSGetServingSystem_t, 583
CurrentmitigationLvl
unpack_tmd_SLQSTmdGetMitigationLvl_t, 677
cust_attr
DMScustSettingInfo, 51
cust_id
DMScustSettingInfo, 51
DMSgetCustomInput, 53
pack_dms_GetCustFeaturesV2_t, 245
pack_dms_SetCustFeaturesV2_t, 250
cust_value
DMScustSettingInfo, 51
pack_dms_SetCustFeaturesV2_t, 250
custSetting
DMScustSettingList, 52
CustomSCP
unpack_nas_GetCDMANetworkParameters_t, 560
CwtMute
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 660
unpack_swiaudio_SLQSGetM2MAVMute_t, 662

dBTechAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
dBTechExtRatValue
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
dBTechExtSoMask
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
dBTechnology
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
dBtechExtAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
dBtechnologyExt
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
DHCPRelayEnabled
pack_dms_SetCustFeature_t, 249
unpack_dms_GetCustFeature_t, 480
DHCPv4LeaseOptTlv
unpack_wds_DHCPv4ClientLease_ind_t, 719
DHCPv4LeaseStateTlv
unpack_wds_DHCPv4ClientLease_ind_t, 719
dLatitude
unpack_pds_SetEventReport_Ind_t, 622
dLongitude
unpack_pds_SetEventReport_Ind_t, 622
DMS_IMGDETAILS_LEN
dms.h, 842
DMS_PM_FACTORY
dms.h, 842
DMS_PM_LOW
dms.h, 842
DMS_PM_OFFLINE
dms.h, 842
DMS_PM_ONLINE
dms.h, 842
DMS_PM_RESET
dms.h, 842
DMS_PM_SHUT_DOWN
dms.h, 842
DMS_VALID_FSN_LEN
dms.h, 843
DMScustSettingInfo, 51
cust_attr, 51
cust_id, 51
cust_value, 51
id_length, 51
value_length, 51
DMScustSettingList, 52
custSetting, 52
list_type, 52
num_instances, 52
DMSgetCustomFeatureV2, 52
pCustSettingInfo, 53
pCustSettingList, 53
pGetCustomInput, 53
DMSgetCustomInput, 53
cust_id, 53
list_type, 53
DRCCover
nas_DRCParams, 128
DRCValue
nas_DRCParams, 128
DTMFInterdigitInterval
voice_DTMFLengths, 789
DTMFPulseWidth
voice_DTMFLengths, 789
DTMFdigit
pack_voice_SLQSVoiceStartContDTMF_t, 383
DTMInd
unpack_nas_SLQSGetServingSystem_t, 583
Data
cat_EventIDDataTlv, 43
data

sMSCAddressInfo, 438
sMSEtwsMessageInfo, 439
sMSTransferRouteMTMessageInfo, 442
uim_authenticationData, 450
data_buf
NASOTAMessageTlv, 226
data_len
NASOTAMessageTlv, 226
dataBearer
pack_wds_SLQSSetWdsEventCallback_t, 404
dataBearerMask
unpack_wds_SLQSGetDataBearerTechnology_t, 738
dataBearerTech
unpack_wds_SLQSGetDUNCallInfo_t, 741
dataBearerTechExt
pack_wds_SLQSSetWdsEventCallback_t, 404
dataCapabilities
nas_dataSrvCapabilities, 122
dataCapabilitiesLen
nas_dataSrvCapabilities, 122
DataCaps
unpack_nas_GetServingNetwork_t, 568
unpack_nas_GetServingNetworkCapabilities_t, 569
dataCaps
unpack_nas_SetDataCapabilitiesCallback_ind_t, 571
DataCapsLen
unpack_nas_GetServingNetwork_t, 568
unpack_nas_GetServingNetworkCapabilities_t, 569
dataCapsSize
unpack_nas_SetDataCapabilitiesCallback_ind_t, 571
dataLen
pack_cat_CATSendEnvelopeCommand_t, 243
pack_cat_CATSendTerminalResponse_t, 244
uim_authenticationData, 450
DataLength
cat_EventIDDataTlv, 43
DataRate
unpack_qos_swiQosFlow_t, 645
dataRateMax
unpack_qos_dataRate_t, 629
dataServiceCaCapability
unpack_dms_GetDeviceCapabilities_t, 483
DataServiceCapability
unpack_dms_GetDeviceCap_t, 482
DataSrvCapabilities
unpack_nas_SLQSGetServingSystem_t, 583
dataSysStatAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
dataSystemStatus
pack_wds_SLQSSetWdsEventCallback_t, 404
Date
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
DateLength
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
day
nas_timeInfo, 209
nas_UniversalTime, 215
dayLtSavingAdj
nas_timeInfo, 209
dayOfWeek
nas_timeInfo, 209
nas_UniversalTime, 215
daylightSavings
nas_qaQmi3Gpp2TimeZone, 183
defaultPDNEnabled
unpack_wds_SLQSGet3GPPConfigItem_t, 736
DefaultRoamInd
unpack_nas_SLQSGetServingSystem_t, 583
delayClass
LibPackGPRSRequestedQoS, 62
wds_GPRSQoS, 808
deliveryErrSDU
LibPackUMTSQoS, 90
wds_UMTSMinQoS, 816
depersonilisationInfo
pack_uim_SLQSUIMDepersonalization_t, 357
description
unpack_omaDmFotaTlv_t, 614
descriptionlength
unpack_omaDmFotaTlv_t, 614
Desription
nas_QmiNas3GppNetworkInfo, 185
destPortRangeEnd
LibPackTFTIDParams, 87
destPortRangeStart
LibPackTFTIDParams, 88
DetailedSvcInfo
unpack_nas_SLQSGetServingSystem_t, 583
DevCrashState
unpack_dms_GetCrashAction_t, 478
Device
pack_swiaudio_SLQSSetM2MAudioAVCFG_t, 337
deviceID
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t, 677
deviceIdLen
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t, 677
DiagInfo
voice_allCallsDiagInfo, 765
voice_arrDiagInfo, 771
diagInfoLen
voice_diagInfo, 788
diagnosticInfo
voice_diagInfo, 788
digitCnt
voice_burstDTMFInfo, 775

dirNum
nas_dirNum, 127
dirNumLen
nas_dirNum, 127
direction
voice_callInfo, 781
DisableIMSI
pack_dms_SetCustFeature_t, 249
unpack_dms_GetCustFeature_t, 480
displayCondition
nas_serviceProviderName, 196
dl_bw_value
nas_PhyCaAggPcellInfo, 174
nas_PhyCaAggScellDlBw, 174
nas_PhyCaAggScellInfo, 178
NASPhyCaAggPcellInfo, 227
NASPhyCaAggScellDlBw, 228
NASPhyCaAggScellInfo, 230
dms.h, 835
ACT_CODE_MAX_SIZE, 842
CK_MAX_SIZE, 842
DMS_IMGDETAILS_LEN, 842
DMS_PM_FACTORY, 842
DMS_PM_LOW, 842
DMS_PM_OFFLINE, 842
DMS_PM_ONLINE, 842
DMS_PM_RESET, 842
DMS_PM_SHUT_DOWN, 842
DMS_VALID_FSN_LEN, 843
ERI_DATA_MAX_SIZE, 843
MAX_BUILD_ID_LEN, 843
MEID_MAX_SIZE, 843
pack_dms_ActivateAutomatic, 843
pack_dms_GetActivationState, 843
pack_dms_GetBandCapability, 844
pack_dms_GetCrashAction, 844
pack_dms_GetCustFeature, 844
pack_dms_GetCustFeaturesV2, 845
pack_dms_GetDeviceCap, 845
pack_dms_GetDeviceCapabilities, 845
pack_dms_GetDeviceHardwareRev, 846
pack_dms_GetDeviceMfr, 846
pack_dms_GetDeviceSerialNumbers, 847
pack_dms_GetFSN, 848
pack_dms_GetFirmwareInfo, 847
pack_dms_GetFirmwareRevision, 847
pack_dms_GetFirmwareRevisions, 848
pack_dms_GetHardwareRevision, 848
pack_dms_GetIMSI, 849
pack_dms_GetManufacturer, 849
pack_dms_GetModelID, 849
pack_dms_GetNetworkTime, 850
pack_dms_GetOfflineReason, 850
pack_dms_GetPRLVersion, 851
pack_dms_GetPower, 850
pack_dms_GetSerialNumbers, 851
pack_dms_GetUSBComp, 851
pack_dms_GetVoiceNumber, 852
pack_dms_ResetToFactoryDefaults, 852
pack_dms_SLQSDmsSwiGetResetInfo, 856
pack_dms_SLQSDmsSwiIndicationRegister, 856
pack_dms_SLQSGetBandCapability, 856
pack_dms_SLQSGetERIFile, 857
pack_dms_SLQSSwiClearDyingGaspStatistics, 857
pack_dms_SLQSSwiGetCrashInfo, 857
pack_dms_SLQSSwiGetDyingGaspCfg, 858
pack_dms_SLQSSwiGetDyingGaspStatistics, 858
pack_dms_SLQSSwiGetFirmwareCurr, 858
pack_dms_SLQSSwiGetFwUpdateStatus, 859
pack_dms_SLQSSwiGetHostDevInfo, 859
pack_dms_SLQSSwiGetOSInfo, 859
pack_dms_SLQSSwiGetSerialNoExt, 860
pack_dms_SLQSSwiSetDyingGaspCfg, 860
pack_dms_SLQSSwiSetHostDevInfo, 860
pack_dms_SLQSSwiSetOSInfo, 861
pack_dms_SLQSUIMGetState, 861
pack_dms_SetActivationStatusCallback, 853
pack_dms_SetCrashAction, 853
pack_dms_SetCustFeature, 853
pack_dms_SetCustFeaturesV2, 854
pack_dms_SetEventReport, 854
pack_dms_SetFirmwarePreference, 854
pack_dms_SetPower, 855
pack_dms_SetUSBComp, 855
pack_dms_UIMChangePIN, 861
pack_dms_UIMGetControlKeyStatus, 862
pack_dms_UIMGetICCID, 862
pack_dms_UIMGetPINStatus, 863
pack_dms_UIMSetControlKeyProtection, 863
pack_dms_UIMSetPINProtection, 863
pack_dms_UIMUnblockControlKey, 864
pack_dms_UIMUnblockPIN, 864
pack_dms_UIMVerifyPIN, 864
pack_dms_ValidateSPC, 865
SPC_SIZE, 843
UNIQUE_ID_LEN, 843
unpack_dms_ActivateAutomatic, 865
unpack_dms_GetActivationState, 866
unpack_dms_GetBandCapability, 866
unpack_dms_GetCrashAction, 866
unpack_dms_GetCustFeature, 867
unpack_dms_GetCustFeaturesV2, 867
unpack_dms_GetDeviceCap, 867
unpack_dms_GetDeviceCapabilities, 868
unpack_dms_GetDeviceHardwareRev, 868
unpack_dms_GetDeviceMfr, 868
unpack_dms_GetDeviceSerialNumbers, 869
unpack_dms_GetFSN, 870
unpack_dms_GetFirmwareInfo, 869
unpack_dms_GetFirmwareRevision, 869
unpack_dms_GetFirmwareRevisions, 870
unpack_dms_GetHardwareRevision, 870
unpack_dms_GetIMSI, 871
unpack_dms_GetManufacturer, 871
unpack_dms_GetModelID, 871

unpack_dms_GetNetworkTime, 872
unpack_dms_GetOfflineReason, 872
unpack_dms_GetPRLVersion, 873
unpack_dms_GetPower, 872
unpack_dms_GetSerialNumbers, 873
unpack_dms_GetUSBComp, 873
unpack_dms_GetVoiceNumber, 874
unpack_dms_ResetToFactoryDefaults, 874
unpack_dms_SLQSDmsSwiGetResetInfo, 878
unpack_dms_SLQSDmsSwiGetResetInfo_Ind, 878
unpack_dms_SLQSDmsSwiIndicationRegister, 878
unpack_dms_SLQSGetBandCapability, 879
unpack_dms_SLQSGetERIFile, 879
unpack_dms_SLQSSwiClearDyingGaspStatistics, 879
unpack_dms_SLQSSwiGetCrashInfo, 880
unpack_dms_SLQSSwiGetDyingGaspCfg, 880
unpack_dms_SLQSSwiGetDyingGaspStatistics, 880
unpack_dms_SLQSSwiGetFirmwareCurr, 881
unpack_dms_SLQSSwiGetFwUpdateStatus, 881
unpack_dms_SLQSSwiGetHostDevInfo, 882
unpack_dms_SLQSSwiGetOSInfo, 882
unpack_dms_SLQSSwiGetSerialNoExt, 882
unpack_dms_SLQSSwiSetDyingGaspCfg, 883
unpack_dms_SLQSSwiSetHostDevInfo, 883
unpack_dms_SLQSSwiSetOSInfo, 883
unpack_dms_SLQSUIMGetState, 884
unpack_dms_SetActivationStatusCallback, 874
unpack_dms_SetCrashAction, 875
unpack_dms_SetCustFeature, 875
unpack_dms_SetCustFeaturesV2, 875
unpack_dms_SetEventReport, 876
unpack_dms_SetEventReport_ind, 876
unpack_dms_SetFirmwarePreference, 876
unpack_dms_SetPower, 877
unpack_dms_SetUSBComp, 877
unpack_dms_UIMChangePIN, 884
unpack_dms_UIMGetControlKeyStatus, 884
unpack_dms_UIMGetICCID, 885
unpack_dms_UIMGetPINStatus, 885
unpack_dms_UIMSetControlKeyProtection, 885
unpack_dms_UIMSetPINProtection, 886
unpack_dms_UIMUnblockControlKey, 886
unpack_dms_UIMUnblockPIN, 886
unpack_dms_UIMVerifyPIN, 887
unpack_dms_ValidateSPC, 887
dms_ActivationStatusTlv, 49
activationStatus, 50
TlvPresent, 50
dms_OperatingModeTlv, 50
operatingMode, 50
TlvPresent, 51
domain
wds_DomainNameList, 808
domainLen
wds_Domain, 807
DomainList
unpack_wds_SLQSGetRuntimeSettings_t, 744
domainName
wds_Domain, 807
dormancyStatAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
dormancyState
unpack_wds_GetDormancyState_t, 725
dormancyStatus
pack_wds_SLQSSetWdsEventCallback_t, 404
unpack_wds_SLQSGetDUNCallInfo_t, 741
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
dtmSupp
nas_GSMSysInfo, 137
dtmSuppValid
nas_GSMSysInfo, 137
dunchannelRate, 53
CurrChanRxRate, 54
CurrChanTxRate, 54
MaxChanRxRate, 54
MaxChanTxRate, 54
Duration
pack_nas_SetNetworkPreference_t, 287
unpack_nas_GetNetworkPreference_t, 565

eAUDIO
common.h, 833
eCAT
common.h, 833
eCTL
common.h, 833
eDMS
common.h, 833
eFW_TYPE_CWE
lite-fw.h, 907
eFW_TYPE_CWE_NVU
lite-fw.h, 907
eFW_TYPE_INVALID
lite-fw.h, 907
eFW_TYPE_MBN
lite-fw.h, 907
eFW_TYPE_MBN_GOBI
lite-fw.h, 907
eFW_TYPE_NVU
lite-fw.h, 907
eFW_TYPE_SPK
lite-fw.h, 907
eIMS
common.h, 833
eIMSA
common.h, 833
eIND
common.h, 834
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_100
nas.h, 937
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_15

nas.h, 937
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_25
nas.h, 937
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_50
nas.h, 937
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_6
nas.h, 937
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_75
nas.h, 937
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED
nas.h, 937
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED
nas.h, 937
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_DECONFIGURED
nas.h, 937
eLOC
common.h, 833
eLOG_DEBUG
common.h, 833
eLOG_FATAL
common.h, 833
eLOG_INFO
common.h, 833
eLOG_WARN
common.h, 833
eModel_9X15
lite-fw.h, 908
eModel_9X30
lite-fw.h, 908
eModel_9x07
lite-fw.h, 908
eModel_Unknown
lite-fw.h, 908
eModel_WP9X15
lite-fw.h, 908
eNAS
common.h, 833
eNAS_LTE_CPHY_CA_BW_NRB_LITE_100
nas.h, 938
eNAS_LTE_CPHY_CA_BW_NRB_LITE_15
nas.h, 938
eNAS_LTE_CPHY_CA_BW_NRB_LITE_25
nas.h, 938
eNAS_LTE_CPHY_CA_BW_NRB_LITE_50
nas.h, 938
eNAS_LTE_CPHY_CA_BW_NRB_LITE_6
nas.h, 938
eNAS_LTE_CPHY_CA_BW_NRB_LITE_75
nas.h, 938
eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED_LITE
nas.h, 938
eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED_LITE
nas.h, 938
eNAS_LTE_CPHY_SCELL_STATE_DECONFIGURED_LITE
nas.h, 938
ePDS
common.h, 833
eQCWWAN_ERR_API_MUTEX_TIMEOUT
qmerrno.h, 1042
eQCWWAN_ERR_BUFFER_SZ
qmerrno.h, 1041
eQCWWAN_ERR_CANCEL_OP
qmerrno.h, 1042
eQCWWAN_ERR_DRIVER
qmerrno.h, 1042
eQCWWAN_ERR_ENUM_BEGIN
qmerrno.h, 1041
eQCWWAN_ERR_ENUM_END
qmerrno.h, 1042
eQCWWAN_ERR_FILE_COPY
qmerrno.h, 1041
eQCWWAN_ERR_FILE_OPEN
qmerrno.h, 1041
eQCWWAN_ERR_GENERAL
qmerrno.h, 1041
eQCWWAN_ERR_INTERNAL
qmerrno.h, 1041
eQCWWAN_ERR_INVALID_ARG
qmerrno.h, 1041
eQCWWAN_ERR_INVALID_DEVID
qmerrno.h, 1041
eQCWWAN_ERR_INVALID_FILE
qmerrno.h, 1041
eQCWWAN_ERR_INVALID_QMI_RSP
qmerrno.h, 1041
eQCWWAN_ERR_INVALID_XID
qmerrno.h, 1042
eQCWWAN_ERR_MALFORMED_QMI_RSP
qmerrno.h, 1041
eQCWWAN_ERR_MEMORY
qmerrno.h, 1041
eQCWWAN_ERR_MULTIPLE_DEVICES
qmerrno.h, 1042
eQCWWAN_ERR_MULTIPLE_SMS_UNSUPPORTED
qmerrno.h, 1042
eQCWWAN_ERR_NO_CANCELABLE_OP
qmerrno.h, 1042
eQCWWAN_ERR_NO_CONNECTION
qmerrno.h, 1041
eQCWWAN_ERR_NO_DEVICE
qmerrno.h, 1041
eQCWWAN_ERR_NO_SIGNAL
qmerrno.h, 1042
eQCWWAN_ERR_NONE
qmerrno.h, 1041
eQCWWAN_ERR_NULL_TLV
qmerrno.h, 1045
eQCWWAN_ERR_OFFLINE
qmerrno.h, 1042
eQCWWAN_ERR_PDU_GENERATION

qmerrno.h, 1042
eQCWWAN_ERR_QMI_ABORTED
qmerrno.h, 1042
eQCWWAN_ERR_QMI_ACCESS_DENIED
qmerrno.h, 1044
eQCWWAN_ERR_QMI_ACK_NOT_SENT
qmerrno.h, 1044
eQCWWAN_ERR_QMI_ARG_TOO_LONG
qmerrno.h, 1042
eQCWWAN_ERR_QMI_AUTHENTICATION_FAILED
qmerrno.h, 1043
eQCWWAN_ERR_QMI_AUTHENTICATION_LOCK
qmerrno.h, 1043
eQCWWAN_ERR_QMI_BUNDLING_NOT_SUPPORTED
qmerrno.h, 1044
eQCWWAN_ERR_QMI_CALL_FAILED
qmerrno.h, 1042
eQCWWAN_ERR_QMI_CARD_BUSY_RSP
qmerrno.h, 1045
eQCWWAN_ERR_QMI_CARD_CALL_CONTROL_FAILED
qmerrno.h, 1044
eQCWWAN_ERR_QMI_CAT_END
qmerrno.h, 1045
eQCWWAN_ERR_QMI_CAT_START
qmerrno.h, 1045
eQCWWAN_ERR_QMI_CAUSE_CODE
qmerrno.h, 1043
eQCWWAN_ERR_QMI_CLIENT_IDS_EXHAUSTED
qmerrno.h, 1042
eQCWWAN_ERR_QMI_CONNECT
qmerrno.h, 1041
eQCWWAN_ERR_QMI_DEVICE_IN_USE
qmerrno.h, 1042
eQCWWAN_ERR_QMI_DEVICE_NOT_READY
qmerrno.h, 1043
eQCWWAN_ERR_QMI_DEVICE_STORAGE_FULL
qmerrno.h, 1043
eQCWWAN_ERR_QMI_DISABLED
qmerrno.h, 1043
eQCWWAN_ERR_QMI_ENCODING
qmerrno.h, 1043
eQCWWAN_ERR_QMI_ENVELOPE_CMD_FAILURE
qmerrno.h, 1045
eQCWWAN_ERR_QMI_EVENT_REG_FAILED
qmerrno.h, 1045
eQCWWAN_ERR_QMI_EXTENDED_INTERNAL
qmerrno.h, 1044
eQCWWAN_ERR_QMI_FDN_RESTRICT
qmerrno.h, 1044
eQCWWAN_ERR_QMI_FLOW_SUSPENDED
qmerrno.h, 1043
eQCWWAN_ERR_QMI_GENERAL
qmerrno.h, 1043
eQCWWAN_ERR_QMI_HARDWARE_RESTRICTED
qmerrno.h, 1044
eQCWWAN_ERR_QMI_IFACE
qmerrno.h, 1041
eQCWWAN_ERR_QMI_INCOMPATIBLE_STATE
qmerrno.h, 1044
eQCWWAN_ERR_QMI_INCORRECT_FLOW_FILTER
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INCORRECT_PIN
qmerrno.h, 1042
eQCWWAN_ERR_QMI_INFO_UNAVAILABLE
qmerrno.h, 1044
eQCWWAN_ERR_QMI_INJECT_TIMEOUT
qmerrno.h, 1044
eQCWWAN_ERR_QMI_INSUFFICIENT_RESOURCES
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INTERFACE_NOT_FOUND
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INTERNAL
qmerrno.h, 1042
eQCWWAN_ERR_QMI_INVALID_ARG
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INVALID_CLIENT_ID
qmerrno.h, 1042
eQCWWAN_ERR_QMI_INVALID_DATA_FORMAT
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INVALID_ENVELOPE_CMD
qmerrno.h, 1045
eQCWWAN_ERR_QMI_INVALID_HANDLE
qmerrno.h, 1042
eQCWWAN_ERR_QMI_INVALID_ID
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INVALID_INDEX
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INVALID_IP_FAMILY_PREF
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INVALID_MCAST_HANDLE
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INVALID_MESSAGE_ID
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INVALID_OPERATION
qmerrno.h, 1044
eQCWWAN_ERR_QMI_INVALID_PDP_TYPE
qmerrno.h, 1042
eQCWWAN_ERR_QMI_INVALID_PINID
qmerrno.h, 1042
eQCWWAN_ERR_QMI_INVALID_PROFILE
qmerrno.h, 1042
eQCWWAN_ERR_QMI_INVALID_PROFILE_TYPE
qmerrno.h, 1042
eQCWWAN_ERR_QMI_INVALID_PS_ATTACH_ACTION
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INVALID_QMI_CMD
qmerrno.h, 1044
eQCWWAN_ERR_QMI_INVALID_QOS_ID
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INVALID_REGISTER_ACTION
qmerrno.h, 1043

eQCWWAN_ERR_QMI_INVALID_SERVICE_TYPE
qmerrno.h, 1042
eQCWWAN_ERR_QMI_INVALID_TECH_PREF
qmerrno.h, 1042
eQCWWAN_ERR_QMI_INVALID_TERMINAL_RSP
qmerrno.h, 1045
eQCWWAN_ERR_QMI_INVALID_TRANSITION
qmerrno.h, 1043
eQCWWAN_ERR_QMI_INVALID_TX_ID
qmerrno.h, 1042
eQCWWAN_ERR_QMI_MALFORMED_MSG
qmerrno.h, 1042
eQCWWAN_ERR_QMI_MAX
qmerrno.h, 1044
eQCWWAN_ERR_QMI_MAX_MCAST_REQUESTS_IN_USE
qmerrno.h, 1043
eQCWWAN_ERR_QMI_MAX_QOS_REQUESTS_IN_USE
qmerrno.h, 1043
eQCWWAN_ERR_QMI_MESSAGE_DELIVERY_FAILURE
qmerrno.h, 1043
eQCWWAN_ERR_QMI_MESSAGE_NOT_SENT
qmerrno.h, 1043
eQCWWAN_ERR_QMI_MISSING_ARG
qmerrno.h, 1042
eQCWWAN_ERR_QMI_MSG_BLOCKED
qmerrno.h, 1044
eQCWWAN_ERR_QMI_NETWORK_ABORTED
qmerrno.h, 1044
eQCWWAN_ERR_QMI_NETWORK_NOT_READY
qmerrno.h, 1043
eQCWWAN_ERR_QMI_NETWORK_QOS_UNAWARE
qmerrno.h, 1043
eQCWWAN_ERR_QMI_NO_EFFECT
qmerrno.h, 1042
eQCWWAN_ERR_QMI_NO_ENTRY
qmerrno.h, 1043
eQCWWAN_ERR_QMI_NO_FREE_PROFILE
qmerrno.h, 1042
eQCWWAN_ERR_QMI_NO_MEMORY
qmerrno.h, 1042
eQCWWAN_ERR_QMI_NO_NETWORK_FOUND
qmerrno.h, 1042
eQCWWAN_ERR_QMI_NO_RADIO
qmerrno.h, 1044
eQCWWAN_ERR_QMI_NO_SUBSCRIPTION
qmerrno.h, 1044
eQCWWAN_ERR_QMI_NO_THRESHOLDS
qmerrno.h, 1042
eQCWWAN_ERR_QMI_NOT_A_MCAST_IFACE
qmerrno.h, 1043
eQCWWAN_ERR_QMI_NOT_PROVISIONED
qmerrno.h, 1042
eQCWWAN_ERR_QMI_NOT_SUPPORTED
qmerrno.h, 1044
eQCWWAN_ERR_QMI_OFFSET
qmerrno.h, 1042
eQCWWAN_ERR_QMI_OP_DEVICE_UNSUPPORTED
qmerrno.h, 1042
eQCWWAN_ERR_QMI_OP_NETWORK_UNSUPPORTED
qmerrno.h, 1042
eQCWWAN_ERR_QMI_OP_PARTIAL_FAILURE
qmerrno.h, 1044
eQCWWAN_ERR_QMI_OUT_OF_CALL
qmerrno.h, 1042
eQCWWAN_ERR_QMI_PIN_BLOCKED
qmerrno.h, 1043
eQCWWAN_ERR_QMI_PIN_PERM_BLOCKED
qmerrno.h, 1043
eQCWWAN_ERR_QMI_POLICY_MISMATCH
qmerrno.h, 1044
eQCWWAN_ERR_QMI_REQ
qmerrno.h, 1041
eQCWWAN_ERR_QMI_REQ_SCH
qmerrno.h, 1041
eQCWWAN_ERR_QMI_REQ_TO
qmerrno.h, 1041
eQCWWAN_ERR_QMI_REQUESTED_NUM_UNSUPPORTED
qmerrno.h, 1043
eQCWWAN_ERR_QMI_RSP
qmerrno.h, 1041
eQCWWAN_ERR_QMI_RSP_TO
qmerrno.h, 1041
eQCWWAN_ERR_QMI_SEGMENT_ORDER
qmerrno.h, 1044
eQCWWAN_ERR_QMI_SEGMENT_TOO_LONG
qmerrno.h, 1044
eQCWWAN_ERR_QMI_SESSION_INACTIVE
qmerrno.h, 1043
eQCWWAN_ERR_QMI_SESSION_INVALID
qmerrno.h, 1043
eQCWWAN_ERR_QMI_SESSION_OWNERSHIP
qmerrno.h, 1043
eQCWWAN_ERR_QMI_SIM_FILE_NOT_FOUND
qmerrno.h, 1044
eQCWWAN_ERR_QMI_SIM_NOT_INITIALIZED
qmerrno.h, 1043
eQCWWAN_ERR_QMI_SMSC_ADDR
qmerrno.h, 1044
eQCWWAN_ERR_QMI_SUPS_FAILURE_CAUSE
qmerrno.h, 1044
eQCWWAN_ERR_QMI_TPDU_TYPE
qmerrno.h, 1044
eQCWWAN_ERR_QMI_UNABORTABLE_TRANSACTION
qmerrno.h, 1042
eQCWWAN_ERR_QMI_UNKNOWN
qmerrno.h, 1043
eQCWWAN_ERR_QMI_WIDTH
qmerrno.h, 1045
eQCWWAN_ERR_RESET

qmerrno.h, 1042
eQCWWAN_ERR_SWICM_AM_VERS_ERROR
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_CALL_IN_PROGRESS
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_END
qmerrno.h, 1045
eQCWWAN_ERR_SWICM_FAILED_TO_KILL_SDK_-PROCESS
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_INVALID_SESSION_ID
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_INVALID_V4_SESSION_I-D
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_INVALID_V6_SESSION_I-D
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_NOT_IMPLEMENTED
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_QMI_CLNT_NOT_SUPPO-RTED
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_QMI_SVC_NOT_SUPPO-RTED
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_SM_NO_AVAILABLE_SE-SSIONS
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_SOCKET_IN_USE
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_START
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_TIMEOUT
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_V4DWN_V6DWN
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_V4DWN_V6UP
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_V4UP_V6DWN
qmerrno.h, 1044
eQCWWAN_ERR_SWICM_V4UP_V6UP
qmerrno.h, 1044
eQCWWAN_ERR_SWIDCS_APP_DISCONNECTED
qmerrno.h, 1045
eQCWWAN_ERR_SWIDCS_DEVNODE_NOT_FOUN-D
qmerrno.h, 1045
eQCWWAN_ERR_SWIDCS_END
qmerrno.h, 1045
eQCWWAN_ERR_SWIDCS_FILEIO_ERR
qmerrno.h, 1045
eQCWWAN_ERR_SWIDCS_IOCTL_ERR
qmerrno.h, 1045
eQCWWAN_ERR_SWIDCS_START
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_CORRUPTED_FW_IMAGE
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_END
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_FILE_NOT_FOUND
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_FIRMWARE_NOT_DOWN-LOADED
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_FW_ENTER_DOWNLOAD-_MODE
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_FW_FLASH_COMPLETE
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_FW_INVALID_SLOT_INDE-X
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_FW_PREFERENCE_MISM-ATCH
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_FW_SAME_AS_CURRENT-_ACTIVE_IMAGE
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_FW_UPDATE_FAIL
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_FW_UPDATE_SUCCESS
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_FW_WAIT_FOR_REBOOT
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_INVALID_CRASH_STATE
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_INVALID_PATH
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_OPENING_DIR
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_OPENING_FILE
qmerrno.h, 1045
eQCWWAN_ERR_SWIIM_START
qmerrno.h, 1045
eQCWWAN_ERR_SWISM_END
qmerrno.h, 1045
eQCWWAN_ERR_SWISMS_BEARER_DATA_NOT_F-OUND
qmerrno.h, 1045
eQCWWAN_ERR_SWISMS_MSG_CORRUPTED
qmerrno.h, 1045
eQCWWAN_ERR_SWISMS_MSG_LEN_TOO_LONG
qmerrno.h, 1045
eQCWWAN_ERR_SWISMS_SMSC_NUM_CORRUPT-ED
qmerrno.h, 1045
eQCWWAN_ERR_SWISMS_START
qmerrno.h, 1045
eQMI_LOC_SESS_STATUS_FAILURE
loc.h, 917
eQMI_LOC_SESS_STATUS_IN_PROGRESS
loc.h, 917
eQMI_LOC_SESS_STATUS_SUCCESS
loc.h, 917
eQMI_LOC_SESS_STATUS_TIMEOUT

loc.h, 917
eQOS
common.h, 833
eREQ
common.h, 834
eRMS
common.h, 833
eRSP
common.h, 834
eSAR
common.h, 833
eSDP_FWDWL_ERR_END
lite-fw.h, 907
eSDP_FWDWL_ERR_FAIL
lite-fw.h, 907
eSDP_FWDWL_ERR_FW_UPGRADE
lite-fw.h, 907
eSDP_FWDWL_ERR_FW_VERSION_FAIL
lite-fw.h, 907
eSDP_FWDWL_ERR_GENERAL
lite-fw.h, 907
eSDP_FWDWL_ERR_INVALID_DEV
lite-fw.h, 907
eSDP_FWDWL_ERR_INVALID_PATH
lite-fw.h, 907
eSDP_FWDWL_ERR_PATH_NOT_SPECIFIED
lite-fw.h, 907
eSDP_FWDWL_ERR_PATH_TOO_LONG
lite-fw.h, 907
eSDP_FWDWL_ERR_PRI_FAIL
lite-fw.h, 907
eSDP_FWDWL_ERR_SDK
lite-fw.h, 907
eSDP_FWDWL_ERR_SET_CBK
lite-fw.h, 907
eSDP_FWDWL_ERR_TIMEOUT
lite-fw.h, 907
eSDP_FWDWL_SUCCESS
lite-fw.h, 907
eSMS
common.h, 833
eSWIAUDIO
common.h, 833
eSWILOC
common.h, 833
eSWIM2MCMD
common.h, 833
eSWIOMA
common.h, 833
eSWIOMAEXT
common.h, 833
eTIMEOUT_10_S
common.h, 834
eTIMEOUT_20_S
common.h, 834
eTIMEOUT_2_S
common.h, 834
eTIMEOUT_300_S
common.h, 834
eTIMEOUT_30_S
common.h, 834
eTIMEOUT_5_S
common.h, 834
eTIMEOUT_60_S
common.h, 834
eTIMEOUT_8_S
common.h, 834
eTIMEOUT_DEFAULT
common.h, 834
eTMD
common.h, 833
eUIM
common.h, 833
eVOICE
common.h, 833
eWDS
common.h, 833
eWDS_ERR_PROFILE_REG_3GPP2_ERR_INVALID_IDENT_FOR_PROFILE
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_3GPP_ACCESS_ERR
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_3GPP_CONTEXT_NOT_DEFINED
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_3GPP_ERR_OUT_OF_PROFILES
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_3GPP_INVAL_PROFILE_FAMILY
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_3GPP_READ_ONLY_FLAG_SET
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_3GPP_VALID_FLAG_NOT_SET
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_END
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_INVAL_PROFILE_FAMILY
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_HNDL
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_IDENT
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_OP
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_NUM
qmerrno.h, 1046

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_-PROFILE_TYPE
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_-SUBS_ID
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_LEN_IN-VALID
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_LIB_NO-T_INITED
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_RESULT_FAIL
qmerrno.h, 1046
eWDS_ERR_PROFILE_REG_RESULT_LIST_END
qmerrno.h, 1046
ECIOThresListLen
nas_ECIOThresh, 129
eLOG_LEVEL
common.h, 833
EMTlv
NASQmiCbkNasSystemSelPrefInd, 232
eQCWWANError
qmerrno.h, 1041
eQMI_SVC
common.h, 833
ERI_DATA_MAX_SIZE
dms.h, 843
ESNString
unpack_dms_GetDeviceSerialNumbers_t, 486
ETWSPLMNInfo
eTWSPLMNInfoTlv, 55
eTWSPLMNInfoTlv, 55
ETWSPLMNInfo, 55
TlvPresent, 55
ETWSPLMNTlv
unpack_sms_SetNewSMSCallback_ind_t, 653
ETWSTlv
unpack_sms_SetNewSMSCallback_ind_t, 653
eTimeout
common.h, 833
eValid
LibPackTFTIDParams, 88
EarMute
pack_audio_SLQSSetAudioProfile_t, 241
pack_swiaudio_SLQSSetM2MAVMute_t, 340
unpack_audio_SLQSGetAudioProfile_t, 473
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 660
unpack_swiaudio_SLQSGetM2MAVMute_t, 662
earfcn
nas_infoInterFreq, 144
nas_LTEInfoIntrafreq, 152
nas_ltePCI, 154
nas_umtsLTENbrCell, 214
earfcn0
nas_lteEARFCN, 146
earfcn1
nas_lteEARFCN, 146
ecio
cdmaSSInfo, 45
hdrSSInfo, 59
nas_ecioListElement, 128
nas_rxInfo, 192
nas_UMTSInfo, 212
tdscdmaSigInfoExt, 444
ecioDelta
nas_SLQSSignalStrengthsIndReq, 200
ecioInfo
nas_SLQSSignalStrengthsInformation, 201
ecioList
unpack_nas_SLQSGetSignalStrength_t, 586
ecioListLen
unpack_nas_SLQSGetSignalStrength_t, 586
ecioThresholdList
nas_SLQSSignalStrengthsIndReq, 200
ecioThresholdListLen
nas_SLQSSignalStrengthsIndReq, 200
egprsSupp
nas_GSMSysInfo, 138
egprsSuppValid
nas_GSMSysInfo, 138
elevation
loc_satelliteInfo, 101
EmerMode
NASEmergencyModeTlv, 222
emmConnState
nas_LTEInfo, 149
emmState
nas_LTEInfo, 149
emmSubState
nas_LTEInfo, 149
Enable
pack_swiaudio_SLQSSetM2MAudioLPBK_t, 337
enable
pack_pds_SetPDSState_t, 313
pack_qos_SLQSSetQosEventCallback_t, 324
enabled
pack_rms_SetSMSWake_t, 324
unpack_rms_GetSMSWake_t, 649
unpack_wds_GetMobileIPProfile_t, 728
EnabledStatus
unpack_pds_SetPdsState_Ind_t, 623
EncryptProt
nas_protocolSubtypeElement, 183
EncryptedPIN1
pack_uim_ChangePin_t, 354
pack_uim_SetPinProtection_t, 356
pack_uim_UnblockPin_t, 363
EndPointType
qos_BindDataPortPeripheralEndPointID_t, 418
EndProactiveSession
cat_EndProactiveSessionTlv, 43
EngineState
unpack_pds_SLQSGetGPSStateInfo_t, 627
engineState

unpack_loc_EngineState_Ind_t, 545
eqmiCbkSetStatus
sms.h, 1063
eriData
eriDataparams, 55
eriDataLen
eriDataparams, 55
eriDataparams, 54
eriData, 55
eriDataLen, 55
eriFile
unpack_dms_SLQSGetERIFile_t, 510
error
unpack_wds_GetLastMobileIPError_t, 726
errorMask
unpack_cat_SetCATEventCallback_t, 475
errorRate
nas_errorRateListElement, 130
errorRateInfo
nas_SLQSSignalStrengthsInformation, 201
errorRateList
unpack_nas_SLQSGetSignalStrength_t, 586
errorRateListLen
unpack_nas_SLQSGetSignalStrength_t, 586
errorState
slotInf, 424
uim_slotInfo, 468
esn
unpack_dms_GetSerialNumbers_t, 497
esnSize
unpack_dms_GetDeviceSerialNumbers_t, 486
EspSpi
unpack_qos_swiQosFilter_t, 641
EtwsMessageInfo
sMSEtwsMessageTlv, 440
event
unpack_qos_SLQSSetQosPriEventCallback_ind_t, 637
unpack_qos_SLQSSetQosStatusCallback_ind_t, 639
event_Index
unpack_cat_SetCatEventCallback_ind_t, 475
EventID
cat_commonEventTlv, 42
EventLength
cat_commonEventTlv, 42
eventMask
pack_cat_SetCATEventCallback_t, 244
pack_uim_SLQSUIMEventRegister_t, 358
unpack_uim_SLQSUIMEventRegister_t, 683
eventRegister
pack_loc_EventRegister_t, 272
eventType
unpack_swioma_SLQSOMADMAlertCallback_ind_t, 670
evrcCapability
voice_prefVoiceSO, 796
executingImage
FMSImageIDEntries, 57
exponent
unpack_qos_pktErrRate_t, 630
extBit
voice_calledPartySubAdd, 775
ExtErrorCode
PackCreateProfileOut, 410
extPowerState
pack_loc_SetExtPowerState_t, 272
extendedErrorCode
unpack_wds_SLQSDeleteProfile_t, 734

FLOAT
SwiDataTypes.h, 1100
FMSImageElement, 55
buildId, 56
buildIdLength, 56
imageId, 56
imageType, 56
FMSImageIDEntries, 57
executingImage, 57
imageIDElement, 57
imageIDSize, 57
imageType, 58
maxImages, 58
FMSImageIdElement, 56
buildID, 57
buildIDLength, 57
failureCount, 57
imageID, 57
storageIndex, 57
FMSImageList, 58
imageIDEntries, 58
listSize, 58
FMSPrefImageList, 58
listEntries, 59
listSize, 59
FOTAUpdate
pack_swioma_SLQSOMADMSetSettings_t, 349
pack_swioma_SLQSOMADMSetSettingsExt_t, 350
unpack_swioma_SLQSOMADMGetSettings_t, 675
FOTAdownload
pack_swioma_SLQSOMADMSetSettings_t, 349
pack_swioma_SLQSOMADMSetSettingsExt_t, 350
unpack_swioma_SLQSOMADMGetSettings_t, 675
FUMOEnable
pack_swioma_SLQSOMADMSetSettingsExt_t, 350
facility
pack_dms_UIMGetControlKeyStatus_t, 255
pack_dms_UIMSetControlKeyProtection_t, 257
pack_dms_UIMUnblockControlKey_t, 258
facilityCk
pack_dms_UIMSetControlKeyProtection_t, 257
pack_dms_UIMUnblockControlKey_t, 258
facilityState
pack_dms_UIMSetControlKeyProtection_t, 257

unpack_dms_UIMGetControlKeyStatus_t, 520
failureCount
FMSImageIdElement, 57
family
pack_wds_GetDefaultProfileNum_t, 385
pack_wds_SetDefaultProfileNum_t, 391
feature
uim_depersonalizationInformation, 454
uim_personalizationStatus, 460
fileID
uim_fileAttributes, 458
uim_fileInfo, 459
fileIndex
pack_uim_ReadTransparent_t, 355
pack_uim_SLQSUIMGetFileAttributes_t, 359
fileSize
uim_fileAttributes, 458
fileType
uim_fileAttributes, 458
fill_pack_ctx
common.h, 834
fill_sdu_hdr
common.h, 834
filterId
LibPackTFTIDParams, 88
fix_rate
pack_swiloc_SwiLocSetAutoStart_t, 345
unpack_swiloc_SwiLocGetAutoStart_t, 669
fix_rate_reported
unpack_swiloc_SwiLocGetAutoStart_t, 669
fix_type
pack_swiloc_SwiLocSetAutoStart_t, 345
unpack_swiloc_SwiLocGetAutoStart_t, 670
fix_type_reported
unpack_swiloc_SwiLocGetAutoStart_t, 670
fixAccuracy
pack_pds_StartPDSTrackingSessionExt_t, 321
fixCount
pack_pds_StartPDSTrackingSessionExt_t, 321
fixInterval
pack_pds_StartPDSTrackingSessionExt_t, 321
fixTimeout
pack_pds_StartPDSTrackingSessionExt_t, 321
flags
sensorData_t, 421
flowLabel
LibPackTFTIDParams, 88
fms.h, 888
GetValidFwPriCombinations, 889
pack_fms_GetImagesPreference, 889
pack_fms_GetStoredImages, 890
pack_fms_SetImagesPreference, 890
unpack_fms_GetImagesPreference, 890
unpack_fms_GetStoredImages, 890
unpack_fms_SetImagesPreference, 890
Forbidden
nas_QmiNas3GppNetworkInfo, 185
forceFlag
pack_pds_SLQSPDSInjectAbsoluteTimeReference-_t, 316
ForceRev0
unpack_nas_GetCDMANetworkParameters_t, 560
format
sMSTransferRouteMTMessageInfo, 443
ForwardMac
nas_protocolSubtypeElement, 183
fqdnAddr
wds_PCSCFFQDNAddress, 810
fqdnLen
wds_PCSCFFQDNAddress, 810
freeSlots
sms_maxStorageSizeResp, 429
freq
nas_PhyCaAggPcellInfo, 174
nas_PhyCaAggScellIndType, 175
nas_PhyCaAggScellInfo, 178
NASPhyCaAggPcellInfo, 227
NASPhyCaAggScellIndType, 229
NASPhyCaAggScellInfo, 230
freqsLen
nas_LTEInfoInterfreq, 150
nas_LTEInfoNeighboringGSM, 153
nas_LTEInfoNeighboringWCDMA, 154
fromServiceId
sms_BroadcastConfig, 425
function
pack_swiloc_SwiLocSetAutoStart_t, 345
unpack_swiloc_SwiLocGetAutoStart_t, 670
function_reported
unpack_swiloc_SwiLocGetAutoStart_t, 670
FwAutoCheck
unpack_swioma_SLQSOMADMGetSettings_t, 675
FwAutoSDM
unpack_swiavms_SLQSAVMSGetSettings_t, 665
FwAvailability
unpack_swioma_SLQSOMADMStartSession_t, 675
FwPromptUpdate
unpack_swiavms_SLQSAVMSGetSettings_t, 665
FwPromptdownload
unpack_swiavms_SLQSAVMSGetSettings_t, 665
fwdloadsize
unpack_omaDmFotaTlv_t, 614
fwloadComplete
unpack_omaDmFotaTlv_t, 615
fwvers
unpack_dms_SLQSSwiGetFirmwareCurr_t, 513

gDlBitRate
LibPackQosClassID, 86
GPRSGrantedQoS
unpack_wds_SLQSGetRuntimeSettings_t, 744
GPSLPM
pack_dms_SetCustFeature_t, 249
unpack_dms_GetCustFeature_t, 480
GPSSel
pack_dms_SetCustFeature_t, 249

unpack_dms_GetCustFeature_t, 480
GSMRSSIThreshListLen
nas_GSMRSSIThresh, 134
GSMSSInfo
unpack_nas_SLQSNasGetSigInfo_t, 599
gUlBitRate
LibPackQosClassID, 86
GWAOPTlv
NASQmiCbkNasSystemSelPrefInd, 232
GWAcqOrderPref
NASGWAcqOrderPrefTlv, 224
GWAddressV4
unpack_wds_SLQSGetRuntimeSettings_t, 744
gcdumpString
crashInformation, 47
gcdumpStrlen
crashInformation, 47
Generator
pack_audio_SLQSGetAudioProfile_t, 237
pack_audio_SLQSGetAudioVolTLBConfig_t, 238
pack_audio_SLQSSetAudioProfile_t, 241
pack_audio_SLQSSetAudioVolTLBConfig_t, 242
pack_swiaudio_SLQSGetM2MAudioVolume_t, 335
pack_swiaudio_SLQSSetM2MAudioVolume_t, 339
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 660
geoSysIdx
nas_AddCDMASysInfo, 107
nas_AddSysInfo, 108
geranArfcn
nas_geranInstInfo, 132
geranBsicBcc
nas_geranInstInfo, 132
geranBsicNcc
nas_geranInstInfo, 133
geranInst
nas_UMTSInfo, 212
GeranInstInfo
nas_UMTSInfo, 212
geranRssi
nas_geranInstInfo, 133
get_version
common.h, 834
getAllCallInfo
voice_arrCallInfo, 770
GetAllCallRmtPtyName
voice_arrRemotePartyName, 772
GetCustomFeatureV2
unpack_dms_GetCustFeaturesV2_t, 481
GetValidFwPriCombinations
fms.h, 889
glo_almanac_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
glo_ephemeris_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
glo_health_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
glo_visible_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
globalCellId
nas_LTEInfoIntrafreq, 152
glog
common.h, 835
gloglvl
common.h, 835
gnssSvId
loc_satelliteInfo, 101
gnssSvUsedList
loc_svUsedforFix, 104
gnssSvUsedList_len
loc_svUsedforFix, 104
Gpp2TimeZone
unpack_nas_SLQSGetServingSystem_t, 583
GppNetworkDSTAdjustment
unpack_nas_SLQSGetServingSystem_t, 583
GppTimeZone
unpack_nas_SLQSGetServingSystem_t, 583
gps_almanac_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
gps_ephemeris_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
gps_health_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
gps_visible_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
GpsEnable
pack_dms_SetCustFeature_t, 249
unpack_dms_GetCustFeature_t, 480
gpsTimeOfWeekMs
loc_gpsTime, 96
gpsWeek
loc_gpsTime, 96
grntDownlinkBitrate
LibPackUMTSQoS, 90
wds_UMTSMinQoS, 816
grntUplinkBitrate
LibPackUMTSQoS, 90
wds_UMTSMinQoS, 816
gsmAmrStat
voice_curAMRConfig, 788
GsmCellInfo
nas_lteGsmCellInfo, 147
gsmUmtsDl
pack_nas_SLQSNasSwiIndicationRegister_t, 301
gsmUmtsUl
pack_nas_SLQSNasSwiIndicationRegister_t, 301
guaranteedRate
unpack_qos_dataRate_t, 629
gwAddressV6
wds_IPV6GWAddressInfo, 810
gwV6PrefixLen
wds_IPV6GWAddressInfo, 810
gyroData
pack_loc_SLQSLOCInjectSensorData_t, 280
gyroTemp
pack_loc_SLQSLOCInjectSensorData_t, 280

gyroTimeSrc
pack_loc_SLQSLOCInjectSensorData_t, 281

HASPI
unpack_wds_GetMobileIPProfile_t, 728
HAState
unpack_wds_GetMobileIPProfile_t, 728
HDOP
loc_precisionDilution, 99
HDRECIOThreshListLen
nas_HDRECIOThresh, 138
HDRIOThreshListLen
nas_HDRIOThresh, 139
HDRRSSIThreshListLen
nas_HDRRSSIThresh, 139
HDRSINRThresListLen
nas_HDRSINRThresh, 140
HDRSINRThreshListLen
nas_HDRSINRThreshold, 141
HDRSSInfo
unpack_nas_SLQSNasGetSigInfo_t, 599
HWVersion
nas_DeviceConfigDetail, 127
HardwareControlledMode
unpack_dms_GetPower_t, 495
has_PdpStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 269
has_PositionDataNMEA
unpack_pds_SetEventReport_Ind_t, 622
has_RatHandoverStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 269
has_RegStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 269
has_ServiceStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 269
has_SessionStatus
unpack_pds_SetEventReport_Ind_t, 622
has_accelTemp
pack_loc_SLQSLOCInjectSensorData_t, 281
has_acceleroTimeSrc
pack_loc_SLQSLOCInjectSensorData_t, 281
has_accleroData
pack_loc_SLQSLOCInjectSensorData_t, 281
has_altitudeSrcInfo
pack_loc_SLQSLOCInjectPosition_t, 278
has_altitudeWrtEllipsoid
pack_loc_SLQSLOCInjectPosition_t, 278
has_altitudeWrtMeanSeaLevel
pack_loc_SLQSLOCInjectPosition_t, 278
has_confidence
pack_loc_SLQSLOCSetCradleMountConfig_t, 282
has_dLatitude
unpack_pds_SetEventReport_Ind_t, 622
has_dLongitude
unpack_pds_SetEventReport_Ind_t, 622
has_gyroData
pack_loc_SLQSLOCInjectSensorData_t, 281
has_gyroTemp
pack_loc_SLQSLOCInjectSensorData_t, 281
has_gyroTimeSrc
pack_loc_SLQSLOCInjectSensorData_t, 281
has_horConfidence
pack_loc_SLQSLOCInjectPosition_t, 278
has_horReliability
pack_loc_SLQSLOCInjectPosition_t, 278
has_horUncCircular
pack_loc_SLQSLOCInjectPosition_t, 278
has_latitude
pack_loc_SLQSLOCInjectPosition_t, 278
has_longitude
pack_loc_SLQSLOCInjectPosition_t, 278
has_opaqueId
pack_loc_SLQSLOCInjectSensorData_t, 281
has_posSrc
unpack_pds_SetEventReport_Ind_t, 622
has_positionSrc
pack_loc_SLQSLOCInjectPosition_t, 278
has_rawHorConfidence
pack_loc_SLQSLOCInjectPosition_t, 278
has_rawHorUncCircular
pack_loc_SLQSLOCInjectPosition_t, 278
has_serverAddrTypeMask
pack_loc_SLQSLOCGetServer_t, 274
has_timestampAge
pack_loc_SLQSLOCInjectPosition_t, 278
has_timestampUtc
pack_loc_SLQSLOCInjectPosition_t, 278
has_vertConfidence
pack_loc_SLQSLOCInjectPosition_t, 278
has_vertRelicability
pack_loc_SLQSLOCInjectPosition_t, 278
has_vertUnc
pack_loc_SLQSLOCInjectPosition_t, 279
hdrActiveProt
nas_HDRSysInfo, 143
hdrActiveProtValid
nas_HDRSysInfo, 143
hdrHybrid
nas_detailSvcInfo, 126
HdrPersonality
unpack_nas_SLQSGetServingSystem_t, 583
hdrPersonality
nas_HDRSysInfo, 143
NASServingSystemInfo, 235
hdrPersonalityValid
nas_HDRSysInfo, 143
hdrSSInfo, 59
ecio, 59
io, 59
rssi, 60
sinr, 60
hdrSrvStatus
nas_detailSvcInfo, 126
healthStatus
loc_satelliteInfo, 101
helper_get_resp_ctx
common.h, 834

helper_get_xid
common.h, 834
helper_set_log_func
common.h, 835
helper_set_log_lvl
common.h, 835
homeOrigVoiceSO
voice_prefVoiceSO, 796
homePageVoiceSO
voice_prefVoiceSO, 796
horConfidence
pack_loc_SLQSLOCInjectPosition_t, 279
horReliability
pack_loc_SLQSLOCInjectPosition_t, 279
horUncCircular
pack_loc_SLQSLOCInjectPosition_t, 279
HorizontalUncertainty
unpack_pds_SLQSGetGPSStateInfo_t, 627
hotSwap
uim_hotSwapStatus, 459
hotSwapLength
uim_hotSwapStatus, 459
hour
nas_timeInfo, 209
nas_UniversalTime, 215
hsCallStatus
nas_WCDMASysInfo, 221
hsCallStatusValid
nas_WCDMASysInfo, 221
hsInd
nas_WCDMASysInfo, 221
hsIndValid
nas_WCDMASysInfo, 221
hwType
wds_DHCPv4HWConfig, 805
wdsDhcpv4HwConfig, 817
hwVer
unpack_dms_GetHardwareRevision_t, 491

iFaceTab
swiaudio_PCMparams, 443
iFaceTabLen
swiaudio_PCMparams, 443
iLTEbandValue
nas_PhyCaAggPcellInfo, 174
nas_PhyCaAggScellInfo, 178
NASPhyCaAggPcellInfo, 227
NASPhyCaAggScellInfo, 230
IMCNflag
unpack_wds_SLQSGetRuntimeSettings_t, 744
IMEIString
unpack_dms_GetDeviceSerialNumbers_t, 486
IMG_MASK_CLEAR
lite-fw.h, 905
IMG_MASK_GENERIC
lite-fw.h, 905
IMG_MASK_MDM
lite-fw.h, 905
IMG_MASK_PRI
lite-fw.h, 905
IMSInfo
sMSOnIMSTlv, 442
IMSTlv
unpack_sms_SetNewSMSCallback_ind_t, 653
INT32
SwiDataTypes.h, 1100
INT8
SwiDataTypes.h, 1100
IOThresListLen
nas_IOThresh, 145
IPAddress
nas_DataStatusDetail, 124
IPAddressV6
ipv6AddressInfo, 61
wds_IPV6AddressInfo, 809
IPFamSupport
pack_dms_SetCustFeature_t, 249
unpack_dms_GetCustFeature_t, 480
IPFamilyPreference
pack_wds_SLQSSetIPFamilyPreference_t, 403
unpack_wds_SLQSGetRuntimeSettings_t, 744
IPSECSPI
LibPackTFTIDParams, 88
IPV6_ADDR_LEN
wds.h, 1171
IPV6AddrInfo
unpack_wds_SLQSGetRuntimeSettings_t, 744
IPV6GWAddrInfo
unpack_wds_SLQSGetRuntimeSettings_t, 744
IPV6PrefixLen
ipv6AddressInfo, 61
wds_IPV6AddressInfo, 809
IPv4
unpack_wds_SLQSGetRuntimeSettings_t, 744
IPv4Addr
wds_IPv4AdTlv, 809
IPv4AddrTlv
unpack_wds_DHCPv4ClientLease_ind_t, 719
IPv4DstAddr
unpack_qos_swiQosFilter_t, 641
IPv4SrcAddr
unpack_qos_swiQosFilter_t, 641
IPv4Tos
unpack_qos_swiQosFilter_t, 641
IPv6DstAddr
unpack_qos_swiQosFilter_t, 641
IPv6Label
unpack_qos_swiQosFilter_t, 642
IPv6SrcAddr
unpack_qos_swiQosFilter_t, 642
IPv6TrafCls
unpack_qos_swiQosFilter_t, 642
Id
unpack_qos_swiQosFilter_t, 641
id
loc_BdsSV, 92
loc_SV, 103

nas_CSGID, 120
pack_dms_UIMChangePIN_t, 255
pack_dms_UIMSetPINProtection_t, 257
pack_dms_UIMUnblockPIN_t, 258
pack_dms_UIMVerifyPIN_t, 259
unpack_qos_QosFlowInfoState_t, 633
unpack_qos_SLQSSetQosStatusCallback_ind_t, 639
id_length
DMScustSettingInfo, 51
IdleState
nas_protocolSubtypeElement, 183
IfaceID
qos_BindDataPortPeripheralEndPointID_t, 418
image_info_t, 60
buildID, 60
buildIDLen, 60
imageType, 60
uniqueID, 60
imageID
FMSImageIdElement, 57
imageIDElement
FMSImageIDEntries, 57
imageIDEntries
FMSImageList, 58
imageIDSize
FMSImageIDEntries, 57
imageId
FMSImageElement, 56
imageList
unpack_fms_GetStoredImages_t, 525
ImageListSize
unpack_fms_GetImagesPreference_t, 524
imageListSize
pack_fms_SetImagesPreference_t, 261
imageType
FMSImageElement, 56
FMSImageIDEntries, 58
image_info_t, 60
ImageTypes
unpack_fms_SetImagesPreference_t, 525
ImageTypesSize
unpack_fms_SetImagesPreference_t, 525
imagelistSize
unpack_fms_GetStoredImages_t, 525
imei_no
unpack_dms_GetSerialNumbers_t, 497
imeiSize
unpack_dms_GetDeviceSerialNumbers_t, 486
imeiSvnSize
unpack_dms_GetDeviceSerialNumbers_t, 486
ImeiSvnString
unpack_dms_GetDeviceSerialNumbers_t, 486
imeisv_svn
unpack_dms_GetSerialNumbers_t, 497
imgType
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 515
ims.h, 891
pack_ims_SLQSGetIMSSMSConfig, 892
pack_ims_SLQSGetIMSUserConfig, 892
pack_ims_SLQSGetIMSVoIPConfig, 893
pack_ims_SLQSGetRegMgrConfig, 893
pack_ims_SLQSGetSIPConfig, 893
pack_ims_SLQSImsConfigIndicationRegister, 894
pack_ims_SLQSSetIMSSMSConfig, 894
pack_ims_SLQSSetIMSUserConfig, 895
pack_ims_SLQSSetIMSVoIPConfig, 895
pack_ims_SLQSSetRegMgrConfig, 896
pack_ims_SLQSSetSIPConfig, 896
unpack_ims_SLQSGetIMSSMSConfig, 897
unpack_ims_SLQSGetIMSUserConfig, 897
unpack_ims_SLQSGetIMSVoIPConfig, 897
unpack_ims_SLQSGetRegMgrConfig, 898
unpack_ims_SLQSGetSIPConfig, 898
unpack_ims_SLQSImsConfigIndicationRegister, 898
unpack_ims_SLQSSetIMSSMSConfig, 899
unpack_ims_SLQSSetIMSUserConfig, 899
unpack_ims_SLQSSetIMSVoIPConfig, 899
unpack_ims_SLQSSetRegMgrConfig, 900
unpack_ims_SLQSSetSIPConfig, 900
ImsRegErrCode
unpack_imsa_SLQSGetIMSARegStatus_t, 535
imsRegState
nas_CommInfo, 119
ImsRegStatus
unpack_imsa_SLQSGetIMSARegStatus_t, 535
imsa.h, 900
pack_imsa_SLQSGetIMSARegStatus, 901
pack_imsa_SLQSGetIMSAServiceStatus, 901
pack_imsa_SLQSRegisterIMSAIndication, 902
unpack_imsa_SLQSGetIMSARegStatus, 902
unpack_imsa_SLQSGetIMSAServiceStatus, 903
unpack_imsa_SLQSRegisterIMSAIndication, 903
imsi
unpack_dms_GetIMSI_t, 491
imsi_11_12
nas_CDMASysInfoExt, 117
imsiM1112
nas_minBasedIMSI, 164
imsiMS1
nas_minBasedIMSI, 164
imsiMS2
nas_minBasedIMSI, 164
imsiT1112
nas_trueIMSI, 210
imsiTS1
nas_trueIMSI, 210
imsiTS2
nas_trueIMSI, 210
imsiTaddrNum
nas_trueIMSI, 210
InUse
nas_QmiNas3GppNetworkInfo, 185
includes_pcs_digit
nas_QmisNasPcsDigit, 186

index
pack_wds_GetMobileIPProfile_t, 386
pack_wds_SetDefaultProfileNum_t, 391
pack_wds_SetMobileIPProfile_t, 394
unpack_qos_swiQosFilter_t, 641
unpack_qos_swiQosFlow_t, 645
unpack_wds_GetDefaultProfileNum_t, 725
index1xPri
uim_cardStatus, 452
index1xSec
uim_cardStatus, 452
indexGwPri
uim_cardStatus, 452
indexGwSec
uim_cardStatus, 452
Info
unpack_nas_SLQSNasSwiOTAMessageCallback-_ind_t, 603
unpack_nas_SLQSSetSysSelectionPrefCallBack-_ind_t, 604
InfoInterfreq
nas_LTEInfoInterfreq, 150
insNmrCellInfo
nas_GERANInfo, 132
instancesSize
unpack_nas_GetRFInfo_t, 566
interval
pack_pds_SetPDSDefaults_t, 313
pack_pds_SetXTRAAutomaticDownload_t, 315
pack_wds_SLQSSetWdsEventCallback_t, 404
Io
unpack_nas_SLQSGetSignalStrength_t, 586
io
hdrSSInfo, 59
nas_SLQSSignalStrengthsInformation, 201
ioDelta
nas_SLQSSignalStrengthsIndReq, 200
Iono_valid
unpack_pds_SLQSGetGPSStateInfo_t, 627
ipAddress
pack_wds_SetDefaultProfile_t, 390
qmuxIPTable, 417
ipFamily
unpack_wds_SLQSSetPacketSrvStatusCallback_-t, 747
ipVersion
LibPackTFTIDParams, 88
ipaddr
unpack_wds_GetDefaultProfile_t, 724
ipaddrv6
unpack_wds_GetDefaultProfile_t, 724
ipv4Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 753
ipv4GWAddress
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 753
ipv6_addr, 60
ipv6addr, 61
prefix, 61
ipv6Address
qmuxIPTable, 417
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 753
ipv6AddressInfo, 61
IPAddressV6, 61
IPV6PrefixLen, 61
ipv6GWAddress
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 753
ipv6addr
ipv6_addr, 61
wds.h, 1209
is856SysId
nas_HDRSysInfo, 143
is856SysIdValid
nas_HDRSysInfo, 143
is_DataRate_Available
unpack_qos_swiQosFlow_t, 645
is_EspSpi_Available
unpack_qos_swiQosFilter_t, 642
is_IPv4DstAddr_Available
unpack_qos_swiQosFilter_t, 642
is_IPv4SrcAddr_Available
unpack_qos_swiQosFilter_t, 642
is_IPv4Tos_Available
unpack_qos_swiQosFilter_t, 642
is_IPv6DstAddr_Available
unpack_qos_swiQosFilter_t, 642
is_IPv6Label_Available
unpack_qos_swiQosFilter_t, 642
is_IPv6SrcAddr_Available
unpack_qos_swiQosFilter_t, 642
is_IPv6TrafCls_Available
unpack_qos_swiQosFilter_t, 642
is_Id_Available
unpack_qos_swiQosFilter_t, 642
is_Jitter_Available
unpack_qos_swiQosFlow_t, 646
is_Latency_Available
unpack_qos_swiQosFlow_t, 646
is_LteBandCapability_Available
unpack_dms_SLQSGetBandCapability_t, 510
is_LteQci_Available
unpack_qos_swiQosFlow_t, 646
is_MaxAllowedPktSz_Available
unpack_qos_swiQosFlow_t, 646
is_MinPolicedPktSz_Available
unpack_qos_swiQosFlow_t, 646
is_NxtHdrProto_Available
unpack_qos_swiQosFilter_t, 642
is_PktErrRate_Available
unpack_qos_swiQosFlow_t, 646
is_Precedence_Available
unpack_qos_swiQosFilter_t, 642
is_ProfileId3GPP2_Available

unpack_qos_swiQosFlow_t, 646
is_RxQFlowGranted_Available
unpack_qos_QosFlowInfo_t, 632
is_TCPDstPort_Available
unpack_qos_swiQosFilter_t, 642
is_TCPSrcPort_Available
unpack_qos_swiQosFilter_t, 642
is_TdsBandCapability_Available
unpack_dms_SLQSGetBandCapability_t, 510
is_TokenBucket_Available
unpack_qos_swiQosFlow_t, 646
is_TrafficClass_Available
unpack_qos_swiQosFlow_t, 646
is_TranDstPort_Available
unpack_qos_swiQosFilter_t, 642
is_TranSrcPort_Available
unpack_qos_swiQosFilter_t, 642
is_TxQFlowGranted_Available
unpack_qos_QosFlowInfo_t, 632
is_UDPDstPort_Available
unpack_qos_swiQosFilter_t, 642
is_UDPSrcPort_Available
unpack_qos_swiQosFilter_t, 642
is_val_3GPP2Pri_Available
unpack_qos_swiQosFlow_t, 646
is_val_3GPPImCn_Available
unpack_qos_swiQosFlow_t, 646
is_val_3GPPResResidualBER_Available
unpack_qos_swiQosFlow_t, 646
is_val_3GPPSigInd_Available
unpack_qos_swiQosFlow_t, 646
is_val_3GPPTraHdlPri_Available
unpack_qos_swiQosFlow_t, 646
isEmpty
voice_getAllCallInformation, 790
isInTraffic
nas_txInfo, 210
isNewFlow
unpack_qos_QosFlowInfoState_t, 633
isPrefDataPath
nas_GSMSrvStatusInfo, 135
nas_SrvStatusInfo, 202
isRadioTuned
nas_rxInfo, 192
nas_RxSigInfo, 193
isSysForbidden
nas_detailSvcInfo, 126
nas_sysInfoCommon, 204
isSysForbiddenValid
nas_sysInfoCommon, 204
isSysPrlMatch
nas_CDMASysInfo, 116
nas_HDRSysInfo, 143
isSysPrlMatchValid
nas_CDMASysInfo, 116
nas_HDRSysInfo, 143
IsVoiceEnabled
pack_dms_SetCustFeature_t, 249
unpack_dms_GetCustFeature_t, 480
Item
pack_audio_SLQSGetAudioPathConfig_t, 237
pack_audio_SLQSGetAudioVolTLBConfig_t, 238
pack_audio_SLQSSetAudioVolTLBConfig_t, 242

Jitter
unpack_qos_swiQosFlow_t, 646

KeyExchange
nas_protocolSubtypeElement, 183

LITE_VOICE_SUPS_SRV_CLASS_DATA
voice.h, 1143
LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITAS-
YNC
voice.h, 1143
LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITSY-
NC
voice.h, 1143
LITE_VOICE_SUPS_SRV_CLASS_FAX
voice.h, 1143
LITE_VOICE_SUPS_SRV_CLASS_NONE
voice.h, 1143
LITE_VOICE_SUPS_SRV_CLASS_PACKETACCESS
voice.h, 1143
LITE_VOICE_SUPS_SRV_CLASS_PADACCESS
voice.h, 1143
LITE_VOICE_SUPS_SRV_CLASS_SMS
voice.h, 1143
LITE_VOICE_SUPS_SRV_CLASS_VOICE
voice.h, 1143
LITEQMI_QMI_CBK_PARAM_NOCHANGE
sms.h, 1063
LITEQMI_QMI_CBK_PARAM_RESET
sms.h, 1063
LITEQMI_QMI_CBK_PARAM_SET
sms.h, 1063
LBPTlv
NASQmiCbkNasSystemSelPrefInd, 232
LOCEVENTMASKGNSSSVINFO
loc.h, 915
LOCEVENTMASKNMEA
loc.h, 916
LOCEVENTMASKWIFIREQ
loc.h, 917
LPCSTR
SwiDataTypes.h, 1100
LTEAttachProfile
unpack_wds_SLQSGet3GPPConfigItem_t, 736
LTEAttachProfileList
unpack_wds_SLQSGet3GPPConfigItem_t, 736
LTEAttachProfileListLen
pack_wds_SLQSSet3GPPConfigItem_t, 402
unpack_wds_SLQSGet3GPPConfigItem_t, 736
LTEBandPref
NASLTEBandPreferenceTlv, 224
LTECphyCaInfo
unpack_nas_SlqsGetLTECphyCAInfo_t, 576

LTERSRPThreshListLen
nas_LTERSRPThresh, 155
LTERSRQThreshListLen
nas_LTERSRQThresh, 156
LTERSSIThreshListLen
nas_LTERSSIThresh, 156
LTESNRThresListLen
nas_LTESNRThresh, 159
LTESNRThreshListLen
nas_LTESNRThreshold, 160
LTESSInfo
unpack_nas_SLQSNasGetSigInfo_t, 599
LTEWCDMACellInfo
nas_LTEInfoNeighboringWCDMA, 154
Lac
unpack_nas_SLQSGetServingSystem_t, 583
lac
nas_GERANInfo, 132
nas_GSMSysInfo, 138
nas_LTESysInfo, 162
nas_UMTSInfo, 212
nas_WCDMASysInfo, 221
lac1
nas_OperatorPLMNData, 172
lac2
nas_OperatorPLMNData, 172
lacValid
nas_GSMSysInfo, 138
nas_LTESysInfo, 162
nas_WCDMASysInfo, 221
language
sms_CDMABroadcastConfig, 425
lastCallDataBearerTech
unpack_wds_SLQSGetDUNCallInfo_t, 741
lastCallDataBearerTechnology
unpack_wds_SLQSGetDataBearerTechnology_t, 738
lastCallRXOKBytesCnt
unpack_wds_SLQSGetDUNCallInfo_t, 741
lastCallTXOKBytesCnt
unpack_wds_SLQSGetDUNCallInfo_t, 741
LastErrCode
nas_DataStatusDetail, 124
Latency
unpack_qos_swiQosFlow_t, 646
Latitude
unpack_pds_SLQSGetGPSStateInfo_t, 627
latitude
pack_loc_SLQSLOCInjectPosition_t, 279
leapSeconds
nas_qaQmi3Gpp2TimeZone, 184
leaseState
wds_DHCPLeaseStateTlv, 803
len
loc_BdsSVInfo, 92
loc_SVInfo, 103
unpack_nas_GetSignalStrengths_t, 569
length
sMSCAddressInfo, 438
sMSEtwsMessageInfo, 439
sMSTransferRouteMTMessageInfo, 443
uim_readTransparentInfo, 461
Level
pack_swiaudio_SLQSSetM2MAudioVolume_t, 339
unpack_swiaudio_SLQSGetM2MAudioVolume_t, 661
LibPackGPRSRequestedQoS, 61
delayClass, 62
meanThroughputClass, 62
peakThroughputClass, 62
precedenceClass, 62
reliabilityClass, 62
LibPackQosClassID, 85
gDlBitRate, 86
gUlBitRate, 86
maxDlBitRate, 86
maxUlBitRate, 86
QCI, 86
LibPackTFTIDParams, 86
destPortRangeEnd, 87
destPortRangeStart, 88
eValid, 88
filterId, 88
flowLabel, 88
IPSECSPI, 88
ipVersion, 88
nextHeader, 88
pSourceIP, 88
sourceIPMask, 88
srcPortRangeEnd, 88
srcPortRangeStart, 88
tosMask, 88
LibPackUMTSQoS, 88
deliveryErrSDU, 90
grntDownlinkBitrate, 90
grntUplinkBitrate, 90
maxDownlinkBitrate, 90
maxSDUSize, 90
maxUplinkBitrate, 90
qosDeliveryOrder, 90
resBerRatio, 91
sduErrorRatio, 91
trafficClass, 91
trafficPriority, 91
transferDelay, 91
LibPackUMTSReqQoSSigInd, 91
SigInd, 91
UMTSReqQoS, 91
LibPackprofile_3GPP, 74
pAPNClass, 79
pAPNDisabledFlag, 79
pAPNName, 79
pAPNnameSize, 79
pAddrAllocPref, 79
pAuthenticationPref, 79
pGPRSMinimumQoS, 79

pGPRSRequestedQos, 79
pIPv4AddrPref, 79
pIPv6AddPref, 79
pImCnFlag, 79
pPDNInactivTimeout, 79
pPDPtype, 79
pPassword, 79
pPasswordSize, 79
pPcscfAddrUsingDhcp, 79
pPcscfAddrUsingPCO, 79
pPdpAccessConFlag, 79
pPdpContext, 79
pPdpDataCompType, 79
pPdpHdrCompType, 79
pPriDNSIPv4AddPref, 79
pPriDNSIPv6addpref, 79
pPrimaryID, 79
pProfilename, 80
pProfilenameSize, 80
pQosClassID, 80
pSecDNSIPv4AddPref, 80
pSecDNSIPv6addpref, 80
pSecondaryFlag, 80
pTFTID1Params, 80
pTFTID2Params, 80
pUMTSMinQoS, 80
pUMTSMinQosSigInd, 80
pUMTSReqQoS, 80
pUMTSReqQoSSigInd, 80
pUsername, 80
pUsernameSize, 80
LibPackprofile_3GPP2, 80
pAPNClass3GPP2, 84
pAPNEnabled3GPP2, 84
pAllowLinger, 84
pApnString, 84
pApnStringSize, 84
pAppPriority, 84
pAppType, 84
pAuthPassword, 84
pAuthPassword_tSize, 84
pAuthProtocol, 84
pAuthRetryCount, 85
pAuthTimeout, 85
pDataMode, 85
pDataRate, 85
pIpcpAckTimeout, 85
pIpcpCreqRetryCount, 85
pIsPcscfAddressNedded, 85
pLcpAckTimeout, 85
pLcpCreqRetryCount, 85
pNegoDnsSrvrPref, 85
pPDNInactivTimeout3GPP2, 85
pPdnType, 85
pPppSessCloseTimer1x, 85
pPppSessCloseTimerDO, 85
pPriV6DnsAddress, 85
pPrimaryV4DnsAddress, 85
pRATType, 85
pSecV6DnsAddress, 85
pSecondaryV4DnsAddress, 85
pUserId, 85
pUserIdSize, 85
libSDP_BuildImagesPreferenceRequest
lite-fw.h, 905
libSDP_CalculateImageMask
lite-fw.h, 905
libSDP_CheckValidFirmwareInfo
lite-fw.h, 906
libSDP_DownloadFW
lite-fw.h, 906
libSDP_ExtractFirmwareParametersByPath
lite-fw.h, 906
libSDP_FirmwareInfo
lite-fw.h, 906
libSDP_GetModelFamily
lite-fw.h, 906
libSDP_GetVersion
lite-fw.h, 906
libSDP_getFileType
lite-fw.h, 906
LibpackProfile3GPP, 62
pAPNClass, 67
pAPNDisabledFlag, 67
pAPNName, 67
pAPNnameSize, 68
pAddrAllocPref, 67
pAuthenticationPref, 68
pGPRSMinimumQoS, 68
pGPRSRequestedQos, 68
pIPv4AddrPref, 68
pIPv6AddPref, 68
pImCnFlag, 68
pPDNInactivTimeout, 68
pPDPtype, 68
pPassword, 68
pPasswordSize, 68
pPcscfAddrUsingDhcp, 68
pPcscfAddrUsingPCO, 68
pPdpAccessConFlag, 68
pPdpContext, 68
pPdpDataCompType, 68
pPdpHdrCompType, 68
pPriDNSIPv4AddPref, 68
pPriDNSIPv6addpref, 68
pPrimaryID, 68
pProfilename, 68
pProfilenameSize, 68
pQosClassID, 68
pSecDNSIPv4AddPref, 68
pSecDNSIPv6addpref, 68
pSecondaryFlag, 68
pTFTID1Params, 68
pTFTID2Params, 68
pUMTSMinQoS, 69
pUMTSMinQosSigInd, 69

pUMTSReqQoS, 69
pUMTSReqQoSSigInd, 69
pUsername, 69
pUsernameSize, 69
LibpackProfile3GPP2, 69
pAPNClass3GPP2, 73
pAPNEnabled3GPP2, 73
pAllowLinger, 73
pApnString, 73
pApnStringSize, 73
pAppPriority, 73
pAppType, 73
pAuthPassword, 73
pAuthPasswordSize, 73
pAuthProtocol, 73
pAuthRetryCount, 73
pAuthTimeout, 73
pDataMode, 73
pDataRate, 73
pIpcpAckTimeout, 73
pIpcpCreqRetryCount, 74
pIsPcscfAddressNedded, 74
pLcpAckTimeout, 74
pLcpCreqRetryCount, 74
pNegoDnsSrvrPref, 74
pPDNInactivTimeout3GPP2, 74
pPdnType, 74
pPppSessCloseTimer1x, 74
pPppSessCloseTimerDO, 74
pPriV6DnsAddress, 74
pPrimaryV4DnsAddress, 74
pRATType, 74
pSecV6DnsAddress, 74
pSecondaryV4DnsAddress, 74
pUserId, 74
pUserIdSize, 74
libsdp_SetReadBlockSize
lite-fw.h, 906
libsdp_set_log_func
lite-fw.h, 906
libsdplogger
lite-fw.h, 906
lineValue
pack_voice_SLQSVoiceALSSelectLine_t, 367
linkage
altSrcInfo_t, 31
list_type
DMScustSettingList, 52
DMSgetCustomInput, 53
pack_dms_GetCustFeaturesV2_t, 245
listEntries
FMSPrefImageList, 59
listSize
FMSImageList, 58
FMSPrefImageList, 59
lite-fw.h
eFW_TYPE_CWE, 907
eFW_TYPE_CWE_NVU, 907
eFW_TYPE_INVALID, 907
eFW_TYPE_MBN, 907
eFW_TYPE_MBN_GOBI, 907
eFW_TYPE_NVU, 907
eFW_TYPE_SPK, 907
eModel_9X15, 908
eModel_9X30, 908
eModel_9x07, 908
eModel_Unknown, 908
eModel_WP9X15, 908
eSDP_FWDWL_ERR_END, 907
eSDP_FWDWL_ERR_FAIL, 907
eSDP_FWDWL_ERR_FW_UPGRADE, 907
eSDP_FWDWL_ERR_FW_VERSION_FAIL, 907
eSDP_FWDWL_ERR_GENERAL, 907
eSDP_FWDWL_ERR_INVALID_DEV, 907
eSDP_FWDWL_ERR_INVALID_PATH, 907
eSDP_FWDWL_ERR_PATH_NOT_SPECIFIED, 907
eSDP_FWDWL_ERR_PATH_TOO_LONG, 907
eSDP_FWDWL_ERR_PRI_FAIL, 907
eSDP_FWDWL_ERR_SDK, 907
eSDP_FWDWL_ERR_SET_CBK, 907
eSDP_FWDWL_ERR_TIMEOUT, 907
eSDP_FWDWL_SUCCESS, 907
lite-fw.h, 904
IMG_MASK_CLEAR, 905
IMG_MASK_GENERIC, 905
IMG_MASK_MDM, 905
IMG_MASK_PRI, 905
libSDP_BuildImagesPreferenceRequest, 905
libSDP_CalculateImageMask, 905
libSDP_CheckValidFirmwareInfo, 906
libSDP_DownloadFW, 906
libSDP_ExtractFirmwareParametersByPath, 906
libSDP_FirmwareInfo, 906
libSDP_GetModelFamily, 906
libSDP_GetVersion, 906
libSDP_getFileType, 906
libsdp_SetReadBlockSize, 906
libsdp_set_log_func, 906
libsdplogger, 906
litefw_BuildImagesPreferenceRequest, 908
litefw_CalculateImageMask, 908
litefw_CheckValidFirmwareInfo, 908
litefw_DownloadFW, 909
litefw_ExtractFirmwareParametersByPath, 909
litefw_FirmwareInfo, 906
litefw_Fw_Type, 907
litefw_GetModelFamily, 910
litefw_GetVersion, 910
litefw_Models, 907
litefw_SetReadBlockSize, 911
litefw_fwdwl_error_codes, 907
litefw_getFileType, 910
litefw_logsenable, 910
litefw_set_log_func, 911
litefw_switch_9x07_to_downloadmode, 911

litefw_switch_to_BootHoldMode, 911
litefwlogger, 906
liteQmiDataBearerMasks
wds.h, 1172
liteServiceClassInformation
voice.h, 1143
litefw_BuildImagesPreferenceRequest
lite-fw.h, 908
litefw_CalculateImageMask
lite-fw.h, 908
litefw_CheckValidFirmwareInfo
lite-fw.h, 908
litefw_DownloadFW
lite-fw.h, 909
litefw_ExtractFirmwareParametersByPath
lite-fw.h, 909
litefw_FirmwareInfo
lite-fw.h, 906
litefw_Fw_Type
lite-fw.h, 907
litefw_GetModelFamily
lite-fw.h, 910
litefw_GetVersion
lite-fw.h, 910
litefw_Models
lite-fw.h, 907
litefw_SetReadBlockSize
lite-fw.h, 911
litefw_fwdwl_error_codes
lite-fw.h, 907
litefw_getFileType
lite-fw.h, 910
litefw_logsenable
lite-fw.h, 910
litefw_set_log_func
lite-fw.h, 911
litefw_switch_9x07_to_downloadmode
lite-fw.h, 911
litefw_switch_to_BootHoldMode
lite-fw.h, 911
litefwlogger
lite-fw.h, 906
liteqmi_GetVersion
common.h, 835
liteqmi_helper_decode7bitAsciiEncString
common.h, 835
liteqmi_log
common.h, 835
loc.h
eQMI_LOC_SESS_STATUS_FAILURE, 917
eQMI_LOC_SESS_STATUS_IN_PROGRESS, 917
eQMI_LOC_SESS_STATUS_SUCCESS, 917
eQMI_LOC_SESS_STATUS_TIMEOUT, 917
loc.h, 912
LOCEVENTMASKNMEA, 916
LOCEVENTMASKWIFIREQ, 917
MAX_TEMP_DATA_LEN, 917
pack_loc_DeleteAssistData, 917
pack_loc_EventRegister, 918
pack_loc_SLQSLOCGetBestAvailPos, 919
pack_loc_SLQSLOCGetServer, 919
pack_loc_SLQSLOCInjectPosition, 920
pack_loc_SLQSLOCInjectSensorData, 920
pack_loc_SLQSLOCInjectUTCTime, 920
pack_loc_SLQSLOCSetCradleMountConfig, 921
pack_loc_SetExtPowerState, 918
pack_loc_SetOperationMode, 918
pack_loc_Start, 921
pack_loc_Stop, 921
unpack_loc_BestAvailPos_Ind, 922
unpack_loc_DeleteAssistData, 922
unpack_loc_DeleteAssistData_Ind, 922
unpack_loc_EngineState_Ind, 923
unpack_loc_EventNMEA_Ind, 923
unpack_loc_EventRegister, 924
unpack_loc_GetServer_Ind, 924
unpack_loc_GnssSvInfo_Ind, 924
unpack_loc_PositionRpt_Ind, 925
unpack_loc_SLQSLOCGetBestAvailPos, 926
unpack_loc_SLQSLOCGetServer, 927
unpack_loc_SLQSLOCInjectPosition, 927
unpack_loc_SLQSLOCInjectSensorData, 927
unpack_loc_SLQSLOCInjectUTCTime, 928
unpack_loc_SLQSLOCSetCradleMountConfig, 928
unpack_loc_SetExtPowerConfig_Ind, 925
unpack_loc_SetExtPowerState, 925
unpack_loc_SetOperationMode, 926
unpack_loc_SetOperationMode_Ind, 926
unpack_loc_Start, 928
unpack_loc_Stop, 929
loc_BdsSV, 91
id, 92
mask, 92
loc_BdsSVInfo, 92
len, 92
pSV, 92
loc_CellDb, 92
mask, 93
loc_ClkInfo, 93
mask, 94
loc_GnssData, 94
mask, 95
loc_IPv4Info, 96
address, 97
port, 97
TlvPresent, 97
loc_IPv6Info, 97
address, 97
port, 97
TlvPresent, 97
loc_LocApplicationInfo, 97
appNameLength, 98
appProviderLength, 98
appVersionLength, 98

appVersionValid, 98
pAppName, 98
pAppProvider, 98
pAppVersion, 98
loc_SV, 102
id, 103
mask, 103
system, 103
loc_SVInfo, 103
len, 103
pSV, 103
loc_gpsTime, 96
gpsTimeOfWeekMs, 96
gpsWeek, 96
loc_precisionDilution, 98
HDOP, 99
PDOP, 99
VDOP, 99
loc_satelliteInfo, 99
azimuth, 101
elevation, 101
gnssSvId, 101
healthStatus, 101
snr, 101
svInfoMask, 101
svListLen, 101
svStatus, 101
system, 101
validMask, 101
loc_sensorDataUsage, 101
aidingIndicatorMask, 102
usageMask, 102
loc_svUsedforFix, 103
gnssSvUsedList, 104
gnssSvUsedList_len, 104
loc_urlAddr, 104
address, 104
TlvPresent, 104
localTimeOffset
nas_qaQmi3Gpp2TimeZone, 184
logString
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 515
logger
common.h, 833
longName
nas_PLMNNetworkNameData, 181
unpack_nas_SLQSGetPLMNName_t, 579
longNameCI
unpack_nas_SLQSGetPLMNName_t, 579
longNameEn
unpack_nas_SLQSGetPLMNName_t, 579
longNameLen
nas_PLMNNetworkNameData, 181
unpack_nas_SLQSGetPLMNName_t, 579
longNameSB
unpack_nas_SLQSGetPLMNName_t, 579
longNameSpareBits
nas_PLMNNetworkNameData, 181
Longitude
unpack_pds_SLQSGetGPSStateInfo_t, 627
longitude
pack_loc_SLQSLOCInjectPosition_t, 279
loopbackMode
pack_wds_SLQSSSetLoopback_t, 405
loopbackMultiplier
pack_wds_SLQSSSetLoopback_t, 405
LteBandCapability
unpack_dms_SLQSGetBandCapability_t, 510
lteEmmDl
pack_nas_SLQSNasSwiIndicationRegister_t, 301
lteEmmUl
pack_nas_SLQSNasSwiIndicationRegister_t, 301
lteEsmDl
pack_nas_SLQSNasSwiIndicationRegister_t, 301
lteEsmUl
pack_nas_SLQSNasSwiIndicationRegister_t, 301
LteGsmCellInfo
nas_LTEInfoNeighboringGSM, 153
LteQci
unpack_qos_swiQosFlow_t, 646
lteRsrpDelta
nas_SLQSSignalStrengthsIndReq, 200
lteRsrpinfo
nas_SLQSSignalStrengthsInformation, 201
lteSSInfo, 105
rsrp, 105
rsrq, 105
rssi, 105
snr, 105
lteSnrDelta
nas_SLQSSignalStrengthsIndReq, 200
lteSnrinfo
nas_SLQSSignalStrengthsInformation, 201
ltersrp
unpack_nas_SLQSGetSignalStrength_t, 586
ltesnr
unpack_nas_SLQSGetSignalStrength_t, 586
lvl
unpack_tmd_SLQSTmdMitigationLvlRptCallback_-ind_t, 677

m_FwBuildId
CarrierImage_t, 40
m_FwImageId
CarrierImage_t, 40
m_PriBuildId
CarrierImage_t, 40
m_PriImageId
CarrierImage_t, 41
m_nCarrierId
CarrierImage_t, 40
m_nFolderId
CarrierImage_t, 40
m_nStorage
CarrierImage_t, 40
MACIndex
nas_NetworkStatEVDO, 169

MAX_BUILD_ID_LEN
dms.h, 843
MAX_ICCID_LENGTH
uim.h, 1123
MAX_MSE_TWS_MSG
sms.h, 1062
MAX_NO_OF_SLOTS
uim.h, 1123
MAX_SENSOR_DATA_LEN
loc.h, 917
MAX_SLOTS_STATUS
uim.h, 1123
MAX_SMS_LIST_SIZE
sms.h, 1062
MAX_TEMP_DATA_LEN
loc.h, 917
MAXVOICEUSSDLENGTH
voice.h, 1142
MCC
nas_CDMASysInfo, 116
nas_CDMASysInfoExt, 117
nas_currentPLMN, 121
nas_GSMSysInfo, 138
nas_LTESysInfo, 162
nas_QmiNas3GppNetworkInfo, 185
nas_QmiNas3GppNetworkRAT, 185
nas_QmisNasPcsDigit, 186
nas_WCDMASysInfo, 221
unpack_nas_GetServingNetwork_t, 568
MDMCallDuration
connectionStatus, 45
MDMConnStatus
connectionStatus, 45
MEID_MAX_SIZE
dms.h, 843
MEIDString
unpack_dms_GetDeviceSerialNumbers_t, 486
MIN
unpack_dms_GetVoiceNumber_t, 500
MINREQBKLEN
common.h, 832
MMTlv
unpack_sms_SetNewSMSCallback_ind_t, 653
MNC
nas_CDMASysInfo, 116
nas_currentPLMN, 121
nas_GSMSysInfo, 138
nas_LTESysInfo, 162
nas_QmiNas3GppNetworkInfo, 185
nas_QmiNas3GppNetworkRAT, 186
nas_QmisNasPcsDigit, 186
nas_WCDMASysInfo, 221
unpack_nas_GetServingNetwork_t, 568
MPTlv
NASQmiCbkNasSystemSelPrefInd, 232
MSGID_AND_LEN
common.h, 832
MSGID_DONT_CARE
common.h, 832
MTMessageInfo
newMTMessageTlv, 236
manString
pack_dms_SLQSSwiSetHostDevInfo_t, 254
unpack_dms_SLQSSwiGetHostDevInfo_t, 516
manufacturer
unpack_dms_GetManufacturer_t, 492
Mask
pack_wds_SLQSGetDUNCallInfo_t, 398
mask
loc_BdsSV, 92
loc_CellDb, 93
loc_ClkInfo, 94
loc_GnssData, 95
loc_SV, 103
unpack_qos_IPv6TrafCls_t, 630
unpack_qos_Tos_t, 648
max
PackSwiAVMSSettingsPeriodsInfo, 415
max_channel_rx_rate
unpack_wds_SLQSGetCurrentChannelRate_t, 738
max_channel_tx_rate
unpack_wds_SLQSGetCurrentChannelRate_t, 738
max_dist
pack_swiloc_SwiLocSetAutoStart_t, 345
unpack_swiloc_SwiLocGetAutoStart_t, 670
max_dist_reported
unpack_swiloc_SwiLocGetAutoStart_t, 670
max_time
pack_swiloc_SwiLocSetAutoStart_t, 345
unpack_swiloc_SwiLocGetAutoStart_t, 670
max_time_reported
unpack_swiloc_SwiLocGetAutoStart_t, 670
MaxAllowedPktSz
unpack_qos_swiQosFlow_t, 646
MaxChanRxRate
dunchannelRate, 54
MaxChanTxRate
dunchannelRate, 54
maxChannelRXRate
unpack_wds_GetConnectionRate_t, 721
maxChannelTXRate
unpack_wds_GetConnectionRate_t, 721
maxDlBitRate
LibPackQosClassID, 86
maxDownlinkBitrate
LibPackUMTSQoS, 90
wds_UMTSMinQoS, 816
maxImages
FMSImageIDEntries, 58
maxMitigationLevel
tmd_mitigationDevList, 445
MaxRXChannelRate
unpack_dms_GetDeviceCap_t, 482
maxRxChannelRate

unpack_dms_GetDeviceCapabilities_t, 483
maxSDUSize
LibPackUMTSQoS, 90
wds_UMTSMinQoS, 816
maxStorageSize
sms_maxStorageSizeResp, 429
MaxTXChannelRate
unpack_dms_GetDeviceCap_t, 482
maxTxChannelRate
unpack_dms_GetDeviceCapabilities_t, 483
maxUlBitRate
LibPackQosClassID, 86
maxUplinkBitrate
LibPackUMTSQoS, 90
wds_UMTSMinQoS, 816
mcc
nas_CSGID, 120
nas_MNRInfo, 165
nas_netSelectionPref, 166
nas_OperatorPLMNData, 172
pack_nas_SLQSGetPLMNName_t, 290
unpack_nas_GetHomeNetwork_t, 564
mccM
nas_minBasedIMSI, 164
mccT
nas_trueIMSI, 210
mdmCallDurationActive
unpack_wds_SLQSGetDUNCallInfo_t, 741
meanThroughputClass
LibPackGPRSRequestedQoS, 62
wds_GPRSQoS, 808
meid
unpack_dms_GetSerialNumbers_t, 497
meidSize
unpack_dms_GetDeviceSerialNumbers_t, 486
meidString
unpack_dms_SLQSSwiGetSerialNoExt_t, 517
message
unpack_sms_SLQSGetSMS_t, 655
message_type
NASOTAMessageTlv, 227
messageClass
sms_routeEntry, 433
messageFailureCode
unpack_sms_SendSMS_t, 652
messageFormat
pack_sms_SaveSMS_t, 326
pack_sms_SendSMS_t, 326
sms_sendAsyncsmsParams, 435
unpack_sms_SLQSGetSMS_t, 655
messageID
unpack_sms_SendSMS_t, 652
messageIndex
pack_sms_SLQSGetSMS_t, 329
pack_sms_SLQSModifySMSStatus_t, 331
qmiSmsMessageList, 415
sMSMTMessageInfo, 441
messageList
unpack_sms_SLQSGetSMSList_t, 657
messageListSize
unpack_sms_SLQSGetSMSList_t, 657
messageMode
sMSMessageModeInfo, 440
unpack_sms_SLQSWmsMemoryFullCallBack_ind_t, 659
MessageModeInfo
messageModeTlv, 106
messageModeTlv, 105
MessageModeInfo, 106
TlvPresent, 106
messageSize
pack_sms_SaveSMS_t, 326
pack_sms_SendSMS_t, 326
sms_sendAsyncsmsParams, 435
unpack_sms_SLQSGetSMS_t, 655
messageTag
pack_sms_SLQSModifySMSStatus_t, 331
qmiSmsMessageList, 415
unpack_sms_SLQSGetSMS_t, 655
messageType
sms_routeEntry, 433
MicMute
pack_audio_SLQSSetAudioProfile_t, 241
pack_swiaudio_SLQSSetM2MAVMute_t, 340
unpack_audio_SLQSGetAudioProfile_t, 473
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 661
unpack_swiaudio_SLQSGetM2MAVMute_t, 662
min
PackSwiAVMSSettingsPeriodsInfo, 415
MinPolicedPktSz
unpack_qos_swiQosFlow_t, 646
minSize
unpack_dms_GetVoiceNumber_t, 500
minute
nas_timeInfo, 209
nas_UniversalTime, 215
mipMode
unpack_wds_GetMobileIP_t, 726
mipStatus
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
mipstatAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
mitigationDevID
pack_tmd_SLQSTmdDeRegNotMitigationLvl_t, 352
pack_tmd_SLQSTmdGetMitigationLvl_t, 352
pack_tmd_SLQSTmdRegNotMitigationLvl_t, 353
mitigationDevIDLen
pack_tmd_SLQSTmdDeRegNotMitigationLvl_t, 352
pack_tmd_SLQSTmdGetMitigationLvl_t, 352
pack_tmd_SLQSTmdRegNotMitigationLvl_t, 353
mitigationDevId

tmd_mitigationDevList, 446
mitigationDevIdLen
tmd_mitigationDevList, 446
MitigationDevList
unpack_tmd_SLQSTmdGetMitigationDevList_t, 676
MitigationDevListLen
unpack_tmd_SLQSTmdGetMitigationDevList_t, 676
mnc
nas_CSGID, 120
nas_MNRInfo, 165
nas_netSelectionPref, 166
nas_OperatorPLMNData, 172
pack_nas_SLQSGetPLMNName_t, 290
unpack_nas_GetHomeNetwork_t, 564
mncPcsDigits
nas_CSGID, 121
mobileCountryCode
sMSEtwsPlmnInfo, 440
mobileIP
pack_wds_SLQSSetWdsEventCallback_t, 404
mobileNetworkCode
sMSEtwsPlmnInfo, 440
mode
pack_dms_SetEventReport_t, 250
pack_dms_SetPower_t, 251
pack_loc_SetOperationMode_t, 273
pack_sms_SLQSGetSmsBroadcastConfig_t, 329
pack_sms_SLQSSetSmsBroadcastActivation_t, 332
pack_sms_SLQSSetSmsBroadcastConfig_t, 333
pack_wds_SetMobileIP_t, 392
uim_refreshevent, 463
voice_callInfo, 781
ModePref
NASModePreferenceTlv, 225
modelString
pack_dms_SLQSSwiSetHostDevInfo_t, 254
unpack_dms_SLQSSwiGetHostDevInfo_t, 516
modelid
unpack_dms_GetModelID_t, 492
modelid_str
unpack_dms_GetFirmwareInfo_t, 488
modemMode
nas_CommInfo, 119
modemindex
pack_fms_SetImagesPreference_t, 261
month
nas_timeInfo, 209
nas_UniversalTime, 215
msgCount
sms_messageWaitingInfoContent, 430
msgProtocol
sms_msgProtocolResp, 430
msgType
sms_messageWaitingInfoContent, 430
msgWaitInfo
sms_getMsgWaitingInfo, 427
msgid
pack_qmi_t, 322
unpack_qmi_t, 628
msgtype
common.h, 834
Mtu
unpack_wds_SLQSGetRuntimeSettings_t, 744
MultDisc
nas_protocolSubtypeElement, 183
multiplier
unpack_qos_pktErrRate_t, 630
MuxID
qos_BindDataPortMuxID_t, 417
muxID
qmuxIPTable, 417

NAI
unpack_wds_GetMobileIPProfile_t, 728
NAS_NAM_NAME_LENGTH
nas.h, 937
NAS_PLMN_LENGTH
nas.h, 937
NASBandPreferenceTlv, 222
band_pref, 222
TlvPresent, 222
NASEmergencyModeTlv, 222
EmerMode, 222
TlvPresent, 222
NASGWAcqOrderPrefTlv, 223
GWAcqOrderPref, 224
TlvPresent, 224
NASLTEBandPreferenceTlv, 224
LTEBandPref, 224
TlvPresent, 224
NASLteNasReleaseInfoTlv, 224
nas_major, 225
nas_minor, 225
nas_release, 225
TlvPresent, 225
NASModePreferenceTlv, 225
ModePref, 225
TlvPresent, 225
NASNetSelPreferenceTlv, 225
NetSelPref, 226
TlvPresent, 226
NASOTAMessageTlv, 226
data_buf, 226
data_len, 226
message_type, 227
TlvPresent, 227
NASPRLPreferenceTlv, 230
PRLPref, 231
TlvPresent, 231
NASPhyCaAggPcellInfo, 227
dl_bw_value, 227
freq, 227
iLTEbandValue, 227
pci, 227

TlvPresent, 227
NASPhyCaAggScellDlBw, 228
dl_bw_value, 228
TlvPresent, 228
NASPhyCaAggScellIndType, 229
freq, 229
pci, 229
scell_state, 229
TlvPresent, 229
NASPhyCaAggScellIndex, 228
scell_idx, 228
TlvPresent, 228
NASPhyCaAggScellInfo, 229
dl_bw_value, 230
freq, 230
iLTEbandValue, 230
pci, 230
scell_state, 230
TlvPresent, 230
NASQmiCbkNasSwiOTAMessageInd, 231
nasRelInfoTlv, 231
otaMsgTlv, 231
timeTlv, 231
NASQmiCbkNasSystemSelPrefInd, 231
BPTlv, 232
EMTlv, 232
GWAOPTlv, 232
LBPTlv, 232
MPTlv, 232
NSPTlv, 232
PRLPTlv, 232
RPTlv, 233
SDPTlv, 233
NASRoamPreferenceTlv, 233
RoamPref, 233
TlvPresent, 233
NASServDomainPrefTlv, 233
SrvDomainPref, 233
TlvPresent, 233
NASServingSystemInfo, 233
csAttachState, 235
hdrPersonality, 235
psAttachState, 235
radioInterfaceList, 235
radioInterfaceNo, 235
registrationState, 235
selectedNetwork, 235
NASTimeInfoTlv, 235
time, 235
TlvPresent, 235
NMEAData
unpack_loc_EventNMEA_Ind_t, 546
NSPTlv
NASQmiCbkNasSystemSelPrefInd, 232
NWQoSStatus
unpack_qos_SLQSQosGetNetworkStatus_t, 634
naiSize
unpack_wds_GetMobileIPProfile_t, 728
namID
pack_nas_SLQSNasGet3GPP2Subscription_t, 296
voice_airTimer, 764
voice_prefVoiceSO, 796
voice_roamTimer, 798
namName
nas_namName, 165
namNameLen
nas_namName, 165
Name
unpack_nas_GetServingNetwork_t, 568
name
unpack_nas_GetHomeNetwork_t, 564
unpack_wds_GetDefaultProfile_t, 724
nameLen
voice_remotePartyName, 797
namePI
voice_remotePartyName, 797
nameSize
unpack_nas_GetHomeNetwork3GPP2_t, 562
unpack_nas_GetServingNetwork_t, 568
nameString
pack_dms_SLQSSwiSetOSInfo_t, 254
unpack_dms_SLQSSwiGetOSInfo_t, 516
namelength
unpack_omaDmFotaTlv_t, 615
namesize
unpack_wds_GetDefaultProfile_t, 724
nas.h
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_100, 937
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_15, 937
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_25, 937
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_50, 937
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_6, 937
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_75, 937
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED, 937
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED, 937
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_DECONFIGURED, 937
eNAS_LTE_CPHY_CA_BW_NRB_LITE_100, 938
eNAS_LTE_CPHY_CA_BW_NRB_LITE_15, 938
eNAS_LTE_CPHY_CA_BW_NRB_LITE_25, 938
eNAS_LTE_CPHY_CA_BW_NRB_LITE_50, 938
eNAS_LTE_CPHY_CA_BW_NRB_LITE_6, 938
eNAS_LTE_CPHY_CA_BW_NRB_LITE_75, 938
eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED_LITE, 938
eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED_LITE, 938

eNAS_LTE_CPHY_SCELL_STATE_DECONFIGURED_LITE, 938
nas.h, 929
NAS_PLMN_LENGTH, 937
pack_nas_GetACCOLC, 938
pack_nas_GetANAAAAuthenticationStatus, 938
pack_nas_GetCDMANetworkParameters, 939
pack_nas_GetHomeNetwork, 939
pack_nas_GetHomeNetwork3GPP2, 939
pack_nas_GetNetworkPreference, 940
pack_nas_GetRFInfo, 940
pack_nas_GetServingNetwork, 940
pack_nas_GetServingNetworkCapabilities, 940
pack_nas_GetSignalStrengths, 941
pack_nas_InitiateDomainAttach, 941
pack_nas_PerformNetworkScan, 941
pack_nas_SLQSConfigSigInfo, 943
pack_nas_SLQSGetErrorRate, 944
pack_nas_SLQSGetNetworkTime, 944
pack_nas_SLQSGetOperatorNameData, 945
pack_nas_SLQSGetPLMNName, 945
pack_nas_SLQSGetServingSystem, 945
pack_nas_SLQSGetSignalStrength, 946
pack_nas_SLQSGetSysInfo, 946
pack_nas_SLQSGetSysSelectionPref, 946
pack_nas_SLQSInitiateNetworkRegistration, 947
pack_nas_SLQSNASGeteDRXParams, 948
pack_nas_SLQSNASSeteDRXParams, 950
pack_nas_SLQSNASSwiGetChannelLock, 950
pack_nas_SLQSNASSwiSetChannelLock, 951
pack_nas_SLQSNasConfigSigInfo2, 947
pack_nas_SLQSNasGet3GPP2Subscription, 948
pack_nas_SLQSNasGetCellLocationInfo, 948
pack_nas_SLQSNasGetHDRColorCode, 949
pack_nas_SLQSNasGetSigInfo, 949
pack_nas_SLQSNasGetTxRxInfo, 949
pack_nas_SLQSNasIndicationRegisterExt, 950
pack_nas_SLQSNasSwiIndicationRegister, 951
pack_nas_SLQSNasSwiModemStatus, 951
pack_nas_SLQSSetBandPreference, 952
pack_nas_SLQSSetSignalStrengthsCallback, 952
pack_nas_SLQSSetSysSelectionPref, 953
pack_nas_SLQSSwiGetHDRPersonality, 953
pack_nas_SLQSSwiGetHDRProtSubtype, 953
pack_nas_SLQSSwiGetHRPDStats, 954
pack_nas_SLQSSwiGetLteCQI, 954
pack_nas_SLQSSwiGetLteSccRxInfo, 954
pack_nas_SLQSSwiNetworkDebug, 955
pack_nas_SLQSSwiPSDetach, 955
pack_nas_SetACCOLC, 942
pack_nas_SetCDMANetworkParameters, 942
pack_nas_SetLURejectCallback, 942
pack_nas_SetNetworkPreference, 943
pack_nas_SetRFInfoCallback, 943
pack_nas_SlqsGetLTECphyCAInfo, 944
unpack_nas_GetACCOLC, 955
unpack_nas_GetANAAAAuthenticationStatus, 956
unpack_nas_GetCDMANetworkParameters, 956
unpack_nas_GetHomeNetwork, 957
unpack_nas_GetHomeNetwork3GPP2, 957
unpack_nas_GetNetworkPreference, 957
unpack_nas_GetRFInfo, 958
unpack_nas_GetServingNetwork, 958
unpack_nas_GetServingNetworkCapabilities, 958
unpack_nas_GetSignalStrengths, 959
unpack_nas_InitiateDomainAttach, 959
unpack_nas_PerformNetworkScan, 959
unpack_nas_SLQSConfigSigInfo, 963
unpack_nas_SLQSGetErrorRate, 963
unpack_nas_SLQSGetNetworkTime, 964
unpack_nas_SLQSGetOperatorNameData, 964
unpack_nas_SLQSGetPLMNName, 965
unpack_nas_SLQSGetServingSystem, 965
unpack_nas_SLQSGetSignalStrength, 966
unpack_nas_SLQSGetSysInfo, 966
unpack_nas_SLQSGetSysSelectionPref, 966
unpack_nas_SLQSInitiateNetworkRegistration, 967
unpack_nas_SLQSNASGeteDRXParams, 968
unpack_nas_SLQSNASSeteDRXParams, 970
unpack_nas_SLQSNASSwiGetChannelLock, 971
unpack_nas_SLQSNASSwiSetChannelLock, 972
unpack_nas_SLQSNasConfigSigInfo2, 967
unpack_nas_SLQSNasGet3GPP2Subscription, 967
unpack_nas_SLQSNasGetCellLocationInfo, 968
unpack_nas_SLQSNasGetHDRColorCode, 968
unpack_nas_SLQSNasGetSigInfo, 969
unpack_nas_SLQSNasGetTxRxInfo, 969
unpack_nas_SLQSNasIndicationRegisterExt, 970
unpack_nas_SLQSNasNetworkTimeCallBack_ind, 970
unpack_nas_SLQSNasSigInfoCallback_ind, 971
unpack_nas_SLQSNasSwiIndicationRegister, 971
unpack_nas_SLQSNasSwiModemStatus, 972
unpack_nas_SLQSNasSwiOTAMessageCallback_ind, 972
unpack_nas_SLQSNasSysInfoCallback_ind, 973
unpack_nas_SLQSNasTimerCallback_ind, 973
unpack_nas_SLQSSetBandPreference, 973
unpack_nas_SLQSSetSignalStrengthsCallback, 974
unpack_nas_SLQSSetSysSelectionPref, 974
unpack_nas_SLQSSetSysSelectionPrefCallBack_ind, 974
unpack_nas_SLQSSwiGetHDRPersonality, 974
unpack_nas_SLQSSwiGetHDRProtSubtype, 975
unpack_nas_SLQSSwiGetHRPDStats, 975
unpack_nas_SLQSSwiGetLteCQI, 976
unpack_nas_SLQSSwiGetLteSccRxInfo, 976
unpack_nas_SLQSSwiNetworkDebug, 976
unpack_nas_SLQSSwiPSDetach, 977
unpack_nas_SetACCOLC, 960
unpack_nas_SetCDMANetworkParameters, 960
unpack_nas_SetDataCapabilitiesCallback_ind, 960

unpack_nas_SetEventReportInd, 961
unpack_nas_SetLURejectCallback, 961
unpack_nas_SetNasLTECphyCaIndCallback_ind, 961
unpack_nas_SetNetworkPreference, 962
unpack_nas_SetRFInfoCallback, 962
unpack_nas_SetRoamingIndicatorCallback_ind, 962
unpack_nas_SetServingSystemCallback_ind, 963
unpack_nas_SlqsGetLTECphyCAInfo, 964
unpack_valid_nas_GetCDMANetworkParameters, 977
unpack_valid_nas_SLQSGetServingSystem, 977
unpack_valid_nas_SLQSGetSignalStrength, 978
unpack_valid_nas_SLQSNasGetSigInfo, 979
nas_ActPilotPNElement, 107
ActSetPilotPN, 107
ActSetPilotPNStrength, 107
nas_AddCDMASysInfo, 107
geoSysIdx, 107
regPrd, 107
nas_AddSysInfo, 108
cellBroadcastCap, 108
geoSysIdx, 108
nas_CDMAChannel, 110
priChA, 110
priChB, 111
secChA, 111
secChB, 111
nas_CDMAECIOThresh, 111
CDMAECIOThreshListLen, 111
pCDMAECIOThreshList, 111
nas_CDMAInfo, 111
baseId, 112
baseLat, 112
baseLong, 112
nid, 112
refpn, 112
sid, 112
nas_CDMARSSIThresh, 112
CDMARSSIThreshListLen, 113
pCDMARSSIThreshList, 113
nas_CDMASysInfo, 113
baseId, 116
baseLat, 116
baseLong, 116
bsInfoValid, 116
bsPRev, 116
bsPRevValid, 116
ccsSupported, 116
ccsSupportedValid, 116
cdmaSysIdValid, 116
isSysPrlMatch, 116
isSysPrlMatchValid, 116
MCC, 116
MNC, 116
networkID, 116
networkIdValid, 116
pRevInUse, 116
pRevInUseValid, 116
packetZone, 116
packetZoneValid, 116
sysInfoCDMA, 116
systemID, 116
nas_CDMASysInfoExt, 117
imsi_11_12, 117
MCC, 117
nas_CSGID, 120
id, 120
mcc, 120
mnc, 120
mncPcsDigits, 121
rat, 121
nas_CallBarringSysInfo, 108
csBarStatus, 109
psBarStatus, 109
nas_CommInfo, 118
imsRegState, 119
modemMode, 119
psState, 120
systemMode, 120
temperature, 120
nas_DRCParams, 127
DRCCover, 128
DRCValue, 128
nas_DataStatusDetail, 122
IPAddress, 124
LastErrCode, 124
nas_DeviceConfigDetail, 126
Chipset, 127
HWVersion, 127
QLIC, 127
Technology, 127
nas_ECIOThresh, 129
ECIOThresListLen, 129
pECIOThresList, 129
nas_GERANInfo, 130
arfcn, 132
bsic, 132
cellID, 132
insNmrCellInfo, 132
lac, 132
nmrInst, 132
plmn, 132
rxLev, 132
timingAdvance, 132
nas_GSMRSSIThresh, 134
GSMRSSIThreshListLen, 134
pGSMRSSIThreshList, 134
nas_GSMSrvStatusInfo, 134
isPrefDataPath, 135
srvStatus, 135
trueSrvStatus, 135
nas_GSMSysInfo, 135
cellId, 137
cellIdValid, 137

dtmSupp, 137
dtmSuppValid, 137
egprsSupp, 138
egprsSuppValid, 138
lac, 138
lacValid, 138
MCC, 138
MNC, 138
networkIdValid, 138
regRejectInfoValid, 138
rejCause, 138
rejectSrvDomain, 138
sysInfoGSM, 138
nas_HDRECIOThresh, 138
HDRECIOThreshListLen, 138
pHDRECIOThreshList, 138
nas_HDRIOThresh, 138
HDRIOThreshListLen, 139
pHDRIOThreshList, 139
nas_HDRRSSIThresh, 139
HDRRSSIThreshListLen, 139
pHDRRSSIThreshList, 139
nas_HDRSINRThresh, 140
HDRSINRThresListLen, 140
pHDRSINRThresList, 140
nas_HDRSINRThreshold, 140
HDRSINRThreshListLen, 141
pHDRSINRThreshList, 141
nas_HDRSysInfo, 141
hdrActiveProt, 143
hdrActiveProtValid, 143
hdrPersonality, 143
hdrPersonalityValid, 143
is856SysId, 143
is856SysIdValid, 143
isSysPrlMatch, 143
isSysPrlMatchValid, 143
sysInfoHDR, 143
nas_IOThresh, 145
IOThresListLen, 145
pIOThresList, 145
nas_LTEInfo, 147
band, 149
bandwidth, 149
emmConnState, 149
emmState, 149
emmSubState, 149
RXChan, 149
TXChan, 149
nas_LTEInfoInterfreq, 150
freqsLen, 150
InfoInterfreq, 150
ueInIdle, 150
nas_LTEInfoIntrafreq, 150
CellParams, 152
cellReselPriority, 152
cellsLen, 152
earfcn, 152
globalCellId, 152
plmn, 152
sIntraSearch, 152
sNonIntraSearch, 152
servingCellId, 152
tac, 152
threshServingLow, 152
ueInIdle, 152
nas_LTEInfoNeighboringGSM, 152
freqsLen, 153
LteGsmCellInfo, 153
ueInIdle, 153
nas_LTEInfoNeighboringWCDMA, 153
freqsLen, 154
ueInIdle, 154
nas_LTERSRPThresh, 155
LTERSRPThreshListLen, 155
pLTERSRPThreshList, 155
nas_LTERSRQThresh, 155
LTERSRQThreshListLen, 156
pLTERSRQThreshList, 156
nas_LTERSSIThresh, 156
LTERSSIThreshListLen, 156
pLTERSSIThreshList, 156
nas_LTESNRThresh, 159
LTESNRThresListLen, 159
pLTESNRThresList, 159
nas_LTESNRThreshold, 159
LTESNRThreshListLen, 160
pLTESNRThreshList, 160
nas_LTESigRptCfg, 156
avgPeriod, 157
rptRate, 157
nas_LTESigRptConfig, 157
avgPeriod, 158
rptRate, 158
nas_LTESysInfo, 160
cellId, 162
cellIdValid, 162
lac, 162
lacValid, 162
MCC, 162
MNC, 162
networkIdValid, 162
regRejectInfoValid, 162
rejCause, 162
rejectSrvDomain, 162
sysInfoLTE, 162
tac, 162
tacValid, 162
nas_MNRInfo, 164
mcc, 165
mnc, 165
rat, 165
nas_NetworkStat1x, 166
ActSetCnt, 168
NeighborSetCnt, 168
pActPilotPNElements, 168

pNeighborSetPilotPN, 168
RX_EC_IO, 168
RX_PWR, 168
SO, 168
State, 168
TX_PWR, 168
nas_NetworkStatEVDO, 168
MACIndex, 169
PER, 170
pSectorID, 170
PilotEnergy, 170
RX_PWR, 170
SNR, 170
SectorIDLen, 170
State, 170
nas_OperatorPLMNData, 171
lac1, 172
lac2, 172
mcc, 172
mnc, 172
PLMNRecID, 172
nas_PLMNNetworkName, 179
numInstance, 180
PLMNNetName, 180
nas_PLMNNetworkNameData, 180
codingScheme, 181
countryInitials, 181
longName, 181
longNameLen, 181
longNameSpareBits, 181
shortName, 181
shortNameLen, 181
shortNameSpareBits, 181
nas_PhyCaAggPcellInfo, 173
dl_bw_value, 174
freq, 174
iLTEbandValue, 174
pci, 174
TlvPresent, 174
nas_PhyCaAggScellDlBw, 174
dl_bw_value, 174
TlvPresent, 174
nas_PhyCaAggScellIndType, 175
freq, 175
pci, 175
scell_state, 175
TlvPresent, 175
nas_PhyCaAggScellIndex, 174
scell_idx, 175
TlvPresent, 175
nas_PhyCaAggScellInfo, 176
dl_bw_value, 178
freq, 178
iLTEbandValue, 178
pci, 178
scell_state, 178
TlvPresent, 178
nas_PilotSetData, 178
NumPilots, 178
pPilotSetInfo, 178
nas_PilotSetParams, 179
PilotPN, 179
PilotStrength, 179
PilotType, 179
nas_QmiNas3GppNetworkInfo, 184
Desription, 185
Forbidden, 185
InUse, 185
MCC, 185
MNC, 185
Preferred, 185
Roaming, 185
nas_QmiNas3GppNetworkRAT, 185
MCC, 185
MNC, 186
RAT, 186
nas_QmisNasPcsDigit, 186
includes_pcs_digit, 186
MCC, 186
MNC, 186
nas_RFInfoTlv, 187
activeBandClass, 188
activeChannel, 188
radioInterface, 188
radioInterfaceSize, 188
TlvPresent, 188
nas_RSRPThresh, 189
pRSRPThresList, 189
RSRPThresListLen, 189
nas_RSRQThresh, 190
pRSRQThresList, 190
RSRQThresListLen, 190
nas_RSSIThresh, 190
pRSSIThresList, 191
RSSIThresListLen, 191
nas_RejectReasonTlv, 186
rejectCause, 187
serviceDomain, 187
TlvPresent, 187
nas_RxSigInfo, 192
isRadioTuned, 193
rsrp, 193
rxChainIndex, 193
rxPower, 193
nas_SLQSSignalStrengthsIndReq, 198
ecioDelta, 200
ecioThresholdList, 200
ecioThresholdListLen, 200
ioDelta, 200
lteRsrpDelta, 200
lteSnrDelta, 200
rsrqDelta, 200
rxSignalStrengthDelta, 200
sinrDelta, 200
sinrThresholdList, 200
sinrThresholdListLen, 200

nas_SLQSSignalStrengthsInformation, 200
ecioInfo, 201
errorRateInfo, 201
io, 201
lteRsrpinfo, 201
lteSnrinfo, 201
rsrqInfo, 201
rxSignalStrengthInfo, 201
sinr, 201
nas_SLQSSignalStrengthsTlv, 201
sSLQSSignalStrengthsInfo, 201
TlvPresent, 201
nas_SccRxInfo, 194
numInstances, 195
rsrq, 195
sigInfo, 195
snr, 195
TlvPresent, 195
nas_SignalStrengthTlv, 198
radioInterface, 198
signalStrength, 198
TlvPresent, 198
nas_SrvStatusInfo, 202
isPrefDataPath, 202
srvStatus, 202
nas_TDSCDMAECIOThresh, 205
nas_TDSCDMARSCPThresh, 205
nas_TDSCDMARSSIThresh, 206
nas_TDSCDMASINRCONFThresh, 206
nas_TDSCDMASINRThresh, 207
nas_UMTSInfo, 210
cellID, 212
ecio, 212
geranInst, 212
GeranInstInfo, 212
lac, 212
plmn, 212
psc, 212
rscp, 212
UMTSInstInfo, 212
uarfcn, 212
umtsInst, 212
nas_UMTSinstInfo, 212
umtsEcio, 213
umtsPsc, 213
umtsRscp, 213
umtsUarfcn, 213
nas_UniversalTime, 214
day, 215
dayOfWeek, 215
hour, 215
minute, 215
month, 215
second, 215
year, 215
nas_WCDMAECIOThresh, 216
nas_WCDMAInfoLTENeighborCell, 216
umtsLTENbrCellLen, 217
wcdmaRRCState, 217
nas_WCDMARSSIThresh, 217
nas_WCDMASysInfo, 218
cellId, 220
cellIdValid, 221
hsCallStatus, 221
hsCallStatusValid, 221
hsInd, 221
hsIndValid, 221
lac, 221
lacValid, 221
MCC, 221
MNC, 221
networkIdValid, 221
psc, 221
pscValid, 221
regRejectInfoValid, 221
rejCause, 221
rejectSrvDomain, 221
sysInfoWCDMA, 221
nas_acqOrderPref, 106
acqOrdeLen, 106
pAcqOrder, 106
nas_callBarStatus, 109
csBarStatus, 110
psBarStatus, 110
nas_cellParams, 117
pci, 118
rsrp, 118
rsrq, 118
rssi, 118
srxlev, 118
nas_currentPLMN, 121
MCC, 121
MNC, 121
netDescr, 121
netDescrLength, 121
nas_dataSrvCapabilities, 122
dataCapabilities, 122
dataCapabilitiesLen, 122
nas_detailSvcInfo, 125
hdrHybrid, 126
hdrSrvStatus, 126
isSysForbidden, 126
srvCapability, 126
srvStatus, 126
nas_dirNum, 127
dirNum, 127
dirNumLen, 127
nas_ecioListElement, 128
ecio, 128
radioIf, 129
nas_errorRateListElement, 129
errorRate, 130
radioIf, 130
nas_geranInstInfo, 132
geranArfcn, 132
geranBsicBcc, 132

geranBsicNcc, 133
geranRssi, 133
nas_gsmCellInfo, 133
arfcn, 133
band1900, 134
bsicId, 134
cellIdValid, 134
rssi, 134
srxlev, 134
nas_homeSIDNID, 143
numInstances, 143
SidNid, 143
nas_infoInterFreq, 143
cell_resel_priority, 144
cellInterFreqParams, 144
cells_len, 144
earfcn, 144
threshXHigh, 144
threshXLow, 145
nas_lteEARFCN, 145
earfcn0, 146
earfcn1, 146
status, 146
nas_lteGsmCellInfo, 146
cellReselPriority, 147
cells_len, 147
GsmCellInfo, 147
nccPermitted, 147
threshGsmHigh, 147
threshGsmLow, 147
nas_ltePCI, 154
earfcn, 154
pci, 154
status, 154
nas_lteRsrpinformation, 154
rsrplevel, 155
nas_lteSnrinformation, 158
snrlevel, 158
nas_lteWcdmaCellInfo, 162
cellReselPriority, 163
cellsLen, 163
threshXhigh, 163
threshXlow, 163
uarfcn, 163
WCDMACellInfo, 163
nas_major
NASLteNasReleaseInfoTlv, 225
nas_minBasedIMSI, 163
imsiM1112, 164
imsiMS1, 164
imsiMS2, 164
mccM, 164
nas_minor
NASLteNasReleaseInfoTlv, 225
nas_namName, 165
namName, 165
namNameLen, 165
nas_netSelectionPref, 165
mcc, 166
mnc, 166
netReg, 166
nas_nmrCellInfo, 170
nmrArfcn, 171
nmrBsic, 171
nmrCellID, 171
nmrLac, 171
nmrPlmn, 171
nmrRxLev, 171
nas_operatorNameString, 171
PLMNName, 171
nas_operatorPLMNList, 172
numInstance, 173
PLMNData, 173
nas_protocolSubtypeElement, 181
AccessMac, 182
AuthProt, 183
ControlMac, 183
EncryptProt, 183
ForwardMac, 183
IdleState, 183
KeyExchange, 183
MultDisc, 183
PhysicalLayer, 183
ReverseMac, 183
SecProt, 183
VirtStream, 183
nas_qaQmi3Gpp2TimeZone, 183
daylightSavings, 183
leapSeconds, 184
localTimeOffset, 184
nas_release
NASLteNasReleaseInfoTlv, 225
nas_roamIndList, 188
numInstances, 189
radioInterface, 189
roamIndicator, 189
nas_rsrqInformation, 189
radioIf, 190
rsrq, 190
nas_rxInfo, 191
ecio, 192
isRadioTuned, 192
phase, 192
rscp, 192
rsrp, 192
rxPower, 192
nas_rxSignalStrengthListElement, 193
radioIf, 194
rxSignalStrength, 194
nas_servSystem, 196
csAttachState, 197
numRadioInterfaces, 197
psAttachState, 197
radioInterface, 197
regState, 197
selNetwork, 197

nas_serviceProviderName, 195
displayCondition, 196
spn, 196
spnLength, 196
nas_sidNid, 197
nid, 198
sid, 198
nas_sysInfoCommon, 202
isSysForbidden, 204
isSysForbiddenValid, 204
roamStatus, 204
roamStatusValid, 204
srvCapability, 204
srvCapabilityValid, 204
srvDomain, 204
srvDomainValid, 204
nas_timeInfo, 207
day, 209
dayLtSavingAdj, 209
dayOfWeek, 209
hour, 209
minute, 209
month, 209
radioInterface, 209
second, 209
timeZone, 209
TlvPresent, 209
year, 209
nas_trueIMSI, 209
imsiT1112, 210
imsiTS1, 210
imsiTS2, 210
imsiTaddrNum, 210
mccT, 210
nas_txInfo, 210
isInTraffic, 210
txPower, 210
nas_umtsLTENbrCell, 213
cellIsTDD, 214
earfcn, 214
pci, 214
rsrp, 214
rsrq, 214
srxlev, 214
nas_wcdmaCellInfo, 215
cpich_ecno, 216
cpich_rscp, 216
psc, 216
srxlev, 216
nas_wcdmaUARFCN, 221
status, 222
uarfcn, 222
NasGetLTECphyCaInfo, 222
PhyCaAggPcellInfo, 223
PhyCaAggScellDlBw, 223
PhyCaAggScellIndType, 223
PhyCaAggScellIndex, 223
PhyCaAggScellInfo, 223
nasRelInfoTlv
NASQmiCbkNasSwiOTAMessageInd, 231
nccPermitted
nas_lteGsmCellInfo, 147
NeighborSetCnt
nas_NetworkStat1x, 168
netDescr
nas_currentPLMN, 121
netDescrLength
nas_currentPLMN, 121
netInfoLen
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
netReg
nas_netSelectionPref, 166
NetSelPref
NASNetSelPreferenceTlv, 226
NetworkID
unpack_nas_SLQSGetServingSystem_t, 583
networkID
nas_CDMASysInfo, 116
networkIdValid
nas_CDMASysInfo, 116
nas_GSMSysInfo, 138
nas_LTESysInfo, 162
nas_WCDMASysInfo, 221
networkInfoLen
unpack_wds_SLQSGetCurrDataSystemStat_t, 737
NetworkType
currNetworkInfo, 49
wds_currNetworkInfo, 801
NewImsRegStatus
unpack_imsa_SLQSGetIMSARegStatus_t, 535
NewMMTlv
unpack_sms_SetNewSMSCallback_ind_t, 653
newMTMessageTlv, 236
MTMessageInfo, 236
TlvPresent, 236
newPINLen
uim_unblockUIMPIN, 469
newPINVal
uim_unblockUIMPIN, 469
newPasswd
pack_voice_SLQSVoiceSetCallBarringPassword_t, 379
newPasswdAgain
pack_voice_SLQSVoiceSetCallBarringPassword_t, 379
newPin
pack_dms_UIMUnblockPIN_t, 258
newValue
pack_dms_UIMChangePIN_t, 255
nextHeader
LibPackTFTIDParams, 88
nid
nas_CDMAInfo, 112
nas_sidNid, 198

unpack_nas_GetHomeNetwork_t, 564
nmrArfcn
nas_nmrCellInfo, 171
nmrBsic
nas_nmrCellInfo, 171
nmrCellID
nas_nmrCellInfo, 171
nmrInst
nas_GERANInfo, 132
nmrLac
nas_nmrCellInfo, 171
nmrPlmn
nas_nmrCellInfo, 171
nmrRxLev
nas_nmrCellInfo, 171
noReplyTimer
voice_callFWExtInfo, 778
voice_callFWInfo, 779
notification
unpack_omaDmNotificationsTlv_t, 616
notificationType
sMSEtwsMessageInfo, 439
notused
unpack_dms_SetCrashAction_t, 501
num_instances
DMScustSettingList, 52
sms_qaQmi3GPP2BroadcastCfgInfo, 431
sms_qaQmi3GPPBroadcastCfgInfo, 432
numApp
slotInf, 424
uim_slotInfo, 468
numCrashes
crashInformation, 47
numEntries
unpack_dms_SLQSSwiGetFirmwareCurr_t, 513
numFeatures
uim_personalizationStatus, 460
numFiles
uim_registerRefresh, 464
NumFlows
unpack_qos_SLQSSetQosEventCallback_ind_t, 637
numInstance
nas_operatorPLMNList, 173
nas_PLMNNetworkName, 180
numInstances
nas_homeSIDNID, 143
nas_roamIndList, 189
nas_SccRxInfo, 195
sms_getMsgWaitingInfo, 427
voice_arrAlertingPattern, 767
voice_arrAlertingType, 768
voice_arrAlphaID, 768
voice_arrCalledPartyNum, 769
voice_arrCallEndReason, 770
voice_arrCallInfo, 770
voice_arrConnectPartyNum, 771
voice_arrDiagInfo, 771
voice_arrRedirPartyNum, 772
voice_arrRemotePartyName, 772
voice_arrRemotePartyNum, 773
voice_arrSvcOption, 773
voice_arrUUSInfo, 774
voice_getCallFWExtInfo, 791
voice_getCallFWInfo, 792
wds_DomainNameList, 808
wds_PCSCFFQDNAddressList, 811
wds_PCSCFIPv4ServerAddressList, 812
numLen
voice_callFWExtInfo, 778
voice_callFWInfo, 779
voice_peerNumberInfo, 794
voice_remotePartyNum, 797
numOfFiles
uim_refreshevent, 463
numOfRoutes
sms_setRoutesReq, 437
numOpt
wds_DHCPLeaseOptTlv, 802
wds_DHCPv4OptionList, 806
wdsDhcpv4OptionList, 818
numPI
voice_peerNumberInfo, 794
NumPilots
nas_PilotSetData, 178
numPlan
voice_callFWExtInfo, 778
voice_connectNumInfo, 786
voice_peerNumberInfo, 794
numPresInd
voice_connectNumInfo, 786
numQosFlow
unpack_qos_SLQSQosSwiReadDataStats_t, 636
numRadioInterfaces
nas_servSystem, 197
NumRxFilters
unpack_qos_QosFlowInfo_t, 632
numSI
voice_peerNumberInfo, 794
numSlot
uim_cardStatus, 452
NumSupUSBComps
unpack_dms_GetUSBComp_t, 499
NumTxFilters
unpack_qos_QosFlowInfo_t, 632
numType
voice_callFWExtInfo, 778
voice_connectNumInfo, 787
voice_peerNumberInfo, 794
number
voice_callFWExtInfo, 778
voice_callFWInfo, 779
voice_peerNumberInfo, 794
numberPlan
voice_callFwdTypeAndPlan, 776
numberType

voice_callFwdTypeAndPlan, 776
NxtHdrProto
unpack_qos_swiQosFilter_t, 642

OKtoRefresh
pack_uim_SLQSUIMRefreshOK_t, 361
OMADMEnable
pack_swioma_SLQSOMADMSetSettingsExt_t, 350
OMADMEnabled
unpack_swiavms_SLQSAVMSGetSettings_t, 665
unpack_swioma_SLQSOMADMGetSettings_t, 675
OMADMLogEnable
pack_swioma_SLQSOMADMSetSettingsExt_t, 350
oddEvenInd
voice_calledPartySubAdd, 775
OfflineReason
unpack_dms_GetPower_t, 495
offset
uim_readTransparentInfo, 461
oldPINLen
uim_changeUIMPIN, 453
oldPINVal
uim_changeUIMPIN, 453
oldPasswd
pack_voice_SLQSVoiceSetCallBarringPassword_t, 379
oldValue
pack_dms_UIMChangePIN_t, 255
opaqueId
pack_loc_SLQSLOCInjectSensorData_t, 281
operatingMode
dms_OperatingModeTlv, 50
OperatingModeTlv
unpack_dms_SetEventReport_ind_t, 503
operation
pack_pds_SetPDSDefaults_t, 313
uim_depersonalizationInformation, 454
OperationMode
unpack_dms_GetPower_t, 495
optCode
wds_DHCPOpt, 804
wds_DHCPv4Option, 805
wdsDhcpv4Option, 817
optList
wds_DHCPLeaseOptTlv, 802
optListData
wds_DHCPLeaseOptTlv, 802
optVal
wds_DHCPv4Option, 805
wdsDhcpv4Option, 818
optValLen
wds_DHCPOpt, 804
wds_DHCPv4Option, 806
wdsDhcpv4Option, 818
otaMsgTlv
NASQmiCbkNasSwiOTAMessageInd, 231

p1Status
unpack_dms_UIMGetPINStatus_t, 522
p1UnblockRetriesLeft
unpack_dms_UIMGetPINStatus_t, 522
p1VerifyRetriesLeft
unpack_dms_UIMGetPINStatus_t, 522
p2Status
unpack_dms_UIMGetPINStatus_t, 522
p2UnblockRetriesLeft
unpack_dms_UIMGetPINStatus_t, 522
p2VerifyRetriesLeft
unpack_dms_UIMGetPINStatus_t, 522
p3GPP2TimeInfo
unpack_nas_SLQSGetNetworkTime_t, 576
p3GPPTimeInfo
unpack_nas_SLQSGetNetworkTime_t, 576
p3GppNetworkInfoInstances
unpack_nas_PerformNetworkScan_t, 571
p3GppNetworkInstanceSize
unpack_nas_PerformNetworkScan_t, 571
p3gppRelease
pack_wds_SLQSSet3GPPConfigItem_t, 402
pAAASPI
pack_wds_SetMobileIPProfile_t, 394
PACK_WDS_IPV4
wds.h, 1171
PACK_WDS_IPV6
wds.h, 1171
pAMRStatus
pack_voice_SLQSVoiceGetConfig_t, 374
pAPN
PackSwiAVMSSettingsAPNInfo, 414
pAPNClass
LibpackProfile3GPP, 67
LibPackprofile_3GPP, 79
pAPNClass3GPP2
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 84
pAPNDisabledFlag
LibpackProfile3GPP, 67
LibPackprofile_3GPP, 79
pAPNEnabled3GPP2
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 84
pAPNInfo
pack_swiavms_SLQSAVMSSetSettings_t, 343
unpack_swiavms_SLQSAVMSGetSettings_t, 665
pAPNName
LibpackProfile3GPP, 67
LibPackprofile_3GPP, 79
pAPNnameSize
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pAVRXAVCHeadroom
audio_RXAVCList, 35
pAVRXAVCSens
audio_RXAVCList, 35
pAccuracy

unpack_pds_GetPDSDefaults_t, 617
pAcqOrder
nas_acqOrderPref, 106
pAcqOrderPref
pack_nas_SLQSSetSysSelectionPref_t, 309
pActPilotPNElements
nas_NetworkStat1x, 168
pAddCDMASysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 611
pAddGSMSysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 611
pAddHDRSysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 611
pAddLTESysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 611
pAddWCDMASysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 611
pAddrAllocPref
LibpackProfile3GPP, 67
LibPackprofile_3GPP, 79
pAddress
pack_wds_SetMobileIPProfile_t, 394
pAirTimer
pack_voice_SLQSVoiceGetConfig_t, 374
pAirTimerCnt
unpack_voice_SLQSVoiceGetConfig_t, 713
pAirTimerConfig
pack_voice_SLQSVoiceSetConfig_t, 380
pAirTimerStatus
unpack_voice_SLQSVoiceSetConfig_t, 716
pAlertType
unpack_voice_SLQSVoiceGetCallInfo_t, 702
pAlertingPattern
unpack_voice_SLQSVoiceGetCallInfo_t, 702
pAllowLinger
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 84
pAlphaIDInfo
unpack_voice_SLQSOriginateUSSD_t, 691
unpack_voice_SLQSVoiceDialCall_t, 693
unpack_voice_SLQSVoiceGetCallBarring_t, 698
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 699
unpack_voice_SLQSVoiceGetCallInfo_t, 702
unpack_voice_SLQSVoiceGetCallWaiting_t, 704
unpack_voice_SLQSVoiceGetCLIP_t, 705
unpack_voice_SLQSVoiceGetCLIR_t, 706
unpack_voice_SLQSVoiceGetCNAP_t, 708
unpack_voice_SLQSVoiceGetCOLP_t, 709
unpack_voice_SLQSVoiceGetCOLR_t, 711
unpack_voice_SLQSVoiceSetCallBarringPassword-_t, 715
unpack_voice_SLQSVoiceSetSUPSService_t, 718
pAltitudeAssumed
unpack_loc_PositionRpt_Ind_t, 554
pAltitudeWrtEllipsoid
pack_pds_SLQSPDSInjectPositionData_t, 318
unpack_loc_BestAvailPos_Ind_t, 542
unpack_loc_PositionRpt_Ind_t, 554
pAltitudeWrtMeanSeaLevel
unpack_loc_BestAvailPos_Ind_t, 542
unpack_loc_PositionRpt_Ind_t, 554
pAltitudeWrtSealevel
pack_pds_SLQSPDSInjectPositionData_t, 318
pAmrMode
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 529
pAmrOctetAligned
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 529
pAmrWBMode
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 529
pAmrWBOctetAligned
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 529
pAmrWbEnable
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 529
pApnString
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 84
pApnStringSize
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 84
pApnname
pack_wds_SetDefaultProfile_t, 390
pAppName
loc_LocApplicationInfo, 98
pAppPriority
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 84
pAppProvider
loc_LocApplicationInfo, 98
pAppSubType
unpack_nas_SLQSSwiGetHDRProtSubtype_t, 606
pAppType
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 84
pAppVersion
loc_LocApplicationInfo, 98
pApplication
pack_nas_SetCDMANetworkParameters_t, 286
pApplicationInfo
pack_loc_Start_t, 283
pArrAlertingPattern
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pArrAlertingType
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pArrAlphaID
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696

pArrCallEndReason
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pArrCallInfo
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pArrCalledPartyNum
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pArrConnectPartyNum
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pArrDiagInfo
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pArrRedirPartyNum
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pArrRemotePartyName
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pArrRemotePartyNum
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pArrSvcOption
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pArrUUSInfo
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
pAuth
pack_wds_SLQSStartDataSession_t, 406
pAuthPassword
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 84
pAuthPassword_tSize
LibPackprofile_3GPP2, 84
pAuthPasswordSize
LibpackProfile3GPP2, 73
pAuthProtocol
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 84
pAuthRetryCount
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 85
pAuthTimeout
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 85
pAuthenticateResult
unpack_uim_SLQSUIMAuthenticate_t, 682
pAuthenticationPref
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pAutoAnsStatus
unpack_voice_SLQSVoiceSetConfig_t, 716
pAutoAnswer
pack_voice_SLQSVoiceGetConfig_t, 375
pack_voice_SLQSVoiceSetConfig_t, 380
pAutoAnswerStat
unpack_voice_SLQSVoiceGetConfig_t, 713
pAutoSelection
unpack_uim_SLQSUIMGetConfiguration_t, 684
pAutosdm
pack_swioma_SLQSOMADMSetSettings_t, 349
pBandPref
pack_nas_SLQSSetSysSelectionPref_t, 309
unpack_nas_SLQSGetSysSelectionPref_t, 594
pBdsSVInfo
pack_loc_Delete_Assist_Data_t, 270
pBinaryUpdateSessionInfo
unpack_swiavms_SLQSAVMSEventReportInd_t, 663
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 666
pBroadcast
pack_nas_SetCDMANetworkParameters_t, 286
pBroadcastConfig
pack_sms_SLQSSetSmsBroadcastConfig_t, 333
unpack_sms_SLQSGetSmsBroadcastConfig_t, 656
pBurstDTMFLengths
pack_voice_SLQSVoiceBurstDTMF_t, 368
pCCResType
unpack_voice_SLQSVoiceGetCallBarring_t, 698
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 699
unpack_voice_SLQSVoiceGetCallWaiting_t, 704
unpack_voice_SLQSVoiceGetCLIP_t, 705
unpack_voice_SLQSVoiceGetCLIR_t, 706
unpack_voice_SLQSVoiceGetCNAP_t, 708
unpack_voice_SLQSVoiceGetCOLP_t, 709
unpack_voice_SLQSVoiceGetCOLR_t, 711
unpack_voice_SLQSVoiceSetCallBarringPassword-_t, 715
pCCResultType
unpack_voice_SLQSVoiceDialCall_t, 693
unpack_voice_SLQSVoiceSetSUPSService_t, 718
pCCSUPSType
unpack_voice_SLQSVoiceDialCall_t, 693
unpack_voice_SLQSVoiceGetCallBarring_t, 698
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 699
unpack_voice_SLQSVoiceGetCallWaiting_t, 704
unpack_voice_SLQSVoiceGetCLIP_t, 705
unpack_voice_SLQSVoiceGetCLIR_t, 707
unpack_voice_SLQSVoiceGetCNAP_t, 708
unpack_voice_SLQSVoiceGetCOLP_t, 709
unpack_voice_SLQSVoiceGetCOLR_t, 711
unpack_voice_SLQSVoiceSetCallBarringPassword-_t, 715
unpack_voice_SLQSVoiceSetSUPSService_t, 718
pCCSuppsType
unpack_voice_SLQSOriginateUSSD_t, 691
pCDMABroadcastConfig
pack_sms_SLQSSetSmsBroadcastConfig_t, 333
unpack_sms_SLQSGetSmsBroadcastConfig_t, 656
pCDMAChannel
unpack_nas_SLQSNasGet3GPP2Subscription_t, 595
pCDMAECIODelta
pack_nas_SLQSNasConfigSigInfo2_t, 294
pCDMAECIOThresh
pack_nas_SLQSNasConfigSigInfo2_t, 294
pCDMAECIOThreshList
nas_CDMAECIOThresh, 111

pCDMAFrameErrRate
unpack_nas_SLQSGetErrorRate_t, 575
pCDMAInfo
unpack_nas_SLQSNasGetCellLocationInfo_t, 596
pCDMARSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 294
pCDMARSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 294
pCDMARSSIThreshList
nas_CDMARSSIThresh, 113
pCDMASigInfo
unpack_nas_SLQSNasSigInfoCallback_ind_t, 601
pCDMASrvStatusInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 611
pCDMASysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 611
pCLIPResp
unpack_voice_SLQSVoiceGetCLIP_t, 705
pCLIRResp
unpack_voice_SLQSVoiceGetCLIR_t, 707
pCLIRType
pack_voice_SLQSVoiceDialCall_t, 370
pCNAPResp
unpack_voice_SLQSVoiceGetCNAP_t, 708
pCOLPResp
unpack_voice_SLQSVoiceGetCOLP_t, 709
pCOLRResp
unpack_voice_SLQSVoiceGetCOLR_t, 711
PCSCFAddrPCO
unpack_wds_SLQSGetRuntimeSettings_t, 744
PCSCFFQDNAddrList
unpack_wds_SLQSGetRuntimeSettings_t, 744
pCSCFPortName
pack_ims_SLQSSetRegMgrConfig_t, 267
pCSCFPortNameLen
pack_ims_SLQSSetRegMgrConfig_t, 267
pCSGID
pack_nas_SLQSSetSysSelectionPref_t, 309
pCUGInfo
pack_voice_SLQSVoiceDialCall_t, 370
pCallBarringPasswd
pack_voice_SLQSVoiceSetSUPSService_t, 383
pCallForwardingNumber
pack_voice_SLQSVoiceSetSUPSService_t, 383
pCallFwdTypeAndPlan
pack_voice_SLQSVoiceSetSUPSService_t, 383
pCallID
pack_voice_SLQSVoiceManageCalls_t, 377
pack_voice_SLQSVoiceSendFlash_t, 378
pack_voice_SLQSVoiceStartContDTMF_t, 383
unpack_voice_SLQSVoiceBurstDTMF_t, 692
unpack_voice_SLQSVoiceDialCall_t, 693
unpack_voice_SLQSVoiceGetCallBarring_t, 698
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 699
unpack_voice_SLQSVoiceGetCallWaiting_t, 704
unpack_voice_SLQSVoiceGetCLIP_t, 705
unpack_voice_SLQSVoiceGetCLIR_t, 706
unpack_voice_SLQSVoiceGetCNAP_t, 708
unpack_voice_SLQSVoiceGetCOLP_t, 709
unpack_voice_SLQSVoiceGetCOLR_t, 711
unpack_voice_SLQSVoiceSendFlash_t, 714
unpack_voice_SLQSVoiceSetCallBarringPassword-_t, 715
unpack_voice_SLQSVoiceSetSUPSService_t, 718
unpack_voice_SLQSVoiceStartContDTMF_t, 718
voice_burstDTMFInfo, 775
pCallId
pack_voice_SLQSVoiceAnswerCall_t, 367
pack_voice_SLQSVoiceEndCall_t, 371
unpack_voice_SLQSOriginateUSSD_t, 691
unpack_voice_SLQSVoiceAnswerCall_t, 692
unpack_voice_SLQSVoiceEndCall_t, 694
pCallInfo
unpack_voice_SLQSVoiceGetCallInfo_t, 702
pCallPartySubAdd
pack_voice_SLQSVoiceDialCall_t, 370
pCallType
pack_voice_SLQSVoiceDialCall_t, 370
pCardResult
unpack_uim_ReadTransparent_t, 680
unpack_uim_SLQSUIMAuthenticate_t, 682
unpack_uim_SLQSUIMGetFileAttributes_t, 685
pCardStatus
unpack_uim_GetCardStatus_t, 679
unpack_uim_SLQSUIMSetStatusChangeCall-Back_ind_t, 686
pCcResultType
unpack_voice_SLQSOriginateUSSD_t, 691
pCellDataMask
pack_pds_ResetPDSData_t, 311
pCellDb
pack_loc_Delete_Assist_Data_t, 270
pChangeDuration
pack_nas_SLQSInitiateNetworkRegistration_t, 291
pChgDuration
pack_nas_SLQSSetSysSelectionPref_t, 309
pClientPerformOperationFlag
pack_swiavms_SLQSAVMSSendSelection_t, 341
pClkInfo
pack_loc_Delete_Assist_Data_t, 270
pCodecSTGain
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
pColorCode
unpack_nas_SLQSNasGetHDRColorCode_t, 598
pConfig
unpack_swiavms_SLQSAVMSEventReportInd_t, 663
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 666
pConfigAltitudeAssumed
pack_loc_Start_t, 283
pConfigurationMask

pack_uim_SLQSUIMGetConfiguration_t, 358
pConnectNumInfo
unpack_voice_SLQSVoiceGetCallInfo_t, 702
pConnectionRequest
unpack_swiavms_SLQSAVMSEventReportInd_t, 663
pConnectionRetryTimers
pack_swiavms_SLQSAVMSSetSettings_t, 343
unpack_swiavms_SLQSAVMSGetSettings_t, 665
pCreateProfileOut
unpack_wds_SLQSCreateProfile_t, 734
pCurAMRConfig
unpack_voice_SLQSVoiceGetConfig_t, 713
pCurPrefVoiceSO
unpack_voice_SLQSVoiceGetConfig_t, 713
pCurProfile
pack_wds_SLQSCreateProfile_t, 395
pCurVoiceDomainPref
unpack_voice_SLQSVoiceGetConfig_t, 713
pCurVoicePrivacyPref
unpack_voice_SLQSVoiceGetConfig_t, 713
pCurrChannelRateInd
pack_wds_SLQSWdsSetEventReport_t, 408
pCurrDataBearerTechInd
pack_wds_SLQSWdsSetEventReport_t, 408
pCurrImgInfo
unpack_dms_SLQSSwiGetFirmwareCurr_t, 513
pCurrPrefDataSysInd
pack_wds_SLQSWdsSetEventReport_t, 408
pCurrTTYMode
unpack_voice_SLQSVoiceGetConfig_t, 713
pCurrentPersonality
unpack_nas_SLQSSwiGetHDRPersonality_t, 605
pCurrentPrsnlty
unpack_nas_SLQSSwiGetHDRProtSubtype_t, 606
pCustSettingInfo
DMSgetCustomFeatureV2, 53
pCustSettingList
DMSgetCustomFeatureV2, 53
pCustomSCP
pack_nas_SetCDMANetworkParameters_t, 286
pCwtMute
pack_swiaudio_SLQSSetM2MAudioProfile_t, 338
pack_swiaudio_SLQSSetM2MAVMute_t, 340
pCycleLen
pack_nas_SLQSNASSeteDRXParams_t, 300
unpack_nas_SLQSNASGeteDRXParams_t, 597
pDDTMInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
PDOP
loc_precisionDilution, 99
PDPType
unpack_wds_SLQSGetRuntimeSettings_t, 744
pDRCParams
unpack_nas_SLQSSwiGetHRPDStats_t, 607
pDTMFTXGain
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
pData
pack_cat_CATSendEnvelopeCommand_t, 243
pack_cat_CATSendTerminalResponse_t, 244
pDataBearer
unpack_wds_GetDataBearerTechnology_t, 722
pDataBearerTechInd
pack_wds_SLQSWdsSetEventReport_t, 408
pDataCallStatusChangeInd
pack_wds_SLQSWdsSetEventReport_t, 408
pDataMode
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 85
pDataRate
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 85
pDataSessionStatus
unpack_swiavms_SLQSAVMSEventReportInd_t, 663
pDataStatusDetail
unpack_nas_SLQSSwiNetworkDebug_t, 609
pDataSystemStatusChangeInd
pack_wds_SLQSWdsSetEventReport_t, 408
pDayltSavAdj
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t, 600
pDefaultPDNEnabled
pack_wds_SLQSSet3GPPConfigItem_t, 402
pDeferTime
pack_swiavms_SLQSAVMSSendSelection_t, 341
pack_swioma_SLQSOMADMSendSelection_t, 348
pDestSMSContent
pack_dms_SLQSSwiSetDyingGaspCfg_t, 253
packgetDyingGaspCfg, 410
pDestSMSNum
pack_dms_SLQSSwiSetDyingGaspCfg_t, 253
packgetDyingGaspCfg, 410
pDetachAction
pack_nas_SLQSSwiPSDetach_t, 310
pDeviceConfigDetail
unpack_nas_SLQSSwiNetworkDebug_t, 609
pDiagInfo
unpack_voice_SLQSVoiceGetCallInfo_t, 702
pDigitBuff
voice_burstDTMFInfo, 775
pDirNum
unpack_nas_SLQSNasGet3GPP2Subscription_t, 595
pDormancyStatusInd
pack_wds_SLQSWdsSetEventReport_t, 409
pDualStandByPrefInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pDuration
unpack_pds_GetXTRAValidity_t, 620
pECIOThresList
nas_ECIOThresh, 129
pECIOThresh
pack_nas_SLQSConfigSigInfo_t, 289

pECMode
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
PER
nas_NetworkStatEVDO, 170
pEVDOPageMonPerChangeInd
pack_wds_SLQSWdsSetEventReport_t, 409
pEarMute
pack_swiaudio_SLQSSetM2MAudioProfile_t, 338
pEdrxEnable
pack_nas_SLQSNASSeteDRXParams_t, 300
unpack_nas_SLQSNASGeteDRXParams_t, 597
pEmerMode
pack_nas_SLQSSetSysSelectionPref_t, 309
unpack_nas_SLQSGetSysSelectionPref_t, 594
pEmergencyCategory
pack_voice_SLQSVoiceDialCall_t, 370
pEnableNotification
pack_wds_DHCPv4ClientLeaseChange_t, 384
pEnabled
pack_wds_SetMobileIPProfile_t, 394
pEnabledStatus
unpack_pds_GetPDSState_t, 618
pEncryptData
pack_uim_ReadTransparent_t, 355
pEncryptedData
unpack_uim_ReadTransparent_t, 680
pEncryptedPIN1
pack_uim_VerifyPin_t, 365
unpack_uim_ChangePin_t, 679
unpack_uim_SetPinProtection_t, 681
unpack_uim_UnblockPin_t, 687
unpack_uim_VerifyPin_t, 688
pErrorRateInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pExtErrCode
UnPackGetProfileSettingOut, 754
pExtErrorCode
unpack_wds_SLQSModifyProfile_t, 745
pFailCause
unpack_voice_SLQSVoiceGetCallBarring_t, 698
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 699
unpack_voice_SLQSVoiceGetCallWaiting_t, 704
unpack_voice_SLQSVoiceGetCLIP_t, 705
unpack_voice_SLQSVoiceGetCLIR_t, 707
unpack_voice_SLQSVoiceGetCNAP_t, 708
unpack_voice_SLQSVoiceGetCOLP_t, 709
unpack_voice_SLQSVoiceGetCOLR_t, 711
unpack_voice_SLQSVoiceManageCalls_t, 713
unpack_voice_SLQSVoiceSetCallBarringPassword-_t, 715
unpack_voice_SLQSVoiceSetSUPSService_t, 718
pFailureReason
unpack_wds_SLQSStartDataSession_t, 751
pFileAttributes
unpack_uim_SLQSUIMGetFileAttributes_t, 685
pFixId
unpack_loc_PositionRpt_Ind_t, 554
pFlag
audio_RXPCMIIRFltr, 37
audio_TXPCMIIRFltr, 39
pFlashPayLd
pack_voice_SLQSVoiceSendFlash_t, 378
pFlashType
pack_voice_SLQSVoiceSendFlash_t, 378
pFollowOnDC
sms_sendAsyncsmsParams, 435
pForceOnDC
sms_sendAsyncsmsParams, 435
pForceRev0
pack_nas_SetCDMANetworkParameters_t, 287
pFwAutoCheck
pack_swioma_SLQSOMADMSetSettings_t, 349
pFwAutoSDM
pack_swiavms_SLQSAVMSSetSettings_t, 343
pGERANInfo
unpack_nas_SLQSNasGetCellLocationInfo_t, 596
pGPRSMinimumQoS
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pGPRSRequestedQos
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pGPSDataMask
pack_pds_ResetPDSData_t, 311
pGPSWeek
unpack_pds_GetXTRAValidity_t, 620
pGPSWeekOffset
unpack_pds_GetXTRAValidity_t, 620
pGSMBER
unpack_nas_SLQSGetErrorRate_t, 575
pGSMCallBarringSysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 611
pGSMCipherDomainSysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 611
pGSMRSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 294
pGSMRSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 294
pGSMRSSIThreshList
nas_GSMRSSIThresh, 134
pGSMSigInfo
unpack_nas_SLQSNasSigInfoCallback_ind_t, 601
pGSMSrvStatusInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 611
pGSMSysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 611
pGWAcqOrderPref
pack_nas_SLQSSetSysSelectionPref_t, 309
unpack_nas_SLQSGetSysSelectionPref_t, 594
pGenerator

pack_swiaudio_SLQSGetM2MAudioProfile_t, 335
pack_swiaudio_SLQSSetM2MAudioProfile_t, 338
pGetCallFWExtInfo
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 699
pGetCallFWInfo
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 699
pGetCustomInput
DMSgetCustomFeatureV2, 53
pGetDyingGaspCfg
unpack_dms_SLQSSwiGetDyingGaspCfg_t, 512
pGetDyingGaspStatistics
unpack_dms_SLQSSwiGetDyingGaspStatistics_t, 512
pGetIndicationRegInfo
unpack_sms_SLQSGetIndicationRegister_t, 654
pGetMsgWaitingInfoResp
unpack_sms_SLQSGetMessageWaiting_t, 655
pGetTransLayerInfo
unpack_sms_SLQSGetTransLayerInfo_t, 657
pGetTransNWRegInfo
unpack_sms_SLQSGetTransNWRegInfo_t, 657
pGnssData
pack_loc_Delete_Assist_Data_t, 270
pGpsTime
unpack_loc_BestAvailPos_Ind_t, 542
unpack_loc_PositionRpt_Ind_t, 554
pHA2002bis
pack_wds_SetMobileIPParameters_t, 393
pHAAuthenticator
pack_wds_SetMobileIPParameters_t, 393
pHASPI
pack_wds_SetMobileIPProfile_t, 394
pHDRECIODelta
pack_nas_SLQSNasConfigSigInfo2_t, 294
pHDRECIOThresh
pack_nas_SLQSNasConfigSigInfo2_t, 294
pHDRECIOThreshList
nas_HDRECIOThresh, 138
pHDRIODelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pHDRIOThresh
pack_nas_SLQSNasConfigSigInfo2_t, 295
pHDRIOThreshList
nas_HDRIOThresh, 139
pHDRNewUATIAssInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pHDRPackErrRate
unpack_nas_SLQSGetErrorRate_t, 575
pHDRRSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pHDRRSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 295
pHDRRSSIThreshList
nas_HDRRSSIThresh, 139
pHDRSINRDelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pHDRSINRThresList
nas_HDRSINRThresh, 140
pHDRSINRThresh
pack_nas_SLQSConfigSigInfo_t, 289
pack_nas_SLQSNasConfigSigInfo2_t, 295
pHDRSINRThreshList
nas_HDRSINRThreshold, 141
pHDRSessionCloseInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pHDRSigInfo
unpack_nas_SLQSNasSigInfoCallback_ind_t, 602
pHDRSrvStatusInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 612
pHDRSysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 612
pHTTPStatus
unpack_swiavms_SLQSAVMSEventReportInd_t, 663
pHaltSubscription
unpack_uim_SLQSUIMGetConfiguration_t, 684
pHeading
unpack_loc_BestAvailPos_Ind_t, 542
unpack_loc_PositionRpt_Ind_t, 554
pHeadingUnc
unpack_loc_BestAvailPos_Ind_t, 542
unpack_loc_PositionRpt_Ind_t, 554
pHomeSIDNID
unpack_nas_SLQSNasGet3GPP2Subscription_t, 595
pHorCirConf
unpack_loc_BestAvailPos_Ind_t, 542
pHorConfidence
unpack_loc_PositionRpt_Ind_t, 554
pHorEllpConf
unpack_loc_BestAvailPos_Ind_t, 542
pHorReliability
unpack_loc_BestAvailPos_Ind_t, 542
unpack_loc_PositionRpt_Ind_t, 554
pHorUncCircular
unpack_loc_BestAvailPos_Ind_t, 542
unpack_loc_PositionRpt_Ind_t, 554
pHorUncEllipseOrientAzimuth
unpack_loc_BestAvailPos_Ind_t, 542
unpack_loc_PositionRpt_Ind_t, 554
pHorUncEllipseSemiMajor
unpack_loc_BestAvailPos_Ind_t, 542
unpack_loc_PositionRpt_Ind_t, 554
pHorUncEllipseSemiMinor
unpack_loc_BestAvailPos_Ind_t, 542
unpack_loc_PositionRpt_Ind_t, 554
pHorizontalAccuracyLvl
pack_loc_Start_t, 284
pHorizontalConfidence
pack_pds_SLQSPDSInjectPositionData_t, 318
pHorizontalUncCircular
pack_pds_SLQSPDSInjectPositionData_t, 318

pHotSwapStatus
unpack_uim_GetCardStatus_t, 679
pHwConfig
pack_wds_SLQSSSetDHCPv4ClientConfig_t, 405
unpack_wds_SLQSSGetDHCPv4ClientConfig_t, 750
PI
voice_callFWExtInfo, 778
PIFACEId
pack_swiaudio_SLQSSetM2MAudioAVCFG_t, 337
pIMSDomain
pack_ims_SLQSSetIMSUserConfig_t, 263
unpack_ims_SLQSGetIMSUserConfig_t, 527
pIMSDomainLen
pack_ims_SLQSSetIMSUserConfig_t, 263
unpack_ims_SLQSGetIMSUserConfig_t, 527
pIMSTestMode
pack_ims_SLQSSetRegMgrConfig_t, 267
unpack_ims_SLQSGetRegMgrConfig_t, 530
pIOThresList
nas_IOThresh, 145
pIOThresh
pack_nas_SLQSConfigSigInfo_t, 289
pIPv4AddrInfo
unpack_loc_GetServer_Ind_t, 547
pIPv4AddrPref
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pIPv6AddPref
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pIPv6AddrInfo
unpack_loc_GetServer_Ind_t, 547
pIgnoreHotSwapSwitch
pack_uim_SLQSUIMPowerUp_t, 360
pImCnFlag
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pImageList
pack_fms_SetImagesPreference_t, 261
unpack_fms_GetImagesPreference_t, 524
pIndicationToken
pack_uim_ChangePin_t, 354
pack_uim_ReadTransparent_t, 355
pack_uim_SetPinProtection_t, 356
pack_uim_SLQSUIMAuthenticate_t, 357
pack_uim_SLQSUIMGetFileAttributes_t, 359
pack_uim_UnblockPin_t, 363
pack_uim_VerifyPin_t, 365
unpack_uim_ChangePin_t, 679
unpack_uim_ReadTransparent_t, 680
unpack_uim_SetPinProtection_t, 681
unpack_uim_SLQSUIMAuthenticate_t, 682
unpack_uim_SLQSUIMGetFileAttributes_t, 685
unpack_uim_UnblockPin_t, 687
unpack_uim_VerifyPin_t, 688
pInfo
pack_voice_AnswerUSSD_t, 365
pack_voice_OriginateUSSD_t, 366
pIntermediateReportState
pack_loc_Start_t, 284
pInterval
unpack_pds_GetPDSDefaults_t, 617
unpack_pds_GetXTRAAutomaticDownload_t, 619
pIpcpAckTimeout
LibpackProfile3GPP2, 73
LibPackprofile_3GPP2, 85
pIpcpCreqRetryCount
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pIsPcscfAddressNedded
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pKeyReferenceID
pack_uim_ChangePin_t, 354
pack_uim_SetPinProtection_t, 356
pack_uim_UnblockPin_t, 364
pack_uim_VerifyPin_t, 365
PLMNData
nas_operatorPLMNList, 173
PLMNName
nas_operatorNameString, 171
PLMNNetName
nas_PLMNNetworkName, 180
PLMNRecID
nas_OperatorPLMNData, 172
pLTEAttachProfile
pack_wds_SLQSSet3GPPConfigItem_t, 402
pLTEAttachProfileList
pack_wds_SLQSSet3GPPConfigItem_t, 402
pLTEBandPref
pack_nas_SLQSSetSysSelectionPref_t, 309
unpack_nas_SLQSGetSysSelectionPref_t, 594
pLTECphyCa
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pLTEInfo
unpack_nas_SLQSNasSwiModemStatus_t, 603
pLTEInfoInterfreq
unpack_nas_SLQSNasGetCellLocationInfo_t, 597
pLTEInfoIntrafreq
unpack_nas_SLQSNasGetCellLocationInfo_t, 597
pLTEInfoNeighboringGSM
unpack_nas_SLQSNasGetCellLocationInfo_t, 597
pLTEInfoNeighboringWCDMA
unpack_nas_SLQSNasGetCellLocationInfo_t, 597
pLTERSRPDelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pLTERSRPThresh
pack_nas_SLQSNasConfigSigInfo2_t, 295
pLTERSRPThreshList
nas_LTERSRPThresh, 155
pLTERSRQDelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pLTERSRQThresh
pack_nas_SLQSNasConfigSigInfo2_t, 295
pLTERSRQThreshList

nas_LTERSRQThresh, 156
pLTERSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pLTERSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 295
pLTERSSIThreshList
nas_LTERSSIThresh, 156
pLTESNRDelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pLTESNRThresList
nas_LTESNRThresh, 159
pLTESNRThresh
pack_nas_SLQSConfigSigInfo_t, 289
pack_nas_SLQSNasConfigSigInfo2_t, 295
pLTESNRThreshList
nas_LTESNRThreshold, 160
pLTESigInfo
unpack_nas_SLQSNasSigInfoCallback_ind_t, 602
pLTESigRptCfg
pack_nas_SLQSConfigSigInfo_t, 289
pLTESigRptConfig
pack_nas_SLQSNasConfigSigInfo2_t, 295
pLTESrvStatusInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 612
pLTESysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 612
pLTEVoiceSupportSysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 612
pLatitude
pack_pds_SLQSPDSInjectPositionData_t, 318
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pLcpAckTimeout
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pLcpCreqRetryCount
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pLeapSeconds
unpack_loc_PositionRpt_Ind_t, 554
pLinktimer
pack_sms_SendSMS_t, 326
sms_sendAsyncsmsParams, 435
pLongitude
pack_pds_SLQSPDSInjectPositionData_t, 318
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pLteEARFCN
pack_nas_SLQSNASSwiSetChannelLock_t, 302
unpack_nas_SLQSNASSwiGetChannelLock_t, 602
pLtePCI
pack_nas_SLQSNASSwiSetChannelLock_t, 302
unpack_nas_SLQSNASSwiGetChannelLock_t, 602
pMCC
unpack_nas_GetHomeNetwork3GPP2_t, 562
pMICGainSelect
unpack_audio_SLQSGetAudioPathConfig_t, 472
pMIPStatusInd
pack_wds_SLQSWdsSetEventReport_t, 409
pMNAAA
pack_wds_SetMobileIPProfile_t, 394
pMNC
unpack_nas_GetHomeNetwork3GPP2_t, 562
pMNCIncPCSDigStat
pack_nas_SLQSSetSysSelectionPref_t, 309
pMNHA
pack_wds_SetMobileIPProfile_t, 395
pMNRInfo
pack_nas_SLQSInitiateNetworkRegistration_t, 291
pMagneticDeviation
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pManagedRoamingInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pMaxStorageSizeReq
pack_sms_SLQSSmsGetMaxStorageSize_t, 334
pMaxStorageSizeResp
unpack_sms_SLQSSmsGetMaxStorageSize_t, 658
pMessage
pack_sms_SaveSMS_t, 326
pack_sms_SendSMS_t, 326
sms_sendAsyncsmsParams, 435
pMessageIndex
pack_sms_SLQSDeleteSMS_t, 328
unpack_sms_SaveSMS_t, 652
pMessageMode
pack_sms_SLQSDeleteSMS_t, 328
pack_sms_SLQSGetSMS_t, 329
pack_sms_SLQSGetSMSList_t, 330
pack_sms_SLQSModifySMSStatus_t, 331
sms_maxStorageSizeReq, 429
pMessageProtocol
unpack_sms_SLQSSmsGetMessageProtocol_t, 658
pMessageTag
pack_sms_SLQSDeleteSMS_t, 328
pMicMute
pack_swiaudio_SLQSSetM2MAudioProfile_t, 338
pMinBasedIMSI
unpack_nas_SLQSNasGet3GPP2Subscription_t, 595
pMinIntervalTime
pack_loc_Start_t, 284
pMinSessionExpiryTimer
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 529
pMncPcsDigitStatus
pack_nas_SLQSInitiateNetworkRegistration_t, 291
pMncPcsStatus
pack_nas_SLQSGetPLMNName_t, 290

pMode
pack_wds_SetMobileIPParameters_t, 393
pModePref
pack_nas_SLQSSetSysSelectionPref_t, 309
unpack_nas_SLQSGetSysSelectionPref_t, 594
pMuxID
pack_qos_BindDataPort_t, 322
pNAI
pack_wds_SetMobileIPProfile_t, 395
pNAMNameInfo
unpack_nas_SLQSNasGet3GPP2Subscription_t, 595
pNID
unpack_nas_GetHomeNetwork3GPP2_t, 562
pNITZInformation
unpack_nas_SLQSGetOperatorNameData_t, 577
pNSEnable
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
pNamID
pack_voice_SLQSVoiceGetConfig_t, 375
pName
pack_wds_SetDefaultProfile_t, 390
unpack_nas_GetHomeNetwork3GPP2_t, 562
pNegoDnsSrvrPref
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pNeighborSetPilotPN
nas_NetworkStat1x, 168
pNetSelPref
pack_nas_SLQSSetSysSelectionPref_t, 309
unpack_nas_SLQSGetSysSelectionPref_t, 594
pNetworkMode
pack_pds_SLQSGetAGPSConfig_t, 316
pack_pds_SLQSSetAGPSConfig_t, 319
pNetworkRejectInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pNetworkStat1x
unpack_nas_SLQSSwiNetworkDebug_t, 609
pNetworkStatEVDO
unpack_nas_SLQSSwiNetworkDebug_t, 609
pNetworkTimeInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pNotifStore
pack_swiavms_SLQSAVMSSetSettings_t, 343
pNotification
unpack_swiavms_SLQSAVMSEventReportInd_t, 663
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 666
pNotificationStore
unpack_swiavms_SLQSAVMSGetSettings_t, 665
pNumberOfPhySlot
unpack_uim_SLQSUIMGetSlotsStatus_t, 685
pNw2DescDisp
unpack_nas_GetHomeNetwork3GPP2_t, 563
pNw2DescEnc
unpack_nas_GetHomeNetwork3GPP2_t, 563
pNw2DescLen
unpack_nas_GetHomeNetwork3GPP2_t, 563
pNw2MCC
unpack_nas_GetHomeNetwork3GPP2_t, 563
pNw2MNC
unpack_nas_GetHomeNetwork3GPP2_t, 563
pNw2Name
unpack_nas_GetHomeNetwork3GPP2_t, 563
pOTASPStatus
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
unpack_voice_SLQSVoiceGetCallInfo_t, 702
pObjectVer
unpack_nas_SLQSSwiNetworkDebug_t, 609
pOperation
unpack_pds_GetPDSDefaults_t, 617
pOperatorNameString
unpack_nas_SLQSGetOperatorNameData_t, 577
pOperatorPLMNList
unpack_nas_SLQSGetOperatorNameData_t, 577
pOptList
wds_DHCPv4OptionList, 806
wdsDhcpv4OptionList, 818
pOptVal
wds_DHCPOpt, 804
pPCMParams
pack_swiaudio_SLQSSetM2MAudioAVCFG_t, 337
pPCSCFPort
unpack_ims_SLQSGetRegMgrConfig_t, 531
pPCSInstance
unpack_nas_PerformNetworkScan_t, 571
pPCSInstanceSize
unpack_nas_PerformNetworkScan_t, 571
pPDNInactivTimeout
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPDNInactivTimeout3GPP2
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pPDPtype
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPLMNNetworkName
unpack_nas_SLQSGetOperatorNameData_t, 577
pPRLPref
pack_nas_SLQSSetSysSelectionPref_t, 309
unpack_nas_SLQSGetSysSelectionPref_t, 594
pPWD
PackSwiAVMSSettingsAPNInfo, 414
pPackageID
pack_swiavms_SLQSAVMSSendSelection_t, 341
unpack_swiavms_SLQSAVMSEventReportInd_t, 664
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 666
pPagingTimeWindow
pack_nas_SLQSNASSeteDRXParams_t, 300
unpack_nas_SLQSNASGeteDRXParams_t, 597
pPass

pack_wds_SLQSStartDataSession_t, 406
pPassword
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pack_wds_SetDefaultProfile_t, 390
pPasswordSize
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPcscfAddrUsingDhcp
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPcscfAddrUsingPCO
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPdnType
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pPdpAccessConFlag
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPdpContext
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPdpDataCompType
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPdpHdrCompType
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPeriodInfo
pack_swiavms_SLQSAVMSSetSettings_t, 343
pPeripheralEndPointID
pack_qos_BindDataPort_t, 322
pPeroidsInfo
unpack_swiavms_SLQSAVMSGetSettings_t, 665
pPersonalityListLength
unpack_nas_SLQSSwiGetHDRPersonality_t, 605
unpack_nas_SLQSSwiGetHDRProtSubtype_t, 606
pPersonalizationStatus
unpack_uim_SLQSUIMGetConfiguration_t, 684
pPhoneCtxtURI
pack_ims_SLQSSetIMSSMSConfig_t, 263
unpack_ims_SLQSGetIMSSMSConfig_t, 526
pPhoneCtxtURILen
pack_ims_SLQSSetIMSSMSConfig_t, 263
unpack_ims_SLQSGetIMSSMSConfig_t, 526
pPilotSetData
unpack_nas_SLQSSwiGetHRPDStats_t, 607
pPilotSetInfo
nas_PilotSetData, 178
pPollingTimer
pack_swiavms_SLQSAVMSSetSettings_t, 343
unpack_swiavms_SLQSAVMSGetSettings_t, 666
pPositionSource
pack_pds_SLQSPDSInjectPositionData_t, 318
pPppSessCloseTimer1x
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pPppSessCloseTimerDO
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pPrecisionDilution
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pPrefVoiceDomain
pack_voice_SLQSVoiceSetConfig_t, 380
pPrefVoicePrivacy
pack_voice_SLQSVoiceGetConfig_t, 375
pPrefVoiceSO
pack_voice_SLQSVoiceGetConfig_t, 375
pack_voice_SLQSVoiceSetConfig_t, 380
pPrefVoiceSOStatus
unpack_voice_SLQSVoiceSetConfig_t, 716
pPreference
unpack_pds_GetXTRANetwork_t, 620
pPriCSCFPort
pack_ims_SLQSSetRegMgrConfig_t, 267
pPriCSCFPortName
unpack_ims_SLQSGetRegMgrConfig_t, 531
pPriCSCFPortNameLen
unpack_ims_SLQSGetRegMgrConfig_t, 531
pPriDNSIPv4AddPref
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPriDNSIPv6addpref
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPriV6DnsAddress
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pPrimaryHA
pack_wds_SetMobileIPProfile_t, 395
pPrimaryID
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 79
pPrimaryV4DnsAddress
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pProfileID
unpack_wds_SLQSCreateProfile_t, 734
pProfileId
pack_wds_SLQSCreateProfile_t, 395
pack_wds_SLQSModifyProfile_t, 401
pack_wds_SLQSSGetDHCPv4ClientConfig_t, 404
pack_wds_SLQSSSetDHCPv4ClientConfig_t, 405
pProfileList
pack_wds_SLQSSet3GPPConfigItem_t, 402
pProfileSettings
unpack_wds_SLQSGetProfileSettings_t, 742
pProfileType
pack_wds_SLQSCreateProfile_t, 396
pack_wds_SLQSModifyProfile_t, 401
pProfilename
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 80
pProfilenameSize

LibpackProfile3GPP, 68
LibPackprofile_3GPP, 80
pProtoSubTypElmnt
unpack_nas_SLQSSwiGetHDRProtSubtype_t, 606
pProtocol
pack_nas_SetCDMANetworkParameters_t, 287
pProtocolSubtypeElement
unpack_nas_SLQSSwiGetHDRPersonality_t, 605
pQosClassID
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 80
pRAT
pack_nas_SLQSSetSysSelectionPref_t, 309
pRATINstance
unpack_nas_PerformNetworkScan_t, 571
pRATInstanceSize
unpack_nas_PerformNetworkScan_t, 571
pRATType
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
PRIString
unpack_dms_GetFirmwareRevision_t, 489
unpack_dms_GetFirmwareRevisions_t, 490
PRLEnable
pack_swioma_SLQSOMADMSetSettingsExt_t, 350
PRLInd
unpack_nas_SLQSGetServingSystem_t, 584
PRLPTlv
NASQmiCbkNasSystemSelPrefInd, 232
PRLPref
NASPRLPreferenceTlv, 231
pRSRPThresList
nas_RSRPThresh, 189
pRSRPThresh
pack_nas_SLQSConfigSigInfo_t, 289
pRSRQThresList
nas_RSRQThresh, 190
pRSRQThresh
pack_nas_SLQSConfigSigInfo_t, 289
pRSSIThresList
nas_RSSIThresh, 191
pRSSIThresh
pack_nas_SLQSConfigSigInfo_t, 289
pRTPRTCPInactTimer
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 530
pRXAGCList
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
pRXAIG
audio_RXAGCList, 34
pRXAVCAGCSwitch
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
pRXAVCList
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
pRXChain0Info
unpack_nas_SLQSNasGetTxRxInfo_t, 599
pRXChain1Info
unpack_nas_SLQSNasGetTxRxInfo_t, 599
pRXComprSlope
audio_RXAGCList, 35
pRXComprThres
audio_RXAGCList, 35
pRXDroppedCount
unpack_wds_GetPacketStatistics_t, 730
pRXExpSlope
audio_RXAGCList, 35
pRXExpThres
audio_RXAGCList, 35
pRXOKBytesLastCall
unpack_wds_GetPacketStatistics_t, 730
pRXOkBytesCount
unpack_wds_GetPacketStatistics_t, 730
pRXPCMIIRFltr
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
pRXPacketErrors
unpack_wds_GetPacketStatistics_t, 730
pRXPacketOverflows
unpack_wds_GetPacketStatistics_t, 730
pRXPacketSuccesses
unpack_wds_GetPacketStatistics_t, 730
pRXStaticGain
audio_RXAGCList, 35
pRXTotalBytes
unpack_wds_GetByteTotals_t, 720
pRadioInterface
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t, 600
pRankIndicatorInd
pack_nas_SLQSNasSwiIndicationRegister_t, 301
pReRegPeriod
pack_wds_SetMobileIPParameters_t, 393
pReRegTraffic
pack_wds_SetMobileIPParameters_t, 393
pReadResult
unpack_uim_ReadTransparent_t, 680
pReasonMask
unpack_dms_GetOfflineReason_t, 494
pRecurrenceType
pack_loc_Start_t, 284
pRefreshEvent
unpack_uim_SLQSUIMRefreshGetLastEvent_t, 686
pRegCallStatInfoEvt
sms_getIndicationReg, 426
sms_setIndicationReg, 436
pRegDTMFEvents
pack_voice_SLQSVoiceIndicationRegister_t, 376
pRegInd
sms_getTransLayerInfo, 427
pRegMgrConfigEvents

pack_ims_SLQSImsConfigIndicationRegister_t, 262
pRegStatus
sms_getTransNWRegInfo, 428
unpack_swiavms_SLQSAVMSEventReportInd_t, 664
pRegTransLayerInfoEvt
sms_getIndicationReg, 426
sms_setIndicationReg, 436
pRegTransNWRegInfoEvt
sms_getIndicationReg, 426
sms_setIndicationReg, 436
pRegVoicePrivacyEvents
pack_voice_SLQSVoiceIndicationRegister_t, 376
pRejectReason
pack_swiavms_SLQSAVMSSendSelection_t, 341
pack_swioma_SLQSOMADMSendSelection_t, 348
pRemainingRetries
unpack_uim_ChangePin_t, 679
unpack_uim_SetPinProtection_t, 681
unpack_uim_SLQSUIMDepersonalization_t, 683
unpack_uim_UnblockPin_t, 687
unpack_uim_VerifyPin_t, 688
pRemotePartyName
unpack_voice_SLQSVoiceGetCallInfo_t, 702
pRemotePartyNum
unpack_voice_SLQSVoiceGetCallInfo_t, 702
pReportChannelRate
pack_wds_SLQSGetDUNCallInfo_t, 398
pReportConnStatus
pack_wds_SLQSGetDUNCallInfo_t, 398
pReportDataBearerTech
pack_wds_SLQSGetDUNCallInfo_t, 398
pReportDormStatus
pack_wds_SLQSGetDUNCallInfo_t, 398
pReqSettings
pack_wds_SLQSGetRuntimeSettings_t, 400
pRequestOptionList
pack_wds_SLQSSSetDHCPv4ClientConfig_t, 405
unpack_wds_SLQSSGetDHCPv4ClientConfig_t, 750
pRequestedTag
pack_sms_SLQSGetSMSList_t, 330
pRetryInterval
pack_wds_SetMobileIPParameters_t, 393
pRetryLimit
pack_wds_SetMobileIPParameters_t, 393
pRetryMessage
sms_sendAsyncsmsParams, 435
pRetryMessageId
sms_sendAsyncsmsParams, 435
pRevInUse
nas_CDMASysInfo, 116
pRevInUseValid
nas_CDMASysInfo, 116
pRevTunneling
pack_wds_SetMobileIPProfile_t, 395
pRingBackTimer
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 529
pRingingTimer
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 530
pRoamPref
pack_nas_SLQSSetSysSelectionPref_t, 309
unpack_nas_SLQSGetSysSelectionPref_t, 594
pRoamTimer
pack_voice_SLQSVoiceGetConfig_t, 375
pRoamTimerCnt
unpack_voice_SLQSVoiceGetConfig_t, 713
pRoamTimerConfig
pack_voice_SLQSVoiceSetConfig_t, 380
pRoamTimerStatus
unpack_voice_SLQSVoiceSetConfig_t, 717
pRoaming
pack_nas_SetCDMANetworkParameters_t, 287
pRscp
unpack_nas_SLQSNasSigInfoCallback_ind_t, 602
PSDomain
unpack_nas_GetServingNetwork_t, 568
pSID
unpack_nas_GetHomeNetwork3GPP2_t, 563
pSIODataPort
pack_qos_BindDataPort_t, 322
pSIPConfigEvents
pack_ims_SLQSImsConfigIndicationRegister_t, 262
pSIPLocalPort
pack_ims_SLQSSetSIPConfig_t, 268
unpack_ims_SLQSGetSIPConfig_t, 532
pSMSAttemptedFlag
packgetDyingGaspStatistics, 411
pSMSCAddress
pack_sms_SetSMSCAddress_t, 327
unpack_sms_GetSMSCAddress_t, 651
pSMSCType
pack_sms_SetSMSCAddress_t, 327
unpack_sms_GetSMSCAddress_t, 651
pSMSConfigEvents
pack_ims_SLQSImsConfigIndicationRegister_t, 262
pSMSFormat
pack_ims_SLQSSetIMSSMSConfig_t, 263
unpack_ims_SLQSGetIMSSMSConfig_t, 526
pSMSOverIPNwInd
pack_ims_SLQSSetIMSSMSConfig_t, 263
unpack_ims_SLQSGetIMSSMSConfig_t, 526
pSPC
pack_nas_SetCDMANetworkParameters_t, 287
pack_wds_SetMobileIPParameters_t, 393
pSV
loc_BdsSVInfo, 92
loc_SVInfo, 103
pSVInfo
pack_loc_Delete_Assist_Data_t, 270

pSarRFState
unpack_sar_SLQSGetRfSarState_t, 651
pSatelliteInfo
unpack_loc_GnssSvInfo_Ind_t, 548
pScanResult
unpack_nas_PerformNetworkScan_t, 571
pSccRxInfo
unpack_nas_SLQSSwiGetLteSccRxInfo_t, 608
pScrAmrEnable
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 530
pScrAmrWbEnable
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 530
pSecDNSIPv4AddPref
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 80
pSecDNSIPv6addpref
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 80
pSecV6DnsAddress
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pSecondaryFlag
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 80
pSecondaryHA
pack_wds_SetMobileIPProfile_t, 395
pSecondaryV4DnsAddress
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pSectorID
nas_NetworkStatEVDO, 170
pSendSmsParams
pack_sms_SLQSSendAsyncSMS_t, 331
pSensorDataUsage
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pServerAddress
pack_pds_SLQSSetAGPSConfig_t, 319
unpack_pds_SLQSGetAGPSConfig_t, 624
pServerPort
pack_pds_SLQSSetAGPSConfig_t, 319
unpack_pds_SLQSGetAGPSConfig_t, 624
pServerURL
pack_pds_SLQSSetAGPSConfig_t, 319
unpack_pds_SLQSGetAGPSConfig_t, 624
pServerURLLength
pack_pds_SLQSSetAGPSConfig_t, 319
unpack_pds_SLQSGetAGPSConfig_t, 624
pServiceClass
pack_voice_SLQSVoiceSetSUPSService_t, 383
pServiceOption
sms_sendAsyncsmsParams, 435
pServingSystemInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pSessionExpiryTimer
pack_ims_SLQSSetIMSVoIPConfig_t, 266
unpack_ims_SLQSGetIMSVoIPConfig_t, 530
pSessionType
unpack_swiavms_SLQSAVMSEventReportInd_t, 664
pSetIndicationRegReq
pack_sms_SLQSSetIndicationRegister_t, 332
pSetRoutesReq
pack_sms_SLQSSmsSetRoutes_t, 334
pSettingResp
unpack_ims_SLQSGetIMSSMSConfig_t, 526
unpack_ims_SLQSGetIMSUserConfig_t, 527
unpack_ims_SLQSGetIMSVoIPConfig_t, 530
unpack_ims_SLQSGetRegMgrConfig_t, 531
unpack_ims_SLQSGetSIPConfig_t, 532
unpack_ims_SLQSSetIMSSMSConfig_t, 532
unpack_ims_SLQSSetIMSUserConfig_t, 533
unpack_ims_SLQSSetIMSVoIPConfig_t, 533
unpack_ims_SLQSSetRegMgrConfig_t, 533
unpack_ims_SLQSSetSIPConfig_t, 534
pSigCompEnabled
pack_ims_SLQSSetSIPConfig_t, 267
unpack_ims_SLQSGetSIPConfig_t, 532
pSigIndReq
pack_nas_SLQSSetSignalStrengthsCallback_t, 304
pSignalStrengthInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pSmsOnIms
sms_sendAsyncsmsParams, 435
pSmsStorage
unpack_sms_SLQSSwiGetSMSStorage_t, 659
pSourceIP
LibPackTFTIDParams, 88
pSpeedHorizontal
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pSpeedUnc
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pSpeedVertical
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pSpeedVerticalUnc
unpack_loc_BestAvailPos_Ind_t, 543
pSrvDomainPref
pack_nas_SLQSSetSysSelectionPref_t, 309
unpack_nas_SLQSGetSysSelectionPref_t, 594
pSrvOpt
unpack_voice_SLQSVoiceGetCallInfo_t, 702
pSrvRegRestriction
pack_nas_SLQSSetSysSelectionPref_t, 309
pSrvcProviderName
unpack_nas_SLQSGetOperatorNameData_t, 577
pStage0Val
audio_RXPCMIIRFltr, 37
audio_TXPCMIIRFltr, 39
pStage1Val
audio_RXPCMIIRFltr, 37

audio_TXPCMIIRFltr, 39
pStage2Val
audio_RXPCMIIRFltr, 37
audio_TXPCMIIRFltr, 39
pStage3Val
audio_RXPCMIIRFltr, 37
audio_TXPCMIIRFltr, 39
pStage4Val
audio_RXPCMIIRFltr, 37
audio_TXPCMIIRFltr, 39
pStageCnt
audio_RXPCMIIRFltr, 37
audio_TXPCMIIRFltr, 39
pStatMask
pack_wds_GetPacketStatistics_t, 387
pSubscribeTimer
pack_ims_SLQSSetSIPConfig_t, 268
unpack_ims_SLQSGetSIPConfig_t, 532
pSubscriptionInfoInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pSuppressSysInfoInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pSuppsNotifEvents
pack_voice_SLQSVoiceIndicationRegister_t, 376
pSvUsedforFix
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pSvcClass
pack_voice_SLQSVoiceGetCallBarring_t, 371
pack_voice_SLQSVoiceGetCallForwardingStatus-
_t, 372
pack_voice_SLQSVoiceGetCallWaiting_t, 373
unpack_voice_SLQSVoiceGetCallBarring_t, 698
unpack_voice_SLQSVoiceGetCallWaiting_t, 704
pSvcType
pack_voice_SLQSVoiceDialCall_t, 370
pSysInfoInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pSysInfoNoChange
unpack_nas_SLQSSysInfoCallback_ind_t, 612
pSystemSelectionInd
pack_nas_SLQSNasIndicationRegisterExt_t, 299
pTDSCDMAECIODelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pTDSCDMAECIOThresh
pack_nas_SLQSNasConfigSigInfo2_t, 295
pTDSCDMAECIOThreshList
nas_TDSCDMAECIOThresh, 205
pTDSCDMARSCPDelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pTDSCDMARSCPThresh
pack_nas_SLQSNasConfigSigInfo2_t, 295
pTDSCDMARSCPThreshList
nas_TDSCDMARSCPThresh, 205
pTDSCDMARSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pTDSCDMARSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 295
pTDSCDMARSSIThreshList
nas_TDSCDMARSSIThresh, 206
pTDSCDMASINRDelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pTDSCDMASINRThresh
pack_nas_SLQSNasConfigSigInfo2_t, 295
pTDSCDMASINRThreshList
nas_TDSCDMASINRThresh, 207
pTDSCDMASigInfoExt
unpack_nas_SLQSNasSigInfoCallback_ind_t, 602
pTFTID1Params
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 80
pTFTID2Params
LibpackProfile3GPP, 68
LibPackprofile_3GPP, 80
pTTYConfigStatus
unpack_voice_SLQSVoiceSetConfig_t, 717
pTTYMode
pack_voice_SLQSVoiceGetConfig_t, 375
pack_voice_SLQSVoiceSetConfig_t, 380
pTXAGCList
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
pTXAIG
audio_TXAGCList, 37
pTXAVCSwitch
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
pTXComprSlope
audio_TXAGCList, 38
pTXComprThres
audio_TXAGCList, 38
pTXDroppedCount
unpack_wds_GetPacketStatistics_t, 730
pTXExpSlope
audio_TXAGCList, 38
pTXExpThres
audio_TXAGCList, 38
pTXGain
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
pTXInfo
unpack_nas_SLQSNasGetTxRxInfo_t, 599
pTXOKBytesLastCall
unpack_wds_GetPacketStatistics_t, 730
pTXOkBytesCount
unpack_wds_GetPacketStatistics_t, 730
pTXPCMIIRFltr
pack_audio_SLQSSetAudioPathConfig_t, 240
unpack_audio_SLQSGetAudioPathConfig_t, 472
pTXPacketErrors
unpack_wds_GetPacketStatistics_t, 730
pTXPacketOverflows
unpack_wds_GetPacketStatistics_t, 730
pTXPacketSuccesses
unpack_wds_GetPacketStatistics_t, 730
pTXStaticGain

audio_TXAGCList, 38
pTXTotalBytes
unpack_wds_GetByteTotals_t, 720
pTdscdmaBandPref
pack_nas_SLQSSetSysSelectionPref_t, 310
pTech
pack_wds_SLQSStartDataSession_t, 406
pTechnologyMask
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pTimeSrc
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pTimeStamp
pack_pds_SLQSPDSInjectPositionData_t, 318
packgetDyingGaspStatistics, 411
pTimeType
pack_pds_SLQSPDSInjectPositionData_t, 318
pTimeUnc
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 555
pTimeZone
unpack_nas_SLQSNasNetworkTimeCallBack_ind-_t, 600
pTimeout
unpack_pds_GetPDSDefaults_t, 617
pTimer
pack_nas_SLQSNasSwiIndicationRegister_t, 301
pTimerSIPReg
pack_ims_SLQSSetSIPConfig_t, 268
unpack_ims_SLQSGetSIPConfig_t, 532
pTimerT1
pack_ims_SLQSSetSIPConfig_t, 268
unpack_ims_SLQSGetSIPConfig_t, 532
pTimerT2
pack_ims_SLQSSetSIPConfig_t, 268
unpack_ims_SLQSGetSIPConfig_t, 532
pTimerTf
pack_ims_SLQSSetSIPConfig_t, 268
unpack_ims_SLQSGetSIPConfig_t, 532
pTimerVal
pack_voice_SLQSVoiceSetSUPSService_t, 383
pTimestampUtc
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 554
pTrackingStatus
unpack_pds_GetPDSState_t, 618
pTransLayerInfo
sms_getTransLayerInfo, 427
pTransferStatInd
pack_wds_SLQSGetDUNCallInfo_t, 398
pack_wds_SLQSWdsSetEventReport_t, 409
pTransferStatusReport
sms_setRoutesReq, 437
pTrueIMSI
unpack_nas_SLQSNasGet3GPP2Subscription_t, 595
pUATI
unpack_nas_SLQSSwiGetHRPDStats_t, 607
pUMTSCellID
unpack_nas_SLQSNasGetCellLocationInfo_t, 597
pUMTSInfo
unpack_nas_SLQSNasGetCellLocationInfo_t, 597
pUMTSMinQoS
LibpackProfile3GPP, 69
LibPackprofile_3GPP, 80
pUMTSMinQosSigInd
LibpackProfile3GPP, 69
LibPackprofile_3GPP, 80
pUMTSReqQoS
LibpackProfile3GPP, 69
LibPackprofile_3GPP, 80
pUMTSReqQoSSigInd
LibpackProfile3GPP, 69
LibPackprofile_3GPP, 80
pURL
unpack_loc_GetServer_Ind_t, 547
pUSSDInfo
unpack_voice_SLQSOriginateUSSD_t, 691
pUUSInFo
pack_voice_SLQSVoiceDialCall_t, 370
pUUSInfo
unpack_voice_SLQSVoiceGetCallInfo_t, 702
pUimSlotsStatus
unpack_uim_SLQSUIMGetSlotsStatus_t, 685
pUname
PackSwiAVMSSettingsAPNInfo, 414
pUser
pack_wds_SLQSStartDataSession_t, 406
pUserConfigEvents
pack_ims_SLQSImsConfigIndicationRegister_t, 262
pUserData
sms_sendAsyncsmsParams, 435
pUserId
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pUserIdSize
LibpackProfile3GPP2, 74
LibPackprofile_3GPP2, 85
pUsername
LibpackProfile3GPP, 69
LibPackprofile_3GPP, 80
pack_wds_SetDefaultProfile_t, 391
pUsernameSize
LibpackProfile3GPP, 69
LibPackprofile_3GPP, 80
pVerboseFailReasonType
unpack_wds_SLQSStartDataSession_t, 751
pVerboseFailureReason
unpack_wds_SLQSStartDataSession_t, 751
pVertConfidence
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 555
pVertReliability
unpack_loc_BestAvailPos_Ind_t, 543

unpack_loc_PositionRpt_Ind_t, 555
pVertUnc
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_PositionRpt_Ind_t, 555
pVerticalConfidence
pack_pds_SLQSPDSInjectPositionData_t, 318
pVerticalUnc
pack_pds_SLQSPDSInjectPositionData_t, 318
pVoIPConfigEvents
pack_ims_SLQSImsConfigIndicationRegister_t, 262
pVoiceDomainPref
pack_voice_SLQSVoiceGetConfig_t, 375
pVoiceDomainPrefStatus
unpack_voice_SLQSVoiceSetConfig_t, 717
pVoicePrivacy
unpack_voice_SLQSVoiceGetAllCallInfo_t, 696
unpack_voice_SLQSVoiceGetCallInfo_t, 702
pVolume
pack_swiaudio_SLQSSetM2MAudioProfile_t, 338
pWAMSParaChanged
unpack_swiavms_SLQSAVMSEventReportInd_t, 664
pWCDMABER
unpack_nas_SLQSGetErrorRate_t, 575
pWCDMACallBarringSysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 612
pWCDMACipherDomainSysInfo
unpack_nas_SLQSGetSysInfo_t, 589
unpack_nas_SLQSSysInfoCallback_ind_t, 612
pWCDMAECIODelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pWCDMAECIOThresh
pack_nas_SLQSNasConfigSigInfo2_t, 295
pWCDMAECIOThreshList
nas_WCDMAECIOThresh, 216
pWCDMAInfoLTENeighborCell
unpack_nas_SLQSNasGetCellLocationInfo_t, 597
pWCDMARSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 295
pWCDMARSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 295
pWCDMARSSIThreshList
nas_WCDMARSSIThresh, 218
pWCDMASigInfo
unpack_nas_SLQSNasSigInfoCallback_ind_t, 602
pWCDMASrvStatusInfo
unpack_nas_SLQSGetSysInfo_t, 590
unpack_nas_SLQSSysInfoCallback_ind_t, 612
pWCDMASysInfo
unpack_nas_SLQSGetSysInfo_t, 590
unpack_nas_SLQSSysInfoCallback_ind_t, 612
pWcdmaUARFCN
pack_nas_SLQSNASSwiSetChannelLock_t, 302
unpack_nas_SLQSNASSwiGetChannelLock_t, 602
pWifiState
pack_pds_SLQSSetPositionMethodState_t, 320
pXid
unpack_loc_BestAvailPos_Ind_t, 543
pXtraDataState
pack_pds_SLQSSetPositionMethodState_t, 320
pXtraTimeState
pack_pds_SLQSSetPositionMethodState_t, 320
pack_audio_SLQSGetAudioPathConfig
audio.h, 822
pack_audio_SLQSGetAudioPathConfig_t, 236
Item, 237
Profile, 237
pack_audio_SLQSGetAudioProfile
audio.h, 822
pack_audio_SLQSGetAudioProfile_t, 237
Generator, 237
pack_audio_SLQSGetAudioVolTLBConfig
audio.h, 823
pack_audio_SLQSGetAudioVolTLBConfig_t, 238
Generator, 238
Item, 238
Profile, 238
Volume, 238
pack_audio_SLQSSetAudioPathConfig
audio.h, 823
pack_audio_SLQSSetAudioPathConfig_t, 238
pCodecSTGain, 240
pECMode, 240
pNSEnable, 240
pRXAGCList, 240
pRXAVCList, 240
pTXAGCList, 240
pTXAVCSwitch, 240
pTXGain, 240
Profile, 240
pack_audio_SLQSSetAudioProfile
audio.h, 824
pack_audio_SLQSSetAudioProfile_t, 240
EarMute, 241
Generator, 241
MicMute, 241
Profile, 241
Volume, 241
pack_audio_SLQSSetAudioVolTLBConfig
audio.h, 824
pack_audio_SLQSSetAudioVolTLBConfig_t, 242
Generator, 242
Item, 242
Profile, 242
VolValue, 242
Volume, 242
pack_cat_CATSendEnvelopeCommand
cat.h, 827
pack_cat_CATSendEnvelopeCommand_t, 242
cmdID, 243
dataLen, 243
pData, 243
pack_cat_CATSendTerminalResponse

cat.h, 828
pack_cat_CATSendTerminalResponse_t, 243
dataLen, 244
pData, 244
refID, 244
pack_cat_SetCATEventCallback
cat.h, 828
pack_cat_SetCATEventCallback_t, 244
eventMask, 244
pack_dms_ActivateAutomatic
dms.h, 843
pack_dms_ActivateAutomatic_t, 245
actCode, 245
pack_dms_GetActivationState
dms.h, 843
pack_dms_GetBandCapability
dms.h, 844
pack_dms_GetCrashAction
dms.h, 844
pack_dms_GetCustFeature
dms.h, 844
pack_dms_GetCustFeaturesV2
dms.h, 845
pack_dms_GetCustFeaturesV2_t, 245
cust_id, 245
list_type, 245
Tlvresult, 245
pack_dms_GetDeviceCap
dms.h, 845
pack_dms_GetDeviceCapabilities
dms.h, 845
pack_dms_GetDeviceHardwareRev
dms.h, 846
pack_dms_GetDeviceMfr
dms.h, 846
pack_dms_GetDeviceSerialNumbers
dms.h, 847
pack_dms_GetFSN
dms.h, 848
pack_dms_GetFirmwareInfo
dms.h, 847
pack_dms_GetFirmwareRevision
dms.h, 847
pack_dms_GetFirmwareRevisions
dms.h, 848
pack_dms_GetHardwareRevision
dms.h, 848
pack_dms_GetIMSI
dms.h, 849
pack_dms_GetManufacturer
dms.h, 849
pack_dms_GetModelID
dms.h, 849
pack_dms_GetNetworkTime
dms.h, 850
pack_dms_GetOfflineReason
dms.h, 850
pack_dms_GetPRLVersion
dms.h, 851
pack_dms_GetPower
dms.h, 850
pack_dms_GetSerialNumbers
dms.h, 851
pack_dms_GetUSBComp
dms.h, 851
pack_dms_GetVoiceNumber
dms.h, 852
pack_dms_ResetToFactoryDefaults
dms.h, 852
pack_dms_ResetToFactoryDefaults_t, 246
spc, 246
pack_dms_SLQSDmsSwiGetResetInfo
dms.h, 856
pack_dms_SLQSDmsSwiIndicationRegister
dms.h, 856
pack_dms_SLQSDmsSwiIndicationRegister_t, 252
resetInfoInd, 252
pack_dms_SLQSGetBandCapability
dms.h, 856
pack_dms_SLQSGetERIFile
dms.h, 857
pack_dms_SLQSSwiClearDyingGaspStatistics
dms.h, 857
pack_dms_SLQSSwiGetCrashInfo
dms.h, 857
pack_dms_SLQSSwiGetCrashInfo_t, 252
clear, 252
pack_dms_SLQSSwiGetDyingGaspCfg
dms.h, 858
pack_dms_SLQSSwiGetDyingGaspStatistics
dms.h, 858
pack_dms_SLQSSwiGetFirmwareCurr
dms.h, 858
pack_dms_SLQSSwiGetFwUpdateStatus
dms.h, 859
pack_dms_SLQSSwiGetHostDevInfo
dms.h, 859
pack_dms_SLQSSwiGetOSInfo
dms.h, 859
pack_dms_SLQSSwiGetSerialNoExt
dms.h, 860
pack_dms_SLQSSwiSetDyingGaspCfg
dms.h, 860
pack_dms_SLQSSwiSetDyingGaspCfg_t, 253
pDestSMSContent, 253
pDestSMSNum, 253
pack_dms_SLQSSwiSetHostDevInfo
dms.h, 860
pack_dms_SLQSSwiSetHostDevInfo_t, 253
manString, 254
modelString, 254
plasmaIDString, 254
swVerString, 254
pack_dms_SLQSSwiSetOSInfo
dms.h, 861
pack_dms_SLQSSwiSetOSInfo_t, 254

nameString, 254
versionString, 254
pack_dms_SLQSUIMGetState
dms.h, 861
pack_dms_SetActivationStatusCallback
dms.h, 853
pack_dms_SetActivationStatusCallback_t, 246
activationState, 246
pack_dms_SetCrashAction
dms.h, 853
pack_dms_SetCrashAction_t, 246
crashAction, 247
pack_dms_SetCustFeature
dms.h, 853
pack_dms_SetCustFeature_t, 247
DHCPRelayEnabled, 249
DisableIMSI, 249
GPSLPM, 249
GPSSel, 249
GpsEnable, 249
IPFamSupport, 249
IsVoiceEnabled, 249
RMAutoConnect, 249
SMSSupport, 249
pack_dms_SetCustFeaturesV2
dms.h, 854
pack_dms_SetCustFeaturesV2_t, 249
cust_id, 250
cust_value, 250
Tlvresult, 250
value_length, 250
pack_dms_SetEventReport
dms.h, 854
pack_dms_SetEventReport_t, 250
mode, 250
pack_dms_SetFirmwarePreference
dms.h, 854
pack_dms_SetPower
dms.h, 855
pack_dms_SetPower_t, 250
mode, 251
Tlvresult, 251
pack_dms_SetUSBComp
dms.h, 855
pack_dms_SetUSBComp_t, 251
Tlvresult, 252
USBComp, 252
pack_dms_UIMChangePIN
dms.h, 861
pack_dms_UIMChangePIN_t, 254
id, 255
newValue, 255
oldValue, 255
pack_dms_UIMGetControlKeyStatus
dms.h, 862
pack_dms_UIMGetControlKeyStatus_t, 255
facility, 255
pack_dms_UIMGetICCID
dms.h, 862
pack_dms_UIMGetICCID_t, 256
Tlvresult, 256
pack_dms_UIMGetPINStatus
dms.h, 863
pack_dms_UIMSetControlKeyProtection
dms.h, 863
pack_dms_UIMSetControlKeyProtection_t, 256
facility, 257
facilityCk, 257
facilityState, 257
pack_dms_UIMSetPINProtection
dms.h, 863
pack_dms_UIMSetPINProtection_t, 257
bEnable, 257
id, 257
value, 257
pack_dms_UIMUnblockControlKey
dms.h, 864
pack_dms_UIMUnblockControlKey_t, 257
facility, 258
facilityCk, 258
pack_dms_UIMUnblockPIN
dms.h, 864
pack_dms_UIMUnblockPIN_t, 258
id, 258
newPin, 258
pukValue, 258
pack_dms_UIMVerifyPIN
dms.h, 864
pack_dms_UIMVerifyPIN_t, 259
id, 259
value, 259
pack_dms_ValidateSPC
dms.h, 865
pack_fms_GetImagesPreference
fms.h, 889
pack_fms_GetImagesPreference_t, 259
Tlvresult, 259
pack_fms_GetStoredImages
fms.h, 890
pack_fms_GetStoredImages_t, 259
Tlvresult, 260
pack_fms_SetImagesPreference
fms.h, 890
pack_fms_SetImagesPreference_t, 260
bForceDownload, 261
imageListSize, 261
modemindex, 261
pImageList, 261
Tlvresult, 261
pack_ims_SLQSGetIMSSMSConfig
ims.h, 892
pack_ims_SLQSGetIMSUserConfig
ims.h, 892
pack_ims_SLQSGetIMSVoIPConfig
ims.h, 893
pack_ims_SLQSGetRegMgrConfig

ims.h, 893
pack_ims_SLQSGetSIPConfig
ims.h, 893
pack_ims_SLQSImsConfigIndicationRegister
ims.h, 894
pack_ims_SLQSImsConfigIndicationRegister_t, 261
pRegMgrConfigEvents, 262
pSIPConfigEvents, 262
pSMSConfigEvents, 262
pUserConfigEvents, 262
pVoIPConfigEvents, 262
pack_ims_SLQSSetIMSSMSConfig
ims.h, 894
pack_ims_SLQSSetIMSSMSConfig_t, 262
pack_ims_SLQSSetIMSUserConfig
ims.h, 895
pack_ims_SLQSSetIMSUserConfig_t, 263
pIMSDomain, 263
pack_ims_SLQSSetIMSVoIPConfig
ims.h, 895
pack_ims_SLQSSetIMSVoIPConfig_t, 263
pAmrMode, 266
pRingingTimer, 266
pack_ims_SLQSSetRegMgrConfig
ims.h, 896
pack_ims_SLQSSetRegMgrConfig_t, 266
pCSCFPortName, 267
pIMSTestMode, 267
pPriCSCFPort, 267
pack_ims_SLQSSetSIPConfig
ims.h, 896
pack_ims_SLQSSetSIPConfig_t, 267
pSIPLocalPort, 268
pSigCompEnabled, 267
pSubscribeTimer, 268
pTimerSIPReg, 268
pTimerT1, 268
pTimerT2, 268
pTimerTf, 268
pack_imsa_SLQSGetIMSARegStatus
imsa.h, 901
pack_imsa_SLQSGetIMSAServiceStatus
imsa.h, 901
pack_imsa_SLQSRegisterIMSAIndication
imsa.h, 902
pack_imsa_SLQSRegisterIMSAIndication_t, 268
PdpStatusConfig, 269
RatHandoverStatusConfig, 269
RegStatusConfig, 269
ServiceStatusConfig, 269
pack_loc_Delete_Assist_Data_t, 269
pBdsSVInfo, 270
pCellDb, 270
pClkInfo, 270
pGnssData, 270
pSVInfo, 270
Tlvresult, 270
pack_loc_DeleteAssistData
loc.h, 917
pack_loc_EventRegister
loc.h, 918
pack_loc_EventRegister_t, 270
eventRegister, 272
Tlvresult, 272
pack_loc_SLQSLOCGetBestAvailPos
loc.h, 919
pack_loc_SLQSLOCGetBestAvailPos_t, 273
Tlvresult, 273
xid, 273
pack_loc_SLQSLOCGetServer
loc.h, 919
pack_loc_SLQSLOCGetServer_t, 274
has_serverAddrTypeMask, 274
serverAddrTypeMask, 274
serverType, 274
pack_loc_SLQSLOCInjectPosition
loc.h, 920
pack_loc_SLQSLOCInjectPosition_t, 274
altitudeSrcInfo, 278
altitudeWrtEllipsoid, 278
altitudeWrtMeanSeaLevel, 278
has_altitudeSrcInfo, 278
has_altitudeWrtEllipsoid, 278
has_horConfidence, 278
has_horReliability, 278
has_horUncCircular, 278
has_latitude, 278
has_longitude, 278
has_positionSrc, 278
has_rawHorConfidence, 278
has_rawHorUncCircular, 278
has_timestampAge, 278
has_timestampUtc, 278
has_vertConfidence, 278
has_vertRelicability, 278
has_vertUnc, 279
horConfidence, 279
horReliability, 279
horUncCircular, 279
latitude, 279
longitude, 279
positionSrc, 279
rawHorConfidence, 279
rawHorUncCircular, 279
timestampAge, 279
timestampUtc, 279
vertConfidence, 279
vertReliability, 279
vertUnc, 279
pack_loc_SLQSLOCInjectSensorData
loc.h, 920
pack_loc_SLQSLOCInjectSensorData_t, 279
accelTemp, 280
acceleroData, 280
acceleroTimeSrc, 280
gyroData, 280

gyroTemp, 280
gyroTimeSrc, 281
has_accelTemp, 281
has_acceleroTimeSrc, 281
has_accleroData, 281
has_gyroData, 281
has_gyroTemp, 281
has_gyroTimeSrc, 281
has_opaqueId, 281
opaqueId, 281
pack_loc_SLQSLOCInjectUTCTime
loc.h, 920
pack_loc_SLQSLOCInjectUTCTime_t, 281
timeMsec, 281
timeUncMsec, 281
pack_loc_SLQSLOCSetCradleMountConfig
loc.h, 921
pack_loc_SLQSLOCSetCradleMountConfig_t, 281
confidence, 282
has_confidence, 282
state, 282
pack_loc_SetExtPowerState
loc.h, 918
pack_loc_SetExtPowerState_t, 272
extPowerState, 272
Tlvresult, 272
pack_loc_SetOperationMode
loc.h, 918
pack_loc_SetOperationMode_t, 272
mode, 273
Tlvresult, 273
pack_loc_Start
loc.h, 921
pack_loc_Start_t, 282
pApplicationInfo, 283
pConfigAltitudeAssumed, 283
pHorizontalAccuracyLvl, 284
pIntermediateReportState, 284
pMinIntervalTime, 284
pRecurrenceType, 284
SessionId, 284
Tlvresult, 284
pack_loc_Stop
loc.h, 921
pack_loc_Stop_t, 284
SessionId, 284
Tlvresult, 284
pack_nas_GetACCOLC
nas.h, 938
pack_nas_GetANAAAAuthenticationStatus
nas.h, 938
pack_nas_GetCDMANetworkParameters
nas.h, 939
pack_nas_GetHomeNetwork
nas.h, 939
pack_nas_GetHomeNetwork3GPP2
nas.h, 939
pack_nas_GetNetworkPreference
nas.h, 940
pack_nas_GetRFInfo
nas.h, 940
pack_nas_GetServingNetwork
nas.h, 940
pack_nas_GetServingNetworkCapabilities
nas.h, 940
pack_nas_GetSignalStrengths
nas.h, 941
pack_nas_InitiateDomainAttach
nas.h, 941
pack_nas_InitiateDomainAttach_t, 284
action, 285
pack_nas_PerformNetworkScan
nas.h, 941
pack_nas_SLQSConfigSigInfo
nas.h, 943
pack_nas_SLQSConfigSigInfo_t, 288
pECIOThresh, 289
pIOThresh, 289
pLTESNRThresh, 289
pLTESigRptCfg, 289
pRSRPThresh, 289
pRSRQThresh, 289
pRSSIThresh, 289
pack_nas_SLQSGetErrorRate
nas.h, 944
pack_nas_SLQSGetNetworkTime
nas.h, 944
pack_nas_SLQSGetOperatorNameData
nas.h, 945
pack_nas_SLQSGetPLMNName
nas.h, 945
pack_nas_SLQSGetPLMNName_t, 289
mcc, 290
mnc, 290
pMncPcsStatus, 290
pack_nas_SLQSGetServingSystem
nas.h, 945
pack_nas_SLQSGetSignalStrength
nas.h, 946
pack_nas_SLQSGetSysInfo
nas.h, 946
pack_nas_SLQSGetSysSelectionPref
nas.h, 946
pack_nas_SLQSInitiateNetworkRegistration
nas.h, 947
pack_nas_SLQSInitiateNetworkRegistration_t, 290
pChangeDuration, 291
pMNRInfo, 291
pMncPcsDigitStatus, 291
regAction, 291
pack_nas_SLQSNASGeteDRXParams
nas.h, 948
pack_nas_SLQSNASSeteDRXParams
nas.h, 950
pack_nas_SLQSNASSeteDRXParams_t, 299
pCycleLen, 300

pEdrxEnable, 300
pack_nas_SLQSNASSwiGetChannelLock
nas.h, 950
pack_nas_SLQSNASSwiSetChannelLock
nas.h, 951
pack_nas_SLQSNASSwiSetChannelLock_t, 301
pack_nas_SLQSNasConfigSigInfo2
nas.h, 947
pack_nas_SLQSNasConfigSigInfo2_t, 291
pHDRIODelta, 295
pHDRIOThresh, 295
pLTESigRptConfig, 295
pack_nas_SLQSNasGet3GPP2Subscription
nas.h, 948
pack_nas_SLQSNasGet3GPP2Subscription_t, 296
namID, 296
pack_nas_SLQSNasGetCellLocationInfo
nas.h, 948
pack_nas_SLQSNasGetHDRColorCode
nas.h, 949
pack_nas_SLQSNasGetSigInfo
nas.h, 949
pack_nas_SLQSNasGetTxRxInfo
nas.h, 949
pack_nas_SLQSNasGetTxRxInfo_t, 296
radio_if, 296
pack_nas_SLQSNasIndicationRegisterExt
nas.h, 950
pack_nas_SLQSNasIndicationRegisterExt_t, 296
pDDTMInd, 299
pDualStandByPrefInd, 299
pErrorRateInd, 299
pHDRSessionCloseInd, 299
pLTECphyCa, 299
pManagedRoamingInd, 299
pNetworkRejectInd, 299
pNetworkTimeInd, 299
pServingSystemInd, 299
pSignalStrengthInd, 299
pSubscriptionInfoInd, 299
pSuppressSysInfoInd, 299
pSysInfoInd, 299
pSystemSelectionInd, 299
pack_nas_SLQSNasSwiIndicationRegister
nas.h, 951
pack_nas_SLQSNasSwiIndicationRegister_t, 300
gsmUmtsDl, 301
gsmUmtsUl, 301
lteEmmDl, 301
lteEmmUl, 301
lteEsmDl, 301
lteEsmUl, 301
pRankIndicatorInd, 301
pTimer, 301
pack_nas_SLQSNasSwiModemStatus
nas.h, 951
pack_nas_SLQSSetBandPreference
nas.h, 952
pack_nas_SLQSSetBandPreference_t, 302
bandPref, 303
pack_nas_SLQSSetSignalStrengthsCallback
nas.h, 952
pack_nas_SLQSSetSignalStrengthsCallback_t, 304
bEnable, 304
pSigIndReq, 304
pack_nas_SLQSSetSysSelectionPref
nas.h, 953
pack_nas_SLQSSetSysSelectionPref_t, 304
pAcqOrderPref, 309
pBandPref, 309
pCSGID, 309
pChgDuration, 309
pEmerMode, 309
pGWAcqOrderPref, 309
pLTEBandPref, 309
pModePref, 309
pNetSelPref, 309
pPRLPref, 309
pRAT, 309
pRoamPref, 309
pSrvDomainPref, 309
pSrvRegRestriction, 309
pTdscdmaBandPref, 310
pack_nas_SLQSSwiGetHDRPersonality
nas.h, 953
pack_nas_SLQSSwiGetHDRProtSubtype
nas.h, 953
pack_nas_SLQSSwiGetHRPDStats
nas.h, 954
pack_nas_SLQSSwiGetLteCQI
nas.h, 954
pack_nas_SLQSSwiGetLteSccRxInfo
nas.h, 954
pack_nas_SLQSSwiNetworkDebug
nas.h, 955
pack_nas_SLQSSwiPSDetach
nas.h, 955
pack_nas_SLQSSwiPSDetach_t, 310
pDetachAction, 310
pack_nas_SetACCOLC
nas.h, 942
pack_nas_SetACCOLC_t, 285
accolc, 285
spc, 285
pack_nas_SetCDMANetworkParameters
nas.h, 942
pack_nas_SetCDMANetworkParameters_t, 285
pApplication, 286
pBroadcast, 286
pCustomSCP, 286
pForceRev0, 287
pProtocol, 287
pRoaming, 287
pSPC, 287
pack_nas_SetLURejectCallback
nas.h, 942

pack_nas_SetNetworkPreference
nas.h, 943
pack_nas_SetNetworkPreference_t, 287
Duration, 287
TechnologyPref, 287
Tlvresult, 288
pack_nas_SetRFInfoCallback
nas.h, 943
pack_nas_SlqsGetLTECphyCAInfo
nas.h, 944
pack_pds_ForceXTRADownload
pds.h, 981
pack_pds_GetPDSDefaults
pds.h, 981
pack_pds_GetPDSState
pds.h, 982
pack_pds_GetPortAutomaticTracking
pds.h, 982
pack_pds_GetServiceAutomaticTracking
pds.h, 982
pack_pds_GetXTRAAutomaticDownload
pds.h, 983
pack_pds_GetXTRANetwork
pds.h, 983
pack_pds_GetXTRAValidity
pds.h, 983
pack_pds_PDSInjectTimeReference
pds.h, 984
pack_pds_PDSInjectTimeReference_t, 310
systemDiscontinuities, 310
systemTime, 310
pack_pds_ResetPDSData
pds.h, 984
pack_pds_ResetPDSData_t, 311
pCellDataMask, 311
pGPSDataMask, 311
pack_pds_SLQSGetAGPSConfig
pds.h, 987
pack_pds_SLQSGetAGPSConfig_t, 315
pNetworkMode, 316
pack_pds_SLQSGetGPSStateInfo
pds.h, 987
pack_pds_SLQSPDSDeterminePosition
pds.h, 988
pack_pds_SLQSPDSInjectAbsoluteTimeReference
pds.h, 988
pack_pds_SLQSPDSInjectAbsoluteTimeReference_t, 316
forceFlag, 316
timeBase, 316
timeMsec, 316
timeUncMsec, 316
pack_pds_SLQSPDSInjectPositionData
pds.h, 988
pack_pds_SLQSPDSInjectPositionData_t, 316
pAltitudeWrtEllipsoid, 318
pAltitudeWrtSealevel, 318
pHorizontalConfidence, 318
pHorizontalUncCircular, 318
pLatitude, 318
pLongitude, 318
pPositionSource, 318
pTimeStamp, 318
pTimeType, 318
pVerticalConfidence, 318
pVerticalUnc, 318
pack_pds_SLQSSetAGPSConfig
pds.h, 989
pack_pds_SLQSSetAGPSConfig_t, 318
pNetworkMode, 319
pServerAddress, 319
pServerPort, 319
pServerURL, 319
pack_pds_SLQSSetPositionMethodState
pds.h, 989
pack_pds_SLQSSetPositionMethodState_t, 319
pWifiState, 320
pXtraDataState, 320
pXtraTimeState, 320
pack_pds_SetEventReportCallback
pds.h, 985
pack_pds_SetEventReportCallback_t, 311
posDataNmea, 312
rptPosData, 312
pack_pds_SetPDSDefaults
pds.h, 985
pack_pds_SetPDSDefaults_t, 312
accuracy, 313
interval, 313
operation, 313
timeout, 313
pack_pds_SetPDSState
pds.h, 985
pack_pds_SetPDSState_t, 313
enable, 313
pack_pds_SetPortAutomaticTracking
pds.h, 986
pack_pds_SetPortAutomaticTracking_t, 313
bAuto, 314
pack_pds_SetServiceAutomaticTracking
pds.h, 986
pack_pds_SetServiceAutomaticTracking_t, 314
bAuto, 314
pack_pds_SetXTRAAutomaticDownload
pds.h, 986
pack_pds_SetXTRAAutomaticDownload_t, 314
bEnabled, 315
interval, 315
pack_pds_SetXTRANetwork
pds.h, 987
pack_pds_SetXTRANetwork_t, 315
preference, 315
pack_pds_StartPDSTrackingSessionExt
pds.h, 990
pack_pds_StartPDSTrackingSessionExt_t, 320
fixAccuracy, 321

fixCount, 321
fixInterval, 321
fixTimeout, 321
sessionControl, 321
sessionOperation, 321
sessionServerOption, 321
sessionType, 321
pack_pds_StopPDSTrackingSession
pds.h, 990
pack_qmi_t, 321
msgid, 322
svc, 322
timeout, 322
xid, 322
pack_qos_BindDataPort
qos.h, 1048
pack_qos_BindDataPort_t, 322
pMuxID, 322
pPeripheralEndPointID, 322
pSIODataPort, 322
pack_qos_SLQSQosGetNetworkStatus
qos.h, 1048
pack_qos_SLQSQosSwiReadApnExtraParams
qos.h, 1049
pack_qos_SLQSQosSwiReadApnExtraParams_t, 323
apnId, 323
pack_qos_SLQSQosSwiReadDataStats
qos.h, 1050
pack_qos_SLQSQosSwiReadDataStats_t, 323
apnId, 323
pack_qos_SLQSSetQosEventCallback
qos.h, 1050
pack_qos_SLQSSetQosEventCallback_t, 323
enable, 324
pack_rms_GetSMSWake
rms.h, 1056
pack_rms_SetSMSWake
rms.h, 1056
pack_rms_SetSMSWake_t, 324
enabled, 324
wake_mask, 324
pack_sar_SLQSGetRfSarState
sar.h, 1058
pack_sar_SLQSSetRfSarState
sar.h, 1058
pack_sar_SLQSSetRfSarState_t, 324
RfSarState, 325
pack_sms_GetSMSCAddress
sms.h, 1063
pack_sms_SLQSDeleteSMS
sms.h, 1064
pack_sms_SLQSDeleteSMS_t, 327
pMessageIndex, 328
pMessageMode, 328
pMessageTag, 328
storageType, 328
pack_sms_SLQSGetIndicationRegister
sms.h, 1065
pack_sms_SLQSGetMessageWaiting
sms.h, 1065
pack_sms_SLQSGetSMS
sms.h, 1065
pack_sms_SLQSGetSMS_t, 328
messageIndex, 329
pMessageMode, 329
storageType, 329
pack_sms_SLQSGetSMSList
sms.h, 1066
pack_sms_SLQSGetSMSList_t, 329
pMessageMode, 330
pRequestedTag, 330
storageType, 330
pack_sms_SLQSGetSmsBroadcastConfig
sms.h, 1066
pack_sms_SLQSGetSmsBroadcastConfig_t, 329
mode, 329
pack_sms_SLQSGetTransLayerInfo
sms.h, 1067
pack_sms_SLQSGetTransNWRegInfo
sms.h, 1067
pack_sms_SLQSModifySMSStatus
sms.h, 1067
pack_sms_SLQSModifySMSStatus_t, 330
messageIndex, 331
messageTag, 331
pMessageMode, 331
storageType, 331
pack_sms_SLQSSendAsyncSMS
sms.h, 1068
pack_sms_SLQSSendAsyncSMS_t, 331
pSendSmsParams, 331
pack_sms_SLQSSetIndicationRegister
sms.h, 1068
pack_sms_SLQSSetIndicationRegister_t, 331
pSetIndicationRegReq, 332
pack_sms_SLQSSetSmsBroadcastActivation
sms.h, 1068
pack_sms_SLQSSetSmsBroadcastActivation_t, 332
broadcastActivate, 332
mode, 332
pack_sms_SLQSSetSmsBroadcastConfig
sms.h, 1069
pack_sms_SLQSSetSmsBroadcastConfig_t, 332
mode, 333
pBroadcastConfig, 333
pCDMABroadcastConfig, 333
pack_sms_SLQSSetSmsStorage
sms.h, 1069
pack_sms_SLQSSetSmsStorage_t, 333
smsStorage, 333
pack_sms_SLQSSmsGetMaxStorageSize
sms.h, 1069
pack_sms_SLQSSmsGetMaxStorageSize_t, 333
pMaxStorageSizeReq, 334
pack_sms_SLQSSmsGetMessageProtocol
sms.h, 1070

pack_sms_SLQSSmsSetRoutes
sms.h, 1070
pack_sms_SLQSSmsSetRoutes_t, 334
pSetRoutesReq, 334
pack_sms_SLQSSwiGetSMSStorage
sms.h, 1071
pack_sms_SaveSMS
sms.h, 1063
pack_sms_SaveSMS_t, 325
messageFormat, 326
messageSize, 326
pMessage, 326
storageType, 326
pack_sms_SendSMS
sms.h, 1063
pack_sms_SendSMS_t, 326
messageFormat, 326
messageSize, 326
pLinktimer, 326
pMessage, 326
pack_sms_SetNewSMSCallback
sms.h, 1064
pack_sms_SetNewSMSCallback_t, 326
status, 327
pack_sms_SetSMSCAddress
sms.h, 1064
pack_sms_SetSMSCAddress_t, 327
pSMSCAddress, 327
pSMSCType, 327
pack_swiaudio_SLQSGetM2MAVMute
swiaudio.h, 1081
pack_swiaudio_SLQSGetM2MAVMute_t, 335
Profile, 335
pack_swiaudio_SLQSGetM2MAudioProfile
swiaudio.h, 1081
pack_swiaudio_SLQSGetM2MAudioProfile_t, 334
pGenerator, 335
pack_swiaudio_SLQSGetM2MAudioVolume
swiaudio.h, 1081
pack_swiaudio_SLQSGetM2MAudioVolume_t, 335
Generator, 335
Profile, 335
pack_swiaudio_SLQSGetM2MSpkrGain
swiaudio.h, 1082
pack_swiaudio_SLQSGetM2MSpkrGain_t, 336
Profile, 336
pack_swiaudio_SLQSSetM2MAVMute
swiaudio.h, 1084
pack_swiaudio_SLQSSetM2MAVMute_t, 339
EarMute, 340
MicMute, 340
pCwtMute, 340
Profile, 340
pack_swiaudio_SLQSSetM2MAudioAVCFG
swiaudio.h, 1082
pack_swiaudio_SLQSSetM2MAudioAVCFG_t, 336
Device, 337
Profile, 337
pack_swiaudio_SLQSSetM2MAudioLPBK
swiaudio.h, 1082
pack_swiaudio_SLQSSetM2MAudioLPBK_t, 337
Enable, 337
pack_swiaudio_SLQSSetM2MAudioNVDef
swiaudio.h, 1083
pack_swiaudio_SLQSSetM2MAudioProfile
swiaudio.h, 1083
pack_swiaudio_SLQSSetM2MAudioProfile_t, 337
pCwtMute, 338
pEarMute, 338
pGenerator, 338
pMicMute, 338
pVolume, 338
Profile, 338
pack_swiaudio_SLQSSetM2MAudioVolume
swiaudio.h, 1083
pack_swiaudio_SLQSSetM2MAudioVolume_t, 338
Generator, 339
Level, 339
Profile, 339
pack_swiaudio_SLQSSetM2MSpkrGain
swiaudio.h, 1084
pack_swiaudio_SLQSSetM2MSpkrGain_t, 340
Profile, 340
Value, 340
pack_swiavms_SLQSAVMSGetSettings
swiavms.h, 1090
pack_swiavms_SLQSAVMSSendSelection
swiavms.h, 1091
pack_swiavms_SLQSAVMSSendSelection_t, 340
pDeferTime, 341
pPackageID, 341
pRejectReason, 341
selection, 341
pack_swiavms_SLQSAVMSSessionGetInfo
swiavms.h, 1091
pack_swiavms_SLQSAVMSSetSettings
swiavms.h, 1092
pack_swiavms_SLQSAVMSSetSettings_t, 341
AutoConnect, 343
AutoReboot, 343
pAPNInfo, 343
pConnectionRetryTimers, 343
pNotifStore, 343
pPeriodInfo, 343
pPollingTimer, 343
PromptFwDownload, 343
PromptFwUpdate, 343
pack_swiavms_SLQSAVMSSetSettingsNoAutoReboot-
Field
swiavms.h, 1093
pack_swiavms_SLQSAVMSStartSession
swiavms.h, 1094
pack_swiavms_SLQSAVMSStartSession_t, 343
sessionType, 343
pack_swiavms_SLQSAVMSStopSession
swiavms.h, 1094

pack_swiavms_SLQSAVMSStopSession_t, 344
sessionType, 344
pack_swiavms_SLQSAvmsSetEventReport
swiavms.h, 1092
pack_swiloc_SwiLocGetAutoStart
swiloc.h, 1100
pack_swiloc_SwiLocSetAutoStart
swiloc.h, 1101
pack_swiloc_SwiLocSetAutoStart_t, 344
fix_rate, 345
fix_type, 345
function, 345
max_dist, 345
max_time, 345
set_fix_rate, 345
set_fix_type, 346
set_function, 346
set_max_dist, 346
set_max_time, 346
pack_swioma_SLQSOMADMAlertCallback
swioma.h, 1103
pack_swioma_SLQSOMADMCancelSession
swioma.h, 1103
pack_swioma_SLQSOMADMCancelSession_t, 346
sessionType, 346
pack_swioma_SLQSOMADMCancelSessionExt
swiomaext.h, 1111
pack_swioma_SLQSOMADMCancelSessionExt_t, 346
sessionType, 346
pack_swioma_SLQSOMADMGetSessionInfo
swioma.h, 1104
pack_swioma_SLQSOMADMGetSessionInfo_t, 347
SessionType, 347
pack_swioma_SLQSOMADMGetSettings
swioma.h, 1105
pack_swioma_SLQSOMADMSendSelection
swioma.h, 1105
pack_swioma_SLQSOMADMSendSelection_t, 347
pDeferTime, 348
pRejectReason, 348
selection, 348
pack_swioma_SLQSOMADMSendSelectionExt
swiomaext.h, 1112
pack_swioma_SLQSOMADMSendSelectionExt_t, 348
selection, 348
pack_swioma_SLQSOMADMSetSettings
swioma.h, 1106
pack_swioma_SLQSOMADMSetSettings_t, 348
FOTAdownload, 349
pAutosdm, 349
pFwAutoCheck, 349
pack_swioma_SLQSOMADMSetSettingsExt
swiomaext.h, 1113
pack_swioma_SLQSOMADMSetSettingsExt_t, 349
pack_swioma_SLQSOMADMStartSession
swioma.h, 1107
pack_swioma_SLQSOMADMStartSession_t, 350
sessionType, 351
pack_swioma_SLQSOMADMStartSessionExt
swiomaext.h, 1113
pack_swioma_SLQSOMADMStartSessionExt_t, 351
sessionType, 351
pack_tmd_SLQSTmdDeRegNotMitigationLvl
tmd.h, 1116
pack_tmd_SLQSTmdDeRegNotMitigationLvl_t, 351
mitigationDevID, 352
mitigationDevIDLen, 352
pack_tmd_SLQSTmdGetMitigationDevList
tmd.h, 1117
pack_tmd_SLQSTmdGetMitigationLvl
tmd.h, 1117
pack_tmd_SLQSTmdGetMitigationLvl_t, 352
mitigationDevID, 352
mitigationDevIDLen, 352
pack_tmd_SLQSTmdRegNotMitigationLvl
tmd.h, 1117
pack_tmd_SLQSTmdRegNotMitigationLvl_t, 352
mitigationDevID, 353
mitigationDevIDLen, 353
pack_uim_ChangePin
uim.h, 1123
pack_uim_ChangePin_t, 353
changePIN, 354
EncryptedPIN1, 354
pIndicationToken, 354
pKeyReferenceID, 354
sessionInfo, 354
Tlvresult, 354
pack_uim_GetCardStatus
uim.h, 1123
pack_uim_ReadTransparent
uim.h, 1124
pack_uim_ReadTransparent_t, 354
fileIndex, 355
pEncryptData, 355
pIndicationToken, 355
readTransparent, 355
sessionInfo, 355
Tlvresult, 355
pack_uim_SLQSUIMAuthenticate
uim.h, 1124
pack_uim_SLQSUIMAuthenticate_t, 356
authData, 357
pIndicationToken, 357
sessionInfo, 357
pack_uim_SLQSUIMDepersonalization
uim.h, 1125
pack_uim_SLQSUIMDepersonalization_t, 357
depersonilisationInfo, 357
pack_uim_SLQSUIMEventRegister
uim.h, 1125
pack_uim_SLQSUIMEventRegister_t, 357
eventMask, 358
pack_uim_SLQSUIMGetConfiguration
uim.h, 1125
pack_uim_SLQSUIMGetConfiguration_t, 358

pConfigurationMask, 358
pack_uim_SLQSUIMGetFileAttributes
uim.h, 1126
pack_uim_SLQSUIMGetFileAttributes_t, 358
fileIndex, 359
pIndicationToken, 359
sessionInfo, 359
pack_uim_SLQSUIMGetSlotsStatus
uim.h, 1126
pack_uim_SLQSUIMPowerDown
uim.h, 1127
pack_uim_SLQSUIMPowerDown_t, 359
slot, 359
pack_uim_SLQSUIMPowerUp
uim.h, 1127
pack_uim_SLQSUIMPowerUp_t, 359
pIgnoreHotSwapSwitch, 360
slot, 360
pack_uim_SLQSUIMRefreshComplete
uim.h, 1127
pack_uim_SLQSUIMRefreshComplete_t, 360
refreshComplete, 360
sessionInfo, 360
pack_uim_SLQSUIMRefreshGetLastEvent
uim.h, 1128
pack_uim_SLQSUIMRefreshGetLastEvent_t, 360
sessionInfo, 361
pack_uim_SLQSUIMRefreshOK
uim.h, 1128
pack_uim_SLQSUIMRefreshOK_t, 361
OKtoRefresh, 361
sessionInfo, 361
pack_uim_SLQSUIMRefreshRegister
uim.h, 1128
pack_uim_SLQSUIMRefreshRegister_t, 361
regRefresh, 362
sessionInfo, 362
pack_uim_SLQSUIMReset
uim.h, 1129
pack_uim_SLQSUIMSwitchSlot
uim.h, 1129
pack_uim_SLQSUIMSwitchSlot_t, 362
bLogicalSlot, 363
ulPhysicalSlot, 363
pack_uim_SetPinProtection
uim.h, 1124
pack_uim_SetPinProtection_t, 355
EncryptedPIN1, 356
pIndicationToken, 356
pKeyReferenceID, 356
pinProtection, 356
sessionInfo, 356
Tlvresult, 356
pack_uim_UnblockPin
uim.h, 1129
pack_uim_UnblockPin_t, 363
EncryptedPIN1, 363
pIndicationToken, 363
pKeyReferenceID, 364
pinProtection, 363
sessionInfo, 364
Tlvresult, 364
pack_uim_VerifyPin
uim.h, 1130
pack_uim_VerifyPin_t, 364
pEncryptedPIN1, 365
pIndicationToken, 365
pKeyReferenceID, 365
sessionInfo, 365
Tlvresult, 365
verifyPIN, 365
pack_voice_AnswerUSSD
voice.h, 1143
pack_voice_AnswerUSSD_t, 365
pInfo, 365
pack_voice_CancelUSSD
voice.h, 1143
pack_voice_OriginateUSSD
voice.h, 1144
pack_voice_OriginateUSSD_t, 365
pInfo, 366
pack_voice_SLQSOriginateUSSD
voice.h, 1144
pack_voice_SLQSOriginateUSSD_t, 366
ussDCS, 366
ussData, 366
ussLen, 366
pack_voice_SLQSVoiceALSSelectLine
voice.h, 1144
pack_voice_SLQSVoiceALSSelectLine_t, 366
lineValue, 367
pack_voice_SLQSVoiceALSSetLineSwitching
voice.h, 1145
pack_voice_SLQSVoiceALSSetLineSwitching_t, 367
switchOption, 367
pack_voice_SLQSVoiceAnswerCall
voice.h, 1145
pack_voice_SLQSVoiceAnswerCall_t, 367
pCallId, 367
pack_voice_SLQSVoiceBindSubscription
voice.h, 1145
pack_voice_SLQSVoiceBindSubscription_t, 368
subsType, 368
pack_voice_SLQSVoiceBurstDTMF
voice.h, 1146
pack_voice_SLQSVoiceBurstDTMF_t, 368
pack_voice_SLQSVoiceDialCall
voice.h, 1146
pack_voice_SLQSVoiceDialCall_t, 369
callNumber, 370
pCLIRType, 370
pCUGInfo, 370
pCallPartySubAdd, 370
pCallType, 370
pEmergencyCategory, 370
pSvcType, 370

pUUSInFo, 370
pack_voice_SLQSVoiceEndCall
voice.h, 1146
pack_voice_SLQSVoiceEndCall_t, 370
pCallId, 371
pack_voice_SLQSVoiceGetAllCallInfo
voice.h, 1147
pack_voice_SLQSVoiceGetCLIP
voice.h, 1149
pack_voice_SLQSVoiceGetCLIR
voice.h, 1149
pack_voice_SLQSVoiceGetCNAP
voice.h, 1149
pack_voice_SLQSVoiceGetCOLP
voice.h, 1150
pack_voice_SLQSVoiceGetCOLR
voice.h, 1150
pack_voice_SLQSVoiceGetCallBarring
voice.h, 1147
pack_voice_SLQSVoiceGetCallBarring_t, 371
pSvcClass, 371
reason, 371
pack_voice_SLQSVoiceGetCallForwardingStatus
voice.h, 1148
pack_voice_SLQSVoiceGetCallForwardingStatus_t, 372
pSvcClass, 372
Reason, 372
pack_voice_SLQSVoiceGetCallInfo
voice.h, 1148
pack_voice_SLQSVoiceGetCallInfo_t, 372
callID, 373
pack_voice_SLQSVoiceGetCallWaiting
voice.h, 1148
pack_voice_SLQSVoiceGetCallWaiting_t, 373
pSvcClass, 373
pack_voice_SLQSVoiceGetConfig
voice.h, 1150
pack_voice_SLQSVoiceGetConfig_t, 373
pAMRStatus, 374
pAirTimer, 374
pAutoAnswer, 375
pNamID, 375
pPrefVoicePrivacy, 375
pPrefVoiceSO, 375
pRoamTimer, 375
pTTYMode, 375
pVoiceDomainPref, 375
pack_voice_SLQSVoiceIndicationRegister
voice.h, 1151
pack_voice_SLQSVoiceIndicationRegister_t, 375
pRegDTMFEvents, 376
pRegVoicePrivacyEvents, 376
pSuppsNotifEvents, 376
pack_voice_SLQSVoiceManageCalls
voice.h, 1151
pack_voice_SLQSVoiceManageCalls_t, 376
pCallID, 377
SUPSType, 377
pack_voice_SLQSVoiceOrigUSSDNoWait
voice.h, 1151
pack_voice_SLQSVoiceOrigUSSDNoWait_t, 377
pack_voice_SLQSVoiceSendFlash
voice.h, 1152
pack_voice_SLQSVoiceSendFlash_t, 377
pCallID, 378
pFlashPayLd, 378
pFlashType, 378
pack_voice_SLQSVoiceSetCallBarringPassword
voice.h, 1152
pack_voice_SLQSVoiceSetCallBarringPassword_t, 378
newPasswd, 379
newPasswdAgain, 379
oldPasswd, 379
Reason, 379
pack_voice_SLQSVoiceSetConfig
voice.h, 1152
pack_voice_SLQSVoiceSetConfig_t, 379
pAirTimerConfig, 380
pAutoAnswer, 380
pPrefVoiceDomain, 380
pPrefVoiceSO, 380
pRoamTimerConfig, 380
pTTYMode, 380
pack_voice_SLQSVoiceSetPreferredPrivacy
voice.h, 1153
pack_voice_SLQSVoiceSetPreferredPrivacy_t, 380
privacyPref, 380
pack_voice_SLQSVoiceSetSUPSService
voice.h, 1153
pack_voice_SLQSVoiceSetSUPSService_t, 380
pCallBarringPasswd, 383
pCallForwardingNumber, 383
pServiceClass, 383
pTimerVal, 383
reason, 383
voiceSvc, 383
pack_voice_SLQSVoiceStartContDTMF
voice.h, 1154
pack_voice_SLQSVoiceStartContDTMF_t, 383
DTMFdigit, 383
pCallID, 383
pack_voice_SLQSVoiceStopContDTMF
voice.h, 1154
pack_voice_SLQSVoiceStopContDTMF_t, 384
callID, 384
pack_wds_DHCPv4ClientLeaseChange
wds.h, 1172
pack_wds_DHCPv4ClientLeaseChange_t, 384
pEnableNotification, 384
pack_wds_GetAutoconnect
wds.h, 1172
pack_wds_GetByteTotals
wds.h, 1173
pack_wds_GetConnectionRate
wds.h, 1173
pack_wds_GetDataBearerTechnology

wds.h, 1173
pack_wds_GetDefaultProfile
wds.h, 1174
pack_wds_GetDefaultProfile_t, 384
profiletype, 385
pack_wds_GetDefaultProfileNum
wds.h, 1174
pack_wds_GetDefaultProfileNum_t, 385
family, 385
type, 385
pack_wds_GetDormancyState
wds.h, 1175
pack_wds_GetDormancyState_t, 385
pack_wds_GetLastMobileIPError
wds.h, 1175
pack_wds_GetLastMobileIPError_t, 386
pack_wds_GetMobileIP
wds.h, 1175
pack_wds_GetMobileIP_t, 386
pack_wds_GetMobileIPProfile
wds.h, 1176
pack_wds_GetMobileIPProfile_t, 386
index, 386
pack_wds_GetPacketStatistics
wds.h, 1176
pack_wds_GetPacketStatistics_t, 387
pStatMask, 387
pack_wds_GetPacketStatus
wds.h, 1177
pack_wds_GetPacketStatus_t, 387
statmask, 388
pack_wds_GetSessionDuration
wds.h, 1177
pack_wds_GetSessionDuration_t, 388
pack_wds_GetSessionState
wds.h, 1178
pack_wds_RMSetTransferStatistics
wds.h, 1178
pack_wds_RMSetTransferStatistics_t, 388
RmTrasnferStaticsReq, 388
pack_wds_SLQSCreateProfile
wds.h, 1181
pack_wds_SLQSCreateProfile_t, 395
pCurProfile, 395
pProfileId, 395
pProfileType, 396
pack_wds_SLQSDeleteProfile
wds.h, 1182
pack_wds_SLQSDeleteProfile_t, 396
profileIndex, 396
profileType, 396
pack_wds_SLQSGet3GPPConfigItem
wds.h, 1182
pack_wds_SLQSGetCurrDataSystemStat
wds.h, 1183
pack_wds_SLQSGetCurrDataSystemStat_t, 396
pack_wds_SLQSGetCurrentChannelRate
wds.h, 1183
pack_wds_SLQSGetDUNCallInfo
wds.h, 1184
pack_wds_SLQSGetDUNCallInfo_t, 397
Mask, 398
pReportChannelRate, 398
pReportConnStatus, 398
pReportDataBearerTech, 398
pReportDormStatus, 398
pTransferStatInd, 398
pack_wds_SLQSGetDataBearerTechnology
wds.h, 1183
pack_wds_SLQSGetDataBearerTechnology_t, 396
pack_wds_SLQSGetProfileSettings
wds.h, 1184
pack_wds_SLQSGetProfileSettings_t, 398
ProfileId, 399
ProfileType, 399
pack_wds_SLQSGetRuntimeSettings
wds.h, 1185
pack_wds_SLQSGetRuntimeSettings_t, 399
pReqSettings, 400
pack_wds_SLQSModifyProfile
wds.h, 1185
pack_wds_SLQSModifyProfile_t, 400
curProfile, 401
pProfileId, 401
pProfileType, 401
pack_wds_SLQSResetPacketStatics
wds.h, 1186
pack_wds_SLQSSGetDHCPv4ClientConfig
wds.h, 1187
pack_wds_SLQSSGetDHCPv4ClientConfig_t, 404
pProfileId, 404
pack_wds_SLQSSGetLoopback
wds.h, 1188
pack_wds_SLQSSSetDHCPv4ClientConfig
wds.h, 1188
pack_wds_SLQSSSetDHCPv4ClientConfig_t, 404
pHwConfig, 405
pProfileId, 405
pack_wds_SLQSSSetLoopback
wds.h, 1188
pack_wds_SLQSSSetLoopback_t, 405
loopbackMode, 405
loopbackMultiplier, 405
pack_wds_SLQSSet3GPPConfigItem
wds.h, 1186
pack_wds_SLQSSet3GPPConfigItem_t, 401
p3gppRelease, 402
pProfileList, 402
pack_wds_SLQSSetIPFamilyPreference
wds.h, 1186
pack_wds_SLQSSetIPFamilyPreference_t, 403
IPFamilyPreference, 403
pack_wds_SLQSSetWdsEventCallback
wds.h, 1187
pack_wds_SLQSSetWdsEventCallback_t, 403
currentDataBearer, 404

dataBearer, 404
dataBearerTechExt, 404
dataSystemStatus, 404
dormancyStatus, 404
interval, 404
mobileIP, 404
transferStats, 404
pack_wds_SLQSStartDataSession
wds.h, 1189
pack_wds_SLQSStartDataSession_t, 405
pAuth, 406
pPass, 406
pTech, 406
pUser, 406
pprofileid3gpp, 406
pprofileid3gpp2, 406
pack_wds_SLQSStopDataSession
wds.h, 1189
pack_wds_SLQSStopDataSession_t, 407
psid, 407
pack_wds_SLQSWdsGoActive
wds.h, 1190
pack_wds_SLQSWdsGoDormant
wds.h, 1190
pack_wds_SLQSWdsSetEventReport
wds.h, 1190
pack_wds_SLQSWdsSetEventReport_t, 407
pCurrChannelRateInd, 408
pCurrDataBearerTechInd, 408
pCurrPrefDataSysInd, 408
pDataBearerTechInd, 408
pDataCallStatusChangeInd, 408
pDataSystemStatusChangeInd, 408
pDormancyStatusInd, 409
pMIPStatusInd, 409
pTransferStatInd, 409
pack_wds_SLQSWdsSwiPDPRuntimeSettings
wds.h, 1191
pack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 409
contextId, 409
contextType, 409
pack_wds_SetAutoconnect
wds.h, 1178
pack_wds_SetAutoconnect_t, 388
acroamsetting, 389
acsetting, 389
pack_wds_SetDefaultProfile
wds.h, 1179
pack_wds_SetDefaultProfile_t, 389
authentication, 390
ipAddress, 390
pApnname, 390
pName, 390
pPassword, 390
pUsername, 391
pdpType, 390
primaryDNS, 390
profileType, 390
secondaryDNS, 391
pack_wds_SetDefaultProfileNum
wds.h, 1179
pack_wds_SetDefaultProfileNum_t, 391
family, 391
index, 391
type, 391
pack_wds_SetMobileIP
wds.h, 1180
pack_wds_SetMobileIP_t, 391
mode, 392
pack_wds_SetMobileIPParameters
wds.h, 1180
pack_wds_SetMobileIPParameters_t, 392
pHA2002bis, 393
pHAAuthenticator, 393
pMode, 393
pReRegPeriod, 393
pReRegTraffic, 393
pRetryInterval, 393
pRetryLimit, 393
pSPC, 393
pack_wds_SetMobileIPProfile
wds.h, 1180
pack_wds_SetMobileIPProfile_t, 393
index, 394
pAAASPI, 394
pAddress, 394
pEnabled, 394
pHASPI, 394
pMNAAA, 394
pMNHA, 395
pNAI, 395
pPrimaryHA, 395
pRevTunneling, 395
pSecondaryHA, 395
spc, 395
pack_wds_SetMuxID
wds.h, 1181
PackCreateProfileOut, 409
ExtErrorCode, 410
ProfileIndex, 410
ProfileType, 410
PackSwiAVMSSettingsAPNInfo, 413
bAPNLength, 413
bPWDLength, 413
bUnameLength, 413
pAPN, 414
pPWD, 414
pUname, 414
PackSwiAVMSSettingsConnectionRetryTimers, 414
Timers, 414
PackSwiAVMSSettingsPeriodsInfo, 414
max, 415
min, 415
PackSwiAvmsSetSettingsAPNInfo, 411
bAPNLength, 411
bPWDLength, 411

bUnameLength, 412
szAPN, 412
szPWD, 412
szUname, 412
PackSwiAvmsSetSettingsConnectionRetryTimers, 412
Timers, 412
PackSwiAvmsSetSettingsPeriodInfo, 413
ulMax, 413
ulMin, 413
package_name
unpack_omaDmFotaTlv_t, 615
packageid_str
unpack_dms_GetFirmwareInfo_t, 488
packetZone
nas_CDMASysInfo, 116
packetZoneValid
nas_CDMASysInfo, 116
packgetDyingGaspCfg, 410
pDestSMSContent, 410
pDestSMSNum, 410
packgetDyingGaspStatistics, 410
pSMSAttemptedFlag, 411
pTimeStamp, 411
path
uim_fileInfo, 459
pathLen
uim_fileInfo, 459
pbAuto
unpack_pds_GetPortAutomaticTracking_t, 618
unpack_pds_GetServiceAutomaticTracking_t, 619
pbEnabled
unpack_pds_GetXTRAAutomaticDownload_t, 619
pbPlatform
unpack_dms_GetOfflineReason_t, 494
pci
nas_cellParams, 118
nas_ltePCI, 154
nas_PhyCaAggPcellInfo, 174
nas_PhyCaAggScellIndType, 175
nas_PhyCaAggScellInfo, 178
nas_umtsLTENbrCell, 214
NASPhyCaAggPcellInfo, 227
NASPhyCaAggScellIndType, 229
NASPhyCaAggScellInfo, 230
pcsfFQDNAddress
wds_PCSCFFQDNAddressList, 811
PdpStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 269
pdpType
pack_wds_SetDefaultProfile_t, 390
pdptype
unpack_wds_GetDefaultProfile_t, 724
pds.h, 979
pack_pds_ForceXTRADownload, 981
pack_pds_GetPDSDefaults, 981
pack_pds_GetPDSState, 982
pack_pds_GetPortAutomaticTracking, 982
pack_pds_GetServiceAutomaticTracking, 982
pack_pds_GetXTRAAutomaticDownload, 983
pack_pds_GetXTRANetwork, 983
pack_pds_GetXTRAValidity, 983
pack_pds_PDSInjectTimeReference, 984
pack_pds_ResetPDSData, 984
pack_pds_SLQSGetAGPSConfig, 987
pack_pds_SLQSGetGPSStateInfo, 987
pack_pds_SLQSPDSDeterminePosition, 988
pack_pds_SLQSPDSInjectAbsoluteTimeReference, 988
pack_pds_SLQSPDSInjectPositionData, 988
pack_pds_SLQSSetAGPSConfig, 989
pack_pds_SLQSSetPositionMethodState, 989
pack_pds_SetEventReportCallback, 985
pack_pds_SetPDSDefaults, 985
pack_pds_SetPDSState, 985
pack_pds_SetPortAutomaticTracking, 986
pack_pds_SetServiceAutomaticTracking, 986
pack_pds_SetXTRAAutomaticDownload, 986
pack_pds_SetXTRANetwork, 987
pack_pds_StartPDSTrackingSessionExt, 990
pack_pds_StopPDSTrackingSession, 990
unpack_pds_ForceXTRADownload, 990
unpack_pds_GetPDSDefaults, 991
unpack_pds_GetPDSState, 991
unpack_pds_GetPortAutomaticTracking, 991
unpack_pds_GetServiceAutomaticTracking, 992
unpack_pds_GetXTRAAutomaticDownload, 992
unpack_pds_GetXTRANetwork, 992
unpack_pds_GetXTRAValidity, 993
unpack_pds_PDSInjectTimeReference, 993
unpack_pds_ResetPDSData, 993
unpack_pds_SLQSGetAGPSConfig, 997
unpack_pds_SLQSGetGPSStateInfo, 997
unpack_pds_SLQSPDSDeterminePosition, 997
unpack_pds_SLQSPDSInjectAbsoluteTime-Reference, 998
unpack_pds_SLQSPDSInjectPositionData, 998
unpack_pds_SLQSSetAGPSConfig, 998
unpack_pds_SLQSSetPositionMethodState, 999
unpack_pds_SetEventReport_Ind, 994
unpack_pds_SetEventReportCallback, 994
unpack_pds_SetPDSDefaults, 994
unpack_pds_SetPDSState, 995
unpack_pds_SetPdsState_Ind, 995
unpack_pds_SetPortAutomaticTracking, 995
unpack_pds_SetServiceAutomaticTracking, 996
unpack_pds_SetXTRAAutomaticDownload, 996
unpack_pds_SetXTRANetwork, 996
unpack_pds_StartPDSTrackingSessionExt, 999
unpack_pds_StopPDSTrackingSession, 999
peakRate
unpack_qos_tokenBucket_t, 647
peakThroughputClass
LibPackGPRSRequestedQoS, 62
wds_GPRSQoS, 808
PersistentTechPref
unpack_nas_GetNetworkPreference_t, 565

persoFeature
appStats, 33
uim_appStatus, 449
persoRetries
appStats, 33
uim_appStatus, 449
persoState
appStats, 33
uim_appStatus, 449
persoUnblockRetries
appStats, 33
uim_appStatus, 449
pfailureCause
unpack_voice_SLQSOriginateUSSD_t, 691
phase
nas_rxInfo, 192
PhyCaAggPcellInfo
NasGetLTECphyCaInfo, 223
PhyCaAggScellDlBw
NasGetLTECphyCaInfo, 223
PhyCaAggScellIndType
NasGetLTECphyCaInfo, 223
PhyCaAggScellIndex
NasGetLTECphyCaInfo, 223
PhyCaAggScellInfo
NasGetLTECphyCaInfo, 223
PhysicalLayer
nas_protocolSubtypeElement, 183
PilotEnergy
nas_NetworkStatEVDO, 170
PilotPN
nas_PilotSetParams, 179
PilotStrength
nas_PilotSetParams, 179
PilotType
nas_PilotSetParams, 179
pin1Len
uim_encryptedPIN1, 455
pin1Retries
appStats, 34
uim_appStatus, 449
pin1State
appStats, 34
uim_appStatus, 449
pin1Val
uim_encryptedPIN1, 455
pin2Retries
appStats, 34
uim_appStatus, 449
pin2State
appStats, 34
uim_appStatus, 449
pinID
uim_changeUIMPIN, 453
uim_setPINProtection, 466
uim_unblockUIMPIN, 469
uim_verifyUIMPIN, 470
pinLen
uim_changeUIMPIN, 453
uim_verifyUIMPIN, 470
pinLength
uim_setPINProtection, 466
pinOperation
uim_setPINProtection, 466
pinProtection
pack_uim_SetPinProtection_t, 356
pack_uim_UnblockPin_t, 363
pinVal
uim_changeUIMPIN, 453
uim_verifyUIMPIN, 470
pinValue
uim_setPINProtection, 466
PkgDescLength
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
PkgDescription
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
PkgName
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
PkgNameLength
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
pkgver
unpack_dms_SLQSSwiGetFirmwareCurr_t, 513
PktErrRate
unpack_qos_swiQosFlow_t, 646
plasmaIDString
pack_dms_SLQSSwiSetHostDevInfo_t, 254
unpack_dms_SLQSSwiGetHostDevInfo_t, 516
plmn
nas_GERANInfo, 132
nas_LTEInfoIntrafreq, 152
nas_UMTSInfo, 212
port
loc_IPv4Info, 97
loc_IPv6Info, 97
unpack_qos_Port_t, 631
posDataNmea
pack_pds_SetEventReportCallback_t, 312
posSrc
unpack_pds_SetEventReport_Ind_t, 622
PositionDataNMEA
unpack_pds_SetEventReport_Ind_t, 622
positionSrc
pack_loc_SLQSLOCInjectPosition_t, 279
pprofileid3gpp
pack_wds_SLQSStartDataSession_t, 406
pprofileid3gpp2
pack_wds_SLQSStartDataSession_t, 406
prDNSIPv4Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 753
prDNSIPv6Address

unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 754
prPCSCFIPv4Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 754
prPCSCFIPv6Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 754
Precedence
unpack_qos_swiQosFilter_t, 642
precedenceClass
LibPackGPRSRequestedQoS, 62
wds_GPRSQoS, 808
prefNetwork
unpack_wds_SLQSGetCurrDataSystemStat_t, 737
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
preference
pack_pds_SetXTRANetwork_t, 315
Preferred
nas_QmiNas3GppNetworkInfo, 185
prefix
ipv6_addr, 61
wds.h, 1209
prefixLen
unpack_qos_IPv6Addr_t, 630
presentationInd
voice_remotePartyNum, 797
priChA
nas_CDMAChannel, 110
priChB
nas_CDMAChannel, 111
priSize
unpack_dms_GetFirmwareRevisions_t, 490
pridns
unpack_wds_GetDefaultProfile_t, 724
pridnsv6
unpack_wds_GetDefaultProfile_t, 724
primaryDNS
pack_wds_SetDefaultProfile_t, 390
PrimaryDNSV4
unpack_wds_SLQSGetRuntimeSettings_t, 745
PrimaryDNSV6
unpack_wds_SLQSGetRuntimeSettings_t, 745
primaryHA
unpack_wds_GetMobileIPProfile_t, 728
privacyPref
pack_voice_SLQSVoiceSetPreferredPrivacy_t, 380
priver
unpack_dms_SLQSSwiGetFirmwareCurr_t, 513
priversion_str
unpack_dms_GetFirmwareInfo_t, 488
Profile
pack_audio_SLQSGetAudioPathConfig_t, 237
pack_audio_SLQSGetAudioVolTLBConfig_t, 238
pack_audio_SLQSSetAudioPathConfig_t, 240
pack_audio_SLQSSetAudioProfile_t, 241
pack_audio_SLQSSetAudioVolTLBConfig_t, 242
pack_swiaudio_SLQSGetM2MAudioVolume_t, 335
pack_swiaudio_SLQSGetM2MAVMute_t, 335
pack_swiaudio_SLQSGetM2MSpkrGain_t, 336
pack_swiaudio_SLQSSetM2MAudioAVCFG_t, 337
pack_swiaudio_SLQSSetM2MAudioProfile_t, 338
pack_swiaudio_SLQSSetM2MAudioVolume_t, 339
pack_swiaudio_SLQSSetM2MAVMute_t, 340
pack_swiaudio_SLQSSetM2MSpkrGain_t, 340
unpack_audio_SLQSGetAudioProfile_t, 473
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 661
ProfileID
unpack_wds_SLQSGetRuntimeSettings_t, 745
ProfileId
pack_wds_SLQSGetProfileSettings_t, 399
profileId
wds_DHCPProfileIdTlv, 804
wds_DHCPv4ProfileId, 806
wdsDhcpv4ProfileId, 819
ProfileId3GPP2
unpack_qos_swiQosFlow_t, 646
ProfileIdTlv
unpack_wds_DHCPv4ClientLease_ind_t, 719
ProfileIndex
PackCreateProfileOut, 410
profileIndex
pack_wds_SLQSDeleteProfile_t, 396
wds_ProfileIdentifier, 812
profileList
unpack_wds_SLQSGet3GPPConfigItem_t, 736
ProfileName
unpack_wds_SLQSGetRuntimeSettings_t, 745
ProfileType
pack_wds_SLQSGetProfileSettings_t, 399
PackCreateProfileOut, 410
unpack_wds_SLQSGetProfileSettings_t, 742
profileType
pack_wds_SetDefaultProfile_t, 390
pack_wds_SLQSDeleteProfile_t, 396
wds_DHCPProfileIdTlv, 804
wds_DHCPv4ProfileId, 807
wds_ProfileIdentifier, 812
wdsDhcpv4ProfileId, 819
profiletype
pack_wds_GetDefaultProfile_t, 385
PromptFwDownload
pack_swiavms_SLQSAVMSSetSettings_t, 343
PromptFwUpdate
pack_swiavms_SLQSAVMSSetSettings_t, 343
Protocol
unpack_nas_GetCDMANetworkParameters_t, 560
ProvisionStatus
voice_CLIPResp, 782
voice_CLIRResp, 783
voice_CNAPResp, 783
voice_COLPResp, 784

voice_COLRResp, 785
psAttachState
nas_servSystem, 197
NASServingSystemInfo, 235
psBarStatus
nas_CallBarringSysInfo, 109
nas_callBarStatus, 110
psState
nas_CommInfo, 120
psc
nas_UMTSInfo, 212
nas_wcdmaCellInfo, 216
nas_WCDMASysInfo, 221
pscValid
nas_WCDMASysInfo, 221
pscsfIPv4Addr
wds_PCSCFIPv4ServerAddressList, 812
psetting
unpack_wds_GetAutoconnect_t, 720
psid
pack_wds_SLQSStopDataSession_t, 407
unpack_wds_SLQSStartDataSession_t, 751
puk1Retries
appStats, 34
uim_appStatus, 449
puk2Retries
appStats, 34
uim_appStatus, 449
pukLen
uim_unblockUIMPIN, 469
pukVal
uim_unblockUIMPIN, 470
pukValue
pack_dms_UIMUnblockPIN_t, 258

QMI_LITE_WDS_CURRENT_CALL_DB_MASK
wds.h, 1172
QMI_LITE_WDS_LAST_CALL_DB_MASK
wds.h, 1172
QCI
LibPackQosClassID, 86
QFlowState
unpack_qos_QosFlowInfo_t, 632
QLIC
nas_DeviceConfigDetail, 127
QMI pack/unpack (lite-qmi), 25
qaGobiApiTableBandClasses.h, 1000
qaGobiApiTableCallControlReturnReasons.h, 1003
qaGobiApiTableCallEndReasons.h, 1003
qaGobiApiTableCarrierCodes.h, 1020
qaGobiApiTableCodingScheme.h, 1022
qaGobiApiTableGpsCapabilityCodes.h, 1024
qaGobiApiTablePowerModes.h, 1025
qaGobiApiTableRadioInterfaces.h, 1026
qaGobiApiTableRegionCodes.h, 1026
qaGobiApiTableServiceOptions.h, 1027
qaGobiApiTableSupServiceInfoClasses.h, 1029
qaGobiApiTableSwiAudio.h, 1029
qaGobiApiTableSwiOMADMSessionStatus.h, 1030
qaGobiApiTableSwiOMADMUpdateCompleteStatus.h, 1031
qaGobiApiTableVoiceCallEndReasons.h, 1032
qm_wds_ds_profile_extended_err_codes
qmerrno.h, 1045
qmerrno.h
eQCWWAN_ERR_API_MUTEX_TIMEOUT, 1042
eQCWWAN_ERR_BUFFER_SZ, 1041
eQCWWAN_ERR_CANCEL_OP, 1042
eQCWWAN_ERR_DRIVER, 1042
eQCWWAN_ERR_ENUM_BEGIN, 1041
eQCWWAN_ERR_ENUM_END, 1042
eQCWWAN_ERR_FILE_COPY, 1041
eQCWWAN_ERR_FILE_OPEN, 1041
eQCWWAN_ERR_GENERAL, 1041
eQCWWAN_ERR_INTERNAL, 1041
eQCWWAN_ERR_INVALID_ARG, 1041
eQCWWAN_ERR_INVALID_DEVID, 1041
eQCWWAN_ERR_INVALID_FILE, 1041
eQCWWAN_ERR_INVALID_QMI_RSP, 1041
eQCWWAN_ERR_INVALID_XID, 1042
eQCWWAN_ERR_MALFORMED_QMI_RSP, 1041
eQCWWAN_ERR_MEMORY, 1041
eQCWWAN_ERR_MULTIPLE_DEVICES, 1042
eQCWWAN_ERR_MULTIPLE_SMS_UNSUPPORTED, 1042
eQCWWAN_ERR_NO_CANCELABLE_OP, 1042
eQCWWAN_ERR_NO_CONNECTION, 1041
eQCWWAN_ERR_NO_DEVICE, 1041
eQCWWAN_ERR_NO_SIGNAL, 1042
eQCWWAN_ERR_NONE, 1041
eQCWWAN_ERR_NULL_TLV, 1045
eQCWWAN_ERR_OFFLINE, 1042
eQCWWAN_ERR_PDU_GENERATION, 1042
eQCWWAN_ERR_QMI_ABORTED, 1042
eQCWWAN_ERR_QMI_ACCESS_DENIED, 1044
eQCWWAN_ERR_QMI_ACK_NOT_SENT, 1044
eQCWWAN_ERR_QMI_ARG_TOO_LONG, 1042
eQCWWAN_ERR_QMI_AUTHENTICATION_FAILED, 1043
eQCWWAN_ERR_QMI_AUTHENTICATION_LOCK, 1043
eQCWWAN_ERR_QMI_BUNDLING_NOT_SUPPORTED, 1044
eQCWWAN_ERR_QMI_CALL_FAILED, 1042
eQCWWAN_ERR_QMI_CARD_BUSY_RSP, 1045
eQCWWAN_ERR_QMI_CARD_CALL_CONTROL_FAILED, 1044
eQCWWAN_ERR_QMI_CAT_END, 1045
eQCWWAN_ERR_QMI_CAT_START, 1045
eQCWWAN_ERR_QMI_CAUSE_CODE, 1043
eQCWWAN_ERR_QMI_CLIENT_IDS_EXHAUSTED, 1042
eQCWWAN_ERR_QMI_CONNECT, 1041
eQCWWAN_ERR_QMI_DEVICE_IN_USE, 1042
eQCWWAN_ERR_QMI_DEVICE_NOT_READY, 1043

eQCWWAN_ERR_QMI_DEVICE_STORAGE_FULL, 1043
eQCWWAN_ERR_QMI_DISABLED, 1043
eQCWWAN_ERR_QMI_ENCODING, 1043
eQCWWAN_ERR_QMI_ENVELOPE_CMD_FAILURE, 1045
eQCWWAN_ERR_QMI_EVENT_REG_FAILED, 1045
eQCWWAN_ERR_QMI_EXTENDED_INTERNAL, 1044
eQCWWAN_ERR_QMI_FDN_RESTRICT, 1044
eQCWWAN_ERR_QMI_FLOW_SUSPENDED, 1043
eQCWWAN_ERR_QMI_GENERAL, 1043
eQCWWAN_ERR_QMI_HARDWARE_RESTRICTED, 1044
eQCWWAN_ERR_QMI_IFACE, 1041
eQCWWAN_ERR_QMI_INCOMPATIBLE_STATE, 1044
eQCWWAN_ERR_QMI_INCORRECT_FLOW_FILTER, 1043
eQCWWAN_ERR_QMI_INCORRECT_PIN, 1042
eQCWWAN_ERR_QMI_INFO_UNAVAILABLE, 1044
eQCWWAN_ERR_QMI_INJECT_TIMEOUT, 1044
eQCWWAN_ERR_QMI_INSUFFICIENT_RESOURCES, 1043
eQCWWAN_ERR_QMI_INTERFACE_NOT_FOUND, 1043
eQCWWAN_ERR_QMI_INTERNAL, 1042
eQCWWAN_ERR_QMI_INVALID_ARG, 1043
eQCWWAN_ERR_QMI_INVALID_CLIENT_ID, 1042
eQCWWAN_ERR_QMI_INVALID_DATA_FORMAT, 1043
eQCWWAN_ERR_QMI_INVALID_ENVELOPE_CMD, 1045
eQCWWAN_ERR_QMI_INVALID_HANDLE, 1042
eQCWWAN_ERR_QMI_INVALID_ID, 1043
eQCWWAN_ERR_QMI_INVALID_INDEX, 1043
eQCWWAN_ERR_QMI_INVALID_IP_FAMILY_PREF, 1043
eQCWWAN_ERR_QMI_INVALID_MCAST_HANDLE, 1043
eQCWWAN_ERR_QMI_INVALID_MESSAGE_ID, 1043
eQCWWAN_ERR_QMI_INVALID_OPERATION, 1044
eQCWWAN_ERR_QMI_INVALID_PDP_TYPE, 1042
eQCWWAN_ERR_QMI_INVALID_PINID, 1042
eQCWWAN_ERR_QMI_INVALID_PROFILE, 1042
eQCWWAN_ERR_QMI_INVALID_PROFILE_TYPE, 1042
eQCWWAN_ERR_QMI_INVALID_PS_ATTACH_ACTION, 1043
eQCWWAN_ERR_QMI_INVALID_QMI_CMD, 1044
eQCWWAN_ERR_QMI_INVALID_QOS_ID, 1043
eQCWWAN_ERR_QMI_INVALID_REGISTER_ACTION, 1043
eQCWWAN_ERR_QMI_INVALID_SERVICE_TYPE, 1042
eQCWWAN_ERR_QMI_INVALID_TECH_PREF, 1042
eQCWWAN_ERR_QMI_INVALID_TERMINAL_RSP, 1045
eQCWWAN_ERR_QMI_INVALID_TRANSITION, 1043
eQCWWAN_ERR_QMI_INVALID_TX_ID, 1042
eQCWWAN_ERR_QMI_MALFORMED_MSG, 1042
eQCWWAN_ERR_QMI_MAX, 1044
eQCWWAN_ERR_QMI_MAX_MCAST_REQUESTS_IN_USE, 1043
eQCWWAN_ERR_QMI_MAX_QOS_REQUESTS_IN_USE, 1043
eQCWWAN_ERR_QMI_MESSAGE_DELIVERY_FAILURE, 1043
eQCWWAN_ERR_QMI_MESSAGE_NOT_SENT, 1043
eQCWWAN_ERR_QMI_MISSING_ARG, 1042
eQCWWAN_ERR_QMI_MSG_BLOCKED, 1044
eQCWWAN_ERR_QMI_NETWORK_ABORTED, 1044
eQCWWAN_ERR_QMI_NETWORK_NOT_READY, 1043
eQCWWAN_ERR_QMI_NETWORK_QOS_UNAWARE, 1043
eQCWWAN_ERR_QMI_NO_EFFECT, 1042
eQCWWAN_ERR_QMI_NO_ENTRY, 1043
eQCWWAN_ERR_QMI_NO_FREE_PROFILE, 1042
eQCWWAN_ERR_QMI_NO_MEMORY, 1042
eQCWWAN_ERR_QMI_NO_NETWORK_FOUND, 1042
eQCWWAN_ERR_QMI_NO_RADIO, 1044
eQCWWAN_ERR_QMI_NO_SUBSCRIPTION, 1044
eQCWWAN_ERR_QMI_NO_THRESHOLDS, 1042
eQCWWAN_ERR_QMI_NOT_A_MCAST_IFACE, 1043
eQCWWAN_ERR_QMI_NOT_PROVISIONED, 1042
eQCWWAN_ERR_QMI_NOT_SUPPORTED, 1044
eQCWWAN_ERR_QMI_OFFSET, 1042
eQCWWAN_ERR_QMI_OP_DEVICE_UNSUPPORTED, 1042
eQCWWAN_ERR_QMI_OP_NETWORK_UNSUPPORTED, 1042
eQCWWAN_ERR_QMI_OP_PARTIAL_FAILURE, 1044
eQCWWAN_ERR_QMI_OUT_OF_CALL, 1042
eQCWWAN_ERR_QMI_PIN_BLOCKED, 1043

eQCWWAN_ERR_QMI_PIN_PERM_BLOCKED, 1043
eQCWWAN_ERR_QMI_POLICY_MISMATCH, 1044
eQCWWAN_ERR_QMI_REQ, 1041
eQCWWAN_ERR_QMI_REQ_SCH, 1041
eQCWWAN_ERR_QMI_REQ_TO, 1041
eQCWWAN_ERR_QMI_REQUESTED_NUM_UNSUPPORTED, 1043
eQCWWAN_ERR_QMI_RSP, 1041
eQCWWAN_ERR_QMI_RSP_TO, 1041
eQCWWAN_ERR_QMI_SEGMENT_ORDER, 1044
eQCWWAN_ERR_QMI_SEGMENT_TOO_LONG, 1044
eQCWWAN_ERR_QMI_SESSION_INACTIVE, 1043
eQCWWAN_ERR_QMI_SESSION_INVALID, 1043
eQCWWAN_ERR_QMI_SESSION_OWNERSHIP, 1043
eQCWWAN_ERR_QMI_SIM_FILE_NOT_FOUND, 1044
eQCWWAN_ERR_QMI_SIM_NOT_INITIALIZED, 1043
eQCWWAN_ERR_QMI_SMSC_ADDR, 1044
eQCWWAN_ERR_QMI_SUPS_FAILURE_CAUSE, 1044
eQCWWAN_ERR_QMI_TPDU_TYPE, 1044
eQCWWAN_ERR_QMI_UNABORTABLE_TRANSACTION, 1042
eQCWWAN_ERR_QMI_UNKNOWN, 1043
eQCWWAN_ERR_QMI_WIDTH, 1045
eQCWWAN_ERR_RESET, 1042
eQCWWAN_ERR_SWICM_AM_VERS_ERROR, 1044
eQCWWAN_ERR_SWICM_CALL_IN_PROGRESS, 1044
eQCWWAN_ERR_SWICM_END, 1045
eQCWWAN_ERR_SWICM_FAILED_TO_KILL_SDK_PROCESS, 1044
eQCWWAN_ERR_SWICM_INVALID_SESSION_ID, 1044
eQCWWAN_ERR_SWICM_INVALID_V4_SESSION_ID, 1044
eQCWWAN_ERR_SWICM_INVALID_V6_SESSION_ID, 1044
eQCWWAN_ERR_SWICM_NOT_IMPLEMENTED, 1044
eQCWWAN_ERR_SWICM_QMI_CLNT_NOT_SUPPORTED, 1044
eQCWWAN_ERR_SWICM_QMI_SVC_NOT_SUPPORTED, 1044
eQCWWAN_ERR_SWICM_SM_NO_AVAILABLE_SESSIONS, 1044
eQCWWAN_ERR_SWICM_SOCKET_IN_USE, 1044
eQCWWAN_ERR_SWICM_START, 1044
eQCWWAN_ERR_SWICM_TIMEOUT, 1044
eQCWWAN_ERR_SWICM_V4DWN_V6DWN, 1044
eQCWWAN_ERR_SWICM_V4DWN_V6UP, 1044
eQCWWAN_ERR_SWICM_V4UP_V6DWN, 1044
eQCWWAN_ERR_SWICM_V4UP_V6UP, 1044
eQCWWAN_ERR_SWIDCS_APP_DISCONNECTED, 1045
eQCWWAN_ERR_SWIDCS_DEVNODE_NOT_FOUND, 1045
eQCWWAN_ERR_SWIDCS_END, 1045
eQCWWAN_ERR_SWIDCS_FILEIO_ERR, 1045
eQCWWAN_ERR_SWIDCS_IOCTL_ERR, 1045
eQCWWAN_ERR_SWIDCS_START, 1045
eQCWWAN_ERR_SWIIM_CORRUPTED_FW_IMAGE, 1045
eQCWWAN_ERR_SWIIM_END, 1045
eQCWWAN_ERR_SWIIM_FILE_NOT_FOUND, 1045
eQCWWAN_ERR_SWIIM_FIRMWARE_NOT_DOWNLOADED, 1045
eQCWWAN_ERR_SWIIM_FW_ENTER_DOWNLOAD_MODE, 1045
eQCWWAN_ERR_SWIIM_FW_FLASH_COMPLETE, 1045
eQCWWAN_ERR_SWIIM_FW_INVALID_SLOT_INDEX, 1045
eQCWWAN_ERR_SWIIM_FW_PREFERENCE_MISMATCH, 1045
eQCWWAN_ERR_SWIIM_FW_SAME_AS_CURRENT_ACTIVE_IMAGE, 1045
eQCWWAN_ERR_SWIIM_FW_UPDATE_FAIL, 1045
eQCWWAN_ERR_SWIIM_FW_UPDATE_SUCCESS, 1045
eQCWWAN_ERR_SWIIM_FW_WAIT_FOR_REBOOT, 1045
eQCWWAN_ERR_SWIIM_INVALID_CRASH_STATE, 1045
eQCWWAN_ERR_SWIIM_INVALID_PATH, 1045
eQCWWAN_ERR_SWIIM_OPENING_DIR, 1045
eQCWWAN_ERR_SWIIM_OPENING_FILE, 1045
eQCWWAN_ERR_SWIIM_START, 1045
eQCWWAN_ERR_SWISM_END, 1045
eQCWWAN_ERR_SWISMS_BEARER_DATA_NOT_FOUND, 1045
eQCWWAN_ERR_SWISMS_MSG_CORRUPTED, 1045
eQCWWAN_ERR_SWISMS_MSG_LEN_TOO_LONG, 1045
eQCWWAN_ERR_SWISMS_SMSC_NUM_CORRUPTED, 1045
eQCWWAN_ERR_SWISMS_START, 1045
eWDS_ERR_PROFILE_REG_3GPP2_ERR_INVALID_IDENT_FOR_PROFILE, 1046
eWDS_ERR_PROFILE_REG_3GPP_ACCESS_ERR, 1046

eWDS_ERR_PROFILE_REG_3GPP_CONTEXT_NOT_DEFINED, 1046
eWDS_ERR_PROFILE_REG_3GPP_ERR_OUT_OF_PROFILES, 1046
eWDS_ERR_PROFILE_REG_3GPP_INVAL_PROFILE_FAMILY, 1046
eWDS_ERR_PROFILE_REG_3GPP_READ_ONLY_FLAG_SET, 1046
eWDS_ERR_PROFILE_REG_3GPP_VALID_FLAG_NOT_SET, 1046
eWDS_ERR_PROFILE_REG_END, 1046
eWDS_ERR_PROFILE_REG_INVAL_PROFILE_FAMILY, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_HNDL, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_IDENT, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_OP, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_NUM, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_TYPE, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_SUBS_ID, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_LEN_INVALID, 1046
eWDS_ERR_PROFILE_REG_RESULT_ERR_LIB_NOT_INITED, 1046
eWDS_ERR_PROFILE_REG_RESULT_FAIL, 1046
eWDS_ERR_PROFILE_REG_RESULT_LIST_END, 1046
qmerrno.h, 1039
eQCWWANError, 1041
qm_wds_ds_profile_extended_err_codes, 1045
qmiSmsMessageList, 415
messageIndex, 415
messageTag, 415
qmiWDSDataBearerTechnology, 415
currentNetwork, 416
ratMask, 416
soMask, 416
qmuxIPTable, 417
ipAddress, 417
ipv6Address, 417
muxID, 417
qos.h, 1046
pack_qos_BindDataPort, 1048
pack_qos_SLQSQosGetNetworkStatus, 1048
pack_qos_SLQSQosSwiReadApnExtraParams, 1049
pack_qos_SLQSQosSwiReadDataStats, 1050
pack_qos_SLQSSetQosEventCallback, 1050
unpack_qos_BindDataPort, 1051
unpack_qos_SLQSQosGetNetworkStatus, 1051
unpack_qos_SLQSQosSwiReadApnExtraParams, 1052
unpack_qos_SLQSQosSwiReadDataStats, 1052
unpack_qos_SLQSSetQosEventCallback, 1053
unpack_qos_SLQSSetQosEventCallback_ind, 1053
unpack_qos_SLQSSetQosNWStatusCallback_ind, 1054
unpack_qos_SLQSSetQosPriEventCallback_ind, 1054
unpack_qos_SLQSSetQosStatusCallback_ind, 1055
qos_BindDataPortMuxID_t, 417
MuxID, 417
qos_BindDataPortPeripheralEndPointID_t, 417
EndPointType, 418
IfaceID, 418
qos_BindDataPortSIODataPort_t, 418
SIODataPort, 418
qosDeliveryOrder
LibPackUMTSQoS, 90
wds_UMTSMinQoS, 816
qosFlow
unpack_qos_SLQSQosSwiReadDataStats_t, 636
QosFlowInfo
unpack_qos_SLQSSetQosEventCallback_ind_t, 637

RAN
unpack_nas_GetServingNetwork_t, 568
RAT
nas_QmiNas3GppNetworkRAT, 186
RATMask
currNetworkInfo, 49
wds_currNetworkInfo, 801
RFBandInfoElements, 418
activeBandClass, 419
activeChannel, 419
radioInterface, 419
unpack_nas_GetRFInfo_t, 566
RFTlv
unpack_nas_SetEventReportInd_t, 572
RMAutoConnect
pack_dms_SetCustFeature_t, 249
unpack_dms_GetCustFeature_t, 481
RPTlv
NASQmiCbkNasSystemSelPrefInd, 233
RRTlv
unpack_nas_SetEventReportInd_t, 572
RSRPThresListLen
nas_RSRPThresh, 189
RSRQThresListLen
nas_RSRQThresh, 190
RSSIThresListLen
nas_RSSIThresh, 191
RX_EC_IO
nas_NetworkStat1x, 168
RX_PWR
nas_NetworkStat1x, 168

nas_NetworkStatEVDO, 170
RXChan
nas_LTEInfo, 149
rXDroppedCount
unpack_wds_GetPacketStatus_t, 731
rXOKBytesLastCall
unpack_wds_GetPacketStatus_t, 732
rXOkBytesCount
unpack_wds_GetPacketStatus_t, 731
rXPacketErrors
unpack_wds_GetPacketStatus_t, 732
rXPacketOverflows
unpack_wds_GetPacketStatus_t, 732
rXPacketSuccesses
unpack_wds_GetPacketStatus_t, 732
radio
unpack_nas_GetSignalStrengths_t, 570
radio_if
pack_nas_SLQSNasGetTxRxInfo_t, 296
radioIf
nas_ecioListElement, 129
nas_errorRateListElement, 130
nas_rsrqInformation, 190
nas_rxSignalStrengthListElement, 194
RadioIfaces
unpack_dms_GetDeviceCap_t, 482
unpack_dms_GetDeviceCapabilities_t, 484
unpack_nas_GetServingNetwork_t, 568
RadioIfacesSize
unpack_dms_GetDeviceCap_t, 482
unpack_nas_GetServingNetwork_t, 568
radioIfacesSize
unpack_dms_GetDeviceCapabilities_t, 484
radioInterface
nas_RFInfoTlv, 188
nas_roamIndList, 189
nas_servSystem, 197
nas_SignalStrengthTlv, 198
nas_timeInfo, 209
RFBandInfoElements, 419
radioInterfaceList
NASServingSystemInfo, 235
radioInterfaceNo
NASServingSystemInfo, 235
radioInterfaceSize
nas_RFInfoTlv, 188
range
unpack_qos_Port_t, 631
rat
nas_CSGID, 121
nas_MNRInfo, 165
RatHandoverStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 269
ratMask
qmiWDSDataBearerTechnology, 416
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
rawHorConfidence
pack_loc_SLQSLOCInjectPosition_t, 279
rawHorUncCircular
pack_loc_SLQSLOCInjectPosition_t, 279
rawLen
uim_fileAttributes, 458
rawValue
uim_fileAttributes, 458
readTransparent
pack_uim_ReadTransparent_t, 355
Reason
pack_voice_SLQSVoiceGetCallForwardingStatus-_t, 372
pack_voice_SLQSVoiceSetCallBarringPassword_t, 379
reason
pack_voice_SLQSVoiceGetCallBarring_t, 371
pack_voice_SLQSVoiceSetSUPSService_t, 383
unpack_qos_SLQSSetQosStatusCallback_ind_t, 639
voice_ccSUPSType, 781
receiptAction
sms_routeEntry, 433
reconfigReqd
unpack_wds_SLQSSetPacketSrvStatusCallback_-t, 747
recordCount
uim_fileAttributes, 458
recordSize
uim_fileAttributes, 458
RedirPartyNum
voice_arrRedirPartyNum, 772
refData
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 515
refID
pack_cat_CATSendTerminalResponse_t, 244
refString
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 515
ReferenceID
cat_AlPhaIdentifierTlv, 41
cat_EventIDDataTlv, 43
refpn
nas_CDMAInfo, 112
refreshComplete
pack_uim_SLQSUIMRefreshComplete_t, 360
RefreshMode
cat_RefreshTlv, 44
RefreshStage
cat_RefreshTlv, 44
regAction
pack_nas_SLQSInitiateNetworkRegistration_t, 291
RegForeignNID
unpack_nas_GetCDMANetworkParameters_t, 560
RegForeignSID
unpack_nas_GetCDMANetworkParameters_t, 560
RegHomeSID
unpack_nas_GetCDMANetworkParameters_t, 560
regPrd
nas_AddCDMASysInfo, 107

regRefresh
pack_uim_SLQSUIMRefreshRegister_t, 362
regRejectInfoValid
nas_GSMSysInfo, 138
nas_LTESysInfo, 162
nas_WCDMASysInfo, 221
regState
nas_servSystem, 197
RegStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 269
registerFlag
uim_registerRefresh, 464
RegistrationState
unpack_nas_GetServingNetwork_t, 568
registrationState
NASServingSystemInfo, 235
rejCause
nas_GSMSysInfo, 138
nas_LTESysInfo, 162
nas_WCDMASysInfo, 221
rejectCause
nas_RejectReasonTlv, 187
rejectSrvDomain
nas_GSMSysInfo, 138
nas_LTESysInfo, 162
nas_WCDMASysInfo, 221
reliabilityClass
LibPackGPRSRequestedQoS, 62
wds_GPRSQoS, 808
remPartyNumber
voice_remotePartyNum, 797
RemotePartyName
voice_getAllCallRmtPtyName, 790
RemotePartyNum
voice_getAllCallRmtPtyNum, 791
ReqMitigationLvl
unpack_tmd_SLQSTmdGetMitigationLvl_t, 677
resBerRatio
LibPackUMTSQoS, 91
wds_UMTSMinQoS, 816
ResCode
unpack_audio_SLQSGetAudioVolTLBConfig_t, 474
unpack_audio_SLQSSetAudioVolTLBConfig_t, 474
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 515
resetInfoInd
pack_dms_SLQSDmsSwiIndicationRegister_t, 252
resultcode
unpack_swiavms_SLQSAVMSEventReportInd_t, 664
unpack_swiavms_SLQSAVMSGetSettings_t, 666
unpack_swiavms_SLQSAVMSSendSelection_t, 666
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 666
unpack_swiavms_SLQSAvmsSetEventReport_t, 667
unpack_swiavms_SLQSAVMSSetSettings_t, 667
unpack_swiavms_SLQSAVMSStartSession_t, 668
unpack_swiavms_SLQSAVMSStopSession_t, 668
RetryCount
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
revTunneling
unpack_wds_GetMobileIPProfile_t, 728
ReverseMac
nas_protocolSubtypeElement, 183
RfSarState
pack_sar_SLQSSetRfSarState_t, 325
RmTrasnferStaticsReq
pack_wds_RMSetTransferStatistics_t, 388
rmTrasnferStaticsReq, 419
bResetStatistics, 419
ulMask, 419
rms.h, 1056
pack_rms_GetSMSWake, 1056
pack_rms_SetSMSWake, 1056
unpack_rms_GetSMSWake, 1057
unpack_rms_SetSMSWake, 1057
RmtPtyNum
voice_arrRemotePartyNum, 773
roamIndicator
nas_roamIndList, 189
RoamIndicatorVal
unpack_nas_SLQSGetServingSystem_t, 584
roamOrigVoiceSO
voice_prefVoiceSO, 796
RoamPref
NASRoamPreferenceTlv, 233
roamStatus
nas_sysInfoCommon, 204
roamStatusValid
nas_sysInfoCommon, 204
roamTimerValue
voice_roamTimer, 798
Roaming
nas_QmiNas3GppNetworkInfo, 185
unpack_nas_GetCDMANetworkParameters_t, 560
unpack_nas_GetServingNetwork_t, 568
roaming
unpack_nas_SetRoamingIndicatorCallback_ind_t, 573
RoamingIndicatorList
unpack_nas_SLQSGetServingSystem_t, 584
routeList
sms_setRoutesReq, 437
routeStorage
sms_routeEntry, 433
rptPosData
pack_pds_SetEventReportCallback_t, 312
rptRate
nas_LTESigRptCfg, 157
nas_LTESigRptConfig, 158
rscp
nas_rxInfo, 192

nas_UMTSInfo, 212
tdscdmaSigInfoExt, 444
rsrp
lteSSInfo, 105
nas_cellParams, 118
nas_rxInfo, 192
nas_RxSigInfo, 193
nas_umtsLTENbrCell, 214
rsrplevel
nas_lteRsrpinformation, 155
rsrq
lteSSInfo, 105
nas_cellParams, 118
nas_rsrqInformation, 190
nas_SccRxInfo, 195
nas_umtsLTENbrCell, 214
rsrqDelta
nas_SLQSSignalStrengthsIndReq, 200
rsrqInfo
nas_SLQSSignalStrengthsInformation, 201
unpack_nas_SLQSGetSignalStrength_t, 586
rssi
cdmaSSInfo, 45
hdrSSInfo, 60
lteSSInfo, 105
nas_cellParams, 118
nas_gsmCellInfo, 134
tdscdmaSigInfoExt, 444
unpack_nas_GetSignalStrengths_t, 570
rx_bytes
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
rx_pkts
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
rxChainIndex
nas_RxSigInfo, 193
RxDropConutTlv
unpack_RMTransferStatistics_ind_t, 650
rxLev
nas_GERANInfo, 132
rxOKBytesCount
unpack_wds_SLQSGetDUNCallInfo_t, 741
RxOkByteCountTlv
unpack_RMTransferStatistics_ind_t, 650
RxOkConutTlv
unpack_RMTransferStatistics_ind_t, 650
rxPower
nas_rxInfo, 192
nas_RxSigInfo, 193
RxQFilter
unpack_qos_QosFlowInfo_t, 632
RxQFlowGranted
unpack_qos_QosFlowInfo_t, 632
rxSignalStrength
nas_rxSignalStrengthListElement, 194
rxSignalStrengthDelta
nas_SLQSSignalStrengthsIndReq, 200
rxSignalStrengthInfo
nas_SLQSSignalStrengthsInformation, 201
rxSignalStrengthList
unpack_nas_SLQSGetSignalStrength_t, 586
rxSignalStrengthListLen
unpack_nas_SLQSGetSignalStrength_t, 586

SCI
unpack_nas_GetCDMANetworkParameters_t, 560
SCM
unpack_nas_GetCDMANetworkParameters_t, 561
SDPTlv
NASQmiCbkNasSystemSelPrefInd, 233
SDU_HDR_LEN
common.h, 832
SHORT
SwiDataTypes.h, 1100
SI
voice_callFWExtInfo, 778
SIODataPort
qos_BindDataPortSIODataPort_t, 418
sIntraSearch
nas_LTEInfoIntrafreq, 152
SLQSSSTlv
unpack_nas_SetEventReportInd_t, 572
SMS_CONFIG_LEN
sms.h, 1062
SMS_MAX_SMS_ROUTES
sms.h, 1062
SMS_NUM_OF_SET
sms.h, 1062
SMSC_TYPE_LEN
sms.h, 1062
sMSCAddressInfo, 438
data, 438
length, 438
sMSCAddressTlv, 438
SMSCInfo, 438
TlvPresent, 438
SMSCInfo
sMSCAddressTlv, 438
SMSCTlv
unpack_sms_SetNewSMSCallback_ind_t, 653
sMSEtwsMessageInfo, 439
data, 439
length, 439
notificationType, 439
sMSEtwsMessageTlv, 439
EtwsMessageInfo, 440
TlvPresent, 440
sMSEtwsPlmnInfo, 440
mobileCountryCode, 440
mobileNetworkCode, 440
sMSMTMessageInfo, 440
messageIndex, 441
storageType, 441
sMSMessageModeInfo, 440
messageMode, 440
sMSOnIMSInfo, 441

smsOnIMS, 441
sMSOnIMSTlv, 441
IMSInfo, 442
TlvPresent, 442
SMSSupport
pack_dms_SetCustFeature_t, 249
unpack_dms_GetCustFeature_t, 481
sMSTransferRouteMTMessageInfo, 442
ackIndicator, 442
data, 442
format, 443
length, 443
transactionID, 443
SNR
nas_NetworkStatEVDO, 170
sNonIntraSearch
nas_LTEInfoIntrafreq, 152
SO
nas_NetworkStat1x, 168
SOMask
currNetworkInfo, 49
wds_currNetworkInfo, 801
SPC_SIZE
dms.h, 843
sPhyCaAggPcellInfo
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 572
sPhyCaAggScellDlBw
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 572
sPhyCaAggScellIndType
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 573
sPhyCaAggScellIndex
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 573
sPhyCaAggScellInfo
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 573
SSInfo
unpack_nas_SetServingSystemCallback_ind_t, 574
sSLQSSignalStrengthsInfo
nas_SLQSSignalStrengthsTlv, 201
SSTlv
unpack_nas_SetEventReportInd_t, 572
SUPSType
pack_voice_SLQSVoiceManageCalls_t, 377
SWI_API
SwiDataTypes.h, 1099
SWIWWANCMAPI.h, 1115
sar.h, 1057
pack_sar_SLQSGetRfSarState, 1058
pack_sar_SLQSSetRfSarState, 1058
unpack_sar_SLQSGetRfSarState, 1058
unpack_sar_SLQSSetRfSarState, 1059
sbas_almanac_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
sbas_ephemeris_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
sbas_health_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
sbas_visible_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 627
scell_idx
nas_PhyCaAggScellIndex, 175
NASPhyCaAggScellIndex, 228
scell_state
nas_PhyCaAggScellIndType, 175
nas_PhyCaAggScellInfo, 178
NASPhyCaAggScellIndType, 229
NASPhyCaAggScellInfo, 230
screeningInd
voice_connectNumInfo, 787
sduErrorRatio
LibPackUMTSQoS, 91
wds_UMTSMinQoS, 816
seDNSIPv4Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 754
seDNSIPv6Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 754
sePCSCFIPv4Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 754
sePCSCFIPv6Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 754
secActivate
uim_fileAttributes, 458
secActivateMask
uim_fileAttributes, 458
secChA
nas_CDMAChannel, 111
secChB
nas_CDMAChannel, 111
secDeactivate
uim_fileAttributes, 458
secDeactivateMask
uim_fileAttributes, 458
secIncrease
uim_fileAttributes, 458
secIncreaseMask
uim_fileAttributes, 458
SecProt
nas_protocolSubtypeElement, 183
secRead
uim_fileAttributes, 458
secReadMask
uim_fileAttributes, 458
secWrite
uim_fileAttributes, 458
secWriteMask
uim_fileAttributes, 458
secdns

unpack_wds_GetDefaultProfile_t, 724
secdnsv6
unpack_wds_GetDefaultProfile_t, 724
second
nas_timeInfo, 209
nas_UniversalTime, 215
secondaryDNS
pack_wds_SetDefaultProfile_t, 391
SecondaryDNSV4
unpack_wds_SLQSGetRuntimeSettings_t, 745
SecondaryDNSV6
unpack_wds_SLQSGetRuntimeSettings_t, 745
secondaryHA
unpack_wds_GetMobileIPProfile_t, 728
SectorIDLen
nas_NetworkStatEVDO, 170
selNetwork
nas_servSystem, 197
selected
sms_BroadcastConfig, 425
sms_CDMABroadcastConfig, 425
selectedNetwork
NASServingSystemInfo, 235
selection
pack_swiavms_SLQSAVMSSendSelection_t, 341
pack_swioma_SLQSOMADMSendSelection_t, 348
pack_swioma_SLQSOMADMSendSelectionExt_t, 348
sensorData_t, 420
flags, 421
sensorDataLen, 421
timeOfFirstSample, 421
timeOffset, 421
xAxis, 421
yAxis, 421
zAxis, 421
sensorDataLen
sensorData_t, 421
ServerAddrList
unpack_wds_SLQSGetRuntimeSettings_t, 745
serverAddrTypeMask
pack_loc_SLQSLOCGetServer_t, 274
serverStatus
unpack_loc_GetServer_Ind_t, 547
serverType
pack_loc_SLQSLOCGetServer_t, 274
unpack_loc_GetServer_Ind_t, 547
serviceCategory
sms_CDMABroadcastConfig, 425
serviceDomain
nas_RejectReasonTlv, 187
ServiceStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 269
servingCellId
nas_LTEInfoIntrafreq, 152
ServingSystem
unpack_nas_SLQSGetServingSystem_t, 584
sessionControl
pack_pds_StartPDSTrackingSessionExt_t, 321
sessionEndReason
unpack_wds_SLQSSetPacketSrvStatusCallback_t, 747
SessionId
pack_loc_Start_t, 284
pack_loc_Stop_t, 284
sessionId
unpack_loc_PositionRpt_Ind_t, 555
sessionInfo
pack_uim_ChangePin_t, 354
pack_uim_ReadTransparent_t, 355
pack_uim_SetPinProtection_t, 356
pack_uim_SLQSUIMAuthenticate_t, 357
pack_uim_SLQSUIMGetFileAttributes_t, 359
pack_uim_SLQSUIMRefreshComplete_t, 360
pack_uim_SLQSUIMRefreshGetLastEvent_t, 361
pack_uim_SLQSUIMRefreshOK_t, 361
pack_uim_SLQSUIMRefreshRegister_t, 362
pack_uim_UnblockPin_t, 364
pack_uim_VerifyPin_t, 365
SessionInfoConfig
unpack_swioma_SLQSOMADMAlertCallback_ind_t, 670
SessionInfoFota
unpack_swioma_SLQSOMADMAlertCallback_ind_t, 671
SessionInfoNotification
unpack_swioma_SLQSOMADMAlertCallback_ind_t, 671
sessionOperation
pack_pds_StartPDSTrackingSessionExt_t, 321
sessionResponse
unpack_swiavms_SLQSAVMSStartSession_t, 668
sessionServerOption
pack_pds_StartPDSTrackingSessionExt_t, 321
SessionState
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
SessionStatus
unpack_pds_SetEventReport_Ind_t, 622
sessionStatus
unpack_loc_PositionRpt_Ind_t, 555
unpack_omaDmNotificationsTlv_t, 616
SessionType
pack_swioma_SLQSOMADMGetSessionInfo_t, 347
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
sessionType
pack_pds_StartPDSTrackingSessionExt_t, 321
pack_swiavms_SLQSAVMSStartSession_t, 343
pack_swiavms_SLQSAVMSStopSession_t, 344
pack_swioma_SLQSOMADMCancelSession_t, 346
pack_swioma_SLQSOMADMCancelSessionExt_t, 346

pack_swioma_SLQSOMADMStartSession_t, 351
pack_swioma_SLQSOMADMStartSessionExt_t, 351
uim_refreshevent, 463
uim_sessionInformation, 465
uim_UIMSessionInformation, 469
unpack_omaDmFotaTlv_t, 615
set_fix_rate
pack_swiloc_SwiLocSetAutoStart_t, 345
set_fix_type
pack_swiloc_SwiLocSetAutoStart_t, 346
set_function
pack_swiloc_SwiLocSetAutoStart_t, 346
set_max_dist
pack_swiloc_SwiLocSetAutoStart_t, 346
set_max_time
pack_swiloc_SwiLocSetAutoStart_t, 346
SetupEventList
cat_EventListTlv, 44
Severity
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
severity
unpack_omaDmFotaTlv_t, 615
shortName
nas_PLMNNetworkNameData, 181
unpack_nas_SLQSGetPLMNName_t, 579
shortNameCI
unpack_nas_SLQSGetPLMNName_t, 579
shortNameEn
unpack_nas_SLQSGetPLMNName_t, 580
shortNameLen
nas_PLMNNetworkNameData, 181
unpack_nas_SLQSGetPLMNName_t, 580
shortNameSB
unpack_nas_SLQSGetPLMNName_t, 580
shortNameSpareBits
nas_PLMNNetworkNameData, 181
sid
nas_CDMAInfo, 112
nas_sidNid, 198
unpack_nas_GetHomeNetwork_t, 564
SidNid
nas_homeSIDNID, 143
SigInd
LibPackUMTSReqQoSSigInd, 91
sigInfo
nas_SccRxInfo, 195
signalStrength
nas_SignalStrengthTlv, 198
signalStrengthReqMask
unpack_nas_SLQSGetSignalStrength_t, 586
SimCapability
unpack_dms_GetDeviceCap_t, 482
simCapability
unpack_dms_GetDeviceCapabilities_t, 484
sinr
hdrSSInfo, 60
nas_SLQSSignalStrengthsInformation, 201
tdscdmaSigInfoExt, 444
unpack_nas_SLQSGetSignalStrength_t, 586
sinrDelta
nas_SLQSSignalStrengthsIndReq, 200
sinrThresholdList
nas_SLQSSignalStrengthsIndReq, 200
sinrThresholdListLen
nas_SLQSSignalStrengthsIndReq, 200
sku_str
unpack_dms_GetFirmwareInfo_t, 488
slot
pack_uim_SLQSUIMPowerDown_t, 359
pack_uim_SLQSUIMPowerUp_t, 360
slot_t, 421
bICCID, 422
bICCIDLength, 422
bLogicalSlot, 422
uPhyCardStatus, 422
uPhySlotStatus, 422
slotInf, 422
AppStatus, 423
cardState, 423
errorState, 424
numApp, 424
upinRetries, 424
upinState, 424
upukRetries, 424
SlotInfo
uim_cardStatus, 452
slots_t, 424
uimSlotStatus, 424
slotsstatusChange
unpack_uim_SetUimSlotStatusChangeCallback_-ind_t, 682
SlqsProfile3GPP
unpackWdsProfileParam, 763
wds_profileInfo, 813
SlqsProfile3GPP2
unpackWdsProfileParam, 763
wds_profileInfo, 813
sms.h
LITEQMI_QMI_CBK_PARAM_NOCHANGE, 1063
LITEQMI_QMI_CBK_PARAM_RESET, 1063
LITEQMI_QMI_CBK_PARAM_SET, 1063
sms.h, 1059
eqmiCbkSetStatus, 1063
MAX_MSE_TWS_MSG, 1062
MAX_SMS_LIST_SIZE, 1062
pack_sms_GetSMSCAddress, 1063
pack_sms_SLQSDeleteSMS, 1064
pack_sms_SLQSGetIndicationRegister, 1065
pack_sms_SLQSGetMessageWaiting, 1065
pack_sms_SLQSGetSMS, 1065
pack_sms_SLQSGetSMSList, 1066
pack_sms_SLQSGetSmsBroadcastConfig, 1066
pack_sms_SLQSGetTransLayerInfo, 1067
pack_sms_SLQSGetTransNWRegInfo, 1067

pack_sms_SLQSModifySMSStatus, 1067
pack_sms_SLQSSendAsyncSMS, 1068
pack_sms_SLQSSetIndicationRegister, 1068
pack_sms_SLQSSetSmsBroadcastActivation, 1068
pack_sms_SLQSSetSmsBroadcastConfig, 1069
pack_sms_SLQSSetSmsStorage, 1069
pack_sms_SLQSSmsGetMaxStorageSize, 1069
pack_sms_SLQSSmsGetMessageProtocol, 1070
pack_sms_SLQSSmsSetRoutes, 1070
pack_sms_SLQSSwiGetSMSStorage, 1071
pack_sms_SaveSMS, 1063
pack_sms_SendSMS, 1063
pack_sms_SetNewSMSCallback, 1064
pack_sms_SetSMSCAddress, 1064
SMS_CONFIG_LEN, 1062
SMS_MAX_SMS_ROUTES, 1062
SMS_NUM_OF_SET, 1062
SMSC_TYPE_LEN, 1062
unpack_sms_GetSMSCAddress, 1071
unpack_sms_SLQSDeleteSMS, 1073
unpack_sms_SLQSGetIndicationRegister, 1073
unpack_sms_SLQSGetMessageWaiting, 1074
unpack_sms_SLQSGetSMS, 1074
unpack_sms_SLQSGetSMSList, 1075
unpack_sms_SLQSGetSmsBroadcastConfig, 1074
unpack_sms_SLQSGetTransLayerInfo, 1075
unpack_sms_SLQSGetTransNWRegInfo, 1075
unpack_sms_SLQSModifySMSStatus, 1076
unpack_sms_SLQSSendAsyncSMS, 1076
unpack_sms_SLQSSetIndicationRegister, 1076
unpack_sms_SLQSSetSmsBroadcastActivation, 1077
unpack_sms_SLQSSetSmsBroadcastConfig, 1077
unpack_sms_SLQSSetSmsStorage, 1077
unpack_sms_SLQSSmsGetMaxStorageSize, 1078
unpack_sms_SLQSSmsGetMessageProtocol, 1078
unpack_sms_SLQSSmsSetRoutes, 1078
unpack_sms_SLQSSwiGetSMSStorage, 1079
unpack_sms_SLQSWmsMemoryFullCallBack_ind, 1079
unpack_sms_SaveSMS, 1071
unpack_sms_SendSMS, 1072
unpack_sms_SetNewSMSCallback, 1072
unpack_sms_SetNewSMSCallback_ind, 1072
unpack_sms_SetSMSCAddress, 1073
sms_BroadcastConfig, 424
fromServiceId, 425
selected, 425
toServiceId, 425
sms_CDMABroadcastConfig, 425
language, 425
selected, 425
serviceCategory, 425
sms_getIndicationReg, 425
pRegCallStatInfoEvt, 426
pRegTransLayerInfoEvt, 426
pRegTransNWRegInfoEvt, 426
sms_getMsgWaitingInfo, 426
msgWaitInfo, 427
numInstances, 427
sms_getTransLayerInfo, 427
pRegInd, 427
pTransLayerInfo, 427
sms_getTransNWRegInfo, 428
pRegStatus, 428
sms_maxStorageSizeReq, 428
pMessageMode, 429
storageType, 429
sms_maxStorageSizeResp, 429
freeSlots, 429
maxStorageSize, 429
sms_messageWaitingInfoContent, 429
activeInd, 430
msgCount, 430
msgType, 430
sms_msgProtocolResp, 430
msgProtocol, 430
sms_qaQmi3GPP2BroadcastCfgInfo, 430
activated_ind, 431
CDMABroadcastConfig, 431
num_instances, 431
sms_qaQmi3GPPBroadcastCfgInfo, 431
activated_ind, 432
broadcastConfig, 432
num_instances, 432
sms_routeEntry, 432
messageClass, 433
messageType, 433
receiptAction, 433
routeStorage, 433
sms_sendAsyncsmsParams, 433
messageFormat, 435
messageSize, 435
pFollowOnDC, 435
pForceOnDC, 435
pLinktimer, 435
pMessage, 435
pRetryMessage, 435
pRetryMessageId, 435
pServiceOption, 435
pSmsOnIms, 435
pUserData, 435
sms_setIndicationReg, 435
pRegCallStatInfoEvt, 436
pRegTransLayerInfoEvt, 436
pRegTransNWRegInfoEvt, 436
sms_setRoutesReq, 436
numOfRoutes, 437
pTransferStatusReport, 437
routeList, 437
sms_transLayerInfo, 437
TransCap, 437
TransType, 437

smsOnIMS
sMSOnIMSInfo, 441
SmsServiceRat
unpack_imsa_SLQSGetIMSAServiceStatus_t, 537
SmsServiceStatus
unpack_imsa_SLQSGetIMSAServiceStatus_t, 537
smsStorage
pack_sms_SLQSSetSmsStorage_t, 333
snr
loc_satelliteInfo, 101
lteSSInfo, 105
nas_SccRxInfo, 195
snrlevel
nas_lteSnrinformation, 158
soMask
qmiWDSDataBearerTechnology, 416
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
Source
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
source
altSrcInfo_t, 31
unpack_dms_GetNetworkTime_t, 493
unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t, 505
unpack_dms_SLQSDmsSwiGetResetInfo_t, 506
sourceIPMask
LibPackTFTIDParams, 88
SourceLength
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
spc
pack_dms_ResetToFactoryDefaults_t, 246
pack_nas_SetACCOLC_t, 285
pack_wds_SetMobileIPProfile_t, 395
spn
nas_serviceProviderName, 196
unpack_nas_SLQSGetPLMNName_t, 580
spnEncoding
unpack_nas_SLQSGetPLMNName_t, 580
spnLength
nas_serviceProviderName, 196
unpack_nas_SLQSGetPLMNName_t, 580
srcPortRangeEnd
LibPackTFTIDParams, 88
srcPortRangeStart
LibPackTFTIDParams, 88
srvCapability
nas_detailSvcInfo, 126
nas_sysInfoCommon, 204
srvCapabilityValid
nas_sysInfoCommon, 204
srvDomain
nas_sysInfoCommon, 204
SrvDomainPref
NASServDomainPrefTlv, 233
srvDomainValid
nas_sysInfoCommon, 204
srvOption
voice_arrSvcOption, 773
srvStatus
nas_detailSvcInfo, 126
nas_GSMSrvStatusInfo, 135
nas_SrvStatusInfo, 202
srxlev
nas_cellParams, 118
nas_gsmCellInfo, 134
nas_umtsLTENbrCell, 214
nas_wcdmaCellInfo, 216
stage
uim_refreshevent, 463
State
nas_NetworkStat1x, 168
nas_NetworkStatEVDO, 170
state
pack_loc_SLQSLOCSetCradleMountConfig_t, 282
unpack_dms_GetActivationState_t, 476
unpack_dms_SLQSUIMGetState_t, 519
unpack_omaDmConfigTlv_t, 613
unpack_omaDmFotaTlv_t, 615
unpack_qos_QosFlowInfoState_t, 633
statmask
pack_wds_GetPacketStatus_t, 388
StatsMask
wds_transferStatInd, 813
statsMask
wds_TrStatInd, 814
StatsPeriod
wds_transferStatInd, 813
statsPeriod
wds_TrStatInd, 814
Status
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
status
nas_lteEARFCN, 146
nas_ltePCI, 154
nas_wcdmaUARFCN, 222
pack_sms_SetNewSMSCallback_t, 327
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_DeleteAssistData_Ind_t, 544
unpack_loc_SetExtPowerConfig_Ind_t, 555
unpack_loc_SetOperationMode_Ind_t, 557
unpack_qos_SLQSSetQosNWStatusCallback_ind_t, 637
unpack_qos_SLQSSetQosStatusCallback_ind_t, 639
storageIndex
FMSImageIdElement, 57
storageType
pack_sms_SaveSMS_t, 326
pack_sms_SLQSDeleteSMS_t, 328
pack_sms_SLQSGetSMS_t, 329
pack_sms_SLQSGetSMSList_t, 330
pack_sms_SLQSModifySMSStatus_t, 331

sms_maxStorageSizeReq, 429
sMSMTMessageInfo, 441
unpack_sms_SLQSWmsMemoryFullCallBack_ind_t, 659
Streaming Download Protocol (lite-fw), 26
String
unpack_dms_GetDeviceHardwareRev_t, 484
unpack_dms_GetDeviceMfr_t, 485
unpack_dms_GetFSN_t, 491
unpack_dms_UIMGetICCID_t, 520
stringSize
unpack_dms_GetDeviceHardwareRev_t, 484
unpack_dms_GetDeviceMfr_t, 485
unpack_dms_UIMGetICCID_t, 520
subAddr
voice_calledPartySubAdd, 775
subAddrLen
voice_calledPartySubAdd, 775
subAddrType
voice_calledPartySubAdd, 776
subnetMask
unpack_qos_IPv4Addr_t, 629
SubnetMaskV4
unpack_wds_SLQSGetRuntimeSettings_t, 745
subsType
pack_voice_SLQSVoiceBindSubscription_t, 368
SupUSBComps
unpack_dms_GetUSBComp_t, 499
SuppOA
voice_CUGInfo, 787
SuppPrefCUG
voice_CUGInfo, 787
svInfoMask
loc_satelliteInfo, 101
svListLen
loc_satelliteInfo, 101
svStatus
loc_satelliteInfo, 101
svc
pack_qmi_t, 322
SvcClass
voice_callFWExtInfo, 778
voice_callFWInfo, 779
SvcStatus
voice_callFWExtInfo, 778
voice_callFWInfo, 779
svcType
voice_ccSUPSType, 781
sw1
uim_cardResult, 451
sw2
uim_cardResult, 451
swVerString
pack_dms_SLQSSwiSetHostDevInfo_t, 254
unpack_dms_SLQSSwiGetHostDevInfo_t, 516
SwiDataTypes.h, 1099
BOOL, 1100
BYTE, 1100
CHAR, 1100
FLOAT, 1100
INT32, 1100
INT8, 1100
LPCSTR, 1100
SHORT, 1100
SWI_API, 1099
ULONG, 1100
ULONGLONG, 1100
UNUSEDPARAM, 1099
USHORT, 1100
WORD, 1100
swiaudio.h, 1079
pack_swiaudio_SLQSGetM2MAVMute, 1081
pack_swiaudio_SLQSGetM2MAudioProfile, 1081
pack_swiaudio_SLQSGetM2MAudioVolume, 1081
pack_swiaudio_SLQSGetM2MSpkrGain, 1082
pack_swiaudio_SLQSSetM2MAVMute, 1084
pack_swiaudio_SLQSSetM2MAudioAVCFG, 1082
pack_swiaudio_SLQSSetM2MAudioLPBK, 1082
pack_swiaudio_SLQSSetM2MAudioNVDef, 1083
pack_swiaudio_SLQSSetM2MAudioProfile, 1083
pack_swiaudio_SLQSSetM2MAudioVolume, 1083
pack_swiaudio_SLQSSetM2MSpkrGain, 1084
unpack_swiaudio_SLQSGetM2MAVMute, 1085
unpack_swiaudio_SLQSGetM2MAudioProfile, 1085
unpack_swiaudio_SLQSGetM2MAudioVolume, 1085
unpack_swiaudio_SLQSGetM2MSpkrGain, 1086
unpack_swiaudio_SLQSSetM2MAVMute, 1088
unpack_swiaudio_SLQSSetM2MAudioAVCFG, 1086
unpack_swiaudio_SLQSSetM2MAudioLPBK, 1086
unpack_swiaudio_SLQSSetM2MAudioNVDef, 1087
unpack_swiaudio_SLQSSetM2MAudioProfile, 1087
unpack_swiaudio_SLQSSetM2MAudioVolume, 1087
unpack_swiaudio_SLQSSetM2MSpkrGain, 1088
swiaudio_PCMparams, 443
iFaceTab, 443
iFaceTabLen, 443
swiavms.h, 1088
pack_swiavms_SLQSAVMSGetSettings, 1090
pack_swiavms_SLQSAVMSSendSelection, 1091
pack_swiavms_SLQSAVMSSessionGetInfo, 1091
pack_swiavms_SLQSAVMSSetSettings, 1092
pack_swiavms_SLQSAVMSSetSettingsNoAutoRebootField, 1093
pack_swiavms_SLQSAVMSStartSession, 1094
pack_swiavms_SLQSAVMSStopSession, 1094
pack_swiavms_SLQSAvmsSetEventReport, 1092
unpack_swiavms_SLQSAVMSEventReportInd, 1095
unpack_swiavms_SLQSAVMSGetSettings, 1095

unpack_swiavms_SLQSAVMSSendSelection, 1096
unpack_swiavms_SLQSAVMSSessionGetInfo, 1096
unpack_swiavms_SLQSAVMSSetSettings, 1097
unpack_swiavms_SLQSAVMSStartSession, 1098
unpack_swiavms_SLQSAVMSStopSession, 1098
unpack_swiavms_SLQSAvmsSetEventReport, 1097
swiloc.h, 1100
pack_swiloc_SwiLocGetAutoStart, 1100
pack_swiloc_SwiLocSetAutoStart, 1101
unpack_swiloc_SwiLocGetAutoStart, 1101
unpack_swiloc_SwiLocSetAutoStart, 1101
swioma.h, 1102
pack_swioma_SLQSOMADMAlertCallback, 1103
pack_swioma_SLQSOMADMCancelSession, 1103
pack_swioma_SLQSOMADMGetSessionInfo, 1104
pack_swioma_SLQSOMADMGetSettings, 1105
pack_swioma_SLQSOMADMSendSelection, 1105
pack_swioma_SLQSOMADMSetSettings, 1106
pack_swioma_SLQSOMADMStartSession, 1107
unpack_swioma_SLQSOMADMAlertCallback, 1107
unpack_swioma_SLQSOMADMAlertCallback_ind, 1108
unpack_swioma_SLQSOMADMCancelSession, 1108
unpack_swioma_SLQSOMADMGetSessionInfo, 1109
unpack_swioma_SLQSOMADMGetSettings, 1109
unpack_swioma_SLQSOMADMSendSelection, 1109
unpack_swioma_SLQSOMADMSetSettings, 1110
unpack_swioma_SLQSOMADMStartSession, 1110
swiomaext.h, 1111
pack_swioma_SLQSOMADMCancelSessionExt, 1111
pack_swioma_SLQSOMADMSendSelectionExt, 1112
pack_swioma_SLQSOMADMSetSettingsExt, 1113
pack_swioma_SLQSOMADMStartSessionExt, 1113
unpack_swioma_SLQSOMADMCancelSessionExt, 1114
unpack_swioma_SLQSOMADMSendSelectionExt, 1114
unpack_swioma_SLQSOMADMSetSettingsExt, 1115
unpack_swioma_SLQSOMADMStartSessionExt, 1115
switchOption
pack_voice_SLQSVoiceALSSetLineSwitching_t, 367
sysInfoCDMA
nas_CDMASysInfo, 116
sysInfoGSM
nas_GSMSysInfo, 138
sysInfoHDR
nas_HDRSysInfo, 143
sysInfoLTE
nas_LTESysInfo, 162
sysInfoWCDMA
nas_WCDMASysInfo, 221
system
loc_satelliteInfo, 101
loc_SV, 103
systemDiscontinuities
pack_pds_PDSInjectTimeReference_t, 310
SystemID
unpack_nas_SLQSGetServingSystem_t, 584
systemID
nas_CDMASysInfo, 116
systemMode
nas_CommInfo, 120
systemTime
pack_pds_PDSInjectTimeReference_t, 310
szAPN
PackSwiAvmsSetSettingsAPNInfo, 412
szAlertMsg
UnpackSwiAvmsEventReportConfig, 757
szCarrier_str
_litefw_FirmwareInfo_, 29
szCarrierPriversion_str
_litefw_FirmwareInfo_, 30
szDescription
UnpackSwiAvmsEventReportBinaryUpdateSessionInfo, 756
szFwversion_str
_litefw_FirmwareInfo_, 30
szModelid_str
_litefw_FirmwareInfo_, 30
szName
UnpackSwiAvmsEventReportBinaryUpdateSessionInfo, 756
szPWD
PackSwiAvmsSetSettingsAPNInfo, 412
szPackageid_str
_litefw_FirmwareInfo_, 30
szSku_str
_litefw_FirmwareInfo_, 30
szUname
PackSwiAvmsSetSettingsAPNInfo, 412
szVersion
UnpackSwiAvmsEventReportBinaryUpdateSessionInfo, 756

t3396_apn
unpack_nas_SLQSNasTimerCallback_ind_t, 604
t3396_plmn_id
unpack_nas_SLQSNasTimerCallback_ind_t, 604
t3396_val
unpack_nas_SLQSNasTimerCallback_ind_t, 604
TCPDstPort
unpack_qos_swiQosFilter_t, 642

TCPSrcPort
unpack_qos_swiQosFilter_t, 642
TDSCDMAECIOThreshListLen
nas_TDSCDMAECIOThresh, 205
TDSCDMARSCPThreshListLen
nas_TDSCDMARSCPThresh, 205
TDSCDMARSSIThreshListLen
nas_TDSCDMARSSIThresh, 206
TDSCDMASINRThreshListLen
nas_TDSCDMASINRThresh, 207
TMD_MAX_DEV_LIST
tmd.h, 1116
TRMessageTlv
unpack_sms_SetNewSMSCallback_ind_t, 653
TX_PWR
nas_NetworkStat1x, 168
TXChan
nas_LTEInfo, 149
tXDroppedCount
unpack_wds_GetPacketStatus_t, 732
tXOKBytesLastCall
unpack_wds_GetPacketStatus_t, 732
tXOkBytesCount
unpack_wds_GetPacketStatus_t, 732
tXPacketErrors
unpack_wds_GetPacketStatus_t, 732
tXPacketOverflows
unpack_wds_GetPacketStatus_t, 732
tXPacketSuccesses
unpack_wds_GetPacketStatus_t, 732
Tables, 27
tac
nas_LTEInfoIntrafreq, 152
nas_LTESysInfo, 162
tacValid
nas_LTESysInfo, 162
TdsBandCapability
unpack_dms_SLQSGetBandCapability_t, 510
tdscdmaSigInfoExt, 443
ecio, 444
rscp, 444
rssi, 444
sinr, 444
techName
unpack_wds_SLQSSetPacketSrvStatusCallback_-t, 747
Technology
nas_DeviceConfigDetail, 127
unpack_wds_SLQSGetRuntimeSettings_t, 745
TechnologyPref
pack_nas_SetNetworkPreference_t, 287
tempData_t, 444
temperature, 445
temperatureDataLen, 445
timeOfFirstSample, 445
timeOffset, 445
timeSource, 445
temperature
nas_CommInfo, 120
tempData_t, 445
temperatureDataLen
tempData_t, 445
threshGsmHigh
nas_lteGsmCellInfo, 147
threshGsmLow
nas_lteGsmCellInfo, 147
threshServingLow
nas_LTEInfoIntrafreq, 152
threshXHigh
nas_infoInterFreq, 144
threshXLow
nas_infoInterFreq, 145
threshXhigh
nas_lteWcdmaCellInfo, 163
threshXlow
nas_lteWcdmaCellInfo, 163
Time
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
time
NASTimeInfoTlv, 235
Time_uncert_ms
unpack_pds_SLQSGetGPSStateInfo_t, 627
timeBase
pack_pds_SLQSPDSInjectAbsoluteTimeReference-_t, 316
TimeLength
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
timeMsec
pack_loc_SLQSLOCInjectUTCTime_t, 281
pack_pds_SLQSPDSInjectAbsoluteTimeReference-_t, 316
timeOfFirstSample
sensorData_t, 421
tempData_t, 445
timeOffset
sensorData_t, 421
tempData_t, 445
timeSource
tempData_t, 445
TimeStmp_gps_week
unpack_pds_SLQSGetGPSStateInfo_t, 627
TimeStmp_tow_ms
unpack_pds_SLQSGetGPSStateInfo_t, 627
timeTlv
NASQmiCbkNasSwiOTAMessageInd, 231
timeUncMsec
pack_loc_SLQSLOCInjectUTCTime_t, 281
pack_pds_SLQSPDSInjectAbsoluteTimeReference-_t, 316
timeZone
nas_timeInfo, 209
timeout
pack_pds_SetPDSDefaults_t, 313
pack_qmi_t, 322

Timers
PackSwiAvmsSetSettingsConnectionRetryTimers, 412
PackSwiAVMSSettingsConnectionRetryTimers, 414
timestamp
unpack_dms_GetNetworkTime_t, 493
timestampAge
pack_loc_SLQSLOCInjectPosition_t, 279
timestampUtc
pack_loc_SLQSLOCInjectPosition_t, 279
timingAdvance
nas_GERANInfo, 132
TlvPresent
cat_commonEventTlv, 42
dms_ActivationStatusTlv, 50
dms_OperatingModeTlv, 51
eTWSPLMNInfoTlv, 55
loc_IPv4Info, 97
loc_IPv6Info, 97
loc_urlAddr, 104
messageModeTlv, 106
nas_PhyCaAggPcellInfo, 174
nas_PhyCaAggScellDlBw, 174
nas_PhyCaAggScellIndex, 175
nas_PhyCaAggScellIndType, 175
nas_PhyCaAggScellInfo, 178
nas_RejectReasonTlv, 187
nas_RFInfoTlv, 188
nas_SccRxInfo, 195
nas_SignalStrengthTlv, 198
nas_SLQSSignalStrengthsTlv, 201
nas_timeInfo, 209
NASBandPreferenceTlv, 222
NASEmergencyModeTlv, 222
NASGWAcqOrderPrefTlv, 224
NASLTEBandPreferenceTlv, 224
NASLteNasReleaseInfoTlv, 225
NASModePreferenceTlv, 225
NASNetSelPreferenceTlv, 226
NASOTAMessageTlv, 227
NASPhyCaAggPcellInfo, 227
NASPhyCaAggScellDlBw, 228
NASPhyCaAggScellIndex, 228
NASPhyCaAggScellIndType, 229
NASPhyCaAggScellInfo, 230
NASPRLPreferenceTlv, 231
NASRoamPreferenceTlv, 233
NASServDomainPrefTlv, 233
NASTimeInfoTlv, 235
newMTMessageTlv, 236
sMSCAddressTlv, 438
sMSEtwsMessageTlv, 440
sMSOnIMSTlv, 442
transferRouteMessageTlv, 446
unpack_pds_SetPdsState_Ind_t, 623
UnpackSwiAvmsEventReportBinaryUpdateSessionInfo, 756
UnpackSwiAvmsEventReportConfig, 757
UnpackSwiAvmsEventReportConnectionRequest, 758
UnpackSwiAvmsEventReportDataSessionStatus, 758
UnpackSwiAvmsEventReportHTTPStatus, 759
UnpackSwiAvmsEventReportNotification, 761
UnpackSwiAvmsEventReportPackageID, 761
UnpackSwiAvmsEventReportRegStatus, 761
UnpackSwiAvmsEventReportSessionType, 762
UnpackSwiAvmsEventReportWAMSParamChange, 763
wds_DataULongLongTlv, 801
wds_DataULongTlv, 802
wds_DHCPLeaseOptTlv, 803
wds_DHCPLeaseStateTlv, 803
wds_DHCPProfileIdTlv, 804
wds_IPv4AdTlv, 809
Tlvresult
pack_dms_GetCustFeaturesV2_t, 245
pack_dms_SetCustFeaturesV2_t, 250
pack_dms_SetPower_t, 251
pack_dms_SetUSBComp_t, 252
pack_dms_UIMGetICCID_t, 256
pack_fms_GetImagesPreference_t, 259
pack_fms_GetStoredImages_t, 260
pack_fms_SetImagesPreference_t, 261
pack_loc_Delete_Assist_Data_t, 270
pack_loc_EventRegister_t, 272
pack_loc_SetExtPowerState_t, 272
pack_loc_SetOperationMode_t, 273
pack_loc_SLQSLOCGetBestAvailPos_t, 273
pack_loc_Start_t, 284
pack_loc_Stop_t, 284
pack_nas_SetNetworkPreference_t, 288
pack_uim_ChangePin_t, 354
pack_uim_ReadTransparent_t, 355
pack_uim_SetPinProtection_t, 356
pack_uim_UnblockPin_t, 364
pack_uim_VerifyPin_t, 365
unpack_cat_SetCATEventCallback_t, 475
unpack_dms_GetBandCapability_t, 478
unpack_dms_GetCrashAction_t, 478
unpack_dms_GetCustFeature_t, 481
unpack_dms_GetCustFeaturesV2_t, 481
unpack_dms_GetDeviceCap_t, 482
unpack_dms_GetDeviceHardwareRev_t, 484
unpack_dms_GetDeviceMfr_t, 485
unpack_dms_GetDeviceSerialNumbers_t, 486
unpack_dms_GetFirmwareInfo_t, 488
unpack_dms_GetFirmwareRevision_t, 489
unpack_dms_GetFirmwareRevisions_t, 490
unpack_dms_GetFSN_t, 491
unpack_dms_GetIMSI_t, 491
unpack_dms_GetManufacturer_t, 492
unpack_dms_GetModelID_t, 492
unpack_dms_GetNetworkTime_t, 493
unpack_dms_GetOfflineReason_t, 494

unpack_dms_GetPower_t, 495
unpack_dms_GetPRLVersion_t, 496
unpack_dms_GetUSBComp_t, 499
unpack_dms_GetVoiceNumber_t, 500
unpack_dms_ResetToFactoryDefaults_t, 501
unpack_dms_SetActivationStatusCallback_t, 501
unpack_dms_SetCustFeature_t, 502
unpack_dms_SetCustFeaturesV2_t, 502
unpack_dms_SetEventReport_ind_t, 503
unpack_dms_SetEventReport_t, 503
unpack_dms_SetFirmwarePreference_t, 503
unpack_dms_SetPower_t, 504
unpack_dms_SetUSBComp_t, 504
unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t, 505
unpack_dms_SLQSDmsSwiGetResetInfo_t, 506
unpack_dms_SLQSDmsSwiIndicationRegister_t, 507
unpack_dms_SLQSGetERIFile_t, 510
unpack_dms_SLQSSwiClearDyingGaspStatistics_t, 511
unpack_dms_SLQSSwiGetCrashInfo_t, 511
unpack_dms_SLQSSwiGetDyingGaspCfg_t, 512
unpack_dms_SLQSSwiGetDyingGaspStatistics_t, 512
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 515
unpack_dms_SLQSSwiGetHostDevInfo_t, 516
unpack_dms_SLQSSwiGetOSInfo_t, 517
unpack_dms_SLQSSwiGetSerialNoExt_t, 517
unpack_dms_SLQSSwiSetDyingGaspCfg_t, 517
unpack_dms_SLQSSwiSetHostDevInfo_t, 518
unpack_dms_SLQSSwiSetOSInfo_t, 518
unpack_dms_SLQSUIMGetState_t, 519
unpack_dms_UIMGetControlKeyStatus_t, 520
unpack_dms_UIMGetICCID_t, 520
unpack_dms_UIMGetPINStatus_t, 522
unpack_dms_UIMSetControlKeyProtection_t, 522
unpack_dms_UIMSetPINProtection_t, 523
unpack_dms_UIMUnblockControlKey_t, 524
unpack_fms_GetImagesPreference_t, 524
unpack_fms_GetStoredImages_t, 525
unpack_fms_SetImagesPreference_t, 525
unpack_loc_BestAvailPos_Ind_t, 543
unpack_loc_Delete_Assist_Data_t, 544
unpack_loc_DeleteAssistData_Ind_t, 544
unpack_loc_EngineState_Ind_t, 545
unpack_loc_EventNMEA_Ind_t, 546
unpack_loc_EventRegister_t, 546
unpack_loc_GetServer_Ind_t, 547
unpack_loc_GnssSvInfo_Ind_t, 548
unpack_loc_PositionRpt_Ind_t, 555
unpack_loc_SetExtPowerConfig_Ind_t, 555
unpack_loc_SetExtPowerState_t, 556
unpack_loc_SetOperationMode_Ind_t, 557
unpack_loc_SetOperationMode_t, 557
unpack_loc_SLQSLOCGetBestAvailPos_t, 557
unpack_loc_Start_t, 558
unpack_loc_Stop_t, 558
unpack_nas_GetNetworkPreference_t, 565
unpack_nas_SetNetworkPreference_t, 573
unpack_nas_SetServingSystemCallback_ind_t, 574
unpack_nas_SlqsGetLTECphyCAInfo_t, 576
unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t, 603
unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t, 604
unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t, 676
unpack_tmd_SLQSTmdGetMitigationDevList_t, 676
unpack_tmd_SLQSTmdGetMitigationLvl_t, 677
unpack_tmd_SLQSTmdRegNotMitigationLvl_t, 678
unpack_uim_ChangePin_t, 679
unpack_uim_GetCardStatus_t, 679
unpack_uim_ReadTransparent_t, 680
unpack_uim_SetPinProtection_t, 681
unpack_uim_UnblockPin_t, 687
unpack_uim_VerifyPin_t, 688
unpack_wds_SLQSCreateProfile_t, 734
unpack_wds_SLQSGetProfileSettings_t, 742
unpack_wds_SLQSSetIPFamilyPreference_t, 746
tmd.h, 1115
pack_tmd_SLQSTmdDeRegNotMitigationLvl, 1116
pack_tmd_SLQSTmdGetMitigationDevList, 1117
pack_tmd_SLQSTmdGetMitigationLvl, 1117
pack_tmd_SLQSTmdRegNotMitigationLvl, 1117
TMD_MAX_DEV_LIST, 1116
unpack_tmd_SLQSTmdDeRegNotMitigationLvl, 1118
unpack_tmd_SLQSTmdGetMitigationDevList, 1118
unpack_tmd_SLQSTmdGetMitigationLvl, 1119
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind, 1119
unpack_tmd_SLQSTmdRegNotMitigationLvl, 1119
tmd_mitigationDevList, 445
maxMitigationLevel, 445
mitigationDevId, 446
mitigationDevIdLen, 446
toServiceId
sms_BroadcastConfig, 425
TokenBucket
unpack_qos_swiQosFlow_t, 646
tokenRate
unpack_qos_tokenBucket_t, 647
tosMask
LibPackTFTIDParams, 88
total_rx_bytes
unpack_qos_SLQSQosSwiReadDataStats_t, 636
total_rx_pkt
unpack_qos_SLQSQosSwiReadDataStats_t, 636
total_tx_bytes
unpack_qos_SLQSQosSwiReadDataStats_t, 636
total_tx_bytes_drp

unpack_qos_SLQSQosSwiReadDataStats_t, 636
total_tx_pkt
unpack_qos_SLQSQosSwiReadDataStats_t, 636
total_tx_pkt_drp
unpack_qos_SLQSQosSwiReadDataStats_t, 636
TrackAreaCode
unpack_nas_SLQSGetServingSystem_t, 584
TrackingStatus
unpack_pds_SetPdsState_Ind_t, 623
TrafficClass
unpack_qos_swiQosFlow_t, 646
trafficClass
LibPackUMTSQoS, 91
wds_UMTSMinQoS, 816
trafficPriority
LibPackUMTSQoS, 91
wds_UMTSMinQoS, 816
TranDstPort
unpack_qos_swiQosFilter_t, 642
TranSrcPort
unpack_qos_swiQosFilter_t, 642
TransCap
sms_transLayerInfo, 437
TransType
sms_transLayerInfo, 437
transactionID
sMSTransferRouteMTMessageInfo, 443
transferDelay
LibPackUMTSQoS, 91
wds_UMTSMinQoS, 816
TransferRouteMTMessageInfo
transferRouteMessageTlv, 446
transferRouteMessageTlv, 446
TlvPresent, 446
TransferRouteMTMessageInfo, 446
transferStats
pack_wds_SLQSSetWdsEventCallback_t, 404
trueSrvStatus
nas_GSMSrvStatusInfo, 135
tx_bytes
unpack_QosFlowStat_t, 648
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
tx_bytes_drp
unpack_QosFlowStat_t, 648
tx_pkt
unpack_QosFlowStat_t, 648
tx_pkt_drp
unpack_QosFlowStat_t, 648
tx_pkts
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
TxDropConutTlv
unpack_RMTransferStatistics_ind_t, 650
txOKBytesCount
unpack_wds_SLQSGetDUNCallInfo_t, 741
TxOkByteCountTlv
unpack_RMTransferStatistics_ind_t, 650
TxOkConutTlv
unpack_RMTransferStatistics_ind_t, 650
txPower
nas_txInfo, 210
TxQFilter
unpack_qos_QosFlowInfo_t, 632
TxQFlowGranted
unpack_qos_QosFlowInfo_t, 632
type
pack_wds_GetDefaultProfileNum_t, 385
pack_wds_SetDefaultProfileNum_t, 391
unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t, 505
unpack_dms_SLQSDmsSwiGetResetInfo_t, 506
unpack_qmi_t, 628
typeSize
unpack_sms_GetSMSCAddress_t, 651

u16PRLVersion
unpack_dms_GetPRLVersion_t, 496
u8PRLPreference
unpack_dms_GetPRLVersion_t, 496
UDPDstPort
unpack_qos_swiQosFilter_t, 642
UDPSrcPort
unpack_qos_swiQosFilter_t, 642
ULONG
SwiDataTypes.h, 1100
ULONGLONG
SwiDataTypes.h, 1100
UMTSGrantedQoS
unpack_wds_SLQSGetRuntimeSettings_t, 745
UMTSInstInfo
nas_UMTSInfo, 212
UMTSLTENbrCell
nas_WCDMAInfoLTENeighborCell, 217
UMTSReqQoS
LibPackUMTSReqQoSSigInd, 91
UNIQUE_ID_LEN
dms.h, 843
UNUSEDPARAM
common.h, 833
SwiDataTypes.h, 1099
uPhyCardStatus
slot_t, 422
uPhySlotStatus
slot_t, 422
USBComp
pack_dms_SetUSBComp_t, 252
unpack_dms_GetUSBComp_t, 499
USHORT
SwiDataTypes.h, 1100
USSInformation
pack_voice_SLQSVoiceOrigUSSDNoWait_t, 377
UUSData
voice_UUSInfo, 800
UUSDatalen
voice_UUSInfo, 800
UUSDcs

voice_UUSInfo, 800
UUSType
voice_UUSInfo, 800
uarfcn
nas_lteWcdmaCellInfo, 163
nas_UMTSInfo, 212
nas_wcdmaUARFCN, 222
ueInIdle
nas_LTEInfoInterfreq, 150
nas_LTEInfoIntrafreq, 152
nas_LTEInfoNeighboringGSM, 153
nas_LTEInfoNeighboringWCDMA, 154
uim.h, 1120
MAX_ICCID_LENGTH, 1123
MAX_NO_OF_SLOTS, 1123
MAX_SLOTS_STATUS, 1123
pack_uim_ChangePin, 1123
pack_uim_GetCardStatus, 1123
pack_uim_ReadTransparent, 1124
pack_uim_SLQSUIMAuthenticate, 1124
pack_uim_SLQSUIMDepersonalization, 1125
pack_uim_SLQSUIMEventRegister, 1125
pack_uim_SLQSUIMGetConfiguration, 1125
pack_uim_SLQSUIMGetFileAttributes, 1126
pack_uim_SLQSUIMGetSlotsStatus, 1126
pack_uim_SLQSUIMPowerDown, 1127
pack_uim_SLQSUIMPowerUp, 1127
pack_uim_SLQSUIMRefreshComplete, 1127
pack_uim_SLQSUIMRefreshGetLastEvent, 1128
pack_uim_SLQSUIMRefreshOK, 1128
pack_uim_SLQSUIMRefreshRegister, 1128
pack_uim_SLQSUIMReset, 1129
pack_uim_SLQSUIMSwitchSlot, 1129
pack_uim_SetPinProtection, 1124
pack_uim_UnblockPin, 1129
pack_uim_VerifyPin, 1130
unpack_uim_ChangePin, 1130
unpack_uim_GetCardStatus, 1131
unpack_uim_ReadTransparent, 1131
unpack_uim_SLQSUIMAuthenticate, 1132
unpack_uim_SLQSUIMDepersonalization, 1132
unpack_uim_SLQSUIMEventRegister, 1133
unpack_uim_SLQSUIMGetConfiguration, 1133
unpack_uim_SLQSUIMGetFileAttributes, 1133
unpack_uim_SLQSUIMGetSlotsStatus, 1134
unpack_uim_SLQSUIMPowerDown, 1134
unpack_uim_SLQSUIMPowerUp, 1134
unpack_uim_SLQSUIMRefreshComplete, 1135
unpack_uim_SLQSUIMRefreshGetLastEvent, 1135
unpack_uim_SLQSUIMRefreshOK, 1135
unpack_uim_SLQSUIMRefreshRegister, 1136
unpack_uim_SLQSUIMReset, 1136
unpack_uim_SLQSUIMSetStatusChangeCallBack_ind, 1136
unpack_uim_SLQSUIMSwitchSlot, 1137
unpack_uim_SetPinProtection, 1131
unpack_uim_SetUimSlotStatusChangeCallback_ind, 1132
unpack_uim_UnblockPin, 1137
unpack_uim_VerifyPin, 1137
uim_UIMSessionInformation, 468
aid, 469
aidLength, 469
sessionType, 469
uim_appStatus, 446
aidLength, 448
aidVal, 449
appState, 449
appType, 449
persoFeature, 449
persoRetries, 449
persoState, 449
persoUnblockRetries, 449
pin1Retries, 449
pin1State, 449
pin2Retries, 449
pin2State, 449
puk1Retries, 449
puk2Retries, 449
univPin, 449
uim_authenticateResult, 449
content, 449
contentLen, 449
uim_authenticationData, 450
context, 450
data, 450
dataLen, 450
uim_cardResult, 451
sw1, 451
sw2, 451
uim_cardStatus, 451
index1xPri, 452
index1xSec, 452
indexGwPri, 452
indexGwSec, 452
numSlot, 452
SlotInfo, 452
uim_changeUIMPIN, 452
oldPINLen, 453
oldPINVal, 453
pinID, 453
pinLen, 453
pinVal, 453
uim_depersonalizationInformation, 453
ckLen, 454
ckVal, 454
feature, 454
operation, 454
uim_encryptedPIN1, 454
pin1Len, 455
pin1Val, 455
uim_fileAttributes, 455
fileID, 458
fileSize, 458

fileType, 458
rawLen, 458
rawValue, 458
recordCount, 458
recordSize, 458
secActivate, 458
secActivateMask, 458
secDeactivate, 458
secDeactivateMask, 458
secIncrease, 458
secIncreaseMask, 458
secRead, 458
secReadMask, 458
secWrite, 458
secWriteMask, 458
uim_fileInfo, 458
fileID, 459
path, 459
pathLen, 459
uim_hotSwapStatus, 459
hotSwap, 459
hotSwapLength, 459
uim_personalizationStatus, 459
feature, 460
numFeatures, 460
unblockLeft, 460
verifyLeft, 460
uim_readResult, 460
content, 461
contentLen, 461
uim_readTransparentInfo, 461
length, 461
offset, 461
uim_refreshevent, 461
aid, 463
aidLength, 463
arrfileInfo, 463
mode, 463
numOfFiles, 463
sessionType, 463
stage, 463
uim_registerRefresh, 463
arrfileInfo, 464
numFiles, 464
registerFlag, 464
voteForInit, 464
uim_remainingRetries, 464
unblockLeft, 464
verifyLeft, 464
uim_sessionInformation, 465
aid, 465
aidLength, 465
sessionType, 465
uim_setPINProtection, 465
pinID, 466
pinLength, 466
pinOperation, 466
pinValue, 466
uim_slotInfo, 466
AppStatus, 468
cardState, 468
errorState, 468
numApp, 468
upinRetries, 468
upinState, 468
upukRetries, 468
uim_unblockUIMPIN, 469
newPINLen, 469
newPINVal, 469
pinID, 469
pukLen, 469
pukVal, 470
uim_verifyUIMPIN, 470
pinID, 470
pinLen, 470
pinVal, 470
uimSlotStatus
slots_t, 424
ulData
wds_DataULongTlv, 802
ulMask
rmTrasnferStaticsReq, 419
ulMax
PackSwiAvmsSetSettingsPeriodInfo, 413
ulMin
PackSwiAvmsSetSettingsPeriodInfo, 413
ulPhysicalSlot
pack_uim_SLQSUIMSwitchSlot_t, 363
ulPkgDownloadComplete
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 756
ulPkgDownloadSize
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 756
ullData
wds_DataULongLongTlv, 802
umtsEcio
nas_UMTSinstInfo, 213
umtsInst
nas_UMTSInfo, 212
umtsLTENbrCellLen
nas_WCDMAInfoLTENeighborCell, 217
umtsPsc
nas_UMTSinstInfo, 213
umtsRscp
nas_UMTSinstInfo, 213
umtsUarfcn
nas_UMTSinstInfo, 213
UnPackGetProfileSettingOut, 754
curProfile, 754
pExtErrCode, 754
unblockLeft
uim_personalizationStatus, 460
uim_remainingRetries, 464
unblockRetriesLeft
unpack_dms_UIMGetControlKeyStatus_t, 520

unpack_dms_UIMSetPINProtection_t, 523
unpack_dms_UIMUnblockControlKey_t, 524
uniqueID
image_info_t, 60
univPin
appStats, 34
uim_appStatus, 449
universalTime
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t, 600
unpack_QosFlowStat_t, 648
bearerId, 648
tx_bytes, 648
tx_bytes_drp, 648
tx_pkt, 648
tx_pkt_drp, 648
unpack_RMTransferStatistics_ind_t, 649
RxDropConutTlv, 650
RxOkByteCountTlv, 650
RxOkConutTlv, 650
TxDropConutTlv, 650
TxOkByteCountTlv, 650
TxOkConutTlv, 650
unpack_audio_SLQSGetAudioPathConfig
audio.h, 825
unpack_audio_SLQSGetAudioPathConfig_t, 470
pCodecSTGain, 472
pECMode, 472
pMICGainSelect, 472
pNSEnable, 472
pRXAGCList, 472
pRXAVCList, 472
pTXAGCList, 472
pTXAVCSwitch, 472
pTXGain, 472
unpack_audio_SLQSGetAudioProfile
audio.h, 825
unpack_audio_SLQSGetAudioProfile_t, 472
EarMute, 473
MicMute, 473
Profile, 473
Volume, 473
unpack_audio_SLQSGetAudioVolTLBConfig
audio.h, 825
unpack_audio_SLQSGetAudioVolTLBConfig_t, 473
ResCode, 474
unpack_audio_SLQSSetAudioPathConfig
audio.h, 826
unpack_audio_SLQSSetAudioProfile
audio.h, 826
unpack_audio_SLQSSetAudioVolTLBConfig
audio.h, 826
unpack_audio_SLQSSetAudioVolTLBConfig_t, 474
ResCode, 474
unpack_cat_CATSendEnvelopeCommand
cat.h, 829
unpack_cat_CATSendTerminalResponse
cat.h, 829
unpack_cat_SetCATEventCallback
cat.h, 829
unpack_cat_SetCATEventCallback_t, 475
errorMask, 475
Tlvresult, 475
unpack_cat_SetCatEventCallback_ind
cat.h, 830
unpack_cat_SetCatEventCallback_ind_t, 474
CCETlv, 474
event_Index, 475
unpack_dms_ActivateAutomatic
dms.h, 865
unpack_dms_GetActivationState
dms.h, 866
unpack_dms_GetActivationState_t, 475
state, 476
unpack_dms_GetBandCapability
dms.h, 866
unpack_dms_GetBandCapability_t, 476
BandCapability, 478
Tlvresult, 478
unpack_dms_GetCrashAction
dms.h, 866
unpack_dms_GetCrashAction_t, 478
DevCrashState, 478
Tlvresult, 478
unpack_dms_GetCustFeature
dms.h, 867
unpack_dms_GetCustFeature_t, 478
DHCPRelayEnabled, 480
DisableIMSI, 480
GPSLPM, 480
GPSSel, 480
GpsEnable, 480
IPFamSupport, 480
IsVoiceEnabled, 480
RMAutoConnect, 481
SMSSupport, 481
Tlvresult, 481
unpack_dms_GetCustFeaturesV2
dms.h, 867
unpack_dms_GetCustFeaturesV2_t, 481
GetCustomFeatureV2, 481
Tlvresult, 481
unpack_dms_GetDeviceCap
dms.h, 867
unpack_dms_GetDeviceCap_t, 481
DataServiceCapability, 482
MaxRXChannelRate, 482
MaxTXChannelRate, 482
RadioIfaces, 482
RadioIfacesSize, 482
SimCapability, 482
Tlvresult, 482
unpack_dms_GetDeviceCapabilities
dms.h, 868
unpack_dms_GetDeviceCapabilities_t, 482
dataServiceCaCapability, 483

maxRxChannelRate, 483
maxTxChannelRate, 483
RadioIfaces, 484
radioIfacesSize, 484
simCapability, 484
unpack_dms_GetDeviceHardwareRev
dms.h, 868
unpack_dms_GetDeviceHardwareRev_t, 484
String, 484
stringSize, 484
Tlvresult, 484
unpack_dms_GetDeviceMfr
dms.h, 868
unpack_dms_GetDeviceMfr_t, 484
String, 485
stringSize, 485
Tlvresult, 485
unpack_dms_GetDeviceSerialNumbers
dms.h, 869
unpack_dms_GetDeviceSerialNumbers_t, 485
ESNString, 486
esnSize, 486
IMEIString, 486
imeiSize, 486
imeiSvnSize, 486
ImeiSvnString, 486
MEIDString, 486
meidSize, 486
Tlvresult, 486
unpack_dms_GetFSN
dms.h, 870
unpack_dms_GetFSN_t, 490
String, 491
Tlvresult, 491
unpack_dms_GetFirmwareInfo
dms.h, 869
unpack_dms_GetFirmwareInfo_t, 486
appversion_str, 488
bootversion_str, 488
carrier_str, 488
cur_carr_name, 488
cur_carr_rev, 488
modelid_str, 488
packageid_str, 488
priversion_str, 488
sku_str, 488
Tlvresult, 488
unpack_dms_GetFirmwareRevision
dms.h, 869
unpack_dms_GetFirmwareRevision_t, 488
AMSSString, 489
amssSize, 489
PRIString, 489
Tlvresult, 489
unpack_dms_GetFirmwareRevisions
dms.h, 870
unpack_dms_GetFirmwareRevisions_t, 489
AMSSString, 490
amssSize, 490
bootSize, 490
BootString, 490
PRIString, 490
priSize, 490
Tlvresult, 490
unpack_dms_GetHardwareRevision
dms.h, 870
unpack_dms_GetHardwareRevision_t, 491
hwVer, 491
unpack_dms_GetIMSI
dms.h, 871
unpack_dms_GetIMSI_t, 491
imsi, 491
Tlvresult, 491
unpack_dms_GetManufacturer
dms.h, 871
unpack_dms_GetManufacturer_t, 492
manufacturer, 492
Tlvresult, 492
unpack_dms_GetModelID
dms.h, 871
unpack_dms_GetModelID_t, 492
modelid, 492
Tlvresult, 492
unpack_dms_GetNetworkTime
dms.h, 872
unpack_dms_GetNetworkTime_t, 493
source, 493
timestamp, 493
Tlvresult, 493
unpack_dms_GetOfflineReason
dms.h, 872
unpack_dms_GetOfflineReason_t, 493
pReasonMask, 494
pbPlatform, 494
Tlvresult, 494
unpack_dms_GetPRLVersion
dms.h, 873
unpack_dms_GetPRLVersion_t, 496
Tlvresult, 496
u16PRLVersion, 496
u8PRLPreference, 496
unpack_dms_GetPower
dms.h, 872
unpack_dms_GetPower_t, 494
HardwareControlledMode, 495
OfflineReason, 495
OperationMode, 495
Tlvresult, 495
unpack_dms_GetSerialNumbers
dms.h, 873
unpack_dms_GetSerialNumbers_t, 496
esn, 497
imei_no, 497
imeisv_svn, 497
meid, 497
unpack_dms_GetUSBComp

dms.h, 873
unpack_dms_GetUSBComp_t, 497
NumSupUSBComps, 499
SupUSBComps, 499
Tlvresult, 499
USBComp, 499
unpack_dms_GetVoiceNumber
dms.h, 874
unpack_dms_GetVoiceNumber_t, 499
MIN, 500
minSize, 500
Tlvresult, 500
VoiceNumber, 500
voiceNumberSize, 500
unpack_dms_ResetToFactoryDefaults
dms.h, 874
unpack_dms_ResetToFactoryDefaults_t, 500
Tlvresult, 501
unpack_dms_SLQSDmsSwiGetResetInfo
dms.h, 878
unpack_dms_SLQSDmsSwiGetResetInfo_Ind
dms.h, 878
unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t, 504
source, 505
Tlvresult, 505
type, 505
unpack_dms_SLQSDmsSwiGetResetInfo_t, 505
source, 506
Tlvresult, 506
type, 506
unpack_dms_SLQSDmsSwiIndicationRegister
dms.h, 878
unpack_dms_SLQSDmsSwiIndicationRegister_t, 506
Tlvresult, 507
unpack_dms_SLQSGetBandCapability
dms.h, 879
unpack_dms_SLQSGetBandCapability_t, 507
bandCapability, 510
LteBandCapability, 510
TdsBandCapability, 510
unpack_dms_SLQSGetERIFile
dms.h, 879
unpack_dms_SLQSGetERIFile_t, 510
eriFile, 510
Tlvresult, 510
unpack_dms_SLQSSwiClearDyingGaspStatistics
dms.h, 879
unpack_dms_SLQSSwiClearDyingGaspStatistics_t, 510
Tlvresult, 511
unpack_dms_SLQSSwiGetCrashInfo
dms.h, 880
unpack_dms_SLQSSwiGetCrashInfo_t, 511
crashInfoParam, 511
Tlvresult, 511
unpack_dms_SLQSSwiGetDyingGaspCfg
dms.h, 880
unpack_dms_SLQSSwiGetDyingGaspCfg_t, 511
pGetDyingGaspCfg, 512
Tlvresult, 512
unpack_dms_SLQSSwiGetDyingGaspStatistics
dms.h, 880
unpack_dms_SLQSSwiGetDyingGaspStatistics_t, 512
pGetDyingGaspStatistics, 512
Tlvresult, 512
unpack_dms_SLQSSwiGetFirmwareCurr
dms.h, 881
unpack_dms_SLQSSwiGetFirmwareCurr_t, 512
carrier, 513
fwvers, 513
numEntries, 513
pCurrImgInfo, 513
pkgver, 513
priver, 513
unpack_dms_SLQSSwiGetFwUpdateStatus
dms.h, 881
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 514
imgType, 515
logString, 515
refData, 515
refString, 515
ResCode, 515
Tlvresult, 515
unpack_dms_SLQSSwiGetHostDevInfo
dms.h, 882
unpack_dms_SLQSSwiGetHostDevInfo_t, 515
manString, 516
modelString, 516
plasmaIDString, 516
swVerString, 516
Tlvresult, 516
unpack_dms_SLQSSwiGetOSInfo
dms.h, 882
unpack_dms_SLQSSwiGetOSInfo_t, 516
nameString, 516
Tlvresult, 517
versionString, 517
unpack_dms_SLQSSwiGetSerialNoExt
dms.h, 882
unpack_dms_SLQSSwiGetSerialNoExt_t, 517
meidString, 517
Tlvresult, 517
unpack_dms_SLQSSwiSetDyingGaspCfg
dms.h, 883
unpack_dms_SLQSSwiSetDyingGaspCfg_t, 517
Tlvresult, 517
unpack_dms_SLQSSwiSetHostDevInfo
dms.h, 883
unpack_dms_SLQSSwiSetHostDevInfo_t, 518
Tlvresult, 518
unpack_dms_SLQSSwiSetOSInfo
dms.h, 883
unpack_dms_SLQSSwiSetOSInfo_t, 518
Tlvresult, 518
unpack_dms_SLQSUIMGetState
dms.h, 884

unpack_dms_SLQSUIMGetState_t, 518
state, 519
Tlvresult, 519
unpack_dms_SetActivationStatusCallback
dms.h, 874
unpack_dms_SetActivationStatusCallback_t, 501
Tlvresult, 501
unpack_dms_SetCrashAction
dms.h, 875
unpack_dms_SetCrashAction_t, 501
notused, 501
unpack_dms_SetCustFeature
dms.h, 875
unpack_dms_SetCustFeature_t, 501
Tlvresult, 502
unpack_dms_SetCustFeaturesV2
dms.h, 875
unpack_dms_SetCustFeaturesV2_t, 502
Tlvresult, 502
unpack_dms_SetEventReport
dms.h, 876
unpack_dms_SetEventReport_ind
dms.h, 876
unpack_dms_SetEventReport_ind_t, 502
ActivationStatusTlv, 503
OperatingModeTlv, 503
Tlvresult, 503
unpack_dms_SetEventReport_t, 503
Tlvresult, 503
unpack_dms_SetFirmwarePreference
dms.h, 876
unpack_dms_SetFirmwarePreference_t, 503
Tlvresult, 503
unpack_dms_SetPower
dms.h, 877
unpack_dms_SetPower_t, 504
Tlvresult, 504
unpack_dms_SetUSBComp
dms.h, 877
unpack_dms_SetUSBComp_t, 504
Tlvresult, 504
unpack_dms_UIMChangePIN
dms.h, 884
unpack_dms_UIMGetControlKeyStatus
dms.h, 884
unpack_dms_UIMGetControlKeyStatus_t, 519
facilityState, 520
Tlvresult, 520
unblockRetriesLeft, 520
verifyRetriesLeft, 520
unpack_dms_UIMGetICCID
dms.h, 885
unpack_dms_UIMGetICCID_t, 520
String, 520
stringSize, 520
Tlvresult, 520
unpack_dms_UIMGetPINStatus
dms.h, 885
unpack_dms_UIMGetPINStatus_t, 520
p1Status, 522
p1UnblockRetriesLeft, 522
p1VerifyRetriesLeft, 522
p2Status, 522
p2UnblockRetriesLeft, 522
p2VerifyRetriesLeft, 522
Tlvresult, 522
unpack_dms_UIMSetControlKeyProtection
dms.h, 885
unpack_dms_UIMSetControlKeyProtection_t, 522
Tlvresult, 522
verifyRetriesLeft, 522
unpack_dms_UIMSetPINProtection
dms.h, 886
unpack_dms_UIMSetPINProtection_t, 522
Tlvresult, 523
unblockRetriesLeft, 523
verifyRetriesLeft, 523
unpack_dms_UIMUnblockControlKey
dms.h, 886
unpack_dms_UIMUnblockControlKey_t, 523
Tlvresult, 524
unblockRetriesLeft, 524
unpack_dms_UIMUnblockPIN
dms.h, 886
unpack_dms_UIMVerifyPIN
dms.h, 887
unpack_dms_ValidateSPC
dms.h, 887
unpack_fms_GetImagesPreference
fms.h, 890
unpack_fms_GetImagesPreference_t, 524
ImageListSize, 524
pImageList, 524
Tlvresult, 524
unpack_fms_GetStoredImages
fms.h, 890
unpack_fms_GetStoredImages_t, 524
imageList, 525
imagelistSize, 525
Tlvresult, 525
unpack_fms_SetImagesPreference
fms.h, 890
unpack_fms_SetImagesPreference_t, 525
ImageTypes, 525
ImageTypesSize, 525
Tlvresult, 525
unpack_ims_SLQSGetIMSSMSConfig
ims.h, 897
unpack_ims_SLQSGetIMSSMSConfig_t, 526
pSettingResp, 526
unpack_ims_SLQSGetIMSUserConfig
ims.h, 897
unpack_ims_SLQSGetIMSUserConfig_t, 526
pIMSDomain, 527
pSettingResp, 527
unpack_ims_SLQSGetIMSVoIPConfig

ims.h, 897
unpack_ims_SLQSGetIMSVoIPConfig_t, 527
pAmrMode, 529
pRingingTimer, 530
pSettingResp, 530
unpack_ims_SLQSGetRegMgrConfig
ims.h, 898
unpack_ims_SLQSGetRegMgrConfig_t, 530
pIMSTestMode, 530
pPCSCFPort, 531
pSettingResp, 531
unpack_ims_SLQSGetSIPConfig
ims.h, 898
unpack_ims_SLQSGetSIPConfig_t, 531
pSIPLocalPort, 532
pSettingResp, 532
pSigCompEnabled, 532
pSubscribeTimer, 532
pTimerSIPReg, 532
pTimerT1, 532
pTimerT2, 532
pTimerTf, 532
unpack_ims_SLQSImsConfigIndicationRegister
ims.h, 898
unpack_ims_SLQSSetIMSSMSConfig
ims.h, 899
unpack_ims_SLQSSetIMSSMSConfig_t, 532
pSettingResp, 532
unpack_ims_SLQSSetIMSUserConfig
ims.h, 899
unpack_ims_SLQSSetIMSUserConfig_t, 532
pSettingResp, 533
unpack_ims_SLQSSetIMSVoIPConfig
ims.h, 899
unpack_ims_SLQSSetIMSVoIPConfig_t, 533
pSettingResp, 533
unpack_ims_SLQSSetRegMgrConfig
ims.h, 900
unpack_ims_SLQSSetRegMgrConfig_t, 533
pSettingResp, 533
unpack_ims_SLQSSetSIPConfig
ims.h, 900
unpack_ims_SLQSSetSIPConfig_t, 534
pSettingResp, 534
unpack_imsa_SLQSGetIMSARegStatus
imsa.h, 902
unpack_imsa_SLQSGetIMSARegStatus_t, 534
ImsRegErrCode, 535
ImsRegStatus, 535
NewImsRegStatus, 535
unpack_imsa_SLQSGetIMSAServiceStatus
imsa.h, 903
unpack_imsa_SLQSGetIMSAServiceStatus_t, 535
SmsServiceRat, 537
SmsServiceStatus, 537
UtServiceRat, 537
UtServiceStatus, 537
VoipServiceRat, 537
VoipServiceStatus, 537
VsServiceRat, 537
VsServiceStatus, 537
VtServiceRat, 537
VtServiceStatus, 537
unpack_imsa_SLQSRegisterIMSAIndication
imsa.h, 903
unpack_loc_BestAvailPos_Ind
loc.h, 922
unpack_loc_BestAvailPos_Ind_t, 537
pAltitudeWrtEllipsoid, 542
pAltitudeWrtMeanSeaLevel, 542
pGpsTime, 542
pHeading, 542
pHeadingUnc, 542
pHorCirConf, 542
pHorEllpConf, 542
pHorReliability, 542
pHorUncCircular, 542
pHorUncEllipseOrientAzimuth, 542
pHorUncEllipseSemiMajor, 542
pHorUncEllipseSemiMinor, 542
pLatitude, 543
pLongitude, 543
pMagneticDeviation, 543
pPrecisionDilution, 543
pSensorDataUsage, 543
pSpeedHorizontal, 543
pSpeedUnc, 543
pSpeedVertical, 543
pSpeedVerticalUnc, 543
pSvUsedforFix, 543
pTechnologyMask, 543
pTimeSrc, 543
pTimeUnc, 543
pTimestampUtc, 543
pVertConfidence, 543
pVertReliability, 543
pVertUnc, 543
pXid, 543
status, 543
Tlvresult, 543
unpack_loc_Delete_Assist_Data_t, 543
Tlvresult, 544
unpack_loc_DeleteAssistData
loc.h, 922
unpack_loc_DeleteAssistData_Ind
loc.h, 922
unpack_loc_DeleteAssistData_Ind_t, 544
status, 544
Tlvresult, 544
unpack_loc_EngineState_Ind
loc.h, 923
unpack_loc_EngineState_Ind_t, 545
engineState, 545
Tlvresult, 545
unpack_loc_EventNMEA_Ind
loc.h, 923

unpack_loc_EventNMEA_Ind_t, 545
NMEAData, 546
Tlvresult, 546
unpack_loc_EventRegister
loc.h, 924
unpack_loc_EventRegister_t, 546
Tlvresult, 546
unpack_loc_GetServer_Ind
loc.h, 924
unpack_loc_GetServer_Ind_t, 546
pIPv4AddrInfo, 547
pIPv6AddrInfo, 547
pURL, 547
serverStatus, 547
serverType, 547
Tlvresult, 547
unpack_loc_GnssSvInfo_Ind
loc.h, 924
unpack_loc_GnssSvInfo_Ind_t, 548
altitudeAssumed, 548
pSatelliteInfo, 548
Tlvresult, 548
unpack_loc_PositionRpt_Ind
loc.h, 925
unpack_loc_PositionRpt_Ind_t, 548
pAltitudeAssumed, 554
pAltitudeWrtEllipsoid, 554
pAltitudeWrtMeanSeaLevel, 554
pFixId, 554
pGpsTime, 554
pHeading, 554
pHeadingUnc, 554
pHorConfidence, 554
pHorReliability, 554
pHorUncCircular, 554
pHorUncEllipseOrientAzimuth, 554
pHorUncEllipseSemiMajor, 554
pHorUncEllipseSemiMinor, 554
pLatitude, 554
pLeapSeconds, 554
pLongitude, 554
pMagneticDeviation, 554
pPrecisionDilution, 554
pSensorDataUsage, 554
pSpeedHorizontal, 554
pSpeedUnc, 554
pSpeedVertical, 554
pSvUsedforFix, 554
pTechnologyMask, 554
pTimeSrc, 554
pTimeUnc, 555
pTimestampUtc, 554
pVertConfidence, 555
pVertReliability, 555
pVertUnc, 555
sessionId, 555
sessionStatus, 555
Tlvresult, 555
unpack_loc_SLQSLOCGetBestAvailPos
loc.h, 926
unpack_loc_SLQSLOCGetBestAvailPos_t, 557
Tlvresult, 557
unpack_loc_SLQSLOCGetServer
loc.h, 927
unpack_loc_SLQSLOCInjectPosition
loc.h, 927
unpack_loc_SLQSLOCInjectSensorData
loc.h, 927
unpack_loc_SLQSLOCInjectUTCTime
loc.h, 928
unpack_loc_SLQSLOCSetCradleMountConfig
loc.h, 928
unpack_loc_SetExtPowerConfig_Ind
loc.h, 925
unpack_loc_SetExtPowerConfig_Ind_t, 555
status, 555
Tlvresult, 555
unpack_loc_SetExtPowerState
loc.h, 925
unpack_loc_SetExtPowerState_t, 556
Tlvresult, 556
unpack_loc_SetOperationMode
loc.h, 926
unpack_loc_SetOperationMode_Ind
loc.h, 926
unpack_loc_SetOperationMode_Ind_t, 556
status, 557
Tlvresult, 557
unpack_loc_SetOperationMode_t, 557
Tlvresult, 557
unpack_loc_Start
loc.h, 928
unpack_loc_Start_t, 558
Tlvresult, 558
unpack_loc_Stop
loc.h, 929
unpack_loc_Stop_t, 558
Tlvresult, 558
unpack_nas_GetACCOLC
nas.h, 955
unpack_nas_GetANAAAAuthenticationStatus
nas.h, 956
unpack_nas_GetCDMANetworkParameters
nas.h, 956
unpack_nas_GetCDMANetworkParameters_t, 558
Application, 560
Broadcast, 560
CustomSCP, 560
ForceRev0, 560
Protocol, 560
RegForeignNID, 560
RegForeignSID, 560
RegHomeSID, 560
Roaming, 560
SCI, 560
SCM, 561

unpack_nas_GetHomeNetwork
nas.h, 957
unpack_nas_GetHomeNetwork3GPP2
nas.h, 957
unpack_nas_GetHomeNetwork3GPP2_t, 561
nameSize, 562
pMCC, 562
pMNC, 562
pNID, 562
pName, 562
pNw2DescDisp, 563
pNw2DescEnc, 563
pNw2DescLen, 563
pNw2MCC, 563
pNw2MNC, 563
pNw2Name, 563
pSID, 563
unpack_nas_GetHomeNetwork_t, 563
mcc, 564
mnc, 564
name, 564
nid, 564
sid, 564
unpack_nas_GetNetworkPreference
nas.h, 957
unpack_nas_GetNetworkPreference_t, 564
ActiveTechPref, 565
Duration, 565
PersistentTechPref, 565
Tlvresult, 565
unpack_nas_GetRFInfo
nas.h, 958
unpack_nas_GetRFInfo_t, 565
instancesSize, 566
RFBandInfoElements, 566
unpack_nas_GetServingNetwork
nas.h, 958
unpack_nas_GetServingNetwork_t, 566
CSDomain, 568
DataCaps, 568
DataCapsLen, 568
MCC, 568
MNC, 568
Name, 568
nameSize, 568
PSDomain, 568
RAN, 568
RadioIfaces, 568
RadioIfacesSize, 568
RegistrationState, 568
Roaming, 568
unpack_nas_GetServingNetworkCapabilities
nas.h, 958
unpack_nas_GetServingNetworkCapabilities_t, 568
DataCaps, 569
DataCapsLen, 569
unpack_nas_GetSignalStrengths
nas.h, 959
unpack_nas_GetSignalStrengths_t, 569
len, 569
radio, 570
rssi, 570
unpack_nas_InitiateDomainAttach
nas.h, 959
unpack_nas_PerformNetworkScan
nas.h, 959
unpack_nas_PerformNetworkScan_t, 570
p3GppNetworkInfoInstances, 571
p3GppNetworkInstanceSize, 571
pPCSInstance, 571
pPCSInstanceSize, 571
pRATINstance, 571
pRATInstanceSize, 571
pScanResult, 571
unpack_nas_SLQSConfigSigInfo
nas.h, 963
unpack_nas_SLQSGetErrorRate
nas.h, 963
unpack_nas_SLQSGetErrorRate_t, 574
pCDMAFrameErrRate, 575
pGSMBER, 575
pHDRPackErrRate, 575
pWCDMABER, 575
unpack_nas_SLQSGetNetworkTime
nas.h, 964
unpack_nas_SLQSGetNetworkTime_t, 576
p3GPP2TimeInfo, 576
p3GPPTimeInfo, 576
unpack_nas_SLQSGetOperatorNameData
nas.h, 964
unpack_nas_SLQSGetOperatorNameData_t, 576
pNITZInformation, 577
pOperatorNameString, 577
pOperatorPLMNList, 577
pPLMNNetworkName, 577
pSrvcProviderName, 577
unpack_nas_SLQSGetPLMNName
nas.h, 965
unpack_nas_SLQSGetPLMNName_t, 577
longName, 579
longNameCI, 579
longNameEn, 579
longNameLen, 579
longNameSB, 579
shortName, 579
shortNameCI, 579
shortNameEn, 580
shortNameLen, 580
shortNameSB, 580
spn, 580
spnEncoding, 580
spnLength, 580
unpack_nas_SLQSGetServingSystem
nas.h, 965
unpack_nas_SLQSGetServingSystem_t, 580
BasestationID, 583

BasestationLatitude, 583
BasestationLongitude, 583
CDMASystemInfoExt, 583
CallBarStatus, 583
CellID, 583
ConcSvcInfo, 583
CurrentPLMN, 583
DTMInd, 583
DataSrvCapabilities, 583
DefaultRoamInd, 583
DetailedSvcInfo, 583
Gpp2TimeZone, 583
GppNetworkDSTAdjustment, 583
GppTimeZone, 583
HdrPersonality, 583
Lac, 583
NetworkID, 583
PRLInd, 584
RoamIndicatorVal, 584
RoamingIndicatorList, 584
ServingSystem, 584
SystemID, 584
TrackAreaCode, 584
unpack_nas_SLQSGetSignalStrength
nas.h, 966
unpack_nas_SLQSGetSignalStrength_t, 584
ecioList, 586
ecioListLen, 586
errorRateList, 586
errorRateListLen, 586
Io, 586
ltersrp, 586
ltesnr, 586
rsrqInfo, 586
rxSignalStrengthList, 586
rxSignalStrengthListLen, 586
signalStrengthReqMask, 586
sinr, 586
unpack_nas_SLQSGetSysInfo
nas.h, 966
unpack_nas_SLQSGetSysInfo_t, 586
pAddCDMASysInfo, 589
pAddGSMSysInfo, 589
pAddHDRSysInfo, 589
pAddLTESysInfo, 589
pCDMASrvStatusInfo, 589
pCDMASysInfo, 589
pGSMCallBarringSysInfo, 589
pGSMCipherDomainSysInfo, 589
pGSMSrvStatusInfo, 589
pGSMSysInfo, 589
pHDRSrvStatusInfo, 589
pHDRSysInfo, 589
pLTESrvStatusInfo, 589
pLTESysInfo, 589
pLTEVoiceSupportSysInfo, 589
pWCDMASysInfo, 590
unpack_nas_SLQSGetSysSelectionPref
nas.h, 966
unpack_nas_SLQSGetSysSelectionPref_t, 590
pBandPref, 594
pEmerMode, 594
pGWAcqOrderPref, 594
pLTEBandPref, 594
pModePref, 594
pNetSelPref, 594
pPRLPref, 594
pRoamPref, 594
pSrvDomainPref, 594
unpack_nas_SLQSInitiateNetworkRegistration
nas.h, 967
unpack_nas_SLQSNASGeteDRXParams
nas.h, 968
unpack_nas_SLQSNASGeteDRXParams_t, 597
pCycleLen, 597
pEdrxEnable, 597
unpack_nas_SLQSNASSeteDRXParams
nas.h, 970
unpack_nas_SLQSNASSwiGetChannelLock
nas.h, 971
unpack_nas_SLQSNASSwiGetChannelLock_t, 602
unpack_nas_SLQSNASSwiSetChannelLock
nas.h, 972
unpack_nas_SLQSNasConfigSigInfo2
nas.h, 967
unpack_nas_SLQSNasGet3GPP2Subscription
nas.h, 967
unpack_nas_SLQSNasGet3GPP2Subscription_t, 594
pDirNum, 595
unpack_nas_SLQSNasGetCellLocationInfo
nas.h, 968
unpack_nas_SLQSNasGetCellLocationInfo_t, 595
pCDMAInfo, 596
pLTEInfoInterfreq, 597
pLTEInfoIntrafreq, 597
pUMTSInfo, 597
unpack_nas_SLQSNasGetHDRColorCode
nas.h, 968
unpack_nas_SLQSNasGetHDRColorCode_t, 598
pColorCode, 598
unpack_nas_SLQSNasGetSigInfo
nas.h, 969
unpack_nas_SLQSNasGetSigInfo_t, 598
CDMASSInfo, 599
GSMSSInfo, 599
HDRSSInfo, 599
LTESSInfo, 599
unpack_nas_SLQSNasGetTxRxInfo
nas.h, 969
unpack_nas_SLQSNasGetTxRxInfo_t, 599
pRXChain0Info, 599
pRXChain1Info, 599
pTXInfo, 599
unpack_nas_SLQSNasIndicationRegisterExt
nas.h, 970
unpack_nas_SLQSNasNetworkTimeCallBack_ind

nas.h, 970
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t, 600
pDayltSavAdj, 600
pRadioInterface, 600
pTimeZone, 600
universalTime, 600
unpack_nas_SLQSNasSigInfoCallback_ind
nas.h, 971
unpack_nas_SLQSNasSigInfoCallback_ind_t, 601
pRscp, 602
unpack_nas_SLQSNasSwiIndicationRegister
nas.h, 971
unpack_nas_SLQSNasSwiModemStatus
nas.h, 972
unpack_nas_SLQSNasSwiModemStatus_t, 602
commonInfo, 603
pLTEInfo, 603
unpack_nas_SLQSNasSwiOTAMessageCallback_ind
nas.h, 972
unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t, 603
Info, 603
Tlvresult, 603
unpack_nas_SLQSNasSysInfoCallback_ind
nas.h, 973
unpack_nas_SLQSNasTimerCallback_ind
nas.h, 973
unpack_nas_SLQSNasTimerCallback_ind_t, 603
t3396_apn, 604
t3396_plmn_id, 604
t3396_val, 604
unpack_nas_SLQSSetBandPreference
nas.h, 973
unpack_nas_SLQSSetSignalStrengthsCallback
nas.h, 974
unpack_nas_SLQSSetSysSelectionPref
nas.h, 974
unpack_nas_SLQSSetSysSelectionPrefCallBack_ind
nas.h, 974
unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t, 604
Info, 604
Tlvresult, 604
unpack_nas_SLQSSwiGetHDRPersonality
nas.h, 974
unpack_nas_SLQSSwiGetHDRPersonality_t, 605
pCurrentPersonality, 605
pPersonalityListLength, 605
pProtocolSubtypeElement, 605
unpack_nas_SLQSSwiGetHDRProtSubtype
nas.h, 975
unpack_nas_SLQSSwiGetHDRProtSubtype_t, 605
pAppSubType, 606
pCurrentPrsnlty, 606
pPersonalityListLength, 606
unpack_nas_SLQSSwiGetHRPDStats
nas.h, 975
unpack_nas_SLQSSwiGetHRPDStats_t, 606
pPilotSetData, 607
pUATI, 607
unpack_nas_SLQSSwiGetLteCQI
nas.h, 976
unpack_nas_SLQSSwiGetLteCQI_t, 607
ValidityCW0, 608
ValidityCW1, 608
unpack_nas_SLQSSwiGetLteSccRxInfo
nas.h, 976
unpack_nas_SLQSSwiGetLteSccRxInfo_t, 608
pSccRxInfo, 608
unpack_nas_SLQSSwiNetworkDebug
nas.h, 976
unpack_nas_SLQSSwiNetworkDebug_t, 608
pDataStatusDetail, 609
pDeviceConfigDetail, 609
pNetworkStat1x, 609
pNetworkStatEVDO, 609
pObjectVer, 609
unpack_nas_SLQSSwiPSDetach
nas.h, 977
unpack_nas_SLQSSysInfoCallback_ind_t, 609
pGSMSysInfo, 611
pHDRSysInfo, 612
pLTESysInfo, 612
pSysInfoNoChange, 612
unpack_nas_SetACCOLC
nas.h, 960
unpack_nas_SetCDMANetworkParameters
nas.h, 960
unpack_nas_SetDataCapabilitiesCallback_ind
nas.h, 960
unpack_nas_SetDataCapabilitiesCallback_ind_t, 571
dataCaps, 571
dataCapsSize, 571
unpack_nas_SetEventReportInd
nas.h, 961
unpack_nas_SetEventReportInd_t, 571
RFTlv, 572
RRTlv, 572
SLQSSSTlv, 572
SSTlv, 572
unpack_nas_SetLURejectCallback
nas.h, 961
unpack_nas_SetNasLTECphyCaIndCallback_ind
nas.h, 961
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 572
unpack_nas_SetNetworkPreference
nas.h, 962
unpack_nas_SetNetworkPreference_t, 573
Tlvresult, 573
unpack_nas_SetRFInfoCallback
nas.h, 962
unpack_nas_SetRoamingIndicatorCallback_ind
nas.h, 962
unpack_nas_SetRoamingIndicatorCallback_ind_t, 573
roaming, 573

unpack_nas_SetServingSystemCallback_ind
nas.h, 963
unpack_nas_SetServingSystemCallback_ind_t, 574
SSInfo, 574
Tlvresult, 574
unpack_nas_SlqsGetLTECphyCAInfo
nas.h, 964
unpack_nas_SlqsGetLTECphyCAInfo_t, 575
LTECphyCaInfo, 576
Tlvresult, 576
unpack_omaDmConfigTlv_t, 612
alertmsg, 613
alertmsglength, 613
state, 613
userInputReq, 613
userInputTimeout, 613
unpack_omaDmFotaTlv_t, 613
description, 614
descriptionlength, 614
fwdloadsize, 614
fwloadComplete, 615
namelength, 615
package_name, 615
sessionType, 615
severity, 615
state, 615
updateCompleteStatus, 615
userInputReq, 615
userInputTimeout, 615
version, 615
versionlength, 615
unpack_omaDmNotificationsTlv_t, 615
notification, 616
sessionStatus, 616
unpack_pds_ForceXTRADownload
pds.h, 990
unpack_pds_GetPDSDefaults
pds.h, 991
unpack_pds_GetPDSDefaults_t, 616
pAccuracy, 617
pInterval, 617
pOperation, 617
pTimeout, 617
unpack_pds_GetPDSState
pds.h, 991
unpack_pds_GetPDSState_t, 617
pEnabledStatus, 618
pTrackingStatus, 618
unpack_pds_GetPortAutomaticTracking
pds.h, 991
unpack_pds_GetPortAutomaticTracking_t, 618
pbAuto, 618
unpack_pds_GetServiceAutomaticTracking
pds.h, 992
unpack_pds_GetServiceAutomaticTracking_t, 618
pbAuto, 619
unpack_pds_GetXTRAAutomaticDownload
pds.h, 992
unpack_pds_GetXTRAAutomaticDownload_t, 619
pInterval, 619
pbEnabled, 619
unpack_pds_GetXTRANetwork
pds.h, 992
unpack_pds_GetXTRANetwork_t, 619
pPreference, 620
unpack_pds_GetXTRAValidity
pds.h, 993
unpack_pds_GetXTRAValidity_t, 620
pDuration, 620
pGPSWeek, 620
pGPSWeekOffset, 620
unpack_pds_PDSInjectTimeReference
pds.h, 993
unpack_pds_ResetPDSData
pds.h, 993
unpack_pds_SLQSGetAGPSConfig
pds.h, 997
unpack_pds_SLQSGetAGPSConfig_t, 623
pServerAddress, 624
pServerPort, 624
pServerURL, 624
unpack_pds_SLQSGetGPSStateInfo
pds.h, 997
unpack_pds_SLQSGetGPSStateInfo_t, 624
Altitude, 627
EngineState, 627
HorizontalUncertainty, 627
Iono_valid, 627
Latitude, 627
Longitude, 627
Time_uncert_ms, 627
ValidMask, 627
VerticalUncertainty, 628
unpack_pds_SLQSPDSDeterminePosition
pds.h, 997
unpack_pds_SLQSPDSInjectAbsoluteTimeReference
pds.h, 998
unpack_pds_SLQSPDSInjectPositionData
pds.h, 998
unpack_pds_SLQSSetAGPSConfig
pds.h, 998
unpack_pds_SLQSSetPositionMethodState
pds.h, 999
unpack_pds_SetEventReport_Ind
pds.h, 994
unpack_pds_SetEventReport_Ind_t, 620
dLatitude, 622
dLongitude, 622
has_PositionDataNMEA, 622
has_SessionStatus, 622
has_dLatitude, 622
has_dLongitude, 622
has_posSrc, 622
posSrc, 622
PositionDataNMEA, 622
SessionStatus, 622

unpack_pds_SetEventReportCallback
pds.h, 994
unpack_pds_SetPDSDefaults
pds.h, 994
unpack_pds_SetPDSState
pds.h, 995
unpack_pds_SetPdsState_Ind
pds.h, 995
unpack_pds_SetPdsState_Ind_t, 622
EnabledStatus, 623
TlvPresent, 623
TrackingStatus, 623
unpack_pds_SetPortAutomaticTracking
pds.h, 995
unpack_pds_SetServiceAutomaticTracking
pds.h, 996
unpack_pds_SetXTRAAutomaticDownload
pds.h, 996
unpack_pds_SetXTRANetwork
pds.h, 996
unpack_pds_StartPDSTrackingSessionExt
pds.h, 999
unpack_pds_StopPDSTrackingSession
pds.h, 999
unpack_qmi_t, 628
msgid, 628
type, 628
xid, 628
unpack_qos_BindDataPort
qos.h, 1051
unpack_qos_IPv4Addr_t, 629
addr, 629
subnetMask, 629
unpack_qos_IPv6Addr_t, 629
addr, 629
prefixLen, 630
unpack_qos_IPv6TrafCls_t, 630
mask, 630
val, 630
unpack_qos_Port_t, 631
port, 631
range, 631
unpack_qos_QosFlowInfo_t, 631
BearerID, 632
is_RxQFlowGranted_Available, 632
is_TxQFlowGranted_Available, 632
NumRxFilters, 632
NumTxFilters, 632
QFlowState, 632
RxQFilter, 632
RxQFlowGranted, 632
TxQFilter, 632
TxQFlowGranted, 632
unpack_qos_QosFlowInfoState_t, 633
id, 633
isNewFlow, 633
state, 633
unpack_qos_SLQSQosGetNetworkStatus
qos.h, 1051
unpack_qos_SLQSQosGetNetworkStatus_t, 633
NWQoSStatus, 634
unpack_qos_SLQSQosSwiReadApnExtraParams
qos.h, 1052
unpack_qos_SLQSQosSwiReadApnExtraParams_t, 634
ambr_dl, 634
ambr_dl_ext, 635
ambr_dl_ext2, 635
ambr_ul, 635
ambr_ul_ext, 635
ambr_ul_ext2, 635
apnId, 635
unpack_qos_SLQSQosSwiReadDataStats
qos.h, 1052
unpack_qos_SLQSQosSwiReadDataStats_t, 635
apnId, 636
numQosFlow, 636
qosFlow, 636
total_rx_bytes, 636
total_rx_pkt, 636
total_tx_bytes, 636
total_tx_pkt, 636
unpack_qos_SLQSSetQosEventCallback
qos.h, 1053
unpack_qos_SLQSSetQosEventCallback_ind
qos.h, 1053
unpack_qos_SLQSSetQosEventCallback_ind_t, 636
NumFlows, 637
QosFlowInfo, 637
unpack_qos_SLQSSetQosNWStatusCallback_ind
qos.h, 1054
unpack_qos_SLQSSetQosNWStatusCallback_ind_t, 637
status, 637
unpack_qos_SLQSSetQosPriEventCallback_ind
qos.h, 1054
unpack_qos_SLQSSetQosPriEventCallback_ind_t, 637
event, 637
unpack_qos_SLQSSetQosStatusCallback_ind
qos.h, 1055
unpack_qos_SLQSSetQosStatusCallback_ind_t, 638
event, 639
id, 639
reason, 639
status, 639
unpack_qos_Tos_t, 647
mask, 648
val, 648
unpack_qos_dataRate_t, 628
dataRateMax, 629
guaranteedRate, 629
unpack_qos_pktErrRate_t, 630
exponent, 630
multiplier, 630
unpack_qos_swiQosFilter_t, 639
EspSpi, 641

IPv4DstAddr, 641
IPv4SrcAddr, 641
IPv4Tos, 641
IPv6DstAddr, 641
IPv6Label, 642
IPv6SrcAddr, 642
IPv6TrafCls, 642
Id, 641
index, 641
is_EspSpi_Available, 642
is_IPv4DstAddr_Available, 642
is_IPv4SrcAddr_Available, 642
is_IPv4Tos_Available, 642
is_IPv6DstAddr_Available, 642
is_IPv6Label_Available, 642
is_IPv6SrcAddr_Available, 642
is_IPv6TrafCls_Available, 642
is_Id_Available, 642
is_NxtHdrProto_Available, 642
is_Precedence_Available, 642
is_TCPDstPort_Available, 642
is_TCPSrcPort_Available, 642
is_TranDstPort_Available, 642
is_TranSrcPort_Available, 642
is_UDPDstPort_Available, 642
is_UDPSrcPort_Available, 642
NxtHdrProto, 642
Precedence, 642
TCPDstPort, 642
TCPSrcPort, 642
TranDstPort, 642
TranSrcPort, 642
UDPDstPort, 642
UDPSrcPort, 642
version, 643
unpack_qos_swiQosFlow_t, 643
DataRate, 645
index, 645
is_DataRate_Available, 645
is_Jitter_Available, 646
is_Latency_Available, 646
is_LteQci_Available, 646
is_MaxAllowedPktSz_Available, 646
is_MinPolicedPktSz_Available, 646
is_PktErrRate_Available, 646
is_ProfileId3GPP2_Available, 646
is_TokenBucket_Available, 646
is_TrafficClass_Available, 646
is_val_3GPP2Pri_Available, 646
is_val_3GPPImCn_Available, 646
is_val_3GPPSigInd_Available, 646
Jitter, 646
Latency, 646
LteQci, 646
MaxAllowedPktSz, 646
MinPolicedPktSz, 646
PktErrRate, 646
ProfileId3GPP2, 646
TokenBucket, 646
TrafficClass, 646
val_3GPP2Pri, 646
val_3GPPImCn, 646
val_3GPPResResidualBER, 646
val_3GPPSigInd, 646
val_3GPPTraHdlPri, 646
unpack_qos_tokenBucket_t, 647
bucketSz, 647
peakRate, 647
tokenRate, 647
unpack_result_code_only
common.h, 835
unpack_rms_GetSMSWake
rms.h, 1057
unpack_rms_GetSMSWake_t, 648
enabled, 649
wake_mask, 649
unpack_rms_SetSMSWake
rms.h, 1057
unpack_sar_SLQSGetRfSarState
sar.h, 1058
unpack_sar_SLQSGetRfSarState_t, 650
pSarRFState, 651
unpack_sar_SLQSSetRfSarState
sar.h, 1059
unpack_sms_GetSMSCAddress
sms.h, 1071
unpack_sms_GetSMSCAddress_t, 651
addressSize, 651
pSMSCAddress, 651
pSMSCType, 651
typeSize, 651
unpack_sms_SLQSDeleteSMS
sms.h, 1073
unpack_sms_SLQSDeleteSMS_t, 654
unpack_sms_SLQSGetIndicationRegister
sms.h, 1073
unpack_sms_SLQSGetIndicationRegister_t, 654
pGetIndicationRegInfo, 654
unpack_sms_SLQSGetMessageWaiting
sms.h, 1074
unpack_sms_SLQSGetMessageWaiting_t, 654
pGetMsgWaitingInfoResp, 655
unpack_sms_SLQSGetSMS
sms.h, 1074
unpack_sms_SLQSGetSMS_t, 655
message, 655
messageFormat, 655
messageSize, 655
messageTag, 655
unpack_sms_SLQSGetSMSList
sms.h, 1075
unpack_sms_SLQSGetSMSList_t, 656
messageList, 657
messageListSize, 657
unpack_sms_SLQSGetSmsBroadcastConfig
sms.h, 1074

unpack_sms_SLQSGetSmsBroadcastConfig_t, 656
pBroadcastConfig, 656
pCDMABroadcastConfig, 656
unpack_sms_SLQSGetTransLayerInfo
sms.h, 1075
unpack_sms_SLQSGetTransLayerInfo_t, 657
pGetTransLayerInfo, 657
unpack_sms_SLQSGetTransNWRegInfo
sms.h, 1075
unpack_sms_SLQSGetTransNWRegInfo_t, 657
unpack_sms_SLQSModifySMSStatus
sms.h, 1076
unpack_sms_SLQSModifySMSStatus_t, 657
unpack_sms_SLQSSendAsyncSMS
sms.h, 1076
unpack_sms_SLQSSetIndicationRegister
sms.h, 1076
unpack_sms_SLQSSetSmsBroadcastActivation
sms.h, 1077
unpack_sms_SLQSSetSmsBroadcastConfig
sms.h, 1077
unpack_sms_SLQSSetSmsStorage
sms.h, 1077
unpack_sms_SLQSSmsGetMaxStorageSize
sms.h, 1078
unpack_sms_SLQSSmsGetMaxStorageSize_t, 658
pMaxStorageSizeResp, 658
unpack_sms_SLQSSmsGetMessageProtocol
sms.h, 1078
unpack_sms_SLQSSmsGetMessageProtocol_t, 658
pMessageProtocol, 658
unpack_sms_SLQSSmsSetRoutes
sms.h, 1078
unpack_sms_SLQSSwiGetSMSStorage
sms.h, 1079
unpack_sms_SLQSSwiGetSMSStorage_t, 659
pSmsStorage, 659
unpack_sms_SLQSWmsMemoryFullCallBack_ind
sms.h, 1079
unpack_sms_SLQSWmsMemoryFullCallBack_ind_t, 659
messageMode, 659
storageType, 659
unpack_sms_SaveSMS
sms.h, 1071
unpack_sms_SaveSMS_t, 651
pMessageIndex, 652
unpack_sms_SendSMS
sms.h, 1072
unpack_sms_SendSMS_t, 652
messageFailureCode, 652
messageID, 652
unpack_sms_SetNewSMSCallback
sms.h, 1072
unpack_sms_SetNewSMSCallback_ind
sms.h, 1072
unpack_sms_SetNewSMSCallback_ind_t, 652
ETWSTlv, 653
IMSTlv, 653
MMTlv, 653
NewMMTlv, 653
SMSCTlv, 653
TRMessageTlv, 653
unpack_sms_SetNewSMSCallback_t, 653
unpack_sms_SetSMSCAddress
sms.h, 1073
unpack_swiaudio_SLQSGetM2MAVMute
swiaudio.h, 1085
unpack_swiaudio_SLQSGetM2MAVMute_t, 661
CwtMute, 662
EarMute, 662
MicMute, 662
unpack_swiaudio_SLQSGetM2MAudioProfile
swiaudio.h, 1085
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 660
CwtMute, 660
EarMute, 660
Generator, 660
MicMute, 661
Profile, 661
Volume, 661
unpack_swiaudio_SLQSGetM2MAudioVolume
swiaudio.h, 1085
unpack_swiaudio_SLQSGetM2MAudioVolume_t, 661
Level, 661
unpack_swiaudio_SLQSGetM2MSpkrGain
swiaudio.h, 1086
unpack_swiaudio_SLQSGetM2MSpkrGain_t, 662
Value, 662
unpack_swiaudio_SLQSSetM2MAVMute
swiaudio.h, 1088
unpack_swiaudio_SLQSSetM2MAudioAVCFG
swiaudio.h, 1086
unpack_swiaudio_SLQSSetM2MAudioLPBK
swiaudio.h, 1086
unpack_swiaudio_SLQSSetM2MAudioNVDef
swiaudio.h, 1087
unpack_swiaudio_SLQSSetM2MAudioProfile
swiaudio.h, 1087
unpack_swiaudio_SLQSSetM2MAudioVolume
swiaudio.h, 1087
unpack_swiaudio_SLQSSetM2MSpkrGain
swiaudio.h, 1088
unpack_swiavms_SLQSAVMSEventReportInd
swiavms.h, 1095
unpack_swiavms_SLQSAVMSEventReportInd_t, 662
pConfig, 663
pConnectionRequest, 663
pDataSessionStatus, 663
pNotification, 663
pPackageID, 664
pRegStatus, 664
pSessionType, 664
resultcode, 664
unpack_swiavms_SLQSAVMSGetSettings
swiavms.h, 1095

unpack_swiavms_SLQSAVMSGetSettings_t, 664
AutoConnect, 665
AutoReboot, 665
FwAutoSDM, 665
FwPromptUpdate, 665
FwPromptdownload, 665
pAPNInfo, 665
pConnectionRetryTimers, 665
pNotificationStore, 665
pPeroidsInfo, 665
pPollingTimer, 666
resultcode, 666
unpack_swiavms_SLQSAVMSSendSelection
swiavms.h, 1096
unpack_swiavms_SLQSAVMSSendSelection_t, 666
resultcode, 666
unpack_swiavms_SLQSAVMSSessionGetInfo
swiavms.h, 1096
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 666
pConfig, 666
pNotification, 666
pPackageID, 666
resultcode, 666
unpack_swiavms_SLQSAVMSSetSettings
swiavms.h, 1097
unpack_swiavms_SLQSAVMSSetSettings_t, 667
resultcode, 667
unpack_swiavms_SLQSAVMSStartSession
swiavms.h, 1098
unpack_swiavms_SLQSAVMSStartSession_t, 667
resultcode, 668
sessionResponse, 668
unpack_swiavms_SLQSAVMSStopSession
swiavms.h, 1098
unpack_swiavms_SLQSAVMSStopSession_t, 668
resultcode, 668
unpack_swiavms_SLQSAvmsSetEventReport
swiavms.h, 1097
unpack_swiavms_SLQSAvmsSetEventReport_t, 667
resultcode, 667
unpack_swiloc_SwiLocGetAutoStart
swiloc.h, 1101
unpack_swiloc_SwiLocGetAutoStart_t, 668
fix_rate, 669
fix_rate_reported, 669
fix_type, 670
fix_type_reported, 670
function, 670
function_reported, 670
max_dist, 670
max_dist_reported, 670
max_time, 670
max_time_reported, 670
unpack_swiloc_SwiLocSetAutoStart
swiloc.h, 1101
unpack_swioma_SLQSOMADMAlertCallback
swioma.h, 1107
unpack_swioma_SLQSOMADMAlertCallback_ind
swioma.h, 1108
unpack_swioma_SLQSOMADMAlertCallback_ind_t, 670
eventType, 670
unpack_swioma_SLQSOMADMCancelSession
swioma.h, 1108
unpack_swioma_SLQSOMADMCancelSessionExt
swiomaext.h, 1114
unpack_swioma_SLQSOMADMGetSessionInfo
swioma.h, 1109
unpack_swioma_SLQSOMADMGetSessionInfo_t, 671
Date, 673
DateLength, 673
PkgDescLength, 673
PkgDescription, 673
PkgName, 673
PkgNameLength, 673
RetryCount, 673
SessionState, 673
SessionType, 673
Severity, 673
Source, 673
SourceLength, 673
Status, 673
Time, 673
TimeLength, 673
UpdateCompleteStatus, 673
unpack_swioma_SLQSOMADMGetSettings
swioma.h, 1109
unpack_swioma_SLQSOMADMGetSettings_t, 673
Autosdm, 674
FOTAdownload, 675
FwAutoCheck, 675
unpack_swioma_SLQSOMADMSendSelection
swioma.h, 1109
unpack_swioma_SLQSOMADMSendSelectionExt
swiomaext.h, 1114
unpack_swioma_SLQSOMADMSetSettings
swioma.h, 1110
unpack_swioma_SLQSOMADMSetSettingsExt
swiomaext.h, 1115
unpack_swioma_SLQSOMADMStartSession
swioma.h, 1110
unpack_swioma_SLQSOMADMStartSession_t, 675
FwAvailability, 675
unpack_swioma_SLQSOMADMStartSessionExt
swiomaext.h, 1115
unpack_tmd_SLQSTmdDeRegNotMitigationLvl
tmd.h, 1118
unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t, 675
Tlvresult, 676
unpack_tmd_SLQSTmdGetMitigationDevList
tmd.h, 1118
unpack_tmd_SLQSTmdGetMitigationDevList_t, 676
MitigationDevList, 676
MitigationDevListLen, 676
Tlvresult, 676
unpack_tmd_SLQSTmdGetMitigationLvl

tmd.h, 1119
unpack_tmd_SLQSTmdGetMitigationLvl_t, 676
CurrentmitigationLvl, 677
ReqMitigationLvl, 677
Tlvresult, 677
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind
tmd.h, 1119
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t, 677
deviceID, 677
deviceIdLen, 677
lvl, 677
unpack_tmd_SLQSTmdRegNotMitigationLvl
tmd.h, 1119
unpack_tmd_SLQSTmdRegNotMitigationLvl_t, 678
Tlvresult, 678
unpack_uim_ChangePin
uim.h, 1130
unpack_uim_ChangePin_t, 678
pEncryptedPIN1, 679
pIndicationToken, 679
pRemainingRetries, 679
Tlvresult, 679
unpack_uim_GetCardStatus
uim.h, 1131
unpack_uim_GetCardStatus_t, 679
pCardStatus, 679
pHotSwapStatus, 679
Tlvresult, 679
unpack_uim_ReadTransparent
uim.h, 1131
unpack_uim_ReadTransparent_t, 679
pCardResult, 680
pEncryptedData, 680
pIndicationToken, 680
pReadResult, 680
Tlvresult, 680
unpack_uim_SLQSUIMAuthenticate
uim.h, 1132
unpack_uim_SLQSUIMAuthenticate_t, 682
pAuthenticateResult, 682
pCardResult, 682
pIndicationToken, 682
unpack_uim_SLQSUIMDepersonalization
uim.h, 1132
unpack_uim_SLQSUIMDepersonalization_t, 682
pRemainingRetries, 683
unpack_uim_SLQSUIMEventRegister
uim.h, 1133
unpack_uim_SLQSUIMEventRegister_t, 683
eventMask, 683
unpack_uim_SLQSUIMGetConfiguration
uim.h, 1133
unpack_uim_SLQSUIMGetConfiguration_t, 683
pAutoSelection, 684
pHaltSubscription, 684
pPersonalizationStatus, 684
unpack_uim_SLQSUIMGetFileAttributes
uim.h, 1133
unpack_uim_SLQSUIMGetFileAttributes_t, 684
pCardResult, 685
pFileAttributes, 685
pIndicationToken, 685
unpack_uim_SLQSUIMGetSlotsStatus
uim.h, 1134
unpack_uim_SLQSUIMGetSlotsStatus_t, 685
pNumberOfPhySlot, 685
pUimSlotsStatus, 685
unpack_uim_SLQSUIMPowerDown
uim.h, 1134
unpack_uim_SLQSUIMPowerUp
uim.h, 1134
unpack_uim_SLQSUIMRefreshComplete
uim.h, 1135
unpack_uim_SLQSUIMRefreshGetLastEvent
uim.h, 1135
unpack_uim_SLQSUIMRefreshGetLastEvent_t, 685
pRefreshEvent, 686
unpack_uim_SLQSUIMRefreshOK
uim.h, 1135
unpack_uim_SLQSUIMRefreshRegister
uim.h, 1136
unpack_uim_SLQSUIMReset
uim.h, 1136
unpack_uim_SLQSUIMSetStatusChangeCallBack_ind
uim.h, 1136
unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t, 686
unpack_uim_SLQSUIMSwitchSlot
uim.h, 1137
unpack_uim_SetPinProtection
uim.h, 1131
unpack_uim_SetPinProtection_t, 680
pEncryptedPIN1, 681
pIndicationToken, 681
pRemainingRetries, 681
Tlvresult, 681
unpack_uim_SetUimSlotStatusChangeCallback_ind
uim.h, 1132
unpack_uim_SetUimSlotStatusChangeCallback_ind_t, 681
bNumberOfPhySlots, 682
slotsstatusChange, 682
unpack_uim_UnblockPin
uim.h, 1137
unpack_uim_UnblockPin_t, 686
pEncryptedPIN1, 687
pIndicationToken, 687
pRemainingRetries, 687
Tlvresult, 687
unpack_uim_VerifyPin
uim.h, 1137
unpack_uim_VerifyPin_t, 687
pEncryptedPIN1, 688
pIndicationToken, 688
pRemainingRetries, 688

Tlvresult, 688
unpack_valid_nas_GetCDMANetworkParameters
nas.h, 977
unpack_valid_nas_SLQSGetServingSystem
nas.h, 977
unpack_valid_nas_SLQSGetSignalStrength
nas.h, 978
unpack_valid_nas_SLQSNasGetSigInfo
nas.h, 979
unpack_voice_AnswerUSSD
voice.h, 1154
unpack_voice_CancelUSSD
voice.h, 1155
unpack_voice_OriginateUSSD
voice.h, 1155
unpack_voice_SLQSOriginateUSSD
voice.h, 1155
unpack_voice_SLQSOriginateUSSD_t, 688
pAlphaIDInfo, 691
pCCSuppsType, 691
pCallId, 691
pCcResultType, 691
pUSSDInfo, 691
pfailureCause, 691
unpack_voice_SLQSVoiceALSSelectLine
voice.h, 1156
unpack_voice_SLQSVoiceALSSetLineSwitching
voice.h, 1156
unpack_voice_SLQSVoiceAnswerCall
voice.h, 1156
unpack_voice_SLQSVoiceAnswerCall_t, 691
pCallId, 692
unpack_voice_SLQSVoiceBindSubscription
voice.h, 1157
unpack_voice_SLQSVoiceBurstDTMF
voice.h, 1157
unpack_voice_SLQSVoiceBurstDTMF_t, 692
pCallID, 692
unpack_voice_SLQSVoiceDialCall
voice.h, 1157
unpack_voice_SLQSVoiceDialCall_t, 692
pAlphaIDInfo, 693
pCCResultType, 693
pCCSUPSType, 693
pCallID, 693
unpack_voice_SLQSVoiceEndCall
voice.h, 1158
unpack_voice_SLQSVoiceEndCall_t, 693
pCallId, 694
unpack_voice_SLQSVoiceGetAllCallInfo
voice.h, 1158
unpack_voice_SLQSVoiceGetAllCallInfo_t, 694
pArrAlertingPattern, 696
pArrAlertingType, 696
pArrAlphaID, 696
pArrCallEndReason, 696
pArrCallInfo, 696
pArrCalledPartyNum, 696
pArrConnectPartyNum, 696
pArrDiagInfo, 696
pArrRedirPartyNum, 696
pArrRemotePartyName, 696
pArrRemotePartyNum, 696
pArrSvcOption, 696
pArrUUSInfo, 696
pVoicePrivacy, 696
unpack_voice_SLQSVoiceGetCLIP
voice.h, 1160
unpack_voice_SLQSVoiceGetCLIP_t, 704
pAlphaIDInfo, 705
pCCResType, 705
pCallID, 705
pFailCause, 705
unpack_voice_SLQSVoiceGetCLIR
voice.h, 1160
unpack_voice_SLQSVoiceGetCLIR_t, 705
pAlphaIDInfo, 706
pCCResType, 706
pCallID, 706
pFailCause, 707
unpack_voice_SLQSVoiceGetCNAP
voice.h, 1160
unpack_voice_SLQSVoiceGetCNAP_t, 707
pAlphaIDInfo, 708
pCCResType, 708
pCallID, 708
pFailCause, 708
unpack_voice_SLQSVoiceGetCOLP
voice.h, 1161
unpack_voice_SLQSVoiceGetCOLP_t, 708
pAlphaIDInfo, 709
pCCResType, 709
pCallID, 709
pFailCause, 709
unpack_voice_SLQSVoiceGetCOLR
voice.h, 1161
unpack_voice_SLQSVoiceGetCOLR_t, 709
pAlphaIDInfo, 711
pCCResType, 711
pCallID, 711
pFailCause, 711
unpack_voice_SLQSVoiceGetCallBarring
voice.h, 1158
unpack_voice_SLQSVoiceGetCallBarring_t, 696
pAlphaIDInfo, 698
pCCResType, 698
pCallID, 698
pFailCause, 698
pSvcClass, 698
unpack_voice_SLQSVoiceGetCallForwardingStatus
voice.h, 1159
unpack_voice_SLQSVoiceGetCallForwardingStatus_t, 698
pAlphaIDInfo, 699
pCCResType, 699
pCallID, 699

pFailCause, 699
unpack_voice_SLQSVoiceGetCallInfo
voice.h, 1159
unpack_voice_SLQSVoiceGetCallInfo_t, 699
pAlertType, 702
pAlertingPattern, 702
pAlphaIDInfo, 702
pCallInfo, 702
pConnectNumInfo, 702
pDiagInfo, 702
pOTASPStatus, 702
pRemotePartyName, 702
pRemotePartyNum, 702
pSrvOpt, 702
pUUSInfo, 702
pVoicePrivacy, 702
unpack_voice_SLQSVoiceGetCallWaiting
voice.h, 1159
unpack_voice_SLQSVoiceGetCallWaiting_t, 703
pAlphaIDInfo, 704
pCCResType, 704
pCallID, 704
pFailCause, 704
pSvcClass, 704
unpack_voice_SLQSVoiceGetConfig
voice.h, 1161
unpack_voice_SLQSVoiceGetConfig_t, 711
pAirTimerCnt, 713
pAutoAnswerStat, 713
pCurAMRConfig, 713
pCurPrefVoiceSO, 713
pCurVoiceDomainPref, 713
pCurVoicePrivacyPref, 713
pCurrTTYMode, 713
pRoamTimerCnt, 713
unpack_voice_SLQSVoiceIndicationRegister
voice.h, 1162
unpack_voice_SLQSVoiceManageCalls
voice.h, 1162
unpack_voice_SLQSVoiceManageCalls_t, 713
pFailCause, 713
unpack_voice_SLQSVoiceOrigUSSDNoWait
voice.h, 1162
unpack_voice_SLQSVoiceSendFlash
voice.h, 1163
unpack_voice_SLQSVoiceSendFlash_t, 713
pCallID, 714
unpack_voice_SLQSVoiceSetCallBarringPassword
voice.h, 1163
unpack_voice_SLQSVoiceSetCallBarringPassword_t, 714
pAlphaIDInfo, 715
pCCResType, 715
pCallID, 715
pFailCause, 715
unpack_voice_SLQSVoiceSetConfig
voice.h, 1163
unpack_voice_SLQSVoiceSetConfig_t, 715
pAirTimerStatus, 716
pAutoAnsStatus, 716
pPrefVoiceSOStatus, 716
pRoamTimerStatus, 717
pTTYConfigStatus, 717
pVoiceDomainPrefStatus, 717
unpack_voice_SLQSVoiceSetPreferredPrivacy
voice.h, 1164
unpack_voice_SLQSVoiceSetSUPSService
voice.h, 1164
unpack_voice_SLQSVoiceSetSUPSService_t, 717
pCallID, 718
pFailCause, 718
unpack_voice_SLQSVoiceStartContDTMF
voice.h, 1164
unpack_voice_SLQSVoiceStartContDTMF_t, 718
pCallID, 718
unpack_voice_SLQSVoiceStopContDTMF
voice.h, 1165
unpack_voice_SLQSVoiceStopContDTMF_t, 718
callID, 719
unpack_wds_DHCPv4ClientLease_ind
wds.h, 1191
unpack_wds_DHCPv4ClientLease_ind_t, 719
DHCPv4LeaseOptTlv, 719
DHCPv4LeaseStateTlv, 719
IPv4AddrTlv, 719
ProfileIdTlv, 719
unpack_wds_DHCPv4ClientLeaseChange
wds.h, 1192
unpack_wds_GetAutoconnect
wds.h, 1192
unpack_wds_GetAutoconnect_t, 719
psetting, 720
unpack_wds_GetByteTotals
wds.h, 1192
unpack_wds_GetByteTotals_t, 720
pRXTotalBytes, 720
pTXTotalBytes, 720
unpack_wds_GetConnectionRate
wds.h, 1193
unpack_wds_GetConnectionRate_t, 720
currentChannelRXRate, 721
currentChannelTXRate, 721
maxChannelRXRate, 721
maxChannelTXRate, 721
unpack_wds_GetDataBearerTechnology
wds.h, 1193
unpack_wds_GetDataBearerTechnology_t, 721
pDataBearer, 722
unpack_wds_GetDefaultProfile
wds.h, 1193
unpack_wds_GetDefaultProfile_t, 722
apnname, 724
apnsize, 724
auth, 724
ipaddr, 724
ipaddrv6, 724

name, 724
namesize, 724
pdptype, 724
pridns, 724
pridnsv6, 724
secdns, 724
secdnsv6, 724
username, 724
usersize, 724
unpack_wds_GetDefaultProfileNum
wds.h, 1194
unpack_wds_GetDefaultProfileNum_t, 724
index, 725
unpack_wds_GetDormancyState
wds.h, 1194
unpack_wds_GetDormancyState_t, 725
dormancyState, 725
unpack_wds_GetLastMobileIPError
wds.h, 1195
unpack_wds_GetLastMobileIPError_t, 725
error, 726
unpack_wds_GetMobileIP
wds.h, 1195
unpack_wds_GetMobileIP_t, 726
mipMode, 726
unpack_wds_GetMobileIPProfile
wds.h, 1195
unpack_wds_GetMobileIPProfile_t, 726
AAASPI, 728
AAAState, 728
address, 728
enabled, 728
HASPI, 728
HAState, 728
NAI, 728
naiSize, 728
primaryHA, 728
revTunneling, 728
secondaryHA, 728
unpack_wds_GetPacketStatistics
wds.h, 1196
unpack_wds_GetPacketStatistics_t, 728
pRXDroppedCount, 730
pRXOKBytesLastCall, 730
pRXOkBytesCount, 730
pRXPacketErrors, 730
pRXPacketOverflows, 730
pRXPacketSuccesses, 730
pTXDroppedCount, 730
pTXOKBytesLastCall, 730
pTXOkBytesCount, 730
pTXPacketErrors, 730
pTXPacketOverflows, 730
pTXPacketSuccesses, 730
unpack_wds_GetPacketStatus
wds.h, 1196
unpack_wds_GetPacketStatus_t, 730
rXDroppedCount, 731
rXOKBytesLastCall, 732
rXOkBytesCount, 731
rXPacketErrors, 732
rXPacketOverflows, 732
rXPacketSuccesses, 732
tXDroppedCount, 732
tXOKBytesLastCall, 732
tXOkBytesCount, 732
tXPacketErrors, 732
tXPacketOverflows, 732
tXPacketSuccesses, 732
unpack_wds_GetSessionDuration
wds.h, 1196
unpack_wds_GetSessionDuration_t, 732
callDuration, 732
unpack_wds_GetSessionState
wds.h, 1197
unpack_wds_GetSessionState_t, 732
connectionStatus, 733
unpack_wds_RMSetTransferStatistics
wds.h, 1197
unpack_wds_RMSetTransferStatistics_t, 733
unpack_wds_RMTransferStatistics_ind
wds.h, 1197
unpack_wds_SLQSCreateProfile
wds.h, 1200
unpack_wds_SLQSCreateProfile_t, 733
pCreateProfileOut, 734
pProfileID, 734
Tlvresult, 734
unpack_wds_SLQSDeleteProfile
wds.h, 1200
unpack_wds_SLQSDeleteProfile_t, 734
extendedErrorCode, 734
unpack_wds_SLQSGet3GPPConfigItem
wds.h, 1201
unpack_wds_SLQSGet3GPPConfigItem_t, 734
_3gppRelease, 736
defaultPDNEnabled, 736
LTEAttachProfile, 736
profileList, 736
unpack_wds_SLQSGetCurrDataSystemStat
wds.h, 1201
unpack_wds_SLQSGetCurrDataSystemStat_t, 736
currNetworkInfo, 737
networkInfoLen, 737
prefNetwork, 737
unpack_wds_SLQSGetCurrentChannelRate
wds.h, 1201
unpack_wds_SLQSGetCurrentChannelRate_t, 737
max_channel_rx_rate, 738
max_channel_tx_rate, 738
unpack_wds_SLQSGetDUNCallInfo
wds.h, 1202
unpack_wds_SLQSGetDUNCallInfo_t, 738
callEndReason, 741
channelRate, 741
connectionStatus, 741

dataBearerTech, 741
dormancyStatus, 741
lastCallDataBearerTech, 741
mdmCallDurationActive, 741
rxOKBytesCount, 741
txOKBytesCount, 741
unpack_wds_SLQSGetDataBearerTechnology
wds.h, 1202
unpack_wds_SLQSGetDataBearerTechnology_t, 738
curDataBearerTechnology, 738
dataBearerMask, 738
lastCallDataBearerTechnology, 738
unpack_wds_SLQSGetProfileSettings
wds.h, 1202
unpack_wds_SLQSGetProfileSettings_t, 741
pProfileSettings, 742
ProfileType, 742
Tlvresult, 742
unpack_wds_SLQSGetRuntimeSettings
wds.h, 1203
unpack_wds_SLQSGetRuntimeSettings_t, 742
APNName, 744
Authentication, 744
DomainList, 744
GPRSGrantedQoS, 744
GWAddressV4, 744
IMCNflag, 744
IPFamilyPreference, 744
IPV6AddrInfo, 744
IPV6GWAddrInfo, 744
IPv4, 744
Mtu, 744
PDPType, 744
PrimaryDNSV4, 745
PrimaryDNSV6, 745
ProfileID, 745
ProfileName, 745
SecondaryDNSV4, 745
SecondaryDNSV6, 745
ServerAddrList, 745
SubnetMaskV4, 745
Technology, 745
UMTSGrantedQoS, 745
Username, 745
unpack_wds_SLQSModifyProfile
wds.h, 1203
unpack_wds_SLQSModifyProfile_t, 745
pExtErrorCode, 745
unpack_wds_SLQSResetPacketStatics
wds.h, 1203
unpack_wds_SLQSSGetDHCPv4ClientConfig
wds.h, 1205
unpack_wds_SLQSSGetDHCPv4ClientConfig_t, 750
pHwConfig, 750
unpack_wds_SLQSSGetLoopback
wds.h, 1205
unpack_wds_SLQSSGetLoopback_t, 750
ByteLoopbackMode, 751
ByteLoopbackMultiplier, 751
unpack_wds_SLQSSSetDHCPv4ClientConfig
wds.h, 1206
unpack_wds_SLQSSSetLoopback
wds.h, 1206
unpack_wds_SLQSSet3GPPConfigItem
wds.h, 1204
unpack_wds_SLQSSetIPFamilyPreference
wds.h, 1204
unpack_wds_SLQSSetIPFamilyPreference_t, 745
Tlvresult, 746
unpack_wds_SLQSSetPacketSrvStatusCallback
wds.h, 1204
unpack_wds_SLQSSetPacketSrvStatusCallback_t, 746
bearerID, 747
conn_status, 747
ipFamily, 747
reconfigReqd, 747
sessionEndReason, 747
techName, 747
verboseSessnEndReason, 748
verboseSessnEndReasonType, 748
unpack_wds_SLQSSetWdsEventCallback
wds.h, 1204
unpack_wds_SLQSSetWdsEventCallback_ind
wds.h, 1205
unpack_wds_SLQSSetWdsEventCallback_ind_t, 748
currDBTechAvail, 749
currNWInfo, 749
dBTechAvail, 749
dBTechnology, 749
dBtechExtAvail, 749
dBtechnologyExt, 749
dataSysStatAvail, 749
dormancyStatAvail, 749
dormancyStatus, 749
mipStatus, 749
mipstatAvail, 749
netInfoLen, 749
prefNetwork, 749
ratMask, 749
rx_bytes, 749
rx_pkts, 749
soMask, 749
tx_bytes, 749
tx_pkts, 749
xferStatAvail, 749
unpack_wds_SLQSStartDataSession
wds.h, 1206
unpack_wds_SLQSStartDataSession_t, 751
pFailureReason, 751
pVerboseFailReasonType, 751
pVerboseFailureReason, 751
psid, 751
unpack_wds_SLQSStopDataSession
wds.h, 1207
unpack_wds_SLQSWdsGoActive
wds.h, 1207

unpack_wds_SLQSWdsGoDormant
wds.h, 1207
unpack_wds_SLQSWdsSetEventReport
wds.h, 1208
unpack_wds_SLQSWdsSwiPDPRuntimeSettings
wds.h, 1208
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 751
apnName, 753
bearerId, 753
contextId, 753
ipv4Address, 753
ipv4GWAddress, 753
ipv6Address, 753
ipv6GWAddress, 753
unpack_wds_SetAutoconnect
wds.h, 1198
unpack_wds_SetDefaultProfile
wds.h, 1198
unpack_wds_SetDefaultProfileNum
wds.h, 1198
unpack_wds_SetMobileIP
wds.h, 1199
unpack_wds_SetMobileIPParameters
wds.h, 1199
unpack_wds_SetMobileIPProfile
wds.h, 1199
unpack_wds_SetMobileIPProfile_t, 733
unpack_wds_SetMuxID
wds.h, 1200
UnpackQmiProfileInfo
wds.h, 1171
UnpackSwiAvmsEventReportBinaryUpdateSessionInfo, 754
bBinaryType, 756
bSerity, 756
bState, 756
bUserInputRequest, 756
szDescription, 756
szName, 756
szVersion, 756
TlvPresent, 756
ulPkgDownloadComplete, 756
ulPkgDownloadSize, 756
wDescriptionLength, 756
wNameLength, 756
wUpdateCompeteStatus, 756
wUserInputTimeout, 756
wVersionLength, 756
UnpackSwiAvmsEventReportConfig, 756
bState, 757
bUserInputRequest, 757
szAlertMsg, 757
TlvPresent, 757
wAlertMsgLength, 757
wUserInputTimeout, 757
UnpackSwiAvmsEventReportConnectionRequest, 757
bUserInputRequest, 758
TlvPresent, 758
wUserInputTimeout, 758
UnpackSwiAvmsEventReportDataSessionStatus, 758
bType, 758
TlvPresent, 758
wErrorCode, 758
UnpackSwiAvmsEventReportHTTPStatus, 758
TlvPresent, 759
wHTTPStatus, 759
UnpackSwiAvmsEventReportNotification, 760
bNotification, 760
TlvPresent, 761
wSessionStatus, 761
UnpackSwiAvmsEventReportPackageID, 761
bPackageID, 761
TlvPresent, 761
UnpackSwiAvmsEventReportRegStatus, 761
bRegStatus, 761
TlvPresent, 761
UnpackSwiAvmsEventReportSessionType, 762
bType, 762
TlvPresent, 762
UnpackSwiAvmsEventReportWAMSParamChange, 762
TlvPresent, 763
wWamsChangeMask, 763
unpackWdsProfileParam, 763
SlqsProfile3GPP, 763
SlqsProfile3GPP2, 763
UpdateCompleteStatus
unpack_swioma_SLQSOMADMGetSessionInfo_t, 673
updateCompleteStatus
unpack_omaDmFotaTlv_t, 615
upinRetries
slotInf, 424
uim_slotInfo, 468
upinState
slotInf, 424
uim_slotInfo, 468
upukRetries
slotInf, 424
uim_slotInfo, 468
usageMask
loc_sensorDataUsage, 102
userInputReq
unpack_omaDmConfigTlv_t, 613
unpack_omaDmFotaTlv_t, 615
userInputTimeout
unpack_omaDmConfigTlv_t, 613
unpack_omaDmFotaTlv_t, 615
Username
unpack_wds_SLQSGetRuntimeSettings_t, 745
username
unpack_wds_GetDefaultProfile_t, 724
usersize
unpack_wds_GetDefaultProfile_t, 724
ussDCS
pack_voice_SLQSOriginateUSSD_t, 366

voice_USSInfo, 799
ussData
pack_voice_SLQSOriginateUSSD_t, 366
voice_USSInfo, 798
ussLen
pack_voice_SLQSOriginateUSSD_t, 366
voice_USSInfo, 799
UtServiceRat
unpack_imsa_SLQSGetIMSAServiceStatus_t, 537
UtServiceStatus
unpack_imsa_SLQSGetIMSAServiceStatus_t, 537
uusInfo
voice_allCallsUUSInfo, 765

VDOP
loc_precisionDilution, 99
val
unpack_qos_IPv6TrafCls_t, 630
unpack_qos_Tos_t, 648
val_3GPP2Pri
unpack_qos_swiQosFlow_t, 646
val_3GPPImCn
unpack_qos_swiQosFlow_t, 646
val_3GPPResResidualBER
unpack_qos_swiQosFlow_t, 646
val_3GPPSigInd
unpack_qos_swiQosFlow_t, 646
val_3GPPTraHdlPri
unpack_qos_swiQosFlow_t, 646
ValidMask
unpack_pds_SLQSGetGPSStateInfo_t, 627
validMask
loc_satelliteInfo, 101
ValidityCW0
unpack_nas_SLQSSwiGetLteCQI_t, 608
ValidityCW1
unpack_nas_SLQSSwiGetLteCQI_t, 608
Value
pack_swiaudio_SLQSSetM2MSpkrGain_t, 340
unpack_swiaudio_SLQSGetM2MSpkrGain_t, 662
value
pack_dms_UIMSetPINProtection_t, 257
pack_dms_UIMVerifyPIN_t, 259
value_length
DMScustSettingInfo, 51
pack_dms_SetCustFeaturesV2_t, 250
verboseSessnEndReason
unpack_wds_SLQSSetPacketSrvStatusCallback_t, 748
verboseSessnEndReasonType
unpack_wds_SLQSSetPacketSrvStatusCallback_t, 748
verifyLeft
uim_personalizationStatus, 460
uim_remainingRetries, 464
verifyPIN
pack_uim_VerifyPin_t, 365
verifyRetriesLeft
unpack_dms_UIMGetControlKeyStatus_t, 520
unpack_dms_UIMSetControlKeyProtection_t, 522
unpack_dms_UIMSetPINProtection_t, 523
version
unpack_omaDmFotaTlv_t, 615
unpack_qos_swiQosFilter_t, 643
versionString
pack_dms_SLQSSwiSetOSInfo_t, 254
unpack_dms_SLQSSwiGetOSInfo_t, 517
versionlength
unpack_omaDmFotaTlv_t, 615
vertConfidence
pack_loc_SLQSLOCInjectPosition_t, 279
vertReliability
pack_loc_SLQSLOCInjectPosition_t, 279
vertUnc
pack_loc_SLQSLOCInjectPosition_t, 279
VerticalUncertainty
unpack_pds_SLQSGetGPSStateInfo_t, 628
VirtStream
nas_protocolSubtypeElement, 183
voice.h
LITE_VOICE_SUPS_SRV_CLASS_DATA, 1143
LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITASYNC, 1143
LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITSYNC, 1143
LITE_VOICE_SUPS_SRV_CLASS_FAX, 1143
LITE_VOICE_SUPS_SRV_CLASS_NONE, 1143
LITE_VOICE_SUPS_SRV_CLASS_PACKETACCESS, 1143
LITE_VOICE_SUPS_SRV_CLASS_PADACCESS, 1143
LITE_VOICE_SUPS_SRV_CLASS_SMS, 1143
LITE_VOICE_SUPS_SRV_CLASS_VOICE, 1143
voice.h, 1138
liteServiceClassInformation, 1143
MAXVOICEUSSDLENGTH, 1142
pack_voice_AnswerUSSD, 1143
pack_voice_CancelUSSD, 1143
pack_voice_OriginateUSSD, 1144
pack_voice_SLQSOriginateUSSD, 1144
pack_voice_SLQSVoiceALSSelectLine, 1144
pack_voice_SLQSVoiceALSSetLineSwitching, 1145
pack_voice_SLQSVoiceAnswerCall, 1145
pack_voice_SLQSVoiceBindSubscription, 1145
pack_voice_SLQSVoiceBurstDTMF, 1146
pack_voice_SLQSVoiceDialCall, 1146
pack_voice_SLQSVoiceEndCall, 1146
pack_voice_SLQSVoiceGetAllCallInfo, 1147
pack_voice_SLQSVoiceGetCLIP, 1149
pack_voice_SLQSVoiceGetCLIR, 1149
pack_voice_SLQSVoiceGetCNAP, 1149
pack_voice_SLQSVoiceGetCOLP, 1150
pack_voice_SLQSVoiceGetCOLR, 1150
pack_voice_SLQSVoiceGetCallBarring, 1147
pack_voice_SLQSVoiceGetCallForwardingStatus, 1148

pack_voice_SLQSVoiceGetCallInfo, 1148
pack_voice_SLQSVoiceGetCallWaiting, 1148
pack_voice_SLQSVoiceGetConfig, 1150
pack_voice_SLQSVoiceIndicationRegister, 1151
pack_voice_SLQSVoiceManageCalls, 1151
pack_voice_SLQSVoiceOrigUSSDNoWait, 1151
pack_voice_SLQSVoiceSendFlash, 1152
pack_voice_SLQSVoiceSetCallBarringPassword, 1152
pack_voice_SLQSVoiceSetConfig, 1152
pack_voice_SLQSVoiceSetPreferredPrivacy, 1153
pack_voice_SLQSVoiceSetSUPSService, 1153
pack_voice_SLQSVoiceStartContDTMF, 1154
pack_voice_SLQSVoiceStopContDTMF, 1154
unpack_voice_AnswerUSSD, 1154
unpack_voice_CancelUSSD, 1155
unpack_voice_OriginateUSSD, 1155
unpack_voice_SLQSOriginateUSSD, 1155
unpack_voice_SLQSVoiceALSSelectLine, 1156
unpack_voice_SLQSVoiceALSSetLineSwitching, 1156
unpack_voice_SLQSVoiceAnswerCall, 1156
unpack_voice_SLQSVoiceBindSubscription, 1157
unpack_voice_SLQSVoiceBurstDTMF, 1157
unpack_voice_SLQSVoiceDialCall, 1157
unpack_voice_SLQSVoiceEndCall, 1158
unpack_voice_SLQSVoiceGetAllCallInfo, 1158
unpack_voice_SLQSVoiceGetCLIP, 1160
unpack_voice_SLQSVoiceGetCLIR, 1160
unpack_voice_SLQSVoiceGetCNAP, 1160
unpack_voice_SLQSVoiceGetCOLP, 1161
unpack_voice_SLQSVoiceGetCOLR, 1161
unpack_voice_SLQSVoiceGetCallBarring, 1158
unpack_voice_SLQSVoiceGetCallForwarding-Status, 1159
unpack_voice_SLQSVoiceGetCallInfo, 1159
unpack_voice_SLQSVoiceGetCallWaiting, 1159
unpack_voice_SLQSVoiceGetConfig, 1161
unpack_voice_SLQSVoiceIndicationRegister, 1162
unpack_voice_SLQSVoiceManageCalls, 1162
unpack_voice_SLQSVoiceOrigUSSDNoWait, 1162
unpack_voice_SLQSVoiceSendFlash, 1163
unpack_voice_SLQSVoiceSetCallBarringPassword, 1163
unpack_voice_SLQSVoiceSetConfig, 1163
unpack_voice_SLQSVoiceSetPreferredPrivacy, 1164
unpack_voice_SLQSVoiceSetSUPSService, 1164
unpack_voice_SLQSVoiceStartContDTMF, 1164
unpack_voice_SLQSVoiceStopContDTMF, 1165
voice_CLIPResp, 781
ActiveStatus, 782
ProvisionStatus, 782
voice_CLIRResp, 782
ActiveStatus, 783
ProvisionStatus, 783
voice_CNAPResp, 783
ActiveStatus, 783
ProvisionStatus, 783
voice_COLPResp, 784
ActiveStatus, 784
ProvisionStatus, 784
voice_COLRResp, 784
ActiveStatus, 785
ProvisionStatus, 785
voice_CUGInfo, 787
CUGIndex, 787
SuppOA, 787
SuppPrefCUG, 787
voice_DTMFLengths, 789
DTMFInterdigitInterval, 789
DTMFPulseWidth, 789
voice_USSInfo, 798
ussDCS, 799
ussData, 798
ussLen, 799
voice_UUSInfo, 799
UUSData, 800
UUSDatalen, 800
UUSDcs, 800
UUSType, 800
voice_airTimer, 763
airTimerValue, 764
namID, 764
voice_allCallsAlphaIDInfo, 764
AlphaIDInfo, 764
callID, 764
voice_allCallsDiagInfo, 764
callID, 765
DiagInfo, 765
voice_allCallsUUSInfo, 765
callID, 765
uusInfo, 765
voice_alphaIDInfo, 765
alphaDcs, 766
alphaLen, 766
alphaText, 766
voice_arrAlertingPattern, 766
alertingPattern, 767
callID, 767
numInstances, 767
voice_arrAlertingType, 767
AlertingType, 768
callID, 768
numInstances, 768
voice_arrAlphaID, 768
allCallsAlphaIDInfoArr, 768
numInstances, 768
voice_arrCallEndReason, 769
callEndReason, 769
callID, 769
numInstances, 770
voice_arrCallInfo, 770
getAllCallInfo, 770
numInstances, 770
voice_arrCalledPartyNum, 768

CalledPartyNum, 769
numInstances, 769
voice_arrConnectPartyNum, 770
ConnectedPartyNum, 771
numInstances, 771
voice_arrDiagInfo, 771
DiagInfo, 771
numInstances, 771
voice_arrRedirPartyNum, 771
numInstances, 772
RedirPartyNum, 772
voice_arrRemotePartyName, 772
GetAllCallRmtPtyName, 772
numInstances, 772
voice_arrRemotePartyNum, 772
numInstances, 773
RmtPtyNum, 773
voice_arrSvcOption, 773
callID, 773
numInstances, 773
srvOption, 773
voice_arrUUSInfo, 773
AllCallsUUSInfo, 774
numInstances, 774
voice_burstDTMFInfo, 774
digitCnt, 775
pCallID, 775
pDigitBuff, 775
voice_callFWExtInfo, 776
noReplyTimer, 778
numLen, 778
numPlan, 778
numType, 778
number, 778
PI, 778
SI, 778
SvcClass, 778
SvcStatus, 778
voice_callFWInfo, 778
noReplyTimer, 779
numLen, 779
number, 779
SvcClass, 779
SvcStatus, 779
voice_callFwdTypeAndPlan, 776
numberPlan, 776
numberType, 776
voice_callInfo, 779
callID, 780
callState, 780
callType, 781
direction, 781
mode, 781
voice_calledPartySubAdd, 775
extBit, 775
oddEvenInd, 775
subAddr, 775
subAddrLen, 775
subAddrType, 776
voice_ccSUPSType, 781
reason, 781
svcType, 781
voice_connectNumInfo, 785
callerID, 786
callerIDLen, 786
numPlan, 786
numPresInd, 786
numType, 787
screeningInd, 787
voice_curAMRConfig, 787
gsmAmrStat, 788
wcdmaAmrStat, 788
voice_diagInfo, 788
diagInfoLen, 788
diagnosticInfo, 788
voice_getAllCallInformation, 789
ALS, 790
Callinfo, 790
isEmpty, 790
voice_getAllCallRmtPtyName, 790
callID, 790
RemotePartyName, 790
voice_getAllCallRmtPtyNum, 790
callID, 791
RemotePartyNum, 791
voice_getCallFWExtInfo, 791
CallFWExtInfo, 791
numInstances, 791
voice_getCallFWInfo, 792
CallFWInfo, 792
numInstances, 792
voice_peerNumberInfo, 792
callID, 794
numLen, 794
numPI, 794
numPlan, 794
numSI, 794
numType, 794
number, 794
voice_prefVoiceSO, 794
evrcCapability, 796
homeOrigVoiceSO, 796
homePageVoiceSO, 796
namID, 796
roamOrigVoiceSO, 796
voice_remotePartyName, 796
callerName, 796
codingScheme, 797
nameLen, 797
namePI, 797
voice_remotePartyNum, 797
numLen, 797
presentationInd, 797
remPartyNumber, 797
voice_roamTimer, 797
namID, 798

roamTimerValue, 798
VoiceNumber
unpack_dms_GetVoiceNumber_t, 500
voiceNumberSize
unpack_dms_GetVoiceNumber_t, 500
voiceSvc
pack_voice_SLQSVoiceSetSUPSService_t, 383
VoipServiceRat
unpack_imsa_SLQSGetIMSAServiceStatus_t, 537
VoipServiceStatus
unpack_imsa_SLQSGetIMSAServiceStatus_t, 537
VolValue
pack_audio_SLQSSetAudioVolTLBConfig_t, 242
Volume
pack_audio_SLQSGetAudioVolTLBConfig_t, 238
pack_audio_SLQSSetAudioProfile_t, 241
pack_audio_SLQSSetAudioVolTLBConfig_t, 242
unpack_audio_SLQSGetAudioProfile_t, 473
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 661
voteForInit
uim_registerRefresh, 464
VsServiceRat
unpack_imsa_SLQSGetIMSAServiceStatus_t, 537
VsServiceStatus
unpack_imsa_SLQSGetIMSAServiceStatus_t, 537
VtServiceRat
unpack_imsa_SLQSGetIMSAServiceStatus_t, 537
VtServiceStatus
unpack_imsa_SLQSGetIMSAServiceStatus_t, 537

wAlertMsgLength
UnpackSwiAvmsEventReportConfig, 757
WCDMACellInfo
nas_lteWcdmaCellInfo, 163
WCDMAECIOThreshListLen
nas_WCDMAECIOThresh, 216
WCDMARSSIThreshListLen
nas_WCDMARSSIThresh, 218
WCDMASSInfo
unpack_nas_SLQSNasGetSigInfo_t, 599
wDescriptionLength
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 756
wErrorCode
UnpackSwiAvmsEventReportDataSessionStatus, 758
wHTTPStatus
UnpackSwiAvmsEventReportHTTPStatus, 759
wNameLength
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 756
WORD
SwiDataTypes.h, 1100
wSessionStatus
UnpackSwiAvmsEventReportNotification, 761
wUpdateCompeteStatus
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 756
wUserInputTimeout
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 756
UnpackSwiAvmsEventReportConfig, 757
UnpackSwiAvmsEventReportConnectionRequest, 758
wVersionLength
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 756
wWamsChangeMask
UnpackSwiAvmsEventReportWAMSParam-Change, 763
wake_mask
pack_rms_SetSMSWake_t, 324
unpack_rms_GetSMSWake_t, 649
wcdmaAmrStat
voice_curAMRConfig, 788
wcdmaRRCState
nas_WCDMAInfoLTENeighborCell, 217
wds.h
QMI_LITE_WDS_CURRENT_CALL_DB_MASK, 1172
QMI_LITE_WDS_LAST_CALL_DB_MASK, 1172
wds.h, 1165
__attribute__, 1172, 1208
BYT_STAT_STAT_MASK, 1171
IPV6_ADDR_LEN, 1171
ipv6addr, 1209
liteQmiDataBearerMasks, 1172
PACK_WDS_IPV4, 1171
PACK_WDS_IPV6, 1171
pack_wds_DHCPv4ClientLeaseChange, 1172
pack_wds_GetAutoconnect, 1172
pack_wds_GetByteTotals, 1173
pack_wds_GetConnectionRate, 1173
pack_wds_GetDataBearerTechnology, 1173
pack_wds_GetDefaultProfile, 1174
pack_wds_GetDefaultProfileNum, 1174
pack_wds_GetDormancyState, 1175
pack_wds_GetLastMobileIPError, 1175
pack_wds_GetMobileIP, 1175
pack_wds_GetMobileIPProfile, 1176
pack_wds_GetPacketStatistics, 1176
pack_wds_GetPacketStatus, 1177
pack_wds_GetSessionDuration, 1177
pack_wds_GetSessionState, 1178
pack_wds_RMSetTransferStatistics, 1178
pack_wds_SLQSCreateProfile, 1181
pack_wds_SLQSDeleteProfile, 1182
pack_wds_SLQSGet3GPPConfigItem, 1182
pack_wds_SLQSGetCurrDataSystemStat, 1183
pack_wds_SLQSGetCurrentChannelRate, 1183
pack_wds_SLQSGetDUNCallInfo, 1184
pack_wds_SLQSGetDataBearerTechnology, 1183
pack_wds_SLQSGetProfileSettings, 1184
pack_wds_SLQSGetRuntimeSettings, 1185
pack_wds_SLQSModifyProfile, 1185
pack_wds_SLQSResetPacketStatics, 1186

pack_wds_SLQSSGetDHCPv4ClientConfig, 1187
pack_wds_SLQSSGetLoopback, 1188
pack_wds_SLQSSSetDHCPv4ClientConfig, 1188
pack_wds_SLQSSSetLoopback, 1188
pack_wds_SLQSSet3GPPConfigItem, 1186
pack_wds_SLQSSetIPFamilyPreference, 1186
pack_wds_SLQSSetWdsEventCallback, 1187
pack_wds_SLQSStartDataSession, 1189
pack_wds_SLQSStopDataSession, 1189
pack_wds_SLQSWdsGoActive, 1190
pack_wds_SLQSWdsGoDormant, 1190
pack_wds_SLQSWdsSetEventReport, 1190
pack_wds_SLQSWdsSwiPDPRuntimeSettings, 1191
pack_wds_SetAutoconnect, 1178
pack_wds_SetDefaultProfile, 1179
pack_wds_SetDefaultProfileNum, 1179
pack_wds_SetMobileIP, 1180
pack_wds_SetMobileIPParameters, 1180
pack_wds_SetMobileIPProfile, 1180
pack_wds_SetMuxID, 1181
prefix, 1209
unpack_wds_DHCPv4ClientLease_ind, 1191
unpack_wds_DHCPv4ClientLeaseChange, 1192
unpack_wds_GetAutoconnect, 1192
unpack_wds_GetByteTotals, 1192
unpack_wds_GetConnectionRate, 1193
unpack_wds_GetDataBearerTechnology, 1193
unpack_wds_GetDefaultProfile, 1193
unpack_wds_GetDefaultProfileNum, 1194
unpack_wds_GetDormancyState, 1194
unpack_wds_GetLastMobileIPError, 1195
unpack_wds_GetMobileIP, 1195
unpack_wds_GetMobileIPProfile, 1195
unpack_wds_GetPacketStatistics, 1196
unpack_wds_GetPacketStatus, 1196
unpack_wds_GetSessionDuration, 1196
unpack_wds_GetSessionState, 1197
unpack_wds_RMSetTransferStatistics, 1197
unpack_wds_RMTransferStatistics_ind, 1197
unpack_wds_SLQSCreateProfile, 1200
unpack_wds_SLQSDeleteProfile, 1200
unpack_wds_SLQSGet3GPPConfigItem, 1201
unpack_wds_SLQSGetCurrDataSystemStat, 1201
unpack_wds_SLQSGetCurrentChannelRate, 1201
unpack_wds_SLQSGetDUNCallInfo, 1202
unpack_wds_SLQSGetDataBearerTechnology, 1202
unpack_wds_SLQSGetProfileSettings, 1202
unpack_wds_SLQSGetRuntimeSettings, 1203
unpack_wds_SLQSModifyProfile, 1203
unpack_wds_SLQSResetPacketStatics, 1203
unpack_wds_SLQSSGetDHCPv4ClientConfig, 1205
unpack_wds_SLQSSGetLoopback, 1205
unpack_wds_SLQSSSetDHCPv4ClientConfig, 1206
unpack_wds_SLQSSSetLoopback, 1206
unpack_wds_SLQSSet3GPPConfigItem, 1204
unpack_wds_SLQSSetIPFamilyPreference, 1204
unpack_wds_SLQSSetPacketSrvStatusCallback, 1204
unpack_wds_SLQSSetWdsEventCallback, 1204
unpack_wds_SLQSSetWdsEventCallback_ind, 1205
unpack_wds_SLQSStartDataSession, 1206
unpack_wds_SLQSStopDataSession, 1207
unpack_wds_SLQSWdsGoActive, 1207
unpack_wds_SLQSWdsGoDormant, 1207
unpack_wds_SLQSWdsSetEventReport, 1208
unpack_wds_SLQSWdsSwiPDPRuntimeSettings, 1208
unpack_wds_SetAutoconnect, 1198
unpack_wds_SetDefaultProfile, 1198
unpack_wds_SetDefaultProfileNum, 1198
unpack_wds_SetMobileIP, 1199
unpack_wds_SetMobileIPParameters, 1199
unpack_wds_SetMobileIPProfile, 1199
unpack_wds_SetMuxID, 1200
UnpackQmiProfileInfo, 1171
wds_DHCPLeaseOptTlv, 802
numOpt, 802
optList, 802
optListData, 802
TlvPresent, 803
wds_DHCPLeaseStateTlv, 803
leaseState, 803
TlvPresent, 803
wds_DHCPOpt, 803
optCode, 804
optValLen, 804
pOptVal, 804
wds_DHCPProfileIdTlv, 804
profileId, 804
profileType, 804
TlvPresent, 804
wds_DHCPv4HWConfig, 804
chaddr, 805
chaddrLen, 805
hwType, 805
wds_DHCPv4Option, 805
optCode, 805
optVal, 805
optValLen, 806
wds_DHCPv4OptionList, 806
numOpt, 806
pOptList, 806
wds_DHCPv4ProfileId, 806
profileId, 806
profileType, 807
wds_DataULongLongTlv, 801
TlvPresent, 801
ullData, 802
wds_DataULongTlv, 802
TlvPresent, 802
ulData, 802

wds_Domain, 807
domainLen, 807
domainName, 807
wds_DomainNameList, 807
domain, 808
numInstances, 808
wds_GPRSQoS, 808
delayClass, 808
meanThroughputClass, 808
peakThroughputClass, 808
precedenceClass, 808
reliabilityClass, 808
wds_IPV6AddressInfo, 809
IPAddressV6, 809
IPV6PrefixLen, 809
wds_IPV6GWAddressInfo, 809
gwAddressV6, 810
gwV6PrefixLen, 810
wds_IPv4AdTlv, 809
IPv4Addr, 809
TlvPresent, 809
wds_PCSCFFQDNAddress, 810
fqdnAddr, 810
fqdnLen, 810
wds_PCSCFFQDNAddressList, 811
numInstances, 811
pcsfFQDNAddress, 811
wds_PCSCFIPv4ServerAddressList, 811
numInstances, 812
pscsfIPv4Addr, 812
wds_ProfileIdentifier, 812
profileIndex, 812
profileType, 812
wds_TrStatInd, 813
statsMask, 814
statsPeriod, 814
wds_UMTSMinQoS, 814
deliveryErrSDU, 816
grntDownlinkBitrate, 816
grntUplinkBitrate, 816
maxDownlinkBitrate, 816
maxSDUSize, 816
maxUplinkBitrate, 816
qosDeliveryOrder, 816
resBerRatio, 816
sduErrorRatio, 816
trafficClass, 816
trafficPriority, 816
transferDelay, 816
wds_currNetworkInfo, 800
NetworkType, 801
RATMask, 801
SOMask, 801
wds_profileInfo, 812
SlqsProfile3GPP, 813
SlqsProfile3GPP2, 813
wds_transferStatInd, 813
StatsMask, 813
StatsPeriod, 813
wdsDhcpv4HwConfig, 816
chaddr, 817
chaddrLen, 817
hwType, 817
wdsDhcpv4Option, 817
optCode, 817
optVal, 818
optValLen, 818
wdsDhcpv4OptionList, 818
numOpt, 818
pOptList, 818
wdsDhcpv4ProfileId, 818
profileId, 819
profileType, 819

xAxis
sensorData_t, 421
xferStatAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 749
xid
pack_loc_SLQSLOCGetBestAvailPos_t, 273
pack_qmi_t, 322
unpack_qmi_t, 628
xtra_start_gps_minutes
unpack_pds_SLQSGetGPSStateInfo_t, 628
xtra_start_gps_week
unpack_pds_SLQSGetGPSStateInfo_t, 628
xtra_valid_duration_hours
unpack_pds_SLQSGetGPSStateInfo_t, 628

yAxis
sensorData_t, 421
year
nas_timeInfo, 209
nas_UniversalTime, 215

zAxis
sensorData_t, 421