LinuxQMISDK-Lite

SLQS04.00.19

Generated by Doxygen 1.8.6

Fri Mar 8 2019 03:09:27

Contents

1 Welcome to the Sierra Wireless Linux QMI SDK API Reference Guide **1**

1.1 Important Notice . . . 1

1.2 Limitation of Liability . . . 1

1.3 Patents . . . 1

1.4 Copyright . . . 2

1.5 Trademarks . . . 2

1.6 Contact Information . . . 2

2 Module Index **3**

2.1 Modules . . . 3

3 Namespace Index **5**

3.1 Namespace List . . . 5

4 Data Structure Index **7**

4.1 Data Structures . . . 7

5 File Index **27**

5.1 File List . . . 27

6 Module Documentation **29**

6.1 QMI pack/unpack (lite-qmi) . . . 29

6.1.1 Detailed Description . . . 29

6.2 Streaming Download Protocol (lite-fw) . . . 30

6.2.1 Detailed Description . . . 30

7 Namespace Documentation **31**

7.1 Tables Namespace Reference . . . 31

7.1.1 Detailed Description . . . 31

8 Data Structure Documentation **33**

8.1 _litefw_FirmwareInfo_ Struct Reference . . . 33

8.1.1 Detailed Description . . . 33

8.1.2 Field Documentation . . . 33

8.1.2.1 szCarrier_str . . . 34
8.1.2.2 szCarrierPriversion_str . . . 34
8.1.2.3 szFwversion_str . . . 34
8.1.2.4 szModelid_str . . . 34
8.1.2.5 szPackageid_str . . . 34
8.1.2.6 szSku_str . . . 34
8.2 altSrcInfo_t Struct Reference . . . 34
8.2.1 Detailed Description . . . 34
8.2.2 Field Documentation . . . 35
8.2.2.1 coverage . . . 35
8.2.2.2 linkage . . . 35
8.2.2.3 source . . . 35
8.3 appStats Struct Reference . . . 35
8.3.1 Detailed Description . . . 35
8.3.2 Field Documentation . . . 37
8.3.2.1 aidLength . . . 37
8.3.2.2 aidVal . . . 37
8.3.2.3 appState . . . 37
8.3.2.4 appType . . . 37
8.3.2.5 persoFeature . . . 37
8.3.2.6 persoRetries . . . 37
8.3.2.7 persoState . . . 37
8.3.2.8 persoUnblockRetries . . . 38
8.3.2.9 pin1Retries . . . 38
8.3.2.10 pin1State . . . 38
8.3.2.11 pin2Retries . . . 38
8.3.2.12 pin2State . . . 38
8.3.2.13 puk1Retries . . . 38
8.3.2.14 puk2Retries . . . 38
8.3.2.15 univPin . . . 38
8.4 audio_RXAGCList Struct Reference . . . 38
8.4.1 Detailed Description . . . 38
8.4.2 Field Documentation . . . 38
8.4.2.1 pRXAIG . . . 39
8.4.2.2 pRXComprSlope . . . 39
8.4.2.3 pRXComprThres . . . 39
8.4.2.4 pRXExpSlope . . . 39
8.4.2.5 pRXExpThres . . . 39
8.4.2.6 pRXStaticGain . . . 39
8.5 audio_RXAVCList Struct Reference . . . 39

8.5.1 Detailed Description . . . 39
8.5.2 Field Documentation . . . 39
8.5.2.1 pAVRXAVCHeadroom . . . 39
8.5.2.2 pAVRXAVCSens . . . 39
8.6 audio_RXPCMIIRFltr Struct Reference . . . 39
8.6.1 Detailed Description . . . 39
8.6.2 Field Documentation . . . 41
8.6.2.1 pFlag . . . 41
8.6.2.2 pStage0Val . . . 41
8.6.2.3 pStage1Val . . . 41
8.6.2.4 pStage2Val . . . 41
8.6.2.5 pStage3Val . . . 41
8.6.2.6 pStage4Val . . . 41
8.6.2.7 pStageCnt . . . 41
8.7 audio_TXAGCList Struct Reference . . . 41
8.7.1 Detailed Description . . . 41
8.7.2 Field Documentation . . . 41
8.7.2.1 pTXAIG . . . 42
8.7.2.2 pTXComprSlope . . . 42
8.7.2.3 pTXComprThres . . . 42
8.7.2.4 pTXExpSlope . . . 42
8.7.2.5 pTXExpThres . . . 42
8.7.2.6 pTXStaticGain . . . 42
8.8 audio_TXPCMIIRFltr Struct Reference . . . 42
8.8.1 Detailed Description . . . 42
8.8.2 Field Documentation . . . 43
8.8.2.1 pFlag . . . 43
8.8.2.2 pStage0Val . . . 43
8.8.2.3 pStage1Val . . . 43
8.8.2.4 pStage2Val . . . 43
8.8.2.5 pStage3Val . . . 43
8.8.2.6 pStage4Val . . . 43
8.8.2.7 pStageCnt . . . 43
8.9 CarrierImage_t Struct Reference . . . 43
8.9.1 Detailed Description . . . 44
8.9.2 Field Documentation . . . 44
8.9.2.1 m_FwBuildId . . . 44
8.9.2.2 m_FwImageId . . . 44
8.9.2.3 m_nCarrierId . . . 44
8.9.2.4 m_nFolderId . . . 44

8.9.2.5 m_nStorage . . . 44
8.9.2.6 m_PriBuildId . . . 45
8.9.2.7 m_PriImageId . . . 45
8.10 cat_AlPhaIdentifierTlv Struct Reference . . . 45
8.10.1 Detailed Description . . . 45
8.10.2 Field Documentation . . . 45
8.10.2.1 AlphaID . . . 45
8.10.2.2 AlphaIDLength . . . 45
8.10.2.3 ReferenceID . . . 45
8.11 cat_commonEventTlv Struct Reference . . . 45
8.11.1 Detailed Description . . . 45
8.11.2 Field Documentation . . . 46
8.11.2.1 CatEvent . . . 46
8.11.2.2 EventID . . . 46
8.11.2.3 EventLength . . . 46
8.11.2.4 TlvPresent . . . 46
8.12 cat_currentCatEvent Union Reference . . . 46
8.12.1 Detailed Description . . . 46
8.12.2 Field Documentation . . . 46
8.12.2.1 CatAlphaIdtfr . . . 46
8.12.2.2 CatEndPS . . . 46
8.12.2.3 CatEventLst . . . 46
8.12.2.4 CatEvIDData . . . 46
8.12.2.5 CatRefresh . . . 46
8.13 cat_EndProactiveSessionTlv Struct Reference . . . 47
8.13.1 Detailed Description . . . 47
8.13.2 Field Documentation . . . 47
8.13.2.1 EndProactiveSession . . . 47
8.14 cat_EventIDDataTlv Struct Reference . . . 47
8.14.1 Detailed Description . . . 47
8.14.2 Field Documentation . . . 47
8.14.2.1 Data . . . 47
8.14.2.2 DataLength . . . 47
8.14.2.3 ReferenceID . . . 47
8.15 cat_EventListTlv Struct Reference . . . 47
8.15.1 Detailed Description . . . 48
8.15.2 Field Documentation . . . 48
8.15.2.1 SetupEventList . . . 48
8.16 cat_RefreshTlv Struct Reference . . . 48
8.16.1 Detailed Description . . . 48

8.16.2 Field Documentation . . . 48
8.16.2.1 RefreshMode . . . 48
8.16.2.2 RefreshStage . . . 48
8.17 cdmaSSInfo Struct Reference . . . 48
8.17.1 Detailed Description . . . 49
8.17.2 Field Documentation . . . 49
8.17.2.1 ecio . . . 49
8.17.2.2 rssi . . . 49
8.18 connectionStatus Struct Reference . . . 49
8.18.1 Detailed Description . . . 49
8.18.2 Field Documentation . . . 49
8.18.2.1 MDMCallDuration . . . 49
8.18.2.2 MDMConnStatus . . . 50
8.19 crashInfoParams Struct Reference . . . 50
8.19.1 Detailed Description . . . 50
8.19.2 Field Documentation . . . 50
8.19.2.1 crashInfo . . . 50
8.19.2.2 crashStatus . . . 50
8.20 crashInformation Struct Reference . . . 50
8.20.1 Detailed Description . . . 50
8.20.2 Field Documentation . . . 51
8.20.2.1 crashData . . . 51
8.20.2.2 crashId . . . 51
8.20.2.3 crashString . . . 51
8.20.2.4 crashStrlen . . . 51
8.20.2.5 gcdumpString . . . 51
8.20.2.6 gcdumpStrlen . . . 51
8.20.2.7 numCrashes . . . 51
8.21 currNetworkInfo Struct Reference . . . 51
8.21.1 Detailed Description . . . 51
8.21.2 Field Documentation . . . 52
8.21.2.1 NetworkType . . . 52
8.21.2.2 RATMask . . . 52
8.21.2.3 SOMask . . . 52
8.22 dms_ActivationStatusTlv Struct Reference . . . 52
8.22.1 Detailed Description . . . 52
8.22.2 Field Documentation . . . 52
8.22.2.1 activationStatus . . . 52
8.22.2.2 TlvPresent . . . 52
8.23 dms_OperatingModeTlv Struct Reference . . . 52

8.23.1 Detailed Description . . . 53
8.23.2 Field Documentation . . . 53
8.23.2.1 operatingMode . . . 53
8.23.2.2 TlvPresent . . . 53
8.24 dms_PSMActiveTimerIndTlv Struct Reference . . . 53
8.24.1 Detailed Description . . . 53
8.24.2 Field Documentation . . . 54
8.24.2.1 ActiveTimerInd . . . 54
8.24.2.2 TlvPresent . . . 54
8.25 dms_PSMActiveTimerTlv Struct Reference . . . 54
8.25.1 Detailed Description . . . 54
8.25.2 Field Documentation . . . 54
8.25.2.1 activeTimer . . . 54
8.25.2.2 TlvPresent . . . 54
8.26 dms_PSMDurationDueToOOSTlv Struct Reference . . . 54
8.26.1 Detailed Description . . . 54
8.26.2 Field Documentation . . . 55
8.26.2.1 durationDueToOOS . . . 55
8.26.2.2 TlvPresent . . . 55
8.27 dms_PSMDurationThresholdTlv Struct Reference . . . 55
8.27.1 Detailed Description . . . 55
8.27.2 Field Documentation . . . 55
8.27.2.1 durationThreshold . . . 55
8.27.2.2 TlvPresent . . . 55
8.28 dms_PSMEarlyWakeupTimeTlv Struct Reference . . . 55
8.28.1 Detailed Description . . . 55
8.28.2 Field Documentation . . . 56
8.28.2.1 earlyWakeupTime . . . 56
8.28.2.2 TlvPresent . . . 56
8.29 dms_PSMEnableStateIndTlv Struct Reference . . . 56
8.29.1 Detailed Description . . . 56
8.29.2 Field Documentation . . . 56
8.29.2.1 EnableStateInd . . . 56
8.29.2.2 TlvPresent . . . 56
8.30 dms_PSMEnableStateTlv Struct Reference . . . 56
8.30.1 Detailed Description . . . 56
8.30.2 Field Documentation . . . 57
8.30.2.1 enableState . . . 57
8.30.2.2 TlvPresent . . . 57
8.31 dms_PSMPeriodicUpdateTimerIndTlv Struct Reference . . . 57

8.31.1 Detailed Description . . . 57
8.31.2 Field Documentation . . . 57
8.31.2.1 PeriodicUpdateTimerInd . . . 57
8.31.2.2 TlvPresent . . . 57
8.32 dms_PSMPeriodicUpdateTimerTlv Struct Reference . . . 57
8.32.1 Detailed Description . . . 57
8.32.2 Field Documentation . . . 58
8.32.2.1 periodicUpdateTimer . . . 58
8.32.2.2 TlvPresent . . . 58
8.33 dms_PSMRandomizationWindowTlv Struct Reference . . . 58
8.33.1 Detailed Description . . . 58
8.33.2 Field Documentation . . . 58
8.33.2.1 randomizationWindow . . . 58
8.33.2.2 TlvPresent . . . 58
8.34 dms_TemperatureTlv Struct Reference . . . 58
8.34.1 Detailed Description . . . 58
8.34.2 Field Documentation . . . 59
8.34.2.1 Temperature . . . 59
8.34.2.2 TempStat . . . 59
8.34.2.3 TlvPresent . . . 59
8.35 dms_UimAutoSwitchActSlotTlv Struct Reference . . . 59
8.35.1 Detailed Description . . . 59
8.35.2 Field Documentation . . . 59
8.35.2.1 TlvPresent . . . 59
8.35.2.2 uimAutoSwitchActSlot . . . 60
8.36 dms_UimStatusTlv Struct Reference . . . 60
8.36.1 Detailed Description . . . 60
8.36.2 Field Documentation . . . 60
8.36.2.1 event . . . 60
8.36.2.2 intf . . . 60
8.36.2.3 TlvPresent . . . 60
8.37 dms_VoltageTlv Struct Reference . . . 60
8.37.1 Detailed Description . . . 60
8.37.2 Field Documentation . . . 61
8.37.2.1 TlvPresent . . . 61
8.37.2.2 Voltage . . . 61
8.37.2.3 VoltStat . . . 61
8.38 DMScustSettingInfo Struct Reference . . . 61
8.38.1 Detailed Description . . . 61
8.38.2 Field Documentation . . . 62

8.38.2.1 cust_attr . . . 62
8.38.2.2 cust_id . . . 62
8.38.2.3 cust_value . . . 62
8.38.2.4 id_length . . . 62
8.38.2.5 value_length . . . 62
8.39 DMScustSettingList Struct Reference . . . 62
8.39.1 Detailed Description . . . 62
8.39.2 Field Documentation . . . 62
8.39.2.1 custSetting . . . 62
8.39.2.2 list_type . . . 62
8.39.2.3 num_instances . . . 62
8.40 DMSgetCustomFeatureV2 Struct Reference . . . 63
8.40.1 Detailed Description . . . 63
8.40.2 Field Documentation . . . 63
8.40.2.1 pCustSettingInfo . . . 63
8.40.2.2 pCustSettingList . . . 63
8.40.2.3 pGetCustomInput . . . 63
8.41 DMSgetCustomInput Struct Reference . . . 63
8.41.1 Detailed Description . . . 63
8.41.2 Field Documentation . . . 64
8.41.2.1 cust_id . . . 64
8.41.2.2 list_type . . . 64
8.42 dunchannelRate Struct Reference . . . 64
8.42.1 Detailed Description . . . 64
8.42.2 Field Documentation . . . 64
8.42.2.1 CurrChanRxRate . . . 64
8.42.2.2 CurrChanTxRate . . . 64
8.42.2.3 MaxChanRxRate . . . 64
8.42.2.4 MaxChanTxRate . . . 64
8.43 eriDataparams Struct Reference . . . 64
8.43.1 Detailed Description . . . 65
8.43.2 Field Documentation . . . 65
8.43.2.1 eriData . . . 65
8.43.2.2 eriDataLen . . . 65
8.44 eTWSPLMNInfoTlv Struct Reference . . . 65
8.44.1 Detailed Description . . . 65
8.44.2 Field Documentation . . . 65
8.44.2.1 ETWSPLMNInfo . . . 65
8.44.2.2 TlvPresent . . . 65
8.45 FMSImageElement Struct Reference . . . 65

8.45.1 Detailed Description . . . 66
8.45.2 Field Documentation . . . 66
8.45.2.1 buildId . . . 66
8.45.2.2 buildIdLength . . . 66
8.45.2.3 imageId . . . 66
8.45.2.4 imageType . . . 66
8.46 FMSImageIdElement Struct Reference . . . 66
8.46.1 Detailed Description . . . 66
8.46.2 Field Documentation . . . 67
8.46.2.1 buildID . . . 67
8.46.2.2 buildIDLength . . . 67
8.46.2.3 failureCount . . . 67
8.46.2.4 imageID . . . 67
8.46.2.5 storageIndex . . . 67
8.47 FMSImageIDEntries Struct Reference . . . 67
8.47.1 Detailed Description . . . 67
8.47.2 Field Documentation . . . 68
8.47.2.1 executingImage . . . 68
8.47.2.2 imageIDElement . . . 68
8.47.2.3 imageIDSize . . . 68
8.47.2.4 imageType . . . 68
8.47.2.5 maxImages . . . 68
8.48 FMSImageList Struct Reference . . . 68
8.48.1 Detailed Description . . . 68
8.48.2 Field Documentation . . . 68
8.48.2.1 imageIDEntries . . . 68
8.48.2.2 listSize . . . 68
8.49 FMSPrefImageList Struct Reference . . . 69
8.49.1 Detailed Description . . . 69
8.49.2 Field Documentation . . . 69
8.49.2.1 listEntries . . . 69
8.49.2.2 listSize . . . 69
8.50 hdrSSInfo Struct Reference . . . 69
8.50.1 Detailed Description . . . 69
8.50.2 Field Documentation . . . 70
8.50.2.1 ecio . . . 70
8.50.2.2 io . . . 70
8.50.2.3 rssi . . . 70
8.50.2.4 sinr . . . 70
8.51 image_info_t Struct Reference . . . 70

8.51.1 Detailed Description . . . 70
8.51.2 Field Documentation . . . 71
8.51.2.1 buildID . . . 71
8.51.2.2 buildIDLen . . . 71
8.51.2.3 imageType . . . 71
8.51.2.4 uniqueID . . . 71
8.52 ims_AMRModeInfo Struct Reference . . . 71
8.52.1 Detailed Description . . . 71
8.52.2 Field Documentation . . . 71
8.52.2.1 amrMode . . . 72
8.52.2.2 TlvPresent . . . 72
8.53 ims_AMROctAlgnInfo Struct Reference . . . 72
8.53.1 Detailed Description . . . 72
8.53.2 Field Documentation . . . 72
8.53.2.1 amrOctAlgn . . . 72
8.53.2.2 TlvPresent . . . 72
8.54 ims_AMRWBModeInfo Struct Reference . . . 72
8.54.1 Detailed Description . . . 72
8.54.2 Field Documentation . . . 73
8.54.2.1 amrWBMode . . . 73
8.54.2.2 TlvPresent . . . 73
8.55 ims_AMRWBOctAlgnInfo Struct Reference . . . 73
8.55.1 Detailed Description . . . 73
8.55.2 Field Documentation . . . 73
8.55.2.1 amrWBOctAlgn . . . 73
8.55.2.2 TlvPresent . . . 73
8.56 ims_CSCFPortNameInfo Struct Reference . . . 73
8.56.1 Detailed Description . . . 74
8.56.2 Field Documentation . . . 74
8.56.2.1 cscfPortName . . . 74
8.56.2.2 TlvPresent . . . 74
8.57 ims_EnabAMRWBInfo Struct Reference . . . 74
8.57.1 Detailed Description . . . 74
8.57.2 Field Documentation . . . 74
8.57.2.1 amrWBEnable . . . 74
8.57.2.2 TlvPresent . . . 74
8.58 ims_EnabSCRAMRInfo Struct Reference . . . 74
8.58.1 Detailed Description . . . 74
8.58.2 Field Documentation . . . 75
8.58.2.1 scrAmrEnable . . . 75

8.58.2.2 TlvPresent . . . 75
8.59 ims_EnabSCRAMRWBInfo Struct Reference . . . 75
8.59.1 Detailed Description . . . 75
8.59.2 Field Documentation . . . 75
8.59.2.1 scrAmrWBEnable . . . 75
8.59.2.2 TlvPresent . . . 75
8.60 ims_IMSDomainInfo Struct Reference . . . 75
8.60.1 Detailed Description . . . 75
8.60.2 Field Documentation . . . 76
8.60.2.1 imsDomainName . . . 76
8.60.2.2 TlvPresent . . . 76
8.61 ims_IMSTestModeInfo Struct Reference . . . 76
8.61.1 Detailed Description . . . 76
8.61.2 Field Documentation . . . 76
8.61.2.1 imsTestMode . . . 76
8.61.2.2 TlvPresent . . . 76
8.62 ims_MinSessExpInfo Struct Reference . . . 76
8.62.1 Detailed Description . . . 76
8.62.2 Field Documentation . . . 77
8.62.2.1 minSessExp . . . 77
8.62.2.2 TlvPresent . . . 77
8.63 ims_PCSCFPortInfo Struct Reference . . . 77
8.63.1 Detailed Description . . . 77
8.63.2 Field Documentation . . . 77
8.63.2.1 priCSCFPort . . . 77
8.63.2.2 TlvPresent . . . 77
8.64 ims_PhCtxtURIInfo Struct Reference . . . 77
8.64.1 Detailed Description . . . 77
8.64.2 Field Documentation . . . 77
8.64.2.1 PhCtxtURI . . . 78
8.64.2.2 TlvPresent . . . 78
8.65 ims_RngBkTmrInfo Struct Reference . . . 78
8.65.1 Detailed Description . . . 78
8.65.2 Field Documentation . . . 78
8.65.2.1 RingBkTmr . . . 78
8.65.2.2 TlvPresent . . . 78
8.66 ims_RngTmrInfo Struct Reference . . . 78
8.66.1 Detailed Description . . . 78
8.66.2 Field Documentation . . . 78
8.66.2.1 RingTmr . . . 79

8.66.2.2 TlvPresent . . . 79
8.67 ims_RTPRTCPInactTmrDurInfo Struct Reference . . . 79
8.67.1 Detailed Description . . . 79
8.67.2 Field Documentation . . . 79
8.67.2.1 InactTmr . . . 79
8.67.2.2 TlvPresent . . . 79
8.68 ims_SessDurInfo Struct Reference . . . 79
8.68.1 Detailed Description . . . 79
8.68.2 Field Documentation . . . 79
8.68.2.1 sessExp . . . 80
8.68.2.2 TlvPresent . . . 80
8.69 ims_SigCompEnInfo Struct Reference . . . 80
8.69.1 Detailed Description . . . 80
8.69.2 Field Documentation . . . 80
8.69.2.1 SigCompEn . . . 80
8.69.2.2 TlvPresent . . . 80
8.70 ims_SIPPortInfo Struct Reference . . . 80
8.70.1 Detailed Description . . . 80
8.70.2 Field Documentation . . . 80
8.70.2.1 SIPLocalPort . . . 80
8.70.2.2 TlvPresent . . . 80
8.71 ims_SIPRegnTmrInfo Struct Reference . . . 81
8.71.1 Detailed Description . . . 81
8.71.2 Field Documentation . . . 81
8.71.2.1 TlvPresent . . . 81
8.71.2.2 tmrSIPRegn . . . 81
8.72 ims_SMSFmtInfo Struct Reference . . . 81
8.72.1 Detailed Description . . . 81
8.72.2 Field Documentation . . . 81
8.72.2.1 smsFormat . . . 81
8.72.2.2 TlvPresent . . . 81
8.73 ims_SMSoIPNwInfo Struct Reference . . . 82
8.73.1 Detailed Description . . . 82
8.73.2 Field Documentation . . . 82
8.73.2.1 smsoIPNW . . . 82
8.73.2.2 TlvPresent . . . 82
8.74 ims_SubscrTmrInfo Struct Reference . . . 82
8.74.1 Detailed Description . . . 82
8.74.2 Field Documentation . . . 82
8.74.2.1 subscrTmr . . . 82

8.74.2.2 TlvPresent . . . 82
8.75 ims_TmrT1Info Struct Reference . . . 82
8.75.1 Detailed Description . . . 83
8.75.2 Field Documentation . . . 83
8.75.2.1 TlvPresent . . . 83
8.75.2.2 tmrT1 . . . 83
8.76 ims_TmrT2Info Struct Reference . . . 83
8.76.1 Detailed Description . . . 83
8.76.2 Field Documentation . . . 83
8.76.2.1 TlvPresent . . . 83
8.76.2.2 tmrT2 . . . 83
8.77 ims_TmrTfInfo Struct Reference . . . 83
8.77.1 Detailed Description . . . 84
8.77.2 Field Documentation . . . 84
8.77.2.1 TlvPresent . . . 84
8.77.2.2 tmrTf . . . 84
8.78 imsa_IMSFailErrCodeTlv Struct Reference . . . 84
8.78.1 Detailed Description . . . 84
8.78.2 Field Documentation . . . 84
8.78.2.1 ImsFailErrCode . . . 84
8.78.2.2 TlvPresent . . . 84
8.79 imsa_IMSRegStatusErrorCodeInfo Struct Reference . . . 84
8.79.1 Detailed Description . . . 85
8.79.2 Field Documentation . . . 85
8.79.2.1 ErrorCode . . . 85
8.79.2.2 TlvPresent . . . 85
8.80 imsa_IMSRegStatusInfo Struct Reference . . . 85
8.80.1 Detailed Description . . . 85
8.80.2 Field Documentation . . . 85
8.80.2.1 ImsRegistered . . . 85
8.80.2.2 TlvPresent . . . 85
8.81 imsa_NewIMSRegStatusInfo Struct Reference . . . 86
8.81.1 Detailed Description . . . 86
8.81.2 Field Documentation . . . 86
8.81.2.1 ImsRegStatus . . . 86
8.81.2.2 TlvPresent . . . 86
8.82 imsa_RatHandoverStatusInfo Struct Reference . . . 86
8.82.1 Detailed Description . . . 86
8.82.2 Field Documentation . . . 87
8.82.2.1 ErrorCodeData . . . 87

8.82.2.2 ErrorCodeLen . . . 87
8.82.2.3 RatHandoverStatus . . . 87
8.82.2.4 SourceRAT . . . 87
8.82.2.5 TargetRAT . . . 87
8.82.2.6 TlvPresent . . . 87
8.83 imsa_SmsRatInfo Struct Reference . . . 87
8.83.1 Detailed Description . . . 87
8.83.2 Field Documentation . . . 87
8.83.2.1 SmsRatVal . . . 88
8.83.2.2 TlvPresent . . . 88
8.84 imsa_SmsSvcStatusInfo Struct Reference . . . 88
8.84.1 Detailed Description . . . 88
8.84.2 Field Documentation . . . 88
8.84.2.1 SmsSvcStatus . . . 88
8.84.2.2 TlvPresent . . . 88
8.85 imsa_UtRatInfo Struct Reference . . . 88
8.85.1 Detailed Description . . . 88
8.85.2 Field Documentation . . . 89
8.85.2.1 TlvPresent . . . 89
8.85.2.2 UtRatVal . . . 89
8.86 imsa_UtSvcStatusInfo Struct Reference . . . 89
8.86.1 Detailed Description . . . 89
8.86.2 Field Documentation . . . 89
8.86.2.1 TlvPresent . . . 89
8.86.2.2 UtSvcStatus . . . 89
8.87 imsa_VoipRatInfo Struct Reference . . . 89
8.87.1 Detailed Description . . . 89
8.87.2 Field Documentation . . . 90
8.87.2.1 TlvPresent . . . 90
8.87.2.2 VoipRatVal . . . 90
8.88 imsa_VoipSvcStatusInfo Struct Reference . . . 90
8.88.1 Detailed Description . . . 90
8.88.2 Field Documentation . . . 90
8.88.2.1 TlvPresent . . . 90
8.88.2.2 VoipSvcStatus . . . 90
8.89 imsa_VtRatInfo Struct Reference . . . 90
8.89.1 Detailed Description . . . 90
8.89.2 Field Documentation . . . 91
8.89.2.1 TlvPresent . . . 91
8.89.2.2 VtRatVal . . . 91

8.90 imsa_VtSvcStatusInfo Struct Reference . . . 91
8.90.1 Detailed Description . . . 91
8.90.2 Field Documentation . . . 91
8.90.2.1 TlvPresent . . . 91
8.90.2.2 VtSvcStatus . . . 91
8.91 ipv6AddressInfo Struct Reference . . . 91
8.91.1 Detailed Description . . . 91
8.91.2 Field Documentation . . . 91
8.91.2.1 IPAddressV6 . . . 92
8.91.2.2 IPV6PrefixLen . . . 92
8.92 LibPackGPRSRequestedQoS Struct Reference . . . 92
8.92.1 Detailed Description . . . 92
8.92.2 Field Documentation . . . 92
8.92.2.1 delayClass . . . 92
8.92.2.2 meanThroughputClass . . . 92
8.92.2.3 peakThroughputClass . . . 92
8.92.2.4 precedenceClass . . . 92
8.92.2.5 reliabilityClass . . . 92
8.93 LibpackProfile3GPP Struct Reference . . . 92
8.93.1 Detailed Description . . . 93
8.93.2 Field Documentation . . . 98
8.93.2.1 pAddrAllocPref . . . 98
8.93.2.2 pAPNClass . . . 98
8.93.2.3 pAPNDisabledFlag . . . 98
8.93.2.4 pAPNName . . . 98
8.93.2.5 pAPNnameSize . . . 98
8.93.2.6 pAuthenticationPref . . . 98
8.93.2.7 pGPRSMinimumQoS . . . 98
8.93.2.8 pGPRSRequestedQos . . . 98
8.93.2.9 pImCnFlag . . . 98
8.93.2.10 pIPv4AddrPref . . . 98
8.93.2.11 pIPv6AddPref . . . 98
8.93.2.12 pPassword . . . 98
8.93.2.13 pPasswordSize . . . 98
8.93.2.14 pPcscfAddrUsingDhcp . . . 98
8.93.2.15 pPcscfAddrUsingPCO . . . 98
8.93.2.16 pPDNInactivTimeout . . . 98
8.93.2.17 pPdpAccessConFlag . . . 98
8.93.2.18 pPdpContext . . . 98
8.93.2.19 pPdpDataCompType . . . 99

8.93.2.20 pPdpHdrCompType . . . 99
8.93.2.21 pPDPtype . . . 99
8.93.2.22 pPriDNSIPv4AddPref . . . 99
8.93.2.23 pPriDNSIPv6addpref . . . 99
8.93.2.24 pPrimaryID . . . 99
8.93.2.25 pProfilename . . . 99
8.93.2.26 pProfilenameSize . . . 99
8.93.2.27 pQosClassID . . . 99
8.93.2.28 pSecDNSIPv4AddPref . . . 99
8.93.2.29 pSecDNSIPv6addpref . . . 99
8.93.2.30 pSecondaryFlag . . . 99
8.93.2.31 pSupportEmergencyCalls . . . 99
8.93.2.32 pTFTID1Params . . . 99
8.93.2.33 pTFTID2Params . . . 99
8.93.2.34 pUMTSMinQoS . . . 99
8.93.2.35 pUMTSMinQosSigInd . . . 99
8.93.2.36 pUMTSReqQoS . . . 99
8.93.2.37 pUMTSReqQoSSigInd . . . 99
8.93.2.38 pUsername . . . 99
8.93.2.39 pUsernameSize . . . 99
8.94 LibpackProfile3GPP2 Struct Reference . . . 99
8.94.1 Detailed Description . . . 100
8.94.2 Field Documentation . . . 104
8.94.2.1 pAllowLinger . . . 104
8.94.2.2 pAPNClass3GPP2 . . . 104
8.94.2.3 pAPNEnabled3GPP2 . . . 104
8.94.2.4 pApnString . . . 104
8.94.2.5 pApnStringSize . . . 104
8.94.2.6 pAppPriority . . . 104
8.94.2.7 pAppType . . . 104
8.94.2.8 pAuthPassword . . . 104
8.94.2.9 pAuthPasswordSize . . . 104
8.94.2.10 pAuthProtocol . . . 104
8.94.2.11 pAuthRetryCount . . . 104
8.94.2.12 pAuthTimeout . . . 104
8.94.2.13 pDataMode . . . 105
8.94.2.14 pDataRate . . . 105
8.94.2.15 pIpcpAckTimeout . . . 105
8.94.2.16 pIpcpCreqRetryCount . . . 105
8.94.2.17 pIsPcscfAddressNedded . . . 105

8.94.2.18 pLcpAckTimeout . . . 105
8.94.2.19 pLcpCreqRetryCount . . . 105
8.94.2.20 pNegoDnsSrvrPref . . . 105
8.94.2.21 pPDNInactivTimeout3GPP2 . . . 105
8.94.2.22 pPdnType . . . 105
8.94.2.23 pPppSessCloseTimer1x . . . 105
8.94.2.24 pPppSessCloseTimerDO . . . 105
8.94.2.25 pPrimaryV4DnsAddress . . . 105
8.94.2.26 pPriV6DnsAddress . . . 105
8.94.2.27 pRATType . . . 105
8.94.2.28 pSecondaryV4DnsAddress . . . 105
8.94.2.29 pSecV6DnsAddress . . . 105
8.94.2.30 pUserId . . . 105
8.94.2.31 pUserIdSize . . . 105
8.95 LibPackprofile_3GPP Struct Reference . . . 105
8.95.1 Detailed Description . . . 106
8.95.2 Field Documentation . . . 110
8.95.2.1 pAddrAllocPref . . . 110
8.95.2.2 pAPNClass . . . 110
8.95.2.3 pAPNDisabledFlag . . . 110
8.95.2.4 pAPNName . . . 110
8.95.2.5 pAPNnameSize . . . 110
8.95.2.6 pAuthenticationPref . . . 110
8.95.2.7 pGPRSMinimumQoS . . . 110
8.95.2.8 pGPRSRequestedQos . . . 110
8.95.2.9 pImCnFlag . . . 110
8.95.2.10 pIPv4AddrPref . . . 110
8.95.2.11 pIPv6AddPref . . . 110
8.95.2.12 pPassword . . . 110
8.95.2.13 pPasswordSize . . . 110
8.95.2.14 pPcscfAddrUsingDhcp . . . 110
8.95.2.15 pPcscfAddrUsingPCO . . . 110
8.95.2.16 pPDNInactivTimeout . . . 110
8.95.2.17 pPdpAccessConFlag . . . 110
8.95.2.18 pPdpContext . . . 110
8.95.2.19 pPdpDataCompType . . . 110
8.95.2.20 pPdpHdrCompType . . . 111
8.95.2.21 pPDPtype . . . 111
8.95.2.22 pPriDNSIPv4AddPref . . . 111
8.95.2.23 pPriDNSIPv6addpref . . . 111

8.95.2.24 pPrimaryID . . . 111
8.95.2.25 pProfilename . . . 111
8.95.2.26 pProfilenameSize . . . 111
8.95.2.27 pQosClassID . . . 111
8.95.2.28 pSecDNSIPv4AddPref . . . 111
8.95.2.29 pSecDNSIPv6addpref . . . 111
8.95.2.30 pSecondaryFlag . . . 111
8.95.2.31 pSupportEmergencyCalls . . . 111
8.95.2.32 pTFTID1Params . . . 111
8.95.2.33 pTFTID2Params . . . 111
8.95.2.34 pUMTSMinQoS . . . 111
8.95.2.35 pUMTSMinQosSigInd . . . 111
8.95.2.36 pUMTSReqQoS . . . 111
8.95.2.37 pUMTSReqQoSSigInd . . . 111
8.95.2.38 pUsername . . . 111
8.95.2.39 pUsernameSize . . . 111
8.96 LibPackprofile_3GPP2 Struct Reference . . . 111
8.96.1 Detailed Description . . . 112
8.96.2 Field Documentation . . . 115
8.96.2.1 pAllowLinger . . . 115
8.96.2.2 pAPNClass3GPP2 . . . 115
8.96.2.3 pAPNEnabled3GPP2 . . . 115
8.96.2.4 pApnString . . . 115
8.96.2.5 pApnStringSize . . . 116
8.96.2.6 pAppPriority . . . 116
8.96.2.7 pAppType . . . 116
8.96.2.8 pAuthPassword . . . 116
8.96.2.9 pAuthPassword_tSize . . . 116
8.96.2.10 pAuthProtocol . . . 116
8.96.2.11 pAuthRetryCount . . . 116
8.96.2.12 pAuthTimeout . . . 116
8.96.2.13 pDataMode . . . 116
8.96.2.14 pDataRate . . . 116
8.96.2.15 pIpcpAckTimeout . . . 116
8.96.2.16 pIpcpCreqRetryCount . . . 116
8.96.2.17 pIsPcscfAddressNedded . . . 116
8.96.2.18 pLcpAckTimeout . . . 116
8.96.2.19 pLcpCreqRetryCount . . . 116
8.96.2.20 pNegoDnsSrvrPref . . . 116
8.96.2.21 pPDNInactivTimeout3GPP2 . . . 116

8.96.2.22 pPdnType . . . 116
8.96.2.23 pPppSessCloseTimer1x . . . 116
8.96.2.24 pPppSessCloseTimerDO . . . 116
8.96.2.25 pPrimaryV4DnsAddress . . . 116
8.96.2.26 pPriV6DnsAddress . . . 116
8.96.2.27 pRATType . . . 116
8.96.2.28 pSecondaryV4DnsAddress . . . 116
8.96.2.29 pSecV6DnsAddress . . . 116
8.96.2.30 pUserId . . . 116
8.96.2.31 pUserIdSize . . . 116
8.97 LibPackQosClassID Struct Reference . . . 116
8.97.1 Detailed Description . . . 117
8.97.2 Field Documentation . . . 117
8.97.2.1 gDlBitRate . . . 117
8.97.2.2 gUlBitRate . . . 117
8.97.2.3 maxDlBitRate . . . 117
8.97.2.4 maxUlBitRate . . . 117
8.97.2.5 QCI . . . 117
8.98 LibPackTFTIDParams Struct Reference . . . 117
8.98.1 Detailed Description . . . 118
8.98.2 Field Documentation . . . 119
8.98.2.1 destPortRangeEnd . . . 119
8.98.2.2 destPortRangeStart . . . 119
8.98.2.3 eValid . . . 119
8.98.2.4 filterId . . . 119
8.98.2.5 flowLabel . . . 119
8.98.2.6 IPSECSPI . . . 119
8.98.2.7 ipVersion . . . 119
8.98.2.8 nextHeader . . . 119
8.98.2.9 pSourceIP . . . 119
8.98.2.10 sourceIPMask . . . 119
8.98.2.11 srcPortRangeEnd . . . 119
8.98.2.12 srcPortRangeStart . . . 119
8.98.2.13 tosMask . . . 119
8.99 LibPackUMTSQoS Struct Reference . . . 119
8.99.1 Detailed Description . . . 120
8.99.2 Field Documentation . . . 121
8.99.2.1 deliveryErrSDU . . . 121
8.99.2.2 grntDownlinkBitrate . . . 121
8.99.2.3 grntUplinkBitrate . . . 121

8.99.2.4 maxDownlinkBitrate . . . 121
8.99.2.5 maxSDUSize . . . 121
8.99.2.6 maxUplinkBitrate . . . 121
8.99.2.7 qosDeliveryOrder . . . 122
8.99.2.8 resBerRatio . . . 122
8.99.2.9 sduErrorRatio . . . 122
8.99.2.10 trafficClass . . . 122
8.99.2.11 trafficPriority . . . 122
8.99.2.12 transferDelay . . . 122
8.100 LibPackUMTSReqQoSSigInd Struct Reference . . . 122
8.100.1 Detailed Description . . . 122
8.100.2 Field Documentation . . . 122
8.100.2.1 SigInd . . . 122
8.100.2.2 UMTSReqQoS . . . 122
8.101 loc_accelAcceptReady Struct Reference . . . 122
8.101.1 Detailed Description . . . 123
8.101.2 Field Documentation . . . 123
8.101.2.1 batchPerSec . . . 123
8.101.2.2 injectEnable . . . 123
8.101.2.3 samplesPerBatch . . . 123
8.102 loc_accelTempAcceptReady Struct Reference . . . 123
8.102.1 Detailed Description . . . 123
8.102.2 Field Documentation . . . 124
8.102.2.1 batchPerSec . . . 124
8.102.2.2 injectEnable . . . 124
8.102.2.3 samplesPerBatch . . . 124
8.103 loc_BdsSV Struct Reference . . . 124
8.103.1 Detailed Description . . . 124
8.103.2 Field Documentation . . . 124
8.103.2.1 id . . . 124
8.103.2.2 mask . . . 124
8.104 loc_BdsSVInfo Struct Reference . . . 124
8.104.1 Detailed Description . . . 125
8.104.2 Field Documentation . . . 125
8.104.2.1 len . . . 125
8.104.2.2 pSV . . . 125
8.105 loc_CellDb Struct Reference . . . 125
8.105.1 Detailed Description . . . 125
8.105.2 Field Documentation . . . 126
8.105.2.1 mask . . . 126

8.106loc_ClkInfo Struct Reference . . . 126
8.106.1 Detailed Description . . . 126
8.106.2 Field Documentation . . . 127
8.106.2.1 mask . . . 127
8.107loc_GnssData Struct Reference . . . 127
8.107.1 Detailed Description . . . 128
8.107.2 Field Documentation . . . 128
8.107.2.1 mask . . . 129
8.108loc_gpsTime Struct Reference . . . 129
8.108.1 Detailed Description . . . 129
8.108.2 Field Documentation . . . 129
8.108.2.1 gpsTimeOfWeekMs . . . 129
8.108.2.2 gpsWeek . . . 129
8.109loc_gyroAcceptReady Struct Reference . . . 129
8.109.1 Detailed Description . . . 129
8.109.2 Field Documentation . . . 130
8.109.2.1 batchPerSec . . . 130
8.109.2.2 injectEnable . . . 130
8.109.2.3 samplesPerBatch . . . 130
8.110loc_gyroTempAcceptReady Struct Reference . . . 130
8.110.1 Detailed Description . . . 130
8.110.2 Field Documentation . . . 131
8.110.2.1 batchPerSec . . . 131
8.110.2.2 injectEnable . . . 131
8.110.2.3 samplesPerBatch . . . 131
8.111loc_IPv4Config Struct Reference . . . 131
8.111.1 Detailed Description . . . 131
8.111.2 Field Documentation . . . 131
8.111.2.1 IPv4Addr . . . 131
8.111.2.2 IPv4Port . . . 131
8.112loc_IPv4Info Struct Reference . . . 131
8.112.1 Detailed Description . . . 131
8.112.2 Field Documentation . . . 132
8.112.2.1 address . . . 132
8.112.2.2 port . . . 132
8.112.2.3 TlvPresent . . . 132
8.113loc_IPv6Config Struct Reference . . . 132
8.113.1 Detailed Description . . . 132
8.113.2 Field Documentation . . . 132
8.113.2.1 IPv6Addr . . . 132

8.113.2.2 IPv6Port . . . 132
8.114loc_IPv6Info Struct Reference . . . 132
8.114.1 Detailed Description . . . 132
8.114.2 Field Documentation . . . 133
8.114.2.1 address . . . 133
8.114.2.2 port . . . 133
8.114.2.3 TlvPresent . . . 133
8.115loc_LocApplicationInfo Struct Reference . . . 133
8.115.1 Detailed Description . . . 133
8.115.2 Field Documentation . . . 134
8.115.2.1 appNameLength . . . 134
8.115.2.2 appProviderLength . . . 134
8.115.2.3 appVersionLength . . . 134
8.115.2.4 appVersionValid . . . 134
8.115.2.5 pAppName . . . 134
8.115.2.6 pAppProvider . . . 134
8.115.2.7 pAppVersion . . . 134
8.116loc_precisionDilution Struct Reference . . . 134
8.116.1 Detailed Description . . . 134
8.116.2 Field Documentation . . . 135
8.116.2.1 HDOP . . . 135
8.116.2.2 PDOP . . . 135
8.116.2.3 VDOP . . . 135
8.117loc_satelliteInfo Struct Reference . . . 135
8.117.1 Detailed Description . . . 135
8.117.2 Field Documentation . . . 137
8.117.2.1 azimuth . . . 137
8.117.2.2 elevation . . . 137
8.117.2.3 gnssSvId . . . 137
8.117.2.4 healthStatus . . . 137
8.117.2.5 snr . . . 137
8.117.2.6 svInfoMask . . . 137
8.117.2.7 svListLen . . . 137
8.117.2.8 svStatus . . . 137
8.117.2.9 system . . . 137
8.117.2.10validMask . . . 137
8.118loc_sensorDataUsage Struct Reference . . . 137
8.118.1 Detailed Description . . . 137
8.118.2 Field Documentation . . . 138
8.118.2.1 aidingIndicatorMask . . . 138

8.118.2.2 usageMask . . . 138
8.119 loc_SV Struct Reference . . . 138
8.119.1 Detailed Description . . . 138
8.119.2 Field Documentation . . . 139
8.119.2.1 id . . . 139
8.119.2.2 mask . . . 139
8.119.2.3 system . . . 139
8.120 loc_SVInfo Struct Reference . . . 139
8.120.1 Detailed Description . . . 139
8.120.2 Field Documentation . . . 139
8.120.2.1 len . . . 139
8.120.2.2 pSV . . . 139
8.121 loc_svUsedforFix Struct Reference . . . 139
8.121.1 Detailed Description . . . 139
8.121.2 Field Documentation . . . 140
8.121.2.1 gnssSvUsedList . . . 140
8.121.2.2 gnssSvUsedList_len . . . 140
8.122 loc_urlAddr Struct Reference . . . 140
8.122.1 Detailed Description . . . 140
8.122.2 Field Documentation . . . 140
8.122.2.1 address . . . 140
8.122.2.2 TlvPresent . . . 140
8.123 loc_URLAddrInfo Struct Reference . . . 140
8.123.1 Detailed Description . . . 141
8.123.2 Field Documentation . . . 141
8.123.2.1 urlAddr . . . 141
8.124 lteSSInfo Struct Reference . . . 141
8.124.1 Detailed Description . . . 141
8.124.2 Field Documentation . . . 141
8.124.2.1 rsrp . . . 142
8.124.2.2 rsrq . . . 142
8.124.2.3 rssi . . . 142
8.124.2.4 snr . . . 142
8.125 messageModeTlv Struct Reference . . . 142
8.125.1 Detailed Description . . . 142
8.125.2 Field Documentation . . . 142
8.125.2.1 MessageModeInfo . . . 142
8.125.2.2 TlvPresent . . . 142
8.126 nas_acqOrderPref Struct Reference . . . 142
8.126.1 Detailed Description . . . 142

8.126.2 Field Documentation . . . 143
8.126.2.1 acqOrdeLen . . . 143
8.126.2.2 pAcqOrder . . . 143
8.127 nas_AcqOrderPrefTlv Struct Reference . . . 143
8.127.1 Detailed Description . . . 143
8.127.2 Field Documentation . . . 143
8.127.2.1 acqOrdeLen . . . 143
8.127.2.2 pAcqOrder . . . 144
8.127.2.3 TlvPresent . . . 144
8.128 nas_ActPilotPNElement Struct Reference . . . 144
8.128.1 Detailed Description . . . 144
8.128.2 Field Documentation . . . 144
8.128.2.1 ActSetPilotPN . . . 144
8.128.2.2 ActSetPilotPNStrength . . . 144
8.129 nas_AddCDMASysInfo Struct Reference . . . 144
8.129.1 Detailed Description . . . 144
8.129.2 Field Documentation . . . 145
8.129.2.1 geoSysIdx . . . 145
8.129.2.2 regPrd . . . 145
8.130 nas_AddSysInfo Struct Reference . . . 145
8.130.1 Detailed Description . . . 145
8.130.2 Field Documentation . . . 145
8.130.2.1 cellBroadcastCap . . . 145
8.130.2.2 geoSysIdx . . . 145
8.131 nas_BandPrefInfoTlv Struct Reference . . . 145
8.131.1 Detailed Description . . . 145
8.131.2 Field Documentation . . . 146
8.131.2.1 bits_129_192 . . . 146
8.131.2.2 bits_193_256 . . . 146
8.131.2.3 bits_1_64 . . . 146
8.131.2.4 bits_65_128 . . . 146
8.131.2.5 TlvPresent . . . 146
8.132 nas_BandPrefTlv Struct Reference . . . 146
8.132.1 Detailed Description . . . 146
8.132.2 Field Documentation . . . 148
8.132.2.1 BandPref . . . 148
8.132.2.2 TlvPresent . . . 148
8.133 nas_CallBarringSysInfo Struct Reference . . . 148
8.133.1 Detailed Description . . . 148
8.133.2 Field Documentation . . . 148

8.133.2.1 csBarStatus . . . 148
8.133.2.2 psBarStatus . . . 148
8.134 nas_callBarStatus Struct Reference . . . 148
8.134.1 Detailed Description . . . 149
8.134.2 Field Documentation . . . 149
8.134.2.1 csBarStatus . . . 149
8.134.2.2 psBarStatus . . . 149
8.135 nas_CDMAChannel Struct Reference . . . 149
8.135.1 Detailed Description . . . 149
8.135.2 Field Documentation . . . 150
8.135.2.1 priChA . . . 150
8.135.2.2 priChB . . . 150
8.135.2.3 secChA . . . 150
8.135.2.4 secChB . . . 150
8.136 nas_CDMAECIOThresh Struct Reference . . . 150
8.136.1 Detailed Description . . . 150
8.136.2 Field Documentation . . . 150
8.136.2.1 CDMAECIOThreshListLen . . . 150
8.136.2.2 pCDMAECIOThreshList . . . 151
8.137 nas_CDMAInfo Struct Reference . . . 151
8.137.1 Detailed Description . . . 151
8.137.2 Field Documentation . . . 151
8.137.2.1 baseId . . . 151
8.137.2.2 baseLat . . . 151
8.137.2.3 baseLong . . . 151
8.137.2.4 nid . . . 152
8.137.2.5 refpn . . . 152
8.137.2.6 sid . . . 152
8.138 nas_CDMARSSIThresh Struct Reference . . . 152
8.138.1 Detailed Description . . . 152
8.138.2 Field Documentation . . . 152
8.138.2.1 CDMARSSIThreshListLen . . . 152
8.138.2.2 pCDMARSSIThreshList . . . 152
8.139 nas_CDMASysInfo Struct Reference . . . 152
8.139.1 Detailed Description . . . 153
8.139.2 Field Documentation . . . 155
8.139.2.1 baseId . . . 155
8.139.2.2 baseLat . . . 155
8.139.2.3 baseLong . . . 155
8.139.2.4 bsInfoValid . . . 155

8.139.2.5 bsPRev . . . 155
8.139.2.6 bsPRevValid . . . 155
8.139.2.7 ccsSupported . . . 155
8.139.2.8 ccsSupportedValid . . . 155
8.139.2.9 cdmaSysIdValid . . . 155
8.139.2.10 isSysPrlMatch . . . 155
8.139.2.11 isSysPrlMatchValid . . . 155
8.139.2.12 MCC . . . 155
8.139.2.13 MNC . . . 155
8.139.2.14 networkID . . . 155
8.139.2.15 networkIdValid . . . 156
8.139.2.16 packetZone . . . 156
8.139.2.17 packetZoneValid . . . 156
8.139.2.18 pRevInUse . . . 156
8.139.2.19 pRevInUseValid . . . 156
8.139.2.20 sysInfoCDMA . . . 156
8.139.2.21 systemID . . . 156
8.140 nas_CDMASysInfoExt Struct Reference . . . 156
8.140.1 Detailed Description . . . 156
8.140.2 Field Documentation . . . 156
8.140.2.1 imsi_11_12 . . . 156
8.140.2.2 MCC . . . 156
8.141 nas_cellParams Struct Reference . . . 156
8.141.1 Detailed Description . . . 157
8.141.2 Field Documentation . . . 157
8.141.2.1 pci . . . 157
8.141.2.2 rsrp . . . 157
8.141.2.3 rsrq . . . 157
8.141.2.4 rssi . . . 157
8.141.2.5 srxlev . . . 157
8.142 nas_ciotAcqOrderPref Struct Reference . . . 157
8.142.1 Detailed Description . . . 157
8.142.2 Field Documentation . . . 158
8.142.2.1 ciotAcqOrderLen . . . 158
8.142.2.2 pCiotAcqOrder . . . 158
8.143 nas_CiotAcqOrderPrefTlv Struct Reference . . . 158
8.143.1 Detailed Description . . . 158
8.143.2 Field Documentation . . . 159
8.143.2.1 ciotAcqOrderLen . . . 159
8.143.2.2 pCiotAcqOrder . . . 159

8.143.2.3 TlvPresent . . . 159
8.144 nas_CiotLteOpModePrefTlv Struct Reference . . . 159
8.144.1 Detailed Description . . . 159
8.144.2 Field Documentation . . . 159
8.144.2.1 ciotLteOpModePref . . . 159
8.144.2.2 TlvPresent . . . 159
8.145 nas_CommInfo Struct Reference . . . 159
8.145.1 Detailed Description . . . 160
8.145.2 Field Documentation . . . 161
8.145.2.1 imsRegState . . . 161
8.145.2.2 modemMode . . . 161
8.145.2.3 psState . . . 161
8.145.2.4 systemMode . . . 161
8.145.2.5 temperature . . . 161
8.146 nas_CSGID Struct Reference . . . 161
8.146.1 Detailed Description . . . 161
8.146.2 Field Documentation . . . 162
8.146.2.1 id . . . 162
8.146.2.2 mcc . . . 162
8.146.2.3 mnc . . . 162
8.146.2.4 mncPcsDigits . . . 162
8.146.2.5 rat . . . 162
8.147 nas_CsgId Struct Reference . . . 162
8.147.1 Detailed Description . . . 162
8.147.2 Field Documentation . . . 162
8.147.2.1 csgId . . . 162
8.147.2.2 TlvPresent . . . 162
8.148 nas_currentPLMN Struct Reference . . . 162
8.148.1 Detailed Description . . . 163
8.148.2 Field Documentation . . . 163
8.148.2.1 MCC . . . 163
8.148.2.2 MNC . . . 163
8.148.2.3 netDescr . . . 163
8.148.2.4 netDescrLength . . . 163
8.149 nas_dataSrvCapabilities Struct Reference . . . 163
8.149.1 Detailed Description . . . 163
8.149.2 Field Documentation . . . 164
8.149.2.1 dataCapabilities . . . 164
8.149.2.2 dataCapabilitiesLen . . . 164
8.150 nas_DataStatusDetail Struct Reference . . . 164

8.150.1 Detailed Description . . . 164
8.150.2 Field Documentation . . . 165
8.150.2.1 IPAddress . . . 165
8.150.2.2 LastErrCode . . . 165
8.151 nas_detailSvcInfo Struct Reference . . . 166
8.151.1 Detailed Description . . . 166
8.151.2 Field Documentation . . . 167
8.151.2.1 hdrHybrid . . . 167
8.151.2.2 hdrSrvStatus . . . 167
8.151.2.3 isSysForbidden . . . 167
8.151.2.4 srvCapability . . . 167
8.151.2.5 srvStatus . . . 167
8.152 nas_DeviceConfigDetail Struct Reference . . . 167
8.152.1 Detailed Description . . . 167
8.152.2 Field Documentation . . . 168
8.152.2.1 Chipset . . . 168
8.152.2.2 HWVersion . . . 168
8.152.2.3 QLIC . . . 168
8.152.2.4 Technology . . . 168
8.153 nas_dirNum Struct Reference . . . 168
8.153.1 Detailed Description . . . 168
8.153.2 Field Documentation . . . 168
8.153.2.1 dirNum . . . 168
8.153.2.2 dirNumLen . . . 168
8.154 nas_DRCParams Struct Reference . . . 168
8.154.1 Detailed Description . . . 169
8.154.2 Field Documentation . . . 169
8.154.2.1 DRCCover . . . 169
8.154.2.2 DRCValue . . . 169
8.155 nas_ecioListElement Struct Reference . . . 169
8.155.1 Detailed Description . . . 169
8.155.2 Field Documentation . . . 169
8.155.2.1 ecio . . . 170
8.155.2.2 radioIf . . . 170
8.156 nas_ECIOThresh Struct Reference . . . 170
8.156.1 Detailed Description . . . 170
8.156.2 Field Documentation . . . 170
8.156.2.1 ECIOThresListLen . . . 170
8.156.2.2 pECIOThresList . . . 170
8.157 nas_EdrxCiotLteMode Struct Reference . . . 170

8.157.1 Detailed Description . . . 170
8.157.2 Field Documentation . . . 171
8.157.2.1 lteOpMode . . . 171
8.157.2.2 TlvPresent . . . 171
8.158 nas_EdrxCycleLength Struct Reference . . . 171
8.158.1 Detailed Description . . . 171
8.158.2 Field Documentation . . . 171
8.158.2.1 cycleLength . . . 171
8.158.2.2 TlvPresent . . . 171
8.159 nas_EdrxEnableType Struct Reference . . . 171
8.159.1 Detailed Description . . . 172
8.159.2 Field Documentation . . . 172
8.159.2.1 edrxEnabled . . . 172
8.159.2.2 TlvPresent . . . 172
8.160 nas_EdrxPagingTimeWindow Struct Reference . . . 172
8.160.1 Detailed Description . . . 172
8.160.2 Field Documentation . . . 172
8.160.2.1 edrxPtw . . . 172
8.160.2.2 TlvPresent . . . 172
8.161 nas_EdrxRatType Struct Reference . . . 172
8.161.1 Detailed Description . . . 173
8.161.2 Field Documentation . . . 173
8.161.2.1 edrxRatType . . . 173
8.161.2.2 TlvPresent . . . 173
8.162 nas_EmerModeTlv Struct Reference . . . 173
8.162.1 Detailed Description . . . 173
8.162.2 Field Documentation . . . 174
8.162.2.1 EmerMode . . . 174
8.162.2.2 TlvPresent . . . 174
8.163 nas_errorRateListElement Struct Reference . . . 174
8.163.1 Detailed Description . . . 174
8.163.2 Field Documentation . . . 175
8.163.2.1 errorRate . . . 175
8.163.2.2 radioIf . . . 175
8.164 nas_ForbiddenNetworks3GPP Struct Reference . . . 175
8.164.1 Detailed Description . . . 175
8.164.2 Field Documentation . . . 176
8.164.2.1 forbiddenNwInstLen . . . 176
8.164.2.2 MCC . . . 176
8.164.2.3 MNC . . . 176

8.164.2.4 TlvPresent . . . 176
8.165 nas_GERANInfo Struct Reference . . . 176
8.165.1 Detailed Description . . . 176
8.165.2 Field Documentation . . . 177
8.165.2.1 arfcn . . . 177
8.165.2.2 bsic . . . 177
8.165.2.3 cellID . . . 177
8.165.2.4 insNmrCellInfo . . . 177
8.165.2.5 lac . . . 177
8.165.2.6 nmrInst . . . 177
8.165.2.7 plmn . . . 177
8.165.2.8 rxLev . . . 177
8.165.2.9 timingAdvance . . . 177
8.166 nas_geranInstInfo Struct Reference . . . 177
8.166.1 Detailed Description . . . 178
8.166.2 Field Documentation . . . 178
8.166.2.1 geranArfcn . . . 178
8.166.2.2 geranBsicBcc . . . 178
8.166.2.3 geranBsicNcc . . . 178
8.166.2.4 geranRssi . . . 178
8.167 nas_gsmCellInfo Struct Reference . . . 178
8.167.1 Detailed Description . . . 178
8.167.2 Field Documentation . . . 179
8.167.2.1 arfcn . . . 179
8.167.2.2 band1900 . . . 179
8.167.2.3 bsicId . . . 179
8.167.2.4 cellIdValid . . . 179
8.167.2.5 rssi . . . 179
8.167.2.6 srxlev . . . 179
8.168 nas_GSMRSSIThresh Struct Reference . . . 179
8.168.1 Detailed Description . . . 179
8.168.2 Field Documentation . . . 180
8.168.2.1 GSMRSSIThreshListLen . . . 180
8.168.2.2 pGSMRSSIThreshList . . . 180
8.169 nas_GSMSrvStatusInfo Struct Reference . . . 180
8.169.1 Detailed Description . . . 180
8.169.2 Field Documentation . . . 181
8.169.2.1 isPrefDataPath . . . 181
8.169.2.2 srvStatus . . . 181
8.169.2.3 trueSrvStatus . . . 181

8.170 nas_GSMSysInfo Struct Reference . . . 181
8.170.1 Detailed Description . . . 181
8.170.2 Field Documentation . . . 183
8.170.2.1 cellId . . . 183
8.170.2.2 cellIdValid . . . 183
8.170.2.3 dtmSupp . . . 183
8.170.2.4 dtmSuppValid . . . 183
8.170.2.5 egprsSupp . . . 183
8.170.2.6 egprsSuppValid . . . 183
8.170.2.7 lac . . . 183
8.170.2.8 lacValid . . . 183
8.170.2.9 MCC . . . 183
8.170.2.10 MNC . . . 183
8.170.2.11 networkIdValid . . . 183
8.170.2.12 regRejectInfoValid . . . 183
8.170.2.13 rejCause . . . 184
8.170.2.14 rejectSrvDomain . . . 184
8.170.2.15 sysInfoGSM . . . 184
8.171 nas_GWAcqOrderPrefTlv Struct Reference . . . 184
8.171.1 Detailed Description . . . 184
8.171.2 Field Documentation . . . 184
8.171.2.1 GWAcqOrderPref . . . 184
8.171.2.2 TlvPresent . . . 184
8.172 nas_HDRECIOThresh Struct Reference . . . 184
8.172.1 Detailed Description . . . 184
8.172.2 Field Documentation . . . 185
8.172.2.1 HDRECIOThreshListLen . . . 185
8.172.2.2 pHDRECIOThreshList . . . 185
8.173 nas_HDRIOThresh Struct Reference . . . 185
8.173.1 Detailed Description . . . 185
8.173.2 Field Documentation . . . 185
8.173.2.1 HDRIOThreshListLen . . . 185
8.173.2.2 pHDRIOThreshList . . . 185
8.174 nas_HDRPersonality_Ind_Data Struct Reference . . . 185
8.174.1 Detailed Description . . . 186
8.174.2 Field Documentation . . . 186
8.174.2.1 pCurrentPersonality . . . 186
8.174.2.2 pPersonalityListLength . . . 186
8.174.2.3 pProtocolSubtypeElement . . . 186
8.175 nas_HDRRSSIThresh Struct Reference . . . 186

8.175.1 Detailed Description . . . 186
8.175.2 Field Documentation . . . 186
8.175.2.1 HDRRSSIThreshListLen . . . 186
8.175.2.2 pHDRRSSIThreshList . . . 187
8.176nas_HDRSINRThresh Struct Reference . . . 187
8.176.1 Detailed Description . . . 187
8.176.2 Field Documentation . . . 187
8.176.2.1 HDRSINRThresListLen . . . 187
8.176.2.2 pHDRSINRThresList . . . 187
8.177nas_HDRSINRThreshold Struct Reference . . . 187
8.177.1 Detailed Description . . . 187
8.177.2 Field Documentation . . . 188
8.177.2.1 HDRSINRThreshListLen . . . 188
8.177.2.2 pHDRSINRThreshList . . . 188
8.178nas_HDRSysInfo Struct Reference . . . 188
8.178.1 Detailed Description . . . 188
8.178.2 Field Documentation . . . 190
8.178.2.1 hdrActiveProt . . . 190
8.178.2.2 hdrActiveProtValid . . . 190
8.178.2.3 hdrPersonality . . . 190
8.178.2.4 hdrPersonalityValid . . . 190
8.178.2.5 is856SysId . . . 190
8.178.2.6 is856SysIdValid . . . 190
8.178.2.7 isSysPrlMatch . . . 190
8.178.2.8 isSysPrlMatchValid . . . 190
8.178.2.9 sysInfoHDR . . . 190
8.179nas_homeSIDNID Struct Reference . . . 190
8.179.1 Detailed Description . . . 190
8.179.2 Field Documentation . . . 190
8.179.2.1 numInstances . . . 190
8.179.2.2 SidNid . . . 190
8.180nas_infoInterFreq Struct Reference . . . 190
8.180.1 Detailed Description . . . 191
8.180.2 Field Documentation . . . 191
8.180.2.1 cell_resel_priority . . . 191
8.180.2.2 cellInterFreqParams . . . 191
8.180.2.3 cells_len . . . 191
8.180.2.4 earfcn . . . 191
8.180.2.5 threshXHigh . . . 192
8.180.2.6 threshXLow . . . 192

8.181 nas_IOThresh Struct Reference . . . 192
8.181.1 Detailed Description . . . 192
8.181.2 Field Documentation . . . 192
8.181.2.1 IOThresListLen . . . 192
8.181.2.2 pIOThresList . . . 192
8.182 nas_lteBandPrefExt Struct Reference . . . 192
8.182.1 Detailed Description . . . 192
8.182.2 Field Documentation . . . 193
8.182.2.1 bits_129_192 . . . 193
8.182.2.2 bits_193_256 . . . 193
8.182.2.3 bits_1_64 . . . 193
8.182.2.4 bits_65_128 . . . 193
8.183 nas_LTEBandPrefTlv Struct Reference . . . 193
8.183.1 Detailed Description . . . 193
8.183.2 Field Documentation . . . 194
8.183.2.1 LTEBandPref . . . 195
8.183.2.2 TlvPresent . . . 195
8.184 nas_lteEARFCN Struct Reference . . . 195
8.184.1 Detailed Description . . . 195
8.184.2 Field Documentation . . . 195
8.184.2.1 earfcn0 . . . 195
8.184.2.2 earfcn1 . . . 195
8.184.2.3 status . . . 195
8.185 nas_lteGsmCellInfo Struct Reference . . . 195
8.185.1 Detailed Description . . . 195
8.185.2 Field Documentation . . . 196
8.185.2.1 cellReselPriority . . . 196
8.185.2.2 cells_len . . . 196
8.185.2.3 GsmCellInfo . . . 196
8.185.2.4 nccPermitted . . . 196
8.185.2.5 threshGsmHigh . . . 196
8.185.2.6 threshGsmLow . . . 196
8.186 nas_LTEInfo Struct Reference . . . 196
8.186.1 Detailed Description . . . 197
8.186.2 Field Documentation . . . 198
8.186.2.1 band . . . 198
8.186.2.2 bandwidth . . . 198
8.186.2.3 emmConnState . . . 198
8.186.2.4 emmState . . . 198
8.186.2.5 emmSubState . . . 198

8.186.2.6 RXChan . . . 198
8.186.2.7 TXChan . . . 198
8.187 nas_LTEInfoInterfreq Struct Reference . . . 199
8.187.1 Detailed Description . . . 199
8.187.2 Field Documentation . . . 199
8.187.2.1 freqsLen . . . 199
8.187.2.2 InfoInterfreq . . . 199
8.187.2.3 ueInIdle . . . 199
8.188 nas_LTEInfoIntrafreq Struct Reference . . . 199
8.188.1 Detailed Description . . . 200
8.188.2 Field Documentation . . . 201
8.188.2.1 CellParams . . . 201
8.188.2.2 cellReselPriority . . . 201
8.188.2.3 cellsLen . . . 201
8.188.2.4 earfcn . . . 201
8.188.2.5 globalCellId . . . 201
8.188.2.6 plmn . . . 201
8.188.2.7 servingCellId . . . 201
8.188.2.8 sIntraSearch . . . 201
8.188.2.9 sNonIntraSearch . . . 201
8.188.2.10 tac . . . 201
8.188.2.11 threshServingLow . . . 201
8.188.2.12 ueInIdle . . . 201
8.189 nas_LTEInfoNeighboringGSM Struct Reference . . . 201
8.189.1 Detailed Description . . . 202
8.189.2 Field Documentation . . . 202
8.189.2.1 freqsLen . . . 202
8.189.2.2 LteGsmCellInfo . . . 202
8.189.2.3 ueInIdle . . . 202
8.190 nas_LTEInfoNeighboringWCDMA Struct Reference . . . 202
8.190.1 Detailed Description . . . 202
8.190.2 Field Documentation . . . 203
8.190.2.1 freqsLen . . . 203
8.190.2.2 LTEWCDMACellInfo . . . 203
8.190.2.3 ueInIdle . . . 203
8.191 nas_LteM1BandPrefTlv Struct Reference . . . 203
8.191.1 Detailed Description . . . 203
8.191.2 Field Documentation . . . 204
8.191.2.1 lteM1BandPref . . . 205
8.191.2.2 TlvPresent . . . 205

8.192nas_LteNb1BandPrefTlv Struct Reference . . . 205
8.192.1 Detailed Description . . . 205
8.192.2 Field Documentation . . . 206
8.192.2.1 lteNb1BandPref . . . 207
8.192.2.2 TlvPresent . . . 207
8.193nas_LTEOperationMode Struct Reference . . . 207
8.193.1 Detailed Description . . . 207
8.193.2 Field Documentation . . . 207
8.193.2.1 pLTEOperationMode . . . 207
8.193.2.2 TlvPresent . . . 207
8.194nas_LteOpMode Struct Reference . . . 207
8.194.1 Detailed Description . . . 207
8.194.2 Field Documentation . . . 208
8.194.2.1 lteOpMode . . . 208
8.194.2.2 TlvPresent . . . 208
8.195nas_ltePCI Struct Reference . . . 208
8.195.1 Detailed Description . . . 208
8.195.2 Field Documentation . . . 208
8.195.2.1 earfcn . . . 208
8.195.2.2 pci . . . 208
8.195.2.3 status . . . 208
8.196nas_lteRsrpinformation Struct Reference . . . 208
8.196.1 Detailed Description . . . 209
8.196.2 Field Documentation . . . 209
8.196.2.1 rsrplevel . . . 209
8.197nas_LTERSRPThresh Struct Reference . . . 209
8.197.1 Detailed Description . . . 209
8.197.2 Field Documentation . . . 209
8.197.2.1 LTERSRPThreshListLen . . . 209
8.197.2.2 pLTERSRPThreshList . . . 209
8.198nas_LTERSRQThresh Struct Reference . . . 209
8.198.1 Detailed Description . . . 210
8.198.2 Field Documentation . . . 210
8.198.2.1 LTERSRQThreshListLen . . . 210
8.198.2.2 pLTERSRQThreshList . . . 210
8.199nas_LTERSSIThresh Struct Reference . . . 210
8.199.1 Detailed Description . . . 210
8.199.2 Field Documentation . . . 210
8.199.2.1 LTERSSIThreshListLen . . . 210
8.199.2.2 pLTERSSIThreshList . . . 210

8.200 nas_LTESigRptCfg Struct Reference . . . 210
8.200.1 Detailed Description . . . 211
8.200.2 Field Documentation . . . 211
8.200.2.1 avgPeriod . . . 211
8.200.2.2 rptRate . . . 211
8.201 nas_LTESigRptConfig Struct Reference . . . 211
8.201.1 Detailed Description . . . 212
8.201.2 Field Documentation . . . 212
8.201.2.1 avgPeriod . . . 212
8.201.2.2 rptRate . . . 212
8.202 nas_lteSnrinformation Struct Reference . . . 212
8.202.1 Detailed Description . . . 212
8.202.2 Field Documentation . . . 213
8.202.2.1 snrlevel . . . 213
8.203 nas_LTESNRThresh Struct Reference . . . 213
8.203.1 Detailed Description . . . 213
8.203.2 Field Documentation . . . 213
8.203.2.1 LTESNRThresListLen . . . 213
8.203.2.2 pLTESNRThresList . . . 213
8.204 nas_LTESNRThreshold Struct Reference . . . 213
8.204.1 Detailed Description . . . 213
8.204.2 Field Documentation . . . 214
8.204.2.1 LTESNRThreshListLen . . . 214
8.204.2.2 pLTESNRThreshList . . . 214
8.205 nas_LTESysInfo Struct Reference . . . 214
8.205.1 Detailed Description . . . 214
8.205.2 Field Documentation . . . 216
8.205.2.1 cellId . . . 216
8.205.2.2 cellIdValid . . . 216
8.205.2.3 lac . . . 216
8.205.2.4 lacValid . . . 216
8.205.2.5 MCC . . . 216
8.205.2.6 MNC . . . 216
8.205.2.7 networkIdValid . . . 216
8.205.2.8 regRejectInfoValid . . . 216
8.205.2.9 rejCause . . . 216
8.205.2.10 rejectSrvDomain . . . 216
8.205.2.11 sysInfoLTE . . . 216
8.205.2.12 tac . . . 216
8.205.2.13 tacValid . . . 216

8.206 nas_lteWcdmaCellInfo Struct Reference . . . 216
8.206.1 Detailed Description . . . 217
8.206.2 Field Documentation . . . 217
8.206.2.1 cellReselPriority . . . 217
8.206.2.2 cellsLen . . . 217
8.206.2.3 threshXhigh . . . 217
8.206.2.4 threshXlow . . . 217
8.206.2.5 uarfcn . . . 217
8.206.2.6 WCDMACellInfo . . . 217
8.207 nas_minBasedIMSI Struct Reference . . . 217
8.207.1 Detailed Description . . . 218
8.207.2 Field Documentation . . . 218
8.207.2.1 imsiM1112 . . . 218
8.207.2.2 imsiMS1 . . . 218
8.207.2.3 imsiMS2 . . . 218
8.207.2.4 mccM . . . 218
8.208 nas_MNRInfo Struct Reference . . . 218
8.208.1 Detailed Description . . . 218
8.208.2 Field Documentation . . . 219
8.208.2.1 mcc . . . 219
8.208.2.2 mnc . . . 219
8.208.2.3 rat . . . 219
8.209 nas_ModePrefTlv Struct Reference . . . 219
8.209.1 Detailed Description . . . 219
8.209.2 Field Documentation . . . 219
8.209.2.1 ModePref . . . 219
8.209.2.2 TlvPresent . . . 219
8.210 nas_namName Struct Reference . . . 219
8.210.1 Detailed Description . . . 220
8.210.2 Field Documentation . . . 220
8.210.2.1 namName . . . 220
8.210.2.2 namNameLen . . . 220
8.211 nas_netSelectionPref Struct Reference . . . 220
8.211.1 Detailed Description . . . 220
8.211.2 Field Documentation . . . 221
8.211.2.1 mcc . . . 221
8.211.2.2 mnc . . . 221
8.211.2.3 netReg . . . 221
8.212 nas_NetSelPrefTlv Struct Reference . . . 221
8.212.1 Detailed Description . . . 221

8.212.2 Field Documentation . . . 221
8.212.2.1 NetSelPref . . . 221
8.212.2.2 TlvPresent . . . 221
8.213nas_NetworkStat1x Struct Reference . . . 221
8.213.1 Detailed Description . . . 222
8.213.2 Field Documentation . . . 223
8.213.2.1 ActSetCnt . . . 223
8.213.2.2 NeighborSetCnt . . . 223
8.213.2.3 pActPilotPNElements . . . 223
8.213.2.4 pNeighborSetPilotPN . . . 223
8.213.2.5 RX_EC_IO . . . 223
8.213.2.6 RX_PWR . . . 223
8.213.2.7 SO . . . 223
8.213.2.8 State . . . 223
8.213.2.9 TX_PWR . . . 223
8.214nas_NetworkStatEVDO Struct Reference . . . 223
8.214.1 Detailed Description . . . 224
8.214.2 Field Documentation . . . 225
8.214.2.1 MACIndex . . . 225
8.214.2.2 PER . . . 225
8.214.2.3 PilotEnergy . . . 225
8.214.2.4 pSectorID . . . 225
8.214.2.5 RX_PWR . . . 225
8.214.2.6 SectorIDLen . . . 225
8.214.2.7 SNR . . . 225
8.214.2.8 State . . . 225
8.215nas_nmrCellInfo Struct Reference . . . 225
8.215.1 Detailed Description . . . 225
8.215.2 Field Documentation . . . 226
8.215.2.1 nmrArfcn . . . 226
8.215.2.2 nmrBsic . . . 226
8.215.2.3 nmrCellID . . . 226
8.215.2.4 nmrLac . . . 226
8.215.2.5 nmrPlmn . . . 226
8.215.2.6 nmrRxLev . . . 226
8.216nas_nr5gBandPref Struct Reference . . . 226
8.216.1 Detailed Description . . . 226
8.216.2 Field Documentation . . . 227
8.216.2.1 bits_129_192 . . . 227
8.216.2.2 bits_193_256 . . . 227

8.216.2.3 bits_1_64 . . . 227
8.216.2.4 bits_65_128 . . . 227
8.217 nas_operatorNameString Struct Reference . . . 227
8.217.1 Detailed Description . . . 227
8.217.2 Field Documentation . . . 227
8.217.2.1 PLMNName . . . 227
8.218 nas_OperatorPLMNData Struct Reference . . . 227
8.218.1 Detailed Description . . . 227
8.218.2 Field Documentation . . . 228
8.218.2.1 lac1 . . . 228
8.218.2.2 lac2 . . . 228
8.218.2.3 mcc . . . 228
8.218.2.4 mnc . . . 228
8.218.2.5 PLMNRecID . . . 228
8.219 nas_operatorPLMNList Struct Reference . . . 228
8.219.1 Detailed Description . . . 228
8.219.2 Field Documentation . . . 229
8.219.2.1 numInstance . . . 229
8.219.2.2 PLMNData . . . 229
8.220 nas_PhyCaAggPcellInfo Struct Reference . . . 229
8.220.1 Detailed Description . . . 229
8.220.2 Field Documentation . . . 229
8.220.2.1 dl_bw_value . . . 229
8.220.2.2 freq . . . 229
8.220.2.3 iLTEbandValue . . . 229
8.220.2.4 pci . . . 229
8.220.2.5 TlvPresent . . . 229
8.221 nas_PhyCaAggScellDlBw Struct Reference . . . 230
8.221.1 Detailed Description . . . 230
8.221.2 Field Documentation . . . 230
8.221.2.1 dl_bw_value . . . 230
8.221.2.2 TlvPresent . . . 230
8.222 nas_PhyCaAggScellIndex Struct Reference . . . 230
8.222.1 Detailed Description . . . 230
8.222.2 Field Documentation . . . 230
8.222.2.1 scell_idx . . . 230
8.222.2.2 TlvPresent . . . 230
8.223 nas_PhyCaAggScellIndType Struct Reference . . . 231
8.223.1 Detailed Description . . . 231
8.223.2 Field Documentation . . . 231

8.223.2.1 freq . . . 231
8.223.2.2 pci . . . 231
8.223.2.3 scell_state . . . 231
8.223.2.4 TlvPresent . . . 231
8.224 nas_PhyCaAggScellInfo Struct Reference . . . 231
8.224.1 Detailed Description . . . 232
8.224.2 Field Documentation . . . 234
8.224.2.1 dl_bw_value . . . 234
8.224.2.2 freq . . . 234
8.224.2.3 iLTEbandValue . . . 234
8.224.2.4 pci . . . 234
8.224.2.5 scell_state . . . 234
8.224.2.6 TlvPresent . . . 234
8.225 nas_PilotSetData Struct Reference . . . 234
8.225.1 Detailed Description . . . 234
8.225.2 Field Documentation . . . 234
8.225.2.1 NumPilots . . . 234
8.225.2.2 pPilotSetInfo . . . 234
8.226 nas_PilotSetParams Struct Reference . . . 235
8.226.1 Detailed Description . . . 235
8.226.2 Field Documentation . . . 235
8.226.2.1 PilotPN . . . 235
8.226.2.2 PilotStrength . . . 235
8.226.2.3 PilotType . . . 235
8.227 nas_PlmnID Struct Reference . . . 235
8.227.1 Detailed Description . . . 235
8.227.2 Field Documentation . . . 236
8.227.2.1 mcc . . . 236
8.227.2.2 mnc . . . 236
8.227.2.3 pcsDigit . . . 236
8.227.2.4 TlvPresent . . . 236
8.228 nas_PLMNNetworkName Struct Reference . . . 236
8.228.1 Detailed Description . . . 236
8.228.2 Field Documentation . . . 236
8.228.2.1 numInstance . . . 236
8.228.2.2 PLMNNetName . . . 236
8.229 nas_PLMNNetworkNameData Struct Reference . . . 236
8.229.1 Detailed Description . . . 237
8.229.2 Field Documentation . . . 238
8.229.2.1 codingScheme . . . 238

8.229.2.2 countryInitials . . . 238
8.229.2.3 longName . . . 238
8.229.2.4 longNameLen . . . 238
8.229.2.5 longNameSpareBits . . . 238
8.229.2.6 shortName . . . 238
8.229.2.7 shortNameLen . . . 238
8.229.2.8 shortNameSpareBits . . . 238
8.230 nas_PRLPrefTlv Struct Reference . . . 238
8.230.1 Detailed Description . . . 238
8.230.2 Field Documentation . . . 239
8.230.2.1 PRLPref . . . 239
8.230.2.2 TlvPresent . . . 239
8.231 nas_protocolSubtypeElement Struct Reference . . . 239
8.231.1 Detailed Description . . . 239
8.231.2 Field Documentation . . . 240
8.231.2.1 AccessMac . . . 240
8.231.2.2 AuthProt . . . 240
8.231.2.3 ControlMac . . . 240
8.231.2.4 EncryptProt . . . 240
8.231.2.5 ForwardMac . . . 240
8.231.2.6 IdleState . . . 240
8.231.2.7 KeyExchange . . . 240
8.231.2.8 MultDisc . . . 240
8.231.2.9 PhysicalLayer . . . 240
8.231.2.10 ReverseMac . . . 240
8.231.2.11 SecProt . . . 240
8.231.2.12 VirtStream . . . 240
8.232 nas_qaQmi3Gpp2TimeZone Struct Reference . . . 240
8.232.1 Detailed Description . . . 241
8.232.2 Field Documentation . . . 241
8.232.2.1 daylightSavings . . . 241
8.232.2.2 leapSeconds . . . 241
8.232.2.3 localTimeOffset . . . 241
8.233 nas_QmiNas3GppNetworkInfo Struct Reference . . . 241
8.233.1 Detailed Description . . . 241
8.233.2 Field Documentation . . . 242
8.233.2.1 Desription . . . 242
8.233.2.2 Forbidden . . . 242
8.233.2.3 InUse . . . 242
8.233.2.4 MCC . . . 242

8.233.2.5 MNC . . . 242
8.233.2.6 Preferred . . . 242
8.233.2.7 Roaming . . . 242
8.234 nas_QmiNas3GppNetworkRAT Struct Reference . . . 242
8.234.1 Detailed Description . . . 243
8.234.2 Field Documentation . . . 243
8.234.2.1 MCC . . . 243
8.234.2.2 MNC . . . 243
8.234.2.3 RAT . . . 243
8.235 nas_QmisNasPcsDigit Struct Reference . . . 243
8.235.1 Detailed Description . . . 243
8.235.2 Field Documentation . . . 244
8.235.2.1 includes_pcs_digit . . . 244
8.235.2.2 MCC . . . 244
8.235.2.3 MNC . . . 244
8.236 nas_QmisNasSlqsNasPCICellInfo Struct Reference . . . 244
8.236.1 Detailed Description . . . 244
8.236.2 Field Documentation . . . 244
8.236.2.1 cellID . . . 244
8.236.2.2 freq . . . 244
8.236.2.3 GlobalCellID . . . 244
8.236.2.4 nasQmisNasPcsDigit . . . 244
8.236.2.5 PlmnLen . . . 244
8.237 nas_QmisNasSlqsNasPCIInfo Struct Reference . . . 245
8.237.1 Detailed Description . . . 245
8.237.2 Field Documentation . . . 245
8.237.2.1 nasQmisNasSlqsNasPCICellInfo . . . 245
8.237.2.2 PCICellInfoLen . . . 245
8.237.2.3 rsrp . . . 245
8.237.2.4 rsrpRx0 . . . 245
8.237.2.5 rsrpRx1 . . . 246
8.237.2.6 rsrq . . . 246
8.237.2.7 rsrqRx0 . . . 246
8.237.2.8 rsrqRx1 . . . 246
8.238 nas_RankIndicatorTlv Struct Reference . . . 246
8.238.1 Detailed Description . . . 246
8.238.2 Field Documentation . . . 246
8.238.2.1 count0 . . . 246
8.238.2.2 count1 . . . 246
8.238.2.3 TlvPresent . . . 246

8.239 nas_RatDisabledMaskTlv Struct Reference . . . 246
8.239.1 Detailed Description . . . 246
8.239.2 Field Documentation . . . 247
8.239.2.1 ratDisabledMask . . . 247
8.239.2.2 TlvPresent . . . 247
8.240 nas_RejectReasonTlv Struct Reference . . . 247
8.240.1 Detailed Description . . . 247
8.240.2 Field Documentation . . . 247
8.240.2.1 rejectCause . . . 247
8.240.2.2 serviceDomain . . . 247
8.240.2.3 TlvPresent . . . 247
8.241 nas_RFBandInfoElements Struct Reference . . . 247
8.241.1 Detailed Description . . . 248
8.241.2 Field Documentation . . . 248
8.241.2.1 activeBandClass . . . 248
8.241.2.2 activeChannel . . . 248
8.241.2.3 radioInterface . . . 248
8.242 nas_RfBandInfoExtFormat Struct Reference . . . 248
8.242.1 Detailed Description . . . 248
8.242.2 Field Documentation . . . 249
8.242.2.1 pInstancesSize . . . 249
8.242.2.2 pRfBandInfoExtFormatParam . . . 249
8.242.2.3 TlvPresent . . . 249
8.243 nas_RfBandInfoExtFormatElements Struct Reference . . . 249
8.243.1 Detailed Description . . . 249
8.243.2 Field Documentation . . . 249
8.243.2.1 activeBand . . . 249
8.243.2.2 activeChannel . . . 249
8.243.2.3 radioInterface . . . 250
8.244 nas_RfBandInfoList Struct Reference . . . 250
8.244.1 Detailed Description . . . 250
8.244.2 Field Documentation . . . 250
8.244.2.1 pInstanceSize . . . 250
8.244.2.2 pRFBandInfoParam . . . 250
8.245 nas_RfBandwidthInfo Struct Reference . . . 250
8.245.1 Detailed Description . . . 250
8.245.2 Field Documentation . . . 251
8.245.2.1 pInstancesSize . . . 251
8.245.2.2 pRfBandwidthInfoParam . . . 251
8.245.2.3 TlvPresent . . . 251

8.246 nas_RfBandwidthInfoElements Struct Reference . . . 251
8.246.1 Detailed Description . . . 251
8.246.2 Field Documentation . . . 251
8.246.2.1 bandwidth . . . 251
8.246.2.2 radioInterface . . . 252
8.247 nas_RfDedicatedBandInfo Struct Reference . . . 252
8.247.1 Detailed Description . . . 252
8.247.2 Field Documentation . . . 252
8.247.2.1 pInstancesSize . . . 252
8.247.2.2 pRfDedicatedBandInfoParam . . . 252
8.247.2.3 TlvPresent . . . 252
8.248 nas_RfDedicatedBandInfoElements Struct Reference . . . 252
8.248.1 Detailed Description . . . 252
8.248.2 Field Documentation . . . 253
8.248.2.1 dedicatedBand . . . 253
8.248.2.2 radioInterface . . . 253
8.249 nas_RFInfoTlv Struct Reference . . . 253
8.249.1 Detailed Description . . . 253
8.249.2 Field Documentation . . . 254
8.249.2.1 activeBandClass . . . 254
8.249.2.2 activeChannel . . . 254
8.249.2.3 radioInterface . . . 254
8.249.2.4 radioInterfaceSize . . . 254
8.249.2.5 TlvPresent . . . 254
8.250 nas_roamIndList Struct Reference . . . 254
8.250.1 Detailed Description . . . 254
8.250.2 Field Documentation . . . 254
8.250.2.1 numInstances . . . 255
8.250.2.2 radioInterface . . . 255
8.250.2.3 roamIndicator . . . 255
8.251 nas_RoamPrefTlv Struct Reference . . . 255
8.251.1 Detailed Description . . . 255
8.251.2 Field Documentation . . . 255
8.251.2.1 RoamPref . . . 255
8.251.2.2 TlvPresent . . . 255
8.252 nas_RSRPThresh Struct Reference . . . 255
8.252.1 Detailed Description . . . 255
8.252.2 Field Documentation . . . 256
8.252.2.1 pRSRPThresList . . . 256
8.252.2.2 RSRPThresListLen . . . 256

8.253 nas_rsrqInformation Struct Reference . . . 256
8.253.1 Detailed Description . . . 256
8.253.2 Field Documentation . . . 256
8.253.2.1 radioIf . . . 256
8.253.2.2 rsrq . . . 256
8.254 nas_RSRQThresh Struct Reference . . . 256
8.254.1 Detailed Description . . . 257
8.254.2 Field Documentation . . . 257
8.254.2.1 pRSRQThresList . . . 257
8.254.2.2 RSRQThresListLen . . . 257
8.255 nas_RSSIThresh Struct Reference . . . 257
8.255.1 Detailed Description . . . 257
8.255.2 Field Documentation . . . 258
8.255.2.1 pRSSIThresList . . . 258
8.255.2.2 RSSIThresListLen . . . 258
8.256 nas_rxInfo Struct Reference . . . 258
8.256.1 Detailed Description . . . 258
8.256.2 Field Documentation . . . 259
8.256.2.1 ecio . . . 259
8.256.2.2 isRadioTuned . . . 259
8.256.2.3 phase . . . 259
8.256.2.4 rscp . . . 259
8.256.2.5 rsrp . . . 259
8.256.2.6 rxPower . . . 259
8.257 nas_RxSigInfo Struct Reference . . . 259
8.257.1 Detailed Description . . . 259
8.257.2 Field Documentation . . . 260
8.257.2.1 isRadioTuned . . . 260
8.257.2.2 rsrp . . . 260
8.257.2.3 rxChainIndex . . . 260
8.257.2.4 rxPower . . . 260
8.258 nas_rxSignalStrengthListElement Struct Reference . . . 260
8.258.1 Detailed Description . . . 260
8.258.2 Field Documentation . . . 261
8.258.2.1 radioIf . . . 261
8.258.2.2 rxSignalStrength . . . 261
8.259 nas_SccRxInfo Struct Reference . . . 261
8.259.1 Detailed Description . . . 261
8.259.2 Field Documentation . . . 262
8.259.2.1 numInstances . . . 262

8.259.2.2 rsrq . . . 262
8.259.2.3 sigInfo . . . 262
8.259.2.4 snr . . . 262
8.259.2.5 TlvPresent . . . 262
8.260 nas_serviceProviderName Struct Reference . . . 262
8.260.1 Detailed Description . . . 262
8.260.2 Field Documentation . . . 262
8.260.2.1 displayCondition . . . 262
8.260.2.2 spn . . . 262
8.260.2.3 spnLength . . . 262
8.261 nas_servSystem Struct Reference . . . 263
8.261.1 Detailed Description . . . 263
8.261.2 Field Documentation . . . 264
8.261.2.1 csAttachState . . . 264
8.261.2.2 numRadioInterfaces . . . 264
8.261.2.3 psAttachState . . . 264
8.261.2.4 radioInterface . . . 264
8.261.2.5 regState . . . 264
8.261.2.6 selNetwork . . . 264
8.262 nas_sidNid Struct Reference . . . 264
8.262.1 Detailed Description . . . 264
8.262.2 Field Documentation . . . 264
8.262.2.1 nid . . . 264
8.262.2.2 sid . . . 264
8.263 nas_SignalStrengthTlv Struct Reference . . . 265
8.263.1 Detailed Description . . . 265
8.263.2 Field Documentation . . . 265
8.263.2.1 radioInterface . . . 265
8.263.2.2 signalStrength . . . 265
8.263.2.3 TlvPresent . . . 265
8.264 nas_SLQSSignalStrengthsIndReq Struct Reference . . . 265
8.264.1 Detailed Description . . . 265
8.264.2 Field Documentation . . . 266
8.264.2.1 ecioDelta . . . 266
8.264.2.2 ecioThresholdList . . . 266
8.264.2.3 ecioThresholdListLen . . . 267
8.264.2.4 ioDelta . . . 267
8.264.2.5 lteRsrpDelta . . . 267
8.264.2.6 lteSnrDelta . . . 267
8.264.2.7 rsrqDelta . . . 267

8.264.2.8 rxSignalStrengthDelta . . . 267
8.264.2.9 sinrDelta . . . 267
8.264.2.10 sinrThresholdList . . . 267
8.264.2.11 sinrThresholdListLen . . . 267
8.265 nas_SLQSSignalStrengthsInformation Struct Reference . . . 267
8.265.1 Detailed Description . . . 267
8.265.2 Field Documentation . . . 268
8.265.2.1 ecioInfo . . . 268
8.265.2.2 errorRateInfo . . . 268
8.265.2.3 io . . . 268
8.265.2.4 lteRsrpinfo . . . 268
8.265.2.5 lteSnrinfo . . . 268
8.265.2.6 rsrqInfo . . . 268
8.265.2.7 rxSignalStrengthInfo . . . 268
8.265.2.8 sinr . . . 268
8.266 nas_SLQSSignalStrengthsTlv Struct Reference . . . 268
8.266.1 Detailed Description . . . 268
8.266.2 Field Documentation . . . 269
8.266.2.1 sSLQSSignalStrengthsInfo . . . 269
8.266.2.2 TlvPresent . . . 269
8.267 nas_SrvDomainPrefTlv Struct Reference . . . 269
8.267.1 Detailed Description . . . 269
8.267.2 Field Documentation . . . 269
8.267.2.1 SrvDomainPref . . . 269
8.267.2.2 TlvPresent . . . 269
8.268 nas_SrvStatusInfo Struct Reference . . . 269
8.268.1 Detailed Description . . . 269
8.268.2 Field Documentation . . . 270
8.268.2.1 isPrefDataPath . . . 270
8.268.2.2 srvStatus . . . 270
8.269 nas_sysInfoCommon Struct Reference . . . 270
8.269.1 Detailed Description . . . 270
8.269.2 Field Documentation . . . 272
8.269.2.1 isSysForbidden . . . 272
8.269.2.2 isSysForbiddenValid . . . 272
8.269.2.3 roamStatus . . . 272
8.269.2.4 roamStatusValid . . . 272
8.269.2.5 srvCapability . . . 272
8.269.2.6 srvCapabilityValid . . . 272
8.269.2.7 srvDomain . . . 272

8.269.2.8 srvDomainValid . . . 272
8.270 nas_TDSCDMAECIOThresh Struct Reference . . . 273
8.270.1 Detailed Description . . . 273
8.270.2 Field Documentation . . . 273
8.270.2.1 pTDSCDMAECIOThreshList . . . 273
8.270.2.2 TDSCDMAECIOThreshListLen . . . 273
8.271 nas_TDSCDMARSCPThresh Struct Reference . . . 273
8.271.1 Detailed Description . . . 273
8.271.2 Field Documentation . . . 273
8.271.2.1 pTDSCDMARSCPThreshList . . . 273
8.271.2.2 TDSCDMARSCPThreshListLen . . . 274
8.272 nas_TDSCDMARSSIThresh Struct Reference . . . 274
8.272.1 Detailed Description . . . 274
8.272.2 Field Documentation . . . 274
8.272.2.1 pTDSCDMARSSIThreshList . . . 274
8.272.2.2 TDSCDMARSSIThreshListLen . . . 274
8.273 nas_TDSCDMASINRCONFThresh Struct Reference . . . 274
8.273.1 Detailed Description . . . 274
8.273.2 Field Documentation . . . 274
8.273.2.1 pTDSCDMASINRCONFThreshList . . . 275
8.273.2.2 TDSCDMASINRCONFThreshListLen . . . 275
8.274 nas_TDSCDMASINRThresh Struct Reference . . . 275
8.274.1 Detailed Description . . . 275
8.274.2 Field Documentation . . . 275
8.274.2.1 pTDSCDMASINRThreshList . . . 275
8.274.2.2 TDSCDMASINRThreshListLen . . . 275
8.275 nas_timeInfo Struct Reference . . . 275
8.275.1 Detailed Description . . . 275
8.275.2 Field Documentation . . . 277
8.275.2.1 day . . . 277
8.275.2.2 dayLtSavingAdj . . . 277
8.275.2.3 dayOfWeek . . . 277
8.275.2.4 hour . . . 277
8.275.2.5 minute . . . 277
8.275.2.6 month . . . 277
8.275.2.7 radioInterface . . . 277
8.275.2.8 second . . . 277
8.275.2.9 timeZone . . . 277
8.275.2.10 TlvPresent . . . 277
8.275.2.11 year . . . 277

8.276 nas_trueIMSI Struct Reference . . . 277
8.276.1 Detailed Description . . . 277
8.276.2 Field Documentation . . . 278
8.276.2.1 imsiT1112 . . . 278
8.276.2.2 imsiTaddrNum . . . 278
8.276.2.3 imsiTS1 . . . 278
8.276.2.4 imsiTS2 . . . 278
8.276.2.5 mccT . . . 278
8.277 nas_txInfo Struct Reference . . . 278
8.277.1 Detailed Description . . . 278
8.277.2 Field Documentation . . . 278
8.277.2.1 isInTraffic . . . 278
8.277.2.2 txPower . . . 278
8.278 nas_UMTSInfo Struct Reference . . . 278
8.278.1 Detailed Description . . . 279
8.278.2 Field Documentation . . . 280
8.278.2.1 cellID . . . 280
8.278.2.2 ecio . . . 280
8.278.2.3 geranInst . . . 280
8.278.2.4 GeranInstInfo . . . 280
8.278.2.5 lac . . . 280
8.278.2.6 plmn . . . 280
8.278.2.7 psc . . . 280
8.278.2.8 rscp . . . 280
8.278.2.9 uarfcn . . . 280
8.278.2.10 umtsInst . . . 280
8.278.2.11 UMTSInstInfo . . . 280
8.279 nas_UMTSinstInfo Struct Reference . . . 280
8.279.1 Detailed Description . . . 280
8.279.2 Field Documentation . . . 281
8.279.2.1 umtsEcio . . . 281
8.279.2.2 umtsPsc . . . 281
8.279.2.3 umtsRscp . . . 281
8.279.2.4 umtsUarfcn . . . 281
8.280 nas_umtsLTENbrCell Struct Reference . . . 281
8.280.1 Detailed Description . . . 281
8.280.2 Field Documentation . . . 282
8.280.2.1 cellIsTDD . . . 282
8.280.2.2 earfcn . . . 282
8.280.2.3 pci . . . 282

8.280.2.4 rsrp . . . 282
8.280.2.5 rsrq . . . 282
8.280.2.6 srxlev . . . 282
8.281 nas_UniversalTime Struct Reference . . . 282
8.281.1 Detailed Description . . . 282
8.281.2 Field Documentation . . . 283
8.281.2.1 day . . . 283
8.281.2.2 dayOfWeek . . . 283
8.281.2.3 hour . . . 283
8.281.2.4 minute . . . 283
8.281.2.5 month . . . 283
8.281.2.6 second . . . 283
8.281.2.7 year . . . 283
8.282 nas_wcdmaCellInfo Struct Reference . . . 283
8.282.1 Detailed Description . . . 283
8.282.2 Field Documentation . . . 284
8.282.2.1 cpich_ecno . . . 284
8.282.2.2 cpich_rscp . . . 284
8.282.2.3 psc . . . 284
8.282.2.4 srxlev . . . 284
8.283 nas_WCDMAECIOThresh Struct Reference . . . 284
8.283.1 Detailed Description . . . 284
8.283.2 Field Documentation . . . 284
8.283.2.1 pWCDMAECIOThreshList . . . 284
8.283.2.2 WCDMAECIOThreshListLen . . . 284
8.284 nas_WCDMAInfoLTENeighborCell Struct Reference . . . 284
8.284.1 Detailed Description . . . 285
8.284.2 Field Documentation . . . 285
8.284.2.1 UMTSLTENbrCell . . . 285
8.284.2.2 umtsLTENbrCellLen . . . 285
8.284.2.3 wcdmaRRCState . . . 285
8.285 nas_WCDMARSSIThresh Struct Reference . . . 285
8.285.1 Detailed Description . . . 285
8.285.2 Field Documentation . . . 286
8.285.2.1 pWCDMARSSIThreshList . . . 286
8.285.2.2 WCDMARSSIThreshListLen . . . 286
8.286 nas_WCDMASysInfo Struct Reference . . . 286
8.286.1 Detailed Description . . . 286
8.286.2 Field Documentation . . . 288
8.286.2.1 cellId . . . 289

8.286.2.2 cellIdValid . . . 289
8.286.2.3 hsCallStatus . . . 289
8.286.2.4 hsCallStatusValid . . . 289
8.286.2.5 hsInd . . . 289
8.286.2.6 hsIndValid . . . 289
8.286.2.7 lac . . . 289
8.286.2.8 lacValid . . . 289
8.286.2.9 MCC . . . 289
8.286.2.10 MNC . . . 289
8.286.2.11 networkIdValid . . . 289
8.286.2.12 psc . . . 289
8.286.2.13 pscValid . . . 289
8.286.2.14 regRejectInfoValid . . . 289
8.286.2.15 rejCause . . . 289
8.286.2.16 rejectSrvDomain . . . 289
8.286.2.17 sysInfoWCDMA . . . 289
8.287 nas_wcdmaUARFCN Struct Reference . . . 289
8.287.1 Detailed Description . . . 289
8.287.2 Field Documentation . . . 290
8.287.2.1 status . . . 290
8.287.2.2 uarfcn . . . 290
8.288 NASAcqOrderPrefTlv Struct Reference . . . 290
8.288.1 Detailed Description . . . 290
8.288.2 Field Documentation . . . 290
8.288.2.1 AcqOrderLen . . . 290
8.288.2.2 AcqOrderPref . . . 290
8.288.2.3 TlvPresent . . . 290
8.289 NASBandPreferenceTlv Struct Reference . . . 290
8.289.1 Detailed Description . . . 290
8.289.2 Field Documentation . . . 290
8.289.2.1 band_pref . . . 290
8.289.2.2 TlvPresent . . . 290
8.290 NASCiotAcqOrderPrefTlv Struct Reference . . . 291
8.290.1 Detailed Description . . . 291
8.290.2 Field Documentation . . . 291
8.290.2.1 CiotAcqOrderLen . . . 291
8.290.2.2 CiotAcqOrderPref . . . 291
8.290.2.3 TlvPresent . . . 291
8.291 NASCiotLteOpModePrefTlv Struct Reference . . . 291
8.291.1 Detailed Description . . . 291

8.291.2 Field Documentation . . . 291
8.291.2.1 CiotLteOpModePref . . . 291
8.291.2.2 TlvPresent . . . 291
8.292 NASEmergencyModeTlv Struct Reference . . . 291
8.292.1 Detailed Description . . . 292
8.292.2 Field Documentation . . . 292
8.292.2.1 EmerMode . . . 292
8.292.2.2 TlvPresent . . . 292
8.293 NasGetLTECphyCaInfo Struct Reference . . . 292
8.293.1 Detailed Description . . . 292
8.293.2 Field Documentation . . . 293
8.293.2.1 PhyCaAggPcellInfo . . . 293
8.293.2.2 PhyCaAggScellDlBw . . . 293
8.293.2.3 PhyCaAggScellIndex . . . 293
8.293.2.4 PhyCaAggScellIndType . . . 293
8.293.2.5 PhyCaAggScellInfo . . . 293
8.294 NASGWAcqOrderPrefTlv Struct Reference . . . 293
8.294.1 Detailed Description . . . 293
8.294.2 Field Documentation . . . 293
8.294.2.1 GWAcqOrderPref . . . 293
8.294.2.2 TlvPresent . . . 293
8.295 NASLTEBandPreferenceTlv Struct Reference . . . 293
8.295.1 Detailed Description . . . 293
8.295.2 Field Documentation . . . 294
8.295.2.1 LTEBandPref . . . 294
8.295.2.2 TlvPresent . . . 294
8.296 NASLteM1BandPrefTlv Struct Reference . . . 294
8.296.1 Detailed Description . . . 294
8.296.2 Field Documentation . . . 294
8.296.2.1 LteM1BandPref . . . 294
8.296.2.2 TlvPresent . . . 294
8.297 NASLteNasReleaseInfoTlv Struct Reference . . . 294
8.297.1 Detailed Description . . . 294
8.297.2 Field Documentation . . . 295
8.297.2.1 nas_major . . . 295
8.297.2.2 nas_minor . . . 295
8.297.2.3 nas_release . . . 295
8.297.2.4 TlvPresent . . . 295
8.298 NASLteNB1BandPrefTlv Struct Reference . . . 295
8.298.1 Detailed Description . . . 295

8.298.2 Field Documentation . . . 295
8.298.2.1 LteNB1BandPref . . . 295
8.298.2.2 TlvPresent . . . 295
8.299 NASModePreferenceTlv Struct Reference . . . 295
8.299.1 Detailed Description . . . 295
8.299.2 Field Documentation . . . 296
8.299.2.1 ModePref . . . 296
8.299.2.2 TlvPresent . . . 296
8.300 NASNetSelPreferenceTlv Struct Reference . . . 296
8.300.1 Detailed Description . . . 296
8.300.2 Field Documentation . . . 296
8.300.2.1 NetSelPref . . . 296
8.300.2.2 TlvPresent . . . 296
8.301 NASNr5gBandPrefTlv Struct Reference . . . 296
8.301.1 Detailed Description . . . 296
8.301.2 Field Documentation . . . 297
8.301.2.1 Nr5gBandPrefbits1_64 . . . 297
8.301.2.2 Nr5gBandPrefbits_129_192 . . . 297
8.301.2.3 Nr5gBandPrefbits_193_256 . . . 297
8.301.2.4 Nr5gBandPrefbits_65_128 . . . 297
8.301.2.5 TlvPresent . . . 297
8.302 NASOTAMessageTlv Struct Reference . . . 297
8.302.1 Detailed Description . . . 297
8.302.2 Field Documentation . . . 297
8.302.2.1 data_buf . . . 297
8.302.2.2 data_len . . . 297
8.302.2.3 message_type . . . 297
8.302.2.4 TlvPresent . . . 298
8.303 NASPhyCaAggPcellInfo Struct Reference . . . 298
8.303.1 Detailed Description . . . 298
8.303.2 Field Documentation . . . 298
8.303.2.1 dl_bw_value . . . 298
8.303.2.2 freq . . . 298
8.303.2.3 iLTEbandValue . . . 298
8.303.2.4 pci . . . 298
8.303.2.5 TlvPresent . . . 298
8.304 NASPhyCaAggScellDlBw Struct Reference . . . 298
8.304.1 Detailed Description . . . 299
8.304.2 Field Documentation . . . 299
8.304.2.1 dl_bw_value . . . 299

8.304.2.2 TlvPresent . . . 299
8.305 NASPhyCaAggScellIndex Struct Reference . . . 299
8.305.1 Detailed Description . . . 299
8.305.2 Field Documentation . . . 299
8.305.2.1 scell_idx . . . 299
8.305.2.2 TlvPresent . . . 299
8.306 NASPhyCaAggScellIndType Struct Reference . . . 299
8.306.1 Detailed Description . . . 300
8.306.2 Field Documentation . . . 300
8.306.2.1 freq . . . 300
8.306.2.2 pci . . . 300
8.306.2.3 scell_state . . . 300
8.306.2.4 TlvPresent . . . 300
8.307 NASPhyCaAggScellInfo Struct Reference . . . 300
8.307.1 Detailed Description . . . 300
8.307.2 Field Documentation . . . 301
8.307.2.1 dl_bw_value . . . 301
8.307.2.2 freq . . . 301
8.307.2.3 iLTEbandValue . . . 301
8.307.2.4 pci . . . 301
8.307.2.5 scell_state . . . 301
8.307.2.6 TlvPresent . . . 301
8.308 NASPRLPreferenceTlv Struct Reference . . . 301
8.308.1 Detailed Description . . . 301
8.308.2 Field Documentation . . . 302
8.308.2.1 PRLPref . . . 302
8.308.2.2 TlvPresent . . . 302
8.309 NASQmiCbkNasSwiOTAMessageInd Struct Reference . . . 302
8.309.1 Detailed Description . . . 302
8.309.2 Field Documentation . . . 302
8.309.2.1 nasRelInfoTlv . . . 302
8.309.2.2 otaMsgTlv . . . 302
8.309.2.3 timeTlv . . . 302
8.310 NASQmiCbkNasSystemSelPrefInd Struct Reference . . . 302
8.310.1 Detailed Description . . . 303
8.310.2 Field Documentation . . . 304
8.310.2.1 AOPTlv . . . 304
8.310.2.2 BPTlv . . . 304
8.310.2.3 CiotAOPTlv . . . 304
8.310.2.4 CiotOpMPTlv . . . 304

8.310.2.5 EMTlv . . . 304
8.310.2.6 GWAOPTlv . . . 304
8.310.2.7 LBPTlv . . . 304
8.310.2.8 M1BandPTlv . . . 304
8.310.2.9 MPTlv . . . 304
8.310.2.10 NB1BandPTlv . . . 304
8.310.2.11 NR5gBandPTlv . . . 304
8.310.2.12 NSPTlv . . . 304
8.310.2.13 PRLPTlv . . . 305
8.310.2.14 RatDMTlv . . . 305
8.310.2.15 RPTlv . . . 305
8.310.2.16 SDPTlv . . . 305
8.311 NASRatDisabledMaskTlv Struct Reference . . . 305
8.311.1 Detailed Description . . . 305
8.311.2 Field Documentation . . . 305
8.311.2.1 RatDisabledMask . . . 305
8.311.2.2 TlvPresent . . . 305
8.312 NASRoamPreferenceTlv Struct Reference . . . 305
8.312.1 Detailed Description . . . 305
8.312.2 Field Documentation . . . 305
8.312.2.1 RoamPref . . . 305
8.312.2.2 TlvPresent . . . 305
8.313 NASServDomainPrefTlv Struct Reference . . . 306
8.313.1 Detailed Description . . . 306
8.313.2 Field Documentation . . . 306
8.313.2.1 SrvDomainPref . . . 306
8.313.2.2 TlvPresent . . . 306
8.314 NASServingSystemInfo Struct Reference . . . 306
8.314.1 Detailed Description . . . 306
8.314.2 Field Documentation . . . 307
8.314.2.1 csAttachState . . . 307
8.314.2.2 hdrPersonality . . . 307
8.314.2.3 psAttachState . . . 307
8.314.2.4 radioInterfaceList . . . 307
8.314.2.5 radioInterfaceNo . . . 307
8.314.2.6 registrationState . . . 307
8.314.2.7 selectedNetwork . . . 307
8.315 NASTimeInfoTlv Struct Reference . . . 307
8.315.1 Detailed Description . . . 308
8.315.2 Field Documentation . . . 308

8.315.2.1 time . . . 308
8.315.2.2 TlvPresent . . . 308
8.316 newMTMessageTlv Struct Reference . . . 308
8.316.1 Detailed Description . . . 308
8.316.2 Field Documentation . . . 308
8.316.2.1 MTMessageInfo . . . 308
8.316.2.2 TlvPresent . . . 308
8.317 pack_audio_SLQSGetAudioPathConfig_t Struct Reference . . . 308
8.317.1 Detailed Description . . . 309
8.317.2 Field Documentation . . . 309
8.317.2.1 Item . . . 309
8.317.2.2 Profile . . . 309
8.318 pack_audio_SLQSGetAudioProfile_t Struct Reference . . . 309
8.318.1 Detailed Description . . . 309
8.318.2 Field Documentation . . . 310
8.318.2.1 Generator . . . 310
8.319 pack_audio_SLQSGetAudioVolTLBConfig_t Struct Reference . . . 310
8.319.1 Detailed Description . . . 310
8.319.2 Field Documentation . . . 310
8.319.2.1 Generator . . . 310
8.319.2.2 Item . . . 310
8.319.2.3 Profile . . . 310
8.319.2.4 Volume . . . 310
8.320 pack_audio_SLQSSetAudioPathConfig_t Struct Reference . . . 310
8.320.1 Detailed Description . . . 311
8.320.2 Field Documentation . . . 312
8.320.2.1 pCodecSTGain . . . 312
8.320.2.2 pDTMFTXGain . . . 312
8.320.2.3 pECMode . . . 312
8.320.2.4 pNSEnable . . . 312
8.320.2.5 Profile . . . 312
8.320.2.6 pRXAGCList . . . 312
8.320.2.7 pRXAVCAGCSwitch . . . 312
8.320.2.8 pRXAVCList . . . 312
8.320.2.9 pRXPCMIIRFltr . . . 312
8.320.2.10 pTXAGCList . . . 312
8.320.2.11 pTXAVCSwitch . . . 312
8.320.2.12 pTXGain . . . 312
8.320.2.13 pTXPCMIIRFltr . . . 312
8.321 pack_audio_SLQSSetAudioProfile_t Struct Reference . . . 312

8.321.1 Detailed Description . . . 313
8.321.2 Field Documentation . . . 313
8.321.2.1 EarMute . . . 313
8.321.2.2 Generator . . . 313
8.321.2.3 MicMute . . . 313
8.321.2.4 Profile . . . 313
8.321.2.5 Volume . . . 313
8.322 pack_audio_SLQSSetAudioVolTLBConfig_t Struct Reference . . . 314
8.322.1 Detailed Description . . . 314
8.322.2 Field Documentation . . . 314
8.322.2.1 Generator . . . 314
8.322.2.2 Item . . . 314
8.322.2.3 Profile . . . 314
8.322.2.4 Volume . . . 314
8.322.2.5 VolValue . . . 314
8.323 pack_cat_CATSendEnvelopeCommand_t Struct Reference . . . 314
8.323.1 Detailed Description . . . 315
8.323.2 Field Documentation . . . 315
8.323.2.1 cmdID . . . 315
8.323.2.2 dataLen . . . 315
8.323.2.3 pData . . . 315
8.324 pack_cat_CATSendTerminalResponse_t Struct Reference . . . 315
8.324.1 Detailed Description . . . 315
8.324.2 Field Documentation . . . 316
8.324.2.1 dataLen . . . 316
8.324.2.2 pData . . . 316
8.324.2.3 refID . . . 316
8.325 pack_cat_SetCATEventCallback_t Struct Reference . . . 316
8.325.1 Detailed Description . . . 316
8.325.2 Field Documentation . . . 316
8.325.2.1 eventMask . . . 316
8.326 pack_dms_ActivateAutomatic_t Struct Reference . . . 317
8.326.1 Detailed Description . . . 317
8.326.2 Field Documentation . . . 317
8.326.2.1 actCode . . . 317
8.327 pack_dms_GetCustFeaturesV2_t Struct Reference . . . 317
8.327.1 Detailed Description . . . 317
8.327.2 Field Documentation . . . 317
8.327.2.1 cust_id . . . 317
8.327.2.2 list_type . . . 317

8.327.2.3 Tlvresult . . . 318
8.328 pack_dms_ResetToFactoryDefaults_t Struct Reference . . . 318
8.328.1 Detailed Description . . . 318
8.328.2 Field Documentation . . . 318
8.328.2.1 spc . . . 318
8.329 pack_dms_SetActivationStatusCallback_t Struct Reference . . . 318
8.329.1 Detailed Description . . . 318
8.329.2 Field Documentation . . . 318
8.329.2.1 activationState . . . 318
8.330 pack_dms_SetCrashAction_t Struct Reference . . . 318
8.330.1 Detailed Description . . . 319
8.330.2 Field Documentation . . . 319
8.330.2.1 crashAction . . . 319
8.331 pack_dms_SetCustFeature_t Struct Reference . . . 319
8.331.1 Detailed Description . . . 319
8.331.2 Field Documentation . . . 321
8.331.2.1 DHCPRelayEnabled . . . 321
8.331.2.2 DisableIMSI . . . 321
8.331.2.3 GpsEnable . . . 321
8.331.2.4 GPSLPM . . . 321
8.331.2.5 GPSSel . . . 321
8.331.2.6 IPFamSupport . . . 321
8.331.2.7 IsVoiceEnabled . . . 321
8.331.2.8 RMAutoConnect . . . 321
8.331.2.9 SMSSupport . . . 321
8.332 pack_dms_SetCustFeaturesV2_t Struct Reference . . . 321
8.332.1 Detailed Description . . . 321
8.332.2 Field Documentation . . . 322
8.332.2.1 cust_id . . . 322
8.332.2.2 cust_value . . . 322
8.332.2.3 Tlvresult . . . 322
8.332.2.4 value_length . . . 322
8.333 pack_dms_SetEventReport_t Struct Reference . . . 322
8.333.1 Detailed Description . . . 322
8.333.2 Field Documentation . . . 322
8.333.2.1 mode . . . 322
8.334 pack_dms_SetIndicationRegister_t Struct Reference . . . 322
8.334.1 Detailed Description . . . 322
8.334.2 Field Documentation . . . 323
8.334.2.1 PSMCfgChangeInfo . . . 323

8.334.2.2 PSMStatus . . . 323
8.334.2.3 RptIMSCapability . . . 323
8.335 pack_dms_SetPower_t Struct Reference . . . 323
8.335.1 Detailed Description . . . 323
8.335.2 Field Documentation . . . 324
8.335.2.1 mode . . . 324
8.335.2.2 TlvResult . . . 324
8.336 pack_dms_SetUSBComp_t Struct Reference . . . 324
8.336.1 Detailed Description . . . 324
8.336.2 Field Documentation . . . 324
8.336.2.1 TlvResult . . . 324
8.336.2.2 USBComp . . . 325
8.337 pack_dms_SLQSDmsSwiIndicationRegister_t Struct Reference . . . 325
8.337.1 Detailed Description . . . 325
8.337.2 Field Documentation . . . 325
8.337.2.1 resetInfoInd . . . 325
8.338 pack_dms_SLQSSetPowerSaveModeConfig_t Struct Reference . . . 325
8.338.1 Detailed Description . . . 325
8.338.2 Field Documentation . . . 326
8.338.2.1 pActiveTimer . . . 326
8.338.2.2 pPeriodicUpdateTimer . . . 326
8.338.2.3 pPsmEnableState . . . 326
8.339 pack_dms_SLQSSwiGetCrashInfo_t Struct Reference . . . 326
8.339.1 Detailed Description . . . 326
8.339.2 Field Documentation . . . 326
8.339.2.1 clear . . . 326
8.340 pack_dms_SLQSSwiSetDyingGaspCfg_t Struct Reference . . . 326
8.340.1 Detailed Description . . . 326
8.340.2 Field Documentation . . . 327
8.340.2.1 pDestSMSContent . . . 327
8.340.2.2 pDestSMSNum . . . 327
8.341 pack_dms_SLQSSwiSetHostDevInfo_t Struct Reference . . . 327
8.341.1 Detailed Description . . . 327
8.341.2 Field Documentation . . . 327
8.341.2.1 manString . . . 327
8.341.2.2 modelString . . . 328
8.341.2.3 plasmaIDString . . . 328
8.341.2.4 swVerString . . . 328
8.342 pack_dms_SLQSSwiSetOSInfo_t Struct Reference . . . 328
8.342.1 Detailed Description . . . 328

8.342.2 Field Documentation . . . 328
8.342.2.1 nameString . . . 328
8.342.2.2 versionString . . . 328
8.343pack_dms_SwiSetEventReport_t Struct Reference . . . 328
8.343.1 Detailed Description . . . 328
8.343.2 Field Documentation . . . 329
8.343.2.1 pTempReport . . . 329
8.343.2.2 pUIMStatusReport . . . 329
8.343.2.3 pVoltReport . . . 329
8.344pack_dms_SwiUimSelect_t Struct Reference . . . 329
8.344.1 Detailed Description . . . 329
8.344.2 Field Documentation . . . 329
8.344.2.1 uim_select . . . 329
8.345pack_dms_UIMChangePIN_t Struct Reference . . . 329
8.345.1 Detailed Description . . . 330
8.345.2 Field Documentation . . . 330
8.345.2.1 id . . . 330
8.345.2.2 newValue . . . 330
8.345.2.3 oldValue . . . 330
8.346pack_dms_UIMGetControlKeyStatus_t Struct Reference . . . 330
8.346.1 Detailed Description . . . 330
8.346.2 Field Documentation . . . 331
8.346.2.1 facility . . . 331
8.347pack_dms_UIMGetICCID_t Struct Reference . . . 331
8.347.1 Detailed Description . . . 331
8.347.2 Field Documentation . . . 331
8.347.2.1 ParamPresenceMask . . . 331
8.347.2.2 Tlvresult . . . 331
8.348pack_dms_UIMSetControlKeyProtection_t Struct Reference . . . 331
8.348.1 Detailed Description . . . 331
8.348.2 Field Documentation . . . 332
8.348.2.1 facility . . . 332
8.348.2.2 facilityCk . . . 332
8.348.2.3 facilityState . . . 332
8.349pack_dms_UIMSetPINProtection_t Struct Reference . . . 332
8.349.1 Detailed Description . . . 332
8.349.2 Field Documentation . . . 332
8.349.2.1 bEnable . . . 332
8.349.2.2 id . . . 332
8.349.2.3 value . . . 332

8.350 pack_dms_UIMUnblockControlKey_t Struct Reference . . . 333
8.350.1 Detailed Description . . . 333
8.350.2 Field Documentation . . . 333
8.350.2.1 facility . . . 333
8.350.2.2 facilityCk . . . 333
8.351 pack_dms_UIMUnblockPIN_t Struct Reference . . . 333
8.351.1 Detailed Description . . . 333
8.351.2 Field Documentation . . . 334
8.351.2.1 id . . . 334
8.351.2.2 newPin . . . 334
8.351.2.3 pukValue . . . 334
8.352 pack_dms_UIMVerifyPIN_t Struct Reference . . . 334
8.352.1 Detailed Description . . . 334
8.352.2 Field Documentation . . . 334
8.352.2.1 id . . . 334
8.352.2.2 value . . . 334
8.353 pack_fms_GetImagesPreference_t Struct Reference . . . 334
8.353.1 Detailed Description . . . 334
8.353.2 Field Documentation . . . 335
8.353.2.1 TlvResult . . . 335
8.354 pack_fms_GetStoredImages_t Struct Reference . . . 335
8.354.1 Detailed Description . . . 335
8.354.2 Field Documentation . . . 335
8.354.2.1 TlvResult . . . 335
8.355 pack_fms_SetImagesPreference_t Struct Reference . . . 335
8.355.1 Detailed Description . . . 335
8.355.2 Field Documentation . . . 336
8.355.2.1 bForceDownload . . . 336
8.355.2.2 imageListSize . . . 336
8.355.2.3 modemIndex . . . 336
8.355.2.4 pImageList . . . 336
8.355.2.5 TlvResult . . . 336
8.356 pack_ims_SLQSImsConfigIndicationRegister_t Struct Reference . . . 336
8.356.1 Detailed Description . . . 336
8.356.2 Field Documentation . . . 337
8.356.2.1 pRegMgrConfigEvents . . . 337
8.356.2.2 pSIPConfigEvents . . . 337
8.356.2.3 pSMSConfigEvents . . . 337
8.356.2.4 pUserConfigEvents . . . 337
8.356.2.5 pVoIPConfigEvents . . . 337

8.357 pack_ims_SLQSSetIMSSMSConfig_t Struct Reference . . . 337
8.357.1 Detailed Description . . . 337
8.357.2 Field Documentation . . . 338
8.357.2.1 pPhoneCtxtURI . . . 338
8.357.2.2 pPhoneCtxtURILen . . . 338
8.357.2.3 pSMSFormat . . . 338
8.357.2.4 pSMSOverIPNwInd . . . 338
8.358 pack_ims_SLQSSetIMSUserConfig_t Struct Reference . . . 338
8.358.1 Detailed Description . . . 338
8.358.2 Field Documentation . . . 338
8.358.2.1 pIMSDomain . . . 338
8.358.2.2 pIMSDomainLen . . . 339
8.359 pack_ims_SLQSSetIMSVoIPConfig_t Struct Reference . . . 339
8.359.1 Detailed Description . . . 339
8.359.2 Field Documentation . . . 341
8.359.2.1 pAmrMode . . . 341
8.359.2.2 pAmrOctetAligned . . . 341
8.359.2.3 pAmrWbEnable . . . 341
8.359.2.4 pAmrWBMode . . . 341
8.359.2.5 pAmrWBOctetAligned . . . 341
8.359.2.6 pMinSessionExpiryTimer . . . 341
8.359.2.7 pRingBackTimer . . . 341
8.359.2.8 pRingingTimer . . . 341
8.359.2.9 pRTPRTCPInactTimer . . . 341
8.359.2.10 pScrAmrEnable . . . 341
8.359.2.11 pScrAmrWbEnable . . . 341
8.359.2.12 pSessionExpiryTimer . . . 341
8.360 pack_ims_SLQSSetRegMgrConfig_t Struct Reference . . . 341
8.360.1 Detailed Description . . . 341
8.360.2 Field Documentation . . . 342
8.360.2.1 pCSCFPortName . . . 342
8.360.2.2 pCSCFPortNameLen . . . 342
8.360.2.3 pIMSTestMode . . . 342
8.360.2.4 pPriCSCFPort . . . 342
8.361 pack_ims_SLQSSetSIPConfig_t Struct Reference . . . 342
8.361.1 Detailed Description . . . 342
8.361.2 Field Documentation . . . 342
8.361.2.1 pSigCompEnabled . . . 343
8.361.2.2 pSIPLocalPort . . . 343
8.361.2.3 pSubscribeTimer . . . 343

8.361.2.4 pTimerSIPReg . . . 343
8.361.2.5 pTimerT1 . . . 343
8.361.2.6 pTimerT2 . . . 343
8.361.2.7 pTimerTf . . . 343
8.362 pack_imsa_SLQSRegisterIMSAIndication_t Struct Reference . . . 343
8.362.1 Detailed Description . . . 343
8.362.2 Field Documentation . . . 344
8.362.2.1 has_PdpStatusConfig . . . 344
8.362.2.2 has_RatHandoverStatusConfig . . . 344
8.362.2.3 has_RegStatusConfig . . . 344
8.362.2.4 has_ServiceStatusConfig . . . 344
8.362.2.5 PdpStatusConfig . . . 344
8.362.2.6 RatHandoverStatusConfig . . . 344
8.362.2.7 RegStatusConfig . . . 344
8.362.2.8 ServiceStatusConfig . . . 344
8.363 pack_loc_Delete_Assist_Data_t Struct Reference . . . 344
8.363.1 Detailed Description . . . 344
8.363.2 Field Documentation . . . 345
8.363.2.1 pBdsSVInfo . . . 345
8.363.2.2 pCellDb . . . 345
8.363.2.3 pClkInfo . . . 345
8.363.2.4 pGnssData . . . 345
8.363.2.5 pSVInfo . . . 345
8.363.2.6 Tlvresult . . . 345
8.364 pack_loc_EventRegister_t Struct Reference . . . 345
8.364.1 Detailed Description . . . 345
8.364.2 Field Documentation . . . 347
8.364.2.1 eventRegister . . . 347
8.364.2.2 Tlvresult . . . 347
8.365 pack_loc_SetExtPowerState_t Struct Reference . . . 347
8.365.1 Detailed Description . . . 347
8.365.2 Field Documentation . . . 347
8.365.2.1 extPowerState . . . 347
8.365.2.2 Tlvresult . . . 347
8.366 pack_loc_SetOperationMode_t Struct Reference . . . 347
8.366.1 Detailed Description . . . 348
8.366.2 Field Documentation . . . 348
8.366.2.1 mode . . . 348
8.366.2.2 Tlvresult . . . 348
8.367 pack_loc_SLQSLOCGetBestAvailPos_t Struct Reference . . . 348

8.367.1 Detailed Description . . . 348
8.367.2 Field Documentation . . . 348
8.367.2.1 TlvResult . . . 348
8.367.2.2 xid . . . 349
8.368pack_loc_SLQSLOCGetServer_t Struct Reference . . . 349
8.368.1 Detailed Description . . . 349
8.368.2 Field Documentation . . . 349
8.368.2.1 has_serverAddrTypeMask . . . 349
8.368.2.2 serverAddrTypeMask . . . 349
8.368.2.3 serverType . . . 349
8.369pack_loc_SLQSLOCInjectPosition_t Struct Reference . . . 349
8.369.1 Detailed Description . . . 350
8.369.2 Field Documentation . . . 353
8.369.2.1 altitudeSrcInfo . . . 353
8.369.2.2 altitudeWrtEllipsoid . . . 353
8.369.2.3 altitudeWrtMeanSeaLevel . . . 353
8.369.2.4 has_altitudeSrcInfo . . . 353
8.369.2.5 has_altitudeWrtEllipsoid . . . 353
8.369.2.6 has_altitudeWrtMeanSeaLevel . . . 353
8.369.2.7 has_horConfidence . . . 353
8.369.2.8 has_horReliability . . . 353
8.369.2.9 has_horUncCircular . . . 353
8.369.2.10has_latitude . . . 353
8.369.2.11has_longitude . . . 353
8.369.2.12has_positionSrc . . . 353
8.369.2.13has_rawHorConfidence . . . 353
8.369.2.14has_rawHorUncCircular . . . 353
8.369.2.15has_timestampAge . . . 353
8.369.2.16has_timestampUtc . . . 353
8.369.2.17has_vertConfidence . . . 353
8.369.2.18has_vertRelicability . . . 354
8.369.2.19has_vertUnc . . . 354
8.369.2.20horConfidence . . . 354
8.369.2.21horReliability . . . 354
8.369.2.22horUncCircular . . . 354
8.369.2.23latitude . . . 354
8.369.2.24longitude . . . 354
8.369.2.25positionSrc . . . 354
8.369.2.26rawHorConfidence . . . 354
8.369.2.27rawHorUncCircular . . . 354

8.369.2.28 timestampAge . . . 354
8.369.2.29 timestampUtc . . . 354
8.369.2.30 vertConfidence . . . 354
8.369.2.31 vertReliability . . . 354
8.369.2.32 vertUnc . . . 354
8.370 pack_loc_SLQSLOCInjectSensorData_t Struct Reference . . . 354
8.370.1 Detailed Description . . . 354
8.370.2 Field Documentation . . . 355
8.370.2.1 acceleroData . . . 355
8.370.2.2 acceleroTimeSrc . . . 355
8.370.2.3 accelTemp . . . 355
8.370.2.4 gyroData . . . 355
8.370.2.5 gyroTemp . . . 356
8.370.2.6 gyroTimeSrc . . . 356
8.370.2.7 has_acceleroTimeSrc . . . 356
8.370.2.8 has_accelTemp . . . 356
8.370.2.9 has_accleroData . . . 356
8.370.2.10 has_gyroData . . . 356
8.370.2.11 has_gyroTemp . . . 356
8.370.2.12 has_gyroTimeSrc . . . 356
8.370.2.13 has_opaqueId . . . 356
8.370.2.14 opaqueId . . . 356
8.371 pack_loc_SLQSLOCInjectUTCTime_t Struct Reference . . . 356
8.371.1 Detailed Description . . . 356
8.371.2 Field Documentation . . . 356
8.371.2.1 timeMsec . . . 356
8.371.2.2 timeUncMsec . . . 356
8.372 pack_loc_SLQSLOCSetCradleMountConfig_t Struct Reference . . . 356
8.372.1 Detailed Description . . . 357
8.372.2 Field Documentation . . . 357
8.372.2.1 confidence . . . 357
8.372.2.2 has_confidence . . . 357
8.372.2.3 state . . . 357
8.373 pack_loc_SLQSLOCSetServer_t Struct Reference . . . 357
8.373.1 Detailed Description . . . 357
8.373.2 Field Documentation . . . 358
8.373.2.1 pIPv4Config . . . 358
8.373.2.2 pIPv6Config . . . 358
8.373.2.3 pURLAddr . . . 358
8.373.2.4 serverType . . . 358

8.374 pack_loc_Start_t Struct Reference . . . 358
8.374.1 Detailed Description . . . 358
8.374.2 Field Documentation . . . 359
8.374.2.1 pApplicationInfo . . . 359
8.374.2.2 pConfigAltitudeAssumed . . . 359
8.374.2.3 pHorizontalAccuracyLvl . . . 359
8.374.2.4 pIntermediateReportState . . . 359
8.374.2.5 pMinIntervalTime . . . 359
8.374.2.6 pRecurrenceType . . . 360
8.374.2.7 SessionId . . . 360
8.374.2.8 Tlvresult . . . 360
8.375 pack_loc_Stop_t Struct Reference . . . 360
8.375.1 Detailed Description . . . 360
8.375.2 Field Documentation . . . 360
8.375.2.1 SessionId . . . 360
8.375.2.2 Tlvresult . . . 360
8.376 pack_nas_InitiateDomainAttach_t Struct Reference . . . 360
8.376.1 Detailed Description . . . 360
8.376.2 Field Documentation . . . 360
8.376.2.1 action . . . 361
8.377 pack_nas_PerformNetworkScanPCI_t Struct Reference . . . 361
8.377.1 Field Documentation . . . 361
8.377.1.1 pNetworkType . . . 361
8.377.1.2 pScanType . . . 361
8.378 pack_nas_SetACCOLC_t Struct Reference . . . 361
8.378.1 Detailed Description . . . 361
8.378.2 Field Documentation . . . 361
8.378.2.1 accolc . . . 361
8.378.2.2 spc . . . 361
8.379 pack_nas_SetCDMANetworkParameters_t Struct Reference . . . 361
8.379.1 Detailed Description . . . 362
8.379.2 Field Documentation . . . 362
8.379.2.1 pApplication . . . 363
8.379.2.2 pBroadcast . . . 363
8.379.2.3 pCustomSCP . . . 363
8.379.2.4 pForceRev0 . . . 363
8.379.2.5 pProtocol . . . 363
8.379.2.6 pRoaming . . . 363
8.379.2.7 pSPC . . . 363
8.380 pack_nas_SetNetworkPreference_t Struct Reference . . . 363

8.380.1 Detailed Description . . . 363
8.380.2 Field Documentation . . . 364
8.380.2.1 Duration . . . 364
8.380.2.2 TechnologyPref . . . 364
8.380.2.3 Tlvresult . . . 364
8.381 pack_nas_SLQSConfigSigInfo_t Struct Reference . . . 364
8.381.1 Detailed Description . . . 364
8.381.2 Field Documentation . . . 365
8.381.2.1 pECIOThresh . . . 365
8.381.2.2 pHDRSINRThresh . . . 365
8.381.2.3 pIOThresh . . . 365
8.381.2.4 pLTESigRptCfg . . . 365
8.381.2.5 pLTESNRThresh . . . 365
8.381.2.6 pRSRPThresh . . . 365
8.381.2.7 pRSRQThresh . . . 365
8.381.2.8 pRSSIThresh . . . 365
8.381.2.9 pTDSCDMASINRCONFThresh . . . 365
8.382 pack_nas_SLQSGetPLMNName_t Struct Reference . . . 365
8.382.1 Detailed Description . . . 365
8.382.2 Field Documentation . . . 366
8.382.2.1 mcc . . . 366
8.382.2.2 mnc . . . 366
8.382.2.3 pMncPcsStatus . . . 366
8.383 pack_nas_SLQSInitiateNetworkRegistration_t Struct Reference . . . 366
8.383.1 Detailed Description . . . 366
8.383.2 Field Documentation . . . 367
8.383.2.1 pChangeDuration . . . 367
8.383.2.2 pMncPcsDigitStatus . . . 367
8.383.2.3 pMNRInfo . . . 367
8.383.2.4 regAction . . . 367
8.384 pack_nas_SLQSNasConfigSigInfo2_t Struct Reference . . . 367
8.384.1 Detailed Description . . . 368
8.384.2 Field Documentation . . . 370
8.384.2.1 pCDMAECIODelta . . . 370
8.384.2.2 pCDMAECIOThresh . . . 370
8.384.2.3 pCDMARSSIDelta . . . 370
8.384.2.4 pCDMARSSIThresh . . . 370
8.384.2.5 pGSMRSSIDelta . . . 370
8.384.2.6 pGSMRSSIThresh . . . 370
8.384.2.7 pHDRECIODelta . . . 370

8.384.2.8 pHDRECIOThresh . . . 371
8.384.2.9 pHDRIODelta . . . 371
8.384.2.10 pHDRIOThresh . . . 371
8.384.2.11 pHDRRSSIDelta . . . 371
8.384.2.12 pHDRRSSIThresh . . . 371
8.384.2.13 pHDRSINRDelta . . . 371
8.384.2.14 pHDRSINRThresh . . . 371
8.384.2.15 pLTERSRPDelta . . . 371
8.384.2.16 pLTERSRPThresh . . . 371
8.384.2.17 pLTERSRQDelta . . . 371
8.384.2.18 pLTERSRQThresh . . . 371
8.384.2.19 pLTERSSIDelta . . . 371
8.384.2.20 pLTERSSIThresh . . . 371
8.384.2.21 pLTESigRptConfig . . . 371
8.384.2.22 pLTESNRDelta . . . 371
8.384.2.23 pLTESNRThresh . . . 371
8.384.2.24 pTDSCDMAECIODelta . . . 371
8.384.2.25 pTDSCDMAECIOThresh . . . 371
8.384.2.26 pTDSCDMARSCPDelta . . . 371
8.384.2.27 pTDSCDMARSCPThresh . . . 371
8.384.2.28 pTDSCDMARSSIDelta . . . 371
8.384.2.29 pTDSCDMARSSIThresh . . . 371
8.384.2.30 pTDSCDMASINRDelta . . . 371
8.384.2.31 pTDSCDMASINRThresh . . . 371
8.384.2.32 pWCDMAECIODelta . . . 371
8.384.2.33 pWCDMAECIOThresh . . . 371
8.384.2.34 pWCDMARSSIDelta . . . 371
8.384.2.35 pWCDMARSSIThresh . . . 371
8.385 pack_nas_SLQSNasGet3GPP2Subscription_t Struct Reference . . . 372
8.385.1 Detailed Description . . . 372
8.385.2 Field Documentation . . . 372
8.385.2.1 namID . . . 372
8.386 pack_nas_SLQSNASGeteDRXParamsExt_t Struct Reference . . . 372
8.386.1 Detailed Description . . . 372
8.386.2 Field Documentation . . . 373
8.386.2.1 pEdrxRAT . . . 373
8.386.2.2 pLteOpMode . . . 373
8.387 pack_nas_SLQSNasGetTxRxInfo_t Struct Reference . . . 373
8.387.1 Detailed Description . . . 373
8.387.2 Field Documentation . . . 373

8.387.2.1 radio_if . . . 373
8.388 pack_nas_SLQSNasIndicationRegisterExt_t Struct Reference . . . 373
8.388.1 Detailed Description . . . 374
8.388.2 Field Documentation . . . 376
8.388.2.1 pDDTMInd . . . 376
8.388.2.2 pDualStandByPrefInd . . . 376
8.388.2.3 pEdrxChangeInfoInd . . . 376
8.388.2.4 pErrorRateInd . . . 376
8.388.2.5 pHDRNewUATIAssInd . . . 376
8.388.2.6 pHDRSessionCloseInd . . . 376
8.388.2.7 pLTECphyCa . . . 376
8.388.2.8 pManagedRoamingInd . . . 376
8.388.2.9 pNetworkRejectInd . . . 376
8.388.2.10 pNetworkTimeInd . . . 376
8.388.2.11 pServingSystemInd . . . 376
8.388.2.12 pSignalStrengthInd . . . 376
8.388.2.13 pSubscriptionInfoInd . . . 376
8.388.2.14 pSuppressSysInfoInd . . . 376
8.388.2.15 pSysInfoInd . . . 376
8.388.2.16 pSystemSelectionInd . . . 376
8.389 pack_nas_SLQSNASSeteDRXParams_t Struct Reference . . . 376
8.389.1 Detailed Description . . . 377
8.389.2 Field Documentation . . . 377
8.389.2.1 pCycleLen . . . 377
8.389.2.2 pEdrxCiotLteMode . . . 378
8.389.2.3 pEdrxEnable . . . 378
8.389.2.4 pEdrxRatType . . . 378
8.389.2.5 pPagingTimeWindow . . . 378
8.390 pack_nas_SLQSNasSwiIndicationRegister_t Struct Reference . . . 378
8.390.1 Detailed Description . . . 378
8.390.2 Field Documentation . . . 379
8.390.2.1 gsmUmtsDl . . . 379
8.390.2.2 gsmUmtsUl . . . 379
8.390.2.3 lteEmmDl . . . 379
8.390.2.4 lteEmmUl . . . 379
8.390.2.5 lteEsmDl . . . 379
8.390.2.6 lteEsmUl . . . 379
8.390.2.7 pRankIndicatorInd . . . 379
8.390.2.8 pTimer . . . 379
8.391 pack_nas_SLQSNASSwiSetChannelLock_t Struct Reference . . . 379

8.391.1 Detailed Description . . . 379
8.391.2 Field Documentation . . . 379
8.391.2.1 pLteEARFCN . . . 379
8.391.2.2 pLtePCI . . . 380
8.391.2.3 pWcdmaUARFCN . . . 380
8.392 pack_nas_SLQSSetBandPreference_t Struct Reference . . . 380
8.392.1 Detailed Description . . . 380
8.392.2 Field Documentation . . . 381
8.392.2.1 bandPref . . . 382
8.393 pack_nas_SLQSSetSignalStrengthsCallback_t Struct Reference . . . 382
8.393.1 Detailed Description . . . 382
8.393.2 Field Documentation . . . 382
8.393.2.1 bEnable . . . 382
8.393.2.2 pSigIndReq . . . 382
8.394 pack_nas_SLQSSetSysSelectionPref_t Struct Reference . . . 382
8.394.1 Detailed Description . . . 382
8.394.2 Field Documentation . . . 387
8.394.2.1 pAcqOrderPref . . . 387
8.394.2.2 pBandPref . . . 387
8.394.2.3 pChgDuration . . . 387
8.394.2.4 pCSGID . . . 387
8.394.2.5 pEmerMode . . . 387
8.394.2.6 pGWAcqOrderPref . . . 387
8.394.2.7 pLTEBandPref . . . 387
8.394.2.8 pMNCIncPCSDigStat . . . 387
8.394.2.9 pModePref . . . 387
8.394.2.10 pNetSelPref . . . 387
8.394.2.11 pPRLPref . . . 387
8.394.2.12 pRAT . . . 387
8.394.2.13 pRoamPref . . . 387
8.394.2.14 pSrvDomainPref . . . 387
8.394.2.15 pSrvRegRestriction . . . 388
8.394.2.16 pTdscdmaBandPref . . . 388
8.395 pack_nas_SLQSSetSysSelectionPrefExt_t Struct Reference . . . 388
8.395.1 Detailed Description . . . 388
8.395.2 Field Documentation . . . 397
8.395.2.1 pAcqOrderPref . . . 397
8.395.2.2 pBandPref . . . 397
8.395.2.3 pChgDuration . . . 397
8.395.2.4 pCiotAcqOrderPref . . . 397

8.395.2.5 pCiotLteOpMode . . . 397
8.395.2.6 pCiotLteOpModePref . . . 397
8.395.2.7 pCSGID . . . 397
8.395.2.8 pEmerMode . . . 397
8.395.2.9 pGWAcqOrderPref . . . 397
8.395.2.10 pLTEBandPref . . . 397
8.395.2.11 pLTEBandPrefExt . . . 397
8.395.2.12 pLteM1BandPref . . . 397
8.395.2.13 pLteNb1BandPref . . . 397
8.395.2.14 pMNCIncPCSDigStat . . . 397
8.395.2.15 pModePref . . . 397
8.395.2.16 pNetSelPref . . . 397
8.395.2.17 pNr5gBandPref . . . 397
8.395.2.18 pPRLPref . . . 398
8.395.2.19 pRAT . . . 398
8.395.2.20 pRoamPref . . . 398
8.395.2.21 pSrvDomainPref . . . 398
8.395.2.22 pSrvRegRestriction . . . 398
8.395.2.23 pTdscdmaBandPref . . . 398
8.396 pack_nas_SLQSSwiPSDetach_t Struct Reference . . . 398
8.396.1 Detailed Description . . . 398
8.396.2 Field Documentation . . . 398
8.396.2.1 pDetachAction . . . 398
8.397 pack_pds_PDSInjectTimeReference_t Struct Reference . . . 398
8.397.1 Detailed Description . . . 398
8.397.2 Field Documentation . . . 399
8.397.2.1 systemDiscontinuities . . . 399
8.397.2.2 systemTime . . . 399
8.398 pack_pds_ResetPDSData_t Struct Reference . . . 399
8.398.1 Detailed Description . . . 399
8.398.2 Field Documentation . . . 399
8.398.2.1 pCellDataMask . . . 400
8.398.2.2 pGPSDataMask . . . 400
8.399 pack_pds_SetEventReportCallback_t Struct Reference . . . 400
8.399.1 Detailed Description . . . 400
8.399.2 Field Documentation . . . 400
8.399.2.1 posDataNmea . . . 400
8.399.2.2 rptPosData . . . 400
8.400 pack_pds_SetPDSDefaults_t Struct Reference . . . 400
8.400.1 Detailed Description . . . 400

8.400.2 Field Documentation . . . 401
8.400.2.1 accuracy . . . 401
8.400.2.2 interval . . . 401
8.400.2.3 operation . . . 401
8.400.2.4 timeout . . . 401
8.401 pack_pds_SetPDSState_t Struct Reference . . . 401
8.401.1 Detailed Description . . . 401
8.401.2 Field Documentation . . . 401
8.401.2.1 enable . . . 401
8.402 pack_pds_SetPortAutomaticTracking_t Struct Reference . . . 401
8.402.1 Detailed Description . . . 402
8.402.2 Field Documentation . . . 402
8.402.2.1 bAuto . . . 402
8.403 pack_pds_SetServiceAutomaticTracking_t Struct Reference . . . 402
8.403.1 Detailed Description . . . 402
8.403.2 Field Documentation . . . 402
8.403.2.1 bAuto . . . 402
8.404 pack_pds_SetXTRAAutomaticDownload_t Struct Reference . . . 402
8.404.1 Detailed Description . . . 403
8.404.2 Field Documentation . . . 403
8.404.2.1 bEnabled . . . 403
8.404.2.2 interval . . . 403
8.405 pack_pds_SetXTRANetwork_t Struct Reference . . . 403
8.405.1 Detailed Description . . . 403
8.405.2 Field Documentation . . . 403
8.405.2.1 preference . . . 403
8.406 pack_pds_SLQSGetAGPSConfig_t Struct Reference . . . 403
8.406.1 Detailed Description . . . 404
8.406.2 Field Documentation . . . 404
8.406.2.1 pNetworkMode . . . 404
8.407 pack_pds_SLQSPDSInjectAbsoluteTimeReference_t Struct Reference . . . 404
8.407.1 Detailed Description . . . 404
8.407.2 Field Documentation . . . 404
8.407.2.1 forceFlag . . . 404
8.407.2.2 timeBase . . . 404
8.407.2.3 timeMsec . . . 405
8.407.2.4 timeUncMsec . . . 405
8.408 pack_pds_SLQSPDSInjectPositionData_t Struct Reference . . . 405
8.408.1 Detailed Description . . . 405
8.408.2 Field Documentation . . . 406

8.408.2.1 pAltitudeWrtEllipsoid . . . 406
8.408.2.2 pAltitudeWrtSealevel . . . 406
8.408.2.3 pHorizontalConfidence . . . 406
8.408.2.4 pHorizontalUncCircular . . . 406
8.408.2.5 pLatitude . . . 406
8.408.2.6 pLongitude . . . 406
8.408.2.7 pPositionSource . . . 406
8.408.2.8 pTimeStamp . . . 406
8.408.2.9 pTimeType . . . 406
8.408.2.10 pVerticalConfidence . . . 406
8.408.2.11 pVerticalUnc . . . 407
8.409 pack_pds_SLQSSetAGPSConfig_t Struct Reference . . . 407
8.409.1 Detailed Description . . . 407
8.409.2 Field Documentation . . . 407
8.409.2.1 pNetworkMode . . . 407
8.409.2.2 pServerAddress . . . 407
8.409.2.3 pServerPort . . . 407
8.409.2.4 pServerURL . . . 407
8.409.2.5 pServerURLLength . . . 407
8.410 pack_pds_SLQSSetPositionMethodState_t Struct Reference . . . 407
8.410.1 Detailed Description . . . 408
8.410.2 Field Documentation . . . 408
8.410.2.1 pWifiState . . . 408
8.410.2.2 pXtraDataState . . . 408
8.410.2.3 pXtraTimeState . . . 408
8.411 pack_pds_StartPDSTrackingSessionExt_t Struct Reference . . . 408
8.411.1 Detailed Description . . . 408
8.411.2 Field Documentation . . . 409
8.411.2.1 fixAccuracy . . . 409
8.411.2.2 fixCount . . . 409
8.411.2.3 fixInterval . . . 409
8.411.2.4 fixTimeout . . . 409
8.411.2.5 sessionControl . . . 409
8.411.2.6 sessionOperation . . . 409
8.411.2.7 sessionServerOption . . . 409
8.411.2.8 sessionType . . . 409
8.412 pack_qmi_t Struct Reference . . . 409
8.412.1 Detailed Description . . . 410
8.412.2 Field Documentation . . . 410
8.412.2.1 msgid . . . 410

8.412.2.2 svc . . . 410
8.412.2.3 timeout . . . 410
8.412.2.4 xid . . . 410
8.413pack_qos_BindDataPort_t Struct Reference . . . 410
8.413.1 Detailed Description . . . 410
8.413.2 Field Documentation . . . 411
8.413.2.1 pMuxID . . . 411
8.413.2.2 pPeripheralEndPointID . . . 411
8.413.2.3 pSIODataPort . . . 411
8.414pack_qos_SLQSQosSwiReadApnExtraParams_t Struct Reference . . . 411
8.414.1 Detailed Description . . . 411
8.414.2 Field Documentation . . . 411
8.414.2.1 apnId . . . 411
8.415pack_qos_SLQSQosSwiReadDataStats_t Struct Reference . . . 411
8.415.1 Detailed Description . . . 411
8.415.2 Field Documentation . . . 411
8.415.2.1 apnId . . . 411
8.416pack_qos_SLQSSetQosEventCallback_t Struct Reference . . . 411
8.416.1 Detailed Description . . . 412
8.416.2 Field Documentation . . . 412
8.416.2.1 enable . . . 412
8.417pack_rms_SetSMSWake_t Struct Reference . . . 412
8.417.1 Detailed Description . . . 412
8.417.2 Field Documentation . . . 412
8.417.2.1 enabled . . . 412
8.417.2.2 wake_mask . . . 412
8.418pack_sar_SLQSSetRfSarState_t Struct Reference . . . 412
8.418.1 Detailed Description . . . 413
8.418.2 Field Documentation . . . 413
8.418.2.1 RfSarState . . . 413
8.419pack_sms_SaveSMS_t Struct Reference . . . 413
8.419.1 Detailed Description . . . 413
8.419.2 Field Documentation . . . 414
8.419.2.1 messageFormat . . . 414
8.419.2.2 messageSize . . . 414
8.419.2.3 pMessage . . . 414
8.419.2.4 storageType . . . 414
8.420pack_sms_SendSMS_t Struct Reference . . . 414
8.420.1 Detailed Description . . . 414
8.420.2 Field Documentation . . . 414

8.420.2.1 messageFormat . . . 414
8.420.2.2 messageSize . . . 414
8.420.2.3 pLinktimer . . . 415
8.420.2.4 pMessage . . . 415
8.421 pack_sms_SetNewSMSCallback_t Struct Reference . . . 415
8.421.1 Detailed Description . . . 415
8.421.2 Field Documentation . . . 415
8.421.2.1 status . . . 415
8.422 pack_sms_SetSMSCAddress_t Struct Reference . . . 415
8.422.1 Detailed Description . . . 415
8.422.2 Field Documentation . . . 415
8.422.2.1 pSMSCAddress . . . 415
8.422.2.2 pSMSCType . . . 415
8.423 pack_sms_SLQSDeleteSMS_t Struct Reference . . . 415
8.423.1 Detailed Description . . . 416
8.423.2 Field Documentation . . . 416
8.423.2.1 pMessageIndex . . . 416
8.423.2.2 pMessageMode . . . 416
8.423.2.3 pMessageTag . . . 416
8.423.2.4 storageType . . . 416
8.424 pack_sms_SLQSGetSMS_t Struct Reference . . . 416
8.424.1 Detailed Description . . . 417
8.424.2 Field Documentation . . . 417
8.424.2.1 messageIndex . . . 417
8.424.2.2 pMessageMode . . . 417
8.424.2.3 storageType . . . 417
8.425 pack_sms_SLQSGetSmsBroadcastConfig_t Struct Reference . . . 417
8.425.1 Detailed Description . . . 417
8.425.2 Field Documentation . . . 417
8.425.2.1 mode . . . 417
8.426 pack_sms_SLQSGetSMSList_t Struct Reference . . . 417
8.426.1 Detailed Description . . . 418
8.426.2 Field Documentation . . . 418
8.426.2.1 pMessageMode . . . 418
8.426.2.2 pRequestedTag . . . 418
8.426.2.3 storageType . . . 418
8.427 pack_sms_SLQSModifySMSStatus_t Struct Reference . . . 418
8.427.1 Detailed Description . . . 418
8.427.2 Field Documentation . . . 419
8.427.2.1 messageIndex . . . 419

8.427.2.2 messageTag . . . 419
8.427.2.3 pMessageMode . . . 419
8.427.2.4 storageType . . . 419
8.428 pack_sms_SLQSSendAsyncSMS_t Struct Reference . . . 419
8.428.1 Detailed Description . . . 419
8.428.2 Field Documentation . . . 419
8.428.2.1 pSendSmsParams . . . 419
8.429 pack_sms_SLQSSetIndicationRegister_t Struct Reference . . . 419
8.429.1 Detailed Description . . . 420
8.429.2 Field Documentation . . . 420
8.429.2.1 pSetIndicationRegReq . . . 420
8.430 pack_sms_SLQSSetSmsBroadcastActivation_t Struct Reference . . . 420
8.430.1 Detailed Description . . . 420
8.430.2 Field Documentation . . . 420
8.430.2.1 broadcastActivate . . . 420
8.430.2.2 mode . . . 420
8.431 pack_sms_SLQSSetSmsBroadcastConfig_t Struct Reference . . . 420
8.431.1 Detailed Description . . . 421
8.431.2 Field Documentation . . . 421
8.431.2.1 mode . . . 421
8.431.2.2 pBroadcastConfig . . . 421
8.431.2.3 pCDMABroadcastConfig . . . 421
8.432 pack_sms_SLQSSetSmsStorage_t Struct Reference . . . 421
8.432.1 Detailed Description . . . 421
8.432.2 Field Documentation . . . 421
8.432.2.1 smsStorage . . . 422
8.433 pack_sms_SLQSSmsGetMaxStorageSize_t Struct Reference . . . 422
8.433.1 Detailed Description . . . 422
8.433.2 Field Documentation . . . 422
8.433.2.1 pMaxStorageSizeReq . . . 422
8.434 pack_sms_SLQSSmsSetRoutes_t Struct Reference . . . 422
8.434.1 Detailed Description . . . 422
8.434.2 Field Documentation . . . 422
8.434.2.1 pSetRoutesReq . . . 422
8.435 pack_swiaudio_SLQSGetM2MAudioProfile_t Struct Reference . . . 422
8.435.1 Detailed Description . . . 423
8.435.2 Field Documentation . . . 423
8.435.2.1 pGenerator . . . 423
8.436 pack_swiaudio_SLQSGetM2MAudioVolume_t Struct Reference . . . 423
8.436.1 Detailed Description . . . 423

8.436.2 Field Documentation . . . 423
8.436.2.1 Generator . . . 423
8.436.2.2 Profile . . . 423
8.437pack_swiaudio_SLQSGetM2MAVMute_t Struct Reference . . . 423
8.437.1 Detailed Description . . . 423
8.437.2 Field Documentation . . . 424
8.437.2.1 Profile . . . 424
8.438pack_swiaudio_SLQSGetM2MSpkrGain_t Struct Reference . . . 424
8.438.1 Detailed Description . . . 424
8.438.2 Field Documentation . . . 424
8.438.2.1 Profile . . . 424
8.439pack_swiaudio_SLQSSetM2MAudioAVCFG_t Struct Reference . . . 424
8.439.1 Detailed Description . . . 424
8.439.2 Field Documentation . . . 425
8.439.2.1 Device . . . 425
8.439.2.2 PIFACEId . . . 425
8.439.2.3 pPCMParams . . . 425
8.439.2.4 Profile . . . 425
8.440pack_swiaudio_SLQSSetM2MAudioLPBK_t Struct Reference . . . 425
8.440.1 Detailed Description . . . 425
8.440.2 Field Documentation . . . 425
8.440.2.1 Enable . . . 425
8.441pack_swiaudio_SLQSSetM2MAudioProfile_t Struct Reference . . . 425
8.441.1 Detailed Description . . . 426
8.441.2 Field Documentation . . . 426
8.441.2.1 pCwtMute . . . 426
8.441.2.2 pEarMute . . . 426
8.441.2.3 pGenerator . . . 426
8.441.2.4 pMicMute . . . 426
8.441.2.5 Profile . . . 426
8.441.2.6 pVolume . . . 426
8.442pack_swiaudio_SLQSSetM2MAudioVolume_t Struct Reference . . . 427
8.442.1 Detailed Description . . . 427
8.442.2 Field Documentation . . . 427
8.442.2.1 Generator . . . 427
8.442.2.2 Level . . . 427
8.442.2.3 Profile . . . 427
8.443pack_swiaudio_SLQSSetM2MAVMute_t Struct Reference . . . 427
8.443.1 Detailed Description . . . 427
8.443.2 Field Documentation . . . 428

8.443.2.1 EarMute . . . 428
8.443.2.2 MicMute . . . 428
8.443.2.3 pCwtMute . . . 428
8.443.2.4 Profile . . . 428
8.444 pack_swiaudio_SLQSSetM2MSpkrGain_t Struct Reference . . . 428
8.444.1 Detailed Description . . . 428
8.444.2 Field Documentation . . . 428
8.444.2.1 Profile . . . 428
8.444.2.2 Value . . . 428
8.445 pack_swiavms_SLQSAVMSSendSelection_t Struct Reference . . . 429
8.445.1 Detailed Description . . . 429
8.445.2 Field Documentation . . . 429
8.445.2.1 pClientPerformOperationFlag . . . 429
8.445.2.2 pDeferTime . . . 429
8.445.2.3 pPackageID . . . 429
8.445.2.4 pRejectReason . . . 429
8.445.2.5 selection . . . 429
8.446 pack_swiavms_SLQSAVMSSetSettings_t Struct Reference . . . 429
8.446.1 Detailed Description . . . 430
8.446.2 Field Documentation . . . 431
8.446.2.1 AutoConnect . . . 431
8.446.2.2 AutoReboot . . . 431
8.446.2.3 pAPNInfo . . . 431
8.446.2.4 pConnectionRetryTimers . . . 431
8.446.2.5 pFwAutoSDM . . . 431
8.446.2.6 pNotifStore . . . 431
8.446.2.7 pPeriodInfo . . . 431
8.446.2.8 pPollingTimer . . . 431
8.446.2.9 PromptFwDownload . . . 431
8.446.2.10 PromptFwUpdate . . . 431
8.447 pack_swiavms_SLQSAVMSSetSettings_v2_t Struct Reference . . . 431
8.447.1 Detailed Description . . . 431
8.447.2 Field Documentation . . . 432
8.447.2.1 AutoConnect . . . 433
8.447.2.2 pAPNInfo . . . 433
8.447.2.3 pAutoReboot . . . 433
8.447.2.4 pConnectionRetryTimers . . . 433
8.447.2.5 pFwAutoSDM . . . 433
8.447.2.6 pNotifStore . . . 433
8.447.2.7 pPeriodInfo . . . 433

8.447.2.8 pPollingTimer . . . 433
8.447.2.9 PromptFwDownload . . . 433
8.447.2.10 PromptFwUpdate . . . 433
8.448 pack_swiavms_SLQSAVMSStartSession_t Struct Reference . . . 433
8.448.1 Detailed Description . . . 433
8.448.2 Field Documentation . . . 433
8.448.2.1 sessionType . . . 433
8.449 pack_swiavms_SLQSAVMSStopSession_t Struct Reference . . . 433
8.449.1 Detailed Description . . . 433
8.449.2 Field Documentation . . . 434
8.449.2.1 sessionType . . . 434
8.450 pack_swidms_SLQSSwiDmsSetMTU_t Struct Reference . . . 434
8.450.1 Detailed Description . . . 434
8.450.2 Field Documentation . . . 434
8.450.2.1 MTUSize . . . 434
8.451 pack_swidms_SLQSSwiDmsSetUsbComp_t Struct Reference . . . 434
8.451.1 Detailed Description . . . 434
8.451.2 Field Documentation . . . 435
8.451.2.1 CfgValue . . . 435
8.452 pack_swidms_SLQSSwiDmsSetUsbNetNum_t Struct Reference . . . 435
8.452.1 Detailed Description . . . 435
8.452.2 Field Documentation . . . 435
8.452.2.1 nUsbNetNum . . . 436
8.453 pack_swiloc_SwiLocSetAutoStart_t Struct Reference . . . 436
8.453.1 Detailed Description . . . 436
8.453.2 Field Documentation . . . 437
8.453.2.1 fix_rate . . . 437
8.453.2.2 fix_type . . . 437
8.453.2.3 function . . . 437
8.453.2.4 max_dist . . . 437
8.453.2.5 max_time . . . 437
8.453.2.6 set_fix_rate . . . 437
8.453.2.7 set_fix_type . . . 437
8.453.2.8 set_function . . . 437
8.453.2.9 set_max_dist . . . 437
8.453.2.10 set_max_time . . . 437
8.454 pack_swioma_SLQSOMADMCancelSession_t Struct Reference . . . 437
8.454.1 Detailed Description . . . 437
8.454.2 Field Documentation . . . 438
8.454.2.1 sessionType . . . 438

8.455pack_swioma_SLQSOMADMCancelSessionExt_t Struct Reference . . . 438
8.455.1 Detailed Description . . . 438
8.455.2 Field Documentation . . . 438
8.455.2.1 sessionType . . . 438
8.456pack_swioma_SLQSOMADMGetSessionInfo_t Struct Reference . . . 438
8.456.1 Detailed Description . . . 438
8.456.2 Field Documentation . . . 439
8.456.2.1 SessionType . . . 439
8.457pack_swioma_SLQSOMADMSendSelection_t Struct Reference . . . 439
8.457.1 Detailed Description . . . 439
8.457.2 Field Documentation . . . 439
8.457.2.1 pDeferTime . . . 439
8.457.2.2 pRejectReason . . . 439
8.457.2.3 selection . . . 439
8.458pack_swioma_SLQSOMADMSendSelectionExt_t Struct Reference . . . 439
8.458.1 Detailed Description . . . 439
8.458.2 Field Documentation . . . 440
8.458.2.1 selection . . . 440
8.459pack_swioma_SLQSOMADMSetSettings_t Struct Reference . . . 440
8.459.1 Detailed Description . . . 440
8.459.2 Field Documentation . . . 441
8.459.2.1 FOTAdownload . . . 441
8.459.2.2 FOTAUpdate . . . 441
8.459.2.3 pAutosdm . . . 441
8.459.2.4 pFwAutoCheck . . . 441
8.460pack_swioma_SLQSOMADMSetSettingsExt_t Struct Reference . . . 441
8.460.1 Detailed Description . . . 441
8.460.2 Field Documentation . . . 442
8.460.2.1 FOTAdownload . . . 442
8.460.2.2 FOTAUpdate . . . 442
8.460.2.3 FUMOEnable . . . 442
8.460.2.4 OMADMEnable . . . 442
8.460.2.5 OMADMLogEnable . . . 442
8.460.2.6 PRLEnable . . . 442
8.461pack_swioma_SLQSOMADMStartSession_t Struct Reference . . . 442
8.461.1 Detailed Description . . . 442
8.461.2 Field Documentation . . . 442
8.461.2.1 sessionType . . . 442
8.462pack_swioma_SLQSOMADMStartSessionExt_t Struct Reference . . . 442
8.462.1 Detailed Description . . . 443

8.462.2 Field Documentation . . . 443
8.462.2.1 sessionType . . . 443
8.463pack_tmd_SLQSTmdDeRegNotMitigationLvl_t Struct Reference . . . 443
8.463.1 Detailed Description . . . 443
8.463.2 Field Documentation . . . 443
8.463.2.1 mitigationDevID . . . 443
8.463.2.2 mitigationDevIDLen . . . 443
8.464pack_tmd_SLQSTmdGetMitigationLvl_t Struct Reference . . . 443
8.464.1 Detailed Description . . . 444
8.464.2 Field Documentation . . . 444
8.464.2.1 mitigationDevID . . . 444
8.464.2.2 mitigationDevIDLen . . . 444
8.465pack_tmd_SLQSTmdRegNotMitigationLvl_t Struct Reference . . . 444
8.465.1 Detailed Description . . . 444
8.465.2 Field Documentation . . . 444
8.465.2.1 mitigationDevID . . . 444
8.465.2.2 mitigationDevIDLen . . . 444
8.466pack_uim_ChangePin_t Struct Reference . . . 444
8.466.1 Detailed Description . . . 445
8.466.2 Field Documentation . . . 445
8.466.2.1 changePIN . . . 445
8.466.2.2 EncryptedPIN1 . . . 445
8.466.2.3 pIndicationToken . . . 445
8.466.2.4 pKeyReferenceID . . . 445
8.466.2.5 sessionInfo . . . 445
8.466.2.6 Tlvresult . . . 445
8.467pack_uim_ReadTransparent_t Struct Reference . . . 445
8.467.1 Detailed Description . . . 446
8.467.2 Field Documentation . . . 446
8.467.2.1 fileIndex . . . 446
8.467.2.2 pEncryptData . . . 446
8.467.2.3 pIndicationToken . . . 446
8.467.2.4 readTransparent . . . 446
8.467.2.5 sessionInfo . . . 446
8.467.2.6 Tlvresult . . . 446
8.468pack_uim_SetPinProtection_t Struct Reference . . . 447
8.468.1 Detailed Description . . . 447
8.468.2 Field Documentation . . . 447
8.468.2.1 EncryptedPIN1 . . . 447
8.468.2.2 pIndicationToken . . . 447

8.468.2.3 pinProtection . . . 447
8.468.2.4 pKeyReferenceID . . . 447
8.468.2.5 sessionInfo . . . 447
8.468.2.6 Tlvresult . . . 448
8.469 pack_uim_SLQSUIMAuthenticate_t Struct Reference . . . 448
8.469.1 Detailed Description . . . 448
8.469.2 Field Documentation . . . 448
8.469.2.1 authData . . . 448
8.469.2.2 pIndicationToken . . . 448
8.469.2.3 sessionInfo . . . 448
8.470 pack_uim_SLQSUIMDepersonalization_t Struct Reference . . . 448
8.470.1 Detailed Description . . . 448
8.470.2 Field Documentation . . . 449
8.470.2.1 depersonilisationInfo . . . 449
8.471 pack_uim_SLQSUIMEventRegister_t Struct Reference . . . 449
8.471.1 Detailed Description . . . 449
8.471.2 Field Documentation . . . 449
8.471.2.1 eventMask . . . 449
8.472 pack_uim_SLQSUIMGetConfiguration_t Struct Reference . . . 449
8.472.1 Detailed Description . . . 449
8.472.2 Field Documentation . . . 449
8.472.2.1 pConfigurationMask . . . 449
8.473 pack_uim_SLQSUIMGetFileAttributes_t Struct Reference . . . 450
8.473.1 Detailed Description . . . 450
8.473.2 Field Documentation . . . 450
8.473.2.1 fileIndex . . . 450
8.473.2.2 pIndicationToken . . . 450
8.473.2.3 sessionInfo . . . 450
8.474 pack_uim_SLQSUIMPowerDown_t Struct Reference . . . 450
8.474.1 Detailed Description . . . 450
8.474.2 Field Documentation . . . 451
8.474.2.1 slot . . . 451
8.475 pack_uim_SLQSUIMPowerUp_t Struct Reference . . . 451
8.475.1 Detailed Description . . . 451
8.475.2 Field Documentation . . . 451
8.475.2.1 pIgnoreHotSwapSwitch . . . 451
8.475.2.2 slot . . . 451
8.476 pack_uim_SLQSUIMRefreshComplete_t Struct Reference . . . 451
8.476.1 Detailed Description . . . 451
8.476.2 Field Documentation . . . 452

8.476.2.1 refreshComplete . . . 452
8.476.2.2 sessionInfo . . . 452
8.477 pack_uim_SLQSUIMRefreshGetLastEvent_t Struct Reference . . . 452
8.477.1 Detailed Description . . . 452
8.477.2 Field Documentation . . . 452
8.477.2.1 sessionInfo . . . 452
8.478 pack_uim_SLQSUIMRefreshOK_t Struct Reference . . . 452
8.478.1 Detailed Description . . . 452
8.478.2 Field Documentation . . . 453
8.478.2.1 OKtoRefresh . . . 453
8.478.2.2 sessionInfo . . . 453
8.479 pack_uim_SLQSUIMRefreshRegister_t Struct Reference . . . 453
8.479.1 Detailed Description . . . 453
8.479.2 Field Documentation . . . 453
8.479.2.1 regRefresh . . . 453
8.479.2.2 sessionInfo . . . 453
8.480 pack_uim_SLQSUIMSwitchSlot_t Struct Reference . . . 453
8.480.1 Detailed Description . . . 453
8.480.2 Field Documentation . . . 454
8.480.2.1 bLogicalSlot . . . 454
8.480.2.2 ulPhysicalSlot . . . 454
8.481 pack_uim_UnblockPin_t Struct Reference . . . 454
8.481.1 Detailed Description . . . 454
8.481.2 Field Documentation . . . 455
8.481.2.1 EncryptedPIN1 . . . 455
8.481.2.2 pIndicationToken . . . 455
8.481.2.3 pinProtection . . . 455
8.481.2.4 pKeyReferenceID . . . 455
8.481.2.5 sessionInfo . . . 455
8.481.2.6 Tlvresult . . . 455
8.482 pack_uim_VerifyPin_t Struct Reference . . . 455
8.482.1 Detailed Description . . . 455
8.482.2 Field Documentation . . . 456
8.482.2.1 pEncryptedPIN1 . . . 456
8.482.2.2 pIndicationToken . . . 456
8.482.2.3 pKeyReferenceID . . . 456
8.482.2.4 sessionInfo . . . 456
8.482.2.5 Tlvresult . . . 456
8.482.2.6 verifyPIN . . . 456
8.483 pack_voice_AnswerUSSD_t Struct Reference . . . 456

8.483.1 Detailed Description . . . 456
8.483.2 Field Documentation . . . 457
8.483.2.1 pInfo . . . 457
8.484 pack_voice_OriginateUSSD_t Struct Reference . . . 457
8.484.1 Detailed Description . . . 457
8.484.2 Field Documentation . . . 457
8.484.2.1 pInfo . . . 457
8.485 pack_voice_SLQSOriginateUSSD_t Struct Reference . . . 457
8.485.1 Detailed Description . . . 457
8.485.2 Field Documentation . . . 458
8.485.2.1 ussData . . . 458
8.485.2.2 ussDCS . . . 458
8.485.2.3 ussLen . . . 458
8.486 pack_voice_SLQSVoiceALSSelectLine_t Struct Reference . . . 458
8.486.1 Detailed Description . . . 458
8.486.2 Field Documentation . . . 458
8.486.2.1 lineValue . . . 458
8.487 pack_voice_SLQSVoiceALSSetLineSwitching_t Struct Reference . . . 458
8.487.1 Detailed Description . . . 458
8.487.2 Field Documentation . . . 458
8.487.2.1 switchOption . . . 458
8.488 pack_voice_SLQSVoiceAnswerCall_t Struct Reference . . . 459
8.488.1 Detailed Description . . . 459
8.488.2 Field Documentation . . . 459
8.488.2.1 pCallId . . . 459
8.489 pack_voice_SLQSVoiceBindSubscription_t Struct Reference . . . 459
8.489.1 Detailed Description . . . 459
8.489.2 Field Documentation . . . 459
8.489.2.1 subsType . . . 459
8.490 pack_voice_SLQSVoiceBurstDTMF_t Struct Reference . . . 459
8.490.1 Detailed Description . . . 460
8.490.2 Field Documentation . . . 460
8.490.2.1 BurstDTMFInfo . . . 460
8.490.2.2 pBurstDTMFLengths . . . 460
8.491 pack_voice_SLQSVoiceDialCall_t Struct Reference . . . 460
8.491.1 Detailed Description . . . 460
8.491.2 Field Documentation . . . 461
8.491.2.1 callNumber . . . 461
8.491.2.2 pCallPartySubAdd . . . 461
8.491.2.3 pCallType . . . 461

8.491.2.4 pCLIRType . . . 461
8.491.2.5 pCUGInfo . . . 461
8.491.2.6 pEmergencyCategory . . . 462
8.491.2.7 pSvcType . . . 462
8.491.2.8 pUUSInFo . . . 462
8.492 pack_voice_SLQSVoiceEndCall_t Struct Reference . . . 462
8.492.1 Detailed Description . . . 462
8.492.2 Field Documentation . . . 462
8.492.2.1 pCallId . . . 462
8.493 pack_voice_SLQSVoiceGetCallBarring_t Struct Reference . . . 462
8.493.1 Detailed Description . . . 462
8.493.2 Field Documentation . . . 463
8.493.2.1 pSvcClass . . . 463
8.493.2.2 reason . . . 463
8.494 pack_voice_SLQSVoiceGetCallForwardingStatus_t Struct Reference . . . 463
8.494.1 Detailed Description . . . 463
8.494.2 Field Documentation . . . 464
8.494.2.1 pSvcClass . . . 464
8.494.2.2 Reason . . . 464
8.495 pack_voice_SLQSVoiceGetCallInfo_t Struct Reference . . . 464
8.495.1 Detailed Description . . . 464
8.495.2 Field Documentation . . . 464
8.495.2.1 callID . . . 464
8.496 pack_voice_SLQSVoiceGetCallWaiting_t Struct Reference . . . 464
8.496.1 Detailed Description . . . 465
8.496.2 Field Documentation . . . 465
8.496.2.1 pSvcClass . . . 465
8.497 pack_voice_SLQSVoiceGetConfig_t Struct Reference . . . 465
8.497.1 Detailed Description . . . 465
8.497.2 Field Documentation . . . 466
8.497.2.1 pAirTimer . . . 466
8.497.2.2 pAMRStatus . . . 466
8.497.2.3 pAutoAnswer . . . 466
8.497.2.4 pNamID . . . 466
8.497.2.5 pPrefVoicePrivacy . . . 466
8.497.2.6 pPrefVoiceSO . . . 466
8.497.2.7 pRoamTimer . . . 466
8.497.2.8 pTTYMode . . . 466
8.497.2.9 pVoiceDomainPref . . . 466
8.498 pack_voice_SLQSVoiceIndicationRegister_t Struct Reference . . . 467

8.498.1 Detailed Description . . . 467
8.498.2 Field Documentation . . . 467
8.498.2.1 pRegDTMFEvents . . . 467
8.498.2.2 pRegVoicePrivacyEvents . . . 467
8.498.2.3 pSuppsNotifEvents . . . 467
8.499 pack_voice_SLQSVoiceManageCalls_t Struct Reference . . . 467
8.499.1 Detailed Description . . . 468
8.499.2 Field Documentation . . . 468
8.499.2.1 pCallID . . . 468
8.499.2.2 SUPSType . . . 468
8.500 pack_voice_SLQSVoiceOrigUSSDNoWait_t Struct Reference . . . 468
8.500.1 Detailed Description . . . 468
8.500.2 Field Documentation . . . 469
8.500.2.1 USSInformation . . . 469
8.501 pack_voice_SLQSVoiceSendFlash_t Struct Reference . . . 469
8.501.1 Detailed Description . . . 469
8.501.2 Field Documentation . . . 469
8.501.2.1 pCallID . . . 469
8.501.2.2 pFlashPayLd . . . 469
8.501.2.3 pFlashType . . . 469
8.502 pack_voice_SLQSVoiceSetCallBarringPassword_t Struct Reference . . . 469
8.502.1 Detailed Description . . . 470
8.502.2 Field Documentation . . . 470
8.502.2.1 newPasswd . . . 470
8.502.2.2 newPasswdAgain . . . 470
8.502.2.3 oldPasswd . . . 470
8.502.2.4 Reason . . . 470
8.503 pack_voice_SLQSVoiceSetConfig_t Struct Reference . . . 470
8.503.1 Detailed Description . . . 471
8.503.2 Field Documentation . . . 472
8.503.2.1 pAirTimerConfig . . . 472
8.503.2.2 pAutoAnswer . . . 472
8.503.2.3 pPrefVoiceDomain . . . 472
8.503.2.4 pPrefVoiceSO . . . 472
8.503.2.5 pRoamTimerConfig . . . 472
8.503.2.6 pTTYMode . . . 472
8.504 pack_voice_SLQSVoiceSetPreferredPrivacy_t Struct Reference . . . 472
8.504.1 Detailed Description . . . 472
8.504.2 Field Documentation . . . 472
8.504.2.1 privacyPref . . . 472

8.505 pack_voice_SLQSVoiceSetSUPSService_t Struct Reference . . . 472
8.505.1 Detailed Description . . . 472
8.505.2 Field Documentation . . . 474
8.505.2.1 pCallBarringPasswd . . . 474
8.505.2.2 pCallForwardingNumber . . . 474
8.505.2.3 pCallFwdTypeAndPlan . . . 474
8.505.2.4 pServiceClass . . . 474
8.505.2.5 pTimerVal . . . 474
8.505.2.6 reason . . . 474
8.505.2.7 voiceSvc . . . 474
8.506 pack_voice_SLQSVoiceStartContDTMF_t Struct Reference . . . 474
8.506.1 Detailed Description . . . 474
8.506.2 Field Documentation . . . 475
8.506.2.1 DTMFdigit . . . 475
8.506.2.2 pCallID . . . 475
8.507 pack_voice_SLQSVoiceStopContDTMF_t Struct Reference . . . 475
8.507.1 Detailed Description . . . 475
8.507.2 Field Documentation . . . 475
8.507.2.1 callID . . . 475
8.508 pack_wds_DHCPv4ClientLeaseChange_t Struct Reference . . . 475
8.508.1 Detailed Description . . . 475
8.508.2 Field Documentation . . . 476
8.508.2.1 pEnableNotification . . . 476
8.509 pack_wds_GetDefaultProfile_t Struct Reference . . . 476
8.509.1 Detailed Description . . . 476
8.509.2 Field Documentation . . . 476
8.509.2.1 profiletype . . . 476
8.510 pack_wds_GetDefaultProfileNum_t Struct Reference . . . 476
8.510.1 Detailed Description . . . 476
8.510.2 Field Documentation . . . 476
8.510.2.1 family . . . 476
8.510.2.2 type . . . 477
8.511 pack_wds_GetDormancyState_t Struct Reference . . . 477
8.511.1 Detailed Description . . . 477
8.512 pack_wds_GetLastMobileIPError_t Struct Reference . . . 477
8.512.1 Detailed Description . . . 477
8.513 pack_wds_GetMobileIP_t Struct Reference . . . 477
8.513.1 Detailed Description . . . 477
8.514 pack_wds_GetMobileIPProfile_t Struct Reference . . . 477
8.514.1 Detailed Description . . . 477

8.514.2 Field Documentation . . . 478
8.514.2.1 index . . . 478
8.515 pack_wds_GetPacketStatistics_t Struct Reference . . . 478
8.515.1 Detailed Description . . . 478
8.515.2 Field Documentation . . . 478
8.515.2.1 pStatMask . . . 478
8.516 pack_wds_GetPacketStatus_t Struct Reference . . . 478
8.516.1 Detailed Description . . . 478
8.516.2 Field Documentation . . . 479
8.516.2.1 statmask . . . 479
8.517 pack_wds_GetSessionDuration_t Struct Reference . . . 479
8.517.1 Detailed Description . . . 479
8.518 pack_wds_RMSetTransferStatistics_t Struct Reference . . . 479
8.518.1 Detailed Description . . . 479
8.518.2 Field Documentation . . . 479
8.518.2.1 RmTrasnferStaticsReq . . . 479
8.519 pack_wds_SetAutoconnect_t Struct Reference . . . 480
8.519.1 Detailed Description . . . 480
8.519.2 Field Documentation . . . 480
8.519.2.1 acroamsetting . . . 480
8.519.2.2 acsetting . . . 480
8.520 pack_wds_SetDefaultProfile_t Struct Reference . . . 480
8.520.1 Detailed Description . . . 480
8.520.2 Field Documentation . . . 481
8.520.2.1 authentication . . . 482
8.520.2.2 ipAddress . . . 482
8.520.2.3 pApnname . . . 482
8.520.2.4 pdpType . . . 482
8.520.2.5 pName . . . 482
8.520.2.6 pPassword . . . 482
8.520.2.7 primaryDNS . . . 482
8.520.2.8 profileType . . . 482
8.520.2.9 pUsername . . . 482
8.520.2.10 secondaryDNS . . . 482
8.521 pack_wds_SetDefaultProfileNum_t Struct Reference . . . 482
8.521.1 Detailed Description . . . 482
8.521.2 Field Documentation . . . 482
8.521.2.1 family . . . 482
8.521.2.2 index . . . 482
8.521.2.3 type . . . 482

8.522 pack_wds_SetMobileIP_t Struct Reference . . . 483
8.522.1 Detailed Description . . . 483
8.522.2 Field Documentation . . . 483
8.522.2.1 mode . . . 483
8.523 pack_wds_SetMobileIPParameters_t Struct Reference . . . 483
8.523.1 Detailed Description . . . 483
8.523.2 Field Documentation . . . 484
8.523.2.1 pHA2002bis . . . 484
8.523.2.2 pHAAuthenticator . . . 484
8.523.2.3 pMode . . . 484
8.523.2.4 pReRegPeriod . . . 484
8.523.2.5 pReRegTraffic . . . 484
8.523.2.6 pRetryInterval . . . 484
8.523.2.7 pRetryLimit . . . 484
8.523.2.8 pSPC . . . 484
8.524 pack_wds_SetMobileIPProfile_t Struct Reference . . . 484
8.524.1 Detailed Description . . . 485
8.524.2 Field Documentation . . . 485
8.524.2.1 index . . . 486
8.524.2.2 pAAASPI . . . 486
8.524.2.3 pAddress . . . 486
8.524.2.4 pEnabled . . . 486
8.524.2.5 pHASPI . . . 486
8.524.2.6 pMNAAA . . . 486
8.524.2.7 pMNHA . . . 486
8.524.2.8 pNAI . . . 486
8.524.2.9 pPrimaryHA . . . 486
8.524.2.10 pRevTunneling . . . 486
8.524.2.11 pSecondaryHA . . . 486
8.524.2.12 spc . . . 486
8.525 pack_wds_SLQSCreateProfile_t Struct Reference . . . 486
8.525.1 Detailed Description . . . 486
8.525.2 Field Documentation . . . 487
8.525.2.1 pCurProfile . . . 487
8.525.2.2 pProfileId . . . 487
8.525.2.3 pProfileType . . . 487
8.526 pack_wds_SLQSDeleteProfile_t Struct Reference . . . 487
8.526.1 Detailed Description . . . 487
8.526.2 Field Documentation . . . 487
8.526.2.1 profileIndex . . . 487

8.526.2.2 profileType . . . 487
8.527 pack_wds_SLQSGetCurrDataSystemStat_t Struct Reference . . . 487
8.527.1 Detailed Description . . . 487
8.528 pack_wds_SLQSGetDataBearerTechnology_t Struct Reference . . . 488
8.528.1 Detailed Description . . . 488
8.529 pack_wds_SLQSGetDUNCallInfo_t Struct Reference . . . 488
8.529.1 Detailed Description . . . 488
8.529.2 Field Documentation . . . 489
8.529.2.1 Mask . . . 489
8.529.2.2 pReportChannelRate . . . 489
8.529.2.3 pReportConnStatus . . . 489
8.529.2.4 pReportDataBearerTech . . . 489
8.529.2.5 pReportDormStatus . . . 489
8.529.2.6 pTransferStatInd . . . 489
8.530 pack_wds_SLQSGetProfileSettings_t Struct Reference . . . 489
8.530.1 Detailed Description . . . 489
8.530.2 Field Documentation . . . 490
8.530.2.1 ProfileId . . . 490
8.530.2.2 ProfileType . . . 490
8.531 pack_wds_SLQSGetRuntimeSettings_t Struct Reference . . . 490
8.531.1 Detailed Description . . . 490
8.531.2 Field Documentation . . . 491
8.531.2.1 pReqSettings . . . 491
8.532 pack_wds_SLQSModifyProfile_t Struct Reference . . . 491
8.532.1 Detailed Description . . . 491
8.532.2 Field Documentation . . . 492
8.532.2.1 curProfile . . . 492
8.532.2.2 pProfileId . . . 492
8.532.2.3 pProfileType . . . 492
8.533 pack_wds_SLQSSet3GPPConfigItem_t Struct Reference . . . 492
8.533.1 Detailed Description . . . 492
8.533.2 Field Documentation . . . 493
8.533.2.1 LTEAttachProfileListLen . . . 493
8.533.2.2 p3gppRelease . . . 493
8.533.2.3 pDefaultPDNEnabled . . . 493
8.533.2.4 pLTEAttachProfile . . . 493
8.533.2.5 pLTEAttachProfileList . . . 493
8.533.2.6 pProfileList . . . 494
8.534 pack_wds_SLQSSetIPFamilyPreference_t Struct Reference . . . 494
8.534.1 Detailed Description . . . 494

8.534.2 Field Documentation . . . 494
8.534.2.1 IPFamilyPreference . . . 494
8.535pack_wds_SLQSSetWdsEventCallback_t Struct Reference . . . 494
8.535.1 Detailed Description . . . 494
8.535.2 Field Documentation . . . 495
8.535.2.1 currentDataBearer . . . 495
8.535.2.2 dataBearer . . . 495
8.535.2.3 dataBearerTechExt . . . 495
8.535.2.4 dataSystemStatus . . . 495
8.535.2.5 dormancyStatus . . . 495
8.535.2.6 interval . . . 495
8.535.2.7 mobileIP . . . 495
8.535.2.8 transferStats . . . 495
8.536pack_wds_SLQSSGetDHCPv4ClientConfig_t Struct Reference . . . 495
8.536.1 Detailed Description . . . 495
8.536.2 Field Documentation . . . 495
8.536.2.1 pProfileId . . . 495
8.537pack_wds_SLQSSSetDHCPv4ClientConfig_t Struct Reference . . . 495
8.537.1 Detailed Description . . . 495
8.537.2 Field Documentation . . . 496
8.537.2.1 pHwConfig . . . 496
8.537.2.2 pProfileId . . . 496
8.537.2.3 pRequestOptionList . . . 496
8.538pack_wds_SLQSSSetLoopback_t Struct Reference . . . 496
8.538.1 Detailed Description . . . 496
8.538.2 Field Documentation . . . 496
8.538.2.1 loopbackMode . . . 496
8.538.2.2 loopbackMultiplier . . . 496
8.539pack_wds_SLQSStartDataSession_t Struct Reference . . . 496
8.539.1 Detailed Description . . . 497
8.539.2 Field Documentation . . . 497
8.539.2.1 pAuth . . . 497
8.539.2.2 pPass . . . 497
8.539.2.3 pprofileid3gpp . . . 497
8.539.2.4 pprofileid3gpp2 . . . 497
8.539.2.5 pTech . . . 497
8.539.2.6 pUser . . . 498
8.540pack_wds_SLQSStopDataSession_t Struct Reference . . . 498
8.540.1 Detailed Description . . . 498
8.540.2 Field Documentation . . . 498

8.540.2.1 psid . . . 498
8.541 pack_wds_SLQSWdsSetEventReport_t Struct Reference . . . 498
8.541.1 Detailed Description . . . 498
8.541.2 Field Documentation . . . 499
8.541.2.1 pCurrChannelRateInd . . . 499
8.541.2.2 pCurrDataBearerTechInd . . . 499
8.541.2.3 pCurrPrefDataSysInd . . . 499
8.541.2.4 pDataBearerTechInd . . . 499
8.541.2.5 pDataCallStatusChangeInd . . . 499
8.541.2.6 pDataSystemStatusChangeInd . . . 500
8.541.2.7 pDormancyStatusInd . . . 500
8.541.2.8 pEVDOPageMonPerChangeInd . . . 500
8.541.2.9 pMIPStatusInd . . . 500
8.541.2.10 pTransferStatInd . . . 500
8.542 pack_wds_SLQSWdsSwiPDPRuntimeSettings_t Struct Reference . . . 500
8.542.1 Detailed Description . . . 500
8.542.2 Field Documentation . . . 500
8.542.2.1 contextId . . . 500
8.542.2.2 contextType . . . 500
8.543 PackCreateProfileOut Struct Reference . . . 500
8.543.1 Detailed Description . . . 500
8.543.2 Field Documentation . . . 501
8.543.2.1 ExtErrorCode . . . 501
8.543.2.2 ProfileIndex . . . 501
8.543.2.3 ProfileType . . . 501
8.544 packgetDyingGaspCfg Struct Reference . . . 501
8.544.1 Detailed Description . . . 501
8.544.2 Field Documentation . . . 501
8.544.2.1 pDestSMSContent . . . 501
8.544.2.2 pDestSMSNum . . . 501
8.545 packgetDyingGaspStatistics Struct Reference . . . 501
8.545.1 Detailed Description . . . 502
8.545.2 Field Documentation . . . 502
8.545.2.1 pSMSAttemptedFlag . . . 502
8.545.2.2 pTimeStamp . . . 502
8.546 PackSwiAvmsSetSettingsAPNInfo Struct Reference . . . 502
8.546.1 Detailed Description . . . 502
8.546.2 Field Documentation . . . 503
8.546.2.1 bAPNLength . . . 503
8.546.2.2 bPWDLength . . . 503

8.546.2.3 bUnameLength . . . 503
8.546.2.4 szAPN . . . 503
8.546.2.5 szPWD . . . 503
8.546.2.6 szUname . . . 503
8.547 PackSwiAvmsSetSettingsConnectionRetryTimers Struct Reference . . . 503
8.547.1 Detailed Description . . . 503
8.547.2 Field Documentation . . . 503
8.547.2.1 Timers . . . 504
8.548 PackSwiAvmsSetSettingsPeriodInfo Struct Reference . . . 504
8.548.1 Detailed Description . . . 504
8.548.2 Field Documentation . . . 504
8.548.2.1 ulMax . . . 504
8.548.2.2 ulMin . . . 504
8.549 PackSwiAVMSSettingsAPNInfo Struct Reference . . . 504
8.549.1 Detailed Description . . . 504
8.549.2 Field Documentation . . . 504
8.549.2.1 bAPNLength . . . 504
8.549.2.2 bPWDLength . . . 505
8.549.2.3 bUnameLength . . . 505
8.549.2.4 pAPN . . . 505
8.549.2.5 pPWD . . . 505
8.549.2.6 pUname . . . 505
8.550 PackSwiAVMSSettingsConnectionRetryTimers Struct Reference . . . 505
8.550.1 Detailed Description . . . 505
8.550.2 Field Documentation . . . 505
8.550.2.1 Timers . . . 505
8.551 PackSwiAVMSSettingsPeriodsInfo Struct Reference . . . 506
8.551.1 Detailed Description . . . 506
8.551.2 Field Documentation . . . 506
8.551.2.1 max . . . 506
8.551.2.2 min . . . 506
8.552 qmiSmsMessageList Struct Reference . . . 506
8.552.1 Detailed Description . . . 506
8.552.2 Field Documentation . . . 506
8.552.2.1 messageIndex . . . 506
8.552.2.2 messageTag . . . 506
8.553 qmiWDSDataBearerTechnology Struct Reference . . . 506
8.553.1 Detailed Description . . . 507
8.553.2 Field Documentation . . . 507
8.553.2.1 currentNetwork . . . 507

8.553.2.2 ratMask . . . 507
8.553.2.3 soMask . . . 507
8.554 qmTlvResult Struct Reference . . . 507
8.554.1 Field Documentation . . . 507
8.554.1.1 DeviceError . . . 507
8.554.1.2 DeviceResult . . . 507
8.554.1.3 TlvPresenceMask . . . 507
8.554.1.4 TlvResultCode . . . 507
8.555 qos_BindDataPortMuxID_t Struct Reference . . . 507
8.555.1 Detailed Description . . . 508
8.555.2 Field Documentation . . . 508
8.555.2.1 MuxID . . . 508
8.556 qos_BindDataPortPeripheralEndPointID_t Struct Reference . . . 508
8.556.1 Detailed Description . . . 508
8.556.2 Field Documentation . . . 508
8.556.2.1 EndPointType . . . 508
8.556.2.2 IfaceID . . . 508
8.557 qos_BindDataPortSIODataPort_t Struct Reference . . . 508
8.557.1 Detailed Description . . . 509
8.557.2 Field Documentation . . . 509
8.557.2.1 SIODataPort . . . 509
8.558 RFBandInfoElements Struct Reference . . . 509
8.558.1 Detailed Description . . . 509
8.558.2 Field Documentation . . . 509
8.558.2.1 activeBandClass . . . 509
8.558.2.2 activeChannel . . . 509
8.558.2.3 radioInterface . . . 509
8.559 rmTrasnferStaticsReq Struct Reference . . . 509
8.559.1 Detailed Description . . . 510
8.559.2 Field Documentation . . . 510
8.559.2.1 bResetStatistics . . . 510
8.559.2.2 ulMask . . . 510
8.560 sensorData_t Struct Reference . . . 510
8.560.1 Detailed Description . . . 510
8.560.2 Field Documentation . . . 511
8.560.2.1 flags . . . 511
8.560.2.2 sensorDataLen . . . 511
8.560.2.3 timeOfFirstSample . . . 511
8.560.2.4 timeOffset . . . 511
8.560.2.5 xAxis . . . 511

8.560.2.6 yAxis . . . 511
8.560.2.7 zAxis . . . 511
8.561 slot_t Struct Reference . . . 512
8.561.1 Detailed Description . . . 512
8.561.2 Field Documentation . . . 512
8.561.2.1 bICCID . . . 512
8.561.2.2 bICCIDLength . . . 512
8.561.2.3 bLogicalSlot . . . 512
8.561.2.4 uPhyCardStatus . . . 512
8.561.2.5 uPhySlotStatus . . . 513
8.562 slotInf Struct Reference . . . 513
8.562.1 Detailed Description . . . 513
8.562.2 Field Documentation . . . 514
8.562.2.1 AppStatus . . . 514
8.562.2.2 cardState . . . 514
8.562.2.3 errorState . . . 514
8.562.2.4 numApp . . . 514
8.562.2.5 upinRetries . . . 514
8.562.2.6 upinState . . . 514
8.562.2.7 upukRetries . . . 514
8.563 slots_t Struct Reference . . . 514
8.563.1 Detailed Description . . . 514
8.563.2 Field Documentation . . . 515
8.563.2.1 uimSlotStatus . . . 515
8.564 sms_BroadcastConfig Struct Reference . . . 515
8.564.1 Detailed Description . . . 515
8.564.2 Field Documentation . . . 515
8.564.2.1 fromServiceId . . . 515
8.564.2.2 selected . . . 515
8.564.2.3 toServiceId . . . 515
8.565 sms_CDMABroadcastConfig Struct Reference . . . 515
8.565.1 Detailed Description . . . 516
8.565.2 Field Documentation . . . 516
8.565.2.1 language . . . 516
8.565.2.2 selected . . . 516
8.565.2.3 serviceCategory . . . 516
8.566 sms_getIndicationReg Struct Reference . . . 516
8.566.1 Detailed Description . . . 516
8.566.2 Field Documentation . . . 517
8.566.2.1 pRegCallStatInfoEvt . . . 517

8.566.2.2 pRegTransLayerInfoEvt . . . 517
8.566.2.3 pRegTransNWRegInfoEvt . . . 517
8.567 sms_getMsgWaitingInfo Struct Reference . . . 517
8.567.1 Detailed Description . . . 517
8.567.2 Field Documentation . . . 517
8.567.2.1 msgWaitInfo . . . 517
8.567.2.2 numInstances . . . 517
8.568 sms_getTransLayerInfo Struct Reference . . . 517
8.568.1 Detailed Description . . . 518
8.568.2 Field Documentation . . . 518
8.568.2.1 pRegInd . . . 518
8.568.2.2 pTransLayerInfo . . . 518
8.569 sms_getTransNWRegInfo Struct Reference . . . 518
8.569.1 Detailed Description . . . 518
8.569.2 Field Documentation . . . 518
8.569.2.1 pRegStatus . . . 519
8.570 sms_maxStorageSizeReq Struct Reference . . . 519
8.570.1 Detailed Description . . . 519
8.570.2 Field Documentation . . . 519
8.570.2.1 pMessageMode . . . 519
8.570.2.2 storageType . . . 519
8.571 sms_maxStorageSizeResp Struct Reference . . . 519
8.571.1 Detailed Description . . . 519
8.571.2 Field Documentation . . . 520
8.571.2.1 freeSlots . . . 520
8.571.2.2 maxStorageSize . . . 520
8.572 sms_messageWaitingInfoContent Struct Reference . . . 520
8.572.1 Detailed Description . . . 520
8.572.2 Field Documentation . . . 520
8.572.2.1 activeInd . . . 520
8.572.2.2 msgCount . . . 520
8.572.2.3 msgType . . . 520
8.573 sms_msgProtocolResp Struct Reference . . . 521
8.573.1 Detailed Description . . . 521
8.573.2 Field Documentation . . . 521
8.573.2.1 msgProtocol . . . 521
8.574 sms_qaQmi3GPP2BroadcastCfgInfo Struct Reference . . . 521
8.574.1 Detailed Description . . . 521
8.574.2 Field Documentation . . . 522
8.574.2.1 activated_ind . . . 522

8.574.2.2 CDMABroadcastConfig . . . 522
8.574.2.3 num_instances . . . 522
8.575 sms_qaQmi3GPPBroadcastCfgInfo Struct Reference . . . 522
8.575.1 Detailed Description . . . 522
8.575.2 Field Documentation . . . 522
8.575.2.1 activated_ind . . . 522
8.575.2.2 broadcastConfig . . . 522
8.575.2.3 num_instances . . . 522
8.576 sms_routeEntry Struct Reference . . . 522
8.576.1 Detailed Description . . . 523
8.576.2 Field Documentation . . . 523
8.576.2.1 messageClass . . . 523
8.576.2.2 messageType . . . 523
8.576.2.3 receiptAction . . . 523
8.576.2.4 routeStorage . . . 523
8.577 sms_sendAsyncsmsParams Struct Reference . . . 523
8.577.1 Detailed Description . . . 524
8.577.2 Field Documentation . . . 525
8.577.2.1 messageFormat . . . 525
8.577.2.2 messageSize . . . 525
8.577.2.3 pFollowOnDC . . . 525
8.577.2.4 pForceOnDC . . . 525
8.577.2.5 pLinktimer . . . 525
8.577.2.6 pMessage . . . 525
8.577.2.7 pRetryMessage . . . 525
8.577.2.8 pRetryMessageId . . . 525
8.577.2.9 pServiceOption . . . 525
8.577.2.10 pSmsOnIms . . . 525
8.577.2.11 pUserData . . . 525
8.578 sms_setIndicationReg Struct Reference . . . 526
8.578.1 Detailed Description . . . 526
8.578.2 Field Documentation . . . 526
8.578.2.1 pRegCallStatInfoEvt . . . 526
8.578.2.2 pRegTransLayerInfoEvt . . . 526
8.578.2.3 pRegTransNWRegInfoEvt . . . 526
8.579 sms_setRoutesReq Struct Reference . . . 526
8.579.1 Detailed Description . . . 527
8.579.2 Field Documentation . . . 527
8.579.2.1 numOfRoutes . . . 527
8.579.2.2 pTransferStatusReport . . . 527

8.579.2.3 routeList . . . 527
8.580 sms_transLayerInfo Struct Reference . . . 527
8.580.1 Detailed Description . . . 527
8.580.2 Field Documentation . . . 527
8.580.2.1 TransCap . . . 528
8.580.2.2 TransType . . . 528
8.581 sMSCAddressInfo Struct Reference . . . 528
8.581.1 Detailed Description . . . 528
8.581.2 Field Documentation . . . 528
8.581.2.1 data . . . 528
8.581.2.2 length . . . 528
8.582 sMSCAddressTlv Struct Reference . . . 528
8.582.1 Detailed Description . . . 528
8.582.2 Field Documentation . . . 528
8.582.2.1 SMSCInfo . . . 529
8.582.2.2 TlvPresent . . . 529
8.583 sMSEtwsMessageInfo Struct Reference . . . 529
8.583.1 Detailed Description . . . 529
8.583.2 Field Documentation . . . 529
8.583.2.1 data . . . 529
8.583.2.2 length . . . 529
8.583.2.3 notificationType . . . 529
8.584 sMSEtwsMessageTlv Struct Reference . . . 529
8.584.1 Detailed Description . . . 529
8.584.2 Field Documentation . . . 530
8.584.2.1 EtwsMessageInfo . . . 530
8.584.2.2 TlvPresent . . . 530
8.585 sMSEtwsPlmnInfo Struct Reference . . . 530
8.585.1 Detailed Description . . . 530
8.585.2 Field Documentation . . . 530
8.585.2.1 mobileCountryCode . . . 530
8.585.2.2 mobileNetworkCode . . . 530
8.586 sMSMessageModeInfo Struct Reference . . . 530
8.586.1 Detailed Description . . . 530
8.586.2 Field Documentation . . . 531
8.586.2.1 messageMode . . . 531
8.587 sMSMTMessageInfo Struct Reference . . . 531
8.587.1 Detailed Description . . . 531
8.587.2 Field Documentation . . . 531
8.587.2.1 messageIndex . . . 531

8.587.2.2 storageType . . . 531
8.588 sMSOnIMSInfo Struct Reference . . . 531
8.588.1 Detailed Description . . . 531
8.588.2 Field Documentation . . . 531
8.588.2.1 smsOnIMS . . . 531
8.589 sMSOnIMSTlv Struct Reference . . . 532
8.589.1 Detailed Description . . . 532
8.589.2 Field Documentation . . . 532
8.589.2.1 IMSInfo . . . 532
8.589.2.2 TlvPresent . . . 532
8.590 sMSTransferRouteMTMessageInfo Struct Reference . . . 532
8.590.1 Detailed Description . . . 532
8.590.2 Field Documentation . . . 533
8.590.2.1 ackIndicator . . . 533
8.590.2.2 data . . . 533
8.590.2.3 format . . . 533
8.590.2.4 length . . . 533
8.590.2.5 transactionID . . . 533
8.591 swi_uint256_t Struct Reference . . . 533
8.591.1 Detailed Description . . . 533
8.591.2 Field Documentation . . . 533
8.591.2.1 word . . . 533
8.592 swiaudio_PCMparams Struct Reference . . . 533
8.592.1 Detailed Description . . . 533
8.592.2 Field Documentation . . . 534
8.592.2.1 iFaceTab . . . 534
8.592.2.2 iFaceTabLen . . . 534
8.593 swidms_ehrpdMTUSizeTlv Struct Reference . . . 534
8.593.1 Detailed Description . . . 534
8.593.2 Field Documentation . . . 534
8.593.2.1 ehrpdMTUSize . . . 534
8.593.2.2 TlvPresent . . . 534
8.594 swidms_hrpdMTUSizeTlv Struct Reference . . . 534
8.594.1 Detailed Description . . . 534
8.594.2 Field Documentation . . . 535
8.594.2.1 hrpdMTUSize . . . 535
8.594.2.2 TlvPresent . . . 535
8.595 swidms_intfaceCfgTlv Struct Reference . . . 535
8.595.1 Detailed Description . . . 535
8.595.2 Field Documentation . . . 536

8.595.2.1 CfgValue . . . 536
8.595.2.2 CurrentCfgType . . . 536
8.595.2.3 TlvPresent . . . 536
8.596 swidms_mtuSize3gppTlv Struct Reference . . . 536
8.596.1 Detailed Description . . . 536
8.596.2 Field Documentation . . . 537
8.596.2.1 MTUSize3gpp . . . 537
8.596.2.2 TlvPresent . . . 537
8.597 swidms_supportedIntBitmaskTlv Struct Reference . . . 537
8.597.1 Detailed Description . . . 537
8.597.2 Field Documentation . . . 537
8.597.2.1 TlvPresent . . . 537
8.597.2.2 ValidBitmasks . . . 537
8.598 swidms_usbMTUSizeTlv Struct Reference . . . 537
8.598.1 Detailed Description . . . 537
8.598.2 Field Documentation . . . 538
8.598.2.1 TlvPresent . . . 538
8.598.2.2 UsbMTUSize . . . 538
8.599 tdscdmaSigInfoExt Struct Reference . . . 538
8.599.1 Detailed Description . . . 538
8.599.2 Field Documentation . . . 538
8.599.2.1 ecio . . . 538
8.599.2.2 rscp . . . 538
8.599.2.3 rssi . . . 538
8.599.2.4 sinr . . . 538
8.600 tempData_t Struct Reference . . . 538
8.600.1 Detailed Description . . . 539
8.600.2 Field Documentation . . . 539
8.600.2.1 temperature . . . 539
8.600.2.2 temperatureDataLen . . . 539
8.600.2.3 timeOfFirstSample . . . 539
8.600.2.4 timeOffset . . . 539
8.600.2.5 timeSource . . . 539
8.601 tmd_mitigationDevList Struct Reference . . . 540
8.601.1 Detailed Description . . . 540
8.601.2 Field Documentation . . . 540
8.601.2.1 maxMitigationLevel . . . 540
8.601.2.2 mitigationDevId . . . 540
8.601.2.3 mitigationDevIdLen . . . 540
8.602 transferRouteMessageTlv Struct Reference . . . 540

8.602.1 Detailed Description . . . 540
8.602.2 Field Documentation . . . 541
8.602.2.1 TlvPresent . . . 541
8.602.2.2 TransferRouteMTMessageInfo . . . 541
8.603 uim_appStatus Struct Reference . . . 541
8.603.1 Detailed Description . . . 541
8.603.2 Field Documentation . . . 543
8.603.2.1 aidLength . . . 543
8.603.2.2 aidVal . . . 543
8.603.2.3 appState . . . 543
8.603.2.4 appType . . . 543
8.603.2.5 persoFeature . . . 543
8.603.2.6 persoRetries . . . 543
8.603.2.7 persoState . . . 543
8.603.2.8 persoUnblockRetries . . . 543
8.603.2.9 pin1Retries . . . 543
8.603.2.10 pin1State . . . 543
8.603.2.11 pin2Retries . . . 544
8.603.2.12 pin2State . . . 544
8.603.2.13 puk1Retries . . . 544
8.603.2.14 puk2Retries . . . 544
8.603.2.15 univPin . . . 544
8.604 uim_authenticateResult Struct Reference . . . 544
8.604.1 Detailed Description . . . 544
8.604.2 Field Documentation . . . 544
8.604.2.1 content . . . 544
8.604.2.2 contentLen . . . 544
8.605 uim_authenticationData Struct Reference . . . 544
8.605.1 Detailed Description . . . 544
8.605.2 Field Documentation . . . 545
8.605.2.1 context . . . 545
8.605.2.2 data . . . 545
8.605.2.3 dataLen . . . 545
8.606 uim_cardResult Struct Reference . . . 545
8.606.1 Detailed Description . . . 545
8.606.2 Field Documentation . . . 546
8.606.2.1 sw1 . . . 546
8.606.2.2 sw2 . . . 546
8.607 uim_cardStatus Struct Reference . . . 546
8.607.1 Detailed Description . . . 546

8.607.2 Field Documentation . . . 547
8.607.2.1 index1xPri . . . 547
8.607.2.2 index1xSec . . . 547
8.607.2.3 indexGwPri . . . 547
8.607.2.4 indexGwSec . . . 547
8.607.2.5 numSlot . . . 547
8.607.2.6 SlotInfo . . . 547
8.608 uim_changeUIMPIN Struct Reference . . . 547
8.608.1 Detailed Description . . . 547
8.608.2 Field Documentation . . . 548
8.608.2.1 oldPINLen . . . 548
8.608.2.2 oldPINVal . . . 548
8.608.2.3 pinID . . . 548
8.608.2.4 pinLen . . . 548
8.608.2.5 pinVal . . . 548
8.609 uim_depersonalizationInformation Struct Reference . . . 548
8.609.1 Detailed Description . . . 548
8.609.2 Field Documentation . . . 549
8.609.2.1 ckLen . . . 549
8.609.2.2 ckVal . . . 549
8.609.2.3 feature . . . 549
8.609.2.4 operation . . . 549
8.610 uim_encryptedPIN1 Struct Reference . . . 549
8.610.1 Detailed Description . . . 549
8.610.2 Field Documentation . . . 550
8.610.2.1 pin1Len . . . 550
8.610.2.2 pin1Val . . . 550
8.611 uim_fileAttributes Struct Reference . . . 550
8.611.1 Detailed Description . . . 550
8.611.2 Field Documentation . . . 553
8.611.2.1 fileID . . . 553
8.611.2.2 fileSize . . . 553
8.611.2.3 fileType . . . 553
8.611.2.4 rawLen . . . 553
8.611.2.5 rawValue . . . 553
8.611.2.6 recordCount . . . 553
8.611.2.7 recordSize . . . 553
8.611.2.8 secActivate . . . 553
8.611.2.9 secActivateMask . . . 553
8.611.2.10 secDeactivate . . . 553

8.611.2.11 secDeactivateMask . . . 553
8.611.2.12 secIncrease . . . 553
8.611.2.13 secIncreaseMask . . . 553
8.611.2.14 secRead . . . 553
8.611.2.15 secReadMask . . . 553
8.611.2.16 secWrite . . . 553
8.611.2.17 secWriteMask . . . 553
8.612 uim_fileInfo Struct Reference . . . 553
8.612.1 Detailed Description . . . 553
8.612.2 Field Documentation . . . 554
8.612.2.1 fileID . . . 554
8.612.2.2 path . . . 554
8.612.2.3 pathLen . . . 554
8.613 uim_hotSwapStatus Struct Reference . . . 554
8.613.1 Detailed Description . . . 554
8.613.2 Field Documentation . . . 554
8.613.2.1 hotSwap . . . 554
8.613.2.2 hotSwapLength . . . 554
8.614 uim_personalizationStatus Struct Reference . . . 554
8.614.1 Detailed Description . . . 555
8.614.2 Field Documentation . . . 555
8.614.2.1 feature . . . 555
8.614.2.2 numFeatures . . . 555
8.614.2.3 unblockLeft . . . 555
8.614.2.4 verifyLeft . . . 555
8.615 uim_readResult Struct Reference . . . 555
8.615.1 Detailed Description . . . 556
8.615.2 Field Documentation . . . 556
8.615.2.1 content . . . 556
8.615.2.2 contentLen . . . 556
8.616 uim_readTransparentInfo Struct Reference . . . 556
8.616.1 Detailed Description . . . 556
8.616.2 Field Documentation . . . 556
8.616.2.1 length . . . 556
8.616.2.2 offset . . . 556
8.617 uim_refreshevent Struct Reference . . . 556
8.617.1 Detailed Description . . . 557
8.617.2 Field Documentation . . . 558
8.617.2.1 aid . . . 558
8.617.2.2 aidLength . . . 558

8.617.2.3 arrfileInfo . . . 558
8.617.2.4 mode . . . 558
8.617.2.5 numOfFiles . . . 558
8.617.2.6 sessionType . . . 558
8.617.2.7 stage . . . 558
8.618 uim_registerRefresh Struct Reference . . . 558
8.618.1 Detailed Description . . . 558
8.618.2 Field Documentation . . . 559
8.618.2.1 arrfileInfo . . . 559
8.618.2.2 numFiles . . . 559
8.618.2.3 registerFlag . . . 559
8.618.2.4 voteForInit . . . 559
8.619 uim_remainingRetries Struct Reference . . . 559
8.619.1 Detailed Description . . . 559
8.619.2 Field Documentation . . . 559
8.619.2.1 unblockLeft . . . 559
8.619.2.2 verifyLeft . . . 560
8.620 uim_sessionInformation Struct Reference . . . 560
8.620.1 Detailed Description . . . 560
8.620.2 Field Documentation . . . 560
8.620.2.1 aid . . . 560
8.620.2.2 aidLength . . . 560
8.620.2.3 sessionType . . . 560
8.621 uim_setPINProtection Struct Reference . . . 560
8.621.1 Detailed Description . . . 561
8.621.2 Field Documentation . . . 561
8.621.2.1 pinID . . . 561
8.621.2.2 pinLength . . . 561
8.621.2.3 pinOperation . . . 561
8.621.2.4 pinValue . . . 561
8.622 uim_slotInfo Struct Reference . . . 561
8.622.1 Detailed Description . . . 562
8.622.2 Field Documentation . . . 563
8.622.2.1 AppStatus . . . 563
8.622.2.2 cardState . . . 563
8.622.2.3 errorState . . . 563
8.622.2.4 numApp . . . 563
8.622.2.5 upinRetries . . . 563
8.622.2.6 upinState . . . 563
8.622.2.7 upukRetries . . . 563

8.623 uim_UIMSessionInformation Struct Reference . . . 563
8.623.1 Detailed Description . . . 563
8.623.2 Field Documentation . . . 564
8.623.2.1 aid . . . 564
8.623.2.2 aidLength . . . 564
8.623.2.3 sessionType . . . 564
8.624 uim_unblockUIMPIN Struct Reference . . . 564
8.624.1 Detailed Description . . . 564
8.624.2 Field Documentation . . . 564
8.624.2.1 newPINLen . . . 564
8.624.2.2 newPINVal . . . 564
8.624.2.3 pinID . . . 564
8.624.2.4 pukLen . . . 565
8.624.2.5 pukVal . . . 565
8.625 uim_verifyUIMPIN Struct Reference . . . 565
8.625.1 Detailed Description . . . 565
8.625.2 Field Documentation . . . 565
8.625.2.1 pinID . . . 565
8.625.2.2 pinLen . . . 565
8.625.2.3 pinVal . . . 565
8.626 unpack_audio_SLQSGetAudioPathConfig_t Struct Reference . . . 565
8.626.1 Detailed Description . . . 566
8.626.2 Field Documentation . . . 567
8.626.2.1 ParamPresenceMask . . . 567
8.626.2.2 pCodecSTGain . . . 567
8.626.2.3 pDTMFTXGain . . . 567
8.626.2.4 pECMode . . . 567
8.626.2.5 pMICGainSelect . . . 567
8.626.2.6 pNSEnable . . . 567
8.626.2.7 pRXAGCList . . . 567
8.626.2.8 pRXAVCAGCSwitch . . . 567
8.626.2.9 pRXAVCList . . . 567
8.626.2.10 pRXPCMIIRFltr . . . 567
8.626.2.11 pTXAGCList . . . 567
8.626.2.12 pTXAVCSwitch . . . 567
8.626.2.13 pTXGain . . . 567
8.626.2.14 pTXPCMIIRFltr . . . 568
8.627 unpack_audio_SLQSGetAudioProfile_t Struct Reference . . . 568
8.627.1 Detailed Description . . . 568
8.627.2 Field Documentation . . . 568

8.627.2.1 EarMute . . . 569
8.627.2.2 MicMute . . . 569
8.627.2.3 ParamPresenceMask . . . 569
8.627.2.4 Profile . . . 569
8.627.2.5 Volume . . . 569
8.628 unpack_audio_SLQSGetAudioVolTLBConfig_t Struct Reference . . . 569
8.628.1 Detailed Description . . . 569
8.628.2 Field Documentation . . . 569
8.628.2.1 ParamPresenceMask . . . 569
8.628.2.2 ResCode . . . 569
8.629 unpack_audio_SLQSSetAudioVolTLBConfig_t Struct Reference . . . 569
8.629.1 Detailed Description . . . 569
8.629.2 Field Documentation . . . 570
8.629.2.1 ParamPresenceMask . . . 570
8.629.2.2 ResCode . . . 570
8.630 unpack_cat_SetCatEventCallback_ind_t Struct Reference . . . 570
8.630.1 Detailed Description . . . 570
8.630.2 Field Documentation . . . 570
8.630.2.1 CCETlv . . . 570
8.630.2.2 event_Index . . . 570
8.630.2.3 ParamPresenceMask . . . 570
8.631 unpack_cat_SetCATEventCallback_t Struct Reference . . . 570
8.631.1 Detailed Description . . . 571
8.631.2 Field Documentation . . . 571
8.631.2.1 errorMask . . . 571
8.631.2.2 ParamPresenceMask . . . 571
8.631.2.3 Tlvresult . . . 571
8.632 unpack_dms_GetActivationState_t Struct Reference . . . 571
8.632.1 Detailed Description . . . 571
8.632.2 Field Documentation . . . 572
8.632.2.1 ParamPresenceMask . . . 572
8.632.2.2 state . . . 572
8.633 unpack_dms_GetBandCapability_t Struct Reference . . . 572
8.633.1 Detailed Description . . . 572
8.633.2 Field Documentation . . . 574
8.633.2.1 BandCapability . . . 574
8.633.2.2 ParamPresenceMask . . . 574
8.633.2.3 Tlvresult . . . 574
8.634 unpack_dms_GetCrashAction_t Struct Reference . . . 574
8.634.1 Detailed Description . . . 574

8.634.2 Field Documentation . . . 574
8.634.2.1 DevCrashState . . . 574
8.634.2.2 ParamPresenceMask . . . 575
8.634.2.3 Tlvresult . . . 575
8.635 unpack_dms_GetCustFeature_t Struct Reference . . . 575
8.635.1 Detailed Description . . . 575
8.635.2 Field Documentation . . . 577
8.635.2.1 DHCPRelayEnabled . . . 577
8.635.2.2 DisableIMSI . . . 577
8.635.2.3 GpsEnable . . . 577
8.635.2.4 GPSLPM . . . 577
8.635.2.5 GPSSel . . . 577
8.635.2.6 IPFamSupport . . . 577
8.635.2.7 IsVoiceEnabled . . . 577
8.635.2.8 ParamPresenceMask . . . 577
8.635.2.9 RMAutoConnect . . . 577
8.635.2.10 SMSSupport . . . 577
8.635.2.11 Tlvresult . . . 577
8.636 unpack_dms_GetCustFeaturesV2_t Struct Reference . . . 577
8.636.1 Detailed Description . . . 577
8.636.2 Field Documentation . . . 578
8.636.2.1 GetCustomFeatureV2 . . . 578
8.636.2.2 ParamPresenceMask . . . 578
8.636.2.3 Tlvresult . . . 578
8.637 unpack_dms_GetDeviceCap_t Struct Reference . . . 578
8.637.1 Detailed Description . . . 578
8.637.2 Field Documentation . . . 579
8.637.2.1 DataServiceCapability . . . 579
8.637.2.2 MaxRXChannelRate . . . 579
8.637.2.3 MaxTXChannelRate . . . 579
8.637.2.4 ParamPresenceMask . . . 579
8.637.2.5 RadioIfaces . . . 579
8.637.2.6 RadioIfacesSize . . . 579
8.637.2.7 SimCapability . . . 579
8.637.2.8 Tlvresult . . . 579
8.638 unpack_dms_GetDeviceCapabilities_t Struct Reference . . . 579
8.638.1 Detailed Description . . . 580
8.638.2 Field Documentation . . . 580
8.638.2.1 dataServiceCaCapability . . . 581
8.638.2.2 maxRxChannelRate . . . 581

8.638.2.3 maxTxChannelRate . . . 581
8.638.2.4 ParamPresenceMask . . . 581
8.638.2.5 RadioIfaces . . . 581
8.638.2.6 radioIfacesSize . . . 581
8.638.2.7 simCapability . . . 581
8.639 unpack_dms_GetDeviceHardwareRev_t Struct Reference . . . 581
8.639.1 Detailed Description . . . 581
8.639.2 Field Documentation . . . 581
8.639.2.1 ParamPresenceMask . . . 581
8.639.2.2 String . . . 581
8.639.2.3 stringSize . . . 581
8.639.2.4 Tlvresult . . . 582
8.640 unpack_dms_GetDeviceMfr_t Struct Reference . . . 582
8.640.1 Detailed Description . . . 582
8.640.2 Field Documentation . . . 582
8.640.2.1 ParamPresenceMask . . . 582
8.640.2.2 String . . . 582
8.640.2.3 stringSize . . . 582
8.640.2.4 Tlvresult . . . 582
8.641 unpack_dms_GetDeviceSerialNumbers_t Struct Reference . . . 582
8.641.1 Detailed Description . . . 583
8.641.2 Field Documentation . . . 584
8.641.2.1 esnSize . . . 584
8.641.2.2 ESNString . . . 584
8.641.2.3 imeiSize . . . 584
8.641.2.4 IMEIString . . . 584
8.641.2.5 imeiSvnSize . . . 584
8.641.2.6 ImeiSvnString . . . 584
8.641.2.7 meidSize . . . 584
8.641.2.8 MEIDString . . . 584
8.641.2.9 ParamPresenceMask . . . 584
8.641.2.10 Tlvresult . . . 584
8.642 unpack_dms_GetFirmwareInfo_t Struct Reference . . . 584
8.642.1 Detailed Description . . . 585
8.642.2 Field Documentation . . . 585
8.642.2.1 appversion_str . . . 585
8.642.2.2 bootversion_str . . . 585
8.642.2.3 carrier_str . . . 586
8.642.2.4 cur_carr_name . . . 586
8.642.2.5 cur_carr_rev . . . 586

8.642.2.6 modelid_str . . . 586
8.642.2.7 packageid_str . . . 586
8.642.2.8 ParamPresenceMask . . . 586
8.642.2.9 priversion_str . . . 586
8.642.2.10 sku_str . . . 586
8.642.2.11 Tlvresult . . . 586
8.643 unpack_dms_GetFirmwareRevision_t Struct Reference . . . 586
8.643.1 Detailed Description . . . 586
8.643.2 Field Documentation . . . 587
8.643.2.1 amssSize . . . 587
8.643.2.2 AMSSString . . . 587
8.643.2.3 ParamPresenceMask . . . 587
8.643.2.4 PRIString . . . 587
8.643.2.5 Tlvresult . . . 587
8.644 unpack_dms_GetFirmwareRevisions_t Struct Reference . . . 587
8.644.1 Detailed Description . . . 587
8.644.2 Field Documentation . . . 588
8.644.2.1 amssSize . . . 588
8.644.2.2 AMSSString . . . 588
8.644.2.3 bootSize . . . 588
8.644.2.4 BootString . . . 588
8.644.2.5 ParamPresenceMask . . . 588
8.644.2.6 priSize . . . 588
8.644.2.7 PRIString . . . 588
8.644.2.8 Tlvresult . . . 588
8.645 unpack_dms_GetFSN_t Struct Reference . . . 588
8.645.1 Detailed Description . . . 588
8.645.2 Field Documentation . . . 589
8.645.2.1 ParamPresenceMask . . . 589
8.645.2.2 String . . . 589
8.645.2.3 Tlvresult . . . 589
8.646 unpack_dms_GetHardwareRevision_t Struct Reference . . . 589
8.646.1 Detailed Description . . . 589
8.646.2 Field Documentation . . . 589
8.646.2.1 hwVer . . . 589
8.646.2.2 ParamPresenceMask . . . 589
8.647 unpack_dms_GetIMSI_t Struct Reference . . . 589
8.647.1 Detailed Description . . . 589
8.647.2 Field Documentation . . . 590
8.647.2.1 imsi . . . 590

8.647.2.2 ParamPresenceMask . . . 590
8.647.2.3 TlvResult . . . 590
8.648 unpack_dms_GetManufacturer_t Struct Reference . . . 590
8.648.1 Detailed Description . . . 590
8.648.2 Field Documentation . . . 590
8.648.2.1 manufacturer . . . 590
8.648.2.2 ParamPresenceMask . . . 590
8.648.2.3 TlvResult . . . 590
8.649 unpack_dms_GetModelID_t Struct Reference . . . 591
8.649.1 Detailed Description . . . 591
8.649.2 Field Documentation . . . 591
8.649.2.1 modelid . . . 591
8.649.2.2 ParamPresenceMask . . . 591
8.649.2.3 TlvResult . . . 591
8.650 unpack_dms_GetNetworkTime_t Struct Reference . . . 591
8.650.1 Detailed Description . . . 591
8.650.2 Field Documentation . . . 592
8.650.2.1 ParamPresenceMask . . . 592
8.650.2.2 source . . . 592
8.650.2.3 timestamp . . . 592
8.650.2.4 TlvResult . . . 592
8.651 unpack_dms_GetOfflineReason_t Struct Reference . . . 592
8.651.1 Detailed Description . . . 592
8.651.2 Field Documentation . . . 593
8.651.2.1 ParamPresenceMask . . . 593
8.651.2.2 pbPlatform . . . 593
8.651.2.3 pReasonMask . . . 593
8.651.2.4 TlvResult . . . 593
8.652 unpack_dms_GetPower_t Struct Reference . . . 593
8.652.1 Detailed Description . . . 593
8.652.2 Field Documentation . . . 594
8.652.2.1 HardwareControlledMode . . . 594
8.652.2.2 OfflineReason . . . 594
8.652.2.3 OperationMode . . . 594
8.652.2.4 ParamPresenceMask . . . 594
8.652.2.5 TlvResult . . . 594
8.653 unpack_dms_GetPRLVersion_t Struct Reference . . . 594
8.653.1 Detailed Description . . . 594
8.653.2 Field Documentation . . . 595
8.653.2.1 ParamPresenceMask . . . 595

8.653.2.2 Tlvresult . . . 595
8.653.2.3 u16PRLVersion . . . 595
8.653.2.4 u8PRLPreference . . . 595
8.654 unpack_dms_GetSerialNumbers_t Struct Reference . . . 595
8.654.1 Detailed Description . . . 595
8.654.2 Field Documentation . . . 596
8.654.2.1 esn . . . 596
8.654.2.2 imei_no . . . 596
8.654.2.3 imeisv_svn . . . 596
8.654.2.4 meid . . . 596
8.654.2.5 ParamPresenceMask . . . 596
8.655 unpack_dms_GetUSBComp_t Struct Reference . . . 596
8.655.1 Detailed Description . . . 596
8.655.2 Field Documentation . . . 598
8.655.2.1 NumSupUSBComps . . . 598
8.655.2.2 ParamPresenceMask . . . 598
8.655.2.3 SupUSBComps . . . 598
8.655.2.4 Tlvresult . . . 598
8.655.2.5 USBComp . . . 598
8.656 unpack_dms_GetVoiceNumber_t Struct Reference . . . 598
8.656.1 Detailed Description . . . 599
8.656.2 Field Documentation . . . 599
8.656.2.1 MIN . . . 599
8.656.2.2 minSize . . . 599
8.656.2.3 ParamPresenceMask . . . 599
8.656.2.4 Tlvresult . . . 599
8.656.2.5 VoiceNumber . . . 599
8.656.2.6 voiceNumberSize . . . 599
8.657 unpack_dms_PSMCfgChange_ind_t Struct Reference . . . 600
8.657.1 Detailed Description . . . 600
8.657.2 Field Documentation . . . 600
8.657.2.1 ActiveTimer . . . 600
8.657.2.2 EnableState . . . 600
8.657.2.3 ParamPresenceMask . . . 600
8.657.2.4 PeriodicUpdateTimer . . . 600
8.657.2.5 Tlvresult . . . 600
8.658 unpack_dms_ResetToFactoryDefaults_t Struct Reference . . . 600
8.658.1 Detailed Description . . . 601
8.658.2 Field Documentation . . . 601
8.658.2.1 ParamPresenceMask . . . 601

8.658.2.2 TlvResult . . . 601
8.659 unpack_dms_SetActivationStatusCallback_t Struct Reference . . . 601
8.659.1 Detailed Description . . . 601
8.659.2 Field Documentation . . . 601
8.659.2.1 ParamPresenceMask . . . 601
8.659.2.2 TlvResult . . . 601
8.660 unpack_dms_SetCrashAction_t Struct Reference . . . 601
8.660.1 Detailed Description . . . 602
8.660.2 Field Documentation . . . 602
8.660.2.1 notused . . . 602
8.660.2.2 ParamPresenceMask . . . 602
8.661 unpack_dms_SetCustFeature_t Struct Reference . . . 602
8.661.1 Detailed Description . . . 602
8.661.2 Field Documentation . . . 602
8.661.2.1 ParamPresenceMask . . . 602
8.661.2.2 TlvResult . . . 602
8.662 unpack_dms_SetCustFeaturesV2_t Struct Reference . . . 602
8.662.1 Detailed Description . . . 603
8.662.2 Field Documentation . . . 603
8.662.2.1 ParamPresenceMask . . . 603
8.662.2.2 TlvResult . . . 603
8.663 unpack_dms_SetEventReport_ind_t Struct Reference . . . 603
8.663.1 Detailed Description . . . 603
8.663.2 Field Documentation . . . 603
8.663.2.1 ActivationStatusTlv . . . 603
8.663.2.2 OperatingModeTlv . . . 604
8.663.2.3 ParamPresenceMask . . . 604
8.663.2.4 TlvResult . . . 604
8.664 unpack_dms_SetEventReport_t Struct Reference . . . 604
8.664.1 Detailed Description . . . 604
8.664.2 Field Documentation . . . 604
8.664.2.1 ParamPresenceMask . . . 604
8.664.2.2 TlvResult . . . 604
8.665 unpack_dms_SetFirmwarePreference_t Struct Reference . . . 604
8.665.1 Detailed Description . . . 604
8.665.2 Field Documentation . . . 605
8.665.2.1 ParamPresenceMask . . . 605
8.665.2.2 TlvResult . . . 605
8.666 unpack_dms_SetIndicationRegister_t Struct Reference . . . 605
8.666.1 Detailed Description . . . 605

8.666.2 Field Documentation . . . 605
8.666.2.1 ParamPresenceMask . . . 605
8.666.2.2 TlvResult . . . 605
8.667 unpack_dms_SetPower_t Struct Reference . . . 605
8.667.1 Detailed Description . . . 605
8.667.2 Field Documentation . . . 606
8.667.2.1 ParamPresenceMask . . . 606
8.667.2.2 TlvResult . . . 606
8.668 unpack_dms_SetUSBComp_t Struct Reference . . . 606
8.668.1 Detailed Description . . . 606
8.668.2 Field Documentation . . . 606
8.668.2.1 ParamPresenceMask . . . 606
8.668.2.2 TlvResult . . . 606
8.669 unpack_dms_SLQSDmsSwiGetPCInfo_t Struct Reference . . . 606
8.669.1 Detailed Description . . . 606
8.669.2 Field Documentation . . . 608
8.669.2.1 has_LpmFlag . . . 608
8.669.2.2 has_PersistentLpm . . . 608
8.669.2.3 has_PowerOffMode . . . 608
8.669.2.4 has_Wdisable . . . 609
8.669.2.5 LpmFlag . . . 609
8.669.2.6 opMode . . . 609
8.669.2.7 ParamPresenceMask . . . 609
8.669.2.8 PersistentLpm . . . 609
8.669.2.9 PowerOffMode . . . 609
8.669.2.10 Wdisable . . . 609
8.670 unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t Struct Reference . . . 609
8.670.1 Detailed Description . . . 609
8.670.2 Field Documentation . . . 610
8.670.2.1 ParamPresenceMask . . . 610
8.670.2.2 source . . . 610
8.670.2.3 TlvResult . . . 610
8.670.2.4 type . . . 610
8.671 unpack_dms_SLQSDmsSwiGetResetInfo_t Struct Reference . . . 610
8.671.1 Detailed Description . . . 610
8.671.2 Field Documentation . . . 611
8.671.2.1 ParamPresenceMask . . . 611
8.671.2.2 source . . . 611
8.671.2.3 TlvResult . . . 611
8.671.2.4 type . . . 611

8.672 unpack_dms_SLQSDmsSwiGetUimSelection_t Struct Reference . . . 611
8.672.1 Detailed Description . . . 611
8.672.2 Field Documentation . . . 612
8.672.2.1 ParamPresenceMask . . . 612
8.672.2.2 pUimAutoSwitchActSlot . . . 612
8.672.2.3 uimSelect . . . 612
8.673 unpack_dms_SLQSDmsSwiIndicationRegister_t Struct Reference . . . 612
8.673.1 Detailed Description . . . 612
8.673.2 Field Documentation . . . 613
8.673.2.1 ParamPresenceMask . . . 613
8.673.2.2 Tlvresult . . . 613
8.674 unpack_dms_SLQSGetBandCapability_t Struct Reference . . . 613
8.674.1 Detailed Description . . . 613
8.674.2 Field Documentation . . . 617
8.674.2.1 bandCapability . . . 617
8.674.2.2 is_LteBandCapability_Available . . . 617
8.674.2.3 is_TdsBandCapability_Available . . . 617
8.674.2.4 LteBandCapability . . . 617
8.674.2.5 ParamPresenceMask . . . 617
8.674.2.6 TdsBandCapability . . . 617
8.675 unpack_dms_SLQSGetERIFile_t Struct Reference . . . 617
8.675.1 Detailed Description . . . 617
8.675.2 Field Documentation . . . 618
8.675.2.1 eriFile . . . 618
8.675.2.2 ParamPresenceMask . . . 618
8.675.2.3 Tlvresult . . . 618
8.676 unpack_dms_SLQSGetPowerSaveModeConfig_t Struct Reference . . . 618
8.676.1 Detailed Description . . . 618
8.676.2 Field Documentation . . . 619
8.676.2.1 pActiveTimer . . . 619
8.676.2.2 ParamPresenceMask . . . 619
8.676.2.3 pDurationDueToOOS . . . 619
8.676.2.4 pDurationThreshold . . . 619
8.676.2.5 pEarlyWakeupTime . . . 619
8.676.2.6 pPeriodicUpdateTimer . . . 619
8.676.2.7 pPsmEnableState . . . 619
8.676.2.8 pRandomizationWindow . . . 619
8.677 unpack_dms_SLQSSetPowerSaveModeConfig_t Struct Reference . . . 619
8.677.1 Detailed Description . . . 619
8.677.2 Field Documentation . . . 620

8.677.2.1 ParamPresenceMask . . . 620
8.677.2.2 Tlvresult . . . 620
8.678 unpack_dms_SLQSSwiClearDyingGaspStatistics_t Struct Reference . . . 620
8.678.1 Detailed Description . . . 620
8.678.2 Field Documentation . . . 620
8.678.2.1 ParamPresenceMask . . . 620
8.678.2.2 Tlvresult . . . 620
8.679 unpack_dms_SLQSSwiGetCrashInfo_t Struct Reference . . . 620
8.679.1 Detailed Description . . . 620
8.679.2 Field Documentation . . . 621
8.679.2.1 crashInfoParam . . . 621
8.679.2.2 ParamPresenceMask . . . 621
8.679.2.3 Tlvresult . . . 621
8.680 unpack_dms_SLQSSwiGetDyingGaspCfg_t Struct Reference . . . 621
8.680.1 Detailed Description . . . 621
8.680.2 Field Documentation . . . 622
8.680.2.1 ParamPresenceMask . . . 622
8.680.2.2 pGetDyingGaspCfg . . . 622
8.680.2.3 Tlvresult . . . 622
8.681 unpack_dms_SLQSSwiGetDyingGaspStatistics_t Struct Reference . . . 622
8.681.1 Detailed Description . . . 622
8.681.2 Field Documentation . . . 622
8.681.2.1 ParamPresenceMask . . . 622
8.681.2.2 pGetDyingGaspStatistics . . . 622
8.681.2.3 Tlvresult . . . 622
8.682 unpack_dms_SLQSSwiGetFirmwareCurr_t Struct Reference . . . 622
8.682.1 Detailed Description . . . 623
8.682.2 Field Documentation . . . 623
8.682.2.1 carrier . . . 623
8.682.2.2 fwvers . . . 623
8.682.2.3 numEntries . . . 623
8.682.2.4 ParamPresenceMask . . . 623
8.682.2.5 pCurrImgInfo . . . 623
8.682.2.6 pkgver . . . 623
8.682.2.7 priver . . . 623
8.683 unpack_dms_SLQSSwiGetFwUpdateStatus_t Struct Reference . . . 623
8.683.1 Detailed Description . . . 624
8.683.2 Field Documentation . . . 625
8.683.2.1 imgType . . . 625
8.683.2.2 logString . . . 625

8.683.2.3 ParamPresenceMask . . . 625
8.683.2.4 refData . . . 625
8.683.2.5 refString . . . 625
8.683.2.6 ResCode . . . 625
8.683.2.7 Tlvresult . . . 625
8.684 unpack_dms_SLQSSwiGetHostDevInfo_t Struct Reference . . . 625
8.684.1 Detailed Description . . . 625
8.684.2 Field Documentation . . . 626
8.684.2.1 manString . . . 626
8.684.2.2 modelString . . . 626
8.684.2.3 ParamPresenceMask . . . 626
8.684.2.4 plasmaIDString . . . 626
8.684.2.5 swVerString . . . 626
8.684.2.6 Tlvresult . . . 626
8.685 unpack_dms_SLQSSwiGetOSInfo_t Struct Reference . . . 626
8.685.1 Detailed Description . . . 626
8.685.2 Field Documentation . . . 627
8.685.2.1 nameString . . . 627
8.685.2.2 ParamPresenceMask . . . 627
8.685.2.3 Tlvresult . . . 627
8.685.2.4 versionString . . . 627
8.686 unpack_dms_SLQSSwiGetSerialNoExt_t Struct Reference . . . 627
8.686.1 Detailed Description . . . 627
8.686.2 Field Documentation . . . 627
8.686.2.1 meidString . . . 627
8.686.2.2 ParamPresenceMask . . . 628
8.686.2.3 Tlvresult . . . 628
8.687 unpack_dms_SLQSSwiSetDyingGaspCfg_t Struct Reference . . . 628
8.687.1 Detailed Description . . . 628
8.687.2 Field Documentation . . . 628
8.687.2.1 ParamPresenceMask . . . 628
8.687.2.2 Tlvresult . . . 628
8.688 unpack_dms_SLQSSwiSetHostDevInfo_t Struct Reference . . . 628
8.688.1 Detailed Description . . . 628
8.688.2 Field Documentation . . . 628
8.688.2.1 ParamPresenceMask . . . 629
8.688.2.2 Tlvresult . . . 629
8.689 unpack_dms_SLQSSwiSetOSInfo_t Struct Reference . . . 629
8.689.1 Detailed Description . . . 629
8.689.2 Field Documentation . . . 629

8.689.2.1 ParamPresenceMask . . . 629
8.689.2.2 Tlvresult . . . 629
8.690 unpack_dms_SLQSUIMGetState_t Struct Reference . . . 629
8.690.1 Detailed Description . . . 629
8.690.2 Field Documentation . . . 630
8.690.2.1 ParamPresenceMask . . . 630
8.690.2.2 state . . . 630
8.690.2.3 Tlvresult . . . 630
8.691 unpack_dms_SwiEventReportCallBack_ind_t Struct Reference . . . 630
8.691.1 Detailed Description . . . 630
8.691.2 Field Documentation . . . 630
8.691.2.1 ParamPresenceMask . . . 630
8.691.2.2 TempTlv . . . 630
8.691.2.3 UimStatusTlv . . . 630
8.691.2.4 VoltTlv . . . 630
8.692 unpack_dms_SwiSetEventReport_t Struct Reference . . . 631
8.692.1 Detailed Description . . . 631
8.692.2 Field Documentation . . . 631
8.692.2.1 ParamPresenceMask . . . 631
8.692.2.2 Tlvresult . . . 631
8.693 unpack_dms_SwiUimSelect_t Struct Reference . . . 631
8.693.1 Detailed Description . . . 631
8.693.2 Field Documentation . . . 631
8.693.2.1 ParamPresenceMask . . . 631
8.693.2.2 Tlvresult . . . 631
8.694 unpack_dms_UIMGetControlKeyStatus_t Struct Reference . . . 632
8.694.1 Detailed Description . . . 632
8.694.2 Field Documentation . . . 632
8.694.2.1 facilityState . . . 632
8.694.2.2 ParamPresenceMask . . . 632
8.694.2.3 Tlvresult . . . 632
8.694.2.4 unblockRetriesLeft . . . 632
8.694.2.5 verifyRetriesLeft . . . 632
8.695 unpack_dms_UIMGetICCID_t Struct Reference . . . 633
8.695.1 Detailed Description . . . 633
8.695.2 Field Documentation . . . 633
8.695.2.1 ParamPresenceMask . . . 633
8.695.2.2 String . . . 633
8.695.2.3 stringSize . . . 633
8.695.2.4 Tlvresult . . . 633

8.696 unpack_dms_UIMGetPINStatus_t Struct Reference . . . 633
8.696.1 Detailed Description . . . 634
8.696.2 Field Documentation . . . 635
8.696.2.1 p1Status . . . 635
8.696.2.2 p1UnblockRetriesLeft . . . 635
8.696.2.3 p1VerifyRetriesLeft . . . 635
8.696.2.4 p2Status . . . 635
8.696.2.5 p2UnblockRetriesLeft . . . 635
8.696.2.6 p2VerifyRetriesLeft . . . 635
8.696.2.7 ParamPresenceMask . . . 635
8.696.2.8 Tlvresult . . . 635
8.697 unpack_dms_UIMSetControlKeyProtection_t Struct Reference . . . 635
8.697.1 Detailed Description . . . 635
8.697.2 Field Documentation . . . 635
8.697.2.1 ParamPresenceMask . . . 635
8.697.2.2 Tlvresult . . . 636
8.697.2.3 verifyRetriesLeft . . . 636
8.698 unpack_dms_UIMSetPINProtection_t Struct Reference . . . 636
8.698.1 Detailed Description . . . 636
8.698.2 Field Documentation . . . 636
8.698.2.1 ParamPresenceMask . . . 636
8.698.2.2 Tlvresult . . . 636
8.698.2.3 unblockRetriesLeft . . . 636
8.698.2.4 verifyRetriesLeft . . . 636
8.699 unpack_dms_UIMUnblockControlKey_t Struct Reference . . . 636
8.699.1 Detailed Description . . . 637
8.699.2 Field Documentation . . . 637
8.699.2.1 ParamPresenceMask . . . 637
8.699.2.2 Tlvresult . . . 637
8.699.2.3 unblockRetriesLeft . . . 637
8.700 unpack_fms_GetImagesPreference_t Struct Reference . . . 637
8.700.1 Detailed Description . . . 637
8.700.2 Field Documentation . . . 638
8.700.2.1 ImageListSize . . . 638
8.700.2.2 ParamPresenceMask . . . 638
8.700.2.3 pImageList . . . 638
8.700.2.4 Tlvresult . . . 638
8.701 unpack_fms_GetStoredImages_t Struct Reference . . . 638
8.701.1 Detailed Description . . . 638
8.701.2 Field Documentation . . . 638

8.701.2.1 imageList . . . 638
8.701.2.2 imagelistSize . . . 638
8.701.2.3 ParamPresenceMask . . . 638
8.701.2.4 Tlvresult . . . 638
8.702 unpack_fms_SetImagesPreference_t Struct Reference . . . 638
8.702.1 Detailed Description . . . 639
8.702.2 Field Documentation . . . 639
8.702.2.1 ImageTypes . . . 639
8.702.2.2 ImageTypesSize . . . 639
8.702.2.3 ParamPresenceMask . . . 639
8.702.2.4 Tlvresult . . . 639
8.703 unpack_ims_SLQSGetIMSSMSConfig_t Struct Reference . . . 639
8.703.1 Detailed Description . . . 639
8.703.2 Field Documentation . . . 640
8.703.2.1 ParamPresenceMask . . . 640
8.703.2.2 pPhoneCtxtURI . . . 640
8.703.2.3 pPhoneCtxtURILen . . . 640
8.703.2.4 pSettingResp . . . 640
8.703.2.5 pSMSFormat . . . 640
8.703.2.6 pSMSOverIPNwInd . . . 640
8.704 unpack_ims_SLQSGetIMSUserConfig_t Struct Reference . . . 640
8.704.1 Detailed Description . . . 640
8.704.2 Field Documentation . . . 641
8.704.2.1 ParamPresenceMask . . . 641
8.704.2.2 pIMSDomain . . . 641
8.704.2.3 pIMSDomainLen . . . 641
8.704.2.4 pSettingResp . . . 641
8.705 unpack_ims_SLQSGetIMSVoIPConfig_t Struct Reference . . . 641
8.705.1 Detailed Description . . . 641
8.705.2 Field Documentation . . . 643
8.705.2.1 pAmrMode . . . 643
8.705.2.2 pAmrOctetAligned . . . 643
8.705.2.3 pAmrWbEnable . . . 643
8.705.2.4 pAmrWBMode . . . 644
8.705.2.5 pAmrWBOctetAligned . . . 644
8.705.2.6 ParamPresenceMask . . . 644
8.705.2.7 pMinSessionExpiryTimer . . . 644
8.705.2.8 pRingBackTimer . . . 644
8.705.2.9 pRingingTimer . . . 644
8.705.2.10 pRTPRTCPInactTimer . . . 644

8.705.2.11 pScrAmrEnable . . . 644
8.705.2.12 pScrAmrWbEnable . . . 644
8.705.2.13 pSessionExpiryTimer . . . 644
8.705.2.14 pSettingResp . . . 644
8.706 unpack_ims_SLQSGetRegMgrConfig_t Struct Reference . . . 644
8.706.1 Detailed Description . . . 644
8.706.2 Field Documentation . . . 645
8.706.2.1 ParamPresenceMask . . . 645
8.706.2.2 pIMSTestMode . . . 645
8.706.2.3 pPCSCFPort . . . 645
8.706.2.4 pPriCSCFPortName . . . 645
8.706.2.5 pPriCSCFPortNameLen . . . 645
8.706.2.6 pSettingResp . . . 645
8.707 unpack_ims_SLQSGetSIPConfig_t Struct Reference . . . 645
8.707.1 Detailed Description . . . 645
8.707.2 Field Documentation . . . 646
8.707.2.1 ParamPresenceMask . . . 646
8.707.2.2 pSettingResp . . . 646
8.707.2.3 pSigCompEnabled . . . 646
8.707.2.4 pSIPLocalPort . . . 646
8.707.2.5 pSubscribeTimer . . . 646
8.707.2.6 pTimerSIPReg . . . 646
8.707.2.7 pTimerT1 . . . 646
8.707.2.8 pTimerT2 . . . 646
8.707.2.9 pTimerTf . . . 646
8.708 unpack_ims_SLQSRegMgrCfgCallBack_ind_t Struct Reference . . . 646
8.708.1 Detailed Description . . . 647
8.708.2 Field Documentation . . . 647
8.708.2.1 ParamPresenceMask . . . 647
8.708.2.2 PCTlv . . . 647
8.708.2.3 PNTlv . . . 647
8.708.2.4 TMTlv . . . 647
8.709 unpack_ims_SLQSSetIMSSMSConfig_t Struct Reference . . . 647
8.709.1 Detailed Description . . . 647
8.709.2 Field Documentation . . . 648
8.709.2.1 ParamPresenceMask . . . 648
8.709.2.2 pSettingResp . . . 648
8.710 unpack_ims_SLQSSetIMSUserConfig_t Struct Reference . . . 648
8.710.1 Detailed Description . . . 648
8.710.2 Field Documentation . . . 648

8.710.2.1 ParamPresenceMask . . . 648
8.710.2.2 pSettingResp . . . 648
8.711 unpack_ims_SLQSSetIMSVoIPConfig_t Struct Reference . . . 648
8.711.1 Detailed Description . . . 648
8.711.2 Field Documentation . . . 649
8.711.2.1 ParamPresenceMask . . . 649
8.711.2.2 pSettingResp . . . 649
8.712 unpack_ims_SLQSSetRegMgrConfig_t Struct Reference . . . 649
8.712.1 Detailed Description . . . 649
8.712.2 Field Documentation . . . 649
8.712.2.1 ParamPresenceMask . . . 649
8.712.2.2 pSettingResp . . . 649
8.713 unpack_ims_SLQSSetSIPConfig_t Struct Reference . . . 649
8.713.1 Detailed Description . . . 649
8.713.2 Field Documentation . . . 650
8.713.2.1 ParamPresenceMask . . . 650
8.713.2.2 pSettingResp . . . 650
8.714 unpack_ims_SLQSSIPCfgCallBack_ind_t Struct Reference . . . 650
8.714.1 Detailed Description . . . 650
8.714.2 Field Documentation . . . 651
8.714.2.1 ParamPresenceMask . . . 651
8.714.2.2 SCTlv . . . 651
8.714.2.3 SPTlv . . . 651
8.714.2.4 SRTlv . . . 651
8.714.2.5 STTlv . . . 651
8.714.2.6 TT1Tlv . . . 651
8.714.2.7 TT2Tlv . . . 651
8.714.2.8 TTfTlv . . . 651
8.715 unpack_ims_SLQSSMSCfgCallBack_ind_t Struct Reference . . . 651
8.715.1 Detailed Description . . . 651
8.715.2 Field Documentation . . . 652
8.715.2.1 ParamPresenceMask . . . 652
8.715.2.2 PCURTlv . . . 652
8.715.2.3 SFTlv . . . 652
8.715.2.4 SINTlv . . . 652
8.716 unpack_ims_SLQSUserCfgCallBack_ind_t Struct Reference . . . 652
8.716.1 Detailed Description . . . 652
8.716.2 Field Documentation . . . 653
8.716.2.1 IDTlv . . . 653
8.716.2.2 ParamPresenceMask . . . 653

8.717 unpack_ims_SLQSVoIPCfgCallBack_ind_t Struct Reference . . . 653
8.717.1 Detailed Description . . . 653
8.717.2 Field Documentation . . . 654
8.717.2.1 AMTlv . . . 654
8.717.2.2 AOATlv . . . 654
8.717.2.3 AWMTlv . . . 654
8.717.2.4 AWOATlv . . . 655
8.717.2.5 EAWTlv . . . 655
8.717.2.6 ESATlv . . . 655
8.717.2.7 ESAWTlv . . . 655
8.717.2.8 MSETlv . . . 655
8.717.2.9 ParamPresenceMask . . . 655
8.717.2.10 RBTTlv . . . 655
8.717.2.11 RTIDTlv . . . 655
8.717.2.12 RTTlv . . . 655
8.717.2.13 SDTlv . . . 655
8.718 unpack_imsa_SLQSGetIMSARegStatus_t Struct Reference . . . 655
8.718.1 Detailed Description . . . 655
8.718.2 Field Documentation . . . 656
8.718.2.1 ImsRegErrCode . . . 656
8.718.2.2 ImsRegStatus . . . 656
8.718.2.3 NewImsRegStatus . . . 656
8.718.2.4 ParamPresenceMask . . . 656
8.719 unpack_imsa_SLQSGetIMSAServiceStatus_t Struct Reference . . . 656
8.719.1 Detailed Description . . . 656
8.719.2 Field Documentation . . . 658
8.719.2.1 ParamPresenceMask . . . 658
8.719.2.2 SmsServiceRat . . . 658
8.719.2.3 SmsServiceStatus . . . 658
8.719.2.4 UtServiceRat . . . 658
8.719.2.5 UtServiceStatus . . . 658
8.719.2.6 VoipServiceRat . . . 658
8.719.2.7 VoipServiceStatus . . . 658
8.719.2.8 VsServiceRat . . . 658
8.719.2.9 VsServiceStatus . . . 658
8.719.2.10 VtServiceRat . . . 658
8.719.2.11 VtServiceStatus . . . 658
8.720 unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t Struct Reference . . . 658
8.720.1 Detailed Description . . . 659
8.720.2 Field Documentation . . . 659

8.720.2.1 FailErrCode . . . 659
8.720.2.2 ParamPresenceMask . . . 659
8.720.2.3 PdpConnState . . . 659
8.721 unpack_imsa_SLQSImsaRatStatusCallBack_ind_t Struct Reference . . . 659
8.721.1 Detailed Description . . . 659
8.721.2 Field Documentation . . . 660
8.721.2.1 ParamPresenceMask . . . 660
8.721.2.2 RatHandover . . . 660
8.722 unpack_imsa_SLQSImsaRegStatusCallBack_ind_t Struct Reference . . . 660
8.722.1 Detailed Description . . . 660
8.722.2 Field Documentation . . . 660
8.722.2.1 IMSRegistration . . . 660
8.722.2.2 IMSRegistrationError . . . 660
8.722.2.3 NewIMSRegistration . . . 660
8.722.2.4 ParamPresenceMask . . . 661
8.723 unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t Struct Reference . . . 661
8.723.1 Detailed Description . . . 661
8.723.2 Field Documentation . . . 662
8.723.2.1 ParamPresenceMask . . . 662
8.723.2.2 SmsRat . . . 662
8.723.2.3 SmsService . . . 662
8.723.2.4 UtRat . . . 662
8.723.2.5 UtService . . . 662
8.723.2.6 VoipRat . . . 662
8.723.2.7 VoipService . . . 662
8.723.2.8 VtRat . . . 662
8.723.2.9 VtService . . . 662
8.724 unpack_loc_BestAvailPos_Ind_t Struct Reference . . . 662
8.724.1 Detailed Description . . . 663
8.724.2 Field Documentation . . . 668
8.724.2.1 pAltitudeWrtEllipsoid . . . 668
8.724.2.2 pAltitudeWrtMeanSeaLevel . . . 668
8.724.2.3 ParamPresenceMask . . . 668
8.724.2.4 pGpsTime . . . 668
8.724.2.5 pHeading . . . 668
8.724.2.6 pHeadingUnc . . . 668
8.724.2.7 pHorCirConf . . . 668
8.724.2.8 pHorEllpConf . . . 668
8.724.2.9 pHorReliability . . . 668
8.724.2.10 pHorUncCircular . . . 668

8.724.2.11 pHorUncEllipseOrientAzimuth . . . 668
8.724.2.12 pHorUncEllipseSemiMajor . . . 668
8.724.2.13 pHorUncEllipseSemiMinor . . . 668
8.724.2.14 pLatitude . . . 668
8.724.2.15 pLongitude . . . 668
8.724.2.16 pMagneticDeviation . . . 668
8.724.2.17 pPrecisionDilution . . . 668
8.724.2.18 pSensorDataUsage . . . 668
8.724.2.19 pSpeedHorizontal . . . 668
8.724.2.20 pSpeedUnc . . . 668
8.724.2.21 pSpeedVertical . . . 668
8.724.2.22 pSpeedVerticalUnc . . . 668
8.724.2.23 pSvUsedforFix . . . 668
8.724.2.24 pTechnologyMask . . . 668
8.724.2.25 pTimeSrc . . . 668
8.724.2.26 pTimestampUtc . . . 668
8.724.2.27 pTimeUnc . . . 668
8.724.2.28 pVertConfidence . . . 669
8.724.2.29 pVertReliability . . . 669
8.724.2.30 pVertUnc . . . 669
8.724.2.31 pXid . . . 669
8.724.2.32 status . . . 669
8.724.2.33 Tlvresult . . . 669
8.725 unpack_loc_CradleMountCallback_Ind_t Struct Reference . . . 669
8.725.1 Detailed Description . . . 669
8.725.2 Field Documentation . . . 669
8.725.2.1 cradleMountConfigStatus . . . 669
8.725.2.2 ParamPresenceMask . . . 669
8.726 unpack_loc_Delete_Assist_Data_t Struct Reference . . . 669
8.726.1 Detailed Description . . . 670
8.726.2 Field Documentation . . . 670
8.726.2.1 ParamPresenceMask . . . 670
8.726.2.2 Tlvresult . . . 670
8.727 unpack_loc_DeleteAssistData_Ind_t Struct Reference . . . 670
8.727.1 Detailed Description . . . 670
8.727.2 Field Documentation . . . 671
8.727.2.1 ParamPresenceMask . . . 671
8.727.2.2 status . . . 671
8.727.2.3 Tlvresult . . . 671
8.728 unpack_loc_EngineState_Ind_t Struct Reference . . . 671

8.728.1 Detailed Description . . . 671
8.728.2 Field Documentation . . . 672
8.728.2.1 engineState . . . 672
8.728.2.2 ParamPresenceMask . . . 672
8.728.2.3 TlvResult . . . 672
8.729 unpack_loc_EventNMEA_Ind_t Struct Reference . . . 672
8.729.1 Detailed Description . . . 672
8.729.2 Field Documentation . . . 672
8.729.2.1 NMEAData . . . 672
8.729.2.2 ParamPresenceMask . . . 672
8.729.2.3 TlvResult . . . 672
8.730 unpack_loc_EventRegister_t Struct Reference . . . 673
8.730.1 Detailed Description . . . 673
8.730.2 Field Documentation . . . 673
8.730.2.1 ParamPresenceMask . . . 673
8.730.2.2 TlvResult . . . 673
8.731 unpack_loc_EventTimeSyncCallback_Ind_t Struct Reference . . . 673
8.731.1 Detailed Description . . . 673
8.731.2 Field Documentation . . . 673
8.731.2.1 ParamPresenceMask . . . 673
8.731.2.2 timeSyncRefCounter . . . 673
8.732 unpack_loc_GetServer_Ind_t Struct Reference . . . 673
8.732.1 Detailed Description . . . 674
8.732.2 Field Documentation . . . 675
8.732.2.1 ParamPresenceMask . . . 675
8.732.2.2 pIPv4AddrInfo . . . 675
8.732.2.3 pIPv6AddrInfo . . . 675
8.732.2.4 pURL . . . 675
8.732.2.5 serverStatus . . . 675
8.732.2.6 serverType . . . 675
8.732.2.7 TlvResult . . . 675
8.733 unpack_loc_GnssSvInfo_Ind_t Struct Reference . . . 675
8.733.1 Detailed Description . . . 675
8.733.2 Field Documentation . . . 676
8.733.2.1 altitudeAssumed . . . 676
8.733.2.2 ParamPresenceMask . . . 676
8.733.2.3 pSatelliteInfo . . . 676
8.733.2.4 TlvResult . . . 676
8.734 unpack_loc_InjectPositionCallback_Ind_t Struct Reference . . . 676
8.734.1 Detailed Description . . . 676

8.734.2 Field Documentation . . . 676
8.734.2.1 ParamPresenceMask . . . 676
8.734.2.2 status . . . 676
8.735 unpack_loc_InjectSensorDataCallback_Ind_t Struct Reference . . . 676
8.735.1 Detailed Description . . . 677
8.735.2 Field Documentation . . . 678
8.735.2.1 injectSensorDataStatus . . . 678
8.735.2.2 pAccelSamplesAccepted . . . 678
8.735.2.3 pAccelTempSamplesAccepted . . . 678
8.735.2.4 ParamPresenceMask . . . 678
8.735.2.5 pGyroSamplesAccepted . . . 678
8.735.2.6 pGyroTempSamplesAccepted . . . 678
8.735.2.7 pOpaqueIdentifier . . . 678
8.736 unpack_loc_InjectTimeSyncDataCallback_Ind_t Struct Reference . . . 678
8.736.1 Detailed Description . . . 678
8.736.2 Field Documentation . . . 679
8.736.2.1 injectTimeSyncStatus . . . 679
8.736.2.2 ParamPresenceMask . . . 679
8.737 unpack_loc_InjectUTCTimeCallback_Ind_t Struct Reference . . . 679
8.737.1 Detailed Description . . . 679
8.737.2 Field Documentation . . . 679
8.737.2.1 ParamPresenceMask . . . 679
8.737.2.2 status . . . 679
8.738 unpack_loc_PositionRpt_Ind_t Struct Reference . . . 679
8.738.1 Detailed Description . . . 680
8.738.2 Field Documentation . . . 685
8.738.2.1 pAltitudeAssumed . . . 685
8.738.2.2 pAltitudeWrtEllipsoid . . . 685
8.738.2.3 pAltitudeWrtMeanSeaLevel . . . 685
8.738.2.4 ParamPresenceMask . . . 685
8.738.2.5 pFixId . . . 685
8.738.2.6 pGpsTime . . . 685
8.738.2.7 pHeading . . . 685
8.738.2.8 pHeadingUnc . . . 685
8.738.2.9 pHorConfidence . . . 685
8.738.2.10 pHorReliability . . . 685
8.738.2.11 pHorUncCircular . . . 685
8.738.2.12 pHorUncEllipseOrientAzimuth . . . 685
8.738.2.13 pHorUncEllipseSemiMajor . . . 685
8.738.2.14 pHorUncEllipseSemiMinor . . . 685

8.738.2.15 pLatitude . . . 685
8.738.2.16 pLeapSeconds . . . 685
8.738.2.17 pLongitude . . . 685
8.738.2.18 pMagneticDeviation . . . 686
8.738.2.19 pPrecisionDilution . . . 686
8.738.2.20 pSensorDataUsage . . . 686
8.738.2.21 pSpeedHorizontal . . . 686
8.738.2.22 pSpeedUnc . . . 686
8.738.2.23 pSpeedVertical . . . 686
8.738.2.24 pSvUsedforFix . . . 686
8.738.2.25 pTechnologyMask . . . 686
8.738.2.26 pTimeSrc . . . 686
8.738.2.27 pTimestampUtc . . . 686
8.738.2.28 pTimeUnc . . . 686
8.738.2.29 pVertConfidence . . . 686
8.738.2.30 pVertReliability . . . 686
8.738.2.31 pVertUnc . . . 686
8.738.2.32 sessionId . . . 686
8.738.2.33 sessionStatus . . . 686
8.738.2.34 Tlvresult . . . 686
8.739 unpack_loc_SensorStreamingCallback_Ind_t Struct Reference . . . 686
8.739.1 Detailed Description . . . 686
8.739.2 Field Documentation . . . 687
8.739.2.1 pAccelAcceptReady . . . 687
8.739.2.2 pAccelTempAcceptReady . . . 687
8.739.2.3 ParamPresenceMask . . . 687
8.739.2.4 pGyroAcceptReady . . . 687
8.739.2.5 pGyroTempAcceptReady . . . 687
8.740 unpack_loc_SetExtPowerConfig_Ind_t Struct Reference . . . 687
8.740.1 Detailed Description . . . 687
8.740.2 Field Documentation . . . 688
8.740.2.1 ParamPresenceMask . . . 688
8.740.2.2 status . . . 688
8.740.2.3 Tlvresult . . . 688
8.741 unpack_loc_SetExtPowerState_t Struct Reference . . . 688
8.741.1 Detailed Description . . . 688
8.741.2 Field Documentation . . . 688
8.741.2.1 ParamPresenceMask . . . 688
8.741.2.2 Tlvresult . . . 688
8.742 unpack_loc_SetOperationMode_Ind_t Struct Reference . . . 689

8.742.1 Detailed Description . . . 689
8.742.2 Field Documentation . . . 689
8.742.2.1 ParamPresenceMask . . . 689
8.742.2.2 status . . . 689
8.742.2.3 Tlvresult . . . 689
8.743 unpack_loc_SetOperationMode_t Struct Reference . . . 689
8.743.1 Detailed Description . . . 689
8.743.2 Field Documentation . . . 690
8.743.2.1 ParamPresenceMask . . . 690
8.743.2.2 Tlvresult . . . 690
8.744 unpack_loc_SetServer_Ind_t Struct Reference . . . 690
8.744.1 Detailed Description . . . 690
8.744.2 Field Documentation . . . 690
8.744.2.1 serverStatus . . . 690
8.744.2.2 Tlvresult . . . 691
8.745 unpack_loc_SLQSLOCGetBestAvailPos_t Struct Reference . . . 691
8.745.1 Detailed Description . . . 691
8.745.2 Field Documentation . . . 691
8.745.2.1 ParamPresenceMask . . . 691
8.745.2.2 Tlvresult . . . 691
8.746 unpack_loc_Start_t Struct Reference . . . 691
8.746.1 Detailed Description . . . 691
8.746.2 Field Documentation . . . 691
8.746.2.1 ParamPresenceMask . . . 691
8.746.2.2 Tlvresult . . . 691
8.747 unpack_loc_Stop_t Struct Reference . . . 691
8.747.1 Detailed Description . . . 692
8.747.2 Field Documentation . . . 692
8.747.2.1 ParamPresenceMask . . . 692
8.747.2.2 Tlvresult . . . 692
8.748 unpack_nas_GetACCOLC_t Struct Reference . . . 692
8.748.1 Detailed Description . . . 692
8.748.2 Field Documentation . . . 692
8.748.2.1 pAccolc . . . 692
8.748.2.2 ParamPresenceMask . . . 692
8.749 unpack_nas_GetANAAAAuthenticationStatus_t Struct Reference . . . 692
8.749.1 Detailed Description . . . 693
8.749.2 Field Documentation . . . 693
8.749.2.1 ParamPresenceMask . . . 693
8.749.2.2 pAuthStatus . . . 693

8.750 unpack_nas_GetCDMANetworkParameters_t Struct Reference . . . 693
8.750.1 Detailed Description . . . 693
8.750.2 Field Documentation . . . 695
8.750.2.1 Application . . . 695
8.750.2.2 Broadcast . . . 695
8.750.2.3 CustomSCP . . . 695
8.750.2.4 ForceRev0 . . . 695
8.750.2.5 ParamPresenceMask . . . 695
8.750.2.6 Protocol . . . 695
8.750.2.7 RegForeignNID . . . 695
8.750.2.8 RegForeignSID . . . 695
8.750.2.9 RegHomeSID . . . 695
8.750.2.10 Roaming . . . 695
8.750.2.11 SCI . . . 695
8.750.2.12 SCM . . . 695
8.751 unpack_nas_GetHomeNetwork3GPP2_t Struct Reference . . . 695
8.751.1 Detailed Description . . . 696
8.751.2 Field Documentation . . . 697
8.751.2.1 nameSize . . . 697
8.751.2.2 ParamPresenceMask . . . 697
8.751.2.3 pMCC . . . 697
8.751.2.4 pMNC . . . 697
8.751.2.5 pName . . . 697
8.751.2.6 pNID . . . 697
8.751.2.7 pNw2DescDisp . . . 698
8.751.2.8 pNw2DescEnc . . . 698
8.751.2.9 pNw2DescLen . . . 698
8.751.2.10 pNw2MCC . . . 698
8.751.2.11 pNw2MNC . . . 698
8.751.2.12 pNw2Name . . . 698
8.751.2.13 pSID . . . 698
8.752 unpack_nas_GetHomeNetwork_t Struct Reference . . . 698
8.752.1 Detailed Description . . . 698
8.752.2 Field Documentation . . . 699
8.752.2.1 mcc . . . 699
8.752.2.2 mnc . . . 699
8.752.2.3 name . . . 699
8.752.2.4 nid . . . 699
8.752.2.5 ParamPresenceMask . . . 699
8.752.2.6 sid . . . 699

8.753 unpack_nas_GetNetworkPreference_t Struct Reference . . . 699
8.753.1 Detailed Description . . . 699
8.753.2 Field Documentation . . . 700
8.753.2.1 ActiveTechPref . . . 700
8.753.2.2 Duration . . . 700
8.753.2.3 ParamPresenceMask . . . 700
8.753.2.4 PersistentTechPref . . . 700
8.753.2.5 Tlvresult . . . 700
8.754 unpack_nas_GetRFInfo_t Struct Reference . . . 700
8.754.1 Detailed Description . . . 701
8.754.2 Field Documentation . . . 701
8.754.2.1 instancesSize . . . 701
8.754.2.2 ParamPresenceMask . . . 701
8.754.2.3 RFBandInfoElements . . . 701
8.755 unpack_nas_GetServingNetwork_t Struct Reference . . . 701
8.755.1 Detailed Description . . . 702
8.755.2 Field Documentation . . . 703
8.755.2.1 CSDomain . . . 703
8.755.2.2 DataCaps . . . 703
8.755.2.3 DataCapsLen . . . 703
8.755.2.4 MCC . . . 703
8.755.2.5 MNC . . . 703
8.755.2.6 Name . . . 704
8.755.2.7 nameSize . . . 704
8.755.2.8 ParamPresenceMask . . . 704
8.755.2.9 PSDomain . . . 704
8.755.2.10 RadioIfaces . . . 704
8.755.2.11 RadioIfacesSize . . . 704
8.755.2.12 RAN . . . 704
8.755.2.13 RegistrationState . . . 704
8.755.2.14 Roaming . . . 704
8.756 unpack_nas_GetServingNetworkCapabilities_t Struct Reference . . . 704
8.756.1 Detailed Description . . . 704
8.756.2 Field Documentation . . . 705
8.756.2.1 DataCaps . . . 705
8.756.2.2 DataCapsLen . . . 705
8.756.2.3 ParamPresenceMask . . . 705
8.757 unpack_nas_GetSignalStrengths_t Struct Reference . . . 705
8.757.1 Detailed Description . . . 705
8.757.2 Field Documentation . . . 705

8.757.2.1 len . . . 705
8.757.2.2 ParamPresenceMask . . . 705
8.757.2.3 radio . . . 705
8.757.2.4 rssi . . . 705
8.758 unpack_nas_PerformNetworkScan_t Struct Reference . . . 706
8.758.1 Detailed Description . . . 706
8.758.2 Field Documentation . . . 707
8.758.2.1 p3GppNetworkInfoInstances . . . 707
8.758.2.2 p3GppNetworkInstanceSize . . . 707
8.758.2.3 ParamPresenceMask . . . 707
8.758.2.4 pPCIInfo . . . 707
8.758.2.5 pPCSInstance . . . 707
8.758.2.6 pPCSInstanceSize . . . 707
8.758.2.7 pRATINstance . . . 707
8.758.2.8 pRATInstanceSize . . . 707
8.758.2.9 pScanResult . . . 707
8.759 unpack_nas_SetDataCapabilitiesCallback_ind_t Struct Reference . . . 707
8.759.1 Detailed Description . . . 707
8.759.2 Field Documentation . . . 708
8.759.2.1 dataCaps . . . 708
8.759.2.2 dataCapsSize . . . 708
8.759.2.3 ParamPresenceMask . . . 708
8.760 unpack_nas_SetEventReportInd_t Struct Reference . . . 708
8.760.1 Detailed Description . . . 708
8.760.2 Field Documentation . . . 709
8.760.2.1 ParamPresenceMask . . . 709
8.760.2.2 RFTlv . . . 709
8.760.2.3 RRTlv . . . 709
8.760.2.4 SLQSSSTlv . . . 709
8.760.2.5 SSTlv . . . 709
8.761 unpack_nas_SetNasLTECphyCaIndCallback_ind_t Struct Reference . . . 709
8.761.1 Detailed Description . . . 709
8.761.2 Field Documentation . . . 710
8.761.2.1 ParamPresenceMask . . . 710
8.761.2.2 sPhyCaAggPcellInfo . . . 710
8.761.2.3 sPhyCaAggScellDlBw . . . 710
8.761.2.4 sPhyCaAggScellIndex . . . 710
8.761.2.5 sPhyCaAggScellIndType . . . 710
8.761.2.6 sPhyCaAggScellInfo . . . 710
8.762 unpack_nas_SetNetworkPreference_t Struct Reference . . . 710

8.762.1 Detailed Description . . . 710
8.762.2 Field Documentation . . . 710
8.762.2.1 ParamPresenceMask . . . 711
8.762.2.2 Tlvresult . . . 711
8.763 unpack_nas_SetRoamingIndicatorCallback_ind_t Struct Reference . . . 711
8.763.1 Detailed Description . . . 711
8.763.2 Field Documentation . . . 711
8.763.2.1 ParamPresenceMask . . . 711
8.763.2.2 roaming . . . 711
8.764 unpack_nas_SetServingSystemCallback_ind_t Struct Reference . . . 711
8.764.1 Detailed Description . . . 711
8.764.2 Field Documentation . . . 712
8.764.2.1 ParamPresenceMask . . . 712
8.764.2.2 SSInfo . . . 712
8.764.2.3 Tlvresult . . . 712
8.765 unpack_nas_SLQSGetErrorRate_t Struct Reference . . . 712
8.765.1 Detailed Description . . . 712
8.765.2 Field Documentation . . . 713
8.765.2.1 ParamPresenceMask . . . 713
8.765.2.2 pCDMAFrameErrRate . . . 713
8.765.2.3 pGSMBER . . . 713
8.765.2.4 pHDRPackErrRate . . . 713
8.765.2.5 pWCDMABER . . . 713
8.766 unpack_nas_SlqsGetLTECphyCAInfo_t Struct Reference . . . 713
8.766.1 Detailed Description . . . 713
8.766.2 Field Documentation . . . 714
8.766.2.1 LTECphyCaInfo . . . 714
8.766.2.2 ParamPresenceMask . . . 714
8.766.2.3 Tlvresult . . . 714
8.767 unpack_nas_SLQSGetNetworkTime_t Struct Reference . . . 714
8.767.1 Detailed Description . . . 714
8.767.2 Field Documentation . . . 714
8.767.2.1 p3GPP2TimeInfo . . . 714
8.767.2.2 p3GPPTimeInfo . . . 714
8.767.2.3 ParamPresenceMask . . . 714
8.768 unpack_nas_SLQSGetOperatorNameData_t Struct Reference . . . 714
8.768.1 Detailed Description . . . 715
8.768.2 Field Documentation . . . 715
8.768.2.1 ParamPresenceMask . . . 715
8.768.2.2 pNITZInformation . . . 715

8.768.2.3 pOperatorNameString . . . 715
8.768.2.4 pOperatorPLMNList . . . 715
8.768.2.5 pPLMNNetworkName . . . 715
8.768.2.6 pSrvcProviderName . . . 715
8.769 unpack_nas_SLQSGetPLMNName_t Struct Reference . . . 716
8.769.1 Detailed Description . . . 716
8.769.2 Field Documentation . . . 718
8.769.2.1 longName . . . 718
8.769.2.2 longNameCI . . . 718
8.769.2.3 longNameEn . . . 718
8.769.2.4 longNameLen . . . 718
8.769.2.5 longNameSB . . . 718
8.769.2.6 ParamPresenceMask . . . 718
8.769.2.7 shortName . . . 718
8.769.2.8 shortNameCI . . . 718
8.769.2.9 shortNameEn . . . 718
8.769.2.10 shortNameLen . . . 718
8.769.2.11 shortNameSB . . . 718
8.769.2.12 spn . . . 718
8.769.2.13 spnEncoding . . . 719
8.769.2.14 spnLength . . . 719
8.770 unpack_nas_SLQSGetServingSystem_t Struct Reference . . . 719
8.770.1 Detailed Description . . . 719
8.770.2 Field Documentation . . . 722
8.770.2.1 BasestationID . . . 722
8.770.2.2 BasestationLatitude . . . 722
8.770.2.3 BasestationLongitude . . . 722
8.770.2.4 CallBarStatus . . . 722
8.770.2.5 CDMA_P_Rev . . . 722
8.770.2.6 CDMASystemInfoExt . . . 722
8.770.2.7 CellID . . . 723
8.770.2.8 ConcSvcInfo . . . 723
8.770.2.9 CurrentPLMN . . . 723
8.770.2.10 DataSrvCapabilities . . . 723
8.770.2.11 DefaultRoamInd . . . 723
8.770.2.12 DetailedSvcInfo . . . 723
8.770.2.13 DTMInd . . . 723
8.770.2.14 Gpp2TimeZone . . . 723
8.770.2.15 GppNetworkDSTAdjustment . . . 723
8.770.2.16 GppTimeZone . . . 723

8.770.2.17 HdrPersonality . . . 723
8.770.2.18 Lac . . . 723
8.770.2.19 NetworkID . . . 723
8.770.2.20 ParamPresenceMask . . . 723
8.770.2.21 PRLInd . . . 723
8.770.2.22 RoamIndicatorVal . . . 723
8.770.2.23 RoamingIndicatorList . . . 723
8.770.2.24 ServingSystem . . . 723
8.770.2.25 SystemID . . . 723
8.770.2.26 TrackAreaCode . . . 723
8.771 unpack_nas_SLQSGetSignalStrength_t Struct Reference . . . 723
8.771.1 Detailed Description . . . 724
8.771.2 Field Documentation . . . 725
8.771.2.1 ecioList . . . 725
8.771.2.2 ecioListLen . . . 725
8.771.2.3 errorRateList . . . 725
8.771.2.4 errorRateListLen . . . 725
8.771.2.5 Io . . . 726
8.771.2.6 Itersrp . . . 726
8.771.2.7 Itesnr . . . 726
8.771.2.8 ParamPresenceMask . . . 726
8.771.2.9 rsrqInfo . . . 726
8.771.2.10 rxSignalStrengthList . . . 726
8.771.2.11 rxSignalStrengthListLen . . . 726
8.771.2.12 signalStrengthReqMask . . . 726
8.771.2.13 sinr . . . 726
8.772 unpack_nas_SLQSGetSysInfo_t Struct Reference . . . 726
8.772.1 Detailed Description . . . 726
8.772.2 Field Documentation . . . 729
8.772.2.1 pAddCDMASysInfo . . . 729
8.772.2.2 pAddGSMSysInfo . . . 729
8.772.2.3 pAddHDRSysInfo . . . 729
8.772.2.4 pAddLTESysInfo . . . 729
8.772.2.5 pAddWCDMASysInfo . . . 729
8.772.2.6 ParamPresenceMask . . . 729
8.772.2.7 pCampedCiotLteOpMode . . . 729
8.772.2.8 pCDMASrvStatusInfo . . . 729
8.772.2.9 pCDMASysInfo . . . 729
8.772.2.10 pGSMCallBarringSysInfo . . . 729
8.772.2.11 pGSMCipherDomainSysInfo . . . 729

8.772.2.12 pGSMSrvStatusInfo . . . 729
8.772.2.13 pGSMSysInfo . . . 729
8.772.2.14 pHDRSrvStatusInfo . . . 729
8.772.2.15 pHDRSysInfo . . . 729
8.772.2.16 pLTESrvStatusInfo . . . 729
8.772.2.17 pLTESysInfo . . . 729
8.772.2.18 pLTEVoiceSupportSysInfo . . . 729
8.772.2.19 pWCDMACallBarringSysInfo . . . 729
8.772.2.20 pWCDMACipherDomainSysInfo . . . 730
8.772.2.21 pWCDMASrvStatusInfo . . . 730
8.772.2.22 pWCDMASysInfo . . . 730
8.773 unpack_nas_SLQSGetSysSelectionPref_t Struct Reference . . . 730
8.773.1 Detailed Description . . . 730
8.773.2 Field Documentation . . . 734
8.773.2.1 ParamPresenceMask . . . 734
8.773.2.2 pBandPref . . . 734
8.773.2.3 pEmerMode . . . 734
8.773.2.4 pGWAcqOrderPref . . . 734
8.773.2.5 pLTEBandPref . . . 734
8.773.2.6 pModePref . . . 734
8.773.2.7 pNetSelPref . . . 734
8.773.2.8 pPRLPref . . . 734
8.773.2.9 pRoamPref . . . 734
8.773.2.10 pSrvDomainPref . . . 734
8.774 unpack_nas_SLQSGetSysSelectionPrefExt_t Struct Reference . . . 734
8.774.1 Detailed Description . . . 735
8.774.2 Field Documentation . . . 736
8.774.2.1 pAcqOrderPref . . . 736
8.774.2.2 pBandPref . . . 736
8.774.2.3 pCiotAcqOrderPref . . . 736
8.774.2.4 pCiotLteOpModePref . . . 737
8.774.2.5 pEmerMode . . . 737
8.774.2.6 pGWAcqOrderPref . . . 737
8.774.2.7 pLTEBandPref . . . 737
8.774.2.8 pLTEBandPrefExt . . . 737
8.774.2.9 pLteM1BandPref . . . 737
8.774.2.10 pLteNb1BandPref . . . 737
8.774.2.11 pModePref . . . 737
8.774.2.12 pNetSelPref . . . 737
8.774.2.13 pNr5gBandPref . . . 737

8.774.2.14 pPRLPref . . . 737
8.774.2.15 pRatDisabledMask . . . 737
8.774.2.16 pRoamPref . . . 737
8.774.2.17 pSrvDomainPref . . . 737
8.775 unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t Struct Reference . . . 737
8.775.1 Detailed Description . . . 737
8.775.2 Field Documentation . . . 738
8.775.2.1 edrxCiotLteModeTlv . . . 738
8.775.2.2 edrxCycleLengthTlv . . . 738
8.775.2.3 edrxEnableTypeTlv . . . 738
8.775.2.4 edrxPagingTimeWindowTlv . . . 738
8.775.2.5 edrxRatTypeTlv . . . 738
8.775.2.6 ParamPresenceMask . . . 738
8.776 unpack_nas_SLQSNasGet3GPP2Subscription_t Struct Reference . . . 738
8.776.1 Detailed Description . . . 738
8.776.2 Field Documentation . . . 739
8.776.2.1 ParamPresenceMask . . . 739
8.776.2.2 pCDMAChannel . . . 739
8.776.2.3 pDirNum . . . 739
8.776.2.4 pHomeSIDNID . . . 739
8.776.2.5 pMinBasedIMSI . . . 739
8.776.2.6 pNAMNameInfo . . . 739
8.776.2.7 pTrueIMSI . . . 739
8.777 unpack_nas_SLQSNasGetCellLocationInfo_t Struct Reference . . . 739
8.777.1 Detailed Description . . . 740
8.777.2 Field Documentation . . . 740
8.777.2.1 ParamPresenceMask . . . 741
8.777.2.2 pCDMAInfo . . . 741
8.777.2.3 pGERANInfo . . . 741
8.777.2.4 pLTEInfoInterfreq . . . 741
8.777.2.5 pLTEInfoIntrafreq . . . 741
8.777.2.6 pLTEInfoNeighboringGSM . . . 741
8.777.2.7 pLTEInfoNeighboringWCDMA . . . 741
8.777.2.8 pUMTSCellID . . . 741
8.777.2.9 pUMTSInfo . . . 741
8.777.2.10 pWCDMAInfoLTENeighborCell . . . 741
8.778 unpack_nas_SLQSNASGeteDRXParams_t Struct Reference . . . 741
8.778.1 Detailed Description . . . 741
8.778.2 Field Documentation . . . 742
8.778.2.1 ParamPresenceMask . . . 742

8.778.2.2 pCycleLen . . . 742
8.778.2.3 pEdrxEnable . . . 742
8.778.2.4 pPagingTimeWindow . . . 742
8.779 unpack_nas_SLQSNASGeteDRXParamsExt_t Struct Reference . . . 742
8.779.1 Detailed Description . . . 742
8.779.2 Field Documentation . . . 743
8.779.2.1 ParamPresenceMask . . . 743
8.779.2.2 pCycleLen . . . 743
8.779.2.3 pEdrxEnable . . . 743
8.779.2.4 pEdrxRAT . . . 743
8.779.2.5 pLteOpMode . . . 743
8.779.2.6 pPagingTimeWindow . . . 743
8.780 unpack_nas_SLQSNASGetForbiddenNetworks_t Struct Reference . . . 743
8.780.1 Detailed Description . . . 744
8.780.2 Field Documentation . . . 744
8.780.2.1 ParamPresenceMask . . . 744
8.780.2.2 pForbiddenNetworks3GPP . . . 744
8.781 unpack_nas_SLQSNasGetHDRColorCode_t Struct Reference . . . 744
8.781.1 Detailed Description . . . 744
8.781.2 Field Documentation . . . 744
8.781.2.1 ParamPresenceMask . . . 744
8.781.2.2 pColorCode . . . 744
8.782 unpack_nas_SLQSNasGetRFInfo_t Struct Reference . . . 744
8.782.1 Detailed Description . . . 745
8.782.2 Field Documentation . . . 745
8.782.2.1 pLTEOperationMode . . . 745
8.782.2.2 pRfBandInfoExtFormat . . . 745
8.782.2.3 pRfBandwidthInfo . . . 745
8.782.2.4 pRfDedicatedBandInfo . . . 745
8.782.2.5 rfbandInfoList . . . 745
8.782.2.6 Tlvresult . . . 745
8.783 unpack_nas_SLQSNasGetSigInfo_t Struct Reference . . . 745
8.783.1 Detailed Description . . . 746
8.783.2 Field Documentation . . . 746
8.783.2.1 CDMASSInfo . . . 746
8.783.2.2 GSMSSInfo . . . 746
8.783.2.3 HDRSSInfo . . . 746
8.783.2.4 LTESSInfo . . . 746
8.783.2.5 ParamPresenceMask . . . 746
8.783.2.6 WCDMASSInfo . . . 746

8.784 unpack_nas_SLQSNasGetTxRxInfo_t Struct Reference . . . 746
8.784.1 Detailed Description . . . 747
8.784.2 Field Documentation . . . 747
8.784.2.1 ParamPresenceMask . . . 747
8.784.2.2 pRXChain0Info . . . 747
8.784.2.3 pRXChain1Info . . . 747
8.784.2.4 pTXInfo . . . 747
8.785 unpack_nas_SLQSNasNetworkRejectCallback_Ind_t Struct Reference . . . 747
8.785.1 Detailed Description . . . 747
8.785.2 Field Documentation . . . 750
8.785.2.1 ParamPresenceMask . . . 750
8.785.2.2 pCsgId . . . 750
8.785.2.3 pLteOpMode . . . 750
8.785.2.4 pPlmnId . . . 750
8.785.2.5 radioIf . . . 750
8.785.2.6 rejectCause . . . 750
8.785.2.7 serviceDomain . . . 750
8.786 unpack_nas_SLQSNasNetworkTimeCallBack_ind_t Struct Reference . . . 750
8.786.1 Detailed Description . . . 750
8.786.2 Field Documentation . . . 751
8.786.2.1 ParamPresenceMask . . . 751
8.786.2.2 pDayltSavAdj . . . 751
8.786.2.3 pRadioInterface . . . 751
8.786.2.4 pTimeZone . . . 751
8.786.2.5 universalTime . . . 751
8.787 unpack_nas_SLQSNasSigInfoCallback_ind_t Struct Reference . . . 751
8.787.1 Detailed Description . . . 752
8.787.2 Field Documentation . . . 752
8.787.2.1 ParamPresenceMask . . . 752
8.787.2.2 pCDMASigInfo . . . 752
8.787.2.3 pGSMSigInfo . . . 752
8.787.2.4 pHDRSigInfo . . . 752
8.787.2.5 pLTESigInfo . . . 752
8.787.2.6 pRscp . . . 752
8.787.2.7 pTDSCDMASigInfoExt . . . 753
8.787.2.8 pWCDMASigInfo . . . 753
8.788 unpack_nas_SLQSNASSwiGetChannelLock_t Struct Reference . . . 753
8.788.1 Detailed Description . . . 753
8.788.2 Field Documentation . . . 753
8.788.2.1 ParamPresenceMask . . . 753

8.788.2.2 pLteEARFCN . . . 753
8.788.2.3 pLtePCI . . . 753
8.788.2.4 pWcdmaUARFCN . . . 753
8.789 unpack_nas_SLQSNasSwiModemStatus_t Struct Reference . . . 753
8.789.1 Detailed Description . . . 754
8.789.2 Field Documentation . . . 754
8.789.2.1 commonInfo . . . 754
8.789.2.2 ParamPresenceMask . . . 754
8.789.2.3 pLTEInfo . . . 754
8.790 unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t Struct Reference . . . 754
8.790.1 Detailed Description . . . 754
8.790.2 Field Documentation . . . 755
8.790.2.1 Info . . . 755
8.790.2.2 ParamPresenceMask . . . 755
8.790.2.3 Tlvresult . . . 755
8.791 unpack_nas_SLQSNasTimerCallback_ind_t Struct Reference . . . 755
8.791.1 Detailed Description . . . 755
8.791.2 Field Documentation . . . 755
8.791.2.1 ParamPresenceMask . . . 755
8.791.2.2 t3396_apn . . . 755
8.791.2.3 t3396_plmn_id . . . 755
8.791.2.4 t3396_val . . . 755
8.792 unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t Struct Reference . . . 755
8.792.1 Detailed Description . . . 756
8.792.2 Field Documentation . . . 756
8.792.2.1 Info . . . 756
8.792.2.2 ParamPresenceMask . . . 756
8.792.2.3 Tlvresult . . . 756
8.793 unpack_nas_SLQSSwiGetHDRPersonality_t Struct Reference . . . 756
8.793.1 Detailed Description . . . 756
8.793.2 Field Documentation . . . 757
8.793.2.1 ParamPresenceMask . . . 757
8.793.2.2 pCurrentPersonality . . . 757
8.793.2.3 pPersonalityListLength . . . 757
8.793.2.4 pProtocolSubtypeElement . . . 757
8.794 unpack_nas_SLQSSwiGetHDRProtSubtype_t Struct Reference . . . 757
8.794.1 Detailed Description . . . 757
8.794.2 Field Documentation . . . 758
8.794.2.1 pAppSubType . . . 758
8.794.2.2 ParamPresenceMask . . . 758

8.794.2.3 pCurrentPrsnlty . . . 758
8.794.2.4 pPersonalityListLength . . . 758
8.794.2.5 pProtoSubTypElmnt . . . 758
8.795 unpack_nas_SLQSSwiGetHRPDStats_t Struct Reference . . . 758
8.795.1 Detailed Description . . . 758
8.795.2 Field Documentation . . . 759
8.795.2.1 ParamPresenceMask . . . 759
8.795.2.2 pDRCParams . . . 759
8.795.2.3 pPilotSetData . . . 759
8.795.2.4 pUATI . . . 759
8.796 unpack_nas_SLQSSwiGetLteCQI_t Struct Reference . . . 759
8.796.1 Detailed Description . . . 759
8.796.2 Field Documentation . . . 760
8.796.2.1 CQIValueCW0 . . . 760
8.796.2.2 CQIValueCW1 . . . 760
8.796.2.3 ParamPresenceMask . . . 760
8.796.2.4 ValidityCW0 . . . 760
8.796.2.5 ValidityCW1 . . . 760
8.797 unpack_nas_SLQSSwiGetLteSccRxInfo_t Struct Reference . . . 760
8.797.1 Detailed Description . . . 760
8.797.2 Field Documentation . . . 760
8.797.2.1 ParamPresenceMask . . . 760
8.797.2.2 pSccRxInfo . . . 760
8.798 unpack_nas_SLQSSwiHDRPersonalityCallback_Ind_t Struct Reference . . . 760
8.798.1 Detailed Description . . . 760
8.798.2 Field Documentation . . . 761
8.798.2.1 ParamPresenceMask . . . 761
8.798.2.2 pHDRPersInd . . . 761
8.799 unpack_nas_SLQSSwiNetworkDebug_t Struct Reference . . . 761
8.799.1 Detailed Description . . . 761
8.799.2 Field Documentation . . . 762
8.799.2.1 ParamPresenceMask . . . 762
8.799.2.2 pDataStatusDetail . . . 762
8.799.2.3 pDeviceConfigDetail . . . 762
8.799.2.4 pNetworkStat1x . . . 762
8.799.2.5 pNetworkStatEVDO . . . 762
8.799.2.6 pObjectVer . . . 762
8.800 unpack_nas_SLQSSwiRandIndicatorCallback_Ind_t Struct Reference . . . 762
8.800.1 Detailed Description . . . 762
8.800.2 Field Documentation . . . 762

8.800.2.1 ParamPresenceMask . . . 762
8.800.2.2 rankIndicatorTlv . . . 762
8.801 unpack_nas_SLQSSysInfoCallback_ind_t Struct Reference . . . 762
8.801.1 Detailed Description . . . 763
8.801.2 Field Documentation . . . 765
8.801.2.1 pAddCDMASysInfo . . . 765
8.801.2.2 pAddGSMSysInfo . . . 765
8.801.2.3 pAddHDRSysInfo . . . 765
8.801.2.4 pAddLTESysInfo . . . 765
8.801.2.5 pAddWCDMASysInfo . . . 765
8.801.2.6 ParamPresenceMask . . . 765
8.801.2.7 pCDMASrvStatusInfo . . . 765
8.801.2.8 pCDMASysInfo . . . 765
8.801.2.9 pGSMCallBarringSysInfo . . . 765
8.801.2.10 pGSMCipherDomainSysInfo . . . 765
8.801.2.11 pGSMSrvStatusInfo . . . 765
8.801.2.12 pGSMSysInfo . . . 765
8.801.2.13 pHDRSrvStatusInfo . . . 766
8.801.2.14 pHDRSysInfo . . . 766
8.801.2.15 pLTESrvStatusInfo . . . 766
8.801.2.16 pLTESysInfo . . . 766
8.801.2.17 pLTEVoiceSupportSysInfo . . . 766
8.801.2.18 pSysInfoNoChange . . . 766
8.801.2.19 pWCDMACallBarringSysInfo . . . 766
8.801.2.20 pWCDMACipherDomainSysInfo . . . 766
8.801.2.21 pWCDMASrvStatusInfo . . . 766
8.801.2.22 pWCDMASysInfo . . . 766
8.802 unpack_omaDmConfigTlv_t Struct Reference . . . 766
8.802.1 Detailed Description . . . 766
8.802.2 Field Documentation . . . 767
8.802.2.1 alertmsg . . . 767
8.802.2.2 alertmsglength . . . 767
8.802.2.3 state . . . 767
8.802.2.4 userInputReq . . . 767
8.802.2.5 userInputTimeout . . . 767
8.803 unpack_omaDmFotaTlv_t Struct Reference . . . 767
8.803.1 Detailed Description . . . 767
8.803.2 Field Documentation . . . 768
8.803.2.1 description . . . 768
8.803.2.2 descriptionlength . . . 768

8.803.2.3 fwdloadsize . . . 768
8.803.2.4 fwloadComplete . . . 768
8.803.2.5 namelength . . . 768
8.803.2.6 package_name . . . 768
8.803.2.7 sessionType . . . 768
8.803.2.8 severity . . . 769
8.803.2.9 state . . . 769
8.803.2.10 updateCompleteStatus . . . 769
8.803.2.11 userInputReq . . . 769
8.803.2.12 userInputTimeout . . . 769
8.803.2.13 version . . . 769
8.803.2.14 versionlength . . . 769
8.804 unpack_omaDmNotificationsTlv_t Struct Reference . . . 769
8.804.1 Detailed Description . . . 769
8.804.2 Field Documentation . . . 770
8.804.2.1 notification . . . 770
8.804.2.2 sessionStatus . . . 770
8.805 unpack_pds_GetPDSDefaults_t Struct Reference . . . 770
8.805.1 Detailed Description . . . 770
8.805.2 Field Documentation . . . 770
8.805.2.1 pAccuracy . . . 770
8.805.2.2 ParamPresenceMask . . . 770
8.805.2.3 pInterval . . . 770
8.805.2.4 pOperation . . . 771
8.805.2.5 pTimeout . . . 771
8.806 unpack_pds_GetPDSState_t Struct Reference . . . 771
8.806.1 Detailed Description . . . 771
8.806.2 Field Documentation . . . 771
8.806.2.1 ParamPresenceMask . . . 771
8.806.2.2 pEnabledStatus . . . 771
8.806.2.3 pTrackingStatus . . . 771
8.807 unpack_pds_GetPortAutomaticTracking_t Struct Reference . . . 771
8.807.1 Detailed Description . . . 772
8.807.2 Field Documentation . . . 772
8.807.2.1 ParamPresenceMask . . . 772
8.807.2.2 pbAuto . . . 772
8.808 unpack_pds_GetServiceAutomaticTracking_t Struct Reference . . . 772
8.808.1 Detailed Description . . . 772
8.808.2 Field Documentation . . . 772
8.808.2.1 ParamPresenceMask . . . 772

8.808.2.2 pbAuto . . . 772
8.809 unpack_pds_GetXTRAAutomaticDownload_t Struct Reference . . . 773
8.809.1 Detailed Description . . . 773
8.809.2 Field Documentation . . . 773
8.809.2.1 ParamPresenceMask . . . 773
8.809.2.2 pbEnabled . . . 773
8.809.2.3 pInterval . . . 773
8.810 unpack_pds_GetXTRANetwork_t Struct Reference . . . 773
8.810.1 Detailed Description . . . 773
8.810.2 Field Documentation . . . 774
8.810.2.1 ParamPresenceMask . . . 774
8.810.2.2 pPreference . . . 774
8.811 unpack_pds_GetXTRAValidity_t Struct Reference . . . 774
8.811.1 Detailed Description . . . 774
8.811.2 Field Documentation . . . 774
8.811.2.1 ParamPresenceMask . . . 775
8.811.2.2 pDuration . . . 775
8.811.2.3 pGPSWeek . . . 775
8.811.2.4 pGPSWeekOffset . . . 775
8.812 unpack_pds_SetEventReport_Ind_t Struct Reference . . . 775
8.812.1 Detailed Description . . . 775
8.812.2 Field Documentation . . . 776
8.812.2.1 dLatitude . . . 776
8.812.2.2 dLongitude . . . 776
8.812.2.3 has_dLatitude . . . 776
8.812.2.4 has_dLongitude . . . 776
8.812.2.5 has_PositionDataNMEA . . . 776
8.812.2.6 has_posSrc . . . 776
8.812.2.7 has_SessionStatus . . . 776
8.812.2.8 ParamPresenceMask . . . 776
8.812.2.9 PositionDataNMEA . . . 777
8.812.2.10 posSrc . . . 777
8.812.2.11 SessionStatus . . . 777
8.813 unpack_pds_SetPdsState_Ind_t Struct Reference . . . 777
8.813.1 Detailed Description . . . 777
8.813.2 Field Documentation . . . 777
8.813.2.1 EnabledStatus . . . 777
8.813.2.2 ParamPresenceMask . . . 777
8.813.2.3 TlvPresent . . . 777
8.813.2.4 TrackingStatus . . . 777

8.814 unpack_pds_SLQSGetAGPSConfig_t Struct Reference . . . 777
8.814.1 Detailed Description . . . 778
8.814.2 Field Documentation . . . 778
8.814.2.1 ParamPresenceMask . . . 778
8.814.2.2 pServerAddress . . . 778
8.814.2.3 pServerPort . . . 778
8.814.2.4 pServerURL . . . 778
8.814.2.5 pServerURLLength . . . 778
8.815 unpack_pds_SLQSGetGPSStateInfo_t Struct Reference . . . 778
8.815.1 Detailed Description . . . 779
8.815.2 Field Documentation . . . 782
8.815.2.1 Altitude . . . 782
8.815.2.2 EngineState . . . 783
8.815.2.3 glo_almanac_sv_msk . . . 783
8.815.2.4 glo_ephemeris_sv_msk . . . 783
8.815.2.5 glo_health_sv_msk . . . 783
8.815.2.6 glo_visible_sv_msk . . . 783
8.815.2.7 gps_almanac_sv_msk . . . 783
8.815.2.8 gps_ephemeris_sv_msk . . . 783
8.815.2.9 gps_health_sv_msk . . . 783
8.815.2.10 gps_visible_sv_msk . . . 783
8.815.2.11 HorizontalUncertainty . . . 783
8.815.2.12 iono_valid . . . 783
8.815.2.13 Latitude . . . 783
8.815.2.14 Longitude . . . 783
8.815.2.15 ParamPresenceMask . . . 783
8.815.2.16 sbas_almanac_sv_msk . . . 783
8.815.2.17 sbas_ephemeris_sv_msk . . . 783
8.815.2.18 sbas_health_sv_msk . . . 783
8.815.2.19 sbas_visible_sv_msk . . . 783
8.815.2.20 Time_uncert_ms . . . 783
8.815.2.21 TimeStmp_gps_week . . . 783
8.815.2.22 TimeStmp_tow_ms . . . 783
8.815.2.23 ValidMask . . . 783
8.815.2.24 VerticalUncertainty . . . 783
8.815.2.25 xtra_start_gps_minutes . . . 783
8.815.2.26 xtra_start_gps_week . . . 783
8.815.2.27 xtra_valid_duration_hours . . . 783
8.816 unpack_qmi_t Struct Reference . . . 783
8.816.1 Detailed Description . . . 784

8.816.2 Field Documentation . . . 784
8.816.2.1 msgid . . . 784
8.816.2.2 type . . . 784
8.816.2.3 xid . . . 784
8.817 unpack_qos_BindDataPort_t Struct Reference . . . 784
8.817.1 Detailed Description . . . 784
8.817.2 Field Documentation . . . 784
8.817.2.1 ParamPresenceMask . . . 784
8.818 unpack_qos_dataRate_t Struct Reference . . . 784
8.818.1 Detailed Description . . . 785
8.818.2 Field Documentation . . . 785
8.818.2.1 dataRateMax . . . 785
8.818.2.2 guaranteedRate . . . 785
8.819 unpack_qos_IPv4Addr_t Struct Reference . . . 785
8.819.1 Detailed Description . . . 785
8.819.2 Field Documentation . . . 785
8.819.2.1 addr . . . 785
8.819.2.2 subnetMask . . . 785
8.820 unpack_qos_IPv6Addr_t Struct Reference . . . 785
8.820.1 Detailed Description . . . 785
8.820.2 Field Documentation . . . 786
8.820.2.1 addr . . . 786
8.820.2.2 prefixLen . . . 786
8.821 unpack_qos_IPv6TrafCls_t Struct Reference . . . 786
8.821.1 Detailed Description . . . 786
8.821.2 Field Documentation . . . 786
8.821.2.1 mask . . . 786
8.821.2.2 val . . . 786
8.822 unpack_qos_pktErrRate_t Struct Reference . . . 786
8.822.1 Detailed Description . . . 786
8.822.2 Field Documentation . . . 787
8.822.2.1 exponent . . . 787
8.822.2.2 multiplier . . . 787
8.823 unpack_qos_Port_t Struct Reference . . . 787
8.823.1 Detailed Description . . . 787
8.823.2 Field Documentation . . . 787
8.823.2.1 port . . . 787
8.823.2.2 range . . . 787
8.824 unpack_qos_QosFlowInfo_t Struct Reference . . . 787
8.824.1 Detailed Description . . . 787

8.824.2 Field Documentation . . . 788
8.824.2.1 BearerID . . . 788
8.824.2.2 is_RxQFlowGranted_Available . . . 788
8.824.2.3 is_TxQFlowGranted_Available . . . 788
8.824.2.4 NumRxFilters . . . 788
8.824.2.5 NumTxFilters . . . 788
8.824.2.6 QFlowState . . . 788
8.824.2.7 RxQFilter . . . 789
8.824.2.8 RxQFlowGranted . . . 789
8.824.2.9 TxQFilter . . . 789
8.824.2.10 TxQFlowGranted . . . 789
8.825 unpack_qos_QosFlowInfoState_t Struct Reference . . . 789
8.825.1 Detailed Description . . . 789
8.825.2 Field Documentation . . . 789
8.825.2.1 id . . . 789
8.825.2.2 isNewFlow . . . 789
8.825.2.3 state . . . 789
8.826 unpack_qos_SLQSQosGetNetworkStatus_t Struct Reference . . . 789
8.826.1 Detailed Description . . . 790
8.826.2 Field Documentation . . . 790
8.826.2.1 NWQoSStatus . . . 790
8.826.2.2 ParamPresenceMask . . . 790
8.827 unpack_qos_SLQSQosSwiReadApnExtraParams_t Struct Reference . . . 790
8.827.1 Detailed Description . . . 790
8.827.2 Field Documentation . . . 791
8.827.2.1 ambr_dl . . . 791
8.827.2.2 ambr_dl_ext . . . 791
8.827.2.3 ambr_dl_ext2 . . . 791
8.827.2.4 ambr_ul . . . 791
8.827.2.5 ambr_ul_ext . . . 791
8.827.2.6 ambr_ul_ext2 . . . 791
8.827.2.7 apnId . . . 791
8.827.2.8 ParamPresenceMask . . . 791
8.828 unpack_qos_SLQSQosSwiReadDataStats_t Struct Reference . . . 791
8.828.1 Detailed Description . . . 792
8.828.2 Field Documentation . . . 793
8.828.2.1 apnId . . . 793
8.828.2.2 numQosFlow . . . 793
8.828.2.3 ParamPresenceMask . . . 793
8.828.2.4 qosFlow . . . 793

8.828.2.5 total_rx_bytes . . . 793
8.828.2.6 total_rx_pkt . . . 793
8.828.2.7 total_tx_bytes . . . 793
8.828.2.8 total_tx_bytes_drp . . . 793
8.828.2.9 total_tx_pkt . . . 793
8.828.2.10 total_tx_pkt_drp . . . 793
8.829 unpack_qos_SLQSSetQosEventCallback_ind_t Struct Reference . . . 793
8.829.1 Detailed Description . . . 793
8.829.2 Field Documentation . . . 793
8.829.2.1 NumFlows . . . 793
8.829.2.2 ParamPresenceMask . . . 794
8.829.2.3 QosFlowInfo . . . 794
8.830 unpack_qos_SLQSSetQosEventCallback_t Struct Reference . . . 794
8.830.1 Detailed Description . . . 794
8.830.2 Field Documentation . . . 794
8.830.2.1 ParamPresenceMask . . . 794
8.831 unpack_qos_SLQSSetQosNWStatusCallback_ind_t Struct Reference . . . 794
8.831.1 Detailed Description . . . 794
8.831.2 Field Documentation . . . 794
8.831.2.1 ParamPresenceMask . . . 794
8.831.2.2 status . . . 794
8.832 unpack_qos_SLQSSetQosPriEventCallback_ind_t Struct Reference . . . 795
8.832.1 Detailed Description . . . 795
8.832.2 Field Documentation . . . 795
8.832.2.1 event . . . 795
8.832.2.2 ParamPresenceMask . . . 795
8.833 unpack_qos_SLQSSetQosStatusCallback_ind_t Struct Reference . . . 795
8.833.1 Detailed Description . . . 795
8.833.2 Field Documentation . . . 796
8.833.2.1 event . . . 796
8.833.2.2 id . . . 796
8.833.2.3 ParamPresenceMask . . . 796
8.833.2.4 reason . . . 796
8.833.2.5 status . . . 796
8.834 unpack_qos_swiQosFilter_t Struct Reference . . . 797
8.834.1 Detailed Description . . . 797
8.834.2 Field Documentation . . . 799
8.834.2.1 EspSpi . . . 799
8.834.2.2 Id . . . 799
8.834.2.3 index . . . 799

8.834.2.4 IPv4DstAddr . . . 799
8.834.2.5 IPv4SrcAddr . . . 799
8.834.2.6 IPv4Tos . . . 799
8.834.2.7 IPv6DstAddr . . . 799
8.834.2.8 IPv6Label . . . 799
8.834.2.9 IPv6SrcAddr . . . 799
8.834.2.10 IPv6TrafCls . . . 799
8.834.2.11 is_EspSpi_Available . . . 799
8.834.2.12 is_Id_Available . . . 799
8.834.2.13 is_IPv4DstAddr_Available . . . 799
8.834.2.14 is_IPv4SrcAddr_Available . . . 799
8.834.2.15 is_IPv4Tos_Available . . . 799
8.834.2.16 is_IPv6DstAddr_Available . . . 799
8.834.2.17 is_IPv6Label_Available . . . 799
8.834.2.18 is_IPv6SrcAddr_Available . . . 799
8.834.2.19 is_IPv6TrafCls_Available . . . 799
8.834.2.20 is_NxtHdrProto_Available . . . 799
8.834.2.21 is_Precedence_Available . . . 799
8.834.2.22 is_TCPDstPort_Available . . . 799
8.834.2.23 is_TCPSrcPort_Available . . . 800
8.834.2.24 is_TranDstPort_Available . . . 800
8.834.2.25 is_TranSrcPort_Available . . . 800
8.834.2.26 is_UDPDstPort_Available . . . 800
8.834.2.27 is_UDPSrcPort_Available . . . 800
8.834.2.28 NxtHdrProto . . . 800
8.834.2.29 Precedence . . . 800
8.834.2.30 TCPDstPort . . . 800
8.834.2.31 TCPSrcPort . . . 800
8.834.2.32 TranDstPort . . . 800
8.834.2.33 TranSrcPort . . . 800
8.834.2.34 UDPDstPort . . . 800
8.834.2.35 UDPSrcPort . . . 800
8.834.2.36 version . . . 800
8.835 unpack_qos_swiQosFlow_t Struct Reference . . . 800
8.835.1 Detailed Description . . . 801
8.835.2 Field Documentation . . . 803
8.835.2.1 DataRate . . . 803
8.835.2.2 index . . . 803
8.835.2.3 is_DataRate_Available . . . 803
8.835.2.4 is_Jitter_Available . . . 803

8.835.2.5 is_Latency_Available . . . 803
8.835.2.6 is_LteQci_Available . . . 803
8.835.2.7 is_MaxAllowedPktSz_Available . . . 803
8.835.2.8 is_MinPolicedPktSz_Available . . . 803
8.835.2.9 is_PktErrRate_Available . . . 803
8.835.2.10 is_ProfileId3GPP2_Available . . . 803
8.835.2.11 is_TokenBucket_Available . . . 803
8.835.2.12 is_TrafficClass_Available . . . 803
8.835.2.13 is_val_3GPP2Pri_Available . . . 803
8.835.2.14 is_val_3GPPImCn_Available . . . 803
8.835.2.15 is_val_3GPPResResidualBER_Available . . . 803
8.835.2.16 is_val_3GPPSigInd_Available . . . 803
8.835.2.17 is_val_3GPPTraHdlPri_Available . . . 803
8.835.2.18 Jitter . . . 803
8.835.2.19 Latency . . . 804
8.835.2.20 LteQci . . . 804
8.835.2.21 MaxAllowedPktSz . . . 804
8.835.2.22 MinPolicedPktSz . . . 804
8.835.2.23 PktErrRate . . . 804
8.835.2.24 ProfileId3GPP2 . . . 804
8.835.2.25 TokenBucket . . . 804
8.835.2.26 TrafficClass . . . 804
8.835.2.27 val_3GPP2Pri . . . 804
8.835.2.28 val_3GPPImCn . . . 804
8.835.2.29 val_3GPPResResidualBER . . . 804
8.835.2.30 val_3GPPSigInd . . . 804
8.835.2.31 val_3GPPTraHdlPri . . . 804
8.836 unpack_qos_tokenBucket_t Struct Reference . . . 804
8.836.1 Detailed Description . . . 804
8.836.2 Field Documentation . . . 804
8.836.2.1 bucketSz . . . 804
8.836.2.2 peakRate . . . 804
8.836.2.3 tokenRate . . . 804
8.837 unpack_qos_Tos_t Struct Reference . . . 805
8.837.1 Detailed Description . . . 805
8.837.2 Field Documentation . . . 805
8.837.2.1 mask . . . 805
8.837.2.2 val . . . 805
8.838 unpack_QosFlowStat_t Struct Reference . . . 805
8.838.1 Detailed Description . . . 805

8.838.2 Field Documentation . . . 806
8.838.2.1 bearerId . . . 806
8.838.2.2 tx_bytes . . . 806
8.838.2.3 tx_bytes_drp . . . 806
8.838.2.4 tx_pkt . . . 806
8.838.2.5 tx_pkt_drp . . . 806
8.839 unpack_result_t Struct Reference . . . 806
8.839.1 Detailed Description . . . 806
8.839.2 Field Documentation . . . 806
8.839.2.1 ParamPresenceMask . . . 806
8.839.2.2 Tlvresult . . . 806
8.840 unpack_rms_GetSMSWake_t Struct Reference . . . 806
8.840.1 Detailed Description . . . 807
8.840.2 Field Documentation . . . 807
8.840.2.1 enabled . . . 807
8.840.2.2 ParamPresenceMask . . . 807
8.840.2.3 wake_mask . . . 807
8.841 unpack_rms_SetSMSWake_t Struct Reference . . . 807
8.841.1 Detailed Description . . . 807
8.841.2 Field Documentation . . . 807
8.841.2.1 ParamPresenceMask . . . 807
8.842 unpack_RMTransferStatistics_ind_t Struct Reference . . . 807
8.842.1 Detailed Description . . . 808
8.842.2 Field Documentation . . . 808
8.842.2.1 ParamPresenceMask . . . 808
8.842.2.2 RxDropConutTlv . . . 808
8.842.2.3 RxOkByteCountTlv . . . 808
8.842.2.4 RxOkConutTlv . . . 808
8.842.2.5 TxDropConutTlv . . . 808
8.842.2.6 TxOkByteCountTlv . . . 808
8.842.2.7 TxOkConutTlv . . . 808
8.843 unpack_sar_SLQSGetRfSarState_t Struct Reference . . . 809
8.843.1 Detailed Description . . . 809
8.843.2 Field Documentation . . . 809
8.843.2.1 ParamPresenceMask . . . 809
8.843.2.2 pSarRFState . . . 809
8.844 unpack_sms_GetSMSCAddress_t Struct Reference . . . 809
8.844.1 Detailed Description . . . 809
8.844.2 Field Documentation . . . 810
8.844.2.1 addressSize . . . 810

8.844.2.2 ParamPresenceMask . . . 810
8.844.2.3 pSMSCAddress . . . 810
8.844.2.4 pSMSCType . . . 810
8.844.2.5 typeSize . . . 810
8.845 unpack_sms_SaveSMS_t Struct Reference . . . 810
8.845.1 Detailed Description . . . 810
8.845.2 Field Documentation . . . 811
8.845.2.1 ParamPresenceMask . . . 811
8.845.2.2 pMessageIndex . . . 811
8.846 unpack_sms_SendSMS_t Struct Reference . . . 811
8.846.1 Detailed Description . . . 811
8.846.2 Field Documentation . . . 811
8.846.2.1 messageFailureCode . . . 811
8.846.2.2 messageID . . . 811
8.846.2.3 ParamPresenceMask . . . 811
8.847 unpack_sms_SetNewSMSCallback_ind_t Struct Reference . . . 811
8.847.1 Detailed Description . . . 812
8.847.2 Field Documentation . . . 812
8.847.2.1 ETWSPLMNTlv . . . 813
8.847.2.2 ETWSTlv . . . 813
8.847.2.3 IMSTlv . . . 813
8.847.2.4 MMTlv . . . 813
8.847.2.5 NewMMTlv . . . 813
8.847.2.6 ParamPresenceMask . . . 813
8.847.2.7 SMSCTlv . . . 813
8.847.2.8 TRMessageTlv . . . 813
8.848 unpack_sms_SetNewSMSCallback_t Struct Reference . . . 813
8.848.1 Detailed Description . . . 813
8.848.2 Field Documentation . . . 813
8.848.2.1 ParamPresenceMask . . . 813
8.849 unpack_sms_SetSMSCAddress_t Struct Reference . . . 813
8.849.1 Detailed Description . . . 813
8.849.2 Field Documentation . . . 814
8.849.2.1 ParamPresenceMask . . . 814
8.850 unpack_sms_SLQSDeleteSMS_t Struct Reference . . . 814
8.850.1 Detailed Description . . . 814
8.850.2 Field Documentation . . . 814
8.850.2.1 ParamPresenceMask . . . 814
8.851 unpack_sms_SLQSGetIndicationRegister_t Struct Reference . . . 814
8.851.1 Detailed Description . . . 814

8.851.2 Field Documentation . . . 815
8.851.2.1 ParamPresenceMask . . . 815
8.851.2.2 pGetIndicationRegInfo . . . 815
8.852 unpack_sms_SLQSGetMessageWaiting_t Struct Reference . . . 815
8.852.1 Detailed Description . . . 815
8.852.2 Field Documentation . . . 815
8.852.2.1 ParamPresenceMask . . . 815
8.852.2.2 pGetMsgWaitingInfoResp . . . 815
8.853 unpack_sms_SLQSGetSMS_t Struct Reference . . . 815
8.853.1 Detailed Description . . . 815
8.853.2 Field Documentation . . . 816
8.853.2.1 message . . . 816
8.853.2.2 messageFormat . . . 816
8.853.2.3 messageSize . . . 816
8.853.2.4 messageTag . . . 816
8.853.2.5 ParamPresenceMask . . . 816
8.854 unpack_sms_SLQSGetSmsBroadcastConfig_t Struct Reference . . . 816
8.854.1 Detailed Description . . . 817
8.854.2 Field Documentation . . . 817
8.854.2.1 ParamPresenceMask . . . 817
8.854.2.2 pBroadcastConfig . . . 817
8.854.2.3 pCDMABroadcastConfig . . . 817
8.855 unpack_sms_SLQSGetSMSList_t Struct Reference . . . 817
8.855.1 Detailed Description . . . 817
8.855.2 Field Documentation . . . 818
8.855.2.1 messageList . . . 818
8.855.2.2 messageListSize . . . 818
8.855.2.3 ParamPresenceMask . . . 818
8.856 unpack_sms_SLQSGetTransLayerInfo_t Struct Reference . . . 818
8.856.1 Detailed Description . . . 818
8.856.2 Field Documentation . . . 818
8.856.2.1 ParamPresenceMask . . . 818
8.856.2.2 pGetTransLayerInfo . . . 818
8.857 unpack_sms_SLQSGetTransNWRegInfo_t Struct Reference . . . 818
8.857.1 Detailed Description . . . 819
8.857.2 Field Documentation . . . 819
8.857.2.1 ParamPresenceMask . . . 819
8.857.2.2 pGetTransNWRegInfo . . . 819
8.858 unpack_sms_SLQSModifySMSStatus_t Struct Reference . . . 819
8.858.1 Detailed Description . . . 819

8.858.2 Field Documentation . . . 819
8.858.2.1 ParamPresenceMask . . . 819
8.859 unpack_sms_SLQSNWRegInfoCallback_ind_t Struct Reference . . . 819
8.859.1 Detailed Description . . . 820
8.859.2 Field Documentation . . . 820
8.859.2.1 NWRegStat . . . 820
8.859.2.2 ParamPresenceMask . . . 820
8.860 unpack_sms_SLQSSendAsyncSMS_t Struct Reference . . . 820
8.860.1 Detailed Description . . . 820
8.860.2 Field Documentation . . . 820
8.860.2.1 ParamPresenceMask . . . 820
8.861 unpack_sms_SLQSSetIndicationRegister_t Struct Reference . . . 820
8.861.1 Detailed Description . . . 821
8.861.2 Field Documentation . . . 821
8.861.2.1 ParamPresenceMask . . . 821
8.862 unpack_sms_SLQSSetSmsBroadcastActivation_t Struct Reference . . . 821
8.862.1 Detailed Description . . . 821
8.862.2 Field Documentation . . . 821
8.862.2.1 ParamPresenceMask . . . 821
8.863 unpack_sms_SLQSSetSmsBroadcastConfig_t Struct Reference . . . 821
8.863.1 Detailed Description . . . 821
8.863.2 Field Documentation . . . 822
8.863.2.1 ParamPresenceMask . . . 822
8.864 unpack_sms_SLQSSetSmsStorage_t Struct Reference . . . 822
8.864.1 Detailed Description . . . 822
8.864.2 Field Documentation . . . 822
8.864.2.1 ParamPresenceMask . . . 822
8.865 unpack_sms_SLQSSmsGetMaxStorageSize_t Struct Reference . . . 822
8.865.1 Detailed Description . . . 822
8.865.2 Field Documentation . . . 822
8.865.2.1 ParamPresenceMask . . . 823
8.865.2.2 pMaxStorageSizeResp . . . 823
8.866 unpack_sms_SLQSSmsGetMessageProtocol_t Struct Reference . . . 823
8.866.1 Detailed Description . . . 823
8.866.2 Field Documentation . . . 823
8.866.2.1 ParamPresenceMask . . . 823
8.866.2.2 pMessageProtocol . . . 823
8.867 unpack_sms_SLQSSmsSetRoutes_t Struct Reference . . . 823
8.867.1 Detailed Description . . . 823
8.867.2 Field Documentation . . . 823

8.867.2.1 ParamPresenceMask . . . 823
8.868 unpack_sms_SLQSSwiGetSMSStorage_t Struct Reference . . . 824
8.868.1 Detailed Description . . . 824
8.868.2 Field Documentation . . . 824
8.868.2.1 ParamPresenceMask . . . 824
8.868.2.2 pSmsStorage . . . 824
8.869 unpack_sms_SLQSTransLayerInfoCallback_ind_t Struct Reference . . . 824
8.869.1 Detailed Description . . . 824
8.869.2 Field Documentation . . . 825
8.869.2.1 ParamPresenceMask . . . 825
8.869.2.2 pTransLayerInfo . . . 825
8.869.2.3 regInd . . . 825
8.870 unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t Struct Reference . . . 825
8.870.1 Detailed Description . . . 825
8.870.2 Field Documentation . . . 827
8.870.2.1 alphaIDLen . . . 827
8.870.2.2 causeCode . . . 827
8.870.2.3 errorClass . . . 827
8.870.2.4 messageID . . . 827
8.870.2.5 msgDelFailureCause . . . 827
8.870.2.6 msgDelFailureType . . . 827
8.870.2.7 pAlphaID . . . 827
8.870.2.8 ParamPresenceMask . . . 827
8.870.2.9 RPCause . . . 827
8.870.2.10 sendStatus . . . 827
8.870.2.11 TPCause . . . 827
8.870.2.12 userData . . . 827
8.871 unpack_sms_SLQSWmsMemoryFullCallBack_ind_t Struct Reference . . . 827
8.871.1 Detailed Description . . . 827
8.871.2 Field Documentation . . . 828
8.871.2.1 messageMode . . . 828
8.871.2.2 ParamPresenceMask . . . 828
8.871.2.3 storageType . . . 828
8.872 unpack_sms_SLQSWmsMessageWaitingCallBack_ind_t Struct Reference . . . 828
8.872.1 Detailed Description . . . 828
8.872.2 Field Documentation . . . 828
8.872.2.1 msgWaitInfo . . . 828
8.872.2.2 numInstances . . . 828
8.872.2.3 ParamPresenceMask . . . 828
8.873 unpack_swiaudio_SLQSGetM2MAudioProfile_t Struct Reference . . . 828

8.873.1 Detailed Description . . . 829
8.873.2 Field Documentation . . . 829
8.873.2.1 CwtMute . . . 829
8.873.2.2 EarMute . . . 829
8.873.2.3 Generator . . . 829
8.873.2.4 MicMute . . . 830
8.873.2.5 ParamPresenceMask . . . 830
8.873.2.6 Profile . . . 830
8.873.2.7 Volume . . . 830
8.874 unpack_swiaudio_SLQSGetM2MAudioVolume_t Struct Reference . . . 830
8.874.1 Detailed Description . . . 830
8.874.2 Field Documentation . . . 830
8.874.2.1 Level . . . 830
8.874.2.2 ParamPresenceMask . . . 830
8.875 unpack_swiaudio_SLQSGetM2MAVMute_t Struct Reference . . . 830
8.875.1 Detailed Description . . . 830
8.875.2 Field Documentation . . . 831
8.875.2.1 CwtMute . . . 831
8.875.2.2 EarMute . . . 831
8.875.2.3 MicMute . . . 831
8.875.2.4 ParamPresenceMask . . . 831
8.876 unpack_swiaudio_SLQSGetM2MSpkrGain_t Struct Reference . . . 831
8.876.1 Detailed Description . . . 831
8.876.2 Field Documentation . . . 832
8.876.2.1 ParamPresenceMask . . . 832
8.876.2.2 Value . . . 832
8.877 unpack_swiavms_SLQSAVMSEventReportInd_t Struct Reference . . . 832
8.877.1 Detailed Description . . . 832
8.877.2 Field Documentation . . . 833
8.877.2.1 ParamPresenceMask . . . 833
8.877.2.2 pBinaryUpdateSessionInfo . . . 833
8.877.2.3 pConfig . . . 833
8.877.2.4 pConnectionRequest . . . 833
8.877.2.5 pDataSessionStatus . . . 833
8.877.2.6 pHTTPStatus . . . 833
8.877.2.7 pNotification . . . 833
8.877.2.8 pPackageID . . . 833
8.877.2.9 pRegStatus . . . 833
8.877.2.10 pSessionType . . . 833
8.877.2.11 pWAMSParaChanged . . . 833

8.877.2.12 resultcode . . . 833
8.878 unpack_swiavms_SLQSAVMSGetSettings_t Struct Reference . . . 833
8.878.1 Detailed Description . . . 834
8.878.2 Field Documentation . . . 835
8.878.2.1 AutoConnect . . . 835
8.878.2.2 AutoReboot . . . 835
8.878.2.3 FwAutoSDM . . . 835
8.878.2.4 FwPromptdownload . . . 836
8.878.2.5 FwPromptUpdate . . . 836
8.878.2.6 OMADMEnabled . . . 836
8.878.2.7 pAPNInfo . . . 836
8.878.2.8 ParamPresenceMask . . . 836
8.878.2.9 pConnectionRetryTimers . . . 836
8.878.2.10 pNotificationStore . . . 836
8.878.2.11 pPeroidsInfo . . . 836
8.878.2.12 pPollingTimer . . . 836
8.878.2.13 resultcode . . . 836
8.879 unpack_swiavms_SLQSAVMSGetSettings_v2_t Struct Reference . . . 836
8.879.1 Detailed Description . . . 836
8.879.2 Field Documentation . . . 838
8.879.2.1 AutoConnect . . . 838
8.879.2.2 FwAutoSDM . . . 838
8.879.2.3 FwPromptdownload . . . 838
8.879.2.4 FwPromptUpdate . . . 838
8.879.2.5 OMADMEnabled . . . 838
8.879.2.6 pAPNInfo . . . 838
8.879.2.7 ParamPresenceMask . . . 838
8.879.2.8 pAutoReboot . . . 838
8.879.2.9 pConnectionRetryTimers . . . 838
8.879.2.10 pNotificationStore . . . 838
8.879.2.11 pPeroidsInfo . . . 838
8.879.2.12 pPollingTimer . . . 838
8.879.2.13 resultcode . . . 838
8.880 unpack_swiavms_SLQSAVMSSendSelection_t Struct Reference . . . 838
8.880.1 Detailed Description . . . 838
8.880.2 Field Documentation . . . 839
8.880.2.1 ParamPresenceMask . . . 839
8.880.2.2 resultcode . . . 839
8.881 unpack_swiavms_SLQSAVMSSessionGetInfo_t Struct Reference . . . 839
8.881.1 Detailed Description . . . 839

8.881.2 Field Documentation . . . 839
8.881.2.1 ParamPresenceMask . . . 839
8.881.2.2 pBinaryUpdateSessionInfo . . . 839
8.881.2.3 pConfig . . . 840
8.881.2.4 pNotification . . . 840
8.881.2.5 pPackageID . . . 840
8.881.2.6 resultcode . . . 840
8.882 unpack_swiavms_SLQSAvmsSetEventReport_t Struct Reference . . . 840
8.882.1 Detailed Description . . . 840
8.882.2 Field Documentation . . . 840
8.882.2.1 ParamPresenceMask . . . 840
8.882.2.2 resultcode . . . 840
8.883 unpack_swiavms_SLQSAVMSSetSettings_t Struct Reference . . . 840
8.883.1 Detailed Description . . . 840
8.883.2 Field Documentation . . . 840
8.883.2.1 ParamPresenceMask . . . 840
8.883.2.2 resultcode . . . 841
8.884 unpack_swiavms_SLQSAVMSSetSettings_v2_t Struct Reference . . . 841
8.884.1 Detailed Description . . . 841
8.884.2 Field Documentation . . . 841
8.884.2.1 ParamPresenceMask . . . 841
8.884.2.2 resultcode . . . 841
8.885 unpack_swiavms_SLQSAVMSStartSession_t Struct Reference . . . 841
8.885.1 Detailed Description . . . 841
8.885.2 Field Documentation . . . 841
8.885.2.1 ParamPresenceMask . . . 841
8.885.2.2 resultcode . . . 842
8.885.2.3 sessionResponse . . . 842
8.886 unpack_swiavms_SLQSAVMSStopSession_t Struct Reference . . . 842
8.886.1 Detailed Description . . . 842
8.886.2 Field Documentation . . . 842
8.886.2.1 ParamPresenceMask . . . 842
8.886.2.2 resultcode . . . 842
8.887 unpack_swidms_SLQSSwiDmsGetMTU_t Struct Reference . . . 842
8.887.1 Detailed Description . . . 842
8.887.2 Field Documentation . . . 843
8.887.2.1 ParamPresenceMask . . . 843
8.887.2.2 pEhrpdMTUSize . . . 843
8.887.2.3 pHrpdMTUSize . . . 843
8.887.2.4 pMTUSize3gpp . . . 843

8.887.2.5 pUsbMTUSize . . . 843
8.888 unpack_swidms_SLQSSwiDmsGetUsbComp_t Struct Reference . . . 843
8.888.1 Detailed Description . . . 843
8.888.2 Field Documentation . . . 843
8.888.2.1 ParamPresenceMask . . . 844
8.888.2.2 pInterfaceCfg . . . 844
8.888.2.3 pSupportedBitmasks . . . 844
8.889 unpack_swidms_SLQSSwiDmsGetUsbNetNum_t Struct Reference . . . 844
8.889.1 Detailed Description . . . 844
8.889.2 Field Documentation . . . 844
8.889.2.1 ParamPresenceMask . . . 844
8.889.2.2 usbNetNum . . . 844
8.890 unpack_swidms_SLQSSwiDmsSetMTU_t Struct Reference . . . 844
8.890.1 Detailed Description . . . 844
8.890.2 Field Documentation . . . 845
8.890.2.1 ParamPresenceMask . . . 845
8.890.2.2 Tlvresult . . . 845
8.891 unpack_swidms_SLQSSwiDmsSetUsbComp_t Struct Reference . . . 845
8.891.1 Detailed Description . . . 845
8.891.2 Field Documentation . . . 845
8.891.2.1 ParamPresenceMask . . . 845
8.891.2.2 Tlvresult . . . 845
8.892 unpack_swiloc_SwiLocGetAutoStart_t Struct Reference . . . 845
8.892.1 Detailed Description . . . 845
8.892.2 Field Documentation . . . 847
8.892.2.1 fix_rate . . . 847
8.892.2.2 fix_rate_reported . . . 847
8.892.2.3 fix_type . . . 847
8.892.2.4 fix_type_reported . . . 847
8.892.2.5 function . . . 847
8.892.2.6 function_reported . . . 847
8.892.2.7 max_dist . . . 847
8.892.2.8 max_dist_reported . . . 847
8.892.2.9 max_time . . . 847
8.892.2.10 max_time_reported . . . 847
8.892.2.11 ParamPresenceMask . . . 847
8.893 unpack_swioma_SLQSOMADMAlertCallback_ind_t Struct Reference . . . 847
8.893.1 Detailed Description . . . 847
8.893.2 Field Documentation . . . 848
8.893.2.1 eventType . . . 848

8.893.2.2 ParamPresenceMask . . . 848
8.893.2.3 SessionInfoConfig . . . 848
8.893.2.4 SessionInfoFota . . . 848
8.893.2.5 SessionInfoNotification . . . 848
8.894 unpack_swioma_SLQSOMADMGetSessionInfo_t Struct Reference . . . 848
8.894.1 Detailed Description . . . 848
8.894.2 Field Documentation . . . 850
8.894.2.1 Date . . . 850
8.894.2.2 DateLength . . . 851
8.894.2.3 ParamPresenceMask . . . 851
8.894.2.4 PkgDescLength . . . 851
8.894.2.5 PkgDescription . . . 851
8.894.2.6 PkgName . . . 851
8.894.2.7 PkgNameLength . . . 851
8.894.2.8 RetryCount . . . 851
8.894.2.9 SessionState . . . 851
8.894.2.10 SessionType . . . 851
8.894.2.11 Severity . . . 851
8.894.2.12 Source . . . 851
8.894.2.13 SourceLength . . . 851
8.894.2.14 Status . . . 851
8.894.2.15 Time . . . 851
8.894.2.16 TimeLength . . . 851
8.894.2.17 UpdateCompleteStatus . . . 851
8.895 unpack_swioma_SLQSOMADMGetSettings_t Struct Reference . . . 851
8.895.1 Detailed Description . . . 851
8.895.2 Field Documentation . . . 852
8.895.2.1 Autosdm . . . 852
8.895.2.2 FOTAdownload . . . 852
8.895.2.3 FOTAUpdate . . . 852
8.895.2.4 FwAutoCheck . . . 853
8.895.2.5 OMADMEnabled . . . 853
8.895.2.6 ParamPresenceMask . . . 853
8.896 unpack_swioma_SLQSOMADMStartSession_t Struct Reference . . . 853
8.896.1 Detailed Description . . . 853
8.896.2 Field Documentation . . . 853
8.896.2.1 FwAvailability . . . 853
8.896.2.2 ParamPresenceMask . . . 853
8.897 unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t Struct Reference . . . 853
8.897.1 Detailed Description . . . 853

8.897.2 Field Documentation . . . 854
8.897.2.1 ParamPresenceMask . . . 854
8.897.2.2 Tlvresult . . . 854
8.898 unpack_tmd_SLQSTmdGetMitigationDevList_t Struct Reference . . . 854
8.898.1 Detailed Description . . . 854
8.898.2 Field Documentation . . . 854
8.898.2.1 MitigationDevList . . . 854
8.898.2.2 MitigationDevListLen . . . 855
8.898.2.3 ParamPresenceMask . . . 855
8.898.2.4 Tlvresult . . . 855
8.899 unpack_tmd_SLQSTmdGetMitigationLvl_t Struct Reference . . . 855
8.899.1 Detailed Description . . . 855
8.899.2 Field Documentation . . . 855
8.899.2.1 CurrentmitigationLvl . . . 855
8.899.2.2 ParamPresenceMask . . . 855
8.899.2.3 ReqMitigationLvl . . . 855
8.899.2.4 Tlvresult . . . 855
8.900 unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t Struct Reference . . . 855
8.900.1 Detailed Description . . . 856
8.900.2 Field Documentation . . . 856
8.900.2.1 deviceID . . . 856
8.900.2.2 deviceIdLen . . . 856
8.900.2.3 lvl . . . 856
8.900.2.4 ParamPresenceMask . . . 856
8.901 unpack_tmd_SLQSTmdRegNotMitigationLvl_t Struct Reference . . . 856
8.901.1 Detailed Description . . . 856
8.901.2 Field Documentation . . . 857
8.901.2.1 ParamPresenceMask . . . 857
8.901.2.2 Tlvresult . . . 857
8.902 unpack_uim_ChangePin_t Struct Reference . . . 857
8.902.1 Detailed Description . . . 857
8.902.2 Field Documentation . . . 857
8.902.2.1 ParamPresenceMask . . . 857
8.902.2.2 pEncryptedPIN1 . . . 857
8.902.2.3 pIndicationToken . . . 857
8.902.2.4 pRemainingRetries . . . 858
8.902.2.5 Tlvresult . . . 858
8.903 unpack_uim_GetCardStatus_t Struct Reference . . . 858
8.903.1 Detailed Description . . . 858
8.903.2 Field Documentation . . . 858

8.903.2.1 ParamPresenceMask . . . 858
8.903.2.2 pCardStatus . . . 858
8.903.2.3 pHotSwapStatus . . . 858
8.903.2.4 Tlvresult . . . 858
8.904 unpack_uim_ReadTransparent_t Struct Reference . . . 858
8.904.1 Detailed Description . . . 859
8.904.2 Field Documentation . . . 859
8.904.2.1 ParamPresenceMask . . . 859
8.904.2.2 pCardResult . . . 859
8.904.2.3 pEncryptedData . . . 859
8.904.2.4 pIndicationToken . . . 859
8.904.2.5 pReadResult . . . 859
8.904.2.6 Tlvresult . . . 859
8.905 unpack_uim_SetPinProtection_t Struct Reference . . . 859
8.905.1 Detailed Description . . . 860
8.905.2 Field Documentation . . . 860
8.905.2.1 ParamPresenceMask . . . 860
8.905.2.2 pEncryptedPIN1 . . . 860
8.905.2.3 pIndicationToken . . . 860
8.905.2.4 pRemainingRetries . . . 860
8.905.2.5 Tlvresult . . . 860
8.906 unpack_uim_SetUimSlotStatusChangeCallback_ind_t Struct Reference . . . 860
8.906.1 Detailed Description . . . 860
8.906.2 Field Documentation . . . 861
8.906.2.1 bNumberOfPhySlots . . . 861
8.906.2.2 ParamPresenceMask . . . 861
8.906.2.3 slotsstatusChange . . . 861
8.907 unpack_uim_SLQSUIMAuthenticate_t Struct Reference . . . 861
8.907.1 Detailed Description . . . 861
8.907.2 Field Documentation . . . 861
8.907.2.1 ParamPresenceMask . . . 861
8.907.2.2 pAuthenticateResult . . . 862
8.907.2.3 pCardResult . . . 862
8.907.2.4 pIndicationToken . . . 862
8.908 unpack_uim_SLQSUIMDepersonalization_t Struct Reference . . . 862
8.908.1 Detailed Description . . . 862
8.908.2 Field Documentation . . . 862
8.908.2.1 ParamPresenceMask . . . 862
8.908.2.2 pRemainingRetries . . . 862
8.909 unpack_uim_SLQSUIMEventRegister_t Struct Reference . . . 862

8.909.1 Detailed Description . . . 862
8.909.2 Field Documentation . . . 863
8.909.2.1 eventMask . . . 863
8.909.2.2 ParamPresenceMask . . . 863
8.910 unpack_uim_SLQSUIMGetConfiguration_t Struct Reference . . . 863
8.910.1 Detailed Description . . . 863
8.910.2 Field Documentation . . . 863
8.910.2.1 ParamPresenceMask . . . 864
8.910.2.2 pAutoSelection . . . 864
8.910.2.3 pHaltSubscription . . . 864
8.910.2.4 pPersonalizationStatus . . . 864
8.911 unpack_uim_SLQSUIMGetFileAttributes_t Struct Reference . . . 864
8.911.1 Detailed Description . . . 864
8.911.2 Field Documentation . . . 864
8.911.2.1 ParamPresenceMask . . . 864
8.911.2.2 pCardResult . . . 864
8.911.2.3 pFileAttributes . . . 864
8.911.2.4 pIndicationToken . . . 864
8.912 unpack_uim_SLQSUIMGetSlotsStatus_t Struct Reference . . . 864
8.912.1 Detailed Description . . . 865
8.912.2 Field Documentation . . . 865
8.912.2.1 ParamPresenceMask . . . 865
8.912.2.2 pNumberOfPhySlot . . . 865
8.912.2.3 pUimSlotsStatus . . . 865
8.913 unpack_uim_SLQSUIMRefreshCallback_Ind_t Struct Reference . . . 865
8.913.1 Detailed Description . . . 865
8.913.2 Field Documentation . . . 866
8.913.2.1 ParamPresenceMask . . . 866
8.913.2.2 refreshEvent . . . 866
8.913.2.3 TlvPresent . . . 866
8.914 unpack_uim_SLQSUIMRefreshGetLastEvent_t Struct Reference . . . 866
8.914.1 Detailed Description . . . 866
8.914.2 Field Documentation . . . 866
8.914.2.1 ParamPresenceMask . . . 866
8.914.2.2 pRefreshEvent . . . 866
8.915 unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t Struct Reference . . . 866
8.915.1 Detailed Description . . . 866
8.915.2 Field Documentation . . . 867
8.915.2.1 ParamPresenceMask . . . 867
8.915.2.2 pCardStatus . . . 867

8.916 unpack_uim_UnblockPin_t Struct Reference . . . 867
8.916.1 Detailed Description . . . 867
8.916.2 Field Documentation . . . 867
8.916.2.1 ParamPresenceMask . . . 867
8.916.2.2 pEncryptedPIN1 . . . 868
8.916.2.3 pIndicationToken . . . 868
8.916.2.4 pRemainingRetries . . . 868
8.916.2.5 Tlvresult . . . 868
8.917 unpack_uim_VerifyPin_t Struct Reference . . . 868
8.917.1 Detailed Description . . . 868
8.917.2 Field Documentation . . . 868
8.917.2.1 ParamPresenceMask . . . 868
8.917.2.2 pEncryptedPIN1 . . . 868
8.917.2.3 pIndicationToken . . . 868
8.917.2.4 pRemainingRetries . . . 868
8.917.2.5 Tlvresult . . . 868
8.918 unpack_voice_allCallStatusCallback_ind_t Struct Reference . . . 869
8.918.1 Detailed Description . . . 869
8.918.2 Field Documentation . . . 870
8.918.2.1 arrCallInfomation . . . 870
8.918.2.2 ParamPresenceMask . . . 870
8.918.2.3 pArrAlertingPattern . . . 870
8.918.2.4 pArrAlertingType . . . 870
8.918.2.5 pArrAlphaID . . . 870
8.918.2.6 pArrCalledPartyNum . . . 870
8.918.2.7 pArrCallEndReason . . . 870
8.918.2.8 pArrConnectPartyNum . . . 870
8.918.2.9 pArrDiagInfo . . . 870
8.918.2.10 pArrRedirPartyNum . . . 870
8.918.2.11 pArrRemotePartyName . . . 870
8.918.2.12 pArrRemotePartyNum . . . 870
8.918.2.13 pArrSvcOption . . . 870
8.919 unpack_voice_DTMFEventCallback_ind_t Struct Reference . . . 871
8.919.1 Detailed Description . . . 871
8.919.2 Field Documentation . . . 871
8.919.2.1 DTMFInformation . . . 871
8.919.2.2 ParamPresenceMask . . . 871
8.919.2.3 pOffLength . . . 871
8.919.2.4 pOnLength . . . 872
8.920 unpack_voice_OTASPStatusCallback_ind_t Struct Reference . . . 872

8.920.1 Detailed Description . . . 872
8.920.2 Field Documentation . . . 873
8.920.2.1 callID . . . 873
8.920.2.2 OTASPStatus . . . 873
8.920.2.3 ParamPresenceMask . . . 873
8.921 unpack_voice_SLQSOriginateUSSD_t Struct Reference . . . 873
8.921.1 Detailed Description . . . 873
8.921.2 Field Documentation . . . 875
8.921.2.1 pAlphaIDInfo . . . 875
8.921.2.2 ParamPresenceMask . . . 875
8.921.2.3 pCallId . . . 875
8.921.2.4 pCcResultType . . . 875
8.921.2.5 pCCSuppsType . . . 875
8.921.2.6 pfailureCause . . . 875
8.921.2.7 pUSSDInfo . . . 875
8.922 unpack_voice_SLQSVoiceAnswerCall_t Struct Reference . . . 875
8.922.1 Detailed Description . . . 875
8.922.2 Field Documentation . . . 876
8.922.2.1 ParamPresenceMask . . . 876
8.922.2.2 pCallId . . . 876
8.923 unpack_voice_SLQSVoiceBurstDTMF_t Struct Reference . . . 876
8.923.1 Detailed Description . . . 876
8.923.2 Field Documentation . . . 876
8.923.2.1 ParamPresenceMask . . . 876
8.923.2.2 pCallID . . . 876
8.924 unpack_voice_SLQSVoiceDialCall_t Struct Reference . . . 876
8.924.1 Detailed Description . . . 877
8.924.2 Field Documentation . . . 877
8.924.2.1 pAlphaIDInfo . . . 877
8.924.2.2 ParamPresenceMask . . . 877
8.924.2.3 pCallID . . . 877
8.924.2.4 pCCResultType . . . 877
8.924.2.5 pCCSUPSType . . . 877
8.925 unpack_voice_SLQSVoiceEndCall_t Struct Reference . . . 877
8.925.1 Detailed Description . . . 878
8.925.2 Field Documentation . . . 878
8.925.2.1 ParamPresenceMask . . . 878
8.925.2.2 pCallId . . . 878
8.926 unpack_voice_SLQSVoiceGetAllCallInfo_t Struct Reference . . . 878
8.926.1 Detailed Description . . . 878

8.926.2 Field Documentation . . . 881
8.926.2.1 ParamPresenceMask . . . 881
8.926.2.2 pArrAlertingPattern . . . 881
8.926.2.3 pArrAlertingType . . . 881
8.926.2.4 pArrAlphaID . . . 881
8.926.2.5 pArrCalledPartyNum . . . 881
8.926.2.6 pArrCallEndReason . . . 881
8.926.2.7 pArrCallInfo . . . 881
8.926.2.8 pArrConnectPartyNum . . . 881
8.926.2.9 pArrDiagInfo . . . 881
8.926.2.10 pArrRedirPartyNum . . . 881
8.926.2.11 pArrRemotePartyName . . . 881
8.926.2.12 pArrRemotePartyNum . . . 881
8.926.2.13 pArrSvcOption . . . 881
8.926.2.14 pArrUUSInfo . . . 881
8.926.2.15 pOTASPStatus . . . 881
8.926.2.16 pVoicePrivacy . . . 881
8.927 unpack_voice_SLQSVoiceGetCallBarring_t Struct Reference . . . 882
8.927.1 Detailed Description . . . 882
8.927.2 Field Documentation . . . 883
8.927.2.1 pAlphaIDInfo . . . 883
8.927.2.2 ParamPresenceMask . . . 883
8.927.2.3 pCallID . . . 883
8.927.2.4 pCCResType . . . 883
8.927.2.5 pCCSUPSType . . . 883
8.927.2.6 pFailCause . . . 883
8.927.2.7 pSvcClass . . . 883
8.928 unpack_voice_SLQSVoiceGetCallForwardingStatus_t Struct Reference . . . 883
8.928.1 Detailed Description . . . 883
8.928.2 Field Documentation . . . 884
8.928.2.1 pAlphaIDInfo . . . 884
8.928.2.2 ParamPresenceMask . . . 884
8.928.2.3 pCallID . . . 884
8.928.2.4 pCCResType . . . 884
8.928.2.5 pCCSUPSType . . . 884
8.928.2.6 pFailCause . . . 885
8.928.2.7 pGetCallFWExtInfo . . . 885
8.928.2.8 pGetCallFWInfo . . . 885
8.929 unpack_voice_SLQSVoiceGetCallInfo_t Struct Reference . . . 885
8.929.1 Detailed Description . . . 885

8.929.2 Field Documentation . . . 887
8.929.2.1 pAlertingPattern . . . 887
8.929.2.2 pAlertType . . . 887
8.929.2.3 pAlphaIDInfo . . . 887
8.929.2.4 ParamPresenceMask . . . 887
8.929.2.5 pCallInfo . . . 887
8.929.2.6 pConnectNumInfo . . . 887
8.929.2.7 pDiagInfo . . . 887
8.929.2.8 pOTASPStatus . . . 887
8.929.2.9 pRemotePartyName . . . 887
8.929.2.10 pRemotePartyNum . . . 887
8.929.2.11 pSrvOpt . . . 888
8.929.2.12 pUUSInfo . . . 888
8.929.2.13 pVoicePrivacy . . . 888
8.930 unpack_voice_SLQSVoiceGetCallWaiting_t Struct Reference . . . 888
8.930.1 Detailed Description . . . 888
8.930.2 Field Documentation . . . 889
8.930.2.1 pAlphaIDInfo . . . 889
8.930.2.2 ParamPresenceMask . . . 889
8.930.2.3 pCallID . . . 889
8.930.2.4 pCCResType . . . 889
8.930.2.5 pCCSUPSType . . . 889
8.930.2.6 pFailCause . . . 889
8.930.2.7 pSvcClass . . . 889
8.931 unpack_voice_SLQSVoiceGetCLIP_t Struct Reference . . . 889
8.931.1 Detailed Description . . . 889
8.931.2 Field Documentation . . . 890
8.931.2.1 pAlphaIDInfo . . . 890
8.931.2.2 ParamPresenceMask . . . 890
8.931.2.3 pCallID . . . 890
8.931.2.4 pCCResType . . . 890
8.931.2.5 pCCSUPSType . . . 890
8.931.2.6 pCLIPResp . . . 891
8.931.2.7 pFailCause . . . 891
8.932 unpack_voice_SLQSVoiceGetCLIR_t Struct Reference . . . 891
8.932.1 Detailed Description . . . 891
8.932.2 Field Documentation . . . 892
8.932.2.1 pAlphaIDInfo . . . 892
8.932.2.2 ParamPresenceMask . . . 892
8.932.2.3 pCallID . . . 892

8.932.2.4 pCCResType . . . 892
8.932.2.5 pCCSUPSType . . . 892
8.932.2.6 pCLIRResp . . . 892
8.932.2.7 pFailCause . . . 892
8.933 unpack_voice_SLQSVoiceGetCNAP_t Struct Reference . . . 892
8.933.1 Detailed Description . . . 892
8.933.2 Field Documentation . . . 893
8.933.2.1 pAlphaIDInfo . . . 893
8.933.2.2 ParamPresenceMask . . . 893
8.933.2.3 pCallID . . . 893
8.933.2.4 pCCResType . . . 893
8.933.2.5 pCCSUPSType . . . 893
8.933.2.6 pCNAPResp . . . 893
8.933.2.7 pFailCause . . . 893
8.934 unpack_voice_SLQSVoiceGetCOLP_t Struct Reference . . . 894
8.934.1 Detailed Description . . . 894
8.934.2 Field Documentation . . . 895
8.934.2.1 pAlphaIDInfo . . . 895
8.934.2.2 ParamPresenceMask . . . 895
8.934.2.3 pCallID . . . 895
8.934.2.4 pCCResType . . . 895
8.934.2.5 pCCSUPSType . . . 895
8.934.2.6 pCOLPResp . . . 895
8.934.2.7 pFailCause . . . 895
8.935 unpack_voice_SLQSVoiceGetCOLR_t Struct Reference . . . 895
8.935.1 Detailed Description . . . 895
8.935.2 Field Documentation . . . 896
8.935.2.1 pAlphaIDInfo . . . 896
8.935.2.2 ParamPresenceMask . . . 896
8.935.2.3 pCallID . . . 896
8.935.2.4 pCCResType . . . 896
8.935.2.5 pCCSUPSType . . . 896
8.935.2.6 pCOLRResp . . . 896
8.935.2.7 pFailCause . . . 896
8.936 unpack_voice_SLQSVoiceGetConfig_t Struct Reference . . . 896
8.936.1 Detailed Description . . . 897
8.936.2 Field Documentation . . . 898
8.936.2.1 pAirTimerCnt . . . 898
8.936.2.2 ParamPresenceMask . . . 898
8.936.2.3 pAutoAnswerStat . . . 898

8.936.2.4 pCurAMRConfig . . . 898
8.936.2.5 pCurPrefVoiceSO . . . 898
8.936.2.6 pCurrTTYMode . . . 898
8.936.2.7 pCurVoiceDomainPref . . . 898
8.936.2.8 pCurVoicePrivacyPref . . . 898
8.936.2.9 pRoamTimerCnt . . . 898
8.937 unpack_voice_SLQSVoiceManageCalls_t Struct Reference . . . 898
8.937.1 Detailed Description . . . 899
8.937.2 Field Documentation . . . 899
8.937.2.1 ParamPresenceMask . . . 899
8.937.2.2 pFailCause . . . 899
8.938 unpack_voice_SLQSVoiceSendFlash_t Struct Reference . . . 899
8.938.1 Detailed Description . . . 899
8.938.2 Field Documentation . . . 899
8.938.2.1 ParamPresenceMask . . . 899
8.938.2.2 pCallID . . . 900
8.939 unpack_voice_SLQSVoiceSetCallBarringPassword_t Struct Reference . . . 900
8.939.1 Detailed Description . . . 900
8.939.2 Field Documentation . . . 901
8.939.2.1 pAlphaIDInfo . . . 901
8.939.2.2 ParamPresenceMask . . . 901
8.939.2.3 pCallID . . . 901
8.939.2.4 pCCResType . . . 901
8.939.2.5 pCCSUPSType . . . 901
8.939.2.6 pFailCause . . . 901
8.940 unpack_voice_SLQSVoiceSetConfig_t Struct Reference . . . 901
8.940.1 Detailed Description . . . 901
8.940.2 Field Documentation . . . 902
8.940.2.1 pAirTimerStatus . . . 902
8.940.2.2 ParamPresenceMask . . . 902
8.940.2.3 pAutoAnsStatus . . . 902
8.940.2.4 pPrefVoiceSOStatus . . . 902
8.940.2.5 pRoamTimerStatus . . . 902
8.940.2.6 pTTYConfigStatus . . . 902
8.940.2.7 pVoiceDomainPrefStatus . . . 902
8.941 unpack_voice_SLQSVoiceSetSUPSService_t Struct Reference . . . 903
8.941.1 Detailed Description . . . 903
8.941.2 Field Documentation . . . 904
8.941.2.1 pAlphaIDInfo . . . 904
8.941.2.2 ParamPresenceMask . . . 904

8.941.2.3 pCallID . . . 904
8.941.2.4 pCCResultType . . . 904
8.941.2.5 pCCSUPSType . . . 904
8.941.2.6 pFailCause . . . 904
8.942 unpack_voice_SLQSVoiceStartContDTMF_t Struct Reference . . . 904
8.942.1 Detailed Description . . . 904
8.942.2 Field Documentation . . . 904
8.942.2.1 ParamPresenceMask . . . 904
8.942.2.2 pCallID . . . 904
8.943 unpack_voice_SLQSVoiceStopContDTMF_t Struct Reference . . . 904
8.943.1 Detailed Description . . . 905
8.943.2 Field Documentation . . . 905
8.943.2.1 callID . . . 905
8.943.2.2 ParamPresenceMask . . . 905
8.944 unpack_voice_SLQSVoiceSUPSCallback_ind_t Struct Reference . . . 905
8.944.1 Detailed Description . . . 905
8.944.2 Field Documentation . . . 907
8.944.2.1 pAlphaIDInfo . . . 907
8.944.2.2 ParamPresenceMask . . . 907
8.944.2.3 pCallBarPasswd . . . 907
8.944.2.4 pCallFwdInfo . . . 908
8.944.2.5 pCallFWNum . . . 908
8.944.2.6 pCallFWTimerVal . . . 908
8.944.2.7 pCallID . . . 908
8.944.2.8 pCLIPstatus . . . 908
8.944.2.9 pCLIRstatus . . . 908
8.944.2.10 pCNAPstatus . . . 908
8.944.2.11 pCOLPstatus . . . 908
8.944.2.12 pCOLRstatus . . . 908
8.944.2.13 pDataSrc . . . 908
8.944.2.14 pFailCause . . . 908
8.944.2.15 pNewPwdData . . . 908
8.944.2.16 pReason . . . 908
8.944.2.17 pSvcClass . . . 908
8.944.2.18 pUSSInfo . . . 908
8.944.2.19 SUPSInformation . . . 908
8.945 unpack_voice_SUPSNotificationCallback_ind_t Struct Reference . . . 908
8.945.1 Detailed Description . . . 908
8.945.2 Field Documentation . . . 910
8.945.2.1 callID . . . 910

8.945.2.2 notifType . . . 910
8.945.2.3 ParamPresenceMask . . . 910
8.945.2.4 pCUGIndex . . . 910
8.945.2.5 pECTNum . . . 910
8.946 unpack_voice_USSDNotificationCallback_ind_t Struct Reference . . . 910
8.946.1 Detailed Description . . . 910
8.946.2 Field Documentation . . . 910
8.946.2.1 notification_Type . . . 910
8.946.2.2 ParamPresenceMask . . . 910
8.946.2.3 USSDNotificationNetworkInfo . . . 910
8.947 unpack_voice_VoiceInfoRecCallback_ind_t Struct Reference . . . 910
8.947.1 Detailed Description . . . 911
8.947.2 Field Documentation . . . 913
8.947.2.1 callID . . . 913
8.947.2.2 ParamPresenceMask . . . 913
8.947.2.3 pCalledPartyInfo . . . 913
8.947.2.4 pCallerIDInfo . . . 913
8.947.2.5 pCallerNameInfo . . . 913
8.947.2.6 pCallingPartyInfo . . . 913
8.947.2.7 pCallWaitInd . . . 913
8.947.2.8 pCLIRCause . . . 913
8.947.2.9 pConnectNumInfo . . . 913
8.947.2.10 pDispInfo . . . 913
8.947.2.11 pExtDispInfo . . . 913
8.947.2.12 pExtDispRecInfo . . . 913
8.947.2.13 pLineCtrlInfo . . . 913
8.947.2.14 pNSSAudioCtrl . . . 913
8.947.2.15 pNSSRelease . . . 913
8.947.2.16 pRedirNumInfo . . . 913
8.947.2.17 pSignalInfo . . . 913
8.948 unpack_voice_voicePrivacyChangeCallback_ind_t Struct Reference . . . 913
8.948.1 Detailed Description . . . 913
8.948.2 Field Documentation . . . 914
8.948.2.1 callID . . . 914
8.948.2.2 ParamPresenceMask . . . 914
8.948.2.3 voicePrivacy . . . 914
8.949 unpack_wds_DHCPv4ClientLease_ind_t Struct Reference . . . 914
8.949.1 Detailed Description . . . 914
8.949.2 Field Documentation . . . 915
8.949.2.1 DHCPv4LeaseOptTlv . . . 915

8.949.2.2 DHCPv4LeaseStateTlv . . . 915
8.949.2.3 IPv4AddrTlv . . . 915
8.949.2.4 ParamPresenceMask . . . 915
8.949.2.5 ProfileIdTlv . . . 915
8.950 unpack_wds_GetAutoconnect_t Struct Reference . . . 915
8.950.1 Detailed Description . . . 915
8.950.2 Field Documentation . . . 915
8.950.2.1 ParamPresenceMask . . . 915
8.950.2.2 psetting . . . 915
8.951 unpack_wds_GetByteTotals_t Struct Reference . . . 915
8.951.1 Detailed Description . . . 915
8.951.2 Field Documentation . . . 916
8.951.2.1 ParamPresenceMask . . . 916
8.951.2.2 pRXTotalBytes . . . 916
8.951.2.3 pTXTotalBytes . . . 916
8.952 unpack_wds_GetConnectionRate_t Struct Reference . . . 916
8.952.1 Detailed Description . . . 916
8.952.2 Field Documentation . . . 917
8.952.2.1 currentChannelRXRate . . . 917
8.952.2.2 currentChannelTXRate . . . 917
8.952.2.3 maxChannelRXRate . . . 917
8.952.2.4 maxChannelTXRate . . . 917
8.952.2.5 ParamPresenceMask . . . 917
8.953 unpack_wds_GetDataBearerTechnology_t Struct Reference . . . 917
8.953.1 Detailed Description . . . 917
8.953.2 Field Documentation . . . 918
8.953.2.1 ParamPresenceMask . . . 918
8.953.2.2 pDataBearer . . . 918
8.954 unpack_wds_GetDefaultProfile_t Struct Reference . . . 918
8.954.1 Detailed Description . . . 919
8.954.2 Field Documentation . . . 920
8.954.2.1 apnname . . . 920
8.954.2.2 apnsize . . . 920
8.954.2.3 auth . . . 920
8.954.2.4 ipaddr . . . 921
8.954.2.5 ipaddrv6 . . . 921
8.954.2.6 name . . . 921
8.954.2.7 namesize . . . 921
8.954.2.8 ParamPresenceMask . . . 921
8.954.2.9 pdptype . . . 921

8.954.2.10 pridns . . . 921
8.954.2.11 pridnsv6 . . . 921
8.954.2.12 secdns . . . 921
8.954.2.13 secdnsv6 . . . 921
8.954.2.14 username . . . 921
8.954.2.15 usersize . . . 921
8.955 unpack_wds_GetDefaultProfileNum_t Struct Reference . . . 921
8.955.1 Detailed Description . . . 921
8.955.2 Field Documentation . . . 921
8.955.2.1 index . . . 921
8.955.2.2 ParamPresenceMask . . . 921
8.956 unpack_wds_GetDormancyState_t Struct Reference . . . 921
8.956.1 Detailed Description . . . 922
8.956.2 Field Documentation . . . 922
8.956.2.1 dormancyState . . . 922
8.956.2.2 ParamPresenceMask . . . 922
8.957 unpack_wds_GetLastMobileIPError_t Struct Reference . . . 922
8.957.1 Detailed Description . . . 922
8.957.2 Field Documentation . . . 922
8.957.2.1 error . . . 923
8.957.2.2 ParamPresenceMask . . . 923
8.958 unpack_wds_GetMobileIP_t Struct Reference . . . 923
8.958.1 Detailed Description . . . 923
8.958.2 Field Documentation . . . 923
8.958.2.1 mipMode . . . 923
8.958.2.2 ParamPresenceMask . . . 923
8.959 unpack_wds_GetMobileIPProfile_t Struct Reference . . . 923
8.959.1 Detailed Description . . . 924
8.959.2 Field Documentation . . . 925
8.959.2.1 AAASPI . . . 925
8.959.2.2 AAAState . . . 925
8.959.2.3 address . . . 925
8.959.2.4 enabled . . . 925
8.959.2.5 HASPI . . . 925
8.959.2.6 HAState . . . 925
8.959.2.7 NAI . . . 925
8.959.2.8 naiSize . . . 925
8.959.2.9 ParamPresenceMask . . . 925
8.959.2.10 primaryHA . . . 925
8.959.2.11 revTunneling . . . 925

8.959.2.12 secondaryHA . . . 925
8.960 unpack_wds_GetPacketStatistics_t Struct Reference . . . 925
8.960.1 Detailed Description . . . 926
8.960.2 Field Documentation . . . 927
8.960.2.1 ParamPresenceMask . . . 927
8.960.2.2 pRXDroppedCount . . . 927
8.960.2.3 pRXOkBytesCount . . . 927
8.960.2.4 pRXOKBytesLastCall . . . 927
8.960.2.5 pRXPacketErrors . . . 927
8.960.2.6 pRXPacketOverflows . . . 927
8.960.2.7 pRXPacketSuccesses . . . 927
8.960.2.8 pTXDroppedCount . . . 927
8.960.2.9 pTXOkBytesCount . . . 927
8.960.2.10 pTXOKBytesLastCall . . . 927
8.960.2.11 pTXPacketErrors . . . 927
8.960.2.12 pTXPacketOverflows . . . 927
8.960.2.13 pTXPacketSuccesses . . . 927
8.961 unpack_wds_GetPacketStatus_t Struct Reference . . . 927
8.961.1 Detailed Description . . . 928
8.961.2 Field Documentation . . . 929
8.961.2.1 ParamPresenceMask . . . 929
8.961.2.2 rXDroppedCount . . . 929
8.961.2.3 rXOkBytesCount . . . 929
8.961.2.4 rXOKBytesLastCall . . . 929
8.961.2.5 rXPacketErrors . . . 929
8.961.2.6 rXPacketOverflows . . . 929
8.961.2.7 rXPacketSuccesses . . . 929
8.961.2.8 tXDroppedCount . . . 929
8.961.2.9 tXOkBytesCount . . . 929
8.961.2.10 tXOKBytesLastCall . . . 929
8.961.2.11 tXPacketErrors . . . 929
8.961.2.12 tXPacketOverflows . . . 929
8.961.2.13 tXPacketSuccesses . . . 929
8.962 unpack_wds_GetSessionDuration_t Struct Reference . . . 929
8.962.1 Detailed Description . . . 929
8.962.2 Field Documentation . . . 930
8.962.2.1 callDuration . . . 930
8.962.2.2 ParamPresenceMask . . . 930
8.963 unpack_wds_GetSessionState_t Struct Reference . . . 930
8.963.1 Detailed Description . . . 930

8.963.2 Field Documentation . . . 930
8.963.2.1 connectionStatus . . . 930
8.963.2.2 ParamPresenceMask . . . 930
8.964 unpack_wds_RMSetTransferStatistics_t Struct Reference . . . 930
8.964.1 Detailed Description . . . 931
8.964.2 Field Documentation . . . 931
8.964.2.1 ParamPresenceMask . . . 931
8.965 unpack_wds_SetMobileIPProfile_t Struct Reference . . . 931
8.965.1 Detailed Description . . . 931
8.965.2 Field Documentation . . . 931
8.965.2.1 ParamPresenceMask . . . 931
8.966 unpack_wds_SLQSCreateProfile_t Struct Reference . . . 931
8.966.1 Detailed Description . . . 931
8.966.2 Field Documentation . . . 932
8.966.2.1 ParamPresenceMask . . . 932
8.966.2.2 pCreateProfileOut . . . 932
8.966.2.3 pProfileID . . . 932
8.966.2.4 Tlvresult . . . 932
8.967 unpack_wds_SLQSDeleteProfile_t Struct Reference . . . 932
8.967.1 Detailed Description . . . 932
8.967.2 Field Documentation . . . 932
8.967.2.1 extendedErrorCode . . . 932
8.967.2.2 ParamPresenceMask . . . 932
8.968 unpack_wds_SLQSDUNCallInfoCallBack_ind_t Struct Reference . . . 933
8.968.1 Detailed Description . . . 933
8.968.2 Field Documentation . . . 934
8.968.2.1 CRTlv . . . 934
8.968.2.2 CSTlv . . . 934
8.968.2.3 DBTTlv . . . 934
8.968.2.4 DSTlv . . . 934
8.968.2.5 LMCERTlv . . . 934
8.968.2.6 ParamPresenceMask . . . 934
8.968.2.7 RXBOTlv . . . 934
8.968.2.8 TXBOTlv . . . 934
8.969 unpack_wds_SLQSGet3GPPConfigItem_t Struct Reference . . . 934
8.969.1 Detailed Description . . . 934
8.969.2 Field Documentation . . . 935
8.969.2.1 _3gppRelease . . . 935
8.969.2.2 defaultPDNEnabled . . . 935
8.969.2.3 LTEAttachProfile . . . 936

8.969.2.4 LTEAttachProfileList . . . 936
8.969.2.5 LTEAttachProfileListLen . . . 936
8.969.2.6 ParamPresenceMask . . . 936
8.969.2.7 profileList . . . 936
8.970 unpack_wds_SLQSGetCurrDataSystemStat_t Struct Reference . . . 936
8.970.1 Detailed Description . . . 936
8.970.2 Field Documentation . . . 936
8.970.2.1 currNetworkInfo . . . 936
8.970.2.2 networkInfoLen . . . 936
8.970.2.3 ParamPresenceMask . . . 937
8.970.2.4 prefNetwork . . . 937
8.971 unpack_wds_SLQSGetCurrentChannelRate_t Struct Reference . . . 937
8.971.1 Detailed Description . . . 937
8.971.2 Field Documentation . . . 938
8.971.2.1 current_channel_rx_rate . . . 938
8.971.2.2 current_channel_tx_rate . . . 938
8.971.2.3 max_channel_rx_rate . . . 938
8.971.2.4 max_channel_tx_rate . . . 938
8.971.2.5 ParamPresenceMask . . . 938
8.972 unpack_wds_SLQSGetDataBearerTechnology_t Struct Reference . . . 938
8.972.1 Detailed Description . . . 938
8.972.2 Field Documentation . . . 938
8.972.2.1 curDataBearerTechnology . . . 938
8.972.2.2 dataBearerMask . . . 939
8.972.2.3 lastCallDataBearerTechnology . . . 939
8.972.2.4 ParamPresenceMask . . . 939
8.973 unpack_wds_SLQSGetDUNCallInfo_t Struct Reference . . . 939
8.973.1 Detailed Description . . . 939
8.973.2 Field Documentation . . . 941
8.973.2.1 callEndReason . . . 941
8.973.2.2 channelRate . . . 941
8.973.2.3 connectionStatus . . . 941
8.973.2.4 dataBearerTech . . . 941
8.973.2.5 dormancyStatus . . . 941
8.973.2.6 lastCallDataBearerTech . . . 941
8.973.2.7 lastCallRXOKBytesCnt . . . 941
8.973.2.8 lastCallTXOKBytesCnt . . . 942
8.973.2.9 mdmCallDurationActive . . . 942
8.973.2.10 ParamPresenceMask . . . 942
8.973.2.11 rxOKBytesCount . . . 942

8.973.2.12 TxOKBytesCount . . . 942
8.974 unpack_wds_SLQSGetProfileSettings_t Struct Reference . . . 942
8.974.1 Detailed Description . . . 942
8.974.2 Field Documentation . . . 942
8.974.2.1 ParamPresenceMask . . . 942
8.974.2.2 pProfileSettings . . . 942
8.974.2.3 ProfileType . . . 942
8.974.2.4 Tlvresult . . . 942
8.975 unpack_wds_SLQSGetRuntimeSettings_t Struct Reference . . . 942
8.975.1 Detailed Description . . . 943
8.975.2 Field Documentation . . . 945
8.975.2.1 APNName . . . 945
8.975.2.2 Authentication . . . 945
8.975.2.3 DomainList . . . 945
8.975.2.4 GPRSGrantedQoS . . . 945
8.975.2.5 GWAddressV4 . . . 945
8.975.2.6 IMCNflag . . . 945
8.975.2.7 IPFamilyPreference . . . 945
8.975.2.8 IPv4 . . . 945
8.975.2.9 IPV6AddrInfo . . . 945
8.975.2.10 IPV6GWAddrInfo . . . 945
8.975.2.11 Mtu . . . 945
8.975.2.12 ParamPresenceMask . . . 945
8.975.2.13 PCSCFAddrPCO . . . 945
8.975.2.14 PCSCFFQDNAddrList . . . 945
8.975.2.15 PDPType . . . 945
8.975.2.16 PrimaryDNSV4 . . . 945
8.975.2.17 PrimaryDNSV6 . . . 945
8.975.2.18 ProfileID . . . 945
8.975.2.19 ProfileName . . . 945
8.975.2.20 SecondaryDNSV4 . . . 945
8.975.2.21 SecondaryDNSV6 . . . 945
8.975.2.22 ServerAddrList . . . 945
8.975.2.23 SubnetMaskV4 . . . 945
8.975.2.24 Technology . . . 946
8.975.2.25 UMTSGrantedQoS . . . 946
8.975.2.26 Username . . . 946
8.976 unpack_wds_SLQSModifyProfile_t Struct Reference . . . 946
8.976.1 Detailed Description . . . 946
8.976.2 Field Documentation . . . 946

8.976.2.1 ParamPresenceMask . . . 946
8.976.2.2 pExtErrorCode . . . 946
8.977 unpack_wds_SLQSSetIPFamilyPreference_t Struct Reference . . . 946
8.977.1 Detailed Description . . . 946
8.977.2 Field Documentation . . . 947
8.977.2.1 ParamPresenceMask . . . 947
8.977.2.2 TlvResult . . . 947
8.978 unpack_wds_SLQSSetPacketSrvStatusCallback_t Struct Reference . . . 947
8.978.1 Detailed Description . . . 947
8.978.2 Field Documentation . . . 948
8.978.2.1 bearerID . . . 948
8.978.2.2 conn_status . . . 949
8.978.2.3 ipFamily . . . 949
8.978.2.4 ParamPresenceMask . . . 949
8.978.2.5 reconfigReqd . . . 949
8.978.2.6 sessionEndReason . . . 949
8.978.2.7 techName . . . 949
8.978.2.8 verboseSessnEndReason . . . 949
8.978.2.9 verboseSessnEndReasonType . . . 949
8.979 unpack_wds_SLQSSetWdsEventCallback_ind_t Struct Reference . . . 949
8.979.1 Detailed Description . . . 949
8.979.2 Field Documentation . . . 953
8.979.2.1 currDBTechAvail . . . 953
8.979.2.2 currNWInfo . . . 953
8.979.2.3 dataSysStatAvail . . . 953
8.979.2.4 dBTechAvail . . . 953
8.979.2.5 dBtechExtAvail . . . 954
8.979.2.6 dBTechExtRatValue . . . 954
8.979.2.7 dBTechExtSoMask . . . 954
8.979.2.8 dBTechnology . . . 954
8.979.2.9 dBtechnologyExt . . . 954
8.979.2.10 dormancyStatAvail . . . 954
8.979.2.11 dormancyStatus . . . 954
8.979.2.12 mipstatAvail . . . 954
8.979.2.13 mipStatus . . . 954
8.979.2.14 netInfoLen . . . 954
8.979.2.15 ParamPresenceMask . . . 954
8.979.2.16 prefNetwork . . . 954
8.979.2.17 ratMask . . . 954
8.979.2.18 rx_bytes . . . 954

8.979.2.19 rx_pkts . . . 954
8.979.2.20 soMask . . . 954
8.979.2.21 tx_bytes . . . 954
8.979.2.22 tx_pkts . . . 954
8.979.2.23 xferStatAvail . . . 954
8.980 unpack_wds_SLQSSGetDHCPv4ClientConfig_t Struct Reference . . . 954
8.980.1 Detailed Description . . . 954
8.980.2 Field Documentation . . . 955
8.980.2.1 ParamPresenceMask . . . 955
8.980.2.2 pHwConfig . . . 955
8.980.2.3 pRequestOptionList . . . 955
8.981 unpack_wds_SLQSSGetLoopback_t Struct Reference . . . 955
8.981.1 Detailed Description . . . 955
8.981.2 Field Documentation . . . 956
8.981.2.1 ByteLoopbackMode . . . 956
8.981.2.2 ByteLoopbackMultiplier . . . 956
8.981.2.3 ParamPresenceMask . . . 956
8.982 unpack_wds_SLQSStartDataSession_t Struct Reference . . . 956
8.982.1 Detailed Description . . . 956
8.982.2 Field Documentation . . . 956
8.982.2.1 ParamPresenceMask . . . 956
8.982.2.2 pFailureReason . . . 956
8.982.2.3 psid . . . 957
8.982.2.4 pVerboseFailReasonType . . . 957
8.982.2.5 pVerboseFailureReason . . . 957
8.983 unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t Struct Reference . . . 957
8.983.1 Detailed Description . . . 957
8.983.2 Field Documentation . . . 959
8.983.2.1 apnName . . . 959
8.983.2.2 bearerId . . . 959
8.983.2.3 contextId . . . 959
8.983.2.4 ipv4Address . . . 959
8.983.2.5 ipv4GWAddress . . . 959
8.983.2.6 ipv6Address . . . 959
8.983.2.7 ipv6GWAddress . . . 959
8.983.2.8 ParamPresenceMask . . . 959
8.983.2.9 prDNSIPv4Address . . . 959
8.983.2.10 prDNSIPv6Address . . . 959
8.983.2.11 prPCSCFIPv4Address . . . 959
8.983.2.12 prPCSCFIPv6Address . . . 959

8.983.2.13 seDNSIPv4Address . . . 959
8.983.2.14 seDNSIPv6Address . . . 959
8.983.2.15 sePCSCFIPv4Address . . . 959
8.983.2.16 sePCSCFIPv6Address . . . 959
8.984 UnPackGetProfileSettingOut Struct Reference . . . 959
8.984.1 Detailed Description . . . 959
8.984.2 Field Documentation . . . 960
8.984.2.1 curProfile . . . 960
8.984.2.2 pExtErrCode . . . 960
8.985 UnpackSwiAvmsEventReportBinaryUpdateSessionInfo Struct Reference . . . 960
8.985.1 Detailed Description . . . 960
8.985.2 Field Documentation . . . 961
8.985.2.1 bBinaryType . . . 961
8.985.2.2 bSerity . . . 961
8.985.2.3 bState . . . 961
8.985.2.4 bUserInputRequest . . . 961
8.985.2.5 szDescription . . . 961
8.985.2.6 szName . . . 961
8.985.2.7 szVersion . . . 961
8.985.2.8 TlvPresent . . . 961
8.985.2.9 ulPkgDownloadComplete . . . 962
8.985.2.10 ulPkgDownloadSize . . . 962
8.985.2.11 wDescriptionLength . . . 962
8.985.2.12 wNameLength . . . 962
8.985.2.13 wUpdateCompeteStatus . . . 962
8.985.2.14 wUserInputTimeout . . . 962
8.985.2.15 wVersionLength . . . 962
8.986 UnpackSwiAvmsEventReportConfig Struct Reference . . . 962
8.986.1 Detailed Description . . . 962
8.986.2 Field Documentation . . . 962
8.986.2.1 bState . . . 962
8.986.2.2 bUserInputRequest . . . 962
8.986.2.3 szAlertMsg . . . 963
8.986.2.4 TlvPresent . . . 963
8.986.2.5 wAlertMsgLength . . . 963
8.986.2.6 wUserInputTimeout . . . 963
8.987 UnpackSwiAvmsEventReportConnectionRequest Struct Reference . . . 963
8.987.1 Detailed Description . . . 963
8.987.2 Field Documentation . . . 963
8.987.2.1 bUserInputRequest . . . 963

8.987.2.2 TlvPresent . . . 963
8.987.2.3 wUserInputTimeout . . . 963
8.988 UnpackSwiAvmsEventReportDataSessionStatus Struct Reference . . . 963
8.988.1 Detailed Description . . . 963
8.988.2 Field Documentation . . . 964
8.988.2.1 bType . . . 964
8.988.2.2 TlvPresent . . . 964
8.988.2.3 wErrorCode . . . 964
8.989 UnpackSwiAvmsEventReportHTTPStatus Struct Reference . . . 964
8.989.1 Detailed Description . . . 964
8.989.2 Field Documentation . . . 965
8.989.2.1 TlvPresent . . . 965
8.989.2.2 wHTTPStatus . . . 966
8.990 UnpackSwiAvmsEventReportNotification Struct Reference . . . 966
8.990.1 Detailed Description . . . 966
8.990.2 Field Documentation . . . 966
8.990.2.1 bNotification . . . 967
8.990.2.2 TlvPresent . . . 967
8.990.2.3 wSessionStatus . . . 967
8.991 UnpackSwiAvmsEventReportPackageID Struct Reference . . . 967
8.991.1 Detailed Description . . . 967
8.991.2 Field Documentation . . . 967
8.991.2.1 bPackageID . . . 967
8.991.2.2 TlvPresent . . . 967
8.992 UnpackSwiAvmsEventReportRegStatus Struct Reference . . . 967
8.992.1 Detailed Description . . . 967
8.992.2 Field Documentation . . . 967
8.992.2.1 bRegStatus . . . 967
8.992.2.2 TlvPresent . . . 968
8.993 UnpackSwiAvmsEventReportSessionType Struct Reference . . . 968
8.993.1 Detailed Description . . . 968
8.993.2 Field Documentation . . . 968
8.993.2.1 bType . . . 968
8.993.2.2 TlvPresent . . . 968
8.994 UnpackSwiAvmsEventReportWAMSParamChange Struct Reference . . . 968
8.994.1 Detailed Description . . . 968
8.994.2 Field Documentation . . . 969
8.994.2.1 TlvPresent . . . 969
8.994.2.2 wWamsChangeMask . . . 969
8.995 unpackWdsProfileParam Union Reference . . . 969

8.995.1 Detailed Description . . . 969
8.995.2 Field Documentation . . . 969
8.995.2.1 SlqsProfile3GPP . . . 969
8.995.2.2 SlqsProfile3GPP2 . . . 969
8.996 voice_airTimer Struct Reference . . . 969
8.996.1 Detailed Description . . . 969
8.996.2 Field Documentation . . . 970
8.996.2.1 airTimerValue . . . 970
8.996.2.2 namID . . . 970
8.997 voice_allCallsAlphaIDInfo Struct Reference . . . 970
8.997.1 Detailed Description . . . 970
8.997.2 Field Documentation . . . 970
8.997.2.1 AlphaIDInfo . . . 970
8.997.2.2 callID . . . 970
8.998 voice_allCallsDiagInfo Struct Reference . . . 970
8.998.1 Detailed Description . . . 970
8.998.2 Field Documentation . . . 971
8.998.2.1 callID . . . 971
8.998.2.2 DiagInfo . . . 971
8.999 voice_allCallsUUSInfo Struct Reference . . . 971
8.999.1 Detailed Description . . . 971
8.999.2 Field Documentation . . . 971
8.999.2.1 callID . . . 971
8.999.2.2 uusInfo . . . 971
8.1000 voice_alphaIDInfo Struct Reference . . . 971
8.1000.1 Detailed Description . . . 971
8.1000.2 Field Documentation . . . 972
8.1000.2.1 alphaDcs . . . 972
8.1000.2.2 alphaLen . . . 972
8.1000.2.3 alphaText . . . 972
8.1001 voice_arrAlertingPattern Struct Reference . . . 972
8.1001.1 Detailed Description . . . 972
8.1001.2 Field Documentation . . . 973
8.1001.2.1 alertingPattern . . . 973
8.1001.2.2 callID . . . 973
8.1001.2.3 numInstances . . . 973
8.1002 voice_arrAlertingType Struct Reference . . . 973
8.1002.1 Detailed Description . . . 973
8.1002.2 Field Documentation . . . 974
8.1002.2.1 AlertingType . . . 974

8.1002.2.2 callID . . . 974
8.1002.2.3 numInstances . . . 974
8.1003 voice_arrAlphaID Struct Reference . . . 974
8.1003.1 Detailed Description . . . 974
8.1003.2 Field Documentation . . . 974
8.1003.2.1 allCallsAlphaIDInfoArr . . . 974
8.1003.2.2 numInstances . . . 974
8.1004 voice_arrCalledPartyNum Struct Reference . . . 974
8.1004.1 Detailed Description . . . 975
8.1004.2 Field Documentation . . . 975
8.1004.2.1 CalledPartyNum . . . 975
8.1004.2.2 numInstances . . . 975
8.1005 voice_arrCallEndReason Struct Reference . . . 975
8.1005.1 Detailed Description . . . 975
8.1005.2 Field Documentation . . . 975
8.1005.2.1 callEndReason . . . 975
8.1005.2.2 callID . . . 976
8.1005.2.3 numInstances . . . 976
8.1006 voice_arrCallInfo Struct Reference . . . 976
8.1006.1 Detailed Description . . . 976
8.1006.2 Field Documentation . . . 976
8.1006.2.1 getAllCallInfo . . . 976
8.1006.2.2 numInstances . . . 976
8.1007 voice_arrConnectPartyNum Struct Reference . . . 976
8.1007.1 Detailed Description . . . 976
8.1007.2 Field Documentation . . . 977
8.1007.2.1 ConnectedPartyNum . . . 977
8.1007.2.2 numInstances . . . 977
8.1008 voice_arrDiagInfo Struct Reference . . . 977
8.1008.1 Detailed Description . . . 977
8.1008.2 Field Documentation . . . 977
8.1008.2.1 DiagInfo . . . 977
8.1008.2.2 numInstances . . . 977
8.1009 voice_arrRedirPartyNum Struct Reference . . . 977
8.1009.1 Detailed Description . . . 977
8.1009.2 Field Documentation . . . 978
8.1009.2.1 numInstances . . . 978
8.1009.2.2 RedirPartyNum . . . 978
8.1010 voice_arrRemotePartyName Struct Reference . . . 978
8.1010.1 Detailed Description . . . 978

8.1010.2 Field Documentation . . . 978
8.1010.2.1 GetAllCallRmtPtyName . . . 978
8.1010.2.2 numInstances . . . 978
8.1011 voice_arrRemotePartyNum Struct Reference . . . 978
8.1011.1 Detailed Description . . . 978
8.1011.2 Field Documentation . . . 979
8.1011.2.1 numInstances . . . 979
8.1011.2.2 RmtPtyNum . . . 979
8.1012 voice_arrSvcOption Struct Reference . . . 979
8.1012.1 Detailed Description . . . 979
8.1012.2 Field Documentation . . . 979
8.1012.2.1 callID . . . 979
8.1012.2.2 numInstances . . . 979
8.1012.2.3 srvOption . . . 979
8.1013 voice_arrUUSInfo Struct Reference . . . 979
8.1013.1 Detailed Description . . . 980
8.1013.2 Field Documentation . . . 980
8.1013.2.1 AllCallsUUSInfo . . . 980
8.1013.2.2 numInstances . . . 980
8.1014 voice_burstDTMFInfo Struct Reference . . . 980
8.1014.1 Detailed Description . . . 980
8.1014.2 Field Documentation . . . 981
8.1014.2.1 digitCnt . . . 981
8.1014.2.2 pCallID . . . 981
8.1014.2.3 pDigitBuff . . . 981
8.1015 voice_calledPartyInfo Struct Reference . . . 981
8.1015.1 Detailed Description . . . 981
8.1015.2 Field Documentation . . . 982
8.1015.2.1 number . . . 982
8.1015.2.2 numLen . . . 982
8.1015.2.3 numPlan . . . 982
8.1015.2.4 numType . . . 982
8.1015.2.5 PI . . . 982
8.1015.2.6 SI . . . 982
8.1016 voice_calledPartySubAdd Struct Reference . . . 982
8.1016.1 Detailed Description . . . 983
8.1016.2 Field Documentation . . . 983
8.1016.2.1 extBit . . . 983
8.1016.2.2 oddEvenInd . . . 983
8.1016.2.3 subAddr . . . 983

8.1016.2.4 subAddrLen . . . 983
8.1016.2.5 subAddrType . . . 983
8.1017 voice_callerIDInfo Struct Reference . . . 983
8.1017.1 Detailed Description . . . 984
8.1017.2 Field Documentation . . . 984
8.1017.2.1 callerID . . . 984
8.1017.2.2 callerIDLen . . . 984
8.1017.2.3 PI . . . 984
8.1018 voice_callFwdTypeAndPlan Struct Reference . . . 984
8.1018.1 Detailed Description . . . 984
8.1018.2 Field Documentation . . . 985
8.1018.2.1 numberPlan . . . 985
8.1018.2.2 numberType . . . 985
8.1019 voice_callFWExtInfo Struct Reference . . . 985
8.1019.1 Detailed Description . . . 985
8.1019.2 Field Documentation . . . 986
8.1019.2.1 noReplyTimer . . . 986
8.1019.2.2 number . . . 986
8.1019.2.3 numLen . . . 987
8.1019.2.4 numPlan . . . 987
8.1019.2.5 numType . . . 987
8.1019.2.6 PI . . . 987
8.1019.2.7 SI . . . 987
8.1019.2.8 SvcClass . . . 987
8.1019.2.9 SvcStatus . . . 987
8.1020 voice_callFWInfo Struct Reference . . . 987
8.1020.1 Detailed Description . . . 987
8.1020.2 Field Documentation . . . 987
8.1020.2.1 noReplyTimer . . . 987
8.1020.2.2 number . . . 988
8.1020.2.3 numLen . . . 988
8.1020.2.4 SvcClass . . . 988
8.1020.2.5 SvcStatus . . . 988
8.1021 voice_callInfo Struct Reference . . . 988
8.1021.1 Detailed Description . . . 988
8.1021.2 Field Documentation . . . 989
8.1021.2.1 callID . . . 989
8.1021.2.2 callState . . . 989
8.1021.2.3 callType . . . 989
8.1021.2.4 direction . . . 989

8.1021.2.5 mode . . . 989
8.1022 voice_callingPartyInfo Struct Reference . . . 989
8.1022.1 Detailed Description . . . 990
8.1022.2 Field Documentation . . . 991
8.1022.2.1 number . . . 991
8.1022.2.2 numLen . . . 991
8.1022.2.3 numPlan . . . 991
8.1022.2.4 numType . . . 991
8.1022.2.5 PI . . . 991
8.1022.2.6 SI . . . 991
8.1023 voice_ccSUPSType Struct Reference . . . 991
8.1023.1 Detailed Description . . . 991
8.1023.2 Field Documentation . . . 991
8.1023.2.1 reason . . . 992
8.1023.2.2 svcType . . . 992
8.1024 voice_CLIPResp Struct Reference . . . 992
8.1024.1 Detailed Description . . . 992
8.1024.2 Field Documentation . . . 992
8.1024.2.1 ActiveStatus . . . 992
8.1024.2.2 ProvisionStatus . . . 992
8.1025 voice_CLIRResp Struct Reference . . . 992
8.1025.1 Detailed Description . . . 992
8.1025.2 Field Documentation . . . 993
8.1025.2.1 ActiveStatus . . . 993
8.1025.2.2 ProvisionStatus . . . 993
8.1026 voice_CNAPResp Struct Reference . . . 993
8.1026.1 Detailed Description . . . 993
8.1026.2 Field Documentation . . . 994
8.1026.2.1 ActiveStatus . . . 994
8.1026.2.2 ProvisionStatus . . . 994
8.1027 voice_COLPResp Struct Reference . . . 994
8.1027.1 Detailed Description . . . 994
8.1027.2 Field Documentation . . . 994
8.1027.2.1 ActiveStatus . . . 994
8.1027.2.2 ProvisionStatus . . . 994
8.1028 voice_COLRResp Struct Reference . . . 994
8.1028.1 Detailed Description . . . 994
8.1028.2 Field Documentation . . . 995
8.1028.2.1 ActiveStatus . . . 995
8.1028.2.2 ProvisionStatus . . . 995

8.1029 voice_connectNumInfo Struct Reference . . . 995
8.1029.1 Detailed Description . . . 995
8.1029.2 Field Documentation . . . 996
8.1029.2.1 callerID . . . 996
8.1029.2.2 callerIDLen . . . 996
8.1029.2.3 numPlan . . . 996
8.1029.2.4 numPresInd . . . 997
8.1029.2.5 numType . . . 997
8.1029.2.6 screeningInd . . . 997
8.1030 voice_CUGInfo Struct Reference . . . 997
8.1030.1 Detailed Description . . . 997
8.1030.2 Field Documentation . . . 997
8.1030.2.1 CUGIndex . . . 997
8.1030.2.2 SuppOA . . . 997
8.1030.2.3 SuppPrefCUG . . . 997
8.1031 voice_curAMRConfig Struct Reference . . . 997
8.1031.1 Detailed Description . . . 997
8.1031.2 Field Documentation . . . 998
8.1031.2.1 gsmAmrStat . . . 998
8.1031.2.2 wcdmaAmrStat . . . 998
8.1032 voice_diagInfo Struct Reference . . . 998
8.1032.1 Detailed Description . . . 998
8.1032.2 Field Documentation . . . 998
8.1032.2.1 diagInfoLen . . . 998
8.1032.2.2 diagnosticInfo . . . 998
8.1033 voice_DTMFInfo Struct Reference . . . 999
8.1033.1 Detailed Description . . . 999
8.1033.2 Field Documentation . . . 999
8.1033.2.1 callID . . . 999
8.1033.2.2 digitBuff . . . 999
8.1033.2.3 digitCnt . . . 999
8.1033.2.4 DTMFEvent . . . 999
8.1034 voice_DTMFLengths Struct Reference . . . 999
8.1034.1 Detailed Description . . . 1000
8.1034.2 Field Documentation . . . 1000
8.1034.2.1 DTMFInterdigitInterval . . . 1000
8.1034.2.2 DTMFPulseWidth . . . 1000
8.1035 voice_ECTNum Struct Reference . . . 1000
8.1035.1 Detailed Description . . . 1000
8.1035.2 Field Documentation . . . 1001

8.1035.2.1 ECTCallState . . . 1001
8.1035.2.2 number . . . 1001
8.1035.2.3 presentationInd . . . 1001
8.1036 voice_extDispRecInfo Struct Reference . . . 1001
8.1036.1 Detailed Description . . . 1001
8.1036.2 Field Documentation . . . 1001
8.1036.2.1 dispType . . . 1001
8.1036.2.2 extDispInfo . . . 1001
8.1036.2.3 extDispInfoLen . . . 1002
8.1037 voice_getAllCallInformation Struct Reference . . . 1002
8.1037.1 Detailed Description . . . 1002
8.1037.2 Field Documentation . . . 1002
8.1037.2.1 ALS . . . 1002
8.1037.2.2 CallInfo . . . 1002
8.1037.2.3 isEmpty . . . 1002
8.1038 voice_getAllCallRmtPtyName Struct Reference . . . 1002
8.1038.1 Detailed Description . . . 1002
8.1038.2 Field Documentation . . . 1003
8.1038.2.1 callID . . . 1003
8.1038.2.2 RemotePartyName . . . 1003
8.1039 voice_getAllCallRmtPtyNum Struct Reference . . . 1003
8.1039.1 Detailed Description . . . 1003
8.1039.2 Field Documentation . . . 1003
8.1039.2.1 callID . . . 1003
8.1039.2.2 RemotePartyNum . . . 1003
8.1040 voice_getCallFWExtInfo Struct Reference . . . 1003
8.1040.1 Detailed Description . . . 1003
8.1040.2 Field Documentation . . . 1004
8.1040.2.1 CallFWExtInfo . . . 1004
8.1040.2.2 numInstances . . . 1004
8.1041 voice_getCallFWInfo Struct Reference . . . 1004
8.1041.1 Detailed Description . . . 1004
8.1041.2 Field Documentation . . . 1004
8.1041.2.1 CallFWInfo . . . 1004
8.1041.2.2 numInstances . . . 1004
8.1042 voice_lineCtrlInfo Struct Reference . . . 1004
8.1042.1 Detailed Description . . . 1005
8.1042.2 Field Documentation . . . 1005
8.1042.2.1 polarityIncluded . . . 1005
8.1042.2.2 pwrDenialTime . . . 1005

8.1042.2.3 revPolarity . . . 1005
8.1042.2.4 toggleMode . . . 1005
8.1043 voice_newPwdData Struct Reference . . . 1005
8.1043.1 Detailed Description . . . 1005
8.1043.2 Field Documentation . . . 1006
8.1043.2.1 newPwd . . . 1006
8.1043.2.2 newPwdAgain . . . 1006
8.1044 voice_NSSAudioCtrl Struct Reference . . . 1006
8.1044.1 Detailed Description . . . 1006
8.1044.2 Field Documentation . . . 1006
8.1044.2.1 downLink . . . 1006
8.1044.2.2 upLink . . . 1006
8.1045 voice_peerNumberInfo Struct Reference . . . 1006
8.1045.1 Detailed Description . . . 1006
8.1045.2 Field Documentation . . . 1007
8.1045.2.1 callID . . . 1008
8.1045.2.2 number . . . 1008
8.1045.2.3 numLen . . . 1008
8.1045.2.4 numPI . . . 1008
8.1045.2.5 numPlan . . . 1008
8.1045.2.6 numSI . . . 1008
8.1045.2.7 numType . . . 1008
8.1046 voice_prefVoiceSO Struct Reference . . . 1008
8.1046.1 Detailed Description . . . 1008
8.1046.2 Field Documentation . . . 1010
8.1046.2.1 evrcCapability . . . 1010
8.1046.2.2 homeOrigVoiceSO . . . 1010
8.1046.2.3 homePageVoiceSO . . . 1010
8.1046.2.4 namID . . . 1010
8.1046.2.5 roamOrigVoiceSO . . . 1010
8.1047 voice_redirNumInfo Struct Reference . . . 1010
8.1047.1 Detailed Description . . . 1010
8.1047.2 Field Documentation . . . 1011
8.1047.2.1 number . . . 1011
8.1047.2.2 numLen . . . 1011
8.1047.2.3 numPlan . . . 1011
8.1047.2.4 numType . . . 1011
8.1047.2.5 PI . . . 1011
8.1047.2.6 reason . . . 1011
8.1047.2.7 SI . . . 1011

8.1048 voice_remotePartyName Struct Reference . . . 1012
8.1048.1 Detailed Description . . . 1012
8.1048.2 Field Documentation . . . 1012
8.1048.2.1 callerName . . . 1012
8.1048.2.2 codingScheme . . . 1012
8.1048.2.3 nameLen . . . 1012
8.1048.2.4 namePI . . . 1012
8.1049 voice_remotePartyNum Struct Reference . . . 1012
8.1049.1 Detailed Description . . . 1013
8.1049.2 Field Documentation . . . 1013
8.1049.2.1 numLen . . . 1013
8.1049.2.2 presentationInd . . . 1013
8.1049.2.3 remPartyNumber . . . 1013
8.1050 voice_roamTimer Struct Reference . . . 1013
8.1050.1 Detailed Description . . . 1013
8.1050.2 Field Documentation . . . 1014
8.1050.2.1 namID . . . 1014
8.1050.2.2 roamTimerValue . . . 1014
8.1051 voice_signalInfo Struct Reference . . . 1014
8.1051.1 Detailed Description . . . 1014
8.1051.2 Field Documentation . . . 1014
8.1051.2.1 alertPitch . . . 1014
8.1051.2.2 signal . . . 1014
8.1051.2.3 signalType . . . 1014
8.1052 voice_SUPSInfo Struct Reference . . . 1015
8.1052.1 Detailed Description . . . 1015
8.1052.2 Field Documentation . . . 1015
8.1052.2.1 isModByCC . . . 1015
8.1052.2.2 svcType . . . 1015
8.1053 voice_USSDNotificationNetworkInfo Struct Reference . . . 1015
8.1053.1 Detailed Description . . . 1015
8.1053.2 Field Documentation . . . 1016
8.1053.2.1 networkInfo . . . 1016
8.1053.2.2 nwPresent . . . 1016
8.1054 voice_USSInfo Struct Reference . . . 1016
8.1054.1 Detailed Description . . . 1016
8.1054.2 Field Documentation . . . 1016
8.1054.2.1 ussData . . . 1016
8.1054.2.2 ussDCS . . . 1016
8.1054.2.3 ussLen . . . 1016

8.1055 voice_UUSInfo Struct Reference . . . 1016
8.1055.1 Detailed Description . . . 1017
8.1055.2 Field Documentation . . . 1017
8.1055.2.1 UUSData . . . 1017
8.1055.2.2 UUSDatalen . . . 1017
8.1055.2.3 UUSDcs . . . 1017
8.1055.2.4 UUSType . . . 1017
8.1056 wds_channelRate Struct Reference . . . 1018
8.1056.1 Detailed Description . . . 1018
8.1056.2 Field Documentation . . . 1018
8.1056.2.1 CurrChanRxRate . . . 1018
8.1056.2.2 CurrChanTxRate . . . 1018
8.1057 wds_ChannelRateTlv Struct Reference . . . 1018
8.1057.1 Detailed Description . . . 1018
8.1057.2 Field Documentation . . . 1018
8.1057.2.1 ChannelRate . . . 1018
8.1057.2.2 TlvPresent . . . 1018
8.1058 wds_ConnStatusTlv Struct Reference . . . 1019
8.1058.1 Detailed Description . . . 1019
8.1058.2 Field Documentation . . . 1019
8.1058.2.1 MDMConnStatus . . . 1019
8.1058.2.2 TlvPresent . . . 1019
8.1059 wds_currNetworkInfo Struct Reference . . . 1019
8.1059.1 Detailed Description . . . 1019
8.1059.2 Field Documentation . . . 1020
8.1059.2.1 NetworkType . . . 1020
8.1059.2.2 RATMask . . . 1020
8.1059.2.3 SOMask . . . 1020
8.1060 wds_DataBearTechTlv Struct Reference . . . 1020
8.1060.1 Detailed Description . . . 1020
8.1060.2 Field Documentation . . . 1020
8.1060.2.1 DataBearerTech . . . 1020
8.1060.2.2 TlvPresent . . . 1021
8.1061 wds_DataULongLongTlv Struct Reference . . . 1021
8.1061.1 Detailed Description . . . 1021
8.1061.2 Field Documentation . . . 1021
8.1061.2.1 TlvPresent . . . 1021
8.1061.2.2 ullData . . . 1021
8.1062 wds_DataULongTlv Struct Reference . . . 1021
8.1062.1 Detailed Description . . . 1021

8.1062.2 Field Documentation . . . 1021
8.1062.2.1 TlvPresent . . . 1021
8.1062.2.2 ulData . . . 1021
8.1063 wds_DHCPLeaseOptTlv Struct Reference . . . 1021
8.1063.1 Detailed Description . . . 1022
8.1063.2 Field Documentation . . . 1022
8.1063.2.1 numOpt . . . 1022
8.1063.2.2 optList . . . 1022
8.1063.2.3 optListData . . . 1022
8.1063.2.4 TlvPresent . . . 1022
8.1064 wds_DHCPLeaseStateTlv Struct Reference . . . 1022
8.1064.1 Detailed Description . . . 1022
8.1064.2 Field Documentation . . . 1022
8.1064.2.1 leaseState . . . 1022
8.1064.2.2 TlvPresent . . . 1023
8.1065 wds_DHCPOpt Struct Reference . . . 1023
8.1065.1 Detailed Description . . . 1023
8.1065.2 Field Documentation . . . 1023
8.1065.2.1 optCode . . . 1023
8.1065.2.2 optValLen . . . 1023
8.1065.2.3 pOptVal . . . 1023
8.1066 wds_DHCPProfileIdTlv Struct Reference . . . 1023
8.1066.1 Detailed Description . . . 1023
8.1066.2 Field Documentation . . . 1024
8.1066.2.1 profileId . . . 1024
8.1066.2.2 profileType . . . 1024
8.1066.2.3 TlvPresent . . . 1024
8.1067 wds_DHCPv4HWConfig Struct Reference . . . 1024
8.1067.1 Detailed Description . . . 1024
8.1067.2 Field Documentation . . . 1024
8.1067.2.1 chaddr . . . 1024
8.1067.2.2 chaddrLen . . . 1024
8.1067.2.3 hwType . . . 1024
8.1068 wds_DHCPv4Option Struct Reference . . . 1024
8.1068.1 Detailed Description . . . 1025
8.1068.2 Field Documentation . . . 1025
8.1068.2.1 optCode . . . 1025
8.1068.2.2 optVal . . . 1025
8.1068.2.3 optValLen . . . 1025
8.1069 wds_DHCPv4OptionList Struct Reference . . . 1025

8.1069.1 Detailed Description . . . 1025
8.1069.2 Field Documentation . . . 1025
8.1069.2.1 numOpt . . . 1025
8.1069.2.2 pOptList . . . 1025
8.1070 wds_DHCPv4ProfileId Struct Reference . . . 1026
8.1070.1 Detailed Description . . . 1026
8.1070.2 Field Documentation . . . 1026
8.1070.2.1 profileId . . . 1026
8.1070.2.2 profileType . . . 1026
8.1071 wds_Domain Struct Reference . . . 1026
8.1071.1 Detailed Description . . . 1026
8.1071.2 Field Documentation . . . 1026
8.1071.2.1 domainLen . . . 1026
8.1071.2.2 domainName . . . 1026
8.1072 wds_DomainNameList Struct Reference . . . 1027
8.1072.1 Detailed Description . . . 1027
8.1072.2 Field Documentation . . . 1027
8.1072.2.1 domain . . . 1027
8.1072.2.2 numInstances . . . 1027
8.1073 wds_DormStatTlv Struct Reference . . . 1027
8.1073.1 Detailed Description . . . 1027
8.1073.2 Field Documentation . . . 1027
8.1073.2.1 DormancyStat . . . 1028
8.1073.2.2 TlvPresent . . . 1028
8.1074 wds_GPRSQoS Struct Reference . . . 1028
8.1074.1 Detailed Description . . . 1028
8.1074.2 Field Documentation . . . 1028
8.1074.2.1 delayClass . . . 1028
8.1074.2.2 meanThroughputClass . . . 1028
8.1074.2.3 peakThroughputClass . . . 1028
8.1074.2.4 precedenceClass . . . 1028
8.1074.2.5 reliabilityClass . . . 1028
8.1075 wds_IPv4AdTlv Struct Reference . . . 1028
8.1075.1 Detailed Description . . . 1029
8.1075.2 Field Documentation . . . 1029
8.1075.2.1 IPv4Addr . . . 1029
8.1075.2.2 TlvPresent . . . 1029
8.1076 wds_IPV6AddressInfo Struct Reference . . . 1029
8.1076.1 Detailed Description . . . 1029
8.1076.2 Field Documentation . . . 1029

8.1076.2.1 IPAddressV6 . . . 1029
8.1076.2.2 IPV6PrefixLen . . . 1029
8.1077 wds_IPV6GWAddressInfo Struct Reference . . . 1029
8.1077.1 Detailed Description . . . 1030
8.1077.2 Field Documentation . . . 1030
8.1077.2.1 gwAddressV6 . . . 1030
8.1077.2.2 gwV6PrefixLen . . . 1030
8.1078 wds_LastMdmCallEndRsnTlv Struct Reference . . . 1030
8.1078.1 Detailed Description . . . 1030
8.1078.2 Field Documentation . . . 1030
8.1078.2.1 CallEndReason . . . 1030
8.1078.2.2 TlvPresent . . . 1030
8.1079 wds_PCSCFFQDNAddress Struct Reference . . . 1031
8.1079.1 Detailed Description . . . 1031
8.1079.2 Field Documentation . . . 1031
8.1079.2.1 fqdnAddr . . . 1031
8.1079.2.2 fqdnLen . . . 1031
8.1080 wds_PCSCFFQDNAddressList Struct Reference . . . 1031
8.1080.1 Detailed Description . . . 1031
8.1080.2 Field Documentation . . . 1031
8.1080.2.1 numInstances . . . 1031
8.1080.2.2 pcsfFQDNAddress . . . 1032
8.1081 wds_PCSCFIPv4ServerAddressList Struct Reference . . . 1032
8.1081.1 Detailed Description . . . 1032
8.1081.2 Field Documentation . . . 1032
8.1081.2.1 numInstances . . . 1032
8.1081.2.2 pcscfIPv4Addr . . . 1032
8.1082 wds_ProfileIdentifier Struct Reference . . . 1032
8.1082.1 Detailed Description . . . 1032
8.1082.2 Field Documentation . . . 1033
8.1082.2.1 profileIndex . . . 1033
8.1082.2.2 profileType . . . 1033
8.1083 wds_profileInfo Union Reference . . . 1033
8.1083.1 Detailed Description . . . 1033
8.1083.2 Field Documentation . . . 1033
8.1083.2.1 SlqsProfile3GPP . . . 1033
8.1083.2.2 SlqsProfile3GPP2 . . . 1033
8.1084 wds_RXBytesOKTlv Struct Reference . . . 1033
8.1084.1 Detailed Description . . . 1033
8.1084.2 Field Documentation . . . 1033

8.1084.2.1 RxByteOKCnt . . . 1034
8.1084.2.2 TlvPresent . . . 1034
8.1085 wds_transferStatInd Struct Reference . . . 1034
8.1085.1 Detailed Description . . . 1034
8.1085.2 Field Documentation . . . 1034
8.1085.2.1 StatsMask . . . 1034
8.1085.2.2 StatsPeriod . . . 1034
8.1086 wds_TrStatInd Struct Reference . . . 1034
8.1086.1 Detailed Description . . . 1034
8.1086.2 Field Documentation . . . 1035
8.1086.2.1 statsMask . . . 1035
8.1086.2.2 statsPeriod . . . 1035
8.1087 wds_TXBytesOKTlv Struct Reference . . . 1035
8.1087.1 Detailed Description . . . 1035
8.1087.2 Field Documentation . . . 1035
8.1087.2.1 TlvPresent . . . 1035
8.1087.2.2 TxByteOKCnt . . . 1035
8.1088 wds_UMTSMinQoS Struct Reference . . . 1035
8.1088.1 Detailed Description . . . 1036
8.1088.2 Field Documentation . . . 1037
8.1088.2.1 deliveryErrSDU . . . 1037
8.1088.2.2 grntDownlinkBitrate . . . 1038
8.1088.2.3 grntUplinkBitrate . . . 1038
8.1088.2.4 maxDownlinkBitrate . . . 1038
8.1088.2.5 maxSDUSize . . . 1038
8.1088.2.6 maxUplinkBitrate . . . 1038
8.1088.2.7 qosDeliveryOrder . . . 1038
8.1088.2.8 resBerRatio . . . 1038
8.1088.2.9 sduErrorRatio . . . 1038
8.1088.2.10 trafficClass . . . 1038
8.1088.2.11 trafficPriority . . . 1038
8.1088.2.12 transferDelay . . . 1038
8.1089 wdsDhcpv4HwConfig Struct Reference . . . 1038
8.1089.1 Detailed Description . . . 1038
8.1089.2 Field Documentation . . . 1038
8.1089.2.1 chaddr . . . 1038
8.1089.2.2 chaddrLen . . . 1038
8.1089.2.3 hwType . . . 1038
8.1090 wdsDhcpv4Option Struct Reference . . . 1039
8.1090.1 Detailed Description . . . 1039

8.1090.2 Field Documentation . . . 1039
8.1090.2.1 optCode . . . 1039
8.1090.2.2 optVal . . . 1039
8.1090.2.3 optValLen . . . 1039
8.1091 wdsDhcpv4OptionList Struct Reference . . . 1039
8.1091.1 Detailed Description . . . 1039
8.1091.2 Field Documentation . . . 1039
8.1091.2.1 numOpt . . . 1040
8.1091.2.2 pOptList . . . 1040
8.1092 wdsDhcpv4ProfileId Struct Reference . . . 1040
8.1092.1 Detailed Description . . . 1040
8.1092.2 Field Documentation . . . 1040
8.1092.2.1 profileId . . . 1040
8.1092.2.2 profileType . . . 1040

9 File Documentation **1041**

9.1 apdoxypages.c File Reference . . . 1041
9.1.1 Detailed Description . . . 1041
9.2 audio.h File Reference . . . 1041
9.2.1 Function Documentation . . . 1042
9.2.1.1 pack_audio_SLQSGetAudioPathConfig . . . 1042
9.2.1.2 pack_audio_SLQSGetAudioProfile . . . 1042
9.2.1.3 pack_audio_SLQSGetAudioVolTLBConfig . . . 1043
9.2.1.4 pack_audio_SLQSSetAudioPathConfig . . . 1043
9.2.1.5 pack_audio_SLQSSetAudioProfile . . . 1044
9.2.1.6 pack_audio_SLQSSetAudioVolTLBConfig . . . 1044
9.2.1.7 unpack_audio_SLQSGetAudioPathConfig . . . 1045
9.2.1.8 unpack_audio_SLQSGetAudioProfile . . . 1045
9.2.1.9 unpack_audio_SLQSGetAudioVolTLBConfig . . . 1045
9.2.1.10 unpack_audio_SLQSSetAudioPathConfig . . . 1046
9.2.1.11 unpack_audio_SLQSSetAudioProfile . . . 1046
9.2.1.12 unpack_audio_SLQSSetAudioVolTLBConfig . . . 1046
9.3 cat.h File Reference . . . 1047
9.3.1 Macro Definition Documentation . . . 1048
9.3.1.1 CAN_COMMON_EVENT_TLV_NUMBER . . . 1048
9.3.1.2 CAT_EVENT_DATA_MAX_LENGTH . . . 1048
9.3.2 Typedef Documentation . . . 1048
9.3.2.1 unpack_cat_CATSendEnvelopeCommand_t . . . 1048
9.3.2.2 unpack_cat_CATSendTerminalResponse_t . . . 1048
9.3.3 Function Documentation . . . 1048

9.3.3.1 pack_cat_CATSendEnvelopeCommand . . . 1048
9.3.3.2 pack_cat_CATSendTerminalResponse . . . 1048
9.3.3.3 pack_cat_SetCATEventCallback . . . 1049
9.3.3.4 unpack_cat_CATSendEnvelopeCommand . . . 1049
9.3.3.5 unpack_cat_CATSendTerminalResponse . . . 1049
9.3.3.6 unpack_cat_SetCATEventCallback . . . 1050
9.3.3.7 unpack_cat_SetCatEventCallback_ind . . . 1050
9.4 common.h File Reference . . . 1050
9.4.1 Macro Definition Documentation . . . 1052
9.4.1.1 DEAULT_LOC_TIMEOUT_IN_SEC . . . 1052
9.4.1.2 MINREQBKLEN . . . 1052
9.4.1.3 MSGID_AND_LEN . . . 1052
9.4.1.4 MSGID_DONT_CARE . . . 1052
9.4.1.5 SDK_VALIDATE_INPUT_PACK_PARAM . . . 1052
9.4.1.6 SDK_VALIDATE_INPUT_PACK_PARAM_AND_FILL_XID . . . 1053
9.4.1.7 SDK_VALIDATE_INPUT_UNPACK_PARAM . . . 1053
9.4.1.8 SDU_HDR_LEN . . . 1053
9.4.1.9 SWI_INIT_UNPACK_RESULT_VALUE . . . 1053
9.4.1.10 UNUSEDPARAM . . . 1053
9.4.2 Typedef Documentation . . . 1053
9.4.2.1 logger . . . 1053
9.4.3 Enumeration Type Documentation . . . 1053
9.4.3.1 eLOG_LEVEL . . . 1053
9.4.3.2 eQMI_SVC . . . 1053
9.4.3.3 eTimeout . . . 1054
9.4.3.4 msgtype . . . 1054
9.4.4 Function Documentation . . . 1055
9.4.4.1 fill_pack_ctx . . . 1055
9.4.4.2 fill_sdu_hdr . . . 1055
9.4.4.3 get_version . . . 1055
9.4.4.4 helper_get_error_code . . . 1055
9.4.4.5 helper_get_error_reason . . . 1055
9.4.4.6 helper_get_req_str . . . 1055
9.4.4.7 helper_get_resp_ctx . . . 1055
9.4.4.8 helper_get_xid . . . 1055
9.4.4.9 helper_isBootLoader_DebugEnabled . . . 1055
9.4.4.10 helper_set_log_func . . . 1056
9.4.4.11 helper_set_log_lvl . . . 1056
9.4.4.12 liteqmi_GetVersion . . . 1056
9.4.4.13 liteqmi_helper_decode7bitAsciiEncString . . . 1056

9.4.4.14 liteqmi_log . . . 1056
9.4.4.15 unpack_result_code_only . . . 1056
9.4.5 Variable Documentation . . . 1056
9.4.5.1 glog . . . 1056
9.4.5.2 gloglvl . . . 1056
9.5 dms.h File Reference . . . 1056
9.5.1 Macro Definition Documentation . . . 1064
9.5.1.1 ACT_CODE_MAX_SIZE . . . 1064
9.5.1.2 CK_MAX_SIZE . . . 1064
9.5.1.3 DMS_IMGDETAILS_LEN . . . 1064
9.5.1.4 DMS_MAX_CUST_ID_LEN . . . 1064
9.5.1.5 DMS_MAX_CUST_VALUE_LEN . . . 1064
9.5.1.6 DMS_MAX_FWUPDATE_LOG_STR_SZ . . . 1064
9.5.1.7 DMS_MAX_FWUPDATE_REF_STR_SZ . . . 1064
9.5.1.8 DMS_MAX_RADIO_IFCS_SIZE . . . 1064
9.5.1.9 DMS_PM_FACTORY . . . 1064
9.5.1.10 DMS_PM_LOW . . . 1064
9.5.1.11 DMS_PM_OFFLINE . . . 1064
9.5.1.12 DMS_PM_ONLINE . . . 1064
9.5.1.13 DMS_PM_PERSISTENT_LOW . . . 1064
9.5.1.14 DMS_PM_RESET . . . 1064
9.5.1.15 DMS_PM_SHUT_DOWN . . . 1064
9.5.1.16 DMS_SET_REG_IND_DISABLE . . . 1064
9.5.1.17 DMS_SET_REG_IND_ENABLE . . . 1064
9.5.1.18 DMS_SET_REG_IND_NO_CHANGE . . . 1064
9.5.1.19 DMS_SET_REPORT_DISABLE . . . 1064
9.5.1.20 DMS_SET_REPORT_ENABLE . . . 1064
9.5.1.21 DMS_SLQSFWINFO_APPVERSION_SZ . . . 1065
9.5.1.22 DMS_SLQSFWINFO_BOOTVERSION_SZ . . . 1065
9.5.1.23 DMS_SLQSFWINFO_CARRIER_SZ . . . 1065
9.5.1.24 DMS_SLQSFWINFO_CUR_CARR_NAME . . . 1065
9.5.1.25 DMS_SLQSFWINFO_CUR_CARR_REV . . . 1065
9.5.1.26 DMS_SLQSFWINFO_MODELID_SZ . . . 1065
9.5.1.27 DMS_SLQSFWINFO_PACKAGEID_SZ . . . 1065
9.5.1.28 DMS_SLQSFWINFO_PRIVERSION_SZ . . . 1065
9.5.1.29 DMS_SLQSFWINFO_SKU_SZ . . . 1065
9.5.1.30 DMS_SWI_SET_IND_DISABLE . . . 1065
9.5.1.31 DMS_SWI_SET_IND_ENABLE . . . 1065
9.5.1.32 DMS_UINT8_MAX_STRING_SZ . . . 1065
9.5.1.33 DMS_VALID_FSN_LEN . . . 1065

9.5.1.34 ERI_DATA_MAX_SIZE . . . 1065
9.5.1.35 MAX_BUILD_ID_LEN . . . 1065
9.5.1.36 MEID_MAX_SIZE . . . 1065
9.5.1.37 SLQS_MAX_DYING_GASP_CFG_SMS_CONTENT_LENGTH . . . 1065
9.5.1.38 SLQS_MAX_DYING_GASP_CFG_SMS_NUMBER_LENGTH . . . 1065
9.5.1.39 SPC_SIZE . . . 1065
9.5.1.40 UNIQUE_ID_LEN . . . 1065
9.5.2 Function Documentation . . . 1065
9.5.2.1 pack_dms_ActivateAutomatic . . . 1065
9.5.2.2 pack_dms_GetActivationState . . . 1066
9.5.2.3 pack_dms_GetBandCapability . . . 1066
9.5.2.4 pack_dms_GetCrashAction . . . 1066
9.5.2.5 pack_dms_GetCustFeature . . . 1067
9.5.2.6 pack_dms_GetCustFeaturesV2 . . . 1067
9.5.2.7 pack_dms_GetDeviceCap . . . 1068
9.5.2.8 pack_dms_GetDeviceCapabilities . . . 1068
9.5.2.9 pack_dms_GetDeviceHardwareRev . . . 1068
9.5.2.10 pack_dms_GetDeviceMfr . . . 1069
9.5.2.11 pack_dms_GetDeviceSerialNumbers . . . 1069
9.5.2.12 pack_dms_GetFirmwareInfo . . . 1069
9.5.2.13 pack_dms_GetFirmwareRevision . . . 1070
9.5.2.14 pack_dms_GetFirmwareRevisions . . . 1070
9.5.2.15 pack_dms_GetFSN . . . 1070
9.5.2.16 pack_dms_GetHardwareRevision . . . 1071
9.5.2.17 pack_dms_GetIMSI . . . 1071
9.5.2.18 pack_dms_GetManufacturer . . . 1071
9.5.2.19 pack_dms_GetModelID . . . 1072
9.5.2.20 pack_dms_GetNetworkTime . . . 1072
9.5.2.21 pack_dms_GetOfflineReason . . . 1072
9.5.2.22 pack_dms_GetPower . . . 1073
9.5.2.23 pack_dms_GetPRLVersion . . . 1073
9.5.2.24 pack_dms_GetSerialNumbers . . . 1073
9.5.2.25 pack_dms_GetUSBComp . . . 1074
9.5.2.26 pack_dms_GetVoiceNumber . . . 1074
9.5.2.27 pack_dms_ResetToFactoryDefaults . . . 1075
9.5.2.28 pack_dms_SetActivationStatusCallback . . . 1075
9.5.2.29 pack_dms_SetCrashAction . . . 1075
9.5.2.30 pack_dms_SetCustFeature . . . 1076
9.5.2.31 pack_dms_SetCustFeaturesV2 . . . 1076
9.5.2.32 pack_dms_SetEventReport . . . 1076

9.5.2.33 pack_dms_SetFirmwarePreference . . . 1077
9.5.2.34 pack_dms_SetIndicationRegister . . . 1077
9.5.2.35 pack_dms_SetPower . . . 1078
9.5.2.36 pack_dms_SetUSBComp . . . 1078
9.5.2.37 pack_dms_SLQSDmsSwiGetPCInfo . . . 1078
9.5.2.38 pack_dms_SLQSDmsSwiGetResetInfo . . . 1079
9.5.2.39 pack_dms_SLQSDmsSwiGetUimSelection . . . 1079
9.5.2.40 pack_dms_SLQSDmsSwiIndicationRegister . . . 1079
9.5.2.41 pack_dms_SLQSGetBandCapability . . . 1080
9.5.2.42 pack_dms_SLQSGetERIFile . . . 1080
9.5.2.43 pack_dms_SLQSGetPowerSaveModeConfig . . . 1081
9.5.2.44 pack_dms_SLQSSetPowerSaveModeConfig . . . 1081
9.5.2.45 pack_dms_SLQSSwiClearDyingGaspStatistics . . . 1081
9.5.2.46 pack_dms_SLQSSwiGetCrashInfo . . . 1082
9.5.2.47 pack_dms_SLQSSwiGetDyingGaspCfg . . . 1082
9.5.2.48 pack_dms_SLQSSwiGetDyingGaspStatistics . . . 1082
9.5.2.49 pack_dms_SLQSSwiGetFirmwareCurr . . . 1083
9.5.2.50 pack_dms_SLQSSwiGetFwUpdateStatus . . . 1083
9.5.2.51 pack_dms_SLQSSwiGetHostDevInfo . . . 1083
9.5.2.52 pack_dms_SLQSSwiGetOSInfo . . . 1084
9.5.2.53 pack_dms_SLQSSwiGetSerialNoExt . . . 1084
9.5.2.54 pack_dms_SLQSSwiSetDyingGaspCfg . . . 1084
9.5.2.55 pack_dms_SLQSSwiSetHostDevInfo . . . 1085
9.5.2.56 pack_dms_SLQSSwiSetOSInfo . . . 1085
9.5.2.57 pack_dms_SLQSUIMGetState . . . 1085
9.5.2.58 pack_dms_SwiSetEventReport . . . 1086
9.5.2.59 pack_dms_SwiUimSelect . . . 1086
9.5.2.60 pack_dms_UIMChangePIN . . . 1087
9.5.2.61 pack_dms_UIMGetControlKeyStatus . . . 1087
9.5.2.62 pack_dms_UIMGetICCID . . . 1087
9.5.2.63 pack_dms_UIMGetPINStatus . . . 1088
9.5.2.64 pack_dms_UIMSetControlKeyProtection . . . 1088
9.5.2.65 pack_dms_UIMSetPINProtection . . . 1088
9.5.2.66 pack_dms_UIMUnblockControlKey . . . 1089
9.5.2.67 pack_dms_UIMUnblockPIN . . . 1089
9.5.2.68 pack_dms_UIMVerifyPIN . . . 1090
9.5.2.69 pack_dms_ValidateSPC . . . 1090
9.5.2.70 unpack_dms_ActivateAutomatic . . . 1090
9.5.2.71 unpack_dms_GetActivationState . . . 1091
9.5.2.72 unpack_dms_GetBandCapability . . . 1091

9.5.2.73 unpack_dms_GetCrashAction . . . 1091
9.5.2.74 unpack_dms_GetCustFeature . . . 1092
9.5.2.75 unpack_dms_GetCustFeaturesV2 . . . 1092
9.5.2.76 unpack_dms_GetDeviceCap . . . 1092
9.5.2.77 unpack_dms_GetDeviceCapabilities . . . 1093
9.5.2.78 unpack_dms_GetDeviceHardwareRev . . . 1093
9.5.2.79 unpack_dms_GetDeviceMfr . . . 1093
9.5.2.80 unpack_dms_GetDeviceSerialNumbers . . . 1094
9.5.2.81 unpack_dms_GetFirmwareInfo . . . 1094
9.5.2.82 unpack_dms_GetFirmwareRevision . . . 1094
9.5.2.83 unpack_dms_GetFirmwareRevisions . . . 1095
9.5.2.84 unpack_dms_GetFSN . . . 1095
9.5.2.85 unpack_dms_GetHardwareRevision . . . 1095
9.5.2.86 unpack_dms_GetIMSI . . . 1096
9.5.2.87 unpack_dms_GetManufacturer . . . 1096
9.5.2.88 unpack_dms_GetModelID . . . 1096
9.5.2.89 unpack_dms_GetNetworkTime . . . 1097
9.5.2.90 unpack_dms_GetOfflineReason . . . 1097
9.5.2.91 unpack_dms_GetPower . . . 1097
9.5.2.92 unpack_dms_GetPRLVersion . . . 1098
9.5.2.93 unpack_dms_GetSerialNumbers . . . 1098
9.5.2.94 unpack_dms_GetUSBComp . . . 1098
9.5.2.95 unpack_dms_GetVoiceNumber . . . 1099
9.5.2.96 unpack_dms_PSMCfgChange_ind . . . 1099
9.5.2.97 unpack_dms_ResetToFactoryDefaults . . . 1099
9.5.2.98 unpack_dms_SetActivationStatusCallback . . . 1100
9.5.2.99 unpack_dms_SetCrashAction . . . 1100
9.5.2.100 unpack_dms_SetCustFeature . . . 1100
9.5.2.101 unpack_dms_SetCustFeaturesV2 . . . 1101
9.5.2.102 unpack_dms_SetEventReport . . . 1101
9.5.2.103 unpack_dms_SetEventReport_ind . . . 1102
9.5.2.104 unpack_dms_SetFirmwarePreference . . . 1102
9.5.2.105 unpack_dms_SetIndicationRegister . . . 1102
9.5.2.106 unpack_dms_SetPower . . . 1103
9.5.2.107 unpack_dms_SetUSBComp . . . 1103
9.5.2.108 unpack_dms_SLQSDmsSwiGetPCInfo . . . 1103
9.5.2.109 unpack_dms_SLQSDmsSwiGetResetInfo . . . 1104
9.5.2.110 unpack_dms_SLQSDmsSwiGetResetInfo_Ind . . . 1104
9.5.2.111 unpack_dms_SLQSDmsSwiGetUimSelection . . . 1104
9.5.2.112 unpack_dms_SLQSDmsSwiIndicationRegister . . . 1105

9.5.2.113 unpack_dms_SLQSGetBandCapability . . . 1105
9.5.2.114 unpack_dms_SLQSGetERIFile . . . 1106
9.5.2.115 unpack_dms_SLQSGetPowerSaveModeConfig . . . 1106
9.5.2.116 unpack_dms_SLQSSetPowerSaveModeConfig . . . 1106
9.5.2.117 unpack_dms_SLQSSwiClearDyingGaspStatistics . . . 1107
9.5.2.118 unpack_dms_SLQSSwiGetCrashInfo . . . 1107
9.5.2.119 unpack_dms_SLQSSwiGetDyingGaspCfg . . . 1107
9.5.2.120 unpack_dms_SLQSSwiGetDyingGaspStatistics . . . 1108
9.5.2.121 unpack_dms_SLQSSwiGetFirmwareCurr . . . 1108
9.5.2.122 unpack_dms_SLQSSwiGetFwUpdateStatus . . . 1108
9.5.2.123 unpack_dms_SLQSSwiGetHostDevInfo . . . 1109
9.5.2.124 unpack_dms_SLQSSwiGetOSInfo . . . 1109
9.5.2.125 unpack_dms_SLQSSwiGetSerialNoExt . . . 1109
9.5.2.126 unpack_dms_SLQSSwiSetDyingGaspCfg . . . 1110
9.5.2.127 unpack_dms_SLQSSwiSetHostDevInfo . . . 1110
9.5.2.128 unpack_dms_SLQSSwiSetOSInfo . . . 1110
9.5.2.129 unpack_dms_SLQSUIMGetState . . . 1111
9.5.2.130 unpack_dms_SwiEventReportCallBack_ind . . . 1111
9.5.2.131 unpack_dms_SwiSetEventReport . . . 1111
9.5.2.132 unpack_dms_SwiUimSelect . . . 1112
9.5.2.133 unpack_dms_UIMChangePIN . . . 1112
9.5.2.134 unpack_dms_UIMGetControlKeyStatus . . . 1112
9.5.2.135 unpack_dms_UIMGetICCID . . . 1113
9.5.2.136 unpack_dms_UIMGetPINStatus . . . 1113
9.5.2.137 unpack_dms_UIMSetControlKeyProtection . . . 1113
9.5.2.138 unpack_dms_UIMSetPINProtection . . . 1114
9.5.2.139 unpack_dms_UIMUnblockControlKey . . . 1114
9.5.2.140 unpack_dms_UIMUnblockPIN . . . 1115
9.5.2.141 unpack_dms_UIMVerifyPIN . . . 1115
9.5.2.142 unpack_dms_ValidateSPC . . . 1115
9.6 fms.h File Reference . . . 1116
9.6.1 Macro Definition Documentation . . . 1117
9.6.1.1 FMS_FW_PRI_BUILD_MATCH_LEN . . . 1117
9.6.1.2 FMS_GOBI_LISTENTRIES_MAX . . . 1117
9.6.1.3 FMS_GOBI_MBN_BUILD_ID_STR_LEN . . . 1117
9.6.1.4 FMS_GOBI_MBN_IMG_ID_SIZE . . . 1117
9.6.1.5 FMS_GOBI_MBN_IMG_ID_STR_LEN . . . 1117
9.6.1.6 FMS_IMAGE_ID_BUILD_ID_LEN . . . 1117
9.6.1.7 FMS_IMAGE_ID_IMG_ID_LEN . . . 1117
9.6.1.8 FMS_IMAGE_ID_MAX_ENTRIES . . . 1117

9.6.1.9 FMS_IMAGE_ID_PRI_IMGTYPE . . . 1117
9.6.1.10 FMS_MAX_IMAGE_ID_ELEMENT . . . 1117
9.6.1.11 FMS_MAX_IMAGE_PREFERENCE_IMAGE_SIZE . . . 1117
9.6.1.12 LITE_TOTAL_IMAGE_ID_STRING_SIZE . . . 1117
9.6.2 Function Documentation . . . 1117
9.6.2.1 GetValidFwPriCombinations . . . 1117
9.6.2.2 pack_fms_GetImagesPreference . . . 1118
9.6.2.3 pack_fms_GetStoredImages . . . 1118
9.6.2.4 pack_fms_SetImagesPreference . . . 1118
9.6.2.5 unpack_fms_GetImagesPreference . . . 1118
9.6.2.6 unpack_fms_GetStoredImages . . . 1118
9.6.2.7 unpack_fms_SetImagesPreference . . . 1119
9.7 ims.h File Reference . . . 1119
9.7.1 Macro Definition Documentation . . . 1121
9.7.1.1 MAX_NAME_LEN . . . 1121
9.7.2 Typedef Documentation . . . 1121
9.7.2.1 unpack_ims_SLQSImsConfigIndicationRegister_t . . . 1121
9.7.3 Function Documentation . . . 1121
9.7.3.1 pack_ims_SLQSGetIMSSMSConfig . . . 1121
9.7.3.2 pack_ims_SLQSGetIMSUserConfig . . . 1121
9.7.3.3 pack_ims_SLQSGetIMSVoIPConfig . . . 1122
9.7.3.4 pack_ims_SLQSGetRegMgrConfig . . . 1122
9.7.3.5 pack_ims_SLQSGetSIPConfig . . . 1123
9.7.3.6 pack_ims_SLQSImsConfigIndicationRegister . . . 1123
9.7.3.7 pack_ims_SLQSSetIMSSMSConfig . . . 1124
9.7.3.8 pack_ims_SLQSSetIMSUserConfig . . . 1124
9.7.3.9 pack_ims_SLQSSetIMSVoIPConfig . . . 1125
9.7.3.10 pack_ims_SLQSSetRegMgrConfig . . . 1125
9.7.3.11 pack_ims_SLQSSetSIPConfig . . . 1126
9.7.3.12 unpack_ims_SLQSGetIMSSMSConfig . . . 1126
9.7.3.13 unpack_ims_SLQSGetIMSUserConfig . . . 1126
9.7.3.14 unpack_ims_SLQSGetIMSVoIPConfig . . . 1127
9.7.3.15 unpack_ims_SLQSGetRegMgrConfig . . . 1127
9.7.3.16 unpack_ims_SLQSGetSIPConfig . . . 1127
9.7.3.17 unpack_ims_SLQSImsConfigIndicationRegister . . . 1128
9.7.3.18 unpack_ims_SLQSRegMgrCfgCallBack_ind . . . 1128
9.7.3.19 unpack_ims_SLQSSetIMSSMSConfig . . . 1128
9.7.3.20 unpack_ims_SLQSSetIMSUserConfig . . . 1129
9.7.3.21 unpack_ims_SLQSSetIMSVoIPConfig . . . 1129
9.7.3.22 unpack_ims_SLQSSetRegMgrConfig . . . 1129

9.7.3.23 unpack_ims_SLQSSetSIPConfig . . . 1130
9.7.3.24 unpack_ims_SLQSSIPCfgCallBack_ind . . . 1130
9.7.3.25 unpack_ims_SLQSSMSCfgCallBack_ind . . . 1130
9.7.3.26 unpack_ims_SLQSUserCfgCallBack_ind . . . 1131
9.7.3.27 unpack_ims_SLQSVoIPCfgCallBack_ind . . . 1131
9.8 imsa.h File Reference . . . 1131
9.8.1 Macro Definition Documentation . . . 1133
9.8.1.1 MAX_ERROR_CODE_LEN . . . 1133
9.8.2 Typedef Documentation . . . 1133
9.8.2.1 unpack_imsa_SLQSRegisterIMSAIndication_t . . . 1133
9.8.3 Function Documentation . . . 1133
9.8.3.1 pack_imsa_SLQSGetIMSARegStatus . . . 1133
9.8.3.2 pack_imsa_SLQSGetIMSAServiceStatus . . . 1133
9.8.3.3 pack_imsa_SLQSRegisterIMSAIndication . . . 1134
9.8.3.4 unpack_imsa_SLQSGetIMSARegStatus . . . 1134
9.8.3.5 unpack_imsa_SLQSGetIMSAServiceStatus . . . 1135
9.8.3.6 unpack_imsa_SLQSImsaPdpStatusCallBack_ind . . . 1135
9.8.3.7 unpack_imsa_SLQSImsaRatStatusCallBack_ind . . . 1136
9.8.3.8 unpack_imsa_SLQSImsaRegStatusCallBack_ind . . . 1136
9.8.3.9 unpack_imsa_SLQSImsaSvcStatusCallBack_ind . . . 1136
9.8.3.10 unpack_imsa_SLQSRegisterIMSAIndication . . . 1137
9.9 lite-fw.h File Reference . . . 1137
9.9.1 Detailed Description . . . 1139
9.9.2 Macro Definition Documentation . . . 1139
9.9.2.1 FIRMWARE_INFO_STRING_SIZE . . . 1139
9.9.2.2 IMG_MASK_CLEAR . . . 1139
9.9.2.3 IMG_MASK_GENERIC . . . 1139
9.9.2.4 IMG_MASK_MDM . . . 1139
9.9.2.5 IMG_MASK_PRI . . . 1139
9.9.2.6 libSDP_BuildImagesPreferenceRequest . . . 1139
9.9.2.7 libSDP_CalculateImageMask . . . 1139
9.9.2.8 LIBSDP_CARRIER_PACKAGE_SKU . . . 1139
9.9.2.9 libSDP_CheckValidFirmwareInfo . . . 1139
9.9.2.10 libSDP_DownloadFW . . . 1139
9.9.2.11 libSDP_ExtractFirmwareParametersByPath . . . 1139
9.9.2.12 libSDP_getFileType . . . 1139
9.9.2.13 libSDP_GetModelFamily . . . 1140
9.9.2.14 libSDP_GetVersion . . . 1140
9.9.2.15 libsdp_set_log_func . . . 1140
9.9.2.16 libsdp_SetReadBlockSize . . . 1140

9.9.2.17 LIBSDP_SKU_STRING_LENGTH . . . 1140
9.9.2.18 LITEFW_CARRIER_PACKAGE_SKU . . . 1140
9.9.2.19 LITEFW_SKU_STRING_LENGTH . . . 1140
9.9.2.20 NULL_TERMINATOR_CHAR_SIZE . . . 1140
9.9.3 Typedef Documentation . . . 1140
9.9.3.1 libSDP_FirmwareInfo . . . 1140
9.9.3.2 libsdplogger . . . 1140
9.9.3.3 litefw_FirmwareInfo . . . 1140
9.9.3.4 litefwlogger . . . 1140
9.9.4 Enumeration Type Documentation . . . 1141
9.9.4.1 litefw_Fw_Type . . . 1141
9.9.4.2 litefw_fwdwl_error_codes . . . 1141
9.9.4.3 litefw_Models . . . 1142
9.9.4.4 litefw_QDL_FLOW_CONTROLs . . . 1142
9.9.4.5 litefw_QDL_MODEs . . . 1142
9.9.5 Function Documentation . . . 1142
9.9.5.1 litefw_BuildImagesPreferenceRequest . . . 1142
9.9.5.2 litefw_CalculateImageMask . . . 1143
9.9.5.3 litefw_CheckValidFirmwareInfo . . . 1143
9.9.5.4 litefw_DownloadFW . . . 1143
9.9.5.5 litefw_ExtractFirmwareParametersByPath . . . 1144
9.9.5.6 litefw_getFileType . . . 1144
9.9.5.7 litefw_GetModelFamily . . . 1144
9.9.5.8 litefw_GetQTLDownloadMode . . . 1145
9.9.5.9 litefw_GetQTLHWFlowControl . . . 1145
9.9.5.10 litefw_GetVersion . . . 1145
9.9.5.11 litefw_logsenable . . . 1145
9.9.5.12 litefw_set_log_func . . . 1145
9.9.5.13 litefw_SetQTLDownloadMode . . . 1146
9.9.5.14 litefw_SetQTLHWFlowControl . . . 1146
9.9.5.15 litefw_SetReadBlockSize . . . 1146
9.9.5.16 litefw_switch_9x07_to_downloadmode . . . 1146
9.9.5.17 litefw_switch_to_BootHoldMode . . . 1147
9.10 loc.h File Reference . . . 1147
9.10.1 Macro Definition Documentation . . . 1151
9.10.1.1 LOC_UINT8_MAX_STRING_SZ . . . 1151
9.10.1.2 LOCEVENTMASKBATCHFULLNOTIFICATION . . . 1151
9.10.1.3 LOCEVENTMASKENGINESTATE . . . 1151
9.10.1.4 LOCEVENTMASKFIXSESSIONSTATE . . . 1151
9.10.1.5 LOCEVENTMASKGEOFENCEBATCHBREACHNOTIFICATION . . . 1151

9.10.1.6 LOCEVENTMASKGEOFENCEBREACHNOTIFICATION . . . 1151
9.10.1.7 LOCEVENTMASKGEOFENCEGENALERT . . . 1151
9.10.1.8 LOCEVENTMASKGNSSMEASUREMENTREPORT . . . 1151
9.10.1.9 LOCEVENTMASKGNSSSVINFO . . . 1151
9.10.1.10 LOCEVENTMASKINJECTPOSITIONREQ . . . 1151
9.10.1.11 LOCEVENTMASKINJECTPREDICTEDORBITSREQ . . . 1151
9.10.1.12 LOCEVENTMASKINJECTTIMEREQ . . . 1152
9.10.1.13 LOCEVENTMASKINJECTWIFIAPDATAREQ . . . 1152
9.10.1.14 LOCEVENTMASKINVALIDVALUE . . . 1152
9.10.1.15 LOCEVENTMASKLIVEBATCHEDPOSITIONREPORT . . . 1152
9.10.1.16 LOCEVENTMASKLOCATIONSERVERCONNECTIONREQ . . . 1152
9.10.1.17 LOCEVENTMASKMOTIONDATACONTROL . . . 1152
9.10.1.18 LOCEVENTMASKNIGEOFENCENOTIFICATION . . . 1152
9.10.1.19 LOCEVENTMASKNINOTIFYVERIFYREQ . . . 1152
9.10.1.20 LOCEVENTMASKNMEA . . . 1152
9.10.1.21 LOCEVENTMASKPEDOMETERCONTROL . . . 1152
9.10.1.22 LOCEVENTMASKPOSITIONREPORT . . . 1152
9.10.1.23 LOCEVENTMASKSENSORSTREAMINGREADYSTATUS . . . 1153
9.10.1.24 LOCEVENTMASKSETSPISTREAMINGREPORT . . . 1153
9.10.1.25 LOCEVENTMASKTIMESYNCREQ . . . 1153
9.10.1.26 LOCEVENTMASKVEHICLEDATAREADYSTATUS . . . 1153
9.10.1.27 LOCEVENTMASKWIFIREQ . . . 1153
9.10.1.28 MAX_LOC_NMEA_STR_LEN . . . 1153
9.10.1.29 MAX_SENSOR_DATA_LEN . . . 1153
9.10.1.30 MAX_TEMP_DATA_LEN . . . 1153
9.10.2 Typedef Documentation . . . 1153
9.10.2.1 unpack_loc_SLQSLOCGetServer_t . . . 1153
9.10.2.2 unpack_loc_SLQSLOCInjectPosition_t . . . 1153
9.10.2.3 unpack_loc_SLQSLOCInjectSensorData_t . . . 1153
9.10.2.4 unpack_loc_SLQSLOCInjectUTCTime_t . . . 1153
9.10.2.5 unpack_loc_SLQSLOCSetCradleMountConfig_t . . . 1153
9.10.3 Enumeration Type Documentation . . . 1153
9.10.3.1 anonymous enum . . . 1153
9.10.4 Function Documentation . . . 1154
9.10.4.1 pack_loc_DeleteAssistData . . . 1154
9.10.4.2 pack_loc_EventRegister . . . 1154
9.10.4.3 pack_loc_SetExtPowerState . . . 1154
9.10.4.4 pack_loc_SetOperationMode . . . 1155
9.10.4.5 pack_loc_SLQSLOCGetBestAvailPos . . . 1155
9.10.4.6 pack_loc_SLQSLOCGetServer . . . 1155

9.10.4.7 pack_loc_SLQSLOCInjectPosition . . . 1156
9.10.4.8 pack_loc_SLQSLOCInjectSensorData . . . 1156
9.10.4.9 pack_loc_SLQSLOCInjectUTCTime . . . 1157
9.10.4.10 pack_loc_SLQSLOCSetCradleMountConfig . . . 1157
9.10.4.11 pack_loc_SLQSLOCSetServer . . . 1157
9.10.4.12 pack_loc_Start . . . 1158
9.10.4.13 pack_loc_Stop . . . 1158
9.10.4.14 unpack_loc_BestAvailPos_Ind . . . 1159
9.10.4.15 unpack_loc_CradleMountCallback_Ind . . . 1159
9.10.4.16 unpack_loc_DeleteAssistData . . . 1159
9.10.4.17 unpack_loc_DeleteAssistData_Ind . . . 1160
9.10.4.18 unpack_loc_EngineState_Ind . . . 1160
9.10.4.19 unpack_loc_EventNMEA_Ind . . . 1160
9.10.4.20 unpack_loc_EventRegister . . . 1161
9.10.4.21 unpack_loc_EventTimeSyncCallback_Ind . . . 1161
9.10.4.22 unpack_loc_GetServer_Ind . . . 1161
9.10.4.23 unpack_loc_GnssSvInfo_Ind . . . 1162
9.10.4.24 unpack_loc_InjectPositionCallback_Ind . . . 1162
9.10.4.25 unpack_loc_InjectSensorDataCallback_Ind . . . 1162
9.10.4.26 unpack_loc_InjectTimeSyncDataCallback_Ind . . . 1163
9.10.4.27 unpack_loc_InjectUTCTimeCallback_Ind . . . 1163
9.10.4.28 unpack_loc_PositionRpt_Ind . . . 1163
9.10.4.29 unpack_loc_SensorStreamingCallback_Ind . . . 1164
9.10.4.30 unpack_loc_SetExtPowerConfig_Ind . . . 1164
9.10.4.31 unpack_loc_SetExtPowerState . . . 1164
9.10.4.32 unpack_loc_SetOperationMode . . . 1165
9.10.4.33 unpack_loc_SetOperationMode_Ind . . . 1165
9.10.4.34 unpack_loc_SetServer_Ind . . . 1165
9.10.4.35 unpack_loc_SLQSLOCGetBestAvailPos . . . 1166
9.10.4.36 unpack_loc_SLQSLOCGetServer . . . 1166
9.10.4.37 unpack_loc_SLQSLOCInjectPosition . . . 1166
9.10.4.38 unpack_loc_SLQSLOCInjectSensorData . . . 1167
9.10.4.39 unpack_loc_SLQSLOCInjectUTCTime . . . 1167
9.10.4.40 unpack_loc_SLQSLOCSetCradleMountConfig . . . 1167
9.10.4.41 unpack_loc_SLQSLOCSetServer . . . 1168
9.10.4.42 unpack_loc_Start . . . 1168
9.10.4.43 unpack_loc_Stop . . . 1168
9.11 nas.h File Reference . . . 1169
9.11.1 Macro Definition Documentation . . . 1179
9.11.1.1 NAS_IMSI_M_S1_LENGTH . . . 1179

9.11.1.2 NAS_IMSI_M_S2_LENGTH . . . 1179
9.11.1.3 NAS_MAX_DESCRIPTION_LENGTH . . . 1179
9.11.1.4 NAS_MAX_NUM_NETWORKS . . . 1179
9.11.1.5 NAS_MAX_SCC_RX_INFO_INSTANCES . . . 1179
9.11.1.6 NAS_MAX_SLQS_NAS_PCI_INFO_LENGTH . . . 1179
9.11.1.7 NAS_MAX_SLQS_NAS_PCI_INFO_PLMN_LENGTH . . . 1179
9.11.1.8 NAS_MCC_MNC_INST_LENGTH . . . 1179
9.11.1.9 NAS_NAM_NAME_LENGTH . . . 1179
9.11.1.10 NAS_OTA_MESSAGE_MAX_BUF_SIZE . . . 1179
9.11.1.11 NAS_PLMN_LENGTH . . . 1180
9.11.1.12 NAS_SERVING_SYSTEM_INFO_MAX_RADIO_INTERFACE_LIST . . . 1180
9.11.2 Typedef Documentation . . . 1180
9.11.2.1 nas_LTEBandPrefExtTlv . . . 1180
9.11.2.2 nas_NR5gBandPrefTlv . . . 1180
9.11.2.3 unpack_nas_InitiateDomainAttach_t . . . 1180
9.11.2.4 unpack_nas_SetACCOLC_t . . . 1180
9.11.2.5 unpack_nas_SetCDMANetworkParameters_t . . . 1180
9.11.2.6 unpack_nas_SetLURejectCallback_t . . . 1180
9.11.2.7 unpack_nas_SetRFInfoCallback_t . . . 1180
9.11.2.8 unpack_nas_SLQSConfigSigInfo_t . . . 1180
9.11.2.9 unpack_nas_SLQSInitiateNetworkRegistration_t . . . 1180
9.11.2.10 unpack_nas_SLQSNasConfigSigInfo2_t . . . 1180
9.11.2.11 unpack_nas_SLQSNasIndicationRegisterExt_t . . . 1180
9.11.2.12 unpack_nas_SLQSNASSeteDRXParams_t . . . 1180
9.11.2.13 unpack_nas_SLQSNasSwiIndicationRegister_t . . . 1180
9.11.2.14 unpack_nas_SLQSNASSwiSetChannelLock_t . . . 1180
9.11.2.15 unpack_nas_SLQSSetBandPreference_t . . . 1180
9.11.2.16 unpack_nas_SLQSSetSignalStrengthsCallback_t . . . 1180
9.11.2.17 unpack_nas_SLQSSetSysSelectionPref_t . . . 1180
9.11.2.18 unpack_nas_SLQSSetSysSelectionPrefExt_t . . . 1180
9.11.2.19 unpack_nas_SLQSSwiPSDetach_t . . . 1180
9.11.3 Enumeration Type Documentation . . . 1180
9.11.3.1 LITE_TYPE_OF_SERVICE_DOMAIN . . . 1181
9.11.3.2 LITEQMI_NAS_LTE_CPHY_CA_BW_NRB . . . 1181
9.11.3.3 LITEQMI_NAS_LTE_CPHY_SCELL_STATE . . . 1181
9.11.3.4 NAS_LTE_CPHY_CA_BW_NRB_LITE . . . 1181
9.11.3.5 NAS_LTE_CPHY_SCELL_STATE_LITE . . . 1181
9.11.4 Function Documentation . . . 1182
9.11.4.1 pack_nas_GetACCOLC . . . 1182
9.11.4.2 pack_nas_GetANAAAAuthenticationStatus . . . 1182

9.11.4.3 pack_nas_GetCDMANetworkParameters . . . 1182
9.11.4.4 pack_nas_GetHomeNetwork . . . 1183
9.11.4.5 pack_nas_GetHomeNetwork3GPP2 . . . 1183
9.11.4.6 pack_nas_GetNetworkPreference . . . 1183
9.11.4.7 pack_nas_GetRFInfo . . . 1183
9.11.4.8 pack_nas_GetServingNetwork . . . 1184
9.11.4.9 pack_nas_GetServingNetworkCapabilities . . . 1184
9.11.4.10 pack_nas_GetSignalStrengths . . . 1184
9.11.4.11 pack_nas_InitiateDomainAttach . . . 1185
9.11.4.12 pack_nas_PerformNetworkScan . . . 1185
9.11.4.13 pack_nas_PerformNetworkScanPCI . . . 1185
9.11.4.14 pack_nas_SetACCOLC . . . 1186
9.11.4.15 pack_nas_SetCDMANetworkParameters . . . 1186
9.11.4.16 pack_nas_SetLURejectCallback . . . 1187
9.11.4.17 pack_nas_SetNetworkPreference . . . 1187
9.11.4.18 pack_nas_SetRFInfoCallback . . . 1187
9.11.4.19 pack_nas_SLQSConfigSigInfo . . . 1188
9.11.4.20 pack_nas_SLQSGetErrorRate . . . 1188
9.11.4.21 pack_nas_SlqsGetLTECphyCAInfo . . . 1188
9.11.4.22 pack_nas_SLQSGetNetworkTime . . . 1188
9.11.4.23 pack_nas_SLQSGetOperatorNameData . . . 1189
9.11.4.24 pack_nas_SLQSGetPLMNName . . . 1189
9.11.4.25 pack_nas_SLQSGetServingSystem . . . 1189
9.11.4.26 pack_nas_SLQSGetSignalStrength . . . 1190
9.11.4.27 pack_nas_SLQSGetSysInfo . . . 1190
9.11.4.28 pack_nas_SLQSGetSysSelectionPref . . . 1191
9.11.4.29 pack_nas_SLQSGetSysSelectionPrefExt . . . 1191
9.11.4.30 pack_nas_SLQSInitiateNetworkRegistration . . . 1191
9.11.4.31 pack_nas_SLQSNasConfigSigInfo2 . . . 1192
9.11.4.32 pack_nas_SLQSNasGet3GPP2Subscription . . . 1192
9.11.4.33 pack_nas_SLQSNasGetCellLocationInfo . . . 1192
9.11.4.34 pack_nas_SLQSNASGeteDRXParams . . . 1193
9.11.4.35 pack_nas_SLQSNASGeteDRXParamsExt . . . 1193
9.11.4.36 pack_nas_SLQSNASGetForbiddenNetworks . . . 1193
9.11.4.37 pack_nas_SLQSNasGetHDRColorCode . . . 1194
9.11.4.38 pack_nas_SLQSNasGetRFInfo . . . 1194
9.11.4.39 pack_nas_SLQSNasGetSigInfo . . . 1194
9.11.4.40 pack_nas_SLQSNasGetTxRxInfo . . . 1195
9.11.4.41 pack_nas_SLQSNasIndicationRegisterExt . . . 1195
9.11.4.42 pack_nas_SLQSNASSeteDRXParams . . . 1196

9.11.4.43 pack_nas_SLQSNASSwiGetChannelLock . . . 1196
9.11.4.44 pack_nas_SLQSNasSwiIndicationRegister . . . 1196
9.11.4.45 pack_nas_SLQSNasSwiModemStatus . . . 1197
9.11.4.46 pack_nas_SLQSNASSwiSetChannelLock . . . 1197
9.11.4.47 pack_nas_SLQSSetBandPreference . . . 1197
9.11.4.48 pack_nas_SLQSSetSignalStrengthsCallback . . . 1198
9.11.4.49 pack_nas_SLQSSetSysSelectionPref . . . 1198
9.11.4.50 pack_nas_SLQSSetSysSelectionPrefExt . . . 1198
9.11.4.51 pack_nas_SLQSSwiGetHDRPersonality . . . 1199
9.11.4.52 pack_nas_SLQSSwiGetHDRProtSubtype . . . 1199
9.11.4.53 pack_nas_SLQSSwiGetHRPDStats . . . 1199
9.11.4.54 pack_nas_SLQSSwiGetLteCQI . . . 1200
9.11.4.55 pack_nas_SLQSSwiGetLteSccRxInfo . . . 1200
9.11.4.56 pack_nas_SLQSSwiNetworkDebug . . . 1200
9.11.4.57 pack_nas_SLQSSwiPSDetach . . . 1201
9.11.4.58 unpack_nas_GetACCOLC . . . 1201
9.11.4.59 unpack_nas_GetANAAAAuthenticationStatus . . . 1202
9.11.4.60 unpack_nas_GetCDMANetworkParameters . . . 1202
9.11.4.61 unpack_nas_GetHomeNetwork . . . 1202
9.11.4.62 unpack_nas_GetHomeNetwork3GPP2 . . . 1203
9.11.4.63 unpack_nas_GetNetworkPreference . . . 1203
9.11.4.64 unpack_nas_GetRFInfo . . . 1203
9.11.4.65 unpack_nas_GetServingNetwork . . . 1204
9.11.4.66 unpack_nas_GetServingNetworkCapabilities . . . 1204
9.11.4.67 unpack_nas_GetSignalStrengths . . . 1204
9.11.4.68 unpack_nas_InitiateDomainAttach . . . 1205
9.11.4.69 unpack_nas_PerformNetworkScan . . . 1205
9.11.4.70 unpack_nas_SetACCOLC . . . 1206
9.11.4.71 unpack_nas_SetCDMANetworkParameters . . . 1206
9.11.4.72 unpack_nas_SetDataCapabilitiesCallback_ind . . . 1206
9.11.4.73 unpack_nas_SetEventReportInd . . . 1207
9.11.4.74 unpack_nas_SetLURejectCallback . . . 1207
9.11.4.75 unpack_nas_SetNasLTECphyCaIndCallback_ind . . . 1207
9.11.4.76 unpack_nas_SetNetworkPreference . . . 1208
9.11.4.77 unpack_nas_SetRFInfoCallback . . . 1208
9.11.4.78 unpack_nas_SetRoamingIndicatorCallback_ind . . . 1208
9.11.4.79 unpack_nas_SetServingSystemCallback_ind . . . 1209
9.11.4.80 unpack_nas_SLQSConfigSigInfo . . . 1209
9.11.4.81 unpack_nas_SLQSGetErrorRate . . . 1209
9.11.4.82 unpack_nas_SlqsGetLTECphyCAInfo . . . 1210

9.11.4.83 unpack_nas_SLQSGetNetworkTime . . . 1210
9.11.4.84 unpack_nas_SLQSGetOperatorNameData . . . 1210
9.11.4.85 unpack_nas_SLQSGetPLMNName . . . 1211
9.11.4.86 unpack_nas_SLQSGetServingSystem . . . 1211
9.11.4.87 unpack_nas_SLQSGetSignalStrength . . . 1211
9.11.4.88 unpack_nas_SLQSGetSysInfo . . . 1212
9.11.4.89 unpack_nas_SLQSGetSysSelectionPref . . . 1212
9.11.4.90 unpack_nas_SLQSGetSysSelectionPrefExt . . . 1213
9.11.4.91 unpack_nas_SLQSInitiateNetworkRegistration . . . 1213
9.11.4.92 unpack_nas_SLQSNasConfigSigInfo2 . . . 1213
9.11.4.93 unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind . . . 1214
9.11.4.94 unpack_nas_SLQSNasGet3GPP2Subscription . . . 1214
9.11.4.95 unpack_nas_SLQSNasGetCellLocationInfo . . . 1215
9.11.4.96 unpack_nas_SLQSNASGeteDRXParams . . . 1215
9.11.4.97 unpack_nas_SLQSNASGeteDRXParamsExt . . . 1215
9.11.4.98 unpack_nas_SLQSNASGetForbiddenNetworks . . . 1216
9.11.4.99 unpack_nas_SLQSNasGetHDRColorCode . . . 1216
9.11.4.100 unpack_nas_SLQSNasGetRFInfo . . . 1216
9.11.4.101 unpack_nas_SLQSNasGetSigInfo . . . 1217
9.11.4.102 unpack_nas_SLQSNasGetTxRxInfo . . . 1217
9.11.4.103 unpack_nas_SLQSNasIndicationRegisterExt . . . 1218
9.11.4.104 unpack_nas_SLQSNasNetworkRejectCallback_Ind . . . 1218
9.11.4.105 unpack_nas_SLQSNasNetworkTimeCallBack_ind . . . 1218
9.11.4.106 unpack_nas_SLQSNASSeteDRXParams . . . 1219
9.11.4.107 unpack_nas_SLQSNasSigInfoCallback_ind . . . 1219
9.11.4.108 unpack_nas_SLQSNASSwiGetChannelLock . . . 1219
9.11.4.109 unpack_nas_SLQSNasSwiIndicationRegister . . . 1220
9.11.4.110 unpack_nas_SLQSNasSwiModemStatus . . . 1220
9.11.4.111 unpack_nas_SLQSNasSwiOTAMessageCallback_ind . . . 1220
9.11.4.112 unpack_nas_SLQSNASSwiSetChannelLock . . . 1221
9.11.4.113 unpack_nas_SLQSNasSysInfoCallback_ind . . . 1221
9.11.4.114 unpack_nas_SLQSNasTimerCallback_ind . . . 1221
9.11.4.115 unpack_nas_SLQSSetBandPreference . . . 1222
9.11.4.116 unpack_nas_SLQSSetSignalStrengthsCallback . . . 1222
9.11.4.117 unpack_nas_SLQSSetSysSelectionPref . . . 1222
9.11.4.118 unpack_nas_SLQSSetSysSelectionPrefCallBack_ind . . . 1223
9.11.4.119 unpack_nas_SLQSSetSysSelectionPrefExt . . . 1223
9.11.4.120 unpack_nas_SLQSSwiGetHDRPersonality . . . 1223
9.11.4.121 unpack_nas_SLQSSwiGetHDRProtSubtype . . . 1224
9.11.4.122 unpack_nas_SLQSSwiGetHRPDStats . . . 1224

9.11.4.123 unpack_nas_SLQSSwiGetLteCQI . . . 1224
9.11.4.124 unpack_nas_SLQSSwiGetLteSccRxInfo . . . 1225
9.11.4.125 unpack_nas_SLQSSwiHDRPersonalityCallback_Ind . . . 1225
9.11.4.126 unpack_nas_SLQSSwiNetworkDebug . . . 1225
9.11.4.127 unpack_nas_SLQSSwiPSDetach . . . 1226
9.11.4.128 unpack_nas_SLQSSwiRandIndicatorCallback_Ind . . . 1226
9.11.4.129 unpack_valid_nas_GetCDMANetworkParameters . . . 1226
9.11.4.130 unpack_valid_nas_SLQSGetServingSystem . . . 1227
9.11.4.131 unpack_valid_nas_SLQSGetSignalStrength . . . 1228
9.11.4.132 unpack_valid_nas_SLQSNasGetSigInfo . . . 1228
9.12 pds.h File Reference . . . 1229
9.12.1 Typedef Documentation . . . 1231
9.12.1.1 unpack_pds_ForceXTRADownload_t . . . 1231
9.12.1.2 unpack_pds_PDSInjectTimeReference_t . . . 1231
9.12.1.3 unpack_pds_ResetPDSData_t . . . 1231
9.12.1.4 unpack_pds_SetEventReportCallback_t . . . 1231
9.12.1.5 unpack_pds_SetPDSDefaults_t . . . 1231
9.12.1.6 unpack_pds_SetPDSState_t . . . 1231
9.12.1.7 unpack_pds_SetPortAutomaticTracking_t . . . 1232
9.12.1.8 unpack_pds_SetServiceAutomaticTracking_t . . . 1232
9.12.1.9 unpack_pds_SetXTRAAutomaticDownload_t . . . 1232
9.12.1.10 unpack_pds_SetXTRANetwork_t . . . 1232
9.12.1.11 unpack_pds_SLQSPDSDeterminePosition_t . . . 1232
9.12.1.12 unpack_pds_SLQSPDSInjectAbsoluteTimeReference_t . . . 1232
9.12.1.13 unpack_pds_SLQSPDSInjectPositionData_t . . . 1232
9.12.1.14 unpack_pds_SLQSSetAGPSConfig_t . . . 1232
9.12.1.15 unpack_pds_SLQSSetPositionMethodState_t . . . 1232
9.12.1.16 unpack_pds_StartPDSTrackingSessionExt_t . . . 1232
9.12.1.17 unpack_pds_StopPDSTrackingSession_t . . . 1232
9.12.2 Function Documentation . . . 1232
9.12.2.1 pack_pds_ForceXTRADownload . . . 1232
9.12.2.2 pack_pds_GetPDSDefaults . . . 1232
9.12.2.3 pack_pds_GetPDSState . . . 1233
9.12.2.4 pack_pds_GetPortAutomaticTracking . . . 1233
9.12.2.5 pack_pds_GetServiceAutomaticTracking . . . 1233
9.12.2.6 pack_pds_GetXTRAAutomaticDownload . . . 1234
9.12.2.7 pack_pds_GetXTRANetwork . . . 1234
9.12.2.8 pack_pds_GetXTRAValidity . . . 1234
9.12.2.9 pack_pds_PDSInjectTimeReference . . . 1235
9.12.2.10 pack_pds_ResetPDSData . . . 1235

9.12.2.11 pack_pds_SetEventReportCallback . . . 1235
9.12.2.12 pack_pds_SetPDSDefaults . . . 1236
9.12.2.13 pack_pds_SetPDSState . . . 1236
9.12.2.14 pack_pds_SetPortAutomaticTracking . . . 1236
9.12.2.15 pack_pds_SetServiceAutomaticTracking . . . 1237
9.12.2.16 pack_pds_SetXTRAAutomaticDownload . . . 1237
9.12.2.17 pack_pds_SetXTRANetwork . . . 1238
9.12.2.18 pack_pds_SLQSGetAGPSConfig . . . 1238
9.12.2.19 pack_pds_SLQSGetGPSStateInfo . . . 1238
9.12.2.20 pack_pds_SLQSPDSDeterminePosition . . . 1239
9.12.2.21 pack_pds_SLQSPDSInjectAbsoluteTimeReference . . . 1239
9.12.2.22 pack_pds_SLQSPDSInjectPositionData . . . 1239
9.12.2.23 pack_pds_SLQSSetAGPSConfig . . . 1240
9.12.2.24 pack_pds_SLQSSetPositionMethodState . . . 1240
9.12.2.25 pack_pds_StartPDSTrackingSessionExt . . . 1240
9.12.2.26 pack_pds_StopPDSTrackingSession . . . 1241
9.12.2.27 unpack_pds_ForceXTRADownload . . . 1241
9.12.2.28 unpack_pds_GetPDSDefaults . . . 1242
9.12.2.29 unpack_pds_GetPDSState . . . 1242
9.12.2.30 unpack_pds_GetPortAutomaticTracking . . . 1242
9.12.2.31 unpack_pds_GetServiceAutomaticTracking . . . 1243
9.12.2.32 unpack_pds_GetXTRAAutomaticDownload . . . 1243
9.12.2.33 unpack_pds_GetXTRANetwork . . . 1243
9.12.2.34 unpack_pds_GetXTRAValidity . . . 1244
9.12.2.35 unpack_pds_PDSInjectTimeReference . . . 1244
9.12.2.36 unpack_pds_ResetPDSData . . . 1244
9.12.2.37 unpack_pds_SetEventReport_Ind . . . 1245
9.12.2.38 unpack_pds_SetEventReportCallback . . . 1245
9.12.2.39 unpack_pds_SetPDSDefaults . . . 1245
9.12.2.40 unpack_pds_SetPDSState . . . 1246
9.12.2.41 unpack_pds_SetPdsState_Ind . . . 1246
9.12.2.42 unpack_pds_SetPortAutomaticTracking . . . 1246
9.12.2.43 unpack_pds_SetServiceAutomaticTracking . . . 1247
9.12.2.44 unpack_pds_SetXTRAAutomaticDownload . . . 1247
9.12.2.45 unpack_pds_SetXTRANetwork . . . 1247
9.12.2.46 unpack_pds_SLQSGetAGPSConfig . . . 1248
9.12.2.47 unpack_pds_SLQSGetGPSStateInfo . . . 1248
9.12.2.48 unpack_pds_SLQSPDSDeterminePosition . . . 1248
9.12.2.49 unpack_pds_SLQSPDSInjectAbsoluteTimeReference . . . 1249
9.12.2.50 unpack_pds_SLQSPDSInjectPositionData . . . 1249

9.12.2.51 unpack_pds_SLQSSetAGPSConfig . . . 1249
9.12.2.52 unpack_pds_SLQSSetPositionMethodState . . . 1250
9.12.2.53 unpack_pds_StartPDSTrackingSessionExt . . . 1250
9.12.2.54 unpack_pds_StopPDSTrackingSession . . . 1250
9.13 qaGobiApiTableBandClasses.h File Reference . . . 1251
9.13.1 Detailed Description . . . 1251
9.13.2 Band Classes (Value - Description) . . . 1251
9.13.2.1 LTE Bands . . . 1252
9.14 qaGobiApiTableCallControlReturnReasons.h File Reference . . . 1254
9.14.1 Detailed Description . . . 1254
9.14.2 S1 . . . 1254
9.15 qaGobiApiTableCallEndReasons.h File Reference . . . 1255
9.15.1 Detailed Description . . . 1255
9.15.2 Call end reason codes (Code - Reason) . . . 1255
9.15.2.1 Technology-agnostic call end reasons . . . 1255
9.15.2.2 EVDO CDMA 1xEV-DO . . . 1256
9.15.2.3 WCDMA/GSM call end reasons . . . 1256
9.15.2.4 EVDO CDMA 1xEV-DO . . . 1258
9.15.2.5 call end reason type . . . 1259
9.15.2.6 Mobile IP call end reasons (Type=1) . . . 1259
9.15.2.7 Internal call end reasons (Type=2) . . . 1261
9.15.2.8 Call Manager defined call end reasons (Type=3) . . . 1263
9.15.2.9 3GPP specification defined call end reasons (Type=6) . . . 1268
9.15.2.10 PPP call end reasons (Type=7) . . . 1270
9.15.2.11 EHRPD call end reasons (Type=8) . . . 1270
9.15.2.12 IPV6 call end reasons (Type=9) . . . 1271
9.16 qaGobiApiTableCarrierCodes.h File Reference . . . 1271
9.16.1 Detailed Description . . . 1271
9.16.2 Carrier Codes (Number - Carrier) . . . 1272
9.17 qaGobiApiTableCodingScheme.h File Reference . . . 1273
9.17.1 Detailed Description . . . 1273
9.17.2 S1 . . . 1274
9.17.2.1 Use of bits 3..0\n\n . . . 1274
9.17.3 Coding Group Bits 7..4(0001) . . . 1274
9.17.3.1 use of bits 3..0 . . . 1274
9.17.4 Coding Group Bits 7..4(0010) . . . 1274
9.17.4.1 use of bits 3..0 . . . 1274
9.17.5 Coding Group Bits 7..4(0011) . . . 1275
9.17.5.1 use of bits 3..0 . . . 1275
9.17.6 Coding Group Bits 7..4(01xx) . . . 1275

9.17.6.1 use of bits 3..0 . . . 1275
9.17.7 Coding Group Bits 7..4(1001) . . . 1275
9.17.7.1 Reserved coding groups . . . 1275
9.17.8 Coding Group Bits 7..4(1010..1101) . . . 1276
9.17.8.1 Reserved coding groups . . . 1276
9.17.9 Coding Group Bits 7..4(1110) . . . 1276
9.17.9.1 Defined by the WAP Forum . . . 1276
9.17.10 Coding Group Bits 7..4 (1111) . . . 1276
9.17.10.1 Data coding / message handling . . . 1276
9.17.11 Macro Definition Documentation . . . 1276
9.17.11.1 __GOBI_API_CODING_SCHEME_H__ . . . 1276
9.18 qaGobiApiTableGpsCapabilityCodes.h File Reference . . . 1276
9.18.1 Detailed Description . . . 1276
9.18.2 GPS capability (Value - Capability) . . . 1276
9.19 qaGobiApiTablePowerModes.h File Reference . . . 1277
9.19.1 Detailed Description . . . 1277
9.19.2 Power Modes (Value - Description) . . . 1277
9.20 qaGobiApiTableRadioInterfaces.h File Reference . . . 1277
9.20.1 Detailed Description . . . 1277
9.20.2 Radio interface . . . 1277
9.20.2.1 Technology (Value - Radio Interface Technology) . . . 1277
9.21 qaGobiApiTableRegionCodes.h File Reference . . . 1278
9.21.1 Detailed Description . . . 1278
9.21.2 Region Codes (Code - Region) . . . 1278
9.22 qaGobiApiTableServiceOptions.h File Reference . . . 1278
9.22.1 Detailed Description . . . 1278
9.22.2 Service Option codes (Code - Reason) . . . 1279
9.22.2.1 Description . . . 1279
9.23 qaGobiApiTableSupServiceInfoClasses.h File Reference . . . 1281
9.23.1 Detailed Description . . . 1281
9.23.2 Supplementary Service Information Classes (Value - Service Class) . . . 1281
9.24 qaGobiApiTableSwiAudio.h File Reference . . . 1281
9.24.1 Detailed Description . . . 1281
9.24.2 ACDB Device (Device ID - description) . . . 1281
9.24.3 Physical Interface (Device ID - description - Interface parameters) . . . 1282
9.25 qaGobiApiTableSwiOMADMSessionStatus.h File Reference . . . 1282
9.25.1 Detailed Description . . . 1282
9.25.2 OMA DM Session Status (Session Status - Meaning - Usage) . . . 1282
9.26 qaGobiApiTableSwiOMADMUpdateCompleteStatus.h File Reference . . . 1283
9.26.1 Detailed Description . . . 1283

9.26.2 OMA DM Update Complete Status (Update Complete Status - Meaning - Usage) 1283
9.27 qaGobiApiTableVoiceCallEndReasons.h File Reference 1284
9.27.1 Detailed Description 1284
9.27.2 Voice Call and supplementary services end reason codes (Code - Reason) 1284
9.27.2.1 General 1284
9.27.2.2 service Errors 1286
9.27.2.3 control cause values 1287
9.27.2.4 reject causes 1289
9.27.2.5 reject causes 1289
9.27.2.6 reject causes 1289
9.27.2.7 stratum reject causes 1290
9.27.2.8 reject causes 1290
9.27.2.9 IP end reasons 1290
9.28 qmerrno.h File Reference 1291
9.28.1 Enumeration Type Documentation 1293
9.28.1.1 eQCWWANError 1293
9.28.1.2 qm_wds_ds_profile_extended_err_codes 1298
9.29 qos.h File Reference 1298
9.29.1 Macro Definition Documentation 1300
9.29.1.1 LITEQMI_MAX_QOS_FILTERS 1300
9.29.1.2 LITEQMI_MAX_QOS_FLOW_PER_APN_STATS 1300
9.29.1.3 LITEQMI_MAX_QOS_FLOWS 1300
9.29.2 Function Documentation 1300
9.29.2.1 pack_qos_BindDataPort 1300
9.29.2.2 pack_qos_SLQSQosGetNetworkStatus 1300
9.29.2.3 pack_qos_SLQSQosSwiReadApnExtraParams 1301
9.29.2.4 pack_qos_SLQSQosSwiReadDataStats 1302
9.29.2.5 pack_qos_SLQSSetQosEventCallback 1302
9.29.2.6 unpack_qos_BindDataPort 1303
9.29.2.7 unpack_qos_SLQSQosGetNetworkStatus 1303
9.29.2.8 unpack_qos_SLQSQosSwiReadApnExtraParams 1304
9.29.2.9 unpack_qos_SLQSQosSwiReadDataStats 1304
9.29.2.10 unpack_qos_SLQSSetQosEventCallback 1305
9.29.2.11 unpack_qos_SLQSSetQosEventCallback_ind 1305
9.29.2.12 unpack_qos_SLQSSetQosNWStatusCallback_ind 1306
9.29.2.13 unpack_qos_SLQSSetQosPriEventCallback_ind 1307
9.29.2.14 unpack_qos_SLQSSetQosStatusCallback_ind 1307
9.30 rms.h File Reference 1308
9.30.1 Macro Definition Documentation 1308
9.30.1.1 __LITEQMI_RMS_H__ 1308

9.30.2 Function Documentation . . . 1308
9.30.2.1 pack_rms_GetSMSWake . . . 1308
9.30.2.2 pack_rms_SetSMSWake . . . 1309
9.30.2.3 unpack_rms_GetSMSWake . . . 1309
9.30.2.4 unpack_rms_SetSMSWake . . . 1309
9.31 sar.h File Reference . . . 1310
9.31.1 Typedef Documentation . . . 1310
9.31.1.1 unpack_sar_SLQSSetRfSarState_t . . . 1310
9.31.2 Function Documentation . . . 1310
9.31.2.1 pack_sar_SLQSGetRfSarState . . . 1310
9.31.2.2 pack_sar_SLQSSetRfSarState . . . 1311
9.31.2.3 unpack_sar_SLQSGetRfSarState . . . 1311
9.31.2.4 unpack_sar_SLQSSetRfSarState . . . 1311
9.32 sms.h File Reference . . . 1312
9.32.1 Macro Definition Documentation . . . 1315
9.32.1.1 MAX_CDMA_ENC_MO_TXT_MSG_SIZE . . . 1315
9.32.1.2 MAX_MS_TRANSFER_ROUTE_MSG . . . 1315
9.32.1.3 MAX_MSC_ADDRESS_SIZE . . . 1315
9.32.1.4 MAX_MSE_TWS_MSG . . . 1315
9.32.1.5 MAX_SMS_LIST_SIZE . . . 1315
9.32.1.6 MAX_SMS_MESSAGE_SIZE . . . 1315
9.32.1.7 SMS_CONFIG_LEN . . . 1316
9.32.1.8 SMS_MAX_SMS_ROUTES . . . 1316
9.32.1.9 SMS_NUM_OF_SET . . . 1316
9.32.1.10 SMSC_TYPE_LEN . . . 1316
9.32.2 Enumeration Type Documentation . . . 1316
9.32.2.1 eqmiCbkSetStatus . . . 1316
9.32.3 Function Documentation . . . 1316
9.32.3.1 pack_sms_GetSMSCAddress . . . 1316
9.32.3.2 pack_sms_SaveSMS . . . 1316
9.32.3.3 pack_sms_SendSMS . . . 1317
9.32.3.4 pack_sms_SetNewSMSCallback . . . 1317
9.32.3.5 pack_sms_SetSMSCAddress . . . 1317
9.32.3.6 pack_sms_SLQSDeleteSMS . . . 1318
9.32.3.7 pack_sms_SLQSGetIndicationRegister . . . 1318
9.32.3.8 pack_sms_SLQSGetMessageWaiting . . . 1318
9.32.3.9 pack_sms_SLQSGetSMS . . . 1319
9.32.3.10 pack_sms_SLQSGetSmsBroadcastConfig . . . 1319
9.32.3.11 pack_sms_SLQSGetSMSList . . . 1319
9.32.3.12 pack_sms_SLQSGetTransLayerInfo . . . 1320

9.32.3.13 pack_sms_SLQSGetTransNWRegInfo . . . 1320
9.32.3.14 pack_sms_SLQSModifySMSStatus . . . 1320
9.32.3.15 pack_sms_SLQSSendAsyncSMS . . . 1321
9.32.3.16 pack_sms_SLQSSetIndicationRegister . . . 1321
9.32.3.17 pack_sms_SLQSSetSmsBroadcastActivation . . . 1322
9.32.3.18 pack_sms_SLQSSetSmsBroadcastConfig . . . 1322
9.32.3.19 pack_sms_SLQSSetSmsStorage . . . 1322
9.32.3.20 pack_sms_SLQSSmsGetMaxStorageSize . . . 1323
9.32.3.21 pack_sms_SLQSSmsGetMessageProtocol . . . 1323
9.32.3.22 pack_sms_SLQSSmsSetRoutes . . . 1323
9.32.3.23 pack_sms_SLQSSwiGetSMSStorage . . . 1324
9.32.3.24 unpack_sms_GetSMSCAddress . . . 1324
9.32.3.25 unpack_sms_SaveSMS . . . 1324
9.32.3.26 unpack_sms_SendSMS . . . 1325
9.32.3.27 unpack_sms_SetNewSMSCallback . . . 1325
9.32.3.28 unpack_sms_SetNewSMSCallback_ind . . . 1325
9.32.3.29 unpack_sms_SetSMSCAddress . . . 1326
9.32.3.30 unpack_sms_SLQSDeleteSMS . . . 1326
9.32.3.31 unpack_sms_SLQSGetIndicationRegister . . . 1327
9.32.3.32 unpack_sms_SLQSGetMessageWaiting . . . 1327
9.32.3.33 unpack_sms_SLQSGetSMS . . . 1327
9.32.3.34 unpack_sms_SLQSGetSmsBroadcastConfig . . . 1328
9.32.3.35 unpack_sms_SLQSGetSMSList . . . 1328
9.32.3.36 unpack_sms_SLQSGetTransLayerInfo . . . 1328
9.32.3.37 unpack_sms_SLQSGetTransNWRegInfo . . . 1329
9.32.3.38 unpack_sms_SLQSModifySMSStatus . . . 1329
9.32.3.39 unpack_sms_SLQSNWRegInfoCallback_ind . . . 1329
9.32.3.40 unpack_sms_SLQSSendAsyncSMS . . . 1330
9.32.3.41 unpack_sms_SLQSSetIndicationRegister . . . 1330
9.32.3.42 unpack_sms_SLQSSetSmsBroadcastActivation . . . 1330
9.32.3.43 unpack_sms_SLQSSetSmsBroadcastConfig . . . 1331
9.32.3.44 unpack_sms_SLQSSetSmsStorage . . . 1331
9.32.3.45 unpack_sms_SLQSSmsGetMaxStorageSize . . . 1331
9.32.3.46 unpack_sms_SLQSSmsGetMessageProtocol . . . 1332
9.32.3.47 unpack_sms_SLQSSmsSetRoutes . . . 1332
9.32.3.48 unpack_sms_SLQSSwiGetSMSStorage . . . 1333
9.32.3.49 unpack_sms_SLQSTransLayerInfoCallback_ind . . . 1333
9.32.3.50 unpack_sms_SLQSWmsAsyncRawSendCallBack_ind . . . 1333
9.32.3.51 unpack_sms_SLQSWmsMemoryFullCallBack_ind . . . 1334
9.32.3.52 unpack_sms_SLQSWmsMessageWaitingCallBack_ind . . . 1334

9.33 swiaudio.h File Reference . . . 1334
9.33.1 Macro Definition Documentation . . . 1336
9.33.1.1 SWIAUDIO_MAX_LEN_IFACE_TABLE . . . 1336
9.33.2 Typedef Documentation . . . 1336
9.33.2.1 unpack_swiaudio_SLQSSetM2MAudioAVCFG_t . . . 1336
9.33.2.2 unpack_swiaudio_SLQSSetM2MAudioLPBK_t . . . 1336
9.33.2.3 unpack_swiaudio_SLQSSetM2MAudioNVDef_t . . . 1336
9.33.2.4 unpack_swiaudio_SLQSSetM2MAudioProfile_t . . . 1336
9.33.2.5 unpack_swiaudio_SLQSSetM2MAudioVolume_t . . . 1336
9.33.2.6 unpack_swiaudio_SLQSSetM2MAVMute_t . . . 1336
9.33.2.7 unpack_swiaudio_SLQSSetM2MSpkrGain_t . . . 1336
9.33.3 Function Documentation . . . 1336
9.33.3.1 pack_swiaudio_SLQSGetM2MAudioProfile . . . 1336
9.33.3.2 pack_swiaudio_SLQSGetM2MAudioVolume . . . 1337
9.33.3.3 pack_swiaudio_SLQSGetM2MAVMute . . . 1337
9.33.3.4 pack_swiaudio_SLQSGetM2MSpkrGain . . . 1337
9.33.3.5 pack_swiaudio_SLQSSetM2MAudioAVCFG . . . 1338
9.33.3.6 pack_swiaudio_SLQSSetM2MAudioLPBK . . . 1338
9.33.3.7 pack_swiaudio_SLQSSetM2MAudioNVDef . . . 1338
9.33.3.8 pack_swiaudio_SLQSSetM2MAudioProfile . . . 1339
9.33.3.9 pack_swiaudio_SLQSSetM2MAudioVolume . . . 1339
9.33.3.10 pack_swiaudio_SLQSSetM2MAVMute . . . 1340
9.33.3.11 pack_swiaudio_SLQSSetM2MSpkrGain . . . 1340
9.33.3.12 unpack_swiaudio_SLQSGetM2MAudioProfile . . . 1340
9.33.3.13 unpack_swiaudio_SLQSGetM2MAudioVolume . . . 1341
9.33.3.14 unpack_swiaudio_SLQSGetM2MAVMute . . . 1341
9.33.3.15 unpack_swiaudio_SLQSGetM2MSpkrGain . . . 1341
9.33.3.16 unpack_swiaudio_SLQSSetM2MAudioAVCFG . . . 1342
9.33.3.17 unpack_swiaudio_SLQSSetM2MAudioLPBK . . . 1342
9.33.3.18 unpack_swiaudio_SLQSSetM2MAudioNVDef . . . 1342
9.33.3.19 unpack_swiaudio_SLQSSetM2MAudioProfile . . . 1343
9.33.3.20 unpack_swiaudio_SLQSSetM2MAudioVolume . . . 1343
9.33.3.21 unpack_swiaudio_SLQSSetM2MAVMute . . . 1343
9.33.3.22 unpack_swiaudio_SLQSSetM2MSpkrGain . . . 1344
9.34 swiavms.h File Reference . . . 1344
9.34.1 Macro Definition Documentation . . . 1346
9.34.1.1 LITEQMI_MAX_GET_SETTINGS_AVMS_APN_STRING_LENGTH . . . 1346
9.34.1.2 LITEQMI_MAX_GET_SETTINGS_AVMS_PWD_STRING_LENGTH . . . 1346
9.34.1.3 LITEQMI_MAX_GET_SETTINGS_AVMS_UNAME_STRING_LENGTH . . . 1346
9.34.1.4 LITEQMI_MAX_SWIOMA_STR_LEN . . . 1346

9.34.1.5 MAX_AVMS_SETTINGS_RETRY_TIMER_NUMBER . . . 1346
9.34.1.6 MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_DESC_LENGTH . . . 1346
9.34.1.7 MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_NAME_LENGTH . . . 1346
9.34.1.8 MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_VERSION_LENGTH . . . 1346
9.34.1.9 MAX_PACK_SWI_AVMS_SESSIONGETINFO_CONFIG_ALERT_MSG_LENGTH . . . 1346
9.34.1.10 MAX_PACK_SWI_AVMS_SET_SETTING_APN_LENGTH . . . 1346
9.34.1.11 MAX_PACK_SWI_AVMS_SET_SETTING_CONNECTION_RETRY_TIMMERS . 1346
9.34.1.12 MAX_PACK_SWI_AVMS_SET_SETTING_PWD_LENGTH . . . 1346
9.34.1.13 MAX_PACK_SWI_AVMS_SET_SETTING_UNAME_LENGTH . . . 1346
9.34.2 Function Documentation . . . 1346
9.34.2.1 pack_swiavms_SLQSAVMSGetSettings . . . 1346
9.34.2.2 pack_swiavms_SLQSAVMSGetSettings_v2 . . . 1347
9.34.2.3 pack_swiavms_SLQSAVMSSendSelection . . . 1348
9.34.2.4 pack_swiavms_SLQSAVMSSessionGetInfo . . . 1348
9.34.2.5 pack_swiavms_SLQSAvmsSetEventReport . . . 1349
9.34.2.6 pack_swiavms_SLQSAVMSSetSettings . . . 1349
9.34.2.7 pack_swiavms_SLQSAVMSSetSettings_v2 . . . 1350
9.34.2.8 pack_swiavms_SLQSAVMSSetSettingsNoAutoRebootField . . . 1351
9.34.2.9 pack_swiavms_SLQSAVMSStartSession . . . 1351
9.34.2.10 pack_swiavms_SLQSAVMSStopSession . . . 1352
9.34.2.11 unpack_swiavms_SLQSAVMSEventReportInd . . . 1352
9.34.2.12 unpack_swiavms_SLQSAVMSGetSettings . . . 1353
9.34.2.13 unpack_swiavms_SLQSAVMSGetSettings_v2 . . . 1353
9.34.2.14 unpack_swiavms_SLQSAVMSSendSelection . . . 1354
9.34.2.15 unpack_swiavms_SLQSAVMSSessionGetInfo . . . 1354
9.34.2.16 unpack_swiavms_SLQSAvmsSetEventReport . . . 1355
9.34.2.17 unpack_swiavms_SLQSAVMSSetSettings . . . 1355
9.34.2.18 unpack_swiavms_SLQSAVMSSetSettings_v2 . . . 1356
9.34.2.19 unpack_swiavms_SLQSAVMSStartSession . . . 1356
9.34.2.20 unpack_swiavms_SLQSAVMSStopSession . . . 1357
9.34.2.21 unpack_swiavms_SLQSAVMSStopSession_avc2 . . . 1357
9.35 SwiDataTypes.h File Reference . . . 1358
9.35.1 Detailed Description . . . 1358
9.35.2 Macro Definition Documentation . . . 1358
9.35.2.1 MEMSET_STATIC_OUTPUT_STRUCT . . . 1358
9.35.2.2 QMI_NO_LTE_FW_SUPPORT . . . 1359
9.35.2.3 QMI_TLV_PLACEHOLDER . . . 1359

9.35.2.4 SWI_API . . . 1359
9.35.2.5 UNUSEDPARAM . . . 1359
9.35.3 Typedef Documentation . . . 1359
9.35.3.1 BOOL . . . 1359
9.35.3.2 BYTE . . . 1359
9.35.3.3 CHAR . . . 1359
9.35.3.4 FLOAT . . . 1359
9.35.3.5 INT32 . . . 1359
9.35.3.6 INT8 . . . 1359
9.35.3.7 LPCSTR . . . 1359
9.35.3.8 qmuint16 . . . 1359
9.35.3.9 qmulong . . . 1359
9.35.3.10 SHORT . . . 1359
9.35.3.11 ULONG . . . 1359
9.35.3.12 ULONGLONG . . . 1359
9.35.3.13 USHORT . . . 1359
9.35.3.14 WORD . . . 1359
9.36 swidms.h File Reference . . . 1359
9.36.1 Typedef Documentation . . . 1360
9.36.1.1 unpack_swidms_SLQSSwiDmsSetUsbNetNum_t . . . 1360
9.36.2 Function Documentation . . . 1360
9.36.2.1 pack_swidms_SLQSSwiDmsGetMTU . . . 1360
9.36.2.2 pack_swidms_SLQSSwiDmsGetUsbComp . . . 1361
9.36.2.3 pack_swidms_SLQSSwiDmsGetUsbNetNum . . . 1361
9.36.2.4 pack_swidms_SLQSSwiDmsSetMTU . . . 1361
9.36.2.5 pack_swidms_SLQSSwiDmsSetUsbComp . . . 1362
9.36.2.6 pack_swidms_SLQSSwiDmsSetUsbNetNum . . . 1362
9.36.2.7 unpack_swidms_SLQSSwiDmsGetMTU . . . 1362
9.36.2.8 unpack_swidms_SLQSSwiDmsGetUsbComp . . . 1363
9.36.2.9 unpack_swidms_SLQSSwiDmsGetUsbNetNum . . . 1363
9.36.2.10 unpack_swidms_SLQSSwiDmsSetMTU . . . 1364
9.36.2.11 unpack_swidms_SLQSSwiDmsSetUsbComp . . . 1364
9.36.2.12 unpack_swidms_SLQSSwiDmsSetUsbNetNum . . . 1364
9.37 swiloc.h File Reference . . . 1365
9.37.1 Typedef Documentation . . . 1365
9.37.1.1 unpack_swiloc_SwiLocSetAutoStart_t . . . 1365
9.37.2 Function Documentation . . . 1365
9.37.2.1 pack_swiloc_SwiLocGetAutoStart . . . 1365
9.37.2.2 pack_swiloc_SwiLocSetAutoStart . . . 1365
9.37.2.3 unpack_swiloc_SwiLocGetAutoStart . . . 1366

9.37.2.4 unpack_swiloc_SwiLocSetAutoStart . . . 1366
9.38 swioma.h File Reference . . . 1366
9.38.1 Macro Definition Documentation . . . 1368
9.38.1.1 LITEQMI_MAX_SWIOMA_STR_LEN . . . 1368
9.38.2 Typedef Documentation . . . 1368
9.38.2.1 unpack_swioma_SLQSOMADMAlertCallback_t . . . 1368
9.38.2.2 unpack_swioma_SLQSOMADMCancelSession_t . . . 1368
9.38.2.3 unpack_swioma_SLQSOMADMSendSelection_t . . . 1368
9.38.2.4 unpack_swioma_SLQSOMADMSetSettings_t . . . 1368
9.38.3 Function Documentation . . . 1368
9.38.3.1 pack_swioma_SLQSOMADMAlertCallback . . . 1368
9.38.3.2 pack_swioma_SLQSOMADMCancelSession . . . 1368
9.38.3.3 pack_swioma_SLQSOMADMGetSessionInfo . . . 1369
9.38.3.4 pack_swioma_SLQSOMADMGetSettings . . . 1370
9.38.3.5 pack_swioma_SLQSOMADMSendSelection . . . 1370
9.38.3.6 pack_swioma_SLQSOMADMSetSettings . . . 1371
9.38.3.7 pack_swioma_SLQSOMADMStartSession . . . 1372
9.38.3.8 unpack_swioma_SLQSOMADMAlertCallback . . . 1372
9.38.3.9 unpack_swioma_SLQSOMADMAlertCallback_ind . . . 1373
9.38.3.10 unpack_swioma_SLQSOMADMCancelSession . . . 1373
9.38.3.11 unpack_swioma_SLQSOMADMGetSessionInfo . . . 1374
9.38.3.12 unpack_swioma_SLQSOMADMGetSettings . . . 1374
9.38.3.13 unpack_swioma_SLQSOMADMSendSelection . . . 1375
9.38.3.14 unpack_swioma_SLQSOMADMSetSettings . . . 1375
9.38.3.15 unpack_swioma_SLQSOMADMStartSession . . . 1376
9.39 swiomaext.h File Reference . . . 1376
9.39.1 Macro Definition Documentation . . . 1377
9.39.1.1 LITEQMI_MAX_SWIOMA_STR_LEN . . . 1377
9.39.2 Typedef Documentation . . . 1377
9.39.2.1 unpack_swioma_SLQSOMADMCancelSessionExt_t . . . 1377
9.39.2.2 unpack_swioma_SLQSOMADMSendSelectionExt_t . . . 1377
9.39.2.3 unpack_swioma_SLQSOMADMSetSettingsExt_t . . . 1377
9.39.2.4 unpack_swioma_SLQSOMADMStartSessionExt_t . . . 1377
9.39.3 Function Documentation . . . 1377
9.39.3.1 pack_swioma_SLQSOMADMCancelSessionExt . . . 1377
9.39.3.2 pack_swioma_SLQSOMADMSendSelectionExt . . . 1378
9.39.3.3 pack_swioma_SLQSOMADMSetSettingsExt . . . 1378
9.39.3.4 pack_swioma_SLQSOMADMStartSessionExt . . . 1379
9.39.3.5 unpack_swioma_SLQSOMADMCancelSessionExt . . . 1380
9.39.3.6 unpack_swioma_SLQSOMADMSendSelectionExt . . . 1380

9.39.3.7 unpack_swioma_SLQSOMADMSetSettingsExt . . . 1380
9.39.3.8 unpack_swioma_SLQSOMADMStartSessionExt . . . 1381
9.40 switype_256bit.h File Reference . . . 1381
9.40.1 Macro Definition Documentation . . . 1382
9.40.1.1 SWI_UINT256_BIT_OFFSET . . . 1382
9.40.1.2 SWI_UINT256_BITS_PER_WORD . . . 1382
9.40.1.3 SWI_UINT256_INT_VALUE . . . 1382
9.40.1.4 SWI_UINT256_WORD_COUNT . . . 1382
9.40.1.5 SWI_UINT256_WORD_OFFSET . . . 1382
9.40.2 Function Documentation . . . 1382
9.40.2.1 swi_uint256_clear_bit . . . 1382
9.40.2.2 swi_uint256_get_bit . . . 1382
9.40.2.3 swi_uint256_print_mask . . . 1382
9.40.2.4 swi_uint256_set_bit . . . 1383
9.41 SWIWWANCMAPI.h File Reference . . . 1383
9.42 tmd.h File Reference . . . 1383
9.42.1 Macro Definition Documentation . . . 1384
9.42.1.1 MAX_MITIGATION_DEV_ID_LEN . . . 1384
9.42.1.2 MAX_MITIGATION_DEV_LIST_LEN . . . 1384
9.42.1.3 TMD_MAX_DEV_LIST . . . 1384
9.42.2 Function Documentation . . . 1384
9.42.2.1 pack_tmd_SLQSTmdDeRegNotMitigationLvl . . . 1384
9.42.2.2 pack_tmd_SLQSTmdGetMitigationDevList . . . 1384
9.42.2.3 pack_tmd_SLQSTmdGetMitigationLvl . . . 1384
9.42.2.4 pack_tmd_SLQSTmdRegNotMitigationLvl . . . 1385
9.42.2.5 unpack_tmd_SLQSTmdDeRegNotMitigationLvl . . . 1385
9.42.2.6 unpack_tmd_SLQSTmdGetMitigationDevList . . . 1386
9.42.2.7 unpack_tmd_SLQSTmdGetMitigationLvl . . . 1386
9.42.2.8 unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind . . . 1386
9.42.2.9 unpack_tmd_SLQSTmdRegNotMitigationLvl . . . 1387
9.43 uim.h File Reference . . . 1387
9.43.1 Macro Definition Documentation . . . 1390
9.43.1.1 MAX_DESCRIPTION_LENGTH . . . 1390
9.43.1.2 MAX_ICCID_LENGTH . . . 1390
9.43.1.3 MAX_NO_OF_APPLICATIONS . . . 1390
9.43.1.4 MAX_NO_OF_SLOTS . . . 1390
9.43.1.5 MAX_SLOTS_STATUS . . . 1390
9.43.1.6 UIM_MAX_ACTIVE_PERS_FEATURES . . . 1390
9.43.1.7 UIM_MAX_CONTENT_LENGTH . . . 1390
9.43.1.8 UIM_MAX_DESCRIPTION_LENGTH . . . 1390

9.43.1.9 UIM_MAX_NO_OF_APPLICATIONS . . . 1390
9.43.1.10 UIM_MAX_NO_OF_SLOTS . . . 1390
9.43.1.11 UIM_UINT8_MAX_STRING_SZ . . . 1390
9.43.2 Typedef Documentation . . . 1390
9.43.2.1 unpack_uim_SLQSUIMPowerDown_t . . . 1390
9.43.2.2 unpack_uim_SLQSUIMPowerUp_t . . . 1390
9.43.2.3 unpack_uim_SLQSUIMRefreshComplete_t . . . 1391
9.43.2.4 unpack_uim_SLQSUIMRefreshOK_t . . . 1391
9.43.2.5 unpack_uim_SLQSUIMRefreshRegister_t . . . 1391
9.43.2.6 unpack_uim_SLQSUIMReset_t . . . 1391
9.43.2.7 unpack_uim_SLQSUIMSwitchSlot_t . . . 1391
9.43.3 Function Documentation . . . 1391
9.43.3.1 pack_uim_ChangePin . . . 1391
9.43.3.2 pack_uim_GetCardStatus . . . 1391
9.43.3.3 pack_uim_ReadTransparent . . . 1391
9.43.3.4 pack_uim_SetPinProtection . . . 1392
9.43.3.5 pack_uim_SLQSUIMAuthenticate . . . 1392
9.43.3.6 pack_uim_SLQSUIMDepersonalization . . . 1393
9.43.3.7 pack_uim_SLQSUIMEventRegister . . . 1393
9.43.3.8 pack_uim_SLQSUIMGetConfiguration . . . 1393
9.43.3.9 pack_uim_SLQSUIMGetFileAttributes . . . 1394
9.43.3.10 pack_uim_SLQSUIMGetSlotsStatus . . . 1394
9.43.3.11 pack_uim_SLQSUIMPowerDown . . . 1394
9.43.3.12 pack_uim_SLQSUIMPowerUp . . . 1395
9.43.3.13 pack_uim_SLQSUIMRefreshComplete . . . 1395
9.43.3.14 pack_uim_SLQSUIMRefreshGetLastEvent . . . 1396
9.43.3.15 pack_uim_SLQSUIMRefreshOK . . . 1396
9.43.3.16 pack_uim_SLQSUIMRefreshRegister . . . 1396
9.43.3.17 pack_uim_SLQSUIMReset . . . 1397
9.43.3.18 pack_uim_SLQSUIMSwitchSlot . . . 1397
9.43.3.19 pack_uim_UnblockPin . . . 1397
9.43.3.20 pack_uim_VerifyPin . . . 1398
9.43.3.21 unpack_uim_ChangePin . . . 1398
9.43.3.22 unpack_uim_GetCardStatus . . . 1399
9.43.3.23 unpack_uim_ReadTransparent . . . 1399
9.43.3.24 unpack_uim_SetPinProtection . . . 1399
9.43.3.25 unpack_uim_SetUimSlotStatusChangeCallback_ind . . . 1400
9.43.3.26 unpack_uim_SLQSUIMAuthenticate . . . 1400
9.43.3.27 unpack_uim_SLQSUIMDepersonalization . . . 1400
9.43.3.28 unpack_uim_SLQSUIMEventRegister . . . 1401

9.43.3.29 unpack_uim_SLQSUIMGetConfiguration . . . 1401
9.43.3.30 unpack_uim_SLQSUIMGetFileAttributes . . . 1401
9.43.3.31 unpack_uim_SLQSUIMGetSlotsStatus . . . 1402
9.43.3.32 unpack_uim_SLQSUIMPowerDown . . . 1402
9.43.3.33 unpack_uim_SLQSUIMPowerUp . . . 1403
9.43.3.34 unpack_uim_SLQSUIMRefreshCallback_Ind . . . 1403
9.43.3.35 unpack_uim_SLQSUIMRefreshComplete . . . 1403
9.43.3.36 unpack_uim_SLQSUIMRefreshGetLastEvent . . . 1404
9.43.3.37 unpack_uim_SLQSUIMRefreshOK . . . 1404
9.43.3.38 unpack_uim_SLQSUIMRefreshRegister . . . 1404
9.43.3.39 unpack_uim_SLQSUIMReset . . . 1405
9.43.3.40 unpack_uim_SLQSUIMSetStatusChangeCallBack_ind . . . 1405
9.43.3.41 unpack_uim_SLQSUIMSwitchSlot . . . 1405
9.43.3.42 unpack_uim_UnblockPin . . . 1406
9.43.3.43 unpack_uim_VerifyPin . . . 1406
9.44 voice.h File Reference . . . 1406
9.44.1 Detailed Description . . . 1412
9.44.2 S1 . . . 1412
9.44.3 Macro Definition Documentation . . . 1412
9.44.3.1 BARRING_PASSWORD_LENGTH . . . 1412
9.44.3.2 MAX_VOICE_CALL_NO_LEN . . . 1412
9.44.3.3 MAX_VOICE_DESCRIPTION_LENGTH . . . 1412
9.44.3.4 MAXVOICEUSSDLENGTH . . . 1412
9.44.3.5 VOICE_MAX_NO_OF_CALLS . . . 1412
9.44.4 Typedef Documentation . . . 1412
9.44.4.1 unpack_voice_AnswerUSSD_t . . . 1412
9.44.4.2 unpack_voice_CancelUSSD_t . . . 1412
9.44.4.3 unpack_voice_OriginateUSSD_t . . . 1412
9.44.4.4 unpack_voice_SLQSVoiceALSSelectLine_t . . . 1412
9.44.4.5 unpack_voice_SLQSVoiceALSSetLineSwitching_t . . . 1412
9.44.4.6 unpack_voice_SLQSVoiceBindSubscription_t . . . 1412
9.44.4.7 unpack_voice_SLQSVoiceIndicationRegister_t . . . 1412
9.44.4.8 unpack_voice_SLQSVoiceOrigUSSDNoWait_t . . . 1412
9.44.4.9 unpack_voice_SLQSVoiceSetPreferredPrivacy_t . . . 1412
9.44.5 Enumeration Type Documentation . . . 1412
9.44.5.1 liteServiceClassInformation . . . 1413
9.44.6 Function Documentation . . . 1413
9.44.6.1 pack_voice_AnswerUSSD . . . 1413
9.44.6.2 pack_voice_CancelUSSD . . . 1413
9.44.6.3 pack_voice_OriginateUSSD . . . 1414

9.44.6.4 pack_voice_SLQSOriginateUSSD . . . 1414
9.44.6.5 pack_voice_SLQSVoiceALSSelectLine . . . 1414
9.44.6.6 pack_voice_SLQSVoiceALSSetLineSwitching . . . 1415
9.44.6.7 pack_voice_SLQSVoiceAnswerCall . . . 1415
9.44.6.8 pack_voice_SLQSVoiceBindSubscription . . . 1415
9.44.6.9 pack_voice_SLQSVoiceBurstDTMF . . . 1416
9.44.6.10 pack_voice_SLQSVoiceDialCall . . . 1416
9.44.6.11 pack_voice_SLQSVoiceEndCall . . . 1417
9.44.6.12 pack_voice_SLQSVoiceGetAllCallInfo . . . 1417
9.44.6.13 pack_voice_SLQSVoiceGetCallBarring . . . 1417
9.44.6.14 pack_voice_SLQSVoiceGetCallForwardingStatus . . . 1418
9.44.6.15 pack_voice_SLQSVoiceGetCallInfo . . . 1418
9.44.6.16 pack_voice_SLQSVoiceGetCallWaiting . . . 1418
9.44.6.17 pack_voice_SLQSVoiceGetCLIP . . . 1419
9.44.6.18 pack_voice_SLQSVoiceGetCLIR . . . 1419
9.44.6.19 pack_voice_SLQSVoiceGetCNAP . . . 1419
9.44.6.20 pack_voice_SLQSVoiceGetCOLP . . . 1420
9.44.6.21 pack_voice_SLQSVoiceGetCOLR . . . 1420
9.44.6.22 pack_voice_SLQSVoiceGetConfig . . . 1420
9.44.6.23 pack_voice_SLQSVoiceIndicationRegister . . . 1421
9.44.6.24 pack_voice_SLQSVoiceManageCalls . . . 1421
9.44.6.25 pack_voice_SLQSVoiceOrigUSSDNoWait . . . 1421
9.44.6.26 pack_voice_SLQSVoiceSendFlash . . . 1422
9.44.6.27 pack_voice_SLQSVoiceSetCallBarringPassword . . . 1422
9.44.6.28 pack_voice_SLQSVoiceSetConfig . . . 1423
9.44.6.29 pack_voice_SLQSVoiceSetPreferredPrivacy . . . 1423
9.44.6.30 pack_voice_SLQSVoiceSetSUPSService . . . 1423
9.44.6.31 pack_voice_SLQSVoiceStartContDTMF . . . 1424
9.44.6.32 pack_voice_SLQSVoiceStopContDTMF . . . 1424
9.44.6.33 unpack_voice_allCallStatusCallback_ind . . . 1424
9.44.6.34 unpack_voice_AnswerUSSD . . . 1425
9.44.6.35 unpack_voice_CancelUSSD . . . 1425
9.44.6.36 unpack_voice_DTMFEventCallback_ind . . . 1425
9.44.6.37 unpack_voice_OriginateUSSD . . . 1426
9.44.6.38 unpack_voice_OTASPStatusCallback_ind . . . 1426
9.44.6.39 unpack_voice_SLQSOriginateUSSD . . . 1427
9.44.6.40 unpack_voice_SLQSVoiceALSSelectLine . . . 1427
9.44.6.41 unpack_voice_SLQSVoiceALSSetLineSwitching . . . 1427
9.44.6.42 unpack_voice_SLQSVoiceAnswerCall . . . 1428
9.44.6.43 unpack_voice_SLQSVoiceBindSubscription . . . 1428

9.44.6.44 unpack_voice_SLQSVoiceBurstDTMF . . . 1428
9.44.6.45 unpack_voice_SLQSVoiceDialCall . . . 1429
9.44.6.46 unpack_voice_SLQSVoiceEndCall . . . 1429
9.44.6.47 unpack_voice_SLQSVoiceGetAllCallInfo . . . 1429
9.44.6.48 unpack_voice_SLQSVoiceGetCallBarring . . . 1430
9.44.6.49 unpack_voice_SLQSVoiceGetCallForwardingStatus . . . 1430
9.44.6.50 unpack_voice_SLQSVoiceGetCallInfo . . . 1430
9.44.6.51 unpack_voice_SLQSVoiceGetCallWaiting . . . 1431
9.44.6.52 unpack_voice_SLQSVoiceGetCLIP . . . 1431
9.44.6.53 unpack_voice_SLQSVoiceGetCLIR . . . 1431
9.44.6.54 unpack_voice_SLQSVoiceGetCNAP . . . 1432
9.44.6.55 unpack_voice_SLQSVoiceGetCOLP . . . 1432
9.44.6.56 unpack_voice_SLQSVoiceGetCOLR . . . 1432
9.44.6.57 unpack_voice_SLQSVoiceGetConfig . . . 1433
9.44.6.58 unpack_voice_SLQSVoiceIndicationRegister . . . 1433
9.44.6.59 unpack_voice_SLQSVoiceManageCalls . . . 1433
9.44.6.60 unpack_voice_SLQSVoiceOrigUSSDNoWait . . . 1434
9.44.6.61 unpack_voice_SLQSVoiceSendFlash . . . 1434
9.44.6.62 unpack_voice_SLQSVoiceSetCallBarringPassword . . . 1434
9.44.6.63 unpack_voice_SLQSVoiceSetConfig . . . 1435
9.44.6.64 unpack_voice_SLQSVoiceSetPreferredPrivacy . . . 1435
9.44.6.65 unpack_voice_SLQSVoiceSetSUPSService . . . 1435
9.44.6.66 unpack_voice_SLQSVoiceStartContDTMF . . . 1436
9.44.6.67 unpack_voice_SLQSVoiceStopContDTMF . . . 1436
9.44.6.68 unpack_voice_SLQSVoiceSUPSCallback_ind . . . 1436
9.44.6.69 unpack_voice_SUPSNotificationCallback_ind . . . 1437
9.44.6.70 unpack_voice_USSDNotificationCallback_ind . . . 1437
9.44.6.71 unpack_voice_VoiceInfoRecCallback_ind . . . 1438
9.44.6.72 unpack_voice_voicePrivacyChangeCallback_ind . . . 1438
9.45 wds.h File Reference . . . 1438
9.45.1 Detailed Description . . . 1445
9.45.2 SO Mask . . . 1445
9.45.3 RAT Mask . . . 1445
9.45.4 Macro Definition Documentation . . . 1446
9.45.4.1 BYT_STAT_STAT_MASK . . . 1446
9.45.4.2 IPV6_ADDRESS_ARRAY_SIZE . . . 1446
9.45.4.3 MAX_WDS_3GPP_CONF_LTE_ATTACH_PROFILE_LIST_SIZE . . . 1446
9.45.4.4 PACK_WDS_IPV4 . . . 1446
9.45.4.5 PACK_WDS_IPV6 . . . 1446
9.45.4.6 WDS_DHCP_MAX_NUM_OPTIONS . . . 1446

9.45.4.7 WDS_DHCP_OPTION_DATA_BUF_SIZE . . . 1446
9.45.4.8 WDS_PROFILE_3GPP . . . 1446
9.45.4.9 WDS_PROFILE_3GPP2 . . . 1446
9.45.4.10 WDS_TFTID_SOURCE_IP_SIZE . . . 1446
9.45.5 Typedef Documentation . . . 1446
9.45.5.1 unpack_wds_DHCPv4ClientLeaseChange_t . . . 1446
9.45.5.2 unpack_wds_SetAutoconnect_t . . . 1446
9.45.5.3 unpack_wds_SetDefaultProfile_t . . . 1446
9.45.5.4 unpack_wds_SetDefaultProfileNum_t . . . 1446
9.45.5.5 unpack_wds_SetMobileIP_t . . . 1446
9.45.5.6 unpack_wds_SetMobileIPParameters_t . . . 1446
9.45.5.7 unpack_wds_SetMuxID_t . . . 1447
9.45.5.8 unpack_wds_SLQSResetPacketStatics_t . . . 1447
9.45.5.9 unpack_wds_SLQSSet3GPPConfigItem_t . . . 1447
9.45.5.10 unpack_wds_SLQSSetWdsEventCallback_t . . . 1447
9.45.5.11 unpack_wds_SLQSSSetDHCPv4ClientConfig_t . . . 1447
9.45.5.12 unpack_wds_SLQSSSetLoopback_t . . . 1447
9.45.5.13 unpack_wds_SLQSStopDataSession_t . . . 1447
9.45.5.14 unpack_wds_SLQSWdsGoActive_t . . . 1447
9.45.5.15 unpack_wds_SLQSWdsGoDormant_t . . . 1447
9.45.5.16 unpack_wds_SLQSWdsSetEventReport_t . . . 1447
9.45.5.17 UnpackQmiProfileInfo . . . 1447
9.45.6 Enumeration Type Documentation . . . 1447
9.45.6.1 liteQmiDataBearerMasks . . . 1447
9.45.7 Function Documentation . . . 1447
9.45.7.1 pack_wds_DHCPv4ClientLeaseChange . . . 1447
9.45.7.2 pack_wds_GetAutoconnect . . . 1448
9.45.7.3 pack_wds_GetByteTotals . . . 1448
9.45.7.4 pack_wds_GetConnectionRate . . . 1449
9.45.7.5 pack_wds_GetDataBearerTechnology . . . 1449
9.45.7.6 pack_wds_GetDefaultProfile . . . 1450
9.45.7.7 pack_wds_GetDefaultProfileNum . . . 1450
9.45.7.8 pack_wds_GetDormancyState . . . 1450
9.45.7.9 pack_wds_GetLastMobileIPError . . . 1451
9.45.7.10 pack_wds_GetMobileIP . . . 1451
9.45.7.11 pack_wds_GetMobileIPProfile . . . 1452
9.45.7.12 pack_wds_GetPacketStatistics . . . 1452
9.45.7.13 pack_wds_GetPacketStatus . . . 1453
9.45.7.14 pack_wds_GetSessionDuration . . . 1453
9.45.7.15 pack_wds_GetSessionState . . . 1453

9.45.7.16 pack_wds_RMSetTransferStatistics . . . 1454
9.45.7.17 pack_wds_SetAutoconnect . . . 1454
9.45.7.18 pack_wds_SetDefaultProfile . . . 1455
9.45.7.19 pack_wds_SetDefaultProfileNum . . . 1455
9.45.7.20 pack_wds_SetMobileIP . . . 1455
9.45.7.21 pack_wds_SetMobileIPParameters . . . 1456
9.45.7.22 pack_wds_SetMobileIPProfile . . . 1456
9.45.7.23 pack_wds_SetMuxID . . . 1457
9.45.7.24 pack_wds_SLQSCreateProfile . . . 1457
9.45.7.25 pack_wds_SLQSDeleteProfile . . . 1458
9.45.7.26 pack_wds_SLQSGet3GPPConfigItem . . . 1458
9.45.7.27 pack_wds_SLQSGetCurrDataSystemStat . . . 1458
9.45.7.28 pack_wds_SLQSGetCurrentChannelRate . . . 1459
9.45.7.29 pack_wds_SLQSGetDataBearerTechnology . . . 1459
9.45.7.30 pack_wds_SLQSGetDUNCallInfo . . . 1460
9.45.7.31 pack_wds_SLQSGetProfileSettings . . . 1460
9.45.7.32 pack_wds_SLQSGetRuntimeSettings . . . 1461
9.45.7.33 pack_wds_SLQSModifyProfile . . . 1461
9.45.7.34 pack_wds_SLQSResetPacketStatics . . . 1461
9.45.7.35 pack_wds_SLQSSet3GPPConfigItem . . . 1462
9.45.7.36 pack_wds_SLQSSetIPFamilyPreference . . . 1462
9.45.7.37 pack_wds_SLQSSetWdsEventCallback . . . 1463
9.45.7.38 pack_wds_SLQSSGetDHCPv4ClientConfig . . . 1463
9.45.7.39 pack_wds_SLQSSGetLoopback . . . 1463
9.45.7.40 pack_wds_SLQSSSetDHCPv4ClientConfig . . . 1464
9.45.7.41 pack_wds_SLQSSSetLoopback . . . 1464
9.45.7.42 pack_wds_SLQSStartDataSession . . . 1465
9.45.7.43 pack_wds_SLQSStopDataSession . . . 1465
9.45.7.44 pack_wds_SLQSWdsGoActive . . . 1465
9.45.7.45 pack_wds_SLQSWdsGoDormant . . . 1466
9.45.7.46 pack_wds_SLQSWdsSetEventReport . . . 1466
9.45.7.47 pack_wds_SLQSWdsSwiPDPRuntimeSettings . . . 1467
9.45.7.48 unpack_wds_DHCPv4ClientLease_ind . . . 1467
9.45.7.49 unpack_wds_DHCPv4ClientLeaseChange . . . 1467
9.45.7.50 unpack_wds_GetAutoconnect . . . 1468
9.45.7.51 unpack_wds_GetByteTotals . . . 1468
9.45.7.52 unpack_wds_GetConnectionRate . . . 1468
9.45.7.53 unpack_wds_GetDataBearerTechnology . . . 1469
9.45.7.54 unpack_wds_GetDefaultProfile . . . 1469
9.45.7.55 unpack_wds_GetDefaultProfileNum . . . 1470

9.45.7.56 unpack_wds_GetDormancyState . . . 1470
9.45.7.57 unpack_wds_GetLastMobileIPError . . . 1470
9.45.7.58 unpack_wds_GetMobileIP . . . 1471
9.45.7.59 unpack_wds_GetMobileIPProfile . . . 1471
9.45.7.60 unpack_wds_GetPacketStatistics . . . 1471
9.45.7.61 unpack_wds_GetPacketStatus . . . 1472
9.45.7.62 unpack_wds_GetSessionDuration . . . 1472
9.45.7.63 unpack_wds_GetSessionState . . . 1472
9.45.7.64 unpack_wds_RMSetTransferStatistics . . . 1473
9.45.7.65 unpack_wds_RMTransferStatistics_ind . . . 1473
9.45.7.66 unpack_wds_SetAutoconnect . . . 1473
9.45.7.67 unpack_wds_SetDefaultProfile . . . 1474
9.45.7.68 unpack_wds_SetDefaultProfileNum . . . 1474
9.45.7.69 unpack_wds_SetMobileIP . . . 1474
9.45.7.70 unpack_wds_SetMobileIPParameters . . . 1475
9.45.7.71 unpack_wds_SetMobileIPProfile . . . 1475
9.45.7.72 unpack_wds_SetMuxID . . . 1475
9.45.7.73 unpack_wds_SLQSCreateProfile . . . 1476
9.45.7.74 unpack_wds_SLQSDeleteProfile . . . 1476
9.45.7.75 unpack_wds_SLQSDUNCallInfoCallBack_ind . . . 1476
9.45.7.76 unpack_wds_SLQSGet3GPPConfigItem . . . 1477
9.45.7.77 unpack_wds_SLQSGetCurrDataSystemStat . . . 1477
9.45.7.78 unpack_wds_SLQSGetCurrentChannelRate . . . 1477
9.45.7.79 unpack_wds_SLQSGetDataBearerTechnology . . . 1478
9.45.7.80 unpack_wds_SLQSGetDUNCallInfo . . . 1478
9.45.7.81 unpack_wds_SLQSGetProfileSettings . . . 1478
9.45.7.82 unpack_wds_SLQSGetRuntimeSettings . . . 1479
9.45.7.83 unpack_wds_SLQSModifyProfile . . . 1479
9.45.7.84 unpack_wds_SLQSResetPacketStatics . . . 1479
9.45.7.85 unpack_wds_SLQSSet3GPPConfigItem . . . 1480
9.45.7.86 unpack_wds_SLQSSetIPFamilyPreference . . . 1480
9.45.7.87 unpack_wds_SLQSSetPacketSrvStatusCallback . . . 1480
9.45.7.88 unpack_wds_SLQSSetWdsEventCallback . . . 1481
9.45.7.89 unpack_wds_SLQSSetWdsEventCallback_ind . . . 1481
9.45.7.90 unpack_wds_SLQSSGetDHCPv4ClientConfig . . . 1481
9.45.7.91 unpack_wds_SLQSSGetLoopback . . . 1482
9.45.7.92 unpack_wds_SLQSSSetDHCPv4ClientConfig . . . 1482
9.45.7.93 unpack_wds_SLQSSSetLoopback . . . 1482
9.45.7.94 unpack_wds_SLQSStartDataSession . . . 1483
9.45.7.95 unpack_wds_SLQSStopDataSession . . . 1483

9.45.7.96 unpack_wds_SLQSWdsGoActive 1483
9.45.7.97 unpack_wds_SLQSWdsGoDormant 1484
9.45.7.98 unpack_wds_SLQSWdsSetEventReport 1484
9.45.7.99 unpack_wds_SLQSWdsSwiPDPRuntimeSettings 1484

Index **1486**

Chapter 1

Welcome to the Sierra Wireless Linux QMI SDK API Reference Guide

This API reference guide contains information about all the modules, in the Sierra Wireless Linux QMI SDK (SLQS). Use the tabs at the top of the page to navigate the reference guide.

- Modules tab – lists all the service modules and provides a link to the API header file in each module.
- References tab – links to reference material.

1.1 Important Notice

Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (i.e., have errors) or be totally lost. Although significant delays or losses of data are rare when wireless devices such as the Sierra Wireless modem are used in a normal manner with a well-constructed network, the Sierra Wireless modem should not be used in situations where failure to transmit or receive data could result in damage of any kind to the user or any other party, including but not limited to personal injury, death, or loss of property. Sierra Wireless accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using the Sierra Wireless modem, or for failure of the Sierra Wireless modem to transmit or receive such data.

1.2 Limitation of Liability

The information in this manual is subject to change without notice and does not represent a commitment on the part of Sierra Wireless. SIERRA WIRELESS AND ITS AFFILIATES SPECIFICALLY DISCLAIM LIABILITY FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS OR REVENUE OR ANTICIPATED PROFITS OR REVENUE ARISING OUT OF THE USE OR INABILITY TO USE ANY SIERRA WIRELESS PRODUCT, EVEN IF SIERRA WIRELESS AND/OR ITS AFFILIATES HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR THEY ARE FORESEEABLE OR FOR CLAIMS BY ANY THIRD PARTY.

Notwithstanding the foregoing, in no event shall Sierra Wireless and/or its affiliates aggregate liability arising under or in connection with the Sierra Wireless product, regardless of the number of events, occurrences, or claims giving rise to liability, be in excess of the price paid by the purchaser for the Sierra Wireless product.

1.3 Patents

Patents This product may contain technology developed by or for Sierra Wireless Inc. This product includes technology licensed from QUALCOMM® 3G. This product is manufactured or sold by Sierra Wireless Inc. or its affiliates

under one or more patents licensed from InterDigital Group.

1.4 Copyright

© 2011-2015 Sierra Wireless. All rights reserved.

1.5 Trademarks

AirCard® and Heart of the Wireless Machine® are registered trademarks of Sierra Wireless. Watcher® is a trademark of Sierra Wireless, registered in the European Community. Sierra Wireless, the Sierra Wireless logo, the red wave design, and the red-tipped antenna are trademarks of Sierra Wireless. Windows® is a registered trademark of Microsoft Corporation. QUALCOMM® is a registered trademark of QUALCOMM Incorporated. Used under license. Linux is a registered trademark of Linus Torvalds. Other trademarks are the property of the respective owners.

1.6 Contact Information

If you have any questions about the Sierra Wireless Linux SDK, contact your Sierra Wireless account manager.

Consult our website for up-to-date product descriptions, documentation, application notes, firmware upgrades, troubleshooting tips, and press releases: http://www.sierrawireless.com.

Chapter 2

Module Index

2.1 Modules

Here is a list of all modules:

QMI pack/unpack (lite-qmi) 29
Streaming Download Protocol (lite-fw) 30

Chapter 3

Namespace Index

3.1 Namespace List

Here is a list of all namespaces with brief descriptions:

Tables 31

Chapter 4

Data Structure Index

4.1 Data Structures

Here are the data structures with brief descriptions:

_litefw_FirmwareInfo_ . . . 33
altSrcInfo_t . . . 34
appStats . . . 35
audio_RXAGCList . . . 38
audio_RXAVCList . . . 39
audio_RXPCMIIRFltr . . . 39
audio_TXAGCList . . . 41
audio_TXPCMIIRFltr . . . 42
CarrierImage_t . . . 43
cat_AlPhaIdentifierTlv . . . 45
cat_commonEventTlv . . . 45
cat_currentCatEvent . . . 46
cat_EndProactiveSessionTlv . . . 47
cat_EventIDDataTlv . . . 47
cat_EventListTlv . . . 47
cat_RefreshTlv . . . 48
cdmaSSInfo . . . 48
connectionStatus . . . 49
crashInfoParams . . . 50
crashInformation . . . 50
currNetworkInfo . . . 51
dms_ActivationStatusTlv . . . 52
dms_OperatingModeTlv . . . 52
dms_PSMActiveTimerIndTlv . . . 53
dms_PSMActiveTimerTlv . . . 54
dms_PSMDurationDueToOOSTlv . . . 54
dms_PSMDurationThresholdTlv . . . 55
dms_PSMEarlyWakeupTimeTlv . . . 55
dms_PSMEnableStateIndTlv . . . 56
dms_PSMEnableStateTlv . . . 56
dms_PSMPeriodicUpdateTimerIndTlv . . . 57
dms_PSMPeriodicUpdateTimerTlv . . . 57
dms_PSMRandomizationWindowTlv . . . 58
dms_TemperatureTlv . . . 58
dms_UimAutoSwitchActSlotTlv . . . 59
dms_UimStatusTlv . . . 60
dms_VoltageTlv . . . 60
DMScustSettingInfo . . . 61

DMScustSettingList . . . 62
DMSgetCustomFeatureV2 . . . 63
DMSgetCustomInput . . . 63
dunchannelRate . . . 64
eriDataparams . . . 64
eTWSPLMNInfoTlv . . . 65
FMSImageElement . . . 65
FMSImageIdElement . . . 66
FMSImageIDEntries . . . 67
FMSImageList . . . 68
FMSPrefImageList . . . 69
hdrSSInfo . . . 69
image_info_t . . . 70
ims_AMRModeInfo . . . 71
ims_AMROctAlgnInfo . . . 72
ims_AMRWBModeInfo . . . 72
ims_AMRWBOctAlgnInfo . . . 73
ims_CSCFPortNameInfo . . . 73
ims_EnabAMRWBInfo . . . 74
ims_EnabSCRAMRInfo . . . 74
ims_EnabSCRAMRWBInfo . . . 75
ims_IMSDomainInfo . . . 75
ims_IMSTestModeInfo . . . 76
ims_MinSessExpInfo . . . 76
ims_PCSCFPortInfo . . . 77
ims_PhCtxtURIInfo . . . 77
ims_RngBkTmrInfo . . . 78
ims_RngTmrInfo . . . 78
ims_RTPRTCPInactTmrDurInfo . . . 79
ims_SessDurInfo . . . 79
ims_SigCompEnInfo . . . 80
ims_SIPPortInfo . . . 80
ims_SIPRegnTmrInfo . . . 81
ims_SMSFmtInfo . . . 81
ims_SMSoIPNwInfo . . . 82
ims_SubscrTmrInfo . . . 82
ims_TmrT1Info . . . 82
ims_TmrT2Info . . . 83
ims_TmrTfInfo . . . 83
imsa_IMSFailErrCodeTlv . . . 84
imsa_IMSRegStatusErrorCodeInfo . . . 84
imsa_IMSRegStatusInfo . . . 85
imsa_NewIMSRegStatusInfo . . . 86
imsa_RatHandoverStatusInfo . . . 86
imsa_SmsRatInfo . . . 87
imsa_SmsSvcStatusInfo . . . 88
imsa_UtRatInfo . . . 88
imsa_UtSvcStatusInfo . . . 89
imsa_VoipRatInfo . . . 89
imsa_VoipSvcStatusInfo . . . 90
imsa_VtRatInfo . . . 90
imsa_VtSvcStatusInfo . . . 91
ipv6AddressInfo . . . 91
LibPackGPRSRequestedQoS . . . 92
LibpackProfile3GPP . . . 92
LibpackProfile3GPP2 . . . 99
LibPackprofile_3GPP . . . 105
LibPackprofile_3GPP2 . . . 111

LibPackQosClassID . . . 116
LibPackTFTIDParams . . . 117
LibPackUMTSQoS . . . 119
LibPackUMTSReqQoSSigInd . . . 122
loc_accelAcceptReady . . . 122
loc_accelTempAcceptReady . . . 123
loc_BdsSV . . . 124
loc_BdsSVInfo . . . 124
loc_CellDb . . . 125
loc_ClkInfo . . . 126
loc_GnssData . . . 127
loc_gpsTime . . . 129
loc_gyroAcceptReady . . . 129
loc_gyroTempAcceptReady . . . 130
loc_IPv4Config . . . 131
loc_IPv4Info . . . 131
loc_IPv6Config . . . 132
loc_IPv6Info . . . 132
loc_LocApplicationInfo . . . 133
loc_precisionDilution . . . 134
loc_satelliteInfo . . . 135
loc_sensorDataUsage . . . 137
loc_SV . . . 138
loc_SVInfo . . . 139
loc_svUsedforFix . . . 139
loc_urlAddr . . . 140
loc_URLAddrInfo . . . 140
lteSSInfo . . . 141
messageModeTlv . . . 142
nas_acqOrderPref . . . 142
nas_AcqOrderPrefTlv . . . 143
nas_ActPilotPNElement . . . 144
nas_AddCDMASysInfo . . . 144
nas_AddSysInfo . . . 145
nas_BandPrefInfoTlv . . . 145
nas_BandPrefTlv . . . 146
nas_CallBarringSysInfo . . . 148
nas_callBarStatus . . . 148
nas_CDMAChannel . . . 149
nas_CDMAECIOThresh . . . 150
nas_CDMAInfo . . . 151
nas_CDMARSSIThresh . . . 152
nas_CDMASysInfo . . . 152
nas_CDMASysInfoExt . . . 156
nas_cellParams . . . 156
nas_ciotAcqOrderPref . . . 157
nas_CiotAcqOrderPrefTlv . . . 158
nas_CiotLteOpModePrefTlv . . . 159
nas_CommInfo . . . 159
nas_CSGID . . . 161
nas_CsgId . . . 162
nas_currentPLMN . . . 162
nas_dataSrvCapabilities . . . 163
nas_DataStatusDetail . . . 164
nas_detailSvcInfo . . . 166
nas_DeviceConfigDetail . . . 167
nas_dirNum . . . 168
nas_DRCParams . . . 168

nas_ecioListElement . . . 169
nas_ECIOThresh . . . 170
nas_EdrxCiotLteMode . . . 170
nas_EdrxCycleLength . . . 171
nas_EdrxEnableType . . . 171
nas_EdrxPagingTimeWindow . . . 172
nas_EdrxRatType . . . 172
nas_EmerModeTlv . . . 173
nas_errorRateListElement . . . 174
nas_ForbiddenNetworks3GPP . . . 175
nas_GERANInfo . . . 176
nas_geranInstInfo . . . 177
nas_gsmCellInfo . . . 178
nas_GSMRSSIThresh . . . 179
nas_GSMSrvStatusInfo . . . 180
nas_GSMSysInfo . . . 181
nas_GWAcqOrderPrefTlv . . . 184
nas_HDRECIOThresh . . . 184
nas_HDRIOThresh . . . 185
nas_HDRPersonality_Ind_Data . . . 185
nas_HDRRSSIThresh . . . 186
nas_HDRSINRThresh . . . 187
nas_HDRSINRThreshold . . . 187
nas_HDRSysInfo . . . 188
nas_homeSIDNID . . . 190
nas_infoInterFreq . . . 190
nas_IOThresh . . . 192
nas_lteBandPrefExt . . . 192
nas_LTEBandPrefTlv . . . 193
nas_lteEARFCN . . . 195
nas_lteGsmCellInfo . . . 195
nas_LTEInfo . . . 196
nas_LTEInfoInterfreq . . . 199
nas_LTEInfoIntrafreq . . . 199
nas_LTEInfoNeighboringGSM . . . 201
nas_LTEInfoNeighboringWCDMA . . . 202
nas_LteM1BandPrefTlv . . . 203
nas_LteNb1BandPrefTlv . . . 205
nas_LTEOperationMode . . . 207
nas_LteOpMode . . . 207
nas_ltePCI . . . 208
nas_lteRsrpinformation . . . 208
nas_LTERSRPThresh . . . 209
nas_LTERSRQThresh . . . 209
nas_LTERSSIThresh . . . 210
nas_LTESigRptCfg . . . 210
nas_LTESigRptConfig . . . 211
nas_lteSnrinformation . . . 212
nas_LTESNRThresh . . . 213
nas_LTESNRThreshold . . . 213
nas_LTESysInfo . . . 214
nas_lteWcdmaCellInfo . . . 216
nas_minBasedIMSI . . . 217
nas_MNRInfo . . . 218
nas_ModePrefTlv . . . 219
nas_namName . . . 219
nas_netSelectionPref . . . 220
nas_NetSelPrefTlv . . . 221

nas_NetworkStat1x . . . 221
nas_NetworkStatEVDO . . . 223
nas_nmrCellInfo . . . 225
nas_nr5gBandPref . . . 226
nas_operatorNameString . . . 227
nas_OperatorPLMNData . . . 227
nas_operatorPLMNList . . . 228
nas_PhyCaAggPcellInfo . . . 229
nas_PhyCaAggScellDlBw . . . 230
nas_PhyCaAggScellIndex . . . 230
nas_PhyCaAggScellIndType . . . 231
nas_PhyCaAggScellInfo . . . 231
nas_PilotSetData . . . 234
nas_PilotSetParams . . . 235
nas_PlmnID . . . 235
nas_PLMNNetworkName . . . 236
nas_PLMNNetworkNameData . . . 236
nas_PRLPrefTlv . . . 238
nas_protocolSubtypeElement . . . 239
nas_qaQmi3Gpp2TimeZone . . . 240
nas_QmiNas3GppNetworkInfo . . . 241
nas_QmiNas3GppNetworkRAT . . . 242
nas_QmisNasPcsDigit . . . 243
nas_QmisNasSlqsNasPCICellInfo . . . 244
nas_QmisNasSlqsNasPCIInfo . . . 245
nas_RankIndicatorTlv . . . 246
nas_RatDisabledMaskTlv . . . 246
nas_RejectReasonTlv . . . 247
nas_RFBandInfoElements . . . 247
nas_RfBandInfoExtFormat . . . 248
nas_RfBandInfoExtFormatElements . . . 249
nas_RfBandInfoList . . . 250
nas_RfBandwidthInfo . . . 250
nas_RfBandwidthInfoElements . . . 251
nas_RfDedicatedBandInfo . . . 252
nas_RfDedicatedBandInfoElements . . . 252
nas_RFInfoTlv . . . 253
nas_roamIndList . . . 254
nas_RoamPrefTlv . . . 255
nas_RSRPThresh . . . 255
nas_rsrqInformation . . . 256
nas_RSRQThresh . . . 256
nas_RSSIThresh . . . 257
nas_rxInfo . . . 258
nas_RxSigInfo . . . 259
nas_rxSignalStrengthListElement . . . 260
nas_SccRxInfo . . . 261
nas_serviceProviderName . . . 262
nas_servSystem . . . 263
nas_sidNid . . . 264
nas_SignalStrengthTlv . . . 265
nas_SLQSSignalStrengthsIndReq . . . 265
nas_SLQSSignalStrengthsInformation . . . 267
nas_SLQSSignalStrengthsTlv . . . 268
nas_SrvDomainPrefTlv . . . 269
nas_SrvStatusInfo . . . 269
nas_sysInfoCommon . . . 270
nas_TDSCDMAECIOThresh . . . 273

nas_TDSCDMARSCPThresh . . . 273
nas_TDSCDMARSSIThresh . . . 274
nas_TDSCDMASINRCONFThresh . . . 274
nas_TDSCDMASINRThresh . . . 275
nas_timeInfo . . . 275
nas_trueIMSI . . . 277
nas_txInfo . . . 278
nas_UMTSInfo . . . 278
nas_UMTSinstInfo . . . 280
nas_umtsLTENbrCell . . . 281
nas_UniversalTime . . . 282
nas_wcdmaCellInfo . . . 283
nas_WCDMAECIOThresh . . . 284
nas_WCDMAInfoLTENeighborCell . . . 284
nas_WCDMARSSIThresh . . . 285
nas_WCDMASysInfo . . . 286
nas_wcdmaUARFCN . . . 289
NASAcqOrderPrefTlv . . . 290
NASBandPreferenceTlv . . . 290
NASCiotAcqOrderPrefTlv . . . 291
NASCiotLteOpModePrefTlv . . . 291
NASEmergencyModeTlv . . . 291
NasGetLTECphyCaInfo . . . 292
NASGWAcqOrderPrefTlv . . . 293
NASLTEBandPreferenceTlv . . . 293
NASLteM1BandPrefTlv . . . 294
NASLteNasReleaseInfoTlv . . . 294
NASLteNB1BandPrefTlv . . . 295
NASModePreferenceTlv . . . 295
NASNetSelPreferenceTlv . . . 296
NASNr5gBandPrefTlv . . . 296
NASOTAMessageTlv . . . 297
NASPhyCaAggPcellInfo . . . 298
NASPhyCaAggScellDlBw . . . 298
NASPhyCaAggScellIndex . . . 299
NASPhyCaAggScellIndType . . . 299
NASPhyCaAggScellInfo . . . 300
NASPRLPreferenceTlv . . . 301
NASQmiCbkNasSwiOTAMessageInd . . . 302
NASQmiCbkNasSystemSelPrefInd . . . 302
NASRatDisabledMaskTlv . . . 305
NASRoamPreferenceTlv . . . 305
NASServDomainPrefTlv . . . 306
NASServingSystemInfo . . . 306
NASTimeInfoTlv . . . 307
newMTMessageTlv . . . 308
pack_audio_SLQSGetAudioPathConfig_t . . . 308
pack_audio_SLQSGetAudioProfile_t . . . 309
pack_audio_SLQSGetAudioVolTLBConfig_t . . . 310
pack_audio_SLQSSetAudioPathConfig_t . . . 310
pack_audio_SLQSSetAudioProfile_t . . . 312
pack_audio_SLQSSetAudioVolTLBConfig_t . . . 314
pack_cat_CATSendEnvelopeCommand_t . . . 314
pack_cat_CATSendTerminalResponse_t . . . 315
pack_cat_SetCATEventCallback_t . . . 316
pack_dms_ActivateAutomatic_t . . . 317
pack_dms_GetCustFeaturesV2_t . . . 317
pack_dms_ResetToFactoryDefaults_t . . . 318

pack_dms_SetActivationStatusCallback_t . . . 318
pack_dms_SetCrashAction_t . . . 318
pack_dms_SetCustFeature_t . . . 319
pack_dms_SetCustFeaturesV2_t . . . 321
pack_dms_SetEventReport_t . . . 322
pack_dms_SetIndicationRegister_t . . . 322
pack_dms_SetPower_t . . . 323
pack_dms_SetUSBComp_t . . . 324
pack_dms_SLQSDmsSwiIndicationRegister_t . . . 325
pack_dms_SLQSSetPowerSaveModeConfig_t . . . 325
pack_dms_SLQSSwiGetCrashInfo_t . . . 326
pack_dms_SLQSSwiSetDyingGaspCfg_t . . . 326
pack_dms_SLQSSwiSetHostDevInfo_t . . . 327
pack_dms_SLQSSwiSetOSInfo_t . . . 328
pack_dms_SwiSetEventReport_t . . . 328
pack_dms_SwiUimSelect_t . . . 329
pack_dms_UIMChangePIN_t . . . 329
pack_dms_UIMGetControlKeyStatus_t . . . 330
pack_dms_UIMGetICCID_t . . . 331
pack_dms_UIMSetControlKeyProtection_t . . . 331
pack_dms_UIMSetPINProtection_t . . . 332
pack_dms_UIMUnblockControlKey_t . . . 333
pack_dms_UIMUnblockPIN_t . . . 333
pack_dms_UIMVerifyPIN_t . . . 334
pack_fms_GetImagesPreference_t . . . 334
pack_fms_GetStoredImages_t . . . 335
pack_fms_SetImagesPreference_t . . . 335
pack_ims_SLQSImsConfigIndicationRegister_t . . . 336
pack_ims_SLQSSetIMSSMSConfig_t . . . 337
pack_ims_SLQSSetIMSUserConfig_t . . . 338
pack_ims_SLQSSetIMSVoIPConfig_t . . . 339
pack_ims_SLQSSetRegMgrConfig_t . . . 341
pack_ims_SLQSSetSIPConfig_t . . . 342
pack_imsa_SLQSRegisterIMSAIndication_t . . . 343
pack_loc_Delete_Assist_Data_t . . . 344
pack_loc_EventRegister_t . . . 345
pack_loc_SetExtPowerState_t . . . 347
pack_loc_SetOperationMode_t . . . 347
pack_loc_SLQSLOCGetBestAvailPos_t . . . 348
pack_loc_SLQSLOCGetServer_t . . . 349
pack_loc_SLQSLOCInjectPosition_t . . . 349
pack_loc_SLQSLOCInjectSensorData_t . . . 354
pack_loc_SLQSLOCInjectUTCTime_t . . . 356
pack_loc_SLQSLOCSetCradleMountConfig_t . . . 356
pack_loc_SLQSLOCSetServer_t . . . 357
pack_loc_Start_t . . . 358
pack_loc_Stop_t . . . 360
pack_nas_InitiateDomainAttach_t . . . 360
pack_nas_PerformNetworkScanPCI_t . . . 361
pack_nas_SetACCOLC_t . . . 361
pack_nas_SetCDMANetworkParameters_t . . . 361
pack_nas_SetNetworkPreference_t . . . 363
pack_nas_SLQSConfigSigInfo_t . . . 364
pack_nas_SLQSGetPLMNName_t . . . 365
pack_nas_SLQSInitiateNetworkRegistration_t . . . 366
pack_nas_SLQSNasConfigSigInfo2_t . . . 367
pack_nas_SLQSNasGet3GPP2Subscription_t . . . 372
pack_nas_SLQSNASGeteDRXParamsExt_t . . . 372

pack_nas_SLQSNasGetTxRxInfo_t . . . 373
pack_nas_SLQSNasIndicationRegisterExt_t . . . 373
pack_nas_SLQSNASSeteDRXParams_t . . . 376
pack_nas_SLQSNasSwiIndicationRegister_t . . . 378
pack_nas_SLQSNASSwiSetChannelLock_t . . . 379
pack_nas_SLQSSetBandPreference_t . . . 380
pack_nas_SLQSSetSignalStrengthsCallback_t . . . 382
pack_nas_SLQSSetSysSelectionPref_t . . . 382
pack_nas_SLQSSetSysSelectionPrefExt_t . . . 388
pack_nas_SLQSSwiPSDetach_t . . . 398
pack_pds_PDSInjectTimeReference_t . . . 398
pack_pds_ResetPDSData_t . . . 399
pack_pds_SetEventReportCallback_t . . . 400
pack_pds_SetPDSDefaults_t . . . 400
pack_pds_SetPDSState_t . . . 401
pack_pds_SetPortAutomaticTracking_t . . . 401
pack_pds_SetServiceAutomaticTracking_t . . . 402
pack_pds_SetXTRAAutomaticDownload_t . . . 402
pack_pds_SetXTRANetwork_t . . . 403
pack_pds_SLQSGetAGPSConfig_t . . . 403
pack_pds_SLQSPDSInjectAbsoluteTimeReference_t . . . 404
pack_pds_SLQSPDSInjectPositionData_t . . . 405
pack_pds_SLQSSetAGPSConfig_t . . . 407
pack_pds_SLQSSetPositionMethodState_t . . . 407
pack_pds_StartPDSTrackingSessionExt_t . . . 408
pack_qmi_t . . . 409
pack_qos_BindDataPort_t . . . 410
pack_qos_SLQSQosSwiReadApnExtraParams_t . . . 411
pack_qos_SLQSQosSwiReadDataStats_t . . . 411
pack_qos_SLQSSetQosEventCallback_t . . . 411
pack_rms_SetSMSWake_t . . . 412
pack_sar_SLQSSetRfSarState_t . . . 412
pack_sms_SaveSMS_t . . . 413
pack_sms_SendSMS_t . . . 414
pack_sms_SetNewSMSCallback_t . . . 415
pack_sms_SetSMSCAddress_t . . . 415
pack_sms_SLQSDeleteSMS_t . . . 415
pack_sms_SLQSGetSMS_t . . . 416
pack_sms_SLQSGetSmsBroadcastConfig_t . . . 417
pack_sms_SLQSGetSMSList_t . . . 417
pack_sms_SLQSModifySMSStatus_t . . . 418
pack_sms_SLQSSendAsyncSMS_t . . . 419
pack_sms_SLQSSetIndicationRegister_t . . . 419
pack_sms_SLQSSetSmsBroadcastActivation_t . . . 420
pack_sms_SLQSSetSmsBroadcastConfig_t . . . 420
pack_sms_SLQSSetSmsStorage_t . . . 421
pack_sms_SLQSSmsGetMaxStorageSize_t . . . 422
pack_sms_SLQSSmsSetRoutes_t . . . 422
pack_swiaudio_SLQSGetM2MAudioProfile_t . . . 422
pack_swiaudio_SLQSGetM2MAudioVolume_t . . . 423
pack_swiaudio_SLQSGetM2MAVMute_t . . . 423
pack_swiaudio_SLQSGetM2MSpkrGain_t . . . 424
pack_swiaudio_SLQSSetM2MAudioAVCFG_t . . . 424
pack_swiaudio_SLQSSetM2MAudioLPBK_t . . . 425
pack_swiaudio_SLQSSetM2MAudioProfile_t . . . 425
pack_swiaudio_SLQSSetM2MAudioVolume_t . . . 427
pack_swiaudio_SLQSSetM2MAVMute_t . . . 427
pack_swiaudio_SLQSSetM2MSpkrGain_t . . . 428

pack_swiavms_SLQSAVMSSendSelection_t . . . 429
pack_swiavms_SLQSAVMSSetSettings_t . . . 429
pack_swiavms_SLQSAVMSSetSettings_v2_t . . . 431
pack_swiavms_SLQSAVMSStartSession_t . . . 433
pack_swiavms_SLQSAVMSStopSession_t . . . 433
pack_swidms_SLQSSwiDmsSetMTU_t . . . 434
pack_swidms_SLQSSwiDmsSetUsbComp_t . . . 434
pack_swidms_SLQSSwiDmsSetUsbNetNum_t . . . 435
pack_swiloc_SwiLocSetAutoStart_t . . . 436
pack_swioma_SLQSOMADMCancelSession_t . . . 437
pack_swioma_SLQSOMADMCancelSessionExt_t . . . 438
pack_swioma_SLQSOMADMGetSessionInfo_t . . . 438
pack_swioma_SLQSOMADMSendSelection_t . . . 439
pack_swioma_SLQSOMADMSendSelectionExt_t . . . 439
pack_swioma_SLQSOMADMSetSettings_t . . . 440
pack_swioma_SLQSOMADMSetSettingsExt_t . . . 441
pack_swioma_SLQSOMADMStartSession_t . . . 442
pack_swioma_SLQSOMADMStartSessionExt_t . . . 442
pack_tmd_SLQSTmdDeRegNotMitigationLvl_t . . . 443
pack_tmd_SLQSTmdGetMitigationLvl_t . . . 443
pack_tmd_SLQSTmdRegNotMitigationLvl_t . . . 444
pack_uim_ChangePin_t . . . 444
pack_uim_ReadTransparent_t . . . 445
pack_uim_SetPinProtection_t . . . 447
pack_uim_SLQSUIMAuthenticate_t . . . 448
pack_uim_SLQSUIMDepersonalization_t . . . 448
pack_uim_SLQSUIMEventRegister_t . . . 449
pack_uim_SLQSUIMGetConfiguration_t . . . 449
pack_uim_SLQSUIMGetFileAttributes_t . . . 450
pack_uim_SLQSUIMPowerDown_t . . . 450
pack_uim_SLQSUIMPowerUp_t . . . 451
pack_uim_SLQSUIMRefreshComplete_t . . . 451
pack_uim_SLQSUIMRefreshGetLastEvent_t . . . 452
pack_uim_SLQSUIMRefreshOK_t . . . 452
pack_uim_SLQSUIMRefreshRegister_t . . . 453
pack_uim_SLQSUIMSwitchSlot_t . . . 453
pack_uim_UnblockPin_t . . . 454
pack_uim_VerifyPin_t . . . 455
pack_voice_AnswerUSSD_t . . . 456
pack_voice_OriginateUSSD_t . . . 457
pack_voice_SLQSOriginateUSSD_t . . . 457
pack_voice_SLQSVoiceALSSelectLine_t . . . 458
pack_voice_SLQSVoiceALSSetLineSwitching_t . . . 458
pack_voice_SLQSVoiceAnswerCall_t . . . 459
pack_voice_SLQSVoiceBindSubscription_t . . . 459
pack_voice_SLQSVoiceBurstDTMF_t . . . 459
pack_voice_SLQSVoiceDialCall_t . . . 460
pack_voice_SLQSVoiceEndCall_t . . . 462
pack_voice_SLQSVoiceGetCallBarring_t . . . 462
pack_voice_SLQSVoiceGetCallForwardingStatus_t . . . 463
pack_voice_SLQSVoiceGetCallInfo_t . . . 464
pack_voice_SLQSVoiceGetCallWaiting_t . . . 464
pack_voice_SLQSVoiceGetConfig_t . . . 465
pack_voice_SLQSVoiceIndicationRegister_t . . . 467
pack_voice_SLQSVoiceManageCalls_t . . . 467
pack_voice_SLQSVoiceOrigUSSDNoWait_t . . . 468
pack_voice_SLQSVoiceSendFlash_t . . . 469
pack_voice_SLQSVoiceSetCallBarringPassword_t . . . 469

pack_voice_SLQSVoiceSetConfig_t . . . 470
pack_voice_SLQSVoiceSetPreferredPrivacy_t . . . 472
pack_voice_SLQSVoiceSetSUPSService_t . . . 472
pack_voice_SLQSVoiceStartContDTMF_t . . . 474
pack_voice_SLQSVoiceStopContDTMF_t . . . 475
pack_wds_DHCPv4ClientLeaseChange_t . . . 475
pack_wds_GetDefaultProfile_t . . . 476
pack_wds_GetDefaultProfileNum_t . . . 476
pack_wds_GetDormancyState_t . . . 477
pack_wds_GetLastMobileIPError_t . . . 477
pack_wds_GetMobileIP_t . . . 477
pack_wds_GetMobileIPProfile_t . . . 477
pack_wds_GetPacketStatistics_t . . . 478
pack_wds_GetPacketStatus_t . . . 478
pack_wds_GetSessionDuration_t . . . 479
pack_wds_RMSetTransferStatistics_t . . . 479
pack_wds_SetAutoconnect_t . . . 480
pack_wds_SetDefaultProfile_t . . . 480
pack_wds_SetDefaultProfileNum_t . . . 482
pack_wds_SetMobileIP_t . . . 483
pack_wds_SetMobileIPParameters_t . . . 483
pack_wds_SetMobileIPProfile_t . . . 484
pack_wds_SLQSCreateProfile_t . . . 486
pack_wds_SLQSDeleteProfile_t . . . 487
pack_wds_SLQSGetCurrDataSystemStat_t . . . 487
pack_wds_SLQSGetDataBearerTechnology_t . . . 488
pack_wds_SLQSGetDUNCallInfo_t . . . 488
pack_wds_SLQSGetProfileSettings_t . . . 489
pack_wds_SLQSGetRuntimeSettings_t . . . 490
pack_wds_SLQSModifyProfile_t . . . 491
pack_wds_SLQSSet3GPPConfigItem_t . . . 492
pack_wds_SLQSSetIPFamilyPreference_t . . . 494
pack_wds_SLQSSetWdsEventCallback_t . . . 494
pack_wds_SLQSSGetDHCPv4ClientConfig_t . . . 495
pack_wds_SLQSSSetDHCPv4ClientConfig_t . . . 495
pack_wds_SLQSSSetLoopback_t . . . 496
pack_wds_SLQSStartDataSession_t . . . 496
pack_wds_SLQSStopDataSession_t . . . 498
pack_wds_SLQSWdsSetEventReport_t . . . 498
pack_wds_SLQSWdsSwiPDPRuntimeSettings_t . . . 500
PackCreateProfileOut . . . 500
packgetDyingGaspCfg . . . 501
packgetDyingGaspStatistics . . . 501
PackSwiAvmsSetSettingsAPNInfo . . . 502
PackSwiAvmsSetSettingsConnectionRetryTimers . . . 503
PackSwiAvmsSetSettingsPeriodInfo . . . 504
PackSwiAVMSSettingsAPNInfo . . . 504
PackSwiAVMSSettingsConnectionRetryTimers . . . 505
PackSwiAVMSSettingsPeriodsInfo . . . 506
qmiSmsMessageList . . . 506
qmiWDSDataBearerTechnology . . . 506
qmTlvResult . . . 507
qos_BindDataPortMuxID_t . . . 507
qos_BindDataPortPeripheralEndPointID_t . . . 508
qos_BindDataPortSIODataPort_t . . . 508
RFBandInfoElements . . . 509
rmTrasnferStaticsReq . . . 509
sensorData_t . . . 510

slot_t . . . 512
slotInf . . . 513
slots_t . . . 514
sms_BroadcastConfig . . . 515
sms_CDMABroadcastConfig . . . 515
sms_getIndicationReg . . . 516
sms_getMsgWaitingInfo . . . 517
sms_getTransLayerInfo . . . 517
sms_getTransNWRegInfo . . . 518
sms_maxStorageSizeReq . . . 519
sms_maxStorageSizeResp . . . 519
sms_messageWaitingInfoContent . . . 520
sms_msgProtocolResp . . . 521
sms_qaQmi3GPP2BroadcastCfgInfo . . . 521
sms_qaQmi3GPPBroadcastCfgInfo . . . 522
sms_routeEntry . . . 522
sms_sendAsyncsmsParams . . . 523
sms_setIndicationReg . . . 526
sms_setRoutesReq . . . 526
sms_transLayerInfo . . . 527
sMSCAddressInfo . . . 528
sMSCAddressTlv . . . 528
sMSEtwsMessageInfo . . . 529
sMSEtwsMessageTlv . . . 529
sMSEtwsPlmnInfo . . . 530
sMSMessageModeInfo . . . 530
sMSMTMessageInfo . . . 531
sMSOnIMSInfo . . . 531
sMSOnIMSTlv . . . 532
sMSTransferRouteMTMessageInfo . . . 532
swi_uint256_t . . . 533
swiaudio_PCMparams . . . 533
swidms_ehrpdMTUSizeTlv . . . 534
swidms_hrpdMTUSizeTlv . . . 534
swidms_intfaceCfgTlv . . . 535
swidms_mtuSize3gppTlv . . . 536
swidms_supportedIntBitmaskTlv . . . 537
swidms_usbMTUSizeTlv . . . 537
tdscdmaSigInfoExt . . . 538
tempData_t . . . 538
tmd_mitigationDevList . . . 540
transferRouteMessageTlv . . . 540
uim_appStatus . . . 541
uim_authenticateResult . . . 544
uim_authenticationData . . . 544
uim_cardResult . . . 545
uim_cardStatus . . . 546
uim_changeUIMPIN . . . 547
uim_depersonalizationInformation . . . 548
uim_encryptedPIN1 . . . 549
uim_fileAttributes . . . 550
uim_fileInfo . . . 553
uim_hotSwapStatus . . . 554
uim_personalizationStatus . . . 554
uim_readResult . . . 555
uim_readTransparentInfo . . . 556
uim_refreshevent . . . 556
uim_registerRefresh . . . 558

uim_remainingRetries . . . 559
uim_sessionInformation . . . 560
uim_setPINProtection . . . 560
uim_slotInfo . . . 561
uim_UIMSessionInformation . . . 563
uim_unblockUIMPIN . . . 564
uim_verifyUIMPIN . . . 565
unpack_audio_SLQSGetAudioPathConfig_t . . . 565
unpack_audio_SLQSGetAudioProfile_t . . . 568
unpack_audio_SLQSGetAudioVolTLBConfig_t . . . 569
unpack_audio_SLQSSetAudioVolTLBConfig_t . . . 569
unpack_cat_SetCatEventCallback_ind_t . . . 570
unpack_cat_SetCATEventCallback_t . . . 570
unpack_dms_GetActivationState_t . . . 571
unpack_dms_GetBandCapability_t . . . 572
unpack_dms_GetCrashAction_t . . . 574
unpack_dms_GetCustFeature_t . . . 575
unpack_dms_GetCustFeaturesV2_t . . . 577
unpack_dms_GetDeviceCap_t . . . 578
unpack_dms_GetDeviceCapabilities_t . . . 579
unpack_dms_GetDeviceHardwareRev_t . . . 581
unpack_dms_GetDeviceMfr_t . . . 582
unpack_dms_GetDeviceSerialNumbers_t . . . 582
unpack_dms_GetFirmwareInfo_t . . . 584
unpack_dms_GetFirmwareRevision_t . . . 586
unpack_dms_GetFirmwareRevisions_t . . . 587
unpack_dms_GetFSN_t . . . 588
unpack_dms_GetHardwareRevision_t . . . 589
unpack_dms_GetIMSI_t . . . 589
unpack_dms_GetManufacturer_t . . . 590
unpack_dms_GetModelID_t . . . 591
unpack_dms_GetNetworkTime_t . . . 591
unpack_dms_GetOfflineReason_t . . . 592
unpack_dms_GetPower_t . . . 593
unpack_dms_GetPRLVersion_t . . . 594
unpack_dms_GetSerialNumbers_t . . . 595
unpack_dms_GetUSBComp_t . . . 596
unpack_dms_GetVoiceNumber_t . . . 598
unpack_dms_PSMCfgChange_ind_t . . . 600
unpack_dms_ResetToFactoryDefaults_t . . . 600
unpack_dms_SetActivationStatusCallback_t . . . 601
unpack_dms_SetCrashAction_t . . . 601
unpack_dms_SetCustFeature_t . . . 602
unpack_dms_SetCustFeaturesV2_t . . . 602
unpack_dms_SetEventReport_ind_t . . . 603
unpack_dms_SetEventReport_t . . . 604
unpack_dms_SetFirmwarePreference_t . . . 604
unpack_dms_SetIndicationRegister_t . . . 605
unpack_dms_SetPower_t . . . 605
unpack_dms_SetUSBComp_t . . . 606
unpack_dms_SLQSDmsSwiGetPCInfo_t . . . 606
unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t . . . 609
unpack_dms_SLQSDmsSwiGetResetInfo_t . . . 610
unpack_dms_SLQSDmsSwiGetUimSelection_t . . . 611
unpack_dms_SLQSDmsSwiIndicationRegister_t . . . 612
unpack_dms_SLQSGetBandCapability_t . . . 613
unpack_dms_SLQSGetERIFile_t . . . 617
unpack_dms_SLQSGetPowerSaveModeConfig_t . . . 618

unpack_dms_SLQSSetPowerSaveModeConfig_t . . . 619
unpack_dms_SLQSSwiClearDyingGaspStatistics_t . . . 620
unpack_dms_SLQSSwiGetCrashInfo_t . . . 620
unpack_dms_SLQSSwiGetDyingGaspCfg_t . . . 621
unpack_dms_SLQSSwiGetDyingGaspStatistics_t . . . 622
unpack_dms_SLQSSwiGetFirmwareCurr_t . . . 622
unpack_dms_SLQSSwiGetFwUpdateStatus_t . . . 623
unpack_dms_SLQSSwiGetHostDevInfo_t . . . 625
unpack_dms_SLQSSwiGetOSInfo_t . . . 626
unpack_dms_SLQSSwiGetSerialNoExt_t . . . 627
unpack_dms_SLQSSwiSetDyingGaspCfg_t . . . 628
unpack_dms_SLQSSwiSetHostDevInfo_t . . . 628
unpack_dms_SLQSSwiSetOSInfo_t . . . 629
unpack_dms_SLQSUIMGetState_t . . . 629
unpack_dms_SwiEventReportCallBack_ind_t . . . 630
unpack_dms_SwiSetEventReport_t . . . 631
unpack_dms_SwiUimSelect_t . . . 631
unpack_dms_UIMGetControlKeyStatus_t . . . 632
unpack_dms_UIMGetICCID_t . . . 633
unpack_dms_UIMGetPINStatus_t . . . 633
unpack_dms_UIMSetControlKeyProtection_t . . . 635
unpack_dms_UIMSetPINProtection_t . . . 636
unpack_dms_UIMUnblockControlKey_t . . . 636
unpack_fms_GetImagesPreference_t . . . 637
unpack_fms_GetStoredImages_t . . . 638
unpack_fms_SetImagesPreference_t . . . 638
unpack_ims_SLQSGetIMSSMSConfig_t . . . 639
unpack_ims_SLQSGetIMSUserConfig_t . . . 640
unpack_ims_SLQSGetIMSVoIPConfig_t . . . 641
unpack_ims_SLQSGetRegMgrConfig_t . . . 644
unpack_ims_SLQSGetSIPConfig_t . . . 645
unpack_ims_SLQSRegMgrCfgCallBack_ind_t . . . 646
unpack_ims_SLQSSetIMSSMSConfig_t . . . 647
unpack_ims_SLQSSetIMSUserConfig_t . . . 648
unpack_ims_SLQSSetIMSVoIPConfig_t . . . 648
unpack_ims_SLQSSetRegMgrConfig_t . . . 649
unpack_ims_SLQSSetSIPConfig_t . . . 649
unpack_ims_SLQSSIPCfgCallBack_ind_t . . . 650
unpack_ims_SLQSSMSCfgCallBack_ind_t . . . 651
unpack_ims_SLQSUserCfgCallBack_ind_t . . . 652
unpack_ims_SLQSVoIPCfgCallBack_ind_t . . . 653
unpack_imsa_SLQSGetIMSARegStatus_t . . . 655
unpack_imsa_SLQSGetIMSAServiceStatus_t . . . 656
unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t . . . 658
unpack_imsa_SLQSImsaRatStatusCallBack_ind_t . . . 659
unpack_imsa_SLQSImsaRegStatusCallBack_ind_t . . . 660
unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t . . . 661
unpack_loc_BestAvailPos_Ind_t . . . 662
unpack_loc_CradleMountCallback_Ind_t . . . 669
unpack_loc_Delete_Assist_Data_t . . . 669
unpack_loc_DeleteAssistData_Ind_t . . . 670
unpack_loc_EngineState_Ind_t . . . 671
unpack_loc_EventNMEA_Ind_t . . . 672
unpack_loc_EventRegister_t . . . 673
unpack_loc_EventTimeSyncCallback_Ind_t . . . 673
unpack_loc_GetServer_Ind_t . . . 673
unpack_loc_GnssSvInfo_Ind_t . . . 675
unpack_loc_InjectPositionCallback_Ind_t . . . 676

unpack_loc_InjectSensorDataCallback_Ind_t . . . 676
unpack_loc_InjectTimeSyncDataCallback_Ind_t . . . 678
unpack_loc_InjectUTCTimeCallback_Ind_t . . . 679
unpack_loc_PositionRpt_Ind_t . . . 679
unpack_loc_SensorStreamingCallback_Ind_t . . . 686
unpack_loc_SetExtPowerConfig_Ind_t . . . 687
unpack_loc_SetExtPowerState_t . . . 688
unpack_loc_SetOperationMode_Ind_t . . . 689
unpack_loc_SetOperationMode_t . . . 689
unpack_loc_SetServer_Ind_t . . . 690
unpack_loc_SLQSLOCGetBestAvailPos_t . . . 691
unpack_loc_Start_t . . . 691
unpack_loc_Stop_t . . . 691
unpack_nas_GetACCOLC_t . . . 692
unpack_nas_GetANAAAAuthenticationStatus_t . . . 692
unpack_nas_GetCDMANetworkParameters_t . . . 693
unpack_nas_GetHomeNetwork3GPP2_t . . . 695
unpack_nas_GetHomeNetwork_t . . . 698
unpack_nas_GetNetworkPreference_t . . . 699
unpack_nas_GetRFInfo_t . . . 700
unpack_nas_GetServingNetwork_t . . . 701
unpack_nas_GetServingNetworkCapabilities_t . . . 704
unpack_nas_GetSignalStrengths_t . . . 705
unpack_nas_PerformNetworkScan_t . . . 706
unpack_nas_SetDataCapabilitiesCallback_ind_t . . . 707
unpack_nas_SetEventReportInd_t . . . 708
unpack_nas_SetNasLTECphyCaIndCallback_ind_t . . . 709
unpack_nas_SetNetworkPreference_t . . . 710
unpack_nas_SetRoamingIndicatorCallback_ind_t . . . 711
unpack_nas_SetServingSystemCallback_ind_t . . . 711
unpack_nas_SLQSGetErrorRate_t . . . 712
unpack_nas_SlqsGetLTECphyCAInfo_t . . . 713
unpack_nas_SLQSGetNetworkTime_t . . . 714
unpack_nas_SLQSGetOperatorNameData_t . . . 714
unpack_nas_SLQSGetPLMNName_t . . . 716
unpack_nas_SLQSGetServingSystem_t . . . 719
unpack_nas_SLQSGetSignalStrength_t . . . 723
unpack_nas_SLQSGetSysInfo_t . . . 726
unpack_nas_SLQSGetSysSelectionPref_t . . . 730
unpack_nas_SLQSGetSysSelectionPrefExt_t . . . 734
unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t . . . 737
unpack_nas_SLQSNasGet3GPP2Subscription_t . . . 738
unpack_nas_SLQSNasGetCellLocationInfo_t . . . 739
unpack_nas_SLQSNASGeteDRXParams_t . . . 741
unpack_nas_SLQSNASGeteDRXParamsExt_t . . . 742
unpack_nas_SLQSNASGetForbiddenNetworks_t . . . 743
unpack_nas_SLQSNasGetHDRColorCode_t . . . 744
unpack_nas_SLQSNasGetRFInfo_t . . . 744
unpack_nas_SLQSNasGetSigInfo_t . . . 745
unpack_nas_SLQSNasGetTxRxInfo_t . . . 746
unpack_nas_SLQSNasNetworkRejectCallback_Ind_t . . . 747
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t . . . 750
unpack_nas_SLQSNasSigInfoCallback_ind_t . . . 751
unpack_nas_SLQSNASSwiGetChannelLock_t . . . 753
unpack_nas_SLQSNasSwiModemStatus_t . . . 753
unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t . . . 754
unpack_nas_SLQSNasTimerCallback_ind_t . . . 755
unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t . . . 755

unpack_nas_SLQSSwiGetHDRPersonality_t . . . 756
unpack_nas_SLQSSwiGetHDRProtSubtype_t . . . 757
unpack_nas_SLQSSwiGetHRPDStats_t . . . 758
unpack_nas_SLQSSwiGetLteCQI_t . . . 759
unpack_nas_SLQSSwiGetLteSccRxInfo_t . . . 760
unpack_nas_SLQSSwiHDRPersonalityCallback_Ind_t . . . 760
unpack_nas_SLQSSwiNetworkDebug_t . . . 761
unpack_nas_SLQSSwiRandIndicatorCallback_Ind_t . . . 762
unpack_nas_SLQSSysInfoCallback_ind_t . . . 762
unpack_omaDmConfigTlv_t . . . 766
unpack_omaDmFotaTlv_t . . . 767
unpack_omaDmNotificationsTlv_t . . . 769
unpack_pds_GetPDSDefaults_t . . . 770
unpack_pds_GetPDSState_t . . . 771
unpack_pds_GetPortAutomaticTracking_t . . . 771
unpack_pds_GetServiceAutomaticTracking_t . . . 772
unpack_pds_GetXTRAAutomaticDownload_t . . . 773
unpack_pds_GetXTRANetwork_t . . . 773
unpack_pds_GetXTRAValidity_t . . . 774
unpack_pds_SetEventReport_Ind_t . . . 775
unpack_pds_SetPdsState_Ind_t . . . 777
unpack_pds_SLQSGetAGPSConfig_t . . . 777
unpack_pds_SLQSGetGPSStateInfo_t . . . 778
unpack_qmi_t . . . 783
unpack_qos_BindDataPort_t . . . 784
unpack_qos_dataRate_t . . . 784
unpack_qos_IPv4Addr_t . . . 785
unpack_qos_IPv6Addr_t . . . 785
unpack_qos_IPv6TrafCls_t . . . 786
unpack_qos_pktErrRate_t . . . 786
unpack_qos_Port_t . . . 787
unpack_qos_QosFlowInfo_t . . . 787
unpack_qos_QosFlowInfoState_t . . . 789
unpack_qos_SLQSQosGetNetworkStatus_t . . . 789
unpack_qos_SLQSQosSwiReadApnExtraParams_t . . . 790
unpack_qos_SLQSQosSwiReadDataStats_t . . . 791
unpack_qos_SLQSSetQosEventCallback_ind_t . . . 793
unpack_qos_SLQSSetQosEventCallback_t . . . 794
unpack_qos_SLQSSetQosNWStatusCallback_ind_t . . . 794
unpack_qos_SLQSSetQosPriEventCallback_ind_t . . . 795
unpack_qos_SLQSSetQosStatusCallback_ind_t . . . 795
unpack_qos_swiQosFilter_t . . . 797
unpack_qos_swiQosFlow_t . . . 800
unpack_qos_tokenBucket_t . . . 804
unpack_qos_Tos_t . . . 805
unpack_QosFlowStat_t . . . 805
unpack_result_t . . . 806
unpack_rms_GetSMSWake_t . . . 806
unpack_rms_SetSMSWake_t . . . 807
unpack_RMTransferStatistics_ind_t . . . 807
unpack_sar_SLQSGetRfSarState_t . . . 809
unpack_sms_GetSMSCAddress_t . . . 809
unpack_sms_SaveSMS_t . . . 810
unpack_sms_SendSMS_t . . . 811
unpack_sms_SetNewSMSCallback_ind_t . . . 811
unpack_sms_SetNewSMSCallback_t . . . 813
unpack_sms_SetSMSCAddress_t . . . 813
unpack_sms_SLQSDeleteSMS_t . . . 814

unpack_sms_SLQSGetIndicationRegister_t . . . 814
unpack_sms_SLQSGetMessageWaiting_t . . . 815
unpack_sms_SLQSGetSMS_t . . . 815
unpack_sms_SLQSGetSmsBroadcastConfig_t . . . 816
unpack_sms_SLQSGetSMSList_t . . . 817
unpack_sms_SLQSGetTransLayerInfo_t . . . 818
unpack_sms_SLQSGetTransNWRegInfo_t . . . 818
unpack_sms_SLQSModifySMSStatus_t . . . 819
unpack_sms_SLQSNWRegInfoCallback_ind_t . . . 819
unpack_sms_SLQSSendAsyncSMS_t . . . 820
unpack_sms_SLQSSetIndicationRegister_t . . . 820
unpack_sms_SLQSSetSmsBroadcastActivation_t . . . 821
unpack_sms_SLQSSetSmsBroadcastConfig_t . . . 821
unpack_sms_SLQSSetSmsStorage_t . . . 822
unpack_sms_SLQSSmsGetMaxStorageSize_t . . . 822
unpack_sms_SLQSSmsGetMessageProtocol_t . . . 823
unpack_sms_SLQSSmsSetRoutes_t . . . 823
unpack_sms_SLQSSwiGetSMSStorage_t . . . 824
unpack_sms_SLQSTransLayerInfoCallback_ind_t . . . 824
unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t . . . 825
unpack_sms_SLQSWmsMemoryFullCallBack_ind_t . . . 827
unpack_sms_SLQSWmsMessageWaitingCallBack_ind_t . . . 828
unpack_swiaudio_SLQSGetM2MAudioProfile_t . . . 828
unpack_swiaudio_SLQSGetM2MAudioVolume_t . . . 830
unpack_swiaudio_SLQSGetM2MAVMute_t . . . 830
unpack_swiaudio_SLQSGetM2MSpkrGain_t . . . 831
unpack_swiavms_SLQSAVMSEventReportInd_t . . . 832
unpack_swiavms_SLQSAVMSGetSettings_t . . . 833
unpack_swiavms_SLQSAVMSGetSettings_v2_t . . . 836
unpack_swiavms_SLQSAVMSSendSelection_t . . . 838
unpack_swiavms_SLQSAVMSSessionGetInfo_t . . . 839
unpack_swiavms_SLQSAvmsSetEventReport_t . . . 840
unpack_swiavms_SLQSAVMSSetSettings_t . . . 840
unpack_swiavms_SLQSAVMSSetSettings_v2_t . . . 841
unpack_swiavms_SLQSAVMSStartSession_t . . . 841
unpack_swiavms_SLQSAVMSStopSession_t . . . 842
unpack_swidms_SLQSSwiDmsGetMTU_t . . . 842
unpack_swidms_SLQSSwiDmsGetUsbComp_t . . . 843
unpack_swidms_SLQSSwiDmsGetUsbNetNum_t . . . 844
unpack_swidms_SLQSSwiDmsSetMTU_t . . . 844
unpack_swidms_SLQSSwiDmsSetUsbComp_t . . . 845
unpack_swiloc_SwiLocGetAutoStart_t . . . 845
unpack_swioma_SLQSOMADMAlertCallback_ind_t . . . 847
unpack_swioma_SLQSOMADMGetSessionInfo_t . . . 848
unpack_swioma_SLQSOMADMGetSettings_t . . . 851
unpack_swioma_SLQSOMADMStartSession_t . . . 853
unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t . . . 853
unpack_tmd_SLQSTmdGetMitigationDevList_t . . . 854
unpack_tmd_SLQSTmdGetMitigationLvl_t . . . 855
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t . . . 855
unpack_tmd_SLQSTmdRegNotMitigationLvl_t . . . 856
unpack_uim_ChangePin_t . . . 857
unpack_uim_GetCardStatus_t . . . 858
unpack_uim_ReadTransparent_t . . . 858
unpack_uim_SetPinProtection_t . . . 859
unpack_uim_SetUimSlotStatusChangeCallback_ind_t . . . 860
unpack_uim_SLQSUIMAuthenticate_t . . . 861
unpack_uim_SLQSUIMDepersonalization_t . . . 862

unpack_uim_SLQSUIMEventRegister_t . . . 862
unpack_uim_SLQSUIMGetConfiguration_t . . . 863
unpack_uim_SLQSUIMGetFileAttributes_t . . . 864
unpack_uim_SLQSUIMGetSlotsStatus_t . . . 864
unpack_uim_SLQSUIMRefreshCallback_Ind_t . . . 865
unpack_uim_SLQSUIMRefreshGetLastEvent_t . . . 866
unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t . . . 866
unpack_uim_UnblockPin_t . . . 867
unpack_uim_VerifyPin_t . . . 868
unpack_voice_allCallStatusCallback_ind_t . . . 869
unpack_voice_DTMFEventCallback_ind_t . . . 871
unpack_voice_OTASPStatusCallback_ind_t . . . 872
unpack_voice_SLQSOriginateUSSD_t . . . 873
unpack_voice_SLQSVoiceAnswerCall_t . . . 875
unpack_voice_SLQSVoiceBurstDTMF_t . . . 876
unpack_voice_SLQSVoiceDialCall_t . . . 876
unpack_voice_SLQSVoiceEndCall_t . . . 877
unpack_voice_SLQSVoiceGetAllCallInfo_t . . . 878
unpack_voice_SLQSVoiceGetCallBarring_t . . . 882
unpack_voice_SLQSVoiceGetCallForwardingStatus_t . . . 883
unpack_voice_SLQSVoiceGetCallInfo_t . . . 885
unpack_voice_SLQSVoiceGetCallWaiting_t . . . 888
unpack_voice_SLQSVoiceGetCLIP_t . . . 889
unpack_voice_SLQSVoiceGetCLIR_t . . . 891
unpack_voice_SLQSVoiceGetCNAP_t . . . 892
unpack_voice_SLQSVoiceGetCOLP_t . . . 894
unpack_voice_SLQSVoiceGetCOLR_t . . . 895
unpack_voice_SLQSVoiceGetConfig_t . . . 896
unpack_voice_SLQSVoiceManageCalls_t . . . 898
unpack_voice_SLQSVoiceSendFlash_t . . . 899
unpack_voice_SLQSVoiceSetCallBarringPassword_t . . . 900
unpack_voice_SLQSVoiceSetConfig_t . . . 901
unpack_voice_SLQSVoiceSetSUPSService_t . . . 903
unpack_voice_SLQSVoiceStartContDTMF_t . . . 904
unpack_voice_SLQSVoiceStopContDTMF_t . . . 904
unpack_voice_SLQSVoiceSUPSCallback_ind_t . . . 905
unpack_voice_SUPSNotificationCallback_ind_t . . . 908
unpack_voice_USSDNotificationCallback_ind_t . . . 910
unpack_voice_VoiceInfoRecCallback_ind_t . . . 910
unpack_voice_voicePrivacyChangeCallback_ind_t . . . 913
unpack_wds_DHCPv4ClientLease_ind_t . . . 914
unpack_wds_GetAutoconnect_t . . . 915
unpack_wds_GetByteTotals_t . . . 915
unpack_wds_GetConnectionRate_t . . . 916
unpack_wds_GetDataBearerTechnology_t . . . 917
unpack_wds_GetDefaultProfile_t . . . 918
unpack_wds_GetDefaultProfileNum_t . . . 921
unpack_wds_GetDormancyState_t . . . 921
unpack_wds_GetLastMobileIPError_t . . . 922
unpack_wds_GetMobileIP_t . . . 923
unpack_wds_GetMobileIPProfile_t . . . 923
unpack_wds_GetPacketStatistics_t . . . 925
unpack_wds_GetPacketStatus_t . . . 927
unpack_wds_GetSessionDuration_t . . . 929
unpack_wds_GetSessionState_t . . . 930
unpack_wds_RMSetTransferStatistics_t . . . 930
unpack_wds_SetMobileIPProfile_t . . . 931
unpack_wds_SLQSCreateProfile_t . . . 931

unpack_wds_SLQSDeleteProfile_t . . . 932
unpack_wds_SLQSDUNCallInfoCallBack_ind_t . . . 933
unpack_wds_SLQSGet3GPPConfigItem_t . . . 934
unpack_wds_SLQSGetCurrDataSystemStat_t . . . 936
unpack_wds_SLQSGetCurrentChannelRate_t . . . 937
unpack_wds_SLQSGetDataBearerTechnology_t . . . 938
unpack_wds_SLQSGetDUNCallInfo_t . . . 939
unpack_wds_SLQSGetProfileSettings_t . . . 942
unpack_wds_SLQSGetRuntimeSettings_t . . . 942
unpack_wds_SLQSModifyProfile_t . . . 946
unpack_wds_SLQSSetIPFamilyPreference_t . . . 946
unpack_wds_SLQSSetPacketSrvStatusCallback_t . . . 947
unpack_wds_SLQSSetWdsEventCallback_ind_t . . . 949
unpack_wds_SLQSSGetDHCPv4ClientConfig_t . . . 954
unpack_wds_SLQSSGetLoopback_t . . . 955
unpack_wds_SLQSStartDataSession_t . . . 956
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t . . . 957
UnPackGetProfileSettingOut . . . 959
UnpackSwiAvmsEventReportBinaryUpdateSessionInfo . . . 960
UnpackSwiAvmsEventReportConfig . . . 962
UnpackSwiAvmsEventReportConnectionRequest . . . 963
UnpackSwiAvmsEventReportDataSessionStatus . . . 963
UnpackSwiAvmsEventReportHTTPStatus . . . 964
UnpackSwiAvmsEventReportNotification . . . 966
UnpackSwiAvmsEventReportPackageID . . . 967
UnpackSwiAvmsEventReportRegStatus . . . 967
UnpackSwiAvmsEventReportSessionType . . . 968
UnpackSwiAvmsEventReportWAMSParamChange . . . 968
unpackWdsProfileParam . . . 969
voice_airTimer . . . 969
voice_allCallsAlphaIDInfo . . . 970
voice_allCallsDiagInfo . . . 970
voice_allCallsUUSInfo . . . 971
voice_alphaIDInfo . . . 971
voice_arrAlertingPattern . . . 972
voice_arrAlertingType . . . 973
voice_arrAlphaID . . . 974
voice_arrCalledPartyNum . . . 974
voice_arrCallEndReason . . . 975
voice_arrCallInfo . . . 976
voice_arrConnectPartyNum . . . 976
voice_arrDiagInfo . . . 977
voice_arrRedirPartyNum . . . 977
voice_arrRemotePartyName . . . 978
voice_arrRemotePartyNum . . . 978
voice_arrSvcOption . . . 979
voice_arrUUSInfo . . . 979
voice_burstDTMFInfo . . . 980
voice_calledPartyInfo . . . 981
voice_calledPartySubAdd . . . 982
voice_callerIDInfo . . . 983
voice_callFwdTypeAndPlan . . . 984
voice_callFWExtInfo . . . 985
voice_callFWInfo . . . 987
voice_callInfo . . . 988
voice_callingPartyInfo . . . 989
voice_ccSUPSType . . . 991
voice_CLIPResp . . . 992

voice_CLIRResp . . . 992
voice_CNAPResp . . . 993
voice_COLPResp . . . 994
voice_COLRResp . . . 994
voice_connectNumInfo . . . 995
voice_CUGInfo . . . 997
voice_curAMRConfig . . . 997
voice_diagInfo . . . 998
voice_DTMFInfo . . . 999
voice_DTMFLengths . . . 999
voice_ECTNum . . . 1000
voice_extDispRecInfo . . . 1001
voice_getAllCallInformation . . . 1002
voice_getAllCallRmtPtyName . . . 1002
voice_getAllCallRmtPtyNum . . . 1003
voice_getCallFWExtInfo . . . 1003
voice_getCallFWInfo . . . 1004
voice_lineCtrlInfo . . . 1004
voice_newPwdData . . . 1005
voice_NSSAudioCtrl . . . 1006
voice_peerNumberInfo . . . 1006
voice_prefVoiceSO . . . 1008
voice_redirNumInfo . . . 1010
voice_remotePartyName . . . 1012
voice_remotePartyNum . . . 1012
voice_roamTimer . . . 1013
voice_signalInfo . . . 1014
voice_SUPSInfo . . . 1015
voice_USSDNotificationNetworkInfo . . . 1015
voice_USSInfo . . . 1016
voice_UUSInfo . . . 1016
wds_channelRate . . . 1018
wds_ChannelRateTlv . . . 1018
wds_ConnStatusTlv . . . 1019
wds_currNetworkInfo . . . 1019
wds_DataBearTechTlv . . . 1020
wds_DataULongLongTlv . . . 1021
wds_DataULongTlv . . . 1021
wds_DHCPLeaseOptTlv . . . 1021
wds_DHCPLeaseStateTlv . . . 1022
wds_DHCPOpt . . . 1023
wds_DHCPProfileIdTlv . . . 1023
wds_DHCPv4HWConfig . . . 1024
wds_DHCPv4Option . . . 1024
wds_DHCPv4OptionList . . . 1025
wds_DHCPv4ProfileId . . . 1026
wds_Domain . . . 1026
wds_DomainNameList . . . 1027
wds_DormStatTlv . . . 1027
wds_GPRSQoS . . . 1028
wds_IPv4AdTlv . . . 1028
wds_IPV6AddressInfo . . . 1029
wds_IPV6GWAddressInfo . . . 1029
wds_LastMdmCallEndRsnTlv . . . 1030
wds_PCSCFFQDNAddress . . . 1031
wds_PCSCFFQDNAddressList . . . 1031
wds_PCSCFIPv4ServerAddressList . . . 1032
wds_ProfileIdentifier . . . 1032

wds_profileInfo 1033
wds_RXBytesOKTlv 1033
wds_transferStatInd 1034
wds_TrStatInd 1034
wds_TXBytesOKTlv 1035
wds_UMTSMinQoS 1035
wdsDhcpv4HwConfig 1038
wdsDhcpv4Option 1039
wdsDhcpv4OptionList 1039
wdsDhcpv4ProfileId 1040

Chapter 5

File Index

5.1 File List

Here is a list of all files with brief descriptions:

apdoxypages.c
Contains the module declaration for the Doxygen output. Also contains the content of the main page and related pages . . . 1041
audio.h . . . 1041
cat.h . . . 1047
common.h . . . 1050
dms.h . . . 1056
fms.h . . . 1116
ims.h . . . 1119
imsa.h . . . 1131
lite-fw.h . . . 1137
loc.h . . . 1147
nas.h . . . 1169
pds.h . . . 1229
qaGobiApiTableBandClasses.h
Network Access Service API Band Classes table . . . 1251
qaGobiApiTableCallControlReturnReasons.h
Call Control Return Reasons table . . . 1254
qaGobiApiTableCallEndReasons.h
Wireless Data Service Call End Reasons . . . 1255
qaGobiApiTableCarrierCodes.h
Carrier Codes table . . . 1271
qaGobiApiTableCodingScheme.h
Data Coding Scheme . . . 1273
qaGobiApiTableGpsCapabilityCodes.h
Position Determination Service API GPS Capability Codes . . . 1276
qaGobiApiTablePowerModes.h
Device Management Service API Power Modes table . . . 1277
qaGobiApiTableRadioInterfaces.h
Network Access Service API Radio Interfaces table . . . 1277
qaGobiApiTableRegionCodes.h
Region Codes table . . . 1278
qaGobiApiTableServiceOptions.h
Voice Service Options . . . 1278
qaGobiApiTableSupServiceInfoClasses.h
Voice Supplementary Service Information Classes . . . 1281
qaGobiApiTableSwiAudio.h
Swi Audio related tables . . . 1281

qaGobiApiTableSwiOMADMSessionStatus.h
Session Status table . . . 1282
qaGobiApiTableSwiOMADMUpdateCompleteStatus.h
Update Complete Status table . . . 1283
qaGobiApiTableVoiceCallEndReasons.h
Voice Service Call and supplementary services end reasons . . . 1284
qmerrno.h . . . 1291
qos.h . . . 1298
rms.h . . . 1308
sar.h . . . 1310
sms.h . . . 1312
swiaudio.h . . . 1334
swiavms.h . . . 1344
SwiDataTypes.h
SWI data types . . . 1358
swidms.h . . . 1359
swiloc.h . . . 1365
swioma.h . . . 1366
swiomaext.h . . . 1376
switype_256bit.h . . . 1381
SWIWWANCMAPI.h . . . 1383
tmd.h . . . 1383
uim.h . . . 1387
voice.h . . . 1406
wds.h . . . 1438

Chapter 6

Module Documentation

6.1 QMI pack/unpack (lite-qmi)

Files

- file common.h
- file dms.h
- file loc.h
- file nas.h
- file qos.h
- file sms.h
- file swioma.h
- file uim.h
- file wds.h
- file fms.h
- file swiloc.h
- file pds.h
- file rms.h
- file sar.h
- file swiavms.h
- file voice.h
- file cat.h
- file imsa.h
- file tmd.h
- file swiomaext.h
- file audio.h
- file swiaudio.h
- file ims.h
- file swidms.h

6.1.1 Detailed Description

6.2 Streaming Download Protocol (lite-fw)

Files

- file lite-fw.h

6.2.1 Detailed Description

Chapter 7

Namespace Documentation

7.1 Tables Namespace Reference

7.1.1 Detailed Description

Tables referenced in the API function headers:

- Table 1 - Call End Reason Codes The reason a call (either in process or connected) was ended. qaGobiApiTableCallEndReasons.h
- Table 2 - Carrier codes List of carrier identification codes. qaGobiApiTableCarrierCodes.h
- Table 3 - Region codes List of region identification codes. qaGobiApiTableRegionCodes.h
- Table 4 - GPS capability codes List of GPS capability codes. qaGobiApiTableGpsCapabilityCodes.h
- Table 5 - Radio Interfaces List of radio interface technologies. qaGobiApiTableRadioInterfaces.h
- Table 6 - Band classes List of band classes. qaGobiApiTableBandClasses.h
- Table 7 - Power modes List of operating modes. qaGobiApiTablePowerModes.h
- Table 8 - Service Options List of Service Options. qaGobiApiTableServiceOptions.h
- Table 9 - Voice Call End Reason List of Voice Call End Reason. qaGobiApiTableVoiceCallEndReasons.h
- Table 10 - Data Coding Scheme List of Data Coding Scheme. qaGobiApiTableCodingScheme.h
- Table 11 - Call Control Return Reasons List of Voice Call Control Return Reasons. qaGobiApiTableCallControlReturnReasons.h
- Table 12 - Supplementary Service Information Classes List of Voice Supplementary Service Information Classes. qaGobiApiTableSupServiceInfoClasses.h
- Table 13 - Audio Calibration Data Base(ACDB) Device List of ACDB devices. qaGobiApiTableSwiAudio.h
- Table 14 - PIFACE List of physical interfaces. qaGobiApiTableSwiAudio.h

Chapter 8

Data Structure Documentation

8.1 _litefw_FirmwareInfo_ Struct Reference

Data Fields

- char szModelid_str [20+1]
- char szFwversion_str [20+1]
- char szSku_str [20+1]
- char szPackageid_str [20+1]
- char szCarrier_str [20+1]
- char szCarrierPriversion_str [20+1]

8.1.1 Detailed Description

This structure contains information of the response parameters associated with a Read Transparent API.

Parameters

szModelid_str	• Model Name String
szFwversion_str	• Firmware Version String.
szSku_str	• SKU String.
szPackageid_str	• Package ID String.
szCarrier_str	• Carrier String.
szCarrier-Priversion_str	• Carrier PRI Version String.

8.1.2 Field Documentation

8.1.2.1 char _litefw_FirmwareInfo_::szCarrier_str[20+1]

8.1.2.2 char _litefw_FirmwareInfo_::szCarrierPriversion_str[20+1]

8.1.2.3 char _litefw_FirmwareInfo_::szFwversion_str[20+1]

8.1.2.4 char _litefw_FirmwareInfo_::szModelid_str[20+1]

8.1.2.5 char _litefw_FirmwareInfo_::szPackageid_str[20+1]

8.1.2.6 char _litefw_FirmwareInfo_::szSku_str[20+1]

8.2 altSrcInfo_t Struct Reference

Data Fields

- uint32_t source
- uint32_t linkage
- uint32_t coverage

8.2.1 Detailed Description

This structure specifies information regarding the altitude source

Parameters

source	• Specifies the source of the altitude • Valid values – 0 - Source is unknown – 1 - GPS is the source – 2 - Cell ID provided the source – 3 - Source is enhanced cell ID – 4 - Wi-Fi is the source – 5 - Terrestrial source – 6 - Hybrid terrestrial source – 7 - Altitude database is the source – 8 - Barometric altimeter is the source – 9 - Other sources
linkage	• Specifies the dependency between the horizontal and altitude position components • Valid values – 0 - Not specified – 1 - Fully interdependent – 2 - Depends on latitude and longitude – 3 - Fully independent

coverage	• Specifies the region of uncertainty. • Valid values – 0 - Not specified – 1 - Altitude uncertainty is valid at the injected horizontal position coordinates only – 2 - Altitude uncertainty applies to the position of the device regardless of horizontal position

8.2.2 Field Documentation

8.2.2.1 uint32_t altSrcInfo_t::coverage

8.2.2.2 uint32_t altSrcInfo_t::linkage

8.2.2.3 uint32_t altSrcInfo_t::source

8.3 appStats Struct Reference

Data Fields

- uint8_t appType
- uint8_t appState
- uint8_t persoState
- uint8_t persoFeature
- uint8_t persoRetries
- uint8_t persoUnblockRetries
- uint8_t aidLength
- uint8_t aidVal [255]
- uint8_t univPin
- uint8_t pin1State
- uint8_t pin1Retries
- uint8_t puk1Retries
- uint8_t pin2State
- uint8_t pin2Retries
- uint8_t puk2Retries

8.3.1 Detailed Description

This structure contains Application Status Information loaded on the card.

Parameters

appType	• Indicates the type of the application. – 0 - Unknown – 1 - SIM card – 2 - USIM application – 3 - RUIM card – 4 - CSIM application – 5 - ISIM application • Other values are reserved for the future and are to be handled as "Unknown".

appState	• Indicates the state of the application. – 0 - Unknown – 1 - Detected – 2 - PIN1 or UPIN is required – 3 - PUK1 or PUK for UPIN is required – 4 - Personalization state must be checked – 5 - PIN1 is blocked – 6 - Illegal – 7 - Ready
persoState	• Indicates the state of the personalization for the application. – 0 - Unknown – 1 - Personalization operation is in progress – 2 - Ready – 3 - Personalization code is required – 4 - PUK for personalization code is required – 5 - Permanently blocked
persoFeature	• Indicates the personalization feature. • This applies only when a personalization code is required to deactivate or unblock personalization. – 0 - GW network personalization – 1 - GW network subset personalization – 2 - GW service provider personalization – 3 - GW corporate personalization – 4 - GW UIM personalization – 5 - 1X network type 1 personalization – 6 - 1X network type 2 personalization – 7 - 1X HRPD personalization – 8 - 1X service provider personalization – 9 - 1X corporate personalization – 10 - 1X RUIM personalization – 11 - Unknown
persoRetries	• Indicates the number of retries remaining to disable the personalization.
persoUnblock-Retries	• Indicates the number of retries remaining to unblock the personalization.
aidLength	• Number of sets of the following elements. i.e. aidVal • If zero(0) then no aidVal information exists.
aidVal[MAX_DE-SCRIPTION_LE-NGTH]	• Application identifier value.

univPin	• Indicates whether UPIN replaces PIN1. – 0 - PIN1 is used – 1 - UPIN replaces PIN1
pin1State	• Indicates the state of PIN1. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked
pin1Retries	• Indicates the number of retries remaining to verify PIN1.
puk1Retries	• Indicates the number of retries remaining to unblock PIN1.
pin2State	• Indicates the state of PIN2. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked
pin2Retries	• Indicates the number of retries remaining to verify PIN2.
puk2Retries	• Indicates the number of retries remaining to unblock PIN2.

8.3.2 Field Documentation

8.3.2.1 uint8_t appStats::aidLength

8.3.2.2 uint8_t appStats::aidVal[255]

8.3.2.3 uint8_t appStats::appState

8.3.2.4 uint8_t appStats::appType

8.3.2.5 uint8_t appStats::persoFeature

8.3.2.6 uint8_t appStats::persoRetries

8.3.2.7 uint8_t appStats::persoState

8.3.2.8 uint8_t appStats::persoUnblockRetries

8.3.2.9 uint8_t appStats::pin1Retries

8.3.2.10 uint8_t appStats::pin1State

8.3.2.11 uint8_t appStats::pin2Retries

8.3.2.12 uint8_t appStats::pin2State

8.3.2.13 uint8_t appStats::puk1Retries

8.3.2.14 uint8_t appStats::puk2Retries

8.3.2.15 uint8_t appStats::univPin

8.4 audio_RXAGCList Struct Reference

Data Fields

- uint16_t * pRXStaticGain
- uint16_t * pRXAIG
- uint16_t * pRXExpThres
- uint16_t * pRXExpSlope
- uint16_t * pRXComprThres
- uint16_t * pRXComprSlope

8.4.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig parameters related to AV_RXAGCLIST.

Parameters

pRXStaticGain	• RX pre-compressor static gain
pRXAIG	• RX pre-compressor gain selection flag
pRXExpThres	• RX expansion threshold
pRXExpSlope	• RX expansion slope
pRXComprThres	• RX compression threshold
pRXComprSlope	• RX compression slope

8.4.2 Field Documentation

8.4.2.1 uint16_t* audio_RXAGCList::pRXAIG

8.4.2.2 uint16_t* audio_RXAGCList::pRXComprSlope

8.4.2.3 uint16_t* audio_RXAGCList::pRXComprThres

8.4.2.4 uint16_t* audio_RXAGCList::pRXExpSlope

8.4.2.5 uint16_t* audio_RXAGCList::pRXExpThres

8.4.2.6 uint16_t* audio_RXAGCList::pRXStaticGain

8.5 audio_RXAVCList Struct Reference

Data Fields

- uint16_t * pAVRXAVCSens
- uint16_t * pAVRXAVCHeadroom

8.5.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig parameters related to AV_RXAVCLIST.

Parameters

pAVRXAVC-Sens	• AVC variation from nominal sensitivity
pAVRXAVC-Headroom	• AVC headroom

8.5.2 Field Documentation

8.5.2.1 uint16_t* audio_RXAVCList::pAVRXAVCHeadroom

8.5.2.2 uint16_t* audio_RXAVCList::pAVRXAVCSens

8.6 audio_RXPCMIIRFltr Struct Reference

Data Fields

- uint16_t * pFlag
- uint16_t * pStageCnt
- uint8_t * pStage0Val
- uint8_t * pStage1Val
- uint8_t * pStage2Val
- uint8_t * pStage3Val
- uint8_t * pStage4Val

8.6.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig parameters related to AV_RXPCMIIRFLTR.

Parameters

pFlag	• Flag – 0x0000 - IIR filter disable – 0xffff - IIR filter enable
pStageCnt	• Stage Count – 0-4
pStage0Val	• A 20 BYTE sized parameter indicating Stage 0 value – A1 – A2 – B0 – B1 – B2
pStage1Val	• A 20 BYTE sized parameter indicating Stage 1 value – A1 – A2 – B0 – B1 – B2
pStage2Val	• A 20 BYTE sized parameter indicating Stage 2 value – A1 – A2 – B0 – B1 – B2
pStage3Val	• A 20 BYTE sized parameter indicating Stage 3 value – A1 – A2 – B0 – B1 – B2
pStage4Val	• A 20 BYTE sized parameter indicating Stage 4 value – A1 – A2 – B0 – B1 – B2

8.6.2 Field Documentation

8.6.2.1 uint16_t* audio_RXPCMIIRFltr::pFlag

8.6.2.2 uint8_t* audio_RXPCMIIRFltr::pStage0Val

8.6.2.3 uint8_t* audio_RXPCMIIRFltr::pStage1Val

8.6.2.4 uint8_t* audio_RXPCMIIRFltr::pStage2Val

8.6.2.5 uint8_t* audio_RXPCMIIRFltr::pStage3Val

8.6.2.6 uint8_t* audio_RXPCMIIRFltr::pStage4Val

8.6.2.7 uint16_t* audio_RXPCMIIRFltr::pStageCnt

8.7 audio_TXAGCList Struct Reference

Data Fields

- uint16_t * pTXStaticGain
- uint16_t * pTXAIG
- uint16_t * pTXExpThres
- uint16_t * pTXExpSlope
- uint16_t * pTXComprThres
- uint16_t * pTXComprSlope

8.7.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig parameters related to AV_TXAGCLIST.

Parameters

pTXStaticGain	• TX pre-compressor static gain
pTXAIG	• TX pre-compressor gain selection flag
pTXExpThres	• TX expansion threshold
pTXExpSlope	• TX expansion slope
pTXComprThres	• TX compression threshold
pTXComprSlope	• TX compression slope

8.7.2 Field Documentation

8.7.2.1 uint16_t* audio_TXAGCList::pTXAIG

8.7.2.2 uint16_t* audio_TXAGCList::pTXComprSlope

8.7.2.3 uint16_t* audio_TXAGCList::pTXComprThres

8.7.2.4 uint16_t* audio_TXAGCList::pTXExpSlope

8.7.2.5 uint16_t* audio_TXAGCList::pTXExpThres

8.7.2.6 uint16_t* audio_TXAGCList::pTXStaticGain

8.8 audio_TXPCMIIRFltr Struct Reference

Data Fields

- uint16_t * pFlag
- uint16_t * pStageCnt
- uint8_t * pStage0Val
- uint8_t * pStage1Val
- uint8_t * pStage2Val
- uint8_t * pStage3Val
- uint8_t * pStage4Val

8.8.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig parameters related to AV_TXPCMIIRFLTR.

Parameters

pFlag	• Flag – 0x0000 - IIR filter disable – 0xffff - IIR filter enable
pStageCnt	• Stage Count – 0-4
pStage0Val	• A 20 BYTE sized parameter indicating Stage 0 value – A1 – A2 – B0 – B1 – B2

pStage1Val	• A 20 BYTE sized parameter indicating Stage 1 value – A1 – A2 – B0 – B1 – B2
pStage2Val	• A 20 BYTE sized parameter indicating Stage 2 value – A1 – A2 – B0 – B1 – B2
pStage3Val	• A 20 BYTE sized parameter indicating Stage 3 value – A1 – A2 – B0 – B1 – B2
pStage4Val	• A 20 BYTE sized parameter indicating Stage 4 value – A1 – A2 – B0 – B1 – B2

8.8.2 Field Documentation

8.8.2.1 uint16_t* audio_TXPCMIIRFltr::pFlag

8.8.2.2 uint8_t* audio_TXPCMIIRFltr::pStage0Val

8.8.2.3 uint8_t* audio_TXPCMIIRFltr::pStage1Val

8.8.2.4 uint8_t* audio_TXPCMIIRFltr::pStage2Val

8.8.2.5 uint8_t* audio_TXPCMIIRFltr::pStage3Val

8.8.2.6 uint8_t* audio_TXPCMIIRFltr::pStage4Val

8.8.2.7 uint16_t* audio_TXPCMIIRFltr::pStageCnt

8.9 CarrierImage_t Struct Reference

Data Fields

- uint32_t m_nCarrierId
- uint32_t m_nFolderId
- uint32_t m_nStorage
- uint8_t m_FwImageId [100]
- uint8_t m_FwBuildId [100]
- uint8_t m_PriImageId [100]
- uint8_t m_PriBuildId [100]

8.9.1 Detailed Description

This structure contains the Carrier Image parameters.

Parameters

m_nCarrierId	• Unique numeric carrier ID indicating the carrier that the following images belong to
m_nFolderId	• Unique numeric folder ID indicating the folder where the images should reside on the host storage.
m_nStorage	• Information of storage type • Values – 0 - Device – 1 - Host
m_FwImageId	• Firmware image ID
m_FwBuildId	• Firmware build ID
m_PriImageId	• PRI image ID
m_PriBuildId	• PRI build ID

8.9.2 Field Documentation

8.9.2.1 uint8_t CarrierImage_t::m_FwBuildId[100]

8.9.2.2 uint8_t CarrierImage_t::m_FwImageId[100]

8.9.2.3 uint32_t CarrierImage_t::m_nCarrierId

8.9.2.4 uint32_t CarrierImage_t::m_nFolderId

8.9.2.5 uint32_t CarrierImage_t::m_nStorage

8.9.2.6 uint8_t CarrierImage_t::m_PriBuildId[100]

8.9.2.7 uint8_t CarrierImage_t::m_PriImageId[100]

8.10 cat_AlPhaIdentifierTlv Struct Reference

Data Fields

- uint8_t ReferenceID
- uint16_t AlphaIDLength
- uint8_t AlphaID [255]

8.10.1 Detailed Description

structure used to store all Alpha Identifier parameters.

Parameters

ReferenceID	- proactive command type that included the alpha identifier - 0x01; sends SMS proactive command
AlphaIDLength	- length of AlphaID (in bytes)
AlphaID	- alpha identifier, encoded as in ETSI TS 102 223 [Section 8.2]

8.10.2 Field Documentation

8.10.2.1 uint8_t cat_AlPhaIdentifierTlv::AlphaID[255]

8.10.2.2 uint16_t cat_AlPhaIdentifierTlv::AlphaIDLength

8.10.2.3 uint8_t cat_AlPhaIdentifierTlv::ReferenceID

8.11 cat_commonEventTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t EventID
- uint16_t EventLength
- union cat_currentCatEvent CatEvent

8.11.1 Detailed Description

Structure used to store all Common CAT Event TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
EventID	- Event ID. Can be any of the following 16 - Display Text 17 - Get In-Key 18 - Get Input 19 - Setup Menu 20 - Select Item 21 - Send SMS - Alpha Identifier 22 - Setup Event List 23 - Setup Idle Mode Text 24 - Language Notification 25 - Refresh 26 - End Proactive Session
EventLength	- Length of pData (in Bytes)
CatEvent	- Structure to the Data specific to the CAT event ID

8.11.2 Field Documentation

8.11.2.1 union cat_currentCatEvent cat_commonEventTlv::CatEvent

8.11.2.2 uint8_t cat_commonEventTlv::EventID

8.11.2.3 uint16_t cat_commonEventTlv::EventLength

8.11.2.4 uint8_t cat_commonEventTlv::TlvPresent

8.12 cat_currentCatEvent Union Reference

Data Fields

- struct cat_EventIDDataTlv CatEvIDData
- struct cat_AlPhaIdentifierTlv CatAlphaIdtfr
- struct cat_EventListTlv CatEventLst
- struct cat_RefreshTlv CatRefresh
- struct cat_EndProactiveSessionTlv CatEndPS

8.12.1 Detailed Description

Union used to represent the current CAT Event Data. Choose the structure based on the EventID received.

- Use cat_EventIDDataTlv if the Event ID is any of the below.
  - 16
  - 17
  - 18
  - 19
  - 20
  - 23
  - 24
- Use cat_AlPhaIdentifierTlv if the Event ID is 21
- Use cat_EventListTlv if the Event ID is 22
- Use cat_RefreshTlv if the Event ID is 25
- Use cat_EndProactiveSessionTlv if the Event ID is 26

8.12.2 Field Documentation

8.12.2.1 struct cat_AlPhaIdentifierTlv cat_currentCatEvent::CatAlphaIdtfr

8.12.2.2 struct cat_EndProactiveSessionTlv cat_currentCatEvent::CatEndPS

8.12.2.3 struct cat_EventListTlv cat_currentCatEvent::CatEventLst

8.12.2.4 struct cat_EventIDDataTlv cat_currentCatEvent::CatEvIDData

8.12.2.5 struct cat_RefreshTlv cat_currentCatEvent::CatRefresh

8.13 cat_EndProactiveSessionTlv Struct Reference

Data Fields

- uint8_t EndProactiveSession

8.13.1 Detailed Description

structure used to store End Proactive Session event parameters.

Parameters

EndProactive-Session	- The proactive session end type values are: • 0x01 - End proactive session command type received from the card • 0x02 - End proactive session internal to ME

8.13.2 Field Documentation

8.13.2.1 uint8_t cat_EndProactiveSessionTlv::EndProactiveSession

8.14 cat_EventIDDataTlv Struct Reference

Data Fields

- uint32_t ReferenceID
- uint16_t DataLength
- uint8_t Data [255]

8.14.1 Detailed Description

structure used to store all Common CAT Event parameters.

Parameters

ReferenceID	- proactive command reference ID.
DataLength	- length of pData (in Bytes)
Data	- command specific to the CAT event ID, encoded as in ETSI TS 102 223 [Section 6.6.X]

8.14.2 Field Documentation

8.14.2.1 uint8_t cat_EventIDDataTlv::Data[255]

8.14.2.2 uint16_t cat_EventIDDataTlv::DataLength

8.14.2.3 uint32_t cat_EventIDDataTlv::ReferenceID

8.15 cat_EventListTlv Struct Reference

Data Fields

- uint32_t SetupEventList

8.15.1 Detailed Description

structure used to store all Event List parameters.

Parameters

SetupEventList	- Setup event list bit mask • 0x00000001 - User Activity Notify • 0x00000002 - Idle Screen Available • 0x00000004 - Lang Selection Notify Each set bit indicates the availability of the corresponding event in Setup Event list proactive command; all unlisted bits are reserved for future use and will be ignored

8.15.2 Field Documentation

8.15.2.1 uint32_t cat_EventListTlv::SetupEventList

8.16 cat_RefreshTlv Struct Reference

Data Fields

- uint16_t RefreshMode
- uint8_t RefreshStage

8.16.1 Detailed Description

structure used to store all Refresh Event parameters.

Parameters

RefreshMode	- The Refresh Event as in ETSI TS 102 223 [Section 8.6]
RefreshStage	- Stage of a refresh procedure • 0x01 - Refresh start • 0x02 - Refresh success • 0x03 - Refresh failed

8.16.2 Field Documentation

8.16.2.1 uint16_t cat_RefreshTlv::RefreshMode

8.16.2.2 uint8_t cat_RefreshTlv::RefreshStage

8.17 cdmaSSInfo Struct Reference

Data Fields

- int8_t rssi
- int16_t ecio

8.17.1 Detailed Description

This structure contains the parameters for CDMA/WCDMA Signal Strength Information

Parameters

rssi	• RSSI in dBm (signed value). • A value of -125 dBm or lower is used to indicate No Signal.
ecio	• ECIO value representing negative 0.5 dBm increments, i.e., 2 means -1 dBm (14 means -7 dBm, 63 means -31.5 dBm).

8.17.2 Field Documentation

8.17.2.1 int16_t cdmaSSInfo::ecio

8.17.2.2 int8_t cdmaSSInfo::rssi

8.18 connectionStatus Struct Reference

Data Fields

- uint8_t MDMConnStatus
- uint64_t MDMCallDuration

8.18.1 Detailed Description

This structure contains modem connection status

Parameters

MDMConn-Status	• Current link status – 0x01 - DISCONNECTED – 0x02 - CONNECTED – 0xff - Invalid data.
MDMCall-Duration	• Call duration in milliseconds. • If the modem connection status is connected, this represent the duration of the current DUN call. • If the modem connection status is disconnected, this represents the duration of the last DUN call since the device was powered up (zero, if no call has been made or if the last call was not DUN). – 0xffffffffffffffff - Invalid data.

8.18.2 Field Documentation

8.18.2.1 uint64_t connectionStatus::MDMCallDuration

8.18.2.2 uint8_t connectionStatus::MDMConnStatus

8.19 crashInfoParams Struct Reference

Data Fields

- uint8_t crashStatus
- crashInformation crashInfo

8.19.1 Detailed Description

This structure contains crash information parameters

Parameters

crashStatus[OUT]	• Device Crash Status • 0 - no crash • 1 - crash has occurred
crashInfo[OUT]	• See crashInformation

8.19.2 Field Documentation

8.19.2.1 crashInformation crashInfoParams::crashInfo

8.19.2.2 uint8_t crashInfoParams::crashStatus

8.20 crashInformation Struct Reference

Data Fields

- uint16_t numCrashes
- uint32_t crashId
- uint32_t crashData
- uint16_t crashStrlen
- char crashString [255]
- uint16_t gcdumpStrlen
- char gcdumpString [1024]

8.20.1 Detailed Description

This structure contains crash information

Parameters

numCrashes[OUT]	• number of instances of the remaining fields
crashId[OUT]	• ramdom crash id assigned at crash

crashData	• crash data[OUT]
crashStrlen[IN/-OUT]	• length of the crashString field as an input, length of the crashString field returned by API as an OUTPUT
crashString	• crash string
gcdumpStrlen[O-UT]	• length of the gcdumpString field as an input, length of the gcdumpString field returned by API as an OUTPUT
gcdumpString[O-UT]	• gcdump string for the crash

8.20.2 Field Documentation

8.20.2.1 uint32_t crashInformation::crashData

8.20.2.2 uint32_t crashInformation::crashId

8.20.2.3 char crashInformation::crashString[255]

8.20.2.4 uint16_t crashInformation::crashStrlen

8.20.2.5 char crashInformation::gcdumpString[1024]

8.20.2.6 uint16_t crashInformation::gcdumpStrlen

8.20.2.7 uint16_t crashInformation::numCrashes

8.21 currNetworkInfo Struct Reference

Data Fields

- uint8_t NetworkType
- uint32_t RATMask
- uint32_t SOMask

8.21.1 Detailed Description

Network information structure

Parameters

NetworkType	• Values: – 0 - 3GPP – 1 - 3GPP2

RATMask	RAT Mask
SOMask	SO Mask

8.21.2 Field Documentation

8.21.2.1 uint8_t currNetworkInfo::NetworkType

8.21.2.2 uint32_t currNetworkInfo::RATMask

8.21.2.3 uint32_t currNetworkInfo::SOMask

8.22 dms_ActivationStatusTlv Struct Reference

Data Fields

- uint16_t TlvPresent
- uint32_t activationStatus

8.22.1 Detailed Description

Activation Status Tlv

Parameters

TlvPresent	• Tlv Present
activationStatus	• Service Activation Code – 0 - Service not activated – 1 - Service activated – 2 - Activation connecting – 3 - Activation connected – 4 - OTASP security authenticated – 5 - OTASP NAM downloaded – 6 - OTASP MDN downloaded – 7 - OTASP IMSI downloaded – 8 - OTASP PRL downloaded – 9 - OTASP SPC downloaded – 10 - OTASP settings committed

8.22.2 Field Documentation

8.22.2.1 uint32_t dms_ActivationStatusTlv::activationStatus

8.22.2.2 uint16_t dms_ActivationStatusTlv::TlvPresent

8.23 dms_OperatingModeTlv Struct Reference

Data Fields

- uint16_t TlvPresent
- uint32_t operatingMode

8.23.1 Detailed Description

Operating Mode Tlv

Parameters

TlvPresent	• Tlv Present
operatingMode	• 0 - Online • 1 - Low power • 2 - Factory test mode • 3 - Offline • 4 - Resetting • 5 - Shutting down • 6 - Persistent low power • 7 - Mode-only low power

8.23.2 Field Documentation

8.23.2.1 uint32_t dms_OperatingModeTlv::operatingMode

8.23.2.2 uint16_t dms_OperatingModeTlv::TlvPresent

8.24 dms_PSMActiveTimerIndTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t ActiveTimerInd

8.24.1 Detailed Description

This Structure used to store DMS PSM Active Timer TLV Value.

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
ActiveTimerInd	• Active Timer • PSM active timer value (in seconds).

8.24.2 Field Documentation

8.24.2.1 uint32_t dms_PSMActiveTimerIndTlv::ActiveTimerInd

8.24.2.2 uint8_t dms_PSMActiveTimerIndTlv::TlvPresent

8.25 dms_PSMActiveTimerTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t activeTimer

8.25.1 Detailed Description

This structure contains the parameters for Power Save Mode active timer.

Parameters

TlvPresent	• Tlv Present.
activeTimer	Active Timer • Power Save mode active timer value (in seconds).

8.25.2 Field Documentation

8.25.2.1 uint32_t dms_PSMActiveTimerTlv::activeTimer

8.25.2.2 uint8_t dms_PSMActiveTimerTlv::TlvPresent

8.26 dms_PSMDurationDueToOOSTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t durationDueToOOS

8.26.1 Detailed Description

This structure contains the parameters for Power Save Mode Duration due to an outage.

Parameters

TlvPresent	• Tlv Present.
durationDueTo-OOS	Duration Due to OOS • Power Save mode duration due to an outage (in seconds).

8.26.2 Field Documentation

8.26.2.1 uint32_t dms_PSMDurationDueToOOSTlv::durationDueToOOS

8.26.2.2 uint8_t dms_PSMDurationDueToOOSTlv::TlvPresent

8.27 dms_PSMDurationThresholdTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t durationThreshold

8.27.1 Detailed Description

This structure contains the parameters for Power Save Mode Duration Threshold.

Parameters

TlvPresent	• Tlv Present.
durationThreshold	Duration Threshold • Minimum duration for the device to benefit by entering PSM (in seconds).

8.27.2 Field Documentation

8.27.2.1 uint32_t dms_PSMDurationThresholdTlv::durationThreshold

8.27.2.2 uint8_t dms_PSMDurationThresholdTlv::TlvPresent

8.28 dms_PSMEarlyWakeupTimeTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t earlyWakeupTime

8.28.1 Detailed Description

This structure contains the parameters for Power Save Mode early wakeup time.

Parameters

TlvPresent	• Tlv Present.
earlyWakeupTime	• Early Wakeup Time • Power Save mode early wakeup time (in seconds) indicating how early the device should exit PSM to offset for bootup and acquisition delay.

8.28.2 Field Documentation

8.28.2.1 uint32_t dms_PSMEarlyWakeupTimeTlv::earlyWakeupTime

8.28.2.2 uint8_t dms_PSMEarlyWakeupTimeTlv::TlvPresent

8.29 dms_PSMEnableStateIndTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t EnableStateInd

8.29.1 Detailed Description

This Structure used to store DMS PSM Enable state TLV Value.

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
EnableStateInd	• PSM Enable State • Values – 0 - PSM is not enabled – 1 - PSM is enabled

8.29.2 Field Documentation

8.29.2.1 uint8_t dms_PSMEnableStateIndTlv::EnableStateInd

8.29.2.2 uint8_t dms_PSMEnableStateIndTlv::TlvPresent

8.30 dms_PSMEnableStateTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t enableState

8.30.1 Detailed Description

This structure contains the parameters for Power Save Mode Enable State.

Parameters

TlvPresent	• Tlv Present.

enableState	Power Save Mode Enable State Values • 0 - PSM is not enabled • 1 - PSM is enabled

8.30.2 Field Documentation

8.30.2.1 uint8_t dms_PSMEnableStateTlv::enableState

8.30.2.2 uint8_t dms_PSMEnableStateTlv::TlvPresent

8.31 dms_PSMPeriodicUpdateTimerIndTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t PeriodicUpdateTimerInd

8.31.1 Detailed Description

This Structure used to store DMS PSM Periodic Update Timer TLV Value.

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
PeriodicUpdate-TimerInd	• Periodic Update Timer • PSM periodic update timer value (in seconds).

8.31.2 Field Documentation

8.31.2.1 uint32_t dms_PSMPeriodicUpdateTimerIndTlv::PeriodicUpdateTimerInd

8.31.2.2 uint8_t dms_PSMPeriodicUpdateTimerIndTlv::TlvPresent

8.32 dms_PSMPeriodicUpdateTimerTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t periodicUpdateTimer

8.32.1 Detailed Description

This structure contains the parameters for Power Save Mode periodic update timer.

Parameters

TlvPresent	• Tlv Present.
periodicUpdate-Timer	Periodic Update Timer • Power Save mode periodic update timer value (in seconds).

8.32.2 Field Documentation

8.32.2.1 uint32_t dms_PSMPeriodicUpdateTimerTlv::periodicUpdateTimer

8.32.2.2 uint8_t dms_PSMPeriodicUpdateTimerTlv::TlvPresent

8.33 dms_PSMRandomizationWindowTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t randomizationWindow

8.33.1 Detailed Description

This structure contains the parameters for Power Save Mode wakeup randomization window.

Parameters

TlvPresent	• Tlv Present.
randomization-Window	Randomization Window • Power Save mode wakeup randomization window (in seconds)

8.33.2 Field Documentation

8.33.2.1 uint32_t dms_PSMRandomizationWindowTlv::randomizationWindow

8.33.2.2 uint8_t dms_PSMRandomizationWindowTlv::TlvPresent

8.34 dms_TemperatureTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t TempStat
- uint16_t Temperature

8.34.1 Detailed Description

This structure stores information about temperature TLV.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
TempStat	• Temperature state – 0 – unknown – 1 – normal – 2 – high (warning) – 3 – high (critical) – 4 – low (critical)
Temperature	• temperature in degree celsius

8.34.2 Field Documentation

8.34.2.1 uint16_t dms_TemperatureTlv::Temperature

8.34.2.2 uint8_t dms_TemperatureTlv::TempStat

8.34.2.3 uint8_t dms_TemperatureTlv::TlvPresent

8.35 dms_UimAutoSwitchActSlotTlv Struct Reference

Data Fields

- uint8_t uimAutoSwitchActSlot
- uint8_t TlvPresent

8.35.1 Detailed Description

This structure contains the TLV required to Get UIM auto active slot Tlv.

Parameters

uimAutoSwitch-ActSlot[Optional]	• When UIMAUTOSWITCH feature enabled and SIM auto-switch is activated, indicates currently active UIM slot. • Values – 0 - slot 1 (e.g. external SIM) – 1 - slot 2 (e.g. embedded SIM)
TlvPresent	• Tlv Present.

8.35.2 Field Documentation

8.35.2.1 uint8_t dms_UimAutoSwitchActSlotTlv::TlvPresent

8.35.2.2 uint8_t dms_UimAutoSwitchActSlotTlv::uimAutoSwitchActSlot

8.36 dms_UimStatusTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t intf
- uint8_t event

8.36.1 Detailed Description

This structure stores information about UIM status TLV.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
intf	• interface type – 0 - External UIM. – 1 - Embedded UIM. – 2 - Remote UIM.
event	• event type – 0 - UIM card removed. – 1 - UIM card inserted.

8.36.2 Field Documentation

8.36.2.1 uint8_t dms_UimStatusTlv::event

8.36.2.2 uint8_t dms_UimStatusTlv::intf

8.36.2.3 uint8_t dms_UimStatusTlv::TlvPresent

8.37 dms_VoltageTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t VoltStat
- uint16_t Voltage

8.37.1 Detailed Description

This structure stores information about voltage TLV.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
VoltStat	• Voltage state – 0 – unknown – 1 – normal – 2 – low (warning) – 3 – low (critical) – 4 – high (critical)
Voltage	• Voltage in mV

8.37.2 Field Documentation

8.37.2.1 uint8_t dms_VoltageTlv::TlvPresent

8.37.2.2 uint16_t dms_VoltageTlv::Voltage

8.37.2.3 uint8_t dms_VoltageTlv::VoltStat

8.38 DMScustSettingInfo Struct Reference

Data Fields

- uint16_t id_length
- uint8_t cust_id [64+1]
- uint16_t value_length
- uint8_t cust_value [8+1]
- uint16_t cust_attr

8.38.1 Detailed Description

This structure contains information about Customization Setting. This TLV is only applicable for 9x30 modules so far

Parameters

id_length	• length of cust_id field
cust_id	• Customization ID (Maximum 64 bytes) • NULL terminated ASCII string.
value_length	• length of cust_value field
cust_value	• Customization Setting Value (Maximum 8 bytes)

cust_attr	• Customization Setting attribute through QMI – bit 0: Values: * 0 - read only * 1 - read/write

8.38.2 Field Documentation

8.38.2.1 uint16_t DMScustSettingInfo::cust_attr

8.38.2.2 uint8_t DMScustSettingInfo::cust_id[64+1]

8.38.2.3 uint8_t DMScustSettingInfo::cust_value[8+1]

8.38.2.4 uint16_t DMScustSettingInfo::id_length

8.38.2.5 uint16_t DMScustSettingInfo::value_length

8.39 DMScustSettingList Struct Reference

Data Fields

- uint8_t list_type
- uint16_t num_instances
- DMScustSettingInfo custSetting [255+1]

8.39.1 Detailed Description

This structure contains the fields of TLV Customization Setting List. This TLV is only applicable for 9x30 modules so far

Parameters

list_type	• list type requested
num_instances	• number of instances of customization setting
custSetting	• See DMScustSettingInfo for more information

8.39.2 Field Documentation

8.39.2.1 DMScustSettingInfo DMScustSettingList::custSetting[255+1]

8.39.2.2 uint8_t DMScustSettingList::list_type

8.39.2.3 uint16_t DMScustSettingList::num_instances

8.40 DMSgetCustomFeatureV2 Struct Reference

Data Fields

- DMSgetCustomInput * pGetCustomInput
- DMScustSettingInfo * pCustSettingInfo
- DMScustSettingList * pCustSettingList

8.40.1 Detailed Description

This struture contains the TLV required to get the Customization Info and customization list.

Parameters

pGetCustom-Input[IN]	• See DMSgetCustomInput for more information
pCustSetting-Info[OUT]	• See DMScustSettingInfo for more information
pCustSetting-List[OUT]	• See DMScustSettingList for more information

8.40.2 Field Documentation

8.40.2.1 DMScustSettingInfo* DMSgetCustomFeatureV2::pCustSettingInfo

8.40.2.2 DMScustSettingList* DMSgetCustomFeatureV2::pCustSettingList

8.40.2.3 DMSgetCustomInput* DMSgetCustomFeatureV2::pGetCustomInput

8.41 DMSgetCustomInput Struct Reference

Data Fields

- uint8_t cust_id [64+1]
- uint8_t list_type

8.41.1 Detailed Description

This structure contains which customization id or the list type want to retrieve from modem. This TLV is only applicable for 9x30 modules so far

Parameters

cust_id	• Customization ID (Maximum 64 bytes) • NULL terminated ASCII string.
list_type	• list type requested

8.41.2 Field Documentation

8.41.2.1 uint8_t DMSgetCustomInput::cust_id[64+1]

8.41.2.2 uint8_t DMSgetCustomInput::list_type

8.42 dunchannelRate Struct Reference

Data Fields

- uint32_t CurrChanTxRate
- uint32_t CurrChanRxRate
- uint32_t MaxChanTxRate
- uint32_t MaxChanRxRate

8.42.1 Detailed Description

This structure contains Channel Rate

Parameters

CurrChanTxRate	• Instantaneous channel Tx rate in bits per second • 0xffffffff - Invalid data.
CurrChanRx-Rate	• Instantaneous channel Rx rate in bits per second • 0xffffffff - Invalid data.
MaxChanTxRate	• maximum Tx rate that can be assigned to the device by the serving system in bits per second • 0xffffffff - Invalid data.
MaxChanRx-Rate	• maximum Rx rate that can be assigned to the device by the serving system in bits per second • 0xffffffff - Invalid data.

8.42.2 Field Documentation

8.42.2.1 uint32_t dunchannelRate::CurrChanRxRate

8.42.2.2 uint32_t dunchannelRate::CurrChanTxRate

8.42.2.3 uint32_t dunchannelRate::MaxChanRxRate

8.42.2.4 uint32_t dunchannelRate::MaxChanTxRate

8.43 eriDataparams Struct Reference

Data Fields

- uint16_t eriDataLen

- uint8_t eriData [1024]

8.43.1 Detailed Description

This structure contains Extended Roaming Indicator(ERI) file parameters

Parameters

eriDataLen	• Upon input, the maximum number of bytes that file contents array can contain. • Upon successful output, actual number of bytes written to file contents array
eriData	• ERI data read from persistent storage(Max size is 1024)

8.43.2 Field Documentation

8.43.2.1 uint8_t eriDataparams::eriData[1024]

8.43.2.2 uint16_t eriDataparams::eriDataLen

8.44 eTWSPLMNInfoTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSEtwsPlmnInfo ETWSPLMNInfo

8.44.1 Detailed Description

This structure contains ETWS PLMN TLV information

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
ETWSPLMNInfo	• ETWS PLMN Information • See sMSEtwsPlmnInfo for more information

8.44.2 Field Documentation

8.44.2.1 sMSEtwsPlmnInfo eTWSPLMNInfoTlv::ETWSPLMNInfo

8.44.2.2 uint8_t eTWSPLMNInfoTlv::TlvPresent

8.45 FMSImageElement Struct Reference

Data Fields

- uint8_t imageType
- uint8_t imageId [100]
- uint8_t buildIdLength
- uint8_t buildId [100]

8.45.1 Detailed Description

This structure contains the Image Element information

Parameters

imageType	• Type of image 0 - Modem 1 - PRI
imageId	• Unique image identifier
buildIdLength	• Length of the build ID string (may be zero)
pBuildId	• Build ID ANSI string with length provided by the previous field

8.45.2 Field Documentation

8.45.2.1 uint8_t FMSImageElement::buildId[100]

8.45.2.2 uint8_t FMSImageElement::buildIdLength

8.45.2.3 uint8_t FMSImageElement::imageId[100]

8.45.2.4 uint8_t FMSImageElement::imageType

8.46 FMSImageIdElement Struct Reference

Data Fields

- uint8_t storageIndex
- uint8_t failureCount
- uint8_t imageID [100]
- uint8_t buildIDLength
- uint8_t buildID [100]

8.46.1 Detailed Description

This structure contains the Image ID list element Information

Parameters

storageIndex	• Index in storage where the image is located(a value of 0xFF indicates that the storage for this type of image is not relevant)
failureCount	• Number of consecutive write attempts to this storage index that have failed(a value of 0xFF indicates unspecified)
imageID	• Image unique identifier(max 16 chars.)
buildIDLength	• Length of the build ID string. If there is no build ID, this field will be 0 and no data will follow.
buildID	• String containing image build information(Max 100 characters)

8.46.2 Field Documentation

8.46.2.1 uint8_t FMSImageIdElement::buildID[100]

8.46.2.2 uint8_t FMSImageIdElement::buildIDLength

8.46.2.3 uint8_t FMSImageIdElement::failureCount

8.46.2.4 uint8_t FMSImageIdElement::imageID[100]

8.46.2.5 uint8_t FMSImageIdElement::storageIndex

8.47 FMSImageIDEntries Struct Reference

Data Fields

- uint8_t imageType
- uint8_t maxImages
- uint8_t executingImage
- uint8_t imageIDSize
- FMSImageIdElement imageIDElement [50]

8.47.1 Detailed Description

This structure contains the list entry Information

Parameters

imageType	• Type of image – 0 - Modem – 1 - PRI

maxImages	• Maximum number of images of this type that may be stored concurrently on the device
executingImage	• Index (into the next array) of image that is currently executing
imageIDSize	• The number of elements in the image ID list
imageIDElement	• Array of ImageIDElement Structure (Max 50 elements) • See FMSImageIdElement

8.47.2 Field Documentation

8.47.2.1 uint8_t FMSImageIDEntries::executingImage

8.47.2.2 FMSImageIdElement FMSImageIDEntries::imageIDElement[50]

8.47.2.3 uint8_t FMSImageIDEntries::imageIDSize

8.47.2.4 uint8_t FMSImageIDEntries::imageType

8.47.2.5 uint8_t FMSImageIDEntries::maxImages

8.48 FMSImageList Struct Reference

Data Fields

- uint8_t listSize
- FMSImageIDEntries imageIDEntries [2]

8.48.1 Detailed Description

This structure contains the Get Stored Images List

Parameters

listSize	• The number of elements in the image list
imageIDEntries	• Array of ImageIDEntries Structure (Max 2 entries)

8.48.2 Field Documentation

8.48.2.1 FMSImageIDEntries FMSImageList::imageIDEntries[2]

8.48.2.2 uint8_t FMSImageList::listSize

8.49 FMSPrefImageList Struct Reference

Data Fields

- uint8_t listSize
- FMSImageElement listEntries [2]

8.49.1 Detailed Description

This structure contains the Preference Image List information

Parameters

listSize	• The number of elements in the image list
pListEntries	• Array of Image entries with size provided by previous field • See FMSImageElement

8.49.2 Field Documentation

8.49.2.1 FMSImageElement FMSPrefImageList::listEntries[2]

8.49.2.2 uint8_t FMSPrefImageList::listSize

8.50 hdrSSInfo Struct Reference

Data Fields

- int8_t rssi
- int16_t ecio
- uint8_t sinr
- int32_t io

8.50.1 Detailed Description

This structure contains the parameters for HDR Signal Strength Information

Parameters

rssi	• RSSI in dBm (signed value). • A value of -125 dBm or lower is used to indicate No Signal.
ecio	• ECIO value representing negative 0.5 dBm increments, i.e., 2 means -1 dBm (14 means -7 dBm, 63 means -31.5 dBm).

sinr	• SINR level. • SINR is only applicable for 1xEV-DO. • Valid levels are 0 to 8, where the maximum value for: – 0 - SINR_LEVEL_0 is -9 dB – 1 - SINR_LEVEL_1 is -6 dB – 2 - SINR_LEVEL_2 is -4.5 dB – 3 - SINR_LEVEL_3 is -3 dB – 4 - SINR_LEVEL_4 is -2 dB – 5 - SINR_LEVEL_5 is +1 dB – 6 - SINR_LEVEL_6 is +3 dB – 7 - SINR_LEVEL_7 is +6 dB – 8 - SINR_LEVEL_8 is +9 dB – 0xFF - Not Available
io	• Received IO in dBm. • IO is only applicable for 1xEV-DO.

8.50.2 Field Documentation

8.50.2.1 int16_t hdrSSInfo::ecio

8.50.2.2 int32_t hdrSSInfo::io

8.50.2.3 int8_t hdrSSInfo::rssi

8.50.2.4 uint8_t hdrSSInfo::sinr

8.51 image_info_t Struct Reference

Data Fields

- uint8_t imageType
- uint8_t uniqueID [16]
- uint8_t buildIDLen
- uint8_t buildID [255]

8.51.1 Detailed Description

This structure is used to store image information

Parameters

imageType	• Image Type • Values: – 0 - FW – 1 - configuration

uniqueID	• Image Unique Identifier (ASCII characters)
buildIDLen	• Length of build ID string to follow • If set to zero, build ID string will be blank
buildID	• String containing image information(ASCII characters) • Maximum length of this string is 255 chars

8.51.2 Field Documentation

8.51.2.1 uint8_t image_info_t::buildID[255]

8.51.2.2 uint8_t image_info_t::buildIDLen

8.51.2.3 uint8_t image_info_t::imageType

8.51.2.4 uint8_t image_info_t::uniqueID[16]

8.52 ims_AMRModeInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t amrMode

8.52.1 Detailed Description

This structure store information about AMR NB mode.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
amrMode	Bitmask indicating AMR modes. Values: • 0x1 – 4.75 kbps • 0x2 – 5.15 kbps • 0x4 – 5.9 kbps • 0x8 – 6.17 kbps • 0x10 – 7.4 kbps • 0x20 – 7.95 kbps • 0x40 – 10.2 kbps • 0x80 – 12.2 kbps

8.52.2 Field Documentation

8.52.2.1 uint8_t ims_AMRModeInfo::amrMode

8.52.2.2 uint8_t ims_AMRModeInfo::TlvPresent

8.53 ims_AMROctAlgnInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t amrOctAlgn

8.53.1 Detailed Description

This structure store information about AMR NB octet aligned.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
amrOctAlgn	-1- if octet aligned -0- if octed not aligned

8.53.2 Field Documentation

8.53.2.1 uint8_t ims_AMROctAlgnInfo::amrOctAlgn

8.53.2.2 uint8_t ims_AMROctAlgnInfo::TlvPresent

8.54 ims_AMRWBModeInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t amrWBMode

8.54.1 Detailed Description

This structure store information about AMR WB mode.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
amrWBMode	Bitmask indicating AMR WB modes. Values: • 0x1 – 6.60 kbps • 0x2 – 8.85 kbps • 0x4 – 12.65 kbps • 0x8 – 14.25 kbps • 0x10 – 15.85 kbps • 0x20 – 18.25 kbps • 0x40 – 19.85 kbps • 0x80 – 23.05 kbps • 0x100 – 23.85 kbps

8.54.2 Field Documentation

8.54.2.1 uint16_t ims_AMRWBModeInfo::amrWBMode

8.54.2.2 uint8_t ims_AMRWBModeInfo::TlvPresent

8.55 ims_AMRWBOctAlgnInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t amrWBOctAlgn

8.55.1 Detailed Description

This structure store information about AMR WB octet aligned.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
amrWBOctAlgn	-1- if octet aligned -0- if octed not aligned

8.55.2 Field Documentation

8.55.2.1 uint8_t ims_AMRWBOctAlgnInfo::amrWBOctAlgn

8.55.2.2 uint8_t ims_AMRWBOctAlgnInfo::TlvPresent

8.56 ims_CSCFPortNameInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t cscfPortName [255]

8.56.1 Detailed Description

This structure hold parameters about CSCF port info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
cscfPortName	-CSCF port name string

8.56.2 Field Documentation

8.56.2.1 uint8_t ims_CSCFPortNameInfo::cscfPortName[255]

8.56.2.2 uint8_t ims_CSCFPortNameInfo::TlvPresent

8.57 ims_EnabAMRWBInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t amrWBEnable

8.57.1 Detailed Description

This structure store information about Enable AMR WB.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
amrWBEnable	-1- Enable -0- Disable

8.57.2 Field Documentation

8.57.2.1 uint8_t ims_EnabAMRWBInfo::amrWBEnable

8.57.2.2 uint8_t ims_EnabAMRWBInfo::TlvPresent

8.58 ims_EnabSCRAMRInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t scrAmrEnable

8.58.1 Detailed Description

This structure store information about Enable SCR AMR .

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
scrAmrEnable	-1- Enable -0- Disable

8.58.2 Field Documentation

8.58.2.1 uint8_t ims_EnabSCRAMRInfo::scrAmrEnable

8.58.2.2 uint8_t ims_EnabSCRAMRInfo::TlvPresent

8.59 ims_EnabSCRAMRWBInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t scrAmrWBEnable

8.59.1 Detailed Description

This structure store information about Enable SCR AMR WB.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
scrAmrWB-Enable	-1- Enable -0- Disable

8.59.2 Field Documentation

8.59.2.1 uint8_t ims_EnabSCRAMRWBInfo::scrAmrWBEnable

8.59.2.2 uint8_t ims_EnabSCRAMRWBInfo::TlvPresent

8.60 ims_IMSDomainInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t imsDomainName [255]

8.60.1 Detailed Description

This structure hold parameters about IMS domain info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0

imsDomain-Name	-IMS domain name string

8.60.2 Field Documentation

8.60.2.1 uint8_t ims_IMSDomainInfo::imsDomainName[255]

8.60.2.2 uint8_t ims_IMSDomainInfo::TlvPresent

8.61 ims_IMSTestModeInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t imsTestMode

8.61.1 Detailed Description

This structure hold parameters about ims test mode info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
imsTestMode	-1- if IMS test mode is enabled -0- if IMS test mode is disabled

8.61.2 Field Documentation

8.61.2.1 uint8_t ims_IMSTestModeInfo::imsTestMode

8.61.2.2 uint8_t ims_IMSTestModeInfo::TlvPresent

8.62 ims_MinSessExpInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t minSessExp

8.62.1 Detailed Description

This structure store information about minimum session expiry info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
minSessExp	• minimum session expiry in seconds

8.62.2 Field Documentation

8.62.2.1 uint16_t ims_MinSessExpInfo::minSessExp

8.62.2.2 uint8_t ims_MinSessExpInfo::TlvPresent

8.63 ims_PCSCFPortInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t priCSCFPort

8.63.1 Detailed Description

This structure hold parameters about primary CSCF port info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
priCSCFPort	• primary CSCF port number

8.63.2 Field Documentation

8.63.2.1 uint16_t ims_PCSCFPortInfo::priCSCFPort

8.63.2.2 uint8_t ims_PCSCFPortInfo::TlvPresent

8.64 ims_PhCtxtURIInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t PhCtxtURI [255]

8.64.1 Detailed Description

This structure hold parameters about Phone context URI info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
PhCtxtURI	-Phone context URI string

8.64.2 Field Documentation

8.64.2.1 uint8_t ims_PhCtxtURIInfo::PhCtxtURI[255]

8.64.2.2 uint8_t ims_PhCtxtURIInfo::TlvPresent

8.65 ims_RngBkTmrInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t RingBkTmr

8.65.1 Detailed Description

This structure hold parameters about Ring back timer.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
RingBkTmr	• Duration, in seconds, of the Ringback timer

8.65.2 Field Documentation

8.65.2.1 uint16_t ims_RngBkTmrInfo::RingBkTmr

8.65.2.2 uint8_t ims_RngBkTmrInfo::TlvPresent

8.66 ims_RngTmrInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t RingTmr

8.66.1 Detailed Description

This structure hold parameters about Ring timer.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
RingTmr	• Duration, in seconds, of the Ring timer

8.66.2 Field Documentation

8.66.2.1 uint16_t ims_RngTmrInfo::RingTmr

8.66.2.2 uint8_t ims_RngTmrInfo::TlvPresent

8.67 ims_RTPRTCPInactTmrDurInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t InactTmr

8.67.1 Detailed Description

This structure hold parameters about RTP/RTCP timer.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
InactTmr	• Duration, in seconds, of the RTP/RTCP inactivity timer

8.67.2 Field Documentation

8.67.2.1 uint16_t ims_RTPRTCPInactTmrDurInfo::InactTmr

8.67.2.2 uint8_t ims_RTPRTCPInactTmrDurInfo::TlvPresent

8.68 ims_SessDurInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t sessExp

8.68.1 Detailed Description

This structure store information about session duration info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
sessExp	• session duration in seconds

8.68.2 Field Documentation

8.68.2.1 uint16_t ims_SessDurInfo::sessExp

8.68.2.2 uint8_t ims_SessDurInfo::TlvPresent

8.69 ims_SigCompEnInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t SigCompEn

8.69.1 Detailed Description

This structure hold parameters about SigComp status.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
SigCompEn	-1- if SigComp is enabled -0- if IMS SigComp is disabled

8.69.2 Field Documentation

8.69.2.1 uint8_t ims_SigCompEnInfo::SigCompEn

8.69.2.2 uint8_t ims_SigCompEnInfo::TlvPresent

8.70 ims_SIPPortInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t SIPLocalPort

8.70.1 Detailed Description

This structure stores information about SIP port info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
SIPLocalPort	-SIP local port

8.70.2 Field Documentation

8.70.2.1 uint16_t ims_SIPPortInfo::SIPLocalPort

8.70.2.2 uint8_t ims_SIPPortInfo::TlvPresent

8.71 ims_SIPRegnTmrInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t tmrSIPRegn

8.71.1 Detailed Description

This structure stores information about SIP registration timer.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
tmrSIPRegn	-Initial SIP registration duration, in seconds

8.71.2 Field Documentation

8.71.2.1 uint8_t ims_SIPRegnTmrInfo::TlvPresent

8.71.2.2 uint32_t ims_SIPRegnTmrInfo::tmrSIPRegn

8.72 ims_SMSFmtInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t smsFormat

8.72.1 Detailed Description

This structure hold parameters about SMS format info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
smsFormat	• 0- IMS_SETTINGS_SMS_FORMAT_3GPP2 • 1- IMS_SETTINGS_SMS_FORMAT_3GPP

8.72.2 Field Documentation

8.72.2.1 uint8_t ims_SMSFmtInfo::smsFormat

8.72.2.2 uint8_t ims_SMSFmtInfo::TlvPresent

8.73 ims_SMSoIPNwInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t smsoIPNW

8.73.1 Detailed Description

This structure hold parameters about SMS over IP network.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
smsoIPNW	-1- if MO SMS turned on -0- if MO SMS turned off

8.73.2 Field Documentation

8.73.2.1 uint8_t ims_SMSoIPNwInfo::smsoIPNW

8.73.2.2 uint8_t ims_SMSoIPNwInfo::TlvPresent

8.74 ims_SubscrTmrInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t subscrTmr

8.74.1 Detailed Description

This structure stores information about subscriber timer.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
subscrTmr	-Duration, in seconds, of the subscription by the UE for IMS registration notifications.

8.74.2 Field Documentation

8.74.2.1 uint32_t ims_SubscrTmrInfo::subscrTmr

8.74.2.2 uint8_t ims_SubscrTmrInfo::TlvPresent

8.75 ims_TmrT1Info Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t tmrT1

8.75.1 Detailed Description

This structure stores information about timer T1.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
tmrT1	-RTT estimate, in milliseconds.

8.75.2 Field Documentation

8.75.2.1 uint8_t ims_TmrT1Info::TlvPresent

8.75.2.2 uint32_t ims_TmrT1Info::tmrT1

8.76 ims_TmrT2Info Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t tmrT2

8.76.1 Detailed Description

This structure stores information about timer T2.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
tmrT2	-Maximum retransmit interval, in msec, for non-invite requests and invite responses.

8.76.2 Field Documentation

8.76.2.1 uint8_t ims_TmrT2Info::TlvPresent

8.76.2.2 uint32_t ims_TmrT2Info::tmrT2

8.77 ims_TmrTfInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t tmrTf

8.77.1 Detailed Description

This structure store information about timer TF.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
tmrTf	-Non-invite transaction timeout timer, in msec

8.77.2 Field Documentation

8.77.2.1 uint8_t ims_TmrTfInfo::TlvPresent

8.77.2.2 uint32_t ims_TmrTfInfo::tmrTf

8.78 imsa_IMSFailErrCodeTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t ImsFailErrCode

8.78.1 Detailed Description

This structure hold parameters about IMS failure code for PDP connection.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
ImsFailErrCode	• 0 -IMSA_PDP_STATUS_OTHER_FAILURE – Generic failure reason • 1 -IMSA_PDP_STATUS_OPTION_UNSUBSCRIBED – Option is unsubscribed • 2 -IMSA_PDP_STATUS_UNKNOWN_PDP – PDP was unknown

8.78.2 Field Documentation

8.78.2.1 uint32_t imsa_IMSFailErrCodeTlv::ImsFailErrCode

8.78.2.2 uint8_t imsa_IMSFailErrCodeTlv::TlvPresent

8.79 imsa_IMSRegStatusErrorCodeInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t ErrorCode

8.79.1 Detailed Description

This structure hold parameters about IMS registration error info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
ErrorCode	Error codes when registration status is IMSA_STATUS_NOT_REGISTERED • Values: • 3xx – Redirection responses • 4xx – Client failure responses • 5xx – Server failure responses • 6xx – Global failure responses

8.79.2 Field Documentation

8.79.2.1 uint16_t imsa_IMSRegStatusErrorCodeInfo::ErrorCode

8.79.2.2 uint8_t imsa_IMSRegStatusErrorCodeInfo::TlvPresent

8.80 imsa_IMSRegStatusInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t ImsRegistered

8.80.1 Detailed Description

This structure hold parameters about IMS registration info (decprecated tlv).

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
ImsRegistered	• Values: • 0 -Not registered • 1- Registered

8.80.2 Field Documentation

8.80.2.1 uint8_t imsa_IMSRegStatusInfo::ImsRegistered

8.80.2.2 uint8_t imsa_IMSRegStatusInfo::TlvPresent

8.81 imsa_NewIMSRegStatusInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t ImsRegStatus

8.81.1 Detailed Description

This structure hold parameters about IMS registration info (new tlv).

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
ImsRegStatus	• Values: • 0 -IMSA_STATUS_NOT_REGISTERED- Not registered for IMS • 1- IMSA_STATUS_REGISTERING – Registering for IMS • 2- IMSA_STATUS_REGISTERED – Registered for IMS

8.81.2 Field Documentation

8.81.2.1 uint32_t imsa_NewIMSRegStatusInfo::ImsRegStatus

8.81.2.2 uint8_t imsa_NewIMSRegStatusInfo::TlvPresent

8.82 imsa_RatHandoverStatusInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t RatHandoverStatus
- uint32_t SourceRAT
- uint32_t TargetRAT
- uint8_t ErrorCodeLen
- uint8_t ErrorCodeData [256]

8.82.1 Detailed Description

This structure hold parameters about RAT handover status.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
RatHandover-Status	• RAT handover status

SourceRAT	• source RAT info: IWLAN/WWAN
TargetRAT	• target TAT info: IWLAN/WWAN
ErrorCodeLen	• error code length
ErrorCodeData	• handover failure code string when status is IMSA_STATUS_RAT_HO_FAILURE

8.82.2 Field Documentation

8.82.2.1 uint8_t imsa_RatHandoverStatusInfo::ErrorCodeData[256]

8.82.2.2 uint8_t imsa_RatHandoverStatusInfo::ErrorCodeLen

8.82.2.3 uint32_t imsa_RatHandoverStatusInfo::RatHandoverStatus

8.82.2.4 uint32_t imsa_RatHandoverStatusInfo::SourceRAT

8.82.2.5 uint32_t imsa_RatHandoverStatusInfo::TargetRAT

8.82.2.6 uint8_t imsa_RatHandoverStatusInfo::TlvPresent

8.83 imsa_SmsRatInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t SmsRatVal

8.83.1 Detailed Description

This structure hold parameters about SMS RAT info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
SmsRatVal	• Values: • 0-IMSA_WLAN – IMS service is registered on WLAN • 1-IMSA_WWAN – IMS service is registered on WWAN • 2-IMSA_IWLAN – IMS service is registered on interworking WLAN

8.83.2 Field Documentation

8.83.2.1 uint32_t imsa_SmsRatInfo::SmsRatVal

8.83.2.2 uint8_t imsa_SmsRatInfo::TlvPresent

8.84 imsa_SmsSvcStatusInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t SmsSvcStatus

8.84.1 Detailed Description

This structure hold parameters about SMS service info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
SmsSvcStatus	• Values: -0 – IMS SMS service is not available -1 – IMS SMS is in limited service -2 – IMS SMS is in full service

8.84.2 Field Documentation

8.84.2.1 uint32_t imsa_SmsSvcStatusInfo::SmsSvcStatus

8.84.2.2 uint8_t imsa_SmsSvcStatusInfo::TlvPresent

8.85 imsa_UtRatInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t UtRatVal

8.85.1 Detailed Description

This structure hold parameters about UT RAT info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
UtRatVal	• Values: • 0-IMSA_WLAN – IMS service is registered on WLAN • 1-IMSA_WWAN – IMS service is registered on WWAN • 2-IMSA_IWLAN – IMS service is registered on interworking WLAN

8.85.2 Field Documentation

8.85.2.1 uint8_t imsa_UtRatInfo::TlvPresent

8.85.2.2 uint32_t imsa_UtRatInfo::UtRatVal

8.86 imsa_UtSvcStatusInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t UtSvcStatus

8.86.1 Detailed Description

This structure hold parameters about UT service info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
UtSvcStatus	• Values: -0 – IMS UT service is not available -2 – IMS UT is in full service

8.86.2 Field Documentation

8.86.2.1 uint8_t imsa_UtSvcStatusInfo::TlvPresent

8.86.2.2 uint32_t imsa_UtSvcStatusInfo::UtSvcStatus

8.87 imsa_VoipRatInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t VoipRatVal

8.87.1 Detailed Description

This structure hold parameters about VOIP RAT info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
VoipRatVal	• Values: • 0-IMSA_WLAN – IMS service is registered on WLAN • 1-IMSA_WWAN – IMS service is registered on WWAN • 2-IMSA_IWLAN – IMS service is registered on interworking WLAN

8.87.2 Field Documentation

8.87.2.1 uint8_t imsa_VoipRatInfo::TlvPresent

8.87.2.2 uint32_t imsa_VoipRatInfo::VoipRatVal

8.88 imsa_VoipSvcStatusInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t VoipSvcStatus

8.88.1 Detailed Description

This structure hold parameters about VOIP service info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
VoipSvcStatus	• Values: -0 – IMS VOIP service is not available -2 – IMS VOIP is in full service

8.88.2 Field Documentation

8.88.2.1 uint8_t imsa_VoipSvcStatusInfo::TlvPresent

8.88.2.2 uint32_t imsa_VoipSvcStatusInfo::VoipSvcStatus

8.89 imsa_VtRatInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t VtRatVal

8.89.1 Detailed Description

This structure hold parameters about VT RAT info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
VtRatVal	• Values: • 0-IMSA_WLAN – IMS service is registered on WLAN • 1-IMSA_WWAN – IMS service is registered on WWAN • 2-IMSA_IWLAN – IMS service is registered on interworking WLAN

8.89.2 Field Documentation

8.89.2.1 uint8_t imsa_VtRatInfo::TlvPresent

8.89.2.2 uint32_t imsa_VtRatInfo::VtRatVal

8.90 imsa_VtSvcStatusInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t VtSvcStatus

8.90.1 Detailed Description

This structure hold parameters about VT service info.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
VtSvcStatus	• Values: -0 – IMS VT service is not available -2 – IMS VT is in full service

8.90.2 Field Documentation

8.90.2.1 uint8_t imsa_VtSvcStatusInfo::TlvPresent

8.90.2.2 uint32_t imsa_VtSvcStatusInfo::VtSvcStatus

8.91 ipv6AddressInfo Struct Reference

Data Fields

- uint8_t IPV6PrefixLen
- uint16_t IPAddressV6 [8]

8.91.1 Detailed Description

This structure contains the IPv6 address information

Parameters

IPV6PrefixLen	Length of the received IPv6 address • 0xff - Invalid IPv6 address information.
IPAddressV6	IPv6 address(in network byte order)

8.91.2 Field Documentation

8.91.2.1 uint16_t ipv6AddressInfo::IPAddressV6[8]

8.91.2.2 uint8_t ipv6AddressInfo::IPV6PrefixLen

8.92 LibPackGPRSRequestedQoS Struct Reference

Data Fields

- uint32_t precedenceClass
- uint32_t delayClass
- uint32_t reliabilityClass
- uint32_t peakThroughputClass
- uint32_t meanThroughputClass

8.92.1 Detailed Description

This structure contains the GPRS Quality Of Service Information

Parameters

precedence-Class	• Precedence class
delayClass	• Delay class
reliabilityClass	• Reliability class
peak-Throughput-Class	• Peak throughput class
mean-Throughput-Class	• Mean throughput class

8.92.2 Field Documentation

8.92.2.1 uint32_t LibPackGPRSRequestedQoS::delayClass

8.92.2.2 uint32_t LibPackGPRSRequestedQoS::meanThroughputClass

8.92.2.3 uint32_t LibPackGPRSRequestedQoS::peakThroughputClass

8.92.2.4 uint32_t LibPackGPRSRequestedQoS::precedenceClass

8.92.2.5 uint32_t LibPackGPRSRequestedQoS::reliabilityClass

8.93 LibpackProfile3GPP Struct Reference

Data Fields

- uint8_t * pProfilename

- uint16_t * pProfilenameSize
- uint8_t * pPDPtype
- uint8_t * pPdpHdrCompType
- uint8_t * pPdpDataCompType
- uint8_t * pAPNName
- uint16_t * pAPNnameSize
- uint32_t * pPriDNSIPv4AddPref
- uint32_t * pSecDNSIPv4AddPref
- LibPackUMTSQoS * pUMTSReqQoS
- LibPackUMTSQoS * pUMTSMinQoS
- LibPackGPRSRequestedQoS * pGPRSRequestedQos
- LibPackGPRSRequestedQoS * pGPRSMinimumQoS
- uint8_t * pUsername
- uint16_t * pUsernameSize
- uint8_t * pPassword
- uint16_t * pPasswordSize
- uint8_t * pAuthenticationPref
- uint32_t * pIPv4AddrPref
- uint8_t * pPcscfAddrUsingPCO
- uint8_t * pPdpAccessConFlag
- uint8_t * pPcscfAddrUsingDhcp
- uint8_t * pImCnFlag
- LibPackTFTIDParams * pTFTID1Params
- LibPackTFTIDParams * pTFTID2Params
- uint8_t * pPdpContext
- uint8_t * pSecondaryFlag
- uint8_t * pPrimaryID
- uint16_t * pIPv6AddPref
- LibPackUMTSReqQoSSigInd * pUMTSReqQoSSigInd
- LibPackUMTSReqQoSSigInd * pUMTSMinQosSigInd
- uint16_t * pPriDNSIPv6addpref
- uint16_t * pSecDNSIPv6addpref
- uint8_t * pAddrAllocPref
- LibPackQosClassID * pQosClassID
- uint8_t * pAPNDisabledFlag
- uint32_t * pPDNInactivTimeout
- uint8_t * pAPNClass
- uint8_t * pSupportEmergencyCalls

8.93.1 Detailed Description

This structure contains Input parameters of unpack_wds_SLQSGetProfileSettings_t Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

pProfileName	• One or more uint8_ts describing the profile • NULL pointer - Invalid data. • Bit to check in ParamPresenceMask - **16**
pProfilename-Size;	• This parameter is an input parameter and should be initialised to the size of pProfileName field. Size of this parameter is 2 uint8_ts. • Bit to check in ParamPresenceMask - **16**

pPDPType	• Packet Data Protocol (PDP) type specifies the type of data payload exchanged over the air link when the packet data session is established with this profile – 0x00 - PDP-IP (IPv4) – 0x01 - PDP-PPP – 0x02 - PDP-IPV6 – 0x03 - PDP-IPV4V6 • Bit to check in ParamPresenceMask - **17**
pPdpHdrCompType	• PDP header compression type – 0 - PDP header compression is OFF – 1 - Manufacturer preferred compression – 2 - PDP header compression based on RFC 1144 – 3 - PDP header compression based on RFC 25074 PDP header compression based on RFC 3095 • Bit to check in ParamPresenceMask - **18**
pPdpDataCompType	• PDP data compression type – 0 - PDP data compression is OFF – 1 - Manufacturer preferred compression – 2 - V.42BIS data compression – 3 - V.44 data compression • Bit to check in ParamPresenceMask - **19**
pAPNName	• Access point name • Bit to check in ParamPresenceMask - **20**
pAPNnameSize;	• This parameter is an input parameter and should be initialised to the size of pAPNName field. Size of this parameter is 2 uint8_ts. • Bit to check in ParamPresenceMask - **20**
pPriDNSIPv4AddPref	• Primary DNS IPv4 Address Preference • Bit to check in ParamPresenceMask - **21**
pSecDNSIPv4AddPref	• Secondary DNS IPv4 Address Preference • Bit to check in ParamPresenceMask - **22**
pUMTSReqQoS	• UMTS Requested QoS • Bit to check in ParamPresenceMask - **23**
pUMTSMinQoS	• UMTS Minimum QoS • Bit to check in ParamPresenceMask - **24**

pGPRS-RequestedQoS	• GPRS Requested QoS • Bit to check in ParamPresenceMask - **25**
pGPRS-MinimumQoS	• GPRS Minimum QoS • Bit to check in ParamPresenceMask - **26**
pUsername	• User name • Bit to check in ParamPresenceMask - **27**
pUsernameSize;	• This parameter is an input parameter and should be initialised to the size of pUsername field. Size of this parameter is 2 uint8_ts. • Bit to check in ParamPresenceMask - **27**
pPassword	• Password • Bit to check in ParamPresenceMask - **28**
pPasswordSize;	• This parameter is an input parameter and should be initialised to the size of pPassword field. Size of this parameter is 2 uint8_ts. • Bit to check in ParamPresenceMask - **28**
pAuthentication-Pref	• Authentication Preference – Bit map that indicates the authentication algorithm preference * Bit 0 - PAP preference · 0 - PAP is never performed · 1 - PAP may be performed * Bit 1 - CHAP preference · 0 - CHAP is never performed · 1 - CHAP may be performed * If more than one bit is set, then the device decides which authentication procedure is performed while setting up the data session. For example, the device may have a policy to select the most secure authentication mechanism. • Bit to check in ParamPresenceMask - **29**
pIPv4AddrPref	• IPv4 Address Preference • Bit to check in ParamPresenceMask - **30**
pPcscfAddr-UsingPCO	• P-CSCF Address using PCO Flag – 1 - (TRUE) implies request PCSCF address using PCO – 0 - (FALSE) implies do not request By default, this value is 0 • Bit to check in ParamPresenceMask - **31**

pPdpAccess-ConFlag	• PDP access control flag – 0 - PDP access control none – 1 - PDP access control reject – 2 - PDP access control permission • Bit to check in ParamPresenceMask - **32**
pPcscfAddr-UsingDhcp	• P-CSCF address using DHCP – 1 - (TRUE) implies Request PCSCF address using DHCP – 0 - (FALSE) implies do not request By default, value is 0 • Bit to check in ParamPresenceMask - **33**
pImCnFlag	• IM CN flag – 1 - (TRUE) implies request IM CN flag for this profile – 0 - (FALSE) implies do not request IM CN flag for this profile • Bit to check in ParamPresenceMask - **34**
pTFTID1Params	• Traffic Flow Template • Bit to check in ParamPresenceMask - **35**
pTFTID2Params	• Traffic Flow Template • Bit to check in ParamPresenceMask - **36**
pPdpContext	• PDP context number • Bit to check in ParamPresenceMask - **37**
pSecondaryFlag	• PDP context secondary flag – 1 - (TRUE) implies this is secondary profile – 0 - (FALSE) implies this is not secondary profile • Bit to check in ParamPresenceMask - **38**
pPrimaryID	• PDP context primary ID • function SLQSGetProfileSettings() returns a default value 0xFF if this parameter is not returned by the device • Bit to check in ParamPresenceMask - **39**
pIPv6AddPref	• IPv6 address preference Preferred IPv6 address to be assigned to the TE; actual assigned address is negotiated with the network and may differ from this value; if not specified, the IPv6 address is obtained automatically from the network • Bit to check in ParamPresenceMask - **40**

pUMTSReqQoS-SigInd	• UMTS requested QoS with Signalling Indication flag • Bit to check in ParamPresenceMask - **41**
pUMTSMinQoS-SigInd	• UMTS minimum QoS with Signalling Indication flag • Bit to check in ParamPresenceMask - **42**
pPrimaryDNSIPv6addpref	• Primary DNS IPv6 address preference – The value may be used as a preference during negotiation with the network; if not specified, the wireless device will attempt to obtain the DNS address automatically from the network; the negotiated value is provided to the host via DHCP • Bit to check in ParamPresenceMask - **43**
pSecondaryDNSIPv6addpref	• Secondary DNS IPv6 address preference • Bit to check in ParamPresenceMask - **44**
paddrAllocationPref	• DHCP/NAS preference – This enumerated value may be used to indicate the address allocation preference * 0 - NAS signaling is used for address allocation * 1 - DHCP is used for address allocation • Bit to check in ParamPresenceMask - **45**
pQosClassID	• 3GPP LTE QoS parameters • Bit to check in ParamPresenceMask - **46**
pAPNDisabledFlag	• Optional 1 uint8_t Flag indicating if the APN is disabled/enabled • If set, the profile can not be used for making data calls • Any data call is failed locally • Values: – 0 - FALSE(default) – 1 - True • This parameter is currently read only and can be read by using the function SLQSGetProfileSettings(). • Bit to check in ParamPresenceMask - **47**
pPDNInactivTimeout	• Optional 4 uint8_ts indicating the duration of inactivity timer in seconds • If the PDP context/PDN connection is inactive for this duration i.e. No data Tx/Rx occurs, the PDP context/PDN connection is disconnected • Default value of zero indicates infinite value • This parameter is currently read only and can be read by using the function SLQSGetProfileSettings(). • Bit to check in ParamPresenceMask - **48**

pAPNClass	• Optional 1 uint8_t numeric identifier representing the APN in profile • Can be set and queried but is not used by the modem • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings(). • Bit to check in ParamPresenceMask - **49**
pSupport-EmergencyCalls	• Optional 1 Byte Flag indicating if the emergency call support is disabled/enabled • Can be queried to get current status • Values: – 0 - FALSE(default) – 1 - TRUE • Bit to check in ParamPresenceMask - **54**

8.93.2 Field Documentation

8.93.2.1 uint8_t* LibpackProfile3GPP::pAddrAllocPref

8.93.2.2 uint8_t* LibpackProfile3GPP::pAPNClass

8.93.2.3 uint8_t* LibpackProfile3GPP::pAPNDisabledFlag

8.93.2.4 uint8_t* LibpackProfile3GPP::pAPNName

8.93.2.5 uint16_t* LibpackProfile3GPP::pAPNnameSize

8.93.2.6 uint8_t* LibpackProfile3GPP::pAuthenticationPref

8.93.2.7 LibPackGPRSRequestedQoS* LibpackProfile3GPP::pGPRSMinimumQoS

8.93.2.8 LibPackGPRSRequestedQoS* LibpackProfile3GPP::pGPRSRequestedQos

8.93.2.9 uint8_t* LibpackProfile3GPP::pImCnFlag

8.93.2.10 uint32_t* LibpackProfile3GPP::pIPv4AddrPref

8.93.2.11 uint16_t* LibpackProfile3GPP::pIPv6AddPref

8.93.2.12 uint8_t* LibpackProfile3GPP::pPassword

8.93.2.13 uint16_t* LibpackProfile3GPP::pPasswordSize

8.93.2.14 uint8_t* LibpackProfile3GPP::pPcscfAddrUsingDhcp

8.93.2.15 uint8_t* LibpackProfile3GPP::pPcscfAddrUsingPCO

8.93.2.16 uint32_t* LibpackProfile3GPP::pPDNInactivTimeout

8.93.2.17 uint8_t* LibpackProfile3GPP::pPdpAccessConFlag

8.93.2.18 uint8_t* LibpackProfile3GPP::pPdpContext

8.93.2.19 uint8_t* LibpackProfile3GPP::pPdpDataCompType

8.93.2.20 uint8_t* LibpackProfile3GPP::pPdpHdrCompType

8.93.2.21 uint8_t* LibpackProfile3GPP::pPDPtype

8.93.2.22 uint32_t* LibpackProfile3GPP::pPriDNSIPv4AddPref

8.93.2.23 uint16_t* LibpackProfile3GPP::pPriDNSIPv6addpref

8.93.2.24 uint8_t* LibpackProfile3GPP::pPrimaryID

8.93.2.25 uint8_t* LibpackProfile3GPP::pProfilename

8.93.2.26 uint16_t* LibpackProfile3GPP::pProfilenameSize

8.93.2.27 **LibPackQosClassID*** LibpackProfile3GPP::pQosClassID

8.93.2.28 uint32_t* LibpackProfile3GPP::pSecDNSIPv4AddPref

8.93.2.29 uint16_t* LibpackProfile3GPP::pSecDNSIPv6addpref

8.93.2.30 uint8_t* LibpackProfile3GPP::pSecondaryFlag

8.93.2.31 uint8_t* LibpackProfile3GPP::pSupportEmergencyCalls

8.93.2.32 **LibPackTFTIDParams*** LibpackProfile3GPP::pTFTID1Params

8.93.2.33 **LibPackTFTIDParams*** LibpackProfile3GPP::pTFTID2Params

8.93.2.34 **LibPackUMTSQoS*** LibpackProfile3GPP::pUMTSMinQoS

8.93.2.35 **LibPackUMTSReqQoSSigInd*** LibpackProfile3GPP::pUMTSMinQosSigInd

8.93.2.36 **LibPackUMTSQoS*** LibpackProfile3GPP::pUMTSReqQoS

8.93.2.37 **LibPackUMTSReqQoSSigInd*** LibpackProfile3GPP::pUMTSReqQoSSigInd

8.93.2.38 uint8_t* LibpackProfile3GPP::pUsername

8.93.2.39 uint16_t* LibpackProfile3GPP::pUsernameSize

8.94 LibpackProfile3GPP2 Struct Reference

Data Fields

- uint8_t * pNegoDnsSrvrPref
- uint32_t * pPppSessCloseTimerDO
- uint32_t * pPppSessCloseTimer1x
- uint8_t * pAllowLinger
- uint16_t * pLcpAckTimeout
- uint16_t * pIpcpAckTimeout
- uint16_t * pAuthTimeout
- uint8_t * pLcpCreqRetryCount
- uint8_t * pIpcpCreqRetryCount

- uint8_t * pAuthRetryCount
- uint8_t * pAuthProtocol
- uint8_t * pUserId
- uint16_t * pUserIdSize
- uint8_t * pAuthPassword
- uint16_t * pAuthPasswordSize
- uint8_t * pDataRate
- uint32_t * pAppType
- uint8_t * pDataMode
- uint8_t * pAppPriority
- uint8_t * pApnString
- uint16_t * pApnStringSize
- uint8_t * pPdnType
- uint8_t * pIsPcscfAddressNedded
- uint32_t * pPrimaryV4DnsAddress
- uint32_t * pSecondaryV4DnsAddress
- uint16_t * pPriV6DnsAddress
- uint16_t * pSecV6DnsAddress
- uint8_t * pRATType
- uint8_t * pAPNEnabled3GPP2
- uint32_t * pPDNInactivTimeout3GPP2
- uint8_t * pAPNClass3GPP2

8.94.1 Detailed Description

This structure contains the 3GPP2 profile parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

pNegoDnsSrvr-Pref	• Negotiate DNS Server Preference – 1 - (TRUE)implies request DNS addresses from the PDSN – 0 - (FALSE)implies do not request DNS addresses from the PDSN – Default value is 1 (TRUE) • Bit to check in ParamPresenceMask - **144**
pPppSessClose-TimerDO	• PPP Session Close Timer for DO – Timer value (in seconds) on DO indicating how long the PPP Session should linger before closing down • Bit to check in ParamPresenceMask - **145**
pPppSessClose-Timer1x	• PPP Session Close Timer for 1X – Timer value (in seconds) on 1X indicating how long the PPP session should linger before closing down • Bit to check in ParamPresenceMask - **146**

pAllowLinger	• Allow/disallow lingering of interface – 1 -(TRUE) implies allow lingering – 0 -(FALSE) implies do not allow lingering • Bit to check in ParamPresenceMask - **147**
pLcpAckTimeout	• LCP ACK Timeout – Value of LCP ACK Timeout in milliseconds • Bit to check in ParamPresenceMask - **148**
pIpcpAck-Timeout	• IPCP ACK Timeout – Value of IPCP ACK Timeout in milliseconds • Bit to check in ParamPresenceMask - **149**
pAuthTimeout	• AUTH Timeout – Value of Authentication Timeout in milliseconds • Bit to check in ParamPresenceMask - **150**
pLcpCreqRetry-Count	• LCP Configuration Request Retry Count • Bit to check in ParamPresenceMask - **151**
pIpcpCreqRetry-Count	• IPCP Configuration Request Retry Count • Bit to check in ParamPresenceMask - **152**
pAuthRetry-Count	• Authentication Retry Count value • Bit to check in ParamPresenceMask - **153**
pAuthProtocol	• Authentication Protocol – 1 - PAP – 2 - CHAP – 3 - PAP or CHAP • Bit to check in ParamPresenceMask - **154**
pUserId	• User ID to be used during data network authentication • maximum length allowed is 127 uint8_ts; • QMI_ERR_ARG_TOO_LONG will be returned if the storage on the wireless device is insufficient in size to hold the value. • Bit to check in ParamPresenceMask - **155**
pUserIdSize;	• This parameter is an input parameter and should be initialised to the size of pUserId field. Size of this parameter is 2 uint8_ts. • Bit to check in ParamPresenceMask - **155**

pAuthPassword	• Password to be used during data network authentication; • maximum length allowed is 127 uint8_ts • QMI_ERR_ARG_TOO_LONG will be returned if the storage on the wireless device is insufficient in size to hold the value. • Bit to check in ParamPresenceMask - **156**
pAuthPassword-Size;	• This parameter is an input parameter and should be initialised to the size of pAuthPassword field. Size of this parameter is 2 uint8_ts. • Bit to check in ParamPresenceMask - **156**
pDataRate	• Data Rate Requested – 0 - Low (Low speed Service Options (SO15) only) – 1 - Medium (SO33 + low R-SCH) – 2 - High (SO33 + high R-SCH) – Default is 2 • Bit to check in ParamPresenceMask - **157**
pAppType	• Application Type: – 0x00000001 - Default Application Type – 0x00000020 - LBS Application Type – 0x00000040 - Tethered Application Type – This parameter is not used while creating/modifying a profile • Bit to check in ParamPresenceMask - **158**
pDataMode	• Data Mode to use: – 0 - CDMA or HDR (Hybrid 1X/1xEV-DO) – 1 - CDMA Only (1X only) – 2 - HDR Only (1xEV-DO only) – Default is 0 • Bit to check in ParamPresenceMask - **159**
pAppPriority	• Application Priority – Numerical 1 uint8_t value defining the application priority; higher value implies higher priority – This parameter is not used while creating/modifying a profile • Bit to check in ParamPresenceMask - **160**
pApnString	• String representing the Access Point Name • maximum length allowed is 100 uint8_ts • QMI_ERR_ARG_TOO_LONG will be returned if the APN name is too long. • Bit to check in ParamPresenceMask - **161**

pApnStringSize;	• This parameter is an input parameter and should be initialised to the size of pApnString field. Size of this parameter is 2 uint8_ts. • Bit to check in ParamPresenceMask - **161**
pPdnType	• Packed Data Network Type Requested: – 0 - IPv4 PDN Type – 1 - IPv6 PDN Type – 2 - IPv4 or IPv6 PDN Type – 3 - Unspecified PDN Type (implying no preference) • Bit to check in ParamPresenceMask - **162**
pIsPcscf-AddressNedded	• This boolean value is used to control if PCSCF address is requested from PDSN – 1 -(TRUE) implies request for PCSCF value from the PDSN – 0 -(FALSE) implies do not request for PCSCF value from the PDSN • Bit to check in ParamPresenceMask - **163**
pPrimaryV4Dns-Address	• IPv4 Primary DNS address – The Primary IPv4 DNS address that can be statically assigned to the UE • Bit to check in ParamPresenceMask - **164**
pSecondaryV4-DnsAddress	• IPv4 Secondary DNS address – The Secondary IPv4 DNS address that can be statically assigned to the UE • Bit to check in ParamPresenceMask - **165**
pPriV6Dns-Address	• Primary IPv6 DNS address – The Primary IPv6 DNS address that can be statically assigned to the UE • Bit to check in ParamPresenceMask - **166**
pSecV6Dns-Address	• Secondary IPv6 DNS address – The Secondary IPv6 DNS address that can be statically assigned to the UE • Bit to check in ParamPresenceMask - **167**
pRATType	• Optional 1 uint8_t Flag indicating RAT Type • Values: – 1 - HRPD – 2 - EHRPD – 3 - HRPD_EHRPD • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings(). • Bit to check in ParamPresenceMask - **168**

pAPNEnabled3-GPP2	• Optional 1 uint8_t Flag indicating if the APN is disabled/enabled • If disabled, the profile can not be used for making data calls • Values: – 0 - Disabled – 1 - Enabled(default value) • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings(). • Bit to check in ParamPresenceMask - **169**
pPDNInactiv-Timeout3GPP2	• Optional 4 uint8_ts indicating the duration of inactivity timer in seconds • If the PDP context/PDN connection is inactive for this duration i.e. No data Tx/Rx occurs, the PDP context/PDN connection is disconnected • Default value of zero indicates infinite value • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings(). • Bit to check in ParamPresenceMask - **170**
pAPNClass3GP-P2	• Optional 1 uint8_t numeric identifier representing the APN in profile • Can be set and queried but is not used by the modem • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings(). • Bit to check in ParamPresenceMask - **171**

8.94.2 Field Documentation

8.94.2.1 uint8_t* LibpackProfile3GPP2::pAllowLinger

8.94.2.2 uint8_t* LibpackProfile3GPP2::pAPNClass3GPP2

8.94.2.3 uint8_t* LibpackProfile3GPP2::pAPNEnabled3GPP2

8.94.2.4 uint8_t* LibpackProfile3GPP2::pApnString

8.94.2.5 uint16_t* LibpackProfile3GPP2::pApnStringSize

8.94.2.6 uint8_t* LibpackProfile3GPP2::pAppPriority

8.94.2.7 uint32_t* LibpackProfile3GPP2::pAppType

8.94.2.8 uint8_t* LibpackProfile3GPP2::pAuthPassword

8.94.2.9 uint16_t* LibpackProfile3GPP2::pAuthPasswordSize

8.94.2.10 uint8_t* LibpackProfile3GPP2::pAuthProtocol

8.94.2.11 uint8_t* LibpackProfile3GPP2::pAuthRetryCount

8.94.2.12 uint16_t* LibpackProfile3GPP2::pAuthTimeout

8.94.2.13 uint8_t* LibpackProfile3GPP2::pDataMode

8.94.2.14 uint8_t* LibpackProfile3GPP2::pDataRate

8.94.2.15 uint16_t* LibpackProfile3GPP2::pIpcpAckTimeout

8.94.2.16 uint8_t* LibpackProfile3GPP2::pIpcpCreqRetryCount

8.94.2.17 uint8_t* LibpackProfile3GPP2::pIsPcscfAddressNedded

8.94.2.18 uint16_t* LibpackProfile3GPP2::pLcpAckTimeout

8.94.2.19 uint8_t* LibpackProfile3GPP2::pLcpCreqRetryCount

8.94.2.20 uint8_t* LibpackProfile3GPP2::pNegoDnsSrvrPref

8.94.2.21 uint32_t* LibpackProfile3GPP2::pPDNInactivTimeout3GPP2

8.94.2.22 uint8_t* LibpackProfile3GPP2::pPdnType

8.94.2.23 uint32_t* LibpackProfile3GPP2::pPppSessCloseTimer1x

8.94.2.24 uint32_t* LibpackProfile3GPP2::pPppSessCloseTimerDO

8.94.2.25 uint32_t* LibpackProfile3GPP2::pPrimaryV4DnsAddress

8.94.2.26 uint16_t* LibpackProfile3GPP2::pPriV6DnsAddress

8.94.2.27 uint8_t* LibpackProfile3GPP2::pRATType

8.94.2.28 uint32_t* LibpackProfile3GPP2::pSecondaryV4DnsAddress

8.94.2.29 uint16_t* LibpackProfile3GPP2::pSecV6DnsAddress

8.94.2.30 uint8_t* LibpackProfile3GPP2::pUserId

8.94.2.31 uint16_t* LibpackProfile3GPP2::pUserIdSize

8.95 LibPackprofile_3GPP Struct Reference

Data Fields

- uint8_t * pProfilename
- uint16_t * pProfilenameSize
- uint8_t * pPDPtype
- uint8_t * pPdpHdrCompType
- uint8_t * pPdpDataCompType
- uint8_t * pAPNName
- uint16_t * pAPNnameSize
- uint32_t * pPriDNSIPv4AddPref
- uint32_t * pSecDNSIPv4AddPref
- LibPackUMTSQoS * pUMTSReqQoS
- LibPackUMTSQoS * pUMTSMinQoS
- LibPackGPRSRequestedQoS * pGPRSRequestedQos
- LibPackGPRSRequestedQoS * pGPRSMinimumQoS

- uint8_t * pUsername
- uint16_t * pUsernameSize
- uint8_t * pPassword
- uint16_t * pPasswordSize
- uint8_t * pAuthenticationPref
- uint32_t * pIPv4AddrPref
- uint8_t * pPcscfAddrUsingPCO
- uint8_t * pPdpAccessConFlag
- uint8_t * pPcscfAddrUsingDhcp
- uint8_t * pImCnFlag
- LibPackTFTIDParams * pTFTID1Params
- LibPackTFTIDParams * pTFTID2Params
- uint8_t * pPdpContext
- uint8_t * pSecondaryFlag
- uint8_t * pPrimaryID
- uint16_t * pIPv6AddPref
- LibPackUMTSReqQoSSigInd * pUMTSReqQoSSigInd
- LibPackUMTSReqQoSSigInd * pUMTSMinQosSigInd
- uint16_t * pPriDNSIPv6addpref
- uint16_t * pSecDNSIPv6addpref
- uint8_t * pAddrAllocPref
- LibPackQosClassID * pQosClassID
- uint8_t * pAPNDisabledFlag
- uint32_t * pPDNInactivTimeout
- uint8_t * pAPNClass
- uint8_t * pSupportEmergencyCalls

8.95.1 Detailed Description

This structure contains Input/Output parameters of pack_wds_SLQSCreateProfile

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

pProfileName	• One or more bytes describing the profile
pProfilename-Size;	• This parameter is an input parameter and should be initialised to the size of pProfileName field. Size of this parameter is 2 bytes.
pPDPType	• Packet Data Protocol (PDP) type specifies the type of data payload exchanged over the air link when the packet data session is established with this profile – 0x00 - PDP-IP (IPv4) – 0x01 - PDP-PPP – 0x02 - PDP-IPV6 – 0x03 - PDP-IPV4V6

pPdpHdrComp-Type	• PDP header compression type – 0 - PDP header compression is OFF – 1 - Manufacturer preferred compression – 2 - PDP header compression based on RFC 1144 – 3 - PDP header compression based on RFC 25074 PDP header compression based on RFC 3095
pPdpDataComp-Type	• PDP data compression type – 0 - PDP data compression is OFF – 1 - Manufacturer preferred compression – 2 - V.42BIS data compression – 3 - V.44 data compression
pAPNName	• Access point name
pAPNnameSize;	• This parameter is an input parameter and should be initialised to the size of pAPNName field. Size of this parameter is 2 bytes.
pPriDNSIPv4-AddPref	• Primary DNS IPv4 Address Preference
pSecDNSIPv4-AddPref	• Secondary DNS IPv4 Address Preference
pUMTSReqQoS	• UMTS Requested QoS
pUMTSMinQoS	• UMTS Minimum QoS
pGPRS-RequestedQoS	• GPRS Minimum QoS
pUsername	• User name
pUsernameSize;	• This parameter is an input parameter and should be initialised to the size of pUsername field. Size of this parameter is 2 bytes.
pPassword	• Password
pPasswordSize;	• This parameter is an input parameter and should be initialised to the size of pPassword field. Size of this parameter is 2 bytes.

pAuthentication-Pref	• Authentication Preference – Bit map that indicates the authentication algorithm preference * Bit 0 - PAP preference · 0 - PAP is never performed · 1 - PAP may be performed * Bit 1 - CHAP preference · 0 - CHAP is never performed · 1 - CHAP may be performed * If more than one bit is set, then the device decides which authentication procedure is performed while setting up the data session. For example, the device may have a policy to select the most secure authentication mechanism.
pIPv4AddrPref	• IPv4 Address Preference
pPcscfAddr-UsingPCO	• P-CSCF Address using PCO Flag – 1 - (TRUE) implies request PCSCF address using PCO – 0 - (FALSE) implies do not request By default, this value is 0
pPdpAccess-ConFlag	• PDP access control flag – 0 - PDP access control none – 1 - PDP access control reject – 2 - PDP access control permission
pPcscfAddr-UsingDhcp	• P-CSCF address using DHCP – 1 - (TRUE) implies Request PCSCF address using DHCP – 0 - (FALSE) implies do not request By default, value is 0
pImCnFlag	• IM CN flag – 1 - (TRUE) implies request IM CN flag for this profile – 0 - (FALSE) implies do not request IM CN flag for this profile
pTFTID1Params	• Traffic Flow Template
pTFTID2Params	• Traffic Flow Template
pPdpContext	• PDP context number
pSecondaryFlag	• PDP context secondary flag – 1 - (TRUE) implies this is secondary profile – 0 - (FALSE) implies this is not secondary profile

pPrimaryID	• PDP context primary ID • function SLQSGetProfileSettings() returns a default value 0xFF if this parameter is not returned by the device
pIPv6AddPref	• IPv6 address preference Preferred IPv6 address to be assigned to the TE; actual assigned address is negotiated with the network and may differ from this value; if not specified, the IPv6 address is obtained automatically from the network
pUMTSReqQoS-SigInd	• UMTS requested QoS with Signalling Indication flag
pUMTSMinQoS-SigInd	• UMTS minimum QoS with Signalling Indication flag
pPrimaryDNSI-Pv6addpref	• Primary DNS IPv6 address preference – The value may be used as a preference during negotiation with the network; if not specified, the wireless device will attempt to obtain the DNS address automatically from the network; the negotiated value is provided to the host via DHCP
pSecondaryDN-SIPv6addpref	• Secondary DNS IPv6 address preference
paddrAllocation-Pref	• DHCP/NAS preference – This enumerated value may be used to indicate the address allocation preference * 0 - NAS signaling is used for address allocation * 1 - DHCP is used for address allocation
pQosClassID	• 3GPP LTE QoS parameters
pAPNDisabled-Flag	• Optional 1 uint8_t Flag indicating if the APN is disabled/enabled • If set, the profile can not be used for making data calls • Any data call is failed locally • Values: – 0 - FALSE(default) – 1 - True • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().
pPDNInactiv-Timeout	• Optional 4 Bytes indicating the duration of inactivity timer in seconds • If the PDP context/PDN connection is inactive for this duration i.e. No data Tx/Rx occurs, the PDP context/PDN connection is disconnected • Default value of zero indicates infinite value • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().

pAPNClass	• Optional 1 uint8_t numeric identifier representing the APN in profile • Can be set and queried but is not used by the modem • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().
pSupport-EmergencyCalls	• Optional 1 Byte Flag indicating if the emergency call support is disabled/enabled • If set, the profile can be used for making emergency calls • Values: – 0 - FALSE(default) – 1 - TRUE

8.95.2 Field Documentation

8.95.2.1 uint8_t* LibPackprofile_3GPP::pAddrAllocPref

8.95.2.2 uint8_t* LibPackprofile_3GPP::pAPNClass

8.95.2.3 uint8_t* LibPackprofile_3GPP::pAPNDisabledFlag

8.95.2.4 uint8_t* LibPackprofile_3GPP::pAPNName

8.95.2.5 uint16_t* LibPackprofile_3GPP::pAPNnameSize

8.95.2.6 uint8_t* LibPackprofile_3GPP::pAuthenticationPref

8.95.2.7 LibPackGPRSRequestedQoS* LibPackprofile_3GPP::pGPRSMinimumQoS

8.95.2.8 LibPackGPRSRequestedQoS* LibPackprofile_3GPP::pGPRSRequestedQos

8.95.2.9 uint8_t* LibPackprofile_3GPP::pImCnFlag

8.95.2.10 uint32_t* LibPackprofile_3GPP::pIPv4AddrPref

8.95.2.11 uint16_t* LibPackprofile_3GPP::pIPv6AddPref

8.95.2.12 uint8_t* LibPackprofile_3GPP::pPassword

8.95.2.13 uint16_t* LibPackprofile_3GPP::pPasswordSize

8.95.2.14 uint8_t* LibPackprofile_3GPP::pPcscfAddrUsingDhcp

8.95.2.15 uint8_t* LibPackprofile_3GPP::pPcscfAddrUsingPCO

8.95.2.16 uint32_t* LibPackprofile_3GPP::pPDNInactivTimeout

8.95.2.17 uint8_t* LibPackprofile_3GPP::pPdpAccessConFlag

8.95.2.18 uint8_t* LibPackprofile_3GPP::pPdpContext

8.95.2.19 uint8_t* LibPackprofile_3GPP::pPdpDataCompType

8.95.2.20 uint8_t* LibPackprofile_3GPP::pPdpHdrCompType

8.95.2.21 uint8_t* LibPackprofile_3GPP::pPDPtype

8.95.2.22 uint32_t* LibPackprofile_3GPP::pPriDNSIPv4AddPref

8.95.2.23 uint16_t* LibPackprofile_3GPP::pPriDNSIPv6addpref

8.95.2.24 uint8_t* LibPackprofile_3GPP::pPrimaryID

8.95.2.25 uint8_t* LibPackprofile_3GPP::pProfilename

8.95.2.26 uint16_t* LibPackprofile_3GPP::pProfilenameSize

8.95.2.27 LibPackQosClassID* LibPackprofile_3GPP::pQosClassID

8.95.2.28 uint32_t* LibPackprofile_3GPP::pSecDNSIPv4AddPref

8.95.2.29 uint16_t* LibPackprofile_3GPP::pSecDNSIPv6addpref

8.95.2.30 uint8_t* LibPackprofile_3GPP::pSecondaryFlag

8.95.2.31 uint8_t* LibPackprofile_3GPP::pSupportEmergencyCalls

8.95.2.32 LibPackTFTIDParams* LibPackprofile_3GPP::pTFTID1Params

8.95.2.33 LibPackTFTIDParams* LibPackprofile_3GPP::pTFTID2Params

8.95.2.34 LibPackUMTSQoS* LibPackprofile_3GPP::pUMTSMinQoS

8.95.2.35 LibPackUMTSReqQoSSigInd* LibPackprofile_3GPP::pUMTSMinQosSigInd

8.95.2.36 LibPackUMTSQoS* LibPackprofile_3GPP::pUMTSReqQoS

8.95.2.37 LibPackUMTSReqQoSSigInd* LibPackprofile_3GPP::pUMTSReqQoSSigInd

8.95.2.38 uint8_t* LibPackprofile_3GPP::pUsername

8.95.2.39 uint16_t* LibPackprofile_3GPP::pUsernameSize

8.96 LibPackprofile_3GPP2 Struct Reference

Data Fields

- uint8_t * pNegoDnsSrvrPref
- uint32_t * pPppSessCloseTimerDO
- uint32_t * pPppSessCloseTimer1x
- uint8_t * pAllowLinger
- uint16_t * pLcpAckTimeout
- uint16_t * pIpcpAckTimeout
- uint16_t * pAuthTimeout
- uint8_t * pLcpCreqRetryCount
- uint8_t * pIpcpCreqRetryCount
- uint8_t * pAuthRetryCount
- uint8_t * pAuthProtocol

- uint8_t * pUserId
- uint16_t * pUserIdSize
- uint8_t * pAuthPassword
- uint16_t * pAuthPassword_tSize
- uint8_t * pDataRate
- uint32_t * pAppType
- uint8_t * pDataMode
- uint8_t * pAppPriority
- uint8_t * pApnString
- uint16_t * pApnStringSize
- uint8_t * pPdnType
- uint8_t * pIsPcscfAddressNedded
- uint32_t * pPrimaryV4DnsAddress
- uint32_t * pSecondaryV4DnsAddress
- uint16_t * pPriV6DnsAddress
- uint16_t * pSecV6DnsAddress
- uint8_t * pRATType
- uint8_t * pAPNEnabled3GPP2
- uint32_t * pPDNInactivTimeout3GPP2
- uint8_t * pAPNClass3GPP2

8.96.1 Detailed Description

This structure contains the 3GPP2 profile parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

pNegoDnsSrvr-Pref	• Negotiate DNS Server Preference – 1 - (TRUE)implies request DNS addresses from the PDSN – 0 - (FALSE)implies do not request DNS addresses from the PDSN – Default value is 1 (TRUE)
pPppSessClose-TimerDO	• PPP Session Close Timer for DO – Timer value (in seconds) on DO indicating how long the PPP Session should linger before closing down
pPppSessClose-Timer1x	• PPP Session Close Timer for 1X – Timer value (in seconds) on 1X indicating how long the PPP session should linger before closing down
pAllowLinger	• Allow/disallow lingering of interface – 1 -(TRUE) implies allow lingering – 0 -(FALSE) implies do not allow lingering
pLcpAckTimeout	• LCP ACK Timeout – Value of LCP ACK Timeout in milliseconds

pIpcpAck-Timeout	• IPCP ACK Timeout – Value of IPCP ACK Timeout in milliseconds
pAuthTimeout	• AUTH Timeout – Value of Authentication Timeout in milliseconds
pLcpCreqRetry-Count	• LCP Configuration Request Retry Count
pIpcpCreqRetry-Count	• IPCP Configuration Request Retry Count
pAuthRetry-Count	• Authentication Retry Count value
pAuthProtocol	• Authentication Protocol – 1 - PAP – 2 - CHAP – 3 - PAP or CHAP
pUserId	• User ID to be used during data network authentication • maximum length allowed is 127 bytes; • QMI_ERR_ARG_TOO_LONG will be returned if the storage on the wireless device is insufficient in size to hold the value.
pUserIdSize;	• This parameter is an input parameter and should be initialised to the size of pUserId field. Size of this parameter is 2 bytes.
pAuthPassword	• Password to be used during data network authentication; • maximum length allowed is 127 bytes • QMI_ERR_ARG_TOO_LONG will be returned if the storage on the wireless device is insufficient in size to hold the value.
pAuthPassword-Size;	• This parameter is an input parameter and should be initialised to the size of pAuthPassword field. Size of this parameter is 2 bytes.
pDataRate	• Data Rate Requested – 0 - Low (Low speed Service Options (SO15) only) – 1 - Medium (SO33 + low R-SCH) – 2 - High (SO33 + high R-SCH) – Default is 2

pAppType	• Application Type: – 0x00000001 - Default Application Type – 0x00000020 - LBS Application Type – 0x00000040 - Tethered Application Type – This parameter is not used while creating/modifying a profile
pDataMode	• Data Mode to use: – 0 - CDMA or HDR (Hybrid 1X/1xEV-DO) – 1 - CDMA Only (1X only) – 2 - HDR Only (1xEV-DO only) – Default is 0
pAppPriority	• Application Priority – Numerical 1 uint8_t value defining the application priority; higher value implies higher priority – This parameter is not used while creating/modifying a profile
pApnString	• String representing the Access Point Name • maximum length allowed is 100 bytes • QMI_ERR_ARG_TOO_LONG will be returned if the APN name is too long.
pApnStringSize;	• This parameter is an input parameter and should be initialised to the size of pApnString field. Size of this parameter is 2 bytes.
pPdnType	• Packed Data Network Type Requested: – 0 - IPv4 PDN Type – 1 - IPv6 PDN Type – 2 - IPv4 or IPv6 PDN Type – 3 - Unspecified PDN Type (implying no preference)
pIsPcscf-AddressNedded	• This boolean value is used to control if PCSCF address is requested from PDSN – 1 -(TRUE) implies request for PCSCF value from the PDSN – 0 -(FALSE) implies do not request for PCSCF value from the PDSN
pPrimaryV4Dns-Address	• IPv4 Primary DNS address – The Primary IPv4 DNS address that can be statically assigned to the UE
pSecondaryV4-DnsAddress	• IPv4 Secondary DNS address – The Secondary IPv4 DNS address that can be statically assigned to the UE

pPriV6Dns-Address	• Primary IPv6 DNS address – The Primary IPv6 DNS address that can be statically assigned to the UE
pSecV6Dns-Address	• Secondary IPv6 DNS address – The Secondary IPv6 DNS address that can be statically assigned to the UE
pRATType	• Optional 1 uint8_t Flag indicating RAT Type • Values: – 1 - HRPD – 2 - EHRPD – 3 - HRPD_EHRPD • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().
pAPNEnabled3-GPP2	• Optional 1 uint8_t Flag indicating if the APN is disabled/enabled • If disabled, the profile can not be used for making data calls • Values: – 0 - Disabled – 1 - Enabled(default value) • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().
pPDNInactiv-Timeout3GPP2	• Optional 4 Bytes indicating the duration of inactivity timer in seconds • If the PDP context/PDN connection is inactive for this duration i.e. No data Tx/Rx occurs, the PDP context/PDN connection is disconnected • Default value of zero indicates infinite value • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().
pAPNClass3GP-P2	• Optional 1 uint8_t numeric identifier representing the APN in profile • Can be set and queried but is not used by the modem • This parameter is currently read only and can be read by using the function SLQSGetProfile-Settings().

8.96.2 Field Documentation

8.96.2.1 uint8_t* LibPackprofile_3GPP2::pAllowLinger

8.96.2.2 uint8_t* LibPackprofile_3GPP2::pAPNClass3GPP2

8.96.2.3 uint8_t* LibPackprofile_3GPP2::pAPNEnabled3GPP2

8.96.2.4 uint8_t* LibPackprofile_3GPP2::pApnString

8.96.2.5 uint16_t* LibPackprofile_3GPP2::pApnStringSize

8.96.2.6 uint8_t* LibPackprofile_3GPP2::pAppPriority

8.96.2.7 uint32_t* LibPackprofile_3GPP2::pAppType

8.96.2.8 uint8_t* LibPackprofile_3GPP2::pAuthPassword

8.96.2.9 uint16_t* LibPackprofile_3GPP2::pAuthPassword_tSize

8.96.2.10 uint8_t* LibPackprofile_3GPP2::pAuthProtocol

8.96.2.11 uint8_t* LibPackprofile_3GPP2::pAuthRetryCount

8.96.2.12 uint16_t* LibPackprofile_3GPP2::pAuthTimeout

8.96.2.13 uint8_t* LibPackprofile_3GPP2::pDataMode

8.96.2.14 uint8_t* LibPackprofile_3GPP2::pDataRate

8.96.2.15 uint16_t* LibPackprofile_3GPP2::pIpcpAckTimeout

8.96.2.16 uint8_t* LibPackprofile_3GPP2::pIpcpCreqRetryCount

8.96.2.17 uint8_t* LibPackprofile_3GPP2::pIsPcscfAddressNedded

8.96.2.18 uint16_t* LibPackprofile_3GPP2::pLcpAckTimeout

8.96.2.19 uint8_t* LibPackprofile_3GPP2::pLcpCreqRetryCount

8.96.2.20 uint8_t* LibPackprofile_3GPP2::pNegoDnsSrvrPref

8.96.2.21 uint32_t* LibPackprofile_3GPP2::pPDNInactivTimeout3GPP2

8.96.2.22 uint8_t* LibPackprofile_3GPP2::pPdnType

8.96.2.23 uint32_t* LibPackprofile_3GPP2::pPppSessCloseTimer1x

8.96.2.24 uint32_t* LibPackprofile_3GPP2::pPppSessCloseTimerDO

8.96.2.25 uint32_t* LibPackprofile_3GPP2::pPrimaryV4DnsAddress

8.96.2.26 uint16_t* LibPackprofile_3GPP2::pPriV6DnsAddress

8.96.2.27 uint8_t* LibPackprofile_3GPP2::pRATType

8.96.2.28 uint32_t* LibPackprofile_3GPP2::pSecondaryV4DnsAddress

8.96.2.29 uint16_t* LibPackprofile_3GPP2::pSecV6DnsAddress

8.96.2.30 uint8_t* LibPackprofile_3GPP2::pUserId

8.96.2.31 uint16_t* LibPackprofile_3GPP2::pUserIdSize

8.97 LibPackQosClassID Struct Reference

Data Fields

- uint8_t QCI
- uint32_t gDlBitRate
- uint32_t maxDlBitRate
- uint32_t gUlBitRate
- uint32_t maxUlBitRate

8.97.1 Detailed Description

This structure contains 3GPP LTE QoS parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

QCI	• QOS specified using the QOS Class Identifier (QOS) values QCI value 0 - Requests the network to assign the appropriate QCI value QCI values 1-4 - Associated with guaranteed bit rates QCI values 5-9 - Associated with non-guaranteed bit rates
gDlBitRate	• Guaranteed DL bit rate
maxDlBitRate	• Maximum DL bit rate
gUlBitRate	• Guaranteed UL bit rate
maxUlBitRate	• Maximum UL bit rate

8.97.2 Field Documentation

8.97.2.1 uint32_t LibPackQosClassID::gDlBitRate

8.97.2.2 uint32_t LibPackQosClassID::gUlBitRate

8.97.2.3 uint32_t LibPackQosClassID::maxDlBitRate

8.97.2.4 uint32_t LibPackQosClassID::maxUlBitRate

8.97.2.5 uint8_t LibPackQosClassID::QCI

8.98 LibPackTFTIDParams Struct Reference

Data Fields

- uint8_t filterId
- uint8_t eValid
- uint8_t ipVersion

- uint16_t * pSourceIP
- uint8_t sourceIPMask
- uint8_t nextHeader
- uint16_t destPortRangeStart
- uint16_t destPortRangeEnd
- uint16_t srcPortRangeStart
- uint16_t srcPortRangeEnd
- uint32_t IPSECSPI
- uint16_t tosMask
- uint32_t flowLabel

8.98.1 Detailed Description

This structure contains traffic flow template parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

filterId	• Filter identifier
eValid	• Evaluation precedence index
ipVersion	• IP version number – 4 - IPv4 – 6 - IPv6
pSourceIP	• Source IP address – IPv4 - Fill the first 4 uint8_ts – IPv6 - Fill all the 16 uint8_ts
sourceIPMask	• Mask value for the source address
nextHeader	• Next header/protocol value
destPortRange-Start	• Start value of the destination port range
destPortRange-End	• End value of the destination port range
srcPortRange-Start	• Start value of the source port range
srcPortRange-End	• End value of the source port range

IPSECSPI	• IPSEC security parameter index
tosMask	• TOS mask (Traffic class for IPv6)
flowLabel	• Flow label

8.98.2 Field Documentation

8.98.2.1 uint16_t LibPackTFTIDParams::destPortRangeEnd

8.98.2.2 uint16_t LibPackTFTIDParams::destPortRangeStart

8.98.2.3 uint8_t LibPackTFTIDParams::eValid

8.98.2.4 uint8_t LibPackTFTIDParams::filterId

8.98.2.5 uint32_t LibPackTFTIDParams::flowLabel

8.98.2.6 uint32_t LibPackTFTIDParams::IPSECSPI

8.98.2.7 uint8_t LibPackTFTIDParams::ipVersion

8.98.2.8 uint8_t LibPackTFTIDParams::nextHeader

8.98.2.9 uint16_t* LibPackTFTIDParams::pSourceIP

8.98.2.10 uint8_t LibPackTFTIDParams::sourceIPMask

8.98.2.11 uint16_t LibPackTFTIDParams::srcPortRangeEnd

8.98.2.12 uint16_t LibPackTFTIDParams::srcPortRangeStart

8.98.2.13 uint16_t LibPackTFTIDParams::tosMask

8.99 LibPackUMTSQoS Struct Reference

Data Fields

- uint8_t trafficClass
- uint32_t maxUplinkBitrate
- uint32_t maxDownlinkBitrate
- uint32_t grntUplinkBitrate
- uint32_t grntDownlinkBitrate
- uint8_t qosDeliveryOrder
- uint32_t maxSDUSize
- uint8_t sduErrorRatio
- uint8_t resBerRatio
- uint8_t deliveryErrSDU
- uint32_t transferDelay
- uint32_t trafficPriority

8.99.1 Detailed Description

This structure contains the UMTS Quality Of Service Information

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

trafficClass	• 0x00 - Subscribed • 0x01 - Conversational • 0x02 - Streaming • 0x03 - Interactive • 0x04 - Background • 0xff - Invalid UMTS Quality Of Service Information.
maxUplinkBitrate	• Maximum uplink bit rate in bits/sec
maxDownlink-Bitrate	• Maximum downlink bit rate in bits/sec
grntUplinkBitrate	• Guaranteed uplink bit rate in bits/sec
grntDownlink-Bitrate	• Guranteed downlink bit rate in bits/sec
qosDelivery-Order	- Qos delivery order • 0x00 - Subscribe • 0x01 - delivery order on • 0x02 - delivery order off
maxSDUSize	• Maximum SDU size
sduErrorRatio	- SDU error ratio • Target value for fraction of SDUs lost or detected as erroneous. • 0x00 - Subscribe • 0x01 - $1*10^{\wedge}(-2)$ • 0x02 - $7*10^{\wedge}(-3)$ • 0x03 - $1*10^{\wedge}(-3)$ • 0x04 - $1*10^{\wedge}(-4)$ • 0x05 - $1*10^{\wedge}(-5)$ • 0x06 - $1*10^{\wedge}(-6)$ • 0x07 - $1*10^{\wedge}(-1)$

resBerRatio	- Residual bit error ratio • Target value for undetected bit error ratio in in the delivered SDUs. • 0x00 - Subscribe • 0x01 - 5∗10^(-2) • 0x02 - 1∗10^(-2) • 0x03 - 5∗10^(-3) • 0x04 - 4∗10^(-3) • 0x05 - 1∗10^(-3) • 0x06 - 1∗10^(-4) • 0x07 - 1∗10^(-5) • 0x08 - 1∗10^(-6) • 0x09 - 1∗10^(-8)
deliveryErrSDU	- Delivery of erroneous SDUs • Indicates whether SDUs detected as erroneous shall be delivered or not. • 0x00 - Subscribe • 0x01 - 5∗10^(-2) • 0x02 - 1∗10^(-2) • 0x03 - 5∗10^(-3) • 0x04 - 4∗10^(-3) • 0x05 - 1∗10^(-3) • 0x06 - 1∗10^(-4) • 0x07 - 1∗10^(-5) • 0x08 - 1∗10^(-6) • 0x09 - 1∗10^(-8)
transferDelay	- Transfer delay (ms) • Indicates the targeted time between a request to transfer an SDU at one SAP to its delivery at the other SAP in milliseconds.
trafficPriority	- Transfer handling priority • Specifies the relative importance for handling of SDUs that belong to the UMTS bearer, compared to the SDUs of other bearers.

Note

Check trafficClass before use.

8.99.2 Field Documentation

8.99.2.1 uint8_t LibPackUMTSQoS::deliveryErrSDU

8.99.2.2 uint32_t LibPackUMTSQoS::grntDownlinkBitrate

8.99.2.3 uint32_t LibPackUMTSQoS::grntUplinkBitrate

8.99.2.4 uint32_t LibPackUMTSQoS::maxDownlinkBitrate

8.99.2.5 uint32_t LibPackUMTSQoS::maxSDUSize

8.99.2.6 uint32_t LibPackUMTSQoS::maxUplinkBitrate

8.99.2.7 uint8_t LibPackUMTSQoS::qosDeliveryOrder

8.99.2.8 uint8_t LibPackUMTSQoS::resBerRatio

8.99.2.9 uint8_t LibPackUMTSQoS::sduErrorRatio

8.99.2.10 uint8_t LibPackUMTSQoS::trafficClass

8.99.2.11 uint32_t LibPackUMTSQoS::trafficPriority

8.99.2.12 uint32_t LibPackUMTSQoS::transferDelay

8.100 LibPackUMTSReqQoSSigInd Struct Reference

Data Fields

- LibPackUMTSQoS UMTSReqQoS
- uint8_t SigInd

8.100.1 Detailed Description

This structure contains UMTS requested QoS with Signaling Indication flag

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

UMTSReqQoS	• Contains the UMTS Quality Of Service Information • See LibPackUMTSQoS
SigInd	- Signaling Indication flag • TRUE - Signaling indication ON • FALSE - Signaling indication OFF

8.100.2 Field Documentation

8.100.2.1 uint8_t LibPackUMTSReqQoSSigInd::SigInd

8.100.2.2 LibPackUMTSQoS LibPackUMTSReqQoSSigInd::UMTSReqQoS

8.101 loc_accelAcceptReady Struct Reference

Data Fields

- uint8_t injectEnable
- uint16_t samplesPerBatch
- uint16_t batchPerSec

8.101.1 Detailed Description

This structure contains Accelerometer Accept Ready Info

Parameters

injectEnable	• GNSS location engine is ready to accept data from sensor. • Values • 0x01 - Ready to accept sensor data • 0x00 - Not ready to accept sensor data
samplesPer-Batch	• number of samples per batch the GNSS location engine is to receive. • samplingFrequency = samplesPerBatch ∗ batchesPerSecond • samplesPerBatch must be a nonzero positive value.
batchPerSec	• LTE NAS version minor • Number of sensor-data batches the GNSS location engine is to receive per second. • BatchesPerSecond must be a nonzero positive value.

8.101.2 Field Documentation

8.101.2.1 uint16_t loc_accelAcceptReady::batchPerSec

8.101.2.2 uint8_t loc_accelAcceptReady::injectEnable

8.101.2.3 uint16_t loc_accelAcceptReady::samplesPerBatch

8.102 loc_accelTempAcceptReady Struct Reference

Data Fields

- uint8_t injectEnable
- uint16_t samplesPerBatch
- uint16_t batchPerSec

8.102.1 Detailed Description

This structure contains Accelerometer Temperature Accept Ready Info

Parameters

injectEnable	• GNSS location engine is ready to accept data from sensor. • Values • 0x01 - Ready to accept sensor data • 0x00 - Not ready to accept sensor data

samplesPer-Batch	• number of samples per batch the GNSS location engine is to receive. • samplingFrequency = samplesPerBatch ∗ batchesPerSecond • samplesPerBatch must be a nonzero positive value.
batchPerSec	• LTE NAS version minor • Number of sensor-data batches the GNSS location engine is to receive per second. • BatchesPerSecond must be a nonzero positive value.

8.102.2 Field Documentation

8.102.2.1 uint16_t loc_accelTempAcceptReady::batchPerSec

8.102.2.2 uint8_t loc_accelTempAcceptReady::injectEnable

8.102.2.3 uint16_t loc_accelTempAcceptReady::samplesPerBatch

8.103 loc_BdsSV Struct Reference

Data Fields

- uint16_t id
- uint8_t mask

8.103.1 Detailed Description

This structure contains the BDS SV Info

Parameters

id	• SV ID of the satellite whose data is to be deleted. – Range for BDS: 201 to 237
mask	• Indicates if the ephemeris or almanac for a satellite is to be deleted • Valid values: – QMI_LOC_MASK_DELETE_EPHEMERIS (0x01) - Delete ephemeris for the satellite – QMI_LOC_MASK_DELETE_ALMANAC (0x02) - Delete almanac for the satellite

8.103.2 Field Documentation

8.103.2.1 uint16_t loc_BdsSV::id

8.103.2.2 uint8_t loc_BdsSV::mask

8.104 loc_BdsSVInfo Struct Reference

Data Fields

- uint8_t len
- loc_BdsSV * pSV

8.104.1 Detailed Description

This structure contains the number of sets of the BDS SVN Info

Parameters

len	• Number of sets of the following elements: – gnssSvId – deleteSvInfoMask
pSV	• Pointer to struct loc_BdsSV. See loc_BdsSV for more information

8.104.2 Field Documentation

8.104.2.1 uint8_t loc_BdsSVInfo::len

8.104.2.2 loc_BdsSV* loc_BdsSVInfo::pSV

8.105 loc_CellDb Struct Reference

Data Fields

- uint32_t mask

8.105.1 Detailed Description

This structure contains the cell database

Parameters

mask	• Mask for the cell database assistance data that is to be deleted • Valid values: – 0x00000001 - DELETE_CELLDB_POS – 0x00000002 - DELETE_CELLDB_LATEST_GPS_POS – 0x00000004 - DELETE_CELLDB_OTA_POS – 0x00000008 - DELETE_CELLDB_EXT_REF_POS – 0x00000010 - DELETE_CELLDB_TIMETAG – 0x00000020 - DELETE_CELLDB_CELLID – 0x00000040 - DELETE_CELLDB_CACHED_CELLID – 0x00000080 - DELETE_CELLDB_LAST_SRV_CELL – 0x00000100 - DELETE_CELLDB_CUR_SRV_CELL – 0x00000200 - DELETE_CELLDB_NEIGHBOR_INFO

8.105.2 Field Documentation

8.105.2.1 uint32_t loc_CellDb::mask

8.106 loc_ClkInfo Struct Reference

Data Fields

- uint32_t mask

8.106.1 Detailed Description

This structure contains the clock Info

Parameters

mask	• Mask for the clock information assistance data that is to be deleted • Valid bitmasks: – QMI_LOC_MASK_DELETE_CLOCK_INFO_TIME_EST (0x00000001) - Mask to delete time estimate from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_FREQ_EST (0x00000002) - Mask to delete frequency estimate from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_WEEK_NUMBER (0x00000004) - Mask to delete week number from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_RTC_TIME (0x00000008) - Mask to delete RTC time from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_TIME_TRANSFER (0x00000010) - Mask to delete time transfer from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GPSTIME_EST (0x00000020) - Mask to delete GPS time estimate from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GLOTIME_EST (0x00000040) - Mask to delete GLONASS time estimate from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GLODAY_NUMBER (0x00000080) - Mask to delete GLONASS day number from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GLO4YEAR_NUMBER (0x00000100) - Mask to delete GLONASS four year number from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GLO_RF_GRP_DELAY (0x00000200) - Mask to delete GLONASS RF GRP delay from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_DISABLE_TT (0x00000400) - Mask to delete disable TT from clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GG_LEAPSEC (0x00000800) - Mask to delete a BDS time estimate from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GG_GGTB (0x00001000) - Mask to delete a BDS time estimate from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_BDSTIME_EST (0x00002000) - Mask to delete a BDS time estimate from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_GB_GBTB (0x00004000) - Mask to delete Glonass-to-BDS time bias-related information from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_BG_BGTB (0x00008000) - Mask to delete BDS-to-GLONASS time bias-related information from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_BDSWEEK_NUMBER (0x00010000) - Mask to delete the BDS week number from the clock information – QMI_LOC_MASK_DELETE_CLOCK_INFO_BDS_RF_GRP_DELAY (0x00020000) - Mask to delete the BDS RF GRP delay from the clock information

8.106.2 Field Documentation

8.106.2.1 uint32_t loc_ClkInfo::mask

8.107 loc_GnssData Struct Reference

Data Fields

- uint64_t mask

8.107.1 Detailed Description

This structure contains the GNSS data

Parameters

mask	• Mask for the GNSS data that is to be deleted • Valid values: – QMI_LOC_MASK_DELETE_GPS_SVDIR (0x00000001) - Mask to delete GPS SVDIR – QMI_LOC_MASK_DELETE_GPS_SVSTEER (0x00000002) - Mask to delete GPS SVSTEER – QMI_LOC_MASK_DELETE_GPS_TIME (0x00000004) - Mask to delete GPS time – QMI_LOC_MASK_DELETE_GPS_ALM_CORR (0x00000008) - Mask to delete almanac correlation – QMI_LOC_MASK_DELETE_GLO_SVDIR (0x00000010) - Mask to delete GLONASS SVDIR – QMI_LOC_MASK_DELETE_GLO_SVSTEER (0x00000020) - Mask to delete GLONASS SVSTEER – QMI_LOC_MASK_DELETE_GLO_TIME (0x00000040) - Mask to delete GLONASS time – QMI_LOC_MASK_DELETE_GLO_ALM_CORR (0x00000080) - Mask to delete GLONASS almanac correlation – QMI_LOC_MASK_DELETE_SBAS_SVDIR (0x00000100) - Mask to delete SBAS SVDIR – QMI_LOC_MASK_DELETE_SBAS_SVSTEER (0x00000200) - Mask to delete SBAS SVSTEER – QMI_LOC_MASK_DELETE_POSITION (0x00000400) - Mask to delete position estimate – QMI_LOC_MASK_DELETE_TIME (0x00000800) - Mask to delete time estimate – QMI_LOC_MASK_DELETE_IONO (0x00001000) - Mask to delete IONO – QMI_LOC_MASK_DELETE_UTC (0x00002000) - Mask to delete UTC estimate – QMI_LOC_MASK_DELETE_HEALTH (0x00004000) - Mask to delete SV health record – QMI_LOC_MASK_DELETE_SADATA (0x00008000) - Mask to delete SADATA – QMI_LOC_MASK_DELETE_RTI (0x00010000) - Mask to delete RTI – QMI_LOC_MASK_DELETE_SV_NO_EXIST (0x00020000) - Mask to delete SV_NO_EXIST – QMI_LOC_MASK_DELETE_FREQ_BIAS_EST (0x00040000) - Mask to delete frequency bias estimate – QMI_LOC_MASK_DELETE_BDS_SVDIR (0x00080000) - Mask to delete BDS SVDIR – QMI_LOC_MASK_DELETE_BDS_SVSTEER (0x00100000) - Mask to delete BDS SVSTEER – QMI_LOC_MASK_DELETE_BDS_TIME (0x00200000) - Mask to delete BDS time – QMI_LOC_MASK_DELETE_BDS_ALM_CORR (0x00400000) - Mask to delete BDS almanac correlation – QMI_LOC_MASK_DELETE_GNSS_SV_BLACKLIST_GPS (0x00800000) - Mask to delete GNSS SV blacklist GPS – QMI_LOC_MASK_DELETE_GNSS_SV_BLACKLIST_GLO (0x01000000) - Mask to delete GNSS SV blacklist GLO – QMI_LOC_MASK_DELETE_GNSS_SV_BLACKLIST_BDS (0x02000000) - Mask to delete GNSS SV blacklist BDS

8.107.2 Field Documentation

8.107.2.1 uint64_t loc_GnssData::mask

8.108 loc_gpsTime Struct Reference

Data Fields

- uint16_t gpsWeek
- uint32_t gpsTimeOfWeekMs

8.108.1 Detailed Description

This structure contains GPS Time info.

Parameters

gpsWeek	• Current GPS week as calculated from midnight, Jan. 6, 1980. • Units - Weeks
gpsTimeOf-WeekMs	• Amount of time into the current GPS week. • Units - Milliseconds

8.108.2 Field Documentation

8.108.2.1 uint32_t loc_gpsTime::gpsTimeOfWeekMs

8.108.2.2 uint16_t loc_gpsTime::gpsWeek

8.109 loc_gyroAcceptReady Struct Reference

Data Fields

- uint8_t injectEnable
- uint16_t samplesPerBatch
- uint16_t batchPerSec

8.109.1 Detailed Description

This structure contains Gyroscope Accept Ready Info

Parameters

injectEnable	• GNSS location engine is ready to accept data from sensor. • Values • 0x01 - Ready to accept sensor data • 0x00 - Not ready to accept sensor data

samplesPer-Batch	• number of samples per batch the GNSS location engine is to receive. • samplingFrequency = samplesPerBatch ∗ batchesPerSecond • samplesPerBatch must be a nonzero positive value.
batchPerSec	• LTE NAS version minor • Number of sensor-data batches the GNSS location engine is to receive per second. • BatchesPerSecond must be a nonzero positive value.

8.109.2 Field Documentation

8.109.2.1 uint16_t loc_gyroAcceptReady::batchPerSec

8.109.2.2 uint8_t loc_gyroAcceptReady::injectEnable

8.109.2.3 uint16_t loc_gyroAcceptReady::samplesPerBatch

8.110 loc_gyroTempAcceptReady Struct Reference

Data Fields

- uint8_t injectEnable
- uint16_t samplesPerBatch
- uint16_t batchPerSec

8.110.1 Detailed Description

This structure contains Gyroscope Temperature Accept Ready Info

Parameters

injectEnable	• GNSS location engine is ready to accept data from sensor. • Values • 0x01 - Ready to accept sensor data • 0x00 - Not ready to accept sensor data
samplesPer-Batch	• number of samples per batch the GNSS location engine is to receive. • samplingFrequency = samplesPerBatch ∗ batchesPerSecond • samplesPerBatch must be a nonzero positive value.
batchPerSec	• LTE NAS version minor • Number of sensor-data batches the GNSS location engine is to receive per second. • BatchesPerSecond must be a nonzero positive value.

8.110.2 Field Documentation

8.110.2.1 uint16_t loc_gyroTempAcceptReady::batchPerSec

8.110.2.2 uint8_t loc_gyroTempAcceptReady::injectEnable

8.110.2.3 uint16_t loc_gyroTempAcceptReady::samplesPerBatch

8.111 loc_IPv4Config Struct Reference

Data Fields

- uint32_t IPv4Addr
- uint16_t IPv4Port

8.111.1 Detailed Description

This structure specifies information regarding the IPv4 address and port.

Parameters

IPv4Addr	• IPv4 address.
IPv4Port	• IPv4 port.

8.111.2 Field Documentation

8.111.2.1 uint32_t loc_IPv4Config::IPv4Addr

8.111.2.2 uint16_t loc_IPv4Config::IPv4Port

8.112 loc_IPv4Info Struct Reference

Data Fields

- uint32_t address
- uint16_t port
- uint8_t TlvPresent

8.112.1 Detailed Description

This structure contains LOC Server IPV4 info field.

Parameters

address	• IPv4 address.
port	• IPv4 port.

TlvPresent	• Tlv Present or not

8.112.2 Field Documentation

8.112.2.1 uint32_t loc_IPv4Info::address

8.112.2.2 uint16_t loc_IPv4Info::port

8.112.2.3 uint8_t loc_IPv4Info::TlvPresent

8.113 loc_IPv6Config Struct Reference

Data Fields

- uint16_t IPv6Addr [8]
- uint32_t IPv6Port

8.113.1 Detailed Description

This structure specifies information regarding the IPv6 address and port.

Parameters

IPv6Addr	• IPv6 address. • Type - Array of unsigned integers • Maximum length of the array: 8
IPv6Port	• IPv6 port.

8.113.2 Field Documentation

8.113.2.1 uint16_t loc_IPv6Config::IPv6Addr[8]

8.113.2.2 uint32_t loc_IPv6Config::IPv6Port

8.114 loc_IPv6Info Struct Reference

Data Fields

- uint16_t address [8]
- uint32_t port
- uint8_t TlvPresent

8.114.1 Detailed Description

This structure contains LOC Get Server IPV6 info field.

Parameters

address	• IPv6 address. • Type - Array of unsigned integers • Maximum length of the array - 8
port	• IPv6 port.
TlvPresent	• Tlv Present or not

8.114.2 Field Documentation

8.114.2.1 uint16_t loc_IPv6Info::address[8]

8.114.2.2 uint32_t loc_IPv6Info::port

8.114.2.3 uint8_t loc_IPv6Info::TlvPresent

8.115 loc_LocApplicationInfo Struct Reference

Data Fields

- uint8_t appProviderLength
- uint8_t * pAppProvider
- uint8_t appNameLength
- uint8_t * pAppName
- uint8_t appVersionValid
- uint8_t appVersionLength
- uint8_t * pAppVersion

8.115.1 Detailed Description

This structure contains the Application Information

Parameters

appProvider-Length	• Length of the Application Provider
pAppProvider	• Application Provider • Depends upon the Length of application Provider
appNameLength	• Length of Application Name
pAppName	• Application Name • Depends upon the Length of application Name

appVersionValid	• Specifies whether the application version string contains a valid value • 0x00 (FALSE) Application version string is invalid • 0x01 (TRUE) Application version string is valid
appVersion-Length	• Length of Application Version
pAppVersion	• Application Version • Depends upon the Length of application Version

8.115.2 Field Documentation

8.115.2.1 uint8_t loc_LocApplicationInfo::appNameLength

8.115.2.2 uint8_t loc_LocApplicationInfo::appProviderLength

8.115.2.3 uint8_t loc_LocApplicationInfo::appVersionLength

8.115.2.4 uint8_t loc_LocApplicationInfo::appVersionValid

8.115.2.5 uint8_t* loc_LocApplicationInfo::pAppName

8.115.2.6 uint8_t* loc_LocApplicationInfo::pAppProvider

8.115.2.7 uint8_t* loc_LocApplicationInfo::pAppVersion

8.116 loc_precisionDilution Struct Reference

Data Fields

- uint32_t PDOP
- uint32_t HDOP
- uint32_t VDOP

8.116.1 Detailed Description

This structure contains Dilution of precision associated with this position.

Parameters

PDOP	• Position dilution of precision. • Range - 1 (highest accuracy) to 50 (lowest accuracy) • PDOP = square root of (Square of HDOP + Square of VDOP2)
HDOP	• Horizontal dilution of precision. • Range - 1 (highest accuracy) to 50 (lowest accuracy)

VDOP	• Vertical dilution of precision. • Range- 1 (highest accuracy) to 50 (lowest accuracy)

8.116.2 Field Documentation

8.116.2.1 uint32_t loc_precisionDilution::HDOP

8.116.2.2 uint32_t loc_precisionDilution::PDOP

8.116.2.3 uint32_t loc_precisionDilution::VDOP

8.117 loc_satelliteInfo Struct Reference

Data Fields

- uint8_t svListLen
- uint32_t validMask
- uint32_t system
- uint16_t gnssSvId
- uint8_t healthStatus
- uint32_t svStatus
- uint8_t svInfoMask
- float elevation
- float azimuth
- float snr

8.117.1 Detailed Description

Contain fields in struct loc_satelliteInfo

Parameters

svListLen	• number of sets of the following elements: – validMask – system – gnssSvid – healthStatus – svStatus – svInfoMask – elevation – azimuth – snr

validMask	• Bitmask indicating which of the fields in this TLV are valid. Valid bitmasks: – 0x00000001 - VALID_SYSTEM – 0x00000002 - VALID_GNSS_SVID – 0x00000004 - VALID_HEALTH_STATUS – 0x00000008 - VALID_PROCESS_STATUS – 0x00000010 - VALID_SVINFO_MASK – 0x00000020 - VALID_ELEVATION – 0x00000040 - VALID_AZIMUTH – 0x00000080 - VALID_SNR
system	• Indicates to which constellation this SV belongs. Valid values: – eQMI_LOC_SV_SYSTEM_GPS (1) - GPS satellite – eQMI_LOC_SV_SYSTEM_GALILEO (2) - GALILEO satellite – eQMI_LOC_SV_SYSTEM_SBAS (3) - SBAS satellite – eQMI_LOC_SV_SYSTEM_COMPASS (4) - COMPASS satellite – eQMI_LOC_SV_SYSTEM_GLONASS (5) - GLONASS satellite – eQMI_LOC_SV_SYSTEM_BDS (6) - BDS satellite
gnssSvId	• GNSS SV ID. The GPS and GLONASS SVs can be disambiguated using the system field. Range: – FOR GPS: 1 to 32 – FOR GLONASS: 1 to 32 – FOR SBAS: 120 to 151 – for BDS: 201 to 237
healthStatus	• health status. Range: 0 - 1 – 0 - unhealthy – 1 - healthy
svStatus	• SV process status. Valid values: – eQMI_LOC_SV_STATUS_IDLE (1) - SV is not being actively processed – eQMI_LOC_SV_STATUS_SEARCH (2) - The system is searching for this SV – eQMI_LOC_SV_STATUS_TRACK (3) - SV is being tracked
svInfoMask	• Indicates whether almanac and ephemeris information is available. Valid bitmasks: – 0x01 - SVINFO_HAS_EPHEMERIS – 0x02 - SVINFO_HAS_ALMANAC
elevation	• SV elevation angle. – Units: Degrees – Range: 0 to 90

azimuth	• SV azimuth angle. – Units: Degrees – Range: 0 to 360
snr	• SV signal-to-noise ratio – Units: dB-Hz

8.117.2 Field Documentation

8.117.2.1 float loc_satelliteInfo::azimuth

8.117.2.2 float loc_satelliteInfo::elevation

8.117.2.3 uint16_t loc_satelliteInfo::gnssSvId

8.117.2.4 uint8_t loc_satelliteInfo::healthStatus

8.117.2.5 float loc_satelliteInfo::snr

8.117.2.6 uint8_t loc_satelliteInfo::svInfoMask

8.117.2.7 uint8_t loc_satelliteInfo::svListLen

8.117.2.8 uint32_t loc_satelliteInfo::svStatus

8.117.2.9 uint32_t loc_satelliteInfo::system

8.117.2.10 uint32_t loc_satelliteInfo::validMask

8.118 loc_sensorDataUsage Struct Reference

Data Fields

- uint32_t usageMask
- uint32_t aidingIndicatorMask

8.118.1 Detailed Description

This structure contains Sensor Data Usage info.

Parameters

usageMask	• Specifies which sensors were used in calculating the position in the position report. – Value * 0x00000001 - Accelerometer used * 0x00000002 - Gyroscope used

aidingIndicator-Mask	• Specifies which results were aided by sensors. – Value * 0x00000001 - AIDED_HEADING * 0x00000002 - AIDED_SPEED * 0x00000004 - AIDED_POSITION * 0x00000008 - AIDED_VELOCITY

8.118.2 Field Documentation

8.118.2.1 uint32_t loc_sensorDataUsage::aidingIndicatorMask

8.118.2.2 uint32_t loc_sensorDataUsage::usageMask

8.119 loc_SV Struct Reference

Data Fields

- uint16_t id
- uint32_t system
- uint8_t mask

8.119.1 Detailed Description

This structure contains the Delete LOC SV Info

Parameters

id	• LOC SV ID of the satellite whose data is to be deleted • Range: – For GPS: 1 to 32 – For SBAS: 33 to 64 – For GLONASS: 65 to 96
system	• Indicates to which constellation this loc_SV belongs • Valid values: – eQMI_LOC_SV_SYSTEM_GPS (1) - GPS satellite – eQMI_LOC_SV_SYSTEM_GALILEO (2) - GALILEO satellite – eQMI_LOC_SV_SYSTEM_SBAS (3) - SBAS satellite – eQMI_LOC_SV_SYSTEM_COMPASS (4) - COMPASS satellite – eQMI_LOC_SV_SYSTEM_GLONASS (5) - GLONASS satellite – eQMI_LOC_SV_SYSTEM_BDS (6) - BDS satellite
mask	• Indicates if the ephemeris or almanac for a satellite is to be deleted • Valid values: – 0x01 - DELETE_EPHEMERIS – 0x02 - DELETE_ALMANAC

8.119.2 Field Documentation

8.119.2.1 uint16_t loc_SV::id

8.119.2.2 uint8_t loc_SV::mask

8.119.2.3 uint32_t loc_SV::system

8.120 loc_SVInfo Struct Reference

Data Fields

- uint8_t len
- loc_SV * pSV

8.120.1 Detailed Description

This structure contains the elements of Delete LOC SV Info

Parameters

len	• Number of sets of the following elements in struct loc_SV: – gnssSvId – system – deleteSvInfoMask
pSV	• Pointer to struct loc_SV. See loc_SV for more information

8.120.2 Field Documentation

8.120.2.1 uint8_t loc_SVInfo::len

8.120.2.2 loc_SV* loc_SVInfo::pSV

8.121 loc_svUsedforFix Struct Reference

Data Fields

- uint8_t gnssSvUsedList_len
- uint16_t gnssSvUsedList [255]

8.121.1 Detailed Description

This structure contains SVs Used to Calculate the Fix.

Parameters

gnssSvUsedList_len	• Number of sets of gnssSvUsedList

pGnssSvUsed-List	• Entry in the list contains the SV ID of a satellite used for calculating this position report. • Following information is associated with each SV ID: – GPS - 1 to 32 – SBAS - 33 to 64 – GLONASS - 65 to 96 – QZSS - 193 to 197 – BDS - 201 to 237

8.121.2 Field Documentation

8.121.2.1 uint16_t loc_svUsedforFix::gnssSvUsedList[255]

8.121.2.2 uint8_t loc_svUsedforFix::gnssSvUsedList_len

8.122 loc_urlAddr Struct Reference

Data Fields

- char address [256]
- uint8_t TlvPresent

8.122.1 Detailed Description

This structure contains LOC Get Server URL address field.

Parameters

address	• Uniform Resource Locator • Type - NULL terminated string • Maximum string length (including NULL terminator) 256
TlvPresent	• Tlv Present or not

8.122.2 Field Documentation

8.122.2.1 char loc_urlAddr::address[256]

8.122.2.2 uint8_t loc_urlAddr::TlvPresent

8.123 loc_URLAddrInfo Struct Reference

Data Fields

- char urlAddr [256]

8.123.1 Detailed Description

This structure specifies information regarding the URL.

Parameters

urlAddr	• URL address. • Type - NULL-terminated string • Maximum string length (including NULL terminator) - 256

8.123.2 Field Documentation

8.123.2.1 char loc_URLAddrInfo::urlAddr[256]

8.124 lteSSInfo Struct Reference

Data Fields

- int8_t rssi
- int8_t rsrq
- int16_t rsrp
- int16_t snr

8.124.1 Detailed Description

This structure contains the parameters for LTE Signal Strength Information

Parameters

rssi	• RSSI in dBm (signed value). • A value of -125 dBm or lower is used to indicate No Signal. – For CDMA and UMTS, this indicates forward link pilot Ec – For GSM, this indicates received signal strength
rsrq	• RSRQ value in dB (signed integer value) as measured by L1. • Range: -3 to -20 (-3 means -3 dB, -20 means -20 dB).
rsrp	• Current RSRP in dBm as measured by L1. • Range: -44 to -140 (-44 means -44 dBm, -140 means -140 dBm).
snr	• SNR level as a scaled integer in units of 0.1 dB. e.g., -16 dB has a value of -160 and 24.6 dB has a value of 246,

8.124.2 Field Documentation

8.124.2.1 int16_t lteSSInfo::rsrp

8.124.2.2 int8_t lteSSInfo::rsrq

8.124.2.3 int8_t lteSSInfo::rssi

8.124.2.4 int16_t lteSSInfo::snr

8.125 messageModeTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSMessageModeInfo MessageModeInfo

8.125.1 Detailed Description

This structure contains message mode TLV information.

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
MessageMode-Info	• Message Mode • See sMSMessageModeInfo for more information

8.125.2 Field Documentation

8.125.2.1 sMSMessageModeInfo messageModeTlv::MessageModeInfo

8.125.2.2 uint8_t messageModeTlv::TlvPresent

8.126 nas_acqOrderPref Struct Reference

Data Fields

- uint8_t acqOrdeLen
- uint8_t * pAcqOrder

8.126.1 Detailed Description

Contain the Acquisition Order Preference.

Parameters

acqOrdeLen	• Number of sets of the following elements.

pAcqOrder	• Acquisition order preference to be set. Values: – 0x01 - NAS_RADIO_IF_CDMA_1X - cdma2000 1X – 0x02 - NAS_RADIO_IF_CDMA_1XEVDO - cdma2000 HRPD (1xEV-DO) – 0x04 - NAS_RADIO_IF_GSM - GSM – 0x05 - NAS_RADIO_IF_UMTS - UMTS – 0x08 - NAS_RADIO_IF_LTE - LTE – 0x09 - NAS_RADIO_IF_TDSCDMA - TD-SCDMA

8.126.2 Field Documentation

8.126.2.1 uint8_t nas_acqOrderPref::acqOrdeLen

8.126.2.2 uint8_t* nas_acqOrderPref::pAcqOrder

8.127 nas_AcqOrderPrefTlv Struct Reference

Data Fields

- uint8_t acqOrdeLen
- uint8_t * pAcqOrder
- uint8_t TlvPresent

8.127.1 Detailed Description

Contain the Acquisition Order Preference.

Parameters

acqOrdeLen	• Number of sets of the following elements.
pAcqOrder	• Acquisition order preference to be set. Values: – 0x01 - NAS_RADIO_IF_CDMA_1X - cdma2000 1X – 0x02 - NAS_RADIO_IF_CDMA_1XEVDO - cdma2000 HRPD (1xEV-DO) – 0x04 - NAS_RADIO_IF_GSM - GSM – 0x05 - NAS_RADIO_IF_UMTS - UMTS – 0x08 - NAS_RADIO_IF_LTE - LTE – 0x09 - NAS_RADIO_IF_TDSCDMA - TD-SCDMA – 0x0C - NAS_RADIO_IF_NR5G - NR5G
TlvPresent	• Tlv Present

8.127.2 Field Documentation

8.127.2.1 uint8_t nas_AcqOrderPrefTlv::acqOrdeLen

8.127.2.2 uint8_t* nas_AcqOrderPrefTlv::pAcqOrder

8.127.2.3 uint8_t nas_AcqOrderPrefTlv::TlvPresent

8.128 nas_ActPilotPNElement Struct Reference

Data Fields

- uint16_t ActSetPilotPN
- uint8_t ActSetPilotPNStrength

8.128.1 Detailed Description

This structure contains pilot PN Element.

Parameters

ActSetPilotPN	• Active Pilot PN
ActSetPilotPN-Strength	• Active Pilot PN strength

8.128.2 Field Documentation

8.128.2.1 uint16_t nas_ActPilotPNElement::ActSetPilotPN

8.128.2.2 uint8_t nas_ActPilotPNElement::ActSetPilotPNStrength

8.129 nas_AddCDMASysInfo Struct Reference

Data Fields

- uint16_t geoSysIdx
- uint16_t regPrd

8.129.1 Detailed Description

Structure for storing the Additional CDMA System Information.

Parameters

geoSysIdx	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used.
regPrd	• Registration period after the CDMA system is acquired. • When the CDMA registration period is not valid, 0xFFFF is used.

8.129.2 Field Documentation

8.129.2.1 uint16_t nas_AddCDMASysInfo::geoSysIdx

8.129.2.2 uint16_t nas_AddCDMASysInfo::regPrd

8.130 nas_AddSysInfo Struct Reference

Data Fields

- uint16_t geoSysIdx
- uint32_t cellBroadcastCap

8.130.1 Detailed Description

Structure for storing the Additional GSM and WCDMA System Information.

Parameters

geoSysIdx	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used.
cellBroadcast-Cap	• Cell broadcast capability of the serving system. • When the CDMA registration period is not valid, 0xFFFF is used. – NAS_CELL_BROADCAST_CAP_UNKNOWN - Cell broadcast support is unknown – NAS_CELL_BROADCAST_CAP_OFF - Cell broadcast is not supported – NAS_CELL_BROADCAST_CAP_ON - Cell broadcast is supported

8.130.2 Field Documentation

8.130.2.1 uint32_t nas_AddSysInfo::cellBroadcastCap

8.130.2.2 uint16_t nas_AddSysInfo::geoSysIdx

8.131 nas_BandPrefInfoTlv Struct Reference

Data Fields

- uint64_t bits_1_64
- uint64_t bits_65_128
- uint64_t bits_129_192
- uint64_t bits_193_256
- uint8_t TlvPresent

8.131.1 Detailed Description

Contain the Band Preference.

Parameters

bits_1_64	• Bits 1 to 64 of the 256-bit Operating Band bitmask.
bits_65_128	• Bits 65 to 128 of the 256-bit Operating Band bitmask.
bits_129_192	• Bits 129 to 192 of the 256-bit Operating Band bitmask.
bits_193_256	• Bits 193 to 256 of the 256-bit Operating Band bitmask.
TlvPresent	• Tlv Present

8.131.2 Field Documentation

8.131.2.1 uint64_t nas_BandPrefInfoTlv::bits_129_192

8.131.2.2 uint64_t nas_BandPrefInfoTlv::bits_193_256

8.131.2.3 uint64_t nas_BandPrefInfoTlv::bits_1_64

8.131.2.4 uint64_t nas_BandPrefInfoTlv::bits_65_128

8.131.2.5 uint8_t nas_BandPrefInfoTlv::TlvPresent

8.132 nas_BandPrefTlv Struct Reference

Data Fields

- uint64_t BandPref
- uint8_t TlvPresent

8.132.1 Detailed Description

Contain the band preference for system selection preferences.

Parameters

BandPref	• Bitmask representing the radio technologies that are disabled. • Bit values: • Bit mask representing the band preference • Bit values: – Bit 0 - Band Class 0, A-System – Bit 1 - Band Class 0, B-System, Band Class 0 AB, GSM 850 Band – Bit 2 - Band Class 1, all blocks – Bit 3 - Band Class 2 place holder – Bit 4 - Band Class 3, A-System – Bit 5 - Band Class 4, all blocks – Bit 6 - Band Class 5, all blocks – Bit 7 - GSM_DCS_1800 band – Bit 8 - GSM Extended GSM (E-GSM) 900 band – Bit 9 - GSM Primary GSM (P-GSM) 900 band – Bit 10 - Band Class 6 – Bit 11 - Band Class 7 – Bit 12 - Band Class 8 – Bit 13 - Band Class 9 – Bit 14 - Band Class 10 – Bit 15 - Band Class 11 – Bit 16 - GSM 450 band – Bit 17 - GSM 480 band – Bit 18 - GSM 750 band – Bit 19 - GSM 850 band – Bit 20 - GSM Railways GSM 900 Band – Bit 21 - GSM PCS 1900 band – Bit 22 - WCDMA Europe, Japan, and China IMT 2100 band – Bit 23 - WCDMA U.S. PCS 1900 band – Bit 24 - WCDMA Europe and China DCS 1800 band – Bit 25 - WCDMA U.S. 1700 band – Bit 26 - WCDMA U.S. 850 band – Bit 27 - WCDMA Japan 800 band – Bit 28 - Band Class 12 – Bit 29 - Band Class 14 – Bit 30 - Reserved – Bit 31 - Band Class 15 – Bit 32 to 47 - Reserved – Bit 48 - WCDMA Europe 2600 band – Bit 49 - WCDMA Europe and Japan 900 band – Bit 50 - WCDMA Japan 1700 band – Bit 51 to 55 - Reserved – Bit 56 - Band Class 16 – Bit 57 - Band Class 17 – Bit 58 - Band Class 18 – Bit 59 - Band Class 19 – Bit 60 to 64 - Reserved

TlvPresent	• Tlv Present

8.132.2 Field Documentation

8.132.2.1 uint64_t nas_BandPrefTlv::BandPref

8.132.2.2 uint8_t nas_BandPrefTlv::TlvPresent

8.133 nas_CallBarringSysInfo Struct Reference

Data Fields

- uint32_t csBarStatus
- uint32_t psBarStatus

8.133.1 Detailed Description

Structure for storing the GSM and WCDMA Call Barring System Information.

Parameters

csBarStatus	• Call barring status for circuit-switched calls. – NAS_CELL_ACCESS_NORMAL_ONLY - Cell access is allowed for normal calls only – NAS_CELL_ACCESS_EMERGENCY_ONLY - Cell access is allowed for emergency calls only – NAS_CELL_ACCESS_NO_CALLS - Cell access is not allowed for any call type – NAS_CELL_ACCESS_ALL_CALLS - Cell access is allowed for all call types – NAS_CELL_ACCESS_UNKNOWN - Cell access type is unknown
psBarStatus	• Call barring status for packet-switched calls. – NAS_CELL_ACCESS_NORMAL_ONLY - Cell access is allowed for normal calls only – NAS_CELL_ACCESS_EMERGENCY_ONLY - Cell access is allowed for emergency calls only – NAS_CELL_ACCESS_NO_CALLS - Cell access is not allowed for any call type – NAS_CELL_ACCESS_ALL_CALLS - Cell access is allowed for all call types – NAS_CELL_ACCESS_UNKNOWN - Cell access type is unknown

8.133.2 Field Documentation

8.133.2.1 uint32_t nas_CallBarringSysInfo::csBarStatus

8.133.2.2 uint32_t nas_CallBarringSysInfo::psBarStatus

8.134 nas_callBarStatus Struct Reference

Data Fields

- uint32_t csBarStatus
- uint32_t psBarStatus

8.134.1 Detailed Description

This structure contains Call Barring Status.

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

csBarStatus	• Call Barring Status for circuit-switched calls. • Values: • NAS_CELL_ACCESS_NORMAL_ONLY - Cell access is allowed for normal calls only • NAS_CELL_ACCESS_EMERGENCY_ONLY - Cell access is allowed for emergency calls only • NAS_CELL_ACCESS_NO_CALLS - Cell access is not allowed for any call type • NAS_CELL_ACCESS_ALL_CALLS - Cell access is allowed for all call types • NAS_CELL_ACCESS_UNKNOWN - Cell access type is unknown
psBarStatus	• Call Barring Status for packet-switched calls. • Values: – NAS_CELL_ACCESS_NORMAL_ONLY - Cell access is allowed for normal calls only – NAS_CELL_ACCESS_EMERGENCY_ONLY - Cell access is allowed for emergency calls only – NAS_CELL_ACCESS_NO_CALLS - Cell access is not allowed for any call type – NAS_CELL_ACCESS_ALL_CALLS - Cell access is allowed for all call types – NAS_CELL_ACCESS_UNKNOWN - Cell access type is unknown

8.134.2 Field Documentation

8.134.2.1 uint32_t nas_callBarStatus::csBarStatus

8.134.2.2 uint32_t nas_callBarStatus::psBarStatus

8.135 nas_CDMAChannel Struct Reference

Data Fields

- uint16_t priChA
- uint16_t priChB
- uint16_t secChA
- uint16_t secChB

8.135.1 Detailed Description

This structure contains CDMA channel.

Parameters

priChA	• A Channel number for the primary carrier. – 0xFFFF - Not Available
priChB	• B Channel number for the primary carrier. – 0xFFFF - Not Available
secChA	• A Channel number for the secondary carrier. – 0xFFFF - Not Available
secChB	• B Channel number for the secondary carrier. – 0xFFFF - Not Available

8.135.2 Field Documentation

8.135.2.1 uint16_t nas_CDMAChannel::priChA

8.135.2.2 uint16_t nas_CDMAChannel::priChB

8.135.2.3 uint16_t nas_CDMAChannel::secChA

8.135.2.4 uint16_t nas_CDMAChannel::secChB

8.136 nas_CDMAECIOThresh Struct Reference

Data Fields

- uint8_t CDMAECIOThreshListLen
- int16_t * pCDMAECIOThreshList

8.136.1 Detailed Description

This structure contains CDMA ECIO threshold related parameters.

Parameters

CDMAECIO-ThreshListLen	• Length of the CDMA ECIO threshold list parameter to follow
pCDMAECIO-ThreshList	• Array of ECIO thresholds (in units of 0.1 dB) • Maximum of 32 values. Range for ECIO values: -31.5 to 0 (in dB)

8.136.2 Field Documentation

8.136.2.1 uint8_t nas_CDMAECIOThresh::CDMAECIOThreshListLen

8.136.2.2 int16_t* nas_CDMAECIOThresh::pCDMAECIOThreshList

8.137 nas_CDMAInfo Struct Reference

Data Fields

- uint16_t sid
- uint16_t nid
- uint16_t baseId
- uint16_t refpn
- uint32_t baseLat
- uint32_t baseLong

8.137.1 Detailed Description

This structure contains information about the CDMA Network.

Parameters

sid	• System ID. – 0xFFFF - Not Available
nid	• Network ID. – 0xFFFF - Not Available
baseId	• Base station ID. – 0xFFFF - Not Available
refpn	• Reference PN. – 0xFFFF - Not Available
baseLat	• Latitude of the current base station in units of 0.25 sec. – 0xFFFFFFFF - Not Available
baseLong	• Longitude of the current base station in units of 0.25 sec. – 0xFFFFFFFF - Not Available

8.137.2 Field Documentation

8.137.2.1 uint16_t nas_CDMAInfo::baseId

8.137.2.2 uint32_t nas_CDMAInfo::baseLat

8.137.2.3 uint32_t nas_CDMAInfo::baseLong

8.137.2.4 uint16_t nas_CDMAInfo::nid

8.137.2.5 uint16_t nas_CDMAInfo::refpn

8.137.2.6 uint16_t nas_CDMAInfo::sid

8.138 nas_CDMARSSIThresh Struct Reference

Data Fields

- uint8_t CDMARSSIThreshListLen
- int16_t * pCDMARSSIThreshList

8.138.1 Detailed Description

This structure contains CDMA RSSI threshold related parameters.

Parameters

CDMARSSI-ThreshListLen	• Length of the CDMARSSI threshold list parameter to follow
pCDMARSSI-ThreshList	• Array of RSSI thresholds (in units of 0.1 dBm) • maximum of 32 values. • Range for RSSI values:-105 to -21 (in dBm).

8.138.2 Field Documentation

8.138.2.1 uint8_t nas_CDMARSSIThresh::CDMARSSIThreshListLen

8.138.2.2 int16_t* nas_CDMARSSIThresh::pCDMARSSIThreshList

8.139 nas_CDMASysInfo Struct Reference

Data Fields

- nas_sysInfoCommon sysInfoCDMA
- uint8_t isSysPrlMatchValid
- uint8_t isSysPrlMatch
- uint8_t pRevInUseValid
- uint8_t pRevInUse
- uint8_t bsPRevValid
- uint8_t bsPRev
- uint8_t ccsSupportedValid
- uint8_t ccsSupported
- uint8_t cdmaSysIdValid
- uint16_t systemID
- uint16_t networkID
- uint8_t bsInfoValid
- uint16_t baseId
- uint32_t baseLat

- uint32_t baseLong
- uint8_t packetZoneValid
- uint16_t packetZone
- uint8_t networkIdValid
- uint8_t MCC [3]
- uint8_t MNC [3]

8.139.1 Detailed Description

Structure for storing the CDMA System Information.

Parameters

sysInfoCDMA	• See nas_sysInfoCommon for more information.
isSysPrlMatch-Valid	• Indicates whether the system PRL match is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
isSysPrlMatch	• Indicates whether the system is in a PRL. • Only applies to CDMA/HDR. – 0x00 - System is not in a PRL – 0x01 - System is in a PRL – 0xFF - Not Available • If the system is not in a PRL, roam_status carries the value from the default roaming indicator in the PRL. • If the system is in a PRL, roam_status is set to the value based on the standard specification.
pRevInUseValid	• Indicates whether the P_Rev in use is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
pRevInUse	• The lesser of the base station P_Rev and mobile P_Rev • Only applicable for CDMA. – 0xFF - Not Available
bsPRevValid	• Indicates whether the base station P_Rev is valid – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
bsPRev	• Base station P_Rev. • Only applicable for CDMA. – 0xFF - Not Available

ccsSupported-Valid	• Indicates whether the supported concurrent service is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
ccsSupported	• Whether concurrent service is supported. • Only applicable for CDMA. – 0x00 - Not supported – 0x01 - Supported – 0xFF - Not Available
cdmaSysIdValid	• Indicates whether the CDMA system ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
systemID	• System ID. – 0xFFFF - Not Available
networkID	• Network ID. – 0xFFFF - Not Available
bsInfoValid	• Indicates whether the base station information is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
baseLat	• Base station latitude in units of 0.25 sec. • Expressed as a two's complement signed number with positive numbers signifying North latitudes. – 0xFFFFFFFF - Not Available
baseLong	• Base station longitude in units of 0.25 sec. • Expressed as a two's complement signed number with positive numbers signifying East latitudes. – 0xFFFFFFFF - Not Available
packetZoneValid	• Indicates whether the packet zone is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available

packetZone	• Packet zone (8-bit). – 0xFFFF indicates no packet zone. • Only applicable for CDMA.
networkIdValid	• Indicates whether the network ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
MCC[NAS_PLMN_LENGTH]	• Mobile Country Code. • MCC digits in ASCII characters • MCC wildcard value is returned as {'3', 0xFF, 0xFF}.
MNC[NAS_PLMN_LENGTH]	• Mobile Network Code. • MNC digits in ASCII characters • An unused byte is set to 0xFF. • MNC wildcard value is returned as {'7', 0xFF, 0xFF}.

8.139.2 Field Documentation

8.139.2.1 uint16_t nas_CDMASysInfo::baseId

8.139.2.2 uint32_t nas_CDMASysInfo::baseLat

8.139.2.3 uint32_t nas_CDMASysInfo::baseLong

8.139.2.4 uint8_t nas_CDMASysInfo::bsInfoValid

8.139.2.5 uint8_t nas_CDMASysInfo::bsPRev

8.139.2.6 uint8_t nas_CDMASysInfo::bsPRevValid

8.139.2.7 uint8_t nas_CDMASysInfo::ccsSupported

8.139.2.8 uint8_t nas_CDMASysInfo::ccsSupportedValid

8.139.2.9 uint8_t nas_CDMASysInfo::cdmaSysIdValid

8.139.2.10 uint8_t nas_CDMASysInfo::isSysPrlMatch

8.139.2.11 uint8_t nas_CDMASysInfo::isSysPrlMatchValid

8.139.2.12 uint8_t nas_CDMASysInfo::MCC[3]

8.139.2.13 uint8_t nas_CDMASysInfo::MNC[3]

8.139.2.14 uint16_t nas_CDMASysInfo::networkID

8.139.2.15 uint8_t nas_CDMASysInfo::networkIdValid

8.139.2.16 uint16_t nas_CDMASysInfo::packetZone

8.139.2.17 uint8_t nas_CDMASysInfo::packetZoneValid

8.139.2.18 uint8_t nas_CDMASysInfo::pRevInUse

8.139.2.19 uint8_t nas_CDMASysInfo::pRevInUseValid

8.139.2.20 nas_sysInfoCommon nas_CDMASysInfo::sysInfoCDMA

8.139.2.21 uint16_t nas_CDMASysInfo::systemID

8.140 nas_CDMASysInfoExt Struct Reference

Data Fields

- uint16_t MCC
- uint8_t imsi_11_12

8.140.1 Detailed Description

This structure contains CDMA system information extension

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

MCC	• Mobile Country Code
imsi_11_12	• IMSI_11_12

8.140.2 Field Documentation

8.140.2.1 uint8_t nas_CDMASysInfoExt::imsi_11_12

8.140.2.2 uint16_t nas_CDMASysInfoExt::MCC

8.141 nas_cellParams Struct Reference

Data Fields

- uint16_t pci
- int16_t rsrq
- int16_t rsrp
- int16_t rssi
- int16_t srxlev

8.141.1 Detailed Description

This structure contains information about the Cell parameters.

Parameters

pci	• Physical cell ID. • Range: 0 to 503.
rsrq	• Current RSRQ in 1/10 dB as measured by L1. • Range: -20.0 dB to -3.0 dB.
rsrp	• Current RSRP in 1/10 dBm as measured by L1. • Range: -140.0 dBm to -44.0 dBm.
rssi	• Current RSSI in 1/10 dBm as measured by L1. • Range: -120.0 dBm to 0.
srxlev	• Cell selection Rx level (Srxlev) value. • Range: -128 to 128. • This field is only valid when ue_in_idle is TRUE.

8.141.2 Field Documentation

8.141.2.1 uint16_t nas_cellParams::pci

8.141.2.2 int16_t nas_cellParams::rsrp

8.141.2.3 int16_t nas_cellParams::rsrq

8.141.2.4 int16_t nas_cellParams::rssi

8.141.2.5 int16_t nas_cellParams::srxlev

8.142 nas_ciotAcqOrderPref Struct Reference

Data Fields

- uint8_t ciotAcqOrderLen
- uint32_t * pCiotAcqOrder

8.142.1 Detailed Description

Contain the CIOT Acquisition Order Preference.

Parameters

ciotAcqOrderLen	• Number of sets of the following elements.
pCiotAcqOrder	• CIOT Acquisition order preference to be set. • Values – 0x01 - cdma2000 ®1X – 0x02 - cdma2000 ® HRPD (1xEV-DO) – 0x04 - GSM – 0x05 - UMTS – 0x08 - LTE – 0x09 - TD-SCDMA – 0x0a - LTE_M1 – 0x0b - LTE_NB1

8.142.2 Field Documentation

8.142.2.1 uint8_t nas_ciotAcqOrderPref::ciotAcqOrderLen

8.142.2.2 uint32_t* nas_ciotAcqOrderPref::pCiotAcqOrder

8.143 nas_CiotAcqOrderPrefTlv Struct Reference

Data Fields

- uint8_t ciotAcqOrderLen
- uint32_t * pCiotAcqOrder
- uint8_t TlvPresent

8.143.1 Detailed Description

Contain the CIOT Acquisition Order Preference.

Parameters

ciotAcqOrderLen	• Number of sets of the following elements.
pCiotAcqOrder	• CIOT Acquisition order preference to be set. • Values – 0x01 - cdma2000 ®1X – 0x02 - cdma2000 ® HRPD (1xEV-DO) – 0x04 - GSM – 0x05 - UMTS – 0x08 - LTE – 0x09 - TD-SCDMA – 0x0a - LTE_M1 – 0x0b - LTE_NB1

TlvPresent	• Tlv Present

8.143.2 Field Documentation

8.143.2.1 uint8_t nas_CiotAcqOrderPrefTlv::ciotAcqOrderLen

8.143.2.2 uint32_t* nas_CiotAcqOrderPrefTlv::pCiotAcqOrder

8.143.2.3 uint8_t nas_CiotAcqOrderPrefTlv::TlvPresent

8.144 nas_CiotLteOpModePrefTlv Struct Reference

Data Fields

- uint64_t ciotLteOpModePref
- uint8_t TlvPresent

8.144.1 Detailed Description

Contain the CIOT LTE Operational Mode Preference.

Parameters

ciotLteOpMode-Pref	• CIOT LTE Operational Mode Preference • Values: – Bit 0 (0x01) - LTE wideband – Bit 1 (0x02) - LTE M1 – Bit 2 (0x04) - LTE NB1 All unlisted bits are reserved for future use and the service point ignores them if used.
TlvPresent	• Tlv Present

8.144.2 Field Documentation

8.144.2.1 uint64_t nas_CiotLteOpModePrefTlv::ciotLteOpModePref

8.144.2.2 uint8_t nas_CiotLteOpModePrefTlv::TlvPresent

8.145 nas_CommInfo Struct Reference

Data Fields

- int8_t temperature
- uint8_t modemMode
- uint8_t systemMode
- uint8_t imsRegState

- uint8_t psState

8.145.1 Detailed Description

Structure for storing the common information for the device.

Parameters

temperature	• Temperature. – 8-bit signed integer – 0xFF - Not Available.
modemMode	• Modem Operating Mode. – 0x00 - POWERING OFF – 0x01 - FACTORY TEST – 0x02 - OFFLINE – 0x03 - OFFLINE_AMPS – 0x04 - OFFLINE_CDMA – 0x05 - ONLINE – 0x06 - LOW POWER MODE – 0x07 - RESETTING – 0x08 - NETWORK TEST – 0x09 - OFFLINE REQUEST – 0x0A - PSEUDO ONLINE – 0x0B - RESETTING MODEM – 0xFF - Unknown
systemMode	• System Acquisition Mode. – 0x00 - No service – 0x01 - AMPS – 0x02 - CDMA – 0x03 - GSM – 0x04 - HDR – 0x05 - WCDMA – 0x06 - GPS – 0x08 - WLAN – 0x09 - LTE – 0xFF - Unknown
imsRegState	• IMS Registration State. – 0x00 - NO SRV – 0x01 - IN PROG – 0x02 - FAILED – 0x03 - LIMITED – 0x04 - FULL SRV – 0xFF - Unknown

psState	• PS Attach State. – 0x00 - Attached – 0x01 - Detached – 0xFF - Unknown

8.145.2 Field Documentation

8.145.2.1 uint8_t nas_CommInfo::imsRegState

8.145.2.2 uint8_t nas_CommInfo::modemMode

8.145.2.3 uint8_t nas_CommInfo::psState

8.145.2.4 uint8_t nas_CommInfo::systemMode

8.145.2.5 int8_t nas_CommInfo::temperature

8.146 nas_CSGID Struct Reference

Data Fields

- uint16_t mcc
- uint16_t mnc
- uint8_t mncPcsDigits
- uint32_t id
- uint8_t rat

8.146.1 Detailed Description

Contain the CSGID.

Parameters

mcc	• MCC value. Range 0 to 999
mnc	• MNC value. Range 0 to 999
mncPcsDigits	• TRUE - MNC is a three-digit value; e.g., a reported value of 90 corresponds to an MNC value of 090 • FALSE - MNC is a two-digit value; e.g., a reported value of 90 corresponds to an MNC value of 90
id	• Closed subscriber group identifier.

rat	• Radio interface technology of the CSG network. Values: – 0x04 - RADIO_IF_GSM - GSM – 0x05 - RADIO_IF_UMTS - UMTS – 0x08 - RADIO_IF_LTE - LTE – 0x09 - RADIO_IF_TDSCDMA - TDS

8.146.2 Field Documentation

8.146.2.1 uint32_t nas_CSGID::id

8.146.2.2 uint16_t nas_CSGID::mcc

8.146.2.3 uint16_t nas_CSGID::mnc

8.146.2.4 uint8_t nas_CSGID::mncPcsDigits

8.146.2.5 uint8_t nas_CSGID::rat

8.147 nas_CsgId Struct Reference

Data Fields

- uint32_t csgId
- uint8_t TlvPresent

8.147.1 Detailed Description

This structure contains csg ID.

Parameters

csgId	• Closed subscriber group identifier.
TlvPresent	• Tlv Present or not

8.147.2 Field Documentation

8.147.2.1 uint32_t nas_CsgId::csgId

8.147.2.2 uint8_t nas_CsgId::TlvPresent

8.148 nas_currentPLMN Struct Reference

Data Fields

- uint16_t MCC

- uint16_t MNC
- uint8_t netDescrLength
- uint8_t netDescr [255]

8.148.1 Detailed Description

This structure contains the current PLMN parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

MCC	• mobile country code – A 16 bit representation of MCC – Range 0 to 999
MNC	• mobile network code – A 16 bit representation of MNC – Range 0 to 999
netDescrLength	• Length of Network description field • Defaults to zero
netDescr	• Network Description – optional string containing network name or description

8.148.2 Field Documentation

8.148.2.1 uint16_t nas_currentPLMN::MCC

8.148.2.2 uint16_t nas_currentPLMN::MNC

8.148.2.3 uint8_t nas_currentPLMN::netDescr[255]

8.148.2.4 uint8_t nas_currentPLMN::netDescrLength

8.149 nas_dataSrvCapabilities Struct Reference

Data Fields

- uint8_t dataCapabilitiesLen
- uint8_t dataCapabilities [32]

8.149.1 Detailed Description

This structure contains the data services capability

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

dataCapabilities-Len	• Length of data capabilities list • Defaults to zero
dataCapabilities	• List of data capabilities • Values: – 0x01 - GPRS – 0x02 - EDGE – 0x03 - HSDPA – 0x04 - HSUPA – 0x05 - WCDMA – 0x06 - CDMA – 0x07 - EV-DO Rev0 – 0x08 - EV-DO RevA – 0x09 - GSM – 0x0A - EV-DO Rev B – 0x0B - LTE – 0x0C - HSDPA+ – 0x0D - DC-HSDPA+

8.149.2 Field Documentation

8.149.2.1 uint8_t nas_dataSrvCapabilities::dataCapabilities[32]

8.149.2.2 uint8_t nas_dataSrvCapabilities::dataCapabilitiesLen

8.150 nas_DataStatusDetail Struct Reference

Data Fields

- uint32_t IPAddress
- uint8_t LastErrCode

8.150.1 Detailed Description

This structure contains data status detail

Parameters

IPAddress	• IP Address • 0xABCDEFGH - AB.CD.EF.GH • Example: – 0x12345678 - 18.52.86.120 0x12=18 0x34=52 0x56=86 0x78=120 • 0xFFFFFFFF - NA

LastErrCode	• MIP Error code – 0x00 - MIP_RRP_CODE_SUCCESS – 0x01 - MIP_RRP_CODE_SUCCESS_NO_SIM_BINDINGS – 0x40 - MIP_RRP_CODE_FAILURE_FA_REASON_UNSPECIFIED – 0x41 - MIP_RRP_CODE_FAILURE_FA_ADMIN_PROHIBITED – 0x42 - MIP_RRP_CODE_FAILURE_FA_INSUFFICIENT_RESOURCES – 0x43 - MIP_RRP_CODE_FAILURE_FA_MOBILE_NODE_FAILED_AUTH – 0x44 - MIP_RRP_CODE_FAILURE_FA_HA_FAILED_AUTH – 0x45 - MIP_RRP_CODE_FAILURE_FA_REQUESTED_LIFETIME_TOO_LONG – 0x46 - MIP_RRP_CODE_FAILURE_FA_MALFORMED_REQUEST – 0x47 - MIP_RRP_CODE_FAILURE_FA_MALFORMED_REPLY – 0x48 - MIP_RRP_CODE_FAILURE_FA_ENCAPSULATION_UNAVAILABLE – 0x49 - MIP_RRP_CODE_FAILURE_FA_VJHC_UNAVAILABLE – 0x4A - MIP_RRP_CODE_FAILURE_FA_CANT_REV_TUN – 0x4B - MIP_RRP_CODE_FAILURE_FA_MUST_REV_TUN – 0x4C - MIP_RRP_CODE_FAILURE_FA_BAD_TTL – 0x4D - MIP_RRP_CODE_FAILURE_INVALID_COA – 0x4F - MIP_RRP_CODE_FAILURE_FA_DELIVERY_STYLE_NOT_SUPPORTED – 0x59 - MIP_RRP_CODE_FAILURE_FA_VS_REASON – 0x61 - MIP_RRP_CODE_FAILURE_MISSING_NAI – 0x62 - MIP_RRP_CODE_FAILURE_MISSING_HA_ADDR – 0x63 - MIP_RRP_CODE_FAILURE_MISSING_HOMEADDR – 0x68 - MIP_RRP_CODE_FAILURE_UNKNOWN_CHALLENGE – 0x69 - MIP_RRP_CODE_FAILURE_MISSING_CHALLENGE – 0x6A - MIP_RRP_CODE_FAILURE_STALE_CHALLENGE – 0x6B - MIP_RRP_CODE_FAILURE_MISSING_MN_FA – 0x80 - MIP_RRP_CODE_FAILURE_HA_REASON_UNSPECIFIED – 0x81 - MIP_RRP_CODE_FAILURE_HA_ADMIN_PROHIBITED – 0x82 - MIP_RRP_CODE_FAILURE_HA_INSUFFICIENT_RESOURCES – 0x83 - MIP_RRP_CODE_FAILURE_HA_MOBILE_NODE_FAILED_AUTH – 0x84 - MIP_RRP_CODE_FAILURE_HA_FA_FAILED_AUTH – 0x85 - MIP_RRP_CODE_FAILURE_HA_REG_ID_MISMATCH – 0x86 - MIP_RRP_CODE_FAILURE_HA_MALFORMED_REQUEST – 0x88 - MIP_RRP_CODE_FAILURE_UNKNOWN_HA – 0x89 - MIP_RRP_CODE_FAILURE_HA_CANT_REV_TUN – 0x8A - MIP_RRP_CODE_FAILURE_HA_MUST_REV_TUN – 0x8B - MIP_RRP_CODE_FAILURE_HA_ENCAPSULATION_UNAVAILABLE – 0x8F - MIP_RRP_CODE_FAILURE_REDIRECTED_HA – 0x90 - MIP_RRP_CODE_FAILURE_HA_BAD_AAA_AUTH – 0xFF - NA

8.150.2 Field Documentation

8.150.2.1 uint32_t nas_DataStatusDetail::IPAddress

8.150.2.2 uint8_t nas_DataStatusDetail::LastErrCode

8.151 nas_detailSvcInfo Struct Reference

Data Fields

- uint8_t srvStatus
- uint8_t srvCapability
- uint8_t hdrSrvStatus
- uint8_t hdrHybrid
- uint8_t isSysForbidden

8.151.1 Detailed Description

This structure contains Detailed Service information

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

srvStatus	• Service status • Values: – 0x00 - No service – 0x01 - Limited service – 0x02 - Service available – 0x03 - Limited regional service – 0x04 - MS in power save or deep sleep
srvCapability	• System's service capability • Values: – 0x00 - No Service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - MS found the right system but not yet registered/attached
hdrSrvStatus	• HDR service status • Values: – 0x00 - No service – 0x01 - Limited service – 0x02 - Service available – 0x03 - Limited regional service – 0x04 - MS in power save or deep sleep
hdrHybrid	• HDR hybrid information • Values: – 0x00 - System is not hybrid – 0x01 - System is hybrid

isSysForbidden	• Forbidden system information • Values: – 0x00 - System is not a forbidden system – 0x01 - System is a forbidden system

8.151.2 Field Documentation

8.151.2.1 uint8_t nas_detailSvcInfo::hdrHybrid

8.151.2.2 uint8_t nas_detailSvcInfo::hdrSrvStatus

8.151.2.3 uint8_t nas_detailSvcInfo::isSysForbidden

8.151.2.4 uint8_t nas_detailSvcInfo::srvCapability

8.151.2.5 uint8_t nas_detailSvcInfo::srvStatus

8.152 nas_DeviceConfigDetail Struct Reference

Data Fields

- uint8_t Technology
- uint8_t QLIC
- uint8_t Chipset
- uint8_t HWVersion

8.152.1 Detailed Description

This structure contains device configure detail.

Parameters

Technology	• Current technology in use – 0x00 - 1x RTT – 0x01 - EVDO Rev 0 – 0x02 - EVDO Rev A – 0xFF - NA
QLIC	• Quasi Linear Interference Cancellation – 0x00 - Not supported – 0x01 - Supported
Chipset	• Qualcomm platform – 0x4E - MDM6200 – 0x4F - MDM6600 – 0xFF - NA

HWVersion	• Hardware version – 0x00 - BSHWREV0 – 0x01 - BSHWREV1 – 0x02 - BSHWREV2 – 0x03 - BSHWREV3 – 0x04 - BSHWREVMAX – 0xFF - BSHWREVUNKNOWN

8.152.2 Field Documentation

8.152.2.1 uint8_t nas_DeviceConfigDetail::Chipset

8.152.2.2 uint8_t nas_DeviceConfigDetail::HWVersion

8.152.2.3 uint8_t nas_DeviceConfigDetail::QLIC

8.152.2.4 uint8_t nas_DeviceConfigDetail::Technology

8.153 nas_dirNum Struct Reference

Data Fields

- uint8_t dirNumLen
- uint8_t dirNum [255]

8.153.1 Detailed Description

This structure contains the parameters for Directory Number Information

Parameters

dirNumLen	• Number of sets of the following elements: – dir_num • If zero(0), then no information follows.
dirNum	• Directory number in ASCII characters.

8.153.2 Field Documentation

8.153.2.1 uint8_t nas_dirNum::dirNum[255]

8.153.2.2 uint8_t nas_dirNum::dirNumLen

8.154 nas_DRCParams Struct Reference

Data Fields

- uint8_t DRCValue
- uint8_t DRCCover

8.154.1 Detailed Description

This structure contains DRC information.

Parameters

DRCValue	• Current Data Rate Channel
DRCCover	• Current Data Rate Channel cover

8.154.2 Field Documentation

8.154.2.1 uint8_t nas_DRCParams::DRCCover

8.154.2.2 uint8_t nas_DRCParams::DRCValue

8.155 nas_ecioListElement Struct Reference

Data Fields

- int16_t ecio
- uint8_t radioIf

8.155.1 Detailed Description

This structure contains the ECIO Information

Parameters

ecio	• ECIO value in dBm
radioIf	• Radio interface technology of the signal being measured – 0x00 – RADIO_IF_NO_SVC – None (no service) – 0x01 – RADIO_IF_CDMA_1X – cdma2000® 1X – 0x02 – RADIO_IF_CDMA_1XEVDO – cdma2000 HRPD (1xEV-DO) – 0x03 – RADIO_IF_AMPS – AMPS – 0x04 – RADIO_IF_GSM – GSM – 0x05 – RADIO_IF_UMTS – UMTS

8.155.2 Field Documentation

8.155.2.1 int16_t nas_ecioListElement::ecio

8.155.2.2 uint8_t nas_ecioListElement::radioIf

8.156 nas_ECIOThresh Struct Reference

Data Fields

- uint8_t ECIOThresListLen
- int16_t * pECIOThresList

8.156.1 Detailed Description

This sturcture contain ECIO threshold list.

Parameters

ECIOThresList-Len	• Length of the ECIO threshold list parameter to follow
pECIOThresList	• Sequence of thresholds delimiting ECIO event reporting bands • Every time a new ECIO value crosses a threshold value, an event report indication message with the new ECIO value is sent to the requesting control point. For this field – Each ECIO threshold value is a signed 2 byte value – Each ECIO threshold value increments in negative 0.5 dB, e.g., an ECIO threshold value of 2 means -1dB – Maximum number of threshold values is 16 – At least one value must be specified – Threshold values specified above are used for all RATs

8.156.2 Field Documentation

8.156.2.1 uint8_t nas_ECIOThresh::ECIOThresListLen

8.156.2.2 int16_t* nas_ECIOThresh::pECIOThresList

8.157 nas_EdrxCiotLteMode Struct Reference

Data Fields

- uint32_t lteOpMode
- uint8_t TlvPresent

8.157.1 Detailed Description

This structure contains the parameters for LTE Operational Mode Indicator Type.

Parameters

lteOpMode	• CIOT LTE mode. • Values – NAS_CIOT_SYS_MODE_NO_SRV (0x00) - No service – NAS_CIOT_SYS_MODE_LTE_WB (0x01) - Camped on LTE wideband – NAS_CIOT_SYS_MODE_LTE_M1 (0x02) - Camped on LTE M1 – NAS_CIOT_SYS_MODE_LTE_NB1 (0x03) - Camped on LTE NB1
TlvPresent	• Tlv Present.

8.157.2 Field Documentation

8.157.2.1 uint32_t nas_EdrxCiotLteMode::lteOpMode

8.157.2.2 uint8_t nas_EdrxCiotLteMode::TlvPresent

8.158 nas_EdrxCycleLength Struct Reference

Data Fields

- uint8_t cycleLength
- uint8_t TlvPresent

8.158.1 Detailed Description

This structure contains the parameters for eDRX Cycle Length Indicator Type.

Parameters

cycleLength	• eDRX cycle length. Value is per 3GPP TS 24.008 Rel-13 Section 10.5.5.32.
TlvPresent	• Tlv Present.

8.158.2 Field Documentation

8.158.2.1 uint8_t nas_EdrxCycleLength::cycleLength

8.158.2.2 uint8_t nas_EdrxCycleLength::TlvPresent

8.159 nas_EdrxEnableType Struct Reference

Data Fields

- uint8_t edrxEnabled
- uint8_t TlvPresent

8.159.1 Detailed Description

This structure contains the parameters for eDRX Enabled Indicator Type.

Parameters

edrxEnabled	• Values – 0x00 - Disabled – 0x01 - Enabled
TlvPresent	• Tlv Present.

8.159.2 Field Documentation

8.159.2.1 uint8_t nas_EdrxEnableType::edrxEnabled

8.159.2.2 uint8_t nas_EdrxEnableType::TlvPresent

8.160 nas_EdrxPagingTimeWindow Struct Reference

Data Fields

- uint8_t edrxPtw
- uint8_t TlvPresent

8.160.1 Detailed Description

This structure contains the parameters for eDRX Paging Time Window Indicator Type.

Parameters

edrxPtw	• eDRX paging time window. Value is per 3GPP TS 24.008 Rel-13 Section 10.5.5.32
TlvPresent	• Tlv Present.

8.160.2 Field Documentation

8.160.2.1 uint8_t nas_EdrxPagingTimeWindow::edrxPtw

8.160.2.2 uint8_t nas_EdrxPagingTimeWindow::TlvPresent

8.161 nas_EdrxRatType Struct Reference

Data Fields

- uint8_t edrxRatType
- uint8_t TlvPresent

8.161.1 Detailed Description

This structure contains the parameters for eDRX RAT type Indicator Type.

Parameters

edrxRatType	• Radio access technology • Values – NAS_RADIO_IF_NO_SVC (0x00) - None (no service) – NAS_RADIO_IF_CDMA_1X (0x01) - cdma2000 ® 1X – NAS_RADIO_IF_CDMA_1XEVDO (0x02) - cdma2000 ® HRPD (1xEV-DO) – NAS_RADIO_IF_AMPS (0x03) - AMPS – NAS_RADIO_IF_GSM (0x04) - GSM – NAS_RADIO_IF_UMTS (0x05) - UMTS – NAS_RADIO_IF_WLAN (0x06) - WLAN – NAS_RADIO_IF_GPS (0x07) - GPS – NAS_RADIO_IF_LTE (0x08) - LTE – NAS_RADIO_IF_TDSCDMA (0x09) - TD-SCDMA – NAS_RADIO_IF_LTE_M1 (0x0a) - LTE-M1 – NAS_RADIO_IF_LTE_NB1 (0x0b) - LTE-NB1 – NAS_RADIO_IF_NO_CHANGE (-1) - No change
TlvPresent	• Tlv Present.

8.161.2 Field Documentation

8.161.2.1 uint8_t nas_EdrxRatType::edrxRatType

8.161.2.2 uint8_t nas_EdrxRatType::TlvPresent

8.162 nas_EmerModeTlv Struct Reference

Data Fields

- uint8_t EmerMode
- uint8_t TlvPresent

8.162.1 Detailed Description

Contain the emergency Mode parameters for system selection preferences.

Parameters

EmerMode	• Emergency Mode • Values: – 0 - OFF (normal) – 1 - ON (Emergency)

TlvPresent	• Tlv Present

8.162.2 Field Documentation

8.162.2.1 uint8_t nas_EmerModeTlv::EmerMode

8.162.2.2 uint8_t nas_EmerModeTlv::TlvPresent

8.163 nas_errorRateListElement Struct Reference

Data Fields

- uint16_t errorRate
- uint8_t radioIf

8.163.1 Detailed Description

This structure contains the Error Rate Information

Parameters

errorRate	• Error rate value corresponds to the RAT that is currently registered. – For CDMA, the error rate reported is Frame Error Rate: * Valid error rate values between 1 and 10000 are returned to indicate percentage, e.g., a value of 300 means the error rate is 3% * A value of 0xFFFF indicates that the error rate is unknown or unavailable – For HDR, the error rate reported is Packet Error Rate: * Valid error rate values between 1 and 10000 are returned to indicate percentage, e.g., a value of 300 means the error rate is 3% * A value of 0xFFFF indicates that the error rate is unknown or unavailable – For GSM, the error rate reported is Bit Error Rate: * Valid values are 0, 100, 200, 300, 400, 500, 600, and 700 The reported value divided by 100 gives the error rate as an RxQual value, e.g.,a value of 300 represents an RxQual value of 3. * A value of 25500 indicates No Data – For WCDMA, the error rate reported is Block Error Rate (BLER): * Valid values are 1 to 10000 * The reported value divided by 100 provides the error rate in percentages, e.g., a value of 300 represents a BLER of 3%. * A value of 0 indicates No Data

radioIf	• Radio interface technology of the signal being measured – 0x00 – RADIO_IF_NO_SVC – None (no service) – 0x01 – RADIO_IF_CDMA_1X – cdma2000® 1X – 0x02 – RADIO_IF_CDMA_1XEVDO – cdma2000 HRPD (1xEV-DO) – 0x03 – RADIO_IF_AMPS – AMPS – 0x04 – RADIO_IF_GSM – GSM – 0x05 – RADIO_IF_UMTS – UMTS

8.163.2 Field Documentation

8.163.2.1 uint16_t nas_errorRateListElement::errorRate

8.163.2.2 uint8_t nas_errorRateListElement::radioIf

8.164 nas_ForbiddenNetworks3GPP Struct Reference

Data Fields

- uint16_t forbiddenNwInstLen
- uint16_t MCC [255]
- uint16_t MNC [255]
- uint8_t TlvPresent

8.164.1 Detailed Description

This structure contains the ForbiddenNetworks3GPP response parameters.

Parameters

forbiddenNwInst-Len	• Number of sets of the following elements – MCC – MNC
MCC	• Mobile Country Code • A 16-bit integer representation of MCC • Range: 0 to 999
MNC	• Mobile Network Code • A 16-bit integer representation of MNC • Range: 0 to 999
TlvPresent	• Tlv Present

8.164.2 Field Documentation

8.164.2.1 uint16_t nas_ForbiddenNetworks3GPP::forbiddenNwInstLen

8.164.2.2 uint16_t nas_ForbiddenNetworks3GPP::MCC[255]

8.164.2.3 uint16_t nas_ForbiddenNetworks3GPP::MNC[255]

8.164.2.4 uint8_t nas_ForbiddenNetworks3GPP::TlvPresent

8.165 nas_GERANInfo Struct Reference

Data Fields

- uint32_t cellID
- uint8_t plmn [3]
- uint16_t lac
- uint16_t arfcn
- uint8_t bsic
- uint32_t timingAdvance
- uint16_t rxLev
- uint8_t nmrInst
- nas_nmrCellInfo insNmrCellInfo [255]

8.165.1 Detailed Description

This structure contains information about the GERAN Network.

Parameters

cellID	• Cell ID. • 0xFFFFFFFF indicates cell ID information is not present.
plmn[NAS_PLMN_LENGTH]	• MCC/MNC information coded as octet 3, 4, and 5. • This field is ignored when nmrCellID is not present.
lac	• Location area code. • This field is ignored when nmrCellID is not present. – 0xFFFF - Not Available
arfcn	• Absolute RF channel number. – 0xFFFF - Not Available
bsic	• Base station identity code. – 0xFF - Not Available

timingAdvance	• Measured delay (in bit periods; 1 bit period = 48/13 microsecond) of access burst transmission on RACH or PRACH to the expected signal from an MS at zero distance under static channel conditions. – 0xFFFFFFFF - Not Available
rxLev	• Serving Cell Rx measurement. • Values range between 0 and 63. • Mapped to a measured signal level: – Rxlev 0 is a signal strength less than -110 dBm – Rxlev 1 is -110 dBm to -109 dBm – Rxlev 2 is -109 dBm to -108 dBm – ... – Rxlev 62 is -49 dBm to -48 dBm – Rxlev 63 is greater than -48 dBm – 0xFFFF - Not Available
nmrInst	• Provides the number of set of instances which follow. • If 0(zero), then no information follows it.
insNmrCellInfo[-NAS_MAX_DESCRIPTION_LENGTH]	• See nas_nmrCellInfo for more information.

8.165.2 Field Documentation

8.165.2.1 uint16_t nas_GERANInfo::arfcn

8.165.2.2 uint8_t nas_GERANInfo::bsic

8.165.2.3 uint32_t nas_GERANInfo::cellID

8.165.2.4 nas_nmrCellInfo nas_GERANInfo::insNmrCellInfo[255]

8.165.2.5 uint16_t nas_GERANInfo::lac

8.165.2.6 uint8_t nas_GERANInfo::nmrInst

8.165.2.7 uint8_t nas_GERANInfo::plmn[3]

8.165.2.8 uint16_t nas_GERANInfo::rxLev

8.165.2.9 uint32_t nas_GERANInfo::timingAdvance

8.166 nas_geranInstInfo Struct Reference

Data Fields

- uint16_t geranArfcn

- uint8_t geranBsicNcc
- uint8_t geranBsicBcc
- int16_t geranRssi

8.166.1 Detailed Description

This structure contains information about the GERAN Instances in UMTS Network.

Parameters

geranArfcn	• Absolute RF channel number.
geranBsicNcc	• Base station identity code network color code. • 0xFF indicates information is not present.
geranBsicBcc	• Base station identity code base station color code. • 0xFF indicates information is not present.
geranRssi	• Received signal strength indicator.

8.166.2 Field Documentation

8.166.2.1 uint16_t nas_geranInstInfo::geranArfcn

8.166.2.2 uint8_t nas_geranInstInfo::geranBsicBcc

8.166.2.3 uint8_t nas_geranInstInfo::geranBsicNcc

8.166.2.4 int16_t nas_geranInstInfo::geranRssi

8.167 nas_gsmCellInfo Struct Reference

Data Fields

- uint16_t arfcn
- uint8_t band1900
- uint8_t cellIdValid
- uint8_t bsicId
- int16_t rssi
- int16_t srxlev

8.167.1 Detailed Description

This structure contains information about the GSM Cell.

Parameters

arfcn	• GSM frequency being reported. • Range: 0 to 1023.
band1900	• Band indicator for the GSM ARFCN • This field is only valid if arfcn is in the overlapping region. • If TRUE and the cell is in the overlapping region, the ARFCN is on the 1900 band. • If FALSE, it is on the 1800 band.
cellIdValid	• Flag indicating whether the base station identity code ID is valid.
bsicId	• Base station identity code ID, including base station color code and network color code. • The lower 6 bits can be set to any value.
rssi	• Measured RSSI value in 1/10 dB. • Range: -200.0 dB to 0
srxlev	• Cell selection Rx level (Srxlev) value. • Range: -128 to 128. • This field is only valid when ue_in_idle is TRUE.

8.167.2 Field Documentation

8.167.2.1 uint16_t nas_gsmCellInfo::arfcn

8.167.2.2 uint8_t nas_gsmCellInfo::band1900

8.167.2.3 uint8_t nas_gsmCellInfo::bsicId

8.167.2.4 uint8_t nas_gsmCellInfo::cellIdValid

8.167.2.5 int16_t nas_gsmCellInfo::rssi

8.167.2.6 int16_t nas_gsmCellInfo::srxlev

8.168 nas_GSMRSSIThresh Struct Reference

Data Fields

- uint8_t GSMRSSIThreshListLen
- int16_t * pGSMRSSIThreshList

8.168.1 Detailed Description

This structure contains GSM RSSI threshold related parameters.

Parameters

GSMRSSI-ThreshListLen	• Length of the GSM RSSI threshold list parameter to follow
pGSMRSSI-ThreshList	• Array of RSSI thresholds (in units of 0.1 dBm) • Maximum of 32 values • Range for RSSI values: -111 to -48 (in dBm)

8.168.2 Field Documentation

8.168.2.1 uint8_t nas_GSMRSSIThresh::GSMRSSIThreshListLen

8.168.2.2 int16_t* nas_GSMRSSIThresh::pGSMRSSIThreshList

8.169 nas_GSMSrvStatusInfo Struct Reference

Data Fields

- uint8_t srvStatus
- uint8_t trueSrvStatus
- uint8_t isPrefDataPath

8.169.1 Detailed Description

Structure for storing the service status information for GSM, WCDMA and LTE networks.

Parameters

srvStatus	• Service status of the system. – 0x00 - No service – 0x01 - Limited service – 0x02 - Service – 0x03 - Limited regional service – 0x04 - Power save – 0xFF - Not Available
trueSrvStatus	• True service status of the system. • Not applicable to CDMA/HDR. – 0x00 - No service – 0x01 - Limited service – 0x02 - Service – 0x03 - Limited regional service – 0x04 - Power save – 0xFF - Not Available

isPrefDataPath	• Whether the RAT is the preferred data path. – 0x00 - Not preferred – 0x01 - Preferred – 0xFF - Not Available

8.169.2 Field Documentation

8.169.2.1 uint8_t nas_GSMSrvStatusInfo::isPrefDataPath

8.169.2.2 uint8_t nas_GSMSrvStatusInfo::srvStatus

8.169.2.3 uint8_t nas_GSMSrvStatusInfo::trueSrvStatus

8.170 nas_GSMSysInfo Struct Reference

Data Fields

- nas_sysInfoCommon sysInfoGSM
- uint8_t lacValid
- uint16_t lac
- uint8_t cellIdValid
- uint32_t cellId
- uint8_t regRejectInfoValid
- uint8_t rejectSrvDomain
- uint8_t rejCause
- uint8_t networkIdValid
- uint8_t MCC [3]
- uint8_t MNC [3]
- uint8_t egprsSuppValid
- uint8_t egprsSupp
- uint8_t dtmSuppValid
- uint8_t dtmSupp

8.170.1 Detailed Description

Structure for storing the GSM System Information.

Parameters

sysInfoGSM	• See nas_sysInfoCommon for more information.
lacValid	• Indicates whether the location area code is valid.. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available

lac	• Location area code. • Only applies to 3GPP. – 0xFFFF - Not Available
cellIdValid	• Indicates whether the cell ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
cellId	• Cell ID. – 0xFFFFFFFF - Not Available
regRejectInfo-Valid	• Indicates whether the registration reject information is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
rejectSrvDomain	• Type of service domain in which the registration is rejected. – 0x00 - SYS_SRV_DOMAIN_NO_SRV - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - Camped – 0xFF - Not Available
rejCause	• Reject cause values sent are specified in [3GPP TS 24.008, Section 10.5.3.6 and 10.5.5.14] – 0xFF - Not Available
networkIdValid	• Indicates whether the network ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
MCC[NAS_PLM-N_LENGTH]	• Mobile Country Code. • MCC digits in ASCII characters
MNC[NAS_PLM-N_LENGTH]	• Mobile Network Code. • MNC digits in ASCII characters • An unused byte is set to 0xFF. • In case of two-digit MNC values, the third (unused) digit is set to 0xFF. For example, 15 (a two-digit MNC) is reported using the byte stream 0x31 0x35 0xFF.

egprsSuppValid	• Indicates whether the EGPRS support is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
egprsSupp	• EGPRS support indication. • Only applicable for GSM. – 0x00 - Not available – 0x01 - Available – 0xFF - Not Available
dtmSuppValid	• Indicates whether Dual Transfer mode support is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
dtmSupp	• Dual Transfer mode support indication. • Only applicable for GSM. – 0x00 - Not available – 0x01 - Available – 0xFF - Not Available

8.170.2 Field Documentation

8.170.2.1 uint32_t nas_GSMSysInfo::cellId

8.170.2.2 uint8_t nas_GSMSysInfo::cellIdValid

8.170.2.3 uint8_t nas_GSMSysInfo::dtmSupp

8.170.2.4 uint8_t nas_GSMSysInfo::dtmSuppValid

8.170.2.5 uint8_t nas_GSMSysInfo::egprsSupp

8.170.2.6 uint8_t nas_GSMSysInfo::egprsSuppValid

8.170.2.7 uint16_t nas_GSMSysInfo::lac

8.170.2.8 uint8_t nas_GSMSysInfo::lacValid

8.170.2.9 uint8_t nas_GSMSysInfo::MCC[3]

8.170.2.10 uint8_t nas_GSMSysInfo::MNC[3]

8.170.2.11 uint8_t nas_GSMSysInfo::networkIdValid

8.170.2.12 uint8_t nas_GSMSysInfo::regRejectInfoValid

8.170.2.13 uint8_t nas_GSMSysInfo::rejCause

8.170.2.14 uint8_t nas_GSMSysInfo::rejectSrvDomain

8.170.2.15 nas_sysInfoCommon nas_GSMSysInfo::sysInfoGSM

8.171 nas_GWAcqOrderPrefTlv Struct Reference

Data Fields

- uint32_t GWAcqOrderPref
- uint8_t TlvPresent

8.171.1 Detailed Description

Contain the GSM/WCDMA Acquisition order preference for system selection preferences.

Parameters

GWAcqOrder-Pref	• Parameter indicating GSM/WCDMA Acquisition order Preference • Values: – 0x00 - Automatic – 0x01 - GSM then WCDMA – 0x02 - WCDMA then GSM
TlvPresent	• Tlv Present

8.171.2 Field Documentation

8.171.2.1 uint32_t nas_GWAcqOrderPrefTlv::GWAcqOrderPref

8.171.2.2 uint8_t nas_GWAcqOrderPrefTlv::TlvPresent

8.172 nas_HDRECIOThresh Struct Reference

Data Fields

- uint8_t HDRECIOThreshListLen
- int16_t * pHDRECIOThreshList

8.172.1 Detailed Description

This structure contains HDR ECIO threshold related parameters.

Parameters

HDRECIO-ThreshListLen	• Length of the HDR ECIO threshold list parameter to follow

pHDRECIO-ThreshList	• Array of ECIO thresholds (in units of 0.1 dB) • Maximum of 32 values • Range for ECIO values: -31.5 to 0 (in dB).

8.172.2 Field Documentation

8.172.2.1 uint8_t nas_HDRECIOThresh::HDRECIOThreshListLen

8.172.2.2 int16_t* nas_HDRECIOThresh::pHDRECIOThreshList

8.173 nas_HDRIOThresh Struct Reference

Data Fields

- uint8_t HDRIOThreshListLen
- int16_t * pHDRIOThreshList

8.173.1 Detailed Description

This structure contains HDR IO threshold related parameters.

Parameters

HDRIOThresh-ListLen	• Length of the HDR IO threshold list parameter to follow
pHDRIOThresh-List	• Array of IO thresholds (in units of 0.1 dBm) • Maximum of 32 values • Range for IO values: -128 to -13 (in dBm).

8.173.2 Field Documentation

8.173.2.1 uint8_t nas_HDRIOThresh::HDRIOThreshListLen

8.173.2.2 int16_t* nas_HDRIOThresh::pHDRIOThreshList

8.174 nas_HDRPersonality_Ind_Data Struct Reference

Data Fields

- uint16_t * pCurrentPersonality
- uint8_t * pPersonalityListLength
- nas_protocolSubtypeElement * pProtocolSubtypeElement

8.174.1 Detailed Description

Elements for HDR Personality indication.

Parameters

pCurrent-Personality	• Current active personality index. • Bit to check in ParamPresenceMask - **16**
pPersonalityList-Length	• Number of Personality Protocol Subtype contains in this response. • Bit to check in ParamPresenceMask - **17**
pProtocol-SubtypeElement	• See nas_protocolSubtypeElement for more information. • Bit to check in ParamPresenceMask - **17**

8.174.2 Field Documentation

8.174.2.1 uint16_t* nas_HDRPersonality_Ind_Data::pCurrentPersonality

8.174.2.2 uint8_t* nas_HDRPersonality_Ind_Data::pPersonalityListLength

8.174.2.3 nas_protocolSubtypeElement* nas_HDRPersonality_Ind_Data::pProtocolSubtypeElement

8.175 nas_HDRRSSIThresh Struct Reference

Data Fields

- uint8_t HDRRSSIThreshListLen
- int16_t * pHDRRSSIThreshList

8.175.1 Detailed Description

This structure contains HDR RSSI threshold related parameters.

Parameters

HDRRSSI-ThreshListLen	• Length of the HDR RSSI threshold list parameter to follow
pHDRRSSI-ThreshList	• Array of RSSI thresholds (in units of 0.1 dBm) • Maximum of 32 values. • Range for RSSI values: -118 to -13 (in dBm).

8.175.2 Field Documentation

8.175.2.1 uint8_t nas_HDRRSSIThresh::HDRRSSIThreshListLen

8.175.2.2 int16_t* nas_HDRRSSIThresh::pHDRRSSIThreshList

8.176 nas_HDRSINRThresh Struct Reference

Data Fields

- uint8_t HDRSINRThresListLen
- uint8_t * pHDRSINRThresList

8.176.1 Detailed Description

This structure contains HDR SINR threshold list.

Parameters

HDRSINRThres-ListLen	• Length of the HDR SINR threshold list parameter to follow
pHDRSINR-ThresList	• Sequence of thresholds delimiting SINR event reporting bands • Every time a new SINR value crosses a threshold value, an event report indication message with the new SINR value is sent to the requesting control point. For this field – SINR is reported only for HDR – Each SINR threshold value is an unsigned 1 byte value – Maximum number of threshold values is 16 – At least one value must be specified

8.176.2 Field Documentation

8.176.2.1 uint8_t nas_HDRSINRThresh::HDRSINRThresListLen

8.176.2.2 uint8_t* nas_HDRSINRThresh::pHDRSINRThresList

8.177 nas_HDRSINRThreshold Struct Reference

Data Fields

- uint8_t HDRSINRThreshListLen
- uint16_t * pHDRSINRThreshList

8.177.1 Detailed Description

This structure contains HDR SINR threshold related parameters.

Parameters

HDRSINR-ThreshListLen	• Length of the HDR ECIO threshold list parameter to follow

pHDRSINR-ThreshList	• Array of SINR level thresholds (in units of 1) • maximum of 32 values. • Valid levels are 0 to 8 – 0x00 - SINR_LEVEL_0 is -9 dB – 0x01 - SINR_LEVEL_1 is -6 dB – 0x02 - SINR_LEVEL_2 is -4.5 dB – 0x03 - SINR_LEVEL_3 is -3 dB – 0x04 - SINR_LEVEL_4 is -2 dB – 0x05 - SINR_LEVEL_5 is +1 dB – 0x06 - SINR_LEVEL_6 is +3 dB – 0x07 - SINR_LEVEL_7 is +6 dB – 0x08 - SINR_LEVEL_8 is +9 dB

8.177.2 Field Documentation

8.177.2.1 uint8_t nas_HDRSINRThreshold::HDRSINRThreshListLen

8.177.2.2 uint16_t* nas_HDRSINRThreshold::pHDRSINRThreshList

8.178 nas_HDRSysInfo Struct Reference

Data Fields

- nas_sysInfoCommon sysInfoHDR
- uint8_t isSysPrlMatchValid
- uint8_t isSysPrlMatch
- uint8_t hdrPersonalityValid
- uint8_t hdrPersonality
- uint8_t hdrActiveProtValid
- uint8_t hdrActiveProt
- uint8_t is856SysIdValid
- uint8_t is856SysId [16]

8.178.1 Detailed Description

Structure for storing the HDR System Information.

Parameters

sysInfoHDR	• See nas_sysInfoCommon for more information.
isSysPrlMatch-Valid	• Indicates whether the system PRL match is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available

isSysPrlMatch	• Indicates whether the system is in a PRL. • Only applies to CDMA/HDR. – 0x00 - System is not in a PRL – 0x01 - System is in a PRL – 0xFF - Not Available • If the system is not in a PRL, roam_status carries the value from the default roaming indicator in the PRL. • If the system is in a PRL, roam_status is set to the value based on the standard specification.
hdrPersonality-Valid	• Indicates whether the HDR personality is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
hdrPersonality	• HDR personality information. • Only applicable for HDR. – 0x00 - None – 0x02 - HRPD – 0x03 - eHRPD – 0xFF - Not Available
hdrActiveProt-Valid	• Indicates whether the HDR active protocol revision information is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
hdrActiveProt	• HDR active protocol revision information . • Only applicable for HDR. – 0x00 - None – 0x02 - HDR Rel 0 – 0x03 - HDR Rel A – 0x04 - HDR Rel B – 0xFF - Not Available
is856SysIdValid	• Indicates whether the IS-856 system ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
is856SysId[SLQ-S_SYSTEM_ID-_SIZE]	• IS-856 system ID. • Only applicable for HDR.

8.178.2 Field Documentation

8.178.2.1 uint8_t nas_HDRSysInfo::hdrActiveProt

8.178.2.2 uint8_t nas_HDRSysInfo::hdrActiveProtValid

8.178.2.3 uint8_t nas_HDRSysInfo::hdrPersonality

8.178.2.4 uint8_t nas_HDRSysInfo::hdrPersonalityValid

8.178.2.5 uint8_t nas_HDRSysInfo::is856SysId[16]

8.178.2.6 uint8_t nas_HDRSysInfo::is856SysIdValid

8.178.2.7 uint8_t nas_HDRSysInfo::isSysPrlMatch

8.178.2.8 uint8_t nas_HDRSysInfo::isSysPrlMatchValid

8.178.2.9 nas_sysInfoCommon nas_HDRSysInfo::sysInfoHDR

8.179 nas_homeSIDNID Struct Reference

Data Fields

- uint8_t numInstances
- nas_sidNid SidNid [255]

8.179.1 Detailed Description

This structure contains Home SID/NID

Parameters

numInstances	• Number of sets of the following elements: – sid – nid • If zero(0), then no information follows.
SidNid	• See nas_sidNid for more information

8.179.2 Field Documentation

8.179.2.1 uint8_t nas_homeSIDNID::numInstances

8.179.2.2 nas_sidNid nas_homeSIDNID::SidNid[255]

8.180 nas_infoInterFreq Struct Reference

Data Fields

- uint16_t earfcn
- uint8_t threshXLow
- uint8_t threshXHigh
- uint8_t cell_resel_priority
- uint8_t cells_len
- nas_cellParams cellInterFreqParams [255]

8.180.1 Detailed Description

This structure contains information about the inter-frequency.

Parameters

earfcn	• E-UTRA absolute radio frequency channel number of the serving cell. • Range: 0 to 65535.
threshXLow	• Cell Srxlev low threshold. • Range: 0 to 31. • When the serving cell does not exceed thresh_serving_low, the value of an evaluated cell must be smaller than this value to be considered for re-selection.
threshXHigh	• Cell Srxlev high threshold. • Range: 0 to 31. • When the serving cell exceeds thresh_serving_low, the value of an evaluated cell must be greater than this value to be considered for re-selection.
cell_resel_priority	• Cell re-selection priority • Range: 0 to 7. • This field is only valid when ue_in_idle is TRUE.
cells_len	• Provides the number of set of cell params.
cellInterFreqParams[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_cellParams for more information.

8.180.2 Field Documentation

8.180.2.1 uint8_t nas_infoInterFreq::cell_resel_priority

8.180.2.2 nas_cellParams nas_infoInterFreq::cellInterFreqParams[255]

8.180.2.3 uint8_t nas_infoInterFreq::cells_len

8.180.2.4 uint16_t nas_infoInterFreq::earfcn

8.180.2.5 uint8_t nas_infoInterFreq::threshXHigh

8.180.2.6 uint8_t nas_infoInterFreq::threshXLow

8.181 nas_IOThresh Struct Reference

Data Fields

- uint8_t IOThresListLen
- int32_t * pIOThresList

8.181.1 Detailed Description

This structure contains IO threshold list.

Parameters

IOThresListLen	• Length of the IO threshold list parameter to follow
pIOThresList	• Sequence of thresholds delimiting IO event reporting bands • Every time a new IO value crosses a threshold value, an event report indication message with the new IO value is sent to the requesting control point. For this field – IO is applicable only for HDR – Each IO threshold value is a signed 4 byte value – Maximum number of threshold values is 16 – At least one value must be specified

8.181.2 Field Documentation

8.181.2.1 uint8_t nas_IOThresh::IOThresListLen

8.181.2.2 int32_t* nas_IOThresh::pIOThresList

8.182 nas_lteBandPrefExt Struct Reference

Data Fields

- uint64_t bits_1_64
- uint64_t bits_65_128
- uint64_t bits_129_192
- uint64_t bits_193_256

8.182.1 Detailed Description

Contain the LTE Band Preference Extended parameters

Parameters

bits_1_64	• Bits 1 to 64 of the 256-bit LTE E-UTRA Operating Band bitmask.
bits_65_128	• Bits 65 to 128 of the 256-bit LTE E-UTRA Operating Band bitmask.
bits_129_192	• Bits 129 to 192 of the 256-bit LTE E-UTRA Operating Band bitmask.
bits_193_256	• Bits 193 to 256 of the 256-bit LTE E-UTRA Operating Band bitmask.

8.182.2 Field Documentation

8.182.2.1 uint64_t nas_lteBandPrefExt::bits_129_192

8.182.2.2 uint64_t nas_lteBandPrefExt::bits_193_256

8.182.2.3 uint64_t nas_lteBandPrefExt::bits_1_64

8.182.2.4 uint64_t nas_lteBandPrefExt::bits_65_128

8.183 nas_LTEBandPrefTlv Struct Reference

Data Fields

- uint64_t LTEBandPref
- uint8_t TlvPresent

8.183.1 Detailed Description

Contain the LTE Band Preference for system selection preferences.

Parameters

LTEBandPref	• Bit mask representing the LTE band preference • Bit Values – Bit 0 - E-UTRA Operating Band 1 – Bit 1 - E-UTRA Operating Band 2 – Bit 2 - E-UTRA Operating Band 3 – Bit 3 - E-UTRA Operating Band 4 – Bit 4 - E-UTRA Operating Band 5 – Bit 5 - E-UTRA Operating Band 6 – Bit 6 - E-UTRA Operating Band 7 – Bit 7 - E-UTRA Operating Band 8 – Bit 8 - E-UTRA Operating Band 9 – Bit 9 - E-UTRA Operating Band 10 – Bit 10 - E-UTRA Operating Band 11 – Bit 11 - E-UTRA Operating Band 12 – Bit 12 - E-UTRA Operating Band 13 – Bit 13 - E-UTRA Operating Band 14 – Bit 16 - E-UTRA Operating Band 17 – Bit 17 - E-UTRA Operating Band 18 – Bit 18 - E-UTRA Operating Band 19 – Bit 19 - E-UTRA Operating Band 20 – Bit 20 - E-UTRA Operating Band 21 – Bit 22 - E-UTRA Operating Band 23 – Bit 23 - E-UTRA Operating Band 24 – Bit 24 - E-UTRA Operating Band 25 – Bit 25 - E-UTRA Operating Band 26 – Bit 27 - E-UTRA Operating Band 28 – Bit 28 - E-UTRA Operating Band 29 – Bit 29 - E-UTRA Operating Band 32 – Bit 32 - E-UTRA Operating Band 33 – Bit 33 - E-UTRA Operating Band 34 – Bit 34 - E-UTRA Operating Band 35 – Bit 35 - E-UTRA Operating Band 36 – Bit 36 - E-UTRA Operating Band 37 – Bit 37 - E-UTRA Operating Band 38 – Bit 38 - E-UTRA Operating Band 39 – Bit 39 - E-UTRA Operating Band 40 – Bit 40 - E-UTRA Operating Band 41 – Bit 41 - E-UTRA Operating Band 42 – Bit 42 - E-UTRA Operating Band 43 – Bit 60 - E-UTRA Operating Band 125 – All other bits are reserved
TlvPresent	• Tlv Present

8.183.2 Field Documentation

8.183.2.1 uint64_t nas_LTEBandPrefTlv::LTEBandPref

8.183.2.2 uint8_t nas_LTEBandPrefTlv::TlvPresent

8.184 nas_lteEARFCN Struct Reference

Data Fields

- uint8_t status
- uint32_t earfcn0
- uint32_t earfcn1

8.184.1 Detailed Description

This structure contains LTE EARFCN infromation.

Parameters

status	• 0 - Disable • 1 - Enable
earfcn0	• Primary DL EARFCN to which the UE is locked
earfcn1	• Secondary DL EARFCN to which the UE is locked • Note : Make earfcn1 value equal to earfcn0 if only one EARFCN is desired.

8.184.2 Field Documentation

8.184.2.1 uint32_t nas_lteEARFCN::earfcn0

8.184.2.2 uint32_t nas_lteEARFCN::earfcn1

8.184.2.3 uint8_t nas_lteEARFCN::status

8.185 nas_lteGsmCellInfo Struct Reference

Data Fields

- uint8_t cellReselPriority
- uint8_t threshGsmHigh
- uint8_t threshGsmLow
- uint8_t nccPermitted
- uint8_t cells_len
- nas_gsmCellInfo GsmCellInfo [255]

8.185.1 Detailed Description

This structure contains information about the LTE GSM Cell.

Parameters

cellReselPriority	• Priority of this frequency group. • Range: 0 to 7. • This field is only valid when ue_in_idle is TRUE.
threshGsmHigh	• Reselection threshold for high priority layers. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE.
threshGsmLow	• Reselection threshold for low priority layers. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE.
nccPermitted	• Bitmask specifying whether a neighbor with a specific network color code is to be reported. • Range: 0 to 255. • Bit n set to 1 means a neighbor with NCC n must be included in the report. This flag is synonymous with a blacklist in other RATs. • This field is only valid when ue_in_idle is TRUE.
cells_len	• Provides the number of set of gsm cells.
GsmCellInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_gsmCellInfo for more information.

8.185.2 Field Documentation

8.185.2.1 uint8_t nas_lteGsmCellInfo::cellReselPriority

8.185.2.2 uint8_t nas_lteGsmCellInfo::cells_len

8.185.2.3 nas_gsmCellInfo nas_lteGsmCellInfo::GsmCellInfo[255]

8.185.2.4 uint8_t nas_lteGsmCellInfo::nccPermitted

8.185.2.5 uint8_t nas_lteGsmCellInfo::threshGsmHigh

8.185.2.6 uint8_t nas_lteGsmCellInfo::threshGsmLow

8.186 nas_LTEInfo Struct Reference

Data Fields

- uint8_t band
- uint8_t bandwidth
- uint16_t RXChan
- uint16_t TXChan

- uint8_t emmState
- uint8_t emmSubState
- uint8_t emmConnState

8.186.1 Detailed Description

Structure for storing the LTE information for the device.

Parameters

band	• LTE Band – 1 ∼ 40 (Band in decimal) – 0xFF - Invalid
bandwidth	• BandWidth. – 0x00 - 1.4 MHz – 0x01 - 3 MHz – 0x02 - 5 MHz – 0x03 - 10 MHz – 0x04 - 15 MHz – 0x05 - 20 MHz – 0x06 - Invalid – 0xFF - Unknown
RXChan	• RX channel number in decimal – 0xFFFF - Not Available
TXChan	• TX channel number in decimal – 0xFFFF - Not Available
emmState	• EMM State. – 0x00 - Deregistered – 0x01 - Reg Initiated – 0x02 - Registered – 0x03 - TAU Initiated – 0x04 - SR Initiated – 0x05 - Dereg Initiated – 0x06 - Invalid – 0xFF - Unknown

emmSubState	• EMM Sub State. – 0xFF - NOT Applicable • When EMM_state is 0x00: – 0x00 - No IMSI – 0x01 - PLMN Search – 0x02 - Attach Needed – 0x03 - No Cell – 0x04 - Attaching – 0x05 - Normal Service – 0x06 - Limited Service – 0x07 - Waiting for PDN • When EMM_state is 0x01: – 0x00 - Waiting for NW – 0x01 - Waiting for ESM • When EMM_state is 0x02: – 0x00 - Normal Service – 0x01 - Update Needed – 0x02 - Attempt Update – 0x03 - No Cell – 0x04 - PLMN Search – 0x05 - Limited Service – 0x06 - MM Update – 0x07 - IMSI Detach – 0x08 - Waiting for ESM
emmConnState	• EMM Connected Mode State. – 0x00 - RRC Idle – 0x01 - Waiting RRC Cfm – 0x02 - RRC Connected – 0x03 - RRC Releasing – 0xFF - Unknown

8.186.2 Field Documentation

8.186.2.1 uint8_t nas_LTEInfo::band

8.186.2.2 uint8_t nas_LTEInfo::bandwidth

8.186.2.3 uint8_t nas_LTEInfo::emmConnState

8.186.2.4 uint8_t nas_LTEInfo::emmState

8.186.2.5 uint8_t nas_LTEInfo::emmSubState

8.186.2.6 uint16_t nas_LTEInfo::RXChan

8.186.2.7 uint16_t nas_LTEInfo::TXChan

8.187 nas_LTEInfoInterfreq Struct Reference

Data Fields

- uint8_t ueInIdle
- uint8_t freqsLen
- nas_infoInterFreq InfoInterfreq [255]

8.187.1 Detailed Description

This structure contains information about the LTE Inter-Frequency Network.

Parameters

ueInIdle	• TRUE if the UE is in Idle mode, otherwise FALSE. – 0xFF - Not Available
freqsLen	• Provides the number of set of inter frequency information. • If 0(zero), then no information follows it.
InfoInterfreq[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_infoInterFreq for more information.

8.187.2 Field Documentation

8.187.2.1 uint8_t nas_LTEInfoInterfreq::freqsLen

8.187.2.2 nas_infoInterFreq nas_LTEInfoInterfreq::InfoInterfreq[255]

8.187.2.3 uint8_t nas_LTEInfoInterfreq::ueInIdle

8.188 nas_LTEInfoIntrafreq Struct Reference

Data Fields

- uint8_t ueInIdle
- uint8_t plmn [3]
- uint16_t tac
- uint32_t globalCellId
- uint16_t earfcn
- uint16_t servingCellId
- uint8_t cellReselPriority
- uint8_t sNonIntraSearch
- uint8_t threshServingLow
- uint8_t sIntraSearch
- uint8_t cellsLen
- nas_cellParams CellParams [255]

8.188.1 Detailed Description

This structure contains information about the LTE Intra-Frequency Network.

Parameters

ueInIdle	• TRUE if the UE is in Idle mode, otherwise FALSE. – 0xFF - Not Available
plmn[NAS_PLMN_LENGTH]	• PLMN ID coded as octet 3, 4, and 5.
tac	• Tracking area code. – 0xFFFF - Not Available
globalCellId	• Global cell ID in the system information block. – 0xFFFFFFFF - Not Available
earfcn	• E-UTRA absolute radio frequency channel number of the serving cell. • Range: 0 to 65535. – 0xFFFF - Not Available
servingCellId	• LTE serving cell ID. • Range: 0 to 503. • This is the cell ID of the serving cell and can be found in the cell list. – 0xFFFF - Not Available
cellReselPriority	• Priority for serving frequency. • Range: 0 to 7. • This field is only valid when ue_in_idle is TRUE. – 0xFF - Not Available
sNonIntraSearch	• S non-intra search threshold to control non-intrafrequency searches. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE. – 0xFF - Not Available
threshServingLow	• Serving cell low threshold. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE. – 0xFF - Not Available

sIntraSearch	• S Intra search threshold. • Range: 0 to 31. • The current cell measurement must fall below this threshold to consider intrafrequency for reselection. • This field is only valid when ue_in_idle is TRUE. – 0xFF - Not Available
cellsLen	• Provides the number of set of cell params. • If 0(zero), then no information follows it.
CellParams[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_cellParams for more information.

8.188.2 Field Documentation

8.188.2.1 nas_cellParams nas_LTEInfoIntrafreq::CellParams[255]

8.188.2.2 uint8_t nas_LTEInfoIntrafreq::cellReselPriority

8.188.2.3 uint8_t nas_LTEInfoIntrafreq::cellsLen

8.188.2.4 uint16_t nas_LTEInfoIntrafreq::earfcn

8.188.2.5 uint32_t nas_LTEInfoIntrafreq::globalCellId

8.188.2.6 uint8_t nas_LTEInfoIntrafreq::plmn[3]

8.188.2.7 uint16_t nas_LTEInfoIntrafreq::servingCellId

8.188.2.8 uint8_t nas_LTEInfoIntrafreq::sIntraSearch

8.188.2.9 uint8_t nas_LTEInfoIntrafreq::sNonIntraSearch

8.188.2.10 uint16_t nas_LTEInfoIntrafreq::tac

8.188.2.11 uint8_t nas_LTEInfoIntrafreq::threshServingLow

8.188.2.12 uint8_t nas_LTEInfoIntrafreq::ueInIdle

8.189 nas_LTEInfoNeighboringGSM Struct Reference

Data Fields

- uint8_t ueInIdle
- uint8_t freqsLen
- nas_lteGsmCellInfo LteGsmCellInfo [255]

8.189.1 Detailed Description

This structure contains information about the LTE Neighboring GSM Network.

Parameters

ueInIdle	• TRUE if the UE is in Idle mode, otherwise FALSE. – 0xFF - Not Available
freqsLen	• Provides the number of set of LTE GSM cell information. • If 0(zero), then no information follows it.
LteGsmCellInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_lteGsmCellInfo for more information.

8.189.2 Field Documentation

8.189.2.1 uint8_t nas_LTEInfoNeighboringGSM::freqsLen

8.189.2.2 nas_lteGsmCellInfo nas_LTEInfoNeighboringGSM::LteGsmCellInfo[255]

8.189.2.3 uint8_t nas_LTEInfoNeighboringGSM::ueInIdle

8.190 nas_LTEInfoNeighboringWCDMA Struct Reference

Data Fields

- uint8_t ueInIdle
- uint8_t freqsLen
- nas_lteWcdmaCellInfo LTEWCDMACellInfo [255]

8.190.1 Detailed Description

This structure contains information about the LTE Neighboring WCDMA Network.

Parameters

ueInIdle	• TRUE if the UE is in Idle mode, otherwise FALSE. – 0xFF - Not Available
freqsLen	• Provides the number of set of LTE WCDMA cell information. • If 0(zero), then no information follows it.
LTEWCDMACellInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_lteWcdmaCellInfo for more information.

8.190.2 Field Documentation

8.190.2.1 uint8_t nas_LTEInfoNeighboringWCDMA::freqsLen

8.190.2.2 nas_lteWcdmaCellInfo nas_LTEInfoNeighboringWCDMA::LTEWCDMACellInfo[255]

8.190.2.3 uint8_t nas_LTEInfoNeighboringWCDMA::ueInIdle

8.191 nas_LteM1BandPrefTlv Struct Reference

Data Fields

- uint64_t lteM1BandPref
- uint8_t TlvPresent

8.191.1 Detailed Description

Contain the LTE M1 band Preference.

Parameters

lteM1BandPref	• Bitmask representing the LTE M1 band preference • Bit Values – Bit 0 - E-UTRA Operating Band 1 – Bit 1 - E-UTRA Operating Band 2 – Bit 2 - E-UTRA Operating Band 3 – Bit 3 - E-UTRA Operating Band 4 – Bit 4 - E-UTRA Operating Band 5 – Bit 5 - E-UTRA Operating Band 6 – Bit 6 - E-UTRA Operating Band 7 – Bit 7 - E-UTRA Operating Band 8 – Bit 8 - E-UTRA Operating Band 9 – Bit 9 - E-UTRA Operating Band 10 – Bit 10 - E-UTRA Operating Band 11 – Bit 11 - E-UTRA Operating Band 12 – Bit 12 - E-UTRA Operating Band 13 – Bit 13 - E-UTRA Operating Band 14 – Bit 16 - E-UTRA Operating Band 17 – Bit 17 - E-UTRA Operating Band 18 – Bit 18 - E-UTRA Operating Band 19 – Bit 19 - E-UTRA Operating Band 20 – Bit 20 - E-UTRA Operating Band 21 – Bit 22 - E-UTRA Operating Band 23 – Bit 23 - E-UTRA Operating Band 24 – Bit 24 - E-UTRA Operating Band 25 – Bit 25 - E-UTRA Operating Band 26 – Bit 27 - E-UTRA Operating Band 28 – Bit 28 - E-UTRA Operating Band 29 – Bit 29 - E-UTRA Operating Band 32 – Bit 32 - E-UTRA Operating Band 33 – Bit 33 - E-UTRA Operating Band 34 – Bit 34 - E-UTRA Operating Band 35 – Bit 35 - E-UTRA Operating Band 36 – Bit 36 - E-UTRA Operating Band 37 – Bit 37 - E-UTRA Operating Band 38 – Bit 38 - E-UTRA Operating Band 39 – Bit 39 - E-UTRA Operating Band 40 – Bit 40 - E-UTRA Operating Band 41 – Bit 41 - E-UTRA Operating Band 42 – Bit 42 - E-UTRA Operating Band 43 – Bit 60 - E-UTRA Operating Band 125 – Bit 61 - E-UTRA Operating Band 126 – Bit 62 - E-UTRA Operating Band 127
TlvPresent	• Tlv Present

8.191.2 Field Documentation

8.191.2.1 uint64_t nas_LteM1BandPrefTlv::lteM1BandPref

8.191.2.2 uint8_t nas_LteM1BandPrefTlv::TlvPresent

8.192 nas_LteNb1BandPrefTlv Struct Reference

Data Fields

- uint64_t lteNb1BandPref
- uint8_t TlvPresent

8.192.1 Detailed Description

Contain the LTE NB1 band Preference.

Parameters

lteNb1BandPref	• Bitmask representing the LTE NB1 band preference. • Bit Values – Bit 0 - E-UTRA Operating Band 1 – Bit 1 - E-UTRA Operating Band 2 – Bit 2 - E-UTRA Operating Band 3 – Bit 3 - E-UTRA Operating Band 4 – Bit 4 - E-UTRA Operating Band 5 – Bit 5 - E-UTRA Operating Band 6 – Bit 6 - E-UTRA Operating Band 7 – Bit 7 - E-UTRA Operating Band 8 – Bit 8 - E-UTRA Operating Band 9 – Bit 9 - E-UTRA Operating Band 10 – Bit 10 - E-UTRA Operating Band 11 – Bit 11 - E-UTRA Operating Band 12 – Bit 12 - E-UTRA Operating Band 13 – Bit 13 - E-UTRA Operating Band 14 – Bit 16 - E-UTRA Operating Band 17 – Bit 17 - E-UTRA Operating Band 18 – Bit 18 - E-UTRA Operating Band 19 – Bit 19 - E-UTRA Operating Band 20 – Bit 20 - E-UTRA Operating Band 21 – Bit 22 - E-UTRA Operating Band 23 – Bit 23 - E-UTRA Operating Band 24 – Bit 24 - E-UTRA Operating Band 25 – Bit 25 - E-UTRA Operating Band 26 – Bit 27 - E-UTRA Operating Band 28 – Bit 28 - E-UTRA Operating Band 29 – Bit 29 - E-UTRA Operating Band 32 – Bit 32 - E-UTRA Operating Band 33 – Bit 33 - E-UTRA Operating Band 34 – Bit 34 - E-UTRA Operating Band 35 – Bit 35 - E-UTRA Operating Band 36 – Bit 36 - E-UTRA Operating Band 37 – Bit 37 - E-UTRA Operating Band 38 – Bit 38 - E-UTRA Operating Band 39 – Bit 39 - E-UTRA Operating Band 40 – Bit 40 - E-UTRA Operating Band 41 – Bit 41 - E-UTRA Operating Band 42 – Bit 42 - E-UTRA Operating Band 43 – Bit 60 - E-UTRA Operating Band 125 – Bit 61 - E-UTRA Operating Band 126 – Bit 62 - E-UTRA Operating Band 127
TlvPresent	• Tlv Present

8.192.2 Field Documentation

8.192.2.1 uint64_t nas_LteNb1BandPrefTlv::lteNb1BandPref

8.192.2.2 uint8_t nas_LteNb1BandPrefTlv::TlvPresent

8.193 nas_LTEOperationMode Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t * pLTEOperationMode

8.193.1 Detailed Description

This structure contains the nas_LTEOperationMode response parameters.

Parameters

TlvPresent	• Tlv Present
pLTEOperation-Mode	• LTE Operational Mode

8.193.2 Field Documentation

8.193.2.1 uint32_t* nas_LTEOperationMode::pLTEOperationMode

8.193.2.2 uint8_t nas_LTEOperationMode::TlvPresent

8.194 nas_LteOpMode Struct Reference

Data Fields

- uint32_t lteOpMode
- uint8_t TlvPresent

8.194.1 Detailed Description

This structure contains LTE Operational Mode

Parameters

lteOpMode	• LTE Operational Mode • CIOT LTE mode on which reject indication is received. • Values – NAS_CIOT_SYS_MODE_NO_SRV (0x00) - No service – NAS_CIOT_SYS_MODE_LTE_WB (0x01) - Camped on LTE wideband – NAS_CIOT_SYS_MODE_LTE_M1 (0x02) - Camped on LTE M1 – NAS_CIOT_SYS_MODE_LTE_NB1 (0x03) - Camped on LTE NB1

TlvPresent	• Tlv Present or not

8.194.2 Field Documentation

8.194.2.1 uint32_t nas_LteOpMode::lteOpMode

8.194.2.2 uint8_t nas_LteOpMode::TlvPresent

8.195 nas_ltePCI Struct Reference

Data Fields

- uint8_t status
- uint32_t earfcn
- uint32_t pci

8.195.1 Detailed Description

This structure contains LTE PCI infromation.

Parameters

status	• 0 - Disable • 1 - Enable
earfcn	• UARFCN to which UE is locked
pci	• PCI to which the UE is locked

8.195.2 Field Documentation

8.195.2.1 uint32_t nas_ltePCI::earfcn

8.195.2.2 uint32_t nas_ltePCI::pci

8.195.2.3 uint8_t nas_ltePCI::status

8.196 nas_lteRsrpinformation Struct Reference

Data Fields

- int16_t rsrplevel

8.196.1 Detailed Description

This structure contains the LTE RSRP Information

Parameters

rsrplevel	• LTE RSRP in dBm as a mesaured by L1. Range: -44 to -140(-44 means -44dBm, -140 means -140dBm).

8.196.2 Field Documentation

8.196.2.1 int16_t nas_lteRsrpinformation::rsrplevel

8.197 nas_LTERSRPThresh Struct Reference

Data Fields

- uint8_t LTERSRPThreshListLen
- int16_t * pLTERSRPThreshList

8.197.1 Detailed Description

This structure contains LTE RSRP threshold related parameters.

Parameters

LTERSRP-ThreshListLen	• Length of the LTE RSRP threshold list parameter to follow
pLTERSRP-ThreshList	• Array of RSRP thresholds (in units of 0.1 dBm) • Maximum of 32 values • Range for RSRP values: -140 to -44 (in dBm).

8.197.2 Field Documentation

8.197.2.1 uint8_t nas_LTERSRPThresh::LTERSRPThreshListLen

8.197.2.2 int16_t* nas_LTERSRPThresh::pLTERSRPThreshList

8.198 nas_LTERSRQThresh Struct Reference

Data Fields

- uint8_t LTERSRQThreshListLen
- int16_t * pLTERSRQThreshList

8.198.1 Detailed Description

This structure contains LTE RSRQ threshold related parameters.

Parameters

LTERSRQ-ThreshListLen	• Length of the LTE RSRQ threshold list parameter to follow
pLTERSRQ-ThreshList	• Array of RSRQ thresholds (in units of 0.1 dBm) • Maximum of 32 values. • Range for RSRQ values: -20 to -3 (in dBm)

8.198.2 Field Documentation

8.198.2.1 uint8_t nas_LTERSRQThresh::LTERSRQThreshListLen

8.198.2.2 int16_t* nas_LTERSRQThresh::pLTERSRQThreshList

8.199 nas_LTERSSIThresh Struct Reference

Data Fields

- uint8_t LTERSSIThreshListLen
- int16_t * pLTERSSIThreshList

8.199.1 Detailed Description

This structure contains LTE RSSI threshold related parameters.

Parameters

LTERSSI-ThreshListLen	• Length of the LTE RSSI threshold list parameter to follow
pLTERSSI-ThreshList	• Array of RSSI thresholds (in units of 0.1 dBm) • Maximum of 32 values. • Range for RSSI values: -120 to 0 (in dBm)

8.199.2 Field Documentation

8.199.2.1 uint8_t nas_LTERSSIThresh::LTERSSIThreshListLen

8.199.2.2 int16_t* nas_LTERSSIThresh::pLTERSSIThreshList

8.200 nas_LTESigRptCfg Struct Reference

Data Fields

- uint8_t rptRate
- uint8_t avgPeriod

8.200.1 Detailed Description

This structure contains LTE signal report config.

Parameters

rptRate	• Rate on how often the LTE signal must be checked for reporting • Values: – 0 - Report using the default configuration – 1 - Report every 1 sec – 2 - Report every 2 sec – 3 - Report every 3 sec – 4 - Report every 4 sec – 5 - Report every 5 sec
avgPeriod	• Averaging period to be used for the LTE signal • Values: – 0 - Average using the default configuration – 1 - Average over 1 sec – 2 - Average over 2 sec – 3 - Average over 3 sec – 4 - Average over 4 sec – 5 - Average over 5 sec – 6 - Average over 6 sec – 7 - Average over 7 sec – 8 - Average over 8 sec – 9 - Average over 9 sec – 10 - Average over 10 sec

8.200.2 Field Documentation

8.200.2.1 uint8_t nas_LTESigRptCfg::avgPeriod

8.200.2.2 uint8_t nas_LTESigRptCfg::rptRate

8.201 nas_LTESigRptConfig Struct Reference

Data Fields

- uint8_t rptRate
- uint8_t avgPeriod

8.201.1 Detailed Description

This structure contains LTE RSRP threshold related parameters.

Parameters

rptRate	• Rate on how often the LTE signal must be checked for reporting Values • 0 - Report using the default configuration • 1 - Report every 1 sec • 2 - Report every 2 sec • 3 - Report every 3 sec • 4 - Report every 4 sec • 5 - Report every 5 sec
avgPeriod	• Averaging period to be used for the LTE signal. • Values – 0 - Average using the default configuration – 1 - Average over 1 sec – 2 - Average over 2 sec – 3 - Average over 3 sec – 4 - Average over 4 sec – 5 - Average over 5 sec – 6 - Average over 6 sec – 7 - Average over 7 sec – 8 - Average over 8 sec – 9 - Average over 9 sec – 10 - Average over 10 sec

8.201.2 Field Documentation

8.201.2.1 uint8_t nas_LTESigRptConfig::avgPeriod

8.201.2.2 uint8_t nas_LTESigRptConfig::rptRate

8.202 nas_lteSnrinformation Struct Reference

Data Fields

- int16_t snrlevel

8.202.1 Detailed Description

This structure contains the LTE SNR Information

Parameters

snrlevel	• LTE SNR level as a scaled integer in units of 0.1dB e.g. -16dB has a value of -160 and 24.6dB has value of 246.

8.202.2 Field Documentation

8.202.2.1 int16_t nas_lteSnrinformation::snrlevel

8.203 nas_LTESNRThresh Struct Reference

Data Fields

- uint8_t LTESNRThresListLen
- int16_t * pLTESNRThresList

8.203.1 Detailed Description

This structure contains LTE SNR threshold list.

Parameters

LTESNRThres-ListLen	• Length of the LTE SNR threshold list parameter to follow
pLTESNRThres-List	• Sequence of thresholds delimiting SNR event reporting bands • Every time a SNR value crosses a threshold value, an event report indication message with the new SNR value is sent to the requesting control point. For this field – For LTE, each SNR threshold value is a signed 2 Byte value – Maximum number of threshold values is 16 – At least one value must be specified – SNR level as a scaled integer in units of 0.1 dB; e.g., -16 dB has a value of -160 and 24.6 dB has a value of 246

8.203.2 Field Documentation

8.203.2.1 uint8_t nas_LTESNRThresh::LTESNRThresListLen

8.203.2.2 int16_t* nas_LTESNRThresh::pLTESNRThresList

8.204 nas_LTESNRThreshold Struct Reference

Data Fields

- uint8_t LTESNRThreshListLen
- int16_t * pLTESNRThreshList

8.204.1 Detailed Description

This structure contains LTE SNR threshold related parameters.

Parameters

LTESNRThresh-ListLen	• Length of the LTE SNR threshold list parameter to follow

pLTESNR-ThreshList	• Array of SNR thresholds (in units of 0.1 dB) • Maximum of 32 values • Range for SNR values: -20 to 30 (in dB).

8.204.2 Field Documentation

8.204.2.1 uint8_t nas_LTESNRThreshold::LTESNRThreshListLen

8.204.2.2 int16_t* nas_LTESNRThreshold::pLTESNRThreshList

8.205 nas_LTESysInfo Struct Reference

Data Fields

- nas_sysInfoCommon sysInfoLTE
- uint8_t lacValid
- uint16_t lac
- uint8_t cellIdValid
- uint32_t cellId
- uint8_t regRejectInfoValid
- uint8_t rejectSrvDomain
- uint8_t rejCause
- uint8_t networkIdValid
- uint8_t MCC [3]
- uint8_t MNC [3]
- uint8_t tacValid
- uint16_t tac

8.205.1 Detailed Description

Structure for storing the LTE System Information.

Parameters

sysInfoLTE	• See nas_sysInfoCommon for more information.
lacValid	• Indicates whether the location area code is valid.. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
lac	• Location area code. • Only applies to 3GPP. – 0xFFFF - Not Available

cellIdValid	• Indicates whether the cell ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
cellId	• Cell ID. – 0xFFFFFFFF - Not Available
regRejectInfo-Valid	• Indicates whether the registration reject information is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
rejectSrvDomain	• Type of service domain in which the registration is rejected. – 0x00 - SYS_SRV_DOMAIN_NO_SRV - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - Camped – 0xFF - Not Available
rejCause	• Reject cause values sent are specified in [3GPP TS 24.008, Section 10.5.3.6]. and [3GPP TS 24.301, Section 9.9.3.9] – 0xFF - Not Available
networkIdValid	• Indicates whether the network ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
MCC[NAS_PLM-N_LENGTH]	• Mobile Country Code. • MCC digits in ASCII characters
MNC[NAS_PLM-N_LENGTH]	• Mobile Network Code. • MNC digits in ASCII characters • An unused byte is set to 0xFF. • In case of two-digit MNC values, the third (unused) digit is set to 0xFF. For example, 15 (a two-digit MNC) is reported using the byte stream 0x31 0x35 0xFF.

tacValid	• Indicates whether tracking area code is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
tac	• Tracking area code. • Only applicable for LTE. – 0xFFFF - Not Available

8.205.2 Field Documentation

8.205.2.1 uint32_t nas_LTESysInfo::cellId

8.205.2.2 uint8_t nas_LTESysInfo::cellIdValid

8.205.2.3 uint16_t nas_LTESysInfo::lac

8.205.2.4 uint8_t nas_LTESysInfo::lacValid

8.205.2.5 uint8_t nas_LTESysInfo::MCC[3]

8.205.2.6 uint8_t nas_LTESysInfo::MNC[3]

8.205.2.7 uint8_t nas_LTESysInfo::networkIdValid

8.205.2.8 uint8_t nas_LTESysInfo::regRejectInfoValid

8.205.2.9 uint8_t nas_LTESysInfo::rejCause

8.205.2.10 uint8_t nas_LTESysInfo::rejectSrvDomain

8.205.2.11 nas_sysInfoCommon nas_LTESysInfo::sysInfoLTE

8.205.2.12 uint16_t nas_LTESysInfo::tac

8.205.2.13 uint8_t nas_LTESysInfo::tacValid

8.206 nas_lteWcdmaCellInfo Struct Reference

Data Fields

- uint16_t uarfcn
- uint8_t cellReselPriority
- uint16_t threshXhigh
- uint16_t threshXlow
- uint8_t cellsLen
- nas_wcdmaCellInfo WCDMACellInfo [255]

8.206.1 Detailed Description

This structure contains information about the LTE WCDMA Cell.

Parameters

uarfcn	• WCDMA layer frequency. • Range: 0 to 16383.
cellReselPriority	• Cell re-selection priority. • Range: 0 to 7. • This field is only valid when ue_in_idle is TRUE.
threshXhigh	• Re-selection low threshold. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE.
threshXlow	• Re-selection high threshold. • Range: 0 to 31. • This field is only valid when ue_in_idle is TRUE.
cellsLen	• Provides the number of set of WCDMA cells.
WCDMACellInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_wcdmaCellInfo for more information.

8.206.2 Field Documentation

8.206.2.1 uint8_t nas_lteWcdmaCellInfo::cellReselPriority

8.206.2.2 uint8_t nas_lteWcdmaCellInfo::cellsLen

8.206.2.3 uint16_t nas_lteWcdmaCellInfo::threshXhigh

8.206.2.4 uint16_t nas_lteWcdmaCellInfo::threshXlow

8.206.2.5 uint16_t nas_lteWcdmaCellInfo::uarfcn

8.206.2.6 nas_wcdmaCellInfo nas_lteWcdmaCellInfo::WCDMACellInfo[255]

8.207 nas_minBasedIMSI Struct Reference

Data Fields

- uint8_t mccM [3]
- uint16_t imsiM1112
- uint8_t imsiMS1 [7]

- uint8_t imsiMS2 [3]

8.207.1 Detailed Description

This structure contains MIN-based IMSI.

Parameters

mccM	• ASCII character representation of MCC_M
imsiM1112	• ASCII character representation of IMSI_M_11_12 value – 0xFFFF - Not Available
imsiMS1	• ASCII character representation of IMSI_M_S1 value
imsiMS2	• ASCII character representation of IMSI_M_S2 value

8.207.2 Field Documentation

8.207.2.1 uint16_t nas_minBasedIMSI::imsiM1112

8.207.2.2 uint8_t nas_minBasedIMSI::imsiMS1[7]

8.207.2.3 uint8_t nas_minBasedIMSI::imsiMS2[3]

8.207.2.4 uint8_t nas_minBasedIMSI::mccM[3]

8.208 nas_MNRInfo Struct Reference

Data Fields

- uint16_t mcc
- uint16_t mnc
- uint32_t rat

8.208.1 Detailed Description

Structure contains Manual Network Register Information parameters

Parameters

mcc	• A 16-bit integer representation of Mobile Country Code. Range - 0 to 999.
mnc	• A 16-bit integer representation of Mobile Network Code. Range - 0 to 999.

rat	• Radio access technology for which to register. – 0x04 - RADIO_IF_GSM – 0x05 - RADIO_IF_UMTS – 0x08 - RADIO_IF_LTE

8.208.2 Field Documentation

8.208.2.1 uint16_t nas_MNRInfo::mcc

8.208.2.2 uint16_t nas_MNRInfo::mnc

8.208.2.3 uint32_t nas_MNRInfo::rat

8.209 nas_ModePrefTlv Struct Reference

Data Fields

- uint16_t ModePref
- uint8_t TlvPresent

8.209.1 Detailed Description

Contain the radio technology mode preference

Parameters

ModePref	• Bit Mask indicating the radio technology mode preference • Bit values: – Bit 0 - cdma2000 1x – Bit 1 - cdma2000 HRPD(1xEV-DO) – Bit 2 - GSM – Bit 3 - UMTS – Bit 4 - LTE – Bit 5 - TD-SCDMA – Bit 6 - NR5G
TlvPresent	• Tlv Present

8.209.2 Field Documentation

8.209.2.1 uint16_t nas_ModePrefTlv::ModePref

8.209.2.2 uint8_t nas_ModePrefTlv::TlvPresent

8.210 nas_namName Struct Reference

Data Fields

- uint8_t namNameLen
- uint8_t namName [12]

8.210.1 Detailed Description

This structure contains NAM Name.

Parameters

namNameLen	• Number of sets of the following elements: – nam_name • If zero(0), then no information follows.
namName	• Name information in ASCII. The maximum length of nam_name is 12.

8.210.2 Field Documentation

8.210.2.1 uint8_t nas_namName::namName[12]

8.210.2.2 uint8_t nas_namName::namNameLen

8.211 nas_netSelectionPref Struct Reference

Data Fields

- uint8_t netReg
- uint16_t mcc
- uint16_t mnc

8.211.1 Detailed Description

Contain the network selection preference.

Parameters

netReg	• specifies one of the following actions: – 0x00 - Automatic registration * Device registers according to its provisioning; mcc and mnc fields are ignored – 0x01 - Manual Registration * Device registers to specified network; mcc and mnc must contain valid values
mcc	• MCC value. Range 0 to 999
mnc	• MNC value. Range 0 to 999

8.211.2 Field Documentation

8.211.2.1 uint16_t nas_netSelectionPref::mcc

8.211.2.2 uint16_t nas_netSelectionPref::mnc

8.211.2.3 uint8_t nas_netSelectionPref::netReg

8.212 nas_NetSelPrefTlv Struct Reference

Data Fields

- uint8_t NetSelPref
- uint8_t TlvPresent

8.212.1 Detailed Description

Contain the Network selection Preference for system selection preferences.

Parameters

NetSelPref	• Parameter indicating network selection preference • Values: – 0x00 - Automatic network selection – 0x01 - Manual network selection
TlvPresent	• Tlv Present

8.212.2 Field Documentation

8.212.2.1 uint8_t nas_NetSelPrefTlv::NetSelPref

8.212.2.2 uint8_t nas_NetSelPrefTlv::TlvPresent

8.213 nas_NetworkStat1x Struct Reference

Data Fields

- uint8_t State
- uint16_t SO
- uint32_t RX_PWR
- uint16_t RX_EC_IO
- uint32_t TX_PWR
- uint8_t ActSetCnt
- nas_ActPilotPNElement * pActPilotPNElements
- uint8_t NeighborSetCnt
- uint16_t * pNeighborSetPilotPN

8.213.1 Detailed Description

This structure contains network stat 1x.

Parameters

State	• CDMA current access state – 0x01 - Searching – 0x02 - Idle – 0x03 - Traffic – Others - NA
SO	• CDMA service option – 0xFFFF - Not in a call – 0x0001 - Basic Variable Rate Voice Service(8kbps) – 0x0002 - Mobile Station Loopback(8kbps) – 0x0003 - Enhanced Variable Rate Codec(EVRC) Voice Service(8kbps) – 0x0006 - Short message Services(Rate Set 1) – 0x0009 - Mobile Station Loopback(13kbps) – 0x000E - Short Message Service (Rate Set 2) – 0x0011 - High Rate Voice Service(13kbps) – 0x0020 - Test Data Service Option(TDSO) – 0x0021 - cdma2000 High Speed Packet Data Service, Internet or ISO Protocol Stack – 0x0044 - EVRC-B Voice Service(8 kbps) – 0x0046 - EVRC-WB Voice Service(8 kbps) – 0x0049 - Voice Echo mode supports smart blanking(EVRC-NW) – 0x004B - Enhanced loopback – 0x8000 - Proprietary Service Option (Qualcomm Inc.)
RX_PWR	• RX Pwr(dBm) – 0xABCD00EF - -ABCD.EF dBm – ABCD00EF should be transferred to decimal while displaying – Example: 0x12340056 - -4660.86dBm 0x1234 = 4660, 0x0056 = 86 – 0xFFFFFFFF - NA
RX_EC_IO	• RX EC/IO(dB) – 0xABCD - -AB.CD dB – ABCD should be transferred to decimal while displaying – Example: 0x1234 - -18.52dB 0x12 = 18, 0x34 = 52 – 0xFFFF - NA
TX_PWR	• TX PWR(dBm) – 0xFFFFFFFF - NA – Others - display actual value in decimal – Example: 0x1234 - -4660dBm 0x1234 = 4660

ActSetCnt	• Count of active pilot PN elements • As input specifies number of sets of parameter pActPilotElements for which memory has been assigned • As output specifies the actual number of sets of parameter pActPilotElements returned by device
pActPilotPN-Elements	• See nas_ActPilotPNElement for more information
NeighborSetCnt	• Count of neighbor pilot PN elements • As input specifies number of sets of parameter pNeighborSetPilotPN for which memory has been assigned • As output specifies the actual number of sets of parameter pNeighborSetPilotPN returned by device
pNeighborSet-PilotPN	• Neighbor pilot PN

8.213.2 Field Documentation

8.213.2.1 uint8_t nas_NetworkStat1x::ActSetCnt

8.213.2.2 uint8_t nas_NetworkStat1x::NeighborSetCnt

8.213.2.3 nas_ActPilotPNElement* nas_NetworkStat1x::pActPilotPNElements

8.213.2.4 uint16_t* nas_NetworkStat1x::pNeighborSetPilotPN

8.213.2.5 uint16_t nas_NetworkStat1x::RX_EC_IO

8.213.2.6 uint32_t nas_NetworkStat1x::RX_PWR

8.213.2.7 uint16_t nas_NetworkStat1x::SO

8.213.2.8 uint8_t nas_NetworkStat1x::State

8.213.2.9 uint32_t nas_NetworkStat1x::TX_PWR

8.214 nas_NetworkStatEVDO Struct Reference

Data Fields

- uint8_t State
- uint8_t MACIndex
- uint8_t SectorIDLen
- uint16_t * pSectorID
- uint16_t RX_PWR
- uint16_t PER
- uint16_t PilotEnergy
- uint8_t SNR

8.214.1 Detailed Description

This structure contains network stat EVDO.

Parameters

State	• EVDO network access state – 0x00 - Sleep – 0x01 - Searching – 0x02 - Idle – 0x03 - Active – 0xFF - NA
MACIndex	• HDR Mac index – 0xFF - NA – Others - Display the actual value in decimal – Example: 0x12 - 18 0x12 = 18
SectorIDLen	(IN/OUT) • Sector ID length • As input specifies length of parameter pSectorID for which memory has been assigned • As output specifies the actual length of parameter pSectorID returned by device
pSectorID	• Sector ID
RX_PWR	• TX PWR(dBm) – 0xABCD - -ABCD dBm – ABCD should be transferred to decimal while displaying – Example: 0x1234 - -4660dBm 0x1234 = 4660 – 0xFFFF - NA
PER	• HDR Packet Error Rate – 0xFFFF - Unknown – Others - display the actual value in decimal – Example: 0x1234 - -4660dBm 0x1234 = 4660
PilotEnergy	• Pilt Energy (dB) – 0xFFFF - NA – 0xABCD should be transferred to decimal while displaying – Example: 0x1234 - -4660dBm 0x1234 = 4660
SNR	• Signal to Noise ratio (dB)

8.214.2 Field Documentation

8.214.2.1 uint8_t nas_NetworkStatEVDO::MACIndex

8.214.2.2 uint16_t nas_NetworkStatEVDO::PER

8.214.2.3 uint16_t nas_NetworkStatEVDO::PilotEnergy

8.214.2.4 uint16_t* nas_NetworkStatEVDO::pSectorID

8.214.2.5 uint16_t nas_NetworkStatEVDO::RX_PWR

8.214.2.6 uint8_t nas_NetworkStatEVDO::SectorIDLen

8.214.2.7 uint8_t nas_NetworkStatEVDO::SNR

8.214.2.8 uint8_t nas_NetworkStatEVDO::State

8.215 nas_nmrCellInfo Struct Reference

Data Fields

- uint32_t nmrCellID
- uint8_t nmrPlmn [3]
- uint16_t nmrLac
- uint16_t nmrArfcn
- uint8_t nmrBsic
- uint16_t nmrRxLev

8.215.1 Detailed Description

This structure contains information about the Network Measurement Report (NMR) Cell Information.

Parameters

nmrCellID	• Cell ID. • 0xFFFFFFFF indicates cell ID information is not present.
nmrPlmn[NAS_PLMN_LENGTH]	• MCC/MNC information coded as octet 3, 4, and 5. • This field is ignored when nmrCellID is not present.
nmrLac	• Location area code. • This field is ignored when nmrCellID is not present. – 0xFFFF - Not Available
nmrArfcn	• Absolute RF channel number. – 0xFFFF - Not Available

nmrBsic	• Base station identity code. – 0xFF - Not Available
nmrRxLev	• Cell Rx measurement. • Values range between 0 and 63. • Mapped to a measured signal level: – Rxlev 0 is a signal strength less than -110 dBm – Rxlev 1 is -110 dBm to -109 dBm – Rxlev 2 is -109 dBm to -108 dBm – ... – Rxlev 62 is -49 dBm to -48 dBm – Rxlev 63 is greater than -48 dBm – 0xFFFF - Not Available

8.215.2 Field Documentation

8.215.2.1 uint16_t nas_nmrCellInfo::nmrArfcn

8.215.2.2 uint8_t nas_nmrCellInfo::nmrBsic

8.215.2.3 uint32_t nas_nmrCellInfo::nmrCellID

8.215.2.4 uint16_t nas_nmrCellInfo::nmrLac

8.215.2.5 uint8_t nas_nmrCellInfo::nmrPlmn[3]

8.215.2.6 uint16_t nas_nmrCellInfo::nmrRxLev

8.216 nas_nr5gBandPref Struct Reference

Data Fields

- uint64_t bits_1_64
- uint64_t bits_65_128
- uint64_t bits_129_192
- uint64_t bits_193_256

8.216.1 Detailed Description

Contain the NR5G Band Preference.

Parameters

bits_1_64	• Bits 1 to 64 of the 256-bit NR5G Operating Band bitmask.
bits_65_128	• Bits 65 to 128 of the 256-bit NR5G Operating Band bitmask.

bits_129_192	• Bits 129 to 192 of the 256-bit NR5G Operating Band bitmask.
bits_193_256	• Bits 193 to 256 of the 256-bit NR5G Operating Band bitmask.

8.216.2 Field Documentation

8.216.2.1 uint64_t nas_nr5gBandPref::bits_129_192

8.216.2.2 uint64_t nas_nr5gBandPref::bits_193_256

8.216.2.3 uint64_t nas_nr5gBandPref::bits_1_64

8.216.2.4 uint64_t nas_nr5gBandPref::bits_65_128

8.217 nas_operatorNameString Struct Reference

Data Fields

- uint8_t PLMNName [255]

8.217.1 Detailed Description

This structure contains PLMN name.

Parameters

PLMNName	• PLMN name must be coded in a default 7-bit alphabet with b8 set to 0.

8.217.2 Field Documentation

8.217.2.1 uint8_t nas_operatorNameString::PLMNName[255]

8.218 nas_OperatorPLMNData Struct Reference

Data Fields

- uint8_t mcc [3]
- uint8_t mnc [3]
- uint16_t lac1
- uint16_t lac2
- uint8_t PLMNRecID

8.218.1 Detailed Description

This structure contains Operator PLMN.

Parameters

mcc	• MCC in ASCII string (a value of D in any of the digits is to be used to indicate a "wild" value for that corresponding digit).
mnc	• MNC in ASCII string (a value of D in any of the digits is to be used to indicate a "wild" value for that corresponding digit; digit 3 in MNC is optional and when not present, will be set as ASCII F).
lac1	• Location area code 1.
lac2	• Location area code 1.
PLMNRecID	• PLMN network name record identifier.

8.218.2 Field Documentation

8.218.2.1 uint16_t nas_OperatorPLMNData::lac1

8.218.2.2 uint16_t nas_OperatorPLMNData::lac2

8.218.2.3 uint8_t nas_OperatorPLMNData::mcc[3]

8.218.2.4 uint8_t nas_OperatorPLMNData::mnc[3]

8.218.2.5 uint8_t nas_OperatorPLMNData::PLMNRecID

8.219 nas_operatorPLMNList Struct Reference

Data Fields

- uint16_t numInstance
- nas_OperatorPLMNData PLMNData [255]

8.219.1 Detailed Description

This structure contains Operator PLMN List.

Parameters

numInstance	• Number of sets of the elements.
PLMNData	• Refer OperatorPLMNLData for details (Optional).

8.219.2 Field Documentation

8.219.2.1 uint16_t nas_operatorPLMNList::numInstance

8.219.2.2 nas_OperatorPLMNData nas_operatorPLMNList::PLMNData[255]

8.220 nas_PhyCaAggPcellInfo Struct Reference

Data Fields

- int pci
- int freq
- NAS_LTE_CPHY_CA_BW_NRB_LITE dl_bw_value
- int iLTEbandValue
- uint8_t TlvPresent

8.220.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Pcell Information.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
dl_bw_value	• Downlink Bandwidth Values. • See NAS_LTE_CPHY_CA_BW_NRB_LITE for more information.
scell_state	• Scell state Values. • See NAS_LTE_CPHY_SCELL_STATE_LITE for more information.
TlvPresent	• Tlv Present.

8.220.2 Field Documentation

8.220.2.1 NAS_LTE_CPHY_CA_BW_NRB_LITE nas_PhyCaAggPcellInfo::dl_bw_value

8.220.2.2 int nas_PhyCaAggPcellInfo::freq

8.220.2.3 int nas_PhyCaAggPcellInfo::iLTEbandValue

8.220.2.4 int nas_PhyCaAggPcellInfo::pci

8.220.2.5 uint8_t nas_PhyCaAggPcellInfo::TlvPresent

8.221 nas_PhyCaAggScellDlBw Struct Reference

Data Fields

- NAS_LTE_CPHY_CA_BW_NRB_LITE dl_bw_value
- uint8_t TlvPresent

8.221.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation Downlink Bandwidth of Scell.

Parameters

dl_bw_value	• Downlink Bandwidth Values. • See NAS_LTE_CPHY_CA_BW_NRB_LITE for more information.

8.221.2 Field Documentation

8.221.2.1 NAS_LTE_CPHY_CA_BW_NRB_LITE nas_PhyCaAggScellDlBw::dl_bw_value

8.221.2.2 uint8_t nas_PhyCaAggScellDlBw::TlvPresent

8.222 nas_PhyCaAggScellIndex Struct Reference

Data Fields

- uint8_t scell_idx
- uint8_t TlvPresent

8.222.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Index.

Parameters

scell_idx	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
TlvPresent	• Tlv Present.

8.222.2 Field Documentation

8.222.2.1 uint8_t nas_PhyCaAggScellIndex::scell_idx

8.222.2.2 uint8_t nas_PhyCaAggScellIndex::TlvPresent

8.223 nas_PhyCaAggScellIndType Struct Reference

Data Fields

- int pci
- int freq
- NAS_LTE_CPHY_SCELL_STATE_LITE scell_state
- uint8_t TlvPresent

8.223.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Indicator Type.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
scell_state	• Scell state Values. • See NAS_LTE_CPHY_SCELL_STATE_LITE for more information.
TlvPresent	• Tlv Present.

8.223.2 Field Documentation

8.223.2.1 int nas_PhyCaAggScellIndType::freq

8.223.2.2 int nas_PhyCaAggScellIndType::pci

8.223.2.3 NAS_LTE_CPHY_SCELL_STATE_LITE nas_PhyCaAggScellIndType::scell_state

8.223.2.4 uint8_t nas_PhyCaAggScellIndType::TlvPresent

8.224 nas_PhyCaAggScellInfo Struct Reference

Data Fields

- int pci
- int freq
- NAS_LTE_CPHY_CA_BW_NRB_LITE dl_bw_value
- uint16_t iLTEbandValue
- NAS_LTE_CPHY_SCELL_STATE_LITE scell_state
- uint8_t TlvPresent

8.224.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Information.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
dl_bw_value	• Downlink Bandwidth Values. • See NAS_LTE_CPHY_CA_BW_NRB_LITE for more information.

iLTEbandValue	• Band value. • Range for LTE Band class 120 to 160. – 120 - LTE E-UTRA Operating Band 1 – 121 - LTE E-UTRA Operating Band 2 – 122 - LTE E-UTRA Operating Band 3 – 123 - LTE E-UTRA Operating Band 4 – 124 - LTE E-UTRA Operating Band 5 – 125 - LTE E-UTRA Operating Band 6 – 126 - LTE E-UTRA Operating Band 7 – 127 - LTE E-UTRA Operating Band 8 – 128 - LTE E-UTRA Operating Band 9 – 129 - LTE E-UTRA Operating Band 10 – 130 - LTE E-UTRA Operating Band 11 – 131 - LTE E-UTRA Operating Band 12 – 132 - LTE E-UTRA Operating Band 13 – 133 - LTE E-UTRA Operating Band 14 – 134 - LTE E-UTRA Operating Band 17 – 135 - LTE E-UTRA Operating Band 33 – 136 - LTE E-UTRA Operating Band 34 – 137 - LTE E-UTRA Operating Band 35 – 138 - LTE E-UTRA Operating Band 36 – 139 - LTE E-UTRA Operating Band 37 – 140 - LTE E-UTRA Operating Band 38 – 141 - LTE E-UTRA Operating Band 39 – 142 - LTE E-UTRA Operating Band 40 – 143 - LTE E-UTRA Operating Band 18 – 144 - LTE E-UTRA Operating Band 19 – 145 - LTE E-UTRA Operating Band 20 – 146 - LTE E-UTRA Operating Band 21 – 147 - LTE E-UTRA Operating Band 24 – 148 - LTE E-UTRA Operating Band 25 – 149 - LTE E-UTRA Operating Band 41 – 150 - LTE E-UTRA Operating Band 42 – 151 - LTE E-UTRA Operating Band 43 – 152 - LTE E-UTRA Operating Band 23 – 153 - LTE E-UTRA Operating Band 26 – 154 - LTE E-UTRA Operating Band 32 – 155 - LTE E-UTRA Operating Band 125 – 156 - LTE E-UTRA Operating Band 126 – 157 - LTE E-UTRA Operating Band 127 – 158 - LTE E-UTRA Operating Band 28 – 159 - LTE E-UTRA Operating Band 29 – 160 - LTE E-UTRA Operating Band 30
scell_state	• Scell state Values. • See NAS_LTE_CPHY_SCELL_STATE_LITE for more information.

TlvPresent	• Tlv Present.

8.224.2 Field Documentation

8.224.2.1 NAS_LTE_CPHY_CA_BW_NRB_LITE nas_PhyCaAggScellInfo::dl_bw_value

8.224.2.2 int nas_PhyCaAggScellInfo::freq

8.224.2.3 uint16_t nas_PhyCaAggScellInfo::iLTEbandValue

8.224.2.4 int nas_PhyCaAggScellInfo::pci

8.224.2.5 NAS_LTE_CPHY_SCELL_STATE_LITE nas_PhyCaAggScellInfo::scell_state

8.224.2.6 uint8_t nas_PhyCaAggScellInfo::TlvPresent

8.225 nas_PilotSetData Struct Reference

Data Fields

- uint8_t NumPilots
- nas_PilotSetParams * pPilotSetInfo

8.225.1 Detailed Description

This structure contains pilot sets data.

Parameters

NumPilots	• Number of Pilot Sets • As input specifies number of sets of parameter pPilotSetInfo for which memory has been assigned • As output specifies the actual number of sets of parameter pPilotSetInfo returned by device
pPilotSetInfo	• Pilot Set Parameters • See nas_PilotSetParams for more information.

note A buffer under sized error is returned if the number of sets of pPilotSetInfo returned by the device is greater than the value in NumPilots input parameter.

8.225.2 Field Documentation

8.225.2.1 uint8_t nas_PilotSetData::NumPilots

8.225.2.2 nas_PilotSetParams* nas_PilotSetData::pPilotSetInfo

8.226 nas_PilotSetParams Struct Reference

Data Fields

- uint32_t PilotType
- uint16_t PilotPN
- uint16_t PilotStrength

8.226.1 Detailed Description

This structure contains pilot sets parameters.

Parameters

PilotType	• 0x00 - NAS_HRPD_PILOT_CURR_ACT_PLT Current Active Pilot • 0x01 - NAS_HRPD_PILOT_NEIGHBOR_PLT Neighbor pilot information
PilotPN	• Pilot PN sequence offset index
PilotStrength	• Strength of the pilot (in dB)

8.226.2 Field Documentation

8.226.2.1 uint16_t nas_PilotSetParams::PilotPN

8.226.2.2 uint16_t nas_PilotSetParams::PilotStrength

8.226.2.3 uint32_t nas_PilotSetParams::PilotType

8.227 nas_PlmnID Struct Reference

Data Fields

- uint16_t mcc
- uint16_t mnc
- uint8_t pcsDigit
- uint8_t TlvPresent

8.227.1 Detailed Description

This structure contains PLMN ID information

Parameters

mcc	• A 16-bit integer representation of MCC. Range: 0 to 999
mnc	• A 16-bit integer representation of MNC. Range: 0 to 999

pcsDigit	• This field is used to interpret the length of the corresponding MNC reported in the TLVs (in this table) with an mnc or mobile_network_code field. Values: – TRUE - MNC is a three-digit value; for example, a reported value of 90 corresponds to an MNC value of 090 – FALSE - MNC is a two-digit value; for example, a reported value of 90 corresponds to an MNC value of 90
TlvPresent	• Tlv Present or not

8.227.2 Field Documentation

8.227.2.1 uint16_t nas_PlmnID::mcc

8.227.2.2 uint16_t nas_PlmnID::mnc

8.227.2.3 uint8_t nas_PlmnID::pcsDigit

8.227.2.4 uint8_t nas_PlmnID::TlvPresent

8.228 nas_PLMNNetworkName Struct Reference

Data Fields

- uint8_t numInstance
- nas_PLMNNetworkNameData PLMNNetName [255]

8.228.1 Detailed Description

This structure contains NITZ Information list.

Parameters

numInstance	• Number of sets of the elements.
PLMNNetName	• Refer nas_PLMNNetworkNameData for details (Optional).

8.228.2 Field Documentation

8.228.2.1 uint8_t nas_PLMNNetworkName::numInstance

8.228.2.2 nas_PLMNNetworkNameData nas_PLMNNetworkName::PLMNNetName[255]

8.229 nas_PLMNNetworkNameData Struct Reference

Data Fields

- uint8_t codingScheme
- uint8_t countryInitials
- uint8_t longNameSpareBits
- uint8_t shortNameSpareBits
- uint8_t longNameLen
- uint8_t longName [255]
- uint8_t shortNameLen
- uint8_t shortName [255]

8.229.1 Detailed Description

This structure contains NITZ Information.

Parameters

codingScheme	• Coding scheme: – 0 - CODING_SCHEME_CELL_BROADCAST_GSM - Cell broadcast data coding scheme, GSM default alphabet, language unspecified;defined in 3GPP TS 23.038. – 1 - CODING_SCHEME_UCS2 - UCS2 (16 bit);defined in ISO/IEC 10646
countryInitials	• Country's initials: – 0 - COUNTRY_INITIALS_DO_NOT_ADD - MS should not add the letters for the country's initials to the text string. – 1 - COUNTRY_INITIALS_ADD - MS should add the letters for the country's initials and a separator, e.g., a space, to the text string.
longNameSpare-Bits	• Long Name Spare Bits: – 1 - SPARE_BITS_8 - Bit 8 is spare and set to 0 in octet n – 2 - SPARE_BITS_7_TO_8 - Bits 7 and 8 are spare and set to 0 in octet n. – 3 - SPARE_BITS_6_TO_8 - Bits 6 to 8 (inclusive) are spare and set to 0 in octet n. – 4 - SPARE_BITS_5_TO_8 - Bits 5 to 8 (inclusive) are spare and set to 0 in octet n. – 5 - SPARE_BITS_4_TO_8 - Bits 4 to 8 (inclusive) are spare and set to 0 in octet n. – 6 - SPARE_BITS_3_TO_8 - Bits 3 to 8 (inclusive) are spare and set to 0 in octet n. – 7 - SPARE_BITS_2_TO_8 - Bits 2 to 8 (inclusive) are spare and set to 0 in octet n. – 0 - SPARE_BITS_UNKNOWN - Carries no information about the number of spare bits in octet n.
shortName-SpareBits	• Short Name Spare Bits: – 1 - SPARE_BITS_8 - Bit 8 is spare and set to 0 in octet n. – 2 - SPARE_BITS_7_TO_8 - Bits 7 and 8 are spare and set to 0 in octet n. – 3 - SPARE_BITS_6_TO_8 - Bits 6 to 8 (inclusive) are spare and set to 0 in octet n. – 4 - SPARE_BITS_5_TO_8 - Bits 5 to 8 (inclusive) are spare and set to 0 in octet n. – 5 - SPARE_BITS_4_TO_8 - Bits 4 to 8 (inclusive) are spare and set to 0 in octet n. – 6 - SPARE_BITS_3_TO_8 - Bits 3 to 8 (inclusive) are spare and set to 0 in octet n. – 7 - SPARE_BITS_2_TO_8 - Bits 2 to 8 (inclusive) are spare and set to 0 in octet n. – 0 - SPARE_BITS_UNKNOWN - Carries no information about the number of spare bits in octet n.

longNameLen	• It provides the length of long name.
longName	• Long name string in coding_scheme.
shortNameLen	• It provides the length of short name.
shortName	• Short name string in coding_scheme.

8.229.2 Field Documentation

8.229.2.1 uint8_t nas_PLMNNetworkNameData::codingScheme

8.229.2.2 uint8_t nas_PLMNNetworkNameData::countryInitials

8.229.2.3 uint8_t nas_PLMNNetworkNameData::longName[255]

8.229.2.4 uint8_t nas_PLMNNetworkNameData::longNameLen

8.229.2.5 uint8_t nas_PLMNNetworkNameData::longNameSpareBits

8.229.2.6 uint8_t nas_PLMNNetworkNameData::shortName[255]

8.229.2.7 uint8_t nas_PLMNNetworkNameData::shortNameLen

8.229.2.8 uint8_t nas_PLMNNetworkNameData::shortNameSpareBits

8.230 nas_PRLPrefTlv Struct Reference

Data Fields

- uint16_t PRLPref
- uint8_t TlvPresent

8.230.1 Detailed Description

Contain the PRL preference for system selection preferences.

Parameters

PRLPref	• Parameter indicating the CDMA PRL Preference • Values: – 0x0001 - Acquire available system only on the A side – 0x0002 - Acquire available system only on the B side – 0x3FFF - Acquire any available systems

TlvPresent	• Tlv Present

8.230.2 Field Documentation

8.230.2.1 uint16_t nas_PRLPrefTlv::PRLPref

8.230.2.2 uint8_t nas_PRLPrefTlv::TlvPresent

8.231 nas_protocolSubtypeElement Struct Reference

Data Fields

- uint16_t PhysicalLayer
- uint16_t ControlMac
- uint16_t AccessMac
- uint16_t ForwardMac
- uint16_t ReverseMac
- uint16_t KeyExchange
- uint16_t AuthProt
- uint16_t EncryptProt
- uint16_t SecProt
- uint16_t IdleState
- uint16_t MultDisc
- uint16_t VirtStream

8.231.1 Detailed Description

This structure contains protocol subtype element.

Parameters

PhysicalLayer	• Specifies Physical Layer Protocol subtype
ControlMac	• Specifies Control Channel MAC Protocol subtype
AccessMac	• Specifies Access Channel MAC Protocol subtype
ForwardMac	• Specifies Forward Traffic Channel MAC Protocol subtype
ReverseMac	• Specifies Reverse Traffic Channel MAC Protocol subtype
KeyExchange	• Specifies Key exchange Protocol subtype

AuthProt	• Specifies Authentication Protocol subtype
EncryptProt	• Specifies Encryption Protocol subtype
SecProt	• Specifies Security Protocol subtype
IdleState	• Specifies Idle state Protocol subtype
MultDisc	• Specifies Generic multimode capability discovery Protocol subtype
VirtStream	• Specifies Generic Virtual Stream Protocol subtype

8.231.2 Field Documentation

8.231.2.1 uint16_t nas_protocolSubtypeElement::AccessMac

8.231.2.2 uint16_t nas_protocolSubtypeElement::AuthProt

8.231.2.3 uint16_t nas_protocolSubtypeElement::ControlMac

8.231.2.4 uint16_t nas_protocolSubtypeElement::EncryptProt

8.231.2.5 uint16_t nas_protocolSubtypeElement::ForwardMac

8.231.2.6 uint16_t nas_protocolSubtypeElement::IdleState

8.231.2.7 uint16_t nas_protocolSubtypeElement::KeyExchange

8.231.2.8 uint16_t nas_protocolSubtypeElement::MultDisc

8.231.2.9 uint16_t nas_protocolSubtypeElement::PhysicalLayer

8.231.2.10 uint16_t nas_protocolSubtypeElement::ReverseMac

8.231.2.11 uint16_t nas_protocolSubtypeElement::SecProt

8.231.2.12 uint16_t nas_protocolSubtypeElement::VirtStream

8.232 nas_qaQmi3Gpp2TimeZone Struct Reference

Data Fields

- uint8_t leapSeconds
- uint8_t localTimeOffset
- uint8_t daylightSavings

8.232.1 Detailed Description

This structure contains the 3GPP2TimeZone parameters

Parameters

leapSeconds	• leap seconds - Number of leap seconds since the start of CDMA system time.
localTimeOffset	• Local Time Offset - Offset of system time in units of 30 minutes; the value in this field conveys as 8 bit 2's compliment number.
daylightSavings	• Day Light Savings Indicator – 0x00 - OFF (daylight savings not in effect) – 0x01 - ON (daylight savings in effect)

8.232.2 Field Documentation

8.232.2.1 uint8_t nas_qaQmi3Gpp2TimeZone::daylightSavings

8.232.2.2 uint8_t nas_qaQmi3Gpp2TimeZone::leapSeconds

8.232.2.3 uint8_t nas_qaQmi3Gpp2TimeZone::localTimeOffset

8.233 nas_QmiNas3GppNetworkInfo Struct Reference

Data Fields

- uint16_t MCC
- uint16_t MNC
- uint32_t InUse
- uint32_t Roaming
- uint32_t Forbidden
- uint32_t Preferred
- char Desription [255]

8.233.1 Detailed Description

Contain the 3GPP network information.

Parameters

MCC	• Mobile Country Code
MNC	• Mobile Network Code

InUse	• Is the Network the current serving Network – 0 - Unknown – 1 - Current serving network – 2 - Not current serving network, available
Roaming	• Home/Roam Status of the Network – 0 - Unknown – 1 - Home – 2 - Roam
Forbidden	• Is the Network in the forbidden network list – 0 - Unknown – 1 - Forbidden – 2 - Not Forbidden
Preferred	• Is the Network in the Preferred network list – 0 - Unknown – 1 - Preferred – 2 - Not Preferred
Description	• Network Name/Description • This is a NULL terminated string.

8.233.2 Field Documentation

8.233.2.1 char nas_QmiNas3GppNetworkInfo::Desription[255]

8.233.2.2 uint32_t nas_QmiNas3GppNetworkInfo::Forbidden

8.233.2.3 uint32_t nas_QmiNas3GppNetworkInfo::InUse

8.233.2.4 uint16_t nas_QmiNas3GppNetworkInfo::MCC

8.233.2.5 uint16_t nas_QmiNas3GppNetworkInfo::MNC

8.233.2.6 uint32_t nas_QmiNas3GppNetworkInfo::Preferred

8.233.2.7 uint32_t nas_QmiNas3GppNetworkInfo::Roaming

8.234 nas_QmiNas3GppNetworkRAT Struct Reference

Data Fields

- uint16_t MCC
- uint16_t MNC
- uint8_t RAT

8.234.1 Detailed Description

Contain the 3GPP radio access technology information.

Parameters

MCC	• Mobile Country Code
MNC	• Mobile Network Code
RAT	• Radio Access Technology – 0x04 - GERAN – 0x05 - UMTS – 0x08 - LTE – 0x09 - TD-SCDMA

8.234.2 Field Documentation

8.234.2.1 uint16_t nas_QmiNas3GppNetworkRAT::MCC

8.234.2.2 uint16_t nas_QmiNas3GppNetworkRAT::MNC

8.234.2.3 uint8_t nas_QmiNas3GppNetworkRAT::RAT

8.235 nas_QmisNasPcsDigit Struct Reference

Data Fields

- uint16_t MCC
- uint16_t MNC
- uint8_t includes_pcs_digit

8.235.1 Detailed Description

Contain the PCS Digit information

Parameters

MCC	• Mobile Country Code
MNC	• Mobile Network Code
includes_pcs_digit	• this field is use to interpret the length of corresponding MNC reported • 0x01 - MNC is a three-digit value • 0x00 - MNC is a two-digit value

8.235.2 Field Documentation

8.235.2.1 uint8_t nas_QmisNasPcsDigit::includes_pcs_digit

8.235.2.2 uint16_t nas_QmisNasPcsDigit::MCC

8.235.2.3 uint16_t nas_QmisNasPcsDigit::MNC

8.236 nas_QmisNasSlqsNasPCICellInfo Struct Reference

Data Fields

- uint32_t freq
- uint16_t cellID
- uint32_t GlobalCellID
- uint8_t PlmnLen
- nas_QmisNasPcsDigit nasQmisNasPcsDigit [255]

8.236.1 Detailed Description

Contain the PCI Cell Info.

Parameters

freq	• Aboslute cell's frequency. Range 0 to 65535.
cellID	• Cell ID.
GlobalCellID	• Global Cell ID.
PlmnLen	• Number of Plmn(nasQmisNasPcsDigit) information sets.
nasQmisNas-PcsDigit	• See nas_QmisNasPcsDigit for more information.

8.236.2 Field Documentation

8.236.2.1 uint16_t nas_QmisNasSlqsNasPCICellInfo::cellID

8.236.2.2 uint32_t nas_QmisNasSlqsNasPCICellInfo::freq

8.236.2.3 uint32_t nas_QmisNasSlqsNasPCICellInfo::GlobalCellID

8.236.2.4 nas_QmisNasPcsDigit nas_QmisNasSlqsNasPCICellInfo::nasQmisNasPcsDigit[255]

8.236.2.5 uint8_t nas_QmisNasSlqsNasPCICellInfo::PlmnLen

8.237 nas_QmisNasSlqsNasPCIInfo Struct Reference

Data Fields

- uint8_t PCICellInfoLen
- nas_QmisNasSlqsNasPCICellInfo nasQmisNasSlqsNasPCICellInfo [255]
- uint16_t rsrp
- uint16_t rsrpRx0
- uint16_t rsrpRx1
- uint16_t rsrq
- uint16_t rsrqRx0
- uint16_t rsrqRx1

8.237.1 Detailed Description

Contain the NAS Perform network scan PCI information

Parameters

PCICellInfoLen	• Number of PCI Cell Info(PCICellInfo) information sets.
nasQmisNasSlqsNasPCICellInfo	• See nas_QmisNasSlqsNasPCICellInfo for more information.
rsrp	• Combined RSRP.
rsrpRx0	• Rx0 RSRP.
rsrpRx1	• Rx1 RSRP.
rsrq	• Combined RSRQ.
rsrqRx0	• Rx0 RSRQ.
rsrpRx1	• Rx1 RSRQ.

8.237.2 Field Documentation

8.237.2.1 nas_QmisNasSlqsNasPCICellInfo nas_QmisNasSlqsNasPCIInfo::nasQmisNasSlqsNasPCICellInfo[255]

8.237.2.2 uint8_t nas_QmisNasSlqsNasPCIInfo::PCICellInfoLen

8.237.2.3 uint16_t nas_QmisNasSlqsNasPCIInfo::rsrp

8.237.2.4 uint16_t nas_QmisNasSlqsNasPCIInfo::rsrpRx0

8.237.2.5 uint16_t nas_QmisNasSlqsNasPCIInfo::rsrpRx1

8.237.2.6 uint16_t nas_QmisNasSlqsNasPCIInfo::rsrq

8.237.2.7 uint16_t nas_QmisNasSlqsNasPCIInfo::rsrqRx0

8.237.2.8 uint16_t nas_QmisNasSlqsNasPCIInfo::rsrqRx1

8.238 nas_RankIndicatorTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t count0
- uint32_t count1

8.238.1 Detailed Description

Elements for Rank indicator TLV.

Parameters

TlvPresent	• value is 1 if TLV is present, otherwise 0
count0	• count of Rank1
count1	• count of Rank2

8.238.2 Field Documentation

8.238.2.1 uint32_t nas_RankIndicatorTlv::count0

8.238.2.2 uint32_t nas_RankIndicatorTlv::count1

8.238.2.3 uint8_t nas_RankIndicatorTlv::TlvPresent

8.239 nas_RatDisabledMaskTlv Struct Reference

Data Fields

- uint16_t ratDisabledMask
- uint8_t TlvPresent

8.239.1 Detailed Description

Contain the RAT disabled mask

Parameters

ratDisabledMask	• Bitmask representing the radio technologies that are disabled. • Bit values: – Bit 0 (0x01) - cdma2000 ® 1X – Bit 1 (0x02) - cdma2000 ® HRPD(1xEV-DO) – Bit 2 (0x04) - GSM – Bit 3 (0x08) - UMTS – Bit 4 (0x10) - LTE – Bit 5 (0x20) - TD-SCDMA – Bit 6 (0x40) - NR5G All unlisted bits are reserved for future use and the service point ignores them if used.
TlvPresent	• Tlv Present

8.239.2 Field Documentation

8.239.2.1 uint16_t nas_RatDisabledMaskTlv::ratDisabledMask

8.239.2.2 uint8_t nas_RatDisabledMaskTlv::TlvPresent

8.240 nas_RejectReasonTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t serviceDomain
- uint32_t rejectCause

8.240.1 Detailed Description

This structure contains paramaters reject reason.

Parameters

TlvPresent	indicating the presence of the TLV in the QMI ind
serviceDomain	service domain
rejectCause	cause of reject

8.240.2 Field Documentation

8.240.2.1 uint32_t nas_RejectReasonTlv::rejectCause

8.240.2.2 uint32_t nas_RejectReasonTlv::serviceDomain

8.240.2.3 uint8_t nas_RejectReasonTlv::TlvPresent

8.241 nas_RFBandInfoElements Struct Reference

Data Fields

- uint8_t radioInterface
- uint16_t activeBandClass
- uint16_t activeChannel

8.241.1 Detailed Description

This structure contains the RFBandInfo response parameters.

Parameters

radioInterface	• Radio interface technology – See Tables for Radio Interface
activeBandClass	• Active Band Class – See Tables for Band Classes
activeChannel	• Active channel (0 if channel is not relevant to the reported technology)

8.241.2 Field Documentation

8.241.2.1 uint16_t nas_RFBandInfoElements::activeBandClass

8.241.2.2 uint16_t nas_RFBandInfoElements::activeChannel

8.241.2.3 uint8_t nas_RFBandInfoElements::radioInterface

8.242 nas_RfBandInfoExtFormat Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t * pInstancesSize
- struct nas_RfBandInfoExtFormatElements * pRfBandInfoExtFormatParam

8.242.1 Detailed Description

This structure contains the nas_RfBandInfoExtFormat response parameters.

Parameters

TlvPresent	• Tlv Present
pInstancesSize[-IN/OUT]	• Number of sets of the RFBandInfoElements • Upon input, maximum number of elements that the RF info instances array can contain. • Upon successful output, actual number of elements in RF info instances array.
pRfBandInfoExt-FormatParam	• See nas_RfBandInfoExtFormatElements for more information

8.242.2 Field Documentation

8.242.2.1 uint8_t* nas_RfBandInfoExtFormat::pInstancesSize

8.242.2.2 struct nas_RfBandInfoExtFormatElements* nas_RfBandInfoExtFormat::pRfBandInfoExtFormatParam

8.242.2.3 uint8_t nas_RfBandInfoExtFormat::TlvPresent

8.243 nas_RfBandInfoExtFormatElements Struct Reference

Data Fields

- uint8_t radioInterface
- uint16_t activeBand
- uint32_t activeChannel

8.243.1 Detailed Description

This structure contains the RF Band Information, Extended Format.

Parameters

radioInterface	• Radio interface technology – See Tables for Radio Interface
activeBand	• Active Band Class – See Tables for Band Classes
activeChannel	• Active channel (0 if channel is not relevant to the reported technology)

8.243.2 Field Documentation

8.243.2.1 uint16_t nas_RfBandInfoExtFormatElements::activeBand

8.243.2.2 uint32_t nas_RfBandInfoExtFormatElements::activeChannel

8.243.2.3 uint8_t nas_RfBandInfoExtFormatElements::radioInterface

8.244 nas_RfBandInfoList Struct Reference

Data Fields

- uint8_t * pInstanceSize
- struct nas_RFBandInfoElements * pRFBandInfoParam

8.244.1 Detailed Description

This structure contains the RfBandInfoList response parameters.

Parameters

pInstanceSize[IN/OUT]	• Number of sets of the RFBandInfoElements • Upon input, maximum number of elements that the RF info instances array can contain. • Upon successful output, actual number of elements in RF info instances array.
pRFBandInfoParam	• See nas_RFBandInfoElements for more information

8.244.2 Field Documentation

8.244.2.1 uint8_t* nas_RfBandInfoList::pInstanceSize

8.244.2.2 struct nas_RFBandInfoElements* nas_RfBandInfoList::pRFBandInfoParam

8.245 nas_RfBandwidthInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t * pInstancesSize
- struct nas_RfBandwidthInfoElements * pRfBandwidthInfoParam

8.245.1 Detailed Description

This structure contains the nas_RfBandwidthInfo response parameters.

Parameters

TlvPresent	• Tlv Present
pInstancesSize[IN/OUT]	• Number of sets of the RFBandInfoElements • Upon input, maximum number of elements that the RF info instances array can contain. • Upon successful output, actual number of elements in RF info instances array.

pRfBandwidth-InfoParam	• See nas_RfBandwidthInfoElements for more information

8.245.2 Field Documentation

8.245.2.1 uint8_t* nas_RfBandwidthInfo::pInstancesSize

8.245.2.2 struct nas_RfBandwidthInfoElements* nas_RfBandwidthInfo::pRfBandwidthInfoParam

8.245.2.3 uint8_t nas_RfBandwidthInfo::TlvPresent

8.246 nas_RfBandwidthInfoElements Struct Reference

Data Fields

- uint8_t radioInterface
- uint32_t bandwidth

8.246.1 Detailed Description

This structure contains the RF Bandwidth Information List parameters.

Parameters

radioInterface	• Radio interface technology – See Tables for Radio Interface
bandwidth	• Bandwidth – Values * NAS_LTE_BW_NRB_6 (0) - LTE 1.4 MHz bandwidth * NAS_LTE_BW_NRB_15 (1) - LTE 3 MHz bandwidth * NAS_LTE_BW_NRB_25 (2) - LTE 5 MHz bandwidth * NAS_LTE_BW_NRB_50 (3) - LTE 10 MHz bandwidth * NAS_LTE_BW_NRB_75 (4) - LTE 15 MHz bandwidth * NAS_LTE_BW_NRB_100 (5) - LTE 20 MHz bandwidth * NAS_NR5G_BW_NRB_6 (6) - NR5G 1.4 MHz bandwidth * NAS_NR5G_BW_NRB_15 (7) - NR5G 3 MHz bandwidth * NAS_NR5G_BW_NRB_25 (8) - NR5G 5 MHz bandwidth * NAS_NR5G_BW_NRB_50 (9) - NR5G 10 MHz bandwidth * NAS_NR5G_BW_NRB_75 (10) - NR5G 15 MHz bandwidth * NAS_NR5G_BW_NRB_100 (11) - NR5G 20 MHz bandwidth

8.246.2 Field Documentation

8.246.2.1 uint32_t nas_RfBandwidthInfoElements::bandwidth

8.246.2.2 uint8_t nas_RfBandwidthInfoElements::radioInterface

8.247 nas_RfDedicatedBandInfo Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t * pInstancesSize
- struct nas_RfDedicatedBandInfoElements * pRfDedicatedBandInfoParam

8.247.1 Detailed Description

This structure contains the nas_RfDedicatedBandInfo response parameters.

Parameters

TlvPresent	• Tlv Present
pInstancesSize[-IN/OUT]	• Number of sets of the RFBandInfoElements • Upon input, maximum number of elements that the RF info instances array can contain. • Upon successful output, actual number of elements in RF info instances array.
pRfDedicated-BandInfoParam	• See nas_RfDedicatedBandInfoElements for more information

8.247.2 Field Documentation

8.247.2.1 uint8_t* nas_RfDedicatedBandInfo::pInstancesSize

8.247.2.2 struct nas_RfDedicatedBandInfoElements* nas_RfDedicatedBandInfo::pRfDedicatedBandInfoParam

8.247.2.3 uint8_t nas_RfDedicatedBandInfo::TlvPresent

8.248 nas_RfDedicatedBandInfoElements Struct Reference

Data Fields

- uint8_t radioInterface
- uint16_t dedicatedBand

8.248.1 Detailed Description

This structure contains the RF Dedicated Band Info.

Parameters

radioInterface	• Radio interface technology – See Tables for Radio Interface

dedicatedBand	• Dedicated Band Class – See Tables for Band Classes

8.248.2 Field Documentation

8.248.2.1 uint16_t nas_RfDedicatedBandInfoElements::dedicatedBand

8.248.2.2 uint8_t nas_RfDedicatedBandInfoElements::radioInterface

8.249 nas_RFInfoTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t radioInterfaceSize
- uint32_t radioInterface [255]
- uint32_t activeBandClass [255]
- uint32_t activeChannel [255]

8.249.1 Detailed Description

This structure contains paramaters RF Band Information List.

Parameters

TlvPresent	indicating the presence of the TLV in the QMI ind
radioInterface-Size	Number of sets of the following elements • radioInterface • activeBandClass • activeChannel
radioInterface	radio interface technology of the signal being measured • 0x01 - cdma2000 1X • 0x02 - cdma2000 HRPD (1xEV-DO) • 0x03 - AMPS • 0x04 - GSM • 0x05 - UMTS • 0x08 - LTE • 0x09 - TD-SCDMA
activeBandClass	active band class • 00 to 39 - CDMA band classes • 40 to 79 - GSM band classes • 80 to 91 - WCDMA band classes • 120 to 160 - LTE band classes • 200 to 205 - TD-SCDMA band classes
activeChannel	active channel • Active channel. If the channel is not relevant to the technology, a value of 0 is returned.

8.249.2 Field Documentation

8.249.2.1 uint32_t nas_RFInfoTlv::activeBandClass[255]

8.249.2.2 uint32_t nas_RFInfoTlv::activeChannel[255]

8.249.2.3 uint32_t nas_RFInfoTlv::radioInterface[255]

8.249.2.4 uint8_t nas_RFInfoTlv::radioInterfaceSize

8.249.2.5 uint8_t nas_RFInfoTlv::TlvPresent

8.250 nas_roamIndList Struct Reference

Data Fields

- uint8_t numInstances
- uint8_t radioInterface [32]
- uint8_t roamIndicator [32]

8.250.1 Detailed Description

This structure contains the Roaming Indicator List

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

numInstances	• number of sets of radio interface currently in use and roaming indicator – defaults to zero
radioInterface	• Radio Interface currently in use • Values: – 0x01 - RADIO_IF_CDMA_1X - cdma2000 1X – 0x02 - RADIO_IF_CDMA_1XEVDO - cdma2000 HRPD (1xEV-DO) – 0x03 - RADIO_IF_AMPS - AMPS – 0x04 - RADIO_IF_GSM - GSM – 0x05 - RADIO_IF_UMTS - UMTS – 0x08 - RADIO_IF_LTE - LTE
roamIndicator	• Roaming Indicator • Values: – 0x00 - Roaming – 0x01 - Home

8.250.2 Field Documentation

8.250.2.1 uint8_t nas_roamIndList::numInstances

8.250.2.2 uint8_t nas_roamIndList::radioInterface[32]

8.250.2.3 uint8_t nas_roamIndList::roamIndicator[32]

8.251 nas_RoamPrefTlv Struct Reference

Data Fields

- uint16_t RoamPref
- uint8_t TlvPresent

8.251.1 Detailed Description

Contain the roaming preference for system selection preferences.

Parameters

RoamPref	• Parameter indicating the roaming Preference • Values: – 0x01 - Acquire only systems for which the roaming indicator is off – 0x02 - Acquire a system as long as its roaming indicator is not off – 0x03 - Acquire only systems for which the roaming indicator is off or solid on, i.e. not flashing; CDMA only – 0xFF - Acquire systems, regardless of their roaming indicator
TlvPresent	• Tlv Present

8.251.2 Field Documentation

8.251.2.1 uint16_t nas_RoamPrefTlv::RoamPref

8.251.2.2 uint8_t nas_RoamPrefTlv::TlvPresent

8.252 nas_RSRPThresh Struct Reference

Data Fields

- uint8_t RSRPThresListLen
- int16_t * pRSRPThresList

8.252.1 Detailed Description

This structure contains RSRP threshold list.

Parameters

RSRPThresList-Len	• Length of the RSRP threshold list parameter to follow
pRSRPThresList	• Sequence of thresholds delimiting current RSRP event reporting bands • Every time a new RSRP value crosses a specified threshold value, an event report indication message with the new RSRQ value is sent to the requesting control point. For this field – RSRP values are applicable only for LTE – RSRP values are measured in dBm, with a range of -44 dBm to -140 dBm – Each RSRP threshold value is a signed byte value – Maximum number of threshold values is 16 – At least one value must be specified

8.252.2 Field Documentation

8.252.2.1 int16_t* nas_RSRPThresh::pRSRPThresList

8.252.2.2 uint8_t nas_RSRPThresh::RSRPThresListLen

8.253 nas_rsrqInformation Struct Reference

Data Fields

- int8_t rsrq
- uint8_t radioIf

8.253.1 Detailed Description

This structure contains the RSRQ Information

Parameters

rsrq	• RSRQ value in dB (signed integer value); valid range is -3 to -20 (-3 means -3 dB, -20 means -20 dB)
radioIf	• Radio interface technology of the signal being measured – 0x08 – LTE

8.253.2 Field Documentation

8.253.2.1 uint8_t nas_rsrqInformation::radioIf

8.253.2.2 int8_t nas_rsrqInformation::rsrq

8.254 nas_RSRQThresh Struct Reference

Data Fields

- uint8_t RSRQThresListLen
- int8_t * pRSRQThresList

8.254.1 Detailed Description

This structure contains RSRQ threshold list.

Parameters

RSRQThresList-Len	• Length of the RSRQ threshold list parameter to follow
pRSRQThresList	• Sequence of thresholds delimiting current RSRQ event reporting bands • Every time a new RSRQ value crosses a threshold value, an event report indication message with the new RSRQ value is sent to the requesting control point. For this field – RSRQ values are applicable only for LTE – RSRQ values are measured in dBm, with a range of -20 dBm to -3 dBm – Each RSRQ threshold value is a signed byte value – Maximum number of threshold values is 16 – At least one value must be specified

8.254.2 Field Documentation

8.254.2.1 int8_t* nas_RSRQThresh::pRSRQThresList

8.254.2.2 uint8_t nas_RSRQThresh::RSRQThresListLen

8.255 nas_RSSIThresh Struct Reference

Data Fields

- uint8_t RSSIThresListLen
- int8_t * pRSSIThresList

8.255.1 Detailed Description

This sturcture contain RSSI threshold list.

Parameters

RSSIThresList-Len	• Length of the RSSI threshold list parameter to follow
pRSSIThresList	• RSSI in dBm(signed bytes) • A value of -125 dBm or lower is used to indicate No Signal • RSSI values have the following ranges (in dBm) – CDMA is -105 to -21 – HDR is -118 to -13 – GSM is -111 to -48 – WCDMA is -121 to 0 – LTE is -120 to 0 • Threshold values specified above are used for all RATs • The maximum number of threshold values is 16, each a signed byte value.

8.255.2 Field Documentation

8.255.2.1 int8_t* nas_RSSIThresh::pRSSIThresList

8.255.2.2 uint8_t nas_RSSIThresh::RSSIThresListLen

8.256 nas_rxInfo Struct Reference

Data Fields

- uint8_t isRadioTuned
- int32_t rxPower
- int32_t ecio
- int32_t rscp
- int32_t rsrp
- uint32_t phase

8.256.1 Detailed Description

This structure contains rx radio infomation.

Parameters

isRadioTuned	• Whether Rx is tuned to a channel: – 0x00 - Not tuned – 0x01 - Tuned – 0xFF - Not Available • If the radio is tuned, instantaneous values are set for the signal information fields below. • If the radio is not tuned, or is delayed or invalid, the values are set depending on each technology.
rx_pwr	• Rx power value in 1/10 dbm resolution.

ecio	• ECIO in 1/10 dB; valid for CDMA, HDR, GSM, WCDMA, and LTE.
rscp	• Received signal code power in 1/10 dbm. • Valid for WCDMA.
rsrp	• Current reference signal received power in 1/10 dbm valid for LTE.
phase	• Phase in 1/100 degrees; valid for LTE. • When the phase is unknown, 0xFFFFFFFF is used.

8.256.2 Field Documentation

8.256.2.1 int32_t nas_rxInfo::ecio

8.256.2.2 uint8_t nas_rxInfo::isRadioTuned

8.256.2.3 uint32_t nas_rxInfo::phase

8.256.2.4 int32_t nas_rxInfo::rscp

8.256.2.5 int32_t nas_rxInfo::rsrp

8.256.2.6 int32_t nas_rxInfo::rxPower

8.257 nas_RxSigInfo Struct Reference

Data Fields

- uint8_t rxChainIndex
- uint8_t isRadioTuned
- int32_t rxPower
- int32_t rsrp

8.257.1 Detailed Description

This structure contains the parameters for Rx Signal Info.

Parameters

rxChainIndex	• Rx antenna path • Valid Values – 0 - Primary Rx – 1 - Diversity Rx

isRadioTuned	• Rx path is tuned to a channel or Not • Values – 0x00 - Not tuned – 0x01 - Tuned

Note

If the radio is tuned, the instantaneous values are set for the fields below. If the radio is not tuned, the values set below may be invalid.

Parameters

rxPower	• Rx power value in 1/10 dBm resolution
rsrp	• Current reference signal received power in 1/10 dBm resolution

8.257.2 Field Documentation

8.257.2.1 uint8_t nas_RxSigInfo::isRadioTuned

8.257.2.2 int32_t nas_RxSigInfo::rsrp

8.257.2.3 uint8_t nas_RxSigInfo::rxChainIndex

8.257.2.4 int32_t nas_RxSigInfo::rxPower

8.258 nas_rxSignalStrengthListElement Struct Reference

Data Fields

- int16_t rxSignalStrength
- uint8_t radioIf

8.258.1 Detailed Description

This structure contains the Received Signal Strength Information

Parameters

rxSignalStrength	• Received signal strength in dBm – For CDMA and UMTS, this indicates forward link pilotEc. – For GSM, the received signal strength. – For LTE, this indicates the total received wideband power observed by UE.

radioIf	• Radio interface technology of the signal being radio_if measured – 0x00 – RADIO_IF_NO_SVC – None (no service) – 0x01 – RADIO_IF_CDMA_1X – cdma2000® 1X – 0x02 – RADIO_IF_CDMA_1XEVDO – cdma2000 HRPD (1xEV-DO) – 0x03 – RADIO_IF_AMPS – AMPS – 0x04 – RADIO_IF_GSM – GSM – 0x05 – RADIO_IF_UMTS – UMTS – 0x08 – RADIO_IF_LTE – LTE

Note

First elemnet of the RSSI list always contains the current Signal strength and Radio Interface.

8.258.2 Field Documentation

8.258.2.1 uint8_t nas_rxSignalStrengthListElement::radioIf

8.258.2.2 int16_t nas_rxSignalStrengthListElement::rxSignalStrength

8.259 nas_SccRxInfo Struct Reference

Data Fields

- int32_t rsrq
- int16_t snr
- uint8_t numInstances
- nas_RxSigInfo sigInfo [255]
- uint8_t TlvPresent

8.259.1 Detailed Description

This structure contains information about the SccRxInfo parameters.

Parameters

rsrq	• Current reference signal • Receive quality in 1/10 dB resolution
snr	• Reference signal signal-to-noise ratio in dB. • Range -10 to 30
numInstances	• Number of sets of the following – rxChainIndex – isRadioTuned – rxPower – rsrp

sigInfo	• See nas_RxSigInfo for more information
TlvPresent	• Tlv Present.

8.259.2 Field Documentation

8.259.2.1 uint8_t nas_SccRxInfo::numInstances

8.259.2.2 int32_t nas_SccRxInfo::rsrq

8.259.2.3 nas_RxSigInfo nas_SccRxInfo::sigInfo[255]

8.259.2.4 int16_t nas_SccRxInfo::snr

8.259.2.5 uint8_t nas_SccRxInfo::TlvPresent

8.260 nas_serviceProviderName Struct Reference

Data Fields

- uint8_t displayCondition
- uint8_t spnLength
- uint8_t spn [255]

8.260.1 Detailed Description

This structure contains service provider name.

Parameters

displayCondition	• Display condition.
spnLength	• It provides length of spn.
spn	• Service provider name string must use: The SMS default 7-bit coded alphabet as defined in 3GPP TS 23.038 with bit 8 set to 9.

8.260.2 Field Documentation

8.260.2.1 uint8_t nas_serviceProviderName::displayCondition

8.260.2.2 uint8_t nas_serviceProviderName::spn[255]

8.260.2.3 uint8_t nas_serviceProviderName::spnLength

8.261 nas_servSystem Struct Reference

Data Fields

- uint8_t regState
- uint8_t csAttachState
- uint8_t psAttachState
- uint8_t selNetwork
- uint8_t numRadioInterfaces
- uint8_t radioInterface [32]

8.261.1 Detailed Description

This structure contains the Serving System parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

regState	• Registration state - Registration state of the mobile • Values: – 0 - Not Registered; mobile is not currently searching for a new network to provide service – 1 - Registered with a network – 2 - Not registered, but mobile is currently searching for a new network to provide service – 3 - Registration denied by visible network – 4 - Registration state is unknown
csAttachState	• CS Attach State - Circuit-switched domain attach state of the mobile • Values: – 0 - Unknown or not applicable – 1 - Attached – 2 - Detached
psAttachState	• PS Attach State - Packet-switched domain attach state of the mobile • Values: – 0 - Unknown or not applicable – 1 - Attached – 2 - Detached
selNetwork	• Selected Network - Type of selected radio access network • Values: – 0 - Unknown – 1 - 3GPP2 network – 2 - 3GPP network
numRadio-Interfaces	• In Use Radio Interfaces Number – Number of radio interfaces currently in use – defaults to zero

radioInterface	• Radio Interface currently in use • Values: – 0x00 - RADIO_IF_NO_SVC - None(no service) – 0x01 - RADIO_IF_CDMA_1X - cdma2000 1X – 0x02 - RADIO_IF_CDMA_1XEVDO - cdma2000 HRPD (1xEV-DO) – 0x03 - RADIO_IF_AMPS - AMPS – 0x04 - RADIO_IF_GSM - GSM – 0x05 - RADIO_IF_UMTS - UMTS – 0x08 - RADIO_IF_LTE - LTE

8.261.2 Field Documentation

8.261.2.1 uint8_t nas_servSystem::csAttachState

8.261.2.2 uint8_t nas_servSystem::numRadioInterfaces

8.261.2.3 uint8_t nas_servSystem::psAttachState

8.261.2.4 uint8_t nas_servSystem::radioInterface[32]

8.261.2.5 uint8_t nas_servSystem::regState

8.261.2.6 uint8_t nas_servSystem::selNetwork

8.262 nas_sidNid Struct Reference

Data Fields

- uint16_t nid
- uint16_t sid

8.262.1 Detailed Description

This structure contains the parameters for SidNid Information

Parameters

nid	• Network ID
sid	• System ID

8.262.2 Field Documentation

8.262.2.1 uint16_t nas_sidNid::nid

8.262.2.2 uint16_t nas_sidNid::sid

8.263 nas_SignalStrengthTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- int8_t signalStrength
- uint32_t radioInterface

8.263.1 Detailed Description

This structure contains paramaters Signal Strength.

Parameters

TlvPresent	indicating the presence of the TLV in the QMI ind
signalStrength	signal strength
radioInterface	radio interface technology of the signal being measured

8.263.2 Field Documentation

8.263.2.1 uint32_t nas_SignalStrengthTlv::radioInterface

8.263.2.2 int8_t nas_SignalStrengthTlv::signalStrength

8.263.2.3 uint8_t nas_SignalStrengthTlv::TlvPresent

8.264 nas_SLQSSignalStrengthsIndReq Struct Reference

Data Fields

- uint8_t rxSignalStrengthDelta
- uint8_t ecioDelta
- uint8_t ioDelta
- uint8_t sinrDelta
- uint8_t rsrqDelta
- uint8_t ecioThresholdListLen
- int16_t ecioThresholdList [10]
- uint8_t sinrThresholdListLen
- uint8_t sinrThresholdList [5]
- uint16_t lteSnrDelta
- uint8_t lteRsrpDelta

8.264.1 Detailed Description

Structure for storing the input parameters passed for SLQSSetSignalStrengthsCallback by the user.

Parameters

rxSignal-StrengthDelta	• RSSI delta(in dBm) at which an event report indication, including the current RSSI, will be sent to the requesting control point.

ecioDelta	• ECIO delta at which an event report indication, ecioDelta including the current ECIO, will be sent to the requesting control point. • ECIO delta is an unsigned 1 byte value that increments in negative 0.5 dBm, e.g., ecio_delta of 2 means a change of -1 dBm.
ioDelta	• IO delta (in dBm) at which an event report indication, ioDelta including the current IO, will be sent to the requesting control point.
sinrDelta	• SINR delta level at which an event report indication, sinrDelta including the current SINR, will be sent to the requesting control point.
rsrqDelta	• RSRQ delta level at which an event report indication, including the current RSRQ, will be sent to the requesting control point.
ecioThreshold-ListLen	• Number of elements in the ECIO threshold list.
ecioThreshold-List	• A sequence of thresholds delimiting EcIo event reporting bands. Every time a new EcIo value crosses a threshold value, an event report indication message with the new ECIO value is sent to the requesting control point. For this field: – Maximum number of threshold values is 10 – At least one value must be specified.
sinrThreshold-ListLen	• Number of elements in the SINR threshold list.
sinrThreshold-List	• A sequence of thresholds delimiting SINR event reporting bands. Every time a new SINR value crosses a threshold value, an event report indication message with the new sinr value is sent to the requesting control point. For this field: – Maximum number of threshold values is 5 – At least one value must be specified.
ltesnrdelta	• LTE SNR delta level at which an event report indication, including the current SNR, will be sent to the requesting control point. LTE SNR delta level is an unsigned 2 byte value, representing the delta in units of 0.1 dB, e.g., lte_snr_delta of 3 means a change 0.3dB.
ltersrpdelta	-LTE RSRP delta level at which an event report -indication, including the current RSRP, will be sent -to the requesting control point. LTE RSRP delta -level is an unsigned 1 byte value, representing the -delta in dB.

8.264.2 Field Documentation

8.264.2.1 uint8_t nas_SLQSSignalStrengthsIndReq::ecioDelta

8.264.2.2 int16_t nas_SLQSSignalStrengthsIndReq::ecioThresholdList[10]

8.264.2.3 uint8_t nas_SLQSSignalStrengthsIndReq::ecioThresholdListLen

8.264.2.4 uint8_t nas_SLQSSignalStrengthsIndReq::ioDelta

8.264.2.5 uint8_t nas_SLQSSignalStrengthsIndReq::lteRsrpDelta

8.264.2.6 uint16_t nas_SLQSSignalStrengthsIndReq::lteSnrDelta

8.264.2.7 uint8_t nas_SLQSSignalStrengthsIndReq::rsrqDelta

8.264.2.8 uint8_t nas_SLQSSignalStrengthsIndReq::rxSignalStrengthDelta

8.264.2.9 uint8_t nas_SLQSSignalStrengthsIndReq::sinrDelta

8.264.2.10 uint8_t nas_SLQSSignalStrengthsIndReq::sinrThresholdList[5]

8.264.2.11 uint8_t nas_SLQSSignalStrengthsIndReq::sinrThresholdListLen

8.265 nas_SLQSSignalStrengthsInformation Struct Reference

Data Fields

- nas_rxSignalStrengthListElement rxSignalStrengthInfo
- nas_ecioListElement ecioInfo
- uint32_t io
- uint8_t sinr
- nas_errorRateListElement errorRateInfo
- nas_rsrqInformation rsrqInfo
- nas_lteSnrinformation lteSnrinfo
- nas_lteRsrpinformation lteRsrpinfo

8.265.1 Detailed Description

This structure contains paramaters signal strengths information.

Parameters

rxSignal-StrengthInfo	• signal strength info list • Bit to check in ParamPresenceMask - **19**
ecioInfo	• ecio info list • Bit to check in ParamPresenceMask - **20**
io	• received IO in dBm; IO is only applicable for 1xEV-DO • Bit to check in ParamPresenceMask - **21**
sinr	• SINR level • Bit to check in ParamPresenceMask - **22**

errorRateInfo	• error rate info • Bit to check in ParamPresenceMask - **23**
rsrqInfo	• rsrq info • Bit to check in ParamPresenceMask - **24**
lteSnrinfo	• lte Snr information • Bit to check in ParamPresenceMask - **25**
lteRsrpinfo	• lte rsrp info • Bit to check in ParamPresenceMask - **26**

8.265.2 Field Documentation

8.265.2.1 nas_ecioListElement nas_SLQSSignalStrengthsInformation::ecioInfo

8.265.2.2 nas_errorRateListElement nas_SLQSSignalStrengthsInformation::errorRateInfo

8.265.2.3 uint32_t nas_SLQSSignalStrengthsInformation::io

8.265.2.4 nas_lteRsrpinformation nas_SLQSSignalStrengthsInformation::lteRsrpinfo

8.265.2.5 nas_lteSnrinformation nas_SLQSSignalStrengthsInformation::lteSnrinfo

8.265.2.6 nas_rsrqInformation nas_SLQSSignalStrengthsInformation::rsrqInfo

8.265.2.7 nas_rxSignalStrengthListElement nas_SLQSSignalStrengthsInformation::rxSignalStrengthInfo

8.265.2.8 uint8_t nas_SLQSSignalStrengthsInformation::sinr

8.266 nas_SLQSSignalStrengthsTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- nas_SLQSSignalStrengthsInformation sSLQSSignalStrengthsInfo

8.266.1 Detailed Description

This structure contains paramaters SLQS Signal Strength.

Parameters

TlvPresent	indicating the presence of the TLV in the QMI ind
sSLQSSignal-StrengthsInfo	signal strength info

8.266.2 Field Documentation

8.266.2.1 nas_SLQSSignalStrengthsInformation nas_SLQSSignalStrengthsTlv::sSLQSSignalStrengthsInfo

8.266.2.2 uint8_t nas_SLQSSignalStrengthsTlv::TlvPresent

8.267 nas_SrvDomainPrefTlv Struct Reference

Data Fields

- uint32_t SrvDomainPref
- uint8_t TlvPresent

8.267.1 Detailed Description

Contain the Service domain Preference for system selection preferences.

Parameters

SrvDomainPref	• Parameter indicating Service domain preference • Values: – 0x00 - Circuit switched only – 0x01 - Packet switched only – 0x02 - Circuit switched and packet switched – 0x03 - Packet switched attach – 0x04 - Packet switched detach
TlvPresent	• Tlv Present

8.267.2 Field Documentation

8.267.2.1 uint32_t nas_SrvDomainPrefTlv::SrvDomainPref

8.267.2.2 uint8_t nas_SrvDomainPrefTlv::TlvPresent

8.268 nas_SrvStatusInfo Struct Reference

Data Fields

- uint8_t srvStatus
- uint8_t isPrefDataPath

8.268.1 Detailed Description

Structure for storing the service status information for CDMA and HDR networks.

Parameters

srvStatus	• Service status of the system. – 0x00 - No service – 0x01 - Limited service – 0x02 - Service – 0x03 - Limited regional service – 0x04 - Power save – 0xFF - Not Available
isPrefDataPath	• Whether the RAT is the preferred data path. – 0x00 - Not preferred – 0x01 - Preferred – 0xFF - Not Available

8.268.2 Field Documentation

8.268.2.1 uint8_t nas_SrvStatusInfo::isPrefDataPath

8.268.2.2 uint8_t nas_SrvStatusInfo::srvStatus

8.269 nas_sysInfoCommon Struct Reference

Data Fields

- uint8_t srvDomainValid
- uint8_t srvDomain
- uint8_t srvCapabilityValid
- uint8_t srvCapability
- uint8_t roamStatusValid
- uint8_t roamStatus
- uint8_t isSysForbiddenValid
- uint8_t isSysForbidden

8.269.1 Detailed Description

Structure for storing the System Information common to CDMA, HDR, GSM, WCDMA and LTE networks.

Parameters

srvDomainValid	• Indicates whether the service domain is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available

srvDomain	• Service domain registered on the system. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - Camped – 0xFF - Not Available
srvCapability-Valid	• Indicates whether the service capability is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
srvCapability	• Current system's service capability. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - Camped – 0xFF - Not Available
roamStatusValid	• Indicates whether the roaming status is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available

roamStatus	• Current roaming status. – 0x00 - Off – 0x01 - On – 0x02 - Blinking – 0x03 - Out of the neighborhood – 0x04 - Out of the building – 0x05 - Preferred system – 0x06 - Available system – 0x07 - Alliance partner – 0x08 - Premium partner – 0x09 - Full service – 0x0A - Partial service – 0x0B - Banner is on – 0x0C - Banner is off – 0x0D to 0x3F - Reserved for Standard Enhanced Roaming Indicator Numbers – 0x40 to 0x7F - Reserved for Non-Standard Enhanced Roaming Indicator Numbers – 0x40 to 0xFF - Reserved. – 0xFF - Not Available • Values from 0x02 onward are only applicable for 3GPP2
isSysForbidden-Valid	• Indicates whether the forbidden system is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
isSysForbidden	• Whether the system is forbidden. – 0x00 - Not forbidden – 0x01 - Forbidden – 0xFF - Not Available

8.269.2 Field Documentation

8.269.2.1 uint8_t nas_sysInfoCommon::isSysForbidden

8.269.2.2 uint8_t nas_sysInfoCommon::isSysForbiddenValid

8.269.2.3 uint8_t nas_sysInfoCommon::roamStatus

8.269.2.4 uint8_t nas_sysInfoCommon::roamStatusValid

8.269.2.5 uint8_t nas_sysInfoCommon::srvCapability

8.269.2.6 uint8_t nas_sysInfoCommon::srvCapabilityValid

8.269.2.7 uint8_t nas_sysInfoCommon::srvDomain

8.269.2.8 uint8_t nas_sysInfoCommon::srvDomainValid

8.270 nas_TDSCDMAECIOThresh Struct Reference

Data Fields

- uint8_t TDSCDMAECIOThreshListLen
- float * pTDSCDMAECIOThreshList

8.270.1 Detailed Description

This structure contains TDSCDMA ECIO threshold related parameters.

Parameters

TDSCDMAECIOThreshListLen	• Length of the TDSCDMA ECIO threshold list parameter to follow
pTDSCDMAECIOThreshList	• Array of ECIO thresholds (in dB) used by TD-SCDMA • Maximum of 32 values.

8.270.2 Field Documentation

8.270.2.1 float* nas_TDSCDMAECIOThresh::pTDSCDMAECIOThreshList

8.270.2.2 uint8_t nas_TDSCDMAECIOThresh::TDSCDMAECIOThreshListLen

8.271 nas_TDSCDMARSCPThresh Struct Reference

Data Fields

- uint8_t TDSCDMARSCPThreshListLen
- int16_t * pTDSCDMARSCPThreshList

8.271.1 Detailed Description

This structure contains TDSCDMA RSCP threshold related parameters.

Parameters

TDSCDMARSCPThreshListLen	• Length of the TDSCDMA RSCP threshold list parameter to follow
pTDSCDMARSCPThreshList	• Array of RSCP thresholds (in units of 0.1 dBm) • Maximum of 32 values • Range for RSCP values: -120 to -25 (in dBm).

8.271.2 Field Documentation

8.271.2.1 int16_t* nas_TDSCDMARSCPThresh::pTDSCDMARSCPThreshList

8.271.2.2 uint8_t nas_TDSCDMARSCPThresh::TDSCDMARSCPThreshListLen

8.272 nas_TDSCDMARSSIThresh Struct Reference

Data Fields

- uint8_t TDSCDMARSSIThreshListLen
- float * pTDSCDMARSSIThreshList

8.272.1 Detailed Description

This structure contains TDSCDMA RSSI threshold related parameters.

Parameters

TDSCDMARSSIThreshListLen	• Length of the TDSCDMA RSSI threshold list parameter to follow
pTDSCDMARSSIThreshList	• Array of RSSI thresholds (in dBm) used by TD-SCDMA • Maximum of 32 values.

8.272.2 Field Documentation

8.272.2.1 float* nas_TDSCDMARSSIThresh::pTDSCDMARSSIThreshList

8.272.2.2 uint8_t nas_TDSCDMARSSIThresh::TDSCDMARSSIThreshListLen

8.273 nas_TDSCDMASINRCONFThresh Struct Reference

Data Fields

- uint8_t TDSCDMASINRCONFThreshListLen
- float * pTDSCDMASINRCONFThreshList

8.273.1 Detailed Description

This structure contains TDSCDMA SINR threshold list.

Parameters

TDSCDMASINRCONFThreshListLen	• Length of the TDSCDMA SINR threshold list parameter to follow
pTDSCDMASINRCONFThreshList	• Array of SINR thresholds (in dB) used by TD-SCDMA • Maximum of 32 values

8.273.2 Field Documentation

8.273.2.1 float* nas_TDSCDMASINRCONFThresh::pTDSCDMASINRCONFThreshList

8.273.2.2 uint8_t nas_TDSCDMASINRCONFThresh::TDSCDMASINRCONFThreshListLen

8.274 nas_TDSCDMASINRThresh Struct Reference

Data Fields

- uint8_t TDSCDMASINRThreshListLen
- float * pTDSCDMASINRThreshList

8.274.1 Detailed Description

This structure contains TDSCDMA SINR threshold related parameters.

Parameters

TDSCDMASINRThreshListLen	• Length of the TDSCDMA SINR threshold list parameter to follow
pTDSCDMASINRThreshList	• Array of SINR thresholds (in dB) used by TD-SCDMA • Maximum of 32 values

8.274.2 Field Documentation

8.274.2.1 float* nas_TDSCDMASINRThresh::pTDSCDMASINRThreshList

8.274.2.2 uint8_t nas_TDSCDMASINRThresh::TDSCDMASINRThreshListLen

8.275 nas_timeInfo Struct Reference

Data Fields

- uint16_t year
- uint8_t month
- uint8_t day
- uint8_t hour
- uint8_t minute
- uint8_t second
- uint8_t dayOfWeek
- int8_t timeZone
- uint8_t dayLtSavingAdj
- uint8_t radioInterface
- uint8_t TlvPresent

8.275.1 Detailed Description

This structure contains the parameters for Network Time.

Parameters

year	• Year
month	• Month • 1 is January and 12 is December
day	• Day • Range - 1 to 31
hour	• Hour • Range - 0 to 59
minute	• Minute • Range - 0 to 59
second	• Second • Range - 0 to 59
dayOfWeek	• Day of the week • 0 is Monday and 6 is Sunday
timeZone	• Offset from Universal time • The difference between local time and Universal time, in increments of 15 min • Signed Value
dayLtSavingAdj	• Daylight saving adjustment in hours • Possible values - 0, 1, and 2. • This field is ignored if radio_if is NAS_RADIO_IF_CDMA_1XEVDO
radioInterface	• Radio interface from which the information comes • Values – 0x01 - NAS_RADIO_IF_CDMA_1X - cdma2000 1X – 0x02 - NAS_RADIO_IF_CDMA_1XEVDO - cdma2000 HRPD (1xEV-DO) – 0x04 - NAS_RADIO_IF_GSM - GSM – 0x05 - NAS_RADIO_IF_UMTS - UMTS – 0x08 - NAS_RADIO_IF_LTE - LTE – 0x09 - NAS_RADIO_IF_TDSCDMA -TD-SCDMA
TlvPresent	• Tlv Present.

8.275.2 Field Documentation

8.275.2.1 uint8_t nas_timeInfo::day

8.275.2.2 uint8_t nas_timeInfo::dayLtSavingAdj

8.275.2.3 uint8_t nas_timeInfo::dayOfWeek

8.275.2.4 uint8_t nas_timeInfo::hour

8.275.2.5 uint8_t nas_timeInfo::minute

8.275.2.6 uint8_t nas_timeInfo::month

8.275.2.7 uint8_t nas_timeInfo::radioInterface

8.275.2.8 uint8_t nas_timeInfo::second

8.275.2.9 int8_t nas_timeInfo::timeZone

8.275.2.10 uint8_t nas_timeInfo::TlvPresent

8.275.2.11 uint16_t nas_timeInfo::year

8.276 nas_trueIMSI Struct Reference

Data Fields

- uint8_t mccT [3]
- uint16_t imsiT1112
- uint8_t imsiTS1 [7]
- uint8_t imsiTS2 [3]
- uint8_t imsiTaddrNum

8.276.1 Detailed Description

This structure contains True IMSI.

Parameters

mccT	• ASCII character representation of MCC_T
imsiT1112	• ASCII character representation of IMSI_T_11_12 value – 0xFFFF - Not Available
imsiTS1	• ASCII character representation of IMSI_T_S1 value
imsiTS2	• ASCII character representation of IMSI_T_S2 value

imsiTaddrNum	• Value of IMSI_T_ADDR_NUM – 0xFF - Not Available

8.276.2 Field Documentation

8.276.2.1 uint16_t nas_truelMSI::imsiT1112

8.276.2.2 uint8_t nas_truelMSI::imsiTaddrNum

8.276.2.3 uint8_t nas_truelMSI::imsiTS1[7]

8.276.2.4 uint8_t nas_truelMSI::imsiTS2[3]

8.276.2.5 uint8_t nas_truelMSI::mccT[3]

8.277 nas_txInfo Struct Reference

Data Fields

- uint8_t isInTraffic
- int32_t txPower

8.277.1 Detailed Description

This structure contains tx radio infomation.

Parameters

isInTraffic	• Whether the device is in traffic. – 0x00 - not in traffic – 0x01 - in traffic • The txPower field is only meaningful when in the device is in traffic.
txPower	• Tx power value in 1/10 dbm.

8.277.2 Field Documentation

8.277.2.1 uint8_t nas_txInfo::isInTraffic

8.277.2.2 int32_t nas_txInfo::txPower

8.278 nas_UMTSInfo Struct Reference

Data Fields

- uint16_t cellID

- uint8_t plmn [3]
- uint16_t lac
- uint16_t uarfcn
- uint16_t psc
- int16_t rscp
- int16_t ecio
- uint8_t umtsInst
- nas_UMTSinstInfo UMTSInstInfo [255]
- uint8_t geranInst
- nas_geranInstInfo GeranInstInfo [255]

8.278.1 Detailed Description

This structure contains information about the UMTS Network.

Parameters

cellID	• Cell ID. • 0xFFFFFFFF indicates cell ID information is not present.
plmn[NAS_PLMN_LENGTH]	• MCC/MNC information coded as octet 3, 4, and 5. • This field is ignored when nmrCellID is not present.
lac	• Location area code. • This field is ignored when nmrCellID is not present. – 0xFFFF - Not Available
uarfcn	• UTRA absolute RF channel number. – 0xFFFF - Not Available
psc	• Primary scrambling code. – 0xFFFF - Not Available
rscp	• Received signal code power. – 0xFFFF - Not Available
ecio	• ECIO(Signal-to-Interference-ratio). – 0xFFFF - Not Available
umtsInst	• Provides the number of set of UMTS info instances. • If 0(zero), then no information follows it.
UMTSInstInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_UMTSinstInfo for more information.

geranInst	• Provides the number of set of GERAN info instances. • If 0(zero), then no information follows it.
GeranInstInfo[NAS_MAX_DESCRIPTION_LENGTH]	• See nas_geranInstInfo for more information.

8.278.2 Field Documentation

8.278.2.1 uint16_t nas_UMTSInfo::cellID

8.278.2.2 int16_t nas_UMTSInfo::ecio

8.278.2.3 uint8_t nas_UMTSInfo::geranInst

8.278.2.4 nas_geranInstInfo nas_UMTSInfo::GeranInstInfo[255]

8.278.2.5 uint16_t nas_UMTSInfo::lac

8.278.2.6 uint8_t nas_UMTSInfo::plmn[3]

8.278.2.7 uint16_t nas_UMTSInfo::psc

8.278.2.8 int16_t nas_UMTSInfo::rscp

8.278.2.9 uint16_t nas_UMTSInfo::uarfcn

8.278.2.10 uint8_t nas_UMTSInfo::umtsInst

8.278.2.11 nas_UMTSinstInfo nas_UMTSInfo::UMTSInstInfo[255]

8.279 nas_UMTSinstInfo Struct Reference

Data Fields

- uint16_t umtsUarfcn
- uint16_t umtsPsc
- int16_t umtsRscp
- int16_t umtsEcio

8.279.1 Detailed Description

This structure contains information about the UMTS Instances in UMTS Network.

Parameters

umtsUarfcn	• UTRA absolute RF channel number.
umtsPsc	• Primary scrambling code.

umtsRscp	• Received signal code power.
umtsEcio	• ECIO(Signal-to-Interference-ratio).

8.279.2 Field Documentation

8.279.2.1 int16_t nas_UMTSinstInfo::umtsEcio

8.279.2.2 uint16_t nas_UMTSinstInfo::umtsPsc

8.279.2.3 int16_t nas_UMTSinstInfo::umtsRscp

8.279.2.4 uint16_t nas_UMTSinstInfo::umtsUarfcn

8.280 nas_umtsLTENbrCell Struct Reference

Data Fields

- uint16_t earfcn
- uint16_t pci
- uint32_t rsrp
- uint32_t rsrq
- int16_t srxlev
- uint8_t cellIsTDD

8.280.1 Detailed Description

This structure contains information about the UMTS LTE neighbour Cell.

Parameters

earfcn	• E-UTRA absolute RF channel number of the detected cell.
pci	• Physical cell ID of the detected cell. • Range is defined in 3GPP TS 36.211
rsrp	• Current received signal strength indication (in dBm) of the detected cell.
rsrq	• Current reference signal received quality (in dB) of the detected cell.
srxlev	• Cell selection Rx level (Srxlev) value of the detected cell in linear scale. • This field is only valid when wcdma_rrc_state is not NAS_WCDMA_RRC_STATE_CEL_FACH or NAS_WCDMA_RRC_STATE_CELL_DCH.

cellIsTDD	• TRUE if the cell is TDD; FALSE if the cell is FDD.

8.280.2 Field Documentation

8.280.2.1 uint8_t nas_umtsLTENbrCell::cellIsTDD

8.280.2.2 uint16_t nas_umtsLTENbrCell::earfcn

8.280.2.3 uint16_t nas_umtsLTENbrCell::pci

8.280.2.4 uint32_t nas_umtsLTENbrCell::rsrp

8.280.2.5 uint32_t nas_umtsLTENbrCell::rsrq

8.280.2.6 int16_t nas_umtsLTENbrCell::srxlev

8.281 nas_UniversalTime Struct Reference

Data Fields

- uint16_t year
- uint8_t month
- uint8_t day
- uint8_t hour
- uint8_t minute
- uint8_t second
- uint8_t dayOfWeek

8.281.1 Detailed Description

This structure contains the parameters for Universal Time Information.

Parameters

year	• Year.
month	• Month. – 1 is January and 12 is December.
day	• Day. – Range 1 to 31.
hour	• Hour. – Range 0 to 59.

minute	• Minute. – Range 0 to 59.
second	• Second. – Range 0 to 59.
dayOfWeek	• Day of the Week. – 0 is Monday and 6 is Sunday.

8.281.2 Field Documentation

8.281.2.1 uint8_t nas_UniversalTime::day

8.281.2.2 uint8_t nas_UniversalTime::dayOfWeek

8.281.2.3 uint8_t nas_UniversalTime::hour

8.281.2.4 uint8_t nas_UniversalTime::minute

8.281.2.5 uint8_t nas_UniversalTime::month

8.281.2.6 uint8_t nas_UniversalTime::second

8.281.2.7 uint16_t nas_UniversalTime::year

8.282 nas_wcdmaCellInfo Struct Reference

Data Fields

- uint16_t psc
- int16_t cpich_rscp
- int16_t cpich_ecno
- int16_t srxlev

8.282.1 Detailed Description

This structure contains information about the WCDMA Cell.

Parameters

psc	• Primary scrambling code. • Range: 0 to 511.
cpich_rscp	• Absolute power level (in 1/10 dBm) of the common pilot channel as received by the UE. • Range: -120.0 dBm to -25.0 dBm

cpich_ecno	• CPICH Ec/No; ratio (in 1/10 dB) of the received energy per PN chip for the CPICH to the total received power spectral density at the UE antenna connector. • Range: -50.0 dB to 0.
srxlev	• Cell selection Rx level (Srxlev) value. • Range: -128 to 128. • This field is only valid when ue_in_idle is TRUE.

8.282.2 Field Documentation

8.282.2.1 int16_t nas_wcdmaCellInfo::cpich_ecno

8.282.2.2 int16_t nas_wcdmaCellInfo::cpich_rscp

8.282.2.3 uint16_t nas_wcdmaCellInfo::psc

8.282.2.4 int16_t nas_wcdmaCellInfo::srxlev

8.283 nas_WCDMAECIOThresh Struct Reference

Data Fields

- uint8_t WCDMAECIOThreshListLen
- int16_t * pWCDMAECIOThreshList

8.283.1 Detailed Description

This structure contains WCDMA ECIO threshold related parameters.

Parameters

WCDMAECIO-ThreshListLen	• Length of the WCDMA ECIO threshold list parameter to follow
pWCDMAECIO-ThreshList	• Array of ECIO thresholds (in units of 0.1 dB) • Maximum of 32 values • Range for ECIO values: -31.5 to 0 (in dB)

8.283.2 Field Documentation

8.283.2.1 int16_t* nas_WCDMAECIOThresh::pWCDMAECIOThreshList

8.283.2.2 uint8_t nas_WCDMAECIOThresh::WCDMAECIOThreshListLen

8.284 nas_WCDMAInfoLTENeighborCell Struct Reference

Data Fields

- uint32_t wcdmaRRCState
- uint8_t umtsLTENbrCellLen
- nas_umtsLTENbrCell UMTSLTENbrCell [255]

8.284.1 Detailed Description

This structure contains information about the WCDMA - LTE Neighboring Cell Info Set.

Parameters

wcdmaRRC-State	• WCDMA RRC states. • Defined in 3GPP TS 25.331 • Values: – 0x00 - NAS_WCDMA_RRC_STATE_DISCONNECTED ∗ WCDMA RRC State is IDLE – 0x01 - NAS_WCDMA_RRC_STATE_CELL_PCH ∗ WCDMA RRC state is CELL_PCH – 0x02 - NAS_WCDMA_RRC_STATE_URA_PCH ∗ WCDMA RRC state is URA_PCH – 0x03 - NAS_WCDMA_RRC_STATE_CELL_FACH ∗ WCDMA RRC state is CELL_FACH – 0x04 - NAS_WCDMA_RRC_STATE_CELL_DCH ∗ WCDMA RRC state is CELL_DCH
umtsLTENbr-CellLen	• Number of sets of UMTS LTE Neighbors.
UMTSLTENbr-Cell	• See nas_umtsLTENbrCell for more information.

8.284.2 Field Documentation

8.284.2.1 nas_umtsLTENbrCell nas_WCDMAInfoLTENeighborCell::UMTSLTENbrCell[255]

8.284.2.2 uint8_t nas_WCDMAInfoLTENeighborCell::umtsLTENbrCellLen

8.284.2.3 uint32_t nas_WCDMAInfoLTENeighborCell::wcdmaRRCState

8.285 nas_WCDMARSSIThresh Struct Reference

Data Fields

- uint8_t WCDMARSSIThreshListLen
- int16_t ∗ pWCDMARSSIThreshList

8.285.1 Detailed Description

This structure contains WCDMA RSSI threshold related parameters.

Parameters

WCDMARSSI-ThreshListLen	• Length of the WCDMA RSSI threshold list parameter to follow
pWCDMARSSI-ThreshList	• Array of RSSI thresholds (in units of 0.1 dBm) • Maximum of 32 values. • Range for RSSI values: -121 to 0 (in dBm)

8.285.2 Field Documentation

8.285.2.1 int16_t* nas_WCDMARSSIThresh::pWCDMARSSIThreshList

8.285.2.2 uint8_t nas_WCDMARSSIThresh::WCDMARSSIThreshListLen

8.286 nas_WCDMASysInfo Struct Reference

Data Fields

- nas_sysInfoCommon sysInfoWCDMA
- uint8_t lacValid
- uint16_t lac
- uint8_t cellIdValid
- uint32_t cellId
- uint8_t regRejectInfoValid
- uint8_t rejectSrvDomain
- uint8_t rejCause
- uint8_t networkIdValid
- uint8_t MCC [3]
- uint8_t MNC [3]
- uint8_t hsCallStatusValid
- uint8_t hsCallStatus
- uint8_t hsIndValid
- uint8_t hsInd
- uint8_t pscValid
- uint16_t psc

8.286.1 Detailed Description

Structure for storing the WCDMA System Information.

Parameters

sysInfoWCDMA	• See nas_sysInfoCommon for more information.
lacValid	• Indicates whether the location area code is valid.. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available

lac	• Location area code. • Only applies to 3GPP. – 0xFFFF - Not Available
cellIdValid	• Indicates whether the cell ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
cellId	• Cell ID. – 0xFFFFFFFF - Not Available
regRejectInfo-Valid	• Indicates whether the registration reject information is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
rejectSrvDomain	• Type of service domain in which the registration is rejected. – 0x00 - SYS_SRV_DOMAIN_NO_SRV - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched – 0x04 - Camped – 0xFF - Not Available
rejCause	• Reject cause values sent are specified in [3GPP TS 24.008, Section 10.5.3.6]. – 0xFF - Not Available
networkIdValid	• Indicates whether the network ID is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
MCC[NAS_PLM-N_LENGTH]	• Mobile Country Code. • MCC digits in ASCII characters
MNC[NAS_PLM-N_LENGTH]	• Mobile Network Code. • MNC digits in ASCII characters • An unused byte is set to 0xFF. • In case of two-digit MNC values, the third (unused) digit is set to 0xFF. For example, 15 (a two-digit MNC) is reported using the byte stream 0x31 0x35 0xFF.

hsCallStatus-Valid	• Indicates whether the high-speed call status is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
hsCallStatus	• Call status on high speed. • Only applicable for WCDMA. – 0x00 - HSDPA and HSUPA are unsupported – 0x01 - HSDPA is supported – 0x02 - HSUPA is supported – 0x03 - HSDPA and HSUPA are supported – 0x04 - HSDPA+ is supported – 0x05 - HSDPA+ and HSUPA are supported – 0x06 - Dual-cell HSDPA+ is supported – 0x07 - Dual-cell HSDPA+ and HSUPA are supported – 0xFF - Not Available
hsIndValid	• Indicates whether high-speed service indication is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
hsInd	• High-speed service indication • Only applicable for WCDMA. – 0x00 - HSDPA and HSUPA are unsupported – 0x01 - HSDPA is supported – 0x02 - HSUPA is supported – 0x03 - HSDPA and HSUPA are supported – 0x04 - HSDPA+ is supported – 0x05 - HSDPA+ and HSUPA are supported – 0x06 - Dual-cell HSDPA+ is supported – 0x07 - Dual-cell HSDPA+ and HSUPA are supported – 0xFF - Not Available
pscValid	• Indicates whether primary scrambling code is valid. – 0x00 - Invalid – 0x01 - Valid – 0xFF - Not Available
psc	• Primary scrambling code. – 0xFFFF - Not Available

8.286.2 Field Documentation

8.286.2.1 uint32_t nas_WCDMASysInfo::cellId

8.286.2.2 uint8_t nas_WCDMASysInfo::cellIdValid

8.286.2.3 uint8_t nas_WCDMASysInfo::hsCallStatus

8.286.2.4 uint8_t nas_WCDMASysInfo::hsCallStatusValid

8.286.2.5 uint8_t nas_WCDMASysInfo::hsInd

8.286.2.6 uint8_t nas_WCDMASysInfo::hsIndValid

8.286.2.7 uint16_t nas_WCDMASysInfo::lac

8.286.2.8 uint8_t nas_WCDMASysInfo::lacValid

8.286.2.9 uint8_t nas_WCDMASysInfo::MCC[3]

8.286.2.10 uint8_t nas_WCDMASysInfo::MNC[3]

8.286.2.11 uint8_t nas_WCDMASysInfo::networkIdValid

8.286.2.12 uint16_t nas_WCDMASysInfo::psc

8.286.2.13 uint8_t nas_WCDMASysInfo::pscValid

8.286.2.14 uint8_t nas_WCDMASysInfo::regRejectInfoValid

8.286.2.15 uint8_t nas_WCDMASysInfo::rejCause

8.286.2.16 uint8_t nas_WCDMASysInfo::rejectSrvDomain

8.286.2.17 nas_sysInfoCommon nas_WCDMASysInfo::sysInfoWCDMA

8.287 nas_wcdmaUARFCN Struct Reference

Data Fields

- uint8_t status
- uint32_t uarfcn

8.287.1 Detailed Description

This structure contains WCDMA UARFCN infromation.

Parameters

status	• 0 - Disable • 1 - Enable
uarfcn	• UARFCN to which UE is locked

8.287.2 Field Documentation

8.287.2.1 uint8_t nas_wcdmaUARFCN::status

8.287.2.2 uint32_t nas_wcdmaUARFCN::uarfcn

8.288 NASAcqOrderPrefTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t AcqOrderLen
- uint8_t AcqOrderPref [255]

8.288.1 Detailed Description

Structure used to store acquisition order preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
AcqOrderPref	- Acquisition order Preference Value

8.288.2 Field Documentation

8.288.2.1 uint8_t NASAcqOrderPrefTlv::AcqOrderLen

8.288.2.2 uint8_t NASAcqOrderPrefTlv::AcqOrderPref[255]

8.288.2.3 uint8_t NASAcqOrderPrefTlv::TlvPresent

8.289 NASBandPreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t band_pref

8.289.1 Detailed Description

Structure used to store all Band Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
band_pref	- Roaming Indication Value

8.289.2 Field Documentation

8.289.2.1 uint64_t NASBandPreferenceTlv::band_pref

8.289.2.2 uint8_t NASBandPreferenceTlv::TlvPresent

8.290 NASCiotAcqOrderPrefTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t CiotAcqOrderLen
- uint32_t CiotAcqOrderPref [255]

8.290.1 Detailed Description

Structure used to store CIOT acquisition order preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
CiotAcqOrder-Pref	- CIOT Acquisition order Preference Value

8.290.2 Field Documentation

8.290.2.1 uint8_t NASCiotAcqOrderPrefTlv::CiotAcqOrderLen

8.290.2.2 uint32_t NASCiotAcqOrderPrefTlv::CiotAcqOrderPref[255]

8.290.2.3 uint8_t NASCiotAcqOrderPrefTlv::TlvPresent

8.291 NASCiotLteOpModePrefTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t CiotLteOpModePref

8.291.1 Detailed Description

Structure used to store CIOT LTE Operational Mode Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
CiotLteOpMode-Pref	- Bitmask representing the CIoT LTE operational mode preference

8.291.2 Field Documentation

8.291.2.1 uint64_t NASCiotLteOpModePrefTlv::CiotLteOpModePref

8.291.2.2 uint8_t NASCiotLteOpModePrefTlv::TlvPresent

8.292 NASEmergencyModeTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t EmerMode

8.292.1 Detailed Description

Structure used to store Emergency Mode TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
EmerMode	- Emergency Mode Value

8.292.2 Field Documentation

8.292.2.1 uint8_t NASEmergencyModeTlv::EmerMode

8.292.2.2 uint8_t NASEmergencyModeTlv::TlvPresent

8.293 NasGetLTECphyCaInfo Struct Reference

Data Fields

- NASPhyCaAggSCellIndType PhyCaAggSCellIndType
- NASPhyCaAggSCellDlBw PhyCaAggSCellDlBw
- NASPhyCaAggSCellInfo PhyCaAggSCellInfo
- NASPhyCaAggPCellInfo PhyCaAggPCellInfo
- NASPhyCaAggSCellIndex PhyCaAggSCellIndex

8.293.1 Detailed Description

This structure contains the parameters for aggregation event information.

Parameters

PhyCaAggSCell-IndType	• see NASPhyCaAggSCellIndType • Bit to check in ParamPresenceMask - **16**
PhyCaAggSCell-DlBw	• see NASPhyCaAggSCellDlBw • Bit to check in ParamPresenceMask - **17**
PhyCaAggSCell-Info	• see NASPhyCaAggSCellInfo • Bit to check in ParamPresenceMask - **18**
PhyCaAggPcell-Info	• see NASPhyCaAggPCellInfo • Bit to check in ParamPresenceMask - **19**

PhyCaAggScell-Index	• see NASPhyCaAggScellIndex • Bit to check in ParamPresenceMask - **20**

8.293.2 Field Documentation

8.293.2.1 NASPhyCaAggPcellInfo NasGetLTECphyCaInfo::PhyCaAggPcellInfo

8.293.2.2 NASPhyCaAggScellDlBw NasGetLTECphyCaInfo::PhyCaAggScellDlBw

8.293.2.3 NASPhyCaAggScellIndex NasGetLTECphyCaInfo::PhyCaAggScellIndex

8.293.2.4 NASPhyCaAggScellIndType NasGetLTECphyCaInfo::PhyCaAggScellIndType

8.293.2.5 NASPhyCaAggScellInfo NasGetLTECphyCaInfo::PhyCaAggScellInfo

8.294 NASGWAcqOrderPrefTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t GWAcqOrderPref

8.294.1 Detailed Description

Structure used to store GSM/WCDMA acquisition order preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
GWAcqOrder-Pref	- GSM/WCDMA acquisition order Preference Value

8.294.2 Field Documentation

8.294.2.1 uint32_t NASGWAcqOrderPrefTlv::GWAcqOrderPref

8.294.2.2 uint8_t NASGWAcqOrderPrefTlv::TlvPresent

8.295 NASLTEBandPreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t LTEBandPref

8.295.1 Detailed Description

Structure used to store LTE Band Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
LTEBandPref	- LTE Band Preference Value

8.295.2 Field Documentation

8.295.2.1 uint64_t NASLTEBandPreferenceTlv::LTEBandPref

8.295.2.2 uint8_t NASLTEBandPreferenceTlv::TlvPresent

8.296 NASLteM1BandPrefTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t LteM1BandPref

8.296.1 Detailed Description

Purpose: Structure used to store LTE M1 Band Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
LteM1BandPref	- Bitmask representing the LTE M1 band preference

8.296.2 Field Documentation

8.296.2.1 uint64_t NASLteM1BandPrefTlv::LteM1BandPref

8.296.2.2 uint8_t NASLteM1BandPrefTlv::TlvPresent

8.297 NASLteNasReleaseInfoTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t nas_release
- uint8_t nas_major
- uint8_t nas_minor

8.297.1 Detailed Description

This structure contains LTE Nas Release Infomation

Parameters

Tlvresult	• unpack result
nas_release	• LTE NAS release

nas_major	• LTE NAS version major
nas_minor	• LTE NAS version minor

8.297.2 Field Documentation

8.297.2.1 uint8_t NASLteNasReleaseInfoTlv::nas_major

8.297.2.2 uint8_t NASLteNasReleaseInfoTlv::nas_minor

8.297.2.3 uint8_t NASLteNasReleaseInfoTlv::nas_release

8.297.2.4 uint8_t NASLteNasReleaseInfoTlv::TlvPresent

8.298 NASLteNB1BandPrefTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t LteNB1BandPref

8.298.1 Detailed Description

Structure used to store LTE NB1 Band Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
LteNB1BandPref	- Bitmask representing the LTE NB1 band preference

8.298.2 Field Documentation

8.298.2.1 uint64_t NASLteNB1BandPrefTlv::LteNB1BandPref

8.298.2.2 uint8_t NASLteNB1BandPrefTlv::TlvPresent

8.299 NASModePreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t ModePref

8.299.1 Detailed Description

Structure used to store Mode Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
ModePref	- Mode Preference Value

8.299.2 Field Documentation

8.299.2.1 uint16_t NASModePreferenceTlv::ModePref

8.299.2.2 uint8_t NASModePreferenceTlv::TlvPresent

8.300 NASNetSelPreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t NetSelPref

8.300.1 Detailed Description

Structure used to store Network Selection Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
NetSelPref	- Network Selection Preference Value

8.300.2 Field Documentation

8.300.2.1 uint8_t NASNetSelPreferenceTlv::NetSelPref

8.300.2.2 uint8_t NASNetSelPreferenceTlv::TlvPresent

8.301 NASNr5gBandPrefTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t Nr5gBandPrefbits1_64
- uint64_t Nr5gBandPrefbits_65_128
- uint64_t Nr5gBandPrefbits_129_192
- uint64_t Nr5gBandPrefbits_193_256

8.301.1 Detailed Description

Structure used to store NR5G Band Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
Nr5gBandPref	- NR5G Band Preference

8.301.2 Field Documentation

8.301.2.1 uint64_t NASNr5gBandPrefTlv::Nr5gBandPrefbits1_64

8.301.2.2 uint64_t NASNr5gBandPrefTlv::Nr5gBandPrefbits_129_192

8.301.2.3 uint64_t NASNr5gBandPrefTlv::Nr5gBandPrefbits_193_256

8.301.2.4 uint64_t NASNr5gBandPrefTlv::Nr5gBandPrefbits_65_128

8.301.2.5 uint8_t NASNr5gBandPrefTlv::TlvPresent

8.302 NASOTAMessageTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t message_type
- uint16_t data_len
- uint8_t data_buf [2048]

8.302.1 Detailed Description

This structure contains OTA message

Parameters

Tlvresult	• unpack result
message_type	• message type – 0 - LTE ESM uplink – 1 - LTE ESM downlink – 2 - LTE EMM uplink – 3 - LTE EMM downlink – 4 - GSM/UMTS uplink – 5 - GSM/UMTS downlink
data_len	• OTA Message Content Length
data_buf	• OTA Message Content

8.302.2 Field Documentation

8.302.2.1 uint8_t NASOTAMessageTlv::data_buf[2048]

8.302.2.2 uint16_t NASOTAMessageTlv::data_len

8.302.2.3 uint32_t NASOTAMessageTlv::message_type

8.302.2.4 uint8_t NASOTAMessageTlv::TlvPresent

8.303 NASPhyCaAggPcellInfo Struct Reference

Data Fields

- uint32_t pci
- uint32_t freq
- LITEQMI_NAS_LTE_CPHY_CA_BW_NRB dl_bw_value
- uint32_t iLTEbandValue
- uint8_t TlvPresent

8.303.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Pcell Information.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
dl_bw_value	• Downlink Bandwidth Values. • See LITEQMI_NAS_LTE_CPHY_CA_BW_NRB for more information.
scell_state	• Scell state Values. • See LITEQMI_NAS_LTE_CPHY_SCELL_STATE for more information.
TlvPresent	• Tlv Present.

8.303.2 Field Documentation

8.303.2.1 LITEQMI_NAS_LTE_CPHY_CA_BW_NRB NASPhyCaAggPcellInfo::dl_bw_value

8.303.2.2 uint32_t NASPhyCaAggPcellInfo::freq

8.303.2.3 uint32_t NASPhyCaAggPcellInfo::iLTEbandValue

8.303.2.4 uint32_t NASPhyCaAggPcellInfo::pci

8.303.2.5 uint8_t NASPhyCaAggPcellInfo::TlvPresent

8.304 NASPhyCaAggScellDlBw Struct Reference

Data Fields

- LITEQMI_NAS_LTE_CPHY_CA_BW_NRB dl_bw_value
- uint8_t TlvPresent

8.304.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation Downlink Bandwidth of Scell.

Parameters

dl_bw_value	• Downlink Bandwidth Values. • See LITEQMI_NAS_LTE_CPHY_CA_BW_NRB for more information.

8.304.2 Field Documentation

8.304.2.1 LITEQMI_NAS_LTE_CPHY_CA_BW_NRB NASPhyCaAggScellDlBw::dl_bw_value

8.304.2.2 uint8_t NASPhyCaAggScellDlBw::TlvPresent

8.305 NASPhyCaAggScellIndex Struct Reference

Data Fields

- uint8_t scell_idx
- uint8_t TlvPresent

8.305.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Index.

Parameters

scell_idx	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
TlvPresent	• Tlv Present.

8.305.2 Field Documentation

8.305.2.1 uint8_t NASPhyCaAggScellIndex::scell_idx

8.305.2.2 uint8_t NASPhyCaAggScellIndex::TlvPresent

8.306 NASPhyCaAggScellIndType Struct Reference

Data Fields

- uint32_t pci
- uint32_t freq
- LITEQMI_NAS_LTE_CPHY_SCELL_STATE scell_state
- uint8_t TlvPresent

8.306.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Indeicator Type.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
scell_state	• Scell state Values. • See LITEQMI_NAS_LTE_CPHY_SCELL_STATE for more information.
TlvPresent	• Tlv Present.

8.306.2 Field Documentation

8.306.2.1 uint32_t NASPhyCaAggScellIndType::freq

8.306.2.2 uint32_t NASPhyCaAggScellIndType::pci

8.306.2.3 LITEQMI_NAS_LTE_CPHY_SCELL_STATE NASPhyCaAggScellIndType::scell_state

8.306.2.4 uint8_t NASPhyCaAggScellIndType::TlvPresent

8.307 NASPhyCaAggScellInfo Struct Reference

Data Fields

- uint32_t pci
- uint32_t freq
- LITEQMI_NAS_LTE_CPHY_CA_BW_NRB dl_bw_value
- uint32_t iLTEbandValue
- LITEQMI_NAS_LTE_CPHY_SCELL_STATE scell_state
- uint8_t TlvPresent

8.307.1 Detailed Description

This structure contains the parameters for Physical Carrier aggregation of Scell Information.

Parameters

pci	• Physical cell ID of the SCell Range. • Range for ID values: 0 to 503.
freq	• Frequency of the absolute cell Range. • Range for ID values: 0 to 65535.
dl_bw_value	• Downlink Bandwidth Values. • See LITEQMI_NAS_LTE_CPHY_CA_BW_NRB for more information.
iLTEbandValue	• Band value. • Range for LTE Band class 120 to 160.
scell_state	• Scell state Values. • See LITEQMI_NAS_LTE_CPHY_SCELL_STATE for more information.
TlvPresent	• Tlv Present.

8.307.2 Field Documentation

8.307.2.1 LITEQMI_NAS_LTE_CPHY_CA_BW_NRB NASPhyCaAggScellInfo::dl_bw_value

8.307.2.2 uint32_t NASPhyCaAggScellInfo::freq

8.307.2.3 uint32_t NASPhyCaAggScellInfo::iLTEbandValue

8.307.2.4 uint32_t NASPhyCaAggScellInfo::pci

8.307.2.5 LITEQMI_NAS_LTE_CPHY_SCELL_STATE NASPhyCaAggScellInfo::scell_state

8.307.2.6 uint8_t NASPhyCaAggScellInfo::TlvPresent

8.308 NASPRLPreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t PRLPref

8.308.1 Detailed Description

Structure used to store CDMA PRL Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
PRLPref	- CDMA PRL Preference Value

8.308.2 Field Documentation

8.308.2.1 uint16_t NASPRLPreferenceTlv::PRLPref

8.308.2.2 uint8_t NASPRLPreferenceTlv::TlvPresent

8.309 NASQmiCbkNasSwiOTAMessageInd Struct Reference

Data Fields

- NASOTAMessageTlv otaMsgTlv
- NASLteNasReleaseInfoTlv nasRelInfoTlv
- NASTimeInfoTlv timeTlv

8.309.1 Detailed Description

This structure contains OTA message

Parameters

otaMsgTlv	• See NASOTAMessageTlv for more details • Bit to check in ParamPresenceMask - **1**
nasRelInfoTlv	• See NASLteNasReleaseInfoTlv for more details • Bit to check in ParamPresenceMask - **16**
timeTlv	• See NASTimeInfoTlv for more details • Bit to check in ParamPresenceMask - **17**

8.309.2 Field Documentation

8.309.2.1 NASLteNasReleaseInfoTlv NASQmiCbkNasSwiOTAMessageInd::nasRelInfoTlv

8.309.2.2 NASOTAMessageTlv NASQmiCbkNasSwiOTAMessageInd::otaMsgTlv

8.309.2.3 NASTimeInfoTlv NASQmiCbkNasSwiOTAMessageInd::timeTlv

8.310 NASQmiCbkNasSystemSelPrefInd Struct Reference

Data Fields

- NASEmergencyModeTlv EMTlv
- NASModePreferenceTlv MPTlv
- NASBandPreferenceTlv BPTlv
- NASPRLPreferenceTlv PRLPTlv
- NASRoamPreferenceTlv RPTlv
- NASLTEBandPreferenceTlv LBPTlv
- NASNetSelPreferenceTlv NSPTlv
- NASServDomainPrefTlv SDPTlv

- NASGWAcqOrderPrefTlv GWAOPTlv
- NASAcqOrderPrefTlv AOPTlv
- NASRatDisabledMaskTlv RatDMTlv
- NASCiotLteOpModePrefTlv CiotOpMPTlv
- NASLteM1BandPrefTlv M1BandPTlv
- NASLteNB1BandPrefTlv NB1BandPTlv
- NASCiotAcqOrderPrefTlv CiotAOPTlv
- NASNr5gBandPrefTlv NR5gBandPTlv

8.310.1 Detailed Description

Structure used to store all QMI Notification parameters.

Parameters

EMTlv	- Emergency mode Tlv • See NASEmergencyModeTlv for more details • Bit to check in ParamPresenceMask - **16**
MPTlv	- Mode preference Tlv • See NASModePreferenceTlv for more details • Bit to check in ParamPresenceMask - **17**
BPTlv	- Band preference Tlv • See NASBandPreferenceTlv for more details • Bit to check in ParamPresenceMask - **18**
PRLPTlv	- PRL preference Tlv • See NASPRLPreferenceTlv for more details • Bit to check in ParamPresenceMask - **19**
RPTlv	- Roaming preference Tlv • See NASRoamPreferenceTlv for more details • Bit to check in ParamPresenceMask - **20**
LBPTlv	- LTE band preference Tlv • See NASLTEBandPreferenceTlv for more details • Bit to check in ParamPresenceMask - **21**
NSPTlv	- Network selection preference Tlv • See NASNetSelPreferenceTlv for more details • Bit to check in ParamPresenceMask - **22**
SDPTlv	- Service domain preference Tlv • See NASServDomainPrefTlv for more details • Bit to check in ParamPresenceMask - **24**
GWAOPTlv	- GSM WCDMA Acquisition Order Preference Tlv • See NASGWAcqOrderPrefTlv for more details • Bit to check in ParamPresenceMask - **25**
AOPTlv	- Acquisition Order Preference Tlv • See NASAcqOrderPrefTlv for more details • Bit to check in ParamPresenceMask - **28**

RatDMTlv	- Disabled RAT Bitmask Tlv • See NASRatDisabledMaskTlv for more details • Bit to check in ParamPresenceMask - **34**
CiotOpMPTlv	- CIOT LTE Operational Mode Preference Tlv • See NASCiotLteOpModePrefTlv for more details • Bit to check in ParamPresenceMask - **36**
M1BandPTlv	- LTE M1 Band Preference Tlv • See NASLteM1BandPrefTlv for more details • Bit to check in ParamPresenceMask - **37**
NB1BandPTlv	- LTE NB1 Band Preference Tlv • See NASLteNB1BandPrefTlv for more details • Bit to check in ParamPresenceMask - **38**
CiotAOPTlv	- CIOT acquisition order preference Tlv • See NASCiotAcqOrderPrefTlv for more details • Bit to check in ParamPresenceMask - **39**
NR5gBandPTlv	- NR5G Band Preference Tlv • See NASNr5gBandPrefTlv for more details • Bit to check in ParamPresenceMask - **40**

Note: None

8.310.2 Field Documentation

8.310.2.1 NASAcqOrderPrefTlv NASQmiCbkNasSystemSelPrefInd::AOPTlv

8.310.2.2 NASBandPreferenceTlv NASQmiCbkNasSystemSelPrefInd::BPTlv

8.310.2.3 NASCiotAcqOrderPrefTlv NASQmiCbkNasSystemSelPrefInd::CiotAOPTlv

8.310.2.4 NASCiotLteOpModePrefTlv NASQmiCbkNasSystemSelPrefInd::CiotOpMPTlv

8.310.2.5 NASEmergencyModeTlv NASQmiCbkNasSystemSelPrefInd::EMTlv

8.310.2.6 NASGWAcqOrderPrefTlv NASQmiCbkNasSystemSelPrefInd::GWAOPTlv

8.310.2.7 NASLTEBandPreferenceTlv NASQmiCbkNasSystemSelPrefInd::LBPTlv

8.310.2.8 NASLteM1BandPrefTlv NASQmiCbkNasSystemSelPrefInd::M1BandPTlv

8.310.2.9 NASModePreferenceTlv NASQmiCbkNasSystemSelPrefInd::MPTlv

8.310.2.10 NASLteNB1BandPrefTlv NASQmiCbkNasSystemSelPrefInd::NB1BandPTlv

8.310.2.11 NASNr5gBandPrefTlv NASQmiCbkNasSystemSelPrefInd::NR5gBandPTlv

8.310.2.12 NASNetSelPreferenceTlv NASQmiCbkNasSystemSelPrefInd::NSPTlv

8.310.2.13 NASPRLPreferenceTlv NASQmiCbkNasSystemSelPrefInd::PRLPTlv

8.310.2.14 NASRatDisabledMaskTlv NASQmiCbkNasSystemSelPrefInd::RatDMTlv

8.310.2.15 NASRoamPreferenceTlv NASQmiCbkNasSystemSelPrefInd::RPTlv

8.310.2.16 NASServDomainPrefTlv NASQmiCbkNasSystemSelPrefInd::SDPTlv

8.311 NASRatDisabledMaskTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t RatDisabledMask

8.311.1 Detailed Description

Structure used to store Disabled RAT Bitmask TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
RatDisabled-Mask	- Bitmask representing the radio technologies that are disabled

8.311.2 Field Documentation

8.311.2.1 uint16_t NASRatDisabledMaskTlv::RatDisabledMask

8.311.2.2 uint8_t NASRatDisabledMaskTlv::TlvPresent

8.312 NASRoamPreferenceTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t RoamPref

8.312.1 Detailed Description

Structure used to store Roaming Preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
RoamPref	- Roaming Preference Value

8.312.2 Field Documentation

8.312.2.1 uint16_t NASRoamPreferenceTlv::RoamPref

8.312.2.2 uint8_t NASRoamPreferenceTlv::TlvPresent

8.313 NASServDomainPrefTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t SrvDomainPref

8.313.1 Detailed Description

Structure used to store Service domain preference TLV Value.

Parameters

TlvPresent	- Boolean indicating the presence of the TLV in the QMI response
SrvDomainPref	- Service Domain Preference Value

8.313.2 Field Documentation

8.313.2.1 uint32_t NASServDomainPrefTlv::SrvDomainPref

8.313.2.2 uint8_t NASServDomainPrefTlv::TlvPresent

8.314 NASServingSystemInfo Struct Reference

Data Fields

- uint8_t registrationState
- uint8_t csAttachState
- uint8_t psAttachState
- uint8_t selectedNetwork
- uint8_t radioInterfaceNo
- uint8_t radioInterfaceList [255]
- uint8_t hdrPersonality

8.314.1 Detailed Description

This structure will hold the serving system parameters information

Parameters

registrationState	- Registration state of the mobile • 0 - QMI_NAS_NOT_REGISTERED Not registered;mobile is not currently searching for a new network to provide service • 1 - QMI_NAS_REGISTERED Registered with a network • 2 - QMI_NAS_NOT_REGISTERED_SEARCHING Not registered, but mobile is currently searching for a new network to provide service • 3 - QMI_NAS_REGISTRATION_DENIED Registration denied by the visible network • 4 - QMI_NAS_REGISTRATION_UNKNOWN Registration state is unknown
csAttachState	- Circuit Switch domain attach state of the mobile • 0 - Unknown or not applicable • 1 - Attached • 2 - Detached

psAttachState	- Packet domain attach state of the mobile • 0 - Unknown or not applicable • 1 - Attached • 2 - Detached
selectedNetwork	- Type of selected radio access network • 0x00 - Unknown • 0x01 - 3GPP2 network • 0x02 - 3GPP network
radioInterfaceNo	- Number of radio interfaces currently in use; this indicates how many radio_if identifiers follow this field
radioInterface-List	- Radio interface currently in use (each is 1 byte) • 0x00 - None (no service) • 0x01 - cdma2000 1X • 0x02 - cdma2000 HRPD (1xEV-DO) • 0x03 - AMPS • 0x04 - GSM • 0x05 - UMTS • 0x08 - LTE
hdrPersonality	- HDR personality information (valid only for EVDO) • 0x00 - Unknown • 0x01 - HRPD • 0x02 - eHRPD

Note: None

8.314.2 Field Documentation

8.314.2.1 uint8_t NASServingSystemInfo::csAttachState

8.314.2.2 uint8_t NASServingSystemInfo::hdrPersonality

8.314.2.3 uint8_t NASServingSystemInfo::psAttachState

8.314.2.4 uint8_t NASServingSystemInfo::radioInterfaceList[255]

8.314.2.5 uint8_t NASServingSystemInfo::radioInterfaceNo

8.314.2.6 uint8_t NASServingSystemInfo::registrationState

8.314.2.7 uint8_t NASServingSystemInfo::selectedNetwork

8.315 NASTimeInfoTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t time

8.315.1 Detailed Description

This structure contains LTE Nas time Infomation

Parameters

Tlvresult	• unpack result
time	• Seconds in local time since Jan. 6th 1980 00:00:00 UTC

8.315.2 Field Documentation

8.315.2.1 uint64_t NASTimeInfoTlv::time

8.315.2.2 uint8_t NASTimeInfoTlv::TlvPresent

8.316 newMTMessageTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSMTMessageInfo MTMessageInfo

8.316.1 Detailed Description

This structure contains MT message TLV information.

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
MTMessageInfo	• MT Message • See sMSMTMessageInfo for more information

8.316.2 Field Documentation

8.316.2.1 sMSMTMessageInfo newMTMessageTlv::MTMessageInfo

8.316.2.2 uint8_t newMTMessageTlv::TlvPresent

8.317 pack_audio_SLQSGetAudioPathConfig_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Item

8.317.1 Detailed Description

This structure contains the pack parameters for Get Audio Path Config.

Parameters

Profile	• Audio Profile – 0-9
Item	• Item – 0 - AV_EC – 1 - AV_NS – 2 - AV_TXVOL – 3 - AV_DTMFTXG – 4 - AV_CODECSTG – 5 - AV_TXPCMIIRFLTR – 6 - AV_RXPCMIIRFLTR – 7 - AV_MICGAIN – 8 - AV_RXAGC – 9 - AV_TXAGC – 10 - AV_RXAGCLIST – 11 - AV_RXAVCLIST – 12 - AV_TXAGCLIST

8.317.2 Field Documentation

8.317.2.1 uint8_t pack_audio_SLQSGetAudioPathConfig_t::Item

8.317.2.2 uint8_t pack_audio_SLQSGetAudioPathConfig_t::Profile

8.318 pack_audio_SLQSGetAudioProfile_t Struct Reference

Data Fields

- uint8_t Generator

8.318.1 Detailed Description

This structure contains the pack parameters to Get Audio Profile.

Parameters

Generator	• Audio Generator – 0 - Voice – 1 - Key Beep – 2 - MIDI

8.318.2 Field Documentation

8.318.2.1 uint8_t pack_audio_SLQSGetAudioProfile_t::Generator

8.319 pack_audio_SLQSGetAudioVolTLBConfig_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Generator
- uint8_t Volume
- uint8_t Item

8.319.1 Detailed Description

This structure contains the pack parameters for SLQSGetAudioVolTLBConfig.

Parameters

Profile	• Audio Profile – 0-9
Generator	• Audio Generator – 0-2
Volume	• Audio Volume Level – 0-7
Item	• Item – 13 - AV_RXVOLDB – 14 - AV_DTMFVOLDB – 15 - AV_PAD

8.319.2 Field Documentation

8.319.2.1 uint8_t pack_audio_SLQSGetAudioVolTLBConfig_t::Generator

8.319.2.2 uint8_t pack_audio_SLQSGetAudioVolTLBConfig_t::Item

8.319.2.3 uint8_t pack_audio_SLQSGetAudioVolTLBConfig_t::Profile

8.319.2.4 uint8_t pack_audio_SLQSGetAudioVolTLBConfig_t::Volume

8.320 pack_audio_SLQSSetAudioPathConfig_t Struct Reference

Data Fields

- uint8_t Profile

- uint8_t * pECMode
- uint8_t * pNSEnable
- uint16_t * pTXGain
- uint16_t * pDTMFTXGain
- uint16_t * pCodecSTGain
- audio_TXPCMIIRFltr * pTXPCMIIRFltr
- audio_RXPCMIIRFltr * pRXPCMIIRFltr
- uint8_t * pRXAVCAGCSwitch
- uint8_t * pTXAVCSwitch
- audio_RXAGCList * pRXAGCList
- audio_RXAVCList * pRXAVCList
- audio_TXAGCList * pTXAGCList

8.320.1 Detailed Description

This structure contains the pack parameters for SLQSSetAudioPathConfig .

Parameters

Profile	[Mandatory] • Audio Profile – 0-9
pECMode	[Optional] • AV_EC – 0 - Echo cancellation off – 1 - Handset echo mode – 2 - Headset mode – 3 - Car kit mode – 4 - Speaker Mode
pNSEnable	[Optional] • Noise Suppression – 0 - Noise suppression off – 1 - Noise suppression on
pTXGain	[Optional] • TX Voice volume – 0x0000 - 0xffff
pDTMFTXGain	[Optional] • AV_DTMFTXG – 0x0000 - 0xffff
pCodecSTGain	[Optional] • AV_CODECSTG – 0x0000 - 0xffff
pTXPCMIIRFltr	[Optional] • See audio_TXPCMIIRFltr for more information
pRXPCMIIRFltr	[Optional] • See audio_RXPCMIIRFltr for more information

pRXAVCAGC-Switch	[Optional] • RX AVC/AGC Switch
pTXAVCSwitch	[Optional] • TX AVC Switch
pRXAGCList	[Optional] • See audio_RXAGCList for more information
pRXAVCList	[Optional] • See audio_RXAVCList for more information
pTXAGCList	[Optional] • See audio_TXAGCList for more information

8.320.2 Field Documentation

8.320.2.1 uint16_t* pack_audio_SLQSSetAudioPathConfig_t::pCodecSTGain

8.320.2.2 uint16_t* pack_audio_SLQSSetAudioPathConfig_t::pDTMFTXGain

8.320.2.3 uint8_t* pack_audio_SLQSSetAudioPathConfig_t::pECMode

8.320.2.4 uint8_t* pack_audio_SLQSSetAudioPathConfig_t::pNSEnable

8.320.2.5 uint8_t pack_audio_SLQSSetAudioPathConfig_t::Profile

8.320.2.6 audio_RXAGCList* pack_audio_SLQSSetAudioPathConfig_t::pRXAGCList

8.320.2.7 uint8_t* pack_audio_SLQSSetAudioPathConfig_t::pRXAVCAGCSwitch

8.320.2.8 audio_RXAVCList* pack_audio_SLQSSetAudioPathConfig_t::pRXAVCList

8.320.2.9 audio_RXPCMIIRFltr* pack_audio_SLQSSetAudioPathConfig_t::pRXPCMIIRFltr

8.320.2.10 audio_TXAGCList* pack_audio_SLQSSetAudioPathConfig_t::pTXAGCList

8.320.2.11 uint8_t* pack_audio_SLQSSetAudioPathConfig_t::pTXAVCSwitch

8.320.2.12 uint16_t* pack_audio_SLQSSetAudioPathConfig_t::pTXGain

8.320.2.13 audio_TXPCMIIRFltr* pack_audio_SLQSSetAudioPathConfig_t::pTXPCMIIRFltr

8.321 pack_audio_SLQSSetAudioProfile_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t EarMute
- uint8_t MicMute
- uint8_t Generator
- uint8_t Volume

8.321.1 Detailed Description

This structure contains pack parameters to Set Audio Profile.

Parameters

Profile	• Audio Profile – 0 - Handset – 1 - Headset – 2 - Car Kit – 3 - Speaker phone – 4 - Auxiliary – 5 - TTY – 6 - Auxiliary external PCM – 7 - Primary external PCM – 8 - External slave PCM – 9 - I2S
EarMute	• Ear Mute Setting – 0 - unmuted – 1 - muted
MicMute	• MIC Mute Setting – 0 - unmuted – 1 - muted
Generator	• Audio Generator – 0 - Voice – 1 - Key Beep – 2 - MIDI
Volume	• Audio Volume Level – 0 to 7

8.321.2 Field Documentation

8.321.2.1 uint8_t pack_audio_SLQSSetAudioProfile_t::EarMute

8.321.2.2 uint8_t pack_audio_SLQSSetAudioProfile_t::Generator

8.321.2.3 uint8_t pack_audio_SLQSSetAudioProfile_t::MicMute

8.321.2.4 uint8_t pack_audio_SLQSSetAudioProfile_t::Profile

8.321.2.5 uint8_t pack_audio_SLQSSetAudioProfile_t::Volume

8.322 pack_audio_SLQSSetAudioVolTLBConfig_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Generator
- uint8_t Volume
- uint8_t Item
- uint16_t VolValue

8.322.1 Detailed Description

This structure contains the pack parameters for SLQSSetAudioVolTLBConfig.

Parameters

Profile	• Audio Profile – 0-9
Generator	• Audio Generator – 0-2
Volume	• Audio Volume Level – 0-7
Item	• Item – 13 - AV_RXVOLDB – 14 - AV_DTMFVOLDB – 15 - AV_PAD
Value	• Value to be set to the volume table

8.322.2 Field Documentation

8.322.2.1 uint8_t pack_audio_SLQSSetAudioVolTLBConfig_t::Generator

8.322.2.2 uint8_t pack_audio_SLQSSetAudioVolTLBConfig_t::Item

8.322.2.3 uint8_t pack_audio_SLQSSetAudioVolTLBConfig_t::Profile

8.322.2.4 uint8_t pack_audio_SLQSSetAudioVolTLBConfig_t::Volume

8.322.2.5 uint16_t pack_audio_SLQSSetAudioVolTLBConfig_t::VolValue

8.323 pack_cat_CATSendEnvelopeCommand_t Struct Reference

Data Fields

- uint32_t cmdID
- uint32_t dataLen
- uint8_t * pData

8.323.1 Detailed Description

Structure used to store envelope command data.

Parameters

cmdID	• Envelope command type – 0x01 - Menu Selection – 0x02 - Event DL User activity – 0x03 - Event DL Idle Screen Available – 0x04 - Event DL Language Selection
dataLen	• Length of pData in bytes
pData	• Encoded envelope data as defined in ETSI TS 102 223, section 7 [Smart Cards: Card Application Toolkit (CAT) – Release 4]

8.323.2 Field Documentation

8.323.2.1 uint32_t pack_cat_CATSendEnvelopeCommand_t::cmdID

8.323.2.2 uint32_t pack_cat_CATSendEnvelopeCommand_t::dataLen

8.323.2.3 uint8_t* pack_cat_CATSendEnvelopeCommand_t::pData

8.324 pack_cat_CATSendTerminalResponse_t Struct Reference

Data Fields

- uint32_t refID
- uint32_t dataLen
- uint8_t * pData

8.324.1 Detailed Description

Structure used to terminal response data.

Parameters

refID	• Proactive command reference ID. The value should be the same as indicated in the CAT event callback data for the relevant proactive command.

dataLen	• Terminal response data length
pData	• Terminal response for the relevant proactive command encoded as per ETSI TS 102 223, section 6.8 [Smart Cards: Card Application Toolkit (CAT) – Release 4]

8.324.2 Field Documentation

8.324.2.1 uint32_t pack_cat_CATSendTerminalResponse_t::dataLen

8.324.2.2 uint8_t* pack_cat_CATSendTerminalResponse_t::pData

8.324.2.3 uint32_t pack_cat_CATSendTerminalResponse_t::refID

8.325 pack_cat_SetCATEventCallback_t Struct Reference

Data Fields

- uint32_t eventMask

8.325.1 Detailed Description

This structure contains sEnables/disables the CAT event callback pack variable.

Parameters

eventMask	• bitmask of CAT events to register for – 0x00000001 - Display Text – 0x00000002 - Get In-Key – 0x00000004 - Get Input – 0x00000008 - Setup Menu – 0x00000010 - Select Item – 0x00000020 - Send SMS - Alpha Identifier – 0x00000040 - Setup Event: User Activity – 0x00000080 - Setup Event: Idle Screen Notify – 0x00000100 - Setup Event: Language Sel Notify – 0x00000200 - Setup Idle Mode Text – 0x00000400 - Language Notification – 0x00000800 - Refresh – 0x00001000 - End Proactive Session

8.325.2 Field Documentation

8.325.2.1 uint32_t pack_cat_SetCATEventCallback_t::eventMask

8.326 pack_dms_ActivateAutomatic_t Struct Reference

Data Fields

- uint8_t actCode [81]

8.326.1 Detailed Description

This structure contains UIM activate automation information

Parameters

actCode	• NULL-terminated string representing activation code (maximum string length of 12). • Specific carrier requirements may dictate actual activation code that is applicable, e.g., "∗22899"

8.326.2 Field Documentation

8.326.2.1 uint8_t pack_dms_ActivateAutomatic_t::actCode[81]

8.327 pack_dms_GetCustFeaturesV2_t Struct Reference

Data Fields

- uint8_t cust_id [64+1]
- uint8_t list_type
- uint16_t Tlvresult

8.327.1 Detailed Description

This structure contains which customization id or the list type want to retrieve from modem. This TLV is only applicable for 9x30 modules so far

Parameters

cust_id	• Customization ID (Maximum 64 bytes) • NULL terminated ASCII string.
list_type	• list type requested
Tlvresult	• Pack Result

8.327.2 Field Documentation

8.327.2.1 uint8_t pack_dms_GetCustFeaturesV2_t::cust_id[64+1]

8.327.2.2 uint8_t pack_dms_GetCustFeaturesV2_t::list_type

8.327.2.3 uint16_t pack_dms_GetCustFeaturesV2_t::Tlvresult

8.328 pack_dms_ResetToFactoryDefaults_t Struct Reference

Data Fields

- uint8_t spc [6]

8.328.1 Detailed Description

This structure contains UIM reset to factory default information

Parameters

spc[IN]	• Service programming code in ASCII format (digits 0 to 9 only)

8.328.2 Field Documentation

8.328.2.1 uint8_t pack_dms_ResetToFactoryDefaults_t::spc[6]

8.329 pack_dms_SetActivationStatusCallback_t Struct Reference

Data Fields

- uint8_t activationState

8.329.1 Detailed Description

This structure is used to store Set Service Activation Status callback parameter pack.

Parameters

activationState	• Service activation state. • Values – 0 - Do not report – 1 - Report activation state changes

8.329.2 Field Documentation

8.329.2.1 uint8_t pack_dms_SetActivationStatusCallback_t::activationState

8.330 pack_dms_SetCrashAction_t Struct Reference

Data Fields

- uint8_t crashAction

8.330.1 Detailed Description

This structure is used to store pack_dms_SetCrashAction parameters.

Parameters

crashAction	• 0 - USB Memory Download. Modem will reset after a crash and will stay in USB download mode with only DM port enumerated. • 1 - Reset. Modem will reset and come back in ONLINE mode. Minimal crash data will be available and can be extracted with at!gcdump? AT command • 2 - No Action

8.330.2 Field Documentation

8.330.2.1 uint8_t pack_dms_SetCrashAction_t::crashAction

8.331 pack_dms_SetCustFeature_t Struct Reference

Data Fields

- uint32_t GpsEnable
- uint8_t DisableIMSI
- uint16_t IPFamSupport
- uint8_t RMAutoConnect
- uint8_t GPSSel
- uint8_t SMSSupport
- uint8_t IsVoiceEnabled
- uint8_t DHCPRelayEnabled
- uint8_t GPSLPM

8.331.1 Detailed Description

This structure contains current settings of custom features pack parameters

Parameters

GpsEnable	• describes if GPS is enabled or disabled • values: – 0x00 - GPS is disabled – 0x01 - GPS is enabled
DisableIMSI	• optional 1 byte parameter • describes if IMSI display is enabled or disabled • values: – 0x00 - Allow display of IMSI – 0x01 - Do not display IMSI

IPFamSupport	• optional 2 byte BitMask • bitmask representing the IP families supported • values: – 0x01 - IPv4 – 0x02 - IPv6 – 0x04 - IPv4v6
RMAutoConnect	• optional 1 byte parameter • QMI Mode RM Net Auto Connect Support • values: – 0x00 - Not Supported – 0x01 - Supported
GPSSel	• optional 1 byte parameter • GPS Antenna Select • values: – 0x00 - Dedicated GPS Port – 0x01 - GPS Rx over AUX Port – 0x02 - GPS Rx over dedicated GPS port with no bias voltage applied
SMSSupport	• optional 1 byte parameter • SMS support • values: – 0x00 - Not supported – 0x01 - supported • Used to determine whether or not to hide SMS from user
IsVoiceEnabled	• optional 1 byte parameter • Voice support • values: – 0x00 - Enable voice on both AT and QMI interface (default) – 0x01 - Reserved – 0x02 - Disable voice on both AT and QMI interface
DHCPRelay-Enabled	• optional 1 byte parameter • DHCP Relay support • values: – 0x00 - Disable DHCP relay – 0x01 - Enable DHCP relay

GPSLPM	• optional 1 byte parameter • GPSLPM support • values: – 0x00 - Enable GPS in Low Power Mode – 0x01 - Disable GPS in Low Power Mode

8.331.2 Field Documentation

8.331.2.1 uint8_t pack_dms_SetCustFeature_t::DHCPRelayEnabled

8.331.2.2 uint8_t pack_dms_SetCustFeature_t::DisableIMSI

8.331.2.3 uint32_t pack_dms_SetCustFeature_t::GpsEnable

8.331.2.4 uint8_t pack_dms_SetCustFeature_t::GPSLPM

8.331.2.5 uint8_t pack_dms_SetCustFeature_t::GPSSel

8.331.2.6 uint16_t pack_dms_SetCustFeature_t::IPFamSupport

8.331.2.7 uint8_t pack_dms_SetCustFeature_t::IsVoiceEnabled

8.331.2.8 uint8_t pack_dms_SetCustFeature_t::RMAutoConnect

8.331.2.9 uint8_t pack_dms_SetCustFeature_t::SMSSupport

8.332 pack_dms_SetCustFeaturesV2_t Struct Reference

Data Fields

- uint8_t cust_id [64+1]
- uint16_t value_length
- uint8_t cust_value [8+1]
- uint16_t Tlvresult

8.332.1 Detailed Description

This structure contains customization settings set to modem pack

Parameters

cust_id	• Customization ID (Maximum 64 bytes) • NULL terminated ASCII string.
value_length	• length of cust_value field
cust_value	• Customization Setting Value (Maximum 8 bytes)

Tlvresult	• Pack Result

8.332.2 Field Documentation

8.332.2.1 uint8_t pack_dms_SetCustFeaturesV2_t::cust_id[64+1]

8.332.2.2 uint8_t pack_dms_SetCustFeaturesV2_t::cust_value[8+1]

8.332.2.3 uint16_t pack_dms_SetCustFeaturesV2_t::Tlvresult

8.332.2.4 uint16_t pack_dms_SetCustFeaturesV2_t::value_length

8.333 pack_dms_SetEventReport_t Struct Reference

Data Fields

- uint8_t mode

8.333.1 Detailed Description

This structure is used to store pack_dms_SetEventReport parameters.

Parameters

mode	• Operating Mode • 0 - reset • 1 - set • 2 - no change

8.333.2 Field Documentation

8.333.2.1 uint8_t pack_dms_SetEventReport_t::mode

8.334 pack_dms_SetIndicationRegister_t Struct Reference

Data Fields

- uint8_t PSMStatus
- uint8_t PSMCfgChangeInfo
- uint8_t RptIMSCapability

8.334.1 Detailed Description

This structure contains the DMS Register Indication request parameters

Parameters

PSMStatus	• Power Save Mode Status • Values – 0 - Do not report – 1 - Report PSM status – 2 - No Change
PSMCfgChange-Info	• Power Save Mode Configuration Change Information • Values – 0 - Do not report – 1 - Report Power Save Mode configuration changes – 2 - No Change
RptIMS-Capability	• Report IMS Capability • Values – 0 - Do not report – 1 - Report IMS capability – 2 - No Change

8.334.2 Field Documentation

8.334.2.1 uint8_t pack_dms_SetIndicationRegister_t::PSMCfgChangeInfo

8.334.2.2 uint8_t pack_dms_SetIndicationRegister_t::PSMStatus

8.334.2.3 uint8_t pack_dms_SetIndicationRegister_t::RptIMSCapability

8.335 pack_dms_SetPower_t Struct Reference

Data Fields

- uint32_t mode
- uint16_t Tlvresult

8.335.1 Detailed Description

Structure to store pack the operating mode of the device.

Parameters

mode	• Selected operating mode – See qaGobiApiTablePowerModes.h for power modes
Tlvresult	• pack Tlv Result.

8.335.2 Field Documentation

8.335.2.1 uint32_t pack_dms_SetPower_t::mode

8.335.2.2 uint16_t pack_dms_SetPower_t::Tlvresult

8.336 pack_dms_SetUSBComp_t Struct Reference

Data Fields

- uint8_t USBComp
- uint16_t Tlvresult

8.336.1 Detailed Description

This structure is used to store USB composition information pack paramters

Parameters

USBComp	• Current USB Composition • Values: – 0..5 - Reserved (non-QMI) – 6 - DM NMEA AT QMI – 7 - DM NMEA AT QMI1 QMI2 QMI3 – 8 - DM NMEA AT MBIM – 9 - MBIM – 10 - NMEA MBIM – 11 - DM MBIM – 12 - DM NMEA MBIM 13-22 are combined compositions. One is for Win8 MBIM interfaces, another is for legacy QMI interfaces – 13 - 6 for QMI, 8 for MBIM – 14 - 6 for QMI, 9 for MBIM – 15 - 6 for QMI, 10 for MBIM – 16 - 6 for QMI, 11 for MBIM – 17 - 6 for QMI, 12 for MBIM – 18 - 7 for QMI, 8 for MBIM – 19 - 7 for QMI, 9 for MBIM – 20 - 7 for QMI, 10 for MBIM – 21 - 7 for QMI, 11 for MBIM – 22 - 7 for QMI, 12 for MBIM
Tlvresult	• pack Tlv Result.

8.336.2 Field Documentation

8.336.2.1 uint16_t pack_dms_SetUSBComp_t::Tlvresult

8.336.2.2 uint8_t pack_dms_SetUSBComp_t::USBComp

8.337 pack_dms_SLQSDmsSwiIndicationRegister_t Struct Reference

Data Fields

- uint8_t resetInfoInd

8.337.1 Detailed Description

This structure contains set registration state for different indication pack

Parameters

resetInfoInd[IN]	• Values – 0 - Disable – 1 - Enable

8.337.2 Field Documentation

8.337.2.1 uint8_t pack_dms_SLQSDmsSwiIndicationRegister_t::resetInfoInd

8.338 pack_dms_SLQSSetPowerSaveModeConfig_t Struct Reference

Data Fields

- uint8_t * pPsmEnableState
- uint32_t * pActiveTimer
- uint32_t * pPeriodicUpdateTimer

8.338.1 Detailed Description

This structure contains the Power Save Mode (PSM) configuration parameter.

Parameters

pPsmEnable-State	[Optional] • PSM Enable State • Values – 0 - PSM is not enabled – 1 - PSM is enabled
pActiveTimer	[Optional] • Active Timer • PSM active timer value (in seconds). • ActiveTimer encoding is the GPRS timer 2 encoding specified in Table 10.5.172 of 3GPP TS 24.008.

pPeriodic-UpdateTimer	[Optional] • Periodic Update Timer • PSM periodic update timer value (in seconds) • Periodic Update Timer encoding is the GPRS timer 3 encoding specified in Table 10.5.163a of 3GPP TS 24.008.

8.338.2 Field Documentation

8.338.2.1 uint32_t* pack_dms_SLQSSetPowerSaveModeConfig_t::pActiveTimer

8.338.2.2 uint32_t* pack_dms_SLQSSetPowerSaveModeConfig_t::pPeriodicUpdateTimer

8.338.2.3 uint8_t* pack_dms_SLQSSetPowerSaveModeConfig_t::pPsmEnableState

8.339 pack_dms_SLQSSwiGetCrashInfo_t Struct Reference

Data Fields

- uint8_t clear

8.339.1 Detailed Description

This structure contains pack_dms_SLQSSwiGetCrashInfo parameters

Parameters

clear	• 0 - do not clear crash data after response • 1 - clear crash data after response

8.339.2 Field Documentation

8.339.2.1 uint8_t pack_dms_SLQSSwiGetCrashInfo_t::clear

8.340 pack_dms_SLQSSwiSetDyingGaspCfg_t Struct Reference

Data Fields

- uint8_t * pDestSMSNum
- uint8_t * pDestSMSContent

8.340.1 Detailed Description

This structure is used to store pack_dms_SLQSSwiSetDyingGaspCfg parameters

Parameters

pDestSMSNum[IN]	• SMS Destination Number as string of 8 bit ASCII Characters Max 20 chars. • Optional parameter.
pDestSMSContent[IN]	• SMS COntent as a string of 8 bit ASCII text characters Max 160 chars. • Optional parameter.

8.340.2 Field Documentation

8.340.2.1 uint8_t* pack_dms_SLQSSwiSetDyingGaspCfg_t::pDestSMSContent

8.340.2.2 uint8_t* pack_dms_SLQSSwiSetDyingGaspCfg_t::pDestSMSNum

8.341 pack_dms_SLQSSwiSetHostDevInfo_t Struct Reference

Data Fields

- char manString [255]
- char modelString [255]
- char swVerString [255]
- char plasmaIDString [255]

8.341.1 Detailed Description

This structure contains SWI set host device info unpack information

Parameters

manString[IN]	• Host Device Manufacturer Name • Null terminated ASCII String
modelString[IN]	• Host Device Model String • Null terminated ASCII string.
swVerString[IN]	• Host Device Software Version String • Null terminated ASCII string
plasmaIDString[IN]	• Host Device Plasma ID String • Null terminated alphanumeric ASCII string

8.341.2 Field Documentation

8.341.2.1 char pack_dms_SLQSSwiSetHostDevInfo_t::manString[255]

8.341.2.2 char pack_dms_SLQSSwiSetHostDevInfo_t::modelString[255]

8.341.2.3 char pack_dms_SLQSSwiSetHostDevInfo_t::plasmaIDString[255]

8.341.2.4 char pack_dms_SLQSSwiSetHostDevInfo_t::swVerString[255]

8.342 pack_dms_SLQSSwiSetOSInfo_t Struct Reference

Data Fields

- char nameString [255]
- char versionString [255]

8.342.1 Detailed Description

This structure contains SWI set host OS info pack information

Parameters

nameString[IN]	Host device manufacture String • NULL terminated ASCII string.
VersionString[IN]	Host device model String • NULL terminated ASCII string.

8.342.2 Field Documentation

8.342.2.1 char pack_dms_SLQSSwiSetOSInfo_t::nameString[255]

8.342.2.2 char pack_dms_SLQSSwiSetOSInfo_t::versionString[255]

8.343 pack_dms_SwiSetEventReport_t Struct Reference

Data Fields

- uint8_t * pTempReport
- uint8_t * pVoltReport
- uint8_t * pUIMStatusReport

8.343.1 Detailed Description

This structure is used to store pack_dms_SwiSetEventReport parameters.

Parameters

pTempReport	(optional) • Temperature indicator. – 0 - Do not report – 1 - Report when state changes

pVoltReport	(optional) • Voltage Indicator. – 0 - Do not report – 1 - Report when state changes
pUIMStatus-Report	(optional) • UIM status Indicator. – 0 - Do not report – 1 - Report when state changes

8.343.2 Field Documentation

8.343.2.1 uint8_t* pack_dms_SwiSetEventReport_t::pTempReport

8.343.2.2 uint8_t* pack_dms_SwiSetEventReport_t::pUIMStatusReport

8.343.2.3 uint8_t* pack_dms_SwiSetEventReport_t::pVoltReport

8.344 pack_dms_SwiUimSelect_t Struct Reference

Data Fields

- uint8_t uim_select

8.344.1 Detailed Description

This structure is used to store pack_dms_SwiUimSelect parameters.

Parameters

uim_select	• Selection of UIM Card – 0 - External UIM Interface – 1 - Embedded UIM – 2 - Remote UIM – 3 - Auto switch

Note

Auto switch is applicable only if UIMAUTOSWITCH feature is enabled. This feature will activate the auto-switch mechanism if it is inactive.

8.344.2 Field Documentation

8.344.2.1 uint8_t pack_dms_SwiUimSelect_t::uim_select

8.345 pack_dms_UIMChangePIN_t Struct Reference

Data Fields

- uint8_t id
- uint8_t oldValue [255]
- uint8_t newValue [255]

8.345.1 Detailed Description

This structure contains UIM Unblock PIN Information

Parameters

id[IN]	• PIN ID – 1 (PIN1 / CHV1) – 2 (PIN2 / CHV2)
oldValue[IN]	• Old PIN value of PIN to change
newValue[IN]	• New PIN value of PIN to change

8.345.2 Field Documentation

8.345.2.1 uint8_t pack_dms_UIMChangePIN_t::id

8.345.2.2 uint8_t pack_dms_UIMChangePIN_t::newValue[255]

8.345.2.3 uint8_t pack_dms_UIMChangePIN_t::oldValue[255]

8.346 pack_dms_UIMGetControlKeyStatus_t Struct Reference

Data Fields

- uint8_t facility

8.346.1 Detailed Description

This structure contains UIM get control key status information

Parameters

facility[IN]	• MT or network facility – 0 - Network Personalization (PN) – 1 - Network Subset Personalization (PU) – 2 - Service Provider Personalization (PP) – 3 - Corporate Personalization (PC) – 4 - UIM Personalization (PF)

8.346.2 Field Documentation

8.346.2.1 uint8_t pack_dms_UIMGetControlKeyStatus_t::facility

8.347 pack_dms_UIMGetICCID_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.347.1 Detailed Description

This structure contains UIM Get ICCID pack

Parameters

Tlvresult	• Pack result.

8.347.2 Field Documentation

8.347.2.1 swi_uint256_t pack_dms_UIMGetICCID_t::ParamPresenceMask

8.347.2.2 uint16_t pack_dms_UIMGetICCID_t::Tlvresult

8.348 pack_dms_UIMSetControlKeyProtection_t Struct Reference

Data Fields

- uint8_t facility
- uint8_t facilityState
- uint8_t facilityCk [8]

8.348.1 Detailed Description

This structure contains UIM Set control key protection information

Parameters

facility[IN]	• MT or network facility – 0 - Network Personalization (PN) – 1 - Network Subset Personalization (PU) – 2 - Service Provider Personalization (PP) – 3 - Corporate Personalization (PC) – 4 - UIM Personalization (PF)

facilityState[IN]	• UIM facility state – 0 - Deactivated – 1 - Activated – 2 - Blocked
facilityCk[IN]	• Facility depersonalization control key, string in ASCII text (maximum 8 bytes)

8.348.2 Field Documentation

8.348.2.1 uint8_t pack_dms_UIMSetControlKeyProtection_t::facility

8.348.2.2 uint8_t pack_dms_UIMSetControlKeyProtection_t::facilityCk[8]

8.348.2.3 uint8_t pack_dms_UIMSetControlKeyProtection_t::facilityState

8.349 pack_dms_UIMSetPINProtection_t Struct Reference

Data Fields

- uint8_t id
- uint8_t bEnable
- uint8_t value [255]

8.349.1 Detailed Description

This structure contains PIN Protection Information

Parameters

id[IN]	• PIN ID – 1 (PIN1 / CHV1) – 2 (PIN2 / CHV2)
bEnable[IN]	• Enable/disable PIN protection, 0 = Disable
pValue[IN]	• PIN value of the PIN to be enabled/disabled

8.349.2 Field Documentation

8.349.2.1 uint8_t pack_dms_UIMSetPINProtection_t::bEnable

8.349.2.2 uint8_t pack_dms_UIMSetPINProtection_t::id

8.349.2.3 uint8_t pack_dms_UIMSetPINProtection_t::value[255]

8.350 pack_dms_UIMUnblockControlKey_t Struct Reference

Data Fields

- uint8_t facility
- uint8_t facilityCk [8]

8.350.1 Detailed Description

This structure contains UIM unblock Control Key information

Parameters

facility[IN]	• MT or network facility – 0 - Network Personalization (PN) – 1 - Network Subset Personalization (PU) – 2 - Service Provider Personalization (PP) – 3 - Corporate Personalization (PC) – 4 - UIM Personalization (PF)
facilityCk[IN]	• Facility depersonalization control key, string in ASCII text (maximum 8 bytes)

8.350.2 Field Documentation

8.350.2.1 uint8_t pack_dms_UIMUnblockControlKey_t::facility

8.350.2.2 uint8_t pack_dms_UIMUnblockControlKey_t::facilityCk[8]

8.351 pack_dms_UIMUnblockPIN_t Struct Reference

Data Fields

- uint8_t id
- uint8_t pukValue [255]
- uint8_t newPin [255]

8.351.1 Detailed Description

This structure contains UIM Unblock PIN Information

Parameters

id[IN]	• PIN ID – 1 (PIN1 / CHV1) – 2 (PIN2 / CHV2)
pukValue[IN]	• PUK value of PIN to be unblocked

newPin[IN]	• New PIN value for the PIN to be unblocked

8.351.2 Field Documentation

8.351.2.1 uint8_t pack_dms_UIMUnblockPIN_t::id

8.351.2.2 uint8_t pack_dms_UIMUnblockPIN_t::newPin[255]

8.351.2.3 uint8_t pack_dms_UIMUnblockPIN_t::pukValue[255]

8.352 pack_dms_UIMVerifyPIN_t Struct Reference

Data Fields

- uint8_t id
- uint8_t value [255]

8.352.1 Detailed Description

This structure contains PIN Value Information

Parameters

id[IN]	• PIN ID – 1 (PIN1 / CHV1) – 2 (PIN2 / CHV2)
value[IN]	• PIN value of the PIN to be enabled/disabled

8.352.2 Field Documentation

8.352.2.1 uint8_t pack_dms_UIMVerifyPIN_t::id

8.352.2.2 uint8_t pack_dms_UIMVerifyPIN_t::value[255]

8.353 pack_fms_GetImagesPreference_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.353.1 Detailed Description

This structure contains the Get Image Preference information pack

Parameters

Tlvresult	• Pack result

8.353.2 Field Documentation

8.353.2.1 uint16_t pack_fms_GetImagesPreference_t::Tlvresult

8.354 pack_fms_GetStoredImages_t Struct Reference

Data Fields

- uint16_t Tlvresult

8.354.1 Detailed Description

This structure contains the Get Stored Images pack

Parameters

Tlvresult	• Pack result

8.354.2 Field Documentation

8.354.2.1 uint16_t pack_fms_GetStoredImages_t::Tlvresult

8.355 pack_fms_SetImagesPreference_t Struct Reference

Data Fields

- uint32_t imageListSize
- FMSPrefImageList * pImageList
- uint32_t bForceDownload
- uint8_t modemindex
- uint16_t Tlvresult

8.355.1 Detailed Description

This structure contains the Set Images Preference pack

Parameters

imageListSize	• Image List Size
pImageList	• Image List • See FMSPrefImageList

bForceDownload	• 0 - Not Force Donwload. • 1 - Focrce Download.
modemindex	• Modem Index.
Tlvresult	• Unpack result

8.355.2 Field Documentation

8.355.2.1 uint32_t pack_fms_SetImagesPreference_t::bForceDownload

8.355.2.2 uint32_t pack_fms_SetImagesPreference_t::imageListSize

8.355.2.3 uint8_t pack_fms_SetImagesPreference_t::modemindex

8.355.2.4 FMSPrefImageList* pack_fms_SetImagesPreference_t::pImageList

8.355.2.5 uint16_t pack_fms_SetImagesPreference_t::Tlvresult

8.356 pack_ims_SLQSImsConfigIndicationRegister_t Struct Reference

Data Fields

- uint8_t * pSIPConfigEvents
- uint8_t * pRegMgrConfigEvents
- uint8_t * pSMSConfigEvents
- uint8_t * pUserConfigEvents
- uint8_t * pVoIPConfigEvents

8.356.1 Detailed Description

This structure contains parameters of IMS Config Indication Register

Parameters

pSIPConfig-Events(optional)	• Registration Indication For SIP Configuration Events. • When this registration is enabled, the device learns of SIP config events via the QMI_IMS_SIP-_CONFIG_IND indication. – 0x00 - Disable – 0x01 - Enable
pRegMgrConfig-Events(optional)	• Registration Indication For Registration Manager Configuration Events. • When this registration is enabled, the device learns of Reg Mgr config events via the QMI_IMS-_REG_MGR_CONFIG_IND indication. – 0x00 - Disable – 0x01 - Enable

pSMSConfig-Events(optional)	• Registration Indication For SMS Configuration Events. • When this registration is enabled, the device learns of SMS config events via the QMI_IMS_SMS_CONFIG_IND indication. – 0x00 - Disable – 0x01 - Enable
pUserConfig-Events(optional)	• Registration Indication For User Configuration Events. • When this registration is enabled, the device learns of user config events via the QMI_IMS_USER_CONFIG_IND indication. – 0x00 - Disable – 0x01 - Enable
pVoIPConfig-Events(optional)	• Registration Indication For VoIP Configuration Events. • When this registration is enabled, the device learns of VOIP config events via the QMI_IMS_VOIP_CONFIG_IND indication. – 0x00 - Disable – 0x01 - Enable

Note

One of the optional parameter is mandatory to be present in the request.

8.356.2 Field Documentation

8.356.2.1 uint8_t* pack_ims_SLQSImsConfigIndicationRegister_t::pRegMgrConfigEvents

8.356.2.2 uint8_t* pack_ims_SLQSImsConfigIndicationRegister_t::pSIPConfigEvents

8.356.2.3 uint8_t* pack_ims_SLQSImsConfigIndicationRegister_t::pSMSConfigEvents

8.356.2.4 uint8_t* pack_ims_SLQSImsConfigIndicationRegister_t::pUserConfigEvents

8.356.2.5 uint8_t* pack_ims_SLQSImsConfigIndicationRegister_t::pVoIPConfigEvents

8.357 pack_ims_SLQSSetIMSSMSConfig_t Struct Reference

Data Fields

- uint8_t * pSMSFormat
- uint8_t * pSMSOverIPNwInd
- uint8_t * pPhoneCtxtURILen
- uint8_t * pPhoneCtxtURI

8.357.1 Detailed Description

This structure contains the SLQSSetIMSSMSConfig pack parameters.

Parameters

pSMSFormat	• SMS format – 0 - 3GPP – 1 - 3GPP2
pSMSOverIPNw-Ind	• SMS over IP Network Indication Flag – TRUE - Turn on mobile-originated SMS – FALSE - Turn off mobile-originated SMS
pPhoneCtxtURI-Len	• Length of Phone context Universal Resource Identifier to follow
pPhoneCtxtURI	• Phone context universal resource identifier • Length of this string must be specified in pPhoneCtxtURILen parameter

8.357.2 Field Documentation

8.357.2.1 uint8_t* pack_ims_SLQSSetIMSSMSConfig_t::pPhoneCtxtURI

8.357.2.2 uint8_t* pack_ims_SLQSSetIMSSMSConfig_t::pPhoneCtxtURILen

8.357.2.3 uint8_t* pack_ims_SLQSSetIMSSMSConfig_t::pSMSFormat

8.357.2.4 uint8_t* pack_ims_SLQSSetIMSSMSConfig_t::pSMSOverIPNwInd

8.358 pack_ims_SLQSSetIMSUserConfig_t Struct Reference

Data Fields

- uint8_t * pIMSDomainLen
- uint8_t * pIMSDomain

8.358.1 Detailed Description

This structure contains the SLQSSetIMSUserConfig pack parameters.

Parameters

pIMSDomainLen	• Length of IMS Domain Name to follow
pIMSDomain	• IMS domain name

8.358.2 Field Documentation

8.358.2.1 uint8_t* pack_ims_SLQSSetIMSUserConfig_t::pIMSDomain

8.358.2.2 uint8_t* pack_ims_SLQSSetIMSUserConfig_t::pIMSDomainLen

8.359 pack_ims_SLQSSetIMSVoIPConfig_t Struct Reference

Data Fields

- uint16_t * pSessionExpiryTimer
- uint16_t * pMinSessionExpiryTimer
- uint8_t * pAmrWbEnable
- uint8_t * pScrAmrEnable
- uint8_t * pScrAmrWbEnable
- uint8_t * pAmrMode
- uint16_t * pAmrWBMode
- uint8_t * pAmrOctetAligned
- uint8_t * pAmrWBOctetAligned
- uint16_t * pRingingTimer
- uint16_t * pRingBackTimer
- uint16_t * pRTPRTCPInactTimer

8.359.1 Detailed Description

This structure contains the SLQSSetIMSVoIPConfig pack parameters.

Parameters

pSessionExpiry-Timer	• Session duration, in seconds
pMinSession-ExpiryTimer	• Minimum allowed value for session expiry timer, in seconds
pAmrWbEnable	• Flag to enable/disable Adaptive Multirate Codec(AMR) WideBand(WB) audio • Values: – True - Enable – False - Disable
pScrAmrEnable	• Flag to enable/disable Source Control Rate(SCR) for AMR NarrowBand (NB) • Values: – True - Enable – False - Disable
pScrAmrWb-Enable	• Flag to enable/disable SCR for AMR WB Audio • Values: – True - Enable – False - Disable

pAmrMode	• BitMask for AMR NB modes allowed • Values: – 0x1 - 4.75 kbps – 0x2 - 5.15 kbps – 0x4 - 5.9 kbps – 0x8 - 6.17 kbps – 0x10 - 7.4 kbps – 0x20 - 7.95 kbps – 0x40 - 10.2 kbps – 0x80 - 12.2 kbps
pAmrWBMode	• BitMask for AMR WB modes allowed • Values: – 0x1 - 6.60 kbps – 0x2 - 8.85 kbps – 0x4 - 12.65 kbps – 0x8 - 14.25 kbps – 0x10 - 15.85 kbps – 0x20 - 18.25 kbps – 0x40 - 19.85 kbps – 0x80 - 23.05 kbps – 0x100 - 23.85 kbps
pAmrOctet-Aligned	• Flag to indicate if the octet is aligned for AMR NB Audio • Values: – True - Aligned – False - Not aligned, Bandwidth Efficient mode
pAmrWBOctet-Aligned	• Flag to indicate if the octet is aligned for AMR WB Audio • Values: – True - Aligned – False - Not aligned, Bandwidth Efficient mode
pRingingTimer	• Duration of ringing timer, in seconds. The ringing timer starts on the ringing event. If the call is not answered within the duration of this timer, the call is disconnected.
pRingBackTimer	• Duration of ringback timer, in seconds. The ringback timer starts on the ringback event. If the call is not answered within the duration of this timer, the call is disconnected.
pRTPRTCP-InactTimer	• Duration of RTP/RTCP inactivity timer, in seconds. If no RTP/RTCP packet is received prior to the expiry of this timer, the call is disconnected.

8.359.2 Field Documentation

8.359.2.1 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pAmrMode

8.359.2.2 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pAmrOctetAligned

8.359.2.3 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pAmrWbEnable

8.359.2.4 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pAmrWBMode

8.359.2.5 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pAmrWBOctetAligned

8.359.2.6 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pMinSessionExpiryTimer

8.359.2.7 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pRingBackTimer

8.359.2.8 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pRingingTimer

8.359.2.9 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pRTPRTCPInactTimer

8.359.2.10 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pScrAmrEnable

8.359.2.11 uint8_t* pack_ims_SLQSSetIMSVoIPConfig_t::pScrAmrWbEnable

8.359.2.12 uint16_t* pack_ims_SLQSSetIMSVoIPConfig_t::pSessionExpiryTimer

8.360 pack_ims_SLQSSetRegMgrConfig_t Struct Reference

Data Fields

- uint16_t * pPriCSCFPort
- uint8_t * pCSCFPortNameLen
- uint8_t * pCSCFPortName
- uint8_t * pIMSTestMode

8.360.1 Detailed Description

This structure contains the SLQSSetRegMgrConfig pack parameters.

Parameters

pPriCSCFPort	• Primary call session control function port
pCSCFPort-NameLen	• Length of the CSCF Port name parameter to follow
pCSCFPort-Name	• Call Session control port, fully qualified domain name • Length of this string must be specified in pCSCFPortNameLen parameter
pIMSTestMode	• IMS Test mode Enabled. – TRUE - Enable, no IMS registration – FALSE - Disable, IMS registration is initiated

8.360.2 Field Documentation

8.360.2.1 uint8_t* pack_ims_SLQSSetRegMgrConfig_t::pCSCFPortName

8.360.2.2 uint8_t* pack_ims_SLQSSetRegMgrConfig_t::pCSCFPortNameLen

8.360.2.3 uint8_t* pack_ims_SLQSSetRegMgrConfig_t::pIMSTestMode

8.360.2.4 uint16_t* pack_ims_SLQSSetRegMgrConfig_t::pPriCSCFPort

8.361 pack_ims_SLQSSetSIPConfig_t Struct Reference

Data Fields

- uint16_t * pSIPLocalPort
- uint32_t * pTimerSIPReg
- uint32_t * pSubscribeTimer
- uint32_t * pTimerT1
- uint32_t * pTimerT2
- uint32_t * pTimerTf
- uint8_t * pSigCompEnabled

8.361.1 Detailed Description

This structure contains the SLQSSetSIPConfig pack parameters.

Parameters

pSIPLocalPort	• Primary call session control function SIP port number
pTimerSIPReg	• Initial SIP registration duration from the User equipment, in seconds
pSubscribeTimer	• Duration of the subscription by the UE for IMS registration notifications, in seconds
pTimerT1	• RTT estimate, in milliseconds
pTimerT2	• The maximum retransmit interval for non-invite requests and invite responses, in milliseconds
pTimerTf	• Non-invite transaction timeout timer, in milliseconds
pSigComp-Enabled	• Sig Comp Status – TRUE - Enable – FALSE - Disable

8.361.2 Field Documentation

8.361.2.1 uint8_t* pack_ims_SLQSSetSIPConfig_t::pSigCompEnabled

8.361.2.2 uint16_t* pack_ims_SLQSSetSIPConfig_t::pSIPLocalPort

8.361.2.3 uint32_t* pack_ims_SLQSSetSIPConfig_t::pSubscribeTimer

8.361.2.4 uint32_t* pack_ims_SLQSSetSIPConfig_t::pTimerSIPReg

8.361.2.5 uint32_t* pack_ims_SLQSSetSIPConfig_t::pTimerT1

8.361.2.6 uint32_t* pack_ims_SLQSSetSIPConfig_t::pTimerT2

8.361.2.7 uint32_t* pack_ims_SLQSSetSIPConfig_t::pTimerTf

8.362 pack_imsa_SLQSRegisterIMSAIndication_t Struct Reference

Data Fields

- int has_RegStatusConfig
- uint8_t RegStatusConfig
- int has_ServiceStatusConfig
- uint8_t ServiceStatusConfig
- int has_RatHandoverStatusConfig
- uint8_t RatHandoverStatusConfig
- int has_PdpStatusConfig
- uint8_t PdpStatusConfig

8.362.1 Detailed Description

This structure contains parameters of IMSA Config Indication Register

Parameters

RegStatus-Config(optional)	• Register Indication For Registration status. • When this registration is enabled, the device learns of Registration status via the QMI_IMSA_-REGISTRATION_STATUS_IND indication. – 0x00 - Disable – 0x01 - Enable
ServiceStatus-Config(optional)	• Register Indication For Service status Events. • When this registration is enabled, the device learns of Service status via the QMI_IMSA_SER-VICE_STATUS_IND indication. – 0x00 - Disable – 0x01 - Enable
RatHandover-Status-Config(optional)	• Registration Indication For RAT handover status. • When this registration is enabled, the device learns of RAT handover status via the QMI_IMSA-_RAT_HANDOVER_STATUS_IND indication. – 0x00 - Disable – 0x01 - Enable

PdpStatus-Config(optional)	• PDP Status Configuration. – 0x00 - Disable – 0x01 - Enable

Note

One of the optional parameter is mandatory to be present in the request.

8.362.2 Field Documentation

8.362.2.1 int pack_imsa_SLQSRegisterIMSAIndication_t::has_PdpStatusConfig

8.362.2.2 int pack_imsa_SLQSRegisterIMSAIndication_t::has_RatHandoverStatusConfig

8.362.2.3 int pack_imsa_SLQSRegisterIMSAIndication_t::has_RegStatusConfig

8.362.2.4 int pack_imsa_SLQSRegisterIMSAIndication_t::has_ServiceStatusConfig

8.362.2.5 uint8_t pack_imsa_SLQSRegisterIMSAIndication_t::PdpStatusConfig

8.362.2.6 uint8_t pack_imsa_SLQSRegisterIMSAIndication_t::RatHandoverStatusConfig

8.362.2.7 uint8_t pack_imsa_SLQSRegisterIMSAIndication_t::RegStatusConfig

8.362.2.8 uint8_t pack_imsa_SLQSRegisterIMSAIndication_t::ServiceStatusConfig

8.363 pack_loc_Delete_Assist_Data_t Struct Reference

Data Fields

- loc_SVInfo * pSVInfo
- loc_GnssData * pGnssData
- loc_CellDb * pCellDb
- loc_ClkInfo * pClkInfo
- loc_BdsSVInfo * pBdsSVInfo
- uint16_t Tlvresult

8.363.1 Detailed Description

This structure contains LOC delete assist data pack

Parameters

pSVInfo	• Pointer to struct loc_SVInfo. See loc_SVInfo for more information
pGnssData	• Pointer to struct loc_GnssData. See loc_GnssData for more information
pCellDb	• Pointer to struct loc_CellDb. See loc_CellDb for more information

pClkInfo	• Pointer to struct loc_ClkInfo. See loc_ClkInfo for more information
pBdsSVInfo	• Pointer to struct loc_BdsSVInfo. See loc_BdsSVInfo for more information
TlvResult	• Pack delete assist data request result.

8.363.2 Field Documentation

8.363.2.1 loc_BdsSVInfo* pack_loc_Delete_Assist_Data_t::pBdsSVInfo

8.363.2.2 loc_CellDb* pack_loc_Delete_Assist_Data_t::pCellDb

8.363.2.3 loc_ClkInfo* pack_loc_Delete_Assist_Data_t::pClkInfo

8.363.2.4 loc_GnssData* pack_loc_Delete_Assist_Data_t::pGnssData

8.363.2.5 loc_SVInfo* pack_loc_Delete_Assist_Data_t::pSVInfo

8.363.2.6 uint16_t pack_loc_Delete_Assist_Data_t::TlvResult

8.364 pack_loc_EventRegister_t Struct Reference

Data Fields

- uint64_t eventRegister
- uint16_t TlvResult

8.364.1 Detailed Description

This structure contains the Parameter for RegisterEvents

Parameters

eventRegister	• Specifies the events that the control point is interested in receiving. -Values – 0x00000001 - to receive position report event indications – 0x00000002 - to receive satellite report event indications.These reports are sent at a 1 Hz rate. – 0x00000004 - to receive NMEA reports for position and satellites in view.The report is at a 1 Hz rate. – 0x00000008 - to receive NI Notify/Verify request event indications – 0x00000010 - to receive time injection request event indications. – 0x00000020 - to receive predicted orbits request event indications. – 0x00000040 - to receive position injection request event indications. – 0x00000080 - to receive engine state report event indications. – 0x00000100 - to receive fix session status report event indications. – 0x00000200 - to receive Wi-Fi position request event indications. – 0x00000400 - to receive notifications from the location engine indicating its readiness to accept data from the sensors(accelerometer, gyroscope, etc.). – 0x00000800 - to receive time sync requests from the GPS engine. Time sync enables the GPS engine to synchronize its clock with the sensor processor's clock. – 0x00001000 - to receive Stationary Position Indicator (SPI) streaming report indications. – 0x00002000 - to receive location server requests. These requests are generated when the service wishes to establish a connection with a location server. – 0x00004000 - to receive notifications related to network-initiated Geofences. These events notify the client when a network-initiated Geofence is added, deleted, or edited. – 0x00008000 - to receive Geofence alerts. These alerts are generated to inform the client of the changes that may affect a Geofence, e.g., if GPS is turned off or if the network is unavailable. – 0x00010000 - to receive notifications when a Geofence is breached. These events are generated when a UE enters or leaves the perimeter of a Geofence. This breach report is for a single Geofence. – 0x00020000 - to register for pedometer control requests from the location engine. The location engine sends this event to control the injection of pedometer reports. – 0x00040000 - to register for motion data control requests from the location engine. The location engine sends this event to control the injection of motion data. – 0x00080000 - to receive notification when a batch is full. The location engine sends this event to notify of Batch Full for ongoing batching session. – 0x00100000 - to receive position report indications along with an ongoing batching session. The location engine sends this event to notify the batched position report while a batching session is ongoing. – 0x00200000 - to receive Wi-Fi Access Point (AP) data inject request event indications. – 0x00400000 - to receive notifications when a Geofence is breached. These events are generated when a UE enters or leaves the perimeter of a Geofence. This breach notification is for multiple Geofences. Breaches from multiple Geofences are all batched and sent in the same notification. – 0x00800000 - to receive notifications from the location engine indicating its readiness to accept vehicle data (vehicle accelerometer, vehicle angular rate, vehicle odometry, etc.). – 0x01000000 - to receive system clock and satellite measurement report events (system clock, SV time, Doppler, etc.). – 0x02000000 - to receive satellite position reports as polynomials.Reports are generated only for the GNSS satellite constellations that are enabled using QMI_LOC_SET_GNSS_-CONSTELL_REPORT_CONFIG.

Note

Multiple events can be registered by OR the individual masks and sending them in this TLV. All unused bits in this mask must be set to 0.

Parameters

TlvResult	• Pack result.

8.364.2 Field Documentation

8.364.2.1 uint64_t pack_loc_EventRegister_t::eventRegister

8.364.2.2 uint16_t pack_loc_EventRegister_t::TlvResult

8.365 pack_loc_SetExtPowerState_t Struct Reference

Data Fields

- uint32_t extPowerState
- uint16_t TlvResult

8.365.1 Detailed Description

This structure contains the Parameter External Power Source State pack.

Parameters

extPowerState	• Specifies the Power state; injected by the control point. • Values – 0 - Device is not connected to an external power source – 1 - Device is connected to an external power source – 2 - Unknown external power state
TlvResult	• Pack result.

8.365.2 Field Documentation

8.365.2.1 uint32_t pack_loc_SetExtPowerState_t::extPowerState

8.365.2.2 uint16_t pack_loc_SetExtPowerState_t::TlvResult

8.366 pack_loc_SetOperationMode_t Struct Reference

Data Fields

- uint32_t mode
- uint16_t TlvResult

8.366.1 Detailed Description

This structure contains Set Operation Mode pack

Parameters

mode	• Valid values: – eQMI_LOC_OPER_MODE_DEFAULT (1) - Use the default engine mode – eQMI_LOC_OPER_MODE_MSB (2) - Use the MS-based mode – eQMI_LOC_OPER_MODE_MSA (3) - Use the MS-assisted mode – eQMI_LOC_OPER_MODE_STANDALONE (4) - Use Standalone mode – eQMI_LOC_OPER_MODE_CELL_ID (5) - Use cell ID; this mode is only valid for GSM/UMTS networks – eQMI_LOC_OPER_MODE_WWAN (6) - Use WWAN measurements to calculate the position; if this mode is set, AFLT will be used for 1X networks and OTDOA will be used for LTE networks
Tlvresult	• Pack result.

8.366.2 Field Documentation

8.366.2.1 uint32_t pack_loc_SetOperationMode_t::mode

8.366.2.2 uint16_t pack_loc_SetOperationMode_t::Tlvresult

8.367 pack_loc_SLQSLOCGetBestAvailPos_t Struct Reference

Data Fields

- uint32_t xid
- uint16_t Tlvresult

8.367.1 Detailed Description

This structure contains Set Operation Mode pack

Parameters

xid	• Identifies the transaction. • The transaction ID is returned in the Get Best Available Position indication.
Tlvresult	• Pack result.

8.367.2 Field Documentation

8.367.2.1 uint16_t pack_loc_SLQSLOCGetBestAvailPos_t::Tlvresult

8.367.2.2 uint32_t pack_loc_SLQSLOCGetBestAvailPos_t::xid

8.368 pack_loc_SLQSLOCGetServer_t Struct Reference

Data Fields

- uint32_t serverType
- int has_serverAddrTypeMask
- uint8_t serverAddrTypeMask

8.368.1 Detailed Description

This structure contains parameters to Gets the location server. Please check has_<Param_Name> field for presence of optional parameters

Parameters

serverType	• Type of server. • Valid values – eQMI_LOC_SERVER_TYPE_CDMA_PDE (1) - Server type is CDMA PDE – eQMI_LOC_SERVER_TYPE_CDMA_MPC (2) - Server type is CDMA MPC – eQMI_LOC_SERVER_TYPE_UMTS_SLP (3) - Server type is UMTS SLP – eQMI_LOC_SERVER_TYPE_CUSTOM_PDE (4)- Server type is custom PDE
serverAddrTypeMask	• Optional parameter • Type of address the client wants. If unspecified, the indication will contain all the types of addresses it has for the specified server type. • Valid bitmasks – 0x01 - IPv4 – 0x02 - IPv6 – 0x04 - URL

8.368.2 Field Documentation

8.368.2.1 int pack_loc_SLQSLOCGetServer_t::has_serverAddrTypeMask

8.368.2.2 uint8_t pack_loc_SLQSLOCGetServer_t::serverAddrTypeMask

8.368.2.3 uint32_t pack_loc_SLQSLOCGetServer_t::serverType

8.369 pack_loc_SLQSLOCInjectPosition_t Struct Reference

Data Fields

- double latitude
- int has_latitude
- double longitude
- int has_longitude
- float horUncCircular

- int has_horUncCircular
- uint8_t horConfidence
- int has_horConfidence
- uint32_t horReliability
- int has_horReliability
- float altitudeWrtEllipsoid
- int has_altitudeWrtEllipsoid
- float altitudeWrtMeanSeaLevel
- int has_altitudeWrtMeanSeaLevel
- float vertUnc
- int has_vertUnc
- uint8_t vertConfidence
- int has_vertConfidence
- uint32_t vertReliability
- int has_vertRelicability
- altSrcInfo_t altitudeSrcInfo
- int has_altitudeSrcInfo
- uint64_t timestampUtc
- int has_timestampUtc
- uint32_t timestampAge
- int has_timestampAge
- uint32_t positionSrc
- int has_positionSrc
- float rawHorUncCircular
- int has_rawHorUncCircular
- uint8_t rawHorConfidence
- int has_rawHorConfidence

8.369.1 Detailed Description

This structure contains LOC Inject Position parameters Please check has_<Param_Name> field for presence of optional parameters

Parameters

latitude	• Optional parameter • Type - Floating point • Units - Degrees • Range - -90.0 to 90.0 • Positive values indicate northern latitude • Negative values indicate southern latitude • Note - This field must be specified together with pLongitude and pHorUncCircular.
longitude	• Optional parameter • Type - Floating point • Units - Degrees • Range - -180.0 to 180.0 • Positive values indicate eastern latitude • Negative values indicate western latitude • Note - This field must be specified together with pLatitude and pHorUncCircular.

horUncCircular	• Optional parameter • Horizontal position uncertainty. • Units - Meters • Note - This field must be specified together with pLatitude and pLongitude.
horConfidence	• Optional parameter • Horizontal confidence. • Units - Percent • Values – Valid Values - 1 to 99 – Invalid Values - 0, 101 to 255 – If 100 is received, reinterpret to 99 • Note - This field must be specified together with horizontal uncertainty. If not specified when pHorUncCircular is set, the default value is 50.
horReliability	• Optional parameter – Values * 0 - Location reliability is not set. * 1 - Location reliability is very low; use it at your own risk * 2 - Location reliability is low; little or no cross-checking is possible. * 3 - Location reliability is medium; limited cross-check passed * 4 - Location reliability is high; strong cross-check passed
altitudeWrt-Ellipsoid	• Optional parameter • Altitude With Respect to Ellipsoid. • Units - Meters • Values – Positive - height – Negative = depth
altitudeWrt-MeanSeaLevel	• Optional parameter • Altitude With Respect to Sea Level. • Units - Meters
vertUnc	• Optional parameter • Vertical uncertainty. • Units - Meters • Note - This is mandatory if either pAltitudeWrtEllipsoid or pAltitudeWrtMeanSeaLevel is specified.

vertConfidence	• Optional parameter • Vertical confidence. • Units - Percentage • Values – Valid Values - 0 to 99 – Invalid Values - 0, 100-256 – If 100 is received, reinterpret to 99 • Note - This field must be specified together with the vertical uncertainty. If not specified, the default value will be 50.
vertReliability	• Optional parameter – Values * 0 - Location reliability is not set. * 1 - Location reliability is very low; use it at your own risk. * 2 - Location reliability is low; little or no cross-checking is possible * 3 - Location reliability is medium; limited cross-check passed * 4 - Location reliability is high; strong cross-check passed
altitudeSrcInfo	• Optional parameter – Pointer to struct altitudeSrcInfo. See altitudeSrcInfo for more information
timestampUtc	• Optional parameter • UTC timestamp • Units - Milliseconds since Jan. 1, 1970
timestampAge	• Optional parameter • Position age, which is an estimate of how long ago this fix was made. • Units - Milliseconds
positionSrc	• Optional parameter • Source from which this position was obtained • Valid values – 0 - Position source is GNSS – 1 - Position source is Cell ID – 2 - Position source is Enhanced Cell ID – 3 - Position source is Wi-Fi – 4 - Position source is Terrestrial – 5 - Position source is GNSS Terrestrial Hybrid – 6 - Other sources • Note - If altitude is specified and the altitude source is not specified, the engine assumes that the altitude was obtained using the specified position source. – If both altitude and altitude source are specified, the engine assumes that only latitude and longitude were obtained using the specified position source.

rawHorUncCircular	• Optional parameter • Horizontal position uncertainty (circular) without any optimization. • Units - Meters
rawHorConfidence	• Optional parameter • Horizontal confidence associated with raw horizontal uncertainty • Units: Percent • Values – Valid values - 1 to 99 – Invalid values - 0, 101 to 255 – If 100 is received, reinterpret to 99 • Note - This field must be specified together with raw horizontal uncertainty. If not specified when rawHorUncCircular is set, the default value is 50.

8.369.2 Field Documentation

8.369.2.1 altSrcInfo_t pack_loc_SLQSLOCInjectPosition_t::altitudeSrcInfo

8.369.2.2 float pack_loc_SLQSLOCInjectPosition_t::altitudeWrtEllipsoid

8.369.2.3 float pack_loc_SLQSLOCInjectPosition_t::altitudeWrtMeanSeaLevel

8.369.2.4 int pack_loc_SLQSLOCInjectPosition_t::has_altitudeSrcInfo

8.369.2.5 int pack_loc_SLQSLOCInjectPosition_t::has_altitudeWrtEllipsoid

8.369.2.6 int pack_loc_SLQSLOCInjectPosition_t::has_altitudeWrtMeanSeaLevel

8.369.2.7 int pack_loc_SLQSLOCInjectPosition_t::has_horConfidence

8.369.2.8 int pack_loc_SLQSLOCInjectPosition_t::has_horReliability

8.369.2.9 int pack_loc_SLQSLOCInjectPosition_t::has_horUncCircular

8.369.2.10 int pack_loc_SLQSLOCInjectPosition_t::has_latitude

8.369.2.11 int pack_loc_SLQSLOCInjectPosition_t::has_longitude

8.369.2.12 int pack_loc_SLQSLOCInjectPosition_t::has_positionSrc

8.369.2.13 int pack_loc_SLQSLOCInjectPosition_t::has_rawHorConfidence

8.369.2.14 int pack_loc_SLQSLOCInjectPosition_t::has_rawHorUncCircular

8.369.2.15 int pack_loc_SLQSLOCInjectPosition_t::has_timestampAge

8.369.2.16 int pack_loc_SLQSLOCInjectPosition_t::has_timestampUtc

8.369.2.17 int pack_loc_SLQSLOCInjectPosition_t::has_vertConfidence

8.369.2.18 int pack_loc_SLQSLOCInjectPosition_t::has_vertRelicability

8.369.2.19 int pack_loc_SLQSLOCInjectPosition_t::has_vertUnc

8.369.2.20 uint8_t pack_loc_SLQSLOCInjectPosition_t::horConfidence

8.369.2.21 uint32_t pack_loc_SLQSLOCInjectPosition_t::horReliability

8.369.2.22 float pack_loc_SLQSLOCInjectPosition_t::horUncCircular

8.369.2.23 double pack_loc_SLQSLOCInjectPosition_t::latitude

8.369.2.24 double pack_loc_SLQSLOCInjectPosition_t::longitude

8.369.2.25 uint32_t pack_loc_SLQSLOCInjectPosition_t::positionSrc

8.369.2.26 uint8_t pack_loc_SLQSLOCInjectPosition_t::rawHorConfidence

8.369.2.27 float pack_loc_SLQSLOCInjectPosition_t::rawHorUncCircular

8.369.2.28 uint32_t pack_loc_SLQSLOCInjectPosition_t::timestampAge

8.369.2.29 uint64_t pack_loc_SLQSLOCInjectPosition_t::timestampUtc

8.369.2.30 uint8_t pack_loc_SLQSLOCInjectPosition_t::vertConfidence

8.369.2.31 uint32_t pack_loc_SLQSLOCInjectPosition_t::vertReliability

8.369.2.32 float pack_loc_SLQSLOCInjectPosition_t::vertUnc

8.370 pack_loc_SLQSLOCInjectSensorData_t Struct Reference

Data Fields

- int has_opaqueId
- uint32_t opaqueId
- int has_accleroData
- sensorData_t acceleroData
- int has_gyroData
- sensorData_t gyroData
- int has_acceleroTimeSrc
- uint32_t acceleroTimeSrc
- int has_gyroTimeSrc
- uint32_t gyroTimeSrc
- int has_accelTemp
- tempData_t accelTemp
- int has_gyroTemp
- tempData_t gyroTemp

8.370.1 Detailed Description

This structure contains parameters to inject sensor data into the GNSS location engine Please check has_<Param-_Name> field for presence of optional parameters

Parameters

opaqueId	• Opaque Identifier (Optional parameter) • An opaque identifier that is sent in by the client that will be echoed in the indication so the client can relate the indication to the request.
acceleroData	• 3-Axis Accelerometer Data (Optional parameter) • Pointer to struct sensorData. See sensorData_t for more information
gyroData	• 3-Axis Cyroscope Data (Optional parameter) • Pointer to struct sensorData. See sensorData_t for more information
acceleroTimeSrc	• 3-Axis Accelerometer Data Time Source (Optional parameter) • The location service uses this field to identify the time reference used in the accelerometer data time stamps. • If not specified, the location service assumes that the time source for the accelerometer data is unknown. • Valid values – 0 - Sensor time source is unspecified – 1 - Time source is common between the sensors and the location engine
gyroTimeSrc	• 3-Axis Gyroscope Data Time Source (Optional) • The location service uses this field to identify the time reference used in the gyroscope data time stamps. • If not specified, the location service assumes that the time source for the gyroscope data is unknown. • Valid values – 0 - Sensor time source is unspecified – 1 - Time source is common between the sensors and the location engine
accelTemp	• Accelerometer Temperature Data (Optional parameter) • Pointer to struct tempratureData. See tempData_t for more information
gyroTemp	• Gyroscope Temperature Data (Optional parameter) • Pointer to struct tempratureData. See tempData_t for more information

8.370.2 Field Documentation

8.370.2.1 sensorData_t pack_loc_SLQSLOCInjectSensorData_t::acceleroData

8.370.2.2 uint32_t pack_loc_SLQSLOCInjectSensorData_t::acceleroTimeSrc

8.370.2.3 tempData_t pack_loc_SLQSLOCInjectSensorData_t::accelTemp

8.370.2.4 sensorData_t pack_loc_SLQSLOCInjectSensorData_t::gyroData

8.370.2.5 tempData_t pack_loc_SLQSLOCInjectSensorData_t::gyroTemp

8.370.2.6 uint32_t pack_loc_SLQSLOCInjectSensorData_t::gyroTimeSrc

8.370.2.7 int pack_loc_SLQSLOCInjectSensorData_t::has_acceleroTimeSrc

8.370.2.8 int pack_loc_SLQSLOCInjectSensorData_t::has_accelTemp

8.370.2.9 int pack_loc_SLQSLOCInjectSensorData_t::has_accleroData

8.370.2.10 int pack_loc_SLQSLOCInjectSensorData_t::has_gyroData

8.370.2.11 int pack_loc_SLQSLOCInjectSensorData_t::has_gyroTemp

8.370.2.12 int pack_loc_SLQSLOCInjectSensorData_t::has_gyroTimeSrc

8.370.2.13 int pack_loc_SLQSLOCInjectSensorData_t::has_opaqueId

8.370.2.14 uint32_t pack_loc_SLQSLOCInjectSensorData_t::opaqueId

8.371 pack_loc_SLQSLOCInjectUTCTime_t Struct Reference

Data Fields

- uint64_t timeMsec
- uint32_t timeUncMsec

8.371.1 Detailed Description

This structure contains inject UTC time parameter.

Parameters

timeMsec	• The UTC time since Jan. 1, 1970
timeUncMsec	• The time Uncertainty

8.371.2 Field Documentation

8.371.2.1 uint64_t pack_loc_SLQSLOCInjectUTCTime_t::timeMsec

8.371.2.2 uint32_t pack_loc_SLQSLOCInjectUTCTime_t::timeUncMsec

8.372 pack_loc_SLQSLOCSetCradleMountConfig_t Struct Reference

Data Fields

- uint32_t state
- int has_confidence
- uint8_t confidence

8.372.1 Detailed Description

This structure contains parameters to set current cradle mount configuration Please check has_<Param_Name> field for presence of optional parameters

Parameters

state	• Cradle Mount State • Valid values: – 0 - Device is mounted on the cradle – 1 - Device is not mounted on the cradle – 2 - Unknown cradle mount state
confidence	• Cradle Mount Confidence (Optional) • Confidence in the Cradle Mount state expressed as a percentage. • Range - 0 to 100

8.372.2 Field Documentation

8.372.2.1 uint8_t pack_loc_SLQSLOCSetCradleMountConfig_t::confidence

8.372.2.2 int pack_loc_SLQSLOCSetCradleMountConfig_t::has_confidence

8.372.2.3 uint32_t pack_loc_SLQSLOCSetCradleMountConfig_t::state

8.373 pack_loc_SLQSLOCSetServer_t Struct Reference

Data Fields

- uint32_t serverType
- loc_IPv4Config * pIPv4Config
- loc_IPv6Config * pIPv6Config
- loc_URLAddrInfo * pURLAddr

8.373.1 Detailed Description

This structure contains parameters to set A-GPS Server

Parameters

serverType	• Type of server • Valid values: – 1 - Server type is CDMA PDE – 2 - Server type is CDMA MPC – 3 - Server type is UMTS SLP – 4 - Server type is custom PDE

pIPv4Config	• IPv4 address and port (Optional) • See loc_IPv4Config for more information
pIPv6Config	• IPv6 address and port (Optional) • See loc_IPv6Config for more information
pURLAddr	• Uniform Resource Locator (Optional) • See loc_URLAddrInfo for more information

8.373.2 Field Documentation

8.373.2.1 loc_IPv4Config* pack_loc_SLQSLOCSetServer_t::pIPv4Config

8.373.2.2 loc_IPv6Config* pack_loc_SLQSLOCSetServer_t::pIPv6Config

8.373.2.3 loc_URLAddrInfo* pack_loc_SLQSLOCSetServer_t::pURLAddr

8.373.2.4 uint32_t pack_loc_SLQSLOCSetServer_t::serverType

8.374 pack_loc_Start_t Struct Reference

Data Fields

- uint8_t SessionId
- uint32_t * pRecurrenceType
- uint32_t * pHorizontalAccuracyLvl
- uint32_t * pIntermediateReportState
- uint32_t * pMinIntervalTime
- loc_LocApplicationInfo * pApplicationInfo
- uint32_t * pConfigAltitudeAssumed
- uint16_t Tlvresult

8.374.1 Detailed Description

This structure contains the LOC Start pack

Parameters

SessionId	• ID of the session as identified by the control point. • Range: 0 to 255
pRecurrence-Type	• Optional Parameter • Specifies the type of session in which the control point is interested. • Defaults to SINGLE. -Values – 1 - Request periodic position fixes – 2 - Request a single position fix

pHorizontal-AccuracyLvl	• Optional Parameter • Specifies the horizontal accuracy level required by the control point. • Defaults to LOW • Values – 1 - Low accuracy – 2 - Medium accuracy – 3 - High accuracy
pIntermediate-ReportState	• Optional Parameter • Specifies if the control point is interested in receiving intermediate reports. • ON by default. • Values – 1 - Intermediate reports are turned on – 2 - Intermediate reports are turned off
pMinInterval-Time	• Optional Parameter • Minimum time interval, specified by the control point, that must elapse between position reports. • Units - Milliseconds • Default - 1000 ms
LocApplication-Info	• Optional Parameter • LOC Application Parameters • See loc_LocApplicationInfo for more information
pConfigAltitude-Assumed	• Optional Parameter • Configuration for Altitude Assumed Info in GNSS SV Info Event • Defaults to ENABLED. • Values – 1 - Enable Altitude Assumed information in GNSS SV Info Event – 2 - Disable Altitude Assumed information in GNSS SV Info Event
Tlvresult	• Unpack result.

8.374.2 Field Documentation

8.374.2.1 loc_LocApplicationInfo* pack_loc_Start_t::pApplicationInfo

8.374.2.2 uint32_t* pack_loc_Start_t::pConfigAltitudeAssumed

8.374.2.3 uint32_t* pack_loc_Start_t::pHorizontalAccuracyLvl

8.374.2.4 uint32_t* pack_loc_Start_t::pIntermediateReportState

8.374.2.5 uint32_t* pack_loc_Start_t::pMinIntervalTime

8.374.2.6 uint32_t* pack_loc_Start_t::pRecurrenceType

8.374.2.7 uint8_t pack_loc_Start_t::SessionId

8.374.2.8 uint16_t pack_loc_Start_t::Tlvresult

8.375 pack_loc_Stop_t Struct Reference

Data Fields

- uint8_t SessionId
- uint16_t Tlvresult

8.375.1 Detailed Description

This structure contains Stop LOC pack

Parameters

sessionId	• ID of the session as identified by the control point. • Range: 0 to 255
Tlvresult	• Unpack result.

8.375.2 Field Documentation

8.375.2.1 uint8_t pack_loc_Stop_t::SessionId

8.375.2.2 uint16_t pack_loc_Stop_t::Tlvresult

8.376 pack_nas_InitiateDomainAttach_t Struct Reference

Data Fields

- uint32_t action

8.376.1 Detailed Description

Pack structure for Initiates a domain attach/detach of the device.

Parameters

action	• Domain action to attempt 1 - Attach 2 - Detach

8.376.2 Field Documentation

8.376.2.1 uint32_t pack_nas_InitiateDomainAttach_t::action

8.377 pack_nas_PerformNetworkScanPCI_t Struct Reference

Data Fields

- uint8_t * pNetworkType
- uint32_t * pScanType

8.377.1 Field Documentation

8.377.1.1 uint8_t* pack_nas_PerformNetworkScanPCI_t::pNetworkType

8.377.1.2 uint32_t* pack_nas_PerformNetworkScanPCI_t::pScanType

8.378 pack_nas_SetACCOLC_t Struct Reference

Data Fields

- int8_t spc [6]
- uint8_t accolc

8.378.1 Detailed Description

Sets the access overload class (ACCOLC)

Parameters

spc	• service programming code NULL-terminated string of six digit
accolc	• ACCOLC : Valid range is 0 to 15

8.378.2 Field Documentation

8.378.2.1 uint8_t pack_nas_SetACCOLC_t::accolc

8.378.2.2 int8_t pack_nas_SetACCOLC_t::spc[6]

8.379 pack_nas_SetCDMANetworkParameters_t Struct Reference

Data Fields

- char * pSPC
- uint8_t * pForceRev0
- uint8_t * pCustomSCP
- uint32_t * pProtocol
- uint32_t * pBroadcast
- uint32_t * pApplication
- uint32_t * pRoaming

8.379.1 Detailed Description

Pack structure to set CDMA Network parameters.

Parameters

pSPC	• Six digit service programming code (not necessary when only the roaming field is being set)
pForceRev0	• (Optional)Force CDMA 1x-EV-DO Rev. 0 mode – 0 - Disabled – 1 - Enabled Note: Enabled can only be specified if pCustomSCP state is set to Disabled
pCustomSCP	• (Optional)Use a custom config for CDMA 1x-EV-DO SCP – 0 - Disabled – 1 - Enabled Note: Enabled can only be specified if pForceRev0 is set to Disabled
pProtocol	• Protocol mask for custom SCP config – 0x00000001 - Subtype 2 Physical Layer – 0x00000002 - Enhanced CCMAC – 0x00000004 - Enhanced ACMAC – 0x00000008 - Enhanced FTCMAC – 0x00000010 - Subtype 3 RTCMAC – 0x00000020 - Subsystem 1 RTCMAC – 0x00000040 - Enhanced Idle – 0x00000080 - Generic Multimode Capable Disc Port – 0xFFFFFFFF - Unknown
pBroadcast	• Broadcast mask for custom SCP config – 0x00000001 - Generic broadcast enabled – 0xFFFFFFFF - Unknown
pApplication	• Application mask for custom SCP config – 0x00000001 - SN Multiflow Packet Application – 0x00000002 - SN Enhanced Multiflow Packet Application – 0xFFFFFFFF - Unknown
pRoaming	• Roaming preference – 0 - Automatic – 1 - Home Only – 2 - Affiliated Roaming Only – 3 - Home and Affiliated Roaming – 0xFFFFFFFF - Unknown

8.379.2 Field Documentation

8.379.2.1 uint32_t* pack_nas_SetCDMANetworkParameters_t::pApplication

8.379.2.2 uint32_t* pack_nas_SetCDMANetworkParameters_t::pBroadcast

8.379.2.3 uint8_t* pack_nas_SetCDMANetworkParameters_t::pCustomSCP

8.379.2.4 uint8_t* pack_nas_SetCDMANetworkParameters_t::pForceRev0

8.379.2.5 uint32_t* pack_nas_SetCDMANetworkParameters_t::pProtocol

8.379.2.6 uint32_t* pack_nas_SetCDMANetworkParameters_t::pRoaming

8.379.2.7 char* pack_nas_SetCDMANetworkParameters_t::pSPC

8.380 pack_nas_SetNetworkPreference_t Struct Reference

Data Fields

- uint32_t TechnologyPref
- uint32_t Duration
- uint16_t Tlvresult

8.380.1 Detailed Description

This structure contains pack set network preference parameters.

Parameters

TechnologyPref[IN]	• Bitmask representing the radio technology preference set. • No bits set indicates to the device to automatically determine the technology to use • Values: – Bit 0 - Technology is 3GPP2 – Bit 1 - Technology is 3GPP • Any combination of the following may be returned: – Bit 2 - Analog - AMPS if 3GPP2, GSM if 3GPP – Bit 3 - Digital - CDMA if 3GPP2, WCDMA if 3GPP – Bit 4 - HDR – Bit 5 - LTE – Bits 6 to 15 - Reserved
Duration[IN]	• Duration of active preference – 0 - Permanent – 1 - Power cycle – 2 - Until the end of the next call or a power cycle – 3 - Until the end of the next call, a specified time, or a power cycle – 4 to 6 - Until the end of the next call
Tlvresult	• pack result

8.380.2 Field Documentation

8.380.2.1 uint32_t pack_nas_SetNetworkPreference_t::Duration

8.380.2.2 uint32_t pack_nas_SetNetworkPreference_t::TechnologyPref

8.380.2.3 uint16_t pack_nas_SetNetworkPreference_t::Tlvresult

8.381 pack_nas_SLQSConfigSigInfo_t Struct Reference

Data Fields

- nas_RSSIThresh * pRSSIThresh
- nas_ECIOThresh * pECIOThresh
- nas_HDRSINRThresh * pHDRSINRThresh
- nas_LTESNRThresh * pLTESNRThresh
- nas_IOThresh * pIOThresh
- nas_RSRQThresh * pRSRQThresh
- nas_RSRPThresh * pRSRPThresh
- nas_LTESigRptCfg * pLTESigRptCfg
- nas_TDSCDMASINRCONFThresh * pTDSCDMASINRCONFThresh

8.381.1 Detailed Description

Structure for ConfigSigInfo pack.

Parameters

pRSSIThresh	• RSSI threshold List • See nas_RSSIThresh for more details
pECIOThresh	• ECIO Threshold List • See nas_ECIOThresh for more details
pHDRSINR-Thresh	• HDR SINR Threshold List • See nas_HDRSINRThresh for more details
pLTESNR-Thresh	• LTE SNR Threshold List • See nas_LTESNRThresh for more details
pIOThresh	• IO Threshold List • See nas_IOThresh for more details
pRSRQThresh	• RSRQ Threshold List • See nas_RSRQThresh for more details

pRSRPThresh	• RSRP Threshold List • See nas_RSRPThresh for more details
pLTESigRptCfg	• LTE signal report config • See nas_LTESigRptCfg for more details
pTDSCDMASIN-RCONFThresh	• TD-SCDMA SINR Threshold List • See nas_TDSCDMASINRCONFThresh for more details

8.381.2 Field Documentation

8.381.2.1 nas_ECIOThresh∗ pack_nas_SLQSConfigSigInfo_t::pECIOThresh

8.381.2.2 nas_HDRSINRThresh∗ pack_nas_SLQSConfigSigInfo_t::pHDRSINRThresh

8.381.2.3 nas_IOThresh∗ pack_nas_SLQSConfigSigInfo_t::pIOThresh

8.381.2.4 nas_LTESigRptCfg∗ pack_nas_SLQSConfigSigInfo_t::pLTESigRptCfg

8.381.2.5 nas_LTESNRThresh∗ pack_nas_SLQSConfigSigInfo_t::pLTESNRThresh

8.381.2.6 nas_RSRPThresh∗ pack_nas_SLQSConfigSigInfo_t::pRSRPThresh

8.381.2.7 nas_RSRQThresh∗ pack_nas_SLQSConfigSigInfo_t::pRSRQThresh

8.381.2.8 nas_RSSIThresh∗ pack_nas_SLQSConfigSigInfo_t::pRSSIThresh

8.381.2.9 nas_TDSCDMASINRCONFThresh∗ pack_nas_SLQSConfigSigInfo_t::pTDSCDMASINRCONFThresh

8.382 pack_nas_SLQSGetPLMNName_t Struct Reference

Data Fields

- uint16_t mcc
- uint16_t mnc
- uint8_t ∗ pMncPcsStatus

8.382.1 Detailed Description

This structure contains pack get operator name for specificed network parameters.

Parameters

mcc	• A 16-bit integer representation of MCC. Range: 0 to 999
mnc	• A 16-bit integer representation of MNC. Range: 0 to 999

pMncPcsStatus	• MNC PCS Digit Include Status • Used to interpret the length of the corresponding MNC reported in the PLMN TLV(0x01). • Values – TRUE - MNC is a three-digit value. e.g. a reported value of 90 corresponds to an MNC value of 090 – FALSE - MNC is a two-digit value. e.g. a reported value of 90 corresponds to an MNC value of 90

Note

If pMncPcsStatus is not present, an MNC smaller than 100 is assumed to be a two-digit value, and an MNC greater than or equal to 100 is assumed to be a three digit value.

8.382.2 Field Documentation

8.382.2.1 uint16_t pack_nas_SLQSGetPLMNName_t::mcc

8.382.2.2 uint16_t pack_nas_SLQSGetPLMNName_t::mnc

8.382.2.3 uint8_t* pack_nas_SLQSGetPLMNName_t::pMncPcsStatus

8.383 pack_nas_SLQSInitiateNetworkRegistration_t Struct Reference

Data Fields

- uint32_t regAction
- nas_MNRInfo * pMNRInfo
- uint32_t * pChangeDuration
- uint8_t * pMncPcsDigitStatus

8.383.1 Detailed Description

This structure contains Initiate Network Registration request parameters

Parameters

regAction	• Specifies one of the following register actions : – AUTO_REGISTER - Device registers according to its provisioning and optional parameters supplied with the command are ignored. – MANUAL_REGISTER - Device registers to a specified network and the optional Manual Network Register Information parameter pMNRInfo must also be included for the command to process successfully and supported only for 3GPP.
pMNRInfo	[Optional] • Pointer to structure MNRInfo – See nas_MNRInfo for more information

pChange-Duration	[Optional] • Duration of the change. – 0x00 - Power cycle - Remains active until the next device power cycle – 0x01 - Permanent - Remains active through power cycles until changed by the client
pMncPcsDigit-Status	[Optional] • MNC PCS Digit Include Status – True - MNC is a 3-digit value. – False - MNC is a 2-digit value.

8.383.2 Field Documentation

8.383.2.1 uint32_t* pack_nas_SLQSInitiateNetworkRegistration_t::pChangeDuration

8.383.2.2 uint8_t* pack_nas_SLQSInitiateNetworkRegistration_t::pMncPcsDigitStatus

8.383.2.3 nas_MNRInfo* pack_nas_SLQSInitiateNetworkRegistration_t::pMNRInfo

8.383.2.4 uint32_t pack_nas_SLQSInitiateNetworkRegistration_t::regAction

8.384 pack_nas_SLQSNasConfigSigInfo2_t Struct Reference

Data Fields

- nas_CDMARSSIThresh * pCDMARSSIThresh
- uint16_t * pCDMARSSIDelta
- nas_CDMAECIOThresh * pCDMAECIOThresh
- uint16_t * pCDMAECIODelta
- nas_HDRRSSIThresh * pHDRRSSIThresh
- uint16_t * pHDRRSSIDelta
- nas_HDRECIOThresh * pHDRECIOThresh
- uint16_t * pHDRECIODelta
- nas_HDRSINRThreshold * pHDRSINRThresh
- uint16_t * pHDRSINRDelta
- nas_HDRIOThresh * pHDRIOThresh
- uint16_t * pHDRIODelta
- nas_GSMRSSIThresh * pGSMRSSIThresh
- uint16_t * pGSMRSSIDelta
- nas_WCDMARSSIThresh * pWCDMARSSIThresh
- uint16_t * pWCDMARSSIDelta
- nas_WCDMAECIOThresh * pWCDMAECIOThresh
- uint16_t * pWCDMAECIODelta
- nas_LTERSSIThresh * pLTERSSIThresh
- uint16_t * pLTERSSIDelta
- nas_LTESNRThreshold * pLTESNRThresh
- uint16_t * pLTESNRDelta
- nas_LTERSRQThresh * pLTERSRQThresh
- uint16_t * pLTERSRQDelta
- nas_LTERSRPThresh * pLTERSRPThresh
- uint16_t * pLTERSRPDelta
- nas_LTESigRptConfig * pLTESigRptConfig

- nas_TDSCDMARSCPThresh * pTDSCDMARSCPThresh
- uint16_t * pTDSCDMARSCPDelta
- nas_TDSCDMARSSIThresh * pTDSCDMARSSIThresh
- float * pTDSCDMARSSIDelta
- nas_TDSCDMAECIOThresh * pTDSCDMAECIOThresh
- float * pTDSCDMAECIODelta
- nas_TDSCDMASINRThresh * pTDSCDMASINRThresh
- float * pTDSCDMASINRDelta

8.384.1 Detailed Description

This structure contains pack set the signal strength reporting thresholds parameters.

Parameters

pCDMARSSI-Thresh	• CDMA RSSI threshold List
pCDMARSSI-Delta	• RSSI delta (in units of 0.1 dBm). • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pCDMAECIO-Thresh	• CDMA ECIO Threshold List
pCDMAECIO-Delta	• ECIO delta (in units of 0.1 dB). • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pHDRRSSI-Thresh	• HDR RSSI Threshold List
pHDRRSSIDelta	• RSSI delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pHDRECIO-Thresh	• HDR ECIO Threshold List
pHDRECIODelta	• ECIO delta (in units of 0.1 dB) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pHDRSINR-Thresh	• HDR SINR Threshold List
pHDRSINRDelta	• SINR delta (in units of 1 SINR level) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pHDRIOThresh	• HDR IO Threshold List

pHDRIODelta	• IO delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pGSMRSSI-Thresh	• GSM RSSI Threshold List • See nas_GSMRSSIThresh for more details
pGSMRSSIDelta	• RSSI delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pWCDMARSSI-Thresh	• WCDMA RSSI Threshold List • See nas_WCDMARSSIThresh for more details
pWCDMARSSI-Delta	• RSSI delta (in units of 0.1 dBm). • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pWCDMAECIO-Thresh	• WCDMA ECIO Threshold List
pWCDMAECIO-Delta	• ECIO delta (in units of 0.1 dB) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pLTERSSI-Thresh	• LTE RSSI Threshold List
pLTERSSIDelta	• RSSI delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pLTESNR-Thresh	• LTE SNR Threshold List
pLTESNRDelta	• SNR delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pLTERSRQ-Thresh	• LTE RSRQ Threshold List
pLTERSRQ-Delta	• RSRQ delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pLTERSRP-Thresh	• LTE RSRP Threshold List

pLTERSRPDelta	• RSRP delta (in units of 0.1 dBm). • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pLTESigRpt-Config	• LTE Signal Report Config
pTDSCDMARS-CPThresh	• TDSCDMA RSCP Threshold List
pTDSCDMARS-CPDelta	• RSCP delta (in units of 0.1 dBm) • A value of 0 is rejected with a QMI_ERR_INVALID_ARG error.
pTDSCDMARS-SIThresh	• TDSCDMA RSSI Threshold List
pTDSCDMARS-SIDelta	• RSSI delta (in dBm) used by TD-SCDMA.
pTDSCDMAECI-OThresh	• TDSCDMA ECIO Threshold List
pTDSCDMAECI-ODelta	• ECIO delta (in dB) used by TD-SCDMA
pTDSCDMASIN-RThresh	• TDSCDMA SINR Threshold List
pTDSCDMASIN-RDelta	• SINR delta (in dB) used by TD-SCDMA.

Note

Mixture of threshold and delta values can be provided in the request. But for each type and RAT,only one of threshold list or delta value is to be provided.

8.384.2 Field Documentation

8.384.2.1 uint16_t* pack_nas_SLQSNasConfigSigInfo2_t::pCDMAECIODelta

8.384.2.2 nas_CDMAECIOThresh* pack_nas_SLQSNasConfigSigInfo2_t::pCDMAECIOThresh

8.384.2.3 uint16_t* pack_nas_SLQSNasConfigSigInfo2_t::pCDMARSSIDelta

8.384.2.4 nas_CDMARSSIThresh* pack_nas_SLQSNasConfigSigInfo2_t::pCDMARSSIThresh

8.384.2.5 uint16_t* pack_nas_SLQSNasConfigSigInfo2_t::pGSMRSSIDelta

8.384.2.6 nas_GSMRSSIThresh* pack_nas_SLQSNasConfigSigInfo2_t::pGSMRSSIThresh

8.384.2.7 uint16_t* pack_nas_SLQSNasConfigSigInfo2_t::pHDRECIODelta

8.384.2.8 **nas_HDRECIOThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRECIOThresh

8.384.2.9 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRIODelta

8.384.2.10 **nas_HDRIOThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRIOThresh

8.384.2.11 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRRSSIDelta

8.384.2.12 **nas_HDRRSSIThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRRSSIThresh

8.384.2.13 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRSINRDelta

8.384.2.14 **nas_HDRSINRThreshold*** pack_nas_SLQSNasConfigSigInfo2_t::pHDRSINRThresh

8.384.2.15 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSRPDelta

8.384.2.16 **nas_LTERSRPThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSRPThresh

8.384.2.17 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSRQDelta

8.384.2.18 **nas_LTERSRQThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSRQThresh

8.384.2.19 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSSIDelta

8.384.2.20 **nas_LTERSSIThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pLTERSSIThresh

8.384.2.21 **nas_LTESigRptConfig*** pack_nas_SLQSNasConfigSigInfo2_t::pLTESigRptConfig

8.384.2.22 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pLTESNRDelta

8.384.2.23 **nas_LTESNRThreshold*** pack_nas_SLQSNasConfigSigInfo2_t::pLTESNRThresh

8.384.2.24 **float*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMAECIODelta

8.384.2.25 **nas_TDSCDMAECIOThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMAECIOThresh

8.384.2.26 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMARSCPDelta

8.384.2.27 **nas_TDSCDMARSCPThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMARSCPThresh

8.384.2.28 **float*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMARSSIDelta

8.384.2.29 **nas_TDSCDMARSSIThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMARSSIThresh

8.384.2.30 **float*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMASINRDelta

8.384.2.31 **nas_TDSCDMASINRThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pTDSCDMASINRThresh

8.384.2.32 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pWCDMAECIODelta

8.384.2.33 **nas_WCDMAECIOThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pWCDMAECIOThresh

8.384.2.34 **uint16_t*** pack_nas_SLQSNasConfigSigInfo2_t::pWCDMARSSIDelta

8.384.2.35 **nas_WCDMARSSIThresh*** pack_nas_SLQSNasConfigSigInfo2_t::pWCDMARSSIThresh

8.385 pack_nas_SLQSNasGet3GPP2Subscription_t Struct Reference

Data Fields

- uint8_t namID

8.385.1 Detailed Description

Structure for 3GPP2 Subscription pack.

Parameters

namID	[Mandatory] • NAM ID of the information to be retrieved. The index starts from 0. A nam_id of 0xFF is used to retrieve information of current NAM.

8.385.2 Field Documentation

8.385.2.1 uint8_t pack_nas_SLQSNasGet3GPP2Subscription_t::namID

8.386 pack_nas_SLQSNASGeteDRXParamsExt_t Struct Reference

Data Fields

- uint8_t * pEdrxRAT
- uint32_t * pLteOpMode

8.386.1 Detailed Description

This structure contains the SLQSNASGeteDRXParamsExt request parameters.

Parameters

pEdrxRAT	[Optional] • eDRX Radio Access Technology • Values – NAS_RADIO_IF_NO_SVC (0x00) - None (no service) – NAS_RADIO_IF_CDMA_1X (0x01) - cdma2000 ® 1X – NAS_RADIO_IF_CDMA_1XEVDO (0x02) - cdma2000 ® HRPD (1xEV-DO) – NAS_RADIO_IF_AMPS (0x03) - AMPS – NAS_RADIO_IF_GSM (0x04) - GSM – NAS_RADIO_IF_UMTS (0x05) - UMTS – NAS_RADIO_IF_WLAN (0x06) - WLAN – NAS_RADIO_IF_GPS (0x07) - GPS – NAS_RADIO_IF_LTE (0x08) - LTE – NAS_RADIO_IF_TDSCDMA (0x09) - TD-SCDMA – NAS_RADIO_IF_LTE_M1 (0x0a) - LTE-M1 – NAS_RADIO_IF_LTE_NB1 (0x0b) - LTE-NB1 – NAS_RADIO_IF_NO_CHANGE (-1) - No change Note: The device will use "0x08 - NAS_-RADIO_IF_LTE" as the default value if the TLV is omitted.

pLteOpMode	[Optional] • LTE Operational Mode • Values – NAS_CIOT_SYS_MODE_NO_ SRV (0x00) - No service – NAS_CIOT_SYS_MODE_LTE_ WB (0x01) - Camped on LTE wideband – NAS_CIOT_SYS_MODE_LTE_ M1 (0x02) - Camped on LTE M1 – NAS_CIOT_SYS_MODE_LTE_ NB1 (0x03) - Camped on LTE NB1 Note: This TLV should be set when edrx_rat_type is LTE.

8.386.2 Field Documentation

8.386.2.1 uint8_t* pack_nas_SLQSNASGeteDRXParamsExt_t::pEdrxRAT

8.386.2.2 uint32_t* pack_nas_SLQSNASGeteDRXParamsExt_t::pLteOpMode

8.387 pack_nas_SLQSNasGetTxRxInfo_t Struct Reference

Data Fields

- uint8_t radio_if

8.387.1 Detailed Description

Structure for TxRx Info pack

Parameters

radio_if	[Mandatory] • Radio interface technology of the signal being measured • Valid Values – 0x01 - NAS_RADIO_IF_CDMA_1X - CDMA – 0x02 - NAS_RADIO_IF_CDMA_1XEVDO - HDR – 0x04 - NAS_RADIO_IF_GSM - GSM – 0x05 - NAS_RADIO_IF_UMTS - UMTS – 0x08 - NAS_RADIO_IF_LTE - LTE

8.387.2 Field Documentation

8.387.2.1 uint8_t pack_nas_SLQSNasGetTxRxInfo_t::radio_if

8.388 pack_nas_SLQSNasIndicationRegisterExt_t Struct Reference

Data Fields

- uint8_t * pSystemSelectionInd
- uint8_t * pDDTMInd
- uint8_t * pServingSystemInd
- uint8_t * pDualStandByPrefInd

- uint8_t * pSubscriptionInfoInd
- uint8_t * pNetworkTimeInd
- uint8_t * pSysInfoInd
- uint8_t * pSignalStrengthInd
- uint8_t * pErrorRateInd
- uint8_t * pHDRNewUATIAssInd
- uint8_t * pHDRSessionCloseInd
- uint8_t * pManagedRoamingInd
- uint8_t * pNetworkRejectInd
- uint8_t * pSuppressSysInfoInd
- uint8_t * pLTECphyCa
- uint8_t * pEdrxChangeInfoInd

8.388.1 Detailed Description

This structure contains pack indication register parameters.

Parameters

pSystemSelectionInd	[Optional] • System Selection Preference indication registration. The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pDDTMInd	[Optional] • DDTM (Data Dedicated Transmission Mode) indication registration. The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pServingSystemInd	[Optional] • Serving System indication registration. The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pDualStandByPrefInd	[Optional] • Dual Standby Preference indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pSubscriptionInfoInd	[Optional] • Subscription Information indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pNetworkTimeInd	[Optional] • Network Time indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable

pSysInfoInd	[Optional] • System Information indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pSignalStrength-Ind	[Optional] • Signal Strength indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pErrorRateInd	[Optional] • Error Rate indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pHDRNewUATI-AssInd	[Optional] • HDR New UATI Assigned indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pHDRSession-CloseInd	[Optional] • HDR Session Closed indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pManaged-RoamingInd	[Optional] • Managed Roaming indication registration.The callbacks would not be invoked if the indication is disabled. – 0x00 - Disable
pNetworkReject-Ind	[Optional] • Network reject information indication registration.The following callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable
pSuppressSys-InfoInd	[Optional] • Controls the reporting of QMI_NAS_SYS_INFO_IND when only the reject_cause field has changed. Values: – 0x00 - Disable – 0x01 - Enable- 0x01 - Enable
pLTECphyCa	[Optional] • LTE Physical Carrier Aggregation Information.The following callbacks would not be invoked if the indication is disabled. – 0x00 - Disable (default value) – 0x01 - Enable

pEdrxChange-InfoInd	[Optional] • EDRX Change Info indication registration.The following callbacks would not be invoked if the indication is disabled. – 0x00 - Disable – 0x01 - Enable

8.388.2 Field Documentation

8.388.2.1 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pDDTMInd

8.388.2.2 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pDualStandByPrefInd

8.388.2.3 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pEdrxChangeInfoInd

8.388.2.4 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pErrorRateInd

8.388.2.5 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pHDRNewUATIAssInd

8.388.2.6 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pHDRSessionCloseInd

8.388.2.7 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pLTECphyCa

8.388.2.8 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pManagedRoamingInd

8.388.2.9 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pNetworkRejectInd

8.388.2.10 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pNetworkTimeInd

8.388.2.11 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pServingSystemInd

8.388.2.12 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pSignalStrengthInd

8.388.2.13 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pSubscriptionInfoInd

8.388.2.14 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pSuppressSysInfoInd

8.388.2.15 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pSysInfoInd

8.388.2.16 uint8_t* pack_nas_SLQSNasIndicationRegisterExt_t::pSystemSelectionInd

8.389 pack_nas_SLQSNASSeteDRXParams_t Struct Reference

Data Fields

- uint8_t * pEdrxEnable
- uint8_t * pCycleLen
- uint8_t * pPagingTimeWindow
- uint8_t * pEdrxRatType
- uint32_t * pEdrxCiotLteMode

8.389.1 Detailed Description

This structure contains the SLQSNASSeteDRXParams request parameters.

Parameters

pEdrxEnable	[Optional] • eDRX Enable • Values – 0x00 - Disable – 0x01 - Enable
pCycleLen	[Optional] • eDRX cycle length • Value to be set per 3GPP TS 24.008 Rel-13 Section 10.5.5.32
pPagingTime-Window	[Optional] • eDRX paging time window • Value to be set per 3GPP TS 24.008 Rel-13 Section 10.5.5.32
pEdrxRatType	[Optional] • Radio access technology • Values – NAS_RADIO_IF_NO_SVC (0x00) - None (no service) – NAS_RADIO_IF_CDMA_1X (0x01) - cdma2000 ® 1X – NAS_RADIO_IF_CDMA_1XEVDO (0x02) cdma2000 ® HRPD (1xEV-DO) – NAS_RADIO_IF_AMPS (0x03) - AMPS – NAS_RADIO_IF_GSM (0x04) - GSM – NAS_RADIO_IF_UMTS (0x05) - UMTS – NAS_RADIO_IF_WLAN (0x06) - WLAN – NAS_RADIO_IF_GPS (0x07) - GPS – NAS_RADIO_IF_LTE (0x08) - LTE – NAS_RADIO_IF_TDSCDMA (0x09)- TD-SCDMA – NAS_RADIO_IF_LTE_M1 (0x0a) - LTE-M1 – NAS_RADIO_IF_LTE_NB1 (0x0b) - LTE-NB1 – NAS_RADIO_IF_NO_CHANGE (-1)- No change Note: The device will use “0x08 - NAS_RADIO_IF_LTE” as the default value if the TLV is omitted.
pEdrxCiotLte-Mode	[Optional] • CIOT LTE mode • Values – NAS_CIOT_SYS_MODE_NO_ SRV(0x00) - No service – NAS_CIOT_SYS_MODE_LTE_ WB(0x01) - Camped on LTE wideband – NAS_CIOT_SYS_MODE_LTE_ M1(0x02) - Camped on LTE M1 – NAS_CIOT_SYS_MODE_LTE_ NB1(0x03) - Camped on LTE NB1 Note: This TLV should be set when pEdrxRatType is LTE.

8.389.2 Field Documentation

8.389.2.1 uint8_t* pack_nas_SLQSNASSeteDRXParams_t::pCycleLen

8.389.2.2 uint32_t* pack_nas_SLQSNASSeteDRXParams_t::pEdrxCiotLteMode

8.389.2.3 uint8_t* pack_nas_SLQSNASSeteDRXParams_t::pEdrxEnable

8.389.2.4 uint8_t* pack_nas_SLQSNASSeteDRXParams_t::pEdrxRatType

8.389.2.5 uint8_t* pack_nas_SLQSNASSeteDRXParams_t::pPagingTimeWindow

8.390 pack_nas_SLQSNasSwiIndicationRegister_t Struct Reference

Data Fields

- uint8_t lteEsmUl
- uint8_t lteEsmDl
- uint8_t lteEmmUl
- uint8_t lteEmmDl
- uint8_t gsmUmtsUl
- uint8_t gsmUmtsDl
- uint8_t * pRankIndicatorInd
- uint8_t * pTimer

8.390.1 Detailed Description

This structure contains the OTA message indication.

Parameters

lteEsmUl	• 0 - do not report • 1 - report LTE ESM uplink messages
lteEsmDl	• 0 - do not report • 1 - report LTE ESM downlink messages
lteEmmUl	• 0 - do not report • 1 - report LTE EMM uplink messages
lteEmmDl	• 0 - do not report • 1 - report GSM/UMTS uplink messages
gsmUmtsUl	• 0 - do not report • 1 - report GSM/UMTS uplink messages
gsmUmtsDl	• 0 - do not report • 1 - report GSM/UMTS downlink messages
pRankIndicator-Ind	• 0 - do not report • 1 - report Rank Indicator messages

pTimer	• 0 - do not report • 1 - report Timer Indicator messages

8.390.2 Field Documentation

8.390.2.1 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::gsmUmtsDl

8.390.2.2 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::gsmUmtsUl

8.390.2.3 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::lteEmmDl

8.390.2.4 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::lteEmmUl

8.390.2.5 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::lteEsmDl

8.390.2.6 uint8_t pack_nas_SLQSNasSwiIndicationRegister_t::lteEsmUl

8.390.2.7 uint8_t* pack_nas_SLQSNasSwiIndicationRegister_t::pRankIndicatorInd

8.390.2.8 uint8_t* pack_nas_SLQSNasSwiIndicationRegister_t::pTimer

8.391 pack_nas_SLQSNASSwiSetChannelLock_t Struct Reference

Data Fields

- nas_wcdmaUARFCN * pWcdmaUARFCN
- nas_lteEARFCN * pLteEARFCN
- nas_ltePCI * pLtePCI

8.391.1 Detailed Description

Structure for ChannelLock pack.

Parameters

pWcdmaUARFCN	[Optional] • See nas_wcdmaUARFCN for more information
pLteEARFCN	[Optional] • See nas_lteEARFCN for more information
pLtePCI	[Optional] • See nas_ltePCI for more information

8.391.2 Field Documentation

8.391.2.1 nas_lteEARFCN* pack_nas_SLQSNASSwiSetChannelLock_t::pLteEARFCN

8.391.2.2 nas_ltePCI* pack_nas_SLQSNASSwiSetChannelLock_t::pLtePCI

8.391.2.3 nas_wcdmaUARFCN* pack_nas_SLQSNASSwiSetChannelLock_t::pWcdmaUARFCN

8.392 pack_nas_SLQSSetBandPreference_t Struct Reference

Data Fields

- uint64_t bandPref

8.392.1 Detailed Description

Provides information about the band preference.

Parameters

bandpreference	• Bit mask representing the band preference to be set. • Bit position meanings: – 0 - BC0_A - Band Class 0, A-System – 1 - BC0_B - Band Class 0, B-System, Band Class 0 AB , GSM 850 Band – 2 - BC1 - Band Class 1, all blocks – 3 - BC2 - Band Class 2 place holder – 4 - BC3 - Band Class 3, A-System – 5 - BC4 - Band Class 4, all blocks – 6 - BC5 - Band Class 5, all blocks – 7 - GSM_DCS_1800 - GSM DCS band – 8 - GSM_EGSM_900 - GSM Extended GSM (E-GSM) band – 9 - GSM_PGSM_900 - GSM Primary GSM (P-GSM) band – 10 - BC6 - Band Class 6 – 11 - BC7 - Band Class 7 – 12 - BC8 - Band Class 8 – 13 - BC9 - Band Class 9 – 14 - BC10 - Band Class 10 – 15 - BC11 - Band Class 11 – 16 - GSM_450 - GSM 450 band – 17 - GSM_480 - GSM 480 band – 18 - GSM_750 - GSM 750 band – 19 - GSM_850 - GSM 850 band – 20 - GSM_RGSM_900 - GSM Railways GSM Band – 21 - GSM_PCS_1900 - GSM PCS band – 22 - WCDMA_I_IMT_2000 - WCDMA EUROPE JAPAN and CHINA IMT 2100 band – 23 - WCDMA_II_PCS_1900 - WCDMA US PCS 1900 band – 24 - WCDMA_III_1700 - WCDMA EUROPE and CHINA DCS 1800 band – 25 - WCDMA_IV_1700 - WCDMA US 1700 band – 26 - WCDMA_V_850 - WCDMA US 850 band – 27 - WCDMA_VI_800 - WCDMA JAPAN 800 band – 28 - BC12 - Band Class 12 – 29 - BC14 - Band Class 14 – 30 - RESERVED_2 - Reserved 2 – 31 - BC15 - Band Class 15 – 32 - 47 - Reserved – 48 - WCDMA_VII_2600 - WCDMA EUROPE 2600 band – 49 - WCDMA_VIII_900 - WCDMA EUROPE and JAPAN 900 band – 50 - WCDMA_IX_1700 - WCDMA JAPAN 1700 band – 51 to 55 - Reserved – 56 - BBC16 - Band Class 16 – 57 - BC17 - Band Class 17 – 58 - BC18 - Band Class 18 – 59 - BC19 - Band Class 19 – 60 to 64 - Reserved

8.392.2 Field Documentation

8.392.2.1 uint64_t pack_nas_SLQSSetBandPreference_t::bandPref

8.393 pack_nas_SLQSSetSignalStrengthsCallback_t Struct Reference

Data Fields

- uint8_t bEnable
- nas_SLQSSignalStrengthsIndReq * pSigIndReq

8.393.1 Detailed Description

This structure contains paramaters pack set strength thresholds callback.

Parameters

bEnable	0/1 to disable/enable RSSI signal stregth indication
pSigIndReq	parameters to control signal strength indication

8.393.2 Field Documentation

8.393.2.1 uint8_t pack_nas_SLQSSetSignalStrengthsCallback_t::bEnable

8.393.2.2 nas_SLQSSignalStrengthsIndReq* pack_nas_SLQSSetSignalStrengthsCallback_t::pSigIndReq

8.394 pack_nas_SLQSSetSysSelectionPref_t Struct Reference

Data Fields

- uint8_t * pEmerMode
- uint16_t * pModePref
- uint64_t * pBandPref
- uint16_t * pPRLPref
- uint16_t * pRoamPref
- uint64_t * pLTEBandPref
- struct nas_netSelectionPref * pNetSelPref
- uint8_t * pChgDuration
- uint8_t * pMNCIncPCSDigStat
- uint32_t * pSrvDomainPref
- uint32_t * pGWAcqOrderPref
- uint64_t * pTdscdmaBandPref
- struct nas_acqOrderPref * pAcqOrderPref
- uint32_t * pSrvRegRestriction
- struct nas_CSGID * pCSGID
- unsigned char * pRAT

8.394.1 Detailed Description

Contain the system selection preferences.

Parameters

pEmerMode	• Optional parameter specifying the emergency Mode • Values: – 0 - OFF (normal) – 1 - ON (Emergency)
pModePref	• Optional parameter • Bit Mask indicating the radio technology mode preference • Bit values: – Bit 0 - cdma2000 1x – Bit 1 - cdma2000 HRPD(1xEV-DO) – Bit 2 - GSM – Bit 3 - UMTS – Bit 4 - LTE

pBandPref	• Optional parameter • Bit mask representing the band preference • Bit values: – Bit 0 - Band Class 0, A-System – Bit 1 - Band Class 0, B-System, Band Class 0 AB, GSM 850 Band – Bit 2 - Band Class 1, all blocks – Bit 3 - Band Class 2 place holder – Bit 4 - Band Class 3, A-System – Bit 5 - Band Class 4, all blocks – Bit 6 - Band Class 5, all blocks – Bit 7 - GSM_DCS_1800 band – Bit 8 - GSM Extended GSM (E-GSM) 900 band – Bit 9 - GSM Primary GSM (P-GSM) 900 band – Bit 10 - Band Class 6 – Bit 11 - Band Class 7 – Bit 12 - Band Class 8 – Bit 13 - Band Class 9 – Bit 14 - Band Class 10 – Bit 15 - Band Class 11 – Bit 16 - GSM 450 band – Bit 17 - GSM 480 band – Bit 18 - GSM 750 band – Bit 19 - GSM 850 band – Bit 20 - GSM Railways GSM 900 Band – Bit 21 - GSM PCS 1900 band – Bit 22 - WCDMA Europe, Japan, and China IMT 2100 band – Bit 23 - WCDMA U.S. PCS 1900 band – Bit 24 - WCDMA Europe and China DCS 1800 band – Bit 25 - WCDMA U.S. 1700 band – Bit 26 - WCDMA U.S. 850 band – Bit 27 - WCDMA Japan 800 band – Bit 28 - Band Class 12 – Bit 29 - Band Class 14 – Bit 30 - Reserved – Bit 31 - Band Class 15 – Bit 32 to 47 - Reserved – Bit 48 - WCDMA Europe 2600 band – Bit 49 - WCDMA Europe and Japan 900 band – Bit 50 - WCDMA Japan 1700 band – Bit 51 to 55 - Reserved – Bit 56 - Band Class 16 – Bit 57 - Band Class 17 – Bit 58 - Band Class 18 – Bit 59 - Band Class 19 – Bit 60 to 64 - Reserved

pPRLPref	• Optional parameter indicating the CDMA PRL Preference • Values: – 0x0001 - Acquire available system only on the A side – 0x0002 - Acquire available system only on the B side – 0x3FFF - Acquire any available systems
pRoamPref	• Optional parameter indicating the roaming Preference • Values: – 0x01 - Acquire only systems for which the roaming indicator is off – 0x02 - Acquire a system as long as its roaming indicator is not off – 0x03 - Acquire only systems for which the roaming indicator is off or solid on, i.e. not flashing; CDMA only – 0xFF - Acquire systems, regardless of their roaming indicator
pLTEBandPref	• Optional parameter • Bit mask representing the LTE band preference • Bit Values – Bit 0 - E-UTRA Operating Band 1 – Bit 1 - E-UTRA Operating Band 2 – Bit 2 - E-UTRA Operating Band 3 – Bit 3 - E-UTRA Operating Band 4 – Bit 4 - E-UTRA Operating Band 5 – Bit 5 - E-UTRA Operating Band 6 – Bit 6 - E-UTRA Operating Band 7 – Bit 7 - E-UTRA Operating Band 8 – Bit 8 - E-UTRA Operating Band 9 – Bit 9 - E-UTRA Operating Band 10 – Bit 10 - E-UTRA Operating Band 11 – Bit 11 - E-UTRA Operating Band 12 – Bit 12 - E-UTRA Operating Band 13 – Bit 13 - E-UTRA Operating Band 14 – Bit 16 - E-UTRA Operating Band 17 – Bit 17 - E-UTRA Operating Band 18 – Bit 18 - E-UTRA Operating Band 19 – Bit 19 - E-UTRA Operating Band 20 – Bit 20 - E-UTRA Operating Band 21 – Bit 32 - E-UTRA Operating Band 33 – Bit 33 - E-UTRA Operating Band 34 – Bit 34 - E-UTRA Operating Band 35 – Bit 35 - E-UTRA Operating Band 36 – Bit 36 - E-UTRA Operating Band 37 – Bit 37 - E-UTRA Operating Band 38 – Bit 38 - E-UTRA Operating Band 39 – Bit 39 - E-UTRA Operating Band 40 – All other bits are reserved

pNetSelPref	- netSelectionPref • Optional parameter for specifying Network Selection Preference • Modem selects networks based on this parameter(if present). • see nas_netSelectionPref for more information
pChgDuration	• Optional parameter specifying the duration of the change • Values: – 0x00 - Power cycle - Remains active until the next device power cycle – 0x01 - Permanent - Remains active through power cycles until changed by client – Device will use "0x01 - permanent" as default if this parameter is omitted
pMNCIncPCS-DigStat	• Optional parameter indicating if MNC includes PCS digit • Values: – TRUE - MNC is a 3 digit value; e.g., a reported value of 90 corresponds to an MNC value of 090 – FALSE - MNC is a 2-digit value; e.g., a reported value of 90 corresponds to an MNC value of 90
pSrvDomainPref	• Optional parameter indicating Service domain preference • Values: – 0x00 - Circuit switched only – 0x01 - Packet switched only – 0x02 - Circuit switched and packet switched – 0x03 - Packet switched attach – 0x04 - Packet switched detach
pGWAcqOrder-Pref	• Optional parameter indicating GSM/WCDMA Acquisition order Preference • Values: – 0x00 - Automatic – 0x01 - GSM then WCDMA – 0x02 - WCDMA then GSM
pTdscdmaBand-Pref	• Optional parameter indicating bitmask representing the TD-SCDMA band preference to be set. • Values: – 0x01 - TD-SCDMA Band A – 0x02 - TD-SCDMA Band B – 0x04 - TD-SCDMA Band C – 0x08 - TD-SCDMA Band D – 0x10 - TD-SCDMA Band E – 0x20 - TD-SCDMA Band F – All other bits are reserved
pAcqOrderPref	- acqOrderPref • Optional parameter for specifying Acquisition Order Preference • see nas_acqOrderPref for more information

pSrvReg-Restriction	• Optional parameter indicating Network Selection Registration Restriction Preference • Values: – 0x00 - Device follows the normal registration process – 0x01 - Device camps on the network according to its provisioning, but does not register – 0x02 - Device selects the network for limited service – All other values are reserved.
pCSGID	- CSGID • Optional parameter for specifying CSG ID • Either of pNetSelPref or pCSGID can be set. • see nas_CSGID for more information
pRAT	• Optional parameter Radio Access Technology order Preference • Values: – 0x04 - GSM – 0x05 - UMTS – 0x08 - LTE – 0x09 - TDSCDMA

8.394.2 Field Documentation

8.394.2.1 struct nas_acqOrderPref* pack_nas_SLQSSetSysSelectionPref_t::pAcqOrderPref

8.394.2.2 uint64_t* pack_nas_SLQSSetSysSelectionPref_t::pBandPref

8.394.2.3 uint8_t* pack_nas_SLQSSetSysSelectionPref_t::pChgDuration

8.394.2.4 struct nas_CSGID* pack_nas_SLQSSetSysSelectionPref_t::pCSGID

8.394.2.5 uint8_t* pack_nas_SLQSSetSysSelectionPref_t::pEmerMode

8.394.2.6 uint32_t* pack_nas_SLQSSetSysSelectionPref_t::pGWAcqOrderPref

8.394.2.7 uint64_t* pack_nas_SLQSSetSysSelectionPref_t::pLTEBandPref

8.394.2.8 uint8_t* pack_nas_SLQSSetSysSelectionPref_t::pMNCInclPCSDigStat

8.394.2.9 uint16_t* pack_nas_SLQSSetSysSelectionPref_t::pModePref

8.394.2.10 struct nas_netSelectionPref* pack_nas_SLQSSetSysSelectionPref_t::pNetSelPref

8.394.2.11 uint16_t* pack_nas_SLQSSetSysSelectionPref_t::pPRLPref

8.394.2.12 unsigned char* pack_nas_SLQSSetSysSelectionPref_t::pRAT

8.394.2.13 uint16_t* pack_nas_SLQSSetSysSelectionPref_t::pRoamPref

8.394.2.14 uint32_t* pack_nas_SLQSSetSysSelectionPref_t::pSrvDomainPref

8.394.2.15 uint32_t* pack_nas_SLQSSetSysSelectionPref_t::pSrvRegRestriction

8.394.2.16 uint64_t* pack_nas_SLQSSetSysSelectionPref_t::pTdscdmaBandPref

8.395 pack_nas_SLQSSetSysSelectionPrefExt_t Struct Reference

Data Fields

- uint8_t * pEmerMode
- uint16_t * pModePref
- uint64_t * pBandPref
- uint16_t * pPRLPref
- uint16_t * pRoamPref
- uint64_t * pLTEBandPref
- struct nas_netSelectionPref * pNetSelPref
- uint8_t * pChgDuration
- uint8_t * pMNCIncPCSDigStat
- uint32_t * pSrvDomainPref
- uint32_t * pGWAcqOrderPref
- uint64_t * pTdscdmaBandPref
- struct nas_acqOrderPref * pAcqOrderPref
- uint32_t * pSrvRegRestriction
- struct nas_CSGID * pCSGID
- unsigned char * pRAT
- struct nas_lteBandPrefExt * pLTEBandPrefExt
- uint64_t * pCiotLteOpModePref
- uint64_t * pLteM1BandPref
- uint64_t * pLteNb1BandPref
- uint32_t * pCiotLteOpMode
- struct nas_ciotAcqOrderPref * pCiotAcqOrderPref
- struct nas_nr5gBandPref * pNr5gBandPref

8.395.1 Detailed Description

Contain the system selection preferences.

Parameters

pEmerMode	• Optional parameter specifying the emergency Mode • Values: – 0 - OFF (normal) – 1 - ON (Emergency)

pModePref	• Optional parameter • Bit Mask indicating the radio technology mode preference • Bit values: – Bit 0 - cdma2000 1x – Bit 1 - cdma2000 HRPD(1xEV-DO) – Bit 2 - GSM – Bit 3 - UMTS – Bit 4 - LTE – Bit 5 - TD-SCDMA – Bit 6 - NR5G

pBandPref	• Optional parameter • Bit mask representing the band preference • Bit values: – Bit 0 - Band Class 0, A-System – Bit 1 - Band Class 0, B-System, Band Class 0 AB, GSM 850 Band – Bit 2 - Band Class 1, all blocks – Bit 3 - Band Class 2 place holder – Bit 4 - Band Class 3, A-System – Bit 5 - Band Class 4, all blocks – Bit 6 - Band Class 5, all blocks – Bit 7 - GSM_DCS_1800 band – Bit 8 - GSM Extended GSM (E-GSM) 900 band – Bit 9 - GSM Primary GSM (P-GSM) 900 band – Bit 10 - Band Class 6 – Bit 11 - Band Class 7 – Bit 12 - Band Class 8 – Bit 13 - Band Class 9 – Bit 14 - Band Class 10 – Bit 15 - Band Class 11 – Bit 16 - GSM 450 band – Bit 17 - GSM 480 band – Bit 18 - GSM 750 band – Bit 19 - GSM 850 band – Bit 20 - GSM Railways GSM 900 Band – Bit 21 - GSM PCS 1900 band – Bit 22 - WCDMA Europe, Japan, and China IMT 2100 band – Bit 23 - WCDMA U.S. PCS 1900 band – Bit 24 - WCDMA Europe and China DCS 1800 band – Bit 25 - WCDMA U.S. 1700 band – Bit 26 - WCDMA U.S. 850 band – Bit 27 - WCDMA Japan 800 band – Bit 28 - Band Class 12 – Bit 29 - Band Class 14 – Bit 30 - Reserved – Bit 31 - Band Class 15 – Bit 32 to 47 - Reserved – Bit 48 - WCDMA Europe 2600 band – Bit 49 - WCDMA Europe and Japan 900 band – Bit 50 - WCDMA Japan 1700 band – Bit 51 to 55 - Reserved – Bit 56 - Band Class 16 – Bit 57 - Band Class 17 – Bit 58 - Band Class 18 – Bit 59 - Band Class 19 – Bit 60 to 64 - Reserved

pPRLPref	• Optional parameter indicating the CDMA PRL Preference • Values: – 0x0001 - Acquire available system only on the A side – 0x0002 - Acquire available system only on the B side – 0x3FFF - Acquire any available systems
pRoamPref	• Optional parameter indicating the roaming Preference • Values: – 0x01 - Acquire only systems for which the roaming indicator is off – 0x02 - Acquire a system as long as its roaming indicator is not off – 0x03 - Acquire only systems for which the roaming indicator is off or solid on, i.e. not flashing; CDMA only – 0xFF - Acquire systems, regardless of their roaming indicator

pLTEBandPref	• Optional parameter • Bit mask representing the LTE band preference • Bit Values – Bit 0 - E-UTRA Operating Band 1 – Bit 1 - E-UTRA Operating Band 2 – Bit 2 - E-UTRA Operating Band 3 – Bit 3 - E-UTRA Operating Band 4 – Bit 4 - E-UTRA Operating Band 5 – Bit 5 - E-UTRA Operating Band 6 – Bit 6 - E-UTRA Operating Band 7 – Bit 7 - E-UTRA Operating Band 8 – Bit 8 - E-UTRA Operating Band 9 – Bit 9 - E-UTRA Operating Band 10 – Bit 10 - E-UTRA Operating Band 11 – Bit 11 - E-UTRA Operating Band 12 – Bit 12 - E-UTRA Operating Band 13 – Bit 13 - E-UTRA Operating Band 14 – Bit 16 - E-UTRA Operating Band 17 – Bit 17 - E-UTRA Operating Band 18 – Bit 18 - E-UTRA Operating Band 19 – Bit 19 - E-UTRA Operating Band 20 – Bit 20 - E-UTRA Operating Band 21 – Bit 22 - E-UTRA Operating Band 23 – Bit 23 - E-UTRA Operating Band 24 – Bit 24 - E-UTRA Operating Band 25 – Bit 25 - E-UTRA Operating Band 26 – Bit 27 - E-UTRA Operating Band 28 – Bit 28 - E-UTRA Operating Band 29 – Bit 29 - E-UTRA Operating Band 32 – Bit 32 - E-UTRA Operating Band 33 – Bit 33 - E-UTRA Operating Band 34 – Bit 34 - E-UTRA Operating Band 35 – Bit 35 - E-UTRA Operating Band 36 – Bit 36 - E-UTRA Operating Band 37 – Bit 37 - E-UTRA Operating Band 38 – Bit 38 - E-UTRA Operating Band 39 – Bit 39 - E-UTRA Operating Band 40 – Bit 40 - E-UTRA Operating Band 41 – Bit 41 - E-UTRA Operating Band 42 – Bit 42 - E-UTRA Operating Band 43 – Bit 60 - E-UTRA Operating Band 125 – All other bits are reserved

pNetSelPref	- netSelectionPref • Optional parameter for specifying Network Selection Preference • Modem selects networks based on this parameter(if present). • Either of pNetSelPref or pCSGID can be set. • see nas_netSelectionPref for more information
pChgDuration	• Optional parameter specifying the duration of the change • At least one system selection setting to be set if pChgDuration is populated. • Values: – 0x00 - Power cycle - Remains active until the next device power cycle – 0x01 - Permanent - Remains active through power cycles until changed by client – Device will use "0x01 - permanent" as default if this parameter is omitted
pMNCIncPCS-DigStat	• Optional parameter indicating if MNC includes PCS digit • pNetSelPref is expected if MNC includes PCS digit is set to 1. • Values: – TRUE - MNC is a 3 digit value; e.g., a reported value of 90 corresponds to an MNC value of 090 – FALSE - MNC is a 2-digit value; e.g., a reported value of 90 corresponds to an MNC value of 90
pSrvDomainPref	• Optional parameter indicating Service domain preference • Values: – 0x00 - Circuit switched only – 0x01 - Packet switched only – 0x02 - Circuit switched and packet switched – 0x03 - Packet switched attach – 0x04 - Packet switched detach
pGWAcqOrder-Pref	• Optional parameter indicating GSM/WCDMA Acquisition order Preference • Values: – 0x00 - Automatic – 0x01 - GSM then WCDMA – 0x02 - WCDMA then GSM
pTdscdmaBand-Pref	• Optional parameter indicating bitmask representing the TD-SCDMA band preference to be set. • Values: – 0x01 - TD-SCDMA Band A – 0x02 - TD-SCDMA Band B – 0x04 - TD-SCDMA Band C – 0x08 - TD-SCDMA Band D – 0x10 - TD-SCDMA Band E – 0x20 - TD-SCDMA Band F – All other bits are reserved

pAcqOrderPref	- acqOrderPref • Optional parameter for specifying Acquisition Order Preference • see nas_acqOrderPref for more information
pSrvReg-Restriction	• Optional parameter indicating Network Selection Registration Restriction Preference • Values: – 0x00 - Device follows the normal registration process – 0x01 - Device camps on the network according to its provisioning, but does not register – 0x02 - Device selects the network for limited service – All other values are reserved.
pCSGID	- CSGID • Optional parameter for specifying CSG ID • Either of pNetSelPref or pCSGID can be set. • see nas_CSGID for more information
pRAT	• Optional parameter Radio Access Technology order Preference • Values: – 0x04 - GSM – 0x05 - UMTS – 0x08 - LTE – 0x09 - TDSCDMA – 0x0A - LTE-M1 – 0x0B - LTE-NB1 – 0x0C - NR5G
pLTEBandPref-Ext[IN]	• LTE Band Preference Extended • see nas_lteBandPrefExt for more information
pCiotLteOp-ModePref[IN]	• CIOT LTE Operational Mode Preference • Bitmask representing the CIoT LTE operational mode preference to be set. • Values : – Bit 0 - LTE wideband – Bit 1 - LTE M1 – Bit 2 - LTE NB1 All unlisted bits are reserved for future use and the service point ignores them if used. If this TLV is not present, the modem will use the value read from the NV during bootup.

pLteM1Band-Pref[IN]	• Bitmask representing the LTE M1 band preference to be set. • Bit Values – Bit 0 - E-UTRA Operating Band 1 – Bit 1 - E-UTRA Operating Band 2 – Bit 2 - E-UTRA Operating Band 3 – Bit 3 - E-UTRA Operating Band 4 – Bit 4 - E-UTRA Operating Band 5 – Bit 5 - E-UTRA Operating Band 6 – Bit 6 - E-UTRA Operating Band 7 – Bit 7 - E-UTRA Operating Band 8 – Bit 8 - E-UTRA Operating Band 9 – Bit 9 - E-UTRA Operating Band 10 – Bit 10 - E-UTRA Operating Band 11 – Bit 11 - E-UTRA Operating Band 12 – Bit 12 - E-UTRA Operating Band 13 – Bit 13 - E-UTRA Operating Band 14 – Bit 16 - E-UTRA Operating Band 17 – Bit 17 - E-UTRA Operating Band 18 – Bit 18 - E-UTRA Operating Band 19 – Bit 19 - E-UTRA Operating Band 20 – Bit 20 - E-UTRA Operating Band 21 – Bit 22 - E-UTRA Operating Band 23 – Bit 23 - E-UTRA Operating Band 24 – Bit 24 - E-UTRA Operating Band 25 – Bit 25 - E-UTRA Operating Band 26 – Bit 27 - E-UTRA Operating Band 28 – Bit 28 - E-UTRA Operating Band 29 – Bit 29 - E-UTRA Operating Band 32 – Bit 32 - E-UTRA Operating Band 33 – Bit 33 - E-UTRA Operating Band 34 – Bit 34 - E-UTRA Operating Band 35 – Bit 35 - E-UTRA Operating Band 36 – Bit 36 - E-UTRA Operating Band 37 – Bit 37 - E-UTRA Operating Band 38 – Bit 38 - E-UTRA Operating Band 39 – Bit 39 - E-UTRA Operating Band 40 – Bit 40 - E-UTRA Operating Band 41 – Bit 41 - E-UTRA Operating Band 42 – Bit 42 - E-UTRA Operating Band 43 – Bit 60 - E-UTRA Operating Band 125 – Bit 61 - E-UTRA Operating Band 126 – Bit 62 - E-UTRA Operating Band 127

- If this field is not present, the modem will use the M1 band preference value read from the NV.

Parameters

pLteNb1Band-Pref[IN]	• Bitmask representing the LTE NB1 band preference to be set. • Bit Values – Bit 0 - E-UTRA Operating Band 1 – Bit 1 - E-UTRA Operating Band 2 – Bit 2 - E-UTRA Operating Band 3 – Bit 3 - E-UTRA Operating Band 4 – Bit 4 - E-UTRA Operating Band 5 – Bit 5 - E-UTRA Operating Band 6 – Bit 6 - E-UTRA Operating Band 7 – Bit 7 - E-UTRA Operating Band 8 – Bit 8 - E-UTRA Operating Band 9 – Bit 9 - E-UTRA Operating Band 10 – Bit 10 - E-UTRA Operating Band 11 – Bit 11 - E-UTRA Operating Band 12 – Bit 12 - E-UTRA Operating Band 13 – Bit 13 - E-UTRA Operating Band 14 – Bit 16 - E-UTRA Operating Band 17 – Bit 17 - E-UTRA Operating Band 18 – Bit 18 - E-UTRA Operating Band 19 – Bit 19 - E-UTRA Operating Band 20 – Bit 20 - E-UTRA Operating Band 21 – Bit 22 - E-UTRA Operating Band 23 – Bit 23 - E-UTRA Operating Band 24 – Bit 24 - E-UTRA Operating Band 25 – Bit 25 - E-UTRA Operating Band 26 – Bit 27 - E-UTRA Operating Band 28 – Bit 28 - E-UTRA Operating Band 29 – Bit 29 - E-UTRA Operating Band 32 – Bit 32 - E-UTRA Operating Band 33 – Bit 33 - E-UTRA Operating Band 34 – Bit 34 - E-UTRA Operating Band 35 – Bit 35 - E-UTRA Operating Band 36 – Bit 36 - E-UTRA Operating Band 37 – Bit 37 - E-UTRA Operating Band 38 – Bit 38 - E-UTRA Operating Band 39 – Bit 39 - E-UTRA Operating Band 40 – Bit 40 - E-UTRA Operating Band 41 – Bit 41 - E-UTRA Operating Band 42 – Bit 42 - E-UTRA Operating Band 43 – Bit 60 - E-UTRA Operating Band 125 – Bit 61 - E-UTRA Operating Band 126 – Bit 62 - E-UTRA Operating Band 127 • If this field is not present, the modem will use the NB1 band preference value read from the NV.

pCiotLteOpMode	• This TLV is used when the net_sel_pref is MANUAL and RAT TLV is LTE. • This TLV indicates the the operational mode to be used during the manual LTE PLMN selection. • Values : – 0x00 - No service – 0x01 - Camped on LTE wideband – 0x02 - Camped on LTE M1 – 0x03 - Camped on LTE NB1
pCiotAcqOrder-Pref[IN]	• CIOT Acquisition Order Preference • see nas_ciotAcqOrderPref for more information
pNr5gBandPref[-IN]	• NR5G Band Preference • see nas_nr5gBandPref for more information

8.395.2 Field Documentation

8.395.2.1 struct nas_acqOrderPref* pack_nas_SLQSSetSysSelectionPrefExt_t::pAcqOrderPref

8.395.2.2 uint64_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pBandPref

8.395.2.3 uint8_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pChgDuration

8.395.2.4 struct nas_ciotAcqOrderPref* pack_nas_SLQSSetSysSelectionPrefExt_t::pCiotAcqOrderPref

8.395.2.5 uint32_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pCiotLteOpMode

8.395.2.6 uint64_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pCiotLteOpModePref

8.395.2.7 struct nas_CSGID* pack_nas_SLQSSetSysSelectionPrefExt_t::pCSGID

8.395.2.8 uint8_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pEmerMode

8.395.2.9 uint32_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pGWAcqOrderPref

8.395.2.10 uint64_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pLTEBandPref

8.395.2.11 struct nas_lteBandPrefExt* pack_nas_SLQSSetSysSelectionPrefExt_t::pLTEBandPrefExt

8.395.2.12 uint64_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pLteM1BandPref

8.395.2.13 uint64_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pLteNb1BandPref

8.395.2.14 uint8_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pMNCIncPCSDigStat

8.395.2.15 uint16_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pModePref

8.395.2.16 struct nas_netSelectionPref* pack_nas_SLQSSetSysSelectionPrefExt_t::pNetSelPref

8.395.2.17 struct nas_nr5gBandPref* pack_nas_SLQSSetSysSelectionPrefExt_t::pNr5gBandPref

8.395.2.18 uint16_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pPRLPref

8.395.2.19 unsigned char* pack_nas_SLQSSetSysSelectionPrefExt_t::pRAT

8.395.2.20 uint16_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pRoamPref

8.395.2.21 uint32_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pSrvDomainPref

8.395.2.22 uint32_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pSrvRegRestriction

8.395.2.23 uint64_t* pack_nas_SLQSSetSysSelectionPrefExt_t::pTdscdmaBandPref

8.396 pack_nas_SLQSSwiPSDetach_t Struct Reference

Data Fields

- uint8_t * pDetachAction

8.396.1 Detailed Description

Structure for PS connection detach pack.

Parameters

pDetachAction[I-N]	• Values – 2- Initiates an immediate packet domain detach.

8.396.2 Field Documentation

8.396.2.1 uint8_t* pack_nas_SLQSSwiPSDetach_t::pDetachAction

8.397 pack_pds_PDSInjectTimeReference_t Struct Reference

Data Fields

- uint64_t systemTime
- uint16_t systemDiscontinuities

8.397.1 Detailed Description

Structure contain the parameter for PDS Inject time.

Parameters

systemTime	• System time(milliseconds)
system-Discontinuities	• Number of system time discontinuities

8.397.2 Field Documentation

8.397.2.1 uint16_t pack_pds_PDSInjectTimeReference_t::systemDiscontinuities

8.397.2.2 uint64_t pack_pds_PDSInjectTimeReference_t::systemTime

8.398 pack_pds_ResetPDSData_t Struct Reference

Data Fields

- uint32_t * pGPSDataMask
- uint32_t * pCellDataMask

8.398.1 Detailed Description

Structure contain the parameter to Resets the specified PDS data.

Parameters

pGPSDataMask	• Bitmask of GPS data to clear (optional) – 0x00000001 - EPH – 0x00000002 - ALM – 0x00000004 - POS – 0x00000008 - TIME – 0x00000010 - IONO – 0x00000020 - UTC – 0x00000040 - HEALTH – 0x00000080 - SVDIR – 0x00000100 - SVSTEER – 0x00000200 - SADATA – 0x00000400 - RTI – 0x00000800 - ALM_CORR – 0x00001000 - FREQ_BIAS_EST
pCellDataMask	• Bitmask of cell data to clear (optional) – 0x00000001 - POS – 0x00000002 - LATEST_GPS_POS – 0x00000004 - OTA_POS – 0x00000008 - EXT_REF_POS – 0x00000010 - TIMETAG – 0x00000020 - CELLID – 0x00000040 - CACHED_CELLID – 0x00000080 - LAST_SRV_CELL – 0x00000100 - CUR_SRV_CELL – 0x00000200 - NEIGHBOR_INFO

8.398.2 Field Documentation

8.398.2.1 uint32_t* pack_pds_ResetPDSData_t::pCellDataMask

8.398.2.2 uint32_t* pack_pds_ResetPDSData_t::pGPSDataMask

8.399 pack_pds_SetEventReportCallback_t Struct Reference

Data Fields

- uint8_t posDataNmea
- uint8_t rptPosData

8.399.1 Detailed Description

Structure contain the parameter for the automatic tracking configuration for the NMEA COM port.

Parameters

posDataNmea	• Report new position data in NMEA format. • Values – 0x00 - Disable – 0x01 - Enable
rptPosData	• Report new position data in raw format. • Values – 0x00 - Disable – 0x01 - Enable

8.399.2 Field Documentation

8.399.2.1 uint8_t pack_pds_SetEventReportCallback_t::posDataNmea

8.399.2.2 uint8_t pack_pds_SetEventReportCallback_t::rptPosData

8.400 pack_pds_SetPDSDefaults_t Struct Reference

Data Fields

- uint32_t operation
- uint8_t timeout
- uint32_t interval
- uint32_t accuracy

8.400.1 Detailed Description

Structure containing session configuration parameters.

Parameters

operation	• Current session operating mode – 0 - Standalone – 1 - MS based – 2 - MS assisted
timeout	• Maximum amount of time (seconds) to work on each fix, maximum is 255
interval	• Interval (seconds) between fix requests
accuracy	• Preferred accuracy threshold (meters)

8.400.2 Field Documentation

8.400.2.1 uint32_t pack_pds_SetPDSDefaults_t::accuracy

8.400.2.2 uint32_t pack_pds_SetPDSDefaults_t::interval

8.400.2.3 uint32_t pack_pds_SetPDSDefaults_t::operation

8.400.2.4 uint8_t pack_pds_SetPDSDefaults_t::timeout

8.401 pack_pds_SetPDSState_t Struct Reference

Data Fields

- uint32_t enable

8.401.1 Detailed Description

Structure contain PDS state parameters.

Parameters

enable	• Desired PDS state – Zero - disable – Non-Zero - enable

8.401.2 Field Documentation

8.401.2.1 uint32_t pack_pds_SetPDSState_t::enable

8.402 pack_pds_SetPortAutomaticTracking_t Struct Reference

Data Fields

- uint32_t bAuto

8.402.1 Detailed Description

Structure contain the parameter for the automatic tracking configuration for the NMEA COM port.

Parameters

bAuto	• Enable automatic tracking for NMEA COM port – 0x00 - Disabled – 0x01 - Enabled

8.402.2 Field Documentation

8.402.2.1 uint32_t pack_pds_SetPortAutomaticTracking_t::bAuto

8.403 pack_pds_SetServiceAutomaticTracking_t Struct Reference

Data Fields

- uint32_t bAuto

8.403.1 Detailed Description

Structure contain the parameter to Sets the automatic tracking state.

Parameters

bAuto	• Automatic tracking session started for service – 0x00 - Disabled – 0x01 - Enabled

8.403.2 Field Documentation

8.403.2.1 uint32_t pack_pds_SetServiceAutomaticTracking_t::bAuto

8.404 pack_pds_SetXTRAAutomaticDownload_t Struct Reference

Data Fields

- uint32_t bEnabled
- uint16_t interval

8.404.1 Detailed Description

Structure contain the parameter to set the XTRA automatic database download configuration.

Parameters

bEnabled	• Automatic XTRA download status – 0 - Disabled – 1 - Enabled
interval	• Interval (hours) between XTRA downloads

8.404.2 Field Documentation

8.404.2.1 uint32_t pack_pds_SetXTRAAutomaticDownload_t::bEnabled

8.404.2.2 uint16_t pack_pds_SetXTRAAutomaticDownload_t::interval

8.405 pack_pds_SetXTRANetwork_t Struct Reference

Data Fields

- uint32_t preference

8.405.1 Detailed Description

Structure contain the parameter to Sets the XTRA WWAN network preference

Parameters

preference	• XTRA WWAN network preference – 0x00 - None (any available network) – 0x01 - Home-only, only when on home systems – 0x02 - Roam-only, only when on non-home systems

8.405.2 Field Documentation

8.405.2.1 uint32_t pack_pds_SetXTRANetwork_t::preference

8.406 pack_pds_SLQSGetAGPSConfig_t Struct Reference

Data Fields

- uint8_t * pNetworkMode

8.406.1 Detailed Description

Structure contain the parameter to PDS AGPS (MS-based) configuration pack.

Parameters

pNetworkMode	• Network Mode of AGPS Server [optional - should be present in Multimode Systems] – 0x00 - UMTS – 0x01 - CDMA

8.406.2 Field Documentation

8.406.2.1 uint8_t* pack_pds_SLQSGetAGPSConfig_t::pNetworkMode

8.407 pack_pds_SLQSPDSInjectAbsoluteTimeReference_t Struct Reference

Data Fields

- uint64_t timeMsec
- uint32_t timeUncMsec
- uint8_t timeBase
- uint8_t forceFlag

8.407.1 Detailed Description

Structure contain the parameter to Injects a absolute time reference.

Parameters

timeMsec	• Represents the number of milliseconds elapsed since either a GPS or UTC time base. If the time base is UTC, this value should NOT include leap seconds
timeUncMsec	• Time uncertainty in milliseconds
timeBase	• Time base – 0x00 - GPS (midnight, Jan 6, 1980) – 0x01 - UTC (midnight, Jan 1, 1970)
forceFlag	• Force acceptance of data

8.407.2 Field Documentation

8.407.2.1 uint8_t pack_pds_SLQSPDSInjectAbsoluteTimeReference_t::forceFlag

8.407.2.2 uint8_t pack_pds_SLQSPDSInjectAbsoluteTimeReference_t::timeBase

8.407.2.3 uint64_t pack_pds_SLQSPDSInjectAbsoluteTimeReference_t::timeMsec

8.407.2.4 uint32_t pack_pds_SLQSPDSInjectAbsoluteTimeReference_t::timeUncMsec

8.408 pack_pds_SLQSPDSInjectPositionData_t Struct Reference

Data Fields

- uint64_t * pTimeStamp
- uint64_t * pLatitude
- uint64_t * pLongitude
- uint32_t * pAltitudeWrtEllipsoid
- uint32_t * pAltitudeWrtSealevel
- uint32_t * pHorizontalUncCircular
- uint32_t * pVerticalUnc
- uint8_t * pHorizontalConfidence
- uint8_t * pVerticalConfidence
- uint8_t * pPositionSource
- uint8_t * pTimeType

8.408.1 Detailed Description

Position Data Parameters from the external source to be injected to PDS engine.

Parameters

pTimeStamp	• Timestamp of the injected position in msec. The time can be of type UTC, GPS, or Age and is defined in the pTimeType parameter. If the pTimeType is not present, the timestamp shall be assumed to be UTC time
pLatitude	• Latitude position referenced to the WGS-84 reference ellipsoid, counting positive angles north of the equator and negative angles south of the equator. Value (in decimal degrees) in the range from -90 degrees to +90 degrees.Value in double float format (refer toIEEE Std 754-1985)
pLongitude	• Longitude position referenced to the WGS-84 reference ellipsoid, counting positive angles east of the Greenwich Meridian and negative angles west of Greenwich meridian. Value (in decimal degrees) in the range from -180 degrees to +180 degrees.
pAltitudeWrt-Ellipsoid	• Height above the WGS-84 reference ellipsoid. Value conveys height (in meters). When injecting altitude information, the control point should include either this parameter or the pAltitudeWrt-Sealevel parameter. Value in single float format (refer to IEEE Std 754-1985)
pAltitudeWrt-Sealevel	• Height of MS above the mean sea level in units (in meters). When injecting altitude information, the control point should include either this parameter or the pAltitudeWrtEllipsoid parameter. Value in single float format (refer to IEEE Std 754-1985)
pHorizontalUnc-Circular	• Circular horizontal uncertainty (in meters). This parameter must be included if the latitude and longitude parameters are specified. Value in single float format (refer to IEEE Std 754-1985)

pVerticalUnc	• Vertical uncertainty (in meters). This parameter must be included if one of the altitude parameter are specified.Value in single float format (refer to IEEE Std 754-1985)
pHorizontal-Confidence	• Confidence value of the location horizontal uncertainty, specified as percentage, 1 to 100. This parameter must be included if the latitude and longitude parameters are specified.
pVertical-Confidence	• Confidence value of the location vertical uncertainty, specified as percentage, 1 to 100. This parameter must be included if one of the altitude paramters are specified.
pPositionSource	• Source of injected position: – 0x00 - Unknown – 0x01 - GPS – 0x02 - Cell ID – 0x03 - Enhanced cell ID – 0x04 - WiFi – 0x05 - Terrestrial – 0x06 - Terrestrial hybrid – 0x07 - Other
pTimeType	• Defines the time value set in the pTimeStamp parameter. – 0x00 - UTC Time: starting Jan 1, 1970 – 0x01 - GPS Time: starting Jan 6, 1980 – 0x02 - Age: Age of position information

8.408.2 Field Documentation

8.408.2.1 uint32_t* pack_pds_SLQSPDSInjectPositionData_t::pAltitudeWrtEllipsoid

8.408.2.2 uint32_t* pack_pds_SLQSPDSInjectPositionData_t::pAltitudeWrtSealevel

8.408.2.3 uint8_t* pack_pds_SLQSPDSInjectPositionData_t::pHorizontalConfidence

8.408.2.4 uint32_t* pack_pds_SLQSPDSInjectPositionData_t::pHorizontalUncCircular

8.408.2.5 uint64_t* pack_pds_SLQSPDSInjectPositionData_t::pLatitude

8.408.2.6 uint64_t* pack_pds_SLQSPDSInjectPositionData_t::pLongitude

8.408.2.7 uint8_t* pack_pds_SLQSPDSInjectPositionData_t::pPositionSource

8.408.2.8 uint64_t* pack_pds_SLQSPDSInjectPositionData_t::pTimeStamp

8.408.2.9 uint8_t* pack_pds_SLQSPDSInjectPositionData_t::pTimeType

8.408.2.10 uint8_t* pack_pds_SLQSPDSInjectPositionData_t::pVerticalConfidence

8.408.2.11 uint32_t* pack_pds_SLQSPDSInjectPositionData_t::pVerticalUnc

8.409 pack_pds_SLQSSetAGPSConfig_t Struct Reference

Data Fields

- uint32_t * pServerAddress
- uint32_t * pServerPort
- uint8_t * pServerURL
- uint8_t * pServerURLLength
- uint8_t * pNetworkMode

8.409.1 Detailed Description

Structure contain the parameter to Sets the PDS AGPS (MS-based) configuration.

Parameters

pServerAddress	• IPv4 address of AGPS server [optional]
pServerPort	• Port number of AGPS server [optional - should be present when pServerAddress is present]
pServerURL	• URL of the AGPS server [optional]
pServerURL-Length	• URL length of AGPS server [optional - should be present when pServerURL is present]
pNetworkMode	• Network Mode of AGPS Server [optional - should be present in Multimode Systems] – 0x00 - UMTS – 0x01 - CDMA

8.409.2 Field Documentation

8.409.2.1 uint8_t* pack_pds_SLQSSetAGPSConfig_t::pNetworkMode

8.409.2.2 uint32_t* pack_pds_SLQSSetAGPSConfig_t::pServerAddress

8.409.2.3 uint32_t* pack_pds_SLQSSetAGPSConfig_t::pServerPort

8.409.2.4 uint8_t* pack_pds_SLQSSetAGPSConfig_t::pServerURL

8.409.2.5 uint8_t* pack_pds_SLQSSetAGPSConfig_t::pServerURLLength

8.410 pack_pds_SLQSSetPositionMethodState_t Struct Reference

Data Fields

- uint8_t * pXtraTimeState

- uint8_t * pXtraDataState
- uint8_t * pWifiState

8.410.1 Detailed Description

Parameters to Set state of positioning method for a device.

Parameters

pXtraTimeState	• XTRA Time Position Method State. • Values: – 0x00 - Disable – 0x01 - Enable
pXtraDataState	• XTRA Data Position Method State. • Values: – 0x00 - Disable – 0x01 - Enable
Latitude	• WiFi Position Method State • Values: – 0x00 - Disable – 0x01 - Enable

8.410.2 Field Documentation

8.410.2.1 uint8_t* pack_pds_SLQSSetPositionMethodState_t::pWifiState

8.410.2.2 uint8_t* pack_pds_SLQSSetPositionMethodState_t::pXtraDataState

8.410.2.3 uint8_t* pack_pds_SLQSSetPositionMethodState_t::pXtraTimeState

8.411 pack_pds_StartPDSTrackingSessionExt_t Struct Reference

Data Fields

- uint8_t sessionControl
- uint8_t sessionType
- uint8_t sessionOperation
- uint8_t sessionServerOption
- uint8_t fixTimeout
- uint32_t fixInterval
- uint32_t fixCount
- uint32_t fixAccuracy

8.411.1 Detailed Description

Structure contain the parameter for PDS tracking session.

Parameters

sessionControl	• Control method: – 0x0 - Manual
sessionType	• Type: – 0x0 - New
session-Operation	• Operating mode: – 0x00 - Standalone – 0x01 - MS-based
sessionServer-Option	• Location server option: – 0x0 - Default
fixTimeout	• Maximum time to work on each fix (in seconds, max 255)
fixCount	• Count of position fix requests for this session (must be at least 1)
fixInterval	• interval between position fix requests (in seconds)
fixAccuracy	• Preferred accuracy threshold(in meters)

8.411.2 Field Documentation

8.411.2.1 uint32_t pack_pds_StartPDSTrackingSessionExt_t::fixAccuracy

8.411.2.2 uint32_t pack_pds_StartPDSTrackingSessionExt_t::fixCount

8.411.2.3 uint32_t pack_pds_StartPDSTrackingSessionExt_t::fixInterval

8.411.2.4 uint8_t pack_pds_StartPDSTrackingSessionExt_t::fixTimeout

8.411.2.5 uint8_t pack_pds_StartPDSTrackingSessionExt_t::sessionControl

8.411.2.6 uint8_t pack_pds_StartPDSTrackingSessionExt_t::sessionOperation

8.411.2.7 uint8_t pack_pds_StartPDSTrackingSessionExt_t::sessionServerOption

8.411.2.8 uint8_t pack_pds_StartPDSTrackingSessionExt_t::sessionType

8.412 pack_qmi_t Struct Reference

Data Fields

- uint16_t xid
- int timeout
- uint16_t msgid
- uint8_t svc

8.412.1 Detailed Description

qmi request context

Parameters

in	*xid*	transaction id
out	*timeout*	timeout recommended in seconds
out	*msgid*	message id
out	*svc*	qmi service

8.412.2 Field Documentation

8.412.2.1 uint16_t pack_qmi_t::msgid

8.412.2.2 uint8_t pack_qmi_t::svc

8.412.2.3 int pack_qmi_t::timeout

8.412.2.4 uint16_t pack_qmi_t::xid

8.413 pack_qos_BindDataPort_t Struct Reference

Data Fields

- qos_BindDataPortPeripheralEndPointID_t * pPeripheralEndPointID
- qos_BindDataPortMuxID_t * pMuxID
- qos_BindDataPortSIODataPort_t * pSIODataPort

8.413.1 Detailed Description

Structure that contains the request Binds a control point to a data port.

Parameters

pPeripheralEnd-PointID	• See qos_BindDataPortPeripheralEndPointID_t for more information.
pMuxID	• See qos_BindDataPortMuxID_t for more information.
pSIODataPort	• See qos_BindDataPortSIODataPort_t for more information.

8.413.2 Field Documentation

8.413.2.1 qos_BindDataPortMuxID_t* pack_qos_BindDataPort_t::pMuxID

8.413.2.2 qos_BindDataPortPeripheralEndPointID_t* pack_qos_BindDataPort_t::pPeripheralEndPointID

8.413.2.3 qos_BindDataPortSIODataPort_t* pack_qos_BindDataPort_t::pSIODataPort

8.414 pack_qos_SLQSQosSwiReadApnExtraParams_t Struct Reference

Data Fields

- uint32_t apnId

8.414.1 Detailed Description

Structure that contains the APN ID to obtain extra APN parameters

Parameters

apnId[IN]	• APN id

8.414.2 Field Documentation

8.414.2.1 uint32_t pack_qos_SLQSQosSwiReadApnExtraParams_t::apnId

8.415 pack_qos_SLQSQosSwiReadDataStats_t Struct Reference

Data Fields

- uint32_t apnId

8.415.1 Detailed Description

Structure that contains the APN ID to obtain data statistics

Parameters

apnId[IN]	• APN id

8.415.2 Field Documentation

8.415.2.1 uint32_t pack_qos_SLQSQosSwiReadDataStats_t::apnId

8.416 pack_qos_SLQSSetQosEventCallback_t Struct Reference

Data Fields

- uint8_t enable

8.416.1 Detailed Description

Structure that contains the APN ID to obtain data statistics

Parameters

in	*enable*	• 1 - Enable QoS event reporting • 0 - Disable QoS event reporting

8.416.2 Field Documentation

8.416.2.1 uint8_t pack_qos_SLQSSetQosEventCallback_t::enable

8.417 pack_rms_SetSMSWake_t Struct Reference

Data Fields

- uint32_t enabled
- uint32_t wake_mask

8.417.1 Detailed Description

Pack set SMS wake parameters

Parameters

enabled	• SMS wake functionality enabled – 0 - Disabled – 1 - Enabled
wake_mask	• SMS wake mask to search for incoming messages (only relevant when enabled)

8.417.2 Field Documentation

8.417.2.1 uint32_t pack_rms_SetSMSWake_t::enabled

8.417.2.2 uint32_t pack_rms_SetSMSWake_t::wake_mask

8.418 pack_sar_SLQSSetRfSarState_t Struct Reference

Data Fields

- uint32_t RfSarState

8.418.1 Detailed Description

This sturcture contain sets the specified RF SAR state parameter.

Parameters

RfSarState	• SAR RF State – QMI_SAR_RF_STATE_DEFAULT – QMI_SAR_RF_STATE_1 – QMI_SAR_RF_STATE_2 – QMI_SAR_RF_STATE_3 – QMI_SAR_RF_STATE_4 – QMI_SAR_RF_STATE_5 – QMI_SAR_RF_STATE_6 – QMI_SAR_RF_STATE_7 – QMI_SAR_RF_STATE_8

8.418.2 Field Documentation

8.418.2.1 uint32_t pack_sar_SLQSSetRfSarState_t::RfSarState

8.419 pack_sms_SaveSMS_t Struct Reference

Data Fields

- uint32_t storageType
- uint32_t messageFormat
- uint32_t messageSize
- uint8_t * pMessage

8.419.1 Detailed Description

Sutructure containing parameters to Save an SMS message to device memory

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
messageFormat	• Message format – 0 - CDMA (IS-637B) – 1 - 5 (Reserved) – 6 - GSM/WCDMA PP
messageSize	• The length of the message contents in bytes

pMessage	• The message contents

8.419.2 Field Documentation

8.419.2.1 uint32_t pack_sms_SaveSMS_t::messageFormat

8.419.2.2 uint32_t pack_sms_SaveSMS_t::messageSize

8.419.2.3 uint8_t* pack_sms_SaveSMS_t::pMessage

8.419.2.4 uint32_t pack_sms_SaveSMS_t::storageType

8.420 pack_sms_SendSMS_t Struct Reference

Data Fields

- uint32_t messageFormat
- uint32_t messageSize
- uint8_t * pMessage
- uint8_t * pLinktimer

8.420.1 Detailed Description

This structure contains pack send SMS parameters.

Parameters

messageFormat	• Message format – 0 - CDMA (IS-637B) – 1 - 5 (Reserved) – 6 - GSM/WCDMA PP
messageSize	• The length of the message contents in bytes
pLinktimer	• GW SMS link open for the specified number of second
pMessage	• The message contents in PDU format contains SMS header and payload message

8.420.2 Field Documentation

8.420.2.1 uint32_t pack_sms_SendSMS_t::messageFormat

8.420.2.2 uint32_t pack_sms_SendSMS_t::messageSize

8.420.2.3 uint8_t* pack_sms_SendSMS_t::pLinktimer

8.420.2.4 uint8_t* pack_sms_SendSMS_t::pMessage

8.421 pack_sms_SetNewSMSCallback_t Struct Reference

Data Fields

- enum eqmiCbkSetStatus status

8.421.1 Detailed Description

This strucure contains pack set new SMS callback parameters.

Parameters

status	callback parameter

8.421.2 Field Documentation

8.421.2.1 enum eqmiCbkSetStatus pack_sms_SetNewSMSCallback_t::status

8.422 pack_sms_SetSMSCAddress_t Struct Reference

Data Fields

- uint8_t * pSMSCAddress
- uint8_t * pSMSCType

8.422.1 Detailed Description

Structure to Set the SMS center address.

Parameters

SMSCAddress	• The SMS center address represented as a NULL terminated string
SMSCType	• The SMS center address type represented as a NULL terminated string (optional).

8.422.2 Field Documentation

8.422.2.1 uint8_t* pack_sms_SetSMSCAddress_t::pSMSCAddress

8.422.2.2 uint8_t* pack_sms_SetSMSCAddress_t::pSMSCType

8.423 pack_sms_SLQSDeleteSMS_t Struct Reference

Data Fields

- uint32_t storageType
- uint32_t * pMessageIndex
- uint32_t * pMessageTag
- uint8_t * pMessageMode

8.423.1 Detailed Description

This structure contains pack delete SMS parameters.

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
pMessageIndex	• (Optional) message index
pMessageTag	• (Optional) message tag – 0 - Read – 1 - Not read – 2 - Mobile originated and sent – 3 - Mobile originated but not yet sent
pMessageMode	• (Optional) message mode • this must be included if the device is capable of supporting more than one protocol • e.g. CDMA and GW – 0x00 - CDMA, LTE (if network type is CDMA) – 0x01 - GW, LTE (if network type is UMTS)

8.423.2 Field Documentation

8.423.2.1 uint32_t* pack_sms_SLQSDeleteSMS_t::pMessageIndex

8.423.2.2 uint8_t* pack_sms_SLQSDeleteSMS_t::pMessageMode

8.423.2.3 uint32_t* pack_sms_SLQSDeleteSMS_t::pMessageTag

8.423.2.4 uint32_t pack_sms_SLQSDeleteSMS_t::storageType

8.424 pack_sms_SLQSGetSMS_t Struct Reference

Data Fields

- uint32_t storageType
- uint32_t messageIndex
- uint8_t * pMessageMode

8.424.1 Detailed Description

This sturcture contains pack get SMS parameters.

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
messageIndex	• Message index
pMessageMode	• 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS)

8.424.2 Field Documentation

8.424.2.1 uint32_t pack_sms_SLQSGetSMS_t::messageIndex

8.424.2.2 uint8_t* pack_sms_SLQSGetSMS_t::pMessageMode

8.424.2.3 uint32_t pack_sms_SLQSGetSMS_t::storageType

8.425 pack_sms_SLQSGetSmsBroadcastConfig_t Struct Reference

Data Fields

- uint8_t mode

8.425.1 Detailed Description

This structure contains get SMS boardcast configure parameter.

Parameters

mode	• Mode – 0x00 - CDMA, LTE (if network type is CDMA) – 0x01 - GW, LTE (if network type is UMTS)

8.425.2 Field Documentation

8.425.2.1 uint8_t pack_sms_SLQSGetSmsBroadcastConfig_t::mode

8.426 pack_sms_SLQSGetSMSList_t Struct Reference

Data Fields

- uint32_t storageType
- uint32_t * pRequestedTag
- uint8_t * pMessageMode

8.426.1 Detailed Description

This structure contains pack get SMS list parameters.

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
requestedTag	• (Optional) Message tag – 0 - Read – 1 - Not read – 2 - Mobile originated and sent – 3 - Mobile originated but not yet sent
messageMode	• 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS)

8.426.2 Field Documentation

8.426.2.1 uint8_t* pack_sms_SLQSGetSMSList_t::pMessageMode

8.426.2.2 uint32_t* pack_sms_SLQSGetSMSList_t::pRequestedTag

8.426.2.3 uint32_t pack_sms_SLQSGetSMSList_t::storageType

8.427 pack_sms_SLQSModifySMSStatus_t Struct Reference

Data Fields

- uint32_t storageType
- uint32_t messageIndex
- uint32_t messageTag
- uint8_t * pMessageMode

8.427.1 Detailed Description

This structure contains pack modify SMS status parameters.

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
messageIndex	• Message index
messageTag	• Message tag – 0 - Read – 1 - Not read
pMessageMode	• 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS)

8.427.2 Field Documentation

8.427.2.1 uint32_t pack_sms_SLQSModifySMSStatus_t::messageIndex

8.427.2.2 uint32_t pack_sms_SLQSModifySMSStatus_t::messageTag

8.427.2.3 uint8_t* pack_sms_SLQSModifySMSStatus_t::pMessageMode

8.427.2.4 uint32_t pack_sms_SLQSModifySMSStatus_t::storageType

8.428 pack_sms_SLQSSendAsyncSMS_t Struct Reference

Data Fields

- sms_sendAsyncsmsParams * pSendSmsParams

8.428.1 Detailed Description

Structure contain Parameter to Send an SMS message for immediate over-the-air transmission

Parameters

pSendSms-Params	• structure containing the SMS parameters. Refer sms_sendasyncsmsparams

8.428.2 Field Documentation

8.428.2.1 sms_sendAsyncsmsParams* pack_sms_SLQSSendAsyncSMS_t::pSendSmsParams

8.429 pack_sms_SLQSSetIndicationRegister_t Struct Reference

Data Fields

- sms_setIndicationReg * pSetIndicationRegReq

8.429.1 Detailed Description

Structure contain Parameter that sets the registration state of different WMS indications.

Parameters

pSetIndication-Reg	• Pointer to structure of indicationRegReqParams – See sms_setIndicationReg for more information

8.429.2 Field Documentation

8.429.2.1 sms_setIndicationReg* pack_sms_SLQSSetIndicationRegister_t::pSetIndicationRegReq

8.430 pack_sms_SLQSSetSmsBroadcastActivation_t Struct Reference

Data Fields

- uint8_t mode
- uint8_t broadcastActivate

8.430.1 Detailed Description

Structure contain parameters that Enables or disables the reception of broadcast SMS messages.

Parameters

Mode	• Mode • 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS)
broadcast-Activate	• 0x00 - Disable broadcast • 0x01 - Activate broadcast

8.430.2 Field Documentation

8.430.2.1 uint8_t pack_sms_SLQSSetSmsBroadcastActivation_t::broadcastActivate

8.430.2.2 uint8_t pack_sms_SLQSSetSmsBroadcastActivation_t::mode

8.431 pack_sms_SLQSSetSmsBroadcastConfig_t Struct Reference

Data Fields

- uint8_t mode
- sms_qaQmi3GPPBroadcastCfgInfo * pBroadcastConfig
- sms_qaQmi3GPP2BroadcastCfgInfo * pCDMABroadcastConfig

8.431.1 Detailed Description

Structure containing parameters that provides the information about the SMS BroadcastConfiguration

Parameters

mode	• Mode – 0x00 - CDMA, LTE (if network type is CDMA) – 0x01 - GW, LTE (if network type is UMTS)
pBroadcast-Config	• The data for 3GPP Broadcast Information(Optional).
pCDMA-BroadcastConfig	• The data for 3GPP2 Broadcast Information(Optional).

8.431.2 Field Documentation

8.431.2.1 uint8_t pack_sms_SLQSSetSmsBroadcastConfig_t::mode

8.431.2.2 sms_qaQmi3GPPBroadcastCfgInfo* pack_sms_SLQSSetSmsBroadcastConfig_t::pBroadcastConfig

8.431.2.3 sms_qaQmi3GPP2BroadcastCfgInfo* pack_sms_SLQSSetSmsBroadcastConfig_t::pCDMABroadcastConfig

8.432 pack_sms_SLQSSetSmsStorage_t Struct Reference

Data Fields

- uint8_t smsStorage

8.432.1 Detailed Description

Structure contain Parameter to set the SMS Storage on the device

Parameters

smsStorage	• SMS Storage – 0x01 - device's permanent memory – 0x02 - UICC

8.432.2 Field Documentation

8.432.2.1 uint8_t pack_sms_SLQSSetSmsStorage_t::smsStorage

8.433 pack_sms_SLQSSmsGetMaxStorageSize_t Struct Reference

Data Fields

- sms_maxStorageSizeReq * pMaxStorageSizeReq

8.433.1 Detailed Description

This structure contains get maximum storage size.

Parameters

pMaxStorage-SizeReq	• Request parameters for SmsSLQSGetMaxStorageSize – See sms_maxStorageSizeReq for more information

8.433.2 Field Documentation

8.433.2.1 sms_maxStorageSizeReq* pack_sms_SLQSSmsGetMaxStorageSize_t::pMaxStorageSizeReq

8.434 pack_sms_SLQSSmsSetRoutes_t Struct Reference

Data Fields

- sms_setRoutesReq * pSetRoutesReq

8.434.1 Detailed Description

Structure contain parameter that Sets the action performed on SMS message receipt for specified message routes. It also specifies the action performed on SMS receipt of status reports.

Parameters

pSetRoutesReq	• Pointer to structure of smsSetRoutesReq – See sms_setRoutesReq for more information

8.434.2 Field Documentation

8.434.2.1 sms_setRoutesReq* pack_sms_SLQSSmsSetRoutes_t::pSetRoutesReq

8.435 pack_swiaudio_SLQSGetM2MAudioProfile_t Struct Reference

Data Fields

- uint8_t * pGenerator

8.435.1 Detailed Description

This structure contains the SLQSGetM2MAudioProfile pack parameters.

Parameters

pGenerator[optional]	• Generator – 0 - Voice

8.435.2 Field Documentation

8.435.2.1 uint8_t* pack_swiaudio_SLQSGetM2MAudioProfile_t::pGenerator

8.436 pack_swiaudio_SLQSGetM2MAudioVolume_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Generator

8.436.1 Detailed Description

This structure contains the SLQSGetM2MAudioVolume pack parameters.

Parameters

Profile	• Audio Profile – 0-5
Generator	• Generator – 0 - Voice

8.436.2 Field Documentation

8.436.2.1 uint8_t pack_swiaudio_SLQSGetM2MAudioVolume_t::Generator

8.436.2.2 uint8_t pack_swiaudio_SLQSGetM2MAudioVolume_t::Profile

8.437 pack_swiaudio_SLQSGetM2MAVMute_t Struct Reference

Data Fields

- uint8_t Profile

8.437.1 Detailed Description

This structure contains the SLQSGetM2MAVMute pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5

8.437.2 Field Documentation

8.437.2.1 uint8_t pack_swiaudio_SLQSGetM2MAVMute_t::Profile

8.438 pack_swiaudio_SLQSGetM2MSpkrGain_t Struct Reference

Data Fields

- uint8_t Profile

8.438.1 Detailed Description

This structure contains the SLQSGetM2MSpkrGain pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5

8.438.2 Field Documentation

8.438.2.1 uint8_t pack_swiaudio_SLQSGetM2MSpkrGain_t::Profile

8.439 pack_swiaudio_SLQSSetM2MAudioAVCFG_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Device
- uint8_t PIFACEId
- swiaudio_PCMparams * pPCMParams

8.439.1 Detailed Description

This structure contains the SLQSSetM2MAudioAVCFG pack parameters.

Parameters

Profile	• Audio Profile – 0-5

Device	• ACDB Device • See qaGobiApiTableSwiAudio.h for more information on ACDB Device
PIFACEId	• Physical Interface • See qaGobiApiTableSwiAudio.h for more information on physical interface
pPCMParams	• PCM parameters • See swiaudio_PCMparams for more information

8.439.2 Field Documentation

8.439.2.1 uint8_t pack_swiaudio_SLQSSetM2MAudioAVCFG_t::Device

8.439.2.2 uint8_t pack_swiaudio_SLQSSetM2MAudioAVCFG_t::PIFACEId

8.439.2.3 swiaudio_PCMparams* pack_swiaudio_SLQSSetM2MAudioAVCFG_t::pPCMParams

8.439.2.4 uint8_t pack_swiaudio_SLQSSetM2MAudioAVCFG_t::Profile

8.440 pack_swiaudio_SLQSSetM2MAudioLPBK_t Struct Reference

Data Fields

- uint8_t Enable

8.440.1 Detailed Description

This structure contains the SLQSSetM2MAudioLPBK pack parameters.

Parameters

Enable	• Operation to be performed – 0 - stop – 1 - VOCODER loop – 2 - internal codec loop

8.440.2 Field Documentation

8.440.2.1 uint8_t pack_swiaudio_SLQSSetM2MAudioLPBK_t::Enable

8.441 pack_swiaudio_SLQSSetM2MAudioProfile_t Struct Reference

Data Fields

- uint8_t Profile

- uint8_t * pEarMute
- uint8_t * pMicMute
- uint8_t * pGenerator
- uint8_t * pVolume
- uint8_t * pCwtMute

8.441.1 Detailed Description

This structure contains the SLQSSetM2MAudioProfile pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5
pEarMute	• Ear Mute – 0 - mute – 1 - unmute
pMicMute	• Mic Mute – 0 - mute – 1 - unmute
pGenerator	• Generator – 0 - voice
pVolume	• Set RX Volume level – 0-5
pCwtMute	• Call Waiting Tone Mute – 0 - Mute – 1 - UnMute

8.441.2 Field Documentation

8.441.2.1 uint8_t* pack_swiaudio_SLQSSetM2MAudioProfile_t::pCwtMute

8.441.2.2 uint8_t* pack_swiaudio_SLQSSetM2MAudioProfile_t::pEarMute

8.441.2.3 uint8_t* pack_swiaudio_SLQSSetM2MAudioProfile_t::pGenerator

8.441.2.4 uint8_t* pack_swiaudio_SLQSSetM2MAudioProfile_t::pMicMute

8.441.2.5 uint8_t pack_swiaudio_SLQSSetM2MAudioProfile_t::Profile

8.441.2.6 uint8_t* pack_swiaudio_SLQSSetM2MAudioProfile_t::pVolume

8.442 pack_swiaudio_SLQSSetM2MAudioVolume_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t Generator
- uint8_t Level

8.442.1 Detailed Description

This structure contains the SLQSSetM2MAudioProfile pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5
Generator	• Generator – 0 - voice
Level	• Audio volume level – 0-5

8.442.2 Field Documentation

8.442.2.1 uint8_t pack_swiaudio_SLQSSetM2MAudioVolume_t::Generator

8.442.2.2 uint8_t pack_swiaudio_SLQSSetM2MAudioVolume_t::Level

8.442.2.3 uint8_t pack_swiaudio_SLQSSetM2MAudioVolume_t::Profile

8.443 pack_swiaudio_SLQSSetM2MAVMute_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t EarMute
- uint8_t MicMute
- uint8_t * pCwtMute

8.443.1 Detailed Description

This structure contains the SLQSSetM2MAVMute pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5

EarMute	• Ear Mute – 0-1
MicMute	• Mic Mute – 0-1
pCwtMute	[Optional] • Call Waiting Tone Mute – 0-1

8.443.2 Field Documentation

8.443.2.1 uint8_t pack_swiaudio_SLQSSetM2MAVMute_t::EarMute

8.443.2.2 uint8_t pack_swiaudio_SLQSSetM2MAVMute_t::MicMute

8.443.2.3 uint8_t* pack_swiaudio_SLQSSetM2MAVMute_t::pCwtMute

8.443.2.4 uint8_t pack_swiaudio_SLQSSetM2MAVMute_t::Profile

8.444 pack_swiaudio_SLQSSetM2MSpkrGain_t Struct Reference

Data Fields

- uint8_t Profile
- uint16_t Value

8.444.1 Detailed Description

This structure contains the SLQSSetM2MSpkrGain pack parameters.

Parameters

Profile	• Audio Profile Number – 0-5
Value	• RX speakerphone gain – 0x0 - 0x7fff

8.444.2 Field Documentation

8.444.2.1 uint8_t pack_swiaudio_SLQSSetM2MSpkrGain_t::Profile

8.444.2.2 uint16_t pack_swiaudio_SLQSSetM2MSpkrGain_t::Value

8.445 pack_swiavms_SLQSAVMSSendSelection_t Struct Reference

Data Fields

- uint8_t selection
- uint32_t * pDeferTime
- uint8_t * pClientPerformOperationFlag
- uint8_t * pPackageID
- uint16_t * pRejectReason

8.445.1 Detailed Description

Structure containing the AVMS selection

Parameters

selection[IN]	• User Selection – 0x01 - Accept – 0x02 - Reject – 0x03 - Defer
pDeferTime[IN/-OPTIONAL]	• Defer time in minutes. A value of 0 will cause the prompt to be resent immediately.
pClientPerform-OperationFlag[I-N/OPTIONAL]	• Client operation flag after accept. – 0: if modem performs the operation (download or update) – 1: if client performs the operation (download or update)
pPackageID[IN/-OPTIONAL]	• Package ID.
pRejectReason[-IN/OPTIONAL]	• Reject Reason.

8.445.2 Field Documentation

8.445.2.1 uint8_t* pack_swiavms_SLQSAVMSSendSelection_t::pClientPerformOperationFlag

8.445.2.2 uint32_t* pack_swiavms_SLQSAVMSSendSelection_t::pDeferTime

8.445.2.3 uint8_t* pack_swiavms_SLQSAVMSSendSelection_t::pPackageID

8.445.2.4 uint16_t* pack_swiavms_SLQSAVMSSendSelection_t::pRejectReason

8.445.2.5 uint8_t pack_swiavms_SLQSAVMSSendSelection_t::selection

8.446 pack_swiavms_SLQSAVMSSetSettings_t Struct Reference

Data Fields

- uint8_t AutoConnect
- uint8_t AutoReboot
- uint8_t PromptFwDownload
- uint8_t PromptFwUpdate
- uint8_t * pFwAutoSDM
- uint32_t * pPollingTimer
- PackSwiAvmsSetSettingsConnectionRetryTimers * pConnectionRetryTimers
- PackSwiAvmsSetSettingsAPNInfo * pAPNInfo
- uint8_t * pNotifStore
- PackSwiAvmsSetSettingsPeriodInfo * pPeriodInfo

8.446.1 Detailed Description

Structure containing the AVMS settings to be set on the device This maps to structure SLQSAVMSSetSettings

Parameters

AutoConnect[IN]	• Auto Connect to AirVantage server – 0x00 - FALSE – 0x01 - TRUE
AutoReboot[IN]	• Automatic device reboot when the request is received from AirVantage server – 0x00 - FALSE – 0x01 - TRUE
PromptFwDownload[IN]	• Firmware Auto Download – 0x00 - FALSE – 0x01 - TRUE
PromptFwUpdate[IN]	• 1 byte parameter indicating FOTA Automatic update – 0x00 - Firmware autoupdate FALSE – 0x01 - Firmware autoupdate TRUE
pFwAutoSDM[IN/OPTIONAL]	• OMA Automatic UI Alert Response – 0x00 - DISABLED – 0x01 - ENABLED ACCEPT – 0x02 - ENABLED REJECT
pPollingTimer[IN/OPTIONAL]	• Polling timer to connect to AVMS server – 0-525600 (min) – 0:disabled
pConnectionRetryTimers[IN/OPTIONAL]	• See PackSwiAvmsSetSettingsConnectionRetryTimers for more information

pAPNInfo[IN/OPTIONAL]	• See PackSwiAvmsSetSettingsAPNInfo for more information
pNotifStore[IN/OPTIONAL]	• See PackSwiAvmsSetSettingsAPNInfo for more information
pPeriodInfo[IN/OPTIONAL]	• See PackSwiAvmsSetSettingsAPNInfo for more information

8.446.2 Field Documentation

8.446.2.1 uint8_t pack_swiavms_SLQSAVMSSetSettings_t::AutoConnect

8.446.2.2 uint8_t pack_swiavms_SLQSAVMSSetSettings_t::AutoReboot

8.446.2.3 PackSwiAvmsSetSettingsAPNInfo* pack_swiavms_SLQSAVMSSetSettings_t::pAPNInfo

8.446.2.4 PackSwiAvmsSetSettingsConnectionRetryTimers* pack_swiavms_SLQSAVMSSetSettings_t::pConnectionRetryTimers

8.446.2.5 uint8_t* pack_swiavms_SLQSAVMSSetSettings_t::pFwAutoSDM

8.446.2.6 uint8_t* pack_swiavms_SLQSAVMSSetSettings_t::pNotifStore

8.446.2.7 PackSwiAvmsSetSettingsPeriodInfo* pack_swiavms_SLQSAVMSSetSettings_t::pPeriodInfo

8.446.2.8 uint32_t* pack_swiavms_SLQSAVMSSetSettings_t::pPollingTimer

8.446.2.9 uint8_t pack_swiavms_SLQSAVMSSetSettings_t::PromptFwDownload

8.446.2.10 uint8_t pack_swiavms_SLQSAVMSSetSettings_t::PromptFwUpdate

8.447 pack_swiavms_SLQSAVMSSetSettings_v2_t Struct Reference

Data Fields

- uint8_t AutoConnect
- uint8_t PromptFwDownload
- uint8_t PromptFwUpdate
- uint8_t * pFwAutoSDM
- uint32_t * pPollingTimer
- PackSwiAvmsSetSettingsConnectionRetryTimers * pConnectionRetryTimers
- PackSwiAvmsSetSettingsAPNInfo * pAPNInfo
- uint8_t * pNotifStore
- PackSwiAvmsSetSettingsPeriodInfo * pPeriodInfo
- uint8_t * pAutoReboot

8.447.1 Detailed Description

Structure containing the AVMS settings to be set on the device This maps to structure SLQSAVMSSetSettings_v2 (For AVC2 service)

Parameters

AutoConnect[IN]	• Auto Connect to AirVantage server – 0x00 - FALSE – 0x01 - TRUE
PromptFwDownload[IN]	• Firmware Auto Download – 0x00 - FALSE – 0x01 - TRUE
PromptFwUpdate[IN]	• 1 byte parameter indicating FOTA Automatic update – 0x00 - Firmware autoupdate FALSE – 0x01 - Firmware autoupdate TRUE
pFwAutoSDM[IN/OPTIONAL]	• OMA Automatic UI Alert Response – 0x00 - DISABLED – 0x01 - ENABLED ACCEPT – 0x02 - ENABLED REJECT
pPollingTimer[IN/OPTIONAL]	• Polling timer to connect to AVMS server – 0-525600 (min) – 0:disabled
pConnectionRetryTimers[IN/OPTIONAL]	• See PackSwiAvmsSetSettingsConnectionRetryTimers for more information
pAPNInfo[IN/OPTIONAL]	• See PackSwiAvmsSetSettingsAPNInfo for more information
pNotifStore[IN/OPTIONAL]	• See PackSwiAvmsSetSettingsAPNInfo for more information
pPeriodInfo[IN/OPTIONAL]	• See PackSwiAvmsSetSettingsAPNInfo for more information
pAutoReboot[IN/OPTIONAL]	• Automatic device reboot when the request is received from AirVantage server – 0x00 - FALSE – 0x01 - TRUE

Note

Setting PromptFwDownload/PromptFwUpdate as TRUE implies AutoConnect to be also TRUE even if AutoConnect was set FALSE initially. Automatic firmware download/update selection trumps the connection setting flag.

8.447.2 Field Documentation

8.447.2.1 uint8_t pack_swiavms_SLQSAVMSSetSettings_v2_t::AutoConnect

8.447.2.2 PackSwiAvmsSetSettingsAPNInfo* pack_swiavms_SLQSAVMSSetSettings_v2_t::pAPNInfo

8.447.2.3 uint8_t* pack_swiavms_SLQSAVMSSetSettings_v2_t::pAutoReboot

8.447.2.4 PackSwiAvmsSetSettingsConnectionRetryTimers* pack_swiavms_SLQSAVMSSetSettings_v2_t::pConnectionRetryTimers

8.447.2.5 uint8_t* pack_swiavms_SLQSAVMSSetSettings_v2_t::pFwAutoSDM

8.447.2.6 uint8_t* pack_swiavms_SLQSAVMSSetSettings_v2_t::pNotifStore

8.447.2.7 PackSwiAvmsSetSettingsPeriodInfo* pack_swiavms_SLQSAVMSSetSettings_v2_t::pPeriodInfo

8.447.2.8 uint32_t* pack_swiavms_SLQSAVMSSetSettings_v2_t::pPollingTimer

8.447.2.9 uint8_t pack_swiavms_SLQSAVMSSetSettings_v2_t::PromptFwDownload

8.447.2.10 uint8_t pack_swiavms_SLQSAVMSSetSettings_v2_t::PromptFwUpdate

8.448 pack_swiavms_SLQSAVMSStartSession_t Struct Reference

Data Fields

- uint8_t sessionType

8.448.1 Detailed Description

Structure that contains the session type request for AVMS start session command

Parameters

sessionType[IN]	• Session type – 0x01 - FOTA, to check availability of FW Update. This field is mandatory in OMA-DM case but not necessary in LWM2M one. To keep compatibility, this shall be used in LWM2M without any specific treatment.

8.448.2 Field Documentation

8.448.2.1 uint8_t pack_swiavms_SLQSAVMSStartSession_t::sessionType

8.449 pack_swiavms_SLQSAVMSStopSession_t Struct Reference

Data Fields

- uint8_t sessionType

8.449.1 Detailed Description

Structure that contains the session type for AVMS Stop session command

Parameters

sessionType	• Session type – 0x01 - FOTA, to suspend FOTA session. – 0xFF - Suspend ongoing FOTA session or stop any other active AVMS session.
resultcode	• Tlv Result Code

8.449.2 Field Documentation

8.449.2.1 uint8_t pack_swiavms_SLQSAVMSStopSession_t::sessionType

8.450 pack_swidms_SLQSSwiDmsSetMTU_t Struct Reference

Data Fields

- uint16_t MTUSize

8.450.1 Detailed Description

This structure contains the Set MTU request parameter.

Parameters

MTUSize	• Set MTU size • MTU Values – 0 - use default value – 576 to 2000 - other values required by carrier. – Set the same MTU for all RAT/interfaces. – New MTU size effective after modem reboot.

8.450.2 Field Documentation

8.450.2.1 uint16_t pack_swidms_SLQSSwiDmsSetMTU_t::MTUSize

8.451 pack_swidms_SLQSSwiDmsSetUsbComp_t Struct Reference

Data Fields

- uint32_t CfgValue

8.451.1 Detailed Description

This structure contains the Set Usb Interface Config request parameter.

Parameters

CfgValue	• Host composition bit mask, see supported USB interface bitmasks, not supported by QMI object setting for 9x50 modules – 0x00000001 - DIAG interface – 0x00000002 - ADB interface – 0x00000004 - NMEA interface – 0x00000008 - MODEM interface – 0x00000010 - RESERVED5 – 0x00000020 - RESERVED6 – 0x00000040 - RESERVED7 – 0x00000080 - RESERVED8 – 0x00000100 - RMENT0 interface – 0x00000200 - RESERVED10 – 0x00000400 - RMENT1 interface – 0x00000800 - RESERVED12 – 0x00001000 - MBIM interface – 0x00002000 - RESERVED14 – 0x00004000 - RNDIS interface – 0x00008000 - RESERVED16 – 0x00010000 - AUDIO interface – 0x00020000 - RESERVED18 – 0x00080000 - ECM interface – 0x00100000 - RESERVED21 – 0x00200000 - RESERVED22 – 0xFFC00000 - RESERVED

8.451.2 Field Documentation

8.451.2.1 uint32_t pack_swidms_SLQSSwiDmsSetUsbComp_t::CfgValue

8.452 pack_swidms_SLQSSwiDmsSetUsbNetNum_t Struct Reference

Data Fields

- uint8_t nUsbNetNum

8.452.1 Detailed Description

This structure contains usb net number to set on remote endpoint for QMAP configuration

Parameters

nUsbNetNum	• value of usb net numbers to set for the device • range is 0-8

8.452.2 Field Documentation

8.452.2.1 uint8_t pack_swidms_SLQSSwiDmsSetUsbNetNum_t::nUsbNetNum

8.453 pack_swiloc_SwiLocSetAutoStart_t Struct Reference

Data Fields

- uint8_t function
- int set_function
- uint8_t fix_type
- int set_fix_type
- uint8_t max_time
- int set_max_time
- uint32_t max_dist
- int set_max_dist
- uint32_t fix_rate
- int set_fix_rate

8.453.1 Detailed Description

This structure contains SWI LOC Get Auto Start setting

Parameters

function	• Setting to indicate when modem should start an automatic GNSS fix – 0 - disabled – 1 - At bootup – 2 - When NMEA port is opened
set_function	• 0 - do not set to modem • I - set to modem
fix_type	• Type of GNSS fix: – 1 - Default Engine mode – 2 - MS-Based – 3 - MS-Assisted – 4 - Standalone
set_fix_type	• 0 - do not set to modem • I - set to modem
max_time	• Maximum time allowed for the receiver to get a fix in seconds • Valid range: 1-255
set_max_time	• 0 - do not set to modem • I - set to modem

max_dist	• Maximum uncertainty of a fix measured by distance in meters • Valid range: 1 - 4294967280
set_max_dist	• 0 - do not set to modem • l - set to modem
fix_rate	• Time between fixes in seconds • Valid range: 1–65535
set_fix_rate	• 0 - do not set to modem • l - set to modem

8.453.2 Field Documentation

8.453.2.1 uint32_t pack_swiloc_SwiLocSetAutoStart_t::fix_rate

8.453.2.2 uint8_t pack_swiloc_SwiLocSetAutoStart_t::fix_type

8.453.2.3 uint8_t pack_swiloc_SwiLocSetAutoStart_t::function

8.453.2.4 uint32_t pack_swiloc_SwiLocSetAutoStart_t::max_dist

8.453.2.5 uint8_t pack_swiloc_SwiLocSetAutoStart_t::max_time

8.453.2.6 int pack_swiloc_SwiLocSetAutoStart_t::set_fix_rate

8.453.2.7 int pack_swiloc_SwiLocSetAutoStart_t::set_fix_type

8.453.2.8 int pack_swiloc_SwiLocSetAutoStart_t::set_function

8.453.2.9 int pack_swiloc_SwiLocSetAutoStart_t::set_max_dist

8.453.2.10 int pack_swiloc_SwiLocSetAutoStart_t::set_max_time

8.454 pack_swioma_SLQSOMADMCancelSession_t Struct Reference

Data Fields

- uint32_t sessionType

8.454.1 Detailed Description

Structure that contains the session type for OMA cancel session command

Parameters

sessionType	[in] • Session type – 0x01 - FOTA, to check availability of FW Update – 0xFF - Cancel any active OMADM session

8.454.2 Field Documentation

8.454.2.1 uint32_t pack_swioma_SLQSOMADMCancelSession_t::sessionType

8.455 pack_swioma_SLQSOMADMCancelSessionExt_t Struct Reference

Data Fields

- uint32_t sessionType

8.455.1 Detailed Description

Structure that contains the session type for OMA cancel session command

Parameters

sessionType	[IN] • Session type – 0x01 - FOTA, to check availability of FW Update – 0xFF - Cancel any active OMADM session

8.455.2 Field Documentation

8.455.2.1 uint32_t pack_swioma_SLQSOMADMCancelSessionExt_t::sessionType

8.456 pack_swioma_SLQSOMADMGetSessionInfo_t Struct Reference

Data Fields

- uint32_t SessionType

8.456.1 Detailed Description

Structure that contains the session type for OMA get session info command

Parameters

SessionType	[in] • Session type – 0x01 - FOTA – 0xFF - Any active OMADM session. If no active sessions are available, then previous OMADM session info is returned

8.456.2 Field Documentation

8.456.2.1 uint32_t pack_swioma_SLQSOMADMGetSessionInfo_t::SessionType

8.457 pack_swioma_SLQSOMADMSendSelection_t Struct Reference

Data Fields

- uint32_t selection
- uint32_t * pDeferTime
- uint32_t * pRejectReason

8.457.1 Detailed Description

Structure containing the OMA DM selection

Parameters

selection	[in] • OMA-DM NIA Selection – 0x01 - Accept – 0x02 - Reject – 0x03 - Defer
pDeferTime	[in] • Defer time in minutes. A value of 0 will cause the prompt to be resent immediately. • This TLV is mandatory if selection is set to 0x03.
pRejectReason	[in] • Reject Reason • This TLV is processed if selection is set to 0x02. If it is not present, the reject reason 0 is used as default.

8.457.2 Field Documentation

8.457.2.1 uint32_t* pack_swioma_SLQSOMADMSendSelection_t::pDeferTime

8.457.2.2 uint32_t* pack_swioma_SLQSOMADMSendSelection_t::pRejectReason

8.457.2.3 uint32_t pack_swioma_SLQSOMADMSendSelection_t::selection

8.458 pack_swioma_SLQSOMADMSendSelectionExt_t Struct Reference

Data Fields

- uint32_t selection

8.458.1 Detailed Description

Structure containing the OMA DM selection

Parameters

selection	[IN] • OMA-DM NIA Selection – 0x01 - Accept – 0x02 - Reject – 0x03 - Defer

8.458.2 Field Documentation

8.458.2.1 uint32_t pack_swioma_SLQSOMADMSendSelectionExt_t::selection

8.459 pack_swioma_SLQSOMADMSetSettings_t Struct Reference

Data Fields

- uint8_t FOTAdownload
- uint8_t FOTAUpdate
- uint8_t * pAutosdm
- uint8_t * pFwAutoCheck

8.459.1 Detailed Description

Structure containing the OMA DM settings to be set on the device This maps to structure SLQSOMADMSettings-ReqParams3

Parameters

FOTAdownload	• 1 Byte parameter indicating support for FOTA Automatic download – 0x00 - Firmware autodownload FALSE – 0x01 - Firmware autodownload TRUE
FOTAUpdate	• 1 byte parameter indicating FOTA Automatic update – 0x00 - Firmware autoupdate FALSE – 0x01 - Firmware autoupdate TRUE
pAutosdm	• Optional 1 byte parameter indicating OMA Automatic UI Alert Response – 0x00 - Disabled – 0x01 - Enabled Accept – 0x02 - Enabled Reject
pFwAutoCheck	• Optional 1 byte parameter indicating OMA Automatic Check for Firmware Update on Power-Up Response – 0x00 - Disabled – 0x01 - Enabled

8.459.2 Field Documentation

8.459.2.1 uint8_t pack_swioma_SLQSOMADMSetSettings_t::FOTAdownload

8.459.2.2 uint8_t pack_swioma_SLQSOMADMSetSettings_t::FOTAUpdate

8.459.2.3 uint8_t* pack_swioma_SLQSOMADMSetSettings_t::pAutosdm

8.459.2.4 uint8_t* pack_swioma_SLQSOMADMSetSettings_t::pFwAutoCheck

8.460 pack_swioma_SLQSOMADMSetSettingsExt_t Struct Reference

Data Fields

- uint8_t FOTAdownload
- uint8_t FOTAUpdate
- uint8_t OMADMEnable
- uint8_t OMADMLogEnable
- uint8_t FUMOEnable
- uint8_t PRLEnable

8.460.1 Detailed Description

Structure containing the OMA DM settings to be set on the device This maps to structure SLQSOMADMSetSettingsExt

Parameters

FOTAdownload	• 1 Byte parameter indicating support for FOTA Automatic download – 0x00 - Firmware autodownload FALSE – 0x01 - Firmware autodownload TRUE
FOTAUpdate	• 1 byte parameter indicating FOTA Automatic update – 0x00 - Firmware autoupdate FALSE – 0x01 - Firmware autoupdate TRUE
OMADMEnable	[IN] • 1 byte parameter indicating OMA DM – 0x00 - OMA DM Disabled – 0x01 - OMA DM Enabled
OMADMLogEnable	[IN] • 1 byte parameter indicating OMA DM Logs – 0x00 - OMA DM Logs Disabled – 0x01 - OMA DM Logs Enabled
FUMOEnable	[IN] • 1 byte parameter indicating FUMO enabled – 0x00 - FUMO Disabled – 0x01 - FUMO enabled

PRLEnable	[IN] • 1 byte parameter indicating PRL Enabled – 0x00 - PRL Disabled – 0x01 - PRL Enabled – 0x02 - Launch a CI PRL – 0x03 - PRL Enabled and PRL automatic update every 45 days – 0x04 - PRL Enabled and PRL update ever 90 days

8.460.2 Field Documentation

8.460.2.1 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::FOTAdownload

8.460.2.2 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::FOTAUpdate

8.460.2.3 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::FUMOEnable

8.460.2.4 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::OMADMEnable

8.460.2.5 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::OMADMLogEnable

8.460.2.6 uint8_t pack_swioma_SLQSOMADMSetSettingsExt_t::PRLEnable

8.461 pack_swioma_SLQSOMADMStartSession_t Struct Reference

Data Fields

- uint32_t sessionType

8.461.1 Detailed Description

Structure that contains the session type for OMA start session command

Parameters

sessionType[IN]	• Session type – 0x01 - FOTA, to check availability of FW Update – 0x02 - DM, to check availability of DM Update – 0x03 - PRL, to check availability of PRL Update

8.461.2 Field Documentation

8.461.2.1 uint32_t pack_swioma_SLQSOMADMStartSession_t::sessionType

8.462 pack_swioma_SLQSOMADMStartSessionExt_t Struct Reference

Data Fields

- uint32_t sessionType

8.462.1 Detailed Description

Structure that contains the session type for OMA start session command

Parameters

sessionType	[IN] • Session type – 0x01 - FOTA, to check availability of FW Update – 0x02 - DM, to check availability of DM Update – 0x03 - PRL, to check availability of PRL Update

8.462.2 Field Documentation

8.462.2.1 uint32_t pack_swioma_SLQSOMADMStartSessionExt_t::sessionType

8.463 pack_tmd_SLQSTmdDeRegNotMitigationLvl_t Struct Reference

Data Fields

- uint8_t mitigationDevIDLen
- char mitigationDevID [255]

8.463.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

mitigationDevID-Len	• Number of sets of the following elements – mitigation_dev_id
mitigationDevID	• Mitigation device ID

8.463.2 Field Documentation

8.463.2.1 char pack_tmd_SLQSTmdDeRegNotMitigationLvl_t::mitigationDevID[255]

8.463.2.2 uint8_t pack_tmd_SLQSTmdDeRegNotMitigationLvl_t::mitigationDevIDLen

8.464 pack_tmd_SLQSTmdGetMitigationLvl_t Struct Reference

Data Fields

- uint8_t mitigationDevIDLen
- char mitigationDevID [255]

8.464.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

mitigationDevID-Len	• Number of sets of the following elements – mitigation_dev_id
mitigationDevID	• Mitigation device ID

8.464.2 Field Documentation

8.464.2.1 char pack_tmd_SLQSTmdGetMitigationLvl_t::mitigationDevID[255]

8.464.2.2 uint8_t pack_tmd_SLQSTmdGetMitigationLvl_t::mitigationDevIDLen

8.465 pack_tmd_SLQSTmdRegNotMitigationLvl_t Struct Reference

Data Fields

- uint8_t mitigationDevIDLen
- char mitigationDevID [255]

8.465.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

mitigationDevID-Len	• Number of sets of the following elements – mitigation_dev_id
mitigationDevID	• Mitigation device ID

8.465.2 Field Documentation

8.465.2.1 char pack_tmd_SLQSTmdRegNotMitigationLvl_t::mitigationDevID[255]

8.465.2.2 uint8_t pack_tmd_SLQSTmdRegNotMitigationLvl_t::mitigationDevIDLen

8.466 pack_uim_ChangePin_t Struct Reference

Data Fields

- uim_encryptedPIN1 EncryptedPIN1
- uint32_t * pIndicationToken

- uint8_t * pKeyReferenceID
- uim_sessionInformation sessionInfo
- uim_changeUIMPIN changePIN
- uint16_t TlvResult

8.466.1 Detailed Description

This structure contains information of the request parameters associated with a Change PIN API.

Parameters

sessionInfo	• See uim_sessionInformation for more information.
changePIN	• See uim_changeUIMPIN for more information.
pKeyReferenceID(optional)	• Indicates the PIN key reference ID. • Indicates the PIN key reference ID. Valid values are from 1 to 8, respectively, for application 1 to application 8. • This TLV is used only for PIN1 and PIN2 and is ignored in all other cases.
pIndicationToken(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Valid Values – 0 - Result of operation in response. Indication will not be generated by the modem – Any other positive number - Result of operation in indication. Indication will have same token value set by this function

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.466.2 Field Documentation

8.466.2.1 uim_changeUIMPIN pack_uim_ChangePin_t::changePIN

8.466.2.2 uim_encryptedPIN1 pack_uim_ChangePin_t::EncryptedPIN1

8.466.2.3 uint32_t* pack_uim_ChangePin_t::pIndicationToken

8.466.2.4 uint8_t* pack_uim_ChangePin_t::pKeyReferenceID

8.466.2.5 uim_sessionInformation pack_uim_ChangePin_t::sessionInfo

8.466.2.6 uint16_t pack_uim_ChangePin_t::TlvResult

8.467 pack_uim_ReadTransparent_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo
- uim_fileInfo fileIndex
- uim_readTransparentInfo readTransparent
- uint32_t * pIndicationToken
- uint8_t * pEncryptData
- uint16_t Tlvresult

8.467.1 Detailed Description

This structure contains information of the request parameters associated with a Read Transparent API.

Parameters

sessionInfo	• See uim_sessionInformation for more information.
fileIndex	• See uim_fileInfo for more information.
readTransparent	• See uim_readTransparentInfo for more information.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Valid Values – 0 - Result of operation in response. Indication will not be generated by the modem – Any other positive number - Result of operation in indication. Indication will have same token value set by this function
pEncrypt-Data(optional)	• Encrypt Data. • Indicates whether the data read from the card is to be encrypted.

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.467.2 Field Documentation

8.467.2.1 uim_fileInfo pack_uim_ReadTransparent_t::fileIndex

8.467.2.2 uint8_t* pack_uim_ReadTransparent_t::pEncryptData

8.467.2.3 uint32_t* pack_uim_ReadTransparent_t::pIndicationToken

8.467.2.4 uim_readTransparentInfo pack_uim_ReadTransparent_t::readTransparent

8.467.2.5 uim_sessionInformation pack_uim_ReadTransparent_t::sessionInfo

8.467.2.6 uint16_t pack_uim_ReadTransparent_t::Tlvresult

8.468 pack_uim_SetPinProtection_t Struct Reference

Data Fields

- uim_encryptedPIN1 EncryptedPIN1
- uint32_t * pIndicationToken
- uint8_t * pKeyReferenceID
- uim_sessionInformation sessionInfo
- uim_setPINProtection pinProtection
- uint16_t TlvResult

8.468.1 Detailed Description

This structure contains information of the request parameters associated with a set pin protection API.

Parameters

sessionInfo	• See uim_sessionInformation for more information.
pinProtection	• See uim_setPINProtection for more information.
pKeyReferenceID(optional)	• Indicates the PIN key reference ID. • Indicates the PIN key reference ID. Valid values are from 1 to 8, respectively, for application 1 to application 8. • This TLV is used only for PIN1 and PIN2 and is ignored in all other cases.
pIndicationToken(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Valid Values – 0 - Result of operation in response. Indication will not be generated by the modem – Any other positive number - Result of operation in indication. Indication will have same token value set by this function

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.468.2 Field Documentation

8.468.2.1 uim_encryptedPIN1 pack_uim_SetPinProtection_t::EncryptedPIN1

8.468.2.2 uint32_t* pack_uim_SetPinProtection_t::pIndicationToken

8.468.2.3 uim_setPINProtection pack_uim_SetPinProtection_t::pinProtection

8.468.2.4 uint8_t* pack_uim_SetPinProtection_t::pKeyReferenceID

8.468.2.5 uim_sessionInformation pack_uim_SetPinProtection_t::sessionInfo

8.468.2.6 uint16_t pack_uim_SetPinProtection_t::TlvResult

8.469 pack_uim_SLQSUIMAuthenticate_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo
- uim_authenticationData authData
- uint32_t * pIndicationToken

8.469.1 Detailed Description

This structure contains information of the request parameters associated with a SLQSUIMAuthenticate.

Parameters

sessionInfo	• See uim_sessionInformation for more information.
authData	• See uim_authenticationData for more information.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication.

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.469.2 Field Documentation

8.469.2.1 uim_authenticationData pack_uim_SLQSUIMAuthenticate_t::authData

8.469.2.2 uint32_t* pack_uim_SLQSUIMAuthenticate_t::pIndicationToken

8.469.2.3 uim_sessionInformation pack_uim_SLQSUIMAuthenticate_t::sessionInfo

8.470 pack_uim_SLQSUIMDepersonalization_t Struct Reference

Data Fields

- uim_depersonalizationInformation depersonilisationInfo

8.470.1 Detailed Description

This structure contains information of the request parameters associated with a Depersonalization.

Parameters

depersonilisation-Info	• See uim_depersonalizationInformation for more information.

8.470.2 Field Documentation

8.470.2.1 uim_depersonalizationInformation pack_uim_SLQSUIMDepersonalization_t::depersonilisationInfo

8.471 pack_uim_SLQSUIMEventRegister_t Struct Reference

Data Fields

- uint32_t eventMask

8.471.1 Detailed Description

This structure contains pack event register parameter.

Parameters

eventMask	- bit 1 - card status • bit 4 - physical slot status

8.471.2 Field Documentation

8.471.2.1 uint32_t pack_uim_SLQSUIMEventRegister_t::eventMask

8.472 pack_uim_SLQSUIMGetConfiguration_t Struct Reference

Data Fields

- uint32_t * pConfigurationMask

8.472.1 Detailed Description

This structure contains information of the request parameters associated with Get Configuration to get the modem configuration for the UIM module

Parameters

pConfiguration-Mask(optional)	• Requested configurations – Bit 0 - Automatic selection – Bit 1 - Personalization status – Bit 2 - Halt subscription – All other bits are reserved for future use

Note

- if the TLV is missing, the service returns all configuration items in the response.

8.472.2 Field Documentation

8.472.2.1 uint32_t* pack_uim_SLQSUIMGetConfiguration_t::pConfigurationMask

8.473 pack_uim_SLQSUIMGetFileAttributes_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo
- uim_fileInfo fileIndex
- uint32_t * pIndicationToken

8.473.1 Detailed Description

This structure contains information of the request parameters associated with a Get File Attributes

Parameters

sessionInfo	• See uim_sessionInformation for more information.
fileIndex	• See uim_fileInfo for more information.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication.

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.473.2 Field Documentation

8.473.2.1 uim_fileInfo pack_uim_SLQSUIMGetFileAttributes_t::fileIndex

8.473.2.2 uint32_t* pack_uim_SLQSUIMGetFileAttributes_t::pIndicationToken

8.473.2.3 uim_sessionInformation pack_uim_SLQSUIMGetFileAttributes_t::sessionInfo

8.474 pack_uim_SLQSUIMPowerDown_t Struct Reference

Data Fields

- uint8_t slot

8.474.1 Detailed Description

This structure contains information of the request parameters associated with a Power Down.

Parameters

slot	• Indicates the slot to be used. – 1 - Slot 1 – 2 - Slot 2

8.474.2 Field Documentation

8.474.2.1 uint8_t pack_uim_SLQSUIMPowerDown_t::slot

8.475 pack_uim_SLQSUIMPowerUp_t Struct Reference

Data Fields

- uint8_t slot
- uint8_t * pIgnoreHotSwapSwitch

8.475.1 Detailed Description

This structure contains information of the request parameters associated with a Power Down.

Parameters

slot	• Indicates the slot to be used. – 1 - Slot 1 – 2 - Slot 2
pIgnoreHot-Swap-Switch(optional)	• Hot-swap switch status. – 0 - Checks the hot-swap switch status – 1 - Ignores the hot-swap switch status

8.475.2 Field Documentation

8.475.2.1 uint8_t* pack_uim_SLQSUIMPowerUp_t::pIgnoreHotSwapSwitch

8.475.2.2 uint8_t pack_uim_SLQSUIMPowerUp_t::slot

8.476 pack_uim_SLQSUIMRefreshComplete_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo
- uint8_t refreshComplete

8.476.1 Detailed Description

This structure contains information of the request parameters associated with a Refresh Complete event.

Parameters

sessionInfo(-Mandatory)	• See uim_sessionInformation for more information.

refresh-Complete(-Mandatory)	• Indicates whether the refresh was successful. Valid values: – 0 - Refresh was not completed successfully – 1 - Refresh was completed successfully

8.476.2 Field Documentation

8.476.2.1 uint8_t pack_uim_SLQSUIMRefreshComplete_t::refreshComplete

8.476.2.2 uim_sessionInformation pack_uim_SLQSUIMRefreshComplete_t::sessionInfo

8.477 pack_uim_SLQSUIMRefreshGetLastEvent_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo

8.477.1 Detailed Description

This structure contains information of the request parameters associated with a Refresh Get Last Event.

Parameters

sessionInfo(-Mandatory)	• See uim_sessionInformation for more information.

8.477.2 Field Documentation

8.477.2.1 uim_sessionInformation pack_uim_SLQSUIMRefreshGetLastEvent_t::sessionInfo

8.478 pack_uim_SLQSUIMRefreshOK_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo
- uint8_t OKtoRefresh

8.478.1 Detailed Description

This structure contains Parameters of the Session Information

Parameters

sessionInfo	• Session Information • See uim_sessionInformation for more information

OKtoRefresh	• Indicates whether a refresh is OK. Valid values: – 0 - Not OK to refresh – 1 - OK to refresh

8.478.2 Field Documentation

8.478.2.1 uint8_t pack_uim_SLQSUIMRefreshOK_t::OKtoRefresh

8.478.2.2 uim_sessionInformation pack_uim_SLQSUIMRefreshOK_t::sessionInfo

8.479 pack_uim_SLQSUIMRefreshRegister_t Struct Reference

Data Fields

- uim_sessionInformation sessionInfo
- uim_registerRefresh regRefresh

8.479.1 Detailed Description

This structure contains information of the request parameters associated with a Refresh Register.

Parameters

sessionInfo	• Session Information params • See uim_sessionInformation for more information
regRefresh	• Register Refresh parameters • See uim_registerRefresh for more information

8.479.2 Field Documentation

8.479.2.1 uim_registerRefresh pack_uim_SLQSUIMRefreshRegister_t::regRefresh

8.479.2.2 uim_sessionInformation pack_uim_SLQSUIMRefreshRegister_t::sessionInfo

8.480 pack_uim_SLQSUIMSwitchSlot_t Struct Reference

Data Fields

- uint8_t bLogicalSlot
- uint32_t ulPhysicalSlot

8.480.1 Detailed Description

This structure contains information of the request parameters associated with a Switch Slot.

Parameters

bLogicalSlot	• Indicates the slot to be used. – 1 - Slot 1 – 2 - Slot 2 – 3 - Slot 3 – 4 - Slot 4 – 5 - Slot 5
ulPhysicalSlot	• 1 - Slot 1 • 2 - Slot 2 • 3 - Slot 3 • 4 - Slot 4 • 5 - Slot 5

8.480.2 Field Documentation

8.480.2.1 uint8_t pack_uim_SLQSUIMSwitchSlot_t::bLogicalSlot

8.480.2.2 uint32_t pack_uim_SLQSUIMSwitchSlot_t::ulPhysicalSlot

8.481 pack_uim_UnblockPin_t Struct Reference

Data Fields

- uim_encryptedPIN1 EncryptedPIN1
- uint32_t * pIndicationToken
- uint8_t * pKeyReferenceID
- uim_sessionInformation sessionInfo
- uim_unblockUIMPIN pinProtection
- uint16_t Tlvresult

8.481.1 Detailed Description

This structure contains information of the request parameters associated with a Unblock PIN API.

Parameters

EncryptedPIN1	• See uim_encryptedPIN1 for more information.
sessionInfo	• See uim_sessionInformation for more information.
pinProtection	• See uim_unblockUIMPIN for more information.

pKeyReferenceI-D(optional)	• Indicates the PIN key reference ID. • Indicates the PIN key reference ID. Valid values are from 1 to 8, respectively, for application 1 to application 8. • This TLV is used only for PIN1 and PIN2 and is ignored in all other cases.
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Valid Values – 0 - Result of operation in response. Indication will not be generated by the modem – Any other positive number - Result of operation in indication. Indication will have same token value set by this function

8.481.2 Field Documentation

8.481.2.1 uim_encryptedPIN1 pack_uim_UnblockPin_t::EncryptedPIN1

8.481.2.2 uint32_t* pack_uim_UnblockPin_t::pIndicationToken

8.481.2.3 uim_unblockUIMPIN pack_uim_UnblockPin_t::pinProtection

8.481.2.4 uint8_t* pack_uim_UnblockPin_t::pKeyReferenceID

8.481.2.5 uim_sessionInformation pack_uim_UnblockPin_t::sessionInfo

8.481.2.6 uint16_t pack_uim_UnblockPin_t::Tlvresult

8.482 pack_uim_VerifyPin_t Struct Reference

Data Fields

- uim_encryptedPIN1 * pEncryptedPIN1
- uint32_t * pIndicationToken
- uint8_t * pKeyReferenceID
- uim_sessionInformation sessionInfo
- uim_verifyUIMPIN verifyPIN
- uint16_t Tlvresult

8.482.1 Detailed Description

This structure contains information of the request parameters associated with a verify PIN API.

Parameters

sessionInfo	• See uim_sessionInformation for more information.
verifyPIN	• See uim_verifyUIMPIN for more information.

pEncryptedPIN1(optional)	• See uim_encryptedPIN1 for more information.
pKeyReferenceID(optional)	• Indicates the PIN key reference ID. • Indicates the PIN key reference ID. Valid values are from 1 to 8, respectively, for application 1 to application 8. • This TLV is used only for PIN1 and PIN2 and is ignored in all other cases.
pIndicationToken(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Valid Values – 0 - Result of operation in response. Indication will not be generated by the modem – Any other positive number - Result of operation in indication. Indication will have same token value set by this function

Note

Using NULL for the pointers would make sure that the parameter is not added to the request.

8.482.2 Field Documentation

8.482.2.1 uim_encryptedPIN1∗ pack_uim_VerifyPin_t::pEncryptedPIN1

8.482.2.2 uint32_t∗ pack_uim_VerifyPin_t::pIndicationToken

8.482.2.3 uint8_t∗ pack_uim_VerifyPin_t::pKeyReferenceID

8.482.2.4 uim_sessionInformation pack_uim_VerifyPin_t::sessionInfo

8.482.2.5 uint16_t pack_uim_VerifyPin_t::Tlvresult

8.482.2.6 uim_verifyUIMPIN pack_uim_VerifyPin_t::verifyPIN

8.483 pack_voice_AnswerUSSD_t Struct Reference

Data Fields

- uint8_t ∗ pInfo

8.483.1 Detailed Description

This structure contains pack anser USSD parameter.

Parameters

pInfo	• USS information • See voice_USSInfo for more details

8.483.2 Field Documentation

8.483.2.1 uint8_t* pack_voice_AnswerUSSD_t::pInfo

8.484 pack_voice_OriginateUSSD_t Struct Reference

Data Fields

- uint8_t * pInfo

8.484.1 Detailed Description

This structure contains pack orginate USSD parameter.

Parameters

pInfo	• USS information • See voice_USSInfo for more details

8.484.2 Field Documentation

8.484.2.1 uint8_t* pack_voice_OriginateUSSD_t::pInfo

8.485 pack_voice_SLQSOriginateUSSD_t Struct Reference

Data Fields

- uint8_t ussDCS
- uint8_t ussLen
- uint8_t ussData [182]

8.485.1 Detailed Description

This structure contains USS Information

Parameters

ussDCS	• 1 - ASCII coding scheme • 2 - 8-BIT coding scheme • 3 - UCS2
ussLen	• Range 1 to 182
ussData	• Data encoded as per the DCS

8.485.2 Field Documentation

8.485.2.1 uint8_t pack_voice_SLQSOriginateUSSD_t::ussData[182]

8.485.2.2 uint8_t pack_voice_SLQSOriginateUSSD_t::ussDCS

8.485.2.3 uint8_t pack_voice_SLQSOriginateUSSD_t::ussLen

8.486 pack_voice_SLQSVoiceALSSelectLine_t Struct Reference

Data Fields

- uint8_t lineValue

8.486.1 Detailed Description

This structure contains ALS Select Line Information Parameters.

Parameters

lineValue	• ALS Line Value. – 0x00 - ALS_LINE1 - Line 1 (default) – 0x01 - ALS_LINE2 - Line 2

8.486.2 Field Documentation

8.486.2.1 uint8_t pack_voice_SLQSVoiceALSSelectLine_t::lineValue

8.487 pack_voice_SLQSVoiceALSSetLineSwitching_t Struct Reference

Data Fields

- uint8_t switchOption

8.487.1 Detailed Description

This structure contains ALS Set Line Switching Information Parameters.

Parameters

switchOption	• Switch Option. – 0x00 - VOICE_LINE_SWITCHING_NOT_ALLOWED - Line switching is not allowed – 0x01 - VOICE_LINE_SWITCHING_ALLOWED - Line switching is allowed

8.487.2 Field Documentation

8.487.2.1 uint8_t pack_voice_SLQSVoiceALSSetLineSwitching_t::switchOption

8.488 pack_voice_SLQSVoiceAnswerCall_t Struct Reference

Data Fields

- uint8_t * pCallId

8.488.1 Detailed Description

Contains the parameters passed for pack voice Answer Call.

Parameters

pCallId	• Unique call identifier for the call that must be answered.

8.488.2 Field Documentation

8.488.2.1 uint8_t* pack_voice_SLQSVoiceAnswerCall_t::pCallId

8.489 pack_voice_SLQSVoiceBindSubscription_t Struct Reference

Data Fields

- uint8_t subsType

8.489.1 Detailed Description

This structure contains Bind Subscription Information Parameters.

Parameters

subsType	• Subscription Type. – 0x00 - VOICE_SUBS_TYPE_PRIMARY - Primary – 0x01 - VOICE_SUBS_TYPE_SECONDARY - Secondary

8.489.2 Field Documentation

8.489.2.1 uint8_t pack_voice_SLQSVoiceBindSubscription_t::subsType

8.490 pack_voice_SLQSVoiceBurstDTMF_t Struct Reference

Data Fields

- voice_burstDTMFInfo BurstDTMFInfo
- voice_DTMFLengths * pBurstDTMFLengths

8.490.1 Detailed Description

This structure contains parameters of burst Dual-Tone Multifrequency (DTMF)

Parameters

BurstDTMFInfo	• Burst DTMF Information – See voice_burstDTMFInfo for more information
pBurstDTMF-Lengths	[optional] • DTMF Lengths – See voice_DTMFLengths for more information • NULL pointer - Invalid data.

8.490.2 Field Documentation

8.490.2.1 voice_burstDTMFInfo pack_voice_SLQSVoiceBurstDTMF_t::BurstDTMFInfo

8.490.2.2 voice_DTMFLengths∗ pack_voice_SLQSVoiceBurstDTMF_t::pBurstDTMFLengths

8.491 pack_voice_SLQSVoiceDialCall_t Struct Reference

Data Fields

- uint8_t callNumber [81]
- uint8_t ∗ pCallType
- uint8_t ∗ pCLIRType
- voice_UUSInfo ∗ pUUSInFo
- voice_CUGInfo ∗ pCUGInfo
- uint8_t ∗ pEmergencyCategory
- voice_calledPartySubAdd ∗ pCallPartySubAdd
- uint8_t ∗ pSvcType

8.491.1 Detailed Description

This structure contains Voice Call Request Parameters

Parameters

callNumber[81]	• Number to be dialed in ASCII string, NULL terminated. • Length Range [1 to 81]
pCall-Type(optional)	• the type of call to be dialed. CALL_TYPE_VOICE is automatically selected if this parameter is not provided. When CALL_TYPE_NON_STD_OTASP is selected, the call is sent as a nonstandard OTASP call regardless of the digit string Call type values are: – 0x00 - CALL_TYPE_VOICE - Voice (automatic selection) – 0x01 - CALL_TYPE_VOICE_FORCED - Avoid modem call classification – 0x08 - CALL_TYPE_NON_STD_OTASP - Nonstandard OTASP∗ – 0x09 - CALL_TYPE_EMERGENCY - Emergency

pCLIR-Type(optional)	• CLIR type values are: – 0x01 - CLIR_SUPPRESSION - Suppression – 0x02 - CLIR_INVOCATION - Invocation
pUUSIn-Fo(optional)	• Pointer to structure of UUSInfo – See voice_UUSInfo for more information
pCUG-Info(optional)	• Pointer to structure of CUGInfo – See voice_CUGInfo for more information
pEmergency-Category(optional)	• Bit mask of emergency number categories. This is only applicable when the call type is set to Emergency. – Bit 0 - VOICE_EMER_CAT_POLICE_BIT - Police – Bit 1 - VOICE_EMER_CAT_AMBULANCE_BIT - Ambulance – Bit 2 - VOICE_EMER_CAT_FIRE_BRIGADE_BIT- Fire brigade – Bit 3 - VOICE_EMER_CAT_MARINE_GUARD_BIT - Marine guard – Bit 4 - VOICE_EMER_CAT_MOUNTAIN_RESCUE_BIT - Mountain rescue – Bit 5 - VOICE_EMER_CAT_MANUAL_ECALL_BIT - Manual emergency call – Bit 6 - VOICE_EMER_CAT_AUTO_ECALL_BIT - Automatic emergency call – Bit 7 - VOICE_EMER_CAT_SPARE_BIT - Spare bit
pCallPartySub-Add(optional)	• Pointer to structure of calledPartySubAdd – See voice_calledPartySubAdd for more information
pSvc-Type(optional)	• Service Type. – 0x01 - VOICE_DIAL_CALL_SRV_TYPE_AUTOMATIC - Automatic – 0x02 - VOICE_DIAL_CALL_SRV_TYPE_GSM - GSM – 0x03 - VOICE_DIAL_CALL_SRV_TYPE_WCDMA - WCDMA – 0x04 - VOICE_DIAL_CALL_SRV_TYPE_CDMA_AUTOMATIC - CDMA automatic – 0x05 - VOICE_DIAL_CALL_SRV_TYPE_GSM_WCDMA - GSM or WCDMA – 0x06 - VOICE_DIAL_CALL_SRV_TYPE_LTE -LTE

8.491.2 Field Documentation

8.491.2.1 uint8_t pack_voice_SLQSVoiceDialCall_t::callNumber[81]

8.491.2.2 voice_calledPartySubAdd* pack_voice_SLQSVoiceDialCall_t::pCallPartySubAdd

8.491.2.3 uint8_t* pack_voice_SLQSVoiceDialCall_t::pCallType

8.491.2.4 uint8_t* pack_voice_SLQSVoiceDialCall_t::pCLIRType

8.491.2.5 voice_CUGInfo* pack_voice_SLQSVoiceDialCall_t::pCUGInfo

8.491.2.6 uint8_t* pack_voice_SLQSVoiceDialCall_t::pEmergencyCategory

8.491.2.7 uint8_t* pack_voice_SLQSVoiceDialCall_t::pSvcType

8.491.2.8 voice_UUSInfo* pack_voice_SLQSVoiceDialCall_t::pUUSInFo

8.492 pack_voice_SLQSVoiceEndCall_t Struct Reference

Data Fields

- uint8_t * pCallId

8.492.1 Detailed Description

This structure contain pack voice end call parameter.

Parameters

pCallId	• Unique call identifier for the call that must be ended

8.492.2 Field Documentation

8.492.2.1 uint8_t* pack_voice_SLQSVoiceEndCall_t::pCallId

8.493 pack_voice_SLQSVoiceGetCallBarring_t Struct Reference

Data Fields

- uint8_t reason
- uint8_t * pSvcClass

8.493.1 Detailed Description

This structure contains Voice Get Call Barring Pack Parameters

Parameters

reason	• Call Barring Reason • Values: – 0x07 - QMI_VOICE_REASON_BARR_ALLOUTGOING - All outgoing – 0x08 - QMI_VOICE_REASON_BARR_OUTGOINGINT - Outgoing internal – 0x09 - QMI_VOICE_REASON_BARR_OUTGOINGINTEXTOHOME - Outgoing external to home – 0x0A - QMI_VOICE_REASON_BARR_ALLINCOMING - All incoming – 0x0B - QMI_VOICE_REASON_BARR_INCOMINGROAMING - Roaming incoming – 0x0C - QMI_VOICE_REASON_BARR_ALLBARRING - All calls are barred – 0x0D - QMI_VOICE_REASON_BARR_ALLOUTGOINGBARRING - All outgoing calls are barred – 0x0E - QMI_VOICE_REASON_BARR_ALLINCOMINGBARRING - All incoming calls are barred
pSvcClass	• Service class is a combination (sum) of information class constants (optional) • See qaGobiApiTableSupServiceInfoClasses.h for service classes. • Service Class is set to 0 if call waiting is not active for any of the information classes. • 0xFF,if Not Available

8.493.2 Field Documentation

8.493.2.1 uint8_t* pack_voice_SLQSVoiceGetCallBarring_t::pSvcClass

8.493.2.2 uint8_t pack_voice_SLQSVoiceGetCallBarring_t::reason

8.494 pack_voice_SLQSVoiceGetCallForwardingStatus_t Struct Reference

Data Fields

- uint8_t Reason
- uint8_t * pSvcClass

8.494.1 Detailed Description

This structure contains Voice Get Call Forwarding Status Pack Parameters

Parameters

Reason	• Call Forwarding Reason • Values: – 0x01 - QMI_VOICE_REASON_FWDREASON_UNCONDITIONAL - Unconditional call forwarding – 0x02 - QMI_VOICE_REASON_FWDREASON_MOBILEBUSY - Forward when the mobile is busy – 0x03 - QMI_VOICE_REASON_FWDREASON_NOREPLY - Forward when there is no reply – 0x04 - QMI_VOICE_REASON_FWDREASON_UNREACHABLE - Forward when the call is unreachable – 0x05 - QMI_VOICE_REASON_FWDREASON_ALLFORWARDING - All forwarding – 0x06 - QMI_VOICE_REASON_FWDREASON_ALLCONDITIONAL - All conditional forwarding
pSvcClass(optional)	• Service Class is a combination (sum) of information class constants • See qaGobiApiTableSupServiceInfoClasses.h for service classes.

8.494.2 Field Documentation

8.494.2.1 uint8_t* pack_voice_SLQSVoiceGetCallForwardingStatus_t::pSvcClass

8.494.2.2 uint8_t pack_voice_SLQSVoiceGetCallForwardingStatus_t::Reason

8.495 pack_voice_SLQSVoiceGetCallInfo_t Struct Reference

Data Fields

- uint8_t callID

8.495.1 Detailed Description

This structure contains information of the request parameters associated with a call.

Parameters

callID	• Call identifier for the call queried for information.

8.495.2 Field Documentation

8.495.2.1 uint8_t pack_voice_SLQSVoiceGetCallInfo_t::callID

8.496 pack_voice_SLQSVoiceGetCallWaiting_t Struct Reference

Data Fields

- uint8_t * pSvcClass

8.496.1 Detailed Description

This structure contains Voice Get Call Waiting Response Parameters

Parameters

pSvcClass	• Service class is a combination (sum) of information class constants (optional) • See qaGobiApiTableSupServiceInfoClasses.h for service classes. • Service Class is set to 0 if call waiting is not active for any of the information classes. • 0xFF,if Not Available

8.496.2 Field Documentation

8.496.2.1 uint8_t* pack_voice_SLQSVoiceGetCallWaiting_t::pSvcClass

8.497 pack_voice_SLQSVoiceGetConfig_t Struct Reference

Data Fields

- uint8_t * pAutoAnswer
- uint8_t * pAirTimer
- uint8_t * pRoamTimer
- uint8_t * pTTYMode
- uint8_t * pPrefVoiceSO
- uint8_t * pAMRStatus
- uint8_t * pPrefVoicePrivacy
- uint8_t * pNamID
- uint8_t * pVoiceDomainPref

8.497.1 Detailed Description

This structure contains Voice Get Configuration Request Parameters

Parameters

pAuto-Answer(optional)	• Indicator to retrieve the Auto Answer Information. – 0x01 - Include auto answer information
pAir-Timer(optional)	• Indicator to retrieve the Air Timer Information. – 0x01 - Include air calls timer count information • Currently Not Supported.
pRoam-Timer(optional)	• Indicator to retrieve the Roam Timer Information. – 0x01 - Include roam calls timer information • Currently Not Supported.

pTTY-Mode(optional)	• Indicator to retrieve the TTY Mode Information. – 0x01 - Include TTY configuration status information
pPrefVoiceS-O(optional)	• Indicator to retrieve the Preferred Voice SO Information. – 0x01 - Include preferred voice configuration status information • Currently Not Supported.
pAMR-Status(optional)	• Indicator to retrieve the AMR Status Information. – 0x01 - Include AMR status information
pPrefVoice-Privacy(optional)	• Indicator to retrieve the Preferred Voice Privacy Information. – 0x01 - Include preferred voice privacy status information
pNamI-D(optional)	• Index of the Number Assignment Module Index (CDMA subscription) to be configured • Range: 0 to 3. • Some modems support only 1 or 2 NAMs. • The NAM Index is valid only when the request contains at least one of Air Timer, Roam Timer, and Preferred Voice SO. • If no nam_id value is specified in the request,the default value is 0.
pVoiceDomain-Pref(optional)	• Indicator to retrieve the Preferred Voice Domain Information. – 0x01 - Include voice domain preference information

Note

Using NULL for the pointers would make sure that the parameter is not returned.

8.497.2 Field Documentation

8.497.2.1 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pAirTimer

8.497.2.2 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pAMRStatus

8.497.2.3 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pAutoAnswer

8.497.2.4 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pNamID

8.497.2.5 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pPrefVoicePrivacy

8.497.2.6 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pPrefVoiceSO

8.497.2.7 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pRoamTimer

8.497.2.8 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pTTYMode

8.497.2.9 uint8_t* pack_voice_SLQSVoiceGetConfig_t::pVoiceDomainPref

8.498 pack_voice_SLQSVoiceIndicationRegister_t Struct Reference

Data Fields

- uint8_t * pRegDTMFEvents
- uint8_t * pRegVoicePrivacyEvents
- uint8_t * pSuppsNotifEvents

8.498.1 Detailed Description

This structure contains parameters of Indication Register Information

Parameters

pRegDTMF-Events(optional)	• Registration Indication For DTMF Events. • When this registration is enabled, the device learns of DTMF events via the QMI_VOICE_DTMF_IND indication. – 0x00 - Disable – 0x01 - Enable
pRegVoice-Privacy-Events(optional)	• Registration Indication For Voice Privacy Events. • When this registration is enabled, the device learns of DTMF events via the QMI_VOICE_PRIVACY_IND indication. – 0x00 - Disable – 0x01 - Enable
pSuppsNotif-Events(optional)	• Registration Indication For Supplementary Service Notification Events. • When this registration is enabled, the device learns of DTMF events via the QMI_VOICE_SUPS_NOTIFICATION_IND indication. – 0x00 - Disable – 0x01 - Enable

Note

One of the optional parameter is mandatory to be present in the request.

8.498.2 Field Documentation

8.498.2.1 uint8_t* pack_voice_SLQSVoiceIndicationRegister_t::pRegDTMFEvents

8.498.2.2 uint8_t* pack_voice_SLQSVoiceIndicationRegister_t::pRegVoicePrivacyEvents

8.498.2.3 uint8_t* pack_voice_SLQSVoiceIndicationRegister_t::pSuppsNotifEvents

8.499 pack_voice_SLQSVoiceManageCalls_t Struct Reference

Data Fields

- uint8_t SUPSType

- uint8_t * pCallID

8.499.1 Detailed Description

This structure contains Manage Calls Information.

Parameters

SUPSType	• Supplementary service type during the call. – 0x01 - SUPS_TYPE_RELEASE_HELD_OR_WAITING * Release is held or waiting – 0x02 - SUPS_TYPE_RELEASE_ACTIVE_ACCEPT_HELD_OR_WAITING * Release is active and accepting held or waiting – 0x03 - SUPS_TYPE_HOLD_ACTIVE_ACCEPT_WAITING_OR_HELD * Hold is active and accepting waiting or held – 0x04 - SUPS_TYPE_HOLD_ALL_EXCEPT_SPECIFIED_CALL * Hold all calls except a specified one – 0x05 - SUPS_TYPE_MAKE_CONFERENCE_CALL * Make a conference call – 0x06 - SUPS_TYPE_EXPLICIT_CALL_TRANSFER * Explicit call transfer – 0x07 - SUPS_TYPE_CCBS_ACTIVATION * Activate completion of calls to busy subscriber – 0x08 - SUPS_TYPE_END_ALL_CALLS * End all calls – 0x09 - SUPS_TYPE_RELEASE_SPECIFIED_CALL * Release a specified call
pCallID[Optional]	• Applicable only for SUPSType 0x04, 0x07, and 0x09 • NULL pointer - Invalid data.

8.499.2 Field Documentation

8.499.2.1 uint8_t* pack_voice_SLQSVoiceManageCalls_t::pCallID

8.499.2.2 uint8_t pack_voice_SLQSVoiceManageCalls_t::SUPSType

8.500 pack_voice_SLQSVoiceOrigUSSDNoWait_t Struct Reference

Data Fields

- struct voice_USSInfo USSInformation

8.500.1 Detailed Description

This structure contains Orig USSD No Wait Information Parameters.

Parameters

USSInformation	• See voice_USSInfo for more information.

8.500.2 Field Documentation

8.500.2.1 struct voice_USSInfo pack_voice_SLQSVoiceOrigUSSDNoWait_t::USSInformation

8.501 pack_voice_SLQSVoiceSendFlash_t Struct Reference

Data Fields

- uint8_t * pCallID
- uint8_t * pFlashPayLd
- uint8_t * pFlashType

8.501.1 Detailed Description

This structure contains the flash information associated with a call.

Parameters

pCallID	• Unique call identifier associated with the current call.
pFlashPayLd(optional)	• Payload in ASCII to be sent in Flash. • Variable Length, NULL terminated.
pFlashType(optional)	• Flash type. – 0 - Simple Flash (default) – 1 - Activate answer hold – 2 - Deactivate answer hold

8.501.2 Field Documentation

8.501.2.1 uint8_t* pack_voice_SLQSVoiceSendFlash_t::pCallID

8.501.2.2 uint8_t* pack_voice_SLQSVoiceSendFlash_t::pFlashPayLd

8.501.2.3 uint8_t* pack_voice_SLQSVoiceSendFlash_t::pFlashType

8.502 pack_voice_SLQSVoiceSetCallBarringPassword_t Struct Reference

Data Fields

- uint8_t Reason
- uint8_t oldPasswd [4]
- uint8_t newPasswd [4]

- uint8_t newPasswdAgain [4]

8.502.1 Detailed Description

This structure contains Voice Set Call Barring Password Pack Parameters

Parameters

Reason	• Call Barring Reason • Values: – 0x07 - QMI_VOICE_REASON_BARR_ALLOUTGOING - All outgoing – 0x08 - QMI_VOICE_REASON_BARR_OUTGOINGINT - Outgoing internal – 0x09 - QMI_VOICE_REASON_BARR_OUTGOINGINTEXTOHOME - Outgoing external to home – 0x0A - QMI_VOICE_REASON_BARR_ALLINCOMING - All incoming – 0x0B - QMI_VOICE_REASON_BARR_INCOMINGROAMING - Roaming incoming – 0x0C - QMI_VOICE_REASON_BARR_ALLBARRING - All calls are barred – 0x0D - QMI_VOICE_REASON_BARR_ALLOUTGOINGBARRING - All outgoing calls are barred – 0x0E - QMI_VOICE_REASON_BARR_ALLINCOMINGBARRING - All incoming calls are barred
oldPasswd[BARRING_PASSWORD_LENGTH]	• Old password. – Password consists of 4 ASCII digits. – Range: 0000 to 9999.
newPasswd[BARRING_PASSWORD_LENGTH]	• New password. – Password consists of 4 ASCII digits. – Range: 0000 to 9999.
newPasswdAgain[BARRING_PASSWORD_LENGTH]	• New password Again. – Password consists of 4 ASCII digits. – Range: 0000 to 9999.

8.502.2 Field Documentation

8.502.2.1 uint8_t pack_voice_SLQSVoiceSetCallBarringPassword_t::newPasswd[4]

8.502.2.2 uint8_t pack_voice_SLQSVoiceSetCallBarringPassword_t::newPasswdAgain[4]

8.502.2.3 uint8_t pack_voice_SLQSVoiceSetCallBarringPassword_t::oldPasswd[4]

8.502.2.4 uint8_t pack_voice_SLQSVoiceSetCallBarringPassword_t::Reason

8.503 pack_voice_SLQSVoiceSetConfig_t Struct Reference

Data Fields

- uint8_t * pAutoAnswer
- voice_airTimer * pAirTimerConfig
- voice_roamTimer * pRoamTimerConfig
- uint8_t * pTTYMode
- voice_prefVoiceSO * pPrefVoiceSO
- uint8_t * pPrefVoiceDomain

8.503.1 Detailed Description

This structure contains information about the Set Configuration Request Parameters.

Parameters

pAutoAnswer	• Value specified is written to NV_AUTO_ANSWER_I. (optional) • Values: – 0x00 - Disable – 0x01 - Enable
pAirTimerConfig	• Value specified is written to NV_AIR_CNT_I. (optional) • See voice_airTimer for more information
pRoamTimer-Config	• Value specified is written to NV_ROAM_CNT_I. (optional) • See voice_roamTimer for more information
pTTYMode	• Value specified is written to NV_TTY_I. (optional) • Values: – 0x00 - TTY_MODE_FULL - Full – 0x01 - TTY_MODE_VCO - Voice carry over – 0x02 - TTY_MODE_HCO - Hearing carry over – 0x03 - TTY_MODE_OFF - Off
pPrefVoiceSO	• Value specified is written to NV_PREF_VOICE_SO_I. (optional) • See voice_prefVoiceSO for more information
pPrefVoice-Domain	• Preferred Voice-Domain. (optional) • Values: – 0x00 - VOICE_DOMAIN_PREF_CS_ONLY - Circuit-switched (CS) only – 0x01 - VOICE_DOMAIN_PREF_PS_ONLY - Packet-switched (PS) only – 0x02 - VOICE_DOMAIN_PREF_CS_PREF - CS is preferred, PS is secondary – 0x03 - VOICE_DOMAIN_PREF_PS_PREF - PS is preferred, CS is secondary

Note

One of the optional parameters must be present in the request.

8.503.2 Field Documentation

8.503.2.1 voice_airTimer* pack_voice_SLQSVoiceSetConfig_t::pAirTimerConfig

8.503.2.2 uint8_t* pack_voice_SLQSVoiceSetConfig_t::pAutoAnswer

8.503.2.3 uint8_t* pack_voice_SLQSVoiceSetConfig_t::pPrefVoiceDomain

8.503.2.4 voice_prefVoiceSO* pack_voice_SLQSVoiceSetConfig_t::pPrefVoiceSO

8.503.2.5 voice_roamTimer* pack_voice_SLQSVoiceSetConfig_t::pRoamTimerConfig

8.503.2.6 uint8_t* pack_voice_SLQSVoiceSetConfig_t::pTTYMode

8.504 pack_voice_SLQSVoiceSetPreferredPrivacy_t Struct Reference

Data Fields

- uint8_t privacyPref

8.504.1 Detailed Description

This structure contains the preferred voice privacy values.

Parameters

privacyPref	• Voice Privacy Preference – 0x00 - VOICE_PRIVACY_STANDARD - Standard privacy – 0x01 - VOICE_PRIVACY_ENHANCED - Enhanced privacy

8.504.2 Field Documentation

8.504.2.1 uint8_t pack_voice_SLQSVoiceSetPreferredPrivacy_t::privacyPref

8.505 pack_voice_SLQSVoiceSetSUPSService_t Struct Reference

Data Fields

- uint8_t voiceSvc
- uint8_t reason
- uint8_t * pServiceClass
- uint8_t * pCallBarringPasswd
- uint8_t * pCallForwardingNumber
- uint8_t * pTimerVal
- voice_callFwdTypeAndPlan * pCallFwdTypeAndPlan

8.505.1 Detailed Description

This structure contains Supplementary Service request parameters related to different features and their activation, deactivation, registration and erasure (applicable only for 3GPP)

Parameters

voiceSvc	• Manages all call-independent supplementary services, such as activation, deactivation, registration, and erasure (mandatory) – 0x01 - VOICE_SERVICE_ACTIVATE – 0x02 - VOICE_SERVICE_DEACTIVATE – 0x03 - VOICE_SERVICE_REGISTER – 0x04 - VOICE_SERVICE_ERASE
reason	• supplementary service reason values (mandatory) – 0x01 - QMI_VOICE_REASON_FWD_UNCONDITIONAL Unconditional call forwarding – 0x02 - QMI_VOICE_REASON_FWD_MOBILEBUSY Forward when the mobile is busy – 0x03 - QMI_VOICE_REASON_FWD_NOREPLY Forward when there is no reply – 0x04 - QMI_VOICE_REASON_FWD_UNREACHABLE Forward when the call is unreachable – 0x05 - QMI_VOICE_REASON_FWD_ALLFORWARDING All forwarding – 0x06 - QMI_VOICE_REASON_FWD_ALLCONDITIONAL All conditional forwarding – 0x07 - QMI_VOICE_REASON_BARR_ALLOUTGOING All outgoing calls are barred – 0x08 - QMI_VOICE_REASON_BARR_OUTGOINGINT Outgoing internal calls are barred – 0x09 - QMI_VOICE_REASON_BARR_OUTGOINGINTEXTOHOME Outgoing calls external to home are barred – 0x0A - QMI_VOICE_REASON_BARR_ALLINCOMING All incoming calls are barred – 0x0B - QMI_VOICE_REASON_BARR_INCOMINGROAMING Roaming incoming calls are barred – 0x0C - QMI_VOICE_REASON_BARR_ALLBARRING All calls are barred – 0x0D - QMI_VOICE_REASON_BARR_ALLOUTGOINGBARRING All outgoing calls are barred – 0x0E - QMI_VOICE_REASON_BARR_ALLINCOMINGBARRING All incoming calls are barred – 0x0F - QMI_VOICE_REASON_CALLWAITING Call waiting
pServiceClass	• Service class is a combination (sum) of information class constants (optional) – See liteServiceClassInformation for more information
pCallBarring-Passwd	• Password is required if call barring is provisioned using a password. Password consists of 4 ASCII digits. Range: 0000 to 9999 (optional)

pCallForwarding-Number	• Call forwarding number to be registered with the network. This has to be included in the request only when the service is set to VOICE_SERVICE_REGISTER. NULL terminated ASCII string. (optional)
pTimerVal	• Call forwarding no reply timer value in seconds. This has to be included in the request only when the service is set to VOICE_SERVICE_REGISTER and the reason is QMI_VOICE_REASON_FWD_NOREPLY. (optional) – Range: 5 to 30 in steps of 5
pCallFwdType-AndPlan	• Information about call forwarding type and plan. This parameter is ignored when the Call Forwarding Number is not included (optional) – See voice_callFwdTypeAndPlan for more information

8.505.2 Field Documentation

8.505.2.1 uint8_t* pack_voice_SLQSVoiceSetSUPSService_t::pCallBarringPasswd

8.505.2.2 uint8_t* pack_voice_SLQSVoiceSetSUPSService_t::pCallForwardingNumber

8.505.2.3 voice_callFwdTypeAndPlan* pack_voice_SLQSVoiceSetSUPSService_t::pCallFwdTypeAndPlan

8.505.2.4 uint8_t* pack_voice_SLQSVoiceSetSUPSService_t::pServiceClass

8.505.2.5 uint8_t* pack_voice_SLQSVoiceSetSUPSService_t::pTimerVal

8.505.2.6 uint8_t pack_voice_SLQSVoiceSetSUPSService_t::reason

8.505.2.7 uint8_t pack_voice_SLQSVoiceSetSUPSService_t::voiceSvc

8.506 pack_voice_SLQSVoiceStartContDTMF_t Struct Reference

Data Fields

- uint8_t * pCallID
- uint8_t DTMFdigit

8.506.1 Detailed Description

This structure contains parameters of continuous DTMF

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. Start continuous DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device

DTMFdigit	• DTMF digit in ASCII.

8.506.2 Field Documentation

8.506.2.1 uint8_t pack_voice_SLQSVoiceStartContDTMF_t::DTMFdigit

8.506.2.2 uint8_t* pack_voice_SLQSVoiceStartContDTMF_t::pCallID

8.507 pack_voice_SLQSVoiceStopContDTMF_t Struct Reference

Data Fields

- uint8_t callID

8.507.1 Detailed Description

This structure contains parameters of stop continuous DTMF

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. Stop continuous DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device

8.507.2 Field Documentation

8.507.2.1 uint8_t pack_voice_SLQSVoiceStopContDTMF_t::callID

8.508 pack_wds_DHCPv4ClientLeaseChange_t Struct Reference

Data Fields

- uint8_t * pEnableNotification

8.508.1 Detailed Description

WDS SWI DHCPv4 Client Lease Change Structure

Parameters

pEnable-Notification	• Enable Notification or not

8.508.2 Field Documentation

8.508.2.1 uint8_t* pack_wds_DHCPv4ClientLeaseChange_t::pEnableNotification

8.509 pack_wds_GetDefaultProfile_t Struct Reference

Data Fields

- uint32_t profiletype

8.509.1 Detailed Description

This structure contains pack get default profile information.

Parameters

profiletype	profile type • 0 - WDS_PROFILE_TYPE_3GPP (0x00) - 3GPP • 1 - WDS_PROFILE_TYPE_3GPP (0x01) - 3GPP2 • 2 - WDS_PROFILE_TYPE_EPC (0x02) - EPC

8.509.2 Field Documentation

8.509.2.1 uint32_t pack_wds_GetDefaultProfile_t::profiletype

8.510 pack_wds_GetDefaultProfileNum_t Struct Reference

Data Fields

- uint8_t type
- uint8_t family

8.510.1 Detailed Description

This structure contains pack Get Default Profile Number information.

Parameters

type	profile type • 0 - 3GPP • 1 - 3GPP2
family	profile family • 0 - Embedded • 1 - Tethered

8.510.2 Field Documentation

8.510.2.1 uint8_t pack_wds_GetDefaultProfileNum_t::family

8.510.2.2 uint8_t pack_wds_GetDefaultProfileNum_t::type

8.511 pack_wds_GetDormancyState_t Struct Reference

8.511.1 Detailed Description

This structure contains pack get dormancy state information.

Parameters

NULL	• this is a dummy structure

8.512 pack_wds_GetLastMobileIPError_t Struct Reference

8.512.1 Detailed Description

This structure contains pack get last mobile IP error information.

Parameters

NULL	• this is a dummy structure

8.513 pack_wds_GetMobileIP_t Struct Reference

8.513.1 Detailed Description

This structure contains pack get mobile IP information.

Parameters

NULL	• this is a dummy structure

8.514 pack_wds_GetMobileIPProfile_t Struct Reference

Data Fields

- uint8_t index

8.514.1 Detailed Description

This structure contains pack get mobile IP profile information.

Parameters

index	• Mobile IP profile ID

8.514.2 Field Documentation

8.514.2.1 uint8_t pack_wds_GetMobileIPProfile_t::index

8.515 pack_wds_GetPacketStatistics_t Struct Reference

Data Fields

- uint32_t * pStatMask

8.515.1 Detailed Description

This structure contains pack get packet statistics information.

Parameters

pStatMask	• Packet Statistics Mask – 0x00000001 - Tx packets OK – 0x00000002 - Rx packets OK – 0x00000004 - Tx packet errors – 0x00000008 - Rx packet errors – 0x00000010 - Tx overflows – 0x00000020 - Rx overflows – 0x00000040 - Tx bytes OK – 0x00000080 - Rx bytes OK

8.515.2 Field Documentation

8.515.2.1 uint32_t* pack_wds_GetPacketStatistics_t::pStatMask

8.516 pack_wds_GetPacketStatus_t Struct Reference

Data Fields

- uint32_t statmask

8.516.1 Detailed Description

This structure contains pack get packet status information.

Parameters

statmask	packet statistics mask • 0x00000001 - Tx packets OK • 0x00000002 - Rx packets OK • 0x00000004 - Tx packet errors • 0x00000008 - Rx packet errors • 0x00000010 - Tx overflows • 0x00000020 - Rx overflows • 0x00000040 - Tx bytes OK • 0x00000080 - Rx bytes OK • 0x00000100 - Tx packets dropped • 0x00000200 - Rx packets dropped

8.516.2 Field Documentation

8.516.2.1 uint32_t pack_wds_GetPacketStatus_t::statmask

8.517 pack_wds_GetSessionDuration_t Struct Reference

8.517.1 Detailed Description

This structure contains pack get session duration information.

Parameters

NULL	• this is a dummy structure

8.518 pack_wds_RMSetTransferStatistics_t Struct Reference

Data Fields

- rmTrasnferStaticsReq RmTrasnferStaticsReq

8.518.1 Detailed Description

This structure contains pack fetch current data system transfer statistics information.

Parameters

RmTrasnfer-StaticsReq[IN]	• See rmTrasnferStaticsReq for more information

8.518.2 Field Documentation

8.518.2.1 rmTrasnferStaticsReq pack_wds_RMSetTransferStatistics_t::RmTrasnferStaticsReq

8.519 pack_wds_SetAutoconnect_t Struct Reference

Data Fields

- uint8_t acsetting
- uint8_t acroamsetting

8.519.1 Detailed Description

auto connect data session parameters.

Parameters

acsetting	• Current autoconnect setting: – 0x00 - Autoconnect disabled – 0x01 - Autoconnect enabled – 0x02 - Autoconnect paused (resume on powercycle)
acroamsetting	• Current autoconnect roaming status – 0x00 - Autoconnect always allowed – 0x01 - Autoconnect while in home service area only

8.519.2 Field Documentation

8.519.2.1 uint8_t pack_wds_SetAutoconnect_t::acroamsetting

8.519.2.2 uint8_t pack_wds_SetAutoconnect_t::acsetting

8.520 pack_wds_SetDefaultProfile_t Struct Reference

Data Fields

- uint32_t profileType
- uint32_t pdpType
- uint32_t ipAddress
- uint32_t primaryDNS
- uint32_t secondaryDNS
- uint32_t authentication
- uint8_t * pName
- uint8_t * pUsername
- uint8_t * pApnname
- uint8_t * pPassword

8.520.1 Detailed Description

Writes the default profile settings to the device. The default profile is used to establish an autoconnect data session.

Parameters

profileType	• Type of profile – 0 - 3GPP – 1 - 3GPP2
pdpType	• Packet Data Protocol (PDP) type specifies the type of data payload exchanged over the air link when the packet data session is established with this profile (optional) – 0 - PDP-IP (IPv4) – 1 - PDP-PPP – 2 - PDP-IPv6 – 3 - PDP-IPv4v6
ipAddress	• Preferred IPv4 addr to be assigned to device (optional)
primaryDNS	• Primary DNS Ipv4 address preference (optional)
secondaryDNS	• Secondary DNS Ipv4 address preference (optional)
authentication	• Bitmap that indicates authentication algorithm preference (optional) – 0x00000001 - PAP preference * 0 - Never performed * 1 - May be performed – 0x00000002 - CHAP preference * 0 - Never performed * 1 - May be performed – All other bits are reserved and must be set to 0 – If more than 1 bit is set, then device decides which authentication procedure is performed while setting up data session e.g. the device may have a policy to select the most secure authentication mechanism.
pName	• profile Name (optional)
pUsername	• Username used during network authentication (optional)
pAPNName	• Access point name. NULL-terminated string parameter that is a logical name used to select GGSN and external packet data network (optional) • If value is NULL or omitted, then subscription default value will be requested.
pPassword	• Password used during network authentication (optional)

8.520.2 Field Documentation

8.520.2.1 uint32_t pack_wds_SetDefaultProfile_t::authentication

8.520.2.2 uint32_t pack_wds_SetDefaultProfile_t::ipAddress

8.520.2.3 uint8_t* pack_wds_SetDefaultProfile_t::pApnname

8.520.2.4 uint32_t pack_wds_SetDefaultProfile_t::pdpType

8.520.2.5 uint8_t* pack_wds_SetDefaultProfile_t::pName

8.520.2.6 uint8_t* pack_wds_SetDefaultProfile_t::pPassword

8.520.2.7 uint32_t pack_wds_SetDefaultProfile_t::primaryDNS

8.520.2.8 uint32_t pack_wds_SetDefaultProfile_t::profileType

8.520.2.9 uint8_t* pack_wds_SetDefaultProfile_t::pUsername

8.520.2.10 uint32_t pack_wds_SetDefaultProfile_t::secondaryDNS

8.521 pack_wds_SetDefaultProfileNum_t Struct Reference

Data Fields

- uint8_t type
- uint8_t family
- uint8_t index

8.521.1 Detailed Description

This structure to hold Set default profile number

Parameters

type	Identifies the technology type of the profile • 0 - 3GPP • 1 - 3GPP2
family	Identifies the family of profile • 0 - Embedded • 1 - Tethered
index	Profile number to be set as default profile.

8.521.2 Field Documentation

8.521.2.1 uint8_t pack_wds_SetDefaultProfileNum_t::family

8.521.2.2 uint8_t pack_wds_SetDefaultProfileNum_t::index

8.521.2.3 uint8_t pack_wds_SetDefaultProfileNum_t::type

8.522 pack_wds_SetMobileIP_t Struct Reference

Data Fields

- uint32_t mode

8.522.1 Detailed Description

This structure contains set mobile IP pack information.

Parameters

mode	• Mobile IP setting – 0 - Mobile IP off (simple IP only) – 1 - Mobile IP preferred – 2 - Mobile IP only

8.522.2 Field Documentation

8.522.2.1 uint32_t pack_wds_SetMobileIP_t::mode

8.523 pack_wds_SetMobileIPParameters_t Struct Reference

Data Fields

- char * pSPC
- uint32_t * pMode
- uint8_t * pRetryLimit
- uint8_t * pRetryInterval
- uint8_t * pReRegPeriod
- uint8_t * pReRegTraffic
- uint8_t * pHAAuthenticator
- uint8_t * pHA2002bis

8.523.1 Detailed Description

Mobile IP parameters information.

Parameters

pSPC	• NULL-terminated string representing six digit service programming code.
pMode	• Mode to be set (optional) – 0 - Mobile IP off (simple IP only) – 1 - Mobile IP preferred – 2 - Mobile IP only

pRetryLimit	• Registration retry attempt limit (optional)
pRetryInterval	• Registration retry attempt interval used to determine the time between registration attempts (optional)
pReRegPeriod	• Period (in minutes) to attempt re-registration before current registration expires (optional)
pReRegTraffic	• Re-registration only if traffic since last attempt (optional) – Zero - Disabled – NonZero - Enabled
pHA-Authenticator	• MH-HA authenticator calculator (optional) – Zero - Disabled – NonZero - Enabled
pHA2002bis	• MH-HA RFC 2002bis authentication instead of RFC2002 (optional) – Zero - Disabled – NonZero - Enabled

8.523.2 Field Documentation

8.523.2.1 uint8_t* pack_wds_SetMobileIPParameters_t::pHA2002bis

8.523.2.2 uint8_t* pack_wds_SetMobileIPParameters_t::pHAAuthenticator

8.523.2.3 uint32_t* pack_wds_SetMobileIPParameters_t::pMode

8.523.2.4 uint8_t* pack_wds_SetMobileIPParameters_t::pReRegPeriod

8.523.2.5 uint8_t* pack_wds_SetMobileIPParameters_t::pReRegTraffic

8.523.2.6 uint8_t* pack_wds_SetMobileIPParameters_t::pRetryInterval

8.523.2.7 uint8_t* pack_wds_SetMobileIPParameters_t::pRetryLimit

8.523.2.8 char* pack_wds_SetMobileIPParameters_t::pSPC

8.524 pack_wds_SetMobileIPProfile_t Struct Reference

Data Fields

- int8_t spc [10]
- uint8_t index
- uint8_t * pEnabled
- uint32_t * pAddress

- uint32_t * pPrimaryHA
- uint32_t * pSecondaryHA
- uint8_t * pRevTunneling
- int8_t * pNAI
- uint32_t * pHASPI
- uint32_t * pAAASPI
- int8_t * pMNHA
- int8_t * pMNAAA

8.524.1 Detailed Description

Sets the mobile IP parameters.

Parameters

spc	• Six digit service programming code string
index	• Index of the profile to modify
pEnabled	• (Optional) Enable profile? 0 - Disabled Nonzero - Enabled
pAddress	• (Optional) Home IPv4 address
pPrimaryHA	• (Optional) Primary home agent IPv4 address
pSecondaryHA	• (Optional) Secondary home agent IPv4 address
pRevTunneling	• (Optional) Enable reverse tunneling? 0 - Disabled Nonzero - Enabled
pNAI	• (Optional) Network access identifier string
pHASPI	• (Optional) Home agent security parameter index
pAAASPI	• (Optional) AAA server security parameter index
pMNHA	• (Optional) MN-HA key string
pMNAAA	• (Optional) MN-AAA key string

8.524.2 Field Documentation

8.524.2.1 uint8_t pack_wds_SetMobileIPProfile_t::index

8.524.2.2 uint32_t* pack_wds_SetMobileIPProfile_t::pAAASPI

8.524.2.3 uint32_t* pack_wds_SetMobileIPProfile_t::pAddress

8.524.2.4 uint8_t* pack_wds_SetMobileIPProfile_t::pEnabled

8.524.2.5 uint32_t* pack_wds_SetMobileIPProfile_t::pHASPI

8.524.2.6 int8_t* pack_wds_SetMobileIPProfile_t::pMNAAA

8.524.2.7 int8_t* pack_wds_SetMobileIPProfile_t::pMNHA

8.524.2.8 int8_t* pack_wds_SetMobileIPProfile_t::pNAI

8.524.2.9 uint32_t* pack_wds_SetMobileIPProfile_t::pPrimaryHA

8.524.2.10 uint8_t* pack_wds_SetMobileIPProfile_t::pRevTunneling

8.524.2.11 uint32_t* pack_wds_SetMobileIPProfile_t::pSecondaryHA

8.524.2.12 int8_t pack_wds_SetMobileIPProfile_t::spc[10]

8.525 pack_wds_SLQSCreateProfile_t Struct Reference

Data Fields

- uint8_t * pProfileId
- uint8_t * pProfileType
- wds_profileInfo * pCurProfile

8.525.1 Detailed Description

This structure contains pack create profile.

Parameters

pProfileId	• 1 to 16 for 3GPP profile (EM/MC73xx or earlier) • 1 to 24 for 3GPP profile (EM/MC74xx onwards) • 101 to 106 for 3GPP2 profile
pProfileType	• Identifies the technology type of the profile – 0x00 - 3GPP – 0x01 - 3GPP2 – NULL is not allowed
pCurProfile	• union of 3GPP and 3GPP2 profile • See wds_profileInfo

Note

- If profileID is NULL, 3GPP profile will be created and index will be assigned based on availability in device.
- If profileID is not NULL depending on pProfileType 3GPP/3GPP2 relevant profile will be created

8.525.2 Field Documentation

8.525.2.1 wds_profileInfo* pack_wds_SLQSCreateProfile_t::pCurProfile

8.525.2.2 uint8_t* pack_wds_SLQSCreateProfile_t::pProfileId

8.525.2.3 uint8_t* pack_wds_SLQSCreateProfile_t::pProfileType

8.526 pack_wds_SLQSDeleteProfile_t Struct Reference

Data Fields

- uint8_t profileType
- uint8_t profileIndex

8.526.1 Detailed Description

This structure contains the information about the profile to be deleted.

Parameters

profileType	• Identifies the type of profile – 0x00 - 3GPP • Note: Deletion of 3GPP2 profiles is not supported.
profileIndex	• Index of the configured profile to be deleted – Value between 1 - 16 (EM/MC73xx or earlier) – Value between 1 - 24 (EM/MC74xx onwards)

8.526.2 Field Documentation

8.526.2.1 uint8_t pack_wds_SLQSDeleteProfile_t::profileIndex

8.526.2.2 uint8_t pack_wds_SLQSDeleteProfile_t::profileType

8.527 pack_wds_SLQSGetCurrDataSystemStat_t Struct Reference

8.527.1 Detailed Description

This structure contains pack get current data system state information.

Parameters

NULL	• this is a dummy structure

8.528 pack_wds_SLQSGetDataBearerTechnology_t Struct Reference

8.528.1 Detailed Description

This structure contains pack get data bearer technology information.

Parameters

NULL	• this is a dummy structure

8.529 pack_wds_SLQSGetDUNCallInfo_t Struct Reference

Data Fields

- uint32_t Mask
- uint8_t * pReportConnStatus
- wds_transferStatInd * pTransferStatInd
- uint8_t * pReportDormStatus
- uint8_t * pReportDataBearerTech
- uint8_t * pReportChannelRate

8.529.1 Detailed Description

This structure contains the DUN Call Info Request parameters.

Parameters

Mask	• Mandatory parameter • Set the bits corresponding to the information requested to 1 • All other bits must be set to 0. • If any values are not available or applicable, the corresponding TLVs are not returned in the response. – Bit 0 - Connection Status – Bit 1 - Last call end reason – Bit 2 - Tx/Rx bytes OK – Bit 3 - Dormancy status – Bit 4 - Data bearer – Bit 5 - Channel rate – Bit 6 - Call active duration
pReportConn-Status	• Connect Status Indicator – 0 - Do not report – 1 - Report connection status and call end reason
pTransferStatInd	• See wds_transferStatInd for more information

pReportDormStatus	• Dormancy Status Indicator – 0 - Do not report – 1 - Report traffic channel state of interface used for data connection
pReportDataBearerTech	• Current Data Bearer Technology Indicator – 0 - Do not report – 1 - Report radio interface used for data transfer when it changes
pReportChannelRate	• Channel Rate Indicator – 0 - Do not report – 1 - Report channel rate

8.529.2 Field Documentation

8.529.2.1 uint32_t pack_wds_SLQSGetDUNCallInfo_t::Mask

8.529.2.2 uint8_t* pack_wds_SLQSGetDUNCallInfo_t::pReportChannelRate

8.529.2.3 uint8_t* pack_wds_SLQSGetDUNCallInfo_t::pReportConnStatus

8.529.2.4 uint8_t* pack_wds_SLQSGetDUNCallInfo_t::pReportDataBearerTech

8.529.2.5 uint8_t* pack_wds_SLQSGetDUNCallInfo_t::pReportDormStatus

8.529.2.6 wds_transferStatInd* pack_wds_SLQSGetDUNCallInfo_t::pTransferStatInd

8.530 pack_wds_SLQSGetProfileSettings_t Struct Reference

Data Fields

- uint8_t ProfileId
- uint8_t ProfileType

8.530.1 Detailed Description

This structure contains pack get profile settings information.

Parameters

ProfileID	• 1 to 16 for 3GPP profile (EM/MC73xx or earlier) • 1 to 24 for 3GPP profile (EM/MC74xx onwards) • 101 to 106 for 3GPP2 profile
ProfileType	• Identifies the technology type of the profile – 0x00 - 3GPP – 0x01 - 3GPP2

Note

- If profileID is NULL, 3GPP profile will be fetched and index will be assigned based on availability in device.
- If profileID is not NULL depending on pProfileType 3GPP/3GPP2 relevant profile will be fetched

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

8.530.2 Field Documentation

8.530.2.1 uint8_t pack_wds_SLQSGetProfileSettings_t::ProfileId

8.530.2.2 uint8_t pack_wds_SLQSGetProfileSettings_t::ProfileType

8.531 pack_wds_SLQSGetRuntimeSettings_t Struct Reference

Data Fields

- uint32_t * pReqSettings

8.531.1 Detailed Description

This structure contains pack get runtime settings information

Parameters

pReqSettings	Requested Settings (Optional Parameter) • Set bits to 1, corresponding to requested information. All other bits must be set to 0. • If the values are not available, the corresponding TLVs are not returned in the response. • Absence of this mask TLV results in the device returning all of the available information corresponding to bits 0 through 12. • In cases where the information from bit 13 or greater is required, this TLV with all the necessary bits set must be present in the request. • Values – Bit 0 - Profile identifier – Bit 1 - Profile name – Bit 2 - PDP type – Bit 3 - APN name – Bit 4 - DNS address – Bit 5 - UMTS/GPRS granted QoS – Bit 6 - Username – Bit 7 - Authentication Protocol – Bit 8 - IP address – Bit 9 - Gateway info (address and subnet mask) – Bit 10 - PCSCF address using PCO flag – Bit 11 - PCSCF server address list – Bit 12 - PCSCF domain name list – Bit 13 - MTU – Bit 14 - domain name list – Bit 15 - IP family – Bit 16 - IM_CM flag – Bit 17 - Technology name – Bit 18 - Operator reserved PCO (Not Supported on MC/EM73xx)

8.531.2 Field Documentation

8.531.2.1 uint32_t* pack_wds_SLQSGetRuntimeSettings_t::pReqSettings

8.532 pack_wds_SLQSModifyProfile_t Struct Reference

Data Fields

- uint8_t * pProfileId
- uint8_t * pProfileType
- wds_profileInfo curProfile

8.532.1 Detailed Description

This structure contains pack modify profile information.

Parameters

pProfileId	• 1 to 16 for 3GPP profile (EM/MC73xx or earlier) • 1 to 24 for 3GPP profile (EM/MC74xx onwards) • 101 to 106 for 3GPP2 profile
pProfileType	• Identifies the technology type of the profile – 0x00 - 3GPP – 0x01 - 3GPP2 – NULL is not allowed
curProfile	• union of 3GPP and 3GPP2 profile • See wds_profileInfo

Note

- If profileID is NULL, 3GPP profile will be created and index will be assigned based on availability in device.
- If profileID is not NULL depending on pProfileType 3GPP/3GPP2 relevant profile will be created

8.532.2 Field Documentation

8.532.2.1 wds_profileInfo pack_wds_SLQSModifyProfile_t::curProfile

8.532.2.2 uint8_t* pack_wds_SLQSModifyProfile_t::pProfileId

8.532.2.3 uint8_t* pack_wds_SLQSModifyProfile_t::pProfileType

8.533 pack_wds_SLQSSet3GPPConfigItem_t Struct Reference

Data Fields

- uint16_t * pLTEAttachProfile
- uint16_t * pProfileList
- uint8_t * pDefaultPDNEnabled
- uint8_t * p3gppRelease
- uint16_t * pLTEAttachProfileList
- uint16_t LTEAttachProfileListLen

8.533.1 Detailed Description

This structure contains pack set 3GPP configuration item information.

Parameters

pLTEAttach-Profile	• Optional parameter • LTE Attach Profile – points to a single WORD Value indicating the attached LTE Profile – Optional parameter with possible values 1-16 (EM/MC73xx or earlier) • This setting is deprecated on MC/EM74xx

ProfileList	Profile List • an array of 4 profile configurations • Each element points to a single WORD value indicating profile • Optional parameter with possible values – 1 - 16 (MC/EM73xx and before) – 1 - 24 (MC/EM74xx and onwards) • function SLQSGet3GPPConfigItem() returns a default value 255 if no 3gpp configuration is present
pDefaultPDN-Enabled	• Optional parameter – 0 - disabled – 1 - enabled
p3gppRelease	3GPP release • Optional parameter – 0 - Release_99 – 1 - Release_5 – 2 - Release_6 – 3 - Release_7 – 4 - Release_8 • In 9x30 and onwards – 5 - Release 9 – 6 - Release 10 – 7 - Release 11
pLTEAttach-ProfileList	• pointer to WORD array indicating LTE Attach Profile List – Optional parameter – possible values: 1-24 – This setting is only supported for MC/EM74xx onwards – Please provide attach profiles in order of decreasing priority in this list.
LTEAttach-ProfileListLen	• Number of element in pLTEAttachProfileList – valid range: 1-24 – This setting is only supported for MC/EM74xx onwards

8.533.2 Field Documentation

8.533.2.1 uint16_t pack_wds_SLQSSet3GPPConfigItem_t::LTEAttachProfileListLen

8.533.2.2 uint8_t* pack_wds_SLQSSet3GPPConfigItem_t::p3gppRelease

8.533.2.3 uint8_t* pack_wds_SLQSSet3GPPConfigItem_t::pDefaultPDNEnabled

8.533.2.4 uint16_t* pack_wds_SLQSSet3GPPConfigItem_t::pLTEAttachProfile

8.533.2.5 uint16_t* pack_wds_SLQSSet3GPPConfigItem_t::pLTEAttachProfileList

8.533.2.6 uint16_t* pack_wds_SLQSSet3GPPConfigItem_t::pProfileList

8.534 pack_wds_SLQSSetIPFamilyPreference_t Struct Reference

Data Fields

- uint8_t IPFamilyPreference

8.534.1 Detailed Description

This structure contains pack set IP family preference information

Parameters

IPFamily-Preference	IP Family preference • PACK_WDS_IPV4 IP Version 4 • PACK_WDS_IPV6 IP Version 6

8.534.2 Field Documentation

8.534.2.1 uint8_t pack_wds_SLQSSetIPFamilyPreference_t::IPFamilyPreference

8.535 pack_wds_SLQSSetWdsEventCallback_t Struct Reference

Data Fields

- uint8_t dataBearer
- uint8_t dormancyStatus
- uint8_t mobileIP
- uint8_t transferStats
- uint8_t currentDataBearer
- uint8_t dataSystemStatus
- uint8_t dataBearerTechExt
- uint8_t interval

8.535.1 Detailed Description

This structure contains set WDS event callback information.

Parameters

dataBearer	data bearer
dormancyStatus	dormancy status
mobileIP	mobile IP
currentData-Bearer	current data bearer
dataSystem-Status	data system status
dataBearerTech-Ext	data Bearer Technology Extended
interval	interval

8.535.2 Field Documentation

8.535.2.1 uint8_t pack_wds_SLQSSetWdsEventCallback_t::currentDataBearer

8.535.2.2 uint8_t pack_wds_SLQSSetWdsEventCallback_t::dataBearer

8.535.2.3 uint8_t pack_wds_SLQSSetWdsEventCallback_t::dataBearerTechExt

8.535.2.4 uint8_t pack_wds_SLQSSetWdsEventCallback_t::dataSystemStatus

8.535.2.5 uint8_t pack_wds_SLQSSetWdsEventCallback_t::dormancyStatus

8.535.2.6 uint8_t pack_wds_SLQSSetWdsEventCallback_t::interval

8.535.2.7 uint8_t pack_wds_SLQSSetWdsEventCallback_t::mobileIP

8.535.2.8 uint8_t pack_wds_SLQSSetWdsEventCallback_t::transferStats

8.536 pack_wds_SLQSSGetDHCPv4ClientConfig_t Struct Reference

Data Fields

- wdsDhcpv4ProfileId * pProfileId

8.536.1 Detailed Description

This structure contain get DHCPv4 client configure.

Parameters

pProfileId	pointer to Profile Id structure • See wdsDhcpv4ProfileId

8.536.2 Field Documentation

8.536.2.1 wdsDhcpv4ProfileId* pack_wds_SLQSSGetDHCPv4ClientConfig_t::pProfileId

8.537 pack_wds_SLQSSSetDHCPv4ClientConfig_t Struct Reference

Data Fields

- wds_DHCPv4ProfileId * pProfileId
- wds_DHCPv4HWConfig * pHwConfig
- wds_DHCPv4OptionList * pRequestOptionList

8.537.1 Detailed Description

WDS SWI DHCPv4 Config Structure

Parameters

pProfileId	• pointer to Profile Id structure
pHWConfig	• pointer to HW Config structure
pRequestOption-List	• pointer to Option List structure to be sent in DHCP request

8.537.2 Field Documentation

8.537.2.1 wds_DHCPv4HWConfig∗ pack_wds_SLQSSSetDHCPv4ClientConfig_t::pHwConfig

8.537.2.2 wds_DHCPv4ProfileId∗ pack_wds_SLQSSSetDHCPv4ClientConfig_t::pProfileId

8.537.2.3 wds_DHCPv4OptionList∗ pack_wds_SLQSSSetDHCPv4ClientConfig_t::pRequestOptionList

8.538 pack_wds_SLQSSSetLoopback_t Struct Reference

Data Fields

- uint8_t loopbackMode
- uint8_t loopbackMultiplier

8.538.1 Detailed Description

This structure contains pack set loopback information.

Parameters

loopbackMode	• Loopback Mode. – 0 - Disable – 1 - Enable
loopback-Multiplier	• Loopback multiplier. Number of downlink bytes to send for each uplink byte.

8.538.2 Field Documentation

8.538.2.1 uint8_t pack_wds_SLQSSSetLoopback_t::loopbackMode

8.538.2.2 uint8_t pack_wds_SLQSSSetLoopback_t::loopbackMultiplier

8.539 pack_wds_SLQSStartDataSession_t Struct Reference

Data Fields

- uint8_t ∗ pTech

- uint32_t * pprofileid3gpp
- uint32_t * pprofileid3gpp2
- uint32_t * pAuth
- char * pUser
- char * pPass

8.539.1 Detailed Description

This structure contains pack Start Data Session Information.

Parameters

pTech	• Indicates the technology preference – 1 - UMTS – 2 - CDMA – 3 - eMBMS – 4 - Modem Link Label. Modem Link is an interface for transferring data between entities on AP and modem. • optional
pprofileid3gpp	• pointer to 3GPP profile id • optional
pprofileid3gpp2	• pointer to 3GPP2 profile id • optional
pAuth	• Authentication type, it can be PAP or CHAP • optional
pUser	• username for authentication process • optional
pPass	• password for authentication process • optional

8.539.2 Field Documentation

8.539.2.1 uint32_t* pack_wds_SLQSStartDataSession_t::pAuth

8.539.2.2 char* pack_wds_SLQSStartDataSession_t::pPass

8.539.2.3 uint32_t* pack_wds_SLQSStartDataSession_t::pprofileid3gpp

8.539.2.4 uint32_t* pack_wds_SLQSStartDataSession_t::pprofileid3gpp2

8.539.2.5 uint8_t* pack_wds_SLQSStartDataSession_t::pTech

8.539.2.6 char* pack_wds_SLQSStartDataSession_t::pUser

8.540 pack_wds_SLQSStopDataSession_t Struct Reference

Data Fields

- uint32_t * psid

8.540.1 Detailed Description

This structure contains pack stop data session information.

Parameters

psid	session id

8.540.2 Field Documentation

8.540.2.1 uint32_t* pack_wds_SLQSStopDataSession_t::psid

8.541 pack_wds_SLQSWdsSetEventReport_t Struct Reference

Data Fields

- uint8_t * pCurrChannelRateInd
- wds_TrStatInd * pTransferStatInd
- uint8_t * pDataBearerTechInd
- uint8_t * pDormancyStatusInd
- uint8_t * pMIPStatusInd
- uint8_t * pCurrDataBearerTechInd
- uint8_t * pDataCallStatusChangeInd
- uint8_t * pCurrPrefDataSysInd
- uint8_t * pEVDOPageMonPerChangeInd
- uint8_t * pDataSystemStatusChangeInd

8.541.1 Detailed Description

This structure contains the information about the Set Event Report Request parameters.

Parameters

pCurrChannel-RateInd	(optional) • Current Channel Rate Indicator. – 0 - Do not report – 1 - Report channel rate when it changes
pTransferStatInd	(optional) • See wds_TrStatInd for more information.
pDataBearer-TechInd	(optional) • Data Bearer Technology Indicator. – 0 - Do not report – 1 - Report radio interface used for data transfer when it changes

pDormancyStatusInd	(optional) • Dormancy Status indicator. – 0 - Do not report – 1 - Report traffic channel state of interface used for data connection
pMIPStatusInd	(optional) • MIP Status Indicator. – 0 - Do not report – 1 - Report MIP status
pCurrDataBearerTechInd	(optional) • Current Data Bearer Technology Indicator. – 0 - Do not report – 1 - Report current data bearer technology when it changes
pDataCallStatusChangeInd	(optional) • Data Call Status Change Indicator. – 0 - Do not report – 1 - Report data call status change when it changes
pCurrPrefDataSysInd	(optional) • Current Preferred Data System Indicator. – 0 - Do not report – 1 - Report preferred data system when it changes
pEVDOPageMonPerChangeInd	(optional) • EV-DO Page Monitor Period Change Indicator. – 0 - Do not report – 1 - Report EV-DO page monitor period change event
pDataSystemStatusChangeInd	(optional) • Data System Status Change Indicator. – 0 - Do not report – 1 - Report data system status change event

Note

At least one parameter should be present.

8.541.2 Field Documentation

8.541.2.1 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pCurrChannelRateInd

8.541.2.2 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pCurrDataBearerTechInd

8.541.2.3 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pCurrPrefDataSysInd

8.541.2.4 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pDataBearerTechInd

8.541.2.5 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pDataCallStatusChangeInd

8.541.2.6 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pDataSystemStatusChangeInd

8.541.2.7 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pDormancyStatusInd

8.541.2.8 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pEVDOPageMonPerChangeInd

8.541.2.9 uint8_t* pack_wds_SLQSWdsSetEventReport_t::pMIPStatusInd

8.541.2.10 wds_TrStatInd* pack_wds_SLQSWdsSetEventReport_t::pTransferStatInd

8.542 pack_wds_SLQSWdsSwiPDPRuntimeSettings_t Struct Reference

Data Fields

- uint8_t contextId
- uint8_t contextType

8.542.1 Detailed Description

This structure contains the PDP Runtime Settings Request parameters.

Parameters

contextId	• Context Identifier
contextType	• Identifies technology type – 0 - 3GPP – 1 - 3GPP2

8.542.2 Field Documentation

8.542.2.1 uint8_t pack_wds_SLQSWdsSwiPDPRuntimeSettings_t::contextId

8.542.2.2 uint8_t pack_wds_SLQSWdsSwiPDPRuntimeSettings_t::contextType

8.543 PackCreateProfileOut Struct Reference

Data Fields

- uint8_t ProfileType
- uint8_t ProfileIndex
- uint16_t ExtErrorCode

8.543.1 Detailed Description

This structure contains out parameter Information

Parameters

ProfileType	• Identifies the type of profile 0x00 = 3GPP 0x01 = 3GPP2 • Bit to check in ParamPresenceMask - **1**
ProfileIndex	• Index identifying the profile that was created • Bit to check in ParamPresenceMask - **1**
ExtErrorCode	• The extended error code received from DS Profile subsystem • Bit to check in ParamPresenceMask - **224**

8.543.2 Field Documentation

8.543.2.1 uint16_t PackCreateProfileOut::ExtErrorCode

8.543.2.2 uint8_t PackCreateProfileOut::ProfileIndex

8.543.2.3 uint8_t PackCreateProfileOut::ProfileType

8.544 packgetDyingGaspCfg Struct Reference

Data Fields

- uint8_t * pDestSMSNum
- uint8_t * pDestSMSContent

8.544.1 Detailed Description

This struture contains the TLV required to get the Dysing GASP Config.

Parameters

pDestSMSNum[IN]	• SMS Destination Number as string of 8 bit ASCII Characters Max 20 chars. • Optional parameter.
pDestSMSContent[IN]	• SMS COntent as a string of 8 bit ASCII text characters Max 160 chars. • Optional parameter.

8.544.2 Field Documentation

8.544.2.1 uint8_t* packgetDyingGaspCfg::pDestSMSContent

8.544.2.2 uint8_t* packgetDyingGaspCfg::pDestSMSNum

8.545 packgetDyingGaspStatistics Struct Reference

Data Fields

- uint32_t * pTimeStamp
- uint8_t * pSMSAttemptedFlag

8.545.1 Detailed Description

This structure contains Get Dysing GASP Statistics

Parameters

pTimeStamp[OUT]	• Timestamp of the last time power loss was detected and Dying Gasp feature was triggered. • UTC time in seconds since Jan 06, 1980 (GPS Epoch).
pSMSAttemptedFlag[OUT]	• Indicates whether device attempted to send SMS in the last power loss event. • 0 - SMS not attempted • 1 - SMS attempted • This only indicates device sent the SMS but does not guarantee network delivery.

8.545.2 Field Documentation

8.545.2.1 uint8_t* packgetDyingGaspStatistics::pSMSAttemptedFlag

8.545.2.2 uint32_t* packgetDyingGaspStatistics::pTimeStamp

8.546 PackSwiAvmsSetSettingsAPNInfo Struct Reference

Data Fields

- uint8_t bAPNLength
- uint8_t szAPN [49]
- uint8_t bUnameLength
- uint8_t szUname [29]
- uint8_t bPWDLength
- uint8_t szPWD [29]

8.546.1 Detailed Description

This structure contains pack set settings APN information.

Parameters

bAPNLength	APN Length.
szAPN	APN String.
bUnameLength	Username Length.
szUname	User Name String.
bPWDLength	Password Length.
szPWD	Password String.

8.546.2 Field Documentation

8.546.2.1 uint8_t PackSwiAvmsSetSettingsAPNInfo::bAPNLength

8.546.2.2 uint8_t PackSwiAvmsSetSettingsAPNInfo::bPWDLength

8.546.2.3 uint8_t PackSwiAvmsSetSettingsAPNInfo::bUnameLength

8.546.2.4 uint8_t PackSwiAvmsSetSettingsAPNInfo::szAPN[49]

8.546.2.5 uint8_t PackSwiAvmsSetSettingsAPNInfo::szPWD[29]

8.546.2.6 uint8_t PackSwiAvmsSetSettingsAPNInfo::szUname[29]

8.547 PackSwiAvmsSetSettingsConnectionRetryTimers Struct Reference

Data Fields

- uint16_t Timers [8]

8.547.1 Detailed Description

This structure contains the SLQSAVMSSetSettings Polling timer to connect to AVMS server.

Parameters

Timers[0]	- Timer 1. • 0-20160 (min) • 0:retry disabled
Timers[1]	- Timer 2. • 1-20160 (min)
Timers[2]	- Timer 3. • 1-20160 (min)
Timers[3]	- Timer 4. • 1-20160 (min)
Timers[4]	- Timer 5. • 1-20160 (min)
Timers[5]	- Timer 6. • 1-20160 (min)
Timers[6]	- Timer 7. • 1-20160 (min)
Timers[7]	- Timer 8. • 1-20160 (min)

8.547.2 Field Documentation

8.547.2.1 uint16_t PackSwiAvmsSetSettingsConnectionRetryTimers::Timers[8]

8.548 PackSwiAvmsSetSettingsPeriodInfo Struct Reference

Data Fields

- uint32_t ulMin
- uint32_t ulMax

8.548.1 Detailed Description

This structure contain pack set settings period information.

Parameters

ulMin	Min period in seconds.
ulMax	Max period in seconds.

8.548.2 Field Documentation

8.548.2.1 uint32_t PackSwiAvmsSetSettingsPeriodInfo::ulMax

8.548.2.2 uint32_t PackSwiAvmsSetSettingsPeriodInfo::ulMin

8.549 PackSwiAVMSSettingsAPNInfo Struct Reference

Data Fields

- uint8_t bAPNLength
- uint8_t * pAPN
- uint8_t bUnameLength
- uint8_t * pUname
- uint8_t bPWDLength
- uint8_t * pPWD

8.549.1 Detailed Description

This structure contains the SLQSAVMSGetSettings APN Info to connect to AVMS server.

Parameters

bAPNLength	- APN Length(Max 49).
szAPN	- APN.
bUnameLength	- User Name Length (Max 29).
szUname	- User Name.
bPWDLength	- Password Length (Max 29).
szPWD	- Password.

8.549.2 Field Documentation

8.549.2.1 uint8_t PackSwiAVMSSettingsAPNInfo::bAPNLength

8.549.2.2 uint8_t PackSwiAVMSSettingsAPNInfo::bPWDLength

8.549.2.3 uint8_t PackSwiAVMSSettingsAPNInfo::bUnameLength

8.549.2.4 uint8_t* PackSwiAVMSSettingsAPNInfo::pAPN

8.549.2.5 uint8_t* PackSwiAVMSSettingsAPNInfo::pPWD

8.549.2.6 uint8_t* PackSwiAVMSSettingsAPNInfo::pUname

8.550 PackSwiAVMSSettingsConnectionRetryTimers Struct Reference

Data Fields

- uint16_t Timers [8]

8.550.1 Detailed Description

This structure contains the SLQSAVMSGetSettings Polling timer to connect to AVMS server.

Parameters

Timers[0]	- Timer 1. • 0-20160 (min) • 0:retry disabled
Timers[1]	- Timer 2. • 1-20160 (min)
Timers[2]	- Timer 3. • 1-20160 (min)
Timers[3]	- Timer 4. • 1-20160 (min)
Timers[4]	- Timer 5. • 1-20160 (min)
Timers[5]	- Timer 6. • 1-20160 (min)
Timers[6]	- Timer 7. • 1-20160 (min)
Timers[7]	- Timer 8. • 1-20160 (min)

8.550.2 Field Documentation

8.550.2.1 uint16_t PackSwiAVMSSettingsConnectionRetryTimers::Timers[8]

8.551 PackSwiAVMSSettingsPeriodsInfo Struct Reference

Data Fields

- uint32_t min
- uint32_t max

8.551.1 Detailed Description

This structure contains the SLQSAVMSSettings Min/Max Period of an Observation.

Parameters

min	- Min period in seconds.
max	- Max period in seconds.

8.551.2 Field Documentation

8.551.2.1 uint32_t PackSwiAVMSSettingsPeriodsInfo::max

8.551.2.2 uint32_t PackSwiAVMSSettingsPeriodsInfo::min

8.552 qmiSmsMessageList Struct Reference

Data Fields

- uint32_t messageIndex
- uint32_t messageTag

8.552.1 Detailed Description

This structure contains SMS message list.

Parameters

messageIndex	• Message index of each matched message
messageTag	• Messagetag

8.552.2 Field Documentation

8.552.2.1 uint32_t qmiSmsMessageList::messageIndex

8.552.2.2 uint32_t qmiSmsMessageList::messageTag

8.553 qmiWDSDataBearerTechnology Struct Reference

Data Fields

- uint8_t currentNetwork
- uint32_t ratMask
- uint32_t soMask

8.553.1 Detailed Description

Structure to hold the current data bearer technology values

Parameters

currentNetwork[-OUT]	• current selected network – 0 - UNKNOWN – 1 - 3GPP2 – 2 - 3GPP – 0xff - Invalid data.
ratMask[OUT]	RAT Mask
soMask[OUT]	SO Mask

8.553.2 Field Documentation

8.553.2.1 uint8_t qmiWDSDataBearerTechnology::currentNetwork

8.553.2.2 uint32_t qmiWDSDataBearerTechnology::ratMask

8.553.2.3 uint32_t qmiWDSDataBearerTechnology::soMask

8.554 qmTlvResult Struct Reference

Data Fields

- swi_uint256_t TlvPresenceMask
- qmulong TlvResultCode
- qmuint16 DeviceResult
- qmuint16 DeviceError

8.554.1 Field Documentation

8.554.1.1 qmuint16 qmTlvResult::DeviceError

8.554.1.2 qmuint16 qmTlvResult::DeviceResult

8.554.1.3 swi_uint256_t qmTlvResult::TlvPresenceMask

8.554.1.4 qmulong qmTlvResult::TlvResultCode

8.555 qos_BindDataPortMuxID_t Struct Reference

Data Fields

- uint8_t MuxID

8.555.1 Detailed Description

Structure that contains the request Binds a control point to a data port Mux ID data.

Parameters

MuxID	Mux ID: • 0x80-0x8F : valid value

8.555.2 Field Documentation

8.555.2.1 uint8_t qos_BindDataPortMuxID_t::MuxID

8.556 qos_BindDataPortPeripheralEndPointID_t Struct Reference

Data Fields

- uint32_t EndPointType
- uint32_t IfaceID

8.556.1 Detailed Description

Structure that contains the request Binds a control point to a data port Periapheral End Point Type data.

Parameters

EndPointType	Peripheral end point type. Values: • 0 - Reserved • 1 - HSIC • 2 - HSUSB • 3 - PCIE • 4 - Embedded
IfaceID	Peripheral interface number.

8.556.2 Field Documentation

8.556.2.1 uint32_t qos_BindDataPortPeripheralEndPointID_t::EndPointType

8.556.2.2 uint32_t qos_BindDataPortPeripheralEndPointID_t::IfaceID

8.557 qos_BindDataPortSIODataPort_t Struct Reference

Data Fields

- uint16_t SIODataPort

8.557.1 Detailed Description

Structure that contains the request Binds a control point to a data port SIO Data Port data.

Parameters

u16SIODataPort	SIO Data Port to which the client binds

8.557.2 Field Documentation

8.557.2.1 uint16_t qos_BindDataPortSIODataPort_t::SIODataPort

8.558 RFBandInfoElements Struct Reference

Data Fields

- uint8_t radioInterface
- uint16_t activeBandClass
- uint16_t activeChannel

8.558.1 Detailed Description

This structure contains the RFBandInfo response parameters.

Parameters

radioInterface	• Radio interface technology – See Tables for Radio Interface
activeBandClass	• Active Band Class – See Tables for Band Classes
activeChannel	• Active channel (0 if channel is not relevant to the reported technology)

8.558.2 Field Documentation

8.558.2.1 uint16_t RFBandInfoElements::activeBandClass

8.558.2.2 uint16_t RFBandInfoElements::activeChannel

8.558.2.3 uint8_t RFBandInfoElements::radioInterface

8.559 rmTrasnferStaticsReq Struct Reference

Data Fields

- uint8_t bResetStatistics
- uint32_t ulMask

8.559.1 Detailed Description

RM Transfer Satistics Structure

Parameters

bResetStatistics	• Reset Statistics • Values: • 0 - Not Reset • Other - Reset
ulMask	• Enable/Disable RM Transfer Satatistics Indiscation Mask • Bit 0: Tx Packet Ok • Bit 1: Rx Packet Ok • Bit 2: Tx Bytes Ok • Bit 3: Rx Bytes Ok • Bit 4: Tx Packets Dropped • Bit 5: Rx Packets Dropped • Value: -0 - Disable -1 - Enable

8.559.2 Field Documentation

8.559.2.1 uint8_t rmTrasnferStaticsReq::bResetStatistics

8.559.2.2 uint32_t rmTrasnferStaticsReq::ulMask

8.560 sensorData_t Struct Reference

Data Fields

- uint32_t timeOfFirstSample
- uint8_t flags
- uint8_t sensorDataLen
- uint16_t timeOffset [64]
- uint32_t xAxis [64]
- uint32_t yAxis [64]
- uint32_t zAxis [64]

8.560.1 Detailed Description

This structure specifies information regarding the 3-Axis Sensor Data. Please check has_<Param_Name> field for presence of optional parameters

Parameters

timeOfFirst-Sample	• Denotes a full 32-bit time stamp of the first (oldest) sample in this message. • The time stamp is in the time reference scale that is used by the sensor time source. • Units - Milliseconds

flags	• Flags to indicate any deviation from the default measurement assumptions. • All unused bits in this field must be set to 0. • Valid bitmasks – 0x01 - Bitmask to specify that a sign reversal is required while interpreting the sensor data; only applies to the accelerometer samples – 0x02 - Bitmask to specify that the sensor time stamp is the same as the modem time stamp
sensorDataLen	• Number of sets of the following elements – timeOffset – xAxis – yAxis – zAxis
timeOffset	• Sample time offset • Units - Milliseconds
xAxis	• Sensor x-axis sample. • Units Accelerometer - Meters/seconds square • Units Gyroscope - Radians/second
yAxis	• Sensor Y-axis sample. • Units Accelerometer - Meters/seconds square • Units Gyroscope - Radians/second
xAxis	• Sensor Z-axis sample. • Units Accelerometer - Meters/seconds square • Units Gyroscope - Radians/second

8.560.2 Field Documentation

8.560.2.1 uint8_t sensorData_t::flags

8.560.2.2 uint8_t sensorData_t::sensorDataLen

8.560.2.3 uint32_t sensorData_t::timeOfFirstSample

8.560.2.4 uint16_t sensorData_t::timeOffset[64]

8.560.2.5 uint32_t sensorData_t::xAxis[64]

8.560.2.6 uint32_t sensorData_t::yAxis[64]

8.560.2.7 uint32_t sensorData_t::zAxis[64]

8.561 slot_t Struct Reference

Data Fields

- uint32_t uPhyCardStatus
- uint32_t uPhySlotStatus
- uint8_t bLogicalSlot
- uint8_t bICCIDLength
- uint8_t bICCID [255]

8.561.1 Detailed Description

This structure contains information of the response parameters associated with a Get Slots Status API.

Parameters

uPhyCardStatus	• State of the card in the Pyhsical Slot Status. – 0x00 - Unknown. – 0x01 - Absent. – 0x02 - Present.
uPhySlotStatus	• State of the Physical Slot status. – 0x00 Inactive. – 0x01 Activate.
bLogicalSlot	• Logical Slot associated with this physical slot. THis is valid if the physical slot is active. – 1 - Slot 1. – 2 - Slot 2. – 3 - Slot 3. – 4 - Slot 4. – 5 - Slot 5.
bLogicalSlot	• Number of sets the sets of ICCCID
bICCID[MAX_ICCID_LENGTH]	• Contains the ICCID of the card in the physical slot.

8.561.2 Field Documentation

8.561.2.1 uint8_t slot_t::bICCID[255]

8.561.2.2 uint8_t slot_t::bICCIDLength

8.561.2.3 uint8_t slot_t::bLogicalSlot

8.561.2.4 uint32_t slot_t::uPhyCardStatus

8.561.2.5 uint32_t slot_t::uPhySlotStatus

8.562 slotInf Struct Reference

Data Fields

- uint8_t cardState
- uint8_t upinState
- uint8_t upinRetries
- uint8_t upukRetries
- uint8_t errorState
- uint8_t numApp
- appStats AppStatus [10]

8.562.1 Detailed Description

This structure contains information about the SLOTS present.

Parameters

cardState	• Indicates the state of the card for each slot. – 0 - Absent – 1 - Present – 2 - Error
upinState	• Indicates the state of UPIN. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked – 0xFF - Not Available
upinRetries	• Indicates the number of retries remaining to verify the UPIN. • If 0xFF, information not available.
upukRetries	• Indicates the number of retries remaining to unblock the UPIN. • If 0xFF, information not available.

errorState	• Indicates the reason for the card error, and is valid only when the card state is Error – 0 - Unknown – 1 - Power down – 2 - Poll error – 3 - No ATR received – 4 - Volt mismatch – 5 - Parity error – 6 - Unknown; possibly removed – 7 - Card returned technical problems – 0xFF - Not Available • Other values are possible and reserved for future use. • When an unknown value is received, it is to be handled as "Unknown".
numApp	• Indicates the number of applications available on the card. • The following block is repeated for each application. i.e. AppStatus. • If zero(0) then no AppStatus information exists.
AppStatus[MAX_NO_OF_APPLICATIONS]	• See appStats for more information.

8.562.2 Field Documentation

8.562.2.1 appStats slotInf::AppStatus[10]

8.562.2.2 uint8_t slotInf::cardState

8.562.2.3 uint8_t slotInf::errorState

8.562.2.4 uint8_t slotInf::numApp

8.562.2.5 uint8_t slotInf::upinRetries

8.562.2.6 uint8_t slotInf::upinState

8.562.2.7 uint8_t slotInf::upukRetries

8.563 slots_t Struct Reference

Data Fields

- slot_t uimSlotStatus [255]

8.563.1 Detailed Description

This structure contains slots status.

Parameters

uimSlotStatus	• See slot_t

8.563.2 Field Documentation

8.563.2.1 slot_t slots_t::uimSlotStatus[255]

8.564 sms_BroadcastConfig Struct Reference

Data Fields

- uint16_t fromServiceId
- uint16_t toServiceId
- uint8_t selected

8.564.1 Detailed Description

This structure contains BroadcastConfig parameters

Parameters

fromServiceId	• Starting point of range of CBM message identifiers
toServiceId	• Ending point of range of CBM message identifiers
selected	• Range of CBM message identifiers indicated by from_service_id and to_service_id – 0x00 – Not selected – 0x01 – Selected

8.564.2 Field Documentation

8.564.2.1 uint16_t sms_BroadcastConfig::fromServiceId

8.564.2.2 uint8_t sms_BroadcastConfig::selected

8.564.2.3 uint16_t sms_BroadcastConfig::toServiceId

8.565 sms_CDMABroadcastConfig Struct Reference

Data Fields

- uint16_t serviceCategory
- uint16_t language
- uint8_t selected

8.565.1 Detailed Description

This structure contains CDMABroadcastConfig parameters

Parameters

serviceCategory	• Service category
language	• Language
selected	• Specified service_category and language – 0x00 – Not selected – 0x01 – Selected

8.565.2 Field Documentation

8.565.2.1 uint16_t sms_CDMABroadcastConfig::language

8.565.2.2 uint8_t sms_CDMABroadcastConfig::selected

8.565.2.3 uint16_t sms_CDMABroadcastConfig::serviceCategory

8.566 sms_getIndicationReg Struct Reference

Data Fields

- uint8_t * pRegTransLayerInfoEvt
- uint8_t * pRegTransNWRegInfoEvt
- uint8_t * pRegCallStatInfoEvt

8.566.1 Detailed Description

This structure contains Get Indication Register Response parameters

Parameters

pRegTrans-LayerInfoEvt	- • Optional parameter indicating registration status of transport layer information events • Values: – 0x00 - Disabled – 0x01 - Enabled
pRegTransNW-RegInfoEvt	- • Optional parameter indicating registration status of transport network registration information events • Values: – 0x00 - Disabled – 0x01 - Enabled

pRegCallStat-InfoEvt	- Optional parameter indicating registration status of call status information events
	- Values:
	  – 0x00 - Disabled
	  – 0x01 - Enabled

8.566.2 Field Documentation

8.566.2.1 uint8_t* sms_getIndicationReg::pRegCallStatInfoEvt

8.566.2.2 uint8_t* sms_getIndicationReg::pRegTransLayerInfoEvt

8.566.2.3 uint8_t* sms_getIndicationReg::pRegTransNWRegInfoEvt

8.567 sms_getMsgWaitingInfo Struct Reference

Data Fields

- uint8_t numInstances
- sms_messageWaitingInfoContent msgWaitInfo [0xFF]

8.567.1 Detailed Description

This structure contains Get Message Waiting Info Response parameters

Parameters

numInstances	- Number of sets of the elements in structure sms_messageWaitingInfoContent
pMsgWaitInfo	- Pointer to structure of sms_messageWaitingInfoContent. – See sms_messageWaitingInfoContent for more information.

8.567.2 Field Documentation

8.567.2.1 sms_messageWaitingInfoContent sms_getMsgWaitingInfo::msgWaitInfo[0xFF]

8.567.2.2 uint8_t sms_getMsgWaitingInfo::numInstances

8.568 sms_getTransLayerInfo Struct Reference

Data Fields

- uint8_t * pRegInd
- sms_transLayerInfo * pTransLayerInfo

8.568.1 Detailed Description

This structure contains Get Transport Layer Info Response parameters

Parameters

pRegInd	- • Optional parameter indicating if transport layer is registered • Values: – 0x00 - Transport layer is not registered – 0x01 - Transport layer is registered • returns a default value 0xFF if no response is received from the device.
pTransLayerInfo	• Pointer to structure of sms_transLayerInfo. – Optional parameter – See sms_transLayerInfo for more information • returns a default value 0xFF for parameter values if no response is received from the device.

8.568.2 Field Documentation

8.568.2.1 uint8_t* sms_getTransLayerInfo::pRegInd

8.568.2.2 sms_transLayerInfo* sms_getTransLayerInfo::pTransLayerInfo

8.569 sms_getTransNWRegInfo Struct Reference

Data Fields

- uint8_t * pRegStatus

8.569.1 Detailed Description

This structure contains transport network registration info parameter

Parameters

pRegStatus	- • Optional parameter indicating transport layer network registration status • Values: – 0x00 - No service – 0x01 - In progress – 0x02 - Failed – 0x03 - Limited Service – 0x04 - Full Service • returns a default value 0xFF if no response is received from the device.

8.569.2 Field Documentation

8.569.2.1 uint8_t* sms_getTransNWRegInfo::pRegStatus

8.570 sms_maxStorageSizeReq Struct Reference

Data Fields

- uint8_t storageType
- uint8_t * pMessageMode

8.570.1 Detailed Description

This structure contains get store max size request parameters

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV
pMessage-Mode(optional	parameter) • 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS)

Note

The Message Mode TLV must be included if the device is capable of supporting more than one protocol

8.570.2 Field Documentation

8.570.2.1 uint8_t* sms_maxStorageSizeReq::pMessageMode

8.570.2.2 uint8_t sms_maxStorageSizeReq::storageType

8.571 sms_maxStorageSizeResp Struct Reference

Data Fields

- uint32_t maxStorageSize
- uint32_t freeSlots

8.571.1 Detailed Description

This structure contains get store max size response parameters

Parameters

maxStorageSize	- • Memory Store Size

freeSlots	- Optional parameter indicating how much Memory is available - returns a default value 0xFFFFFFFF for parameter values if no response is received from the device.

8.571.2 Field Documentation

8.571.2.1 uint32_t sms_maxStorageSizeResp::freeSlots

8.571.2.2 uint32_t sms_maxStorageSizeResp::maxStorageSize

8.572 sms_messageWaitingInfoContent Struct Reference

Data Fields

- uint8_t msgType
- uint8_t activeInd
- uint8_t msgCount

8.572.1 Detailed Description

This structure contains message waiting information per instance

Parameters

msgType	- Message type
	  – 0x00 - MWI_MESSAGE_TYPE_VOICMAIL - Voicemail
	  – 0x01 - MWI_MESSAGE_TYPE_FAX - Fax
	  – 0X02 - MWI_MESSAGE_TYPE_EMAIL - Email
	  – 0x03 - MWI_MESSAGE_TYPE_OTHER - Other
	  – 0x04 - MWI_MESSAGE_TYPE_VIDEOMAIL - Videomail

activeInd	- Indicates whether the indication is active
	  – 0x00 - Inactive
	  – 0x01 - Active

msgCount	- Number of messages

8.572.2 Field Documentation

8.572.2.1 uint8_t sms_messageWaitingInfoContent::activeInd

8.572.2.2 uint8_t sms_messageWaitingInfoContent::msgCount

8.572.2.3 uint8_t sms_messageWaitingInfoContent::msgType

8.573 sms_msgProtocolResp Struct Reference

Data Fields

- uint8_t msgProtocol

8.573.1 Detailed Description

This structure contains get message protocol response parameters

Parameters

msgProtocol	- • Message Protocol • Values: – 0x00 - MESSAGE_PROTOCOL_CDMA – 0x01 - MESSAGE_PROTOCOL_WCDMA

8.573.2 Field Documentation

8.573.2.1 uint8_t sms_msgProtocolResp::msgProtocol

8.574 sms_qaQmi3GPP2BroadcastCfgInfo Struct Reference

Data Fields

- uint8_t activated_ind
- uint16_t num_instances
- sms_CDMABroadcastConfig CDMABroadcastConfig [0x05]

8.574.1 Detailed Description

This structure contains the 3GPP2 Broadcast Configuration Information parameters

Parameters

activated_ind	• Broadcast SMS – 0x00 - Deactivated – 0x01 - Activated
num_instances	• Number of sets (N) of parameters Following each set describes one entry in the broadcast configuration table. – serviceCategory – language – selected
broadcastConfig	• A CDMABroadcastConfig structure array. • Further defined by the structure sms_CDMABroadcastConfig

8.574.2 Field Documentation

8.574.2.1 uint8_t sms_qaQmi3GPP2BroadcastCfgInfo::activated_ind

8.574.2.2 sms_CDMABroadcastConfig sms_qaQmi3GPP2BroadcastCfgInfo::CDMABroadcastConfig[0x05]

8.574.2.3 uint16_t sms_qaQmi3GPP2BroadcastCfgInfo::num_instances

8.575 sms_qaQmi3GPPBroadcastCfgInfo Struct Reference

Data Fields

- uint8_t activated_ind
- uint16_t num_instances
- sms_BroadcastConfig broadcastConfig [0x05]

8.575.1 Detailed Description

This structure contains the 3GPP Broadcast Configuration Information parameters

Parameters

activated_ind	• Broadcast SMS – 0x00 - Deactivated – 0x01 - Activated
num_instances	• Number of sets (N) of parameters Following each set describes one entry in the broadcast configuration table. – fromServiceId – toServiceId – selected
broadcastConfig	• A BroadcastConfig structure array. • Further defined by the structure sms_BroadcastConfig

8.575.2 Field Documentation

8.575.2.1 uint8_t sms_qaQmi3GPPBroadcastCfgInfo::activated_ind

8.575.2.2 sms_BroadcastConfig sms_qaQmi3GPPBroadcastCfgInfo::broadcastConfig[0x05]

8.575.2.3 uint16_t sms_qaQmi3GPPBroadcastCfgInfo::num_instances

8.576 sms_routeEntry Struct Reference

Data Fields

- uint8_t messageType
- uint8_t messageClass

- uint8_t routeStorage
- uint8_t receiptAction

8.576.1 Detailed Description

This structure contains SMS route entry details

Parameters

messageType	- Message type matching this route - Values: – 0x00 - MESSAGE_TYPE_POINT_TO_POINT

messageClass	- Message Class
	- Values:
	  – 0x00 - MESSAGE_CLASS_0
	  – 0x01 - MESSAGE_CLASS_1
	  – 0x02 - MESSAGE_CLASS_2
	  – 0x03 - MESSAGE_CLASS_3
	  – 0x04 - MESSAGE_CLASS_NONE
	  – 0x05 - MESSAGE_CLASS_CDMA

routeStorage	- If the receiptAction is store where to store the message
	- Values:
	  – 0x00 - STORAGE_TYPE_UIM
	  – 0x01 - STORAGE_TYPE_NV
	  – 0xFF - STORAGE_TYPE_NONE

receiptAction	- Action to be taken on receipt of a message matching the specified type and class for this route
	- Values:
	  – 0x00 - DISCARD (discarded without notification)
	  – 0x01 - STORE AND NOTIFY (stored and notified to the registered clients)
	  – 0x02 - TRANSFER ONLY (transferred to the client, client expected to send the ACK)
	  – 0x03 - TRANSFER AND ACK (transferred to the client, device expected to send the ACK)

8.576.2 Field Documentation

8.576.2.1 uint8_t sms_routeEntry::messageClass

8.576.2.2 uint8_t sms_routeEntry::messageType

8.576.2.3 uint8_t sms_routeEntry::receiptAction

8.576.2.4 uint8_t sms_routeEntry::routeStorage

8.577 sms_sendAsyncsmsParams Struct Reference

Data Fields

- uint32_t messageFormat
- uint32_t messageSize
- uint8_t * pMessage
- uint8_t * pForceOnDC
- uint8_t * pServiceOption
- uint8_t * pFollowOnDC
- uint8_t * pLinktimer
- uint8_t * pSmsOnIms
- uint8_t * pRetryMessage
- uint32_t * pRetryMessageId
- uint32_t * pUserData

8.577.1 Detailed Description

This structure contains SMS parameters

Parameters

messageFormat	• Message format • Values: – 0 - CDMA (IS-637B) – 1 - 5 (Reserved) – 6 - GSM/WCDMA PP
messageSize	• The length of the message contents in bytes
pMessage	• The message contents
pForceOnDC	• Force the message to be sent on the CDMA dedicated channel. • Values: – 0x00 - Do not care about the channel on which the message is sent – 0x01 - Request to send the message over the dedicated channel
pServiceOption	• Service option: • Values: – 0x00 - SO_AUTO - AUTO (choose the best service option) – 0x06 - SO_6 - Service option 6 – 0x0E - SO_14 - Service option 14
pFollowOnDC	• Flag to request not to disconnect the CDMA dedicated channel after the send operation is complete. • This TLV can be included if more messages are expected to follow. • Values: – 0x01 - FOLLOW_ON_DC_ON - On (don't disconnect after send operation) Any value other than 0x01 is treated as an absence of this TLV.

pLinktimer	• Keeps the GW SMS link open for the specified number of seconds; can be enabled if more messages are expected to follow
pSmsOnIms	• Indicates whether the message is to be sent on IMS. • Values: – 0x00 - Message is not to be sent on IMS – 0x01 - Message is to be sent on IMS – 0x02 to 0xFF - Reserved
pRetryMessage	• Indicates this message is a retry message. • Values: – 0x01 - WMS_MESSAGE_IS_A_RETRY - Message is a retry message Note: Any value other than 0x01 in this field is treated as an absence of this TLV.
pRetryMessage-Id	• Message ID to be used in the retry message. • The message ID specified here is used instead of the messsage ID encoded in the raw message.
pUserData	• Enables the control point to associate the request with the corresponding indication. • The control point might send numerous requests. • This TLV will help the control point to identify the request for which the received indication belongs.

8.577.2 Field Documentation

8.577.2.1 uint32_t sms_sendAsyncsmsParams::messageFormat

8.577.2.2 uint32_t sms_sendAsyncsmsParams::messageSize

8.577.2.3 uint8_t* sms_sendAsyncsmsParams::pFollowOnDC

8.577.2.4 uint8_t* sms_sendAsyncsmsParams::pForceOnDC

8.577.2.5 uint8_t* sms_sendAsyncsmsParams::pLinktimer

8.577.2.6 uint8_t* sms_sendAsyncsmsParams::pMessage

8.577.2.7 uint8_t* sms_sendAsyncsmsParams::pRetryMessage

8.577.2.8 uint32_t* sms_sendAsyncsmsParams::pRetryMessageId

8.577.2.9 uint8_t* sms_sendAsyncsmsParams::pServiceOption

8.577.2.10 uint8_t* sms_sendAsyncsmsParams::pSmsOnIms

8.577.2.11 uint32_t* sms_sendAsyncsmsParams::pUserData

8.578 sms_setIndicationReg Struct Reference

Data Fields

- uint8_t * pRegTransLayerInfoEvt
- uint8_t * pRegTransNWRegInfoEvt
- uint8_t * pRegCallStatInfoEvt

8.578.1 Detailed Description

This structure contains Indication Register request parameters

Parameters

pRegTransLayerInfoEvt	- • Optional parameter indicating registration status of transport layer information events • Values: – 0x00 - Disabled – 0x01 - Enabled – NULL - No change - specifying NULL indicates that the device will continue to use the existing setting (disable/enable) which has been previously set for the device
pRegTransNWRegInfoEvt	- • Optional parameter indicating registration status of transport network registration information events • Values: – 0x00 - Disabled – 0x01 - Enabled – NULL - No change - specifying NULL indicates that the device will continue to use the existing setting (disable/enable) which has been previously set for the device
pRegCallStatInfoEvt	- • Optional parameter indicating registration status of call status information events • Values: – 0x00 - Disabled – 0x01 - Enabled – NULL - No change - specifying NULL indicates that the device will continue to use the existing setting (disable/enable) which has been previously set for the device

8.578.2 Field Documentation

8.578.2.1 uint8_t* sms_setIndicationReg::pRegCallStatInfoEvt

8.578.2.2 uint8_t* sms_setIndicationReg::pRegTransLayerInfoEvt

8.578.2.3 uint8_t* sms_setIndicationReg::pRegTransNWRegInfoEvt

8.579 sms_setRoutesReq Struct Reference

Data Fields

- uint16_t numOfRoutes

- sms_routeEntry routeList [0x0A]
- uint8_t * pTransferStatusReport

8.579.1 Detailed Description

This structure contains SMS route request parameters

Parameters

numOfRoutes	- • Number of sets of the following element
routeList	- • Array containing the set of sms_routeEntry
pTransferStatus-Report	- • 0x01 - Status report are transferred to the client (optional)

8.579.2 Field Documentation

8.579.2.1 uint16_t sms_setRoutesReq::numOfRoutes

8.579.2.2 uint8_t* sms_setRoutesReq::pTransferStatusReport

8.579.2.3 sms_routeEntry sms_setRoutesReq::routeList[0x0A]

8.580 sms_transLayerInfo Struct Reference

Data Fields

- uint8_t TransType
- uint8_t TransCap

8.580.1 Detailed Description

This structure contains Transport Layer Information

Parameters

TransType	• Transport Type – 0x00 - IMS
TransCap	• Transport Capability • Values: – 0x00 - CDMA – 0x01 - GW

8.580.2 Field Documentation

8.580.2.1 uint8_t sms_transLayerInfo::TransCap

8.580.2.2 uint8_t sms_transLayerInfo::TransType

8.581 sMSCAddressInfo Struct Reference

Data Fields

- uint8_t length
- uint8_t data [256]

8.581.1 Detailed Description

This structure contains SMSC information

Parameters

length	• Number of sets of following element
data	• SMSC address

8.581.2 Field Documentation

8.581.2.1 uint8_t sMSCAddressInfo::data[256]

8.581.2.2 uint8_t sMSCAddressInfo::length

8.582 sMSCAddressTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSCAddressInfo SMSCInfo

8.582.1 Detailed Description

This structure contains SMSC TLV information

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
SMSCInfo	• SMSC Address • See sMSCAddressInfo for more information

8.582.2 Field Documentation

8.582.2.1 sMSCAddressInfo sMSCAddressTlv::SMSCInfo

8.582.2.2 uint8_t sMSCAddressTlv::TlvPresent

8.583 sMSEtwsMessageInfo Struct Reference

Data Fields

- uint8_t notificationType
- uint16_t length
- uint8_t data [1254]

8.583.1 Detailed Description

This structure contains ETWS information

Parameters

notificationType	• Message mode 0x00 - Primary 0x01 - Secondary GSM 0x02 - Secondary UMTS
length	• Number of sets of following elements
data	• Raw message data

8.583.2 Field Documentation

8.583.2.1 uint8_t sMSEtwsMessageInfo::data[1254]

8.583.2.2 uint16_t sMSEtwsMessageInfo::length

8.583.2.3 uint8_t sMSEtwsMessageInfo::notificationType

8.584 sMSEtwsMessageTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSEtwsMessageInfo EtwsMessageInfo

8.584.1 Detailed Description

This structure contains ETWS TLV information

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response

EtwsMessage-Info	• ETWS Message • See sMSEtwsMessageInfo for more information

8.584.2 Field Documentation

8.584.2.1 sMSEtwsMessageInfo sMSEtwsMessageTlv::EtwsMessageInfo

8.584.2.2 uint8_t sMSEtwsMessageTlv::TlvPresent

8.585 sMSEtwsPlmnInfo Struct Reference

Data Fields

- uint16_t mobileCountryCode
- uint16_t mobileNetworkCode

8.585.1 Detailed Description

This structure contains ETWS PLMN information

Parameters

mobileCountry-Code	• 16 bit representation of MCC value range : 0 -999
mobileNetwork-Code	• 16 bit representation of MNC value range : 0 -999

8.585.2 Field Documentation

8.585.2.1 uint16_t sMSEtwsPlmnInfo::mobileCountryCode

8.585.2.2 uint16_t sMSEtwsPlmnInfo::mobileNetworkCode

8.586 sMSMessageModeInfo Struct Reference

Data Fields

- uint8_t messageMode

8.586.1 Detailed Description

This structure contains message mode information.

Parameters

messageMode	• Message Mode – 0x00 - CDMA – 0x01 - GW

8.586.2 Field Documentation

8.586.2.1 uint8_t sMSMessageModeInfo::messageMode

8.587 sMSMTMessageInfo Struct Reference

Data Fields

- uint32_t storageType
- uint32_t messageIndex

8.587.1 Detailed Description

This structure contains MT message information.

Parameters

storageType	memory storage 0x00-UIM 0x01-NV
messageIndex	MT Message index

8.587.2 Field Documentation

8.587.2.1 uint32_t sMSMTMessageInfo::messageIndex

8.587.2.2 uint32_t sMSMTMessageInfo::storageType

8.588 sMSOnIMSInfo Struct Reference

Data Fields

- uint8_t smsOnIMS

8.588.1 Detailed Description

This structure contains SMS on IMS information

Parameters

smsOnIMS	SMS on IMS

8.588.2 Field Documentation

8.588.2.1 uint8_t sMSOnIMSInfo::smsOnIMS

8.589 sMSOnIMSTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSOnIMSInfo IMSInfo

8.589.1 Detailed Description

This structure contains SMS on IMS TLV information.

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
IMSInfo	• SMS on IMS • See sMSOnIMSInfo for more information

8.589.2 Field Documentation

8.589.2.1 sMSOnIMSInfo sMSOnIMSTlv::IMSInfo

8.589.2.2 uint8_t sMSOnIMSTlv::TlvPresent

8.590 sMSTransferRouteMTMessageInfo Struct Reference

Data Fields

- uint8_t ackIndicator
- uint32_t transactionID
- uint8_t format
- uint16_t length
- uint8_t data [256]

8.590.1 Detailed Description

This structure contains Transfer route MT message information.

Parameters

ackIndicator	• Parameter to indicate if ACK must be sent by the control point 0x00 - Send ACK 0x01 - Do not send ACK
transactionID	• Transaction ID of the message
format	• Message format 0x00 - CDMA 0x02 - 0x05 - Reserved 0x06 - GW_PP 0x07 - GW_BC

length	• Length of the raw message. This length should not exceed the maximum WMS payload length of 256 bytes
data	• Raw message data

8.590.2 Field Documentation

8.590.2.1 uint8_t sMSTransferRouteMTMessageInfo::ackIndicator

8.590.2.2 uint8_t sMSTransferRouteMTMessageInfo::data[256]

8.590.2.3 uint8_t sMSTransferRouteMTMessageInfo::format

8.590.2.4 uint16_t sMSTransferRouteMTMessageInfo::length

8.590.2.5 uint32_t sMSTransferRouteMTMessageInfo::transactionID

8.591 swi_uint256_t Struct Reference

Data Fields

- uint16_t word [16]

8.591.1 Detailed Description

SWI 256 bit data type

8.591.2 Field Documentation

8.591.2.1 uint16_t swi_uint256_t::word[16]

8.592 swiaudio_PCMparams Struct Reference

Data Fields

- uint8_t iFaceTabLen
- uint8_t iFaceTab [255]

8.592.1 Detailed Description

This structure contains the PCM parameters.

Parameters

iFaceTabLen	• Number of sets of iface table

iFaceTab	• Physical Interface Parameters • See qaGobiApiTableSwiAudio.h for more information on physical interface parameters

8.592.2 Field Documentation

8.592.2.1 uint8_t swiaudio_PCMparams::iFaceTab[255]

8.592.2.2 uint8_t swiaudio_PCMparams::iFaceTabLen

8.593 swidms_ehrpdMTUSizeTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t ehrpdMTUSize

8.593.1 Detailed Description

This structure contains the parameters for EHRPD MTU Size.

Parameters

TlvPresent	• Tlv Present.
ehrpdMTUSize	EHRPD size • Size of EHRPD MTU

8.593.2 Field Documentation

8.593.2.1 uint16_t swidms_ehrpdMTUSizeTlv::ehrpdMTUSize

8.593.2.2 uint8_t swidms_ehrpdMTUSizeTlv::TlvPresent

8.594 swidms_hrpdMTUSizeTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t hrpdMTUSize

8.594.1 Detailed Description

This structure contains the parameters for HRPD MTU Size.

Parameters

TlvPresent	• Tlv Present.
hrpdMTUSize	HRPD size • Size of HRPD MTU

8.594.2 Field Documentation

8.594.2.1 uint16_t swidms_hrpdMTUSizeTlv::hrpdMTUSize

8.594.2.2 uint8_t swidms_hrpdMTUSizeTlv::TlvPresent

8.595 swidms_intfaceCfgTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t CurrentCfgType
- uint32_t CfgValue

8.595.1 Detailed Description

This structure contains the parameters for host usb interface composition

Parameters

TlvPresent	• Tlv Present.
CurrentCfgType	• Current configure type, see values below: – 1 - MBIM – 2 - USBIF + PCIE – 3 - RMNET – 4 - RNDIS – 5 - PCIE only

CfgValue	• Host composition bit mask, see supported USB interface bitmasks, not supported by QMI object setting for 9x50 modules – 0x00000001 - DIAG interface – 0x00000002 - ADB interface – 0x00000004 - NMEA interface – 0x00000008 - MODEM interface – 0x00000010 - RESERVED5 – 0x00000020 - RESERVED6 – 0x00000040 - RESERVED7 – 0x00000080 - RESERVED8 – 0x00000100 - RMENT0 interface – 0x00000200 - RESERVED10 – 0x00000400 - RMENT1 interface – 0x00000800 - RESERVED12 – 0x00001000 - MBIM interface – 0x00002000 - RESERVED14 – 0x00004000 - RNDIS interface – 0x00008000 - RESERVED16 – 0x00010000 - AUDIO interface – 0x00020000 - RESERVED18 – 0x00080000 - ECM interface – 0x00100000 - RESERVED21 – 0x00200000 - RESERVED22 – 0xFFC00000 - RESERVED

8.595.2 Field Documentation

8.595.2.1 uint32_t swidms_intfaceCfgTlv::CfgValue

8.595.2.2 uint32_t swidms_intfaceCfgTlv::CurrentCfgType

8.595.2.3 uint8_t swidms_intfaceCfgTlv::TlvPresent

8.596 swidms_mtuSize3gppTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t MTUSize3gpp

8.596.1 Detailed Description

This structure contains the parameters for 3GPP MTU Size.

Parameters

TlvPresent	• Tlv Present.

MTUSize3gpp	3GPP MTU size • Size of 3GPP MTU

8.596.2 Field Documentation

8.596.2.1 uint16_t swidms_mtuSize3gppTlv::MTUSize3gpp

8.596.2.2 uint8_t swidms_mtuSize3gppTlv::TlvPresent

8.597 swidms_supportedIntBitmaskTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t ValidBitmasks

8.597.1 Detailed Description

This structure contains the parameters for supported usb bitmasks

Parameters

TlvPresent	• Tlv Present.
ValidBitmasks	• for current configuration type, this is the supported bitmasks that the host can change.

8.597.2 Field Documentation

8.597.2.1 uint8_t swidms_supportedIntBitmaskTlv::TlvPresent

8.597.2.2 uint32_t swidms_supportedIntBitmaskTlv::ValidBitmasks

8.598 swidms_usbMTUSizeTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t UsbMTUSize

8.598.1 Detailed Description

This structure contains the parameters for USB MTU Size

Parameters

TlvPresent	• Tlv Present.

UsbMTUSize	USB MTU size • Size of USB MTU

8.598.2 Field Documentation

8.598.2.1 uint8_t swidms_usbMTUSizeTlv::TlvPresent

8.598.2.2 uint16_t swidms_usbMTUSizeTlv::UsbMTUSize

8.599 tdscdmaSigInfoExt Struct Reference

Data Fields

- float rssi
- float rscp
- float ecio
- float sinr

8.599.1 Detailed Description

This structure contains the TDSCDMA Signal Strength Info Extended

Parameters

rssi	• Measured RSSI in dB
rscp[Optional]	• Measured RSCP in dBm
ecio[Optional]	• Measured ECIO in dBm.
sinr[Optional]	• Measured SINR in dB. -15 dB is sent to clients if the actual SINR is less than -15 dB

8.599.2 Field Documentation

8.599.2.1 float tdscdmaSigInfoExt::ecio

8.599.2.2 float tdscdmaSigInfoExt::rscp

8.599.2.3 float tdscdmaSigInfoExt::rssi

8.599.2.4 float tdscdmaSigInfoExt::sinr

8.600 tempData_t Struct Reference

Data Fields

- uint32_t timeSource
- uint32_t timeOfFirstSample
- uint8_t temperatureDataLen
- uint16_t timeOffset [64]
- uint32_t temperature [64]

8.600.1 Detailed Description

This structure specifies information regarding the Temperature Data. Please check has_<Param_Name> field for presence of optional parameters

Parameters

timeSource	• Time source of the sensor data • Valid values – 0 - Sensor time source is unspecified – 1 - Time source is common between the sensors and the location engine
timeOfFirst-Sample	• Denotes a full 32-bit time stamp of the first (oldest) sample in this message. • The time stamp is in the time reference scale that is used by the sensor time source. • Units - Milliseconds
temperature-DataLen	• Number of sets of the following elements – timeOffset – temperature
timeOffset	• Sample time offset • Units - Milliseconds
temperature	• Sensor temperature. • Type - Floating point • Units - Degrees Celsius • Range -50 to +100.00

8.600.2 Field Documentation

8.600.2.1 uint32_t tempData_t::temperature[64]

8.600.2.2 uint8_t tempData_t::temperatureDataLen

8.600.2.3 uint32_t tempData_t::timeOfFirstSample

8.600.2.4 uint16_t tempData_t::timeOffset[64]

8.600.2.5 uint32_t tempData_t::timeSource

8.601 tmd_mitigationDevList Struct Reference

Data Fields

- uint8_t mitigationDevIdLen
- char mitigationDevId [255]
- uint8_t maxMitigationLevel

8.601.1 Detailed Description

This structure contains mitigation devices list

Parameters

mitigationDevId-Len	• Number of sets of the following elements – mitigation_dev_id
mitigationDevId	• Mitigation device ID.
maxMitigation-Level	• Maximum valid mitigation level. • Valid range - 0 to max_mitigation_level.

8.601.2 Field Documentation

8.601.2.1 uint8_t tmd_mitigationDevList::maxMitigationLevel

8.601.2.2 char tmd_mitigationDevList::mitigationDevId[255]

8.601.2.3 uint8_t tmd_mitigationDevList::mitigationDevIdLen

8.602 transferRouteMessageTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- sMSTransferRouteMTMessageInfo TransferRouteMTMessageInfo

8.602.1 Detailed Description

This structure contains Transfer route MT message TLV information.

Parameters

TlvPresent	• Boolean indicating the presence of the TLV in the QMI response
TransferRouteM-TMessageInfo	• Transfer Route MT Message • See sMSTransferRouteMTMessageInfo for more information

8.602.2 Field Documentation

8.602.2.1 uint8_t transferRouteMessageTlv::TlvPresent

8.602.2.2 sMSTransferRouteMTMessageInfo transferRouteMessageTlv::TransferRouteMTMessageInfo

8.603 uim_appStatus Struct Reference

Data Fields

- uint8_t appType
- uint8_t appState
- uint8_t persoState
- uint8_t persoFeature
- uint8_t persoRetries
- uint8_t persoUnblockRetries
- uint8_t aidLength
- uint8_t aidVal [255]
- uint8_t univPin
- uint8_t pin1State
- uint8_t pin1Retries
- uint8_t puk1Retries
- uint8_t pin2State
- uint8_t pin2Retries
- uint8_t puk2Retries

8.603.1 Detailed Description

This structure contains Application Status Information loaded on the card.

Parameters

appType	• Indicates the type of the application. – 0 - Unknown – 1 - SIM card – 2 - USIM application – 3 - RUIM card – 4 - CSIM application – 5 - ISIM application • Other values are reserved for the future and are to be handled as "Unknown".
appState	• Indicates the state of the application. – 0 - Unknown – 1 - Detected – 2 - PIN1 or UPIN is required – 3 - PUK1 or PUK for UPIN is required – 4 - Personalization state must be checked – 5 - PIN1 is blocked – 6 - Illegal – 7 - Ready

persoState	• Indicates the state of the personalization for the application. – 0 - Unknown – 1 - Personalization operation is in progress – 2 - Ready – 3 - Personalization code is required – 4 - PUK for personalization code is required – 5 - Permanently blocked
persoFeature	• Indicates the personalization feature. • This applies only when a personalization code is required to deactivate or unblock personalization. – 0 - GW network personalization – 1 - GW network subset personalization – 2 - GW service provider personalization – 3 - GW corporate personalization – 4 - GW UIM personalization – 5 - 1X network type 1 personalization – 6 - 1X network type 2 personalization – 7 - 1X HRPD personalization – 8 - 1X service provider personalization – 9 - 1X corporate personalization – 10 - 1X RUIM personalization – 11 - Unknown
persoRetries	• Indicates the number of retries remaining to disable the personalization.
persoUnblockRetries	• Indicates the number of retries remaining to unblock the personalization.
aidLength	• Number of sets of the following elements. i.e. aidVal • If zero(0) then no aidVal information exists.
aidVal[MAX_DESCRIPTION_LENGTH]	• Application identifier value.
univPin	• Indicates whether UPIN replaces PIN1. – 0 - PIN1 is used – 1 - UPIN replaces PIN1

pin1State	• Indicates the state of PIN1. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked
pin1Retries	• Indicates the number of retries remaining to verify PIN1.
puk1Retries	• Indicates the number of retries remaining to unblock PIN1.
pin2State	• Indicates the state of PIN2. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked
pin2Retries	• Indicates the number of retries remaining to verify PIN2.
puk2Retries	• Indicates the number of retries remaining to unblock PIN2.

8.603.2 Field Documentation

8.603.2.1 uint8_t uim_appStatus::aidLength

8.603.2.2 uint8_t uim_appStatus::aidVal[255]

8.603.2.3 uint8_t uim_appStatus::appState

8.603.2.4 uint8_t uim_appStatus::appType

8.603.2.5 uint8_t uim_appStatus::persoFeature

8.603.2.6 uint8_t uim_appStatus::persoRetries

8.603.2.7 uint8_t uim_appStatus::persoState

8.603.2.8 uint8_t uim_appStatus::persoUnblockRetries

8.603.2.9 uint8_t uim_appStatus::pin1Retries

8.603.2.10 uint8_t uim_appStatus::pin1State

8.603.2.11 uint8_t uim_appStatus::pin2Retries

8.603.2.12 uint8_t uim_appStatus::pin2State

8.603.2.13 uint8_t uim_appStatus::puk1Retries

8.603.2.14 uint8_t uim_appStatus::puk2Retries

8.603.2.15 uint8_t uim_appStatus::univPin

8.604 uim_authenticateResult Struct Reference

Data Fields

- uint16_t contentLen
- uint8_t content [1024]

8.604.1 Detailed Description

This structure contains the information about the authenticate result.

Parameters

contentLen	• Length of the following elements i.e. content.
content[UIM_MAX_CONTENT_LENGTH]	• Authenticate data. • This value is a sequence of bytes returned from the card.

8.604.2 Field Documentation

8.604.2.1 uint8_t uim_authenticateResult::content[1024]

8.604.2.2 uint16_t uim_authenticateResult::contentLen

8.605 uim_authenticationData Struct Reference

Data Fields

- uint8_t context
- uint16_t dataLen
- uint8_t data [1024]

8.605.1 Detailed Description

This structure contains the Session Information.

Parameters

context	• Authenticate context. – 0 - Runs the GSM algorithm (valid only on a 2GSIM card) – 1 - Runs the CAVE algorithm (valid only on a RUIM card) – 2 - GSM security context (valid only on a USIM application) – 3 - 3G security context (valid only on a USIM application) – 4 - VGCS/VBS security context (valid only on aUSIM application) – 5 - GBA security context, Bootstrapping mode (valid only on a USIM or ISIM application) – 6 - GBA security context, NAF Derivation mode (valid only on a USIM or ISIM application) – 7 - MBMS security context, MSK Update mode (valid only on a USIM application) – 8 - MBMS security context, MTK Generation mode (valid only on a USIM application) – 9 - MBMS security context, MSK Deletion mode (valid only on a USIM application) – 10 - MBMS security context, MUK Deletion mode (valid only on a USIM application) – 11 - IMS AKA security context (valid only on aISIM application) – 12 - HTTP-digest security context (valid only onan ISIM application) – 13 - Compute IP authentication, CHAP (valid onlyon RUIM or CSIM) – 14 - Compute IP authentication, MN-HA authenticator (valid only on RUIM or CSIM) – 15 - Compute IP authentication, MIP-RRQ hash (valid only on RUIM or CSIM) – 16 - Compute IP authentication, MN-AAA authenticator (valid only on RUIM or CSIM) – 17 - Compute IP authentication, HRPD access authenticator (valid only on RUIM or CSIM) • Other values are possible and reserved for future use.
dataLen	• Length of the following elements i.e. data.
data[UIM_MAX-_DESCRIPTIO-N_LENGTH]	• Authenticate Data.

8.605.2 Field Documentation

8.605.2.1 uint8_t uim_authenticationData::context

8.605.2.2 uint8_t uim_authenticationData::data[1024]

8.605.2.3 uint16_t uim_authenticationData::dataLen

8.606 uim_cardResult Struct Reference

Data Fields

- uint8_t sw1
- uint8_t sw2

8.606.1 Detailed Description

This structure contains the information about the card result.

Parameters

sw1	• SW1 received from the card.
sw2	• SW2 received from the card.

8.606.2 Field Documentation

8.606.2.1 uint8_t uim_cardResult::sw1

8.606.2.2 uint8_t uim_cardResult::sw2

8.607 uim_cardStatus Struct Reference

Data Fields

- uint16_t indexGwPri
- uint16_t index1xPri
- uint16_t indexGwSec
- uint16_t index1xSec
- uint8_t numSlot
- uim_slotInfo SlotInfo [5]

8.607.1 Detailed Description

This structure contains Card Status Information.

Parameters

indexGwPri	• Index of the primary GW provisioning application. • The most significant byte indicates the slot (starting from 0), while the least significant byte indicates the application for that slot (starting from 0). • The value 0xFFFF identifies when the session does not exist.
index1xPri	• Index of the primary 1X provisioning application. • The most significant byte indicates the slot (starting from 0), while the least significant byte indicates the application for that slot (starting from 0). • The value 0xFFFF identifies when the session does not exist.
indexGwSec	• Index of the secondary GW provisioning application. • The most significant byte indicates the slot (starting from 0), while the least significant byte indicates the application for that slot (starting from 0). • The value 0xFFFF identifies when the session does not exist.

index1xSec	• Index of the secondary GW provisioning application. • The most significant byte indicates the slot (starting from 0), while the least significant byte indicates the application for that slot (starting from 0). • The value 0xFFFF identifies when the session does not exist.
numSlot	• Indicates the number of slots available on the device. • The following block is repeated for each slot. i.e. cardState • If zero(0) then no cardState information exists.
SlotInfo	• See uim_slotInfo for more information.

8.607.2 Field Documentation

8.607.2.1 uint16_t uim_cardStatus::index1xPri

8.607.2.2 uint16_t uim_cardStatus::index1xSec

8.607.2.3 uint16_t uim_cardStatus::indexGwPri

8.607.2.4 uint16_t uim_cardStatus::indexGwSec

8.607.2.5 uint8_t uim_cardStatus::numSlot

8.607.2.6 uim_slotInfo uim_cardStatus::SlotInfo[5]

8.608 uim_changeUIMPIN Struct Reference

Data Fields

- uint8_t pinID
- uint8_t oldPINLen
- uint8_t oldPINVal [255]
- uint8_t pinLen
- uint8_t pinVal [255]

8.608.1 Detailed Description

This structure contains the information about the pin parameters that need to be verified.

Parameters

pinID	• Indicates the PIN ID to be changed. – 1 - PIN1 (also called PIN) – 2 - PIN2 – 3 - Universal PIN – 4 - Hidden key

oldPINLen	• Length of the following elements i.e. old pin value.
oldPINVal[MAX_DESCRIPTION_LENGTH]	• Old PIN value. • This value is a sequence of ASCII characters.
pinLen	• Length of the following elements i.e. new pin value.
pinVal[MAX_DESCRIPTION_LENGTH]	• New PIN value. • This value is a sequence of ASCII characters.

8.608.2 Field Documentation

8.608.2.1 uint8_t uim_changeUIMPIN::oldPINLen

8.608.2.2 uint8_t uim_changeUIMPIN::oldPINVal[255]

8.608.2.3 uint8_t uim_changeUIMPIN::pinID

8.608.2.4 uint8_t uim_changeUIMPIN::pinLen

8.608.2.5 uint8_t uim_changeUIMPIN::pinVal[255]

8.609 uim_depersonalizationInformation Struct Reference

Data Fields

- uint8_t feature
- uint8_t operation
- uint8_t ckLen
- uint8_t ckVal [255]

8.609.1 Detailed Description

This structure contains the Depersonalization Information.

Parameters

feature	• Indicates the personalization feature to de-activate or unblock. – 0 - GW network personalization – 1 - GW network subset personalization – 2 - GW service provider personalization – 3 - GW corporate personalization – 4 - GW UIM personalization – 5 - 1X network type 1 personalization – 6 - 1X network type 2 personalization – 7 - 1X HRPD personalization – 8 - 1X service provider personalization – 9 - 1X corporate personalization – 10 - 1X RUIM personalization
operation	• Indicates the operation to perform. – 0 - Deactivate personalization. – 1 - Unblock personalization.
ckLen	• Length of the following elements i.e. control key value.
ckVal[MAX_DESCRIPTION_LENGTH]	• Control key value. • This value is a sequence of ASCII characters.

8.609.2 Field Documentation

8.609.2.1 uint8_t uim_depersonalizationInformation::ckLen

8.609.2.2 uint8_t uim_depersonalizationInformation::ckVal[255]

8.609.2.3 uint8_t uim_depersonalizationInformation::feature

8.609.2.4 uint8_t uim_depersonalizationInformation::operation

8.610 uim_encryptedPIN1 Struct Reference

Data Fields

- uint8_t pin1Len
- uint8_t pin1Val [255]

8.610.1 Detailed Description

This structure contains the encrypted PIN1 Information.

Parameters

pin1Len	• Number of sets of the following elements ie encrypted PIN1 value. • If zero(0), no information follows.
pin1Val	• Encrypted PIN1 value.

Note

This value is returned only when PIN1 is enabled successfully and the feature is supported.

8.610.2 Field Documentation

8.610.2.1 uint8_t uim_encryptedPIN1::pin1Len

8.610.2.2 uint8_t uim_encryptedPIN1::pin1Val[255]

8.611 uim_fileAttributes Struct Reference

Data Fields

- uint16_t fileSize
- uint16_t fileID
- uint8_t fileType
- uint16_t recordSize
- uint16_t recordCount
- uint8_t secRead
- uint16_t secReadMask
- uint8_t secWrite
- uint16_t secWriteMask
- uint8_t secIncrease
- uint16_t secIncreaseMask
- uint8_t secDeactivate
- uint16_t secDeactivateMask
- uint8_t secActivate
- uint16_t secActivateMask
- uint16_t rawLen
- uint8_t rawValue [255]

8.611.1 Detailed Description

This structure contains the information about the File Attributes.

Parameters

fileSize	• Indicates the size of the file.
fileID	• Indicates the ID of the file.

fileType	• Indicates the type of the file. – 0 - Transparent – 1 - Cyclic – 2 - Linear fixed – 3 - Dedicated file – 4 - Master file
recordSize	• Indicates the size of the records. • Only for cyclic and linear fixed files
recordCount	• Indicates the total no. of the records. • Only for linear fixed files
secRead	• Read security attributes. – 0 - Always – 1 - Never – 2 - AND condition – 3 - OR condition – 4 - Single condition
secReadMask	• Mask with read security attributes. • This field is valid only when required by security attributes. – Bit 0 - PIN1 – Bit 1 - PIN2 – Bit 2 - UPIN – Bit 3 - ADM
secWrite	• Write security attributes. – 0 - Always – 1 - Never – 2 - AND condition – 3 - OR condition – 4 - Single condition
secWriteMask	• Mask with write security attributes. • This field is valid only when required by security attributes. – Bit 0 - PIN1 – Bit 1 - PIN2 – Bit 2 - UPIN – Bit 3 - ADM

secIncrease	• Increase security attributes. – 0 - Always – 1 - Never – 2 - AND condition – 3 - OR condition – 4 - Single condition
secIncrease-Mask	• Mask with increase security attributes. • This field is valid only when required by security attributes. – Bit 0 - PIN1 – Bit 1 - PIN2 – Bit 2 - UPIN – Bit 3 - ADM
secDeactivate	• Deactivate security attributes. – 0 - Always – 1 - Never – 2 - AND condition – 3 - OR condition – 4 - Single condition
secDeactivate-Mask	• Mask with deactivate security attributes. • This field is valid only when required by security attributes. – Bit 0 - PIN1 – Bit 1 - PIN2 – Bit 2 - UPIN – Bit 3 - ADM
secActivate	• Activate security attributes. – 0 - Always – 1 - Never – 2 - AND condition – 3 - OR condition – 4 - Single condition
secActivateMask	• Mask with activate security attributes. • This field is valid only when required by security attributes. – Bit 0 - PIN1 – Bit 1 - PIN2 – Bit 2 - UPIN – Bit 3 - ADM
rawLen	• Length of the following elements i.e. raw value.

rawValue[MAX_-DESCRIPTION-_LENGTH]	• Raw value of file attributes.

8.611.2 Field Documentation

8.611.2.1 uint16_t uim_fileAttributes::fileID

8.611.2.2 uint16_t uim_fileAttributes::fileSize

8.611.2.3 uint8_t uim_fileAttributes::fileType

8.611.2.4 uint16_t uim_fileAttributes::rawLen

8.611.2.5 uint8_t uim_fileAttributes::rawValue[255]

8.611.2.6 uint16_t uim_fileAttributes::recordCount

8.611.2.7 uint16_t uim_fileAttributes::recordSize

8.611.2.8 uint8_t uim_fileAttributes::secActivate

8.611.2.9 uint16_t uim_fileAttributes::secActivateMask

8.611.2.10 uint8_t uim_fileAttributes::secDeactivate

8.611.2.11 uint16_t uim_fileAttributes::secDeactivateMask

8.611.2.12 uint8_t uim_fileAttributes::secIncrease

8.611.2.13 uint16_t uim_fileAttributes::secIncreaseMask

8.611.2.14 uint8_t uim_fileAttributes::secRead

8.611.2.15 uint16_t uim_fileAttributes::secReadMask

8.611.2.16 uint8_t uim_fileAttributes::secWrite

8.611.2.17 uint16_t uim_fileAttributes::secWriteMask

8.612 uim_fileInfo Struct Reference

Data Fields

- uint16_t fileID
- uint8_t pathLen
- uint16_t path [255]

8.612.1 Detailed Description

This structure contains paramaters for file Information

Parameters

fileID	• This is Identifier to SIM files; e.g. in UIM "6F07" is Identifier of IMSI File
pathLen	• Length of file Path
path	• Path value. This value must be the complete path of the file, which is a sequence block of 2 bytes (e.g., 0x3F00 0x7FFF) is for LTE (0x3F00 ,0x7F20) is for GSM.

8.612.2 Field Documentation

8.612.2.1 uint16_t uim_fileInfo::fileID

8.612.2.2 uint16_t uim_fileInfo::path[255]

8.612.2.3 uint8_t uim_fileInfo::pathLen

8.613 uim_hotSwapStatus Struct Reference

Data Fields

- uint8_t hotSwapLength
- uint8_t hotSwap [255]

8.613.1 Detailed Description

This structure contains Hot Swap Status Information.

Parameters

hotSwapLength	• Number of sets of the following elements. i.e. hot_swap
hotSwap	• Indicates the status of the hot-swap switch. – 0 - Hot-swap is not supported – 1 - Hot-swap is supported, but the status of the switch is not supported – 2 - Switch indicates that the card is present – 3 - Switch indicates that the card is not present

8.613.2 Field Documentation

8.613.2.1 uint8_t uim_hotSwapStatus::hotSwap[255]

8.613.2.2 uint8_t uim_hotSwapStatus::hotSwapLength

8.614 uim_personalizationStatus Struct Reference

Data Fields

- uint8_t numFeatures
- uint8_t feature [12]
- uint8_t verifyLeft [12]
- uint8_t unblockLeft [12]

8.614.1 Detailed Description

This structure contains the information about the card result.

Parameters

numFeatures	• Number of active personalization features. The following block is repeated for each feature.
feature	• Indicates the personalization feature to deactivate or unblock. Valid values: – 0 - GW network personalization – 1 - GW network subset personalization – 2 - GW service provider personalization – 3 - GW corporate personalization – 4 - GW UIM personalization – 5 - 1X network type 1 personalization – 6 - 1X network type 2 personalization – 7 - 1X HRPD personalization – 8 - 1X service provider personalization – 9 - 1X corporate personalization – 10 - 1X RUIM personalization
verifyLeft	• Number of the remaining attempts to verify the personalization feature.
unblockLeft	• Number of the remaining attempts to unblock the personalization feature.

8.614.2 Field Documentation

8.614.2.1 uint8_t uim_personalizationStatus::feature[12]

8.614.2.2 uint8_t uim_personalizationStatus::numFeatures

8.614.2.3 uint8_t uim_personalizationStatus::unblockLeft[12]

8.614.2.4 uint8_t uim_personalizationStatus::verifyLeft[12]

8.615 uim_readResult Struct Reference

Data Fields

- uint16_t contentLen
- uint8_t content [255]

8.615.1 Detailed Description

This structure contains the information for write operation.

Parameters

contentLen	• Number of sets of content.
content[255]	• Read content. • The content is the sequence of bytes as read from the card.

8.615.2 Field Documentation

8.615.2.1 uint8_t uim_readResult::content[255]

8.615.2.2 uint16_t uim_readResult::contentLen

8.616 uim_readTransparentInfo Struct Reference

Data Fields

- uint16_t offset
- uint16_t length

8.616.1 Detailed Description

This structure contains the information for read operation.

Parameters

offset	• Offset for the read operation.
length	• Length of the content to be read. • The value 0 is used to read the complete file.

8.616.2 Field Documentation

8.616.2.1 uint16_t uim_readTransparentInfo::length

8.616.2.2 uint16_t uim_readTransparentInfo::offset

8.617 uim_refreshevent Struct Reference

Data Fields

- uint8_t stage
- uint8_t mode

- uint8_t sessionType
- uint8_t aidLength
- uint8_t aid [255]
- uint16_t numOfFiles
- uim_fileInfo arrfileInfo [255]

8.617.1 Detailed Description

This structure contains information of parameters associated with the Refresh Event.

Parameters

stage	• Indicates the stage of the Refresh procedure. – 0 - Waiting for OK to refresh – 1 - Refresh started – 2 - Refresh ended successfully – 3 - Refresh failed
mode	• Indicates the Refresh mode. – 0 - Reset – 1 - Init – 2 - Init and FCN – 3 - FCN – 4 - Init and Full FCN – 5 - Application reset – 6 - 3G session reset
sessionType	• Indicates the session type. – 0 - Primary GW provisioning – 1 - Primary 1X provisioning – 2 - Secondary GW provisioning – 3 - Secondary 1X provisioning – 4 - Nonprovisioning on slot 1 – 5 - Nonprovisioning on slot 2 – 6 - Card on slot 1 – 7 - Card on slot 2 – 8 - Logical channel on slot 1 – 9 - Logical channel on slot 2
aidLength	• Number of sets of the following elements – Application Identifier
aid	• Application identifier value or channel ID. This value is required for non-provisioning and for logical channel session types. It is ignored in all other cases

numFiles	• Number of sets of the following elements: – file_id – path_len – path
arrfileInfo	• Array of file Information struct

8.617.2 Field Documentation

8.617.2.1 uint8_t uim_refreshevent::aid[255]

8.617.2.2 uint8_t uim_refreshevent::aidLength

8.617.2.3 uim_fileInfo uim_refreshevent::arrfileInfo[255]

8.617.2.4 uint8_t uim_refreshevent::mode

8.617.2.5 uint16_t uim_refreshevent::numOfFiles

8.617.2.6 uint8_t uim_refreshevent::sessionType

8.617.2.7 uint8_t uim_refreshevent::stage

8.618 uim_registerRefresh Struct Reference

Data Fields

- uint8_t registerFlag
- uint8_t voteForInit
- uint16_t numFiles
- uim_fileInfo arrfileInfo [255]

8.618.1 Detailed Description

This structure contains parameters of refresh Information

Parameters

registerFlag	• Flag that indicates whether to register or deregister for refresh indications. Valid values: – 0 - Deregister – 1 - Register
voteForInit	• Flag that indicates whether to vote for the init when there is a refresh. Valid values: – 0 - Client does not vote for initialization – 1 - Client votes for initialization

numFiles	• Number of sets of the following elements: – file_id – path_len – path
arrfileInfo	• Array of file Information structure. • See uim_fileInfo for more information

8.618.2 Field Documentation

8.618.2.1 uim_fileInfo uim_registerRefresh::arrfileInfo[255]

8.618.2.2 uint16_t uim_registerRefresh::numFiles

8.618.2.3 uint8_t uim_registerRefresh::registerFlag

8.618.2.4 uint8_t uim_registerRefresh::voteForInit

8.619 uim_remainingRetries Struct Reference

Data Fields

- uint8_t verifyLeft
- uint8_t unblockLeft

8.619.1 Detailed Description

This structure contains the information about the retries remaining.

Parameters

verifyLeft	• Number of remaining attempts to verify the PIN. • 0xFF, if unavailable.
unblockLeft	• Number of remaining attempts to unblock the PIN. • 0xFF, if unavailable.

Note

This value is returned only when the enable/disable operation has failed. This information is not sent for a hidden key PIN type.

8.619.2 Field Documentation

8.619.2.1 uint8_t uim_remainingRetries::unblockLeft

8.619.2.2 uint8_t uim_remainingRetries::verifyLeft

8.620 uim_sessionInformation Struct Reference

Data Fields

- uint8_t sessionType
- uint8_t aidLength
- uint8_t aid [255]

8.620.1 Detailed Description

This structure contains the Session Information.

Parameters

sessionType	• Indicates the session type. – 0 - Primary GW provisioning – 1 - Primary 1X provisioning – 2 - Secondary GW provisioning – 3 - Secondary 1X provisioning – 4 - Non-provisioning on slot 1 – 5 - Non-provisioning on slot 2 – 6 - Card on slot 1 – 7 - Card on slot 2 – 8 - Logical channel on slot 1 – 9 - Logical channel on slot 2
aidLength	• Length of the following elements i.e. Application Identifier.
aid	• Application identifier value or channel ID. • This value is required for non-provisioning and for logical channel session types. It is ignored in all other cases.

8.620.2 Field Documentation

8.620.2.1 uint8_t uim_sessionInformation::aid[255]

8.620.2.2 uint8_t uim_sessionInformation::aidLength

8.620.2.3 uint8_t uim_sessionInformation::sessionType

8.621 uim_setPINProtection Struct Reference

Data Fields

- uint8_t pinID
- uint8_t pinOperation

- uint8_t pinLength
- uint8_t pinValue [255]

8.621.1 Detailed Description

This structure contains the information about the pin protection parameters that need to be set.

Parameters

pinID	• Indicates the PIN ID to be enabled or disabled. – 1 - PIN1 (also called PIN) – 2 - PIN2 – 3 - Universal PIN – 4 - Hidden key
pinOperation	• Indicates whether the PIN is enabled or disabled. – 0 - Disable the PIN – 1 - Enable the PIN
pinLength	• Length of the following elements i.e. pin value.
pinValue[MAX_-DESCRIPTION-_LENGTH]	• PIN value. • This value is a sequence of ASCII characters.

8.621.2 Field Documentation

8.621.2.1 uint8_t uim_setPINProtection::pinID

8.621.2.2 uint8_t uim_setPINProtection::pinLength

8.621.2.3 uint8_t uim_setPINProtection::pinOperation

8.621.2.4 uint8_t uim_setPINProtection::pinValue[255]

8.622 uim_slotInfo Struct Reference

Data Fields

- uint8_t cardState
- uint8_t upinState
- uint8_t upinRetries
- uint8_t upukRetries
- uint8_t errorState
- uint8_t numApp
- uim_appStatus AppStatus [10]

8.622.1 Detailed Description

This structure contains information about the SLOTS present.

Parameters

cardState	• Indicates the state of the card for each slot. – 0 - Absent – 1 - Present – 2 - Error
upinState	• Indicates the state of UPIN. – 0 - Unknown – 1 - Enabled and not verified – 2 - Enabled and verified – 3 - Disabled – 4 - Blocked – 5 - Permanently blocked – 0xFF - Not Available
upinRetries	• Indicates the number of retries remaining to verify the UPIN. • If 0xFF, information not available.
upukRetries	• Indicates the number of retries remaining to unblock the UPIN. • If 0xFF, information not available.
errorState	• Indicates the reason for the card error, and is valid only when the card state is Error – 0 - Unknown – 1 - Power down – 2 - Poll error – 3 - No ATR received – 4 - Volt mismatch – 5 - Parity error – 6 - Unknown; possibly removed – 7 - Card returned technical problems – 0xFF - Not Available • Other values are possible and reserved for future use. • When an unknown value is received, it is to be handled as "Unknown".
numApp	• Indicates the number of applications available on the card. • The following block is repeated for each application. i.e. AppStatus. • If zero(0) then no AppStatus information exists.
AppStatus	• See uim_appStatus for more information.

8.622.2 Field Documentation

8.622.2.1 uim_appStatus uim_slotInfo::AppStatus[10]

8.622.2.2 uint8_t uim_slotInfo::cardState

8.622.2.3 uint8_t uim_slotInfo::errorState

8.622.2.4 uint8_t uim_slotInfo::numApp

8.622.2.5 uint8_t uim_slotInfo::upinRetries

8.622.2.6 uint8_t uim_slotInfo::upinState

8.622.2.7 uint8_t uim_slotInfo::upukRetries

8.623 uim_UIMSessionInformation Struct Reference

Data Fields

- uint8_t sessionType
- uint8_t aidLength
- uint8_t aid [255]

8.623.1 Detailed Description

This structure contains the Session Information.

Parameters

sessionType	• Indicates the session type. – 0 - Primary GW provisioning – 1 - Primary 1X provisioning – 2 - Secondary GW provisioning – 3 - Secondary 1X provisioning – 4 - Non-provisioning on slot 1 – 5 - Non-provisioning on slot 2 – 6 - Card on slot 1 – 7 - Card on slot 2 – 8 - Logical channel on slot 1 – 9 - Logical channel on slot 2
aidLength	• Length of the following elements i.e. Application Identifier.
aid	• Application identifier value or channel ID. • This value is required for non-provisioning and for logical channel session types. It is ignored in all other cases.

8.623.2 Field Documentation

8.623.2.1 uint8_t uim_UIMSessionInformation::aid[255]

8.623.2.2 uint8_t uim_UIMSessionInformation::aidLength

8.623.2.3 uint8_t uim_UIMSessionInformation::sessionType

8.624 uim_unblockUIMPIN Struct Reference

Data Fields

- uint8_t pinID
- uint8_t pukLen
- uint8_t pukVal [255]
- uint8_t newPINLen
- uint8_t newPINVal [255]

8.624.1 Detailed Description

This structure contains the information about the unblock pin parameters.

Parameters

pinID	• Indicates the PIN ID to be changed. – 1 - PIN1 (also called PIN) – 2 - PIN2 – 3 - Universal PIN
pukLen	• Length of the following elements i.e. puk value.
pukVal[UIM_MAX_DESCRIPTION_LENGTH]	• PIN Unlock Key value. • This value is a sequence of ASCII characters.
newPINLen	• Length of the following elements i.e. new pin value.
newPINVal[UIM_MAX_DESCRIPTION_LENGTH]	• New PIN value. • This value is a sequence of ASCII characters.

8.624.2 Field Documentation

8.624.2.1 uint8_t uim_unblockUIMPIN::newPINLen

8.624.2.2 uint8_t uim_unblockUIMPIN::newPINVal[255]

8.624.2.3 uint8_t uim_unblockUIMPIN::pinID

8.624.2.4 uint8_t uim_unblockUIMPIN::pukLen

8.624.2.5 uint8_t uim_unblockUIMPIN::pukVal[255]

8.625 uim_verifyUIMPIN Struct Reference

Data Fields

- uint8_t pinID
- uint8_t pinLen
- uint8_t pinVal [255]

8.625.1 Detailed Description

This structure contains the information about the pin parameters that need to be verified.

Parameters

pinID	• Indicates the PIN ID to be verified. – 1 - PIN1 (also called PIN) – 2 - PIN2 – 3 - Universal PIN – 4 - Hidden key
pinLen	• Length of the following elements i.e. pin value.
pinVal[MAX_DESCRIPTION_LENGTH]	• PIN value. • This value is a sequence of ASCII characters.

8.625.2 Field Documentation

8.625.2.1 uint8_t uim_verifyUIMPIN::pinID

8.625.2.2 uint8_t uim_verifyUIMPIN::pinLen

8.625.2.3 uint8_t uim_verifyUIMPIN::pinVal[255]

8.626 unpack_audio_SLQSGetAudioPathConfig_t Struct Reference

Data Fields

- uint8_t * pECMode
- uint8_t * pNSEnable
- uint16_t * pTXGain
- uint16_t * pDTMFTXGain
- uint16_t * pCodecSTGain
- audio_TXPCMIIRFltr * pTXPCMIIRFltr
- audio_RXPCMIIRFltr * pRXPCMIIRFltr
- uint8_t * pMICGainSelect

- uint8_t * pRXAVCAGCSwitch
- uint8_t * pTXAVCSwitch
- audio_RXAGCList * pRXAGCList
- audio_RXAVCList * pRXAVCList
- audio_TXAGCList * pTXAGCList
- swi_uint256_t ParamPresenceMask

8.626.1 Detailed Description

This structure contains the SLQSGetAudioPathConfig response parameters.

Parameters

pECMode	[Optional] • AV_EC – 0 - Echo cancellation off – 1 - Handset mode – 2 - Headset mode – 3 - Car kit mode – 4 - Speaker Mode • Bit to check in ParamPresenceMask - **33**
pNSEnable	[Optional] • AV_NS – 0 - Noise suppression off – 1 - Noise suppression on • Bit to check in ParamPresenceMask - **34**
pTXGain	[Optional] • AV_TXVOL – 0x0000 - 0xffff • Bit to check in ParamPresenceMask - **35**
pDTMFTXGain	[Optional] • AV_DTMFTXG – 0x0000 - 0xffff • Bit to check in ParamPresenceMask - **36**
pCodecSTGain	[Optional] • AV_CODECSTG – 0x0000 - 0xffff • Bit to check in ParamPresenceMask - **37**
pTXPCMIIRFltr	[Optional] • See audio_TXPCMIIRFltr for more information • Bit to check in ParamPresenceMask - **38**
pRXPCMIIRFltr	[Optional] • See audio_RXPCMIIRFltr for more information • Bit to check in ParamPresenceMask - **39**

pMICGainSelect	[Optional] • AV_MICGAIN • Bit to check in ParamPresenceMask - **40**
pRXAVCAGC-Switch	[Optional] • RX AVC/AGC Switch • Bit to check in ParamPresenceMask - **41**
pTXAVCSwitch	[Optional] • TX AVC Switch • Bit to check in ParamPresenceMask - **42**
pRXAGCList	[Optional] • See audio_RXAGCList for more information • Bit to check in ParamPresenceMask - **43**
pRXAVCList	[Optional] • See audio_RXAVCList for more information • Bit to check in ParamPresenceMask - **44**
pTXAGCList	[Optional] • See audio_TXAGCList for more information • Bit to check in ParamPresenceMask - **45**

8.626.2 Field Documentation

8.626.2.1 swi_uint256_t unpack_audio_SLQSGetAudioPathConfig_t::ParamPresenceMask

8.626.2.2 uint16_t* unpack_audio_SLQSGetAudioPathConfig_t::pCodecSTGain

8.626.2.3 uint16_t* unpack_audio_SLQSGetAudioPathConfig_t::pDTMFTXGain

8.626.2.4 uint8_t* unpack_audio_SLQSGetAudioPathConfig_t::pECMode

8.626.2.5 uint8_t* unpack_audio_SLQSGetAudioPathConfig_t::pMICGainSelect

8.626.2.6 uint8_t* unpack_audio_SLQSGetAudioPathConfig_t::pNSEnable

8.626.2.7 audio_RXAGCList* unpack_audio_SLQSGetAudioPathConfig_t::pRXAGCList

8.626.2.8 uint8_t* unpack_audio_SLQSGetAudioPathConfig_t::pRXAVCAGCSwitch

8.626.2.9 audio_RXAVCList* unpack_audio_SLQSGetAudioPathConfig_t::pRXAVCList

8.626.2.10 audio_RXPCMIIRFltr* unpack_audio_SLQSGetAudioPathConfig_t::pRXPCMIIRFltr

8.626.2.11 audio_TXAGCList* unpack_audio_SLQSGetAudioPathConfig_t::pTXAGCList

8.626.2.12 uint8_t* unpack_audio_SLQSGetAudioPathConfig_t::pTXAVCSwitch

8.626.2.13 uint16_t* unpack_audio_SLQSGetAudioPathConfig_t::pTXGain

8.626.2.14 audio_TXPCMIIRFItr* unpack_audio_SLQSGetAudioPathConfig_t::pTXPCMIIRFItr

8.627 unpack_audio_SLQSGetAudioProfile_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t EarMute
- uint8_t MicMute
- uint8_t Volume
- swi_uint256_t ParamPresenceMask

8.627.1 Detailed Description

This structure contains the unpack parameters to Get Audio Profile.

Parameters

Profile	• Audio Profile – 0 - Handset – 1 - Headset – 2 - Car Kit – 3 - Speaker phone – 4 - Auxiliary – 5 - TTY – 6 - Auxiliary external PCM – 7 - Primary external PCM – 8 - External slave PCM – 9 - I2S • Bit to check in ParamPresenceMask - **16**
EarMute	• Ear Mute Setting – 0 - unmuted – 1 - muted • Bit to check in ParamPresenceMask - **17**
MicMute	• MIC Mute Setting – 0 - unmuted – 1 - muted • Bit to check in ParamPresenceMask - **18**
Volume	• Audio Volume Level – 0 to 7 • Bit to check in ParamPresenceMask - **20**

8.627.2 Field Documentation

8.627.2.1 uint8_t unpack_audio_SLQSGetAudioProfile_t::EarMute

8.627.2.2 uint8_t unpack_audio_SLQSGetAudioProfile_t::MicMute

8.627.2.3 swi_uint256_t unpack_audio_SLQSGetAudioProfile_t::ParamPresenceMask

8.627.2.4 uint8_t unpack_audio_SLQSGetAudioProfile_t::Profile

8.627.2.5 uint8_t unpack_audio_SLQSGetAudioProfile_t::Volume

8.628 unpack_audio_SLQSGetAudioVolTLBConfig_t Struct Reference

Data Fields

- uint16_t ResCode
- swi_uint256_t ParamPresenceMask

8.628.1 Detailed Description

This structure contains the unpack parameters for SLQSGetAudioVolTLBConfig.

Parameters

ResCode	• Result of requested item • Bit to check in ParamPresenceMask - **33**

8.628.2 Field Documentation

8.628.2.1 swi_uint256_t unpack_audio_SLQSGetAudioVolTLBConfig_t::ParamPresenceMask

8.628.2.2 uint16_t unpack_audio_SLQSGetAudioVolTLBConfig_t::ResCode

8.629 unpack_audio_SLQSSetAudioVolTLBConfig_t Struct Reference

Data Fields

- uint16_t ResCode
- swi_uint256_t ParamPresenceMask

8.629.1 Detailed Description

This structure contains the unpack parameters for SLQSSetAudioVolTLBConfig.

Parameters

ResCode	• Result of requested item • Bit to check in ParamPresenceMask - **33**

8.629.2 Field Documentation

8.629.2.1 swi_uint256_t unpack_audio_SLQSSetAudioVolTLBConfig_t::ParamPresenceMask

8.629.2.2 uint16_t unpack_audio_SLQSSetAudioVolTLBConfig_t::ResCode

8.630 unpack_cat_SetCatEventCallback_ind_t Struct Reference

Data Fields

- uint8_t event_Index
- struct cat_commonEventTlv CCETlv [11]
- swi_uint256_t ParamPresenceMask

8.630.1 Detailed Description

Structure used to store all CAT Notification Parameters.

Parameters

event_Index	- Event Index
CCETlv	- CAT common event Tlv cat_commonEventTlv for more info. • [0] - Bit to check in ParamPresenceMask for Display Text - **16** • [1] - Bit to check in ParamPresenceMask for Get In-Key - **17** • [2] - Bit to check in ParamPresenceMask for Get Input - **18** • [3] - Bit to check in ParamPresenceMask for Setup Menu - **19** • [4] - Bit to check in ParamPresenceMask for Select Item - **20** • [5] - Bit to check in ParamPresenceMask for Alpha Identifier - **21** • [6] - Bit to check in ParamPresenceMask for Setup Event List - **22** • [7] - Bit to check in ParamPresenceMask for Setup Idle Mode Text - **23** • [8] - Bit to check in ParamPresenceMask for Language Notification - **24** • [9] - Bit to check in ParamPresenceMask for Refresh - **25** • [10] - Bit to check in ParamPresenceMask for End Proactive Session - **26**

8.630.2 Field Documentation

8.630.2.1 struct cat_commonEventTlv unpack_cat_SetCatEventCallback_ind_t::CCETlv[11]

8.630.2.2 uint8_t unpack_cat_SetCatEventCallback_ind_t::event_Index

8.630.2.3 swi_uint256_t unpack_cat_SetCatEventCallback_ind_t::ParamPresenceMask

8.631 unpack_cat_SetCATEventCallback_t Struct Reference

Data Fields

- uint32_t errorMask
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.631.1 Detailed Description

This structure contains sEnables/disables the CAT event callback unpack variable.

Parameters

errorMask	• error bitmask. Each bit set indicates the proactive command that caused the error – 0x00000001 - Display Text – 0x00000002 - Get In-Key – 0x00000004 - Get Input – 0x00000008 - Setup Menu – 0x00000010 - Select Item – 0x00000020 - Send SMS - Alpha Identifier – 0x00000040 - Setup Event: User Activity – 0x00000080 - Setup Event: Idle Screen Notify – 0x00000100 - Setup Event: Language Sel Notify – 0x00000200 - Setup Idle Mode Text – 0x00000400 - Language Notification – 0x00000800 - Refresh – 0x00001000 - End Proactive Session • Bit to check in ParamPresenceMask - **16**
TlvResult	• Unpack Result

8.631.2 Field Documentation

8.631.2.1 uint32_t unpack_cat_SetCATEventCallback_t::errorMask

8.631.2.2 swi_uint256_t unpack_cat_SetCATEventCallback_t::ParamPresenceMask

8.631.2.3 uint16_t unpack_cat_SetCATEventCallback_t::TlvResult

8.632 unpack_dms_GetActivationState_t Struct Reference

Data Fields

- uint8_t state
- swi_uint256_t ParamPresenceMask

8.632.1 Detailed Description

This structure contains unpack_dms_GetActivationState parameters.

Parameters

state[OUT]	• Service Activation Code 0 - Service not activated 1 - Service activated 2 - Activation connecting 3 - Activation connected 4 - OTASP security authenticated 5 - OTASP NAM downloaded 6 - OTASP MDN downloaded 7 - OTASP IMSI downloaded 8 - OTASP PRL downloaded 9 - OTASP SPC downloaded 10 - OTASP settings committed • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.632.2 Field Documentation

8.632.2.1 swi_uint256_t unpack_dms_GetActivationState_t::ParamPresenceMask

8.632.2.2 uint8_t unpack_dms_GetActivationState_t::state

8.633 unpack_dms_GetBandCapability_t Struct Reference

Data Fields

- uint32_t BandCapability
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.633.1 Detailed Description

Structure to store the band capability of the device.

Parameters

BandCapability	Bitmask of bands supported by the device • Bit 0 - Band class 0, A-system • Bit 1 - Band class 0, B-system • Bit 2 - Band class 1, all blocks • Bit 3 - Band class 2 • Bit 4 - Band class 3, A-system • Bit 5 - Band class 4, all blocks • Bit 6 - Band class 5, all blocks • Bit 7 - GSM DCS band (1800) • Bit 8 - GSM Extended GSM (E-GSM) band (900) • Bit 9 - GSM Primary GSM (P-GSM) band (900) • Bit 10 - Band class 6 • Bit 11 - Band class 7 • Bit 12 - Band class 8 • Bit 13 - Band class 9 • Bit 14 - Band class 10 • Bit 15 - Band class 11 • Bit 16 - GSM 450 band • Bit 17 - GSM 480 band • Bit 18 - GSM 750 band • Bit 19 - GSM 850 band • Bit 20 - GSM railways GSM band (900) • Bit 21 - GSM PCS band (1900) • Bit 22 - WCDMA (Europe, Japan, and China) 2100 band • Bit 23 - WCDMA US PCS 1900 band • Bit 24 - WCDMA (Europe and China) DCS 1800 band • Bit 25 - WCDMA US 1700 band • Bit 26 - WCDMA US 850 band • Bit 27 - WCDMA Japan 800 band • Bit 28 - Band class 12 • Bit 29 - Band class 14 • Bit 30 - Reserved • Bit 31 - Band class 15 • Bits 32 through 47 - Reserved • Bit 48 - WCDMA Europe 2600 band • Bit 49 - WCDMA Europe and Japan 900 band • Bit 50 - WCDMA Japan 1700 band • Bits 51 through 55 - Reserved • Bit 56 - Band class 16 • Bit 57 - Band class 17 • Bit 58 - Band class 18 • Bit 59 - Band class 19 • Bit 60 - WCDMA Japan 850 band • Bit 61 - WCDMA 1500 band • Bits 62 and 63 - Reserved

- Bit to check in ParamPresenceMask - **1**

Parameters

TlvResult	• unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.633.2 Field Documentation

8.633.2.1 uint32_t unpack_dms_GetBandCapability_t::BandCapability

8.633.2.2 swi_uint256_t unpack_dms_GetBandCapability_t::ParamPresenceMask

8.633.2.3 uint16_t unpack_dms_GetBandCapability_t::TlvResult

8.634 unpack_dms_GetCrashAction_t Struct Reference

Data Fields

- uint8_t DevCrashState
- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.634.1 Detailed Description

This structure is used to store the Crash State from the device.

Parameters

DevCrashState	• Device Crash State • Values: – 0 - USB Memory Download Modem will reset after a crash and will stay in USB download mode with only ttyUSB0 enumerated. ramdump tool is to be used to recover the crash dump. Modem needs to be reset again to come back in ONLINE mode. – 1 - Reset Modem will reset and come back in ONLINE mode. Minimal crash data will be available and can be extracted with at!gcdump? AT command or SLQSSwiGetCrashInfo() SDK API – 2 - No action • Bit to check in ParamPresenceMask - **1**
TlvResult	• unpack Tlv result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.634.2 Field Documentation

8.634.2.1 uint8_t unpack_dms_GetCrashAction_t::DevCrashState

8.634.2.2 swi_uint256_t unpack_dms_GetCrashAction_t::ParamPresenceMask

8.634.2.3 uint16_t unpack_dms_GetCrashAction_t::Tlvresult

8.635 unpack_dms_GetCustFeature_t Struct Reference

Data Fields

- uint32_t GpsEnable
- uint8_t DisableIMSI
- uint16_t IPFamSupport
- uint8_t RMAutoConnect
- uint8_t GPSSel
- uint8_t SMSSupport
- uint8_t IsVoiceEnabled
- uint8_t DHCPRelayEnabled
- uint8_t GPSLPM
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.635.1 Detailed Description

This structure contains current settings of custom features

Parameters

GpsEnable	• describes if GPS is enabled or disabled • values: – 0x00 - GPS is disabled – 0x01 - GPS is enabled • Bit to check in ParamPresenceMask - **16**
DisableIMSI	• optional 1 byte parameter • describes if IMSI display is enabled or disabled • values: – 0x00 - Allow display of IMSI – 0x01 - Do not display IMSI • Bit to check in ParamPresenceMask - **17**
IPFamSupport	• optional 2 byte BitMask • bitmask representing the IP families supported • values: – 0x01 - IPv4 – 0x02 - IPv6 – 0x04 - IPv4v6 • Bit to check in ParamPresenceMask - **18**

RMAutoConnect	• optional 1 byte parameter • QMI Mode RM Net Auto Connect Support • values: – 0x00 - Not Supported – 0x01 - Supported • Bit to check in ParamPresenceMask - **19**
GPSSel	• optional 1 byte parameter • GPS Antenna Select • values: – 0x00 - Dedicated GPS Port – 0x01 - GPS Rx over AUX Port – 0x02 - GPS Rx over dedicated GPS port with no bias voltage applied • Bit to check in ParamPresenceMask - **20**
SMSSupport	• optional 1 byte parameter • SMS support • values: – 0x00 - Not supported – 0x01 - supported • Bit to check in ParamPresenceMask - **21** • Used to determine whether or not to hide SMS from user
IsVoiceEnabled	• optional 1 byte parameter • Voice support • values: – 0x00 - Enable voice on both AT and QMI interface (default) – 0x01 - Reserved – 0x02 - Disable voice on both AT and QMI interface • Bit to check in ParamPresenceMask - **22**
DHCPRelay-Enabled	• optional 1 byte parameter • DHCP Relay support • values: – 0x00 - Disable DHCP relay – 0x01 - Enable DHCP relay • Bit to check in ParamPresenceMask - **23**
GPSLPM	• optional 1 byte parameter • GPSLPM support • values: – 0x00 - Enable GPS in Low Power Mode – 0x01 - Disable GPS in Low Power Mode • Bit to check in ParamPresenceMask - **24**

Tlvresult	• unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.635.2 Field Documentation

8.635.2.1 uint8_t unpack_dms_GetCustFeature_t::DHCPRelayEnabled

8.635.2.2 uint8_t unpack_dms_GetCustFeature_t::DisableIMSI

8.635.2.3 uint32_t unpack_dms_GetCustFeature_t::GpsEnable

8.635.2.4 uint8_t unpack_dms_GetCustFeature_t::GPSLPM

8.635.2.5 uint8_t unpack_dms_GetCustFeature_t::GPSSel

8.635.2.6 uint16_t unpack_dms_GetCustFeature_t::IPFamSupport

8.635.2.7 uint8_t unpack_dms_GetCustFeature_t::IsVoiceEnabled

8.635.2.8 swi_uint256_t unpack_dms_GetCustFeature_t::ParamPresenceMask

8.635.2.9 uint8_t unpack_dms_GetCustFeature_t::RMAutoConnect

8.635.2.10 uint8_t unpack_dms_GetCustFeature_t::SMSSupport

8.635.2.11 uint16_t unpack_dms_GetCustFeature_t::Tlvresult

8.636 unpack_dms_GetCustFeaturesV2_t Struct Reference

Data Fields

- DMSgetCustomFeatureV2 GetCustomFeatureV2
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.636.1 Detailed Description

This structure contains customization settings set to modem unpack

Parameters

GetCustom-FeatureV2	• See DMSgetCustomFeatureV2 for more information • pCustSettingInfo – Bit to check in ParamPresenceMask - **32** • pCustSettingList – Bit to check in ParamPresenceMask - **33**

Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.636.2 Field Documentation

8.636.2.1 DMSgetCustomFeatureV2 unpack_dms_GetCustFeaturesV2_t::GetCustomFeatureV2

8.636.2.2 swi_uint256_t unpack_dms_GetCustFeaturesV2_t::ParamPresenceMask

8.636.2.3 uint16_t unpack_dms_GetCustFeaturesV2_t::Tlvresult

8.637 unpack_dms_GetDeviceCap_t Struct Reference

Data Fields

- uint32_t MaxTXChannelRate
- uint32_t MaxRXChannelRate
- uint32_t DataServiceCapability
- uint32_t SimCapability
- uint32_t RadioIfacesSize
- uint8_t RadioIfaces [64]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.637.1 Detailed Description

Structure to store the device capabilities

Parameters

MaxTXChannel-Rate	• Maximum transmission rate (in bps) supported by the device • In multi-technology devices, this value will be the greatest rate among all supported technologies • Bit to check in ParamPresenceMask - **1**
MaxRXChannel-Rate	• Maximum reception rate (in bps) supported by the device • In multi-technology devices, this value will be the greatest rate among all supported technologies • Bit to check in ParamPresenceMask - **1**
DataService-Capability	• CS/PS data service capability – 0 - No data services supported – 1 - Only Circuit Switched (CS) services supported – 2 - Only Packet Switched (PS) services supported – 3 - Simultaneous CS and PS – 4 - Non-simultaneous CS and PS • Bit to check in ParamPresenceMask - **1**

SimCapability	Device SIM capability • 0 - SIM not supported • 1 - SIM supported

- Bit to check in ParamPresenceMask - **1**

Parameters

RadioIfacesSize	• Upon input, the maximum number of elements that the radio interface array can contain • Upon successful output, actual number of elements in the radio interface array • Bit to check in ParamPresenceMask - **1**
RadioIfaces	• Radio interface array. This is a structure of array containing the elements below. uint8_t RadioIfaces – See qaGobiApiTableRadioInterfaces.h for Radio Interfaces • Bit to check in ParamPresenceMask - **1**
Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.637.2 Field Documentation

8.637.2.1 uint32_t unpack_dms_GetDeviceCap_t::DataServiceCapability

8.637.2.2 uint32_t unpack_dms_GetDeviceCap_t::MaxRXChannelRate

8.637.2.3 uint32_t unpack_dms_GetDeviceCap_t::MaxTXChannelRate

8.637.2.4 swi_uint256_t unpack_dms_GetDeviceCap_t::ParamPresenceMask

8.637.2.5 uint8_t unpack_dms_GetDeviceCap_t::RadioIfaces[64]

8.637.2.6 uint32_t unpack_dms_GetDeviceCap_t::RadioIfacesSize

8.637.2.7 uint32_t unpack_dms_GetDeviceCap_t::SimCapability

8.637.2.8 uint16_t unpack_dms_GetDeviceCap_t::Tlvresult

8.638 unpack_dms_GetDeviceCapabilities_t Struct Reference

Data Fields

- uint32_t maxTxChannelRate
- uint32_t maxRxChannelRate
- uint32_t dataServiceCaCapability

- uint32_t simCapability
- uint32_t radioIfacesSize
- uint8_t RadioIfaces [255]
- swi_uint256_t ParamPresenceMask

8.638.1 Detailed Description

Gets the device capabilities structure

Parameters

maxTxChannelRate	• Maximum transmission rate (in bps) supported by the device • In multi-technology devices, this value will be the greatest rate among all supported technologies • Bit to check in ParamPresenceMask - **1**
maxRxChannelRate	• Maximum reception rate (in bps) supported by the device • In multi-technology devices, this value will be the greatest rate among all supported technologies • Bit to check in ParamPresenceMask - **1**
dataServiceCaCapability	• CS/PS data service capability – 0 - No data services supported – 1 - Only Circuit Switched (CS) services supported – 2 - Only Packet Switched (PS) services supported – 3 - Simultaneous CS and PS – 4 - Non-simultaneous CS and PS • Bit to check in ParamPresenceMask - **1**
simCapability	• Device SIM capability – 0 - SIM not supported – 1 - SIM supported • Bit to check in ParamPresenceMask - **1**
radioIfacesSize	• Upon input, the maximum number of elements that the radio interface array can contain • Upon successful output, actual number of elements in the radio interface array • Bit to check in ParamPresenceMask - **1**
RadioIfaces[OUT]	• Radio interface array. This is a structure of array containing the elements below. – See qaGobiApiTableRadioInterfaces.h for Radio Interfaces • Bit to check in ParamPresenceMask - **1**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.638.2 Field Documentation

8.638.2.1 uint32_t unpack_dms_GetDeviceCapabilities_t::dataServiceCaCapability

8.638.2.2 uint32_t unpack_dms_GetDeviceCapabilities_t::maxRxChannelRate

8.638.2.3 uint32_t unpack_dms_GetDeviceCapabilities_t::maxTxChannelRate

8.638.2.4 swi_uint256_t unpack_dms_GetDeviceCapabilities_t::ParamPresenceMask

8.638.2.5 uint8_t unpack_dms_GetDeviceCapabilities_t::RadioIfaces[255]

8.638.2.6 uint32_t unpack_dms_GetDeviceCapabilities_t::radioIfacesSize

8.638.2.7 uint32_t unpack_dms_GetDeviceCapabilities_t::simCapability

8.639 unpack_dms_GetDeviceHardwareRev_t Struct Reference

Data Fields

- uint8_t stringSize
- char String [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.639.1 Detailed Description

Structure to store the hardware revision of the device

Parameters

stringSize	• The maximum number of characters (including NULL terminator) that the string array can contain • Bit to check in ParamPresenceMask - **1**
String	• NULL terminated Hardware Revision string • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **1**
Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.639.2 Field Documentation

8.639.2.1 swi_uint256_t unpack_dms_GetDeviceHardwareRev_t::ParamPresenceMask

8.639.2.2 char unpack_dms_GetDeviceHardwareRev_t::String[255]

8.639.2.3 uint8_t unpack_dms_GetDeviceHardwareRev_t::stringSize

8.639.2.4 uint16_t unpack_dms_GetDeviceHardwareRev_t::Tlvresult

8.640 unpack_dms_GetDeviceMfr_t Struct Reference

Data Fields

- uint8_t stringSize
- char String [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.640.1 Detailed Description

This structure is used to store unpack_dms_GetDeviceMfr parameters

Parameters

stringSize	• The maximum number of characters (including NULL terminator) that the string array can contain

- Bit to check in ParamPresenceMask - **1**

Parameters

String	• NULL terminated Device Manufacture string • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **1**
Tlvresult	• unpack Tlv result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.640.2 Field Documentation

8.640.2.1 swi_uint256_t unpack_dms_GetDeviceMfr_t::ParamPresenceMask

8.640.2.2 char unpack_dms_GetDeviceMfr_t::String[255]

8.640.2.3 uint8_t unpack_dms_GetDeviceMfr_t::stringSize

8.640.2.4 uint16_t unpack_dms_GetDeviceMfr_t::Tlvresult

8.641 unpack_dms_GetDeviceSerialNumbers_t Struct Reference

Data Fields

- uint8_t esnSize

- char ESNString [255]
- uint8_t imeiSize
- char IMEIString [255]
- uint8_t meidSize
- char MEIDString [255]
- uint8_t imeiSvnSize
- char ImeiSvnString [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.641.1 Detailed Description

This structure used to store unpack_dms_GetDeviceSerialNumbers parameters

Parameters

esnSize	• The maximum number of characters (including NULL terminator) that the ESN string array can contain • Bit to check in ParamPresenceMask - **16**
ESNString	• NULL-terminated ESN string. Empty string is returned when ESN is not supported/programmed • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **16**
imeiSize	• The maximum number of characters (including NULL terminator) that the IMEI string array can contain • Bit to check in ParamPresenceMask - **17**
IMEIString	• NULL terminated IMEI string. Empty string is returned when IMEI is not supported/programmed • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **17**
meidSize	• The maximum number of characters (including NULL terminator) that the MEID string array can contain • Bit to check in ParamPresenceMask - **18**
MEIDString	• NULL-terminated MEID string. Empty string is returned when MEID is not supported/programmed • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **18**
imeiSvnSize	• The maximum number of characters (including NULL terminator) that the IMEI SVN string array can contain. • Bit to check in ParamPresenceMask - **19**

ImeiSvnString	• NULL-terminated IMEI SVN string. Empty string is returned when IMEI SVN is not supported/programmed. • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **19**
Tlvresult	• unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.641.2 Field Documentation

8.641.2.1 uint8_t unpack_dms_GetDeviceSerialNumbers_t::esnSize

8.641.2.2 char unpack_dms_GetDeviceSerialNumbers_t::ESNString[255]

8.641.2.3 uint8_t unpack_dms_GetDeviceSerialNumbers_t::imeiSize

8.641.2.4 char unpack_dms_GetDeviceSerialNumbers_t::IMEIString[255]

8.641.2.5 uint8_t unpack_dms_GetDeviceSerialNumbers_t::imeiSvnSize

8.641.2.6 char unpack_dms_GetDeviceSerialNumbers_t::ImeiSvnString[255]

8.641.2.7 uint8_t unpack_dms_GetDeviceSerialNumbers_t::meidSize

8.641.2.8 char unpack_dms_GetDeviceSerialNumbers_t::MEIDString[255]

8.641.2.9 swi_uint256_t unpack_dms_GetDeviceSerialNumbers_t::ParamPresenceMask

8.641.2.10 uint16_t unpack_dms_GetDeviceSerialNumbers_t::Tlvresult

8.642 unpack_dms_GetFirmwareInfo_t Struct Reference

Data Fields

- char modelid_str [20]
- char bootversion_str [85]
- char appversion_str [85]
- char sku_str [15]
- char packageid_str [85]
- char carrier_str [20]
- char priversion_str [16]
- char cur_carr_name [17]
- char cur_carr_rev [13]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.642.1 Detailed Description

This structure used to store unpack_dms_GetFirmwareInfo parameters

Parameters

modelid_str	- Mode ID String. • NULL-terminated Mode ID String. • Bit to check in ParamPresenceMask - **16**
bootversion_str	- Boot Version. • NULL-terminated Boot Version String. • Bit to check in ParamPresenceMask - **17**
appversion_str	- Application Version String. • NULL-terminated Application Version String. • Bit to check in ParamPresenceMask - **18**
sku_str	- SKU String. • NULL-terminated SKU String. • Bit to check in ParamPresenceMask - **19**
packageid_str	- Package ID String. • NULL-terminated Package ID String. • deprecated on EM/MC74xx(9x30) devices • Bit to check in ParamPresenceMask - **20**
carrier_str	- Carrier String. • NULL-terminated Carrier String. • Bit to check in ParamPresenceMask - **21**
priversion_str	- PRI Version String. • NULL-terminated PRI Version String. • Bit to check in ParamPresenceMask - **22**
cur_carr_name	- Current Carrier Name String. • NULL-terminated Current Carrier Name String. • Bit to check in ParamPresenceMask - **23**
cur_carr_rev	- Current Carrier Revision String. • NULL-terminated Current Carrier Revision String. • Bit to check in ParamPresenceMask - **24**
Tlvresult	- unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.642.2 Field Documentation

8.642.2.1 char unpack_dms_GetFirmwareInfo_t::appversion_str[85]

8.642.2.2 char unpack_dms_GetFirmwareInfo_t::bootversion_str[85]

8.642.2.3 char unpack_dms_GetFirmwareInfo_t::carrier_str[20]

8.642.2.4 char unpack_dms_GetFirmwareInfo_t::cur_carr_name[17]

8.642.2.5 char unpack_dms_GetFirmwareInfo_t::cur_carr_rev[13]

8.642.2.6 char unpack_dms_GetFirmwareInfo_t::modelid_str[20]

8.642.2.7 char unpack_dms_GetFirmwareInfo_t::packageid_str[85]

8.642.2.8 swi_uint256_t unpack_dms_GetFirmwareInfo_t::ParamPresenceMask

8.642.2.9 char unpack_dms_GetFirmwareInfo_t::priversion_str[16]

8.642.2.10 char unpack_dms_GetFirmwareInfo_t::sku_str[15]

8.642.2.11 uint16_t unpack_dms_GetFirmwareInfo_t::Tlvresult

8.643 unpack_dms_GetFirmwareRevision_t Struct Reference

Data Fields

- uint8_t amssSize
- char AMSSString [255]
- char PRIString [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.643.1 Detailed Description

This structure used to store unpack_dms_GetFirmwareRevision parameters

Parameters

amssSize	• Maximum number of characters (including NULL terminator) that the AMSS string array can contain. • Bit to check in ParamPresenceMask - **1**
AMSSString	• NULL-terminated AMSS revision string. • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **1**
PRIString[OUT]	• NULL-terminated PRI revision string. • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **17**
Tlvresult	• unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.643.2 Field Documentation

8.643.2.1 uint8_t unpack_dms_GetFirmwareRevision_t::amssSize

8.643.2.2 char unpack_dms_GetFirmwareRevision_t::AMSSString[255]

8.643.2.3 swi_uint256_t unpack_dms_GetFirmwareRevision_t::ParamPresenceMask

8.643.2.4 char unpack_dms_GetFirmwareRevision_t::PRIString[255]

8.643.2.5 uint16_t unpack_dms_GetFirmwareRevision_t::Tlvresult

8.644 unpack_dms_GetFirmwareRevisions_t Struct Reference

Data Fields

- uint8_t amssSize
- char AMSSString [255]
- uint8_t bootSize
- char BootString [255]
- uint8_t priSize
- char PRIString [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.644.1 Detailed Description

This structure used to store unpack_dms_GetFirmwareRevisions parameters

Parameters

amssSize	• Maximum number of characters (including NULL terminator) that the AMSS string array can contain • Bit to check in ParamPresenceMask - **1**
AMSSString	• NULL-terminated AMSS revision string • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **1**
bootSize	• Maximum number of characters (including NULL terminator) that the boot string array can contain • Bit to check in ParamPresenceMask - **16**
BootString	• NULL-terminated boot code revision string • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **16**
priSize	• Maximum number of characters (including NULL terminator) that the PRI string array can contain • Bit to check in ParamPresenceMask - **17**

PRIString	• NULL-terminated PRI revision string • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **17**
Tlvresult	• unpack Tlv Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.644.2 Field Documentation

8.644.2.1 uint8_t unpack_dms_GetFirmwareRevisions_t::amssSize

8.644.2.2 char unpack_dms_GetFirmwareRevisions_t::AMSSString[255]

8.644.2.3 uint8_t unpack_dms_GetFirmwareRevisions_t::bootSize

8.644.2.4 char unpack_dms_GetFirmwareRevisions_t::BootString[255]

8.644.2.5 swi_uint256_t unpack_dms_GetFirmwareRevisions_t::ParamPresenceMask

8.644.2.6 uint8_t unpack_dms_GetFirmwareRevisions_t::priSize

8.644.2.7 char unpack_dms_GetFirmwareRevisions_t::PRIString[255]

8.644.2.8 uint16_t unpack_dms_GetFirmwareRevisions_t::Tlvresult

8.645 unpack_dms_GetFSN_t Struct Reference

Data Fields

- char String [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.645.1 Detailed Description

This structure used to store Factory Sequence Number parameter

Parameters

String	• Facorty Sequence Number • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **1**
Tlvresult	• Unpack Result

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.645.2 Field Documentation

8.645.2.1 swi_uint256_t unpack_dms_GetFSN_t::ParamPresenceMask

8.645.2.2 char unpack_dms_GetFSN_t::String[255]

8.645.2.3 uint16_t unpack_dms_GetFSN_t::Tlvresult

8.646 unpack_dms_GetHardwareRevision_t Struct Reference

Data Fields

- char hwVer [255]
- swi_uint256_t ParamPresenceMask

8.646.1 Detailed Description

This structure used to store unpack_dms_GetHardwareRevision parameters

Parameters

hwVer	- Hardware version • NULL-terminated string • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.646.2 Field Documentation

8.646.2.1 char unpack_dms_GetHardwareRevision_t::hwVer[255]

8.646.2.2 swi_uint256_t unpack_dms_GetHardwareRevision_t::ParamPresenceMask

8.647 unpack_dms_GetIMSI_t Struct Reference

Data Fields

- char imsi [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.647.1 Detailed Description

This structure used to store unpack_dms_GetIMSI parameters

Parameters

imsi	- IMSI no. • NULL-terminated String. • Bit to check in ParamPresenceMask - **1**
Tlvresult	- unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.647.2 Field Documentation

8.647.2.1 char unpack_dms_GetIMSI_t::imsi[255]

8.647.2.2 swi_uint256_t unpack_dms_GetIMSI_t::ParamPresenceMask

8.647.2.3 uint16_t unpack_dms_GetIMSI_t::Tlvresult

8.648 unpack_dms_GetManufacturer_t Struct Reference

Data Fields

- char manufacturer [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.648.1 Detailed Description

This structure is used to store device manufacturer information.

Parameters

manufacturer[O-UT]	• NULL terminated string • Bit to check in ParamPresenceMask - **1**
Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.648.2 Field Documentation

8.648.2.1 char unpack_dms_GetManufacturer_t::manufacturer[255]

8.648.2.2 swi_uint256_t unpack_dms_GetManufacturer_t::ParamPresenceMask

8.648.2.3 uint16_t unpack_dms_GetManufacturer_t::Tlvresult

8.649 unpack_dms_GetModelID_t Struct Reference

Data Fields

- char modelid [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.649.1 Detailed Description

This structure used to store unpack_dms_GetModelID parameters

Parameters

modelid	- Device model id. • NULL-terminated String. • Bit to check in ParamPresenceMask - **1**
Tlvresult	- unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.649.2 Field Documentation

8.649.2.1 char unpack_dms_GetModelID_t::modelid[255]

8.649.2.2 swi_uint256_t unpack_dms_GetModelID_t::ParamPresenceMask

8.649.2.3 uint16_t unpack_dms_GetModelID_t::Tlvresult

8.650 unpack_dms_GetNetworkTime_t Struct Reference

Data Fields

- uint16_t source
- uint64_t timestamp
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.650.1 Detailed Description

This structure used to store unpack_dms_GetNetworkTime parameters

Parameters

source	• Source of timestamp 0 - 32 kHz device clock 1 - CDMA network 2 - cdma2000 1xEV-DO network • Bit to check in ParamPresenceMask - **1**

timestamp	• Count of 1.25 ms that have elapsed from the start of GPS time (Jan 6, 1980) • Bit to check in ParamPresenceMask - **1**
TlvResult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

Note

The source of the timestamp provided specifies how the timestamp was determined. The first network time that is available will be returned. If no network time is available, the timestamp is taken from the 32 kHz slow-clock of the device.

8.650.2 Field Documentation

8.650.2.1 swi_uint256_t unpack_dms_GetNetworkTime_t::ParamPresenceMask

8.650.2.2 uint16_t unpack_dms_GetNetworkTime_t::source

8.650.2.3 uint64_t unpack_dms_GetNetworkTime_t::timestamp

8.650.2.4 uint16_t unpack_dms_GetNetworkTime_t::TlvResult

8.651 unpack_dms_GetOfflineReason_t Struct Reference

Data Fields

- uint32_t * pReasonMask
- uint32_t * pbPlatform
- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.651.1 Detailed Description

This structure is used to store reason why the operating mode of the device is currently offline.

Parameters

pReasonMask[-OUT]	• Optional parameter • Bitmask of offline reasons – 0x00000001 - Host image configuration issue – 0x00000002 - PRI image configuration issue – 0x00000004 - PRI version incompatible – 0x00000008 - PRI copy issue – All others - Reserved • Bit to check in ParamPresenceMask - **16**

pbPlatform[OUT]	• Optional parameter • Is the device offline due to a platform restriction? – 0 - No – 1 - Yes • Bit to check in ParamPresenceMask - **17**
Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.651.2 Field Documentation

8.651.2.1 swi_uint256_t unpack_dms_GetOfflineReason_t::ParamPresenceMask

8.651.2.2 uint32_t* unpack_dms_GetOfflineReason_t::pbPlatform

8.651.2.3 uint32_t* unpack_dms_GetOfflineReason_t::pReasonMask

8.651.2.4 uint16_t unpack_dms_GetOfflineReason_t::Tlvresult

8.652 unpack_dms_GetPower_t Struct Reference

Data Fields

- uint32_t OperationMode
- uint32_t OfflineReason
- uint32_t HardwareControlledMode
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.652.1 Detailed Description

This structure used to store unpack_dms_GetPower parameters

Parameters

OperationMode	- operating mode. • 0 - Online (default). • 1 - Low power (airplane) mode. • 2 - Factory test mode. • 3 - Offline. • 4 - Resetting. • 5 - Power off. • 6 - Persistent low power (airplane) mode. • 7 - Mode - only low power. • Bit to check in ParamPresenceMask - **1**

Note

Valid transitions for Power Modes

- Online to Low Power, Persistent low power, Factory test, Offline or Shut Down
- Low power to online, Persistent low power, Offline, or Shut Down
- Persistent low power to Online, Low power, Offline or Shut down
- Factory test to online
- Offline to Reset

Parameters

OfflineReason	- offline reason. • 0x0001 - Host image misconfiguration. • 0x0002 - PRI image misconfiguration. • 0x0004 - PRI version incompatible. • 0x0008 - Device memory is full,cannot copy PRI information. • Bit to check in ParamPresenceMask - **16**
Hardware-ControlledMode	- hardware restricted mode. • 0x00 - FALSE. • 0x01 - TRUE. • Bit to check in ParamPresenceMask - **17**
Tlvresult	- unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.652.2 Field Documentation

8.652.2.1 uint32_t unpack_dms_GetPower_t::HardwareControlledMode

8.652.2.2 uint32_t unpack_dms_GetPower_t::OfflineReason

8.652.2.3 uint32_t unpack_dms_GetPower_t::OperationMode

8.652.2.4 swi_uint256_t unpack_dms_GetPower_t::ParamPresenceMask

8.652.2.5 uint16_t unpack_dms_GetPower_t::Tlvresult

8.653 unpack_dms_GetPRLVersion_t Struct Reference

Data Fields

- uint8_t u8PRLPreference
- uint16_t u16PRLVersion
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.653.1 Detailed Description

This structure used to store unpack_dms_GetPRLVersion parameters

Parameters

u8PRL-Preference	• PRL Preference – 0 - Unset – 1 - Set • Bit to check in ParamPresenceMask - **17**
u16PRLVersion	• PRL version of device. • Bit to check in ParamPresenceMask - **16**
Tlvresult	• unpack Tlv Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.653.2 Field Documentation

8.653.2.1 swi_uint256_t unpack_dms_GetPRLVersion_t::ParamPresenceMask

8.653.2.2 uint16_t unpack_dms_GetPRLVersion_t::Tlvresult

8.653.2.3 uint16_t unpack_dms_GetPRLVersion_t::u16PRLVersion

8.653.2.4 uint8_t unpack_dms_GetPRLVersion_t::u8PRLPreference

8.654 unpack_dms_GetSerialNumbers_t Struct Reference

Data Fields

- char esn [255]
- char imei_no [255]
- char meid [255]
- char imeisv_svn [255]
- swi_uint256_t ParamPresenceMask

8.654.1 Detailed Description

This structure used to store unpack_dms_GetSerialNumbers parameters

Parameters

esn	- Electronic Serial Number of the device. • NULL-terminated ESN string. Empty string is returned when ESN is not supported/programmed. • Bit to check in ParamPresenceMask - **16**
imei_no	- International Mobile Equipment Identity of the device. • NULL terminated IMEI string. Empty string is returned when IMEI is not supported/programmed. • Bit to check in ParamPresenceMask - **17**

meid	- Mobile Equipment Identifier of the device. • NULL-terminated MEID string. Empty string is returned when MEID is not supported/programmed. • Bit to check in ParamPresenceMask - **18**
imeisv_svn	- NULL-terminated IMEI SVN string. Empty string is returned when IMEI SVN is not supported/programmed.imei software version revision. • Bit to check in ParamPresenceMask - **19**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.654.2 Field Documentation

8.654.2.1 char unpack_dms_GetSerialNumbers_t::esn[255]

8.654.2.2 char unpack_dms_GetSerialNumbers_t::imei_no[255]

8.654.2.3 char unpack_dms_GetSerialNumbers_t::imeisv_svn[255]

8.654.2.4 char unpack_dms_GetSerialNumbers_t::meid[255]

8.654.2.5 swi_uint256_t unpack_dms_GetSerialNumbers_t::ParamPresenceMask

8.655 unpack_dms_GetUSBComp_t Struct Reference

Data Fields

- uint8_t USBComp [255]
- uint8_t NumSupUSBComps
- uint8_t SupUSBComps
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.655.1 Detailed Description

This structure is used to store retrieved USB Composition

Parameters

USBComp	• Current USB Composition(optional parameter) • Values: – 0..5 - Reserved (non-QMI) – 6 - DM NMEA AT QMI – 7 - DM NMEA AT QMI1 QMI2 QMI3 – 8 - DM NMEA AT MBIM – 9 - MBIM – 10 - NMEA MBIM – 11 - DM MBIM – 12 - DM NMEA MBIM 13-22 are combined compositions. One is for Win8 MBIM interfaces, another is for legacy QMI interfaces – 13 - 6 for QMI, 8 for MBIM – 14 - 6 for QMI, 9 for MBIM – 15 - 6 for QMI, 10 for MBIM – 16 - 6 for QMI, 11 for MBIM – 17 - 6 for QMI, 12 for MBIM – 18 - 7 for QMI, 8 for MBIM – 19 - 7 for QMI, 9 for MBIM – 20 - 7 for QMI, 10 for MBIM – 21 - 7 for QMI, 11 for MBIM – 22 - 7 for QMI, 12 for MBIM • Bit to check in ParamPresenceMask - **16**
NumSupUSB-Comps	• Number of supported USB compositions in the parameter to follow • Range - 0-255 • Bit to check in ParamPresenceMask - **17**

SupUSBComps	• Optional parameter • List of supported USB compositions(1 Byte each - Max 255) • Total length is defined by pNumSupUSBComps parameter • Values: – 0..5 - Reserved (non-QMI) – 6 - DM NMEA AT QMI – 7 - DM NMEA AT QMI1 QMI2 QMI3 – 8 - DM NMEA AT MBIM – 9 - MBIM – 10 - NMEA MBIM – 11 - DM MBIM – 12 - DM NMEA MBIM 13-22 are combined compositions. One is for Win8 MBIM interfaces, another is for legacy QMI interfaces – 13 - 6 for QMI, 8 for MBIM – 14 - 6 for QMI, 9 for MBIM – 15 - 6 for QMI, 10 for MBIM – 16 - 6 for QMI, 11 for MBIM – 17 - 6 for QMI, 12 for MBIM – 18 - 7 for QMI, 8 for MBIM – 19 - 7 for QMI, 9 for MBIM – 20 - 7 for QMI, 10 for MBIM – 21 - 7 for QMI, 11 for MBIM – 22 - 7 for QMI, 12 for MBIM • Bit to check in ParamPresenceMask - **17**
Tlvresult	• unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.655.2 Field Documentation

8.655.2.1 uint8_t unpack_dms_GetUSBComp_t::NumSupUSBComps

8.655.2.2 swi_uint256_t unpack_dms_GetUSBComp_t::ParamPresenceMask

8.655.2.3 uint8_t unpack_dms_GetUSBComp_t::SupUSBComps

8.655.2.4 uint16_t unpack_dms_GetUSBComp_t::Tlvresult

8.655.2.5 uint8_t unpack_dms_GetUSBComp_t::USBComp[255]

8.656 unpack_dms_GetVoiceNumber_t Struct Reference

Data Fields

- uint8_t voiceNumberSize

- char VoiceNumber [255]
- uint8_t minSize
- char MIN [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.656.1 Detailed Description

Structure to store the voice number in use by the device

Parameters

voiceNumber-Size	• Maximum number of characters (including NULL terminator) that the voice number array can contain. • Bit to check in ParamPresenceMask - **1**
VoiceNumber	• Voice number string: MDN or MS ISDN • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **1**
minSize	• Maximum number of characters (including NULL terminator) that the MIN array can contain. • Bit to check in ParamPresenceMask - **16**
MIN	• Optional Parameter • MIN string: Empty string returned when MIN is not supported/ programmed. • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **16**
Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.656.2 Field Documentation

8.656.2.1 char unpack_dms_GetVoiceNumber_t::MIN[255]

8.656.2.2 uint8_t unpack_dms_GetVoiceNumber_t::minSize

8.656.2.3 swi_uint256_t unpack_dms_GetVoiceNumber_t::ParamPresenceMask

8.656.2.4 uint16_t unpack_dms_GetVoiceNumber_t::Tlvresult

8.656.2.5 char unpack_dms_GetVoiceNumber_t::VoiceNumber[255]

8.656.2.6 uint8_t unpack_dms_GetVoiceNumber_t::voiceNumberSize

8.657 unpack_dms_PSMCfgChange_ind_t Struct Reference

Data Fields

- dms_PSMEnableStateIndTlv EnableState
- dms_PSMActiveTimerIndTlv ActiveTimer
- dms_PSMPeriodicUpdateTimerIndTlv PeriodicUpdateTimer
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.657.1 Detailed Description

DMS Event Report indication structure

Parameters

EnableState	• See dms_PSMEnableStateIndTlv • Bit to check in ParamPresenceMask - **16**
ActiveTimer	• See dms_PSMActiveTimerIndTlv • Bit to check in ParamPresenceMask - **17**
PeriodicUpdate-Timer	• See dms_PSMPeriodicUpdateTimerIndTlv • Bit to check in ParamPresenceMask - **18**
Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.657.2 Field Documentation

8.657.2.1 dms_PSMActiveTimerIndTlv unpack_dms_PSMCfgChange_ind_t::ActiveTimer

8.657.2.2 dms_PSMEnableStateIndTlv unpack_dms_PSMCfgChange_ind_t::EnableState

8.657.2.3 swi_uint256_t unpack_dms_PSMCfgChange_ind_t::ParamPresenceMask

8.657.2.4 dms_PSMPeriodicUpdateTimerIndTlv unpack_dms_PSMCfgChange_ind_t::PeriodicUpdateTimer

8.657.2.5 uint16_t unpack_dms_PSMCfgChange_ind_t::Tlvresult

8.658 unpack_dms_ResetToFactoryDefaults_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.658.1 Detailed Description

This structure contains reset to factory default unpack

Parameters

Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.658.2 Field Documentation

8.658.2.1 swi_uint256_t unpack_dms_ResetToFactoryDefaults_t::ParamPresenceMask

8.658.2.2 uint16_t unpack_dms_ResetToFactoryDefaults_t::Tlvresult

8.659 unpack_dms_SetActivationStatusCallback_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.659.1 Detailed Description

This structure is used to store Set Service Activation Status callback parameter unpack.

Parameters

Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.659.2 Field Documentation

8.659.2.1 swi_uint256_t unpack_dms_SetActivationStatusCallback_t::ParamPresenceMask

8.659.2.2 uint16_t unpack_dms_SetActivationStatusCallback_t::Tlvresult

8.660 unpack_dms_SetCrashAction_t Struct Reference

Data Fields

- uint8_t notused
- swi_uint256_t ParamPresenceMask

8.660.1 Detailed Description

This structure is used to store unpack_dms_SetCrashAction parameters

Parameters

notused	• unpack Tlv result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.660.2 Field Documentation

8.660.2.1 uint8_t unpack_dms_SetCrashAction_t::notused

8.660.2.2 swi_uint256_t unpack_dms_SetCrashAction_t::ParamPresenceMask

8.661 unpack_dms_SetCustFeature_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.661.1 Detailed Description

This structure is used to store unpack_dms_SetCustFeature parameters

Parameters

Tlvresult	• unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.661.2 Field Documentation

8.661.2.1 swi_uint256_t unpack_dms_SetCustFeature_t::ParamPresenceMask

8.661.2.2 uint16_t unpack_dms_SetCustFeature_t::Tlvresult

8.662 unpack_dms_SetCustFeaturesV2_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.662.1 Detailed Description

This structure contains customization settings set to modem unpack

Parameters

Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.662.2 Field Documentation

8.662.2.1 swi_uint256_t unpack_dms_SetCustFeaturesV2_t::ParamPresenceMask

8.662.2.2 uint16_t unpack_dms_SetCustFeaturesV2_t::Tlvresult

8.663 unpack_dms_SetEventReport_ind_t Struct Reference

Data Fields

- dms_ActivationStatusTlv ActivationStatusTlv
- dms_OperatingModeTlv OperatingModeTlv
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.663.1 Detailed Description

DMS Event Report indication structure

Parameters

ActivationStatus-Tlv	• See dms_ActivationStatusTlv • Bit to check in ParamPresenceMask - **19**
OperatingMode-Tlv	• See dms_OperatingModeTlv • Bit to check in ParamPresenceMask - **20**
Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.663.2 Field Documentation

8.663.2.1 dms_ActivationStatusTlv unpack_dms_SetEventReport_ind_t::ActivationStatusTlv

8.663.2.2 dms_OperatingModeTlv unpack_dms_SetEventReport_ind_t::OperatingModeTlv

8.663.2.3 swi_uint256_t unpack_dms_SetEventReport_ind_t::ParamPresenceMask

8.663.2.4 uint16_t unpack_dms_SetEventReport_ind_t::Tlvresult

8.664 unpack_dms_SetEventReport_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.664.1 Detailed Description

This structure is used to store unpack_dms_SetEventReport parameters.

Parameters

Tlvresult	• unpack Tlv result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.664.2 Field Documentation

8.664.2.1 swi_uint256_t unpack_dms_SetEventReport_t::ParamPresenceMask

8.664.2.2 uint16_t unpack_dms_SetEventReport_t::Tlvresult

8.665 unpack_dms_SetFirmwarePreference_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.665.1 Detailed Description

This structure is used to store unpack_dms_SetFirmwarePreference parameters

Parameters

Tlvresult	• unpack Tlv result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.665.2 Field Documentation

8.665.2.1 swi_uint256_t unpack_dms_SetFirmwarePreference_t::ParamPresenceMask

8.665.2.2 uint16_t unpack_dms_SetFirmwarePreference_t::Tlvresult

8.666 unpack_dms_SetIndicationRegister_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.666.1 Detailed Description

This structure is used to store unpack_dms_SetIndicationRegister parameters.

Parameters

Tlvresult	• unpack Tlv result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.666.2 Field Documentation

8.666.2.1 swi_uint256_t unpack_dms_SetIndicationRegister_t::ParamPresenceMask

8.666.2.2 uint16_t unpack_dms_SetIndicationRegister_t::Tlvresult

8.667 unpack_dms_SetPower_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.667.1 Detailed Description

Structure to store unpack the operating mode of the device.

Parameters

Tlvresult	• unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.667.2 Field Documentation

8.667.2.1 swi_uint256_t unpack_dms_SetPower_t::ParamPresenceMask

8.667.2.2 uint16_t unpack_dms_SetPower_t::Tlvresult

8.668 unpack_dms_SetUSBComp_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.668.1 Detailed Description

This structure is used to store unpack USB composition information

Parameters

Tlvresult	• unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.668.2 Field Documentation

8.668.2.1 swi_uint256_t unpack_dms_SetUSBComp_t::ParamPresenceMask

8.668.2.2 uint16_t unpack_dms_SetUSBComp_t::Tlvresult

8.669 unpack_dms_SLQSDmsSwiGetPCInfo_t Struct Reference

Data Fields

- uint8_t opMode
- int has_LpmFlag
- uint32_t LpmFlag
- int has_Wdisable
- uint8_t Wdisable
- int has_PowerOffMode
- uint8_t PowerOffMode
- int has_PersistentLpm
- uint8_t PersistentLpm
- swi_uint256_t ParamPresenceMask

8.669.1 Detailed Description

This structure contains the TLV required to Get device power control status information.

Parameters

opMode	• Selected operating mode. • Values – 0 - Online – 1 - Low power – 2 - Factory Test mode – 3 - Offline – 4 - Resetting – 5 - Shutting down – 6 - Persistent low power – 8 - Conducting network test for GSM/WCDMA • Bit to check in ParamPresenceMask - **1**
has_LpmFlag	LPM Flag Availability. • 0 : Unavailable. • 1 : Available.

• Bit to check in ParamPresenceMask - **16**

Parameters

LpmFlag[-Optional]	• LPM Force Flags • Bitmask – bit0 - Tracks the state of W_DISABLE TLV, indicating state of the W_DISABLE switch. – bit1 - Set if LPM is requested by a host request, such as AT command, QMI or MBIM request. Cleared by a host request to return to online mode. Also set when the device is cold or warm booted in persistent LPM. – bit2 - Set when the device temperature is outside the valid operating range. Cleared if the temperature returns to the normal range. – bit3 - Set when the device voltage is outside the valid operating range. Cleared if the voltage returns to the normal range. – bit4 - Set on power up when BIOS locking is enabled. Cleared when the host has disabled the BIOS lock. – bit5 - Set if the current device configuration does not match the GOBI image preference. – bit6-31 - Additional LPM causes may be added to future products. • Bit to check in ParamPresenceMask - **16**
has_Wdisable	W-Disable Availability. • 0 : Unavailable. • 1 : Available.

• Bit to check in ParamPresenceMask - **17**

Parameters

Wdisable[-Optional]	• W_DISABLE • Values – 0 - Switch set to ON position – 1 - Switch set to OFF position • Bit to check in ParamPresenceMask - **17**
has_PowerOff-Mode	Power off mode Availability. • 0 : Unavailable. • 1 : Available.

• Bit to check in ParamPresenceMask - **18**

Parameters

PowerOffMode[-Optional]	• Power-off Mode • Action taken when W_DISABLE is switched to the OFF position – 0 - LPM – 1 - Shutdown – 2 - Ignore • Bit to check in ParamPresenceMask - **18**
has_Persistent-Lpm	Persistent LPM Availability. • 0 : Unavailable. • 1 : Available.

• Bit to check in ParamPresenceMask - **19**

Parameters

PersistentLpm[-Optional]	• LPM Persistence • Values – 0 - Non-persistent LPM – 1 - Persistent LPM • Bit to check in ParamPresenceMask - **19**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.669.2 Field Documentation

8.669.2.1 int unpack_dms_SLQSDmsSwiGetPCInfo_t::has_LpmFlag

8.669.2.2 int unpack_dms_SLQSDmsSwiGetPCInfo_t::has_PersistentLpm

8.669.2.3 int unpack_dms_SLQSDmsSwiGetPCInfo_t::has_PowerOffMode

8.669.2.4 int unpack_dms_SLQSDmsSwiGetPCInfo_t::has_Wdisable

8.669.2.5 uint32_t unpack_dms_SLQSDmsSwiGetPCInfo_t::LpmFlag

8.669.2.6 uint8_t unpack_dms_SLQSDmsSwiGetPCInfo_t::opMode

8.669.2.7 swi_uint256_t unpack_dms_SLQSDmsSwiGetPCInfo_t::ParamPresenceMask

8.669.2.8 uint8_t unpack_dms_SLQSDmsSwiGetPCInfo_t::PersistentLpm

8.669.2.9 uint8_t unpack_dms_SLQSDmsSwiGetPCInfo_t::PowerOffMode

8.669.2.10 uint8_t unpack_dms_SLQSDmsSwiGetPCInfo_t::Wdisable

8.670 unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t Struct Reference

Data Fields

- uint8_t type
- uint8_t source
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.670.1 Detailed Description

This structure contains the TLV required to Get Reset Info.

Parameters

type[OUT]	• type of reset or power down, possible values listed below: – 0 - unknown – 1 - warm – 2 - hard – 3 - crash – 4 - power down • Bit to check in ParamPresenceMask - **1**
source[OUT]	• entity which initiated the reset or power down, possible values listed below: – 0 - unknown – 1 - user requested (AT!RESET, AT!BOOTHOLD, FW/PRI download - including host-initiated image switching) – 2 - hardware switch (W_DISABLE) – 3 - temperature critical – 4 - voltage critical – 5 - configuration update (SIM-based image switching, RMA reset, NVUPs which request a reset) – 6 - LWM2M (Light Weight M2M client (internal process for LWM2M)) – 7 - OMA-DM – 8 - FOTA

- Bit to check in ParamPresenceMask - **1**

Parameters

Tlvresult[OUT]	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.670.2 Field Documentation

8.670.2.1 swi_uint256_t unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t::ParamPresenceMask

8.670.2.2 uint8_t unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t::source

8.670.2.3 uint16_t unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t::Tlvresult

8.670.2.4 uint8_t unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t::type

8.671 unpack_dms_SLQSDmsSwiGetResetInfo_t Struct Reference

Data Fields

- uint8_t type
- uint8_t source
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.671.1 Detailed Description

This structure contains the TLV required to Get Reset Info.

Parameters

type[OUT]	• type of reset or power down, possible values listed below: – 0 - unknown – 1 - warm – 2 - hard – 3 - crash – 4 - power down • Bit to check in ParamPresenceMask - **1**

source[OUT]	• entity which initiated the reset or power down, possible values listed below: – 0 - unknown – 1 - user requested (AT!RESET, AT!BOOTHOLD, FW/PRI download - including host-initiated image switching) – 2 - hardware switch (W_DISABLE) – 3 - temperature critical – 4 - voltage critical – 5 - configuration update (SIM-based image switching, RMA reset, NVUPs which request a reset) – 6 - LWM2M (Light Weight M2M client (internal process for LWM2M)) – 7 - OMA-DM – 8 - FOTA

- Bit to check in ParamPresenceMask - **1**

Parameters

Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.671.2 Field Documentation

8.671.2.1 swi_uint256_t unpack_dms_SLQSDmsSwiGetResetInfo_t::ParamPresenceMask

8.671.2.2 uint8_t unpack_dms_SLQSDmsSwiGetResetInfo_t::source

8.671.2.3 uint16_t unpack_dms_SLQSDmsSwiGetResetInfo_t::Tlvresult

8.671.2.4 uint8_t unpack_dms_SLQSDmsSwiGetResetInfo_t::type

8.672 unpack_dms_SLQSDmsSwiGetUimSelection_t Struct Reference

Data Fields

- uint8_t uimSelect
- dms_UimAutoSwitchActSlotTlv * pUimAutoSwitchActSlot
- swi_uint256_t ParamPresenceMask

8.672.1 Detailed Description

Structure contains the TLV required to Get currently selected active UIM slot.

Parameters

uimSelect	• Active selected UIM slot • Values – 0 - slot 1 (e.g. external SIM) – 1 - slot 2 (e.g. embedded SIM) – 2 - remote SIM (if supported) – 3 - SIM auto-switch activated

- Bit to check in ParamPresenceMask - **1**

Parameters

pUimAuto-SwitchActSlot	• UIM Auto Switch Active slot • see dms_UimAutoSwitchActSlotTlv for more information • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

Note

: None

8.672.2 Field Documentation

8.672.2.1 swi_uint256_t unpack_dms_SLQSDmsSwiGetUimSelection_t::ParamPresenceMask

8.672.2.2 dms_UimAutoSwitchActSlotTlv* unpack_dms_SLQSDmsSwiGetUimSelection_t::pUimAutoSwitchActSlot

8.672.2.3 uint8_t unpack_dms_SLQSDmsSwiGetUimSelection_t::uimSelect

8.673 unpack_dms_SLQSDmsSwiIndicationRegister_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.673.1 Detailed Description

This structure contains set registration state for different indication unpack

Parameters

Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.673.2 Field Documentation

8.673.2.1 swi_uint256_t unpack_dms_SLQSDmsSwiIndicationRegister_t::ParamPresenceMask

8.673.2.2 uint16_t unpack_dms_SLQSDmsSwiIndicationRegister_t::TlvResult

8.674 unpack_dms_SLQSGetBandCapability_t Struct Reference

Data Fields

- uint64_t bandCapability
- int is_LteBandCapability_Available
- uint64_t LteBandCapability
- int is_TdsBandCapability_Available
- uint64_t TdsBandCapability
- swi_uint256_t ParamPresenceMask

8.674.1 Detailed Description

This structure contains the Band Capabilities response.

Please check is_<Param_Name>_Available field for presence of optional parameters

Parameters

bandCapability[-OUT]	Bitmask of bands supported by the device • Bit 0 - Band class 0, A-system • Bit 1 - Band class 0, B-system • Bit 2 - Band class 1, all blocks • Bit 3 - Band class 2 • Bit 4 - Band class 3, A-system • Bit 5 - Band class 4, all blocks • Bit 6 - Band class 5, all blocks • Bit 7 - GSM DCS band (1800) • Bit 8 - GSM Extended GSM (E-GSM) band (900) • Bit 9 - GSM Primary GSM (P-GSM) band (900) • Bit 10 - Band class 6 • Bit 11 - Band class 7 • Bit 12 - Band class 8 • Bit 13 - Band class 9 • Bit 14 - Band class 10 • Bit 15 - Band class 11 • Bit 16 - GSM 450 band • Bit 17 - GSM 480 band • Bit 18 - GSM 750 band • Bit 19 - GSM 850 band • Bit 20 - GSM railways GSM band (900) • Bit 21 - GSM PCS band (1900) • Bit 22 - WCDMA (Europe, Japan, and China) 2100 band • Bit 23 - WCDMA US PCS 1900 band • Bit 24 - WCDMA (Europe and China) DCS 1800 band • Bit 25 - WCDMA US 1700 band • Bit 26 - WCDMA US 850 band • Bit 27 - WCDMA Japan 800 band • Bit 28 - Band class 12 • Bit 29 - Band class 14 • Bit 30 - Reserved • Bit 31 - Band class 15 • Bits 32 through 47 - Reserved • Bit 48 - WCDMA Europe 2600 band • Bit 49 - WCDMA Europe and Japan 900 band • Bit 50 - WCDMA Japan 1700 band • Bits 51 through 55 - Reserved • Bit 56 - Band class 16 • Bit 57 - Band class 17 • Bit 58 - Band class 18 • Bit 59 - Band class 19 • Bit 60 - WCDMA Japan 850 band • Bit 61 - WCDMA 1500 band • Bits 62 and 63 - Reserved • Bit to check in ParamPresenceMask - **1**

is_LteBand-Capability_-Available[OUT]	LTE Band Capabilities Availability. • 0 : Unavailable. • 1 : Available. • Bit to check in ParamPresenceMask - **16**

LteBand-Capability[OUT]	Bitmask of LTE bands supported by the device • Bit 0 - LTE EUTRAN Band 1 UL:1920-1980; DL: 2110-2170 • Bit 1 - LTE EUTRAN Band 2 UL:1850-1910; DL: 1930-1990 • Bit 2 - LTE EUTRAN Band 3 UL:1710-1785; DL: 1805-1880 • Bit 3 - LTE EUTRAN Band 4 UL:1710-1755; DL: 2110-2155 • Bit 4 - LTE EUTRAN Band 5 UL: 824-849; DL: 869-894 • Bit 5 - LTE EUTRAN Band 6 UL: 830-840; DL: 875-885 • Bit 6 - LTE EUTRAN Band 7 UL:2500-2570; DL: 2620-2690 • Bit 7 - LTE EUTRAN Band 8 UL: 880-915; DL: 925-960 • Bit 8 - LTE EUTRAN Band 9 UL:1749.9-1784.9; DL: 1844.9-1879.9 • Bit 9 - LTE EUTRAN Band 10 UL:1710-1770; DL: 2110-2170 • Bit 10 - LTE EUTRAN Band 11 UL:1427.9-1452.9; DL: 1475.9-1500.9 • Bit 11 - LTE EUTRAN Band 12 UL:698-716; DL: 728-746 • Bit 12 - LTE EUTRAN Band 13 UL: 777-787; DL: 746-756 • Bit 13 - LTE EUTRAN Band 14 UL: 788-798; DL: 758-768 • Bits 14 and 15 - Reserved • Bit 16 - LTE EUTRAN Band 17 UL: 704-716; DL: 734-746 • Bit 17 - LTE EUTRAN Band 18 UL: 815-830; DL: 860-875 • Bit 18 - LTE EUTRAN Band 19 UL: 830-845; DL: 875-890 • Bit 19 - LTE EUTRAN Band 20 UL: 832-862; DL: 791-821 • Bit 20 - LTE EUTRAN Band 21 UL: 1447.9-1462.9; DL: 1495.9-1510.9 • Bit 21 - Reserved • Bit 22 - LTE EUTRAN Band 23 UL: 2000-2020; DL: 2180-2200 • Bit 23 - LTE EUTRAN Band 24 UL: 1626.5-1660.5; DL: 1525-1559 • Bit 24 - LTE EUTRAN Band 25 UL: 1850-1915; DL: 1930-1995 • Bit 25 - LTE EUTRAN Band 26 UL: 814-849; DL: 859-894 • Bit 26 - Reserved • Bit 27 - LTE EUTRAN Band 28 UL: 703-748; DL: 758-803 • Bit 28 - LTE EUTRAN Band 29 UL: 1850-1910 or 1710-1755; DL: 716-728 • Bit 29 - LTE EUTRAN Band 30 UL: 2350-2360; DL: 2305-2315 • Bit 30 - Reserved • Bit 31 - LTE EUTRAN Band 32 DL: 9920-10359 • Bit 32 - LTE EUTRAN Band 33 UL: 1900-1920; DL: 1900-1920 • Bit 33 - LTE EUTRAN Band 34 UL: 2010-2025; DL: 2010-2025 • Bit 34 - LTE EUTRAN Band 35 UL: 1850-1910; DL: 1850-1910 • Bit 35 - LTE EUTRAN Band 36 UL: 1930-1990; DL: 1930-1990 • Bit 36 - LTE EUTRAN Band 37 UL: 1910-1930; DL: 1910-1930 • Bit 37 - LTE EUTRAN Band 38 UL: 2570-2620; DL: 2570-2620 • Bit 38 - LTE EUTRAN Band 39 UL: 1880-1920; DL: 1880-1920 • Bit 39 - LTE EUTRAN Band 40 UL: 2300-2400; DL: 2300-2400 • Bit 40 - LTE EUTRAN Band 41 UL: 2496-2690; DL: 2496-2690 • Bit 41 - LTE EUTRAN Band 42 UL: 3400-3600; DL: 3400-3600 • Bit 42 - LTE EUTRAN Band 43 UL: 3600-3800; DL: 3600-3800 • Bits 43 through 64 - Reserved • Bit to check in ParamPresenceMask - **16**

is_TdsBand-Capability_-Available[OUT]	TDS Band Capabilities Availability. • 0 : Unavailable. • 1 : Available. • Bit to check in ParamPresenceMask - **17**
TdsBand-Capability[OUT]	Bitmask of TDS bands supported by the device. • Bit 0 - TDS Band A 1900 to 1920 MHz, 2010 to 2020 MHz • Bit 1 - TDS Band B 1850 to 1910 MHz, 1930 to 1990 MHz • Bit 2 - TDS Band C 1910 to 1930 MHz • Bit 3 - TDS Band D 2570 to 2620 MHz • Bit 4 - TDS Band E 2300 to 2400 MHz • Bit 5 - TDS Band F 1880 to 1920 MHz • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.674.2 Field Documentation

8.674.2.1 uint64_t unpack_dms_SLQSGetBandCapability_t::bandCapability

8.674.2.2 int unpack_dms_SLQSGetBandCapability_t::is_LteBandCapability_Available

8.674.2.3 int unpack_dms_SLQSGetBandCapability_t::is_TdsBandCapability_Available

8.674.2.4 uint64_t unpack_dms_SLQSGetBandCapability_t::LteBandCapability

8.674.2.5 swi_uint256_t unpack_dms_SLQSGetBandCapability_t::ParamPresenceMask

8.674.2.6 uint64_t unpack_dms_SLQSGetBandCapability_t::TdsBandCapability

8.675 unpack_dms_SLQSGetERIFile_t Struct Reference

Data Fields

- eriDataparams eriFile
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.675.1 Detailed Description

This structure contains Get ERI file unpack

Parameters

eriFile	• Pointer to structure ERIFileparams • See eriDataparams for more information • Bit to check in ParamPresenceMask - **1**

Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.675.2 Field Documentation

8.675.2.1 eriDataparams unpack_dms_SLQSGetERIFile_t::eriFile

8.675.2.2 swi_uint256_t unpack_dms_SLQSGetERIFile_t::ParamPresenceMask

8.675.2.3 uint16_t unpack_dms_SLQSGetERIFile_t::Tlvresult

8.676 unpack_dms_SLQSGetPowerSaveModeConfig_t Struct Reference

Data Fields

- dms_PSMEnableStateTlv * pPsmEnableState
- dms_PSMDurationThresholdTlv * pDurationThreshold
- dms_PSMDurationDueToOOSTlv * pDurationDueToOOS
- dms_PSMRandomizationWindowTlv * pRandomizationWindow
- dms_PSMActiveTimerTlv * pActiveTimer
- dms_PSMPeriodicUpdateTimerTlv * pPeriodicUpdateTimer
- dms_PSMEarlyWakeupTimeTlv * pEarlyWakeupTime
- swi_uint256_t ParamPresenceMask

8.676.1 Detailed Description

This structure contains the Power Save Mode (PSM) configuration parameter.

Parameters

pPsmEnable-State	[Optional] • See dms_PSMEnableStateTlv for more information • Bit to check in ParamPresenceMask - **16**
pDuration-Threshold	[Optional] • See dms_PSMDurationThresholdTlv for more information • Bit to check in ParamPresenceMask - **17**
pDurationDueTo-OOS	[Optional] • See dms_PSMDurationDueToOOSTlv for more information • Bit to check in ParamPresenceMask - **18**
pRandomization-Window	[Optional] • See dms_PSMRandomizationWindowTlv for more information • Bit to check in ParamPresenceMask - **19**

pActiveTimer	[Optional] • See dms_PSMActiveTimerTlv for more information • Bit to check in ParamPresenceMask - **20**
pPeriodic-UpdateTimer	[Optional] • See dms_PSMPeriodicUpdateTimerTlv for more information • Bit to check in ParamPresenceMask - **21**
pEarlyWakeup-Time	[Optional] • See dms_PSMEarlyWakeupTimeTlv for more information • Bit to check in ParamPresenceMask - **22**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.676.2 Field Documentation

8.676.2.1 dms_PSMActiveTimerTlv* unpack_dms_SLQSGetPowerSaveModeConfig_t::pActiveTimer

8.676.2.2 swi_uint256_t unpack_dms_SLQSGetPowerSaveModeConfig_t::ParamPresenceMask

8.676.2.3 dms_PSMDurationDueToOOSTlv* unpack_dms_SLQSGetPowerSaveModeConfig_t::pDurationDueToOOS

8.676.2.4 dms_PSMDurationThresholdTlv* unpack_dms_SLQSGetPowerSaveModeConfig_t::pDurationThreshold

8.676.2.5 dms_PSMEarlyWakeupTimeTlv* unpack_dms_SLQSGetPowerSaveModeConfig_t::pEarlyWakeupTime

8.676.2.6 dms_PSMPeriodicUpdateTimerTlv* unpack_dms_SLQSGetPowerSaveModeConfig_t::pPeriodicUpdateTimer

8.676.2.7 dms_PSMEnableStateTlv* unpack_dms_SLQSGetPowerSaveModeConfig_t::pPsmEnableState

8.676.2.8 dms_PSMRandomizationWindowTlv* unpack_dms_SLQSGetPowerSaveModeConfig_t::pRandomization-Window

8.677 unpack_dms_SLQSSetPowerSaveModeConfig_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.677.1 Detailed Description

This structure is used to store unpack_dms_SLQSSetPowerSaveModeConfig parameters.

Parameters

Tlvresult	• unpack Tlv result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.677.2 Field Documentation

8.677.2.1 swi_uint256_t unpack_dms_SLQSSetPowerSaveModeConfig_t::ParamPresenceMask

8.677.2.2 uint16_t unpack_dms_SLQSSetPowerSaveModeConfig_t::TlvResult

8.678 unpack_dms_SLQSSwiClearDyingGaspStatistics_t Struct Reference

Data Fields

- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.678.1 Detailed Description

This structure contains Clear Dying GASP unpack

Parameters

TlvResult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.678.2 Field Documentation

8.678.2.1 swi_uint256_t unpack_dms_SLQSSwiClearDyingGaspStatistics_t::ParamPresenceMask

8.678.2.2 uint16_t unpack_dms_SLQSSwiClearDyingGaspStatistics_t::TlvResult

8.679 unpack_dms_SLQSSwiGetCrashInfo_t Struct Reference

Data Fields

- uint16_t TlvResult
- crashInfoParams crashInfoParam
- swi_uint256_t ParamPresenceMask

8.679.1 Detailed Description

This structure contains SWI get crash information unpack information

Parameters

TlvResult	• Unpack Result
crashInfoParam[-OUT]	• See crashInfoParams • crashStatus – Bit to check in ParamPresenceMask - **1** • crashInfo – Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.679.2 Field Documentation

8.679.2.1 crashInfoParams unpack_dms_SLQSSwiGetCrashInfo_t::crashInfoParam

8.679.2.2 swi_uint256_t unpack_dms_SLQSSwiGetCrashInfo_t::ParamPresenceMask

8.679.2.3 uint16_t unpack_dms_SLQSSwiGetCrashInfo_t::TlvResult

8.680 unpack_dms_SLQSSwiGetDyingGaspCfg_t Struct Reference

Data Fields

- packgetDyingGaspCfg * pGetDyingGaspCfg
- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.680.1 Detailed Description

This structure contains Get Dying GASP Config unpack

Parameters

pGetDyingGasp-Cfg	• See packgetDyingGaspCfg • pDestSMSNum. – Bit to check in ParamPresenceMask - **16** • pDestSMSContent. – Bit to check in ParamPresenceMask - **17**
TlvResult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.680.2 Field Documentation

8.680.2.1 swi_uint256_t unpack_dms_SLQSSwiGetDyingGaspCfg_t::ParamPresenceMask

8.680.2.2 packgetDyingGaspCfg* unpack_dms_SLQSSwiGetDyingGaspCfg_t::pGetDyingGaspCfg

8.680.2.3 uint16_t unpack_dms_SLQSSwiGetDyingGaspCfg_t::Tlvresult

8.681 unpack_dms_SLQSSwiGetDyingGaspStatistics_t Struct Reference

Data Fields

- packgetDyingGaspStatistics * pGetDyingGaspStatistics
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.681.1 Detailed Description

This structure contains Get Dying GASP Statistics unpack.

Parameters

pGetDyingGasp-Statistics	• See packgetDyingGaspStatistics • pTimeStamp. – Bit to check in ParamPresenceMask - **16** • pSMSAttemptedFlag. – Bit to check in ParamPresenceMask - **17**
Tlvresult	• Unpack Result

8.681.2 Field Documentation

8.681.2.1 swi_uint256_t unpack_dms_SLQSSwiGetDyingGaspStatistics_t::ParamPresenceMask

8.681.2.2 packgetDyingGaspStatistics* unpack_dms_SLQSSwiGetDyingGaspStatistics_t::pGetDyingGaspStatistics

8.681.2.3 uint16_t unpack_dms_SLQSSwiGetDyingGaspStatistics_t::Tlvresult

8.682 unpack_dms_SLQSSwiGetFirmwareCurr_t Struct Reference

Data Fields

- uint8_t numEntries
- image_info_t * pCurrImgInfo
- char priver [16]
- char pkgver [16]
- char fwvers [16]
- char carrier [16]
- swi_uint256_t ParamPresenceMask

8.682.1 Detailed Description

This structure is used to store unpack_dms_SLQSSwiGetFirmwareCurr parameters

Parameters

numEntries[IN/-OUT]	• Number of entries in the image list to follow • The size of the list pCurrImgInfo must be specified when calling the API – Bit to check in ParamPresenceMask - **1**
pCurrImgInfo[O-UT]	• Currently Active Image List – Bit to check in ParamPresenceMask - **1**
priver[OUT]	• PRI version of the currently running firmware • Bit to check in ParamPresenceMask - **1**
pkgver[OUT]	• Package version of the currently running firmware • Bit to check in ParamPresenceMask - **1**
fwvers[OUT]	• firmware version of the currently running firmware • Bit to check in ParamPresenceMask - **1**
carrier[OUT]	• Carrier string of the currently running firmware • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.682.2 Field Documentation

8.682.2.1 char unpack_dms_SLQSSwiGetFirmwareCurr_t::carrier[16]

8.682.2.2 char unpack_dms_SLQSSwiGetFirmwareCurr_t::fwvers[16]

8.682.2.3 uint8_t unpack_dms_SLQSSwiGetFirmwareCurr_t::numEntries

8.682.2.4 swi_uint256_t unpack_dms_SLQSSwiGetFirmwareCurr_t::ParamPresenceMask

8.682.2.5 image_info_t* unpack_dms_SLQSSwiGetFirmwareCurr_t::pCurrImgInfo

8.682.2.6 char unpack_dms_SLQSSwiGetFirmwareCurr_t::pkgver[16]

8.682.2.7 char unpack_dms_SLQSSwiGetFirmwareCurr_t::priver[16]

8.683 unpack_dms_SLQSSwiGetFwUpdateStatus_t Struct Reference

Data Fields

- uint32_t ResCode
- uint8_t imgType
- uint32_t refData
- uint8_t refString [15]
- uint8_t logString [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.683.1 Detailed Description

This structure is used to store Firmware Update Status

Parameters

ResCode	• FW Update Result Code • Values: – 0x00000001 - Successful – 0xFFFFFFFF - Unknown (due to power off reset after firmware update) – 0x100000nn - File update errors while nn will be the exact error number: * 00 - General error – 0x200000nn - NVUP update errors while nn will be the exact error number: * 00 - General error – 0x40000nnn - FOTA update agent errors while nnn will be the exact error number: * 000 ∼ 0FF - Insignia defined error code * 100 ∼ 1FF - Sierra defined error code * See qaGobiApiTableFwDldErrorCodes.h for more detailed information – 0x800000nn - FDT/SSDP reported errors while nn will be the exact error number * See qaGobiApiTableFwDldErrorCodes.h for more detailed information • Bit to check in ParamPresenceMask - **16**
imgType	• Optional parameter • Firmware image type that failed the update • Bit to check in ParamPresenceMask - **17**
refData	• Optional parameter • Failed image reference data • This is normally the offset of the image that caused the failure • Bit to check in ParamPresenceMask - **18**
refString	• Optional parameter • Failed image reference string. This is normally the partition name of the image that caused the failure if applicable. • Bit to check in ParamPresenceMask - **19**

logString	• Optional parameter • Failed image reference string. This is normally the partition name of the image that caused the failure if applicable. • Bit to check in ParamPresenceMask - **20**
TlvResult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.683.2 Field Documentation

8.683.2.1 uint8_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::imgType

8.683.2.2 uint8_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::logString[255]

8.683.2.3 swi_uint256_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::ParamPresenceMask

8.683.2.4 uint32_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::refData

8.683.2.5 uint8_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::refString[15]

8.683.2.6 uint32_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::ResCode

8.683.2.7 uint16_t unpack_dms_SLQSSwiGetFwUpdateStatus_t::TlvResult

8.684 unpack_dms_SLQSSwiGetHostDevInfo_t Struct Reference

Data Fields

- uint16_t TlvResult
- char manString [255]
- char modelString [255]
- char swVerString [255]
- char plasmaIDString [255]
- swi_uint256_t ParamPresenceMask

8.684.1 Detailed Description

This structure contains SWI get host device info unpack information

Parameters

TlvResult	• unpack Result
manString[OUT]	• Host Device Manufacturer Name • Null terminated ASCII String • Bit to check in ParamPresenceMask - **16**

modelString[OUT]	• Host Device Model String • Null terminated ASCII String • Bit to check in ParamPresenceMask - **17**
swVerString[OUT]	• Host Device Software Version String • Null terminated ASCII string • Bit to check in ParamPresenceMask - **18**
plasmaIDString[OUT]	• Host Device Plasma ID String • Null terminated alphanumeric ASCII String. • Bit to check in ParamPresenceMask - **19**
ParamPresenceMask[OUT]	• bitmask representation to indicate valid parameters.

8.684.2 Field Documentation

8.684.2.1 char unpack_dms_SLQSSwiGetHostDevInfo_t::manString[255]

8.684.2.2 char unpack_dms_SLQSSwiGetHostDevInfo_t::modelString[255]

8.684.2.3 swi_uint256_t unpack_dms_SLQSSwiGetHostDevInfo_t::ParamPresenceMask

8.684.2.4 char unpack_dms_SLQSSwiGetHostDevInfo_t::plasmaIDString[255]

8.684.2.5 char unpack_dms_SLQSSwiGetHostDevInfo_t::swVerString[255]

8.684.2.6 uint16_t unpack_dms_SLQSSwiGetHostDevInfo_t::TlvResult

8.685 unpack_dms_SLQSSwiGetOSInfo_t Struct Reference

Data Fields

- uint16_t TlvResult
- char nameString [255]
- char versionString [255]
- swi_uint256_t ParamPresenceMask

8.685.1 Detailed Description

This structure contains SWI get host os info unpack information

Parameters

TlvResult	• Unpack Result

nameString[OUT]	• Host operating system name • Bit to check in ParamPresenceMask - **16**
VersionString[OUT]	• Host operating system version • Bit to check in ParamPresenceMask - **17**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.685.2 Field Documentation

8.685.2.1 char unpack_dms_SLQSSwiGetOSInfo_t::nameString[255]

8.685.2.2 swi_uint256_t unpack_dms_SLQSSwiGetOSInfo_t::ParamPresenceMask

8.685.2.3 uint16_t unpack_dms_SLQSSwiGetOSInfo_t::Tlvresult

8.685.2.4 char unpack_dms_SLQSSwiGetOSInfo_t::versionString[255]

8.686 unpack_dms_SLQSSwiGetSerialNoExt_t Struct Reference

Data Fields

- uint16_t Tlvresult
- char meidString [8]
- swi_uint256_t ParamPresenceMask

8.686.1 Detailed Description

This structure contains SWI get device serial number extension unpack information

Parameters

Tlvresult	• pack Result
meidString[OUT]	• optional parameter, mobile equipment identifier • Bit to check in ParamPresenceMask - **16**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.686.2 Field Documentation

8.686.2.1 char unpack_dms_SLQSSwiGetSerialNoExt_t::meidString[8]

8.686.2.2 swi_uint256_t unpack_dms_SLQSSwiGetSerialNoExt_t::ParamPresenceMask

8.686.2.3 uint16_t unpack_dms_SLQSSwiGetSerialNoExt_t::Tlvresult

8.687 unpack_dms_SLQSSwiSetDyingGaspCfg_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.687.1 Detailed Description

This structure contains set Dying GASP Config unpack

Parameters

Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.687.2 Field Documentation

8.687.2.1 swi_uint256_t unpack_dms_SLQSSwiSetDyingGaspCfg_t::ParamPresenceMask

8.687.2.2 uint16_t unpack_dms_SLQSSwiSetDyingGaspCfg_t::Tlvresult

8.688 unpack_dms_SLQSSwiSetHostDevInfo_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.688.1 Detailed Description

This structure contains SWI set host dev info unpack

Parameters

Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.688.2 Field Documentation

8.688.2.1 swi_uint256_t unpack_dms_SLQSSwiSetHostDevInfo_t::ParamPresenceMask

8.688.2.2 uint16_t unpack_dms_SLQSSwiSetHostDevInfo_t::Tlvresult

8.689 unpack_dms_SLQSSwiSetOSInfo_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.689.1 Detailed Description

This structure contains SWI set host OS info unpack

Parameters

Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.689.2 Field Documentation

8.689.2.1 swi_uint256_t unpack_dms_SLQSSwiSetOSInfo_t::ParamPresenceMask

8.689.2.2 uint16_t unpack_dms_SLQSSwiSetOSInfo_t::Tlvresult

8.690 unpack_dms_SLQSUIMGetState_t Struct Reference

Data Fields

- uint8_t state
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.690.1 Detailed Description

This structure contains UIM get state unpack information

Parameters

state[OUT]	• UIM state • Bit to check in ParamPresenceMask - **1**
Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.690.2 Field Documentation

8.690.2.1 swi_uint256_t unpack_dms_SLQSUIMGetState_t::ParamPresenceMask

8.690.2.2 uint8_t unpack_dms_SLQSUIMGetState_t::state

8.690.2.3 uint16_t unpack_dms_SLQSUIMGetState_t::Tlvresult

8.691 unpack_dms_SwiEventReportCallBack_ind_t Struct Reference

Data Fields

- dms_TemperatureTlv TempTlv
- dms_VoltageTlv VoltTlv
- dms_UimStatusTlv UimStatusTlv
- swi_uint256_t ParamPresenceMask

8.691.1 Detailed Description

Structure used to SWI event report indication parameters.

Parameters

TempTlv	• Temperature status tlv • See dms_TemperatureTlv for more information
VoltTlv	• Voltage status tlv • see dms_VoltageTlv for more information
UimStatusTlv	• UIM status tlv • see dms_UimStatusTlv for more information
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

Note

: None

8.691.2 Field Documentation

8.691.2.1 swi_uint256_t unpack_dms_SwiEventReportCallBack_ind_t::ParamPresenceMask

8.691.2.2 dms_TemperatureTlv unpack_dms_SwiEventReportCallBack_ind_t::TempTlv

8.691.2.3 dms_UimStatusTlv unpack_dms_SwiEventReportCallBack_ind_t::UimStatusTlv

8.691.2.4 dms_VoltageTlv unpack_dms_SwiEventReportCallBack_ind_t::VoltTlv

8.692 unpack_dms_SwiSetEventReport_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.692.1 Detailed Description

This structure is used to store unpack_dms_SwiSetEventReport parameters.

Parameters

Tlvresult	• unpack Tlv result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.692.2 Field Documentation

8.692.2.1 swi_uint256_t unpack_dms_SwiSetEventReport_t::ParamPresenceMask

8.692.2.2 uint16_t unpack_dms_SwiSetEventReport_t::Tlvresult

8.693 unpack_dms_SwiUimSelect_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.693.1 Detailed Description

This structure is used to store unpack_dms_SwiUimSelect parameters.

Parameters

Tlvresult	• unpack Tlv result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.693.2 Field Documentation

8.693.2.1 swi_uint256_t unpack_dms_SwiUimSelect_t::ParamPresenceMask

8.693.2.2 uint16_t unpack_dms_SwiUimSelect_t::Tlvresult

8.694 unpack_dms_UIMGetControlKeyStatus_t Struct Reference

Data Fields

- uint8_t facilityState
- uint8_t verifyRetriesLeft
- uint8_t unblockRetriesLeft
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.694.1 Detailed Description

This structure contains PIN retries status

Parameters

facilityState[OUT]	• Control key status – 0 - Deactivated – 1 - Activated – 2 - Blocked • Bit to check in ParamPresenceMask - **1**
verifyRetriesLeft[OUT]	• Optional parameter • Upon operational failure, this will indicate number of retries left, after which PIN will be blocked. • Bit to check in ParamPresenceMask - **1**
unblockRetriesLeft[OUT]	• Optional parameter • Upon operational failure, this will indicate number of unblock retries left, after which the PIN will be permanently blocked i.e. UIM is unusable. • Bit to check in ParamPresenceMask - **1**
Tlvresult	• Unpack Result
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.694.2 Field Documentation

8.694.2.1 uint8_t unpack_dms_UIMGetControlKeyStatus_t::facilityState

8.694.2.2 swi_uint256_t unpack_dms_UIMGetControlKeyStatus_t::ParamPresenceMask

8.694.2.3 uint16_t unpack_dms_UIMGetControlKeyStatus_t::Tlvresult

8.694.2.4 uint8_t unpack_dms_UIMGetControlKeyStatus_t::unblockRetriesLeft

8.694.2.5 uint8_t unpack_dms_UIMGetControlKeyStatus_t::verifyRetriesLeft

8.695 unpack_dms_UIMGetICCID_t Struct Reference

Data Fields

- uint8_t stringSize
- uint8_t String [255]
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.695.1 Detailed Description

This structure is used to store unpack_dms_UIMGetICCID parameters.

Parameters

stringSize	• Size of String. • Bit to check in ParamPresenceMask - **1**
String	• ICCID String. • Maximum Length is 255 Bytes • Bit to check in ParamPresenceMask - **1**
Tlvresult	• Unack result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.695.2 Field Documentation

8.695.2.1 swi_uint256_t unpack_dms_UIMGetICCID_t::ParamPresenceMask

8.695.2.2 uint8_t unpack_dms_UIMGetICCID_t::String[255]

8.695.2.3 uint8_t unpack_dms_UIMGetICCID_t::stringSize

8.695.2.4 uint16_t unpack_dms_UIMGetICCID_t::Tlvresult

8.696 unpack_dms_UIMGetPINStatus_t Struct Reference

Data Fields

- uint8_t p1Status
- uint8_t p1VerifyRetriesLeft
- uint8_t p1UnblockRetriesLeft
- uint8_t p2Status
- uint8_t p2VerifyRetriesLeft
- uint8_t p2UnblockRetriesLeft
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.696.1 Detailed Description

This structure contains Get PIN Status unpack information

Parameters

p1Status[OUT]	• PIN1 status(0xFFFFFFFF - Unknown) – 0 - PIN not initialized – 1 - PIN enabled, not verified – 2 - PIN enabled, verified – 3 - PIN disabled – 4 - PIN blocked – 5 - PIN permanently blocked • Bit to check in ParamPresenceMask - **17**
p1VerifyRetries-Left[OUT]	• Optional parameter • Upon operational failure, this will indicate number of retries left of PIN1, after which PIN will be blocked. • Bit to check in ParamPresenceMask - **17**
p1Unblock-RetriesLeft[OUT]	• Optional parameter • Upon operational failure, this will indicate number of unblock retries left of PIN1, after which the PIN will be permanently blocked i.e. UIM is unusable. • Bit to check in ParamPresenceMask - **17**
p2Status[OUT]	• PIN2 status(0xFFFFFFFF - Unknown) – 0 - PIN not initialized – 1 - PIN enabled, not verified – 2 - PIN enabled, verified – 3 - PIN disabled – 4 - PIN blocked – 5 - PIN permanently blocked • Bit to check in ParamPresenceMask - **18**
p2VerifyRetries-Left[OUT]	• Optional parameter • Upon operational failure, this will indicate number of retries left of PIN2, after which PIN will be blocked. • Bit to check in ParamPresenceMask - **18**
p2Unblock-RetriesLeft[OUT]	• Optional parameter • Upon operational failure, this will indicate number of unblock retries left of PIN2, after which the PIN will be permanently blocked i.e. UIM is unusable. • Bit to check in ParamPresenceMask - **18**
Tlvresult	• Unpack Result

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.696.2 Field Documentation

8.696.2.1 uint8_t unpack_dms_UIMGetPINStatus_t::p1Status

8.696.2.2 uint8_t unpack_dms_UIMGetPINStatus_t::p1UnblockRetriesLeft

8.696.2.3 uint8_t unpack_dms_UIMGetPINStatus_t::p1VerifyRetriesLeft

8.696.2.4 uint8_t unpack_dms_UIMGetPINStatus_t::p2Status

8.696.2.5 uint8_t unpack_dms_UIMGetPINStatus_t::p2UnblockRetriesLeft

8.696.2.6 uint8_t unpack_dms_UIMGetPINStatus_t::p2VerifyRetriesLeft

8.696.2.7 swi_uint256_t unpack_dms_UIMGetPINStatus_t::ParamPresenceMask

8.696.2.8 uint16_t unpack_dms_UIMGetPINStatus_t::Tlvresult

8.697 unpack_dms_UIMSetControlKeyProtection_t Struct Reference

Data Fields

- uint8_t verifyRetriesLeft
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.697.1 Detailed Description

This structure contains UIM Set control key protection unpack information

Parameters

verifyRetries-Left[OUT]	• Optional parameter • number of retries left after which the control key is blocked • Bit to check in ParamPresenceMask - **16**
Tlvresult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.697.2 Field Documentation

8.697.2.1 swi_uint256_t unpack_dms_UIMSetControlKeyProtection_t::ParamPresenceMask

8.697.2.2 uint16_t unpack_dms_UIMSetControlKeyProtection_t::Tlvresult

8.697.2.3 uint8_t unpack_dms_UIMSetControlKeyProtection_t::verifyRetriesLeft

8.698 unpack_dms_UIMSetPINProtection_t Struct Reference

Data Fields

- uint8_t verifyRetriesLeft
- uint8_t unblockRetriesLeft
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.698.1 Detailed Description

This structure contains PIN retries status

Parameters

verifyRetries-Left[OUT]	• Optional parameter • Upon operational failure, this will indicate number of retries left, after which PIN will be blocked. • Bit to check in ParamPresenceMask - **16**
unblockRetries-Left[OUT]	• Optional parameter • Upon operational failure, this will indicate number of unblock retries left, after which the PIN will be permanently blocked i.e. UIM is unusable. • Bit to check in ParamPresenceMask - **16**
Tlvresult[OUT]	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.698.2 Field Documentation

8.698.2.1 swi_uint256_t unpack_dms_UIMSetPINProtection_t::ParamPresenceMask

8.698.2.2 uint16_t unpack_dms_UIMSetPINProtection_t::Tlvresult

8.698.2.3 uint8_t unpack_dms_UIMSetPINProtection_t::unblockRetriesLeft

8.698.2.4 uint8_t unpack_dms_UIMSetPINProtection_t::verifyRetriesLeft

8.699 unpack_dms_UIMUnblockControlKey_t Struct Reference

Data Fields

- uint8_t unblockRetriesLeft
- uint16_t Tlvresult

- swi_uint256_t ParamPresenceMask

8.699.1 Detailed Description

This structure contains UIM Set control key protection unpack information

Parameters

unblockRetries-Left[OUT]	• Optional parameter • number of unblock retries left after which the control key is permanently blocked • Bit to check in ParamPresenceMask - **16**
Tlvresult[OUT]	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.699.2 Field Documentation

8.699.2.1 swi_uint256_t unpack_dms_UIMUnblockControlKey_t::ParamPresenceMask

8.699.2.2 uint16_t unpack_dms_UIMUnblockControlKey_t::Tlvresult

8.699.2.3 uint8_t unpack_dms_UIMUnblockControlKey_t::unblockRetriesLeft

8.700 unpack_fms_GetImagesPreference_t Struct Reference

Data Fields

- uint32_t ImageListSize
- FMSPrefImageList * pImageList
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.700.1 Detailed Description

This structure contains the Get Image Preference information unpack

Parameters

listSize	• The number of elements in the image list
pListEntries	• Array of Image entries with size provided by previous field • See FMSImageElement • Bit to check in ParamPresenceMask - **1**
Tlvresult	• Unpack result

8.700.2 Field Documentation

8.700.2.1 uint32_t unpack_fms_GetImagesPreference_t::ImageListSize

8.700.2.2 swi_uint256_t unpack_fms_GetImagesPreference_t::ParamPresenceMask

8.700.2.3 FMSPrefImageList* unpack_fms_GetImagesPreference_t::pImageList

8.700.2.4 uint16_t unpack_fms_GetImagesPreference_t::Tlvresult

8.701 unpack_fms_GetStoredImages_t Struct Reference

Data Fields

- uint32_t imagelistSize
- FMSImageList imageList
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.701.1 Detailed Description

This structure contains the Get Stored Images unpack

Parameters

listSize	• The number of elements in the image list
imageList	• Array of Image entries with size provided by previous field • See FMSImageElement • Bit to check in ParamPresenceMask - **1**
Tlvresult	• Unpack result

8.701.2 Field Documentation

8.701.2.1 FMSImageList unpack_fms_GetStoredImages_t::imageList

8.701.2.2 uint32_t unpack_fms_GetStoredImages_t::imagelistSize

8.701.2.3 swi_uint256_t unpack_fms_GetStoredImages_t::ParamPresenceMask

8.701.2.4 uint16_t unpack_fms_GetStoredImages_t::Tlvresult

8.702 unpack_fms_SetImagesPreference_t Struct Reference

Data Fields

- uint32_t ImageTypesSize
- uint8_t ImageTypes [255]

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.702.1 Detailed Description

This structure contains the Set Images Preference unpack

Parameters

ImageTypesSize	• Image Type Size
ImageTypes	• Image Type • Bit to check in ParamPresenceMask - **1**
Tlvresult	• Unpack result

8.702.2 Field Documentation

8.702.2.1 uint8_t unpack_fms_SetImagesPreference_t::ImageTypes[255]

8.702.2.2 uint32_t unpack_fms_SetImagesPreference_t::ImageTypesSize

8.702.2.3 swi_uint256_t unpack_fms_SetImagesPreference_t::ParamPresenceMask

8.702.2.4 uint16_t unpack_fms_SetImagesPreference_t::Tlvresult

8.703 unpack_ims_SLQSGetIMSSMSConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- uint8_t * pSMSFormat
- uint8_t * pSMSOverIPNwInd
- uint8_t * pPhoneCtxtURILen
- uint8_t * pPhoneCtxtURI
- swi_uint256_t ParamPresenceMask

8.703.1 Detailed Description

This structure contains the SLQSGetIMSSMSConfig unpack parameters.

Parameters

pSettingResp	• Settings Response • Bit to check in ParamPresenceMask - **16**

pSMSFormat	• SMS format – 0 - 3GPP – 1 - 3GPP2 • Bit to check in ParamPresenceMask - **17**
pSMSOverIPNw-Ind	• SMS over IP Network Indication Flag – TRUE - Turn on mobile-originated SMS – FALSE - Turn off mobile-originated SMS • Bit to check in ParamPresenceMask - **18**
pPhoneCtxtURI-Len[IN/OUT]	• Size in bytes assigned to the Phone context Universal Resource Identifier to follow
pPhoneCtxtURI	• Phone context universal resource identifier • Length of this string must be specified in pPhoneCtxtURILen parameter • Bit to check in ParamPresenceMask - **19**

8.703.2 Field Documentation

8.703.2.1 swi_uint256_t unpack_ims_SLQSGetIMSSMSConfig_t::ParamPresenceMask

8.703.2.2 uint8_t* unpack_ims_SLQSGetIMSSMSConfig_t::pPhoneCtxtURI

8.703.2.3 uint8_t* unpack_ims_SLQSGetIMSSMSConfig_t::pPhoneCtxtURILen

8.703.2.4 uint8_t* unpack_ims_SLQSGetIMSSMSConfig_t::pSettingResp

8.703.2.5 uint8_t* unpack_ims_SLQSGetIMSSMSConfig_t::pSMSFormat

8.703.2.6 uint8_t* unpack_ims_SLQSGetIMSSMSConfig_t::pSMSOverIPNwInd

8.704 unpack_ims_SLQSGetIMSUserConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- uint8_t * pIMSDomainLen
- uint8_t * pIMSDomain
- swi_uint256_t ParamPresenceMask

8.704.1 Detailed Description

This structure contains the SLQSGetIMSUserConfig pack parameters.

Parameters

pSettingResp	• Settings Response • Bit to check in ParamPresenceMask - **16**
pIMSDomain-Len[IN/OUT]	• Length of IMS Domain Name to follow
pIMSDomain	• IMS domain name • Length of this string must be specified in pIMSDomainLen parameter • Bit to check in ParamPresenceMask - **17**

8.704.2 Field Documentation

8.704.2.1 swi_uint256_t unpack_ims_SLQSGetIMSUserConfig_t::ParamPresenceMask

8.704.2.2 uint8_t* unpack_ims_SLQSGetIMSUserConfig_t::pIMSDomain

8.704.2.3 uint8_t* unpack_ims_SLQSGetIMSUserConfig_t::pIMSDomainLen

8.704.2.4 uint8_t* unpack_ims_SLQSGetIMSUserConfig_t::pSettingResp

8.705 unpack_ims_SLQSGetIMSVoIPConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- uint16_t * pSessionExpiryTimer
- uint16_t * pMinSessionExpiryTimer
- uint8_t * pAmrWbEnable
- uint8_t * pScrAmrEnable
- uint8_t * pScrAmrWbEnable
- uint8_t * pAmrMode
- uint16_t * pAmrWBMode
- uint8_t * pAmrOctetAligned
- uint8_t * pAmrWBOctetAligned
- uint16_t * pRingingTimer
- uint16_t * pRingBackTimer
- uint16_t * pRTPRTCPInactTimer
- swi_uint256_t ParamPresenceMask

8.705.1 Detailed Description

This structure contains the SLQSGetIMSVoIPConfig unpack parameters.

Parameters

pSettingResp	• Settings Response. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE • Bit to check in ParamPresenceMask - **16**

pSessionExpiry-Timer	• Session duration, in seconds • Bit to check in ParamPresenceMask - **17**
pMinSession-ExpiryTimer	• Minimum allowed value for session expiry timer, in seconds • Bit to check in ParamPresenceMask - **18**
pAmrWbEnable	• Flag to enable/disable Adaptive Multirate Codec(AMR) WideBand(WB) audio • Values: – True - Enable – False - Disable • Bit to check in ParamPresenceMask - **19**
pScrAmrEnable	• Flag to enable/disable Source Control Rate(SCR) for AMR NarrowBand (NB) • Values: – True - Enable – False - Disable • Bit to check in ParamPresenceMask - **20**
pScrAmrWb-Enable	• Flag to enable/disable SCR for AMR WB Audio • Values: – True - Enable – False - Disable • Bit to check in ParamPresenceMask - **21**
pAmrMode	• BitMask for AMR NB modes allowed • Values: – 0x1 - 4.75 kbps – 0x2 - 5.15 kbps – 0x4 - 5.9 kbps – 0x8 - 6.17 kbps – 0x10 - 7.4 kbps – 0x20 - 7.95 kbps – 0x40 - 10.2 kbps – 0x80 - 12.2 kbps • Bit to check in ParamPresenceMask - **22**

pAmrWBMode	• BitMask for AMR WB modes allowed • Values: – 0x1 - 6.60 kbps – 0x2 - 8.85 kbps – 0x4 - 12.65 kbps – 0x8 - 14.25 kbps – 0x10 - 15.85 kbps – 0x20 - 18.25 kbps – 0x40 - 19.85 kbps – 0x80 - 23.05 kbps – 0x100 - 23.85 kbps • Bit to check in ParamPresenceMask - **23**
pAmrOctet-Aligned	• Flag to indicate if the octet is aligned for AMR NB Audio • Values: – True - Aligned – False - Not aligned, Bandwidth Efficient mode • Bit to check in ParamPresenceMask - **24**
pAmrWBOctet-Aligned	• Flag to indicate if the octet is aligned for AMR WB Audio • Values: – True - Aligned – False - Not aligned, Bandwidth Efficient mode • Bit to check in ParamPresenceMask - **25**
pRingingTimer	• Duration of ringing timer, in seconds. The ringing timer starts on the ringing event. If the call is not answered within the duration of this timer, the call is disconnected. • Bit to check in ParamPresenceMask - **26**
pRingBackTimer	• Duration of ringback timer, in seconds. The ringback timer starts on the ringback event. If the call is not answered within the duration of this timer, the call is disconnected. • Bit to check in ParamPresenceMask - **27**
pRTPRTCP-InactTimer	• Duration of RTP/RTCP inactivity timer, in seconds. If no RTP/RTCP packet is received prior to the expiry of this timer, the call is disconnected. • Bit to check in ParamPresenceMask - **28**

8.705.2 Field Documentation

8.705.2.1 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pAmrMode

8.705.2.2 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pAmrOctetAligned

8.705.2.3 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pAmrWbEnable

8.705.2.4 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pAmrWBMode

8.705.2.5 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pAmrWBOctetAligned

8.705.2.6 swi_uint256_t unpack_ims_SLQSGetIMSVoIPConfig_t::ParamPresenceMask

8.705.2.7 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pMinSessionExpiryTimer

8.705.2.8 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pRingBackTimer

8.705.2.9 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pRingingTimer

8.705.2.10 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pRTPRTCPInactTimer

8.705.2.11 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pScrAmrEnable

8.705.2.12 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pScrAmrWbEnable

8.705.2.13 uint16_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pSessionExpiryTimer

8.705.2.14 uint8_t* unpack_ims_SLQSGetIMSVoIPConfig_t::pSettingResp

8.706 unpack_ims_SLQSGetRegMgrConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- uint16_t * pPCSCFPort
- uint8_t * pPriCSCFPortNameLen
- uint8_t * pPriCSCFPortName
- uint8_t * pIMSTestMode
- swi_uint256_t ParamPresenceMask

8.706.1 Detailed Description

This structure contains the SLQSGetRegMgrConfig unpack parameters.

Parameters

pSettingResp	• Settings Response • Bit to check in ParamPresenceMask - **16**
pPCSCFPort	• Proxy call session control function port • Bit to check in ParamPresenceMask - **17**
pPriCSCFPort-NameLen(IN/O-UT)	• Size in bytes assigned to the primary CSCF Port name parameter to follow
pPriCSCFPort-Name	• Call Session control port, fully qualified domain name • Length of this string must be specified in pPriCSCFPortNameLen parameter • Bit to check in ParamPresenceMask - **18**

pIMSTestMode	• IMS Test mode Enabled. – TRUE - Enabled – FALSE - Disabled • Bit to check in ParamPresenceMask - **19**

Note

pPriCSCFPortNameLen must be set to a valid value during API call to retrieve pPriCSCFPortName.

8.706.2 Field Documentation

8.706.2.1 swi_uint256_t unpack_ims_SLQSGetRegMgrConfig_t::ParamPresenceMask

8.706.2.2 uint8_t* unpack_ims_SLQSGetRegMgrConfig_t::pIMSTestMode

8.706.2.3 uint16_t* unpack_ims_SLQSGetRegMgrConfig_t::pPCSCFPort

8.706.2.4 uint8_t* unpack_ims_SLQSGetRegMgrConfig_t::pPriCSCFPortName

8.706.2.5 uint8_t* unpack_ims_SLQSGetRegMgrConfig_t::pPriCSCFPortNameLen

8.706.2.6 uint8_t* unpack_ims_SLQSGetRegMgrConfig_t::pSettingResp

8.707 unpack_ims_SLQSGetSIPConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- uint16_t * pSIPLocalPort
- uint32_t * pTimerSIPReg
- uint32_t * pSubscribeTimer
- uint32_t * pTimerT1
- uint32_t * pTimerT2
- uint32_t * pTimerTf
- uint8_t * pSigCompEnabled
- swi_uint256_t ParamPresenceMask

8.707.1 Detailed Description

This structure contains the SLQSGetSIPConfig unpack parameters.

Parameters

pSettingResp	• Settings Response • Bit to check in ParamPresenceMask - **16**
pSIPLocalPort	• Primary call session control function SIP port number • Bit to check in ParamPresenceMask - **17**

pTimerSIPReg	• Initial SIP registration duration from the User equipment, in seconds • Bit to check in ParamPresenceMask - **18**
pSubscribeTimer	• Duration of the subscription by the UE for IMS registration notifications, in seconds • Bit to check in ParamPresenceMask - **19**
pTimerT1	• RTT estimate, in milliseconds • Bit to check in ParamPresenceMask - **20**
pTimerT2	• The maximum retransmit interval for non-invite requests and invite responses, in milliseconds • Bit to check in ParamPresenceMask - **21**
pTimerTf	• Non-invite transaction timeout timer, in milliseconds • Bit to check in ParamPresenceMask - **22**
pSigComp-Enabled	• Sig Comp Status – TRUE - Sig Comp Enabled – FALSE - Sig Comp Disabled • Bit to check in ParamPresenceMask - **23**

8.707.2 Field Documentation

8.707.2.1 swi_uint256_t unpack_ims_SLQSGetSIPConfig_t::ParamPresenceMask

8.707.2.2 uint8_t* unpack_ims_SLQSGetSIPConfig_t::pSettingResp

8.707.2.3 uint8_t* unpack_ims_SLQSGetSIPConfig_t::pSigCompEnabled

8.707.2.4 uint16_t* unpack_ims_SLQSGetSIPConfig_t::pSIPLocalPort

8.707.2.5 uint32_t* unpack_ims_SLQSGetSIPConfig_t::pSubscribeTimer

8.707.2.6 uint32_t* unpack_ims_SLQSGetSIPConfig_t::pTimerSIPReg

8.707.2.7 uint32_t* unpack_ims_SLQSGetSIPConfig_t::pTimerT1

8.707.2.8 uint32_t* unpack_ims_SLQSGetSIPConfig_t::pTimerT2

8.707.2.9 uint32_t* unpack_ims_SLQSGetSIPConfig_t::pTimerTf

8.708 unpack_ims_SLQSRegMgrCfgCallBack_ind_t Struct Reference

Data Fields

- ims_PCSCFPortInfo PCTlv

- ims_CSCFPortNameInfo PNTlv
- ims_IMSTestModeInfo TMTlv
- swi_uint256_t ParamPresenceMask

8.708.1 Detailed Description

Structure used to store Reg Mgr Config Indication Parameters.

Parameters

PCTlv	• Primary PCSCF Port info • See ims_PCSCFPortInfo for more information • Bit to check in ParamPresenceMask - **16**
PNTlv	• CSCF Port info • see ims_CSCFPortNameInfo for more information • Bit to check in ParamPresenceMask - **17**
TMTlv	• IMS test mode info • see ims_IMSTestModeInfo for more information • Bit to check in ParamPresenceMask - **18**

Note

: None

8.708.2 Field Documentation

8.708.2.1 swi_uint256_t unpack_ims_SLQSRegMgrCfgCallBack_ind_t::ParamPresenceMask

8.708.2.2 ims_PCSCFPortInfo unpack_ims_SLQSRegMgrCfgCallBack_ind_t::PCTlv

8.708.2.3 ims_CSCFPortNameInfo unpack_ims_SLQSRegMgrCfgCallBack_ind_t::PNTlv

8.708.2.4 ims_IMSTestModeInfo unpack_ims_SLQSRegMgrCfgCallBack_ind_t::TMTlv

8.709 unpack_ims_SLQSSetIMSSMSConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- swi_uint256_t ParamPresenceMask

8.709.1 Detailed Description

This structure contains the SLQSSetIMSSMSConfig unpack parameters.

Parameters

pSettingResp	• Settings standard response type. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE • Bit to check in ParamPresenceMask - **16**

8.709.2 Field Documentation

8.709.2.1 swi_uint256_t unpack_ims_SLQSSetIMSSMSConfig_t::ParamPresenceMask

8.709.2.2 uint8_t* unpack_ims_SLQSSetIMSSMSConfig_t::pSettingResp

8.710 unpack_ims_SLQSSetIMSUserConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- swi_uint256_t ParamPresenceMask

8.710.1 Detailed Description

This structure contains the SLQSSetIMSUserConfig unpack parameters.

Parameters

pSettingResp	• Settings standard response type. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE • Bit to check in ParamPresenceMask - **16**

8.710.2 Field Documentation

8.710.2.1 swi_uint256_t unpack_ims_SLQSSetIMSUserConfig_t::ParamPresenceMask

8.710.2.2 uint8_t* unpack_ims_SLQSSetIMSUserConfig_t::pSettingResp

8.711 unpack_ims_SLQSSetIMSVoIPConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- swi_uint256_t ParamPresenceMask

8.711.1 Detailed Description

This structure contains the SLQSSetIMSVoIPConfig unpack parameters.

Parameters

pSettingResp	• Settings standard response type. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE • Bit to check in ParamPresenceMask - **16**

8.711.2 Field Documentation

8.711.2.1 swi_uint256_t unpack_ims_SLQSSetIMSVoIPConfig_t::ParamPresenceMask

8.711.2.2 uint8_t* unpack_ims_SLQSSetIMSVoIPConfig_t::pSettingResp

8.712 unpack_ims_SLQSSetRegMgrConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- swi_uint256_t ParamPresenceMask

8.712.1 Detailed Description

This structure contains the SLQSSetRegMgrConfig unpack parameters.

Parameters

pSettingResp	• Settings standard response type. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE • Bit to check in ParamPresenceMask - **16**

8.712.2 Field Documentation

8.712.2.1 swi_uint256_t unpack_ims_SLQSSetRegMgrConfig_t::ParamPresenceMask

8.712.2.2 uint8_t* unpack_ims_SLQSSetRegMgrConfig_t::pSettingResp

8.713 unpack_ims_SLQSSetSIPConfig_t Struct Reference

Data Fields

- uint8_t * pSettingResp
- swi_uint256_t ParamPresenceMask

8.713.1 Detailed Description

This structure contains the SLQSSetSIPConfig unpack parameters.

Parameters

pSettingResp	• Settings standard response type. A settings specific error code is returned when the standard response error type is QMI_ERR_CAUSE_CODE • Bit to check in ParamPresenceMask - **16**

8.713.2 Field Documentation

8.713.2.1 swi_uint256_t unpack_ims_SLQSSetSIPConfig_t::ParamPresenceMask

8.713.2.2 uint8_t* unpack_ims_SLQSSetSIPConfig_t::pSettingResp

8.714 unpack_ims_SLQSSIPCfgCallBack_ind_t Struct Reference

Data Fields

- ims_SIPPortInfo SPTlv
- ims_SIPRegnTmrInfo SRTlv
- ims_SubscrTmrInfo STTlv
- ims_TmrT1Info TT1Tlv
- ims_TmrT2Info TT2Tlv
- ims_TmrTfInfo TTfTlv
- ims_SigCompEnInfo SCTlv
- swi_uint256_t ParamPresenceMask

8.714.1 Detailed Description

Structure used to store Reg Mgr Config Indication Parameters.

Parameters

SPTlv	• SIP port tlv • See ims_SIPPortInfo for more information • Bit to check in ParamPresenceMask - **16**
SRTlv	• SIP Registration Timer tlv • see ims_SIPRegnTmrInfo for more information • Bit to check in ParamPresenceMask - **17**
STTlv	• Subscriber timer tlv • see ims_SubscrTmrInfo for more information • Bit to check in ParamPresenceMask - **18**
TT1Tlv	• Timer T1 tlv • see ims_TmrT1Info for more information • Bit to check in ParamPresenceMask - **19**

TT2Tlv	• Timer T2 tlv • see ims_TmrT2Info for more information • Bit to check in ParamPresenceMask - **20**
TTfTlv	• Timer Tf tlv • see ims_TmrTfInfo for more information • Bit to check in ParamPresenceMask - **21**
SCTlv	• SigComp Status Tlv • see ims_SigCompEnInfo for more information • Bit to check in ParamPresenceMask - **22**

Note

: None

8.714.2 Field Documentation

8.714.2.1 swi_uint256_t unpack_ims_SLQSSIPCfgCallBack_ind_t::ParamPresenceMask

8.714.2.2 ims_SigCompEnInfo unpack_ims_SLQSSIPCfgCallBack_ind_t::SCTlv

8.714.2.3 ims_SIPPortInfo unpack_ims_SLQSSIPCfgCallBack_ind_t::SPTlv

8.714.2.4 ims_SIPRegnTmrInfo unpack_ims_SLQSSIPCfgCallBack_ind_t::SRTlv

8.714.2.5 ims_SubscrTmrInfo unpack_ims_SLQSSIPCfgCallBack_ind_t::STTlv

8.714.2.6 ims_TmrT1Info unpack_ims_SLQSSIPCfgCallBack_ind_t::TT1Tlv

8.714.2.7 ims_TmrT2Info unpack_ims_SLQSSIPCfgCallBack_ind_t::TT2Tlv

8.714.2.8 ims_TmrTfInfo unpack_ims_SLQSSIPCfgCallBack_ind_t::TTfTlv

8.715 unpack_ims_SLQSSMSCfgCallBack_ind_t Struct Reference

Data Fields

- ims_SMSFmtInfo SFTlv
- ims_SMSoIPNwInfo SINTlv
- ims_PhCtxtURIInfo PCURTlv
- swi_uint256_t ParamPresenceMask

8.715.1 Detailed Description

Structure used to store SMS Config Indication Parameters.

Parameters

SFTlv	• SMS format info • See ims_SMSFmtInfo for more information • Bit to check in ParamPresenceMask - **16**
SINTlv	• SMS over IP network info • see ims_SMSoIPNwInfo for more information • Bit to check in ParamPresenceMask - **17**
PCURTlv	• Phone context URI info • see ims_PhCtxtURIInfo for more information • Bit to check in ParamPresenceMask - **18**

Note

: None

8.715.2 Field Documentation

8.715.2.1 swi_uint256_t unpack_ims_SLQSSMSCfgCallBack_ind_t::ParamPresenceMask

8.715.2.2 ims_PhCtxtURIInfo unpack_ims_SLQSSMSCfgCallBack_ind_t::PCURTlv

8.715.2.3 ims_SMSFmtInfo unpack_ims_SLQSSMSCfgCallBack_ind_t::SFTlv

8.715.2.4 ims_SMSoIPNwInfo unpack_ims_SLQSSMSCfgCallBack_ind_t::SINTlv

8.716 unpack_ims_SLQSUserCfgCallBack_ind_t Struct Reference

Data Fields

- ims_IMSDomainInfo IDTlv
- swi_uint256_t ParamPresenceMask

8.716.1 Detailed Description

Structure used to store SMS Config Indication Parameters.

Parameters

IDTlv	• IMS domain info • See ims_IMSDomainInfo for more information • Bit to check in ParamPresenceMask - **16**

Note

: None

8.716.2 Field Documentation

8.716.2.1 ims_IMSDomainInfo unpack_ims_SLQSUserCfgCallBack_ind_t::IDTlv

8.716.2.2 swi_uint256_t unpack_ims_SLQSUserCfgCallBack_ind_t::ParamPresenceMask

8.717 unpack_ims_SLQSVoIPCfgCallBack_ind_t Struct Reference

Data Fields

- ims_SessDurInfo SDTlv
- ims_MinSessExpInfo MSETlv
- ims_EnabAMRWBInfo EAWTlv
- ims_EnabSCRAMRInfo ESATlv
- ims_EnabSCRAMRWBInfo ESAWTlv
- ims_AMRModeInfo AMTlv
- ims_AMRWBModeInfo AWMTlv
- ims_AMROctAlgnInfo AOATlv
- ims_AMRWBOctAlgnInfo AWOATlv
- ims_RngTmrInfo RTTlv
- ims_RngBkTmrInfo RBTTlv
- ims_RTPRTCPInactTmrDurInfo RTIDTlv
- swi_uint256_t ParamPresenceMask

8.717.1 Detailed Description

Structure used to store VOIP Config Indication Parameters.

Parameters

SDTlv	• Session Duration tlv • See ims_SessDurInfo for more information • Bit to check in ParamPresenceMask - **16**
MSETlv	• Minimum Session Timer tlv • see ims_MinSessExpInfo for more information • Bit to check in ParamPresenceMask - **17**
EAWTlv	• Enable AMR WB tlv • see ims_EnabAMRWBInfo for more information • Bit to check in ParamPresenceMask - **18**
ESATlv	• Enable SCR AMR NB tlv • see ims_EnabSCRAMRInfo for more information • Bit to check in ParamPresenceMask - **19**

ESAWTlv	• Enable SCR AMR WB tlv • see ims_EnabSCRAMRWBInfo for more information • Bit to check in ParamPresenceMask - **20**
AMTlv	• AMR NB Mode tlv • see ims_AMRModeInfo for more information • Bit to check in ParamPresenceMask - **21**
AWMTlv	• AMR WB Mode Tlv • see ims_AMRWBModeInfo for more information • Bit to check in ParamPresenceMask - **22**
AOATlv	• AMR NB Octet Aligned tlv • see ims_AMROctAlgnInfo for more information • Bit to check in ParamPresenceMask - **23**
AWOATlv	• AMR WB Octet Aligned tlv • see ims_AMRWBOctAlgnInfo for more information • Bit to check in ParamPresenceMask - **24**
RTTlv	• Ringing Timer Duration tlv • see ims_RngTmrInfo for more information • Bit to check in ParamPresenceMask - **25**
RBTTlv	• Ringback Duration tlv • see ims_RngBkTmrInfo for more information • Bit to check in ParamPresenceMask - **26**
RTIDTlv	• RTP/RTCP Inactivity Timer Duration Tlv • see ims_RTPRTCPInactTmrDurInfo for more information • Bit to check in ParamPresenceMask - **27**

Note

: None

8.717.2 Field Documentation

8.717.2.1 ims_AMRModeInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::AMTlv

8.717.2.2 ims_AMROctAlgnInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::AOATlv

8.717.2.3 ims_AMRWBModeInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::AWMTlv

8.717.2.4 ims_AMRWBOctAlgnInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::AWOATlv

8.717.2.5 ims_EnabAMRWBInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::EAWTlv

8.717.2.6 ims_EnabSCRAMRInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::ESATlv

8.717.2.7 ims_EnabSCRAMRWBInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::ESAWTlv

8.717.2.8 ims_MinSessExpInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::MSETlv

8.717.2.9 swi_uint256_t unpack_ims_SLQSVoIPCfgCallBack_ind_t::ParamPresenceMask

8.717.2.10 ims_RngBkTmrInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::RBTTlv

8.717.2.11 ims_RTPRTCPInactTmrDurInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::RTIDTlv

8.717.2.12 ims_RngTmrInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::RTTlv

8.717.2.13 ims_SessDurInfo unpack_ims_SLQSVoIPCfgCallBack_ind_t::SDTlv

8.718 unpack_imsa_SLQSGetIMSARegStatus_t Struct Reference

Data Fields

- uint8_t ImsRegStatus
- uint16_t ImsRegErrCode
- uint32_t NewImsRegStatus
- swi_uint256_t ParamPresenceMask

8.718.1 Detailed Description

This structure contains response parameters of registration status.

Parameters

ImsRegStatus	• IMS Registration Status (Deprecated). • Values – TRUE - UE is registered on the IMS network – FALSE - UE is not registered on the IMS network • Bit to check in ParamPresenceMask - **16**
ImsRegErrCode	• IMS Registration Error Code. • An error code is returned when the IMS registration status is IMSA_STATUS_NOT_REGISTERED. -Values – 3xx - Redirection responses – 4xx - Client failure responses – 5xx - Server failure responses – 6xx - Global failure responses • Bit to check in ParamPresenceMask - **17**

NewImsReg-Status	• New IMS Registration Status • Values – 0 - Not registered for IMS – 1 - Registering for IMS – 2 - Registered for IMS • Bit to check in ParamPresenceMask - **18**

8.718.2 Field Documentation

8.718.2.1 uint16_t unpack_imsa_SLQSGetIMSARegStatus_t::ImsRegErrCode

8.718.2.2 uint8_t unpack_imsa_SLQSGetIMSARegStatus_t::ImsRegStatus

8.718.2.3 uint32_t unpack_imsa_SLQSGetIMSARegStatus_t::NewImsRegStatus

8.718.2.4 swi_uint256_t unpack_imsa_SLQSGetIMSARegStatus_t::ParamPresenceMask

8.719 unpack_imsa_SLQSGetIMSAServiceStatus_t Struct Reference

Data Fields

- uint32_t SmsServiceStatus
- uint32_t VoipServiceStatus
- uint32_t VtServiceStatus
- uint32_t SmsServiceRat
- uint32_t VoipServiceRat
- uint32_t VtServiceRat
- uint32_t UtServiceStatus
- uint32_t UtServiceRat
- uint32_t VsServiceStatus
- uint32_t VsServiceRat
- swi_uint256_t ParamPresenceMask

8.719.1 Detailed Description

This structure contains response parameters of service status for various IMS services.

Parameters

SmsService-Status	• SMS Service Status. • Values – 0 - IMS SMS service is not available – 1 - IMS SMS is in limited service – 2 - IMS SMS is in full service • Bit to check in ParamPresenceMask - **16**

VoipSeriveStatus	• VoIP Service Status. • Values – 0 - IMS VoIP service is not available – 2 - IMS VoIP is in full service • Bit to check in ParamPresenceMask - **17**
VtServiceStatus	• VT Service Status • Values – 0 - IMS VT service is not available – 2 - IMS VT is in full service • Bit to check in ParamPresenceMask - **18**
SmsServiceRat	• SMS service RAT • Values – 0 - IMS service is registered on WLAN – 1 - IMS service is registered on WWAN – 2 - IMS service is registered on interworking WLAN • Bit to check in ParamPresenceMask - **19**
VoipServiceRat	• VoIP service RAT. • Values – 0 - IMS service is registered on WLAN – 1 - IMS service is registered on WWAN – 2 - IMS service is registered on interworking WLAN • Bit to check in ParamPresenceMask - **20**
VtServiceRat	• VT service RAT. • Values – 0 - IMS service is registered on WLAN – 1 - IMS service is registered on WWAN – 2 - IMS service is registered on interworking WLAN • Bit to check in ParamPresenceMask - **21**
UtServiceStatus	• UT service Status. • Values – 0 - IMS UT service is not available – 2 - IMS UT is in full service • Bit to check in ParamPresenceMask - **22**

UtServiceRat	• UT service RAT. • Values – 0 - IMS service is registered on WLAN – 1 - IMS service is registered on WWAN – 2 - IMS service is registered on interworking WLAN • Bit to check in ParamPresenceMask - **23**
VsServiceStatus	• VS service Status. • Values – 0 - IMS UT service is not available – 2 - IMS UT is in full service • Bit to check in ParamPresenceMask - **24**
VsServiceRat	• VS service RAT. • Values – 0 - IMS service is registered on WLAN – 1 - IMS service is registered on WWAN – 2 - IMS service is registered on interworking WLAN • Bit to check in ParamPresenceMask - **25**

8.719.2 Field Documentation

8.719.2.1 swi_uint256_t unpack_imsa_SLQSGetIMSAServiceStatus_t::ParamPresenceMask

8.719.2.2 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::SmsServiceRat

8.719.2.3 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::SmsServiceStatus

8.719.2.4 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::UtServiceRat

8.719.2.5 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::UtServiceStatus

8.719.2.6 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VoipServiceRat

8.719.2.7 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VoipServiceStatus

8.719.2.8 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VsServiceRat

8.719.2.9 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VsServiceStatus

8.719.2.10 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VtServiceRat

8.719.2.11 uint32_t unpack_imsa_SLQSGetIMSAServiceStatus_t::VtServiceStatus

8.720 unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t Struct Reference

Data Fields

- uint8_t PdpConnState
- imsa_IMSFailErrCodeTlv FailErrCode
- swi_uint256_t ParamPresenceMask

8.720.1 Detailed Description

Structure used to store IMSA PDP status indication Parameters.

Parameters

PdpConnState	• Values: – 0- not connected – 1- connected • Bit to check in ParamPresenceMask - **1**
FailErrCode	• Fail error code when PDP is not connected • See imsa_IMSFailErrCodeTlv for more information • Bit to check in ParamPresenceMask - **16**

Note

: None

8.720.2 Field Documentation

8.720.2.1 imsa_IMSFailErrCodeTlv unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t::FailErrCode

8.720.2.2 swi_uint256_t unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t::ParamPresenceMask

8.720.2.3 uint8_t unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t::PdpConnState

8.721 unpack_imsa_SLQSImsaRatStatusCallBack_ind_t Struct Reference

Data Fields

- imsa_RatHandoverStatusInfo RatHandover
- swi_uint256_t ParamPresenceMask

8.721.1 Detailed Description

Structure used to store IMSA RAT status indication Parameters.

Parameters

RatHandover	• RAT handover status info • See imsa_RatHandoverStatusInfo for more information • Bit to check in ParamPresenceMask - **16**

Note

: None

8.721.2 Field Documentation

8.721.2.1 swi_uint256_t unpack_imsa_SLQSImsaRatStatusCallBack_ind_t::ParamPresenceMask

8.721.2.2 imsa_RatHandoverStatusInfo unpack_imsa_SLQSImsaRatStatusCallBack_ind_t::RatHandover

8.722 unpack_imsa_SLQSImsaRegStatusCallBack_ind_t Struct Reference

Data Fields

- imsa_IMSRegStatusInfo IMSRegistration
- imsa_IMSRegStatusErrorCodeInfo IMSRegistrationError
- imsa_NewIMSRegStatusInfo NewIMSRegistration
- swi_uint256_t ParamPresenceMask

8.722.1 Detailed Description

Structure used to store IMSA registration status indication Parameters.

Parameters

IMSRegistration	• IMS registration info • See imsa_IMSRegStatusInfo for more information • Bit to check in ParamPresenceMask - **1**
IMSRegistration-Error	• IMS registration error • see imsa_IMSRegStatusErrorCodeInfo for more information • Bit to check in ParamPresenceMask - **16**
NewIMS-Registration	• New IMS registration info • see imsa_NewIMSRegStatusInfo for more information • Bit to check in ParamPresenceMask - **17**

Note

: None

8.722.2 Field Documentation

8.722.2.1 imsa_IMSRegStatusInfo unpack_imsa_SLQSImsaRegStatusCallBack_ind_t::IMSRegistration

8.722.2.2 imsa_IMSRegStatusErrorCodeInfo unpack_imsa_SLQSImsaRegStatusCallBack_ind_t::IMSRegistrationError

8.722.2.3 imsa_NewIMSRegStatusInfo unpack_imsa_SLQSImsaRegStatusCallBack_ind_t::NewIMSRegistration

8.722.2.4 swi_uint256_t unpack_imsa_SLQSImsaRegStatusCallBack_ind_t::ParamPresenceMask

8.723 unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t Struct Reference

Data Fields

- imsa_SmsSvcStatusInfo SmsService
- imsa_VoipSvcStatusInfo VoipService
- imsa_VtSvcStatusInfo VtService
- imsa_SmsRatInfo SmsRat
- imsa_VoipRatInfo VoipRat
- imsa_VtRatInfo VtRat
- imsa_UtSvcStatusInfo UtService
- imsa_UtRatInfo UtRat
- swi_uint256_t ParamPresenceMask

8.723.1 Detailed Description

Structure used to store IMSA service status indication Parameters.

Parameters

SmsService	• SMS service info • See imsa_SmsSvcStatusInfo for more information • Bit to check in ParamPresenceMask - **16**
VoipService	• VOIP service info • see imsa_VoipSvcStatusInfo for more information • Bit to check in ParamPresenceMask - **17**
VtService	• VT service info • see imsa_VtSvcStatusInfo for more information • Bit to check in ParamPresenceMask - **18**
SmsRat	• SMS RAT info • see imsa_SmsRatInfo for more information • Bit to check in ParamPresenceMask - **19**
VoipRat	• VOIP RAT info • see imsa_VoipRatInfo for more information • Bit to check in ParamPresenceMask - **20**
VtRat	• VT RAT info • see imsa_VtRatInfo for more information • Bit to check in ParamPresenceMask - **21**

UtService	• UT service info • see imsa_UtSvcStatusInfo for more information • Bit to check in ParamPresenceMask - **22**
UtRat	• UT RAT info • see imsa_UtRatInfo for more information • Bit to check in ParamPresenceMask - **23**

Note

: None

8.723.2 Field Documentation

8.723.2.1 swi_uint256_t unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t::ParamPresenceMask

8.723.2.2 imsa_SmsRatInfo unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t::SmsRat

8.723.2.3 imsa_SmsSvcStatusInfo unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t::SmsService

8.723.2.4 imsa_UtRatInfo unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t::UtRat

8.723.2.5 imsa_UtSvcStatusInfo unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t::UtService

8.723.2.6 imsa_VoipRatInfo unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t::VoipRat

8.723.2.7 imsa_VoipSvcStatusInfo unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t::VoipService

8.723.2.8 imsa_VtRatInfo unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t::VtRat

8.723.2.9 imsa_VtSvcStatusInfo unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t::VtService

8.724 unpack_loc_BestAvailPos_Ind_t Struct Reference

Data Fields

- uint32_t status
- uint32_t * pXid
- uint64_t * pLatitude
- uint64_t * pLongitude
- uint32_t * pHorUncCircular
- uint32_t * pAltitudeWrtEllipsoid
- uint32_t * pVertUnc
- uint64_t * pTimestampUtc
- uint32_t * pTimeUnc
- uint32_t * pHorUncEllipseSemiMinor
- uint32_t * pHorUncEllipseSemiMajor
- uint32_t * pHorUncEllipseOrientAzimuth
- uint8_t * pHorCirConf
- uint8_t * pHorEllpConf

- uint32_t * pHorReliability
- uint32_t * pSpeedHorizontal
- uint32_t * pSpeedUnc
- uint32_t * pAltitudeWrtMeanSeaLevel
- uint8_t * pVertConfidence
- uint32_t * pVertReliability
- uint32_t * pSpeedVertical
- uint32_t * pSpeedVerticalUnc
- uint32_t * pHeading
- uint32_t * pHeadingUnc
- uint32_t * pMagneticDeviation
- uint32_t * pTechnologyMask
- loc_precisionDilution * pPrecisionDilution
- loc_gpsTime * pGpsTime
- uint32_t * pTimeSrc
- loc_sensorDataUsage * pSensorDataUsage
- loc_svUsedforFix * pSvUsedforFix
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.724.1 Detailed Description

This structure contains Best Available Position

Parameters

status	• Valid values: – eQMI_LOC_SUCCESS (0) - Request was completed successfully – eQMI_LOC_GENERAL_FAILURE (1) - Request failed because of a general failure – eQMI_LOC_UNSUPPORTED (2) - Request failed because it is not supported – eQMI_LOC_INVALID_PARAMETER (3) - Request failed because it contained invalid parameters – eQMI_LOC_ENGINE_BUSY (4) - Request failed because the engine is busy – eQMI_LOC_PHONE_OFFLINE (5) - Request failed because the phone is offline – eQMI_LOC_TIMEOUT (6) - Request failed because it timed out – eQMI_LOC_CONFIG_NOT_SUPPORTED (7) - Request failed because an undefined configuration was requested – eQMI_LOC_INSUFFICIENT_MEMORY (8) - Request failed because the engine could not allocate sufficient memory for the request – eQMI_LOC_MAX_GEOFENCE_PROGRAMMED (9) - Request failed because the maximum number of Geofences are already programmed – eQMI_LOC_XTRA_VERSION_CHECK_FAILURE (10) - Location service failed because of an XTRA version-based file format check failure • Bit to check in ParamPresenceMask - **1**
xid	Transaction ID that was specified in the Get Best Available Position request. • Bit to check in ParamPresenceMask - **16**

pLatitude	• Latitude (specified in WGS84 datum) • Type - Floating point • Units - Degrees • Range - -90.0 to 90.0 • Positive values indicate northern latitude • Negative values indicate southern latitude • Bit to check in ParamPresenceMask - **17**
pLongitude	• Longitude (specified in WGS84 datum) • Type - Floating point • Units - Degrees • Range - -180.0 to 180.0 • Positive values indicate eastern latitude • Negative values indicate western latitude • Bit to check in ParamPresenceMask - **18**
pHorUncCircular	• Horizontal position uncertainty. • Units - Meters • Bit to check in ParamPresenceMask - **19**
pAltitudeWrt-Ellipsoid	• Altitude With Respect to WGS84 Ellipsoid. • Units - Meters • Range -500 to 15883 • Bit to check in ParamPresenceMask - **20**
pVertUnc	• Vertical uncertainty. • Units - Meters • Bit to check in ParamPresenceMask - **21**
pTimestampUtc	• UTC timestamp • Units - Milliseconds since Jan. 1, 1970 • Bit to check in ParamPresenceMask - **22**
pTimeUnc	• Time uncertainty. • Units - Milliseconds • Bit to check in ParamPresenceMask - **23**
pHorUncEllipse-SemiMinor	• Semi-minor axis of horizontal elliptical uncertainty. • Units - Meters • Bit to check in ParamPresenceMask - **24**

pHorUncEllipse-SemiMajor	• Semi-major axis of horizontal elliptical uncertainty. • Units: Meters • Bit to check in ParamPresenceMask - **25**
pHorUncEllipse-OrientAzimuth	• Elliptical horizontal uncertainty azimuth of orientation. • Units - Decimal degrees • Range - 0 to 180 • Bit to check in ParamPresenceMask - **26**
pHorCirConf	• Horizontal circular uncertainty confidence • Units: Precent • Range: 0 to 99 • Bit to check in ParamPresenceMask - **27**
pHorEllpConf	• Horizontal elliptical uncertainty confidence • Units: Precent • Range: 0 to 99 • Bit to check in ParamPresenceMask - **28**
pHorReliability	• Values – 0 - Location reliability is not set. – 1 - Location reliability is very low; use it at your own risk – 2 - Location reliability is low; little or no cross-checking is possible. – 3 - Location reliability is medium; limited cross-check passed – 4 - Location reliability is high; strong cross-check passed • Bit to check in ParamPresenceMask - **29**
pSpeed-Horizontal	• Horizontal speed. • Units - Meters/second • Bit to check in ParamPresenceMask - **30**
pSpeedUnc	• 3-D Speed uncertainty. • Units - Meters/second. • Bit to check in ParamPresenceMask - **31**
pAltitudeWrt-MeanSeaLevel	• Altitude With Respect to Sea Level. • Units - Meters • Bit to check in ParamPresenceMask - **32**

pVertConfidence	• Vertical uncertainty confidence. • Units - Percentage • Range 0 to 99 • Bit to check in ParamPresenceMask - **33**
pVertReliability	• Values – 0 - Location reliability is not set. – 1 - Location reliability is very low; use it at your own risk. – 2 - Location reliability is low; little or no cross-checking is possible – 3 - Location reliability is medium; limited cross-check passed – 4 - Location reliability is high; strong cross-check passed • Bit to check in ParamPresenceMask - **34**
pSpeedVertical	• Vertical speed. • Units - Meters/second • Bit to check in ParamPresenceMask - **35**
pSpeedVertical-Unc	• Veritical speed • Units: Meters/second • Bit to check in ParamPresenceMask - **36**
pHeading	• Heading. • Units - Degree • Range 0 to 359.999 • Bit to check in ParamPresenceMask - **37**
pHeadingUnc	• Heading uncertainty. • Units - Degree • Range 0 to 359.999 • Bit to check in ParamPresenceMask - **38**
pMagnetic-Deviation	• Difference between the bearing to true north and the bearing shown on a magnetic compass. The deviation is positive when the magnetic north is east of true north. • Bit to check in ParamPresenceMask - **39**

pTechnology-Mask	• Values – 0x00000001 - Satellites were used to generate the fix – 0x00000002 - Cell towers were used to generate the fix – 0x00000004 - Wi-Fi access points were used to generate the fix – 0x00000008 - Sensors were used to generate the fix – 0x00000010 - Reference Location was used to generate the fix – 0x00000020 - Coarse position injected into the location engine was used to generate the fix – 0x00000040 - AFLT was used to generate the fix – 0x00000080 - GNSS and network-provided measurements were used to generate the fix • Bit to check in ParamPresenceMask - **40**
-pPrecision-Dilution	• See loc_precisionDilution for more information • Bit to check in ParamPresenceMask - **41**
-pGpsTime	• See loc_gpsTime for more information • Bit to check in ParamPresenceMask - **42**
pTimeSrc	• Values – 0 - Invalid time. – 1 - Time is set by the 1X system. – 2 - Time is set by WCDMA/GSM time tagging. – 3 - Time is set by an external injection. – 4 - Time is set after decoding over-the-air GPS navigation data from one GPS satellite. – 5 - Time is set after decoding over-the-air GPS navigation data from multiple satellites. – 6 - Both time of the week and the GPS week number are known. – 7 - Time is set by the position engine after the fix is obtained – 8 - Time is set by the position engine after performing SFT, this is done when the clock time uncertainty is large. – 9 - Time is set after decoding GLO satellites. – 10- Time is set after transforming the GPS to GLO time – 11- Time is set by the sleep time tag provided by the WCDMA network. – 12- Time is set by the sleep time tag provided by the GSM network – 13- Source of the time is unknown – 14- Time is derived from the system clock (better known as the slow clock); GNSS time is maintained irrespective of the GNSS receiver state – 15- Time is set after decoding QZSS satellites. – 16- Time is set after decoding BDS satellites. • Bit to check in ParamPresenceMask - **43**
-pSensorData-Usage	• See loc_sensorDataUsage for more information • Bit to check in ParamPresenceMask - **44**
-pSvUsedforFix	• See loc_svUsedforFix for more information • Bit to check in ParamPresenceMask - **45**

8.724.2 Field Documentation

8.724.2.1 uint32_t* unpack_loc_BestAvailPos_Ind_t::pAltitudeWrtEllipsoid

8.724.2.2 uint32_t* unpack_loc_BestAvailPos_Ind_t::pAltitudeWrtMeanSeaLevel

8.724.2.3 swi_uint256_t unpack_loc_BestAvailPos_Ind_t::ParamPresenceMask

8.724.2.4 loc_gpsTime* unpack_loc_BestAvailPos_Ind_t::pGpsTime

8.724.2.5 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHeading

8.724.2.6 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHeadingUnc

8.724.2.7 uint8_t* unpack_loc_BestAvailPos_Ind_t::pHorCirConf

8.724.2.8 uint8_t* unpack_loc_BestAvailPos_Ind_t::pHorEllpConf

8.724.2.9 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHorReliability

8.724.2.10 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHorUncCircular

8.724.2.11 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHorUncEllipseOrientAzimuth

8.724.2.12 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHorUncEllipseSemiMajor

8.724.2.13 uint32_t* unpack_loc_BestAvailPos_Ind_t::pHorUncEllipseSemiMinor

8.724.2.14 uint64_t* unpack_loc_BestAvailPos_Ind_t::pLatitude

8.724.2.15 uint64_t* unpack_loc_BestAvailPos_Ind_t::pLongitude

8.724.2.16 uint32_t* unpack_loc_BestAvailPos_Ind_t::pMagneticDeviation

8.724.2.17 loc_precisionDilution* unpack_loc_BestAvailPos_Ind_t::pPrecisionDilution

8.724.2.18 loc_sensorDataUsage* unpack_loc_BestAvailPos_Ind_t::pSensorDataUsage

8.724.2.19 uint32_t* unpack_loc_BestAvailPos_Ind_t::pSpeedHorizontal

8.724.2.20 uint32_t* unpack_loc_BestAvailPos_Ind_t::pSpeedUnc

8.724.2.21 uint32_t* unpack_loc_BestAvailPos_Ind_t::pSpeedVertical

8.724.2.22 uint32_t* unpack_loc_BestAvailPos_Ind_t::pSpeedVerticalUnc

8.724.2.23 loc_svUsedforFix* unpack_loc_BestAvailPos_Ind_t::pSvUsedforFix

8.724.2.24 uint32_t* unpack_loc_BestAvailPos_Ind_t::pTechnologyMask

8.724.2.25 uint32_t* unpack_loc_BestAvailPos_Ind_t::pTimeSrc

8.724.2.26 uint64_t* unpack_loc_BestAvailPos_Ind_t::pTimestampUtc

8.724.2.27 uint32_t* unpack_loc_BestAvailPos_Ind_t::pTimeUnc

8.724.2.28 uint8_t* unpack_loc_BestAvailPos_Ind_t::pVertConfidence

8.724.2.29 uint32_t* unpack_loc_BestAvailPos_Ind_t::pVertReliability

8.724.2.30 uint32_t* unpack_loc_BestAvailPos_Ind_t::pVertUnc

8.724.2.31 uint32_t* unpack_loc_BestAvailPos_Ind_t::pXid

8.724.2.32 uint32_t unpack_loc_BestAvailPos_Ind_t::status

8.724.2.33 uint16_t unpack_loc_BestAvailPos_Ind_t::Tlvresult

8.725 unpack_loc_CradleMountCallback_Ind_t Struct Reference

Data Fields

- uint32_t cradleMountConfigStatus
- swi_uint256_t ParamPresenceMask

8.725.1 Detailed Description

This structure contains LOC Cradle Mount Config Status

Parameters

cradleMount-ConfigStatus	• Values – 0 - Request was completed successfully – 1 - Request failed because of a general failure. – 2 - Request failed because it is not supported. – 3 - Request failed because it contained invalid parameters – 4 - Request failed because the engine is busy – 5 - Request failed because the phone is offline – 6 - Request failed because it timed out – 7 - Request failed because an undefined configuration was requested – 8 - engine could not allocate sufficient memory – 9 - Request failed because the maximum number of Geofences are already programmed – 10 -Location service failed because of an XTRA version-based file format check failure • Bit to check in ParamPresenceMask - **1**

8.725.2 Field Documentation

8.725.2.1 uint32_t unpack_loc_CradleMountCallback_Ind_t::cradleMountConfigStatus

8.725.2.2 swi_uint256_t unpack_loc_CradleMountCallback_Ind_t::ParamPresenceMask

8.726 unpack_loc_Delete_Assist_Data_t Struct Reference

Data Fields

- uint16_t Tlvresult

- swi_uint256_t ParamPresenceMask

8.726.1 Detailed Description

This structure contains LOC delete assist data unpack

Parameters

Tlvresult	• Unpack result. • Bit to check in ParamPresenceMask - **2**

8.726.2 Field Documentation

8.726.2.1 swi_uint256_t unpack_loc_Delete_Assist_Data_t::ParamPresenceMask

8.726.2.2 uint16_t unpack_loc_Delete_Assist_Data_t::Tlvresult

8.727 unpack_loc_DeleteAssistData_Ind_t Struct Reference

Data Fields

- uint32_t status
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.727.1 Detailed Description

Contain the parameters passed for SetLocDeleteAssistDataCallback by the device.

Parameters

status	• Status of the Delete Assist Data request • Valid values: – eQMI_LOC_SUCCESS (0) - Request was completed successfully – eQMI_LOC_GENERAL_FAILURE (1) - Request failed because of a general failure – eQMI_LOC_UNSUPPORTED (2) - Request failed because it is not supported – eQMI_LOC_INVALID_PARAMETER (3) - Request failed because it contained invalid parameters – eQMI_LOC_ENGINE_BUSY (4) - Request failed because the engine is busy – eQMI_LOC_PHONE_OFFLINE (5) - Request failed because the phone is offline – eQMI_LOC_TIMEOUT (6) - Request failed because it timed out – eQMI_LOC_CONFIG_NOT_SUPPORTED (7) - Request failed because an undefined configuration was requested – eQMI_LOC_INSUFFICIENT_MEMORY (8) - Request failed because the engine could not allocate sufficient memory for the request – eQMI_LOC_MAX_GEOFENCE_PROGRAMMED (9) - Request failed because the maximum number of Geofences are already programmed – eQMI_LOC_XTRA_VERSION_CHECK_FAILURE (10) - Location service failed because of an XTRA version-based file format check failure • Bit to check in ParamPresenceMask - **1**
TlvResult	• unpack result

8.727.2 Field Documentation

8.727.2.1 swi_uint256_t unpack_loc_DeleteAssistData_Ind_t::ParamPresenceMask

8.727.2.2 uint32_t unpack_loc_DeleteAssistData_Ind_t::status

8.727.2.3 uint16_t unpack_loc_DeleteAssistData_Ind_t::TlvResult

8.728 unpack_loc_EngineState_Ind_t Struct Reference

Data Fields

- uint32_t engineState
- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.728.1 Detailed Description

This structure contains LOC Engine State field.

Parameters

engineState	• Location engine state. • Valid values – 1 - Location engine is on – 2 - Loction engine is off • Bit to check in ParamPresenceMask - **1**
TlvResult	• unpack result

8.728.2 Field Documentation

8.728.2.1 uint32_t unpack_loc_EngineState_Ind_t::engineState

8.728.2.2 swi_uint256_t unpack_loc_EngineState_Ind_t::ParamPresenceMask

8.728.2.3 uint16_t unpack_loc_EngineState_Ind_t::TlvResult

8.729 unpack_loc_EventNMEA_Ind_t Struct Reference

Data Fields

- char NMEAData [201]
- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.729.1 Detailed Description

Contain the parameters passed for SetLocEventMaskNMEACallback by the device.

Parameters

NMEAData	• NMEA string • Type - NULL terminated string • Maximum string length (including NULL terminator) - 201 • Bit to check in ParamPresenceMask - **1**
TlvResult	• unpack result

8.729.2 Field Documentation

8.729.2.1 char unpack_loc_EventNMEA_Ind_t::NMEAData[201]

8.729.2.2 swi_uint256_t unpack_loc_EventNMEA_Ind_t::ParamPresenceMask

8.729.2.3 uint16_t unpack_loc_EventNMEA_Ind_t::TlvResult

8.730 unpack_loc_EventRegister_t Struct Reference

Data Fields

- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.730.1 Detailed Description

This structure contains Event Register unpack

Parameters

TlvResult	• Unpack result. • Bit to check in ParamPresenceMask - **2**

8.730.2 Field Documentation

8.730.2.1 swi_uint256_t unpack_loc_EventRegister_t::ParamPresenceMask

8.730.2.2 uint16_t unpack_loc_EventRegister_t::TlvResult

8.731 unpack_loc_EventTimeSyncCallback_Ind_t Struct Reference

Data Fields

- uint32_t timeSyncRefCounter
- swi_uint256_t ParamPresenceMask

8.731.1 Detailed Description

This structure contains LOC Event Time Sync Reference COunter

Parameters

timeSyncRef-Counter	• Sent by the location engine when it needs to synchronize location engine and control point (sensor processor) times. • Bit to check in ParamPresenceMask - **1**

8.731.2 Field Documentation

8.731.2.1 swi_uint256_t unpack_loc_EventTimeSyncCallback_Ind_t::ParamPresenceMask

8.731.2.2 uint32_t unpack_loc_EventTimeSyncCallback_Ind_t::timeSyncRefCounter

8.732 unpack_loc_GetServer_Ind_t Struct Reference

Data Fields

- uint32_t serverStatus
- uint32_t serverType
- loc_IPv4Info * pIPv4AddrInfo
- loc_IPv6Info * pIPv6AddrInfo
- loc_urlAddr * pURL
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.732.1 Detailed Description

Contain the parameters passed for SetLocGetServerCallback by the device.

Parameters

serverStatus	• Status of the Get Server request. • Valid values – eQMI_LOC_SUCCESS (0) - Request was completed successfully – eQMI_LOC_GENERAL_FAILURE (1) - Request failed because of a general failure – eQMI_LOC_UNSUPPORTED (2) - Request failed because it is not supported – eQMI_LOC_INVALID_PARAMETER (3) - Request failed because it contained invalid parameters – eQMI_LOC_ENGINE_BUSY (4) - Request failed because the engine is busy – eQMI_LOC_PHONE_OFFLINE (5) - Request failed because the phone is offline – eQMI_LOC_TIMEOUT (6) - Request failed because it timed out – eQMI_LOC_CONFIG_NOT_SUPPORTED (7) - Request failed because an undefined configuration was requested – eQMI_LOC_INSUFFICIENT_MEMORY (8) - Request failed because the engine could not allocate sufficient memory for the request – eQMI_LOC_MAX_GEOFENCE_PROGRAMMED (9) - Request failed because the maximum number of Geofences are already programmed – eQMI_LOC_XTRA_VERSION_CHECK_FAILURE (10) - Location service failed because of an XTRA version-based file format check failure • Bit to check in ParamPresenceMask - **1**
serverType	• Type of server. • Valid values – eQMI_LOC_SERVER_TYPE_CDMA_PDE (1) - Server type is CDMA PDE – eQMI_LOC_SERVER_TYPE_CDMA_MPC (2) - Server type is CDMA MPC – eQMI_LOC_SERVER_TYPE_UMTS_SLP (3) - Server type is UMTS SLP – eQMI_LOC_SERVER_TYPE_CUSTOM_PDE (4) - Server type is custom PDE • Bit to check in ParamPresenceMask - **2**
pIPv4AddrInfo	• See loc_IPv4Info for more information. • Bit to check in ParamPresenceMask - **16**
pIPv6AddrInfo	• See loc_IPv6Info for more information. • Bit to check in ParamPresenceMask - **17**

pURL	• See loc_urlAddr for more information. • Bit to check in ParamPresenceMask - **18**

8.732.2 Field Documentation

8.732.2.1 swi_uint256_t unpack_loc_GetServer_Ind_t::ParamPresenceMask

8.732.2.2 loc_IPv4Info* unpack_loc_GetServer_Ind_t::pIPv4AddrInfo

8.732.2.3 loc_IPv6Info* unpack_loc_GetServer_Ind_t::pIPv6AddrInfo

8.732.2.4 loc_urlAddr* unpack_loc_GetServer_Ind_t::pURL

8.732.2.5 uint32_t unpack_loc_GetServer_Ind_t::serverStatus

8.732.2.6 uint32_t unpack_loc_GetServer_Ind_t::serverType

8.732.2.7 uint16_t unpack_loc_GetServer_Ind_t::Tlvresult

8.733 unpack_loc_GnssSvInfo_Ind_t Struct Reference

Data Fields

- uint8_t altitudeAssumed
- loc_satelliteInfo * pSatelliteInfo
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.733.1 Detailed Description

Contain the parameters passed for SetLocGnssSvInfoCallback by the device.

Parameters

altitudeAssumed	• Indicates whether altitude is assumed or calculated – 0x00 (FALSE) - Valid altitude is calculated – 0x01 (TRUE) - Valid altitude is assumed; there may not be enough satellites to determine precise altitude • Bit to check in ParamPresenceMask - **1**
pSatelliteInfo	• See loc_satelliteInfo for more information. • Bit to check in ParamPresenceMask - **16**
Tlvresult	• unpack result

8.733.2 Field Documentation

8.733.2.1 uint8_t unpack_loc_GnssSvInfo_Ind_t::altitudeAssumed

8.733.2.2 swi_uint256_t unpack_loc_GnssSvInfo_Ind_t::ParamPresenceMask

8.733.2.3 loc_satelliteInfo* unpack_loc_GnssSvInfo_Ind_t::pSatelliteInfo

8.733.2.4 uint16_t unpack_loc_GnssSvInfo_Ind_t::TIvresult

8.734 unpack_loc_InjectPositionCallback_Ind_t Struct Reference

Data Fields

- uint32_t status
- swi_uint256_t ParamPresenceMask

8.734.1 Detailed Description

Contain the parameters passed for LOC Inject Position indication by the device.

Parameters

status	• Position Injection Status • Valid values: – 0 - Request was completed successfully – 1 - Request failed because of a general failure. – 2 - Request failed because it is not supported. – 3 - Request failed because it contained invalid parameters – 4 - Request failed because the engine is busy – 5 - Request failed because the phone is offline – 6 - Request failed because it timed out – 7 - Request failed because an undefined configuration was requested – 8 - engine could not allocate sufficient memory – 9 - Request failed because the maximum number of Geofences are already programmed – 10 -Location service failed because of an XTRA version-based file format check failure • Bit to check in ParamPresenceMask - **1**

Note

None

8.734.2 Field Documentation

8.734.2.1 swi_uint256_t unpack_loc_InjectPositionCallback_Ind_t::ParamPresenceMask

8.734.2.2 uint32_t unpack_loc_InjectPositionCallback_Ind_t::status

8.735 unpack_loc_InjectSensorDataCallback_Ind_t Struct Reference

Data Fields

- uint32_t injectSensorDataStatus
- uint32_t * pOpaqueIdentifier
- uint8_t * pAccelSamplesAccepted
- uint8_t * pGyroSamplesAccepted
- uint8_t * pAccelTempSamplesAccepted
- uint8_t * pGyroTempSamplesAccepted
- swi_uint256_t ParamPresenceMask

8.735.1 Detailed Description

This structure contains LOC Inject Sensor Data

Parameters

injectSensorDataStatus	• Values – 0 - Request was completed successfully – 1 - Request failed because of a general failure. – 2 - Request failed because it is not supported. – 3 - Request failed because it contained invalid parameters – 4 - Request failed because the engine is busy – 5 - Request failed because the phone is offline – 6 - Request failed because it timed out – 7 - Request failed because an undefined configuration was requested – 8 - engine could not allocate sufficient memory – 9 - Request failed because the maximum number of Geofences are already programmed – 10 -Location service failed because of an XTRA version-based file format check failure • Bit to check in ParamPresenceMask - **1**
pOpaqueIdentifier[OPTIONAL]	• Sent in by the client echoed so the client can relate the indication to the request. • NULL when this TLV not present • Bit to check in ParamPresenceMask - **16**
pAccelSamplesAccepted[OPTIONAL]	• Lets the client know how many 3-axis accelerometer samples were accepted. • This field is present only if the accelerometer samples were sent in the request. • NULL when this TLV not present • Bit to check in ParamPresenceMask - **17**
pGyroSamplesAccepted[OPTIONAL]	• Lets the client know how many 3-axis gyroscope samples were accepted. • This field is present only if the gyroscope samples were sent in the request. • NULL when this TLV not present • Bit to check in ParamPresenceMask - **18**
pAccelTempSamplesAccepted[OPTIONAL]	• Lets the client know how many accelerometer temperature samples were accepted. • This field is present only if the accelerometer temperature samples were sent in the request. • NULL when this TLV not present • Bit to check in ParamPresenceMask - **19**

pGyroTemp-Samples-Accepted[OPTI-ONAL]	• Lets the client know how many gyroscope temperature samples were accepted. • This field is present only if the gyroscope temperature samples were sent in the request. • NULL when this TLV not present • Bit to check in ParamPresenceMask - **20**

8.735.2 Field Documentation

8.735.2.1 uint32_t unpack_loc_InjectSensorDataCallback_Ind_t::injectSensorDataStatus

8.735.2.2 uint8_t* unpack_loc_InjectSensorDataCallback_Ind_t::pAccelSamplesAccepted

8.735.2.3 uint8_t* unpack_loc_InjectSensorDataCallback_Ind_t::pAccelTempSamplesAccepted

8.735.2.4 swi_uint256_t unpack_loc_InjectSensorDataCallback_Ind_t::ParamPresenceMask

8.735.2.5 uint8_t* unpack_loc_InjectSensorDataCallback_Ind_t::pGyroSamplesAccepted

8.735.2.6 uint8_t* unpack_loc_InjectSensorDataCallback_Ind_t::pGyroTempSamplesAccepted

8.735.2.7 uint32_t* unpack_loc_InjectSensorDataCallback_Ind_t::pOpaqueIdentifier

8.736 unpack_loc_InjectTimeSyncDataCallback_Ind_t Struct Reference

Data Fields

- uint32_t injectTimeSyncStatus
- swi_uint256_t ParamPresenceMask

8.736.1 Detailed Description

This structure contains LOC Inject Time Sync Data Status

Parameters

injectTimeSync-Status	• Values – 0 - Request was completed successfully – 1 - Request failed because of a general failure. – 2 - Request failed because it is not supported. – 3 - Request failed because it contained invalid parameters – 4 - Request failed because the engine is busy – 5 - Request failed because the phone is offline – 6 - Request failed because it timed out – 7 - Request failed because an undefined configuration was requested – 8 - engine could not allocate sufficient memory – 9 - Request failed because the maximum number of Geofences are already programmed – 10 -Location service failed because of an XTRA version-based file format check failure

- * - Bit to check in ParamPresenceMask - **1**

8.736.2 Field Documentation

8.736.2.1 uint32_t unpack_loc_InjectTimeSyncDataCallback_Ind_t::injectTimeSyncStatus

8.736.2.2 swi_uint256_t unpack_loc_InjectTimeSyncDataCallback_Ind_t::ParamPresenceMask

8.737 unpack_loc_InjectUTCTimeCallback_Ind_t Struct Reference

Data Fields

- uint32_t status
- swi_uint256_t ParamPresenceMask

8.737.1 Detailed Description

Contain the parameters passed for Inject UTC time indication by the device.

Parameters

status	• Status of the UTC Time Injection request • Valid values: – 0 - Request was completed successfully – 1 - Request failed because of a general failure. – 2 - Request failed because it is not supported. – 3 - Request failed because it contained invalid parameters – 4 - Request failed because the engine is busy – 5 - Request failed because the phone is offline – 6 - Request failed because it timed out – 7 - Request failed because an undefined configuration was requested – 8 - engine could not allocate sufficient memory – 9 - Request failed because the maximum number of Geofences are already programmed – 10 -Location service failed because of an XTRA version-based file format check failure • Bit to check in ParamPresenceMask - **1**

Note

None

8.737.2 Field Documentation

8.737.2.1 swi_uint256_t unpack_loc_InjectUTCTimeCallback_Ind_t::ParamPresenceMask

8.737.2.2 uint32_t unpack_loc_InjectUTCTimeCallback_Ind_t::status

8.738 unpack_loc_PositionRpt_Ind_t Struct Reference

Data Fields

- uint32_t sessionStatus
- uint8_t sessionId

- uint64_t * pLatitude
- uint64_t * pLongitude
- uint32_t * pHorUncCircular
- uint32_t * pHorUncEllipseSemiMinor
- uint32_t * pHorUncEllipseSemiMajor
- uint32_t * pHorUncEllipseOrientAzimuth
- uint8_t * pHorConfidence
- uint32_t * pHorReliability
- uint32_t * pSpeedHorizontal
- uint32_t * pSpeedUnc
- uint32_t * pAltitudeWrtEllipsoid
- uint32_t * pAltitudeWrtMeanSeaLevel
- uint32_t * pVertUnc
- uint8_t * pVertConfidence
- uint32_t * pVertReliability
- uint32_t * pSpeedVertical
- uint32_t * pHeading
- uint32_t * pHeadingUnc
- uint32_t * pMagneticDeviation
- uint32_t * pTechnologyMask
- loc_precisionDilution * pPrecisionDilution
- uint64_t * pTimestampUtc
- uint8_t * pLeapSeconds
- loc_gpsTime * pGpsTime
- uint32_t * pTimeUnc
- uint32_t * pTimeSrc
- loc_sensorDataUsage * pSensorDataUsage
- uint32_t * pFixId
- loc_svUsedforFix * pSvUsedforFix
- uint8_t * pAltitudeAssumed
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.738.1 Detailed Description

This structure contains Event Position Report Indication unpack

Parameters

sessionStatus	• Values – 0 - Session was successful – 1 - Session is still in progress; further position reports will be generated until either the fix criteria specified by the client are met or the client response timeout occurs. – 2 - Session failed.. – 3 - Fix request failed because the session timed out. – 4 - Fix request failed because the session was ended by the user. – 5 - Fix request failed due to bad parameters in the request. – 6 - Fix request failed because the phone is offline. – 7 - Fix request failed because the engine is locked • Bit to check in ParamPresenceMask - **1**

sessionId	• ID of the session that was specified in the Start request • Range - 0 to 255 • Bit to check in ParamPresenceMask - **2**
pLatitude	• Latitude (specified in WGS84 datum) • Type - Floating point • Units - Degrees • Range - -90.0 to 90.0 • Positive values indicate northern latitude • Negative values indicate southern latitude • Bit to check in ParamPresenceMask - **16**
pLongitude	• Longitude (specified in WGS84 datum) • Type - Floating point • Units - Degrees • Range - -180.0 to 180.0 • Positive values indicate eastern latitude • Negative values indicate western latitude • Bit to check in ParamPresenceMask - **17**
pHorUncCircular	• Horizontal position uncertainty. • Units - Meters • Bit to check in ParamPresenceMask - **18**
pHorUncEllipse-SemiMinor	• Semi-minor axis of horizontal elliptical uncertainty. • Units - Meters • Bit to check in ParamPresenceMask - **19**
pHorUncEllipse-SemiMajor	• Semi-major axis of horizontal elliptical uncertainty. • Units: Meters • Bit to check in ParamPresenceMask - **20**
pHorUncEllipse-OrientAzimuth	• Elliptical horizontal uncertainty azimuth of orientation. • Units - Decimal degrees • Range - 0 to 180 • Bit to check in ParamPresenceMask - **21**

pHorConfidence	• Horizontal uncertainty confidence. • If both elliptical and horizontal uncertainties are specified in this message, the confidence corresponds to the elliptical uncertainty. • Units - Percentage • Range 0-99 • Bit to check in ParamPresenceMask - **22**
pHorReliability	• Values – 0 - Location reliability is not set. – 1 - Location reliability is very low; use it at your own risk – 2 - Location reliability is low; little or no cross-checking is possible. – 3 - Location reliability is medium; limited cross-check passed – 4 - Location reliability is high; strong cross-check passed

• Bit to check in ParamPresenceMask - **23**

Parameters

pSpeed-Horizontal	• Horizontal speed. • Units - Meters/second • Bit to check in ParamPresenceMask - **24**
pSpeedUnc	• 3-D Speed uncertainty. • Units - Meters/second. • Bit to check in ParamPresenceMask - **25**
pAltitudeWrt-Ellipsoid	• Altitude With Respect to WGS84 Ellipsoid. • Units - Meters • Range -500 to 15883 • Bit to check in ParamPresenceMask - **26**
pAltitudeWrt-MeanSeaLevel	• Altitude With Respect to Sea Level. • Units - Meters • Bit to check in ParamPresenceMask - **27**
pVertUnc	• Vertical uncertainty. • Units - Meters • Bit to check in ParamPresenceMask - **28**
pVertConfidence	• Vertical uncertainty confidence. • Units - Percentage • Range 0 to 99 • Bit to check in ParamPresenceMask - **29**

pVertReliability	• Values – 0 - Location reliability is not set. – 1 - Location reliability is very low; use it at your own risk. – 2 - Location reliability is low; little or no cross-checking is possible – 3 - Location reliability is medium; limited cross-check passed – 4 - Location reliability is high; strong cross-check passed – Bit to check in ParamPresenceMask - **30**
pSpeedVertical	• Vertical speed. • Units - Meters/second • Bit to check in ParamPresenceMask - **31**
pHeading	• Heading. • Units - Degree • Range 0 to 359.999 • Bit to check in ParamPresenceMask - **32**
pHeadingUnc	• Heading uncertainty. • Units - Degree • Range 0 to 359.999 • Bit to check in ParamPresenceMask - **33**
pMagnetic-Deviation	• Difference between the bearing to true north and the bearing shown on a magnetic compass. The deviation is positive when the magnetic north is east of true north. • Bit to check in ParamPresenceMask - **34**
pTechnology-Mask	• Values – 0x00000001 - Satellites were used to generate the fix – 0x00000002 - Cell towers were used to generate the fix – 0x00000004 - Wi-Fi access points were used to generate the fix – 0x00000008 - Sensors were used to generate the fix – 0x00000010 - Reference Location was used to generate the fix – 0x00000020 - Coarse position injected into the location engine was used to generate the fix – 0x00000040 - AFLT was used to generate the fix – 0x00000080 - GNSS and network-provided measurements were used to generate the fix • Bit to check in ParamPresenceMask - **35**
pPrecision-Dilution	• See loc_precisionDilution for more information • Bit to check in ParamPresenceMask - **36**

pTimestampUtc	• UTC timestamp • Units - Milliseconds since Jan. 1, 1970 • Bit to check in ParamPresenceMask - **37**
pLeapSeconds	• Leap second information. If leapSeconds is not available, timestampUtc is calculated based on a hard-coded value for leap seconds. • Units - Seconds • Bit to check in ParamPresenceMask - **38**
pGpsTime	• See loc_gpsTime for more information • Bit to check in ParamPresenceMask - **39**
pTimeUnc	• Time uncertainty. • Units - Milliseconds • Bit to check in ParamPresenceMask - **40**
pTimeSrc	• Values – 0 - Invalid time. – 1 - Time is set by the 1X system. – 2 - Time is set by WCDMA/GSM time tagging. – 3 - Time is set by an external injection. – 4 - Time is set after decoding over-the-air GPS navigation data from one GPS satellite. – 5 - Time is set after decoding over-the-air GPS navigation data from multiple satellites. – 6 - Both time of the week and the GPS week number are known. – 7 - Time is set by the position engine after the fix is obtained – 8 - Time is set by the position engine after performing SFT, this is done when the clock time uncertainty is large. – 9 - Time is set after decoding GLO satellites. – 10- Time is set after transforming the GPS to GLO time – 11- Time is set by the sleep time tag provided by the WCDMA network. – 12- Time is set by the sleep time tag provided by the GSM network – 13- Source of the time is unknown – 14- Time is derived from the system clock (better known as the slow clock); GNSS time is maintained irrespective of the GNSS receiver state – 15- Time is set after decoding QZSS satellites. – 16- Time is set after decoding BDS satellites.

• Bit to check in ParamPresenceMask - **41**

Parameters

pSensorData-Usage	• See loc_sensorDataUsage for more information • Bit to check in ParamPresenceMask - **42**

pFixId	• Fix count for the session. Starts with 0 and increments by one for each successive position report for a particular session. • Bit to check in ParamPresenceMask - **43**
pSvUsedforFix	• See loc_svUsedforFix for more information • Bit to check in ParamPresenceMask - **44**
pAltitude-Assumed	• Indicates whether altitude is assumed or calculated. • Value – 0x00 - Altitude is calculated – 0x01 - Altitude is assumed • Bit to check in ParamPresenceMask - **45**

8.738.2 Field Documentation

8.738.2.1 uint8_t* unpack_loc_PositionRpt_Ind_t::pAltitudeAssumed

8.738.2.2 uint32_t* unpack_loc_PositionRpt_Ind_t::pAltitudeWrtEllipsoid

8.738.2.3 uint32_t* unpack_loc_PositionRpt_Ind_t::pAltitudeWrtMeanSeaLevel

8.738.2.4 swi_uint256_t unpack_loc_PositionRpt_Ind_t::ParamPresenceMask

8.738.2.5 uint32_t* unpack_loc_PositionRpt_Ind_t::pFixId

8.738.2.6 loc_gpsTime* unpack_loc_PositionRpt_Ind_t::pGpsTime

8.738.2.7 uint32_t* unpack_loc_PositionRpt_Ind_t::pHeading

8.738.2.8 uint32_t* unpack_loc_PositionRpt_Ind_t::pHeadingUnc

8.738.2.9 uint8_t* unpack_loc_PositionRpt_Ind_t::pHorConfidence

8.738.2.10 uint32_t* unpack_loc_PositionRpt_Ind_t::pHorReliability

8.738.2.11 uint32_t* unpack_loc_PositionRpt_Ind_t::pHorUncCircular

8.738.2.12 uint32_t* unpack_loc_PositionRpt_Ind_t::pHorUncEllipseOrientAzimuth

8.738.2.13 uint32_t* unpack_loc_PositionRpt_Ind_t::pHorUncEllipseSemiMajor

8.738.2.14 uint32_t* unpack_loc_PositionRpt_Ind_t::pHorUncEllipseSemiMinor

8.738.2.15 uint64_t* unpack_loc_PositionRpt_Ind_t::pLatitude

8.738.2.16 uint8_t* unpack_loc_PositionRpt_Ind_t::pLeapSeconds

8.738.2.17 uint64_t* unpack_loc_PositionRpt_Ind_t::pLongitude

8.738.2.18 uint32_t* unpack_loc_PositionRpt_Ind_t::pMagneticDeviation

8.738.2.19 loc_precisionDilution* unpack_loc_PositionRpt_Ind_t::pPrecisionDilution

8.738.2.20 loc_sensorDataUsage* unpack_loc_PositionRpt_Ind_t::pSensorDataUsage

8.738.2.21 uint32_t* unpack_loc_PositionRpt_Ind_t::pSpeedHorizontal

8.738.2.22 uint32_t* unpack_loc_PositionRpt_Ind_t::pSpeedUnc

8.738.2.23 uint32_t* unpack_loc_PositionRpt_Ind_t::pSpeedVertical

8.738.2.24 loc_svUsedforFix* unpack_loc_PositionRpt_Ind_t::pSvUsedforFix

8.738.2.25 uint32_t* unpack_loc_PositionRpt_Ind_t::pTechnologyMask

8.738.2.26 uint32_t* unpack_loc_PositionRpt_Ind_t::pTimeSrc

8.738.2.27 uint64_t* unpack_loc_PositionRpt_Ind_t::pTimestampUtc

8.738.2.28 uint32_t* unpack_loc_PositionRpt_Ind_t::pTimeUnc

8.738.2.29 uint8_t* unpack_loc_PositionRpt_Ind_t::pVertConfidence

8.738.2.30 uint32_t* unpack_loc_PositionRpt_Ind_t::pVertReliability

8.738.2.31 uint32_t* unpack_loc_PositionRpt_Ind_t::pVertUnc

8.738.2.32 uint8_t unpack_loc_PositionRpt_Ind_t::sessionId

8.738.2.33 uint32_t unpack_loc_PositionRpt_Ind_t::sessionStatus

8.738.2.34 uint16_t unpack_loc_PositionRpt_Ind_t::TIvresult

8.739 unpack_loc_SensorStreamingCallback_Ind_t Struct Reference

Data Fields

- loc_accelAcceptReady * pAccelAcceptReady
- loc_gyroAcceptReady * pGyroAcceptReady
- loc_accelTempAcceptReady * pAccelTempAcceptReady
- loc_gyroTempAcceptReady * pGyroTempAcceptReady
- swi_uint256_t ParamPresenceMask

8.739.1 Detailed Description

This structure contains LOC Event Sensor Streaming Ready Status

Parameters

-pAccelAccept-Ready[OPTION-AL]	• See loc_accelAcceptReady for more information • Bit to check in ParamPresenceMask - **16**

-pGyroAccept-Ready[OPTION-AL]	• See loc_gyroAcceptReady for more information • Bit to check in ParamPresenceMask - **17**
-pAccelTemp-AcceptReady[O-PTIONAL]	• See loc_accelTempAcceptReady for more information • Bit to check in ParamPresenceMask - **18**
-pGyroTemp-AcceptReady[O-PTIONAL]	• See loc_gyroTempAcceptReady for more information • Bit to check in ParamPresenceMask - **19**

8.739.2 Field Documentation

8.739.2.1 loc_accelAcceptReady∗ unpack_loc_SensorStreamingCallback_Ind_t::pAccelAcceptReady

8.739.2.2 loc_accelTempAcceptReady∗ unpack_loc_SensorStreamingCallback_Ind_t::pAccelTempAcceptReady

8.739.2.3 swi_uint256_t unpack_loc_SensorStreamingCallback_Ind_t::ParamPresenceMask

8.739.2.4 loc_gyroAcceptReady∗ unpack_loc_SensorStreamingCallback_Ind_t::pGyroAcceptReady

8.739.2.5 loc_gyroTempAcceptReady∗ unpack_loc_SensorStreamingCallback_Ind_t::pGyroTempAcceptReady

8.740 unpack_loc_SetExtPowerConfig_Ind_t Struct Reference

Data Fields

- uint32_t status
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.740.1 Detailed Description

This structure contains LOC Set External Power Configure status field.

Parameters

status	• Valid values – 0 - Request was completed successfully – 1 - Request failed because of a general failure. – 2 - Request failed because it is not supported. – 3 - Request failed because it contained invalid parameters – 4 - Request failed because the engine is busy – 5 - Request failed because the phone is offline – 6 - Request failed because it timed out – 7 - Request failed because an undefined configuration was requested – 8 - engine could not allocate sufficient memory – 9 - Request failed because the maximum number of Geofences are already programmed – 10 -Location service failed because of an XTRA version-based file format check failure • Bit to check in ParamPresenceMask - **1**
TlvResult	• unpack result

8.740.2 Field Documentation

8.740.2.1 swi_uint256_t unpack_loc_SetExtPowerConfig_Ind_t::ParamPresenceMask

8.740.2.2 uint32_t unpack_loc_SetExtPowerConfig_Ind_t::status

8.740.2.3 uint16_t unpack_loc_SetExtPowerConfig_Ind_t::TlvResult

8.741 unpack_loc_SetExtPowerState_t Struct Reference

Data Fields

- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.741.1 Detailed Description

This structure contains Set Ext Power State unpack

Parameters

TlvResult	• Unpack result. • Bit to check in ParamPresenceMask - **2**

8.741.2 Field Documentation

8.741.2.1 swi_uint256_t unpack_loc_SetExtPowerState_t::ParamPresenceMask

8.741.2.2 uint16_t unpack_loc_SetExtPowerState_t::TlvResult

8.742 unpack_loc_SetOperationMode_Ind_t Struct Reference

Data Fields

- uint32_t status
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.742.1 Detailed Description

This structure contains LOC Set External Power Configure status field.

Parameters

status	• Status of the Set Operation Mode request. • Valid values: – 0 - Request was completed successfully – 1 - Request failed because of a general failure – 2 - Request failed because it is not supported – 3 - Request failed because it contained invalid parameters – 4 - Request failed because the engine is busy – 5 - Request failed because the phone is offline – 6 - Request failed because it timed out – 7 - Request failed because an undefined configuration was requested – 8 - Request failed because the engine could not allocate sufficient memory for the request – 9 - Request failed because the maximum number of Geofences are already programmed – 10 - Location service failed because of an XTRA version-based file format check failure • Bit to check in ParamPresenceMask - **1**
Tlvresult	• unpack result

8.742.2 Field Documentation

8.742.2.1 swi_uint256_t unpack_loc_SetOperationMode_Ind_t::ParamPresenceMask

8.742.2.2 uint32_t unpack_loc_SetOperationMode_Ind_t::status

8.742.2.3 uint16_t unpack_loc_SetOperationMode_Ind_t::Tlvresult

8.743 unpack_loc_SetOperationMode_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.743.1 Detailed Description

This structure contains Set Operation Mode unpack

Parameters

Tlvresult	• Unpack result. • Bit to check in ParamPresenceMask - **2**

8.743.2 Field Documentation

8.743.2.1 swi_uint256_t unpack_loc_SetOperationMode_t::ParamPresenceMask

8.743.2.2 uint16_t unpack_loc_SetOperationMode_t::Tlvresult

8.744 unpack_loc_SetServer_Ind_t Struct Reference

Data Fields

- uint32_t serverStatus
- uint16_t Tlvresult

8.744.1 Detailed Description

Contain the parameters passed for SetLocSetServerCallback by the device.

Parameters

serverStatus	• Status of the Get Server request. • Valid values – eQMI_LOC_SUCCESS (0) - Request was completed successfully – eQMI_LOC_GENERAL_FAILURE (1) - Request failed because of a general failure – eQMI_LOC_UNSUPPORTED (2) - Request failed because it is not supported – eQMI_LOC_INVALID_PARAMETER (3) - Request failed because it contained invalid parameters – eQMI_LOC_ENGINE_BUSY (4) - Request failed because the engine is busy – eQMI_LOC_PHONE_OFFLINE (5) - Request failed because the phone is offline – eQMI_LOC_TIMEOUT (6) - Request failed because it timed out – eQMI_LOC_CONFIG_NOT_SUPPORTED (7) - Request failed because an undefined configuration was requested – eQMI_LOC_INSUFFICIENT_MEMORY (8) - Request failed because the engine could not allocate sufficient memory for the request – eQMI_LOC_MAX_GEOFENCE_PROGRAMMED (9) - Request failed because the maximum number of Geofences are already programmed – eQMI_LOC_XTRA_VERSION_CHECK_FAILURE (10) - Location service failed because of an XTRA version-based file format check failure – 0xffffffff - Invalid data.

8.744.2 Field Documentation

8.744.2.1 uint32_t unpack_loc_SetServer_Ind_t::serverStatus

8.744.2.2 uint16_t unpack_loc_SetServer_Ind_t::TlvResult

8.745 unpack_loc_SLQSLOCGetBestAvailPos_t Struct Reference

Data Fields

- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.745.1 Detailed Description

This structure contains Set Operation Mode unpack

Parameters

TlvResult	• Unpack result. • Bit to check in ParamPresenceMask - **2**

8.745.2 Field Documentation

8.745.2.1 swi_uint256_t unpack_loc_SLQSLOCGetBestAvailPos_t::ParamPresenceMask

8.745.2.2 uint16_t unpack_loc_SLQSLOCGetBestAvailPos_t::TlvResult

8.746 unpack_loc_Start_t Struct Reference

Data Fields

- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.746.1 Detailed Description

This structure contains Start LOC unpack

Parameters

TlvResult	• Unpack result. • Bit to check in ParamPresenceMask - **2**

8.746.2 Field Documentation

8.746.2.1 swi_uint256_t unpack_loc_Start_t::ParamPresenceMask

8.746.2.2 uint16_t unpack_loc_Start_t::TlvResult

8.747 unpack_loc_Stop_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.747.1 Detailed Description

This structure contains Stop LOC unpack

Parameters

Tlvresult	• Unpack result. • Bit to check in ParamPresenceMask - **2**

8.747.2 Field Documentation

8.747.2.1 swi_uint256_t unpack_loc_Stop_t::ParamPresenceMask

8.747.2.2 uint16_t unpack_loc_Stop_t::Tlvresult

8.748 unpack_nas_GetACCOLC_t Struct Reference

Data Fields

- uint8_t * pAccolc
- swi_uint256_t ParamPresenceMask

8.748.1 Detailed Description

Retrieves information about the access overload class unpack structure

Parameters

pAccolc	• An 8-bit integer representation of the ACCOLC. – Range: 0 to 15 (0x00 to 0x0F). • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.748.2 Field Documentation

8.748.2.1 uint8_t* unpack_nas_GetACCOLC_t::pAccolc

8.748.2.2 swi_uint256_t unpack_nas_GetACCOLC_t::ParamPresenceMask

8.749 unpack_nas_GetANAAAAuthenticationStatus_t Struct Reference

Data Fields

- uint32_t * pAuthStatus
- swi_uint256_t ParamPresenceMask

8.749.1 Detailed Description

AN-AAA authentication status of the device

Parameters

AN-AAA	Authentication Status. • Status of the last AN-AAA authentication request, if any, for the current 1xEV-DO session. – 0 - AAA_STATUS_FAILED - Authentication failed – 1 - AAA_STATUS_SUCCESS - Authentication success – 2 - AAA_STATUS_NO_REQUEST - No authentication requested • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.749.2 Field Documentation

8.749.2.1 swi_uint256_t unpack_nas_GetANAAAAuthenticationStatus_t::ParamPresenceMask

8.749.2.2 uint32_t* unpack_nas_GetANAAAAuthenticationStatus_t::pAuthStatus

8.750 unpack_nas_GetCDMANetworkParameters_t Struct Reference

Data Fields

- uint8_t SCI
- uint8_t SCM
- uint8_t RegHomeSID
- uint8_t RegForeignSID
- uint8_t RegForeignNID
- uint8_t ForceRev0
- uint8_t CustomSCP
- uint32_t Protocol
- uint32_t Broadcast
- uint32_t Application
- uint32_t Roaming
- swi_uint256_t ParamPresenceMask

8.750.1 Detailed Description

Gets the current CDMA network parameters

Parameters

SCI	• Slot cycle index • Bit to check in ParamPresenceMask - **17**
SCM	• Station class mark • Bit to check in ParamPresenceMask - **18**
RegHomeSID	• Register on home SID – 0 - Disabled – 1 - Enabled • Bit to check in ParamPresenceMask - **19**
RegForeignSID	• Register on foreign SID – 0 - Disabled – 1 - Enabled • Bit to check in ParamPresenceMask - **19**
RegForeignNID	• Register on foreign NID – 0 - Disabled – 1 - Enabled • Bit to check in ParamPresenceMask - **19**
ForceRev0	• Force CDMA 1x-EV-DO Rev. 0 mode – 0 - Disabled – 1 - Enabled • Bit to check in ParamPresenceMask - **20**
CustomSCP	• Use a custom config for CDMA 1x-EV-DO SCP – 0 - Disabled – 1 - Enabled • Bit to check in ParamPresenceMask - **21**
Protocol	• Protocol mask for custom SCP config – 0x00000001 - Subtype 2 Physical Layer – 0x00000002 - Enhanced CCMAC – 0x00000004 - Enhanced ACMAC – 0x00000008 - Enhanced FTCMAC – 0x00000010 - Subtype 3 RTCMAC – 0x00000020 - Subsystem 1 RTCMAC – 0x00000040 - Enhanced Idle – 0x00000080 - Generic Multimode Capable Disc Port • Bit to check in ParamPresenceMask - **21**

Broadcast	• Broadcast mask for custom SCP config – 0x00000001 - Generic broadcast enabled • Bit to check in ParamPresenceMask - **21**
Application	• Application mask for custom SCP config – 0x00000001 - SN Multiflow Packet Application – 0x00000002 - SN Enhanced Multiflow Packet Application • Bit to check in ParamPresenceMask - **21**
Roaming	• Roaming preference – 0 - Automatic – 1 - Home Only – 2 - Affiliated Roaming Only – 3 - Home and Affiliated Roaming • Bit to check in ParamPresenceMask - **22**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.750.2 Field Documentation

8.750.2.1 uint32_t unpack_nas_GetCDMANetworkParameters_t::Application

8.750.2.2 uint32_t unpack_nas_GetCDMANetworkParameters_t::Broadcast

8.750.2.3 uint8_t unpack_nas_GetCDMANetworkParameters_t::CustomSCP

8.750.2.4 uint8_t unpack_nas_GetCDMANetworkParameters_t::ForceRev0

8.750.2.5 swi_uint256_t unpack_nas_GetCDMANetworkParameters_t::ParamPresenceMask

8.750.2.6 uint32_t unpack_nas_GetCDMANetworkParameters_t::Protocol

8.750.2.7 uint8_t unpack_nas_GetCDMANetworkParameters_t::RegForeignNID

8.750.2.8 uint8_t unpack_nas_GetCDMANetworkParameters_t::RegForeignSID

8.750.2.9 uint8_t unpack_nas_GetCDMANetworkParameters_t::RegHomeSID

8.750.2.10 uint32_t unpack_nas_GetCDMANetworkParameters_t::Roaming

8.750.2.11 uint8_t unpack_nas_GetCDMANetworkParameters_t::SCI

8.750.2.12 uint8_t unpack_nas_GetCDMANetworkParameters_t::SCM

8.751 unpack_nas_GetHomeNetwork3GPP2_t Struct Reference

Data Fields

- uint16_t * pMCC
- uint16_t * pMNC
- uint8_t nameSize
- uint8_t * pName
- uint16_t * pSID
- uint16_t * pNID
- uint16_t * pNw2MCC
- uint16_t * pNw2MNC
- uint8_t * pNw2DescDisp
- uint8_t * pNw2DescEnc
- uint8_t * pNw2DescLen
- uint8_t * pNw2Name
- swi_uint256_t ParamPresenceMask

8.751.1 Detailed Description

Structure for HomeNetwork3GPP2 unpack.

Parameters

pMCC	• Mobile country code (UMTS only). • Bit to check in ParamPresenceMask - **1**
pMNC	• Mobile network code (UMTS only). • Bit to check in ParamPresenceMask - **1**
nameSize	• Maximum number of characters (including NULL terminator) that network name array can contain (UMTS only). • Bit to check in ParamPresenceMask - **1**
pName	• Network name or description represented as a NULL terminated string (empty string returned when unknown) (UMTS only). • Bit to check in ParamPresenceMask - **1**
pSID	• Home network system ID – 0xFFFF - Unknown. – Only applies to cdma2000 • Bit to check in ParamPresenceMask - **16**
pNID	• Home network ID – 0xFFFF - Unknown. – Only applies to cdma2000 • Bit to check in ParamPresenceMask - **16**

pNw2MCC	• Mobile country code (3GPP2 only). • Range : 0 to 999 • Bit to check in ParamPresenceMask - **17**
pNw2MNC	• Mobile network code (3GPP2 only). • Range : 0 to 999 • Bit to check in ParamPresenceMask - **17**
pNw2DescDisp	• Network Name Display (3GPP2 only). -Valid Value – 0x00 - Do not display – 0x01 - Display – 0xFF - Unknown • Bit to check in ParamPresenceMask - **17**
pNw2DescEnc	• Encoding of the network description (3GPP2 only). • Valid Value – 0x00 - Octet, unspecified – 0x02 - 7-bit ASCII (liteqmi_helper_decode7bitAsciiEncString) – 0x04 - Unicode – 0x09 - GSM 7-bit default • Bit to check in ParamPresenceMask - **17**
pNw2DescLen	• Network Description Length (3GPP2 only). • Bit to check in ParamPresenceMask - **17**
pNw2Name	• Network Name (3GPP2 only). • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.751.2 Field Documentation

8.751.2.1 uint8_t unpack_nas_GetHomeNetwork3GPP2_t::nameSize

8.751.2.2 swi_uint256_t unpack_nas_GetHomeNetwork3GPP2_t::ParamPresenceMask

8.751.2.3 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pMCC

8.751.2.4 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pMNC

8.751.2.5 uint8_t* unpack_nas_GetHomeNetwork3GPP2_t::pName

8.751.2.6 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pNID

8.751.2.7 uint8_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2DescDisp

8.751.2.8 uint8_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2DescEnc

8.751.2.9 uint8_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2DescLen

8.751.2.10 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2MCC

8.751.2.11 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2MNC

8.751.2.12 uint8_t* unpack_nas_GetHomeNetwork3GPP2_t::pNw2Name

8.751.2.13 uint16_t* unpack_nas_GetHomeNetwork3GPP2_t::pSID

8.752 unpack_nas_GetHomeNetwork_t Struct Reference

Data Fields

- uint16_t mcc
- uint16_t mnc
- char name [255]
- uint16_t sid
- uint16_t nid
- swi_uint256_t ParamPresenceMask

8.752.1 Detailed Description

This structure contains unpack get get home network parameters.

Parameters

mcc	• Mobile country code (UMTS only). • A 16-bit integer representation of MCC. Range: 0 to 999. • Bit to check in ParamPresenceMask - **1**
mnc	• Mobile network code (UMTS only). • A 16-bit integer representation of MNC. Range: 0 to 999. • Bit to check in ParamPresenceMask - **1**
name	• Network name or description represented as a NULL terminated string (empty string returned when unknown) (UMTS only). • Bit to check in ParamPresenceMask - **1**
sid	• Home network system ID – 0xFFFF - Unknown. – Only applies to cdma2000 • Bit to check in ParamPresenceMask - **16**

nid	• Home network ID – 0xFFFF - Unknown. – Only applies to cdma2000 • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.752.2 Field Documentation

8.752.2.1 uint16_t unpack_nas_GetHomeNetwork_t::mcc

8.752.2.2 uint16_t unpack_nas_GetHomeNetwork_t::mnc

8.752.2.3 char unpack_nas_GetHomeNetwork_t::name[255]

8.752.2.4 uint16_t unpack_nas_GetHomeNetwork_t::nid

8.752.2.5 swi_uint256_t unpack_nas_GetHomeNetwork_t::ParamPresenceMask

8.752.2.6 uint16_t unpack_nas_GetHomeNetwork_t::sid

8.753 unpack_nas_GetNetworkPreference_t Struct Reference

Data Fields

- uint32_t ActiveTechPref
- uint32_t Duration
- uint32_t PersistentTechPref
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.753.1 Detailed Description

Returns the network registration preference. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use unpack_nas_SLQSGetSys-SelectionPref() for new firmware versions and new modules

Parameters

TechnologyPref[-OUT]	• Bitmask representing the radio technology preference set. • No bits set indicates to the device to automatically determine the technology to use • Values: – Bit 0 - Technology is 3GPP2 – Bit 1 - Technology is 3GPP • Any combination of the following may be returned: – Bit 2 - Analog - AMPS if 3GPP2, GSM if 3GPP – Bit 3 - Digital - CDMA if 3GPP2, WCDMA if 3GPP – Bit 4 - HDR – Bit 5 - LTE – Bits 6 to 15 - Reserved • Bit to check in ParamPresenceMask - **1**
Duration[OUT]	• Duration of active preference – 0 - Permanent – 1 - Power cycle – 2 - Until the end of the next call or a power cycle – 3 - Until the end of the next call, a specified time, or a power cycle – 4 to 6 - Until the end of the next call • Bit to check in ParamPresenceMask - **1**
Persistent-TechnologyPref[-OUT]	• Bit field representing persistent radio technology preference – Same representation as the pTechnologyPref parameter • Bit to check in ParamPresenceMask - **16**
Tlvresult	• unpack result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.753.2 Field Documentation

8.753.2.1 uint32_t unpack_nas_GetNetworkPreference_t::ActiveTechPref

8.753.2.2 uint32_t unpack_nas_GetNetworkPreference_t::Duration

8.753.2.3 swi_uint256_t unpack_nas_GetNetworkPreference_t::ParamPresenceMask

8.753.2.4 uint32_t unpack_nas_GetNetworkPreference_t::PersistentTechPref

8.753.2.5 uint16_t unpack_nas_GetNetworkPreference_t::Tlvresult

8.754 unpack_nas_GetRFInfo_t Struct Reference

Data Fields

- uint8_t instancesSize
- RFBandInfoElements RFBandInfoElements [255]
- swi_uint256_t ParamPresenceMask

8.754.1 Detailed Description

Structur to strore the RFInfoList

Parameters

instanceSize	• Upon input, maximum number of elements that the RF info instances array can contain. • Upon successful output, actual number of elements in RF info instances array.
RFBandInfo-Elements	• RF info instances array – See RFBandInfoElements for more information • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.754.2 Field Documentation

8.754.2.1 uint8_t unpack_nas_GetRFInfo_t::instancesSize

8.754.2.2 swi_uint256_t unpack_nas_GetRFInfo_t::ParamPresenceMask

8.754.2.3 RFBandInfoElements unpack_nas_GetRFInfo_t::RFBandInfoElements[255]

8.755 unpack_nas_GetServingNetwork_t Struct Reference

Data Fields

- uint32_t RegistrationState
- uint32_t CSDomain
- uint32_t PSDomain
- uint32_t RAN
- uint8_t RadioIfacesSize
- uint8_t RadioIfaces [255]
- uint32_t Roaming
- uint16_t MCC
- uint16_t MNC
- uint8_t nameSize
- uint8_t Name [255]
- uint8_t DataCapsLen
- uint8_t DataCaps [255]
- swi_uint256_t ParamPresenceMask

8.755.1 Detailed Description

This structure contains unpack get get serving network parameters.

Parameters

Registration-State	• Registration state: – 0 - Not registered – 1 - Registered – 2 - Searching/Not Registered – 3 - Registration Denied – 4 - Unknown • Bit to check in ParamPresenceMask - **1**
CSDomain	• Circuit switch domain status: – 0 - Unknown/Not Applicable – 1 - Attached – 2 - Detached • Bit to check in ParamPresenceMask - **1**
PSDomain	• Packet switch domain status – 0 - Unknown/Not Applicable – 1 - Attached – 2 - Detached • Bit to check in ParamPresenceMask - **1**
RAN	• Type of radio access network on which mobile is registered: – 0 - Unknown – 1 - cdma2000 network – 2 - UMTS network • Bit to check in ParamPresenceMask - **1**
RadioIfacesSize	• Upon input, maximum number of elements that the radio interface array contain. • Upon successful output, actual number of elements in the radio interface array. • Bit to check in ParamPresenceMask - **1**
RadioIfaces	• An array of Radio Interface Technology – See qaGobiApiTableRadioInterfaces.h for the Radio Interface Technologies • Bit to check in ParamPresenceMask - **1**
Roaming	• Roaming indicator • Bit to check in ParamPresenceMask - **16**
MCC	• Mobile country code • Bit to check in ParamPresenceMask - **18**

MNC	• Mobile network code • Bit to check in ParamPresenceMask - **18**
nameSize	• Maximum number of characters (including NULL terminator) that network name array can contain; applicable only for UMTS networks • Bit to check in ParamPresenceMask - **18**
Name	• Network name or description represented as a NULL terminated string; empty string is returned when unknown; applicable only for UMTS networks • Bit to check in ParamPresenceMask - **18**
DataCapsLen[IN/OUT]	• Upon input, the maximum number of elements the data capabilities array can contain. • Upon output, the actual number of elements in the data capabilities array. • Bit to check in ParamPresenceMask - **17**
DataCaps[OUT]	• Data capabilities array of unsigned long type – 1 - GPRS – 2 - EDGE – 3 - HSDPA – 4 - HSUPA – 5 - WCDMA – 6 - CDMA 1xRTT – 7 - CDMA 1xEV-DO Rev 0 – 8 - CDMA 1xEV-DO Rev. A – 9 - GSM – 10 - EVDO Rev. B – 11 - LTE – 12 - HSDPA Plus – 13 - Dual Carrier HSDPA Plus • Bit to check in ParamPresenceMask - **17**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.755.2 Field Documentation

8.755.2.1 uint32_t unpack_nas_GetServingNetwork_t::CSDomain

8.755.2.2 uint8_t unpack_nas_GetServingNetwork_t::DataCaps[255]

8.755.2.3 uint8_t unpack_nas_GetServingNetwork_t::DataCapsLen

8.755.2.4 uint16_t unpack_nas_GetServingNetwork_t::MCC

8.755.2.5 uint16_t unpack_nas_GetServingNetwork_t::MNC

8.755.2.6 uint8_t unpack_nas_GetServingNetwork_t::Name[255]

8.755.2.7 uint8_t unpack_nas_GetServingNetwork_t::nameSize

8.755.2.8 swi_uint256_t unpack_nas_GetServingNetwork_t::ParamPresenceMask

8.755.2.9 uint32_t unpack_nas_GetServingNetwork_t::PSDomain

8.755.2.10 uint8_t unpack_nas_GetServingNetwork_t::RadioIfaces[255]

8.755.2.11 uint8_t unpack_nas_GetServingNetwork_t::RadioIfacesSize

8.755.2.12 uint32_t unpack_nas_GetServingNetwork_t::RAN

8.755.2.13 uint32_t unpack_nas_GetServingNetwork_t::RegistrationState

8.755.2.14 uint32_t unpack_nas_GetServingNetwork_t::Roaming

8.756 unpack_nas_GetServingNetworkCapabilities_t Struct Reference

Data Fields

- uint8_t DataCapsLen
- uint8_t DataCaps [255]
- swi_uint256_t ParamPresenceMask

8.756.1 Detailed Description

This structure contains unpack get serving network capabilities parameters.

Parameters

DataCapsLen	• Upon input, the maximum number of elements the data capabilities array can contain. • Upon output, the actual number of elements in the data capabilities array. • Bit to check in ParamPresenceMask - **17**
DataCaps[OUT]	• Data capabilities array of unsigned long type – 1 - GPRS – 2 - EDGE – 3 - HSDPA – 4 - HSUPA – 5 - WCDMA – 6 - CDMA 1xRTT – 7 - CDMA 1xEV-DO Rev 0 – 8 - CDMA 1xEV-DO Rev. A – 9 - GSM – 10 - EVDO Rev. B – 11 - LTE – 12 - HSDPA Plus – 13 - Dual Carrier HSDPA Plus • Bit to check in ParamPresenceMask - **17**

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.756.2 Field Documentation

8.756.2.1 uint8_t unpack_nas_GetServingNetworkCapabilities_t::DataCaps[255]

8.756.2.2 uint8_t unpack_nas_GetServingNetworkCapabilities_t::DataCapsLen

8.756.2.3 swi_uint256_t unpack_nas_GetServingNetworkCapabilities_t::ParamPresenceMask

8.757 unpack_nas_GetSignalStrengths_t Struct Reference

Data Fields

- uint32_t len
- signed char rssi [8]
- uint32_t radio [8]
- swi_uint256_t ParamPresenceMask

8.757.1 Detailed Description

This structure contains unpack get signal strengths parameters.

Parameters

len	• number of rssi & radio items following
rssi	• signal strength array • Bit to check in ParamPresenceMask - **16**
radio	• radio interface array • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.757.2 Field Documentation

8.757.2.1 uint32_t unpack_nas_GetSignalStrengths_t::len

8.757.2.2 swi_uint256_t unpack_nas_GetSignalStrengths_t::ParamPresenceMask

8.757.2.3 uint32_t unpack_nas_GetSignalStrengths_t::radio[8]

8.757.2.4 signed char unpack_nas_GetSignalStrengths_t::rssi[8]

8.758 unpack_nas_PerformNetworkScan_t Struct Reference

Data Fields

- uint8_t * p3GppNetworkInstanceSize
- nas_QmiNas3GppNetworkInfo * p3GppNetworkInfoInstances
- uint8_t * pRATInstanceSize
- nas_QmiNas3GppNetworkRAT * pRATINstance
- uint8_t * pPCSInstanceSize
- nas_QmisNasPcsDigit * pPCSInstance
- uint32_t * pScanResult
- nas_QmisNasSlqsNasPCIInfo * pPCIInfo
- swi_uint256_t ParamPresenceMask

8.758.1 Detailed Description

Contain the network scan information.

Parameters

p3GppNetwork-InstanceSize	• Upon input, maximum number of elements that the network info instance array can contain. • Upon successful output, the actual number of elements in the network info instance array. • Bit to check in ParamPresenceMask - **16**
p3GppNetwork-InfoInstances	• Network info instance array – See nas_QmiNas3GppNetworkInfo for more information • Bit to check in ParamPresenceMask - **16**
pRATInstance-Size	• Upon input, maximum number of elements that the RAT info instance array can contain. • Upon successful output, the actual number of elements in the RAT info instance array. • Bit to check in ParamPresenceMask - **17**
pRATINstance	• RAT info instance array – See nas_QmiNas3GppNetworkRAT for more information • Bit to check in ParamPresenceMask - **17**
pPCSInstance-Size	• Upon input, maximum number of elements that the PCS Digit info instance array can contain. • Upon successful output, the actual number of elements in the PCS Digit info instance array. • Bit to check in ParamPresenceMask - **18**
pPCSInstance	• PCS Digit info instance array – See nas_QmisNasPcsDigit for more information • Bit to check in ParamPresenceMask - **18**

pScanResult	• status of network scan • 0x00 - scan successful • 0x01 - scan was aborted • 0x02 - scan did not complete due to a radio link failure recovery in progress • Bit to check in ParamPresenceMask - **19**
pPCIInfo	• PCI Information – See nas_QmisNasSlqsNasPCIInfo for more information • Bit to check in ParamPresenceMask - **23**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.758.2 Field Documentation

8.758.2.1 nas_QmiNas3GppNetworkInfo* unpack_nas_PerformNetworkScan_t::p3GppNetworkInfoInstances

8.758.2.2 uint8_t* unpack_nas_PerformNetworkScan_t::p3GppNetworkInstanceSize

8.758.2.3 swi_uint256_t unpack_nas_PerformNetworkScan_t::ParamPresenceMask

8.758.2.4 nas_QmisNasSlqsNasPCIInfo* unpack_nas_PerformNetworkScan_t::pPCIInfo

8.758.2.5 nas_QmisNasPcsDigit* unpack_nas_PerformNetworkScan_t::pPCSInstance

8.758.2.6 uint8_t* unpack_nas_PerformNetworkScan_t::pPCSInstanceSize

8.758.2.7 nas_QmiNas3GppNetworkRAT* unpack_nas_PerformNetworkScan_t::pRATINstance

8.758.2.8 uint8_t* unpack_nas_PerformNetworkScan_t::pRATInstanceSize

8.758.2.9 uint32_t* unpack_nas_PerformNetworkScan_t::pScanResult

8.759 unpack_nas_SetDataCapabilitiesCallback_ind_t Struct Reference

Data Fields

- uint8_t dataCapsSize
- uint8_t dataCaps [255]
- swi_uint256_t ParamPresenceMask

8.759.1 Detailed Description

This structure contains unpack set data capabilities callback indication parameters.

Parameters

dataCapsSize	• Number of Data Capabilities • Bit to check in ParamPresenceMask - **17**
dataCaps	• Data Capabilities • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.759.2 Field Documentation

8.759.2.1 uint8_t unpack_nas_SetDataCapabilitiesCallback_ind_t::dataCaps[255]

8.759.2.2 uint8_t unpack_nas_SetDataCapabilitiesCallback_ind_t::dataCapsSize

8.759.2.3 swi_uint256_t unpack_nas_SetDataCapabilitiesCallback_ind_t::ParamPresenceMask

8.760 unpack_nas_SetEventReportInd_t Struct Reference

Data Fields

- nas_SignalStrengthTlv SSTlv
- nas_RFInfoTlv RFTlv
- nas_RejectReasonTlv RRTlv
- nas_SLQSSignalStrengthsTlv SLQSSSTlv
- swi_uint256_t ParamPresenceMask

8.760.1 Detailed Description

This structure contains unpack set event report indication parameters.

Parameters

SSTlv	• signal strength tlv • Bit to check in ParamPresenceMask - **16**
RFTlv	• RF tlv • Bit to check in ParamPresenceMask - **17**
RRTlv	• RR tlv • Bit to check in ParamPresenceMask - **18**

SLQSSSTlv	• signal strength complete info tlv • Bit to check in ParamPresenceMask - **19** • Bit to check in ParamPresenceMask - **20** • Bit to check in ParamPresenceMask - **21** • Bit to check in ParamPresenceMask - **22** • Bit to check in ParamPresenceMask - **23** • Bit to check in ParamPresenceMask - **24** • Bit to check in ParamPresenceMask - **25** • Bit to check in ParamPresenceMask - **26**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.760.2 Field Documentation

8.760.2.1 swi_uint256_t unpack_nas_SetEventReportInd_t::ParamPresenceMask

8.760.2.2 nas_RFInfoTlv unpack_nas_SetEventReportInd_t::RFTlv

8.760.2.3 nas_RejectReasonTlv unpack_nas_SetEventReportInd_t::RRTlv

8.760.2.4 nas_SLQSSignalStrengthsTlv unpack_nas_SetEventReportInd_t::SLQSSSTlv

8.760.2.5 nas_SignalStrengthTlv unpack_nas_SetEventReportInd_t::SSTlv

8.761 unpack_nas_SetNasLTECphyCaIndCallback_ind_t Struct Reference

Data Fields

- nas_PhyCaAggScellIndType sPhyCaAggScellIndType
- nas_PhyCaAggScellDlBw sPhyCaAggScellDlBw
- nas_PhyCaAggScellInfo sPhyCaAggScellInfo
- nas_PhyCaAggPcellInfo sPhyCaAggPcellInfo
- nas_PhyCaAggScellIndex sPhyCaAggScellIndex
- swi_uint256_t ParamPresenceMask

8.761.1 Detailed Description

Structure for storing the LTE PHY CA indication parameters.

Parameters

pPhyCaAgg-ScellIndType	• See nas_PhyCaAggScellIndType for more information. • Bit to check in ParamPresenceMask - **1**
sPhyCaAgg-ScellDlBw	• See nas_PhyCaAggScellDlBw for more information. • Bit to check in ParamPresenceMask - **16**

sPhyCaAgg-ScellInfo	• See nas_PhyCaAggScellInfo for more information. • Bit to check in ParamPresenceMask - **17**
sPhyCaAgg-PcellInfo	• See nas_PhyCaAggPcellInfo for more information. • Bit to check in ParamPresenceMask - **18**
sPhyCaAgg-ScellIndex	• See nas_PhyCaAggScellIndex for more information. • Bit to check in ParamPresenceMask - **19**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.761.2 Field Documentation

8.761.2.1 swi_uint256_t unpack_nas_SetNasLTECphyCaIndCallback_ind_t::ParamPresenceMask

8.761.2.2 nas_PhyCaAggPcellInfo unpack_nas_SetNasLTECphyCaIndCallback_ind_t::sPhyCaAggPcellInfo

8.761.2.3 nas_PhyCaAggScellDlBw unpack_nas_SetNasLTECphyCaIndCallback_ind_t::sPhyCaAggScellDlBw

8.761.2.4 nas_PhyCaAggScellIndex unpack_nas_SetNasLTECphyCaIndCallback_ind_t::sPhyCaAggScellIndex

8.761.2.5 nas_PhyCaAggScellIndType unpack_nas_SetNasLTECphyCaIndCallback_ind_t::sPhyCaAggScellIndType

8.761.2.6 nas_PhyCaAggScellInfo unpack_nas_SetNasLTECphyCaIndCallback_ind_t::sPhyCaAggScellInfo

8.762 unpack_nas_SetNetworkPreference_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.762.1 Detailed Description

This structure contains unpack set network preference parameters.

Parameters

Tlvresult	• unpack result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.762.2 Field Documentation

8.762.2.1 swi_uint256_t unpack_nas_SetNetworkPreference_t::ParamPresenceMask

8.762.2.2 uint16_t unpack_nas_SetNetworkPreference_t::Tlvresult

8.763 unpack_nas_SetRoamingIndicatorCallback_ind_t Struct Reference

Data Fields

- uint8_t roaming
- swi_uint256_t ParamPresenceMask

8.763.1 Detailed Description

This structure contains unpack set roaming indicator callback indication parameters.

Parameters

roaming	• Roaming Indication – 0 - Roaming – 1 - Home – 2 - Roaming partner – >2 - Operator defined values • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.763.2 Field Documentation

8.763.2.1 swi_uint256_t unpack_nas_SetRoamingIndicatorCallback_ind_t::ParamPresenceMask

8.763.2.2 uint8_t unpack_nas_SetRoamingIndicatorCallback_ind_t::roaming

8.764 unpack_nas_SetServingSystemCallback_ind_t Struct Reference

Data Fields

- NASServingSystemInfo SSInfo
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.764.1 Detailed Description

This structure contains unpack set serving system callback indication parameters.

Parameters

SSInfo	• Serving system parameters information – See NASServingSystemInfo for more details • Bit to check in ParamPresenceMask - **1**
Tlvresult	• unpack result • Bit to check in ParamPresenceMask - **2**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.764.2 Field Documentation

8.764.2.1 swi_uint256_t unpack_nas_SetServingSystemCallback_ind_t::ParamPresenceMask

8.764.2.2 NASServingSystemInfo unpack_nas_SetServingSystemCallback_ind_t::SSInfo

8.764.2.3 uint16_t unpack_nas_SetServingSystemCallback_ind_t::Tlvresult

8.765 unpack_nas_SLQSGetErrorRate_t Struct Reference

Data Fields

- uint16_t * pCDMAFrameErrRate
- uint16_t * pHDRPackErrRate
- uint8_t * pGSMBER
- uint8_t * pWCDMABER
- swi_uint256_t ParamPresenceMask

8.765.1 Detailed Description

Structure for Error Rate unpack parameters.

Parameters

pCDMAFrame-ErrRate	• CDMA Frame Error Rate • Valid error rate values between 1 and 10000 are returned to indicate the percentage, e.g., a value of 300 means the error rate is 3%. • A value of 0xFFFF indicates that the error rate is unknown/unavailable. • Bit to check in ParamPresenceMask - **16**
pHDRPackErr-Rate	• HDR Packet Error Rate • Valid error rate values between 1 and 10000 are returned to indicate the percentage, e.g., a value of 300 means the error rate is 3%. • A value of 0xFFFF indicates that the error rate is unknown/unavailable. • Bit to check in ParamPresenceMask - **17**

pGSMBER	• GSM Bit Error Rate • Valid error rate values between 1 and 100 are returned to indicate the percentage value. • A 0% block error rate (BLER) indicates No Data. • Bit to check in ParamPresenceMask - **18**
pWCDMABER	• WCDMA Block Error Rate • Valid error rate values between 1 and 100 are returned to indicate the percentage value. • A value of 0xFF indicates that the error rate is unknown/unavailable. • Bit to check in ParamPresenceMask - **19**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.765.2 Field Documentation

8.765.2.1 swi_uint256_t unpack_nas_SLQSGetErrorRate_t::ParamPresenceMask

8.765.2.2 uint16_t* unpack_nas_SLQSGetErrorRate_t::pCDMAFrameErrRate

8.765.2.3 uint8_t* unpack_nas_SLQSGetErrorRate_t::pGSMBER

8.765.2.4 uint16_t* unpack_nas_SLQSGetErrorRate_t::pHDRPackErrRate

8.765.2.5 uint8_t* unpack_nas_SLQSGetErrorRate_t::pWCDMABER

8.766 unpack_nas_SlqsGetLTECphyCAInfo_t Struct Reference

Data Fields

- NasGetLTECphyCaInfo LTECphyCaInfo
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.766.1 Detailed Description

This structure contains unpack get carrier aggregation event information parameters.

Parameters

LTECphyCa	• Carrier aggregation event information – See NasGetLTECphyCaInfo for more details
Tlvresult	• unpack result • Bit to check in ParamPresenceMask - **2**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.766.2 Field Documentation

8.766.2.1 NasGetLTECphyCaInfo unpack_nas_SlqsGetLTECphyCAInfo_t::LTECphyCaInfo

8.766.2.2 swi_uint256_t unpack_nas_SlqsGetLTECphyCAInfo_t::ParamPresenceMask

8.766.2.3 uint16_t unpack_nas_SlqsGetLTECphyCAInfo_t::TlvResult

8.767 unpack_nas_SLQSGetNetworkTime_t Struct Reference

Data Fields

- nas_timeInfo * p3GPP2TimeInfo
- nas_timeInfo * p3GPPTimeInfo
- swi_uint256_t ParamPresenceMask

8.767.1 Detailed Description

This structure contains information about the GetNetworkTime response parameters.

Parameters

p3GPP2TimeInfo	[Optional] • See nas_timeInfo for more information

- * - Bit to check in ParamPresenceMask - **16**

Parameters

p3GPPTimeInfo	[Optional] – See nas_timeInfo for more information

- * - Bit to check in ParamPresenceMask - **17**

Parameters

ParamPresenceMask	– bitmask representation to indicate valid parameters.

8.767.2 Field Documentation

8.767.2.1 nas_timeInfo* unpack_nas_SLQSGetNetworkTime_t::p3GPP2TimeInfo

8.767.2.2 nas_timeInfo* unpack_nas_SLQSGetNetworkTime_t::p3GPPTimeInfo

8.767.2.3 swi_uint256_t unpack_nas_SLQSGetNetworkTime_t::ParamPresenceMask

8.768 unpack_nas_SLQSGetOperatorNameData_t Struct Reference

Data Fields

- nas_serviceProviderName * pSrvcProviderName
- nas_operatorPLMNList * pOperatorPLMNList

- nas_PLMNNetworkName * pPLMNNetworkName
- nas_operatorNameString * pOperatorNameString
- nas_PLMNNetworkNameData * pNITZInformation
- swi_uint256_t ParamPresenceMask

8.768.1 Detailed Description

Structure for Operator Name unpack.

Parameters

pSrvcProviderName	• Refer nas_serviceProviderName for details (Optional). • Can provide NULL if this parameter is not required. • Bit to check in ParamPresenceMask - **16**
pOperatorPLMNList	• Refer nas_operatorPLMNList for details (Optional). • Can provide NULL if this parameter is not required. • Bit to check in ParamPresenceMask - **17**
pPLMNNetworkName	• Refer nas_PLMNNetworkName for details (Optional). • Can provide NULL if this parameter is not required. • Bit to check in ParamPresenceMask - **18**
pOperatorNameString	• Refer nas_operatorNameString for details (Optional). • Can provide NULL if this parameter is not required. • Bit to check in ParamPresenceMask - **19**
pNITZInformation	• Refer nas_PLMNNetworkNameData for details (Optional). • Can provide NULL if this parameter is not required. • Bit to check in ParamPresenceMask - **20**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.768.2 Field Documentation

8.768.2.1 swi_uint256_t unpack_nas_SLQSGetOperatorNameData_t::ParamPresenceMask

8.768.2.2 nas_PLMNNetworkNameData* unpack_nas_SLQSGetOperatorNameData_t::pNITZInformation

8.768.2.3 nas_operatorNameString* unpack_nas_SLQSGetOperatorNameData_t::pOperatorNameString

8.768.2.4 nas_operatorPLMNList* unpack_nas_SLQSGetOperatorNameData_t::pOperatorPLMNList

8.768.2.5 nas_PLMNNetworkName* unpack_nas_SLQSGetOperatorNameData_t::pPLMNNetworkName

8.768.2.6 nas_serviceProviderName* unpack_nas_SLQSGetOperatorNameData_t::pSrvcProviderName

8.769 unpack_nas_SLQSGetPLMNName_t Struct Reference

Data Fields

- uint8_t spnEncoding
- uint8_t spnLength
- char spn [255]
- uint8_t shortNameEn
- uint8_t shortNameCI
- uint8_t shortNameSB
- char shortNameLen
- uint8_t shortName [255]
- uint8_t longNameEn
- uint8_t longNameCI
- uint8_t longNameSB
- uint8_t longNameLen
- char longName [255]
- swi_uint256_t ParamPresenceMask

8.769.1 Detailed Description

This structure contains unpack get operator name for specificed network parameters.

Parameters

spnEncoding	• Coding scheme used for service provider name. This value is ignored if spn_len is zero Values: – 0x00 - SMS default 7-bit coded alphabet as defined in 3GPP TS 23.038 with bit 8 set to 0 – 0x01 - UCS2 (16 bit, little-endian) 3GPP TS 23.038 – Note: This value is ignored if spnLength is zero. • Bit to check in ParamPresenceMask - **16**
spnLength	• Length of SPN which follows • Note: This SPN value is ignored if spnLength is zero and spnEncoding is 0xff. • Bit to check in ParamPresenceMask - **16**
spn	• Service Provider name string • Bit to check in ParamPresenceMask - **16**
shortNameEn	• Coding scheme used for PLMN short name. This value is ignored if PLMN short name length is zero Values: – 0x00 - SMS default 7-bit coded alphabet as defined in 3GPP TS 23.038 with bit 8 set to 0 – 0x01 - UCS2 (16 bit, little-endian) 3GPP TS 23.038 – Note: This value is ignored if shortNameLen is zero. • Bit to check in ParamPresenceMask - **16**

shortNameCI	• Indicates whether the country initials are to be added to the shortName. This value is ignored if shortNameLen is zero. Values: – 0x00 - Do not add the letters for the countrys initials to the name – 0x01 - Add the countrys initials and a text string to the name – 0xFF - Not specified – Note: This value is ignored if shortNameLen is zero. • Bit to check in ParamPresenceMask - **16**
shortNameSB	• PLMN short name spare bits. This value is ignored if shortNameLen is zero. Values: – 0x01 - Bit 8 is spare and set to 0 in octet – 0x02 - Bits 7 and 8 are spare and set to 0 in octet n – 0x03 - Bits 6 to 8 (inclusive) are spare and set to 0 in octet n – 0x04 - Bits 5 to 8 (inclusive) are spare and set to 0 in octet n – 0x05 - Bits 4 to 8 (inclusive) are spare and set to 0 in octet n – 0x06 - Bits 3 to 8 (inclusive) are spare and set to 0 in octet n – 0x07 - Bits 2 to 8 (inclusive) are spare and set to 0 in octet n – 0x00 - Carries no information about the number of spare bits in octet n – Note: This value is ignored if shortNameLen is zero. • Bit to check in ParamPresenceMask - **16**
shortNameLen	• Length of shortName which follows • Note: This shortName value is ignored if shortNameLen is zero and shortNameEn is 0xff. • Bit to check in ParamPresenceMask - **16**
shortName	• PLMN short name • Bit to check in ParamPresenceMask - **16**
longNameEn	• Coding scheme used for PLMN long name. This value is ignored if PLMN long name length is zero Values: – 0x00 - SMS default 7-bit coded alphabet as defined in 3GPP TS 23.038 with bit 8 set to 0 – 0x01 - UCS2 (16 bit, little-endian) 3GPP TS 23.038 – Note: This value is ignored if shortNameLen is zero. • Bit to check in ParamPresenceMask - **16**
longNameCI	• Indicates whether the country initials are to be added to the longName. This value is ignored if longNameLen is zero. Values: – 0x00 - Do not add the letters for the countrys initials to the name – 0x01 - Add the countrys initials and a text string to the name – 0xFF - Not specified – Note: This value is ignored if shortNameLen is zero. • Bit to check in ParamPresenceMask - **16**

longNameSB	• PLMN long name spare bits. This value is ignored if longNameLen is zero. Values: – 0x01 - Bit 8 is spare and set to 0 in octet – 0x02 - Bits 7 and 8 are spare and set to 0 in octet n – 0x03 - Bits 6 to 8 (inclusive) are spare and set to 0 in octet n – 0x04 - Bits 5 to 8 (inclusive) are spare and set to 0 in octet n – 0x05 - Bits 4 to 8 (inclusive) are spare and set to 0 in octet n – 0x06 - Bits 3 to 8 (inclusive) are spare and set to 0 in octet n – 0x07 - Bits 2 to 8 (inclusive) are spare and set to 0 in octet n – 0x00 - Carries no information about the number of spare bits in octet n – Note: This value is ignored if shortNameLen is zero. • Bit to check in ParamPresenceMask - **16**
longNameLen	• Length of longName which follows • Note: This longName value is ignored if longNameLen is zero and longNameEn is 0xff. • Bit to check in ParamPresenceMask - **16**
longName	• PLMN long name • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.769.2 Field Documentation

8.769.2.1 char unpack_nas_SLQSGetPLMNName_t::longName[255]

8.769.2.2 uint8_t unpack_nas_SLQSGetPLMNName_t::longNameCI

8.769.2.3 uint8_t unpack_nas_SLQSGetPLMNName_t::longNameEn

8.769.2.4 uint8_t unpack_nas_SLQSGetPLMNName_t::longNameLen

8.769.2.5 uint8_t unpack_nas_SLQSGetPLMNName_t::longNameSB

8.769.2.6 swi_uint256_t unpack_nas_SLQSGetPLMNName_t::ParamPresenceMask

8.769.2.7 uint8_t unpack_nas_SLQSGetPLMNName_t::shortName[255]

8.769.2.8 uint8_t unpack_nas_SLQSGetPLMNName_t::shortNameCI

8.769.2.9 uint8_t unpack_nas_SLQSGetPLMNName_t::shortNameEn

8.769.2.10 char unpack_nas_SLQSGetPLMNName_t::shortNameLen

8.769.2.11 uint8_t unpack_nas_SLQSGetPLMNName_t::shortNameSB

8.769.2.12 char unpack_nas_SLQSGetPLMNName_t::spn[255]

8.769.2.13 uint8_t unpack_nas_SLQSGetPLMNName_t::spnEncoding

8.769.2.14 uint8_t unpack_nas_SLQSGetPLMNName_t::spnLength

8.770 unpack_nas_SLQSGetServingSystem_t Struct Reference

Data Fields

- nas_servSystem ServingSystem
- uint8_t RoamIndicatorVal
- nas_dataSrvCapabilities DataSrvCapabilities
- nas_currentPLMN CurrentPLMN
- uint16_t SystemID
- uint16_t NetworkID
- uint16_t BasestationID
- uint32_t BasestationLatitude
- uint32_t BasestationLongitude
- nas_roamIndList RoamingIndicatorList
- uint8_t DefaultRoamInd
- nas_qaQmi3Gpp2TimeZone Gpp2TimeZone
- uint8_t CDMA_P_Rev
- uint8_t GppTimeZone
- uint8_t GppNetworkDSTAdjustment
- uint16_t Lac
- uint32_t CellID
- uint8_t ConcSvcInfo
- uint8_t PRLInd
- uint8_t DTMInd
- nas_detailSvcInfo DetailedSvcInfo
- nas_CDMASysInfoExt CDMASystemInfoExt
- uint8_t HdrPersonality
- uint16_t TrackAreaCode
- nas_callBarStatus CallBarStatus
- swi_uint256_t ParamPresenceMask

8.770.1 Detailed Description

This structure contains the Serving System parameters

- Parameter values default to their data type's maximum unsigned value unless explicitly stated otherwise.

Parameters

ServingSystem	• Serving System • See nas_servSystem for more information • Bit to check in ParamPresenceMask - **1**

RoamIndicator-Val	• Optional parameter indicating Roaming Indicator value • Values: – 0x00 - Roaming – 0x01 - Home – 0x02 - Flashing – 0x03 and above - Operator defined values • Bit to check in ParamPresenceMask - **16**
DataSrv-Capabilities	• Optional parameter indicating Data services capability • See nas_dataSrvCapabilities for more information • Bit to check in ParamPresenceMask - **17**
CurrentPLMN	• Optional parameter indicating Current PLMN • See nas_currentPLMN for more information • Bit to check in ParamPresenceMask - **18**
SystemID	• Optional parameter indicating System ID • Bit to check in ParamPresenceMask - **19**
NetworkID	• Optional parameter indicating Network ID • Bit to check in ParamPresenceMask - **19**
BaseStationID	• Optional parameter indicating Base Station Identification Number • Bit to check in ParamPresenceMask - **20**
BaseStation-Latitude	• Optional parameter indicating Base station latitude in units of 0.25 sec,expressed as a two's complement signed number with positive numbers signifying North latitude • Bit to check in ParamPresenceMask - **20**
Basestation-Longitude	• Optional parameter indicating Base station longitude in units of 0.25 sec, expressed as a Two's complement signed number with positive numbers signifying East longitude • Bit to check in ParamPresenceMask - **20**
Roaming-IndicatorList	• Optional parameter indicating Roaming Indicator List • See nas_roamIndList for more information • Bit to check in ParamPresenceMask - **21**

DefaultRoamInd	• Optional parameter indicating Default Roaming Indicator • Values: – 0x00 - Roaming – 0x01 - Home • Bit to check in ParamPresenceMask - **22**
Gpp2TimeZone	• Optional parameter indicating 3GPP2 Time Zone • See nas_qaQmi3Gpp2TimeZone for more information • Bit to check in ParamPresenceMask - **23**
CDMA_P_Rev	• Optional parameter indicating CDMA P_Rev in use • Bit to check in ParamPresenceMask - **24**
GppTimeZone	• Optional parameter indicating Offset from Universal time, i.e., difference between local time and Universal time, in increments of 15 min. (signed value). • Bit to check in ParamPresenceMask - **26**
GppNetworkDS-TAdjustment	• Optional parameter indicating 3GPP network daylight saving adjustment • Values: – 0x00 - No adjustment for Daylight Saving Time – 0x01 - 1 hr adjustment for Daylight Saving Time – 0x02 - 2 hr adjustment for Daylight Saving Time • Bit to check in ParamPresenceMask - **27**
Lac	• Optional parameter indicating 3GPP Location Area Code • Bit to check in ParamPresenceMask - **28**
CellID	• Optional parameter indicating 3GPP Cell ID • Bit to check in ParamPresenceMask - **29**
ConcSvcInfo	• Optional parameter indicating 3GPP2 concurrent service Info • Values: – 0x00 - Concurrent service not available – 0x01 - Concurrent service available • Bit to check in ParamPresenceMask - **30**
PRLInd	• Optional parameter indicating 3GPP2 PRL Indicator • Values: – 0x00 - System not in PRL – 0x01 - System is in PRL • Bit to check in ParamPresenceMask - **31**

DTMInd	• Optional parameter indicating Dual Transfer Mode Indication(GSM Only) • Values: – 0x00 - DTM not supported – 0x01 - DTM supported • Bit to check in ParamPresenceMask - **32**
DetailedSvcInfo	• Optional parameter indicating Detailed service information • See nas_detailSvcInfo for more information • Bit to check in ParamPresenceMask - **33**
CDMASystem-InfoExt	• Optional parameter indicating CDMA System Info Ext • See nas_CDMASysInfoExt for more information • Bit to check in ParamPresenceMask - **34**
HdrPersonality	• Optional parameter indicating HDR Personality Information • Values: – 0x00 - Unknown – 0x01 - HRPD – 0x02 - eHRPD • Bit to check in ParamPresenceMask - **35**
TrackAreaCode	• Optional parameter indicating Tracking area code information for LTE • Bit to check in ParamPresenceMask - **36**
CallBarStatus	• Optional parameter indicating Call Barring Status • See nas_callBarStatus for more information • Bit to check in ParamPresenceMask - **37**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.770.2 Field Documentation

8.770.2.1 uint16_t unpack_nas_SLQSGetServingSystem_t::BasestationID

8.770.2.2 uint32_t unpack_nas_SLQSGetServingSystem_t::BasestationLatitude

8.770.2.3 uint32_t unpack_nas_SLQSGetServingSystem_t::BasestationLongitude

8.770.2.4 nas_callBarStatus unpack_nas_SLQSGetServingSystem_t::CallBarStatus

8.770.2.5 uint8_t unpack_nas_SLQSGetServingSystem_t::CDMA_P_Rev

8.770.2.6 nas_CDMASysInfoExt unpack_nas_SLQSGetServingSystem_t::CDMASystemInfoExt

8.770.2.7 uint32_t unpack_nas_SLQSGetServingSystem_t::CellID

8.770.2.8 uint8_t unpack_nas_SLQSGetServingSystem_t::ConcSvcInfo

8.770.2.9 nas_currentPLMN unpack_nas_SLQSGetServingSystem_t::CurrentPLMN

8.770.2.10 nas_dataSrvCapabilities unpack_nas_SLQSGetServingSystem_t::DataSrvCapabilities

8.770.2.11 uint8_t unpack_nas_SLQSGetServingSystem_t::DefaultRoamInd

8.770.2.12 nas_detailSvcInfo unpack_nas_SLQSGetServingSystem_t::DetailedSvcInfo

8.770.2.13 uint8_t unpack_nas_SLQSGetServingSystem_t::DTMInd

8.770.2.14 nas_qaQmi3Gpp2TimeZone unpack_nas_SLQSGetServingSystem_t::Gpp2TimeZone

8.770.2.15 uint8_t unpack_nas_SLQSGetServingSystem_t::GppNetworkDSTAdjustment

8.770.2.16 uint8_t unpack_nas_SLQSGetServingSystem_t::GppTimeZone

8.770.2.17 uint8_t unpack_nas_SLQSGetServingSystem_t::HdrPersonality

8.770.2.18 uint16_t unpack_nas_SLQSGetServingSystem_t::Lac

8.770.2.19 uint16_t unpack_nas_SLQSGetServingSystem_t::NetworkID

8.770.2.20 swi_uint256_t unpack_nas_SLQSGetServingSystem_t::ParamPresenceMask

8.770.2.21 uint8_t unpack_nas_SLQSGetServingSystem_t::PRLInd

8.770.2.22 uint8_t unpack_nas_SLQSGetServingSystem_t::RoamIndicatorVal

8.770.2.23 nas_roamIndList unpack_nas_SLQSGetServingSystem_t::RoamingIndicatorList

8.770.2.24 nas_servSystem unpack_nas_SLQSGetServingSystem_t::ServingSystem

8.770.2.25 uint16_t unpack_nas_SLQSGetServingSystem_t::SystemID

8.770.2.26 uint16_t unpack_nas_SLQSGetServingSystem_t::TrackAreaCode

8.771 unpack_nas_SLQSGetSignalStrength_t Struct Reference

Data Fields

- uint16_t signalStrengthReqMask
- uint16_t rxSignalStrengthListLen
- nas_rxSignalStrengthListElement rxSignalStrengthList [18]
- uint16_t ecioListLen
- nas_ecioListElement ecioList [18]
- int32_t Io
- uint8_t sinr
- uint16_t errorRateListLen
- nas_errorRateListElement errorRateList [18]
- nas_rsrqInformation rsrqInfo
- int16_t ltesnr

- int16_t ltersrp
- swi_uint256_t ParamPresenceMask

8.771.1 Detailed Description

This structure contains the Signal Strength Information

Parameters

signalStrength-ReqMask	• Request Mask – Request additional signal information for: Bit 0 - RSSI Information bit Valid values are: 0 - Do Not Request Additional Info for RSSI 1 - Request Additional Info for RSSI Bit 1 - ECIO Information bit Valid values are: 0 - Do Not Request Additional Info for ECIO 1 - Request Additional Info for ECIO Bit 2 - IO Information bit Valid values are: 0 - Do Not Request Additional Info for IO 1 - Request Additional Info for IO Bit 3 - SINR Information bit Valid values are: 0 - Do Not Request Additional Info for SINR 1 - Request Additional Info for SINR Bit 4 - ERROR RATE Information bit Valid values are: 0 - Do Not Request Additional Info for Error Rate 1 - Request Additional Info for Error Rate Bit 5 - RSRQ Information bit Valid values are: 0 - Do Not Request Additional Info for RSRQ 1 - Request Additional Info for RSRQ Bit 6 - LTE SNR information bit Valid values are: 0 - Do not request additional information for LTE SNR 1 - Request additional information for LTE SNR Bit 7 - LTE RSRP Information bit Valid values are: 0 - Do not request additional information for LTE RSRP 1 - Request additional information for LTE RSRP • Bit to check in ParamPresenceMask - **1**
rxSignal-StrengthListLen	• Number of elements in Receive Signal Strength List • Bit to check in ParamPresenceMask - **17**
rxSignal-StrengthList	• See nas_rxSignalStrengthListElement for more information • Bit to check in ParamPresenceMask - **17**
ecioListLen	• Number of elements in ECIO List • Bit to check in ParamPresenceMask - **18**

ecioList	• See nas_ecioListElement for more information • Bit to check in ParamPresenceMask - **18**
Io	• Received Io in dBm; IO is only applicable for 1xEV-DO • Bit to check in ParamPresenceMask - **19**
sinr	• SINR level – SINR is only applicable for 1xEV-DO; valid levels are 0 to 8 where maximum value for 0 - SINR_LEVEL_0 is -9 dB 1 - SINR_LEVEL_1 is -6 dB 2 - SINR_LEVEL_2 is -4.5 dB 3 - SINR_LEVEL_3 is -3 dB 4 - SINR_LEVEL_4 is -2 dB 5 - SINR_LEVEL_5 is +1 dB 6 - SINR_LEVEL_6 is +3 dB 7 - SINR_LEVEL_7 is +6 dB 8 - SINR_LEVEL_8 is +9 dB • Bit to check in ParamPresenceMask - **20**
errorRateListLen	• Number of elements in Error Rate List • Bit to check in ParamPresenceMask - **21**
errorRateList	• See nas_errorRateListElement for more information • Bit to check in ParamPresenceMask - **21**
rsrqInfo	• See nas_rsrqInformation for more information • Bit to check in ParamPresenceMask - **22**
ltesnr	• LTE SNR level as a scaled integer in units of 0.1 dB; e.g., -16 dB has a value of -160 and 24.6 dB has a value of 246. LTE SNR is included only when the current serving system is LTE • Bit to check in ParamPresenceMask - **23**
ltersrp	• LTE SNR level as a scaled integer in units of 0.1 dB; e.g., -16 dB has a value of -160 and 24.6 dB has a value of 246. LTE SNR is included only when the current serving system is LTE • Bit to check in ParamPresenceMask - **24**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.771.2 Field Documentation

8.771.2.1 nas_ecioListElement unpack_nas_SLQSGetSignalStrength_t::ecioList[18]

8.771.2.2 uint16_t unpack_nas_SLQSGetSignalStrength_t::ecioListLen

8.771.2.3 nas_errorRateListElement unpack_nas_SLQSGetSignalStrength_t::errorRateList[18]

8.771.2.4 uint16_t unpack_nas_SLQSGetSignalStrength_t::errorRateListLen

8.771.2.5 int32_t unpack_nas_SLQSGetSignalStrength_t::lo

8.771.2.6 int16_t unpack_nas_SLQSGetSignalStrength_t::ltersrp

8.771.2.7 int16_t unpack_nas_SLQSGetSignalStrength_t::ltesnr

8.771.2.8 swi_uint256_t unpack_nas_SLQSGetSignalStrength_t::ParamPresenceMask

8.771.2.9 nas_rsrqInformation unpack_nas_SLQSGetSignalStrength_t::rsrqInfo

8.771.2.10 nas_rxSignalStrengthListElement unpack_nas_SLQSGetSignalStrength_t::rxSignalStrengthList[18]

8.771.2.11 uint16_t unpack_nas_SLQSGetSignalStrength_t::rxSignalStrengthListLen

8.771.2.12 uint16_t unpack_nas_SLQSGetSignalStrength_t::signalStrengthReqMask

8.771.2.13 uint8_t unpack_nas_SLQSGetSignalStrength_t::sinr

8.772 unpack_nas_SLQSGetSysInfo_t Struct Reference

Data Fields

- nas_SrvStatusInfo * pCDMASrvStatusInfo
- nas_SrvStatusInfo * pHDRSrvStatusInfo
- nas_GSMSrvStatusInfo * pGSMSrvStatusInfo
- nas_GSMSrvStatusInfo * pWCDMASrvStatusInfo
- nas_GSMSrvStatusInfo * pLTESrvStatusInfo
- nas_CDMASysInfo * pCDMASysInfo
- nas_HDRSysInfo * pHDRSysInfo
- nas_GSMSysInfo * pGSMSysInfo
- nas_WCDMASysInfo * pWCDMASysInfo
- nas_LTESysInfo * pLTESysInfo
- nas_AddCDMASysInfo * pAddCDMASysInfo
- uint16_t * pAddHDRSysInfo
- nas_AddSysInfo * pAddGSMSysInfo
- nas_AddSysInfo * pAddWCDMASysInfo
- uint16_t * pAddLTESysInfo
- nas_CallBarringSysInfo * pGSMCallBarringSysInfo
- nas_CallBarringSysInfo * pWCDMACallBarringSysInfo
- uint8_t * pLTEVoiceSupportSysInfo
- uint8_t * pGSMCipherDomainSysInfo
- uint8_t * pWCDMACipherDomainSysInfo
- uint32_t * pCampedCiotLteOpMode
- swi_uint256_t ParamPresenceMask

8.772.1 Detailed Description

This structure contains unpack get system information parameters.

Parameters

pCDMASrvStatusInfo	• See nas_SrvStatusInfo for more information. • Bit to check in ParamPresenceMask - **16**
pHDRSrvStatusInfo	• See nas_SrvStatusInfo for more information. • Bit to check in ParamPresenceMask - **17**
pGSMSrvStatusInfo	• See nas_GSMSrvStatusInfo for more information. • Bit to check in ParamPresenceMask - **18**
pWCDMASrvStatusInfo	• See nas_GSMSrvStatusInfo for more information. • Bit to check in ParamPresenceMask - **19**
pLTESrvStatusInfo	• See nas_GSMSrvStatusInfo for more information. • Bit to check in ParamPresenceMask - **20**
pCDMASysInfo	• See nas_CDMASysInfo for more information. • Bit to check in ParamPresenceMask - **21**
pHDRSysInfo	• See nas_HDRSysInfo for more information. • Bit to check in ParamPresenceMask - **22**
pGSMSysInfo	• See nas_GSMSysInfo for more information. • Bit to check in ParamPresenceMask - **23**
pWCDMASysInfo	• See nas_WCDMASysInfo for more information. • Bit to check in ParamPresenceMask - **24**
pLTESysInfo	• See nas_LTESysInfo for more information. • Bit to check in ParamPresenceMask - **25**
pAddCDMASysInfo	• See nas_AddCDMASysInfo for more information. • Bit to check in ParamPresenceMask - **26**
pAddHDRSysInfo	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used. • Bit to check in ParamPresenceMask - **27**

pAddGSMSys-Info	• See nas_AddSysInfo for more information. • Bit to check in ParamPresenceMask - **28**
pAddWCDMA-SysInfo	• See nas_AddSysInfo for more information. • Bit to check in ParamPresenceMask - **29**
pAddLTESysInfo	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used. • Bit to check in ParamPresenceMask - **30**
pGSMCall-BarringSysInfo	• See nas_CallBarringSysInfo for more information. • Bit to check in ParamPresenceMask - **31**
pWCDMACall-BarringSysInfo	• See nas_CallBarringSysInfo for more information. • Bit to check in ParamPresenceMask - **32**
pLTEVoice-SupportSysInfo	• Indicates voice support status on LTE. – 0x00 - Voice is not supported – 0x01 - Voice is supported • Bit to check in ParamPresenceMask - **33**
pGSMCipher-DomainSysInfo	• Ciphering on the service domain. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched • Bit to check in ParamPresenceMask - **34**
pWCDMA-CipherDomain-SysInfo	• Ciphering on the service domain. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched • Bit to check in ParamPresenceMask - **35**

pCampedCiot-LteOpMode	• Camped CIOT LTE Operational Mode. • Values – NAS_CIOT_SYS_MODE_NO_SRV (0x00) - No service – NAS_CIOT_SYS_MODE_LTE_WB (0x01) - Camped on LTE wideband – NAS_CIOT_SYS_MODE_LTE_M1 (0x02) - Camped on LTE M1 – NAS_CIOT_SYS_MODE_LTE_NB1 (0x03) - Camped on LTE NB1 • Bit to check in ParamPresenceMask - **73**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.772.2 Field Documentation

8.772.2.1 nas_AddCDMASysInfo∗ unpack_nas_SLQSGetSysInfo_t::pAddCDMASysInfo

8.772.2.2 nas_AddSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pAddGSMSysInfo

8.772.2.3 uint16_t∗ unpack_nas_SLQSGetSysInfo_t::pAddHDRSysInfo

8.772.2.4 uint16_t∗ unpack_nas_SLQSGetSysInfo_t::pAddLTESysInfo

8.772.2.5 nas_AddSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pAddWCDMASysInfo

8.772.2.6 swi_uint256_t unpack_nas_SLQSGetSysInfo_t::ParamPresenceMask

8.772.2.7 uint32_t∗ unpack_nas_SLQSGetSysInfo_t::pCampedCiotLteOpMode

8.772.2.8 nas_SrvStatusInfo∗ unpack_nas_SLQSGetSysInfo_t::pCDMASrvStatusInfo

8.772.2.9 nas_CDMASysInfo∗ unpack_nas_SLQSGetSysInfo_t::pCDMASysInfo

8.772.2.10 nas_CallBarringSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pGSMCallBarringSysInfo

8.772.2.11 uint8_t∗ unpack_nas_SLQSGetSysInfo_t::pGSMCipherDomainSysInfo

8.772.2.12 nas_GSMSrvStatusInfo∗ unpack_nas_SLQSGetSysInfo_t::pGSMSrvStatusInfo

8.772.2.13 nas_GSMSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pGSMSysInfo

8.772.2.14 nas_SrvStatusInfo∗ unpack_nas_SLQSGetSysInfo_t::pHDRSrvStatusInfo

8.772.2.15 nas_HDRSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pHDRSysInfo

8.772.2.16 nas_GSMSrvStatusInfo∗ unpack_nas_SLQSGetSysInfo_t::pLTESrvStatusInfo

8.772.2.17 nas_LTESysInfo∗ unpack_nas_SLQSGetSysInfo_t::pLTESysInfo

8.772.2.18 uint8_t∗ unpack_nas_SLQSGetSysInfo_t::pLTEVoiceSupportSysInfo

8.772.2.19 nas_CallBarringSysInfo∗ unpack_nas_SLQSGetSysInfo_t::pWCDMACallBarringSysInfo

8.772.2.20 uint8_t* unpack_nas_SLQSGetSysInfo_t::pWCDMACipherDomainSysInfo

8.772.2.21 nas_GSMSrvStatusInfo* unpack_nas_SLQSGetSysInfo_t::pWCDMASrvStatusInfo

8.772.2.22 nas_WCDMASysInfo* unpack_nas_SLQSGetSysInfo_t::pWCDMASysInfo

8.773 unpack_nas_SLQSGetSysSelectionPref_t Struct Reference

Data Fields

- uint8_t * pEmerMode
- uint16_t * pModePref
- uint64_t * pBandPref
- uint16_t * pPRLPref
- uint16_t * pRoamPref
- uint64_t * pLTEBandPref
- uint8_t * pNetSelPref
- uint32_t * pSrvDomainPref
- uint32_t * pGWAcqOrderPref
- swi_uint256_t ParamPresenceMask

8.773.1 Detailed Description

This structure contains unpack get get system selection preferences parameters.

Parameters

pEmerMode	• Optional parameter specifying the emergency Mode • Values: – 0 - OFF (normal) – 1 - ON (Emergency)

- * - Bit to check in ParamPresenceMask - **16**

Parameters

pModePref	– Optional parameter – Bit Mask indicating the radio technology mode preference – Bit values: * Bit 0 - cdma2000 1x * Bit 1 - cdma2000 HRPD(1xEV-DO) * Bit 2 - GSM * Bit 3 - UMTS * Bit 4 - LTE

- * - Bit to check in ParamPresenceMask - **17**

Parameters

pBandPref	– Optional parameter – Bit mask representing the band preference – Bit values: * Bit 0 - Band Class 0, A-System * Bit 1 - Band Class 0, B-System, Band Class 0 AB, GSM 850 Band * Bit 2 - Band Class 1, all blocks * Bit 3 - Band Class 2 place holder * Bit 4 - Band Class 3, A-System * Bit 5 - Band Class 4, all blocks * Bit 6 - Band Class 5, all blocks * Bit 7 - GSM_DCS_1800 band * Bit 8 - GSM Extended GSM (E-GSM) 900 band * Bit 9 - GSM Primary GSM (P-GSM) 900 band * Bit 10 - Band Class 6 * Bit 11 - Band Class 7 * Bit 12 - Band Class 8 * Bit 13 - Band Class 9 * Bit 14 - Band Class 10 * Bit 15 - Band Class 11 * Bit 16 - GSM 450 band * Bit 17 - GSM 480 band * Bit 18 - GSM 750 band * Bit 19 - GSM 850 band * Bit 20 - GSM Railways GSM 900 Band * Bit 21 - GSM PCS 1900 band * Bit 22 - WCDMA Europe, Japan, and China IMT 2100 band * Bit 23 - WCDMA U.S. PCS 1900 band * Bit 24 - WCDMA Europe and China DCS 1800 band * Bit 25 - WCDMA U.S. 1700 band * Bit 26 - WCDMA U.S. 850 band * Bit 27 - WCDMA Japan 800 band * Bit 28 - Band Class 12 * Bit 29 - Band Class 14 * Bit 30 - Reserved * Bit 31 - Band Class 15 * Bit 32 to 47 - Reserved * Bit 48 - WCDMA Europe 2600 band * Bit 49 - WCDMA Europe and Japan 900 band * Bit 50 - WCDMA Japan 1700 band * Bit 51 to 55 - Reserved * Bit 56 - Band Class 16 * Bit 57 - Band Class 17 * Bit 58 - Band Class 18 * Bit 59 - Band Class 19 * Bit 60 to 64 - Reserved

- $*$ - Bit to check in ParamPresenceMask - **18**

Parameters

pPRLPref	– Optional parameter indicating the CDMA PRL Preference – Values: * 0x0001 - Acquire available system only on the A side * 0x0002 - Acquire available system only on the B side * 0x3FFF - Acquire any available systems

- $*$ - Bit to check in ParamPresenceMask - **19**

Parameters

pRoamPref	– Optional parameter indicating the roaming Preference – Values: * 0x01 - Acquire only systems for which the roaming indicator is off * 0x02 - Acquire a system as long as its roaming indicator is not off * 0x03 - Acquire only systems for which the roaming indicator is off or solid on, i.e. not flashing; CDMA only * 0xFF - Acquire systems, regardless of their roaming indicator

- $*$ - Bit to check in ParamPresenceMask - **20**

Parameters

pLTEBandPref	– Optional parameter – Bit mask representing the LTE band preference – Bit Values * Bit 0 - E-UTRA Operating Band 1 * Bit 1 - E-UTRA Operating Band 2 * Bit 2 - E-UTRA Operating Band 3 * Bit 3 - E-UTRA Operating Band 4 * Bit 4 - E-UTRA Operating Band 5 * Bit 5 - E-UTRA Operating Band 6 * Bit 6 - E-UTRA Operating Band 7 * Bit 7 - E-UTRA Operating Band 8 * Bit 8 - E-UTRA Operating Band 9 * Bit 9 - E-UTRA Operating Band 10 * Bit 10 - E-UTRA Operating Band 11 * Bit 11 - E-UTRA Operating Band 12 * Bit 12 - E-UTRA Operating Band 13 * Bit 13 - E-UTRA Operating Band 14 * Bit 16 - E-UTRA Operating Band 17 * Bit 17 - E-UTRA Operating Band 18 * Bit 18 - E-UTRA Operating Band 19 * Bit 19 - E-UTRA Operating Band 20 * Bit 20 - E-UTRA Operating Band 21 * Bit 32 - E-UTRA Operating Band 33 * Bit 33 - E-UTRA Operating Band 34 * Bit 34 - E-UTRA Operating Band 35 * Bit 35 - E-UTRA Operating Band 36 * Bit 36 - E-UTRA Operating Band 37 * Bit 37 - E-UTRA Operating Band 38 * Bit 38 - E-UTRA Operating Band 39 * Bit 39 - E-UTRA Operating Band 40 * All other bits are reserved

- $*$ - Bit to check in ParamPresenceMask - **21**

Parameters

pNetSelPref	– Optional parameter indicating network selection preference – Values: * 0x00 - Automatic network selection * 0x01 - Manual network selection.

- $*$ - Bit to check in ParamPresenceMask - **22**

Parameters

pSrvDomainPref	– Optional parameter indicating Service domain preference – Values: * 0x00 - Circuit switched only * 0x01 - Packet switched only * 0x02 - Circuit switched and packet switched * 0x03 - Packet switched attach * 0x04 - Packet switched detach

- ∗ - Bit to check in ParamPresenceMask - **24**

Parameters

pGWAcqOrder-Pref	– Optional parameter indicating GSM/WCDMA Acquisition order Preference – Values: * 0x00 - Automatic * 0x01 - GSM then WCDMA * 0x02 - WCDMA then GSM

- ∗ - Bit to check in ParamPresenceMask - **25**

Parameters

ParamPresence-Mask	– bitmask representation to indicate valid parameters.

8.773.2 Field Documentation

8.773.2.1 swi_uint256_t unpack_nas_SLQSGetSysSelectionPref_t::ParamPresenceMask

8.773.2.2 uint64_t∗ unpack_nas_SLQSGetSysSelectionPref_t::pBandPref

8.773.2.3 uint8_t∗ unpack_nas_SLQSGetSysSelectionPref_t::pEmerMode

8.773.2.4 uint32_t∗ unpack_nas_SLQSGetSysSelectionPref_t::pGWAcqOrderPref

8.773.2.5 uint64_t∗ unpack_nas_SLQSGetSysSelectionPref_t::pLTEBandPref

8.773.2.6 uint16_t∗ unpack_nas_SLQSGetSysSelectionPref_t::pModePref

8.773.2.7 uint8_t∗ unpack_nas_SLQSGetSysSelectionPref_t::pNetSelPref

8.773.2.8 uint16_t∗ unpack_nas_SLQSGetSysSelectionPref_t::pPRLPref

8.773.2.9 uint16_t∗ unpack_nas_SLQSGetSysSelectionPref_t::pRoamPref

8.773.2.10 uint32_t∗ unpack_nas_SLQSGetSysSelectionPref_t::pSrvDomainPref

8.774 unpack_nas_SLQSGetSysSelectionPrefExt_t Struct Reference

Data Fields

- nas_EmerModeTlv * pEmerMode
- nas_ModePrefTlv * pModePref
- nas_BandPrefTlv * pBandPref
- nas_PRLPrefTlv * pPRLPref
- nas_RoamPrefTlv * pRoamPref
- nas_LTEBandPrefTlv * pLTEBandPref
- nas_NetSelPrefTlv * pNetSelPref
- nas_SrvDomainPrefTlv * pSrvDomainPref
- nas_GWAcqOrderPrefTlv * pGWAcqOrderPref
- nas_AcqOrderPrefTlv * pAcqOrderPref
- nas_RatDisabledMaskTlv * pRatDisabledMask
- nas_CiotLteOpModePrefTlv * pCiotLteOpModePref
- nas_LteM1BandPrefTlv * pLteM1BandPref
- nas_LteNb1BandPrefTlv * pLteNb1BandPref
- nas_CiotAcqOrderPrefTlv * pCiotAcqOrderPref
- nas_NR5gBandPrefTlv * pNr5gBandPref
- nas_LTEBandPrefExtTlv * pLTEBandPrefExt

8.774.1 Detailed Description

Structure for storing the current preferred system selection settings for the device.

Parameters

pEmerMode	• Optional parameter specifying the emergency Mode • See nas_EmerModeTlv for more information
pModePref	• Optional parameterindicating the radio technology mode preference • See nas_ModePrefTlv for more information
pBandPref	• Optional parameter representing the band preference • See nas_BandPrefTlv for more information
pPRLPref	• Optional parameter indicating the CDMA PRL Preference • See nas_PRLPrefTlv for more information
pRoamPref	• Optional parameter indicating the roaming Preference • See nas_RoamPrefTlv for more information
pLTEBandPref	• Optional parameter representing the LTE band preference • See nas_LTEBandPrefTlv for more information
pNetSelPref	• Optional parameter indicating network selection preference • See nas_NetSelPrefTlv for more information

pSrvDomainPref	• Optional parameter indicating Service domain preference • See nas_SrvDomainPrefTlv for more information
pGWAcqOrder-Pref	• Optional parameter indicating GSM/WCDMA Acquisition order Preference • See nas_GWAcqOrderPrefTlv for more information
pAcqOrderPref	• Optional parameter • Acquisition Order Preference • See nas_AcqOrderPrefTlv for more information
pRatDisabled-Mask	• Optional parameter representing the radio technologies that are disabled. • See nas_RatDisabledMaskTlv for more information
pCiotLteOp-ModePref	• Optional parameter • CIOT LTE Operational Mode Preference • See nas_CiotLteOpModePrefTlv for more information
pLteM1BandPref	• Optional parameter representing the LTE M1 band preference • See nas_LteM1BandPrefTlv for more information
pLteNb1Band-Pref	• Optional parameter representing the LTE NB1 band preference. • See nas_LteNb1BandPrefTlv for more information
pCiotAcqOrder-Pref	• Optional parameter indicating CIOT Acquisition Order Preference • See nas_CiotAcqOrderPrefTlv for more information
pNr5gBandPref	• Optional parameter indicating NR5G Band Preference • See nas_NR5gBandPrefTlv for more information
pLTEBandPref-Ext	• Optional parameter indicating LTE Band Preference Extended • See nas_LTEBandPrefExtTlv for more information

8.774.2 Field Documentation

8.774.2.1 nas_AcqOrderPrefTlv* unpack_nas_SLQSGetSysSelectionPrefExt_t::pAcqOrderPref

8.774.2.2 nas_BandPrefTlv* unpack_nas_SLQSGetSysSelectionPrefExt_t::pBandPref

8.774.2.3 nas_CiotAcqOrderPrefTlv* unpack_nas_SLQSGetSysSelectionPrefExt_t::pCiotAcqOrderPref

8.774.2.4 **nas_CiotLteOpModePrefTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pCiotLteOpModePref

8.774.2.5 **nas_EmerModeTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pEmerMode

8.774.2.6 **nas_GWAcqOrderPrefTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pGWAcqOrderPref

8.774.2.7 **nas_LTEBandPrefTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pLTEBandPref

8.774.2.8 **nas_LTEBandPrefExtTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pLTEBandPrefExt

8.774.2.9 **nas_LteM1BandPrefTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pLteM1BandPref

8.774.2.10 **nas_LteNb1BandPrefTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pLteNb1BandPref

8.774.2.11 **nas_ModePrefTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pModePref

8.774.2.12 **nas_NetSelPrefTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pNetSelPref

8.774.2.13 **nas_NR5gBandPrefTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pNr5gBandPref

8.774.2.14 **nas_PRLPrefTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pPRLPref

8.774.2.15 **nas_RatDisabledMaskTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pRatDisabledMask

8.774.2.16 **nas_RoamPrefTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pRoamPref

8.774.2.17 **nas_SrvDomainPrefTlv**∗ unpack_nas_SLQSGetSysSelectionPrefExt_t::pSrvDomainPref

8.775 unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t Struct Reference

Data Fields

- nas_EdrxEnableType edrxEnableTypeTlv
- nas_EdrxCycleLength edrxCycleLengthTlv
- nas_EdrxPagingTimeWindow edrxPagingTimeWindowTlv
- nas_EdrxRatType edrxRatTypeTlv
- nas_EdrxCiotLteMode edrxCiotLteModeTlv
- swi_uint256_t ParamPresenceMask

8.775.1 Detailed Description

Structure for storing the eDRX Change Info indication parameters.

Parameters

edrxEnableTypeTlv	• See nas_EdrxEnableType for more information. • Bit to check in ParamPresenceMask - **16**
edrxCycleLengthTlv	• See nas_EdrxCycleLength for more information. • Bit to check in ParamPresenceMask - **17**

edrxPagingTime-WindowTlv	• See nas_EdrxPagingTimeWindow for more information. • Bit to check in ParamPresenceMask - **18**
edrxRatTypeTlv	• See nas_EdrxRatType for more information. • Bit to check in ParamPresenceMask - **19**
edrxCiotLte-ModeTlv	• See nas_EdrxCiotLteMode for more information. • Bit to check in ParamPresenceMask - **20**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.775.2 Field Documentation

8.775.2.1 nas_EdrxCiotLteMode unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t::edrxCiotLteModeTlv

8.775.2.2 nas_EdrxCycleLength unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t::edrxCycleLengthTlv

8.775.2.3 nas_EdrxEnableType unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t::edrxEnableTypeTlv

8.775.2.4 nas_EdrxPagingTimeWindow unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t::edrxPagingTimeWindow-Tlv

8.775.2.5 nas_EdrxRatType unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t::edrxRatTypeTlv

8.775.2.6 swi_uint256_t unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t::ParamPresenceMask

8.776 unpack_nas_SLQSNasGet3GPP2Subscription_t Struct Reference

Data Fields

- nas_namName * pNAMNameInfo
- nas_dirNum * pDirNum
- nas_homeSIDNID * pHomeSIDNID
- nas_minBasedIMSI * pMinBasedIMSI
- nas_trueIMSI * pTrueIMSI
- nas_CDMAChannel * pCDMAChannel
- swi_uint256_t ParamPresenceMask

8.776.1 Detailed Description

Structure for 3GPP2Subscription unpack.

Parameters

pNAMNameInfo	[Optional] • See nas_namName for more information • Bit to check in ParamPresenceMask - **16**

pDirNum	[Optional] • See nas_dirNum for more information • Bit to check in ParamPresenceMask - **17**
pHomeSIDNID	[Optional] • See nas_homeSIDNID for more information • Bit to check in ParamPresenceMask - **18**
pMinBasedIMSI	[Optional] • See nas_minBasedIMSI for more information • Bit to check in ParamPresenceMask - **19**
pTrueIMSI	[Optional] • See nas_trueIMSI for more information • Bit to check in ParamPresenceMask - **20**
pCDMAChannel	[Optional] • See nas_CDMAChannel for more information • Bit to check in ParamPresenceMask - **21**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.776.2 Field Documentation

8.776.2.1 swi_uint256_t unpack_nas_SLQSNasGet3GPP2Subscription_t::ParamPresenceMask

8.776.2.2 nas_CDMAChannel* unpack_nas_SLQSNasGet3GPP2Subscription_t::pCDMAChannel

8.776.2.3 nas_dirNum* unpack_nas_SLQSNasGet3GPP2Subscription_t::pDirNum

8.776.2.4 nas_homeSIDNID* unpack_nas_SLQSNasGet3GPP2Subscription_t::pHomeSIDNID

8.776.2.5 nas_minBasedIMSI* unpack_nas_SLQSNasGet3GPP2Subscription_t::pMinBasedIMSI

8.776.2.6 nas_namName* unpack_nas_SLQSNasGet3GPP2Subscription_t::pNAMNameInfo

8.776.2.7 nas_trueIMSI* unpack_nas_SLQSNasGet3GPP2Subscription_t::pTrueIMSI

8.777 unpack_nas_SLQSNasGetCellLocationInfo_t Struct Reference

Data Fields

- nas_GERANInfo * pGERANInfo
- nas_UMTSInfo * pUMTSInfo
- nas_CDMAInfo * pCDMAInfo
- nas_LTEInfoIntrafreq * pLTEInfoIntrafreq
- nas_LTEInfoInterfreq * pLTEInfoInterfreq
- nas_LTEInfoNeighboringGSM * pLTEInfoNeighboringGSM
- nas_LTEInfoNeighboringWCDMA * pLTEInfoNeighboringWCDMA
- uint32_t * pUMTSCellID

- nas_WCDMAInfoLTENeighborCell * pWCDMAInfoLTENeighborCell
- swi_uint256_t ParamPresenceMask

8.777.1 Detailed Description

This structure contains information about the Get Cell Location response parameters.

Parameters

pGERANInfo	• See nas_GERANInfo for more information. • Bit to check in ParamPresenceMask - **16**
pUMTSInfo	• See nas_UMTSInfo for more information. • Bit to check in ParamPresenceMask - **17**
pCDMAInfo	• See nas_CDMAInfo for more information. • Bit to check in ParamPresenceMask - **18**
pLTEInfo-Intrafreq	• See nas_LTEInfoIntrafreq for more information. • Bit to check in ParamPresenceMask - **19**
pLTEInfo-Interfreq	• See nas_LTEInfoInterfreq for more information. • Bit to check in ParamPresenceMask - **20**
pLTEInfo-NeighboringGSM	• See nas_LTEInfoNeighboringGSM for more information. • Bit to check in ParamPresenceMask - **21**
pLTEInfo-NeighboringWCDMA	• See nas_LTEInfoNeighboringWCDMA for more information. • Bit to check in ParamPresenceMask - **22**
pUMTSCellID	• Cell ID. • 0xFFFFFFFF indicates cell ID information is not present. • Bit to check in ParamPresenceMask - **23**
pWCDMAInfoLTENeighborCell	• See nas_WCDMAInfoLTENeighborCell for more information. • Bit to check in ParamPresenceMask - **24**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.777.2 Field Documentation

8.777.2.1 **swi_uint256_t unpack_nas_SLQSNasGetCellLocationInfo_t::ParamPresenceMask**

8.777.2.2 **nas_CDMAInfo∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pCDMAInfo**

8.777.2.3 **nas_GERANInfo∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pGERANInfo**

8.777.2.4 **nas_LTEInfoInterfreq∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pLTEInfoInterfreq**

8.777.2.5 **nas_LTEInfoIntrafreq∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pLTEInfoIntrafreq**

8.777.2.6 **nas_LTEInfoNeighboringGSM∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pLTEInfoNeighboringGSM**

8.777.2.7 **nas_LTEInfoNeighboringWCDMA∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pLTEInfoNeighboringWCDMA**

8.777.2.8 **uint32_t∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pUMTSCellID**

8.777.2.9 **nas_UMTSInfo∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pUMTSInfo**

8.777.2.10 **nas_WCDMAInfoLTENeighborCell∗ unpack_nas_SLQSNasGetCellLocationInfo_t::pWCDMAInfoLTENeighborCell**

8.778 unpack_nas_SLQSNASGeteDRXParams_t Struct Reference

Data Fields

- uint8_t ∗ pCycleLen
- uint8_t ∗ pPagingTimeWindow
- uint8_t ∗ pEdrxEnable
- swi_uint256_t ParamPresenceMask

8.778.1 Detailed Description

This structure contains the SLQSNASGeteDRXParams unpack parameters.

Parameters

pCycleLen	[Optional] • eDRX cycle length • Value is per 3GPP TS 24.008 Rel-13 Section 10.5.5.32 • Bit to check in ParamPresenceMask - **16**
pPagingTime-Window	[Optional] • eDRX paging time window • Value is per 3GPP TS 24.008 Rel-13 Section10.5.5.32 • Bit to check in ParamPresenceMask - **17**
pEdrxEnable	[Optional] • eDRX Enable • Values – 0x00 - Disable – 0x01 - Enable • Bit to check in ParamPresenceMask - **18**

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.778.2 Field Documentation

8.778.2.1 swi_uint256_t unpack_nas_SLQSNASGeteDRXParams_t::ParamPresenceMask

8.778.2.2 uint8_t* unpack_nas_SLQSNASGeteDRXParams_t::pCycleLen

8.778.2.3 uint8_t* unpack_nas_SLQSNASGeteDRXParams_t::pEdrxEnable

8.778.2.4 uint8_t* unpack_nas_SLQSNASGeteDRXParams_t::pPagingTimeWindow

8.779 unpack_nas_SLQSNASGeteDRXParamsExt_t Struct Reference

Data Fields

- uint8_t * pCycleLen
- uint8_t * pPagingTimeWindow
- uint8_t * pEdrxEnable
- uint8_t * pEdrxRAT
- uint32_t * pLteOpMode
- swi_uint256_t ParamPresenceMask

8.779.1 Detailed Description

This structure contains the SLQSNASGeteDRXParams unpack parameters.

Parameters

pCycleLen	[Optional] • eDRX cycle length • Value is per 3GPP TS 24.008 Rel-13 Section 10.5.5.32 • Bit to check in ParamPresenceMask - **16**
pPagingTime-Window	[Optional] • eDRX paging time window • Value is per 3GPP TS 24.008 Rel-13 Section10.5.5.32 • Bit to check in ParamPresenceMask - **17**
pEdrxEnable	[Optional] • eDRX Enable • Values – 0x00 - Disable – 0x01 - Enable • Bit to check in ParamPresenceMask - **18**

pEdrxRAT	[Optional] • eDRX Radio Access Technology • Values – NAS_RADIO_IF_NO_SVC (0x00) - None (no service) – NAS_RADIO_IF_CDMA_1X (0x01) - cdma2000 ® 1X – NAS_RADIO_IF_CDMA_1XEVDO (0x02) - cdma2000 ® HRPD (1xEV-DO) – NAS_RADIO_IF_AMPS (0x03) - AMPS – NAS_RADIO_IF_GSM (0x04) - GSM – NAS_RADIO_IF_UMTS (0x05) - UMTS – NAS_RADIO_IF_WLAN (0x06) - WLAN – NAS_RADIO_IF_GPS (0x07) - GPS – NAS_RADIO_IF_LTE (0x08) - LTE – NAS_RADIO_IF_TDSCDMA (0x09) - TD-SCDMA – NAS_RADIO_IF_LTE_M1 (0x0a) - LTE-M1 – NAS_RADIO_IF_LTE_NB1 (0x0b) - LTE-NB1 – NAS_RADIO_IF_NO_CHANGE (-1) - No change • Bit to check in ParamPresenceMask - **19**
pLteOpMode	[Optional] • LTE Operational Mode • Values – NAS_CIOT_SYS_MODE_NO_ SRV (0x00) - No service – NAS_CIOT_SYS_MODE_LTE_ WB (0x01) - Camped on LTE wideband – NAS_CIOT_SYS_MODE_LTE_ M1 (0x02) - Camped on LTE M1 – NAS_CIOT_SYS_MODE_LTE_ NB1 (0x03) - Camped on LTE NB1 • Bit to check in ParamPresenceMask - **20**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.779.2 Field Documentation

8.779.2.1 swi_uint256_t unpack_nas_SLQSNASGeteDRXParamsExt_t::ParamPresenceMask

8.779.2.2 uint8_t* unpack_nas_SLQSNASGeteDRXParamsExt_t::pCycleLen

8.779.2.3 uint8_t* unpack_nas_SLQSNASGeteDRXParamsExt_t::pEdrxEnable

8.779.2.4 uint8_t* unpack_nas_SLQSNASGeteDRXParamsExt_t::pEdrxRAT

8.779.2.5 uint32_t* unpack_nas_SLQSNASGeteDRXParamsExt_t::pLteOpMode

8.779.2.6 uint8_t* unpack_nas_SLQSNASGeteDRXParamsExt_t::pPagingTimeWindow

8.780 unpack_nas_SLQSNASGetForbiddenNetworks_t Struct Reference

Data Fields

- nas_ForbiddenNetworks3GPP * pForbiddenNetworks3GPP
- swi_uint256_t ParamPresenceMask

8.780.1 Detailed Description

This structure contains the SLQSNASGeteDRXParams request parameters.

Parameters

pForbidden-Networks3GPP	[Optional] • See nas_ForbiddenNetworks3GPP for more information. • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.780.2 Field Documentation

8.780.2.1 swi_uint256_t unpack_nas_SLQSNASGetForbiddenNetworks_t::ParamPresenceMask

8.780.2.2 nas_ForbiddenNetworks3GPP* unpack_nas_SLQSNASGetForbiddenNetworks_t::pForbiddenNetworks3GPP

8.781 unpack_nas_SLQSNasGetHDRColorCode_t Struct Reference

Data Fields

- uint8_t * pColorCode
- swi_uint256_t ParamPresenceMask

8.781.1 Detailed Description

Structure for storing the current preferred system selection settings for the device.

Parameters

pColorCode	[Optional] • Color code value • Color code corresponding to the sector to which the AT is sending the access probe • See 3GPP2 C.S0024-B V3.0, Section 7.11.6.2.1 for more information. – 0xFF - Not Available • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.781.2 Field Documentation

8.781.2.1 swi_uint256_t unpack_nas_SLQSNasGetHDRColorCode_t::ParamPresenceMask

8.781.2.2 uint8_t* unpack_nas_SLQSNasGetHDRColorCode_t::pColorCode

8.782 unpack_nas_SLQSNasGetRFInfo_t Struct Reference

Data Fields

- nas_RfBandInfoList rfbandInfoList
- nas_RfDedicatedBandInfo * pRfDedicatedBandInfo
- nas_RfBandInfoExtFormat * pRfBandInfoExtFormat
- nas_RfBandwidthInfo * pRfBandwidthInfo
- nas_LTEOperationMode * pLTEOperationMode
- uint16_t Tlvresult

8.782.1 Detailed Description

This structure contains the SLQSNasGetRFInfo response parameters.

Parameters

rfbandInfoList	• See nas_RfBandInfoList for more information
pRfDedicated-BandInfo	[Optional] • See nas_RfDedicatedBandInfo for more information
pRfBandInfoExt-Format	[Optional] • See nas_RfBandInfoExtFormat for more information
pRfBandwidth-Info	[Optional] • See nas_RfBandwidthInfo for more information
pLTEOpration-Mode	[Optional] • See nas_LTEOperationMode for more information

8.782.2 Field Documentation

8.782.2.1 nas_LTEOperationMode* unpack_nas_SLQSNasGetRFInfo_t::pLTEOperationMode

8.782.2.2 nas_RfBandInfoExtFormat* unpack_nas_SLQSNasGetRFInfo_t::pRfBandInfoExtFormat

8.782.2.3 nas_RfBandwidthInfo* unpack_nas_SLQSNasGetRFInfo_t::pRfBandwidthInfo

8.782.2.4 nas_RfDedicatedBandInfo* unpack_nas_SLQSNasGetRFInfo_t::pRfDedicatedBandInfo

8.782.2.5 nas_RfBandInfoList unpack_nas_SLQSNasGetRFInfo_t::rfbandInfoList

8.782.2.6 uint16_t unpack_nas_SLQSNasGetRFInfo_t::Tlvresult

8.783 unpack_nas_SLQSNasGetSigInfo_t Struct Reference

Data Fields

- cdmaSSInfo CDMASSInfo
- hdrSSInfo HDRSSInfo
- int8_t GSMSSInfo
- cdmaSSInfo WCDMASSInfo
- lteSSInfo LTESSInfo

- swi_uint256_t ParamPresenceMask

8.783.1 Detailed Description

This structure contains the SLQSNasGetSigInfo response parameters.

Parameters

CDMASSInfo	• See cdmaSSInfo for more information • Bit to check in ParamPresenceMask - **16**
HDRSSInfo	• See hdrSSInfo for more information • Bit to check in ParamPresenceMask - **17**
GSMSSInfo	• GSM signal strength is the RSSI in dBm (signed value). • A value of -125 dBm or lower is used to indicate No Signal. • Bit to check in ParamPresenceMask - **18**
WCDMASSInfo	• See cdmaSSInfo for more information • Bit to check in ParamPresenceMask - **19**
LTESSInfo	• See lteSSInfo for more information • Bit to check in ParamPresenceMask - **20**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.783.2 Field Documentation

8.783.2.1 cdmaSSInfo unpack_nas_SLQSNasGetSigInfo_t::CDMASSInfo

8.783.2.2 int8_t unpack_nas_SLQSNasGetSigInfo_t::GSMSSInfo

8.783.2.3 hdrSSInfo unpack_nas_SLQSNasGetSigInfo_t::HDRSSInfo

8.783.2.4 lteSSInfo unpack_nas_SLQSNasGetSigInfo_t::LTESSInfo

8.783.2.5 swi_uint256_t unpack_nas_SLQSNasGetSigInfo_t::ParamPresenceMask

8.783.2.6 cdmaSSInfo unpack_nas_SLQSNasGetSigInfo_t::WCDMASSInfo

8.784 unpack_nas_SLQSNasGetTxRxInfo_t Struct Reference

Data Fields

- nas_rxInfo * pRXChain0Info
- nas_rxInfo * pRXChain1Info

- nas_txInfo * pTXInfo
- swi_uint256_t ParamPresenceMask

8.784.1 Detailed Description

Structure for TxRx Info unpack

Parameters

pRXChain0Info	[Optional] • See nas_rxInfo for more information. • Bit to check in ParamPresenceMask - **16**
pRXChain1Info	[Optional] • See nas_rxInfo for more information. • Bit to check in ParamPresenceMask - **17**
pTXInfo	[Optional] • See nas_txInfo for more information. • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.784.2 Field Documentation

8.784.2.1 swi_uint256_t unpack_nas_SLQSNasGetTxRxInfo_t::ParamPresenceMask

8.784.2.2 nas_rxInfo* unpack_nas_SLQSNasGetTxRxInfo_t::pRXChain0Info

8.784.2.3 nas_rxInfo* unpack_nas_SLQSNasGetTxRxInfo_t::pRXChain1Info

8.784.2.4 nas_txInfo* unpack_nas_SLQSNasGetTxRxInfo_t::pTXInfo

8.785 unpack_nas_SLQSNasNetworkRejectCallback_Ind_t Struct Reference

Data Fields

- uint8_t radioIf
- LITE_TYPE_OF_SERVICE_DOMAIN serviceDomain
- uint8_t rejectCause
- nas_PlmnID * pPlmnId
- nas_CsgId * pCsgId
- nas_LteOpMode * pLteOpMode
- swi_uint256_t ParamPresenceMask

8.785.1 Detailed Description

Structure for storing the network reject indication parameters.

Parameters

radioIf	• Radio interface from which to get the information. Values: – 0x04 - NAS_RADIO_IF_GSM - GSM – 0x05 - NAS_RADIO_IF_UMTS - UMTS – 0x08 - NAS_RADIO_IF_LTE - LTE – 0x09 - NAS_RADIO_IF_TDSCDMA - TDSCDMA • Bit to check in ParamPresenceMask - **1**
serviceDomain	• Type of service domain in which the registration is rejected. Values: – 0x00 - LITE_SYS_SRV_DOMAIN_NO_SRV - No service – 0x01 - LITE_SYS_SRV_DOMAIN_CS_ONLY - Circuit-switched only – 0x02 - LITE_SYS_SRV_DOMAIN_PS_ONLY - Packet-switched only – 0x03 - LITE_SYS_SRV_DOMAIN_CS_PS - Circuit-switched and packet-switched – 0x04 - LITE_SYS_SRV_DOMAIN_CAMPED - Camped • Bit to check in ParamPresenceMask - **2**

rejectCause	• Reject cause values. – 2 - IMSI unknown in HLR – 3 - Illegal MS – 4 - IMSI unknown in VLR – 5 - IMEI not accepted – 6 - Illegal ME – 7 - EPS services not allowed – 8 - EPS services and non-EPS services not allowed – 9 - UE identity cannot be derived by the network – 10 - Implicitly detached – 11 - PLMN not allowed – 12 - Location Area not allowed – 13 - Roaming not allowed in this location area – 14 - EPS services not allowed in this PLMN – 15 - No Suitable Cells In Location Area – 16 - MSC temporarily not reachable – 17 - Network failure – 18 - CS domain not available – 19 - ESM failure – 20 - MAC failure – 21 - Synch failure – 22 - Congestion – 23 - GSM authentication unacceptable – 24 - Security mode rejected, unspecified – 25 - Not authorized for this CSG – 26 - Non-EPS authentication unacceptable – 32 - Service option not supported – 33 - Requested service option not subscribed – 34 - Service option temporarily out of order – 38 - Call cannot be identified – 48 to 63 - retry upon entry into a new cell – 95 - Semantically incorrect message – 96 - Invalid mandatory information – 97 - Message type non-existent or not implemented – 98 - Message type not compatible with the protocol state – 99 - Information element non-existent or not implemented – 100 - Conditional IE error – 101 - Message not compatible with the protocol state – 111 - Protocol error, unspecified – Note - Any other value received by the mobile station shall be treated as 34, 'Service option temporarily out of order'. * Any other value received by the network shall be treated as 111, 'Protocol error, unspecified'. See 3GPP TS 24.008, Section 4.4.4.7 and Section 10.5.3.6 See qaGobiApiTableCallEndReasons.h for Call End reasons • Bit to check in ParamPresenceMask - **3**

pPlmnId	(optional) • See nas_PlmnID for more information • Bit to check in ParamPresenceMask - **16**
pCsgId	(optional) • See nas_CsgId for more information. • Bit to check in ParamPresenceMask - **17**
pLteOpMode	(optional) • See nas_LteOpMode for more information. • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.785.2 Field Documentation

8.785.2.1 swi_uint256_t unpack_nas_SLQSNasNetworkRejectCallback_Ind_t::ParamPresenceMask

8.785.2.2 nas_CsgId* unpack_nas_SLQSNasNetworkRejectCallback_Ind_t::pCsgId

8.785.2.3 nas_LteOpMode* unpack_nas_SLQSNasNetworkRejectCallback_Ind_t::pLteOpMode

8.785.2.4 nas_PlmnID* unpack_nas_SLQSNasNetworkRejectCallback_Ind_t::pPlmnId

8.785.2.5 uint8_t unpack_nas_SLQSNasNetworkRejectCallback_Ind_t::radioIf

8.785.2.6 uint8_t unpack_nas_SLQSNasNetworkRejectCallback_Ind_t::rejectCause

8.785.2.7 LITE_TYPE_OF_SERVICE_DOMAIN unpack_nas_SLQSNasNetworkRejectCallback_Ind_t::serviceDomain

8.786 unpack_nas_SLQSNasNetworkTimeCallBack_ind_t Struct Reference

Data Fields

- nas_UniversalTime universalTime
- uint8_t * pTimeZone
- uint8_t * pDayltSavAdj
- uint8_t * pRadioInterface
- swi_uint256_t ParamPresenceMask

8.786.1 Detailed Description

Structure for storing the NAS Network Time indication parameters.

Parameters

universalTime	• See nas_UniversalTime for more information. • Bit to check in ParamPresenceMask - **1**

pTimeZone	• Time Zone. • Offset from Universal time, i.e., the difference between local time and Universal time, in increments of 15 min (signed value). • Bit to check in ParamPresenceMask - **16**
pDayltSavAdj	• Daylight Saving Adjustment. • Daylight saving adjustment in hr. – Possible values: 0, 1, and 2. • Bit to check in ParamPresenceMask - **17**
pRadioInterface	• Radio interface from which the information comes • Values – 0x01 - NAS_RADIO_IF_CDMA_1X - cdma2000 1X – 0x02 - NAS_RADIO_IF_CDMA_1XEVDO - cdma2000 HRPD (1xEV-DO) – 0x04 - NAS_RADIO_IF_GSM - GSM – 0x05 - NAS_RADIO_IF_UMTS - UMTS – 0x08 - NAS_RADIO_IF_LTE - LTE – 0x09 - NAS_RADIO_IF_TDSCDMA -TD-SCDMA • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.786.2 Field Documentation

8.786.2.1 swi_uint256_t unpack_nas_SLQSNasNetworkTimeCallBack_ind_t::ParamPresenceMask

8.786.2.2 uint8_t* unpack_nas_SLQSNasNetworkTimeCallBack_ind_t::pDayltSavAdj

8.786.2.3 uint8_t* unpack_nas_SLQSNasNetworkTimeCallBack_ind_t::pRadioInterface

8.786.2.4 uint8_t* unpack_nas_SLQSNasNetworkTimeCallBack_ind_t::pTimeZone

8.786.2.5 nas_UniversalTime unpack_nas_SLQSNasNetworkTimeCallBack_ind_t::universalTime

8.787 unpack_nas_SLQSNasSigInfoCallback_ind_t Struct Reference

Data Fields

- cdmaSSInfo * pCDMASigInfo
- hdrSSInfo * pHDRSigInfo
- int8_t * pGSMSigInfo
- cdmaSSInfo * pWCDMASigInfo
- lteSSInfo * pLTESigInfo
- int8_t * pRscp
- tdscdmaSigInfoExt * pTDSCDMASigInfoExt
- swi_uint256_t ParamPresenceMask

8.787.1 Detailed Description

Structure for storing the nasSigInfo indication parameters.

Parameters

pCDMASigInfo	• See cdmaSSInfo for more information. • Bit to check in ParamPresenceMask - **16**
pHDRSigInfo	• See hdrSSInfo for more information. • Bit to check in ParamPresenceMask - **17**
pGSMSigInfo	• one byte value, GSM signal strength is the RSSI in dBm (signed value). A value of -125 dBm or lower is used to indicate No Signal • Bit to check in ParamPresenceMask - **18**
pWCDMASigInfo	• See cdmaSSInfo for more information. • Bit to check in ParamPresenceMask - **19**
pLTESigInfo	• See lteSSInfo for more information. • Bit to check in ParamPresenceMask - **20**
pRscp	• RSCP of the Primary Common Control Physical Channel (PCCPCH) in dBm. Measurement range: -120 dBm to -25 dBm. • Bit to check in ParamPresenceMask - **21**
pTDSCDMASigInfoExt	• See tdscdmaSigInfoExt for more information. • Bit to check in ParamPresenceMask - **22**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.787.2 Field Documentation

8.787.2.1 swi_uint256_t unpack_nas_SLQSNasSigInfoCallback_ind_t::ParamPresenceMask

8.787.2.2 cdmaSSInfo* unpack_nas_SLQSNasSigInfoCallback_ind_t::pCDMASigInfo

8.787.2.3 int8_t* unpack_nas_SLQSNasSigInfoCallback_ind_t::pGSMSigInfo

8.787.2.4 hdrSSInfo* unpack_nas_SLQSNasSigInfoCallback_ind_t::pHDRSigInfo

8.787.2.5 lteSSInfo* unpack_nas_SLQSNasSigInfoCallback_ind_t::pLTESigInfo

8.787.2.6 int8_t* unpack_nas_SLQSNasSigInfoCallback_ind_t::pRscp

8.787.2.7 tdscdmaSigInfoExt∗ unpack_nas_SLQSNasSigInfoCallback_ind_t::pTDSCDMASigInfoExt

8.787.2.8 cdmaSSInfo∗ unpack_nas_SLQSNasSigInfoCallback_ind_t::pWCDMASigInfo

8.788 unpack_nas_SLQSNASSwiGetChannelLock_t Struct Reference

Data Fields

- nas_wcdmaUARFCN ∗ pWcdmaUARFCN
- nas_lteEARFCN ∗ pLteEARFCN
- nas_ltePCI ∗ pLtePCI
- swi_uint256_t ParamPresenceMask

8.788.1 Detailed Description

Structure for Get Channel Lock unpack.

Parameters

pWcdmaUARFCN	[Optional] • See nas_wcdmaUARFCN for more information • Bit to check in ParamPresenceMask - **16**
pLteEARFCN	[Optional] • See nas_lteEARFCN for more information • Bit to check in ParamPresenceMask - **17**
pLtePCI	[Optional] • See nas_ltePCI for more information • Bit to check in ParamPresenceMask - **18**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.788.2 Field Documentation

8.788.2.1 swi_uint256_t unpack_nas_SLQSNASSwiGetChannelLock_t::ParamPresenceMask

8.788.2.2 nas_lteEARFCN∗ unpack_nas_SLQSNASSwiGetChannelLock_t::pLteEARFCN

8.788.2.3 nas_ltePCI∗ unpack_nas_SLQSNASSwiGetChannelLock_t::pLtePCI

8.788.2.4 nas_wcdmaUARFCN∗ unpack_nas_SLQSNASSwiGetChannelLock_t::pWcdmaUARFCN

8.789 unpack_nas_SLQSNasSwiModemStatus_t Struct Reference

Data Fields

- nas_CommInfo commonInfo
- nas_LTEInfo ∗ pLTEInfo
- swi_uint256_t ParamPresenceMask

8.789.1 Detailed Description

Structure for storing the SLQS Nas Swi Modem Status response parameters.

Parameters

commonInfo	(mandatory) • See nas_CommInfo for more information • Bit to check in ParamPresenceMask - **1**
pLTEInfo	(optional) • See nas_LTEInfo for more information • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.789.2 Field Documentation

8.789.2.1 nas_CommInfo unpack_nas_SLQSNasSwiModemStatus_t::commonInfo

8.789.2.2 swi_uint256_t unpack_nas_SLQSNasSwiModemStatus_t::ParamPresenceMask

8.789.2.3 nas_LTEInfo* unpack_nas_SLQSNasSwiModemStatus_t::pLTEInfo

8.790 unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t Struct Reference

Data Fields

- NASQmiCbkNasSwiOTAMessageInd Info
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.790.1 Detailed Description

This structure contains unpack OTA message indication parameters.

Parameters

Info	• Structure used to store all QMI Notification Info. – See NASQmiCbkNasSwiOTAMessageInd for more details
Tlvresult	• unpack result • Bit to check in ParamPresenceMask - **2**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.790.2 Field Documentation

8.790.2.1 NASQmiCbkNasSwiOTAMessageInd unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t::Info

8.790.2.2 swi_uint256_t unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t::ParamPresenceMask

8.790.2.3 uint16_t unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t::Tlvresult

8.791 unpack_nas_SLQSNasTimerCallback_ind_t Struct Reference

Data Fields

- char t3396_apn [101]
- uint8_t t3396_plmn_id [3]
- uint32_t t3396_val
- swi_uint256_t ParamPresenceMask

8.791.1 Detailed Description

Structure for Network Timer indication parameters.

Parameters

t3396_apn	• apn • Bit to check in ParamPresenceMask - **16**
t3396_plmn_id	• plmn id • Bit to check in ParamPresenceMask - **16**
t3396_val	• timer value • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.791.2 Field Documentation

8.791.2.1 swi_uint256_t unpack_nas_SLQSNasTimerCallback_ind_t::ParamPresenceMask

8.791.2.2 char unpack_nas_SLQSNasTimerCallback_ind_t::t3396_apn[101]

8.791.2.3 uint8_t unpack_nas_SLQSNasTimerCallback_ind_t::t3396_plmn_id[3]

8.791.2.4 uint32_t unpack_nas_SLQSNasTimerCallback_ind_t::t3396_val

8.792 unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t Struct Reference

Data Fields

- NASQmiCbkNasSystemSelPrefInd Info
- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.792.1 Detailed Description

This structure contains unpack set system selection preference callback indication parameters.

Parameters

Info	• Structure used to store all QMI Notification Info. – See NASQmiCbkNasSystemSelPrefInd for more details
TlvResult	• unpack result • Bit to check in ParamPresenceMask - **2**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.792.2 Field Documentation

8.792.2.1 NASQmiCbkNasSystemSelPrefInd unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t::Info

8.792.2.2 swi_uint256_t unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t::ParamPresenceMask

8.792.2.3 uint16_t unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t::TlvResult

8.793 unpack_nas_SLQSSwiGetHDRPersonality_t Struct Reference

Data Fields

- uint16_t * pCurrentPersonality
- uint8_t * pPersonalityListLength
- nas_protocolSubtypeElement * pProtocolSubtypeElement
- swi_uint256_t ParamPresenceMask

8.793.1 Detailed Description

Structure for HDRPersonality unpack.

Parameters

pCurrent-Personality[Out]	• Current active personality index. • Bit to check in ParamPresenceMask - **16**

pPersonalityList-Length[In/Out]	• Number of Personality Protocol Subtype contains in this response. • maximum input value is 3 • Bit to check in ParamPresenceMask - **17**
pProtocol-Subtype-Element[Out]	• See nas_protocolSubtypeElement for more information. • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.793.2 Field Documentation

8.793.2.1 swi_uint256_t unpack_nas_SLQSSwiGetHDRPersonality_t::ParamPresenceMask

8.793.2.2 uint16_t* unpack_nas_SLQSSwiGetHDRPersonality_t::pCurrentPersonality

8.793.2.3 uint8_t* unpack_nas_SLQSSwiGetHDRPersonality_t::pPersonalityListLength

8.793.2.4 nas_protocolSubtypeElement* unpack_nas_SLQSSwiGetHDRPersonality_t::pProtocolSubtypeElement

8.794 unpack_nas_SLQSSwiGetHDRProtSubtype_t Struct Reference

Data Fields

- uint16_t * pCurrentPrsnlty
- uint8_t * pPersonalityListLength
- nas_protocolSubtypeElement * pProtoSubTypElmnt
- uint64_t * pAppSubType
- swi_uint256_t ParamPresenceMask

8.794.1 Detailed Description

Structure for HDRProtSubtype unpack.

Parameters

pCurrent-Personality	• Current active personality index. • Bit to check in ParamPresenceMask - **16**
pPersonalityList-Length	• Number of Personality Protocol Subtype contains in this response. • maximum input value is 4 • Bit to check in ParamPresenceMask - **17**
pProtocol-SubtypeElement	• See nas_protocolSubtypeElement for more information. • Bit to check in ParamPresenceMask - **17**

pAppSubType	• Stream application subtype • Application subtype for each stream • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.794.2 Field Documentation

8.794.2.1 uint64_t* unpack_nas_SLQSSwiGetHDRProtSubtype_t::pAppSubType

8.794.2.2 swi_uint256_t unpack_nas_SLQSSwiGetHDRProtSubtype_t::ParamPresenceMask

8.794.2.3 uint16_t* unpack_nas_SLQSSwiGetHDRProtSubtype_t::pCurrentPrsnlty

8.794.2.4 uint8_t* unpack_nas_SLQSSwiGetHDRProtSubtype_t::pPersonalityListLength

8.794.2.5 nas_protocolSubtypeElement* unpack_nas_SLQSSwiGetHDRProtSubtype_t::pProtoSubTypElmnt

8.795 unpack_nas_SLQSSwiGetHRPDStats_t Struct Reference

Data Fields

- nas_DRCParams * pDRCParams
- uint8_t * pUATI
- nas_PilotSetData * pPilotSetData
- swi_uint256_t ParamPresenceMask

8.795.1 Detailed Description

Structure for HRPD Stats unpack.

Parameters

pDRCParams	• See nas_DRCParams for more information. • Bit to check in ParamPresenceMask - **16**
pUATI	• A 128-bit address that includes the access terminal identifier and subnet ID • Size must be 16 bytes • Bit to check in ParamPresenceMask - **17**
pPilotSetData	• See nas_PilotSetData for more information. • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.795.2 Field Documentation

8.795.2.1 swi_uint256_t unpack_nas_SLQSSwiGetHRPDStats_t::ParamPresenceMask

8.795.2.2 nas_DRCParams* unpack_nas_SLQSSwiGetHRPDStats_t::pDRCParams

8.795.2.3 nas_PilotSetData* unpack_nas_SLQSSwiGetHRPDStats_t::pPilotSetData

8.795.2.4 uint8_t* unpack_nas_SLQSSwiGetHRPDStats_t::pUATI

8.796 unpack_nas_SLQSSwiGetLteCQI_t Struct Reference

Data Fields

- uint8_t ValidityCW0
- uint8_t CQIValueCW0
- uint8_t ValidityCW1
- uint8_t CQIValueCW1
- swi_uint256_t ParamPresenceMask

8.796.1 Detailed Description

This structure contains paramaters unpack fetch CQI parameters for LTE data session.

Parameters

ValidityCW0[OUT]	• Values – 0- Invalid. – 1- Valid. • Bit to check in ParamPresenceMask - **1**
CQIValueCW0[OUT]	• Values – Range 0∼15 • Bit to check in ParamPresenceMask - **1**
ValidityCW1[OUT]	• Values – 0- Invalid. – 1- Valid. • Bit to check in ParamPresenceMask - **1**
CQIValueCW1[OUT]	• Values – Range 0∼15 • Bit to check in ParamPresenceMask - **1**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.796.2 Field Documentation

8.796.2.1 uint8_t unpack_nas_SLQSSwiGetLteCQI_t::CQIValueCW0

8.796.2.2 uint8_t unpack_nas_SLQSSwiGetLteCQI_t::CQIValueCW1

8.796.2.3 swi_uint256_t unpack_nas_SLQSSwiGetLteCQI_t::ParamPresenceMask

8.796.2.4 uint8_t unpack_nas_SLQSSwiGetLteCQI_t::ValidityCW0

8.796.2.5 uint8_t unpack_nas_SLQSSwiGetLteCQI_t::ValidityCW1

8.797 unpack_nas_SLQSSwiGetLteSccRxInfo_t Struct Reference

Data Fields

- nas_SccRxInfo * pSccRxInfo
- swi_uint256_t ParamPresenceMask

8.797.1 Detailed Description

This structure contains unpack get LTE Secondary carrier Rx signal level information parameters.

Parameters

pSccRxInfo	Secondary carrier Rx signal level info • See nas_SccRxInfo – Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.797.2 Field Documentation

8.797.2.1 swi_uint256_t unpack_nas_SLQSSwiGetLteSccRxInfo_t::ParamPresenceMask

8.797.2.2 nas_SccRxInfo* unpack_nas_SLQSSwiGetLteSccRxInfo_t::pSccRxInfo

8.798 unpack_nas_SLQSSwiHDRPersonalityCallback_Ind_t Struct Reference

Data Fields

- nas_HDRPersonality_Ind_Data * pHDRPersInd
- swi_uint256_t ParamPresenceMask

8.798.1 Detailed Description

Structure for HDR Personality indication unpack.

Parameters

pHDRPersInd	• See nas_HDRPersonality_Ind_Data for more information.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.798.2 Field Documentation

8.798.2.1 swi_uint256_t unpack_nas_SLQSSwiHDRPersonalityCallback_Ind_t::ParamPresenceMask

8.798.2.2 nas_HDRPersonality_Ind_Data* unpack_nas_SLQSSwiHDRPersonalityCallback_Ind_t::pHDRPersInd

8.799 unpack_nas_SLQSSwiNetworkDebug_t Struct Reference

Data Fields

- uint8_t * pObjectVer
- nas_NetworkStat1x * pNetworkStat1x
- nas_NetworkStatEVDO * pNetworkStatEVDO
- nas_DeviceConfigDetail * pDeviceConfigDetail
- nas_DataStatusDetail * pDataStatusDetail
- swi_uint256_t ParamPresenceMask

8.799.1 Detailed Description

Structure for SwiNetworkDebug unpack.

Parameters

pObjectVer	• Object's version number for the host to handle – 0xFF - NA – Others - shows in decimal • Bit to check in ParamPresenceMask - **16**
pNetworkStat1x	• See nas_NetworkStat1x for more information • Bit to check in ParamPresenceMask - **17**
pNetworkStatE-VDO	• See nas_NetworkStatEVDO for more information. • Bit to check in ParamPresenceMask - **18**
pDeviceConfig-Detail	• See nas_DeviceConfigDetail for more information. • Bit to check in ParamPresenceMask - **19**
pDataStatus-Detail	• See nas_DataStatusDetail for more information. • Bit to check in ParamPresenceMask - **20**

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.799.2 Field Documentation

8.799.2.1 swi_uint256_t unpack_nas_SLQSSwiNetworkDebug_t::ParamPresenceMask

8.799.2.2 nas_DataStatusDetail* unpack_nas_SLQSSwiNetworkDebug_t::pDataStatusDetail

8.799.2.3 nas_DeviceConfigDetail* unpack_nas_SLQSSwiNetworkDebug_t::pDeviceConfigDetail

8.799.2.4 nas_NetworkStat1x* unpack_nas_SLQSSwiNetworkDebug_t::pNetworkStat1x

8.799.2.5 nas_NetworkStatEVDO* unpack_nas_SLQSSwiNetworkDebug_t::pNetworkStatEVDO

8.799.2.6 uint8_t* unpack_nas_SLQSSwiNetworkDebug_t::pObjectVer

8.800 unpack_nas_SLQSSwiRandIndicatorCallback_Ind_t Struct Reference

Data Fields

- nas_RankIndicatorTlv rankIndicatorTlv
- swi_uint256_t ParamPresenceMask

8.800.1 Detailed Description

Structure for Rank Indicator indication unpack.

Parameters

rankIndicatorTlv	• See nas_RankIndicatorTlv for more information. • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.800.2 Field Documentation

8.800.2.1 swi_uint256_t unpack_nas_SLQSSwiRandIndicatorCallback_Ind_t::ParamPresenceMask

8.800.2.2 nas_RankIndicatorTlv unpack_nas_SLQSSwiRandIndicatorCallback_Ind_t::rankIndicatorTlv

8.801 unpack_nas_SLQSSysInfoCallback_ind_t Struct Reference

Data Fields

- nas_SrvStatusInfo * pCDMASrvStatusInfo
- nas_SrvStatusInfo * pHDRSrvStatusInfo
- nas_GSMSrvStatusInfo * pGSMSrvStatusInfo

- nas_GSMSrvStatusInfo * pWCDMASrvStatusInfo
- nas_GSMSrvStatusInfo * pLTESrvStatusInfo
- nas_CDMASysInfo * pCDMASysInfo
- nas_HDRSysInfo * pHDRSysInfo
- nas_GSMSysInfo * pGSMSysInfo
- nas_WCDMASysInfo * pWCDMASysInfo
- nas_LTESysInfo * pLTESysInfo
- nas_AddCDMASysInfo * pAddCDMASysInfo
- uint16_t * pAddHDRSysInfo
- nas_AddSysInfo * pAddGSMSysInfo
- nas_AddSysInfo * pAddWCDMASysInfo
- uint16_t * pAddLTESysInfo
- nas_CallBarringSysInfo * pGSMCallBarringSysInfo
- nas_CallBarringSysInfo * pWCDMACallBarringSysInfo
- uint8_t * pLTEVoiceSupportSysInfo
- uint8_t * pGSMCipherDomainSysInfo
- uint8_t * pWCDMACipherDomainSysInfo
- uint8_t * pSysInfoNoChange
- swi_uint256_t ParamPresenceMask

8.801.1 Detailed Description

This structure contains unpack system information callback indication parameters.

Parameters

pCDMASrvStatusInfo	• See nas_SrvStatusInfo for more information. • Bit to check in ParamPresenceMask - **16**
pHDRSrvStatusInfo	• See nas_SrvStatusInfo for more information. • Bit to check in ParamPresenceMask - **17**
pGSMSrvStatusInfo	• See nas_GSMSrvStatusInfo for more information. • Bit to check in ParamPresenceMask - **18**
pWCDMASrvStatusInfo	• See nas_GSMSrvStatusInfo for more information. • Bit to check in ParamPresenceMask - **19**
pLTESrvStatusInfo	• See nas_GSMSrvStatusInfo for more information. • Bit to check in ParamPresenceMask - **20**
pCDMASysInfo	• See nas_CDMASysInfo for more information. • Bit to check in ParamPresenceMask - **21**
pHDRSysInfo	• See nas_HDRSysInfo for more information. • Bit to check in ParamPresenceMask - **22**

pGSMSysInfo	• See nas_GSMSysInfo for more information. • Bit to check in ParamPresenceMask - **23**
pWCDMASysInfo	• See nas_WCDMASysInfo for more information. • Bit to check in ParamPresenceMask - **24**
pLTESysInfo	• See nas_LTESysInfo for more information. • Bit to check in ParamPresenceMask - **25**
pAddCDMASysInfo	• See nas_AddCDMASysInfo for more information. • Bit to check in ParamPresenceMask - **26**
pAddHDRSysInfo	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used. • Bit to check in ParamPresenceMask - **27**
pAddGSMSysInfo	• See nas_AddSysInfo for more information. • Bit to check in ParamPresenceMask - **28**
pAddWCDMASysInfo	• See nas_AddSysInfo for more information. • Bit to check in ParamPresenceMask - **29**
pAddLTESysInfo	• System table index referencing the beginning of the geo in which the current serving system is present. • When the system index is not known, 0xFFFF is used. • Bit to check in ParamPresenceMask - **30**
pGSMCallBarringSysInfo	• See nas_CallBarringSysInfo for more information. • Bit to check in ParamPresenceMask - **31**
pWCDMACallBarringSysInfo	• See nas_CallBarringSysInfo for more information. • Bit to check in ParamPresenceMask - **32**
pLTEVoiceSupportSysInfo	• Indicates voice support status on LTE. – 0x00 - Voice is not supported – 0x01 - Voice is supported • Bit to check in ParamPresenceMask - **33**

pGSMCipher-DomainSysInfo	• Ciphering on the service domain. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched • Bit to check in ParamPresenceMask - **34**
pWCDMA-CipherDomain-SysInfo	• Ciphering on the service domain. – 0x00 - No service – 0x01 - Circuit-switched only – 0x02 - Packet-switched only – 0x03 - Circuit-switched and packet-switched • Bit to check in ParamPresenceMask - **35**
pSysInfoNo-Change	• System Info No Change. • Flag used to notify clients that a request to select a network ended with no change in the PLMN. – 0x01 - No change in system information • Bit to check in ParamPresenceMask - **36**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.801.2 Field Documentation

8.801.2.1 nas_AddCDMASysInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pAddCDMASysInfo

8.801.2.2 nas_AddSysInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pAddGSMSysInfo

8.801.2.3 uint16_t∗ unpack_nas_SLQSSysInfoCallback_ind_t::pAddHDRSysInfo

8.801.2.4 uint16_t∗ unpack_nas_SLQSSysInfoCallback_ind_t::pAddLTESysInfo

8.801.2.5 nas_AddSysInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pAddWCDMASysInfo

8.801.2.6 swi_uint256_t unpack_nas_SLQSSysInfoCallback_ind_t::ParamPresenceMask

8.801.2.7 nas_SrvStatusInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pCDMASrvStatusInfo

8.801.2.8 nas_CDMASysInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pCDMASysInfo

8.801.2.9 nas_CallBarringSysInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pGSMCallBarringSysInfo

8.801.2.10 uint8_t∗ unpack_nas_SLQSSysInfoCallback_ind_t::pGSMCipherDomainSysInfo

8.801.2.11 nas_GSMSrvStatusInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pGSMSrvStatusInfo

8.801.2.12 nas_GSMSysInfo∗ unpack_nas_SLQSSysInfoCallback_ind_t::pGSMSysInfo

8.801.2.13 **nas_SrvStatusInfo**∗ unpack_nas_SLQSSysInfoCallback_ind_t::pHDRSrvStatusInfo

8.801.2.14 **nas_HDRSysInfo**∗ unpack_nas_SLQSSysInfoCallback_ind_t::pHDRSysInfo

8.801.2.15 **nas_GSMSrvStatusInfo**∗ unpack_nas_SLQSSysInfoCallback_ind_t::pLTESrvStatusInfo

8.801.2.16 **nas_LTESysInfo**∗ unpack_nas_SLQSSysInfoCallback_ind_t::pLTESysInfo

8.801.2.17 **uint8_t**∗ unpack_nas_SLQSSysInfoCallback_ind_t::pLTEVoiceSupportSysInfo

8.801.2.18 **uint8_t**∗ unpack_nas_SLQSSysInfoCallback_ind_t::pSysInfoNoChange

8.801.2.19 **nas_CallBarringSysInfo**∗ unpack_nas_SLQSSysInfoCallback_ind_t::pWCDMACallBarringSysInfo

8.801.2.20 **uint8_t**∗ unpack_nas_SLQSSysInfoCallback_ind_t::pWCDMACipherDomainSysInfo

8.801.2.21 **nas_GSMSrvStatusInfo**∗ unpack_nas_SLQSSysInfoCallback_ind_t::pWCDMASrvStatusInfo

8.801.2.22 **nas_WCDMASysInfo**∗ unpack_nas_SLQSSysInfoCallback_ind_t::pWCDMASysInfo

8.802 unpack_omaDmConfigTlv_t Struct Reference

Data Fields

- uint8_t state
- uint8_t userInputReq
- uint16_t userInputTimeout
- uint16_t alertmsglength
- uint8_t alertmsg [256]

8.802.1 Detailed Description

This structure will hold the SwiOmaDmConfig session parameters information.

Parameters

state	• 0x01 - OMA-DM Read Request • 0x02 - OMA-DM Change Request • 0x03 - OMA-DM Config Complete
userInputReq	- Bit mask of available user inputs • 0x00 - No user input required.Informational indication • 0x01 - Accept • 0x02 - Reject
userInput-Timeout	• Timeout for user input in minutes. A value of 0 means no time-out
alertmsglength	• Length of Alert message string in bytes
alertmsg	• Alert message in UCS2 (Max 256 characters)

8.802.2 Field Documentation

8.802.2.1 uint8_t unpack_omaDmConfigTlv_t::alertmsg[256]

8.802.2.2 uint16_t unpack_omaDmConfigTlv_t::alertmsglength

8.802.2.3 uint8_t unpack_omaDmConfigTlv_t::state

8.802.2.4 uint8_t unpack_omaDmConfigTlv_t::userInputReq

8.802.2.5 uint16_t unpack_omaDmConfigTlv_t::userInputTimeout

8.803 unpack_omaDmFotaTlv_t Struct Reference

Data Fields

- uint8_t state
- uint8_t userInputReq
- uint16_t userInputTimeout
- uint32_t fwdloadsize
- uint32_t fwloadComplete
- uint16_t updateCompleteStatus
- uint8_t severity
- uint16_t versionlength
- uint8_t version [256]
- uint16_t namelength
- uint8_t package_name [256]
- uint16_t descriptionlength
- uint8_t description [256]
- uint8_t sessionType

8.803.1 Detailed Description

This structure will hold the SwiOmaDmFota session parameters information.

Parameters

state	• 0x01 - No Firmware available • 0x02 - Query Firmware Download • 0x03 - Firmware Downloading • 0x04 - Firmware downloaded • 0x05 - Query Firmware Update • 0x06 - Firmware updating • 0x07 - Firmware updated
userInputReq	- Bit mask of available user inputs • 0x00 - No user input required.Informational indication • 0x01 - Accept • 0x02 - Reject
userInput-Timeout	• Timeout for user input in minutes. A value of 0 means no time-out

fwdloadsize	• The size (in bytes) of the firmware update package
fwloadComplete	• The number of bytes downloaded. Need to determine how often to send this message for progress bar notification. Every 500ms or 5% increment.
update-CompleteStatus	• This field should be looked at only when the OMADM session is complete. • See qaGobiApiTableSwiOMADMUpdateCompleteStatus.h for update complete status.
severity	• 0x01 - Mandatory • 0x02 - Optional
versionlength	• Length of FW Version string in bytes
version	• FW Version string in ASCII (Max 256 characters)
namelength	• Length Package Name string in bytes
package_name	• Package Name in UCS2 (Max 256 characters)
descriptionlength	• Length of description in bytes
description	• Description of Update Package in USC2 (Max 256 characters)
sessionType	• 0x00 - Client initiated • 0x01 - Network initiated

8.803.2 Field Documentation

8.803.2.1 uint8_t unpack_omaDmFotaTlv_t::description[256]

8.803.2.2 uint16_t unpack_omaDmFotaTlv_t::descriptionlength

8.803.2.3 uint32_t unpack_omaDmFotaTlv_t::fwdloadsize

8.803.2.4 uint32_t unpack_omaDmFotaTlv_t::fwloadComplete

8.803.2.5 uint16_t unpack_omaDmFotaTlv_t::namelength

8.803.2.6 uint8_t unpack_omaDmFotaTlv_t::package_name[256]

8.803.2.7 uint8_t unpack_omaDmFotaTlv_t::sessionType

8.803.2.8 uint8_t unpack_omaDmFotaTlv_t::severity

8.803.2.9 uint8_t unpack_omaDmFotaTlv_t::state

8.803.2.10 uint16_t unpack_omaDmFotaTlv_t::updateCompleteStatus

8.803.2.11 uint8_t unpack_omaDmFotaTlv_t::userInputReq

8.803.2.12 uint16_t unpack_omaDmFotaTlv_t::userInputTimeout

8.803.2.13 uint8_t unpack_omaDmFotaTlv_t::version[256]

8.803.2.14 uint16_t unpack_omaDmFotaTlv_t::versionlength

8.804 unpack_omaDmNotificationsTlv_t Struct Reference

Data Fields

- uint8_t notification
- uint16_t sessionStatus

8.804.1 Detailed Description

This structure will hold the SwiOmaDmConfig session notification parameters information.

Parameters

notification	• 0x01 - GPS settings change • 0x02 - Device reset • 0x03 - Device factory reset • 0x04 - CI-DC Session start • 0x05 - CI-DC Session end • 0x06 - CI-PRL Session start • 0x07 - CI-PRL Session end • 0x08 - CI-FUMO Session start • 0x09 - CI-FUMO session end • 0x0A - HFA-DC Session start • 0x0B - HFA-DC Session end • 0x0C - HFA-PRL Session start • 0x0D - HFA-PRL Session end • 0x0E - HFA-FUMO Session start • 0x0F - HFA-FUMO session end • 0x10 - NI Session start • 0x11 - NI session end
sessionStatus	• This field will set to the session status for notifications that occur at the end of a session, zero for all other notifications • See qaGobiApiTableSwiOMADMSessionStatus.h for session completion code.

8.804.2 Field Documentation

8.804.2.1 uint8_t unpack_omaDmNotificationsTlv_t::notification

8.804.2.2 uint16_t unpack_omaDmNotificationsTlv_t::sessionStatus

8.805 unpack_pds_GetPDSDefaults_t Struct Reference

Data Fields

- uint32_t * pOperation
- uint8_t * pTimeout
- uint32_t * pInterval
- uint32_t * pAccuracy
- swi_uint256_t ParamPresenceMask

8.805.1 Detailed Description

Structure contain session configuration parameters.

Parameters

pOperation	• Current session operating mode – 0 - Standalone – 1 - MS based – 2 - MS assisted • Bit to check in ParamPresenceMask - **1**
pTimeout	• Maximum amount of time (seconds) to work on each fix, maximum is 255 • Bit to check in ParamPresenceMask - **1**
pInterval	• Interval (seconds) between fix requests • Bit to check in ParamPresenceMask - **1**
pAccuracy	• Preferred accuracy threshold (meters) • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.805.2 Field Documentation

8.805.2.1 uint32_t* unpack_pds_GetPDSDefaults_t::pAccuracy

8.805.2.2 swi_uint256_t unpack_pds_GetPDSDefaults_t::ParamPresenceMask

8.805.2.3 uint32_t* unpack_pds_GetPDSDefaults_t::pInterval

8.805.2.4 uint32_t* unpack_pds_GetPDSDefaults_t::pOperation

8.805.2.5 uint8_t* unpack_pds_GetPDSDefaults_t::pTimeout

8.806 unpack_pds_GetPDSState_t Struct Reference

Data Fields

- uint32_t * pEnabledStatus
- uint32_t * pTrackingStatus
- swi_uint256_t ParamPresenceMask

8.806.1 Detailed Description

Structure contain parameters of current PDS state.

Parameters

pEnabledStatus	• Current PDS state
	  – 0 - disable
	  – 1 - enable
	• Bit to check in ParamPresenceMask - **1**

pTrackingStatus	• Current PDS tracking session state
	• Values:
	  – 0x00 - Unknown
	  – 0x01 - Inactive
	  – 0x02 - Active
	• Bit to check in ParamPresenceMask - **1**

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.806.2 Field Documentation

8.806.2.1 swi_uint256_t unpack_pds_GetPDSState_t::ParamPresenceMask

8.806.2.2 uint32_t* unpack_pds_GetPDSState_t::pEnabledStatus

8.806.2.3 uint32_t* unpack_pds_GetPDSState_t::pTrackingStatus

8.807 unpack_pds_GetPortAutomaticTracking_t Struct Reference

Data Fields

- uint32_t * pbAuto
- swi_uint256_t ParamPresenceMask

8.807.1 Detailed Description

Structure contain the parameter of automatic tracking configuration for the NMEA COM port.

Parameters

pbAuto	• Automatic tracking enabled for NMEA COM port – 0x00 - Disabled – 0x01 - Enabled – Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.807.2 Field Documentation

8.807.2.1 swi_uint256_t unpack_pds_GetPortAutomaticTracking_t::ParamPresenceMask

8.807.2.2 uint32_t* unpack_pds_GetPortAutomaticTracking_t::pbAuto

8.808 unpack_pds_GetServiceAutomaticTracking_t Struct Reference

Data Fields

- uint32_t * pbAuto
- swi_uint256_t ParamPresenceMask

8.808.1 Detailed Description

Structure contain the parameter for automatic tracking state.

Parameters

pbAuto	• Automatic tracking session started for service – 0x00 - Disabled – 0x01 - Enabled • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.808.2 Field Documentation

8.808.2.1 swi_uint256_t unpack_pds_GetServiceAutomaticTracking_t::ParamPresenceMask

8.808.2.2 uint32_t* unpack_pds_GetServiceAutomaticTracking_t::pbAuto

8.809 unpack_pds_GetXTRAAutomaticDownload_t Struct Reference

Data Fields

- uint32_t * pbEnabled
- uint16_t * pInterval
- swi_uint256_t ParamPresenceMask

8.809.1 Detailed Description

Structure contain the parameter of automatic tracking configuration for the NMEA COM port.

Parameters

pbEnabled	• Automatic XTRA download status – 0 - Disabled – 1 - Enabled • Bit to check in ParamPresenceMask - **16**
pInterval	• Interval (hours) between XTRA downloads • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.809.2 Field Documentation

8.809.2.1 swi_uint256_t unpack_pds_GetXTRAAutomaticDownload_t::ParamPresenceMask

8.809.2.2 uint32_t* unpack_pds_GetXTRAAutomaticDownload_t::pbEnabled

8.809.2.3 uint16_t* unpack_pds_GetXTRAAutomaticDownload_t::pInterval

8.810 unpack_pds_GetXTRANetwork_t Struct Reference

Data Fields

- uint32_t * pPreference
- swi_uint256_t ParamPresenceMask

8.810.1 Detailed Description

Structure contain the parameter for XTRA WWAN network preference

Parameters

pPreference	• XTRA WWAN network preference – 0x00 - None (any available network) – 0x01 - Home-only, only when on home systems – 0x02 - Roam-only, only when on non-home systems • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.810.2 Field Documentation

8.810.2.1 swi_uint256_t unpack_pds_GetXTRANetwork_t::ParamPresenceMask

8.810.2.2 uint32_t* unpack_pds_GetXTRANetwork_t::pPreference

8.811 unpack_pds_GetXTRAValidity_t Struct Reference

Data Fields

- uint16_t * pGPSWeek
- uint16_t * pGPSWeekOffset
- uint16_t * pDuration
- swi_uint256_t ParamPresenceMask

8.811.1 Detailed Description

Structure contain the parameter for XTRA database validity period

Parameters

pGPSWeek	• Starting GPS week of validity period • Bit to check in ParamPresenceMask - **19**
pGPSWeek-Offset	• Starting GPS week offset (minutes) of validity period • Bit to check in ParamPresenceMask - **19**
pDuration	• Length of validity period (hours) • NULL pointer - Invalid data. • Bit to check in ParamPresenceMask - **19**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.811.2 Field Documentation

8.811.2.1 swi_uint256_t unpack_pds_GetXTRAValidity_t::ParamPresenceMask

8.811.2.2 uint16_t* unpack_pds_GetXTRAValidity_t::pDuration

8.811.2.3 uint16_t* unpack_pds_GetXTRAValidity_t::pGPSWeek

8.811.2.4 uint16_t* unpack_pds_GetXTRAValidity_t::pGPSWeekOffset

8.812 unpack_pds_SetEventReport_Ind_t Struct Reference

Data Fields

- uint8_t has_PositionDataNMEA
- char PositionDataNMEA [200]
- uint8_t has_dLongitude
- double dLongitude
- uint8_t has_dLatitude
- double dLatitude
- uint8_t has_SessionStatus
- uint8_t SessionStatus
- uint8_t has_posSrc
- uint32_t posSrc
- swi_uint256_t ParamPresenceMask

8.812.1 Detailed Description

Structure contain the parameter for the Set event report Indication. Please check has_<Param_Name> field for presence of optional parameters

Parameters

PositionDataNMEA	• Position Data NMEA. • String containing the position data in NMEA sentence format (maximum 200 bytes). • Bit to check in ParamPresenceMask - **16**
dLongitude	• Longitude position referenced to the WGS-84 reference ellipsoid, counting positive angles east of the Greenwich Meridian and negative angles west of the Greenwich Meridian. • Units - Decimal degrees • Range - -180 to +180 • Note - Value is in double float format • Bit to check in ParamPresenceMask - **19**
dLatitude	• Latitude position referenced to the WGS-84 reference ellipsoid, counting positive angles north of the equator and negative angles south of the equator. • Units: Decimal degrees • Range: -90 to +90 • Note - Value is in double float format • Bit to check in ParamPresenceMask - **19**

session_status	• Position Session Status • Status of current session. • Values – 0x00 - Success – 0x01 - In progress – 0x02 - General failure – 0x03 - Timeout – 0x04 - User ended the session – 0x05 - Bad parameter – 0x06 - Phone is offline – 0x07 - Engine is locked – 0x08 - E911 session in progress • Bit to check in ParamPresenceMask - **18** • Note - This TLV is always sent while a fix is being generated or if it halts due to an error. The Parsed Position Data TLV (0x13) is included if the session status is Success (0x00) or In Progress (0x01); otherwise this TLV is passed alone.
posSrc	• Position Source • This TLV is always sent with the Parsed Position Data TLV (0x13) when the latitude/longitude is marked as valid. Source of the position (bitmask). • Values – 0x00000001 - GPS – 0x00000002 – Cell ID – 0x00000004 – GLONASS – 0x00000008 – Network – 0x00000010 – External position injection • Bit to check in ParamPresenceMask - **28**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.812.2 Field Documentation

8.812.2.1 double unpack_pds_SetEventReport_Ind_t::dLatitude

8.812.2.2 double unpack_pds_SetEventReport_Ind_t::dLongitude

8.812.2.3 uint8_t unpack_pds_SetEventReport_Ind_t::has_dLatitude

8.812.2.4 uint8_t unpack_pds_SetEventReport_Ind_t::has_dLongitude

8.812.2.5 uint8_t unpack_pds_SetEventReport_Ind_t::has_PositionDataNMEA

8.812.2.6 uint8_t unpack_pds_SetEventReport_Ind_t::has_posSrc

8.812.2.7 uint8_t unpack_pds_SetEventReport_Ind_t::has_SessionStatus

8.812.2.8 swi_uint256_t unpack_pds_SetEventReport_Ind_t::ParamPresenceMask

8.812.2.9 char unpack_pds_SetEventReport_Ind_t::PositionDataNMEA[200]

8.812.2.10 uint32_t unpack_pds_SetEventReport_Ind_t::posSrc

8.812.2.11 uint8_t unpack_pds_SetEventReport_Ind_t::SessionStatus

8.813 unpack_pds_SetPdsState_Ind_t Struct Reference

Data Fields

- uint16_t TlvPresent
- uint32_t EnabledStatus
- uint32_t TrackingStatus
- swi_uint256_t ParamPresenceMask

8.813.1 Detailed Description

Structure contain the parameter for the Set PDS State Indication.

Parameters

EnabledStatus	• GPS service state. • Values – 0x00 - Disable – 0x01 - Enable • Bit to check in ParamPresenceMask - **1**
TrackingStatus	• Tracking session state. • Values – 0x00 - Unknown – 0x01 - Inactive – 0x02 - Active • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.813.2 Field Documentation

8.813.2.1 uint32_t unpack_pds_SetPdsState_Ind_t::EnabledStatus

8.813.2.2 swi_uint256_t unpack_pds_SetPdsState_Ind_t::ParamPresenceMask

8.813.2.3 uint16_t unpack_pds_SetPdsState_Ind_t::TlvPresent

8.813.2.4 uint32_t unpack_pds_SetPdsState_Ind_t::TrackingStatus

8.814 unpack_pds_SLQSGetAGPSConfig_t Struct Reference

Data Fields

- uint32_t * pServerAddress
- uint32_t * pServerPort
- uint8_t * pServerURL
- uint8_t * pServerURLLength
- swi_uint256_t ParamPresenceMask

8.814.1 Detailed Description

Structure contain the parameter for PDS AGPS (MS-based) configuration unpack.

Parameters

pServerAddress	• IPv4 address of AGPS server. "0" if not set • Bit to check in ParamPresenceMask - **16**
pServerPort	• Port number of AGPS server. "0" if not set • Bit to check in ParamPresenceMask - **16**
pServerURL	• URL of the AGPS server. "0" if not set • Bit to check in ParamPresenceMask - **17**
pServerURL-Length	• URL length of AGPS server. "0" if not set • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.814.2 Field Documentation

8.814.2.1 swi_uint256_t unpack_pds_SLQSGetAGPSConfig_t::ParamPresenceMask

8.814.2.2 uint32_t* unpack_pds_SLQSGetAGPSConfig_t::pServerAddress

8.814.2.3 uint32_t* unpack_pds_SLQSGetAGPSConfig_t::pServerPort

8.814.2.4 uint8_t* unpack_pds_SLQSGetAGPSConfig_t::pServerURL

8.814.2.5 uint8_t* unpack_pds_SLQSGetAGPSConfig_t::pServerURLLength

8.815 unpack_pds_SLQSGetGPSStateInfo_t Struct Reference

Data Fields

- uint8_t EngineState
- uint32_t ValidMask
- uint64_t Latitude
- uint64_t Longitude

- uint32_t HorizontalUncertainty
- uint32_t Altitude
- uint32_t VerticalUncertainty
- uint32_t TimeStmp_tow_ms
- uint16_t TimeStmp_gps_week
- uint32_t Time_uncert_ms
- uint8_t Iono_valid
- uint32_t gps_ephemeris_sv_msk
- uint32_t gps_almanac_sv_msk
- uint32_t gps_health_sv_msk
- uint32_t gps_visible_sv_msk
- uint32_t glo_ephemeris_sv_msk
- uint32_t glo_almanac_sv_msk
- uint32_t glo_health_sv_msk
- uint32_t glo_visible_sv_msk
- uint32_t sbas_ephemeris_sv_msk
- uint32_t sbas_almanac_sv_msk
- uint32_t sbas_health_sv_msk
- uint32_t sbas_visible_sv_msk
- uint16_t xtra_start_gps_week
- uint16_t xtra_start_gps_minutes
- uint16_t xtra_valid_duration_hours
- swi_uint256_t ParamPresenceMask

8.815.1 Detailed Description

Structure contain the parameter for GPS state Info.

Parameters

EngineState	• Values: – 0 - OFF – 1 - ON • This field is always valid • Bit to check in ParamPresenceMask - **16**
ValidMask	• Mask of valid state information data. • Values: – 0x00000001 - Position(latitude/longitude/horizontal uncertainty) – 0x00000002 - Altitude and vertical uncertainty – 0x00000004 - Time ms – 0x00000008 - Time week number – 0x00000010 - Time uncertainty – 0x00000020 - Iono validity – 0x00000040 - GPS ephemeris – 0x00000080 - GPS almanac – 0x00000100 - GPS health – 0x00000200 - GPS visible SVs – 0x00000400 - GLONASS ephemeris – 0x00000800 - GLONASS almanac – 0x00001000 - GLONASS health – 0x00002000 - GLONASS visible SVs – 0x00004000 - SBAS ephemeris – 0x00008000 - SBAS almanac – 0x00010000 - SBAS health – 0x00020000 - SBAS visible SVs – 0x00040000 - XTRA information • Bit to check in ParamPresenceMask - **16**
Latitude	• Latitude position referenced to the WGS-84 reference ellipsoid, counting positive angles north of the equator and negative angles south of the equator. • Units: Decimal degrees • Range: -90 to +90 degrees. • Value is in double float format (refer to IEEE Std 754-1985) • Bit to check in ParamPresenceMask - **16**
Longitude	• Longitude position referenced to the WGS-84 reference ellipsoid, counting positive angles east of the Greenwich Meridian and negative angles west of Greenwich meridian. • Units: Decimal degrees • Range: -180 to +180 degrees • Value is in double float format (refer to IEEE Std 754-1985) • Bit to check in ParamPresenceMask - **16**

Horizontal-Uncertainty	• Circular horizontal uncertainty (in meters). The uncertainty is provided at 63 percent confidence. • Value is in single float format (refer to IEEE Std 754-1985) • Bit to check in ParamPresenceMask - **16**
Altitude	• Height above the WGS-84 reference ellipsoid. Value conveys height (in meters) plus 500 m • Range -500 to 15883 • Value in single float format (refer to IEEE Std 754-1985) • Bit to check in ParamPresenceMask - **16**
Vertical-Uncertainty	• Vertical uncertainty (in meters). The uncertainty is provided at 68 percent confidence. • Value in single float format (refer to IEEE Std 754-1985) • Bit to check in ParamPresenceMask - **16**
TimeStmp_tow_ms	• Time stamp in GPS time of week(in milliseconds) • Bit to check in ParamPresenceMask - **16**
TimeStmp_gps_week	• GPS week number • Bit to check in ParamPresenceMask - **16**
Time_uncert_ms	• Time uncertainty (in milliseconds). The uncertainty is provided at 99 percent confidence. • Bit to check in ParamPresenceMask - **16**
Iono_valid	• Iono validity. • Values: – 0 - Invalid – 1 - Valid • Bit to check in ParamPresenceMask - **16**
gps_ephemeris_sv_msk	• GPS SV mask for ephemeris; if the bit is set, ephemeris for that SV is available. • Bit to check in ParamPresenceMask - **16**
gps_almanac_sv_msk	• GPS SV mask for almanac; if the bit is set, almanac for that SV is available. • Bit to check in ParamPresenceMask - **16**
gps_health_sv_msk	• GPS SV mask for health; if the bit is set, health for that SV is available. • Bit to check in ParamPresenceMask - **16**
gps_visible_sv_msk	• GPS SV mask for visible Svs; if the bit is set, the SV is available. • Bit to check in ParamPresenceMask - **16**

glo_ephemeris_sv_msk	• GLONASS SV mask for ephemeris; if the bit is set, ephemeris for that SV is available. • Bit to check in ParamPresenceMask - **16**
glo_almanac_sv_msk	• GLONASS SV mask for almanac; if the bit is set, almanac for that SV is available. • Bit to check in ParamPresenceMask - **16**
glo_health_sv_msk	• GLONASS SV mask for health; if the bit is set, health for that SV is available. • Bit to check in ParamPresenceMask - **16**
glo_visible_sv_msk	• GLONASS SV mask for visible SVs; if the bit is set, the SV is available. • Bit to check in ParamPresenceMask - **16**
sbas_ephemeris_sv_msk	• SBAS SV mask for ephemeris; if the bit is set, ephemeris for that SV is available. • Bit to check in ParamPresenceMask - **16**
sbas_almanac_sv_msk	• SBAS SV mask for almanac; if the bit is set, almanac for that SV is available. • Bit to check in ParamPresenceMask - **16**
sbas_health_sv_msk	• SBAS SV mask for health; if the bit is set, health for that SV is available. • Bit to check in ParamPresenceMask - **16**
sbas_visible_sv_msk	• SBAS SV mask for visible SVs; if the bit is set, the SV is available. • Bit to check in ParamPresenceMask - **16**
xtra_start_gps_week	• Current XTRA information is valid starting from this GPS week number • Bit to check in ParamPresenceMask - **16**
xtra_start_gps_minutes	• Current XTRA information is valid starting from the GPS minutes with the GPS week • Bit to check in ParamPresenceMask - **16**
xtra_valid_duration_hours	• XTRA information is valid for this many hours starting from the specified GPS week/minutes • Bit to check in ParamPresenceMask - **16**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.815.2 Field Documentation

8.815.2.1 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::Altitude

8.815.2.2 uint8_t unpack_pds_SLQSGetGPSStateInfo_t::EngineState

8.815.2.3 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::glo_almanac_sv_msk

8.815.2.4 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::glo_ephemeris_sv_msk

8.815.2.5 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::glo_health_sv_msk

8.815.2.6 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::glo_visible_sv_msk

8.815.2.7 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::gps_almanac_sv_msk

8.815.2.8 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::gps_ephemeris_sv_msk

8.815.2.9 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::gps_health_sv_msk

8.815.2.10 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::gps_visible_sv_msk

8.815.2.11 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::HorizontalUncertainty

8.815.2.12 uint8_t unpack_pds_SLQSGetGPSStateInfo_t::Iono_valid

8.815.2.13 uint64_t unpack_pds_SLQSGetGPSStateInfo_t::Latitude

8.815.2.14 uint64_t unpack_pds_SLQSGetGPSStateInfo_t::Longitude

8.815.2.15 swi_uint256_t unpack_pds_SLQSGetGPSStateInfo_t::ParamPresenceMask

8.815.2.16 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::sbas_almanac_sv_msk

8.815.2.17 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::sbas_ephemeris_sv_msk

8.815.2.18 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::sbas_health_sv_msk

8.815.2.19 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::sbas_visible_sv_msk

8.815.2.20 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::Time_uncert_ms

8.815.2.21 uint16_t unpack_pds_SLQSGetGPSStateInfo_t::TimeStmp_gps_week

8.815.2.22 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::TimeStmp_tow_ms

8.815.2.23 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::ValidMask

8.815.2.24 uint32_t unpack_pds_SLQSGetGPSStateInfo_t::VerticalUncertainty

8.815.2.25 uint16_t unpack_pds_SLQSGetGPSStateInfo_t::xtra_start_gps_minutes

8.815.2.26 uint16_t unpack_pds_SLQSGetGPSStateInfo_t::xtra_start_gps_week

8.815.2.27 uint16_t unpack_pds_SLQSGetGPSStateInfo_t::xtra_valid_duration_hours

8.816 unpack_qmi_t Struct Reference

Data Fields

- enum msgtype type
- uint16_t msgid
- uint16_t xid

8.816.1 Detailed Description

qmi response context

Parameters

out	*type*	message type
out	*msgid*	message id
out	*xid*	transaction id

8.816.2 Field Documentation

8.816.2.1 uint16_t unpack_qmi_t::msgid

8.816.2.2 enum msgtype unpack_qmi_t::type

8.816.2.3 uint16_t unpack_qmi_t::xid

8.817 unpack_qos_BindDataPort_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.817.1 Detailed Description

This structure contains unpack Qos BindDataPort.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.817.2 Field Documentation

8.817.2.1 swi_uint256_t unpack_qos_BindDataPort_t::ParamPresenceMask

8.818 unpack_qos_dataRate_t Struct Reference

Data Fields

- uint32_t dataRateMax
- uint32_t guaranteedRate

8.818.1 Detailed Description

This structure contains the IP flow data rate min max

Parameters

dataRateMax	Maximum required data rate (bits per second)
guaranteedRate	Minimum guaranteed data rate (bits per second)

8.818.2 Field Documentation

8.818.2.1 uint32_t unpack_qos_dataRate_t::dataRateMax

8.818.2.2 uint32_t unpack_qos_dataRate_t::guaranteedRate

8.819 unpack_qos_IPv4Addr_t Struct Reference

Data Fields

- uint32_t addr
- uint32_t subnetMask

8.819.1 Detailed Description

This structure contains the IPv4 filter address

Parameters

addr	IPv4 address
subnetMask	A packet matches if: • (addr and subnetMask) == (IP pkt addr & subnetMask) Callers to set up a filter with a range of source addresses, if needed; subnet mask of all 1s (255.255.255.255) specifies a single address value

8.819.2 Field Documentation

8.819.2.1 uint32_t unpack_qos_IPv4Addr_t::addr

8.819.2.2 uint32_t unpack_qos_IPv4Addr_t::subnetMask

8.820 unpack_qos_IPv6Addr_t Struct Reference

Data Fields

- uint8_t addr [16]
- uint8_t prefixLen

8.820.1 Detailed Description

This structure contains the IPv6 filter address

Parameters

addr	IPv6 address (in network byte order); this is a 16-byte byte array (in Big-endian format)
prefixLen	IPv6 filter prefix length; can take a value between 0 and 128 Note: A packet matches if the IPv6 source address bytes until the prefix lengths are equal. Therefore prefix length can be used to set a filter with a range of source addresses. A prefix length of 128 specifies a single address value.

8.820.2 Field Documentation

8.820.2.1 uint8_t unpack_qos_IPv6Addr_t::addr[16]

8.820.2.2 uint8_t unpack_qos_IPv6Addr_t::prefixLen

8.821 unpack_qos_IPv6TrafCls_t Struct Reference

Data Fields

- uint8_t val
- uint8_t mask

8.821.1 Detailed Description

This structure contains the IPv6 filter traffic class

Parameters

val	The traffic class value
mask	The packet matches the traffic class filter if: (IPv6_filter_traffic_class_val and IPv6_filter_traffic_class_mask) == (Traffic class value in the IP packet & IPv6_filter_traffic_class_mask) Example: • IPv6_filter_tc_val = 00101000 • IPv6_filter_tc_mask = 11111100 Filter will compare only the first 6 bits in IPv6_filter_traffic_class with the first 6 bits in the traffic class field of the IP packet; first 6 bits in the traffic class field of the IP packet must be 001010 to match filter; last 2 bits can be anything, since they are ignored by filtering

8.821.2 Field Documentation

8.821.2.1 uint8_t unpack_qos_IPv6TrafCls_t::mask

8.821.2.2 uint8_t unpack_qos_IPv6TrafCls_t::val

8.822 unpack_qos_pktErrRate_t Struct Reference

Data Fields

- uint16_t multiplier
- uint16_t exponent

8.822.1 Detailed Description

This structure contains the IP flow packet error rate

Parameters

multiplier	Factor m in calculating packet error rate: E = m∗10∗∗(-p)
exponent	Factor p in calculating packet error rate (see above)

8.822.2 Field Documentation

8.822.2.1 uint16_t unpack_qos_pktErrRate_t::exponent

8.822.2.2 uint16_t unpack_qos_pktErrRate_t::multiplier

8.823 unpack_qos_Port_t Struct Reference

Data Fields

- uint16_t port
- uint16_t range

8.823.1 Detailed Description

This structure contains the Port Filter

Parameters

port	port value of the filter
range	range specifies the number of ports to be included in the filter starting from port; filter will match if port in the IP packet lies between port and (port + range) Range value of 0 implies that only one value of the port is valid, as specified by the port

8.823.2 Field Documentation

8.823.2.1 uint16_t unpack_qos_Port_t::port

8.823.2.2 uint16_t unpack_qos_Port_t::range

8.824 unpack_qos_QosFlowInfo_t Struct Reference

Data Fields

- unpack_qos_QosFlowInfoState_t QFlowState
- uint8_t is_TxQFlowGranted_Available
- unpack_qos_swiQosFlow_t TxQFlowGranted
- uint8_t is_RxQFlowGranted_Available
- unpack_qos_swiQosFlow_t RxQFlowGranted
- uint8_t NumTxFilters
- unpack_qos_swiQosFilter_t TxQFilter [25]
- uint8_t NumRxFilters
- unpack_qos_swiQosFilter_t RxQFilter [25]
- uint8_t BearerID

8.824.1 Detailed Description

Structure with QoS flow details.

Please check is_<Param_Name>_Available field for presence of optional parameters

Parameters

QFlowState	• QoS flow state information, please check unpack_qos_QosFlowInfoState_t for more information
is_TxQFlowGranted_Available	• TRUE if optional TxQFlowGranted is available
TxQFlowGranted	• The Tx Qos flow granted, please check unpack_qos_swiQosFlow_t for more information
is_RxQFlowGranted_Available	• TRUE if optional RxQFlowGranted is available
RxQFlowGranted	• The Rx Qos flow granted, please check unpack_qos_swiQosFlow_t for more information
NumTxFilters	• Number of Tx filters available
TxQFilter	• The Tx Qos filter, please check unpack_qos_swiQosFilter_t for more information • See LITEQMI_MAX_QOS_FILTERS for more information
NumRxFilters	• Number of Tx filters available
RxQFilter	• The Rx Qos filter, please check unpack_qos_swiQosFilter_t for more information • See LITEQMI_MAX_QOS_FILTERS for more information
BearerID	• The bearer ID • Bearer ID or Radio Link Protocol (RLP) ID of the activated flow. • Valid Values - 0 to 16 • 0xFF - Invalid value.

8.824.2 Field Documentation

8.824.2.1 uint8_t unpack_qos_QosFlowInfo_t::BearerID

8.824.2.2 uint8_t unpack_qos_QosFlowInfo_t::is_RxQFlowGranted_Available

8.824.2.3 uint8_t unpack_qos_QosFlowInfo_t::is_TxQFlowGranted_Available

8.824.2.4 uint8_t unpack_qos_QosFlowInfo_t::NumRxFilters

8.824.2.5 uint8_t unpack_qos_QosFlowInfo_t::NumTxFilters

8.824.2.6 unpack_qos_QosFlowInfoState_t unpack_qos_QosFlowInfo_t::QFlowState

8.824.2.7 unpack_qos_swiQosFilter_t unpack_qos_QosFlowInfo_t::RxQFilter[25]

8.824.2.8 unpack_qos_swiQosFlow_t unpack_qos_QosFlowInfo_t::RxQFlowGranted

8.824.2.9 unpack_qos_swiQosFilter_t unpack_qos_QosFlowInfo_t::TxQFilter[25]

8.824.2.10 unpack_qos_swiQosFlow_t unpack_qos_QosFlowInfo_t::TxQFlowGranted

8.825 unpack_qos_QosFlowInfoState_t Struct Reference

Data Fields

- uint32_t id
- uint8_t isNewFlow
- uint8_t state

8.825.1 Detailed Description

This structure contains QoS flow state

Parameters

id	QoS identifier
isNewFlow	• 1 - Newly added flow • 0 - Existing flow
state	This indicates that the flow that was added/modified/deleted: • 0x01 - Flow activated • 0x02 - Flow modified • 0x03 - Flow deleted • 0x04 - Flow suspended • 0x05 - Flow enabled • 0x06 - Flow disabled

8.825.2 Field Documentation

8.825.2.1 uint32_t unpack_qos_QosFlowInfoState_t::id

8.825.2.2 uint8_t unpack_qos_QosFlowInfoState_t::isNewFlow

8.825.2.3 uint8_t unpack_qos_QosFlowInfoState_t::state

8.826 unpack_qos_SLQSQosGetNetworkStatus_t Struct Reference

Data Fields

- uint8_t NWQoSStatus
- swi_uint256_t ParamPresenceMask

8.826.1 Detailed Description

Structure that contains the response to get NW QoS status command

Parameters

NWQoSStatus	Network QoS support status • 0 - No QoS support in network • 1 - Network supports QoS • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.826.2 Field Documentation

8.826.2.1 uint8_t unpack_qos_SLQSQosGetNetworkStatus_t::NWQoSStatus

8.826.2.2 swi_uint256_t unpack_qos_SLQSQosGetNetworkStatus_t::ParamPresenceMask

8.827 unpack_qos_SLQSQosSwiReadApnExtraParams_t Struct Reference

Data Fields

- uint32_t apnId
- uint8_t ambr_ul
- uint8_t ambr_dl
- uint8_t ambr_ul_ext
- uint8_t ambr_dl_ext
- uint8_t ambr_ul_ext2
- uint8_t ambr_dl_ext2
- swi_uint256_t ParamPresenceMask

8.827.1 Detailed Description

Structure that contains extra APN parameters

Parameters

apnId	• APN id • ID identifing the APN that the client would like to query the AMBR params • Bit to check in ParamPresenceMask - **3**
ambr_ul	• APN AMBR uplink • APN AMBR uplink values from 1 kbps to 8640 kbps • Bit to check in ParamPresenceMask - **3**
ambr_dl	• APN AMBR downlink • APN AMBR downlink values from 1 kbps to 8640 kbps • Bit to check in ParamPresenceMask - **3**

ambr_ul_ext	• Extended APN AMBR uplink • APN AMBR uplink values from 8700 kbps to 256 Mbps • Bit to check in ParamPresenceMask - **3**
ambr_dl_ext	• Extended APN AMBR downlink • APN AMBR downlink values from 8700 kbps to 256 Mbps • Bit to check in ParamPresenceMask - **3**
ambr_ul_ext2	• Second extended APN AMBR uplink • APN AMBR uplink values from 256 Mbps to 65280 Mbps • Bit to check in ParamPresenceMask - **3**
ambr_dl_ext2	• Second extended APN AMBR downlink • APN AMBR downlink values from 256 Mbps to 65280 Mbps • Bit to check in ParamPresenceMask - **3**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.827.2 Field Documentation

8.827.2.1 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_dl

8.827.2.2 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_dl_ext

8.827.2.3 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_dl_ext2

8.827.2.4 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_ul

8.827.2.5 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_ul_ext

8.827.2.6 uint8_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ambr_ul_ext2

8.827.2.7 uint32_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::apnId

8.827.2.8 swi_uint256_t unpack_qos_SLQSQosSwiReadApnExtraParams_t::ParamPresenceMask

8.828 unpack_qos_SLQSQosSwiReadDataStats_t Struct Reference

Data Fields

- uint32_t apnId
- uint32_t total_tx_pkt
- uint32_t total_tx_pkt_drp
- uint32_t total_rx_pkt
- uint64_t total_tx_bytes
- uint64_t total_tx_bytes_drp

- uint64_t total_rx_bytes
- uint32_t numQosFlow
- unpack_QosFlowStat_t qosFlow [10]
- swi_uint256_t ParamPresenceMask

8.828.1 Detailed Description

Structure that contains APN data statistics

Parameters

apnId	• APN id • ID identifing the connected APN that the client would like to query the data statistic for • Bit to check in ParamPresenceMask - **3**
total_tx_pkt	• sum of all packets sent • Bit to check in ParamPresenceMask - **3**
total_tx_pkt_drp	• sum of all(TX) packets dropped • Bit to check in ParamPresenceMask - **3**
total_rx_pkt	• sum of all packets received • Bit to check in ParamPresenceMask - **3**
total_tx_bytes	• sum of all bytes sent • Bit to check in ParamPresenceMask - **3**
total_tx_bytes_drp	• sum of all(TX) bytes dropped • Bit to check in ParamPresenceMask - **3**
total_rx_bytes	• number of received bytes for the QoS flow ID • Bit to check in ParamPresenceMask - **3**
numQosFlow	• pointer to number of QoS flow Stat • Bit to check in ParamPresenceMask - **4**
qosFlow[LITEQMI_MAX_QOS_FLOW_PER_APN_STATS]	• Data statistic per QoS flow • See unpack_QosFlowStat_t for more information • See LITEQMI_MAX_QOS_FLOW_PER_APN_STATS for more information • Bit to check in ParamPresenceMask - **4**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.828.2 Field Documentation

8.828.2.1 uint32_t unpack_qos_SLQSQosSwiReadDataStats_t::apnId

8.828.2.2 uint32_t unpack_qos_SLQSQosSwiReadDataStats_t::numQosFlow

8.828.2.3 swi_uint256_t unpack_qos_SLQSQosSwiReadDataStats_t::ParamPresenceMask

8.828.2.4 unpack_QosFlowStat_t unpack_qos_SLQSQosSwiReadDataStats_t::qosFlow[10]

8.828.2.5 uint64_t unpack_qos_SLQSQosSwiReadDataStats_t::total_rx_bytes

8.828.2.6 uint32_t unpack_qos_SLQSQosSwiReadDataStats_t::total_rx_pkt

8.828.2.7 uint64_t unpack_qos_SLQSQosSwiReadDataStats_t::total_tx_bytes

8.828.2.8 uint64_t unpack_qos_SLQSQosSwiReadDataStats_t::total_tx_bytes_drp

8.828.2.9 uint32_t unpack_qos_SLQSQosSwiReadDataStats_t::total_tx_pkt

8.828.2.10 uint32_t unpack_qos_SLQSQosSwiReadDataStats_t::total_tx_pkt_drp

8.829 unpack_qos_SLQSSetQosEventCallback_ind_t Struct Reference

Data Fields

- uint8_t NumFlows
- unpack_qos_QosFlowInfo_t QosFlowInfo [8]
- swi_uint256_t ParamPresenceMask

8.829.1 Detailed Description

Structure with QoS event details

Parameters

NumFlows	• Number of QoS flows available • Bit to check in ParamPresenceMask - **16**
QosFlowInfo	• The Qos flow details, please check unpack_qos_QosFlowInfo_t for more information • See LITEQMI_MAX_QOS_FLOWS for more information • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.829.2 Field Documentation

8.829.2.1 uint8_t unpack_qos_SLQSSetQosEventCallback_ind_t::NumFlows

8.829.2.2 swi_uint256_t unpack_qos_SLQSSetQosEventCallback_ind_t::ParamPresenceMask

8.829.2.3 unpack_qos_QosFlowInfo_t unpack_qos_SLQSSetQosEventCallback_ind_t::QosFlowInfo[8]

8.830 unpack_qos_SLQSSetQosEventCallback_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.830.1 Detailed Description

This structure contains unpack QOS SLQSSetQosEventCallback. param ParamPresenceMask

- bitmask representation to indicate valid parameters.

8.830.2 Field Documentation

8.830.2.1 swi_uint256_t unpack_qos_SLQSSetQosEventCallback_t::ParamPresenceMask

8.831 unpack_qos_SLQSSetQosNWStatusCallback_ind_t Struct Reference

Data Fields

- uint8_t status
- swi_uint256_t ParamPresenceMask

8.831.1 Detailed Description

Structure with network's QoS status

Parameters

status	Network QoS support status • 0x00 - Current network does not support QoS • 0x01 - Current network supports QoS • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

Note

- Technology Supported: CDMA

8.831.2 Field Documentation

8.831.2.1 swi_uint256_t unpack_qos_SLQSSetQosNWStatusCallback_ind_t::ParamPresenceMask

8.831.2.2 uint8_t unpack_qos_SLQSSetQosNWStatusCallback_ind_t::status

8.832 unpack_qos_SLQSSetQosPriEventCallback_ind_t Struct Reference

Data Fields

- uint16_t event
- swi_uint256_t ParamPresenceMask

8.832.1 Detailed Description

Structure with QoS primary flow events

Parameters

event	Event which causes this indication: • 0x0001 - Primary flow QoS modify operation success • 0x0002 - Primary flow QoS modify operation failure • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.832.2 Field Documentation

8.832.2.1 uint16_t unpack_qos_SLQSSetQosPriEventCallback_ind_t::event

8.832.2.2 swi_uint256_t unpack_qos_SLQSSetQosPriEventCallback_ind_t::ParamPresenceMask

8.833 unpack_qos_SLQSSetQosStatusCallback_ind_t Struct Reference

Data Fields

- uint32_t id
- uint8_t status
- uint8_t event
- uint8_t reason
- swi_uint256_t ParamPresenceMask

8.833.1 Detailed Description

Structure with QoS status indication details

Parameters

id	• Index identifying the QoS flow whose status is being reported • Bit to check in ParamPresenceMask - **1**
status	Current QoS flow status: • 0x01 - QMI_QOS_STATUS_ACTIVATED • 0x02 - QMI_QOS_STATUS_SUSPENDED • 0x03 - QMI_QOS_STATUS_GONE • Bit to check in ParamPresenceMask - **1**

event	• 0x01 - QMI_QOS_ACTIVATED_EV • 0x02 - QMI_QOS_SUSPENDED_EV • 0x03 - QMI_QOS_GONE_EV • 0x04 - QMI_QOS_MODIFY_ACCEPTED_EV • 0x05 - QMI_QOS_MODIFY_REJECTED_EV • 0x06 - QMI_QOS_INFO_CODE_UPDATED_EV • Bit to check in ParamPresenceMask - **1**
reason	• 0x01 - QMI_QOS_INVALID_PARAMS • 0x02 - QMI_QOS_INTERNAL_CALL_ENDED • 0x03 - QMI_QOS_INTERNAL_ERROR • 0x04 - QMI_QOS_INSUFFICIENT_LOCAL_Resources • 0x05 - QMI_QOS_TIMED_OUT_OPERATION • 0x06 - QMI_QOS_INTERNAL_UNKNOWN_CAUSE_CODE • 0x07 - QMI_QOS_INTERNAL_MODIFY_IN_PROGRESS • 0x08 - QMI_QOS_NOT_SUPPORTED • 0x09 - QMI_QOS_NOT_AVAILABLE • 0x0A - QMI_QOS_NOT_GUARANTEED • 0x0B - QMI_QOS_INSUFFICIENT_NETWORK_RESOURCES • 0x0C - QMI_QOS_AWARE_SYSTEM • 0x0D - QMI_QOS_UNAWARE_SYSTEM • 0x0E - QOS_REJECTED_OPERATION • 0x0F - QMI_QOS_WILL_GRANT_WHEN_QOS_RESUMED • 0x10 - QMI_QOS_NETWORK_CALL_ENDED • 0x11 - QMI_QOS_NETWORK_SERVICE_NOT_AVAILABLE • 0x12 - QMI_QOS_NETWORK_L2_LINK_RELEASED • 0x13 - QMI_QOS_NETWORK_L2_LINK_REESTAB_REJ • 0x14 - QMI_QOS_NETWORK_L2_LINK_REESTAB_IND • 0x15 - QMI_QOS_NETWORK_UNKNOWN_CAUSE_CODE • 0x16 - QMI_NETWORK_BUSY • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.833.2 Field Documentation

8.833.2.1 uint8_t unpack_qos_SLQSSetQosStatusCallback_ind_t::event

8.833.2.2 uint32_t unpack_qos_SLQSSetQosStatusCallback_ind_t::id

8.833.2.3 swi_uint256_t unpack_qos_SLQSSetQosStatusCallback_ind_t::ParamPresenceMask

8.833.2.4 uint8_t unpack_qos_SLQSSetQosStatusCallback_ind_t::reason

8.833.2.5 uint8_t unpack_qos_SLQSSetQosStatusCallback_ind_t::status

8.834 unpack_qos_swiQosFilter_t Struct Reference

Data Fields

- uint8_t index
- uint8_t version
- uint8_t is_IPv4SrcAddr_Available
- unpack_qos_IPv4Addr_t IPv4SrcAddr
- uint8_t is_IPv4DstAddr_Available
- unpack_qos_IPv4Addr_t IPv4DstAddr
- uint8_t is_NxtHdrProto_Available
- uint8_t NxtHdrProto
- uint8_t is_IPv4Tos_Available
- unpack_qos_Tos_t IPv4Tos
- uint8_t is_IPv6SrcAddr_Available
- unpack_qos_IPv6Addr_t IPv6SrcAddr
- uint8_t is_IPv6DstAddr_Available
- unpack_qos_IPv6Addr_t IPv6DstAddr
- uint8_t is_IPv6TrafCls_Available
- unpack_qos_IPv6TrafCls_t IPv6TrafCls
- uint8_t is_IPv6Label_Available
- uint32_t IPv6Label
- uint8_t is_TCPSrcPort_Available
- unpack_qos_Port_t TCPSrcPort
- uint8_t is_TCPDstPort_Available
- unpack_qos_Port_t TCPDstPort
- uint8_t is_UDPSrcPort_Available
- unpack_qos_Port_t UDPSrcPort
- uint8_t is_UDPDstPort_Available
- unpack_qos_Port_t UDPDstPort
- uint8_t is_EspSpi_Available
- uint32_t EspSpi
- uint8_t is_Precedence_Available
- uint16_t Precedence
- uint8_t is_Id_Available
- uint16_t Id
- uint8_t is_TranSrcPort_Available
- unpack_qos_Port_t TranSrcPort
- uint8_t is_TranDstPort_Available
- unpack_qos_Port_t TranDstPort

8.834.1 Detailed Description

This structure contains the QoS Filter Request.

Please check is_<Param_Name>_Available field for presence of optional parameters

Parameters

index	Mandatory parameter IP filter index Integer that uniquely identifies each filter instance This TLV must be present in the request
version	Mandatory parameter IP filter version Identifies whether the filter is associated with IPv4 or IPv6; value specified also implies that only TLVs defined for that IP version, i.e., TLVs with IPv4 or IPv6 in the name, can be specified • 0x04 - IPv4 • 0x06 - Ipv6
IPv4SrcAddr	IPv4 filter soruce address See unpack_qos_IPv4Addr_t for more information • Implemented only for unsolicited indication
IPv4DstAddr	IPv4 filter destination address See unpack_qos_IPv4Addr_t for more information • Implemented only for unsolicited indication
NxtHdrProto	IP filter next header protocol This TLV must be present if any non-IP filter TLV(s) are provided If this field is specified, only IP packets belonging to specified higher layer protocol are considered when filtering The following protocols may be specified: • 0x01 = ICMP • 0x06 = TCP • 0x11 = UDP • 0x32 = ESP Note: The next header protocol field will be set to 0xFD (TCP & UDP) if a TFT is received specifying a source or destination port number, but IP next header type is not specified.
IPv4Tos	IPv4 filter type of service See unpack_qos_Tos_t for more information
IPv6SrcAddr	IPv6 filter soruce address See unpack_qos_IPv6Addr_t for more information • Implemented only for unsolicited indication
IPv6DstAddr	IPv6 filter destination address See unpack_qos_IPv6Addr_t for more information • Implemented only for unsolicited indication
IPv6TrafCls	IPv6 filter traffic class See unpack_qos_IPv6TrafCls_t for more information
IPv6Label	IPv6 flow label Packet matches the IPv6 flow label filter if: (∗pIPv6Label == flow label in the IPv6 header) • Implemented only for unsolicited indication
TCPSrcPort	TCP filter source port filter See unpack_qos_Port_t for more information • Implemented only for unsolicited indication
TCPDstPort	TCP filter destination port filter See unpack_qos_Port_t for more information • Implemented only for unsolicited indication
UDPSrcPort	UDP filter source port filter See unpack_qos_Port_t for more information • Implemented only for unsolicited indication
UDPDstPort	UDP filter destination port filter See unpack_qos_Port_t for more information • Implemented only for unsolicited indication
EspSpi	ESP filter security policy index Security policy index to uniquely identify each IP flow for filtering encrypted packets for encapsulating security payload • Implemented only for unsolicited indication
Precedence	Filter Precedence Specifies the order in which filters are applied; lower numerical value has higher precedence Note: This TLV only applies to network-initiated QoS; QoS requests containing this TLV from control points will be ignored

Id	Filter ID Unique identifier for each filter;filter ID is assigned by the modem Note: This TLV only applies to network-initiated QoS; QoS requests containing this TLV from control points will be ignored
TranSrcPort	Transport protocolfilter source port See unpack_qos_Port_t for more information • Implemented only for unsolicited indication
UDPDstPort	Transport protocol filter destination port See unpack_qos_Port_t for more information • Implemented only for unsolicited indication

8.834.2 Field Documentation

8.834.2.1 uint32_t unpack_qos_swiQosFilter_t::EspSpi

8.834.2.2 uint16_t unpack_qos_swiQosFilter_t::Id

8.834.2.3 uint8_t unpack_qos_swiQosFilter_t::index

8.834.2.4 unpack_qos_IPv4Addr_t unpack_qos_swiQosFilter_t::IPv4DstAddr

8.834.2.5 unpack_qos_IPv4Addr_t unpack_qos_swiQosFilter_t::IPv4SrcAddr

8.834.2.6 unpack_qos_Tos_t unpack_qos_swiQosFilter_t::IPv4Tos

8.834.2.7 unpack_qos_IPv6Addr_t unpack_qos_swiQosFilter_t::IPv6DstAddr

8.834.2.8 uint32_t unpack_qos_swiQosFilter_t::IPv6Label

8.834.2.9 unpack_qos_IPv6Addr_t unpack_qos_swiQosFilter_t::IPv6SrcAddr

8.834.2.10 unpack_qos_IPv6TrafCls_t unpack_qos_swiQosFilter_t::IPv6TrafCls

8.834.2.11 uint8_t unpack_qos_swiQosFilter_t::is_EspSpi_Available

8.834.2.12 uint8_t unpack_qos_swiQosFilter_t::is_Id_Available

8.834.2.13 uint8_t unpack_qos_swiQosFilter_t::is_IPv4DstAddr_Available

8.834.2.14 uint8_t unpack_qos_swiQosFilter_t::is_IPv4SrcAddr_Available

8.834.2.15 uint8_t unpack_qos_swiQosFilter_t::is_IPv4Tos_Available

8.834.2.16 uint8_t unpack_qos_swiQosFilter_t::is_IPv6DstAddr_Available

8.834.2.17 uint8_t unpack_qos_swiQosFilter_t::is_IPv6Label_Available

8.834.2.18 uint8_t unpack_qos_swiQosFilter_t::is_IPv6SrcAddr_Available

8.834.2.19 uint8_t unpack_qos_swiQosFilter_t::is_IPv6TrafCls_Available

8.834.2.20 uint8_t unpack_qos_swiQosFilter_t::is_NxtHdrProto_Available

8.834.2.21 uint8_t unpack_qos_swiQosFilter_t::is_Precedence_Available

8.834.2.22 uint8_t unpack_qos_swiQosFilter_t::is_TCPDstPort_Available

8.834.2.23 uint8_t unpack_qos_swiQosFilter_t::is_TCPSrcPort_Available

8.834.2.24 uint8_t unpack_qos_swiQosFilter_t::is_TranDstPort_Available

8.834.2.25 uint8_t unpack_qos_swiQosFilter_t::is_TranSrcPort_Available

8.834.2.26 uint8_t unpack_qos_swiQosFilter_t::is_UDPDstPort_Available

8.834.2.27 uint8_t unpack_qos_swiQosFilter_t::is_UDPSrcPort_Available

8.834.2.28 uint8_t unpack_qos_swiQosFilter_t::NxtHdrProto

8.834.2.29 uint16_t unpack_qos_swiQosFilter_t::Precedence

8.834.2.30 unpack_qos_Port_t unpack_qos_swiQosFilter_t::TCPDstPort

8.834.2.31 unpack_qos_Port_t unpack_qos_swiQosFilter_t::TCPSrcPort

8.834.2.32 unpack_qos_Port_t unpack_qos_swiQosFilter_t::TranDstPort

8.834.2.33 unpack_qos_Port_t unpack_qos_swiQosFilter_t::TranSrcPort

8.834.2.34 unpack_qos_Port_t unpack_qos_swiQosFilter_t::UDPDstPort

8.834.2.35 unpack_qos_Port_t unpack_qos_swiQosFilter_t::UDPSrcPort

8.834.2.36 uint8_t unpack_qos_swiQosFilter_t::version

8.835 unpack_qos_swiQosFlow_t Struct Reference

Data Fields

- uint8_t index
- uint8_t is_ProfileId3GPP2_Available
- uint16_t ProfileId3GPP2
- uint8_t is_val_3GPP2Pri_Available
- uint8_t val_3GPP2Pri
- uint8_t is_TrafficClass_Available
- uint8_t TrafficClass
- uint8_t is_DataRate_Available
- unpack_qos_dataRate_t DataRate
- uint8_t is_TokenBucket_Available
- unpack_qos_tokenBucket_t TokenBucket
- uint8_t is_Latency_Available
- uint32_t Latency
- uint8_t is_Jitter_Available
- uint32_t Jitter
- uint8_t is_PktErrRate_Available
- unpack_qos_pktErrRate_t PktErrRate
- uint8_t is_MinPolicedPktSz_Available
- uint32_t MinPolicedPktSz
- uint8_t is_MaxAllowedPktSz_Available
- uint32_t MaxAllowedPktSz
- uint8_t is_val_3GPPResResidualBER_Available
- uint16_t val_3GPPResResidualBER

- uint8_t is_val_3GPPTraHdlPri_Available
- uint8_t val_3GPPTraHdlPri
- uint8_t is_val_3GPPImCn_Available
- uint8_t val_3GPPImCn
- uint8_t is_val_3GPPSigInd_Available
- uint8_t val_3GPPSigInd
- uint8_t is_LteQci_Available
- uint8_t LteQci

8.835.1 Detailed Description

This structure contains the QoS Flow Request.

Please check is_<Param_Name>_Available field for presence of optional parameters

Parameters

index	• Mandatory parameter • IP flow index • Integer that uniquely identifies each flow instance • Unique index must be assigned by the control point to every flow_spec instance
ProfileId3GPP2	• IP flow 3GPP2 profile ID • A profile ID is shorthand for a defined set of QoS flow parameters specified by the network; to be present while requesting QoS for a CDMA device
val_3GPP2Pri	• IP flow 3GPP2 flow priority • Flow priority used by the network in case of contention between flows with same QoS; this parameter applies for CDMA devices
TrafficClass	• IP flow traffic class • Integer that designates the requested traffic class: • 0 - Conversational • 1 - Streaming • 2 - Interactive • 3 - Background
DataRate	• IP flow data rate min max • See unpack_qos_dataRate_t for more information
TokenBucket	• IP flow data rate token bucket • See unpack_qos_tokenBucket_t for more information
Latency	• IP flow latency • Maximum delay (in milliseconds) that can be tolerated by an IP packet during transfer through the wireless link

Jitter	• IP flow jitter • Difference between the maximum and minimum latency (in milliseconds) that can be tolerated by an IP packet during the transfer through the wireless link
PktErrRate	• IP flow packet error rate • See unpack_qos_pktErrRate_t for more information
MinPolicedPktSz	• IP flow minimum policed packet size • Integer that defines the minimum packet size (in bytes) that will be policed for QoS guarantees; any IP packets that are smaller than the minimum specified policed size may not receive requested QoS
MaxAllowedPktSz	• IP flow maximum allowed packet size • Integer that defines the maximum packet size (in bytes) allowed in the IP flow; any IP packets greater in size than the maximum allowed packet size are not queued for transmission
val_3GPPResResidualBER	• IP flow 3GPP residual bit error rate • residual_bit_error_rate • 0 = 5∗10-2 residual BER • 1 = 1∗10-2 residual BER • 2 = 5∗10-3 residual BER • 3 = 4∗10-3 residual BER • 4 = 1∗10-3 residual BER • 5 = 1∗10-4 residual BER • 6 = 1∗10-5 residual BER • 7 = 1∗10-6 residual BER • 8 = 6∗10-8 residual BER • Integer that indicates the undetected BER for each IP flow in the delivered packets; Tapplies only to 3GPP networks
val_3GPPTraHdlPri	• 3GPP traffic handling priority • 0 - Relative traffic handling priority 1 • 1 - Relative traffic handling priority 2 • 2 - Relative traffic handling priority 3 • Defines the relative priority of the flow; applies only to 3GPP networks
val_3GPPImCn	• IP flow 3GPP IM CN flag • IM CN subsystem signaling flag: • 0x00 - FALSE • 0x01 - TRUE • This parameter applies only to 3GPP networks

val_3GPPSigInd	• IP flow 3GPP signaling indication • 0x00 - FALSE • 0x01 - TRUE • This parameter applies only to 3GPP networks
LteQci	• LTE QoS Class Identifier • QoS Class Identifier(QCI) is a required parameter to request QoS in LTE • QCI values: – QCI value 0 requests the network to assign the appropriate QCI value – QCI values 1-4 are associated with guaranteed bitrates – QCI values 5-9 are associated with nonguaranteed bitrates, so the values specified as guaranteed and maximum bitrates are ignored

8.835.2 Field Documentation

8.835.2.1 unpack_qos_dataRate_t unpack_qos_swiQosFlow_t::DataRate

8.835.2.2 uint8_t unpack_qos_swiQosFlow_t::index

8.835.2.3 uint8_t unpack_qos_swiQosFlow_t::is_DataRate_Available

8.835.2.4 uint8_t unpack_qos_swiQosFlow_t::is_Jitter_Available

8.835.2.5 uint8_t unpack_qos_swiQosFlow_t::is_Latency_Available

8.835.2.6 uint8_t unpack_qos_swiQosFlow_t::is_LteQci_Available

8.835.2.7 uint8_t unpack_qos_swiQosFlow_t::is_MaxAllowedPktSz_Available

8.835.2.8 uint8_t unpack_qos_swiQosFlow_t::is_MinPolicedPktSz_Available

8.835.2.9 uint8_t unpack_qos_swiQosFlow_t::is_PktErrRate_Available

8.835.2.10 uint8_t unpack_qos_swiQosFlow_t::is_ProfileId3GPP2_Available

8.835.2.11 uint8_t unpack_qos_swiQosFlow_t::is_TokenBucket_Available

8.835.2.12 uint8_t unpack_qos_swiQosFlow_t::is_TrafficClass_Available

8.835.2.13 uint8_t unpack_qos_swiQosFlow_t::is_val_3GPP2Pri_Available

8.835.2.14 uint8_t unpack_qos_swiQosFlow_t::is_val_3GPPImCn_Available

8.835.2.15 uint8_t unpack_qos_swiQosFlow_t::is_val_3GPPResResidualBER_Available

8.835.2.16 uint8_t unpack_qos_swiQosFlow_t::is_val_3GPPSigInd_Available

8.835.2.17 uint8_t unpack_qos_swiQosFlow_t::is_val_3GPPTraHdlPri_Available

8.835.2.18 uint32_t unpack_qos_swiQosFlow_t::Jitter

8.835.2.19 uint32_t unpack_qos_swiQosFlow_t::Latency

8.835.2.20 uint8_t unpack_qos_swiQosFlow_t::LteQci

8.835.2.21 uint32_t unpack_qos_swiQosFlow_t::MaxAllowedPktSz

8.835.2.22 uint32_t unpack_qos_swiQosFlow_t::MinPolicedPktSz

8.835.2.23 unpack_qos_pktErrRate_t unpack_qos_swiQosFlow_t::PktErrRate

8.835.2.24 uint16_t unpack_qos_swiQosFlow_t::ProfileId3GPP2

8.835.2.25 unpack_qos_tokenBucket_t unpack_qos_swiQosFlow_t::TokenBucket

8.835.2.26 uint8_t unpack_qos_swiQosFlow_t::TrafficClass

8.835.2.27 uint8_t unpack_qos_swiQosFlow_t::val_3GPP2Pri

8.835.2.28 uint8_t unpack_qos_swiQosFlow_t::val_3GPPImCn

8.835.2.29 uint16_t unpack_qos_swiQosFlow_t::val_3GPPResResidualBER

8.835.2.30 uint8_t unpack_qos_swiQosFlow_t::val_3GPPSigInd

8.835.2.31 uint8_t unpack_qos_swiQosFlow_t::val_3GPPTraHdlPri

8.836 unpack_qos_tokenBucket_t Struct Reference

Data Fields

- uint32_t peakRate
- uint32_t tokenRate
- uint32_t bucketSz

8.836.1 Detailed Description

This structure contains the TP flow data rate token bucket

Parameters

peakRate	Maximum rate at which data can be transmitted when the token bucket is full (bits per second)
tokenRate	Rate at which tokens will be put in the token bucket (bits per second); a token is required to be present in the bucket to send a byte of data
bucketSz	Maximum number of tokens that can be accumulated at any instance (bytes); controls the size of the burst that is allowed at any given time

8.836.2 Field Documentation

8.836.2.1 uint32_t unpack_qos_tokenBucket_t::bucketSz

8.836.2.2 uint32_t unpack_qos_tokenBucket_t::peakRate

8.836.2.3 uint32_t unpack_qos_tokenBucket_t::tokenRate

8.837 unpack_qos_Tos_t Struct Reference

Data Fields

- uint8_t val
- uint8_t mask

8.837.1 Detailed Description

This structure contains the IPv4 filter type of service

Parameters

val	Type of service value
mask	Packet matches the TOS filter if: (IPv4_filter_tos_val and IPv4_filter_tos_mask) == (TOS value in the IP packet & IPv4_filter_tos_mask) Example: • IPv4_filter_tos_val = 00101000 • IPv4_filter_tos_mask = 11111100 The filter will compare only the first 6 bits in the IPv4_filter_type_of_service with the first 6 bits in the TOS field of the IP packet. The first 6 bits in the TOS field of the IP packet must be 001010 to match the filter. The last 2 bits can be anything since they are ignored by filtering.

8.837.2 Field Documentation

8.837.2.1 uint8_t unpack_qos_Tos_t::mask

8.837.2.2 uint8_t unpack_qos_Tos_t::val

8.838 unpack_QosFlowStat_t Struct Reference

Data Fields

- uint32_t bearerId
- uint32_t tx_pkt
- uint32_t tx_pkt_drp
- uint64_t tx_bytes
- uint64_t tx_bytes_drp

8.838.1 Detailed Description

This structure contains the Data statistic per QoS flow

Parameters

bearerId	• Bearer ID
tx_pkt	• number of sent packets for the QoS flow ID
tx_pkt_drp	• number of dropped(TX) packets for the QoS flow ID

tx_bytes	• number of sent bytes for the QoS flow ID
tx_bytes_drp	• number of dropped(TX) bytes for the QoS flow ID

8.838.2 Field Documentation

8.838.2.1 uint32_t unpack_QosFlowStat_t::bearerId

8.838.2.2 uint64_t unpack_QosFlowStat_t::tx_bytes

8.838.2.3 uint64_t unpack_QosFlowStat_t::tx_bytes_drp

8.838.2.4 uint32_t unpack_QosFlowStat_t::tx_pkt

8.838.2.5 uint32_t unpack_QosFlowStat_t::tx_pkt_drp

8.839 unpack_result_t Struct Reference

Data Fields

- uint16_t TlvresultSwi_uint256_t ParamPresenceMask

8.839.1 Detailed Description

unpack result struct

Parameters

out	*Tlvresult*	
out	*ParamPresence-Mask*	Parameter presence bit mask

8.839.2 Field Documentation

8.839.2.1 swi_uint256_t unpack_result_t::ParamPresenceMask

8.839.2.2 uint16_t unpack_result_t::Tlvresult

8.840 unpack_rms_GetSMSWake_t Struct Reference

Data Fields

- uint32_t enabled
- uint32_t wake_mask
- swi_uint256_t ParamPresenceMask

8.840.1 Detailed Description

Unpack get SMS wake parameters

Parameters

enabled	• SMS wake functionality enabled – 0 - Disabled – 1 - Enabled • Bit to check in ParamPresenceMask - **16**
wake_mask	• SMS wake mask to search for incoming messages (only relevant when enabled) • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.840.2 Field Documentation

8.840.2.1 uint32_t unpack_rms_GetSMSWake_t::enabled

8.840.2.2 swi_uint256_t unpack_rms_GetSMSWake_t::ParamPresenceMask

8.840.2.3 uint32_t unpack_rms_GetSMSWake_t::wake_mask

8.841 unpack_rms_SetSMSWake_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.841.1 Detailed Description

This structure contains unpack Set SMS Wake.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.841.2 Field Documentation

8.841.2.1 swi_uint256_t unpack_rms_SetSMSWake_t::ParamPresenceMask

8.842 unpack_RMTransferStatistics_ind_t Struct Reference

Data Fields

- wds_DataULongTlv TxOkConutTlv

- wds_DataULongTlv RxOkConutTlv
- wds_DataULongLongTlv TxOkByteCountTlv
- wds_DataULongLongTlv RxOkByteCountTlv
- wds_DataULongTlv TxDropConutTlv
- wds_DataULongTlv RxDropConutTlv
- swi_uint256_t ParamPresenceMask

8.842.1 Detailed Description

WDS packet RM Transfer Statistics data structure for individual session

Parameters

TxOkConutTlv	• Tx Ok Packet Tlv Value. • Bit to check in ParamPresenceMask - **16**
RxOkConutTlv	• Rx Ok Packet Tlv Value. • Bit to check in ParamPresenceMask - **17**
TxOkByteCount-Tlv	• Tx Ok Byte Count Packet Tlv Value. • Bit to check in ParamPresenceMask - **25**
RxOkByteCount-Tlv	• Rx Ok Byte Count Packet Tlv Value. • Bit to check in ParamPresenceMask - **26**
TxDropConutTlv	• Tx Drop Count Packet Tlv Value. • Bit to check in ParamPresenceMask - **37**
RxDropConutTlv	• Rx Drop Count Packet Tlv Value. • Bit to check in ParamPresenceMask - **38**

8.842.2 Field Documentation

8.842.2.1 swi_uint256_t unpack_RMTransferStatistics_ind_t::ParamPresenceMask

8.842.2.2 wds_DataULongTlv unpack_RMTransferStatistics_ind_t::RxDropConutTlv

8.842.2.3 wds_DataULongLongTlv unpack_RMTransferStatistics_ind_t::RxOkByteCountTlv

8.842.2.4 wds_DataULongTlv unpack_RMTransferStatistics_ind_t::RxOkConutTlv

8.842.2.5 wds_DataULongTlv unpack_RMTransferStatistics_ind_t::TxDropConutTlv

8.842.2.6 wds_DataULongLongTlv unpack_RMTransferStatistics_ind_t::TxOkByteCountTlv

8.842.2.7 wds_DataULongTlv unpack_RMTransferStatistics_ind_t::TxOkConutTlv

8.843 unpack_sar_SLQSGetRfSarState_t Struct Reference

Data Fields

- uint32_t * pSarRFState
- swi_uint256_t ParamPresenceMask

8.843.1 Detailed Description

This structure contains unpack get RF SAR state parameter.

Parameters

pSarRFState	• SAR RF State – QMI_SAR_RF_STATE_DEFAULT – QMI_SAR_RF_STATE_1 – QMI_SAR_RF_STATE_2 – QMI_SAR_RF_STATE_3 – QMI_SAR_RF_STATE_4 – QMI_SAR_RF_STATE_5 – QMI_SAR_RF_STATE_6 – QMI_SAR_RF_STATE_7 – QMI_SAR_RF_STATE_8 • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.843.2 Field Documentation

8.843.2.1 swi_uint256_t unpack_sar_SLQSGetRfSarState_t::ParamPresenceMask

8.843.2.2 uint32_t* unpack_sar_SLQSGetRfSarState_t::pSarRFState

8.844 unpack_sms_GetSMSCAddress_t Struct Reference

Data Fields

- uint8_t addressSize
- uint8_t * pSMSCAddress
- uint8_t typeSize
- uint8_t * pSMSCType
- swi_uint256_t ParamPresenceMask

8.844.1 Detailed Description

Structure contains Gets the SMS center address parameters.

Parameters

addressSize	• The maximum number of characters (including NULL terminator) that the SMS center address array can contain. • Bit to check in ParamPresenceMask - **1**
pSMSCAddress	• The SMS center address represented as a NULL terminated string. • Bit to check in ParamPresenceMask - **1**
typeSize	• The maximum number of characters (including NULL terminator) that the SMS center address type array can contain. • Bit to check in ParamPresenceMask - **1**
pSMSCType	• The SMS center address type represented as a NULL terminated string. • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.844.2 Field Documentation

8.844.2.1 uint8_t unpack_sms_GetSMSCAddress_t::addressSize

8.844.2.2 swi_uint256_t unpack_sms_GetSMSCAddress_t::ParamPresenceMask

8.844.2.3 uint8_t* unpack_sms_GetSMSCAddress_t::pSMSCAddress

8.844.2.4 uint8_t* unpack_sms_GetSMSCAddress_t::pSMSCType

8.844.2.5 uint8_t unpack_sms_GetSMSCAddress_t::typeSize

8.845 unpack_sms_SaveSMS_t Struct Reference

Data Fields

- uint32_t * pMessageIndex
- swi_uint256_t ParamPresenceMask

8.845.1 Detailed Description

This structure contains unpack save SMS parameter.

Parameters

pMessageIndex	• The message index assigned by the device • Bit to check in ParamPresenceMask - **1**

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.845.2 Field Documentation

8.845.2.1 swi_uint256_t unpack_sms_SaveSMS_t::ParamPresenceMask

8.845.2.2 uint32_t* unpack_sms_SaveSMS_t::pMessageIndex

8.846 unpack_sms_SendSMS_t Struct Reference

Data Fields

- uint16_t messageID
- uint32_t messageFailureCode
- swi_uint256_t ParamPresenceMask

8.846.1 Detailed Description

This structure contains unpack send SMS parameters.

Parameters

messageID	• WMS message ID • Bit to check in ParamPresenceMask - **1**
messageFailure-Code	• pointer to message failure code. • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.846.2 Field Documentation

8.846.2.1 uint32_t unpack_sms_SendSMS_t::messageFailureCode

8.846.2.2 uint16_t unpack_sms_SendSMS_t::messageID

8.846.2.3 swi_uint256_t unpack_sms_SendSMS_t::ParamPresenceMask

8.847 unpack_sms_SetNewSMSCallback_ind_t Struct Reference

Data Fields

- newMTMessageTlv NewMMTlv
- transferRouteMessageTlv TRMessageTlv
- messageModeTlv MMTlv

- sMSEtwsMessageTlv ETWSTlv
- eTWSPLMNInfoTlv ETWSPLMNTlv
- sMSCAddressTlv SMSCTlv
- sMSOnIMSTlv IMSTlv
- swi_uint256_t ParamPresenceMask

8.847.1 Detailed Description

This structure contains unpack new SMS callback indication.

Parameters

NewMMTlv	• MT message • See newMTMessageTlv for more information • Bit to check in ParamPresenceMask - **16**
TRMessageTlv	• Transfer Route MT Message • See transferRouteMessageTlv for more information • Bit to check in ParamPresenceMask - **17**
MMTlv	• Message mode • See messageModeTlv for more information • Bit to check in ParamPresenceMask - **18**
ETWSTlv	• ETWS Message • See sMSEtwsMessageTlv for more information • Bit to check in ParamPresenceMask - **19**
ETWSPLMNTlv	• ETWS PLMN Information • See eTWSPLMNInfoTlv for more information • Bit to check in ParamPresenceMask - **20**
SMSCTlv	• SMSC Address • See sMSCAddressTlv for more information • Bit to check in ParamPresenceMask - **21**
IMSTlv	• SMS on IMS • See sMSOnIMSTlv for more information • Bit to check in ParamPresenceMask - **22**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.847.2 Field Documentation

8.847.2.1 eTWSPLMNInfoTlv unpack_sms_SetNewSMSCallback_ind_t::ETWSPLMNTlv

8.847.2.2 sMSEtwsMessageTlv unpack_sms_SetNewSMSCallback_ind_t::ETWSTlv

8.847.2.3 sMSOnIMSTlv unpack_sms_SetNewSMSCallback_ind_t::IMSTlv

8.847.2.4 messageModeTlv unpack_sms_SetNewSMSCallback_ind_t::MMTlv

8.847.2.5 newMTMessageTlv unpack_sms_SetNewSMSCallback_ind_t::NewMMTlv

8.847.2.6 swi_uint256_t unpack_sms_SetNewSMSCallback_ind_t::ParamPresenceMask

8.847.2.7 sMSCAddressTlv unpack_sms_SetNewSMSCallback_ind_t::SMSCTlv

8.847.2.8 transferRouteMessageTlv unpack_sms_SetNewSMSCallback_ind_t::TRMessageTlv

8.848 unpack_sms_SetNewSMSCallback_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.848.1 Detailed Description

This structure contains unpack set new SMS callback.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.848.2 Field Documentation

8.848.2.1 swi_uint256_t unpack_sms_SetNewSMSCallback_t::ParamPresenceMask

8.849 unpack_sms_SetSMSCAddress_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.849.1 Detailed Description

This structure contains unpack Set SMS Address parameter.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.849.2 Field Documentation

8.849.2.1 swi_uint256_t unpack_sms_SetSMSCAddress_t::ParamPresenceMask

8.850 unpack_sms_SLQSDeleteSMS_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.850.1 Detailed Description

This structure contains unpack delete SMS parameters.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.850.2 Field Documentation

8.850.2.1 swi_uint256_t unpack_sms_SLQSDeleteSMS_t::ParamPresenceMask

8.851 unpack_sms_SLQSGetIndicationRegister_t Struct Reference

Data Fields

- sms_getIndicationReg * pGetIndicationRegInfo
- swi_uint256_t ParamPresenceMask

8.851.1 Detailed Description

Structure containing Parameters that provides registration state of different WMS indications.

Parameters

pGetIndication-RegInfo	• Pointer to structure of getIndicationReg – See sms_getIndicationReg for more information – pRegTransLayerInfoEvt * Bit to check in ParamPresenceMask - **16** – pRegTransNWRegInfoEvt * Bit to check in ParamPresenceMask - **17** – pRegCallStatInfoEvt * Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.851.2 Field Documentation

8.851.2.1 swi_uint256_t unpack_sms_SLQSGetIndicationRegister_t::ParamPresenceMask

8.851.2.2 sms_getIndicationReg* unpack_sms_SLQSGetIndicationRegister_t::pGetIndicationRegInfo

8.852 unpack_sms_SLQSGetMessageWaiting_t Struct Reference

Data Fields

- sms_getMsgWaitingInfo * pGetMsgWaitingInfoResp
- swi_uint256_t ParamPresenceMask

8.852.1 Detailed Description

Structure contain Parameter that provide information about the message waiting information.

Parameters

pGetMsg-WaitingInfoResp	• Pointer to structure of getMsgWaitingInfoResp – See sms_getMsgWaitingInfo for more information • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.852.2 Field Documentation

8.852.2.1 swi_uint256_t unpack_sms_SLQSGetMessageWaiting_t::ParamPresenceMask

8.852.2.2 sms_getMsgWaitingInfo* unpack_sms_SLQSGetMessageWaiting_t::pGetMsgWaitingInfoResp

8.853 unpack_sms_SLQSGetSMS_t Struct Reference

Data Fields

- uint32_t messageTag
- uint32_t messageFormat
- uint32_t messageSize
- uint8_t message [2048]
- swi_uint256_t ParamPresenceMask

8.853.1 Detailed Description

This sturcture contains unpack get SMS parameters.

Parameters

messageTag	• Message tag – 0 - Read – 1 - Not read – 2 - Mobile originated and sent – 3 - Mobile originated but not yet sent

- Bit to check in ParamPresenceMask - **1**

Parameters

messageFormat	• Message format – 0 - CDMA (IS-637B) – 1 - 5 (Reserved) – 6 - GSM/WCDMA PP

- Bit to check in ParamPresenceMask - **1**

Parameters

messageSize	• Upon input the maximum number of bytes that can be written to the message array. • Upon successful output the actual number of bytes written to the message array. • Bit to check in ParamPresenceMask - **1**
message	• The message contents array
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.853.2 Field Documentation

8.853.2.1 uint8_t unpack_sms_SLQSGetSMS_t::message[2048]

8.853.2.2 uint32_t unpack_sms_SLQSGetSMS_t::messageFormat

8.853.2.3 uint32_t unpack_sms_SLQSGetSMS_t::messageSize

8.853.2.4 uint32_t unpack_sms_SLQSGetSMS_t::messageTag

8.853.2.5 swi_uint256_t unpack_sms_SLQSGetSMS_t::ParamPresenceMask

8.854 unpack_sms_SLQSGetSmsBroadcastConfig_t Struct Reference

Data Fields

- sms_qaQmi3GPPBroadcastCfgInfo * pBroadcastConfig
- sms_qaQmi3GPP2BroadcastCfgInfo * pCDMABroadcastConfig
- swi_uint256_t ParamPresenceMask

8.854.1 Detailed Description

Structure contain parameters that Provides Information about the SMS BroadcastConfiguration

Parameters

pBroadcast-Config	• The data for 3GPP Broadcast Information(Optional). • Bit to check in ParamPresenceMask - **16**
pCDMA-BroadcastConfig	• The data for 3GPP2 Broadcast Information(Optional). • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.854.2 Field Documentation

8.854.2.1 swi_uint256_t unpack_sms_SLQSGetSmsBroadcastConfig_t::ParamPresenceMask

8.854.2.2 sms_qaQmi3GPPBroadcastCfgInfo* unpack_sms_SLQSGetSmsBroadcastConfig_t::pBroadcastConfig

8.854.2.3 sms_qaQmi3GPP2BroadcastCfgInfo* unpack_sms_SLQSGetSmsBroadcastConfig_t::pCDMABroadcastConfig

8.855 unpack_sms_SLQSGetSMSList_t Struct Reference

Data Fields

- uint32_t messageListSize
- qmiSmsMessageList messageList [255]
- swi_uint256_t ParamPresenceMask

8.855.1 Detailed Description

This structure contains unpack get SMS list parameters.

Parameters

messageListSize	• Upon input the maximum number of elements that the message list array can contain. • Upon successful output the actual number of elements in the message list array. • Bit to check in ParamPresenceMask - **1**

messageList	• Message List • See qmiSmsMessageList for more information • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.855.2 Field Documentation

8.855.2.1 qmiSmsMessageList unpack_sms_SLQSGetSMSList_t::messageList[255]

8.855.2.2 uint32_t unpack_sms_SLQSGetSMSList_t::messageListSize

8.855.2.3 swi_uint256_t unpack_sms_SLQSGetSMSList_t::ParamPresenceMask

8.856 unpack_sms_SLQSGetTransLayerInfo_t Struct Reference

Data Fields

- sms_getTransLayerInfo * pGetTransLayerInfo
- swi_uint256_t ParamPresenceMask

8.856.1 Detailed Description

Structure contain parameters that gives information about the transport layer.

Parameters

pGetTransLayer-Info	• Pointer to structure of getTransLayerInfo – See sms_getTransLayerInfo for more information – pGetTransLayerInfo->pRegInd * Bit to check in ParamPresenceMask - **16** – pGetTransLayerInfo->pTransLayerInfo * Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.856.2 Field Documentation

8.856.2.1 swi_uint256_t unpack_sms_SLQSGetTransLayerInfo_t::ParamPresenceMask

8.856.2.2 sms_getTransLayerInfo* unpack_sms_SLQSGetTransLayerInfo_t::pGetTransLayerInfo

8.857 unpack_sms_SLQSGetTransNWRegInfo_t Struct Reference

Data Fields

- sms_getTransNWRegInfo * pGetTransNWRegInfo
- swi_uint256_t ParamPresenceMask

8.857.1 Detailed Description

Structure containing parameters that provides transport layer network registration info.

Parameters

pGetTransNW-RegInfo	• Pointer to structure of getTransNWRegInfo – See sms_getTransNWRegInfo for more information – Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.857.2 Field Documentation

8.857.2.1 swi_uint256_t unpack_sms_SLQSGetTransNWRegInfo_t::ParamPresenceMask

8.857.2.2 sms_getTransNWRegInfo* unpack_sms_SLQSGetTransNWRegInfo_t::pGetTransNWRegInfo

8.858 unpack_sms_SLQSModifySMSStatus_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.858.1 Detailed Description

This structure contains unpack modify SMS status parameters.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.858.2 Field Documentation

8.858.2.1 swi_uint256_t unpack_sms_SLQSModifySMSStatus_t::ParamPresenceMask

8.859 unpack_sms_SLQSNWRegInfoCallback_ind_t Struct Reference

Data Fields

- uint8_t NWRegStat
- swi_uint256_t ParamPresenceMask

8.859.1 Detailed Description

Contains the parameters passed for indication about transport network registration change by the device.

Parameters

NWRegStat	• provides the transport network registration information • Values: – 0x00 - No Service – 0x01 - In Progress – 0x02 - Failed – 0x03 - Limited Service – 0x04 - Full Service • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

Note

None

8.859.2 Field Documentation

8.859.2.1 uint8_t unpack_sms_SLQSNWRegInfoCallback_ind_t::NWRegStat

8.859.2.2 swi_uint256_t unpack_sms_SLQSNWRegInfoCallback_ind_t::ParamPresenceMask

8.860 unpack_sms_SLQSSendAsyncSMS_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.860.1 Detailed Description

This structure contains unpack SLQSSendAsyncSMS parameter.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.860.2 Field Documentation

8.860.2.1 swi_uint256_t unpack_sms_SLQSSendAsyncSMS_t::ParamPresenceMask

8.861 unpack_sms_SLQSSetIndicationRegister_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.861.1 Detailed Description

This structure contains unpack SLQSSetIndicationRegister parameter.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.861.2 Field Documentation

8.861.2.1 swi_uint256_t unpack_sms_SLQSSetIndicationRegister_t::ParamPresenceMask

8.862 unpack_sms_SLQSSetSmsBroadcastActivation_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.862.1 Detailed Description

This structure contains unpack SLQSSetSmsBroadcastActivation parameter.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.862.2 Field Documentation

8.862.2.1 swi_uint256_t unpack_sms_SLQSSetSmsBroadcastActivation_t::ParamPresenceMask

8.863 unpack_sms_SLQSSetSmsBroadcastConfig_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.863.1 Detailed Description

This structure contains unpack SLQSSetSmsBroadcastConfig parameters.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.863.2 Field Documentation

8.863.2.1 swi_uint256_t unpack_sms_SLQSSetSmsBroadcastConfig_t::ParamPresenceMask

8.864 unpack_sms_SLQSSetSmsStorage_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.864.1 Detailed Description

This structure contains unpack SLQSSetSmsStorage parameter.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.864.2 Field Documentation

8.864.2.1 swi_uint256_t unpack_sms_SLQSSetSmsStorage_t::ParamPresenceMask

8.865 unpack_sms_SLQSSmsGetMaxStorageSize_t Struct Reference

Data Fields

- sms_maxStorageSizeResp * pMaxStorageSizeResp
- swi_uint256_t ParamPresenceMask

8.865.1 Detailed Description

Structure contain parameters that provides the maximum number of messages that can be stored in the specified memory storage. Also it provides the number of slots currently available

Parameters

pMaxStorage-SizeResp	• Response parameters for SmsSLQSGetMaxStorageSize – See sms_maxStorageSizeResp for more information • pMaxStorageSizeResp->maxStorageSize – Bit to check in ParamPresenceMask - **1** • pMaxStorageSizeResp->freeSlots – Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.865.2 Field Documentation

8.865.2.1 swi_uint256_t unpack_sms_SLQSSmsGetMaxStorageSize_t::ParamPresenceMask

8.865.2.2 sms_maxStorageSizeResp* unpack_sms_SLQSSmsGetMaxStorageSize_t::pMaxStorageSizeResp

8.866 unpack_sms_SLQSSmsGetMessageProtocol_t Struct Reference

Data Fields

- sms_msgProtocolResp * pMessageProtocol
- swi_uint256_t ParamPresenceMask

8.866.1 Detailed Description

Structure contain Parameters that get the message protocol currently in use for the WMS client.

Parameters

pMessage-Protocol	• Pointer to smsMsgprotocolResp – See sms_msgProtocolResp for more information • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.866.2 Field Documentation

8.866.2.1 swi_uint256_t unpack_sms_SLQSSmsGetMessageProtocol_t::ParamPresenceMask

8.866.2.2 sms_msgProtocolResp* unpack_sms_SLQSSmsGetMessageProtocol_t::pMessageProtocol

8.867 unpack_sms_SLQSSmsSetRoutes_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.867.1 Detailed Description

This structure contains unpack SLQSSmsSetRoutes parameter.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.867.2 Field Documentation

8.867.2.1 swi_uint256_t unpack_sms_SLQSSmsSetRoutes_t::ParamPresenceMask

8.868 unpack_sms_SLQSSwiGetSMSStorage_t Struct Reference

Data Fields

- uint32_t * pSmsStorage
- swi_uint256_t ParamPresenceMask

8.868.1 Detailed Description

Structure contain Parameters that return current SMS configuration that is applied to all incoming and outgoing messages.

Parameters

pSmsStorage	• Values: – 0x01 - device's permanent memory – 0x02 - UICC • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.868.2 Field Documentation

8.868.2.1 swi_uint256_t unpack_sms_SLQSSwiGetSMSStorage_t::ParamPresenceMask

8.868.2.2 uint32_t* unpack_sms_SLQSSwiGetSMSStorage_t::pSmsStorage

8.869 unpack_sms_SLQSTransLayerInfoCallback_ind_t Struct Reference

Data Fields

- uint8_t regInd
- sms_transLayerInfo * pTransLayerInfo
- swi_uint256_t ParamPresenceMask

8.869.1 Detailed Description

Contains the parameters passed for the indication about change in transport layer information

Parameters

regInd	• Indicates whether the transport layer is registered or not • Values: – 0x00 - Transport layer is not registered – 0x01 - Transport layer is registered • Bit to check in ParamPresenceMask - **1**

pTransLayerInfo	• Optional parameter • See sms_transLayerInfo for more information • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

Note

None

8.869.2 Field Documentation

8.869.2.1 swi_uint256_t unpack_sms_SLQSTransLayerInfoCallback_ind_t::ParamPresenceMask

8.869.2.2 sms_transLayerInfo* unpack_sms_SLQSTransLayerInfoCallback_ind_t::pTransLayerInfo

8.869.2.3 uint8_t unpack_sms_SLQSTransLayerInfoCallback_ind_t::regInd

8.870 unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t Struct Reference

Data Fields

- uint16_t sendStatus
- uint16_t messageID
- uint16_t causeCode
- uint8_t errorClass
- uint16_t RPCause
- uint8_t TPCause
- uint8_t msgDelFailureType
- uint8_t msgDelFailureCause
- uint8_t alphaIDLen
- uint8_t * pAlphaID
- uint32_t userData
- swi_uint256_t ParamPresenceMask

8.870.1 Detailed Description

This structure contains SMS parameters for indication of RAW ASYNC SEND

Parameters

sendStatus	• Send Status • Values: – QMI_ERR_NONE – No error in the request – QMI_ERR_CAUSE_CODE - SMS cause code – QMI_ERR_MESSAGE_DELIVERY_FAILURE - Message could not be delivered – QMI_ERR_NO_MEMORY - Device could not allocate memory to formulate a response • Bit to check in ParamPresenceMask - **1**

messageID	• Unique ID assigned by WMS for non-retry messages. • Bit to check in ParamPresenceMask - **16**
causeCode	• WMS cause code • Bit to check in ParamPresenceMask - **17**
errorClass	• Error Class • Values: – 0x00 - ERROR_CLASS_TEMPORARY – 0x01 - ERROR_CLASS_PERMANENT • Bit to check in ParamPresenceMask - **18**
RPCause	• GW RP cause • Bit to check in ParamPresenceMask - **19**
TPCause	• GW TP Cause • Bit to check in ParamPresenceMask - **19**
msgDelFailure-Type	• Message delivery failure type • Values: – 0x00 - WMS_MESSAGE_DELIVERY_FAILURE_TEMPORARY – 0x01 - WMS_MESSAGE_DELIVERY_FAILURE_PERMANENT • Bit to check in ParamPresenceMask - **20**
msgDelFailure-Cause	• Message delivery failure cause • Values: – 0x00 - WMS_MESSAGE_BLOCKED_DUE_TO_CALL_CONTROL • Bit to check in ParamPresenceMask - **21**
alphaIDLen	• Number of sets of the pAlphaID • Bit to check in ParamPresenceMask - **22**
pAlphaID	• Alpha ID • Bit to check in ParamPresenceMask - **22**
userData	• Identifies the request associated with this indication. • Bit to check in ParamPresenceMask - **23**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.870.2 Field Documentation

8.870.2.1 uint8_t unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::alphaIDLen

8.870.2.2 uint16_t unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::causeCode

8.870.2.3 uint8_t unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::errorClass

8.870.2.4 uint16_t unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::messageID

8.870.2.5 uint8_t unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::msgDelFailureCause

8.870.2.6 uint8_t unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::msgDelFailureType

8.870.2.7 uint8_t* unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::pAlphaID

8.870.2.8 swi_uint256_t unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::ParamPresenceMask

8.870.2.9 uint16_t unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::RPCause

8.870.2.10 uint16_t unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::sendStatus

8.870.2.11 uint8_t unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::TPCause

8.870.2.12 uint32_t unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t::userData

8.871 unpack_sms_SLQSWmsMemoryFullCallBack_ind_t Struct Reference

Data Fields

- uint8_t storageType
- uint8_t messageMode
- swi_uint256_t ParamPresenceMask

8.871.1 Detailed Description

This structure contains unpack SMS memory full callback indication.

Parameters

storageType	• SMS message storage type – 0 - UIM - Invalid in case of CDMA device that does not require SIM – 1 - NV • Bit to check in ParamPresenceMask - **1**
messageMode	• 0x00 - CDMA, LTE (if network type is CDMA) • 0x01 - GW, LTE (if network type is UMTS) • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.871.2 Field Documentation

8.871.2.1 uint8_t unpack_sms_SLQSWmsMemoryFullCallBack_ind_t::messageMode

8.871.2.2 swi_uint256_t unpack_sms_SLQSWmsMemoryFullCallBack_ind_t::ParamPresenceMask

8.871.2.3 uint8_t unpack_sms_SLQSWmsMemoryFullCallBack_ind_t::storageType

8.872 unpack_sms_SLQSWmsMessageWaitingCallBack_ind_t Struct Reference

Data Fields

- uint8_t numInstances
- sms_messageWaitingInfoContent msgWaitInfo [0xFF]
- swi_uint256_t ParamPresenceMask

8.872.1 Detailed Description

This structure holds information related to message waiting information indication

Parameters

numInstances	• Number of sets of the elements in structure sms_messageWaitingInfoContent • Bit to check in ParamPresenceMask - **1**
msgWaitInfo	• Pointer to structure of sms_messageWaitingInfoContent. – See sms_messageWaitingInfoContent for more information. • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.872.2 Field Documentation

8.872.2.1 sms_messageWaitingInfoContent unpack_sms_SLQSWmsMessageWaitingCallBack_ind_t::msgWaitInfo[0xFF]

8.872.2.2 uint8_t unpack_sms_SLQSWmsMessageWaitingCallBack_ind_t::numInstances

8.872.2.3 swi_uint256_t unpack_sms_SLQSWmsMessageWaitingCallBack_ind_t::ParamPresenceMask

8.873 unpack_swiaudio_SLQSGetM2MAudioProfile_t Struct Reference

Data Fields

- uint8_t Profile
- uint8_t EarMute
- uint8_t MicMute
- uint8_t Generator
- uint8_t Volume
- uint8_t CwtMute

- swi_uint256_t ParamPresenceMask

8.873.1 Detailed Description

This structure contains the SLQSGetM2MAudioProfile unpack parameters.

Parameters

Profile	• Audio Profile – 0-5 • Bit to check in ParamPresenceMask - **1**
EarMute	• Ear Mute – 0 - Mute – 1 - Unmute • Bit to check in ParamPresenceMask - **2**
MicMute	• MIC Mute – 0 - Mute – 1 - Unmute • Bit to check in ParamPresenceMask - **3**
Generator	• Generator – 0 - Voice • Bit to check in ParamPresenceMask - **4**
Volume	• RX volume level – 0-5 • Bit to check in ParamPresenceMask - **5**
CwtMute	• Call waiting tone Mute – 0 - Mute – 1 - Unmute • Bit to check in ParamPresenceMask - **6**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.873.2 Field Documentation

8.873.2.1 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::CwtMute

8.873.2.2 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::EarMute

8.873.2.3 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::Generator

8.873.2.4 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::MicMute

8.873.2.5 swi_uint256_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::ParamPresenceMask

8.873.2.6 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::Profile

8.873.2.7 uint8_t unpack_swiaudio_SLQSGetM2MAudioProfile_t::Volume

8.874 unpack_swiaudio_SLQSGetM2MAudioVolume_t Struct Reference

Data Fields

- uint8_t Level
- swi_uint256_t ParamPresenceMask

8.874.1 Detailed Description

This structure contains the SLQSGetM2MAudioVolume unpack parameters.

Parameters

Level	• The RX Volume Level – 0-5 • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.874.2 Field Documentation

8.874.2.1 uint8_t unpack_swiaudio_SLQSGetM2MAudioVolume_t::Level

8.874.2.2 swi_uint256_t unpack_swiaudio_SLQSGetM2MAudioVolume_t::ParamPresenceMask

8.875 unpack_swiaudio_SLQSGetM2MAVMute_t Struct Reference

Data Fields

- uint8_t EarMute
- uint8_t MicMute
- uint8_t CwtMute
- swi_uint256_t ParamPresenceMask

8.875.1 Detailed Description

This structure contains the SLQSGetM2MAVMute unpack parameters.

Parameters

pEarMute	• Ear Mute – 0-Mute – 1-UnMute • Bit to check in ParamPresenceMask - **1**
pMicMute	• Mic Mute – 0-Mute – 1-unmute • Bit to check in ParamPresenceMask - **2**
CwtMute	• Waiting tone Mute – 0-5 • Bit to check in ParamPresenceMask - **3**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.875.2 Field Documentation

8.875.2.1 uint8_t unpack_swiaudio_SLQSGetM2MAVMute_t::CwtMute

8.875.2.2 uint8_t unpack_swiaudio_SLQSGetM2MAVMute_t::EarMute

8.875.2.3 uint8_t unpack_swiaudio_SLQSGetM2MAVMute_t::MicMute

8.875.2.4 swi_uint256_t unpack_swiaudio_SLQSGetM2MAVMute_t::ParamPresenceMask

8.876 unpack_swiaudio_SLQSGetM2MSpkrGain_t Struct Reference

Data Fields

- uint16_t Value
- swi_uint256_t ParamPresenceMask

8.876.1 Detailed Description

This structure contains the SLQSGetM2MSpkrGain unpack parameters.

Parameters

Value	• RX speakerphone gain – 0x0 - 0x7fff • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.876.2 Field Documentation

8.876.2.1 swi_uint256_t unpack_swiaudio_SLQSGetM2MSpkrGain_t::ParamPresenceMask

8.876.2.2 uint16_t unpack_swiaudio_SLQSGetM2MSpkrGain_t::Value

8.877 unpack_swiavms_SLQSAVMSEventReportInd_t Struct Reference

Data Fields

- UnpackSwiAvmsEventReportBinaryUpdateSessionInfo * pBinaryUpdateSessionInfo
- UnpackSwiAvmsEventReportConfig * pConfig
- UnpackSwiAvmsEventReportNotification * pNotification
- UnpackSwiAvmsEventReportPackageID * pPackageID
- UnpackSwiAvmsEventReportConnectionRequest * pConnectionRequest
- UnpackSwiAvmsEventReportWAMSParamChange * pWAMSParaChanged
- UnpackSwiAvmsEventReportRegStatus * pRegStatus
- UnpackSwiAvmsEventReportDataSessionStatus * pDataSessionStatus
- UnpackSwiAvmsEventReportSessionType * pSessionType
- UnpackSwiAvmsEventReportHTTPStatus * pHTTPStatus
- uint32_t resultcode
- swi_uint256_t ParamPresenceMask

8.877.1 Detailed Description

Structure that contains the session type response for AVMS event report indication command

Parameters

pBinaryUpdateSessionInfo[OUT]	• See UnpackSwiAvmsEventReportBinaryUpdateSessionInfo for more information • Bit to check in ParamPresenceMask - **16**
pConfig[OUT]	• See UnpackSwiAvmsEventReportConfig for more information • Bit to check in ParamPresenceMask - **17**
pNotification[OUT]	• See UnpackSwiAvmsEventReportNotification for more information • Bit to check in ParamPresenceMask - **18**
pPackageID[OUT]	• See UnpackSwiAvmsEventReportPackageID for more information • Bit to check in ParamPresenceMask - **21**
pConnectionRequest[OUT]	• See UnpackSwiAvmsEventReportConnectionRequest for more information • Bit to check in ParamPresenceMask - **19**
pWAMSParaChanged[OUT]	• See UnpackSwiAvmsEventReportWAMSParamChange for more information • Bit to check in ParamPresenceMask - **20**

pRegStatus[OUT]	• See UnpackSwiAvmsEventReportRegStatus for more information • Bit to check in ParamPresenceMask - **22**
pDataSessionStatus[OUT]	• See UnpackSwiAvmsEventReportDataSessionStatus for more information • Bit to check in ParamPresenceMask - **23**
pSessionType[OUT]	• See UnpackSwiAvmsEventReportSessionType for more information • Bit to check in ParamPresenceMask - **24**
pHTTPStatus[OUT]	• See UnpackSwiAvmsEventReportHTTPStatus for more information • Bit to check in ParamPresenceMask - **25**
resultcode	- Tlv Result Code.

8.877.2 Field Documentation

8.877.2.1 swi_uint256_t unpack_swiavms_SLQSAVMSEventReportInd_t::ParamPresenceMask

8.877.2.2 UnpackSwiAvmsEventReportBinaryUpdateSessionInfo* unpack_swiavms_SLQSAVMSEventReportInd_t::pBinaryUpdateSessionInfo

8.877.2.3 UnpackSwiAvmsEventReportConfig* unpack_swiavms_SLQSAVMSEventReportInd_t::pConfig

8.877.2.4 UnpackSwiAvmsEventReportConnectionRequest* unpack_swiavms_SLQSAVMSEventReportInd_t::pConnectionRequest

8.877.2.5 UnpackSwiAvmsEventReportDataSessionStatus* unpack_swiavms_SLQSAVMSEventReportInd_t::pDataSessionStatus

8.877.2.6 UnpackSwiAvmsEventReportHTTPStatus* unpack_swiavms_SLQSAVMSEventReportInd_t::pHTTPStatus

8.877.2.7 UnpackSwiAvmsEventReportNotification* unpack_swiavms_SLQSAVMSEventReportInd_t::pNotification

8.877.2.8 UnpackSwiAvmsEventReportPackageID* unpack_swiavms_SLQSAVMSEventReportInd_t::pPackageID

8.877.2.9 UnpackSwiAvmsEventReportRegStatus* unpack_swiavms_SLQSAVMSEventReportInd_t::pRegStatus

8.877.2.10 UnpackSwiAvmsEventReportSessionType* unpack_swiavms_SLQSAVMSEventReportInd_t::pSessionType

8.877.2.11 UnpackSwiAvmsEventReportWAMSParamChange* unpack_swiavms_SLQSAVMSEventReportInd_t::pWAMSParaChanged

8.877.2.12 uint32_t unpack_swiavms_SLQSAVMSEventReportInd_t::resultcode

8.878 unpack_swiavms_SLQSAVMSGetSettings_t Struct Reference

Data Fields

- uint32_t OMADMEnabled

- uint8_t AutoConnect
- uint8_t AutoReboot
- uint8_t FwPromptdownload
- uint8_t FwPromptUpdate
- uint8_t FwAutoSDM
- uint32_t * pPollingTimer
- PackSwiAVMSSettingsConnectionRetryTimers * pConnectionRetryTimers
- PackSwiAVMSSettingsAPNInfo * pAPNInfo
- uint8_t * pNotificationStore
- PackSwiAVMSSettingsPeriodsInfo * pPeroidsInfo
- uint32_t resultcode
- swi_uint256_t ParamPresenceMask

8.878.1 Detailed Description

Structure that contains the session type response for AVMS Set Settings command

Parameters

OMADMEnabled	- OMA DM Enabled. • 0 - Disabled. • 1 - Enabled.

- Bit to check in ParamPresenceMask - **1**

Parameters

AutoConnect	- Auto Connect. • 0 - Disabled. • 1 - Enabled.

- Bit to check in ParamPresenceMask - **6**

Parameters

AutoReboot	- Auto Reboot. • 0 - Disabled. • 1 - Enabled.

- Bit to check in ParamPresenceMask - **21**

Parameters

Fw-Autodownload	- Firmware auto download. • 0 - Disabled. • 1 - Enabled. – Bit to check in ParamPresenceMask - **3**
FwAutoUpdate	- Firmware auto update. • 0 - Disabled. • 1 - Enabled.

- Bit to check in ParamPresenceMask - **4**

Parameters

FwAutoSDM	- OMA Automatic UI Alert Response. • 0 - Disabled. • 1 - Enabled.

- Bit to check in ParamPresenceMask - **5**

Parameters

pPollingTimer	- Polling timer to connect to AVMS server. • 0-525600 (min) • 0:disabled

- Bit to check in ParamPresenceMask - **16**

Parameters

pConnection-RetryTimers	- Connection Retry timers. • See PackSwiAVMSSettingsConnectionRetryTimers for more information. • Bit to check in ParamPresenceMask - **17**
pAPNInfo	- APN Information. • See PackSwiAVMSSettingsAPNInfo for more information. • Bit to check in ParamPresenceMask - **18**
pNotification-Store	- Notification Storing When Disabled or Offline. • 0 - Disabled. • 1 - Enabled.

- Bit to check in ParamPresenceMask - **19**

Parameters

pPeroidsInfo	- Min and Max Period of an Observation. • See PackSwiAVMSSettingsPeriodsInfo for more information. • Bit to check in ParamPresenceMask - **20**
resultcode	- Tlv Result Code.

8.878.2 Field Documentation

8.878.2.1 uint8_t unpack_swiavms_SLQSAVMSGetSettings_t::AutoConnect

8.878.2.2 uint8_t unpack_swiavms_SLQSAVMSGetSettings_t::AutoReboot

8.878.2.3 uint8_t unpack_swiavms_SLQSAVMSGetSettings_t::FwAutoSDM

8.878.2.4 uint8_t unpack_swiavms_SLQSAVMSGetSettings_t::FwPromptdownload

8.878.2.5 uint8_t unpack_swiavms_SLQSAVMSGetSettings_t::FwPromptUpdate

8.878.2.6 uint32_t unpack_swiavms_SLQSAVMSGetSettings_t::OMADMEnabled

8.878.2.7 PackSwiAVMSSettingsAPNInfo* unpack_swiavms_SLQSAVMSGetSettings_t::pAPNInfo

8.878.2.8 swi_uint256_t unpack_swiavms_SLQSAVMSGetSettings_t::ParamPresenceMask

8.878.2.9 PackSwiAVMSSettingsConnectionRetryTimers* unpack_swiavms_SLQSAVMSGetSettings_t::pConnection-RetryTimers

8.878.2.10 uint8_t* unpack_swiavms_SLQSAVMSGetSettings_t::pNotificationStore

8.878.2.11 PackSwiAVMSSettingsPeriodsInfo* unpack_swiavms_SLQSAVMSGetSettings_t::pPeroidsInfo

8.878.2.12 uint32_t* unpack_swiavms_SLQSAVMSGetSettings_t::pPollingTimer

8.878.2.13 uint32_t unpack_swiavms_SLQSAVMSGetSettings_t::resultcode

8.879 unpack_swiavms_SLQSAVMSGetSettings_v2_t Struct Reference

Data Fields

- uint32_t OMADMEnabled
- uint8_t AutoConnect
- uint8_t FwPromptdownload
- uint8_t FwPromptUpdate
- uint8_t FwAutoSDM
- uint32_t * pPollingTimer
- PackSwiAVMSSettingsConnectionRetryTimers * pConnectionRetryTimers
- PackSwiAVMSSettingsAPNInfo * pAPNInfo
- uint8_t * pNotificationStore
- PackSwiAVMSSettingsPeriodsInfo * pPeroidsInfo
- uint8_t * pAutoReboot
- uint32_t resultcode
- swi_uint256_t ParamPresenceMask

8.879.1 Detailed Description

Structure that contains the sresponse for AVMS Get Settings command It maps with SLQSAVMSSetSettings_v2 (For AVC2 service)

Parameters

OMADMEnabled	- OMA DM Enabeld. • 0 - Disabled. • 1 - Enabled.

- Bit to check in ParamPresenceMask - **1**

Parameters

AutoConnect	- Auto Connect. • 0 - Disabeld. • 1 - Enabeld.

- Bit to check in ParamPresenceMask - **6**

Parameters

Fw-Autodownload	- Firmware auto downalod. • 0 - Disabeld. • 1 - Enabeld. – Bit to check in ParamPresenceMask - **3**
FwAutoUpdate	- Firmware auto update. • 0 - Disabeld. • 1 - Enabeld.

- Bit to check in ParamPresenceMask - **4**

Parameters

FwAutoSDM	- OMA Automatic UI Alert Response. • 0 - Disabeld. • 1 - Enabeld.

- Bit to check in ParamPresenceMask - **5**

Parameters

pPollingTimer[OPTIONAL]	- Polling timer to connect to AVMS server. • 0-525600 (min) • 0:disabled – Bit to check in ParamPresenceMask - **16**
pConnectionRetryTimers[OPTIONAL]	- Connection Retry timers. • See PackSwiAVMSSettingsConnectionRetryTimers for more information. • Bit to check in ParamPresenceMask - **17**
pAPNInfo[OPTIONAL]	- APN Information. • See PackSwiAVMSSettingsAPNInfo for more information. • Bit to check in ParamPresenceMask - **18**
pNotificationStore[OPTIONAL]	- Notification Storing When Disabled or Offline. • 0 - Disabled. • 1 - Enabeld. – Bit to check in ParamPresenceMask - **19**

pPeroidsInfo[OPTIONAL]	- Min and Max Period of an Observation. • See PackSwiAVMSSettingsPeriodsInfo for more information. • Bit to check in ParamPresenceMask - **20**
pAutoReboot[OPTIONAL]	- Auto Reboot. • 0 - Disabeld. • 1 - Enabeld. – Bit to check in ParamPresenceMask - **21**
resultcode	- Tlv Result Code.

8.879.2 Field Documentation

8.879.2.1 uint8_t unpack_swiavms_SLQSAVMSGetSettings_v2_t::AutoConnect

8.879.2.2 uint8_t unpack_swiavms_SLQSAVMSGetSettings_v2_t::FwAutoSDM

8.879.2.3 uint8_t unpack_swiavms_SLQSAVMSGetSettings_v2_t::FwPromptdownload

8.879.2.4 uint8_t unpack_swiavms_SLQSAVMSGetSettings_v2_t::FwPromptUpdate

8.879.2.5 uint32_t unpack_swiavms_SLQSAVMSGetSettings_v2_t::OMADMEnabled

8.879.2.6 PackSwiAVMSSettingsAPNInfo* unpack_swiavms_SLQSAVMSGetSettings_v2_t::pAPNInfo

8.879.2.7 swi_uint256_t unpack_swiavms_SLQSAVMSGetSettings_v2_t::ParamPresenceMask

8.879.2.8 uint8_t* unpack_swiavms_SLQSAVMSGetSettings_v2_t::pAutoReboot

8.879.2.9 PackSwiAVMSSettingsConnectionRetryTimers* unpack_swiavms_SLQSAVMSGetSettings_v2_t::pConnectionRetryTimers

8.879.2.10 uint8_t* unpack_swiavms_SLQSAVMSGetSettings_v2_t::pNotificationStore

8.879.2.11 PackSwiAVMSSettingsPeriodsInfo* unpack_swiavms_SLQSAVMSGetSettings_v2_t::pPeroidsInfo

8.879.2.12 uint32_t* unpack_swiavms_SLQSAVMSGetSettings_v2_t::pPollingTimer

8.879.2.13 uint32_t unpack_swiavms_SLQSAVMSGetSettings_v2_t::resultcode

8.880 unpack_swiavms_SLQSAVMSSendSelection_t Struct Reference

Data Fields

- uint32_t resultcode
- swi_uint256_t ParamPresenceMask

8.880.1 Detailed Description

Structure that contains the session type response for AVMS Selection command

Parameters

resultcode	- Tlv Result Code. • Bit to check in ParamPresenceMask - **2**

8.880.2 Field Documentation

8.880.2.1 swi_uint256_t unpack_swiavms_SLQSAVMSSendSelection_t::ParamPresenceMask

8.880.2.2 uint32_t unpack_swiavms_SLQSAVMSSendSelection_t::resultcode

8.881 unpack_swiavms_SLQSAVMSSessionGetInfo_t Struct Reference

Data Fields

- UnpackSwiAvmsEventReportBinaryUpdateSessionInfo * pBinaryUpdateSessionInfo
- UnpackSwiAvmsEventReportConfig * pConfig
- UnpackSwiAvmsEventReportNotification * pNotification
- UnpackSwiAvmsEventReportPackageID * pPackageID
- uint32_t resultcode
- swi_uint256_t ParamPresenceMask

8.881.1 Detailed Description

Structure that contains the session type response for AVMS get session info command

Parameters

pBinaryUpdate-SessionInfo[OU-T]	• See UnpackSwiAvmsEventReportBinaryUpdateSessionInfo for more information • Bit to check in ParamPresenceMask - **16**
pConfig[OUT]	• See UnpackSwiAvmsEventReportConfig for more information • Bit to check in ParamPresenceMask - **17**
pNotification[O-UT]	• See UnpackSwiAvmsEventReportNotification for more information • Bit to check in ParamPresenceMask - **18**
pPackageID[OU-T]	• See UnpackSwiAvmsEventReportPackageID for more information • Bit to check in ParamPresenceMask - **19**
resultcode	- Tlv Result Code.

8.881.2 Field Documentation

8.881.2.1 swi_uint256_t unpack_swiavms_SLQSAVMSSessionGetInfo_t::ParamPresenceMask

8.881.2.2 UnpackSwiAvmsEventReportBinaryUpdateSessionInfo* unpack_swiavms_SLQSAVMSSessionGetInfo_t::pBinaryUpdateSessionInfo

8.881.2.3 UnpackSwiAvmsEventReportConfig* unpack_swiavms_SLQSAVMSSessionGetInfo_t::pConfig

8.881.2.4 UnpackSwiAvmsEventReportNotification* unpack_swiavms_SLQSAVMSSessionGetInfo_t::pNotification

8.881.2.5 UnpackSwiAvmsEventReportPackageID* unpack_swiavms_SLQSAVMSSessionGetInfo_t::pPackageID

8.881.2.6 uint32_t unpack_swiavms_SLQSAVMSSessionGetInfo_t::resultcode

8.882 unpack_swiavms_SLQSAvmsSetEventReport_t Struct Reference

Data Fields

- uint32_t resultcode
- swi_uint256_t ParamPresenceMask

8.882.1 Detailed Description

Structure that contains the session type response for AVMS set event report command

Parameters

resultcode	- Tlv Result Code. • Bit to check in ParamPresenceMask - **2**

8.882.2 Field Documentation

8.882.2.1 swi_uint256_t unpack_swiavms_SLQSAvmsSetEventReport_t::ParamPresenceMask

8.882.2.2 uint32_t unpack_swiavms_SLQSAvmsSetEventReport_t::resultcode

8.883 unpack_swiavms_SLQSAVMSSetSettings_t Struct Reference

Data Fields

- uint32_t resultcode
- swi_uint256_t ParamPresenceMask

8.883.1 Detailed Description

Structure that contains the session type response for AVMS Set Settings command

Parameters

resultcode	- Tlv Result Code. • Bit to check in ParamPresenceMask - **2**

8.883.2 Field Documentation

8.883.2.1 swi_uint256_t unpack_swiavms_SLQSAVMSSetSettings_t::ParamPresenceMask

8.883.2.2 uint32_t unpack_swiavms_SLQSAVMSSetSettings_t::resultcode

8.884 unpack_swiavms_SLQSAVMSSetSettings_v2_t Struct Reference

Data Fields

- uint32_t resultcode
- swi_uint256_t ParamPresenceMask

8.884.1 Detailed Description

Structure that contains the session type response for AVMS Set Settings command

Parameters

resultcode	- Tlv Result Code. • Bit to check in ParamPresenceMask - **2**

8.884.2 Field Documentation

8.884.2.1 swi_uint256_t unpack_swiavms_SLQSAVMSSetSettings_v2_t::ParamPresenceMask

8.884.2.2 uint32_t unpack_swiavms_SLQSAVMSSetSettings_v2_t::resultcode

8.885 unpack_swiavms_SLQSAVMSStartSession_t Struct Reference

Data Fields

- uint32_t sessionResponse
- uint32_t resultcode
- swi_uint256_t ParamPresenceMask

8.885.1 Detailed Description

Structure that contains the session type response for AVMS start session command

Parameters

Session-Response	- OMA-DM availability CHECK for the requested item. • 0x00000001 - Available. • 0x00000002 - Not Available. • 0x00000003 - Check Timed Out. • Bit to check in ParamPresenceMask - **1**
resultcode	- Tlv Result Code.

8.885.2 Field Documentation

8.885.2.1 swi_uint256_t unpack_swiavms_SLQSAVMSStartSession_t::ParamPresenceMask

8.885.2.2 uint32_t unpack_swiavms_SLQSAVMSStartSession_t::resultcode

8.885.2.3 uint32_t unpack_swiavms_SLQSAVMSStartSession_t::sessionResponse

8.886 unpack_swiavms_SLQSAVMSStopSession_t Struct Reference

Data Fields

- uint32_t resultcode
- swi_uint256_t ParamPresenceMask

8.886.1 Detailed Description

Structure that contains the session type response for AVMS Stop session command

Parameters

resultcode	- Tlv Result Code. • Bit to check in ParamPresenceMask - **2**

8.886.2 Field Documentation

8.886.2.1 swi_uint256_t unpack_swiavms_SLQSAVMSStopSession_t::ParamPresenceMask

8.886.2.2 uint32_t unpack_swiavms_SLQSAVMSStopSession_t::resultcode

8.887 unpack_swidms_SLQSSwiDmsGetMTU_t Struct Reference

Data Fields

- swidms_mtuSize3gppTlv * pMTUSize3gpp
- swidms_hrpdMTUSizeTlv * pHrpdMTUSize
- swidms_ehrpdMTUSizeTlv * pEhrpdMTUSize
- swidms_usbMTUSizeTlv * pUsbMTUSize
- swi_uint256_t ParamPresenceMask

8.887.1 Detailed Description

This structure contains the Get MTU Response parameter.

Parameters

pMTUSize3gpp	[Optional] • See swidms_mtuSize3gppTlv for more information • Bit to check in ParamPresenceMask - **16**
pHrpdMTUSize	[Optional] • See swidms_hrpdMTUSizeTlv for more information • Bit to check in ParamPresenceMask - **17**

pEhrpdMTUSize	[Optional] • See swidms_ehrpdMTUSizeTlv for more information • Bit to check in ParamPresenceMask - **18**
pUsbMTUSize	[Optional] • See swidms_usbMTUSizeTlv for more information • Bit to check in ParamPresenceMask - **19**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.887.2 Field Documentation

8.887.2.1 swi_uint256_t unpack_swidms_SLQSSwiDmsGetMTU_t::ParamPresenceMask

8.887.2.2 swidms_ehrpdMTUSizeTlv* unpack_swidms_SLQSSwiDmsGetMTU_t::pEhrpdMTUSize

8.887.2.3 swidms_hrpdMTUSizeTlv* unpack_swidms_SLQSSwiDmsGetMTU_t::pHrpdMTUSize

8.887.2.4 swidms_mtuSize3gppTlv* unpack_swidms_SLQSSwiDmsGetMTU_t::pMTUSize3gpp

8.887.2.5 swidms_usbMTUSizeTlv* unpack_swidms_SLQSSwiDmsGetMTU_t::pUsbMTUSize

8.888 unpack_swidms_SLQSSwiDmsGetUsbComp_t Struct Reference

Data Fields

- swidms_intfaceCfgTlv * pInterfaceCfg
- swidms_supportedIntBitmaskTlv * pSupportedBitmasks
- swi_uint256_t ParamPresenceMask

8.888.1 Detailed Description

This structure contains the get usb composition response

Parameters

pInterfaceCfg	• See swidms_intfaceCfgTlv for more information • Bit to check in ParamPresenceMask - **1**
pSupported-Bitmasks	[Optional] • See swidms_supportedIntBitmaskTlv for more information • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.888.2 Field Documentation

8.888.2.1 swi_uint256_t unpack_swidms_SLQSSwiDmsGetUsbComp_t::ParamPresenceMask

8.888.2.2 swidms_intfaceCfgTlv* unpack_swidms_SLQSSwiDmsGetUsbComp_t::pInterfaceCfg

8.888.2.3 swidms_supportedIntBitmaskTlv* unpack_swidms_SLQSSwiDmsGetUsbComp_t::pSupportedBitmasks

8.889 unpack_swidms_SLQSSwiDmsGetUsbNetNum_t Struct Reference

Data Fields

- uint8_t usbNetNum
- swi_uint256_t ParamPresenceMask

8.889.1 Detailed Description

This structure contains usb net numbers to get from remote endpoint for QMAP configuration

Parameters

usbNetNum	• value of usb net numbers on the device • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.889.2 Field Documentation

8.889.2.1 swi_uint256_t unpack_swidms_SLQSSwiDmsGetUsbNetNum_t::ParamPresenceMask

8.889.2.2 uint8_t unpack_swidms_SLQSSwiDmsGetUsbNetNum_t::usbNetNum

8.890 unpack_swidms_SLQSSwiDmsSetMTU_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.890.1 Detailed Description

This structure is used to store unpack_swidms_SLQSSwiDmsSetMTU_t parameters.

Parameters

Tlvresult	• unpack Tlv result • Bit to check in ParamPresenceMask - **2**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.890.2 Field Documentation

8.890.2.1 swi_uint256_t unpack_swidms_SLQSSwiDmsSetMTU_t::ParamPresenceMask

8.890.2.2 uint16_t unpack_swidms_SLQSSwiDmsSetMTU_t::Tlvresult

8.891 unpack_swidms_SLQSSwiDmsSetUsbComp_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.891.1 Detailed Description

This structure is used to store unpack_swidms_SLQSSwiDmsSetUsbComp_t parameters.

Parameters

Tlvresult	• unpack Tlv result • Bit to check in ParamPresenceMask - **2**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.891.2 Field Documentation

8.891.2.1 swi_uint256_t unpack_swidms_SLQSSwiDmsSetUsbComp_t::ParamPresenceMask

8.891.2.2 uint16_t unpack_swidms_SLQSSwiDmsSetUsbComp_t::Tlvresult

8.892 unpack_swiloc_SwiLocGetAutoStart_t Struct Reference

Data Fields

- uint8_t function
- int function_reported
- uint8_t fix_type
- int fix_type_reported
- uint8_t max_time
- int max_time_reported
- uint32_t max_dist
- int max_dist_reported
- uint32_t fix_rate
- int fix_rate_reported
- swi_uint256_t ParamPresenceMask

8.892.1 Detailed Description

This structure contains SWI LOC Get Auto Start setting

Parameters

function	• Setting to indicate when modem should start an automatic GNSS fix – 0 - disabled – 1 - At bootup – 2 - When NMEA port is opened • Bit to check in ParamPresenceMask - **16**
function_reported	• 0 - not reported by modem • l - reported by modem
fix_type	• Type of GNSS fix: – 1 - Default Engine mode – 2 - MS-Based – 3 - MS-Assisted – 4 - Standalone • Bit to check in ParamPresenceMask - **17**
fix_type_reported	• 0 - not reported by modem • l - reported by modem
max_time	• Maximum time allowed for the receiver to get a fix in seconds • Valid range: 1-255 • Bit to check in ParamPresenceMask - **18**
max_time_reported	• 0 - not reported by modem • l - reported by modem
max_dist	• Maximum uncertainty of a fix measured by distance in meters • Valid range: 1 - 4294967280 • Bit to check in ParamPresenceMask - **19**
max_dist_reported	• 0 - not reported by modem • l - reported by modem
fix_rate	• Time between fixes in seconds • Valid range: 1–65535 • Bit to check in ParamPresenceMask - **20**
fix_rate_reported	• 0 - not reported by modem • l - reported by modem

8.892.2 Field Documentation

8.892.2.1 uint32_t unpack_swiloc_SwiLocGetAutoStart_t::fix_rate

8.892.2.2 int unpack_swiloc_SwiLocGetAutoStart_t::fix_rate_reported

8.892.2.3 uint8_t unpack_swiloc_SwiLocGetAutoStart_t::fix_type

8.892.2.4 int unpack_swiloc_SwiLocGetAutoStart_t::fix_type_reported

8.892.2.5 uint8_t unpack_swiloc_SwiLocGetAutoStart_t::function

8.892.2.6 int unpack_swiloc_SwiLocGetAutoStart_t::function_reported

8.892.2.7 uint32_t unpack_swiloc_SwiLocGetAutoStart_t::max_dist

8.892.2.8 int unpack_swiloc_SwiLocGetAutoStart_t::max_dist_reported

8.892.2.9 uint8_t unpack_swiloc_SwiLocGetAutoStart_t::max_time

8.892.2.10 int unpack_swiloc_SwiLocGetAutoStart_t::max_time_reported

8.892.2.11 swi_uint256_t unpack_swiloc_SwiLocGetAutoStart_t::ParamPresenceMask

8.893 unpack_swioma_SLQSOMADMAlertCallback_ind_t Struct Reference

Data Fields

- uint32_t eventType
- unpack_omaDmFotaTlv_t SessionInfoFota
- unpack_omaDmConfigTlv_t SessionInfoConfig
- unpack_omaDmNotificationsTlv_t SessionInfoNotification
- swi_uint256_t ParamPresenceMask

8.893.1 Detailed Description

Structure that contains OMA indication information based on eventType Strucutres for which the event is not valid will have values set to 0

Parameters

eventType	• 0x00 - SWIOMA-DM FOTA • 0x01 - SWIOMA-DM Config • 0x02 - SWIOMA-DM Notification • 0xff - indication missing event information.
SessionInfo-Fota[OUT]	• See unpack_omaDmFotaTlv_t for more information • Bit to check in ParamPresenceMask - **16**
SessionInfo-Config[OUT]	• See unpack_omaDmConfigTlv_t for more information • Bit to check in ParamPresenceMask - **17**

SessionInfo-Notification[OUT]	• See unpack_omaDmNotificationsTlv_t for more information • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.893.2 Field Documentation

8.893.2.1 uint32_t unpack_swioma_SLQSOMADMAlertCallback_ind_t::eventType

8.893.2.2 swi_uint256_t unpack_swioma_SLQSOMADMAlertCallback_ind_t::ParamPresenceMask

8.893.2.3 unpack_omaDmConfigTlv_t unpack_swioma_SLQSOMADMAlertCallback_ind_t::SessionInfoConfig

8.893.2.4 unpack_omaDmFotaTlv_t unpack_swioma_SLQSOMADMAlertCallback_ind_t::SessionInfoFota

8.893.2.5 unpack_omaDmNotificationsTlv_t unpack_swioma_SLQSOMADMAlertCallback_ind_t::SessionInfoNotification

8.894 unpack_swioma_SLQSOMADMGetSessionInfo_t Struct Reference

Data Fields

- uint8_t Status
- uint16_t UpdateCompleteStatus
- uint8_t Severity
- uint16_t SourceLength
- uint8_t Source [255]
- uint16_t PkgNameLength
- uint8_t PkgName [255]
- uint16_t PkgDescLength
- uint8_t PkgDescription [255]
- uint16_t DateLength
- uint8_t Date [255]
- uint16_t TimeLength
- uint8_t Time [255]
- uint8_t SessionType
- uint8_t SessionState
- uint16_t RetryCount
- swi_uint256_t ParamPresenceMask

8.894.1 Detailed Description

Structure that contains the session type for OMA get session info unpack command Also used as input parameter to specify the size of variable parameters. (ref. notes)

Parameters

Status	• 1 Byte parameter indicating status – 0x01 - No Firmware available – 0x02 - Query Firmware Download – 0x03 - Firmware Downloading – 0x04 - Firmware Downloaded – 0x05 - Query Firmware Update – 0x06 - Firmware Updating – 0x07 - Firmware Updated • Bit to check in ParamPresenceMask - **16**
Update-CompleteStatus	• 2 byte parameter indicating Update Complete Status – See qaGobiApiTableSwiOMADMUpdateCompleteStatus.h Update Complete Status • Bit to check in ParamPresenceMask - **16**
Severity	• 1 byte parameter indicating severity – 0x01 - Mandatory – 0x02 - Optional • Bit to check in ParamPresenceMask - **16**
SourceLength	• 2 byte parameter indicating Length of Vendor Name String in Bytes. • Bit to check in ParamPresenceMask - **16**
Source	• Variable length parameter indicating Vendor Name in ASCII • See LITEQMI_MAX_SWIOMA_STR_LEN for more information • Bit to check in ParamPresenceMask - **16**
PkgNameLength	• 2 byte parameter indicating Length of Package Name String in Bytes. • Bit to check in ParamPresenceMask - **16**
PkgName	• Variable length parameter indicating Package Name in ASCII • See LITEQMI_MAX_SWIOMA_STR_LEN for more information • Bit to check in ParamPresenceMask - **16**
PkgDescLength	• 2 byte parameter indicating Length of Package Description String in Bytes. • Bit to check in ParamPresenceMask - **16**
PkgDescription	• Variable length parameter indicating Package Description in ASCII • See LITEQMI_MAX_SWIOMA_STR_LEN for more information • Bit to check in ParamPresenceMask - **16**

DateLength	• 2 byte parameter indicating Length of Package Description String in Bytes. • Bit to check in ParamPresenceMask - **16**
Date	• Variable length parameter indicating Package Description in ASCII • See LITEQMI_MAX_SWIOMA_STR_LEN for more information • Bit to check in ParamPresenceMask - **16**
TimeLength	• 2 byte parameter indicating Length of Time String in Bytes. • Bit to check in ParamPresenceMask - **16**
Time	• Variable length parameter indicating Time String in ASCII • See LITEQMI_MAX_SWIOMA_STR_LEN for more information • Bit to check in ParamPresenceMask - **16**
SessionType	• 1 byte parameter reflects the last session started for Sprint – 0x00 - No session since boot – 0x01 - Sprint CI-DC Session – 0x02 - Sprint CI-PRL Session – 0x03 - Sprint CI-FUMO Session – 0x04 - Sprint HFA-DC Session – 0x05 - Sprint HFA-PRL Session – 0x06 - Sprint HFA-FUMO Session – 0x07 - Sprint NI Session • Bit to check in ParamPresenceMask - **16**
SessionState	• 1 byte parameter indicating session state – 0x01 - idle – 0x02 - active – 0x03 - pending • Bit to check in ParamPresenceMask - **16**
RetryCount	• 1 byte parameter indicating retries left count – valid values 0 to 6 • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.894.2 Field Documentation

8.894.2.1 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::Date[255]

8.894.2.2 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::DateLength

8.894.2.3 swi_uint256_t unpack_swioma_SLQSOMADMGetSessionInfo_t::ParamPresenceMask

8.894.2.4 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::PkgDescLength

8.894.2.5 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::PkgDescription[255]

8.894.2.6 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::PkgName[255]

8.894.2.7 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::PkgNameLength

8.894.2.8 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::RetryCount

8.894.2.9 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::SessionState

8.894.2.10 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::SessionType

8.894.2.11 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::Severity

8.894.2.12 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::Source[255]

8.894.2.13 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::SourceLength

8.894.2.14 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::Status

8.894.2.15 uint8_t unpack_swioma_SLQSOMADMGetSessionInfo_t::Time[255]

8.894.2.16 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::TimeLength

8.894.2.17 uint16_t unpack_swioma_SLQSOMADMGetSessionInfo_t::UpdateCompleteStatus

8.895 unpack_swioma_SLQSOMADMGetSettings_t Struct Reference

Data Fields

- uint32_t OMADMEnabled
- uint8_t FOTAdownload
- uint8_t FOTAUpdate
- uint8_t Autosdm
- uint8_t FwAutoCheck
- swi_uint256_t ParamPresenceMask

8.895.1 Detailed Description

Structure containing the OMA DM settings retrieved from the device

Parameters

OMADMEnabled	[out] • Optional 4 byte parameter indicating OMADM service enabled – 0x00000001 - Client-initiated device configuration – 0x00000002 - Network-initiated device configuration – 0x00000010 - Client-initiated FUMO – 0x00000020 - Network-initiated FUMO • Bit to check in ParamPresenceMask - **16**
FOTAdownload	[out] • Optional 1 Byte parameter indicating support for FOTA Automatic download – 0x00 - Host permission required before downloading – 0x01 - Automatically start downloading, no host permission required – 0x02 - Automatically start downloading, while not roaming – 0x03 - Automatically reject download – 0x04 - Automatically reject download with “Enterprise Reject Policy • Bit to check in ParamPresenceMask - **17**
FOTAUpdate	[out] • Optional 1 byte parameter indicating FOTA Automatic update – 0x00 - User permission required before updating firmware – 0x01 - No user permission required before updating firmware – 0x02 - User permission required, auto update on power up • Bit to check in ParamPresenceMask - **18**
Autosdm	[out] • Optional 1 byte parameter indicating OMA Automatic UI Alert Response – 0x00 - Disabled – 0x01 - Enabled Accept – 0x02 - Enabled Reject • Bit to check in ParamPresenceMask - **19**
FwAutoCheck	[out] • Optional 1 byte parameter indicating OMA Automatic Check for Firmware Update on Power-Up Response – 0x00 - Disabled – 0x01 - Enabled • Bit to check in ParamPresenceMask - **20**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.895.2 Field Documentation

8.895.2.1 uint8_t unpack_swioma_SLQSOMADMGetSettings_t::Autosdm

8.895.2.2 uint8_t unpack_swioma_SLQSOMADMGetSettings_t::FOTAdownload

8.895.2.3 uint8_t unpack_swioma_SLQSOMADMGetSettings_t::FOTAUpdate

8.895.2.4 uint8_t unpack_swioma_SLQSOMADMGetSettings_t::FwAutoCheck

8.895.2.5 uint32_t unpack_swioma_SLQSOMADMGetSettings_t::OMADMEnabled

8.895.2.6 swi_uint256_t unpack_swioma_SLQSOMADMGetSettings_t::ParamPresenceMask

8.896 unpack_swioma_SLQSOMADMStartSession_t Struct Reference

Data Fields

- uint32_t FwAvailability
- swi_uint256_t ParamPresenceMask

8.896.1 Detailed Description

Structure that contains the responses for OMA start session command

Parameters

FwAvailability	[out] • OMA-DM CHECK FW Available • Values – 0x00000001 - FW Available. For CIDC and CIPRL, this value will be returned by the modem. CIDC and CIPRL are asynchronous OMADM sessions. – 0x00000002 - FW Not Available – 0x00000003 - FW Check Timed Out • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.896.2 Field Documentation

8.896.2.1 uint32_t unpack_swioma_SLQSOMADMStartSession_t::FwAvailability

8.896.2.2 swi_uint256_t unpack_swioma_SLQSOMADMStartSession_t::ParamPresenceMask

8.897 unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.897.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

TlvResult	• Unpack Result • Bit to check in ParamPresenceMask - **2**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.897.2 Field Documentation

8.897.2.1 swi_uint256_t unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t::ParamPresenceMask

8.897.2.2 uint16_t unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t::TlvResult

8.898 unpack_tmd_SLQSTmdGetMitigationDevList_t Struct Reference

Data Fields

- uint8_t MitigationDevListLen
- tmd_mitigationDevList MitigationDevList [255]
- uint16_t TlvResult
- swi_uint256_t ParamPresenceMask

8.898.1 Detailed Description

This structure contains mitigation devices list from the remote endpoint

Parameters

MitigationDev-ListLen	• Mitigation Device List Length (Optional) • Number of sets of the following elements – MitigationDevList • Bit to check in ParamPresenceMask - **16**
pMitigationDev-List	• Mitigation Device List (Optional) • See tmd_mitigationDevList for more information. • Bit to check in ParamPresenceMask - **16**
TlvResult	• Unpack Result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.898.2 Field Documentation

8.898.2.1 tmd_mitigationDevList unpack_tmd_SLQSTmdGetMitigationDevList_t::MitigationDevList[255]

8.898.2.2 uint8_t unpack_tmd_SLQSTmdGetMitigationDevList_t::MitigationDevListLen

8.898.2.3 swi_uint256_t unpack_tmd_SLQSTmdGetMitigationDevList_t::ParamPresenceMask

8.898.2.4 uint16_t unpack_tmd_SLQSTmdGetMitigationDevList_t::Tlvresult

8.899 unpack_tmd_SLQSTmdGetMitigationLvl_t Struct Reference

Data Fields

- uint8_t CurrentmitigationLvl
- uint8_t ReqMitigationLvl
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.899.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

CurrentmitigationLvl	• Current thermal mitigation level (Optional) – Bit to check in ParamPresenceMask - **16**
ReqMitigationLvl	• Requested Thermal Mitigation Level (Optional) • The requested thermal mitigation level from the client. The default is zero if the client has not previously set the mitigation level. – Bit to check in ParamPresenceMask - **17**
Tlvresult	• Unpack Result
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.899.2 Field Documentation

8.899.2.1 uint8_t unpack_tmd_SLQSTmdGetMitigationLvl_t::CurrentmitigationLvl

8.899.2.2 swi_uint256_t unpack_tmd_SLQSTmdGetMitigationLvl_t::ParamPresenceMask

8.899.2.3 uint8_t unpack_tmd_SLQSTmdGetMitigationLvl_t::ReqMitigationLvl

8.899.2.4 uint16_t unpack_tmd_SLQSTmdGetMitigationLvl_t::Tlvresult

8.900 unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t Struct Reference

Data Fields

- uint8_t deviceIdLen

- char deviceID [255]
- uint8_t lvl
- swi_uint256_t ParamPresenceMask

8.900.1 Detailed Description

Mitigation Level Report

Parameters

deviceIdLen	• Mitigation Device ID Length • Bit to check in ParamPresenceMask - **1**
deviceID	• Mitigation Device ID • Bit to check in ParamPresenceMask - **1**
lvl	• Current thermal mitigation level • Bit to check in ParamPresenceMask - **2**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.900.2 Field Documentation

8.900.2.1 char unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t::deviceID[255]

8.900.2.2 uint8_t unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t::deviceIdLen

8.900.2.3 uint8_t unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t::lvl

8.900.2.4 swi_uint256_t unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t::ParamPresenceMask

8.901 unpack_tmd_SLQSTmdRegNotMitigationLvl_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.901.1 Detailed Description

This structure contains mitigation devices Level request parameters

Parameters

Tlvresult	• Unpack Result • Bit to check in ParamPresenceMask - **2**

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.901.2 Field Documentation

8.901.2.1 swi_uint256_t unpack_tmd_SLQSTmdRegNotMitigationLvl_t::ParamPresenceMask

8.901.2.2 uint16_t unpack_tmd_SLQSTmdRegNotMitigationLvl_t::Tlvresult

8.902 unpack_uim_ChangePin_t Struct Reference

Data Fields

- uim_remainingRetries * pRemainingRetries
- uim_encryptedPIN1 * pEncryptedPIN1
- uint32_t * pIndicationToken
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.902.1 Detailed Description

This structure contains information of the response parameters associated with a set of PIN related API's.

Parameters

pRemaining-Retries(optional)	• See uim_remainingRetries for more information. • Bit to check in ParamPresenceMask - **16**
pEncryptedPI-N1(optional)	• See uim_encryptedPIN1 for more information. • Bit to check in ParamPresenceMask - **17**
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result is provided in a subsequent indication. • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.902.2 Field Documentation

8.902.2.1 swi_uint256_t unpack_uim_ChangePin_t::ParamPresenceMask

8.902.2.2 uim_encryptedPIN1* unpack_uim_ChangePin_t::pEncryptedPIN1

8.902.2.3 uint32_t* unpack_uim_ChangePin_t::pIndicationToken

8.902.2.4 uim_remainingRetries∗ unpack_uim_ChangePin_t::pRemainingRetries

8.902.2.5 uint16_t unpack_uim_ChangePin_t::Tlvresult

8.903 unpack_uim_GetCardStatus_t Struct Reference

Data Fields

- uim_cardStatus ∗ pCardStatus
- uim_hotSwapStatus ∗ pHotSwapStatus
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.903.1 Detailed Description

This structure contains information of the response parameters associated with a Get Card Status API.

Parameters

pCard-Status(optional)	• See uim_cardStatus for more information. • Bit to check in ParamPresenceMask - **16**
pHotSwap-Status(optional)	• See uim_hotSwapStatus for more information. • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.903.2 Field Documentation

8.903.2.1 swi_uint256_t unpack_uim_GetCardStatus_t::ParamPresenceMask

8.903.2.2 uim_cardStatus∗ unpack_uim_GetCardStatus_t::pCardStatus

8.903.2.3 uim_hotSwapStatus∗ unpack_uim_GetCardStatus_t::pHotSwapStatus

8.903.2.4 uint16_t unpack_uim_GetCardStatus_t::Tlvresult

8.904 unpack_uim_ReadTransparent_t Struct Reference

Data Fields

- uim_cardResult ∗ pCardResult
- uim_readResult ∗ pReadResult
- uint32_t ∗ pIndicationToken
- uint8_t ∗ pEncryptedData
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.904.1 Detailed Description

This structure contains information of the response parameters associated with a Read Transparent API.

Parameters

pCardResult	• See uim_cardResult for more information. • Bit to check in ParamPresenceMask - **16**
pReadResult	• See uim_readResult for more information. • Bit to check in ParamPresenceMask - **17**
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Bit to check in ParamPresenceMask - **18**
pEncrypted-Data(optional)	• Encrypted Data. • Indicates whether the data from the card passed in read_result is encrypted. • Bit to check in ParamPresenceMask - **19**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.904.2 Field Documentation

8.904.2.1 swi_uint256_t unpack_uim_ReadTransparent_t::ParamPresenceMask

8.904.2.2 uim_cardResult* unpack_uim_ReadTransparent_t::pCardResult

8.904.2.3 uint8_t* unpack_uim_ReadTransparent_t::pEncryptedData

8.904.2.4 uint32_t* unpack_uim_ReadTransparent_t::pIndicationToken

8.904.2.5 uim_readResult* unpack_uim_ReadTransparent_t::pReadResult

8.904.2.6 uint16_t unpack_uim_ReadTransparent_t::Tlvresult

8.905 unpack_uim_SetPinProtection_t Struct Reference

Data Fields

- uim_remainingRetries * pRemainingRetries
- uim_encryptedPIN1 * pEncryptedPIN1
- uint32_t * pIndicationToken
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.905.1 Detailed Description

This structure contains information of the response parameters associated with a set of PIN related API's.

Parameters

pRemaining-Retries(optional)	• See uim_remainingRetries for more information. • Bit to check in ParamPresenceMask - **16**
pEncryptedPI-N1(optional)	• See uim_encryptedPIN1 for more information. • Bit to check in ParamPresenceMask - **17**
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result is provided in a subsequent indication. • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.905.2 Field Documentation

8.905.2.1 swi_uint256_t unpack_uim_SetPinProtection_t::ParamPresenceMask

8.905.2.2 uim_encryptedPIN1* unpack_uim_SetPinProtection_t::pEncryptedPIN1

8.905.2.3 uint32_t* unpack_uim_SetPinProtection_t::pIndicationToken

8.905.2.4 uim_remainingRetries* unpack_uim_SetPinProtection_t::pRemainingRetries

8.905.2.5 uint16_t unpack_uim_SetPinProtection_t::Tlvresult

8.906 unpack_uim_SetUimSlotStatusChangeCallback_ind_t Struct Reference

Data Fields

- slots_t slotsstatusChange
- uint8_t bNumberOfPhySlots
- swi_uint256_t ParamPresenceMask

8.906.1 Detailed Description

Structure consist of card status params

Parameters

slotsstatus-Change	• See slot_t for more information • Bit to check in ParamPresenceMask - **16**

bNumberOfPhy-Slots	• Number of Physical Slot(s) • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.906.2 Field Documentation

8.906.2.1 uint8_t unpack_uim_SetUimSlotStatusChangeCallback_ind_t::bNumberOfPhySlots

8.906.2.2 swi_uint256_t unpack_uim_SetUimSlotStatusChangeCallback_ind_t::ParamPresenceMask

8.906.2.3 slots_t unpack_uim_SetUimSlotStatusChangeCallback_ind_t::slotsstatusChange

8.907 unpack_uim_SLQSUIMAuthenticate_t Struct Reference

Data Fields

- uim_cardResult * pCardResult
- uim_authenticateResult * pAuthenticateResult
- uint32_t * pIndicationToken
- swi_uint256_t ParamPresenceMask

8.907.1 Detailed Description

This structure contains information of the response parameters associated with a SLQSUIMAuthenticate.

Parameters

pCard-Result(optional)	• See uim_cardResult for more information. • Bit to check in ParamPresenceMask - **16**
pAuthenticate-Result(optional)	• See uim_authenticateResult for more information. • Bit to check in ParamPresenceMask - **17**
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.907.2 Field Documentation

8.907.2.1 swi_uint256_t unpack_uim_SLQSUIMAuthenticate_t::ParamPresenceMask

8.907.2.2 uim_authenticateResult∗ unpack_uim_SLQSUIMAuthenticate_t::pAuthenticateResult

8.907.2.3 uim_cardResult∗ unpack_uim_SLQSUIMAuthenticate_t::pCardResult

8.907.2.4 uint32_t∗ unpack_uim_SLQSUIMAuthenticate_t::pIndicationToken

8.908 unpack_uim_SLQSUIMDepersonalization_t Struct Reference

Data Fields

- uim_remainingRetries ∗ pRemainingRetries
- swi_uint256_t ParamPresenceMask

8.908.1 Detailed Description

This structure contains information of the response parameters associated with a Depersonalization.

Parameters

pRemaining-Retries(optional)	• See uim_remainingRetries for more information. • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.908.2 Field Documentation

8.908.2.1 swi_uint256_t unpack_uim_SLQSUIMDepersonalization_t::ParamPresenceMask

8.908.2.2 uim_remainingRetries∗ unpack_uim_SLQSUIMDepersonalization_t::pRemainingRetries

8.909 unpack_uim_SLQSUIMEventRegister_t Struct Reference

Data Fields

- uint32_t eventMask
- swi_uint256_t ParamPresenceMask

8.909.1 Detailed Description

This structure contains unpack event register parameter.

Parameters

eventMask	- bit 0 - card status • bit 1 - SAP connection • bit 4 - physical slot status

- Bit to check in ParamPresenceMask - **16**

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.909.2 Field Documentation

8.909.2.1 uint32_t unpack_uim_SLQSUIMEventRegister_t::eventMask

8.909.2.2 swi_uint256_t unpack_uim_SLQSUIMEventRegister_t::ParamPresenceMask

8.910 unpack_uim_SLQSUIMGetConfiguration_t Struct Reference

Data Fields

- uint8_t * pAutoSelection
- uim_personalizationStatus * pPersonalizationStatus
- uint8_t * pHaltSubscription
- swi_uint256_t ParamPresenceMask

8.910.1 Detailed Description

This structure contains information of the response parameters associated with Get Configuration.

Parameters

pAuto-Selection(optional)	• Indicates whether the modem is configured to automatically select the provisioning sessions at powerup. • Valid values – 0 - Automatic provisioning is off – 1 - Automatic provisioning is on • Bit to check in ParamPresenceMask - **16**
p-Personalization-Status(optional)	• See uim_personalizationStatus for more information. • Bit to check in ParamPresenceMask - **17**
pHalt-Subscription(optional)	• Indicates if the modem is configured to publish the subscription after successful initialization. • Valid values – 0 - Modem proceeds with publishing the subscription – 1 - Modem does not publish the subscription • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.910.2 Field Documentation

8.910.2.1 swi_uint256_t unpack_uim_SLQSUIMGetConfiguration_t::ParamPresenceMask

8.910.2.2 uint8_t* unpack_uim_SLQSUIMGetConfiguration_t::pAutoSelection

8.910.2.3 uint8_t* unpack_uim_SLQSUIMGetConfiguration_t::pHaltSubscription

8.910.2.4 uim_personalizationStatus* unpack_uim_SLQSUIMGetConfiguration_t::pPersonalizationStatus

8.911 unpack_uim_SLQSUIMGetFileAttributes_t Struct Reference

Data Fields

- uim_cardResult * pCardResult
- uim_fileAttributes * pFileAttributes
- uint32_t * pIndicationToken
- swi_uint256_t ParamPresenceMask

8.911.1 Detailed Description

This structure contains information of the response parameters associated with a Get File Attributes

Parameters

pCard-Result(optional)	• See uim_cardResult for more information. • Bit to check in ParamPresenceMask - **16**
pFile-Attributes(optional)	• See uim_fileAttributes for more information. • Bit to check in ParamPresenceMask - **17**
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result must be provided in a subsequent indication. • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.911.2 Field Documentation

8.911.2.1 swi_uint256_t unpack_uim_SLQSUIMGetFileAttributes_t::ParamPresenceMask

8.911.2.2 uim_cardResult* unpack_uim_SLQSUIMGetFileAttributes_t::pCardResult

8.911.2.3 uim_fileAttributes* unpack_uim_SLQSUIMGetFileAttributes_t::pFileAttributes

8.911.2.4 uint32_t* unpack_uim_SLQSUIMGetFileAttributes_t::pIndicationToken

8.912 unpack_uim_SLQSUIMGetSlotsStatus_t Struct Reference

Data Fields

- uint8_t * pNumberOfPhySlot
- slots_t * pUimSlotsStatus
- swi_uint256_t ParamPresenceMask

8.912.1 Detailed Description

This structure contains information of the response parameters associated with a Get Slots Status API.

Parameters

pNumberOfPhySlot	• Number of sets of the Slot Status. • Bit to check in ParamPresenceMask - **16**
pUimSlotsStatus	• Slots Status See slots_t for more information.. • Bit to check in ParamPresenceMask - **16**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.912.2 Field Documentation

8.912.2.1 swi_uint256_t unpack_uim_SLQSUIMGetSlotsStatus_t::ParamPresenceMask

8.912.2.2 uint8_t* unpack_uim_SLQSUIMGetSlotsStatus_t::pNumberOfPhySlot

8.912.2.3 slots_t* unpack_uim_SLQSUIMGetSlotsStatus_t::pUimSlotsStatus

8.913 unpack_uim_SLQSUIMRefreshCallback_Ind_t Struct Reference

Data Fields

- uint8_t TlvPresent
- uim_refreshevent refreshEvent
- swi_uint256_t ParamPresenceMask

8.913.1 Detailed Description

This structure hold parameters about UIM refresh event indication.

Parameters

TlvPresent	• value is 1 if refresh event TLV is present in indication, otherwise 0
refreshEvent[OPTIONAL]	• see uim_refreshevent • Bit to check in ParamPresenceMask - **16**

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.913.2 Field Documentation

8.913.2.1 swi_uint256_t unpack_uim_SLQSUIMRefreshCallback_Ind_t::ParamPresenceMask

8.913.2.2 uim_refreshevent unpack_uim_SLQSUIMRefreshCallback_Ind_t::refreshEvent

8.913.2.3 uint8_t unpack_uim_SLQSUIMRefreshCallback_Ind_t::TlvPresent

8.914 unpack_uim_SLQSUIMRefreshGetLastEvent_t Struct Reference

Data Fields

- uim_refreshevent * pRefreshEvent
- swi_uint256_t ParamPresenceMask

8.914.1 Detailed Description

This structure contains information of the response parameters associated with a Refresh Get Last Event.

Parameters

refreshEvent(-Optional)	• See uim_refreshevent for more information. • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.914.2 Field Documentation

8.914.2.1 swi_uint256_t unpack_uim_SLQSUIMRefreshGetLastEvent_t::ParamPresenceMask

8.914.2.2 uim_refreshevent* unpack_uim_SLQSUIMRefreshGetLastEvent_t::pRefreshEvent

8.915 unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t Struct Reference

Data Fields

- uim_cardStatus * pCardStatus
- swi_uint256_t ParamPresenceMask

8.915.1 Detailed Description

This structure contains information about Status change callback.

Parameters

pCardStatus	Card Status • See uim_cardStatus for more information. • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.915.2 Field Documentation

8.915.2.1 swi_uint256_t unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t::ParamPresenceMask

8.915.2.2 uim_cardStatus* unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t::pCardStatus

8.916 unpack_uim_UnblockPin_t Struct Reference

Data Fields

- uim_remainingRetries * pRemainingRetries
- uim_encryptedPIN1 * pEncryptedPIN1
- uint32_t * pIndicationToken
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.916.1 Detailed Description

This structure contains information of the response parameters associated with a set of PIN related API's.

Parameters

pRemaining-Retries(optional)	• See uim_remainingRetries for more information. • Bit to check in ParamPresenceMask - **16**
pEncryptedPI-N1(optional)	• See uim_encryptedPIN1 for more information. • Bit to check in ParamPresenceMask - **17**
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result is provided in a subsequent indication. • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.916.2 Field Documentation

8.916.2.1 swi_uint256_t unpack_uim_UnblockPin_t::ParamPresenceMask

8.916.2.2 uim_encryptedPIN1∗ unpack_uim_UnblockPin_t::pEncryptedPIN1

8.916.2.3 uint32_t∗ unpack_uim_UnblockPin_t::pIndicationToken

8.916.2.4 uim_remainingRetries∗ unpack_uim_UnblockPin_t::pRemainingRetries

8.916.2.5 uint16_t unpack_uim_UnblockPin_t::TlvresultTlvresult

8.917 unpack_uim_VerifyPin_t Struct Reference

Data Fields

- uim_remainingRetries ∗ pRemainingRetries
- uim_encryptedPIN1 ∗ pEncryptedPIN1
- uint32_t ∗ pIndicationToken
- uint16_t TlvresultTlvresult
- swi_uint256_t ParamPresenceMask

8.917.1 Detailed Description

This structure contains information of the response parameters associated with a set of PIN related API's.

Parameters

pRemaining-Retries(optional)	• See uim_remainingRetries for more information. • Bit to check in ParamPresenceMask - **16**
pEncryptedPI-N1(optional)	• See uim_encryptedPIN1 for more information. • Bit to check in ParamPresenceMask - **17**
pIndication-Token(optional)	• Response in Indication. • When this TLV is present, it indicates that the result is provided in a subsequent indication. • Bit to check in ParamPresenceMask - **18**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.917.2 Field Documentation

8.917.2.1 swi_uint256_t unpack_uim_VerifyPin_t::ParamPresenceMask

8.917.2.2 uim_encryptedPIN1∗ unpack_uim_VerifyPin_t::pEncryptedPIN1

8.917.2.3 uint32_t∗ unpack_uim_VerifyPin_t::pIndicationToken

8.917.2.4 uim_remainingRetries∗ unpack_uim_VerifyPin_t::pRemainingRetries

8.917.2.5 uint16_t unpack_uim_VerifyPin_t::TlvresultTlvresult

8.918 unpack_voice_allCallStatusCallback_ind_t Struct Reference

Data Fields

- voice_arrCallInfo arrCallInfomation
- voice_arrRemotePartyNum * pArrRemotePartyNum
- voice_arrRemotePartyName * pArrRemotePartyName
- voice_arrAlertingType * pArrAlertingType
- voice_arrSvcOption * pArrSvcOption
- voice_arrCallEndReason * pArrCallEndReason
- voice_arrAlphaID * pArrAlphaID
- voice_arrConnectPartyNum * pArrConnectPartyNum
- voice_arrDiagInfo * pArrDiagInfo
- voice_arrCalledPartyNum * pArrCalledPartyNum
- voice_arrRedirPartyNum * pArrRedirPartyNum
- voice_arrAlertingPattern * pArrAlertingPattern
- swi_uint256_t ParamPresenceMask

8.918.1 Detailed Description

This structure contains information about the indication parameters for all the calls originating or terminating from a particular device.

Parameters

arrCallInfo(mandatory)	• See voice_arrCallInfo for more information. • Bit to check in ParamPresenceMask - **1**
pArrRemotePartyNum(optional)	• See voice_arrRemotePartyNum for more information. • Bit to check in ParamPresenceMask - **16**
pArrRemotePartyName(optional)	• See voice_arrRemotePartyName for more information. • Bit to check in ParamPresenceMask - **17**
pArrAlertingType(optional)	• See voice_arrAlertingType for more information. • Bit to check in ParamPresenceMask - **18**
pArrSvcOption(optional)	• See voice_arrSvcOption for more information. • Bit to check in ParamPresenceMask - **19**
pArrCallEndReason(optional)	• See voice_arrCallEndReason for more information. • Bit to check in ParamPresenceMask - **20**
pArrAlphaID(optional)	• See voice_arrAlphaID for more information. • Bit to check in ParamPresenceMask - **21**

pArrConnect-Party-Num(optional)	• See voice_arrConnectPartyNum for more information. • Bit to check in ParamPresenceMask - **22**
pArrDiag-Info(optional)	• See voice_arrDiagInfo for more information. • Bit to check in ParamPresenceMask - **23**
pArrCalledParty-Num(optional)	• See voice_arrCalledPartyNum for more information. • Bit to check in ParamPresenceMask - **24**
pArrRedirParty-Num(optional)	• See voice_arrRedirPartyNum for more information. • Bit to check in ParamPresenceMask - **25**
pArrAlerting-Pattern(optional)	• See voice_arrAlertingPattern for more information. • Bit to check in ParamPresenceMask - **26**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.918.2 Field Documentation

8.918.2.1 voice_arrCallInfo unpack_voice_allCallStatusCallback_ind_t::arrCallInfomation

8.918.2.2 swi_uint256_t unpack_voice_allCallStatusCallback_ind_t::ParamPresenceMask

8.918.2.3 voice_arrAlertingPattern* unpack_voice_allCallStatusCallback_ind_t::pArrAlertingPattern

8.918.2.4 voice_arrAlertingType* unpack_voice_allCallStatusCallback_ind_t::pArrAlertingType

8.918.2.5 voice_arrAlphaID* unpack_voice_allCallStatusCallback_ind_t::pArrAlphaID

8.918.2.6 voice_arrCalledPartyNum* unpack_voice_allCallStatusCallback_ind_t::pArrCalledPartyNum

8.918.2.7 voice_arrCallEndReason* unpack_voice_allCallStatusCallback_ind_t::pArrCallEndReason

8.918.2.8 voice_arrConnectPartyNum* unpack_voice_allCallStatusCallback_ind_t::pArrConnectPartyNum

8.918.2.9 voice_arrDiagInfo* unpack_voice_allCallStatusCallback_ind_t::pArrDiagInfo

8.918.2.10 voice_arrRedirPartyNum* unpack_voice_allCallStatusCallback_ind_t::pArrRedirPartyNum

8.918.2.11 voice_arrRemotePartyName* unpack_voice_allCallStatusCallback_ind_t::pArrRemotePartyName

8.918.2.12 voice_arrRemotePartyNum* unpack_voice_allCallStatusCallback_ind_t::pArrRemotePartyNum

8.918.2.13 voice_arrSvcOption* unpack_voice_allCallStatusCallback_ind_t::pArrSvcOption

8.919 unpack_voice_DTMFEventCallback_ind_t Struct Reference

Data Fields

- voice_DTMFInfo DTMFInformation
- uint8_t * pOnLength
- uint8_t * pOffLength
- swi_uint256_t ParamPresenceMask

8.919.1 Detailed Description

This structure contains the parameters passed for DTMF event indication by the device.

Parameters

DTMFInformation(mandatory)	See voice_DTMFInfo for more information. • Bit to check in ParamPresenceMask - **1**
pOnLength(optional)	• DTMF Pulse Width – 0x00 - DTMF_ONLENGTH_95MS - 95 ms – 0x01 - DTMF_ONLENGTH_150MS - 150 ms – 0x02 - DTMF_ONLENGTH_200MS - 200 ms – 0x03 - DTMF_ONLENGTH_250MS - 250 ms – 0x04 - DTMF_ONLENGTH_300MS - 300 ms – 0x05 - DTMF_ONLENGTH_350MS - 350 ms – 0x06 - DTMF_ONLENGTH_SMS - SMS Tx special pulse width • Bit to check in ParamPresenceMask - **16**
pOffLength(optional)	• DTMF Interdigit Interval – 0x00 - DTMF_OFFLENGTH_60MS - 60 ms – 0x01 - DTMF_OFFLENGTH_100MS - 100 ms – 0x02 - DTMF_OFFLENGTH_150MS - 150 ms – 0x03 - DTMF_OFFLENGTH_200MS - 200 ms • Bit to check in ParamPresenceMask - **17**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

Note

None

8.919.2 Field Documentation

8.919.2.1 voice_DTMFInfo unpack_voice_DTMFEventCallback_ind_t::DTMFInformation

8.919.2.2 swi_uint256_t unpack_voice_DTMFEventCallback_ind_t::ParamPresenceMask

8.919.2.3 uint8_t* unpack_voice_DTMFEventCallback_ind_t::pOffLength

8.919.2.4 uint8_t* unpack_voice_DTMFEventCallback_ind_t::pOnLength

8.920 unpack_voice_OTASPStatusCallback_ind_t Struct Reference

Data Fields

- uint8_t callID
- uint8_t OTASPStatus
- swi_uint256_t ParamPresenceMask

8.920.1 Detailed Description

This structure consist of OTASP or OTAPA event params

Parameters

callID	• Call identifier for the call. • Bit to check in ParamPresenceMask - **1**
OTASPStatus	• OTASP status for the OTASP call. Values: – 0x00 - OTASP_STATUS_SPL_UNLOCKED.SPL unlocked; only for user-initiated OTASP – 0x01 - OTASP_STATUS_SPRC_RETRIES_EXCEEDED. SPC retries exceeded; only for user-initiated OTASP – 0x02 - OTASP_STATUS_AKEY_EXCHANGED.A-key exchanged; only for user-initiated O-TASP – 0x03 - OTASP_STATUS_SSD_UPDATED. SSD updated; for both user-initiated OTASP and network-initiated OTASP (OTAPA) – 0x04 - OTASP_STATUS_NAM_DOWNLOADED - NAM downloaded; only for user-initiated OTASP – 0x05 - OTASP_STATUS_MDN_DOWNLOADED - MDN downloaded; only for user-initiated OTASP – 0x06 - OTASP_STATUS_IMSI_DOWNLOADED - IMSI downloaded; only for user-initiated OTASP – 0x07 - OTASP_STATUS_PRL_DOWNLOADED - PRL downloaded; only for user-initiated OTASP – 0x08 - OTASP_STATUS_COMMITTED - Commit successful; only for user-initiated OTASP – 0x09 - OTASP_STATUS_OTAPA_STARTED - OTAPA started; only for network-initiated OTASP(OTAPA) – 0x0A - OTASP_STATUS_OTAPA_STOPPED - OTAPA stopped; only for network-initiated OTASP(OTAPA) – 0x0B - OTASP_STATUS_OTAPA_ABORTED - OTAPA aborted; only for network-initiated OTASP(OTAPA) – 0x0C - OTASP_STATUS_OTAPA_COMMITTED - OTAPA committed; only for network-initiated OTASP(OTAPA) • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.920.2 Field Documentation

8.920.2.1 uint8_t unpack_voice_OTASPStatusCallback_ind_t::callID

8.920.2.2 uint8_t unpack_voice_OTASPStatusCallback_ind_t::OTASPStatus

8.920.2.3 swi_uint256_t unpack_voice_OTASPStatusCallback_ind_t::ParamPresenceMask

8.921 unpack_voice_SLQSOriginateUSSD_t Struct Reference

Data Fields

- uint16_t * pfailureCause
- voice_alphaIDInfo * pAlphaIDInfo
- struct voice_USSInfo * pUSSDInfo
- uint8_t * pCcResultType
- uint8_t * pCallId
- voice_ccSUPSType * pCCSuppsType
- swi_uint256_t ParamPresenceMask

8.921.1 Detailed Description

This structure contains the parameters of USS response.

Parameters

pfailureCause

- Failure Cause.
- 0 - QMI_FAILURE_CAUSE_OFFLINE - Phone is offline
- 20 - QMI_FAILURE_CAUSE_CDMA_LOCK - Phone is CDMA locked until a power cycle; CDMA only
- 21 - QMI_FAILURE_CAUSE_NO_SRV - Phone has no service
- 22 - QMI_FAILURE_CAUSE_FADE - Call has ended abnormally
- 23 - QMI_FAILURE_CAUSE_INTERCEPT - Received intercept from the base station; originating only; CDMA only
- 24 - QMI_FAILURE_CAUSE_REORDER - Received reorder from the base station; originating only; CDMA only
- 25 - QMI_FAILURE_CAUSE_REL_NORMAL - Received release from the base station; no reason was given
- 26 - QMI_FAILURE_CAUSE_REL_SO_REJ - Received release from the base station; SO reject; CDMA only
- 27 - QMI_FAILURE_CAUSE_INCOM_CALL - Received incoming call from the base station
- 28 - QMI_FAILURE_CAUSE_ALERT_STOP - Received alert stop from the base station; incoming only; CDMA only
- 29 - QMI_FAILURE_CAUSE_CLIENT_END - Client ended the call
- 30 - QMI_FAILURE_CAUSE_ACTIVATION - Received end activation; OTASP call only; CDMA only
- 31 - QMI_FAILURE_CAUSE_MC_ABORT - MC aborted the origination/conversation; CDMA only
- 32 - QMI_FAILURE_CAUSE_MAX_ACCESS_PROBE - Maximum access probes were transmitted; CDMA only
- 33 - QMI_FAILURE_CAUSE_PSIST_N - Persistence test failure; FEATURE_JCDMA only; CDMA only
- 34 - QMI_FAILURE_CAUSE_UIM_NOT_PRESENT - R-UIM is not present
- 35 - QMI_FAILURE_CAUSE_ACC_IN_PROG - Access attempt is already in progress
- 36 - QMI_FAILURE_CAUSE_ACC_FAIL - Access failure for a reason other than the above
- 37 - QMI_FAILURE_CAUSE_RETRY_ORDER - Received retry order; originating only; IS 2000; CDMA only
- 38 - QMI_FAILURE_CAUSE_CCS_NOT_SUPPORTED_BYBS - Concurrent service is not supported by the base station
- 39 - QMI_FAILURE_CAUSE_NO_RESPONSE_FROM_BS - No response was received from the base station
- 40 - QMI_FAILURE_CAUSE_REJECTED_BY_BS - Call was rejected by the base station; CDMA only
- 41 - QMI_FAILURE_CAUSE_INCOMPATIBLE - Concurrent services requested were not compatible; CDMA only
- 42 - QMI_FAILURE_CAUSE_ACCESS_BLOCK - Access is blocked by the base station; CDMA only
- 43 - QMI_FAILURE_CAUSE_ALREADY_IN_TC - Corresponds to CM_CALL_ORIGERR_ALREADY_IN_TC
- 44 - QMI_FAILURE_CAUSE_EMERGENCY_FLASHED - Call is ended because an emergency call was flashed over this call; CDMA only
- 45 - QMI_FAILURE_CAUSE_USER_CALL_ORIGDURING_GPS - Used if CM is ending a GPS call in preference of a user call
- 46 - QMI_FAILURE_CAUSE_USER_CALL_ORIGDURING_SMS - Used if CM is ending an SMS call in preference of a user call
- 47 - QMI_FAILURE_CAUSE_USER_CALL_ORIGDURING_DATA - Used if CM is ending a data call in preference of an emergency call
- 48 - QMI_FAILURE_CAUSE_REDIR_OR_HANDOFF - Call was rejected because of a redirection or handoff
- 49 - QMI_FAILURE_CAUSE_ACCESS_BLOCK_ALL - Access is blocked by the base station for all mobiles; KDDI-specific; CDMA only
- 50 - QMI_FAILURE_CAUSE_OTASP_SPC_ERR - To support OTASP SPC Error indication
- 51 - QMI_FAILURE_CAUSE_IS707B_MAX_ACC - Maximum access probes for an IS-707B

Generated on Fri Mar 8 2019 03:09:27 for Linux/QMISDK-Lite by Doxygen

AlphaIdentifier	• see voice_alphaIDInfo definition • Bit to check in ParamPresenceMask - **17**
pUSSDInfo	• USS Data from Network (See structure voice_USSInfo) • Bit to check in ParamPresenceMask - **18**
pCcResultType	• CC result code • Bit to check in ParamPresenceMask - **19**
pCallId	• Bit to check in ParamPresenceMask - **20** • NULL pointer - Invalid data.
pCCSuppsType	• See structure 'voice_ccSUPSType' definition • Bit to check in ParamPresenceMask - **21**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.921.2 Field Documentation

8.921.2.1 voice_alphaIDInfo* unpack_voice_SLQSOriginateUSSD_t::pAlphaIDInfo

8.921.2.2 swi_uint256_t unpack_voice_SLQSOriginateUSSD_t::ParamPresenceMask

8.921.2.3 uint8_t* unpack_voice_SLQSOriginateUSSD_t::pCallId

8.921.2.4 uint8_t* unpack_voice_SLQSOriginateUSSD_t::pCcResultType

8.921.2.5 voice_ccSUPSType* unpack_voice_SLQSOriginateUSSD_t::pCCSuppsType

8.921.2.6 uint16_t* unpack_voice_SLQSOriginateUSSD_t::pfailureCause

8.921.2.7 struct voice_USSInfo* unpack_voice_SLQSOriginateUSSD_t::pUSSDInfo

8.922 unpack_voice_SLQSVoiceAnswerCall_t Struct Reference

Data Fields

- uint8_t * pCallId
- swi_uint256_t ParamPresenceMask

8.922.1 Detailed Description

Contains the parameters passed for pack voice Answer Call.

Parameters

pCallId	• Unique call identifier for the call that must be answered. • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.922.2 Field Documentation

8.922.2.1 swi_uint256_t unpack_voice_SLQSVoiceAnswerCall_t::ParamPresenceMask

8.922.2.2 uint8_t* unpack_voice_SLQSVoiceAnswerCall_t::pCallId

8.923 unpack_voice_SLQSVoiceBurstDTMF_t Struct Reference

Data Fields

- uint8_t * pCallID
- swi_uint256_t ParamPresenceMask

8.923.1 Detailed Description

This structure contains Voice Burst DTMF Information for unpack.

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. A burst DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.923.2 Field Documentation

8.923.2.1 swi_uint256_t unpack_voice_SLQSVoiceBurstDTMF_t::ParamPresenceMask

8.923.2.2 uint8_t* unpack_voice_SLQSVoiceBurstDTMF_t::pCallID

8.924 unpack_voice_SLQSVoiceDialCall_t Struct Reference

Data Fields

- uint8_t * pCallID
- voice_alphaIDInfo * pAlphaIDInfo

- uint8_t * pCCResultType
- voice_ccSUPSType * pCCSUPSType
- swi_uint256_t ParamPresenceMask

8.924.1 Detailed Description

This structure contains Voice Call Response Parameters

Parameters

pCallID(optional)	• Unique call identifier for the dialed call • Bit to check in ParamPresenceMask - **16**
pAlphaID-Info(optional)	• Pointer to structure of alphaIDInfo – See voice_alphaIDInfo for more information • Bit to check in ParamPresenceMask - **17**
pCCResult-Type(optional)	• Call Control Result Type. – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service • Bit to check in ParamPresenceMask - **18**
pCCSUPS-Type(optional)	• Pointer to structure of ccSUPSType • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • Bit to check in ParamPresenceMask - **19**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.924.2 Field Documentation

8.924.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceDialCall_t::pAlphaIDInfo

8.924.2.2 swi_uint256_t unpack_voice_SLQSVoiceDialCall_t::ParamPresenceMask

8.924.2.3 uint8_t* unpack_voice_SLQSVoiceDialCall_t::pCallID

8.924.2.4 uint8_t* unpack_voice_SLQSVoiceDialCall_t::pCCResultType

8.924.2.5 voice_ccSUPSType* unpack_voice_SLQSVoiceDialCall_t::pCCSUPSType

8.925 unpack_voice_SLQSVoiceEndCall_t Struct Reference

Data Fields

- uint8_t * pCallId

- swi_uint256_t ParamPresenceMask

8.925.1 Detailed Description

This structure contains unpack voice end call parameter.

Parameters

pCallId	• Unique call identifier for the call that must be ended • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.925.2 Field Documentation

8.925.2.1 swi_uint256_t unpack_voice_SLQSVoiceEndCall_t::ParamPresenceMask

8.925.2.2 uint8_t* unpack_voice_SLQSVoiceEndCall_t::pCallId

8.926 unpack_voice_SLQSVoiceGetAllCallInfo_t Struct Reference

Data Fields

- voice_arrCallInfo * pArrCallInfo
- voice_arrRemotePartyNum * pArrRemotePartyNum
- voice_arrRemotePartyName * pArrRemotePartyName
- voice_arrAlertingType * pArrAlertingType
- voice_arrUUSInfo * pArrUUSInfo
- voice_arrSvcOption * pArrSvcOption
- uint8_t * pOTASPStatus
- uint8_t * pVoicePrivacy
- voice_arrCallEndReason * pArrCallEndReason
- voice_arrAlphaID * pArrAlphaID
- voice_arrConnectPartyNum * pArrConnectPartyNum
- voice_arrDiagInfo * pArrDiagInfo
- voice_arrCalledPartyNum * pArrCalledPartyNum
- voice_arrRedirPartyNum * pArrRedirPartyNum
- voice_arrAlertingPattern * pArrAlertingPattern
- swi_uint256_t ParamPresenceMask

8.926.1 Detailed Description

This structure contains information about the response parameters with all the calls originating or terminating from a particular device.

Parameters

pArrCallInfo(optional)	• See voice_arrCallInfo for more information. • Bit to check in ParamPresenceMask - **16**
pArrRemotePartyNum(optional)	• See voice_arrRemotePartyNum for more information. • Bit to check in ParamPresenceMask - **17**
pArrRemotePartyName(optional)	• See voice_arrRemotePartyName for more information. • Bit to check in ParamPresenceMask - **18**
pArrAlertingType(optional)	• See voice_arrAlertingType for more information. • Bit to check in ParamPresenceMask - **19**
pArrUUSInfo(optional)	• See voice_arrUUSInfo for more information. • Bit to check in ParamPresenceMask - **20**
pArrSvcOption(optional)	• See voice_arrSvcOption for more information. • Bit to check in ParamPresenceMask - **21**

pOTASP-Status(optional)	• OTASP status for the OTASP call. • Applicable only for 3GPP2 devices. – 0x00 - OTASP_STATUS_SPL_UNLOCKED - SPL unlocked; only for user-initiated OTASP – 0x01 - OTASP_STATUS_SPRC_RETRIES_EXCEEDED - SPC retries exceeded; only for user-initiated OTASP – 0x02 - OTASP_STATUS_AKEY_EXCHANGED - A-key exchanged; only for user-initiated OTASP – 0x03 - OTASP_STATUS_SSD_UPDATED - SSD updated; for both user-initiated OTASP and network-initiated OTASP (OTAPA) – 0x04 - OTASP_STATUS_NAM_DOWNLOADED - NAM downloaded; only for user-initiated OTASP – 0x05 - OTASP_STATUS_MDN_DOWNLOADED - MDN downloaded; only for user-initiated OTASP – 0x06 - OTASP_STATUS_IMSI_DOWNLOADED - IMSI downloaded; only for user-initiated OTASP – 0x07 - OTASP_STATUS_PRL_DOWNLOADED - PRL downloaded; only for user-initiated OTASP – 0x08 - OTASP_STATUS_COMMITTED - Commit successful; only for user-initiated OTASP – 0x09 - OTASP_STATUS_OTAPA_STARTED - OTAPA started; only for network-initiated OTASP (OTAPA) – 0x0A - OTASP_STATUS_OTAPA_STOPPED - OTAPA stopped; only for network-initiated OTASP (OTAPA) – 0x0B - OTASP_STATUS_OTAPA_ABORTED - OTAPA aborted; only for network-initiated OTASP (OTAPA) – 0x0C - OTASP_STATUS_OTAPA_COMMITTED - OTAPA committed; only for network-initiated OTASP (OTAPA) – 0xFF - Not Available • Bit to check in ParamPresenceMask - **22**
pVoice-Privacy(optional)	• Voice Privacy. • Values. – 0x00 - VOICE_PRIVACY_STANDARD - Standard privacy – 0x01 - VOICE_PRIVACY_ENHANCED - Enhanced privacy – 0xFF - Not Available • Bit to check in ParamPresenceMask - **23**
pArrCallEnd-Reason(optional)	• See voice_arrCallEndReason for more information. • Bit to check in ParamPresenceMask - **24**
pArrAlphaI-D(optional)	• See voice_arrAlphaID for more information. • Bit to check in ParamPresenceMask - **25**
pArrConnect-Party-Num(optional)	• See voice_arrConnectPartyNum for more information. • Bit to check in ParamPresenceMask - **26**

pArrDiag-Info(optional)	• See voice_arrDiagInfo for more information. • Bit to check in ParamPresenceMask - **27**
pArrCalledParty-Num(optional)	• See voice_arrCalledPartyNum for more information. • Bit to check in ParamPresenceMask - **28**
pArrRedirParty-Num(optional)	• See voice_arrRedirPartyNum for more information. • Bit to check in ParamPresenceMask - **29**
pArrAlerting-Pattern(optional)	• See voice_arrAlertingPattern for more information. • Bit to check in ParamPresenceMask - **30**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.926.2 Field Documentation

8.926.2.1 swi_uint256_t unpack_voice_SLQSVoiceGetAllCallInfo_t::ParamPresenceMask

8.926.2.2 voice_arrAlertingPattern* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrAlertingPattern

8.926.2.3 voice_arrAlertingType* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrAlertingType

8.926.2.4 voice_arrAlphaID* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrAlphaID

8.926.2.5 voice_arrCalledPartyNum* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrCalledPartyNum

8.926.2.6 voice_arrCallEndReason* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrCallEndReason

8.926.2.7 voice_arrCallInfo* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrCallInfo

8.926.2.8 voice_arrConnectPartyNum* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrConnectPartyNum

8.926.2.9 voice_arrDiagInfo* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrDiagInfo

8.926.2.10 voice_arrRedirPartyNum* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrRedirPartyNum

8.926.2.11 voice_arrRemotePartyName* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrRemotePartyName

8.926.2.12 voice_arrRemotePartyNum* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrRemotePartyNum

8.926.2.13 voice_arrSvcOption* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrSvcOption

8.926.2.14 voice_arrUUSInfo* unpack_voice_SLQSVoiceGetAllCallInfo_t::pArrUUSInfo

8.926.2.15 uint8_t* unpack_voice_SLQSVoiceGetAllCallInfo_t::pOTASPStatus

8.926.2.16 uint8_t* unpack_voice_SLQSVoiceGetAllCallInfo_t::pVoicePrivacy

8.927 unpack_voice_SLQSVoiceGetCallBarring_t Struct Reference

Data Fields

- uint8_t * pSvcClass
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType
- swi_uint256_t ParamPresenceMask

8.927.1 Detailed Description

This structure contains Voice Get Call Barring Response Parameters

Parameters

pSvcClass	• Service class is a combination (sum) of information class constants (optional) • See qaGobiApiTableSupServiceInfoClasses.h for service classes. • Service Class is set to 0 if call waiting is not active for any of the information classes. • 0xFF,if Not Available • Bit to check in ParamPresenceMask - **16**
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • Bit to check in ParamPresenceMask - **17**
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • Bit to check in ParamPresenceMask - **18**
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • Bit to check in ParamPresenceMask - **19**
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • Bit to check in ParamPresenceMask - **20**

pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • Bit to check in ParamPresenceMask - **21**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.927.2 Field Documentation

8.927.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCallBarring_t::pAlphaIDInfo

8.927.2.2 swi_uint256_t unpack_voice_SLQSVoiceGetCallBarring_t::ParamPresenceMask

8.927.2.3 uint8_t* unpack_voice_SLQSVoiceGetCallBarring_t::pCallID

8.927.2.4 uint8_t* unpack_voice_SLQSVoiceGetCallBarring_t::pCCResType

8.927.2.5 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCallBarring_t::pCCSUPSType

8.927.2.6 uint16_t* unpack_voice_SLQSVoiceGetCallBarring_t::pFailCause

8.927.2.7 uint8_t* unpack_voice_SLQSVoiceGetCallBarring_t::pSvcClass

8.928 unpack_voice_SLQSVoiceGetCallForwardingStatus_t Struct Reference

Data Fields

- voice_getCallFWInfo * pGetCallFWInfo
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType
- voice_getCallFWExtInfo * pGetCallFWExtInfo
- swi_uint256_t ParamPresenceMask

8.928.1 Detailed Description

This structure contains Voice Get Call Forwarding Status Unpack Parameters

Parameters

pGetCallFWInfo	• Pointer to structure of getCallFWInfo (optional) – See voice_getCallFWInfo for more information • Bit to check in ParamPresenceMask - **16**

pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • Bit to check in ParamPresenceMask - **17**
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • Bit to check in ParamPresenceMask - **18**
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • Bit to check in ParamPresenceMask - **19**
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • Bit to check in ParamPresenceMask - **20**
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • Bit to check in ParamPresenceMask - **21**
pGetCallFWExt-Info	• Pointer to structure of getCallFWExtInfo (optional) – See voice_getCallFWExtInfo for more information • Bit to check in ParamPresenceMask - **22**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.928.2 Field Documentation

8.928.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pAlphaIDInfo

8.928.2.2 swi_uint256_t unpack_voice_SLQSVoiceGetCallForwardingStatus_t::ParamPresenceMask

8.928.2.3 uint8_t* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pCallID

8.928.2.4 uint8_t* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pCCResType

8.928.2.5 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pCCSUPSType

8.928.2.6 uint16_t* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pFailCause

8.928.2.7 voice_getCallFWExtInfo* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pGetCallFWExtInfo

8.928.2.8 voice_getCallFWInfo* unpack_voice_SLQSVoiceGetCallForwardingStatus_t::pGetCallFWInfo

8.929 unpack_voice_SLQSVoiceGetCallInfo_t Struct Reference

Data Fields

- voice_callInfo * pCallInfo
- voice_remotePartyNum * pRemotePartyNum
- uint16_t * pSrvOpt
- uint8_t * pVoicePrivacy
- uint8_t * pOTASPStatus
- voice_remotePartyName * pRemotePartyName
- voice_UUSInfo * pUUSInfo
- uint8_t * pAlertType
- voice_alphaIDInfo * pAlphaIDInfo
- voice_connectNumInfo * pConnectNumInfo
- voice_diagInfo * pDiagInfo
- uint32_t * pAlertingPattern
- swi_uint256_t ParamPresenceMask

8.929.1 Detailed Description

This structure contains information of the unpack parameters associated with a call.

Parameters

pCallInfo(optional)	• See voice_callInfo for more information. • Bit to check in ParamPresenceMask - **16**
pRemotePartyNum(optional)	• See voice_remotePartyNum for more information. • Bit to check in ParamPresenceMask - **17**
pSrvOpt	• Service option(optional) • Applicable only for 3GPP2 devices. • See Table8 qaGobiApiTableServiceOptions.h for standard service option number assignments. • Bit to check in ParamPresenceMask - **18**
pVoicePrivacy	• Voice Privacy.(optional) • Applicable only for 3GPP2 devices. • Values. – 0x00 - VOICE_PRIVACY_STANDARD - Standard privacy – 0x01 - VOICE_PRIVACY_ENHANCED - Enhanced privacy – 0xFF - Not Available • Bit to check in ParamPresenceMask - **19**

pOTASPStatus	• OTASP status for the OTASP call.(optional) • Applicable only for 3GPP2 devices. – 0x00 - OTASP_STATUS_SPL_UNLOCKED - SPL unlocked; only for user-initiated OTASP – 0x01 - OTASP_STATUS_SPRC_RETRIES_EXCEEDED - SPC retries exceeded; only for user-initiated OTASP – 0x02 - OTASP_STATUS_AKEY_EXCHANGED - A-key exchanged; only for user-initiated OTASP – 0x03 - OTASP_STATUS_SSD_UPDATED - SSD updated; for both user-initiated OTASP and network-initiated OTASP (OTAPA) – 0x04 - OTASP_STATUS_NAM_DOWNLOADED - NAM downloaded; only for user-initiated OTASP – 0x05 - OTASP_STATUS_MDN_DOWNLOADED - MDN downloaded; only for user-initiated OTASP – 0x06 - OTASP_STATUS_IMSI_DOWNLOADED - IMSI downloaded; only for user-initiated OTASP – 0x07 - OTASP_STATUS_PRL_DOWNLOADED - PRL downloaded; only for user-initiated OTASP – 0x08 - OTASP_STATUS_COMMITTED - Commit successful; only for user-initiated OTASP – 0x09 - OTASP_STATUS_OTAPA_STARTED - OTAPA started; only for network-initiated OTASP (OTAPA) – 0x0A - OTASP_STATUS_OTAPA_STOPPED - OTAPA stopped; only for network-initiated OTASP (OTAPA) – 0x0B - OTASP_STATUS_OTAPA_ABORTED - OTAPA aborted; only for network-initiated OTASP (OTAPA) – 0x0C - OTASP_STATUS_OTAPA_COMMITTED - OTAPA committed; only for network-initiated OTASP (OTAPA) – 0xFF - Not Available • Bit to check in ParamPresenceMask - **20**
pRemoteParty-Name(optional)	• Applicable only for 3GPP devices. • See voice_remotePartyName for more information. • Bit to check in ParamPresenceMask - **21**
pUUS-Info(optional)	• Applicable only for 3GPP devices. • See voice_UUSInfo for more information. • Bit to check in ParamPresenceMask - **22**
pAlert-Type(optional)	• Alerting type. • Applicable only for 3GPP devices. – 0x00 - ALERTING_LOCAL - Local – 0x01 - ALERTING_REMOTE - Remote – 0xFF - Not Available • Bit to check in ParamPresenceMask - **23**

pAlphaID-Info(optional)	• Applicable only for 3GPP devices. • See voice_alphaIDInfo for more information. • Bit to check in ParamPresenceMask - **24**
pConnectNum-Info(optional)	• See voice_connectNumInfo for more information. • Bit to check in ParamPresenceMask - **25**
pDiag-Info(optional)	• See voice_diagInfo for more information. • Bit to check in ParamPresenceMask - **26**
pAlertingPattern	• Alerting pattern.(optional) – 0x00 - QMI_VOICE_ALERTING_PATTERN_1 - Pattern 1 – 0x01 - QMI_VOICE_ALERTING_PATTERN_2 - Pattern 2 – 0x02 - QMI_VOICE_ALERTING_PATTERN_3 - Pattern 3 – 0x04 - QMI_VOICE_ALERTING_PATTERN_5 - Pattern 5 – 0x05 - QMI_VOICE_ALERTING_PATTERN_6 - Pattern 6 – 0x06 - QMI_VOICE_ALERTING_PATTERN_7 - Pattern 7 – 0x07 - QMI_VOICE_ALERTING_PATTERN_8 - Pattern 8 – 0x08 - QMI_VOICE_ALERTING_PATTERN_9 - Pattern 9 – 0xFF - Not Available • Bit to check in ParamPresenceMask - **27**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.929.2 Field Documentation

8.929.2.1 uint32_t* unpack_voice_SLQSVoiceGetCallInfo_t::pAlertingPattern

8.929.2.2 uint8_t* unpack_voice_SLQSVoiceGetCallInfo_t::pAlertType

8.929.2.3 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCallInfo_t::pAlphaIDInfo

8.929.2.4 swi_uint256_t unpack_voice_SLQSVoiceGetCallInfo_t::ParamPresenceMask

8.929.2.5 voice_callInfo* unpack_voice_SLQSVoiceGetCallInfo_t::pCallInfo

8.929.2.6 voice_connectNumInfo* unpack_voice_SLQSVoiceGetCallInfo_t::pConnectNumInfo

8.929.2.7 voice_diagInfo* unpack_voice_SLQSVoiceGetCallInfo_t::pDiagInfo

8.929.2.8 uint8_t* unpack_voice_SLQSVoiceGetCallInfo_t::pOTASPStatus

8.929.2.9 voice_remotePartyName* unpack_voice_SLQSVoiceGetCallInfo_t::pRemotePartyName

8.929.2.10 voice_remotePartyNum* unpack_voice_SLQSVoiceGetCallInfo_t::pRemotePartyNum

8.929.2.11 uint16_t* unpack_voice_SLQSVoiceGetCallInfo_t::pSrvOpt

8.929.2.12 voice_UUSInfo* unpack_voice_SLQSVoiceGetCallInfo_t::pUUSInfo

8.929.2.13 uint8_t* unpack_voice_SLQSVoiceGetCallInfo_t::pVoicePrivacy

8.930 unpack_voice_SLQSVoiceGetCallWaiting_t Struct Reference

Data Fields

- uint8_t * pSvcClass
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType
- swi_uint256_t ParamPresenceMask

8.930.1 Detailed Description

This structure contains Voice Get Call Waiting Unpack Parameters

Parameters

pSvcClass	• Service class is a combination (sum) of information class constants (optional) • See qaGobiApiTableSupServiceInfoClasses.h for service classes. • Service Class is set to 0 if call waiting is not active for any of the information classes. • 0xFF,if Not Available • Bit to check in ParamPresenceMask - **16**
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • Bit to check in ParamPresenceMask - **17**
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • Bit to check in ParamPresenceMask - **18**
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • Bit to check in ParamPresenceMask - **19**

pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • Bit to check in ParamPresenceMask - **20**
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • Bit to check in ParamPresenceMask - **21**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.930.2 Field Documentation

8.930.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCallWaiting_t::pAlphaIDInfo

8.930.2.2 swi_uint256_t unpack_voice_SLQSVoiceGetCallWaiting_t::ParamPresenceMask

8.930.2.3 uint8_t* unpack_voice_SLQSVoiceGetCallWaiting_t::pCallID

8.930.2.4 uint8_t* unpack_voice_SLQSVoiceGetCallWaiting_t::pCCResType

8.930.2.5 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCallWaiting_t::pCCSUPSType

8.930.2.6 uint16_t* unpack_voice_SLQSVoiceGetCallWaiting_t::pFailCause

8.930.2.7 uint8_t* unpack_voice_SLQSVoiceGetCallWaiting_t::pSvcClass

8.931 unpack_voice_SLQSVoiceGetCLIP_t Struct Reference

Data Fields

- voice_CLIPResp * pCLIPResp
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType
- swi_uint256_t ParamPresenceMask

8.931.1 Detailed Description

This structure contains Voice Get Calling Line Identification Presentation(CLIP) Response Parameters

Parameters

pCLIPResp	• Pointer to structure of CLIPResp (optional) – See voice_CLIPResp for more information • Bit to check in ParamPresenceMask - **16**
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • Bit to check in ParamPresenceMask - **17**
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • Bit to check in ParamPresenceMask - **18**
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • Bit to check in ParamPresenceMask - **19**
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • Bit to check in ParamPresenceMask - **20**
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • Bit to check in ParamPresenceMask - **21**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.931.2 Field Documentation

8.931.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCLIP_t::pAlphaIDInfo

8.931.2.2 swi_uint256_t unpack_voice_SLQSVoiceGetCLIP_t::ParamPresenceMask

8.931.2.3 uint8_t* unpack_voice_SLQSVoiceGetCLIP_t::pCallID

8.931.2.4 uint8_t* unpack_voice_SLQSVoiceGetCLIP_t::pCCResType

8.931.2.5 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCLIP_t::pCCSUPSType

8.931.2.6 voice_CLIPResp* unpack_voice_SLQSVoiceGetCLIP_t::pCLIPResp

8.931.2.7 uint16_t* unpack_voice_SLQSVoiceGetCLIP_t::pFailCause

8.932 unpack_voice_SLQSVoiceGetCLIR_t Struct Reference

Data Fields

- voice_CLIRResp * pCLIRResp
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType
- swi_uint256_t ParamPresenceMask

8.932.1 Detailed Description

This structure contains Voice Get Calling Line Identification Restriction (CLIR) Response Parameters

Parameters

pCLIRResp	• Pointer to structure of CLIRResp (optional) – See voice_CLIRResp for more information • Bit to check in ParamPresenceMask - **16**
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • Bit to check in ParamPresenceMask - **17**
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • Bit to check in ParamPresenceMask - **18**
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • Bit to check in ParamPresenceMask - **19**
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • Bit to check in ParamPresenceMask - **20**

pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • Bit to check in ParamPresenceMask - **21**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.932.2 Field Documentation

8.932.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCLIR_t::pAlphaIDInfo

8.932.2.2 swi_uint256_t unpack_voice_SLQSVoiceGetCLIR_t::ParamPresenceMask

8.932.2.3 uint8_t* unpack_voice_SLQSVoiceGetCLIR_t::pCallID

8.932.2.4 uint8_t* unpack_voice_SLQSVoiceGetCLIR_t::pCCResType

8.932.2.5 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCLIR_t::pCCSUPSType

8.932.2.6 voice_CLIRResp* unpack_voice_SLQSVoiceGetCLIR_t::pCLIRResp

8.932.2.7 uint16_t* unpack_voice_SLQSVoiceGetCLIR_t::pFailCause

8.933 unpack_voice_SLQSVoiceGetCNAP_t Struct Reference

Data Fields

- voice_CNAPResp * pCNAPResp
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType
- swi_uint256_t ParamPresenceMask

8.933.1 Detailed Description

This structure contains Voice Get Calling Name Presentation(CNAP) Response Parameters

Parameters

pCNAPResp	• Pointer to structure of CNAPResp (optional) – See voice_CNAPResp for more information • Bit to check in ParamPresenceMask - **16**

pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • Bit to check in ParamPresenceMask - **17**
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • Bit to check in ParamPresenceMask - **18**
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • Bit to check in ParamPresenceMask - **19**
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • Bit to check in ParamPresenceMask - **20**
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • Bit to check in ParamPresenceMask - **21**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.933.2 Field Documentation

8.933.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCNAP_t::pAlphaIDInfo

8.933.2.2 swi_uint256_t unpack_voice_SLQSVoiceGetCNAP_t::ParamPresenceMask

8.933.2.3 uint8_t* unpack_voice_SLQSVoiceGetCNAP_t::pCallID

8.933.2.4 uint8_t* unpack_voice_SLQSVoiceGetCNAP_t::pCCResType

8.933.2.5 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCNAP_t::pCCSUPSType

8.933.2.6 voice_CNAPResp* unpack_voice_SLQSVoiceGetCNAP_t::pCNAPResp

8.933.2.7 uint16_t* unpack_voice_SLQSVoiceGetCNAP_t::pFailCause

8.934 unpack_voice_SLQSVoiceGetCOLP_t Struct Reference

Data Fields

- voice_COLPResp * pCOLPResp
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType
- swi_uint256_t ParamPresenceMask

8.934.1 Detailed Description

This structure contains Voice Get Connected Line Identification Presentation(COLP) Response Parameters

Parameters

pCOLPResp	• Pointer to structure of COLPResp (optional) – See voice_COLPResp for more information • Bit to check in ParamPresenceMask - **16**
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • Bit to check in ParamPresenceMask - **17**
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • Bit to check in ParamPresenceMask - **18**
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • Bit to check in ParamPresenceMask - **19**
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • Bit to check in ParamPresenceMask - **20**
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • Bit to check in ParamPresenceMask - **21**

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.934.2 Field Documentation

8.934.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCOLP_t::pAlphaIDInfo

8.934.2.2 swi_uint256_t unpack_voice_SLQSVoiceGetCOLP_t::ParamPresenceMask

8.934.2.3 uint8_t* unpack_voice_SLQSVoiceGetCOLP_t::pCallID

8.934.2.4 uint8_t* unpack_voice_SLQSVoiceGetCOLP_t::pCCResType

8.934.2.5 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCOLP_t::pCCSUPSType

8.934.2.6 voice_COLPResp* unpack_voice_SLQSVoiceGetCOLP_t::pCOLPResp

8.934.2.7 uint16_t* unpack_voice_SLQSVoiceGetCOLP_t::pFailCause

8.935 unpack_voice_SLQSVoiceGetCOLR_t Struct Reference

Data Fields

- voice_COLRResp * pCOLRResp
- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType
- swi_uint256_t ParamPresenceMask

8.935.1 Detailed Description

This structure contains Voice Get Connected Line Identification Restriction(COLR) Response Parameters

Parameters

pCOLRResp	• Pointer to structure of COLRResp (optional) – See voice_COLRResp for more information • Bit to check in ParamPresenceMask - **16**
pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • Bit to check in ParamPresenceMask - **17**

pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • Bit to check in ParamPresenceMask - **18**
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • Bit to check in ParamPresenceMask - **19**
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • Bit to check in ParamPresenceMask - **20**
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • Bit to check in ParamPresenceMask - **21**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.935.2 Field Documentation

8.935.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceGetCOLR_t::pAlphaIDInfo

8.935.2.2 swi_uint256_t unpack_voice_SLQSVoiceGetCOLR_t::ParamPresenceMask

8.935.2.3 uint8_t* unpack_voice_SLQSVoiceGetCOLR_t::pCallID

8.935.2.4 uint8_t* unpack_voice_SLQSVoiceGetCOLR_t::pCCResType

8.935.2.5 voice_ccSUPSType* unpack_voice_SLQSVoiceGetCOLR_t::pCCSUPSType

8.935.2.6 voice_COLRResp* unpack_voice_SLQSVoiceGetCOLR_t::pCOLRResp

8.935.2.7 uint16_t* unpack_voice_SLQSVoiceGetCOLR_t::pFailCause

8.936 unpack_voice_SLQSVoiceGetConfig_t Struct Reference

Data Fields

- uint8_t * pAutoAnswerStat
- voice_airTimer * pAirTimerCnt
- voice_roamTimer * pRoamTimerCnt

- uint8_t * pCurrTTYMode
- voice_prefVoiceSO * pCurPrefVoiceSO
- voice_curAMRConfig * pCurAMRConfig
- uint8_t * pCurVoicePrivacyPref
- uint8_t * pCurVoiceDomainPref
- swi_uint256_t ParamPresenceMask

8.936.1 Detailed Description

This structure contains Voice Get Configuration Response Parameters.

Parameters

pAutoAnswer-Stat(optional)	• Auto Answer Status • Value returned is read from NV_AUTO_ANSWER_I. – 0x00 - Disabled – 0x01 - Enabled – 0xFF - Not Available • Bit to check in ParamPresenceMask - **16**
pAirTimer-Cnt(optional)	• Air Timer Count • Value returned is read from NV_AIR_CNT_I. • See voice_airTimer for more information • Bit to check in ParamPresenceMask - **17**
pRoamTimer-Cnt(optional)	• Roam Timer Count • Value returned is read from NV_ROAM_CNT_I. • See voice_roamTimer for more information • Bit to check in ParamPresenceMask - **18**
pCurrTTY-Mode(optional)	• Current TTY Mode • Value returned is read from NV_TTY_I. – 0x00 - TTY_MODE_FULL - Full – 0x01 - TTY_MODE_VCO - Voice carry over – 0x02 - TTY_MODE_HCO - Hearing carry over – 0x03 - TTY_MODE_OFF - Off – 0xFF - Not Available • Bit to check in ParamPresenceMask - **19**
pCurPrefVoiceS-O(optional)	• Current Preferred Voice SO • Value returned is read from NV_PREF_VOICE_SO_I. • See voice_prefVoiceSO for more information • Bit to check in ParamPresenceMask - **20**

pCurAMR-Config(optional)	• Current Adaptive Multi-Rate Configuration. • Values returned are read from NV_GSM_ARM_CALL_CONFIG_I and NV_UMTS_AMR_CODEC_PREFERENCE_CONFIG_I. • See voice_curAMRConfig for more information • Bit to check in ParamPresenceMask - **21**
pCurVoice-Privacy-Pref(optional)	• Current Voice Privacy Preference • Value returned is read from NV_VOICE_PRIV_I. – 0x00 - Standard privacy – 0x01 - Enhanced privacy – 0xFF - Not Available • Bit to check in ParamPresenceMask - **22**
pCurVoice-Domain-Pref(optional)	• Current Voice Domain Preference. – 0x00 - Circuit-switched (CS) only – 0x01 - Packet-switched (PS) only – 0x02 - CS is preferred; PS is secondary – 0x03 - PS is preferred; CS is secondary – 0xFF - Not Available • Bit to check in ParamPresenceMask - **23**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.936.2 Field Documentation

8.936.2.1 voice_airTimer* unpack_voice_SLQSVoiceGetConfig_t::pAirTimerCnt

8.936.2.2 swi_uint256_t unpack_voice_SLQSVoiceGetConfig_t::ParamPresenceMask

8.936.2.3 uint8_t* unpack_voice_SLQSVoiceGetConfig_t::pAutoAnswerStat

8.936.2.4 voice_curAMRConfig* unpack_voice_SLQSVoiceGetConfig_t::pCurAMRConfig

8.936.2.5 voice_prefVoiceSO* unpack_voice_SLQSVoiceGetConfig_t::pCurPrefVoiceSO

8.936.2.6 uint8_t* unpack_voice_SLQSVoiceGetConfig_t::pCurrTTYMode

8.936.2.7 uint8_t* unpack_voice_SLQSVoiceGetConfig_t::pCurVoiceDomainPref

8.936.2.8 uint8_t* unpack_voice_SLQSVoiceGetConfig_t::pCurVoicePrivacyPref

8.936.2.9 voice_roamTimer* unpack_voice_SLQSVoiceGetConfig_t::pRoamTimerCnt

8.937 unpack_voice_SLQSVoiceManageCalls_t Struct Reference

Data Fields

- uint16_t * pFailCause
- swi_uint256_t ParamPresenceMask

8.937.1 Detailed Description

This structure contains Failure cause Information. Populated when API Fails.

Parameters

pFailCause	• Supplementary service failure causes (optional, supply NULL if not required). • See Table8 qaGobiApiTableVoiceCallEndReasons.h for supplementary services failure cause – 0xFFFF is the value when the information is not received from device • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.937.2 Field Documentation

8.937.2.1 swi_uint256_t unpack_voice_SLQSVoiceManageCalls_t::ParamPresenceMask

8.937.2.2 uint16_t* unpack_voice_SLQSVoiceManageCalls_t::pFailCause

8.938 unpack_voice_SLQSVoiceSendFlash_t Struct Reference

Data Fields

- uint8_t * pCallID
- swi_uint256_t ParamPresenceMask

8.938.1 Detailed Description

This structure contains the flash information associated with a call.

Parameters

pCallID	• Unique call identifier associated with the current call. • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.938.2 Field Documentation

8.938.2.1 swi_uint256_t unpack_voice_SLQSVoiceSendFlash_t::ParamPresenceMask

8.938.2.2 uint8_t* unpack_voice_SLQSVoiceSendFlash_t::pCallID

8.939 unpack_voice_SLQSVoiceSetCallBarringPassword_t Struct Reference

Data Fields

- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType
- swi_uint256_t ParamPresenceMask

8.939.1 Detailed Description

This structure contains Voice Set Call Barring Password Unpack Parameters

Parameters

pFailCause	• Supplementary services failure cause (optional) • see qaGobiApiTableVoiceCallEndReasons.h for more information. • 0xFFFF,if Not Available • Bit to check in ParamPresenceMask - **16**
pAlphaIDInfo	• Pointer to structure of alphaIDInfo (optional) – See voice_alphaIDInfo for more information • Bit to check in ParamPresenceMask - **17**
pCCResType	• Call Control Result Type (optional) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - Not Available • Bit to check in ParamPresenceMask - **18**
pCallID	• Call ID of the voice call that resulted from call control. (optional) • It is present when pCCResType is present and is Voice. • If zero(0) then invalid. • Bit to check in ParamPresenceMask - **19**
pCCSUPSType	• Supplementary service data that resulted from call control (optional) • Data is present when pCCResultType is present and is other than Voice. – See voice_ccSUPSType for more information • Bit to check in ParamPresenceMask - **20**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.939.2 Field Documentation

8.939.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceSetCallBarringPassword_t::pAlphaIDInfo

8.939.2.2 swi_uint256_t unpack_voice_SLQSVoiceSetCallBarringPassword_t::ParamPresenceMask

8.939.2.3 uint8_t* unpack_voice_SLQSVoiceSetCallBarringPassword_t::pCallID

8.939.2.4 uint8_t* unpack_voice_SLQSVoiceSetCallBarringPassword_t::pCCResType

8.939.2.5 voice_ccSUPSType* unpack_voice_SLQSVoiceSetCallBarringPassword_t::pCCSUPSType

8.939.2.6 uint16_t* unpack_voice_SLQSVoiceSetCallBarringPassword_t::pFailCause

8.940 unpack_voice_SLQSVoiceSetConfig_t Struct Reference

Data Fields

- uint8_t * pAutoAnsStatus
- uint8_t * pAirTimerStatus
- uint8_t * pRoamTimerStatus
- uint8_t * pTTYConfigStatus
- uint8_t * pPrefVoiceSOStatus
- uint8_t * pVoiceDomainPrefStatus
- swi_uint256_t ParamPresenceMask

8.940.1 Detailed Description

This structure contains information about the Set Configuration Response Parameters.

Parameters

pAutoAnsStatus	• Auto Answer Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. • Bit to check in ParamPresenceMask - **16**
pAirTimerStatus	• Air Timer Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. • Bit to check in ParamPresenceMask - **17**

pRoamTimer-Status	• Roam Timer Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. • Bit to check in ParamPresenceMask - **18**
pTTYConfig-Status	• TTY Config Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. • Bit to check in ParamPresenceMask - **19**
pPrefVoiceSO-Status	• Preferred Voice SO Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. • Bit to check in ParamPresenceMask - **20**
pVoiceDomain-PrefStatus	• Voice-Domain Preference Status. (optional) • Values: – 0x00 - Information was written successfully – 0x01 - Information write failed – 0xFF - Not Available. • Bit to check in ParamPresenceMask - **21**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.940.2 Field Documentation

8.940.2.1 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pAirTimerStatus

8.940.2.2 swi_uint256_t unpack_voice_SLQSVoiceSetConfig_t::ParamPresenceMask

8.940.2.3 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pAutoAnsStatus

8.940.2.4 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pPrefVoiceSOStatus

8.940.2.5 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pRoamTimerStatus

8.940.2.6 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pTTYConfigStatus

8.940.2.7 uint8_t* unpack_voice_SLQSVoiceSetConfig_t::pVoiceDomainPrefStatus

8.941 unpack_voice_SLQSVoiceSetSUPSService_t Struct Reference

Data Fields

- uint16_t * pFailCause
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCCResultType
- uint8_t * pCallID
- voice_ccSUPSType * pCCSUPSType
- swi_uint256_t ParamPresenceMask

8.941.1 Detailed Description

This structure contains Supplementary Service response parameters related to different features and their activation, deactivation, registration and erasure (applicable only for 3GPP)

Parameters

pFailCause	• Supplementary service failure causes (optional, supply NULL if not required). – 0xFFFF is the value when the information is not received from device • Bit to check in ParamPresenceMask - **16**
pAlphaIDInfo	• Pointer to structure of alphaIDInfo. The parameter used to pass the alpha (if any) given by the SIM/R-UIM after call control (optional, supply NULL if not required) – See voice_alphaIDInfo for more information • Bit to check in ParamPresenceMask - **17**
pCCResultType	• Call control result types (optional, supply NULL if not required) – 0x00 - CC_RESULT_TYPE_VOICE - Voice – 0x01 - CC_RESULT_TYPE_SUPS - Supplementary service – 0x02 - CC_RESULT_TYPE_USSD - Unstructured supplementary service – 0xFF - if the device does not provide this information • Bit to check in ParamPresenceMask - **19**
pCallID	• Unique call identifier for the dialed call (optional, supply NULL if not required) – 0x00 - if the device does not provide this information • Bit to check in ParamPresenceMask - **18**
pCCSUPSType	• Data is present when pCCResultType is present and is other than Voice. (optional, supply NULL if not required) – See voice_ccSUPSType for more information • Bit to check in ParamPresenceMask - **20**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.941.2 Field Documentation

8.941.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceSetSUPSService_t::pAlphaIDInfo

8.941.2.2 swi_uint256_t unpack_voice_SLQSVoiceSetSUPSService_t::ParamPresenceMask

8.941.2.3 uint8_t* unpack_voice_SLQSVoiceSetSUPSService_t::pCallID

8.941.2.4 uint8_t* unpack_voice_SLQSVoiceSetSUPSService_t::pCCResultType

8.941.2.5 voice_ccSUPSType* unpack_voice_SLQSVoiceSetSUPSService_t::pCCSUPSType

8.941.2.6 uint16_t* unpack_voice_SLQSVoiceSetSUPSService_t::pFailCause

8.942 unpack_voice_SLQSVoiceStartContDTMF_t Struct Reference

Data Fields

- uint8_t * pCallID
- swi_uint256_t ParamPresenceMask

8.942.1 Detailed Description

This structure contains parameters of continuous DTMF

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. Start continuous DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.942.2 Field Documentation

8.942.2.1 swi_uint256_t unpack_voice_SLQSVoiceStartContDTMF_t::ParamPresenceMask

8.942.2.2 uint8_t* unpack_voice_SLQSVoiceStartContDTMF_t::pCallID

8.943 unpack_voice_SLQSVoiceStopContDTMF_t Struct Reference

Data Fields

- uint8_t callID
- swi_uint256_t ParamPresenceMask

8.943.1 Detailed Description

This structure contains parameters of stop continuous DTMF

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. Stop continuous DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.943.2 Field Documentation

8.943.2.1 uint8_t unpack_voice_SLQSVoiceStopContDTMF_t::callID

8.943.2.2 swi_uint256_t unpack_voice_SLQSVoiceStopContDTMF_t::ParamPresenceMask

8.944 unpack_voice_SLQSVoiceSUPSCallback_ind_t Struct Reference

Data Fields

- voice_SUPSInfo SUPSInformation
- uint8_t * pSvcClass
- uint8_t * pReason
- uint8_t * pCallFWNum
- uint8_t * pCallFWTimerVal
- struct voice_USSInfo * pUSSInfo
- uint8_t * pCallID
- voice_alphaIDInfo * pAlphaIDInfo
- uint8_t * pCallBarPasswd
- voice_newPwdData * pNewPwdData
- uint8_t * pDataSrc
- uint16_t * pFailCause
- voice_getCallFWInfo * pCallFwdInfo
- voice_CLIRResp * pCLIRstatus
- voice_CLIPResp * pCLIPstatus
- voice_COLPResp * pCOLPstatus
- voice_COLRResp * pCOLRstatus
- voice_CNAPResp * pCNAPstatus
- swi_uint256_t ParamPresenceMask

8.944.1 Detailed Description

This structure contains the parameters passed for SUPS info indication by the device.

Parameters

SUPSInformation(mandatory)	• See voice_SUPSInfo for more information. • Bit to check in ParamPresenceMask - **1**
pSvcClass(optional)	• Service class is a combination (sum) of information class constants (optional) • See qaGobiApiTableSupServiceInfoClasses.h for service classes. • Bit to check in ParamPresenceMask - **16**
pReason(optional)	• See qaGobiApiTableCallControlReturnReasons.h for return reasons. • Bit to check in ParamPresenceMask - **17**
pCallFWNum(optional)	• Call forwarding number to be registered with the network. • ASCII String, NULL terminated. • Bit to check in ParamPresenceMask - **18**
pCallFWTimerVal(optional)	• Call Forwarding No Reply Timer. – Range: 5 to 30 in steps of 5. • Bit to check in ParamPresenceMask - **19**
pUSSInfo(optional)	• See voice_USSInfo for more information. • Bit to check in ParamPresenceMask - **20**
pCallID(optional)	• Call identifier of the voice call that has been modified to a supplementary service as a result of call control. • Bit to check in ParamPresenceMask - **21**
pAlphaIDInfo(optional)	• See voice_alphaIDInfo for more information. • Bit to check in ParamPresenceMask - **22**
pCallBarPasswd(optional)	• Password is required if call barring is provisioned using a password. – Password consists of 4 ASCII digits. – Range: 0000 to 9999. • This also serves as the old password in the register password scenario. • Bit to check in ParamPresenceMask - **23**
pNewPwdData(optional)	• See voice_newPwdData for more information. • Bit to check in ParamPresenceMask - **24**

pDataSrc(optional)	• Sups Data Source. • Used to distinguish between the supplementary service data sent to the network and the response received from the network. • If absent, the supplementary service data in this indication can be assumed as a request sent to the network. • Bit to check in ParamPresenceMask - **25**
pFailCause(optional)	• Supplementary services failure cause. • See qaGobiApiTableVoiceCallEndReasons.h for more information. • Bit to check in ParamPresenceMask - **26**
pCallFwdInfo(optional)	• See voice_getCallFWInfo for more information. • Bit to check in ParamPresenceMask - **27**
pCLIRstatus(optional)	• See voice_CLIRResp for more information. • Bit to check in ParamPresenceMask - **28**
pCLIPstatus(optional)	• See voice_CLIPResp for more information. • Bit to check in ParamPresenceMask - **29**
pCOLPstatus(optional)	• See voice_COLPResp for more information. • Bit to check in ParamPresenceMask - **30**
pCOLRstatus(optional)	• See voice_COLRResp for more information. • Bit to check in ParamPresenceMask - **31**
pCNAPstatus(optional)	• See voice_CNAPResp for more information. • Bit to check in ParamPresenceMask - **32**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

Note

None

8.944.2 Field Documentation

8.944.2.1 voice_alphaIDInfo* unpack_voice_SLQSVoiceSUPSCallback_ind_t::pAlphaIDInfo

8.944.2.2 swi_uint256_t unpack_voice_SLQSVoiceSUPSCallback_ind_t::ParamPresenceMask

8.944.2.3 uint8_t* unpack_voice_SLQSVoiceSUPSCallback_ind_t::pCallBarPasswd

8.944.2.4 **voice_getCallFWInfo*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pCallFwdInfo

8.944.2.5 **uint8_t*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pCallFWNum

8.944.2.6 **uint8_t*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pCallFWTimerVal

8.944.2.7 **uint8_t*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pCallID

8.944.2.8 **voice_CLIPResp*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pCLIPstatus

8.944.2.9 **voice_CLIRResp*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pCLIRstatus

8.944.2.10 **voice_CNAPResp*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pCNAPstatus

8.944.2.11 **voice_COLPResp*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pCOLPstatus

8.944.2.12 **voice_COLRResp*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pCOLRstatus

8.944.2.13 **uint8_t*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pDataSrc

8.944.2.14 **uint16_t*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pFailCause

8.944.2.15 **voice_newPwdData*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pNewPwdData

8.944.2.16 **uint8_t*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pReason

8.944.2.17 **uint8_t*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pSvcClass

8.944.2.18 struct **voice_USSInfo*** unpack_voice_SLQSVoiceSUPSCallback_ind_t::pUSSInfo

8.944.2.19 **voice_SUPSInfo** unpack_voice_SLQSVoiceSUPSCallback_ind_t::SUPSInformation

8.945 unpack_voice_SUPSNotificationCallback_ind_t Struct Reference

Data Fields

- uint8_t callID
- uint8_t notifType
- uint16_t * pCUGIndex
- voice_ECTNum * pECTNum
- swi_uint256_t ParamPresenceMask

8.945.1 Detailed Description

Contains the parameters passed for SUPS notification indication by the device.

Parameters

callID	• Unique identifier of the call for which the notification is applicable. (mandatory) • Bit to check in ParamPresenceMask - **1**

notifType	• Notification type parameter (mandatory) – 0x01 - NOTIFICATION_TYPE_OUTGOING_CALL_IS_FORWARDED Originated MO call is being forwarded to another user – 0x02 - NOTIFICATION_TYPE_OUTGOING_CALL_IS_WAITING Originated MO call is waiting at the called user – 0x03 - NOTIFICATION_TYPE_OUTGOING_CUG_CALL Outgoing call is a CUG call – 0x04 - NOTIFICATION_TYPE_OUTGOING_CALLS_BARRED Outgoing calls are barred – 0x05 - NOTIFICATION_TYPE_OUTGOING_CALL_IS_DEFLECTED Outgoing call is deflected – 0x06 - NOTIFICATION_TYPE_INCOMING_CUG_CALL Incoming call is a CUG call – 0x07 - NOTIFICATION_TYPE_INCOMING_CALLS_BARRED Incoming calls are barred – 0x08 - NOTIFICATION_TYPE_INCOMING_FORWARDED_CALL Incoming call received is a forwarded call – 0x09 - NOTIFICATION_TYPE_INCOMING_DEFLECTED_CALL Incoming call is a deflected call – 0x0A - NOTIFICATION_TYPE_INCOMING_CALL_IS_FORWARDED Incoming call is forwarded to another user – 0x0B - NOTIFICATION_TYPE_UNCOND_CALL_FORWARD_ACTIVE Unconditional call forwarding is active – 0x0C - NOTIFICATION_TYPE_COND_CALL_FORWARD_ACTIVE Conditional call forwarding is active – 0x0D - NOTIFICATION_TYPE_CLIR_SUPPRESSION_REJECTED CLIR suppression is rejected – 0x0E - NOTIFICATION_TYPE_CALL_IS_ON_HOLD Call is put on hold at the remote party – 0x0F - NOTIFICATION_TYPE_CALL_IS_RETRIEVED Call is retrieved at the remote party from the hold state – 0x10 - NOTIFICATION_TYPE_CALL_IS_IN_MPTY Call is in a conference – 0x11 - NOTIFICATION_TYPE_INCOMING_CALL_IS_ECT Incoming call is an explicit call transfer • Bit to check in ParamPresenceMask - **1**
pCUGIndex	• The CUG Index used to indicate that the incoming/outgoing call is a CUG call. (optional, NULL when not present) Range: 0x00 to 0x7FFF. • Bit to check in ParamPresenceMask - **16**
pECTNum	• The ECT Number is used to indicate that the incoming call is an explicitly transferred call. (optional, NULL when not present) Refer ECTNum for details. • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

Note

None

8.945.2 Field Documentation

8.945.2.1 uint8_t unpack_voice_SUPSNotificationCallback_ind_t::callID

8.945.2.2 uint8_t unpack_voice_SUPSNotificationCallback_ind_t::notifType

8.945.2.3 swi_uint256_t unpack_voice_SUPSNotificationCallback_ind_t::ParamPresenceMask

8.945.2.4 uint16_t* unpack_voice_SUPSNotificationCallback_ind_t::pCUGIndex

8.945.2.5 voice_ECTNum* unpack_voice_SUPSNotificationCallback_ind_t::pECTNum

8.946 unpack_voice_USSDNotificationCallback_ind_t Struct Reference

Data Fields

- uint8_t notification_Type
- voice_USSDNotificationNetworkInfo USSDNotificationNetworkInfo
- swi_uint256_t ParamPresenceMask

8.946.1 Detailed Description

Structure for storing the USSD notification indication parameters.

Parameters

notification_Type(mandatory)	Values: -0x01-FURTHER_USER_ACTION_NOT_REQUIRED -0x02-FURTHER_USER_ACTION_REQUIRED • Bit to check in ParamPresenceMask - **1**
USSDNotificationNetworkInfo(optional)	• USSD network info (See voice_USSDNotificationNetworkInfo) – Bit to check in ParamPresenceMask - **16**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.946.2 Field Documentation

8.946.2.1 uint8_t unpack_voice_USSDNotificationCallback_ind_t::notification_Type

8.946.2.2 swi_uint256_t unpack_voice_USSDNotificationCallback_ind_t::ParamPresenceMask

8.946.2.3 voice_USSDNotificationNetworkInfo unpack_voice_USSDNotificationCallback_ind_t::USSDNotificationNetworkInfo

8.947 unpack_voice_VoiceInfoRecCallback_ind_t Struct Reference

Data Fields

- uint8_t callID
- voice_signalInfo * pSignalInfo
- voice_callerIDInfo * pCallerIDInfo
- uint8_t * pDispInfo
- uint8_t * pExtDispInfo
- uint8_t * pCallerNameInfo
- uint8_t * pCallWaitInd
- voice_connectNumInfo * pConnectNumInfo
- voice_connectNumInfo * pCallingPartyInfo
- voice_calledPartyInfo * pCalledPartyInfo
- voice_redirNumInfo * pRedirNumInfo
- uint8_t * pCLIRCause
- voice_NSSAudioCtrl * pNSSAudioCtrl
- uint8_t * pNSSRelease
- voice_lineCtrlInfo * pLineCtrlInfo
- voice_extDispRecInfo * pExtDispRecInfo
- swi_uint256_t ParamPresenceMask

8.947.1 Detailed Description

This structure contains Voice record Information

Parameters

callID	[Mandatory] • Call identifier for the call. • Bit to check in ParamPresenceMask - **1**
pSignalInfo[-Optional]	• Signal Information • See voice_signalInfo for more information • Bit to check in ParamPresenceMask - **16**
pCallerIDInfo[-Optional]	• Caller ID Information • See voice_callerIDInfo for more information • Bit to check in ParamPresenceMask - **17**
pDispInfo[-Optional]	• Display Information • Bit to check in ParamPresenceMask - **18**
pExtDispInfo[-Optional]	• Extended Display Information • Bit to check in ParamPresenceMask - **19**
pCallerName-Info[Optional]	• Caller Name Information • Bit to check in ParamPresenceMask - **20**

pCallWaitInd[-Optional]	• Call Waiting Indicator • Bit to check in ParamPresenceMask - **21**
pConnectNum-Info[Optional]	• Connected Number Information • see voice_connectNumInfo for more information • Bit to check in ParamPresenceMask - **22**
pCallingParty-Info[Optional]	• Calling Party Number Information • This structure is having exactly same elements as connectNumInfo • see voice_connectNumInfo for more information • Bit to check in ParamPresenceMask - **23**
pCalledParty-Info[Optional]	• Called Party Number Information • see voice_calledPartyInfo for more information • Bit to check in ParamPresenceMask - **24**
pRedirNumInfo[-Optional]	• Redirecting Number Information • see voice_redirNumInfo for more information • Bit to check in ParamPresenceMask - **25**
pCLIRCause[-Optional]	• National Supplementary Services - CLIR • see voice_NSSAudioCtrl for more information • Bit to check in ParamPresenceMask - **26**
pNSSAudioCtrl[-Optional]	• National Supplementary Services - Audio Control • Bit to check in ParamPresenceMask - **27**
pNSSRelease[-Optional]	• National Supplementary Services - Release • Bit to check in ParamPresenceMask - **28**
pLineCtrlInfo[-Optional]	• Line Control Information • see voice_lineCtrlInfo for more information • Bit to check in ParamPresenceMask - **29**
pExtDispRec-Info[Optional]	• Extended Display Record Information • see voice_extDispRecInfo for more information • Bit to check in ParamPresenceMask - **30**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.947.2 Field Documentation

8.947.2.1 uint8_t unpack_voice_VoiceInfoRecCallback_ind_t::callID

8.947.2.2 swi_uint256_t unpack_voice_VoiceInfoRecCallback_ind_t::ParamPresenceMask

8.947.2.3 voice_calledPartyInfo* unpack_voice_VoiceInfoRecCallback_ind_t::pCalledPartyInfo

8.947.2.4 voice_callerIDInfo* unpack_voice_VoiceInfoRecCallback_ind_t::pCallerIDInfo

8.947.2.5 uint8_t* unpack_voice_VoiceInfoRecCallback_ind_t::pCallerNameInfo

8.947.2.6 voice_connectNumInfo* unpack_voice_VoiceInfoRecCallback_ind_t::pCallingPartyInfo

8.947.2.7 uint8_t* unpack_voice_VoiceInfoRecCallback_ind_t::pCallWaitInd

8.947.2.8 uint8_t* unpack_voice_VoiceInfoRecCallback_ind_t::pCLIRCause

8.947.2.9 voice_connectNumInfo* unpack_voice_VoiceInfoRecCallback_ind_t::pConnectNumInfo

8.947.2.10 uint8_t* unpack_voice_VoiceInfoRecCallback_ind_t::pDispInfo

8.947.2.11 uint8_t* unpack_voice_VoiceInfoRecCallback_ind_t::pExtDispInfo

8.947.2.12 voice_extDispRecInfo* unpack_voice_VoiceInfoRecCallback_ind_t::pExtDispRecInfo

8.947.2.13 voice_lineCtrlInfo* unpack_voice_VoiceInfoRecCallback_ind_t::pLineCtrlInfo

8.947.2.14 voice_NSSAudioCtrl* unpack_voice_VoiceInfoRecCallback_ind_t::pNSSAudioCtrl

8.947.2.15 uint8_t* unpack_voice_VoiceInfoRecCallback_ind_t::pNSSRelease

8.947.2.16 voice_redirNumInfo* unpack_voice_VoiceInfoRecCallback_ind_t::pRedirNumInfo

8.947.2.17 voice_signalInfo* unpack_voice_VoiceInfoRecCallback_ind_t::pSignalInfo

8.948 unpack_voice_voicePrivacyChangeCallback_ind_t Struct Reference

Data Fields

- uint8_t callID
- uint8_t voicePrivacy
- swi_uint256_t ParamPresenceMask

8.948.1 Detailed Description

Contains the parameters passed for voice privacy change indication

Parameters

callID	• Unique identifier of the call for which the voice privacy is applicable. (mandatory) • Bit to check in ParamPresenceMask - **1**

voicePrivacy	• Voice Privacy (mandatory) – 0x00 - VOICE_PRIVACY_STANDARD - Standard privacy – 0x01 - VOICE_PRIVACY_ENHANCED - Enhanced privacy • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

Note

None

8.948.2 Field Documentation

8.948.2.1 uint8_t unpack_voice_voicePrivacyChangeCallback_ind_t::callID

8.948.2.2 swi_uint256_t unpack_voice_voicePrivacyChangeCallback_ind_t::ParamPresenceMask

8.948.2.3 uint8_t unpack_voice_voicePrivacyChangeCallback_ind_t::voicePrivacy

8.949 unpack_wds_DHCPv4ClientLease_ind_t Struct Reference

Data Fields

- wds_DHCPProfileIdTlv ProfileIdTlv
- wds_DHCPLeaseStateTlv DHCPv4LeaseStateTlv
- wds_IPv4AdTlv IPv4AddrTlv
- wds_DHCPLeaseOptTlv DHCPv4LeaseOptTlv
- swi_uint256_t ParamPresenceMask

8.949.1 Detailed Description

This structure contains DHCP IPv4 client lease information

Parameters

ProfileIdTlv	profile identifier information, see wds_DHCPProfileIdTlv for more details • Bit to check in ParamPresenceMask - **1**
DHCPv4Lease-StateTlv	lease state, see wds_DHCPLeaseStateTlv for more details • Bit to check in ParamPresenceMask - **2**
IPv4AddrTlv	IPv4 address, see wds_IPv4AdTlv for more details • Bit to check in ParamPresenceMask - **16**
DHCPv4Lease-OptTlv	DHCP lease option, see wds_DHCPLeaseOptTlv for more details • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.949.2 Field Documentation

8.949.2.1 wds_DHCPLeaseOptTlv unpack_wds_DHCPv4ClientLease_ind_t::DHCPv4LeaseOptTlv

8.949.2.2 wds_DHCPLeaseStateTlv unpack_wds_DHCPv4ClientLease_ind_t::DHCPv4LeaseStateTlv

8.949.2.3 wds_IPv4AdTlv unpack_wds_DHCPv4ClientLease_ind_t::IPv4AddrTlv

8.949.2.4 swi_uint256_t unpack_wds_DHCPv4ClientLease_ind_t::ParamPresenceMask

8.949.2.5 wds_DHCPProfileIdTlv unpack_wds_DHCPv4ClientLease_ind_t::ProfileIdTlv

8.950 unpack_wds_GetAutoconnect_t Struct Reference

Data Fields

- uint32_t * psetting
- swi_uint256_t ParamPresenceMask

8.950.1 Detailed Description

auto connect data session setting parameter.

Parameters

pSetting	• NDIS auto connect setting – 0 - Disabled – 1 - Enabled • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.950.2 Field Documentation

8.950.2.1 swi_uint256_t unpack_wds_GetAutoconnect_t::ParamPresenceMask

8.950.2.2 uint32_t* unpack_wds_GetAutoconnect_t::psetting

8.951 unpack_wds_GetByteTotals_t Struct Reference

Data Fields

- uint64_t * pTXTotalBytes
- uint64_t * pRXTotalBytes
- swi_uint256_t ParamPresenceMask

8.951.1 Detailed Description

This structure contains unpack get byte totals information.

Parameters

pTXTotalBytes	• Bytes transmitted without error • Bit to check in ParamPresenceMask - **16**
pRXTotalBytes	• Bytes received without error • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.951.2 Field Documentation

8.951.2.1 swi_uint256_t unpack_wds_GetByteTotals_t::ParamPresenceMask

8.951.2.2 uint64_t* unpack_wds_GetByteTotals_t::pRXTotalBytes

8.951.2.3 uint64_t* unpack_wds_GetByteTotals_t::pTXTotalBytes

8.952 unpack_wds_GetConnectionRate_t Struct Reference

Data Fields

- uint32_t currentChannelTXRate
- uint32_t currentChannelRXRate
- uint32_t maxChannelTXRate
- uint32_t maxChannelRXRate
- swi_uint256_t ParamPresenceMask

8.952.1 Detailed Description

This structure contains unpack get connection rate information.

Parameters

currentChannel-TXRate	• Current channel Tx rate (in bps) • Bit to check in ParamPresenceMask - **1**
currentChannel-RXRate	• Current channel Rx rate (in bps) • Bit to check in ParamPresenceMask - **1**
maxChannelTX-Rate	• Maximum Tx rate (bps) that may be assigned to device by serving system. • Bit to check in ParamPresenceMask - **1**
maxChannelRX-Rate	• Maximum Rx rate (bps) that may be assigned to device by serving system. • Bit to check in ParamPresenceMask - **1**

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.952.2 Field Documentation

8.952.2.1 uint32_t unpack_wds_GetConnectionRate_t::currentChannelRXRate

8.952.2.2 uint32_t unpack_wds_GetConnectionRate_t::currentChannelTXRate

8.952.2.3 uint32_t unpack_wds_GetConnectionRate_t::maxChannelRXRate

8.952.2.4 uint32_t unpack_wds_GetConnectionRate_t::maxChannelTXRate

8.952.2.5 swi_uint256_t unpack_wds_GetConnectionRate_t::ParamPresenceMask

8.953 unpack_wds_GetDataBearerTechnology_t Struct Reference

Data Fields

- uint32_t * pDataBearer
- swi_uint256_t ParamPresenceMask

8.953.1 Detailed Description

This structure contains unpack get data bearer technology information.

Parameters

pDataBearer[OUT]	• Data bearer technology – 0x01 - CDMA2000 1x – 0x02 - CDMA 1xEV-DO Rev 0 – 0x03 - GSM – 0x04 - UMTS – 0x05 - CDMA2000 HRPD (1xEV-DO Rev A) – 0x06 - EDGE – 0x07 - HSDPA AND WCDMA – 0x08 - WCDMA AND HSUPA – 0x09 - HSDPA AND HSUPA – 0x0A - LTE – 0x0B - CDMA2000 EHRPD – 0x0C - HSDPA+ and WCDMA – 0x0D - HSDPA+ and HSUPA – 0x0E - DC_HSDPA+ and WCDMA – 0x0F - DC_HSDPA+ and HSUPA – 0x10 - HSDPA+ and 64QAM – 0x11 - HSDPA+, 64QAM and HSUPA – 0x12 - TDSCDMA – 0x13 - TDSCDMA and HSDPA – 0xFF - Unknown • Bit to check in ParamPresenceMask - **1**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.953.2 Field Documentation

8.953.2.1 swi_uint256_t unpack_wds_GetDataBearerTechnology_t::ParamPresenceMask

8.953.2.2 uint32_t* unpack_wds_GetDataBearerTechnology_t::pDataBearer

8.954 unpack_wds_GetDefaultProfile_t Struct Reference

Data Fields

- uint32_t pdptype
- uint32_t ipaddr
- uint32_t pridns
- uint32_t secdns
- uint16_t ipaddrv6
- uint16_t pridnsv6
- uint16_t secdnsv6
- uint32_t auth
- uint8_t namesize
- int8_t name [255]
- uint8_t apnsize
- int8_t apnname [255]

- uint8_t usersize
- int8_t username [255]
- swi_uint256_t ParamPresenceMask

8.954.1 Detailed Description

Reads the default profile settings from the device. The default profile is used to establish an auto connect data session.

Parameters

pdptype	• Packet Data Protocol (PDP) type specifies the type of data payload exchanged over the air link when the packet data session is established with this profile – 0 - PDP-IP (IPv4) – 1 - PDP-PPP – 2 - PDP-IPv6 – 3 - PDP-IPv4v6 • Bit to check in ParamPresenceMask - **17**
ipaddr	• Preferred IPv4 address to be assigned to device • Bit to check in ParamPresenceMask - **30**
pridns	• Primary DNS IPv4 address preference • Bit to check in ParamPresenceMask - **21**
secdns	• Secondary DNS IPv4 address preference • Bit to check in ParamPresenceMask - **22**
ipaddrv6	• Preferred IPv6 address to be assigned to device • Bit to check in ParamPresenceMask - **143**
pridnsv6	• Primary DNS Pv6 address preference • Bit to check in ParamPresenceMask - **143**
secdnsv6	• Secondary DNS IPv6 address preference • Bit to check in ParamPresenceMask - **143**

auth	• Bitmap that indicates authentication algorithm preference – 0x00000001 - PAP preference * 0 - Never performed * 1 - May be performed – 0x00000002 - CHAP preference * 0 - Never performed * 1 - May be performed – All other bits are reserved and must be set to 0 – If more than 1 bit is set, then device decides which authentication procedure is performed while setting up data session e.g. the device may have a policy to select the most secure authentication mechanism. • Bit to check in ParamPresenceMask - **29**
namesize	• Maximum number of characters (including NULL terminator) that profile name array can contain. • Bit to check in ParamPresenceMask - **16**
name	• Profile name • Bit to check in ParamPresenceMask - **16**
apnsize	• Maximum number of characters (including NULL terminator) that APN name array can contain • Bit to check in ParamPresenceMask - **20**
apnname	• Access point name. NULL-terminated string parameter that is a logical name used to select GGSN and external packet data network. • If value is NULL or omitted, then subscription default value will be requested. • Bit to check in ParamPresenceMask - **20**
usersize	• Maximum number of characters (including NULL terminator) that username array can contain. • Bit to check in ParamPresenceMask - **27**
username	• Username used during network authentication • Bit to check in ParamPresenceMask - **27**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.954.2 Field Documentation

8.954.2.1 int8_t unpack_wds_GetDefaultProfile_t::apnname[255]

8.954.2.2 uint8_t unpack_wds_GetDefaultProfile_t::apnsize

8.954.2.3 uint32_t unpack_wds_GetDefaultProfile_t::auth

8.954.2.4 uint32_t unpack_wds_GetDefaultProfile_t::ipaddr

8.954.2.5 uint16_t unpack_wds_GetDefaultProfile_t::ipaddrv6

8.954.2.6 int8_t unpack_wds_GetDefaultProfile_t::name[255]

8.954.2.7 uint8_t unpack_wds_GetDefaultProfile_t::namesize

8.954.2.8 swi_uint256_t unpack_wds_GetDefaultProfile_t::ParamPresenceMask

8.954.2.9 uint32_t unpack_wds_GetDefaultProfile_t::pdptype

8.954.2.10 uint32_t unpack_wds_GetDefaultProfile_t::pridns

8.954.2.11 uint16_t unpack_wds_GetDefaultProfile_t::pridnsv6

8.954.2.12 uint32_t unpack_wds_GetDefaultProfile_t::secdns

8.954.2.13 uint16_t unpack_wds_GetDefaultProfile_t::secdnsv6

8.954.2.14 int8_t unpack_wds_GetDefaultProfile_t::username[255]

8.954.2.15 uint8_t unpack_wds_GetDefaultProfile_t::usersize

8.955 unpack_wds_GetDefaultProfileNum_t Struct Reference

Data Fields

- uint8_t index
- swi_uint256_t ParamPresenceMask

8.955.1 Detailed Description

This structure contains unpack Get Default Profile Number information.

Parameters

index	profile index • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.955.2 Field Documentation

8.955.2.1 uint8_t unpack_wds_GetDefaultProfileNum_t::index

8.955.2.2 swi_uint256_t unpack_wds_GetDefaultProfileNum_t::ParamPresenceMask

8.956 unpack_wds_GetDormancyState_t Struct Reference

Data Fields

- uint32_t dormancyState
- swi_uint256_t ParamPresenceMask

8.956.1 Detailed Description

This structure contains unpack get dormancy state information.

Parameters

dormancyState	• Dormancy state of current packet data session – 1 - Traffic channel dormant – 2 - Traffic channel active • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.956.2 Field Documentation

8.956.2.1 uint32_t unpack_wds_GetDormancyState_t::dormancyState

8.956.2.2 swi_uint256_t unpack_wds_GetDormancyState_t::ParamPresenceMask

8.957 unpack_wds_GetLastMobileIPError_t Struct Reference

Data Fields

- uint32_t error
- swi_uint256_t ParamPresenceMask

8.957.1 Detailed Description

structure to store last mobile IP error.

Parameters

error	• Status of last MIP call (or attempt) – Zero - Success – NonZero - Error code See qaGobiApiTableCallEndReasons.h for Mobile IP Error codes • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.957.2 Field Documentation

8.957.2.1 uint32_t unpack_wds_GetLastMobileIPError_t::error

8.957.2.2 swi_uint256_t unpack_wds_GetLastMobileIPError_t::ParamPresenceMask

8.958 unpack_wds_GetMobileIP_t Struct Reference

Data Fields

- uint32_t mipMode
- swi_uint256_t ParamPresenceMask

8.958.1 Detailed Description

This structure contains unpack get mobile IP information.

Parameters

mipMode	• Mobile IP setting – 0 - Mobile IP off (simple IP only) – 1 - Mobile IP preferred – 2 - Mobile IP only • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.958.2 Field Documentation

8.958.2.1 uint32_t unpack_wds_GetMobileIP_t::mipMode

8.958.2.2 swi_uint256_t unpack_wds_GetMobileIP_t::ParamPresenceMask

8.959 unpack_wds_GetMobileIPProfile_t Struct Reference

Data Fields

- uint8_t enabled
- uint32_t address
- uint32_t primaryHA
- uint32_t secondaryHA
- uint8_t revTunneling
- uint8_t naiSize
- int8_t NAI [255]
- uint32_t HASPI
- uint32_t AAASPI
- uint32_t HAState
- uint32_t AAAState
- swi_uint256_t ParamPresenceMask

8.959.1 Detailed Description

This structure contains unpack get mobile IP profile information.

Parameters

enabled	• Profile enabled: – 0 - Disabled – 1 - Enabled • Bit to check in ParamPresenceMask - **16**
address	• Home IPv4 address: • Bit to check in ParamPresenceMask - **17**
primaryHA	• Primary home agent IPv4 address • Bit to check in ParamPresenceMask - **18**
secondaryHA	• Secondary home agent IPv4 address • Bit to check in ParamPresenceMask - **19**
revTunneling	• Reverse tunneling enabled – 0 - Disabled – 1 - Enabled • Bit to check in ParamPresenceMask - **20**
naiSize	• The maximum number of characters (including NULL terminator) that the NAI array can contain. • Bit to check in ParamPresenceMask - **21**
NAI	• Network access identifier string • Bit to check in ParamPresenceMask - **21**
HASPI	• Home agent security parameter index • Bit to check in ParamPresenceMask - **22**
AAASPI	• AAA server security parameter index • Bit to check in ParamPresenceMask - **23**
HAState	• Home agent key state – 0 - Unset – 1 - Set, default value – 2 - Set, modified from default – 3 - 0xFFFFFFFF - Unknown • Bit to check in ParamPresenceMask - **26**

AAAState	• AAA key state – 0 - Unset – 1 - Set, default value – 2 - Set, modified from default – 3 - 0xFFFFFFFF - Unknown • Bit to check in ParamPresenceMask - **27**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.959.2 Field Documentation

8.959.2.1 uint32_t unpack_wds_GetMobileIPProfile_t::AAASPI

8.959.2.2 uint32_t unpack_wds_GetMobileIPProfile_t::AAAState

8.959.2.3 uint32_t unpack_wds_GetMobileIPProfile_t::address

8.959.2.4 uint8_t unpack_wds_GetMobileIPProfile_t::enabled

8.959.2.5 uint32_t unpack_wds_GetMobileIPProfile_t::HASPI

8.959.2.6 uint32_t unpack_wds_GetMobileIPProfile_t::HAState

8.959.2.7 int8_t unpack_wds_GetMobileIPProfile_t::NAI[255]

8.959.2.8 uint8_t unpack_wds_GetMobileIPProfile_t::naiSize

8.959.2.9 swi_uint256_t unpack_wds_GetMobileIPProfile_t::ParamPresenceMask

8.959.2.10 uint32_t unpack_wds_GetMobileIPProfile_t::primaryHA

8.959.2.11 uint8_t unpack_wds_GetMobileIPProfile_t::revTunneling

8.959.2.12 uint32_t unpack_wds_GetMobileIPProfile_t::secondaryHA

8.960 unpack_wds_GetPacketStatistics_t Struct Reference

Data Fields

- uint32_t * pTXPacketSuccesses
- uint32_t * pRXPacketSuccesses
- uint32_t * pTXPacketErrors
- uint32_t * pRXPacketErrors
- uint32_t * pTXPacketOverflows
- uint32_t * pRXPacketOverflows
- uint64_t * pTXOkBytesCount
- uint64_t * pRXOkBytesCount
- uint64_t * pTXOKBytesLastCall
- uint64_t * pRXOKBytesLastCall
- uint32_t * pTXDroppedCount

- uint32_t * pRXDroppedCount
- swi_uint256_t ParamPresenceMask

8.960.1 Detailed Description

This structure contains unpack get packet statistics information.

Parameters

pTXPacket-Successes	• No of transmitted Packets without error. • Bit to check in ParamPresenceMask - **16**
pRXPacket-Successes	• No of received Packets without error. • Bit to check in ParamPresenceMask - **17**
pTXPacketErrors	• Number of outgoing packets with framing errors. • Bit to check in ParamPresenceMask - **18**
pRXPacket-Errors	• Number of incoming packets with framing errors. • Bit to check in ParamPresenceMask - **19**
pTXPacket-Overflows	• Number of packets dropped because Tx buffer overflowed (out of memory). • Bit to check in ParamPresenceMask - **20**
pRXPacket-Overflows	• Number of packets dropped because Rx buffer overflowed (out of memory). • Bit to check in ParamPresenceMask - **21**
pTXOkBytes-Count	• Number of bytes transmitted without error. • Bit to check in ParamPresenceMask - **25**
pRXOkBytes-Count	• Number of bytes received without error. • Bit to check in ParamPresenceMask - **26**
pTXOKBytes-LastCall	• Number of bytes transmitted without error during the last data call (0 if no call was made earlier). Returned only if not in a call, and when the previous call was made using RmNet (for any devices that support • Bit to check in ParamPresenceMask - **27**
pRXOKBytes-LastCall	• Number of bytes received without error during the last data call (0 if no call was made earlier). Returned only if not in a call, and when the previous call was made using RmNet (for any devices that support • Bit to check in ParamPresenceMask - **28**

pTXDropped-Count	• Number of outgoing packets dropped. • Bit to check in ParamPresenceMask - **29**
pRXDropped-Count	• Number of incoming packets dropped. • Bit to check in ParamPresenceMask - **30**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.960.2 Field Documentation

8.960.2.1 swi_uint256_t unpack_wds_GetPacketStatistics_t::ParamPresenceMask

8.960.2.2 uint32_t* unpack_wds_GetPacketStatistics_t::pRXDroppedCount

8.960.2.3 uint64_t* unpack_wds_GetPacketStatistics_t::pRXOkBytesCount

8.960.2.4 uint64_t* unpack_wds_GetPacketStatistics_t::pRXOKBytesLastCall

8.960.2.5 uint32_t* unpack_wds_GetPacketStatistics_t::pRXPacketErrors

8.960.2.6 uint32_t* unpack_wds_GetPacketStatistics_t::pRXPacketOverflows

8.960.2.7 uint32_t* unpack_wds_GetPacketStatistics_t::pRXPacketSuccesses

8.960.2.8 uint32_t* unpack_wds_GetPacketStatistics_t::pTXDroppedCount

8.960.2.9 uint64_t* unpack_wds_GetPacketStatistics_t::pTXOkBytesCount

8.960.2.10 uint64_t* unpack_wds_GetPacketStatistics_t::pTXOKBytesLastCall

8.960.2.11 uint32_t* unpack_wds_GetPacketStatistics_t::pTXPacketErrors

8.960.2.12 uint32_t* unpack_wds_GetPacketStatistics_t::pTXPacketOverflows

8.960.2.13 uint32_t* unpack_wds_GetPacketStatistics_t::pTXPacketSuccesses

8.961 unpack_wds_GetPacketStatus_t Struct Reference

Data Fields

- uint32_t tXPacketSuccesses
- uint32_t rXPacketSuccesses
- uint32_t tXPacketErrors
- uint32_t rXPacketErrors
- uint32_t tXPacketOverflows
- uint32_t rXPacketOverflows
- uint64_t tXOkBytesCount
- uint64_t rXOkBytesCount
- uint64_t tXOKBytesLastCall

- uint64_t rXOKBytesLastCall
- uint32_t tXDroppedCount
- uint32_t rXDroppedCount
- swi_uint256_t ParamPresenceMask

8.961.1 Detailed Description

Returns the packet data transfer statistics since the start of the current packet data.

Parameters

tXPacket-Successes	• No. of packets transmitted without error • Bit to check in ParamPresenceMask - **16**
rXPacket-Successes	• No. of packets received without error • Bit to check in ParamPresenceMask - **17**
tXPacketErrors	• No. of outgoing packets with framing errors • Bit to check in ParamPresenceMask - **18**
rXPacketErrors	• No. of incoming packets with framing errors • Bit to check in ParamPresenceMask - **19**
txPacket-Overflows	• Number of packets dropped because Tx buffer overflowed • Bit to check in ParamPresenceMask - **20**
rxPacket-Overflows	• Number of packets dropped because Rx buffer overflowed • Bit to check in ParamPresenceMask - **21**
txOkBytesCount	• No of bytes transmitted without error. • Bit to check in ParamPresenceMask - **25**
rxOkBytesCount	• No of bytes received without error. • Bit to check in ParamPresenceMask - **26**
txOKBytesLast-Call	• No of bytes transmitted without error during the last data call (0 if no call was made earlier). Returned only if not in a call, and when the previous call was made using RmNet (for any devices that support • Bit to check in ParamPresenceMask - **27**
rxOKBytesLast-Call	• Number of bytes received without error during the last data call (0 if no call was made earlier). Returned only if not in a call, and when the previous call was made using RmNet (for any devices that support • Bit to check in ParamPresenceMask - **28**

txDroppedCount	• Number of outgoing packets dropped. • Bit to check in ParamPresenceMask - **29**
rxDroppedCount	• Number of incoming packets dropped. • Bit to check in ParamPresenceMask - **30**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.961.2 Field Documentation

8.961.2.1 swi_uint256_t unpack_wds_GetPacketStatus_t::ParamPresenceMask

8.961.2.2 uint32_t unpack_wds_GetPacketStatus_t::rXDroppedCount

8.961.2.3 uint64_t unpack_wds_GetPacketStatus_t::rXOkBytesCount

8.961.2.4 uint64_t unpack_wds_GetPacketStatus_t::rXOKBytesLastCall

8.961.2.5 uint32_t unpack_wds_GetPacketStatus_t::rXPacketErrors

8.961.2.6 uint32_t unpack_wds_GetPacketStatus_t::rXPacketOverflows

8.961.2.7 uint32_t unpack_wds_GetPacketStatus_t::rXPacketSuccesses

8.961.2.8 uint32_t unpack_wds_GetPacketStatus_t::tXDroppedCount

8.961.2.9 uint64_t unpack_wds_GetPacketStatus_t::tXOkBytesCount

8.961.2.10 uint64_t unpack_wds_GetPacketStatus_t::tXOKBytesLastCall

8.961.2.11 uint32_t unpack_wds_GetPacketStatus_t::tXPacketErrors

8.961.2.12 uint32_t unpack_wds_GetPacketStatus_t::tXPacketOverflows

8.961.2.13 uint32_t unpack_wds_GetPacketStatus_t::tXPacketSuccesses

8.962 unpack_wds_GetSessionDuration_t Struct Reference

Data Fields

- uint64_t callDuration
- swi_uint256_t ParamPresenceMask

8.962.1 Detailed Description

This structure contains unpack get session duration information.

Parameters

callDuration	• Duration of the current packet session in milliseconds • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.962.2 Field Documentation

8.962.2.1 uint64_t unpack_wds_GetSessionDuration_t::callDuration

8.962.2.2 swi_uint256_t unpack_wds_GetSessionDuration_t::ParamPresenceMask

8.963 unpack_wds_GetSessionState_t Struct Reference

Data Fields

- uint32_t connectionStatus
- swi_uint256_t ParamPresenceMask

8.963.1 Detailed Description

This structure contains unpack get session state information.

Parameters

connection-Status	- state of the current packet data session. • 1 - Disconnected. • 2 - Connected. • 3 - Suspended. • 4 - Authenticating. • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.963.2 Field Documentation

8.963.2.1 uint32_t unpack_wds_GetSessionState_t::connectionStatus

8.963.2.2 swi_uint256_t unpack_wds_GetSessionState_t::ParamPresenceMask

8.964 unpack_wds_RMSetTransferStatistics_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.964.1 Detailed Description

This structure contains unpack fetch current data system transfer statistics information.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.964.2 Field Documentation

8.964.2.1 swi_uint256_t unpack_wds_RMSetTransferStatistics_t::ParamPresenceMask

8.965 unpack_wds_SetMobileIPProfile_t Struct Reference

Data Fields

- swi_uint256_t ParamPresenceMask

8.965.1 Detailed Description

This structure contains set mobile IP profile information.

Parameters

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.965.2 Field Documentation

8.965.2.1 swi_uint256_t unpack_wds_SetMobileIPProfile_t::ParamPresenceMask

8.966 unpack_wds_SLQSCreateProfile_t Struct Reference

Data Fields

- PackCreateProfileOut * pCreateProfileOut
- uint8_t * pProfileID
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.966.1 Detailed Description

This structure contains unpack create profile information.

Parameters

pCreateProfile-Out	• SLQS Create profile Information • See PackCreateProfileOut

pProfileID	• SLQS profile identifier information
TlvresultI	• TLV present flag, TURE if presented, otherwise FALSE
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.966.2 Field Documentation

8.966.2.1 swi_uint256_t unpack_wds_SLQSCreateProfile_t::ParamPresenceMask

8.966.2.2 PackCreateProfileOut* unpack_wds_SLQSCreateProfile_t::pCreateProfileOut

8.966.2.3 uint8_t* unpack_wds_SLQSCreateProfile_t::pProfileID

8.966.2.4 uint16_t unpack_wds_SLQSCreateProfile_t::TlvresultI

8.967 unpack_wds_SLQSDeleteProfile_t Struct Reference

Data Fields

- uint16_t extendedErrorCode
- swi_uint256_t ParamPresenceMask

8.967.1 Detailed Description

This structure contains unpack delete profile information.

Parameters

extendedError-Code[OUT]	• The extended error code received from DS Profile subsystem of type eWDS_ERR_PROFILE_-REG_xxx. • Error code will only will be present if error code eQCWWAN_ERR_QMI_EXTENDED_INTERN-AL is returned by device. • See qm_wds_ds_profile_extended_err_codes enum in qmerrno.h for received error description. • Bit to check in ParamPresenceMask - **224**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.967.2 Field Documentation

8.967.2.1 uint16_t unpack_wds_SLQSDeleteProfile_t::extendedErrorCode

8.967.2.2 swi_uint256_t unpack_wds_SLQSDeleteProfile_t::ParamPresenceMask

8.968 unpack_wds_SLQSDUNCallInfoCallBack_ind_t Struct Reference

Data Fields

- wds_ConnStatusTlv CSTlv
- wds_LastMdmCallEndRsnTlv LMCERTlv
- wds_TXBytesOKTlv TXBOTlv
- wds_RXBytesOKTlv RXBOTlv
- wds_DormStatTlv DSTlv
- wds_DataBearTechTlv DBTTlv
- wds_ChannelRateTlv CRTlv
- swi_uint256_t ParamPresenceMask

8.968.1 Detailed Description

Structure used to store Reg Mgr Config Indication Parameters.

Parameters

CSTlv	• Connection status tlv • See wds_ConnStatusTlv for more information • Bit to check in ParamPresenceMask - **16**
LMCERTlv	• last modem call end reason tlv • see wds_LastMdmCallEndRsnTlv for more information • Bit to check in ParamPresenceMask - **17**
TXBOTlv	• Tx bytes OK tlv • see wds_TXBytesOKTlv for more information • Bit to check in ParamPresenceMask - **18**
RXBOTlv	• Rx bytes OK tlv • see wds_RXBytesOKTlv for more information • Bit to check in ParamPresenceMask - **19**
DSTlv	• Dormancy status tlv • see wds_DormStatTlv for more information • Bit to check in ParamPresenceMask - **20**
DBTTlv	• Data bear technology tlv • see wds_DataBearTechTlv for more information • Bit to check in ParamPresenceMask - **21**
CRTlv	• Channel rate Tlv • see wds_ChannelRateTlv for more information • Bit to check in ParamPresenceMask - **22**

ParamPresence-Mask	• bitmask representation to indicate valid parameters.

Note

: None

8.968.2 Field Documentation

8.968.2.1 wds_ChannelRateTlv unpack_wds_SLQSDUNCallInfoCallBack_ind_t::CRTlv

8.968.2.2 wds_ConnStatusTlv unpack_wds_SLQSDUNCallInfoCallBack_ind_t::CSTlv

8.968.2.3 wds_DataBearTechTlv unpack_wds_SLQSDUNCallInfoCallBack_ind_t::DBTTlv

8.968.2.4 wds_DormStatTlv unpack_wds_SLQSDUNCallInfoCallBack_ind_t::DSTlv

8.968.2.5 wds_LastMdmCallEndRsnTlv unpack_wds_SLQSDUNCallInfoCallBack_ind_t::LMCERTlv

8.968.2.6 swi_uint256_t unpack_wds_SLQSDUNCallInfoCallBack_ind_t::ParamPresenceMask

8.968.2.7 wds_RXBytesOKTlv unpack_wds_SLQSDUNCallInfoCallBack_ind_t::RXBOTlv

8.968.2.8 wds_TXBytesOKTlv unpack_wds_SLQSDUNCallInfoCallBack_ind_t::TXBOTlv

8.969 unpack_wds_SLQSGet3GPPConfigItem_t Struct Reference

Data Fields

- uint16_t LTEAttachProfile
- uint16_t profileList [5]
- uint8_t defaultPDNEnabled
- uint8_t _3gppRelease
- uint16_t LTEAttachProfileList [24]
- uint16_t LTEAttachProfileListLen
- swi_uint256_t ParamPresenceMask

8.969.1 Detailed Description

This structure contains unpack get 3GPP configure item information.

Parameters

	LTEAttachProfile	• LTE Attach Profile – points to a single WORD Value indicating the attached LTE Profile – Optional parameter with possible values 1-16 (EM/MC73xx or earlier) • This setting is deprecated on MC/EM74xx • Bit to check in ParamPresenceMask - **16**

	profileList	Profile List • an array of 4 profile configurations • Each element points to a single WORD value indicating profile • Optional parameter with possible values – 1 - 16 (MC/EM73xx and before) – 1 - 24 (MC/EM74xx and onwards) • function SLQSGet3GPPConfigItem() returns a default value 255 if no 3gpp configuration is present • Bit to check in ParamPresenceMask - **17** • Note: the 5th entry is currently ignored, please set it to zero
out	*defaultPDN-Enabled*	• 0 - disabled • 1 - enabled • Bit to check in ParamPresenceMask - **18**
out	*_3gppRelease*	3GPP release • 0 - Release_99 • 1 - Release_5 • 2 - Release_6 • 3 - Release_7 • 4 - Release_8 • 5 - Release_9 (In 9x30 and toworads) • 6 - Release_10 (In 9x30 and toworads) • 7 - Release_11 (In 9x30 and toworads) • Bit to check in ParamPresenceMask - **19**
out	*LTEAttach-ProfileList*	• pointer to WORD array indiciating LTE Attach Profile List – Optional parameter – possible values: 1-24 – This setting is only supported for MC/EM74xx onwards – Please provide attach profiles in order of decreasing priority in this list. • Bit to check in ParamPresenceMask - **20**
in,out	*LTEAttach-ProfileListLen*	• Number of element in pLTEAttachProfileList – valid range: 1-24 – This setting is only supported for MC/EM74xx onwards • Bit to check in ParamPresenceMask - **20**
	ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.969.2 Field Documentation

8.969.2.1 uint8_t unpack_wds_SLQSGet3GPPConfigItem_t::_3gppRelease

8.969.2.2 uint8_t unpack_wds_SLQSGet3GPPConfigItem_t::defaultPDNEnabled

8.969.2.3 uint16_t unpack_wds_SLQSGet3GPPConfigItem_t::LTEAttachProfile

8.969.2.4 uint16_t unpack_wds_SLQSGet3GPPConfigItem_t::LTEAttachProfileList[24]

8.969.2.5 uint16_t unpack_wds_SLQSGet3GPPConfigItem_t::LTEAttachProfileListLen

8.969.2.6 swi_uint256_t unpack_wds_SLQSGet3GPPConfigItem_t::ParamPresenceMask

8.969.2.7 uint16_t unpack_wds_SLQSGet3GPPConfigItem_t::profileList[5]

8.970 unpack_wds_SLQSGetCurrDataSystemStat_t Struct Reference

Data Fields

- uint8_t prefNetwork
- uint8_t networkInfoLen
- currNetworkInfo currNetworkInfo [255]
- swi_uint256_t ParamPresenceMask

8.970.1 Detailed Description

Data System Status

Parameters

prefNetwork	• Preferred Network • Values: – 0 - 3GPP – 1 - 3GPP2 • Bit to check in ParamPresenceMask - **16**
networkInfoLen	• As input parameter size assigned to next parameter i.e. network information • As output the actual number of network information elements returned by the device • Bit to check in ParamPresenceMask - **16**
currNetworkInfo	• Network information • See currNetworkInfo for more details • Bit to check in ParamPresenceMask - **16**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.970.2 Field Documentation

8.970.2.1 currNetworkInfo unpack_wds_SLQSGetCurrDataSystemStat_t::currNetworkInfo[255]

8.970.2.2 uint8_t unpack_wds_SLQSGetCurrDataSystemStat_t::networkInfoLen

8.970.2.3 swi_uint256_t unpack_wds_SLQSGetCurrDataSystemStat_t::ParamPresenceMask

8.970.2.4 uint8_t unpack_wds_SLQSGetCurrDataSystemStat_t::prefNetwork

8.971 unpack_wds_SLQSGetCurrentChannelRate_t Struct Reference

Data Fields

- uint32_t current_channel_tx_rate
- uint32_t current_channel_rx_rate
- uint32_t max_channel_tx_rate
- uint32_t max_channel_rx_rate
- swi_uint256_t ParamPresenceMask

8.971.1 Detailed Description

This structure contains unpack get current channel rate information.

Parameters

current_channel-_tx_rate	• Current Channel Tx Rate. • Instantaneous channel Tx rate in bits per second. • In 9x15, this is the total current channel rate for all PDNs combined. • In 9x30 and later, this is the channel rate for a specific PDN. • Bit to check in ParamPresenceMask - **1**
current_channel-_rx_rate	• Current Channel Rx Rate. • Instantaneous channel Rx rate in bits per second. • In 9x15, this is the total current channel rate for all PDNs combined. • In 9x30 and later, this is the channel rate for a specific PDN • Bit to check in ParamPresenceMask - **1**
max_channel_-tx_rate	• Max Channel Tx Rate. • Maximum total Tx rate that modem is able to support in current serving system in bits per second. • In 9x15, this is a default hard coded value for the current serving system. • Bit to check in ParamPresenceMask - **1**
max_channel_-rx_rate	• Max Channel Rx Rate. • Maximum total Rx rate that modem is able to support in current serving system in bits per second. • In 9x15, this is a default hard coded value for the current serving system. • Bit to check in ParamPresenceMask - **1**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.971.2 Field Documentation

8.971.2.1 uint32_t unpack_wds_SLQSGetCurrentChannelRate_t::current_channel_rx_rate

8.971.2.2 uint32_t unpack_wds_SLQSGetCurrentChannelRate_t::current_channel_tx_rate

8.971.2.3 uint32_t unpack_wds_SLQSGetCurrentChannelRate_t::max_channel_rx_rate

8.971.2.4 uint32_t unpack_wds_SLQSGetCurrentChannelRate_t::max_channel_tx_rate

8.971.2.5 swi_uint256_t unpack_wds_SLQSGetCurrentChannelRate_t::ParamPresenceMask

8.972 unpack_wds_SLQSGetDataBearerTechnology_t Struct Reference

Data Fields

- uint8_t dataBearerMask
- qmiWDSDataBearerTechnology curDataBearerTechnology
- qmiWDSDataBearerTechnology lastCallDataBearerTechnology
- swi_uint256_t ParamPresenceMask

8.972.1 Detailed Description

Structure to hold the data bearer technology values

Parameters

dataBearerMask[OUT]	• This bit mask indicates if data bearer information for the current and/or last call has been received from the device. If a bit is set, then the information is available in the corresponding structure i.e. the one provided by the caller. Refer to liteQmiDataBearerMasks for bit-mask positions. • Bit to check in ParamPresenceMask - **1**
curDataBearerTechnology[OUT]	• current data bearer technology value. • See qmiWDSDataBearerTechnology • Bit to check in ParamPresenceMask - **1**
lastCallDataBearerTechnology[OUT]	• last call data bearer technology value. • See qmiWDSDataBearerTechnology – NULL if the parameter is not required • Bit to check in ParamPresenceMask - **16**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.972.2 Field Documentation

8.972.2.1 qmiWDSDataBearerTechnology unpack_wds_SLQSGetDataBearerTechnology_t::curDataBearerTechnology

8.972.2.2 uint8_t unpack_wds_SLQSGetDataBearerTechnology_t::dataBearerMask

8.972.2.3 qmiWDSDataBearerTechnology unpack_wds_SLQSGetDataBearerTechnology_t::lastCallDataBearerTechnology

8.972.2.4 swi_uint256_t unpack_wds_SLQSGetDataBearerTechnology_t::ParamPresenceMask

8.973 unpack_wds_SLQSGetDUNCallInfo_t Struct Reference

Data Fields

- connectionStatus connectionStatus
- uint16_t callEndReason
- uint64_t txOKBytesCount
- uint64_t rxOKBytesCount
- uint8_t dormancyStatus
- uint8_t dataBearerTech
- dunchannelRate channelRate
- uint64_t lastCallTXOKBytesCnt
- uint64_t lastCallRXOKBytesCnt
- uint64_t mdmCallDurationActive
- uint8_t lastCallDataBearerTech
- swi_uint256_t ParamPresenceMask

8.973.1 Detailed Description

This structure contains the DUN Call Info response parameters

Parameters

connectionStatus	• See connectionStatus for more information • Bit to check in ParamPresenceMask - **16**
callEndReason	• Last modem call end reason • See qaGobiApiTableCallEndReasons.h for Call End Reason • Only valid if the last call made was DUN, else zero is returned • Bit to check in ParamPresenceMask - **17**
txOKBytesCount	• Number of bytes transmitted without error • Returned only if a data call is up • Bit to check in ParamPresenceMask - **18**
rxOKBytesCount	• Number of bytes received without error • Returned only if a data call is up • Bit to check in ParamPresenceMask - **19**

dormancyStatus	• Current traffic channel status • Returned if a data call is up – 0x01 - Traffic channel dormant – 0x02 - Traffic channel active • Bit to check in ParamPresenceMask - **20**
dataBearerTech	• Current data bearer technology • Returned only if a data call is up – 0x01 - cdma2000 1X – 0x02 - cdma2000 HRPD (1xEV-DO) – 0x03 - GSM – 0x04 - UMTS – 0x05 - cdma200 HRPD (1xEV-DO RevA) – 0x06 - EDGE – 0x07 - HSDPA and WCDMA – 0x08 - WCDMA and HSUPA – 0x09 - HSDPA and HSUPA – 0x0A - LTE – 0x0B - cdma2000 EHRPD – 0x0C - HSDPA+ and WCDMA – 0x0D - HSDPA+ and HSUPA – 0x0E - DC_HSDPA+ and WCDMA – 0x0F - DC_HSDPA+ and HSUPA – 0x10 - HSDPA+ and 64QAM – 0x11 - HSDPA+, 64QAM and HSUPA – 0x12 - TDSCDMA – 0x13 - TDSCDMA and HSDPA • Bit to check in ParamPresenceMask - **21**
channelRate	• See dunchannelRate for more information • Bit to check in ParamPresenceMask - **22**
lastCallTXOK-BytesCnt	• Number of bytes transmitted without error during the last data call (0 if no call was made). • Return only if not in a call and the previous call was made using DUN. • Bit to check in ParamPresenceMask - **23**
lastCallRXOK-BytesCnt	• Number of bytes transmitted without error during the last data call (0 if no call was made). • Return only if not in a call and the previous call was made using DUN. • Bit to check in ParamPresenceMask - **24**

mdmCall-DurationActive	• Duration that the call is active in milliseconds • If the modem connection status is connected, this represents the active duration of the current DUN call • If the modem connection status is disconnected, this represents the duration of the last DUN call since the device was powered up (0 if no call has been made or if the last call was not DUN) • Bit to check in ParamPresenceMask - **25**
lastCallData-BearerTech	• Last Call Data Bearer Technology • Returned only if not in a call and when the previous call was made using DUN – 0x01 - cdma2000 1X – 0x02 - cdma2000 HRPD (1xEV-DO) – 0x03 - GSM – 0x04 - UMTS – 0x05 - cdma200 HRPD (1xEV-DO Rev A) – 0x06 - EDGE – 0x07 - HSDPA and WCDMA – 0x08 - WCDMA and HSUPA – 0x09 - HSDPA and HSUPA – 0x0A - LTE – 0x0B - cdma2000 EHRPD – 0x0C - HSDPA+ and WCDMA – 0x0D - HSDPA+ and HSUPA – 0x0E - DC_HSDPA+ and WCDMA – 0x0F - DC_HSDPA+ and HSUPA – 0x10 - HSDPA+ and 64QAM – 0x11 - HSDPA+, 64QAM and HSUPA – 0x12 - TDSCDMA – 0x13 - TDSCDMA and HSDPA • Bit to check in ParamPresenceMask - **32**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.973.2 Field Documentation

8.973.2.1 uint16_t unpack_wds_SLQSGetDUNCallInfo_t::callEndReason

8.973.2.2 dunchannelRate unpack_wds_SLQSGetDUNCallInfo_t::channelRate

8.973.2.3 connectionStatus unpack_wds_SLQSGetDUNCallInfo_t::connectionStatus

8.973.2.4 uint8_t unpack_wds_SLQSGetDUNCallInfo_t::dataBearerTech

8.973.2.5 uint8_t unpack_wds_SLQSGetDUNCallInfo_t::dormancyStatus

8.973.2.6 uint8_t unpack_wds_SLQSGetDUNCallInfo_t::lastCallDataBearerTech

8.973.2.7 uint64_t unpack_wds_SLQSGetDUNCallInfo_t::lastCallRXOKBytesCnt

8.973.2.8 uint64_t unpack_wds_SLQSGetDUNCallInfo_t::lastCallTXOKBytesCnt

8.973.2.9 uint64_t unpack_wds_SLQSGetDUNCallInfo_t::mdmCallDurationActive

8.973.2.10 swi_uint256_t unpack_wds_SLQSGetDUNCallInfo_t::ParamPresenceMask

8.973.2.11 uint64_t unpack_wds_SLQSGetDUNCallInfo_t::rxOKBytesCount

8.973.2.12 uint64_t unpack_wds_SLQSGetDUNCallInfo_t::txOKBytesCount

8.974 unpack_wds_SLQSGetProfileSettings_t Struct Reference

Data Fields

- UnPackGetProfileSettingOut * pProfileSettings
- uint8_t ProfileType
- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.974.1 Detailed Description

This structure contains the profile setting information of parameter pOutput for API unpack_wds_SLQSGetProfile-Settings

Parameters

pProfileSettings	- Profile Settings
ProfileType	- Profile Type • 0 - Profile 3GPP • 1 - Profile 3GPP2
Tlvresult	- unpack Tlv Result.
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.974.2 Field Documentation

8.974.2.1 swi_uint256_t unpack_wds_SLQSGetProfileSettings_t::ParamPresenceMask

8.974.2.2 UnPackGetProfileSettingOut* unpack_wds_SLQSGetProfileSettings_t::pProfileSettings

8.974.2.3 uint8_t unpack_wds_SLQSGetProfileSettings_t::ProfileType

8.974.2.4 uint16_t unpack_wds_SLQSGetProfileSettings_t::Tlvresult

8.975 unpack_wds_SLQSGetRuntimeSettings_t Struct Reference

Data Fields

- uint32_t IPv4
- uint8_t ProfileName [128]
- uint32_t PDPType

- uint8_t APNName [128]
- uint32_t PrimaryDNSV4
- uint32_t SecondaryDNSV4
- LibPackUMTSQoS UMTSGrantedQoS
- struct wds_GPRSQoS GPRSGrantedQoS
- uint8_t Username [128]
- uint32_t Authentication
- struct wds_ProfileIdentifier ProfileID
- uint32_t GWAddressV4
- uint32_t SubnetMaskV4
- uint8_t PCSCFAddrPCO
- struct wds_PCSCFIPv4ServerAddressList ServerAddrList
- struct wds_PCSCFFQDNAddressList PCSCFFQDNAddrList
- uint16_t PrimaryDNSV6 [8]
- uint16_t SecondaryDNSV6 [8]
- uint32_t Mtu
- struct wds_DomainNameList DomainList
- uint8_t IPFamilyPreference
- uint8_t IMCNflag
- uint16_t Technology
- struct wds_IPV6AddressInfo IPV6AddrInfo
- struct wds_IPV6GWAddressInfo IPV6GWAddrInfo
- swi_uint256_t ParamPresenceMask

8.975.1 Detailed Description

This structure contains unpack get runtime settings information.

Parameters

IPv4	ipv4 address • Bit to check in ParamPresenceMask - **30**
ProfileName	profile name • Bit to check in ParamPresenceMask - **16**
PDPType	PDP type • Bit to check in ParamPresenceMask - **17**
APNName	APN name • Bit to check in ParamPresenceMask - **20**
PrimaryDNSV4	primary dns IPV4 • Bit to check in ParamPresenceMask - **21**
SecondaryDNS-V4	secondary dns IPV4 • Bit to check in ParamPresenceMask - **22**
UMTSGranted-QoS	UMTS Granted Qos • Bit to check in ParamPresenceMask - **23**
GPRSGranted-QoS	GPRS Granted QoS • Bit to check in ParamPresenceMask - **25**

Username	username for authentication process • Bit to check in ParamPresenceMask - **27**
Authentication	authentication for authentication process • Bit to check in ParamPresenceMask - **29**
ProfielID	profile ID • Bit to check in ParamPresenceMask - **31**
GWAddressV4	Gateway IPv4 • Bit to check in ParamPresenceMask - **32**
SubnetMaskV4	Subnet mask IPV4 • Bit to check in ParamPresenceMask - **33**
PCSCFAddrPCO	PCSCF address PCO • Bit to check in ParamPresenceMask - **34**
ServerAddrList	PCSCF server address list IPV4 • Bit to check in ParamPresenceMask - **35**
PCSCFFQDNAddrList	PCSCF FQDN address list IPV4 • Bit to check in ParamPresenceMask - **36**
PrimaryDNSV6	Primary DNS IPV6 • Bit to check in ParamPresenceMask - **39**
SecondryDNSV6	Secondry DNS IPV6 • Bit to check in ParamPresenceMask - **40**
Mtu	actual (runtime) Maximum Transfer Unit • Bit to check in ParamPresenceMask - **41**
DomainList	domain list • Bit to check in ParamPresenceMask - **42**
IPFamilyPreference	ip family preference, it could be IPV4 or IPV6 • Bit to check in ParamPresenceMask - **43**
IMCNflag	IM control flag, value: TRUE or FALSE • Bit to check in ParamPresenceMask - **44**
Technology	technology on which current packet data session is in progress • Values: – 32767 - CDMA – 32764 - UMTS – 30592 - EPC – 30584 - modem link local • Bit to check in ParamPresenceMask - **45**
IPV6AddrInfo	address information IPV6 • Bit to check in ParamPresenceMask - **37**

IPV6GWAddr-Info	gateway address information IPV6 • Bit to check in ParamPresenceMask - **38**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.975.2 Field Documentation

8.975.2.1 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::APNName[128]

8.975.2.2 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::Authentication

8.975.2.3 struct **wds_DomainNameList** unpack_wds_SLQSGetRuntimeSettings_t::DomainList

8.975.2.4 struct **wds_GPRSQoS** unpack_wds_SLQSGetRuntimeSettings_t::GPRSGrantedQoS

8.975.2.5 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::GWAddressV4

8.975.2.6 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::IMCNflag

8.975.2.7 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::IPFamilyPreference

8.975.2.8 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::IPv4

8.975.2.9 struct **wds_IPV6AddressInfo** unpack_wds_SLQSGetRuntimeSettings_t::IPV6AddrInfo

8.975.2.10 struct **wds_IPV6GWAddressInfo** unpack_wds_SLQSGetRuntimeSettings_t::IPV6GWAddrInfo

8.975.2.11 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::Mtu

8.975.2.12 **swi_uint256_t** unpack_wds_SLQSGetRuntimeSettings_t::ParamPresenceMask

8.975.2.13 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::PCSCFAddrPCO

8.975.2.14 struct **wds_PCSCFFQDNAddressList** unpack_wds_SLQSGetRuntimeSettings_t::PCSCFFQDNAddrList

8.975.2.15 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::PDPType

8.975.2.16 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::PrimaryDNSV4

8.975.2.17 uint16_t unpack_wds_SLQSGetRuntimeSettings_t::PrimaryDNSV6[8]

8.975.2.18 struct **wds_ProfileIdentifier** unpack_wds_SLQSGetRuntimeSettings_t::ProfileID

8.975.2.19 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::ProfileName[128]

8.975.2.20 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::SecondaryDNSV4

8.975.2.21 uint16_t unpack_wds_SLQSGetRuntimeSettings_t::SecondaryDNSV6[8]

8.975.2.22 struct **wds_PCSCFIPv4ServerAddressList** unpack_wds_SLQSGetRuntimeSettings_t::ServerAddrList

8.975.2.23 uint32_t unpack_wds_SLQSGetRuntimeSettings_t::SubnetMaskV4

8.975.2.24 uint16_t unpack_wds_SLQSGetRuntimeSettings_t::Technology

8.975.2.25 LibPackUMTSQoS unpack_wds_SLQSGetRuntimeSettings_t::UMTSGrantedQoS

8.975.2.26 uint8_t unpack_wds_SLQSGetRuntimeSettings_t::Username[128]

8.976 unpack_wds_SLQSModifyProfile_t Struct Reference

Data Fields

- uint16_t * pExtErrorCode
- swi_uint256_t ParamPresenceMask

8.976.1 Detailed Description

This structure contains out parameters for unpack_wds_SLQSModifyProfile

Parameters

pExtErrorCode	• The extended error code received from DS Profile subsystem of type eWDS_ERR_PROFILE_-REG_xxx. • Error code will only will be present if error code eQCWWAN_ERR_QMI_EXTENDED_INTERN-AL is returned by device. • See qm_wds_ds_profile_extended_err_codes enum in qmerrno.h for received error description. • Bit to check in ParamPresenceMask - **224**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.976.2 Field Documentation

8.976.2.1 swi_uint256_t unpack_wds_SLQSModifyProfile_t::ParamPresenceMask

8.976.2.2 uint16_t* unpack_wds_SLQSModifyProfile_t::pExtErrorCode

8.977 unpack_wds_SLQSSetIPFamilyPreference_t Struct Reference

Data Fields

- uint16_t Tlvresult
- swi_uint256_t ParamPresenceMask

8.977.1 Detailed Description

This structure contains unpack Set IP family preference information

Parameters

Tlvresult	unpack result
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.977.2 Field Documentation

8.977.2.1 swi_uint256_t unpack_wds_SLQSSetIPFamilyPreference_t::ParamPresenceMask

8.977.2.2 uint16_t unpack_wds_SLQSSetIPFamilyPreference_t::Tlvresult

8.978 unpack_wds_SLQSSetPacketSrvStatusCallback_t Struct Reference

Data Fields

- uint8_t conn_status
- uint8_t reconfigReqd
- uint16_t sessionEndReason
- uint16_t verboseSessnEndReasonType
- uint16_t verboseSessnEndReason
- uint8_t ipFamily
- uint16_t techName
- uint8_t bearerID
- swi_uint256_t ParamPresenceMask

8.978.1 Detailed Description

This structure contains unpack set packet service status callback information.

Parameters

conn_status	connection status. • Current link status. Values: – 1 - DISCONNECTED – 2 - CONNECTED – 3 - SUSPENDED – 4 - AUTHENTICATING • Bit to check in ParamPresenceMask - **1**
reconfigReqd	Indicates whether the network interface on the host needs to be reconfigured. • Values: – 0 - No need to reconfigure. – 1 - Reconfiguration required.

- Bit to check in ParamPresenceMask - **1**

Parameters

sessionEndReason	Call End Reason • See qaGobiApiTableCallEndReasons.h for Call End Reason • Bit to check in ParamPresenceMask - **16**
verboseSessnEndReasonType	Verbose call end reason type • Call end reason type. Values: – 0 - Unspecified – 1 - Mobile IP – 2 - Internal – 3 - Call Manager defined – 6 - 3GPP Specification defined – 7 - PPP – 8 - EHRPD – 9 - IPv6 • Bit to check in ParamPresenceMask - **17**
verboseSessnEndReason	Reason the call ended (verbose) • See qaGobiApiTableCallEndReasons.h for Call End Reason • Bit to check in ParamPresenceMask - **17**
ipFamily	IP family of the packet data connection. • Values – 4 - IPv4 – 6 - IPv6 • Bit to check in ParamPresenceMask - **18**
techName	Technology name of the packet data connection. • Values – 32767 - CDMA – 32764 - UMTS – 30592 - EPC – 30590 - EMBMS – 30584 - Modem Link Local EPC is a logical interface to support LTE/eHRPD handoff. It is returned if the device supports IP session continuity. Modem Link Local is an interface for transferring data between entities on the AP and modem. • Bit to check in ParamPresenceMask - **19**
bearerID	• bearer ID (3GPP) or RLP ID (3GPP2) of the packet data connection. • Valid Values - 0 to 16 – Bit to check in ParamPresenceMask - **20**
ParamPresenceMask	• bitmask representation to indicate valid parameters.

8.978.2 Field Documentation

8.978.2.1 uint8_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::bearerID

8.978.2.2 uint8_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::conn_status

8.978.2.3 uint8_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::ipFamily

8.978.2.4 swi_uint256_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::ParamPresenceMask

8.978.2.5 uint8_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::reconfigReqd

8.978.2.6 uint16_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::sessionEndReason

8.978.2.7 uint16_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::techName

8.978.2.8 uint16_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::verboseSessnEndReason

8.978.2.9 uint16_t unpack_wds_SLQSSetPacketSrvStatusCallback_t::verboseSessnEndReasonType

8.979 unpack_wds_SLQSSetWdsEventCallback_ind_t Struct Reference

Data Fields

- uint8_t xferStatAvail
- uint64_t tx_bytes
- uint64_t rx_bytes
- uint64_t tx_pkts
- uint64_t rx_pkts
- uint8_t mipstatAvail
- uint32_t mipStatus
- uint8_t dBTechAvail
- uint32_t dBTechnology
- uint8_t dormancyStatAvail
- uint32_t dormancyStatus
- uint8_t currDBTechAvail
- uint32_t ratMask
- uint32_t soMask
- uint8_t dataSysStatAvail
- uint8_t prefNetwork
- uint8_t netInfoLen
- wds_currNetworkInfo currNWInfo [255]
- uint8_t dBtechExtAvail
- uint32_t dBtechnologyExt
- uint32_t dBTechExtRatValue
- uint64_t dBTechExtSoMask
- swi_uint256_t ParamPresenceMask

8.979.1 Detailed Description

This structure contains unpack set WDS event callback information.

Parameters

xferStatAvail	transfer statistic available
tx_bytes	• Number of bytes transmitted without error • Bit to check in ParamPresenceMask - **25**

rx_bytes	• Number of bytes received without error • Bit to check in ParamPresenceMask - **26**
tx_pkts	• Number of packets transmitted without error • Bit to check in ParamPresenceMask - **16**
rx_pkts	• Number of packets received without error. • Bit to check in ParamPresenceMask - **17**
mipstatAvail	Mobile IP status available • Bit to check in ParamPresenceMask - **27**
mipStatus	• Status of the last MIP call (or attempt). • Values – 0x00 - Success • Bit to check in ParamPresenceMask - **27**
dBTechAvail	Data Bearer technology available • Bit to check in ParamPresenceMask - **23**
dBTechnology	• Data Bearer technology – Values * 0x01 - cdma2000 ® 1X * 0x02 - cdma2000 ® HRPD (1xEV-DO) * 0x03 - GSM * 0x04 - UMTS * 0x05 - cdma2000 ® HRPD (1xEV-DO RevA) * 0x06 - EDGE * 0x07 - HSDPA and WCDMA * 0x08 - WCDMA and HSUPA * 0x09 - HSDPA and HSUPA * 0x0A - LTE * 0x0B - cdma2000 ® EHRPD * 0x0C - HSDPA+ and WCDMA * 0x0D - HSDPA+ and HSUPA * 0x0E - DC_HSDPA+ and WCDMA * 0x0F - DC_HSDAP+ and HSUPA * 0x10 - HSDPA+ and 64QAM * 0x11 - HSDPA+, 64QAM and HSUPA * 0x12 - TDSCDMA * 0x13 - TDSCDMA and HSDPA * 0x14 - TDSCDMA and HSUPA * -1 - Unknown • Bit to check in ParamPresenceMask - **23**

dormancyStat-Avail	Dormancy status available • Bit to check in ParamPresenceMask - **24**
dormancyStatus	• Dormancy status • Values – 1 - Traffic channel dormant – 2 - Traffic channel active • Bit to check in ParamPresenceMask - **24**
currDBTechAvail	• Current Data Bearer technology available • Bit to check in ParamPresenceMask - **29**
ratMask	• RAT mask to indicate type of technology • Values – 0x00 - DONT_CARE – 0x8000 - NULL_BEARER • CDMA RAT mask – 0x01 - CDMA_1X – 0x02 - EVDO_REV0 – 0x05 - HRPD – 0x0B - EHRPD • UMTS RAT mask – 0x03 - GPRS – 0x04 - WCDMA – 0x06 - EDGE – 0x07 - HSDPA and WCDMA – 0x08 - WCDMA and HSUPA – 0x09 - HSDPA and HSUPA – 0x0A - LTE – 0x0C - HSDPA+ and WCDMA – 0x0D - HSDPA+ and HSUPA – 0x0E - DC_HSDPA+ and WCDMA – 0x0F - DC_HSDPA+ and HSUPA • Bit to check in ParamPresenceMask - **29**
soMask	• SO Mask • Bit to check in ParamPresenceMask - **29**
dataSysStatAvail	• Data System Status available • Bit to check in ParamPresenceMask - **36**

prefNetwork	• preferred network • Values – 0 - 3GPP – 1 - 3GPP2
currNWInfo	• Current Network Info • see wds_currNetworkInfo for more info
dBtechExtAvail	Data bearer technology extended available • Bit to check in ParamPresenceMask - **42**
dBtechnologyExt	• Data bearer technology Extended. • Values – WDS_BEARER_TECH_NETWORK_3GPP (0) - 3GPP – WDS_BEARER_TECH_NETWORK_3GPP2 (1) - 3GPP2 • Bit to check in ParamPresenceMask - **42**
dBTechExtRat-Value	• Data bearer technology Extended RAT Value • Values – WDS_BEARER_TECH_RAT_EX_NULL_BEARER (0x00) - NULL bearer – WDS_BEARER_TECH_RAT_EX_3GPP_WCDMA (0x01) - 3GPP WCDMA – WDS_BEARER_TECH_RAT_EX_3GPP_GERAN (0x02) - 3GPP GERAN – WDS_BEARER_TECH_RAT_EX_3GPP_LTE (0x03) - 3GPP LTE – WDS_BEARER_TECH_RAT_EX_3GPP_TDSCDMA (0x04) - 3GPP TDSCDMA – WDS_BEARER_TECH_RAT_EX_3GPP_WLAN (0x05) - 3GPP WLAN – WDS_BEARER_TECH_RAT_EX_3GPP_MAX (0x64) - 3GPP maximum – WDS_BEARER_TECH_RAT_EX_3GPP2_1X (0x65) - 3GPP2 1X – WDS_BEARER_TECH_RAT_EX_3GPP2_HRPD (0x66) - 3GPP2 HRPD – WDS_BEARER_TECH_RAT_EX_3GPP2_EHRPD (0x67) - 3GPP2 EHRPD – WDS_BEARER_TECH_RAT_EX_3GPP2_WLAN (0x68) - 3GPP2 WLAN – WDS_BEARER_TECH_RAT_EX_3GPP2_MAX (0xC8) - 3GPP2 maximum • Bit to check in ParamPresenceMask - **42**

dBTechExtSo-Mask	• Data bearer technology Extended SO Mask • Service Option (SO) mask to indicate the service option or type of application.An SO mask value of zero indicates that this field is ignored. • Values – 0x00 - SO mask unspecified – 3GPP SO mask * 0x01 - WCDMA * 0x02 - HSDPA * 0x04 - HSUPA * 0x08 - HSDPAPLUS * 0x10 - DC HSDPAPLUS * 0x20 - 64 QAM * 0x40 - HSPA * 0x80 - GPRS * 0x100 - EDGE * 0x200 - GSM * 0x400 - S2B * 0x800 - LTE limited service * 0x1000 - LTE FDD * 0x2000 - LTE TDD – 3GPP2 SO mask * 0x01000000 - 1X IS95 * 0x02000000 - 1X IS2000 * 0x04000000 - 1X IS2000 REL A * 0x08000000 - HDR REV0 DPA * 0x10000000 - HDR REVA DPA * 0x20000000 - HDR REVB DPA * 0x40000000 - HDR REVA MPA * 0x80000000 - HDR REVB MPA * 0x100000000 - HDR REVA EMPA * 0x200000000 - HDR REVB EMPA * 0x400000000 - HDR REVB MMPA * 0x800000000 - HDR EVDO FMC • Bit to check in ParamPresenceMask - **42**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.979.2 Field Documentation

8.979.2.1 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::currDBTechAvail

8.979.2.2 wds_currNetworkInfo unpack_wds_SLQSSetWdsEventCallback_ind_t::currNWInfo[255]

8.979.2.3 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dataSysStatAvail

8.979.2.4 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBTechAvail

8.979.2.5 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBtechExtAvail

8.979.2.6 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBTechExtRatValue

8.979.2.7 uint64_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBTechExtSoMask

8.979.2.8 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBTechnology

8.979.2.9 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dBtechnologyExt

8.979.2.10 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dormancyStatAvail

8.979.2.11 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::dormancyStatus

8.979.2.12 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::mipstatAvail

8.979.2.13 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::mipStatus

8.979.2.14 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::netInfoLen

8.979.2.15 swi_uint256_t unpack_wds_SLQSSetWdsEventCallback_ind_t::ParamPresenceMask

8.979.2.16 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::prefNetwork

8.979.2.17 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::ratMask

8.979.2.18 uint64_t unpack_wds_SLQSSetWdsEventCallback_ind_t::rx_bytes

8.979.2.19 uint64_t unpack_wds_SLQSSetWdsEventCallback_ind_t::rx_pkts

8.979.2.20 uint32_t unpack_wds_SLQSSetWdsEventCallback_ind_t::soMask

8.979.2.21 uint64_t unpack_wds_SLQSSetWdsEventCallback_ind_t::tx_bytes

8.979.2.22 uint64_t unpack_wds_SLQSSetWdsEventCallback_ind_t::tx_pkts

8.979.2.23 uint8_t unpack_wds_SLQSSetWdsEventCallback_ind_t::xferStatAvail

8.980 unpack_wds_SLQSSGetDHCPv4ClientConfig_t Struct Reference

Data Fields

- wdsDhcpv4HwConfig * pHwConfig
- wdsDhcpv4OptionList * pRequestOptionList
- swi_uint256_t ParamPresenceMask

8.980.1 Detailed Description

WDS SWI DHCPv4 Config Structure

Parameters

pHWConfig	• pointer to HW Config structure • See wdsDhcpv4HwConfig • Bit to check in ParamPresenceMask - **16**
pRequestOption-List	• pointer to Option List structure to be sent in DHCP request • See wdsDhcpv4OptionList • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.980.2 Field Documentation

8.980.2.1 swi_uint256_t unpack_wds_SLQSSGetDHCPv4ClientConfig_t::ParamPresenceMask

8.980.2.2 wdsDhcpv4HwConfig* unpack_wds_SLQSSGetDHCPv4ClientConfig_t::pHwConfig

8.980.2.3 wdsDhcpv4OptionList* unpack_wds_SLQSSGetDHCPv4ClientConfig_t::pRequestOptionList

8.981 unpack_wds_SLQSSGetLoopback_t Struct Reference

Data Fields

- uint8_t ByteLoopbackMode
- uint8_t ByteLoopbackMultiplier
- swi_uint256_t ParamPresenceMask

8.981.1 Detailed Description

This structure contains unpack Get loopback information.

Parameters

ByteLoopback-Mode	• Loopback Mode. – 0 - Disable – 1 - Enable • Bit to check in ParamPresenceMask - **16**
ByteLoopback-Multiplier	• Loopback multiplier. Number of downlink bytes to send for each uplink byte. • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.981.2 Field Documentation

8.981.2.1 uint8_t unpack_wds_SLQSSGetLoopback_t::ByteLoopbackMode

8.981.2.2 uint8_t unpack_wds_SLQSSGetLoopback_t::ByteLoopbackMultiplier

8.981.2.3 swi_uint256_t unpack_wds_SLQSSGetLoopback_t::ParamPresenceMask

8.982 unpack_wds_SLQSStartDataSession_t Struct Reference

Data Fields

- uint32_t * psid
- uint32_t * pFailureReason
- uint32_t * pVerboseFailReasonType
- uint32_t * pVerboseFailureReason
- swi_uint256_t ParamPresenceMask

8.982.1 Detailed Description

This structure contains unpack Start Data Session Information.

Parameters

psid	• Assigned session ID when starting a data session • Bit to check in ParamPresenceMask - **1**
pFailureReason	• Reason data session failed to be established • See qaGobiApiTableCallEndReasons.h for Call End Reason • Bit to check in ParamPresenceMask - **16**
pVerboseFail-ReasonType	• Parameter describing type of verbose failure reason • See qaGobiApiTableCallEndReasons.h for Call End Reason Type • Bit to check in ParamPresenceMask - **17**
pVerboseFailure-Reason	• Verbose reason explaining why call failed. Depends on verbFailReasonType parameter • See qaGobiApiTableCallEndReasons.h for Call End Reason • Bit to check in ParamPresenceMask - **17**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.982.2 Field Documentation

8.982.2.1 swi_uint256_t unpack_wds_SLQSStartDataSession_t::ParamPresenceMask

8.982.2.2 uint32_t* unpack_wds_SLQSStartDataSession_t::pFailureReason

8.982.2.3 uint32_t* unpack_wds_SLQSStartDataSession_t::psid

8.982.2.4 uint32_t* unpack_wds_SLQSStartDataSession_t::pVerboseFailReasonType

8.982.2.5 uint32_t* unpack_wds_SLQSStartDataSession_t::pVerboseFailureReason

8.983 unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t Struct Reference

Data Fields

- uint8_t contextId
- uint8_t bearerId
- int8_t apnName [100]
- uint32_t ipv4Address
- uint32_t ipv4GWAddress
- uint32_t prDNSIPv4Address
- uint32_t seDNSIPv4Address
- ipv6AddressInfo ipv6Address
- ipv6AddressInfo ipv6GWAddress
- uint16_t prDNSIPv6Address [8]
- uint16_t seDNSIPv6Address [8]
- uint32_t prPCSCFIPv4Address
- uint32_t sePCSCFIPv4Address
- uint16_t prPCSCFIPv6Address [8]
- uint16_t sePCSCFIPv6Address [8]
- swi_uint256_t ParamPresenceMask

8.983.1 Detailed Description

This structure contains the unpack parameters retrieved by the API unpack_wds_SLQSWdsSwiPDPRuntime-Settings

Parameters

contextId	(optional) • Context Identifier • Bit to check in ParamPresenceMask - **16**
bearerId	(optional) • Bearer Identity • An EPS bearer identity uniquely identifies an EPS bearer for one UE accessing via E-UTRAN. The EPS Bearer Identity is allocated by the MME. • Bit to check in ParamPresenceMask - **17**
apnName	(optional) • APN name associated with the context id • Bit to check in ParamPresenceMask - **18**
ipv4Address	(optional) • IPv4 Address • Bit to check in ParamPresenceMask - **19**

ipv4GWAddress	(optional) • IPv4 Gateway Address • Bit to check in ParamPresenceMask - **20**
prDNSIPv4-Address	(optional) • Primary DNS IPv4 Address • Bit to check in ParamPresenceMask - **21**
seDNSIPv4-Address	(optional) • Secondary DNS IPv4 Address • Bit to check in ParamPresenceMask - **22**
ipv6Address	(optional) • IPv6 Address • Bit to check in ParamPresenceMask - **23**
ipv6GWAddress	(optional) • IPv6 Gateway Address • See ipv6AddressInfo for more information • Bit to check in ParamPresenceMask - **24**
prDNSIPv6-Address	(optional) • Primary IPv6 DNS Address(in network byte order) • This is an 8-element array of 16-bit numbers, each of which is in big-endian format • Bit to check in ParamPresenceMask - **25**
seDNSIPv6-Address	(optional) • Secondary IPv6 DNS Address(in network byte order) • This is an 8-element array of 16-bit numbers, each of which is in big-endian format • Bit to check in ParamPresenceMask - **26**
prPCSCFIPv4-Address	(optional) • Primary PCSCF IPv4 Address • Bit to check in ParamPresenceMask - **27**
sePCSCFIPv4-Address	(optional) • Secondary PCSCF IPv4 Address • Bit to check in ParamPresenceMask - **28**
prPCSCFIPv6-Address	(optional) • Primary PCSCF IPv6 Address • This is an 8-element array of 16-bit numbers, each of which is in big-endian format • Bit to check in ParamPresenceMask - **29**
sePCSCFIPv6-Address	(optional) • Secondary PCSCF IPv6 Address • This is an 8-element array of 16-bit numbers, each of which is in big-endian format • Bit to check in ParamPresenceMask - **30**
ParamPresence-Mask	• bitmask representation to indicate valid parameters.

8.983.2 Field Documentation

8.983.2.1 int8_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::apnName[100]

8.983.2.2 uint8_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::bearerId

8.983.2.3 uint8_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::contextId

8.983.2.4 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::ipv4Address

8.983.2.5 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::ipv4GWAddress

8.983.2.6 ipv6AddressInfo unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::ipv6Address

8.983.2.7 ipv6AddressInfo unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::ipv6GWAddress

8.983.2.8 swi_uint256_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::ParamPresenceMask

8.983.2.9 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::prDNSIPv4Address

8.983.2.10 uint16_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::prDNSIPv6Address[8]

8.983.2.11 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::prPCSCFIPv4Address

8.983.2.12 uint16_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::prPCSCFIPv6Address[8]

8.983.2.13 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::seDNSIPv4Address

8.983.2.14 uint16_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::seDNSIPv6Address[8]

8.983.2.15 uint32_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::sePCSCFIPv4Address

8.983.2.16 uint16_t unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t::sePCSCFIPv6Address[8]

8.984 UnPackGetProfileSettingOut Struct Reference

Data Fields

- UnpackQmiProfileInfo curProfile
- uint16_t * pExtErrCode

8.984.1 Detailed Description

This structure contains the profile settings output

Parameters

curProfile	• Structure containing details of the current profile • See UnpackQmiProfileInfo

pExtErrCode	• pointer to a 2 byte extended error code • Error code will only will be present if error code eQCWWAN_ERR_QMI_EXTENDED_INTERNAL is returned by device. • See qm_wds_ds_profile_extended_err_codes enum in qmerrno.h for received error description. • Bit to check in ParamPresenceMask - **224**

8.984.2 Field Documentation

8.984.2.1 UnpackQmiProfileInfo UnPackGetProfileSettingOut::curProfile

8.984.2.2 uint16_t* UnPackGetProfileSettingOut::pExtErrCode

8.985 UnpackSwiAvmsEventReportBinaryUpdateSessionInfo Struct Reference

Data Fields

- uint8_t bBinaryType
- uint8_t bState
- uint8_t bUserInputRequest
- uint16_t wUserInputTimeout
- uint32_t ulPkgDownloadSize
- uint32_t ulPkgDownloadComplete
- uint16_t wUpdateCompeteStatus
- uint8_t bSerity
- uint16_t wVersionLength
- uint8_t szVersion [128]
- uint16_t wNameLength
- uint8_t szName [128]
- uint16_t wDescriptionLength
- uint8_t szDescription [1024]
- uint8_t TlvPresent

8.985.1 Detailed Description

This structure contains unpack event report binary update session information parameters.

Parameters

bBinaryType	: Type • 1 - Firmware. • 2 - User App. • 3 - Legato Framework.

bStat	: State • 0x01 - No binary update available. • 0x02 - Query binary Download. • 0x03 - Binary Downloading. • 0x04 - Binary downloaded. • 0x05 -Query Binary Update. • 0x06 - Binary updating. • 0x07 - Binary updated.
bUserInput-Request	Bit mask of available user inputs. • 0x00 - No user input required. Informational indication. • 0x01 - Accept. • 0x02 - Reject.
wUserInput-Timeout	Timeout for user input in minutes. A value of 0 means no time-out.
ulPkgDownload-Size	The size (in bytes) of the update package
ulPkgDownload-Complete	The number of bytes being downloaded. For downloading state, this value shall be $>$ 0 and incremented toward the pkg_dload_size. For other states, the value shall be 0 as it is meaningless.
wUpdate-CompeteStatus	Result code.This field should be looked at only when the AVMS session is complete.
bSerity	Serity. • 0x01 - Mandatory. • 0x02 - Optional.
wVersionLength	Length of FW Version string in bytes.
szVersion	FW Version string in ASCII.
wNameLength	Length Package Name string in bytes.
szName	Package Name in UCS2.
wDescription-Length	Length of description in bytes.
szDescription	Description of Update Package in USC2.
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.985.2 Field Documentation

8.985.2.1 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::bBinaryType

8.985.2.2 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::bSerity

8.985.2.3 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::bState

8.985.2.4 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::bUserInputRequest

8.985.2.5 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::szDescription[1024]

8.985.2.6 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::szName[128]

8.985.2.7 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::szVersion[128]

8.985.2.8 uint8_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::TlvPresent

8.985.2.9 uint32_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::ulPkgDownloadComplete

8.985.2.10 uint32_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::ulPkgDownloadSize

8.985.2.11 uint16_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::wDescriptionLength

8.985.2.12 uint16_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::wNameLength

8.985.2.13 uint16_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::wUpdateCompeteStatus

8.985.2.14 uint16_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::wUserInputTimeout

8.985.2.15 uint16_t UnpackSwiAvmsEventReportBinaryUpdateSessionInfo::wVersionLength

8.986 UnpackSwiAvmsEventReportConfig Struct Reference

Data Fields

- uint8_t bState
- uint8_t bUserInputRequest
- uint16_t wUserInputTimeout
- uint16_t wAlertMsgLength
- uint8_t szAlertMsg [200]
- uint8_t TlvPresent

8.986.1 Detailed Description

This structure contains unpack event report configure parameters.

Parameters

bState	State. • 0x01 - AVMS Read Request. • 0x02 - AVMS Change Request. • 0x03 - AVMS Config Complete.
bUserInput-Request	Bit mask of available user inputs. • 0x00 - No user input required. Informational indication. • 0x01 - Accept. • 0x02 - Reject.
wUserInput-Timeout	Timeout for user input in seconds. A value of 0 means no time-out
wAlertMsg-Length	Length of Alert message string in bytes.
szAlertMsg	Alert message in UCS2.
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.986.2 Field Documentation

8.986.2.1 uint8_t UnpackSwiAvmsEventReportConfig::bState

8.986.2.2 uint8_t UnpackSwiAvmsEventReportConfig::bUserInputRequest

8.986.2.3 uint8_t UnpackSwiAvmsEventReportConfig::szAlertMsg[200]

8.986.2.4 uint8_t UnpackSwiAvmsEventReportConfig::TlvPresent

8.986.2.5 uint16_t UnpackSwiAvmsEventReportConfig::wAlertMsgLength

8.986.2.6 uint16_t UnpackSwiAvmsEventReportConfig::wUserInputTimeout

8.987 UnpackSwiAvmsEventReportConnectionRequest Struct Reference

Data Fields

- uint8_t bUserInputRequest
- uint16_t wUserInputTimeout
- uint8_t TlvPresent

8.987.1 Detailed Description

This structure contains unpack event report connection request parameters.

Parameters

bUserInput-Request	Bit mask of available user inputs. • 0x00 - No user input required. Informational indication. • 0x01 - Accept. • 0x02 - Reject.
bUserInput-Request	Timeout for user input in minutes. A value of 0 means no time-out.
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.987.2 Field Documentation

8.987.2.1 uint8_t UnpackSwiAvmsEventReportConnectionRequest::bUserInputRequest

8.987.2.2 uint8_t UnpackSwiAvmsEventReportConnectionRequest::TlvPresent

8.987.2.3 uint16_t UnpackSwiAvmsEventReportConnectionRequest::wUserInputTimeout

8.988 UnpackSwiAvmsEventReportDataSessionStatus Struct Reference

Data Fields

- uint8_t bType
- uint16_t wErrorCode
- uint8_t TlvPresent

8.988.1 Detailed Description

This structure contains unpack evnet report data session status parameters.

Parameters

bType	Notification type. • 0: Data session closed. • 1: Data session activated. • 2: Register made. -3: Data session error.
wErrorCode	LWM2M Session error code. • 0x0000: none
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.988.2 Field Documentation

8.988.2.1 uint8_t UnpackSwiAvmsEventReportDataSessionStatus::bType

8.988.2.2 uint8_t UnpackSwiAvmsEventReportDataSessionStatus::TlvPresent

8.988.2.3 uint16_t UnpackSwiAvmsEventReportDataSessionStatus::wErrorCode

8.989 UnpackSwiAvmsEventReportHTTPStatus Struct Reference

Data Fields

- uint16_t wHTTPStatus
- uint8_t TlvPresent

8.989.1 Detailed Description

This structure contains unpack event report HTTP status parameters.

Parameters

wHTTPStatus	See RFC 7231. • 100 - Continue • 101 - Switching Protocols • 200 - OK • 201 - Created • 202 - Accepted • 203 - Non-Authoritative Information • 204 - No Content • 205 - Reset Content • 206 - Partial Content • 300 - Multiple Choices • 301 - Moved Permanently • 302 - Found • 303 - See Other • 304 - Not Modified • 305 - Use Proxy • 307 - Temporary Redirect • 400 - Bad Request • 401 - Unauthorized • 402 - Payment Required • 403 - Forbidden • 404 - Not Found • 405 - Method Not Allowed • 406 - Not Acceptable • 407 - Proxy Authentication Required • 408 - Request Timeout • 409 - Conflict • 410 - Gone • 411 - Length Required • 412 - Precondition Failed • 413 - Payload Too Large • 414 - URI Too Long • 415 - Unsupported Media Type • 416 - Range Not Satisfiable • 417 - Expectation Failed • 426 - Upgrade Required • 500 - Internal Server Error • 501 - Not Implemented • 502 - Bad Gateway • 503 - Service Unavailable • 504 - Gateway Timeout • 505 - HTTP Version Not Supported
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.989.2 Field Documentation

8.989.2.1 uint8_t UnpackSwiAvmsEventReportHTTPStatus::TlvPresent

8.989.2.2 uint16_t UnpackSwiAvmsEventReportHTTPStatus::wHTTPStatus

8.990 UnpackSwiAvmsEventReportNotification Struct Reference

Data Fields

- uint8_t bNotification
- uint16_t wSessionStatus
- uint8_t TlvPresent

8.990.1 Detailed Description

This structure contains unpack event report notification parameters.

Parameters

bNotification	Notification. • 0x14 - Module starts sending data to server. • 0x15 - Authentication with the server. • 0x16 - session with the server is ended.
wSessionStatus	This field will set to the session status for notifications that occur at the end of a session, zero for all other notifications. • 0x0000: Successful: Session succeeded • 0x0001: Break: Session succeeded • 0x0002: Large Object Handled: Session succeeded • 0x0003: No status: Session succeeded • 0x0004: No more commands: Session succeeded • 0x0005: User cancel: Session cancelled • 0x0100-0x01FF: General errors • 0x0200-0x02FF: Syncml errors • 0x0300-0x03FF: Authentication errors • 0x0400-0x04FF: Protocol errors • 0x0500-0x05FF: Tree errors (DM Only) • 0x0600-0x06FF: Not applicable • 0x0700-0x07FF: Trigger errors • 0x0800-0x08FF: FUMO errors • 0x0900-0x09FF: Communication errors • 0x0A00-0x0AFF: Parsing errors • 0x0B00-0x0CFF: Not applicable • 0x7F00-0x7F12:Insignia errors • 0x7F13: Illegal text: Text received contains illegal characters • 0x7F14: Download failure: Failed to download FOTA image • 0x7F15: Empty session: Session ran successfully, but no information wasa updated • 0x7F16: Factory reset successful: Factory reset succeeded • 0x7F17: Factory reset fail: Factory reset failed
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.990.2 Field Documentation

8.990.2.1 uint8_t UnpackSwiAvmsEventReportNotification::bNotification

8.990.2.2 uint8_t UnpackSwiAvmsEventReportNotification::TlvPresent

8.990.2.3 uint16_t UnpackSwiAvmsEventReportNotification::wSessionStatus

8.991 UnpackSwiAvmsEventReportPackageID Struct Reference

Data Fields

- uint8_t bPackageID
- uint8_t TlvPresent

8.991.1 Detailed Description

This structure contains unpack event report package ID parameters.

Parameters

bPackageID	Package ID of the application binary that this AVMS_EVENT_ID notification is for.
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.991.2 Field Documentation

8.991.2.1 uint8_t UnpackSwiAvmsEventReportPackageID::bPackageID

8.991.2.2 uint8_t UnpackSwiAvmsEventReportPackageID::TlvPresent

8.992 UnpackSwiAvmsEventReportRegStatus Struct Reference

Data Fields

- uint8_t bRegStatus
- uint8_t TlvPresent

8.992.1 Detailed Description

This structure contains unpack event report registration status parameters.

Parameters

bRegStatus	LWM2M Registration status. • 0: Need Bootstrap. • 1: Bootstrap made. • 2: Register made. -3: Update made.
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.992.2 Field Documentation

8.992.2.1 uint8_t UnpackSwiAvmsEventReportRegStatus::bRegStatus

8.992.2.2 uint8_t UnpackSwiAvmsEventReportRegStatus::TlvPresent

8.993 UnpackSwiAvmsEventReportSessionType Struct Reference

Data Fields

- uint8_t bType
- uint8_t TlvPresent

8.993.1 Detailed Description

This structure contains unpack event report session type parameters.

Parameters

bType	Session Type. • 0: Bootstrap session. • 1. DM session
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.993.2 Field Documentation

8.993.2.1 uint8_t UnpackSwiAvmsEventReportSessionType::bType

8.993.2.2 uint8_t UnpackSwiAvmsEventReportSessionType::TlvPresent

8.994 UnpackSwiAvmsEventReportWAMSParamChange Struct Reference

Data Fields

- uint16_t wWamsChangeMask
- uint8_t TlvPresent

8.994.1 Detailed Description

This structure contains unpack event report WAMS parameter change parameters.

Parameters

wWamsChange-Mask	Mask of WAMS parameters changed. • By default set to 0xFF for all changes. • 0x01 - device_login • 0x02 - device_MD5_key • 0x04 - server_login • 0x08 - server_MD5_key • 0x10 - server_URL • 0x20 - Nonce • 0x40 - Application key
TlvPresent	Boolean indicating the presence of the TLV in the QMI response

8.994.2 Field Documentation

8.994.2.1 uint8_t UnpackSwiAvmsEventReportWAMSParamChange::TlvPresent

8.994.2.2 uint16_t UnpackSwiAvmsEventReportWAMSParamChange::wWamsChangeMask

8.995 unpackWdsProfileParam Union Reference

Data Fields

- LibpackProfile3GPP SlqsProfile3GPP
- LibpackProfile3GPP2 SlqsProfile3GPP2

8.995.1 Detailed Description

This union WdsProfileParam consists of Profile3GPP and Profile3GPP2 out of which one will be used to create profile.

Parameters

SlqsProfile3GPP	3GPP profile • See LibpackProfile3GPP
SlqsProfile3GP-P2	3GPP2 profile • See LibpackProfile3GPP2

8.995.2 Field Documentation

8.995.2.1 LibpackProfile3GPP unpackWdsProfileParam::SlqsProfile3GPP

8.995.2.2 LibpackProfile3GPP2 unpackWdsProfileParam::SlqsProfile3GPP2

8.996 voice_airTimer Struct Reference

Data Fields

- uint8_t namID
- uint32_t airTimerValue

8.996.1 Detailed Description

This structure contains information about the Air Timer.

Parameters

namID	• Index of the NAM(Number Assignment Module) to be configured. • Range 0 to 3. • Some modems support only 1 or 2 NAMs. • 0xFF,if not available.

airTimerValue	• Time in minutes. • Cumulative air time is slammed. • 0xFFFFFFFF,if not available.

8.996.2 Field Documentation

8.996.2.1 uint32_t voice_airTimer::airTimerValue

8.996.2.2 uint8_t voice_airTimer::namID

8.997 voice_allCallsAlphaIDInfo Struct Reference

Data Fields

- uint8_t callID
- voice_alphaIDInfo AlphaIDInfo

8.997.1 Detailed Description

This structure contains information for Alpha Identifier for All Calls

Parameters

callID	• Unique call identifier for the call.
AlphaIDInfo	• See voice_alphaIDInfo for more information.

8.997.2 Field Documentation

8.997.2.1 voice_alphaIDInfo voice_allCallsAlphaIDInfo::AlphaIDInfo

8.997.2.2 uint8_t voice_allCallsAlphaIDInfo::callID

8.998 voice_allCallsDiagInfo Struct Reference

Data Fields

- uint8_t callID
- voice_diagInfo DiagInfo

8.998.1 Detailed Description

This structure contains Diagnostic Information for All Calls

Parameters

callID	• Unique call identifier for the call.
DiagInfo	• See voice_diagInfo for more information.

8.998.2 Field Documentation

8.998.2.1 uint8_t voice_allCallsDiagInfo::callID

8.998.2.2 voice_diagInfo voice_allCallsDiagInfo::DiagInfo

8.999 voice_allCallsUUSInfo Struct Reference

Data Fields

- uint8_t callID
- voice_UUSInfo uusInfo

8.999.1 Detailed Description

This structure contains information for User to User Signaling Service for All Calls.

Parameters

callID	• Unique call identifier for the call.
uusInfo	• See voice_UUSInfo for more information.

8.999.2 Field Documentation

8.999.2.1 uint8_t voice_allCallsUUSInfo::callID

8.999.2.2 voice_UUSInfo voice_allCallsUUSInfo::uusInfo

8.1000 voice_alphaIDInfo Struct Reference

Data Fields

- uint8_t alphaDcs
- uint8_t alphaLen
- uint8_t alphaText [255]

8.1000.1 Detailed Description

This structure contains information about the Alpha Identifier.

Parameters

alphaDcs	• Alpha coding scheme – 0x01 - GSM Default_Char – 0x02 - UCS2 – 0xFF - Not Available
alphaLen	• Number of sets of the following elements: – pAlpha_text • If zero(0) then no further information exists.
alphaText[MAX_VOICE_DESCRIPTION_LENGTH]	• Data encoded as per the alpha_dcs

8.1000.2 Field Documentation

8.1000.2.1 uint8_t voice_alphaIDInfo::alphaDcs

8.1000.2.2 uint8_t voice_alphaIDInfo::alphaLen

8.1000.2.3 uint8_t voice_alphaIDInfo::alphaText[255]

8.1001 voice_arrAlertingPattern Struct Reference

Data Fields

- uint8_t numInstances
- uint8_t callID [20]
- uint32_t alertingPattern [20]

8.1001.1 Detailed Description

This structure contains an array of Alerting Pattern.

Parameters

numInstances	• Number of callID, alertingPattern that follow. • If zero(0) then no further information exists.
callID[VOICE_-MAX_NO_OF_-CALLS]	• Array of Unique call identifier for the call.
alertingPattern[-VOICE_MAX_N-O_OF_CALLS]	• Array of Alerting pattern. – 0x00 - QMI_VOICE_ALERTING_PATTERN_1 - Pattern 1 – 0x01 - QMI_VOICE_ALERTING_PATTERN_2 - Pattern 2 – 0x02 - QMI_VOICE_ALERTING_PATTERN_3 - Pattern 3 – 0x04 - QMI_VOICE_ALERTING_PATTERN_5 - Pattern 5 – 0x05 - QMI_VOICE_ALERTING_PATTERN_6 - Pattern 6 – 0x06 - QMI_VOICE_ALERTING_PATTERN_7 - Pattern 7 – 0x07 - QMI_VOICE_ALERTING_PATTERN_8 - Pattern 8 – 0x08 - QMI_VOICE_ALERTING_PATTERN_9 - Pattern 9

8.1001.2 Field Documentation

8.1001.2.1 uint32_t voice_arrAlertingPattern::alertingPattern[20]

8.1001.2.2 uint8_t voice_arrAlertingPattern::callID[20]

8.1001.2.3 uint8_t voice_arrAlertingPattern::numInstances

8.1002 voice_arrAlertingType Struct Reference

Data Fields

- uint8_t numInstances
- uint8_t callID [20]
- uint8_t AlertingType [20]

8.1002.1 Detailed Description

This structure contains an array of Alerting Type.

Parameters

numInstances	• Number of callID, AlertingType that follow. • If zero(0) then no further information exists.
callID[VOICE_-MAX_NO_OF_-CALLS]	• Array of Unique call identifier for the call.

AlertingType[VOICE_MAX_NO_OF_CALLS]	• Array of Alerting type. – 0x00 - ALERTING_LOCAL - Local – 0x01 - ALERTING_REMOTE - Remote

8.1002.2 Field Documentation

8.1002.2.1 uint8_t voice_arrAlertingType::AlertingType[20]

8.1002.2.2 uint8_t voice_arrAlertingType::callID[20]

8.1002.2.3 uint8_t voice_arrAlertingType::numInstances

8.1003 voice_arrAlphaID Struct Reference

Data Fields

- uint8_t numInstances
- voice_allCallsAlphaIDInfo allCallsAlphaIDInfoArr [20]

8.1003.1 Detailed Description

This structure contains an array of Alpha ID Info

Parameters

numInstances	• Number of allCallsAlphaIDInfo that follow. • If zero(0) then no further information exists.
allCallsAlphaIDInfo[VOICE_MAX_NO_OF_CALLS]	• Array of allCallsAlphaIDInfo. • See voice_allCallsAlphaIDInfo for more information.

8.1003.2 Field Documentation

8.1003.2.1 voice_allCallsAlphaIDInfo voice_arrAlphaID::allCallsAlphaIDInfoArr[20]

8.1003.2.2 uint8_t voice_arrAlphaID::numInstances

8.1004 voice_arrCalledPartyNum Struct Reference

Data Fields

- uint8_t numInstances
- voice_peerNumberInfo CalledPartyNum [20]

8.1004.1 Detailed Description

This structure contains an array of Called Party Numbers consisting of information of all the numbers which have been called from the device.

Parameters

numInstances	• Number of calledPartyNum that follow. • If zero(0) then no further information exists.
CalledPartyNum[VOICE_MAX_NO_OF_CALLS]	• Array of CalledPartyNum. • See voice_peerNumberInfo for more information.

8.1004.2 Field Documentation

8.1004.2.1 voice_peerNumberInfo voice_arrCalledPartyNum::CalledPartyNum[20]

8.1004.2.2 uint8_t voice_arrCalledPartyNum::numInstances

8.1005 voice_arrCallEndReason Struct Reference

Data Fields

- uint8_t numInstances
- uint8_t callID [20]
- uint16_t callEndReason [20]

8.1005.1 Detailed Description

This structure contains an array of Call End Reasons.

Parameters

numInstances	• Number of callID, callEndReason that follow. • If zero(0) then no further information exists.
callID[VOICE_MAX_NO_OF_CALLS]	• Array of Unique call identifier for the call.
callEndReason[VOICE_MAX_NO_OF_CALLS]	• Array of Call End Reason . • See Table9 qaGobiApiTableVoiceCallEndReasons.h for a list of valid voice-related call end reasons

8.1005.2 Field Documentation

8.1005.2.1 uint16_t voice_arrCallEndReason::callEndReason[20]

8.1005.2.2 uint8_t voice_arrCallEndReason::callID[20]

8.1005.2.3 uint8_t voice_arrCallEndReason::numInstances

8.1006 voice_arrCallInfo Struct Reference

Data Fields

- uint8_t numInstances
- voice_getAllCallInformation getAllCallInfo [20]

8.1006.1 Detailed Description

This structure contains an array of Call Info

Parameters

numInstances	• Number of getAllCallInfo that follow. • If zero(0) then no further information exists.
getAllCallInfo[VOICE_MAX_NO_OF_CALLS]	• Array of CallInfo. • See voice_getAllCallInformation for more information.

8.1006.2 Field Documentation

8.1006.2.1 voice_getAllCallInformation voice_arrCallInfo::getAllCallInfo[20]

8.1006.2.2 uint8_t voice_arrCallInfo::numInstances

8.1007 voice_arrConnectPartyNum Struct Reference

Data Fields

- uint8_t numInstances
- voice_peerNumberInfo ConnectedPartyNum [20]

8.1007.1 Detailed Description

This structure contains an array of Connected Party Numbers consisting of information regarding all the devices connected.

Parameters

numInstances	• Number of ConnectedPartyNum that follow. • If zero(0) then no further information exists.
ConnectedPartyNum[VOICE_MAX_NO_OF_CALLS]	• Array of ConnectedPartyNum. • See voice_peerNumberInfo for more information.

8.1007.2 Field Documentation

8.1007.2.1 voice_peerNumberInfo voice_arrConnectPartyNum::ConnectedPartyNum[20]

8.1007.2.2 uint8_t voice_arrConnectPartyNum::numInstances

8.1008 voice_arrDiagInfo Struct Reference

Data Fields

- uint8_t numInstances
- voice_allCallsDiagInfo DiagInfo [20]

8.1008.1 Detailed Description

This structure contains an array of Diagnostic Information.

Parameters

numInstances	• Number of DiagInfo that follow. • If zero(0) then no further information exists.
DiagInfo[VOICE_MAX_NO_OF_CALLS]	• Array of DiagInfo. • See voice_allCallsDiagInfo for more information.

8.1008.2 Field Documentation

8.1008.2.1 voice_allCallsDiagInfo voice_arrDiagInfo::DiagInfo[20]

8.1008.2.2 uint8_t voice_arrDiagInfo::numInstances

8.1009 voice_arrRedirPartyNum Struct Reference

Data Fields

- uint8_t numInstances
- voice_peerNumberInfo RedirPartyNum [20]

8.1009.1 Detailed Description

This structure contains an array of Redirecting Party Numbers consisting of information of all the numbers which have been redirected from the device.

Parameters

numInstances	• Number of redirPartyNum that follow. • If zero(0) then no further information exists.

RedirPartyNum[VOICE_MAX_NO_OF_CALLS]	• Array of RedirPartyNum. • See voice_peerNumberInfo for more information.

8.1009.2 Field Documentation

8.1009.2.1 uint8_t voice_arrRedirPartyNum::numInstances

8.1009.2.2 voice_peerNumberInfo voice_arrRedirPartyNum::RedirPartyNum[20]

8.1010 voice_arrRemotePartyName Struct Reference

Data Fields

- uint8_t numInstances
- voice_getAllCallRmtPtyName GetAllCallRmtPtyName [20]

8.1010.1 Detailed Description

This structure contains an array of Remote Party Names

Parameters

numInstances	• Number of remotePartyName that follow. • If zero(0) then no further information exists.
GetAllCallRmtPtyName[MAX_NO_OF_CALLS]	• Array of remotePartyName. • See voice_getAllCallRmtPtyName for more information.

8.1010.2 Field Documentation

8.1010.2.1 voice_getAllCallRmtPtyName voice_arrRemotePartyName::GetAllCallRmtPtyName[20]

8.1010.2.2 uint8_t voice_arrRemotePartyName::numInstances

8.1011 voice_arrRemotePartyNum Struct Reference

Data Fields

- uint8_t numInstances
- voice_getAllCallRmtPtyNum RmtPtyNum [20]

8.1011.1 Detailed Description

This structure contains an array of Remote Party Numbers

Parameters

numInstances	• Number of remotePartyNum that follow. • If zero(0) then no further information exists.
RmtPtyNum[VOICE_MAX_NO_OF_CALLS]	• Array of remotePartyNum. • See voice_getAllCallRmtPtyNum for more information.

8.1011.2 Field Documentation

8.1011.2.1 uint8_t voice_arrRemotePartyNum::numInstances

8.1011.2.2 voice_getAllCallRmtPtyNum voice_arrRemotePartyNum::RmtPtyNum[20]

8.1012 voice_arrSvcOption Struct Reference

Data Fields

- uint8_t numInstances
- uint8_t callID [20]
- uint16_t srvOption [20]

8.1012.1 Detailed Description

This structure contains array an of Servicing option.

Parameters

numInstances	• Number of callID, srvOption that follow. • If zero(0) then no further information exists.
callID[VOICE_MAX_NO_OF_CALLS]	• Array of Unique call identifier for the call.
srvOption[VOICE_MAX_NO_OF_CALLS]	• Array of Service option. • See Table9 qaGobiApiTableServiceOptions.h for standard service option number assignments.

8.1012.2 Field Documentation

8.1012.2.1 uint8_t voice_arrSvcOption::callID[20]

8.1012.2.2 uint8_t voice_arrSvcOption::numInstances

8.1012.2.3 uint16_t voice_arrSvcOption::srvOption[20]

8.1013 voice_arrUUSInfo Struct Reference

Data Fields

- uint8_t numInstances
- voice_allCallsUUSInfo AllCallsUUSInfo [20]

8.1013.1 Detailed Description

This structure contains an array of User to User Signaling Service Information

Parameters

numInstances	• Number of allCallsUUSInfo that follow. • If zero(0) then no further information exists.
AllCallsUUSInfo[VOICE_MAX_NO_OF_CALLS]	• Array of allCallsUUSInfo. • See voice_allCallsUUSInfo for more information.

8.1013.2 Field Documentation

8.1013.2.1 voice_allCallsUUSInfo voice_arrUUSInfo::AllCallsUUSInfo[20]

8.1013.2.2 uint8_t voice_arrUUSInfo::numInstances

8.1014 voice_burstDTMFInfo Struct Reference

Data Fields

- uint8_t * pCallID
- uint8_t digitCnt
- uint8_t pDigitBuff [255]

8.1014.1 Detailed Description

This structure contains Voice Burst DTMF Information

Parameters

pCallID	• Call ID associated with call on which the DTMF information has to be sent. A burst DTMF request is sent to the current active/alerting call when pCallId is set to 0xFF. • This is IN/OUT parameter, value passed by user will be packed in request and value received from the device would be returned to the user. • If the call ID value received is 0, no value has been returned by the device • NULL pointer - Invalid data.
digitCnt	• Length of DTMF digit buffer which follows
pDigitBuff[MAX_VOICE_DESCRIPTION_LENGTH]	• DTMF digit buffer in ASCII, NULL terminated

8.1014.2 Field Documentation

8.1014.2.1 uint8_t voice_burstDTMFInfo::digitCnt

8.1014.2.2 uint8_t* voice_burstDTMFInfo::pCallID

8.1014.2.3 uint8_t voice_burstDTMFInfo::pDigitBuff[255]

8.1015 voice_calledPartyInfo Struct Reference

Data Fields

- uint8_t PI
- uint8_t SI
- uint8_t numType
- uint8_t numPlan
- uint8_t numLen
- uint8_t number [255]

8.1015.1 Detailed Description

This structure contains Called party Number Information

Parameters

PI	• Presentation indicator; refer to [S1, Table 2.7.4.4-1] for valid values.
SI	• Number of sets of following elements – Caller Id
SI	• Number screening indicator. • Values: – 0x00 - QMI_VOICE_SI_USER_PROVIDED_NOT_SCREENED - Provided user is not screened – 0x01 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_PASSED - Provided user passed verification – 0x02 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_FAILED - Provided user failed verification – 0x03 - QMI_VOICE_SI_NETWORK_PROVIDED - Provided network

numType	• Number type. • Values: – 0x00 - QMI_VOICE_NUM_TYPE_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_TYPE_INTERNATIONAL - International – 0x02 - QMI_VOICE_NUM_TYPE_NATIONAL - National – 0x03 - QMI_VOICE_NUM_TYPE_NETWORK_SPECIFIC - Network-specific – 0x04 - QMI_VOICE_NUM_TYPE_SUBSCRIBER - Subscriber – 0x05 - QMI_VOICE_NUM_TYPE_RESERVED - Reserved – 0x06 - QMI_VOICE_NUM_TYPE_ABBREVIATED - Abbreviated – 0x07 - QMI_VOICE_NUM_TYPE_RESERVED_EXTENSION - Reserved extension
numPlan	• Number plan. • Values: – 0x00 - QMI_VOICE_NUM_PLAN_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_PLAN_ISDN - ISDN – 0x03 - QMI_VOICE_NUM_PLAN_DATA - Data – 0x04 - QMI_VOICE_NUM_PLAN_TELEX - Telex – 0x08 - QMI_VOICE_NUM_PLAN_NATIONAL - National – 0x09 - QMI_VOICE_NUM_PLAN_PRIVATE - Private – 0x0B - QMI_VOICE_NUM_PLAN_RESERVED_CTS - Reserved cordless telephony system – 0x0F - QMI_VOICE_NUM_PLAN_RESERVED_EXTENSION - Reserved extension
numLen	• Provides the length of number which follow.
number[255]	• number of numLen length, NULL terminated.

8.1015.2 Field Documentation

8.1015.2.1 uint8_t voice_calledPartyInfo::number[255]

8.1015.2.2 uint8_t voice_calledPartyInfo::numLen

8.1015.2.3 uint8_t voice_calledPartyInfo::numPlan

8.1015.2.4 uint8_t voice_calledPartyInfo::numType

8.1015.2.5 uint8_t voice_calledPartyInfo::PI

8.1015.2.6 uint8_t voice_calledPartyInfo::SI

8.1016 voice_calledPartySubAdd Struct Reference

Data Fields

- uint8_t extBit

- uint8_t subAddrType
- uint8_t oddEvenInd
- uint8_t subAddrLen
- uint8_t subAddr [255]

8.1016.1 Detailed Description

This structure contains information about the Called Sub Party Addresses.

Parameters

extBit	• Extension bit.
subAddrType	• Subaddress type. – 0x00 - NSAP – 0x01 - USER
oddEvenInd	• Even/odd indicator. – 0x00 - Even number of address signals – 0x01 - Odd number of address signals
subAddrLen	• Number of sets of the following elements: – SubAddress
subAddr[MAX_VOICE_DESCRIPTION_LENGTH]	• Array of the SubAddress in BCD number format.

8.1016.2 Field Documentation

8.1016.2.1 uint8_t voice_calledPartySubAdd::extBit

8.1016.2.2 uint8_t voice_calledPartySubAdd::oddEvenInd

8.1016.2.3 uint8_t voice_calledPartySubAdd::subAddr[255]

8.1016.2.4 uint8_t voice_calledPartySubAdd::subAddrLen

8.1016.2.5 uint8_t voice_calledPartySubAdd::subAddrType

8.1017 voice_callerIDInfo Struct Reference

Data Fields

- uint8_t PI
- uint8_t callerIDLen
- uint8_t callerID [255]

8.1017.1 Detailed Description

This structure contains Caller ID Information

Parameters

PI	• Presentation indicator; refer to [S1, Table 2.7.4.4-1] for valid values.
callerIDLen	• Number of sets of following elements – Caller Id
pCallerID	• Caller ID in ASCII string.

8.1017.2 Field Documentation

8.1017.2.1 uint8_t voice_callerIDInfo::callerID[255]

8.1017.2.2 uint8_t voice_callerIDInfo::callerIDLen

8.1017.2.3 uint8_t voice_callerIDInfo::PI

8.1018 voice_callFwdTypeAndPlan Struct Reference

Data Fields

- uint8_t numberType
- uint8_t numberPlan

8.1018.1 Detailed Description

This structure contains Supplementary Service request parameters related to different features and their activation, deactivation, registration and erasure (applicable only for 3GPP)

Parameters

numberType	• Call forwarding number type – 0x00 - QMI_VOICE_NUM_TYPE_UNKNOWN Unknown – 0x01 - QMI_VOICE_NUM_TYPE_INTERNATIONAL International – 0x02 - QMI_VOICE_NUM_TYPE_NATIONAL National – 0x03 - QMI_VOICE_NUM_TYPE_NETWORK_SPECIFIC Network-specific – 0x04 - QMI_VOICE_NUM_TYPE_SUBSCRIBER Subscriber – 0x05 - QMI_VOICE_NUM_TYPE_RESERVED Reserved – 0x06 - QMI_VOICE_NUM_TYPE_ABBREVIATED Abbreviated – 0x07 - QMI_VOICE_NUM_TYPE_RESERVED_EXTENSION Reserved extension

numberPlan	• Call forwarding number plan – 0x00 - QMI_VOICE_NUM_PLAN_UNKNOWN Unknown – 0x01 - QMI_VOICE_NUM_PLAN_ISDN ISDN – 0x03 - QMI_VOICE_NUM_PLAN_DATA Data – 0x04 - QMI_VOICE_NUM_PLAN_TELEX Telex – 0x08 - QMI_VOICE_NUM_PLAN_NATIONAL National – 0x09 - QMI_VOICE_NUM_PLAN_PRIVATE Private – 0x0B - QMI_VOICE_NUM_PLAN_RESERVED_CTS Reserved cordless telephony system – 0x0F - QMI_VOICE_NUM_PLAN_RESERVED_EXTENSION Reserved extension

8.1018.2 Field Documentation

8.1018.2.1 uint8_t voice_callFwdTypeAndPlan::numberPlan

8.1018.2.2 uint8_t voice_callFwdTypeAndPlan::numberType

8.1019 voice_callFWExtInfo Struct Reference

Data Fields

- uint8_t SvcStatus
- uint8_t SvcClass
- uint8_t noReplyTimer
- uint8_t PI
- uint8_t SI
- uint8_t numType
- uint8_t numPlan
- uint8_t numLen
- uint8_t number [255]

8.1019.1 Detailed Description

This structure contains information for Get Call Forwarding Extended Information.

Parameters

SvcStatus	• Service status. Values: – 0x00 - SERVICE_STATUS_INACTIVE - Inactive – 0x01 - SERVICE_STATUS_ACTIVE - Active
SvcClass	• Service Class is a combination (sum) of information class constants • See qaGobiApiTableSupServiceInfoClasses.h for service classes.
noReplyTimer	• No reply timer value in seconds • A value of 0 indicates that no_reply_timer is ignored.

PI	• Presentation indicator; refer to [S1, Table 2.7.4.4-1] for valid values.
SI	• Number screening indicator. • Values: – 0x00 - QMI_VOICE_SI_USER_PROVIDED_NOT_SCREENED - Provided user is not screened – 0x01 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_PASSED - Provided user passed verification – 0x02 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_FAILED - Provided user failed verification – 0x03 - QMI_VOICE_SI_NETWORK_PROVIDED - Provided network
numType	• Number type. • Values: – 0x00 - QMI_VOICE_NUM_TYPE_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_TYPE_INTERNATIONAL - International – 0x02 - QMI_VOICE_NUM_TYPE_NATIONAL - National – 0x03 - QMI_VOICE_NUM_TYPE_NETWORK_SPECIFIC - Network-specific – 0x04 - QMI_VOICE_NUM_TYPE_SUBSCRIBER - Subscriber – 0x05 - QMI_VOICE_NUM_TYPE_RESERVED - Reserved – 0x06 - QMI_VOICE_NUM_TYPE_ABBREVIATED - Abbreviated – 0x07 - QMI_VOICE_NUM_TYPE_RESERVED_EXTENSION - Reserved extension
numPlan	• Number plan. • Values: – 0x00 - QMI_VOICE_NUM_PLAN_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_PLAN_ISDN - ISDN – 0x03 - QMI_VOICE_NUM_PLAN_DATA - Data – 0x04 - QMI_VOICE_NUM_PLAN_TELEX - Telex – 0x08 - QMI_VOICE_NUM_PLAN_NATIONAL - National – 0x09 - QMI_VOICE_NUM_PLAN_PRIVATE - Private – 0x0B - QMI_VOICE_NUM_PLAN_RESERVED_CTS - Reserved cordless telephony system – 0x0F - QMI_VOICE_NUM_PLAN_RESERVED_EXTENSION - Reserved extension
numLen	• Provides the length of number which follow.
number[255]	• number of numLen length, NULL terminated.

8.1019.2 Field Documentation

8.1019.2.1 uint8_t voice_callFWExtInfo::noReplyTimer

8.1019.2.2 uint8_t voice_callFWExtInfo::number[255]

8.1019.2.3 uint8_t voice_callFWExtInfo::numLen

8.1019.2.4 uint8_t voice_callFWExtInfo::numPlan

8.1019.2.5 uint8_t voice_callFWExtInfo::numType

8.1019.2.6 uint8_t voice_callFWExtInfo::PI

8.1019.2.7 uint8_t voice_callFWExtInfo::SI

8.1019.2.8 uint8_t voice_callFWExtInfo::SvcClass

8.1019.2.9 uint8_t voice_callFWExtInfo::SvcStatus

8.1020 voice_callFWInfo Struct Reference

Data Fields

- uint8_t SvcStatus
- uint8_t SvcClass
- uint8_t numLen
- uint8_t number [255]
- uint8_t noReplyTimer

8.1020.1 Detailed Description

This structure contains information for Get Call Forwarding Information.

Parameters

SvcStatus	• Service status. Values: – 0x00 - SERVICE_STATUS_INACTIVE - Inactive – 0x01 - SERVICE_STATUS_ACTIVE - Active
SvcClass	• Service Class is a combination (sum) of information class constants • See qaGobiApiTableSupServiceInfoClasses.h for service classes.
numLen	• Provides the length of number which follow.
number[255]	• number of numLen length, NULL terminated.
noReplyTimer	• No reply timer value in seconds • A value of 0 indicates that noReplyTimer is ignored.

8.1020.2 Field Documentation

8.1020.2.1 uint8_t voice_callFWInfo::noReplyTimer

8.1020.2.2 uint8_t voice_callFWInfo::number[255]

8.1020.2.3 uint8_t voice_callFWInfo::numLen

8.1020.2.4 uint8_t voice_callFWInfo::SvcClass

8.1020.2.5 uint8_t voice_callFWInfo::SvcStatus

8.1021 voice_callInfo Struct Reference

Data Fields

- uint8_t callID
- uint8_t callState
- uint8_t callType
- uint8_t direction
- uint8_t mode

8.1021.1 Detailed Description

This structure contains Information about call state changes. For example, when an incoming call is received, this structure is populated and indicate the incoming call information. When this incoming call is answered, the call status changes from INCOMING to CONVERSATION, which means a change in the call information and this structure is populated again with the changes and notified to/retrived by the user.

Parameters

callID	• Call identifier for the call queried for information. • If zero(0) then invalid.
callState	• Call state. – 0x01 - CALL_STATE_ORIGINATION - Origination – 0x02 - CALL_STATE_INCOMING - Incoming – 0x03 - CALL_STATE_CONVERSATION - Conversation – 0x04 - CALL_STATE_CC_IN_PROGRESS - Call is originating but waiting for call control to complete – 0x05 - CALL_STATE_ALERTING - Alerting – 0x06 - CALL_STATE_HOLD - Hold – 0x07 - CALL_STATE_WAITING - Waiting – 0x08 - CALL_STATE_DISCONNECTING - Disconnecting – 0x09 - CALL_STATE_END - End – 0x0A - CALL_STATE_SETUP - MT call is in Setup state in 3GPP – 0xFF - Not Available

callType	• Call type. – 0x00 - CALL_TYPE_VOICE - Voice – 0x02 - CALL_TYPE_VOICE_IP - Voice over IP – 0x06 - CALL_TYPE_OTAPA - OTAPA – 0x07 - CALL_TYPE_STD_OTASP - Standard OTASP – 0x08 - CALL_TYPE_NON_STD_OTASP - Nonstandard OTASP – 0x09 - CALL_TYPE_EMERGENCY - Emergency – 0xFF - Not Available
direction	• Direction. – 0x01 - CALL_DIRECTION_MO - MO call – 0x02 - CALL_DIRECTION_MT - MT call – 0xFF - Not Available
mode	• Mode. • If the mode field is "0x01 - CDMA",the optional Service Option, Voice Privacy, and OTASP Status (only for OTASP calls) TLVs are included in the response. – 0x01 - CALL_MODE_CDMA - CDMA – 0x02 - CALL_MODE_GSM - GSM – 0x03 - CALL_MODE_UMTS - UMTS – 0x04 - CALL_MODE_LTE - LTE – 0x05 - CALL_MODE_TDS - TD-SCDMA – 0xFF - Not Available

8.1021.2 Field Documentation

8.1021.2.1 uint8_t voice_callInfo::callID

8.1021.2.2 uint8_t voice_callInfo::callState

8.1021.2.3 uint8_t voice_callInfo::callType

8.1021.2.4 uint8_t voice_callInfo::direction

8.1021.2.5 uint8_t voice_callInfo::mode

8.1022 voice_callingPartyInfo Struct Reference

Data Fields

- uint8_t PI
- uint8_t SI
- uint8_t numType
- uint8_t numPlan
- uint8_t numLen
- uint8_t number [255]

8.1022.1 Detailed Description

This structure contains Calling party Number Information

Parameters

PI	• Presentation indicator; refer to [S1, Table 2.7.4.4-1] for valid values.
SI	• Number of sets of following elements – Caller Id
SI	• Number screening indicator. • Values: – 0x00 - QMI_VOICE_SI_USER_PROVIDED_NOT_SCREENED - Provided user is not screened – 0x01 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_PASSED - Provided user passed verification – 0x02 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_FAILED - Provided user failed verification – 0x03 - QMI_VOICE_SI_NETWORK_PROVIDED - Provided network
numType	• Number type. • Values: – 0x00 - QMI_VOICE_NUM_TYPE_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_TYPE_INTERNATIONAL - International – 0x02 - QMI_VOICE_NUM_TYPE_NATIONAL - National – 0x03 - QMI_VOICE_NUM_TYPE_NETWORK_SPECIFIC - Network-specific – 0x04 - QMI_VOICE_NUM_TYPE_SUBSCRIBER - Subscriber – 0x05 - QMI_VOICE_NUM_TYPE_RESERVED - Reserved – 0x06 - QMI_VOICE_NUM_TYPE_ABBREVIATED - Abbreviated – 0x07 - QMI_VOICE_NUM_TYPE_RESERVED_EXTENSION - Reserved extension
numPlan	• Number plan. • Values: – 0x00 - QMI_VOICE_NUM_PLAN_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_PLAN_ISDN - ISDN – 0x03 - QMI_VOICE_NUM_PLAN_DATA - Data – 0x04 - QMI_VOICE_NUM_PLAN_TELEX - Telex – 0x08 - QMI_VOICE_NUM_PLAN_NATIONAL - National – 0x09 - QMI_VOICE_NUM_PLAN_PRIVATE - Private – 0x0B - QMI_VOICE_NUM_PLAN_RESERVED_CTS - Reserved cordless telephony system – 0x0F - QMI_VOICE_NUM_PLAN_RESERVED_EXTENSION - Reserved extension
numLen	• Provides the length of number which follow.

number[255]	• number of numLen length, NULL terminated.

8.1022.2 Field Documentation

8.1022.2.1 uint8_t voice_callingPartyInfo::number[255]

8.1022.2.2 uint8_t voice_callingPartyInfo::numLen

8.1022.2.3 uint8_t voice_callingPartyInfo::numPlan

8.1022.2.4 uint8_t voice_callingPartyInfo::numType

8.1022.2.5 uint8_t voice_callingPartyInfo::PI

8.1022.2.6 uint8_t voice_callingPartyInfo::SI

8.1023 voice_ccSUPSType Struct Reference

Data Fields

- uint8_t svcType
- uint8_t reason

8.1023.1 Detailed Description

This structure contains information about the Call Control Supplementary Service Types

Parameters

svcType	• Service type. – 0x01 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_ACTIVATE - Activate – 0x02 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_DEACTIVATE - Deactivate – 0x03 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_REGISTER - Register – 0x04 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_ERASE - Erase – 0x05 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_INTERROGATE - Interrogate – 0x06 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_REGISTER_PASSWORD - Register password – 0x07 - VOICE_CC_SUPS_RESULT_SERVICE_TYPE_USSD - USSD – 0xFF - Not Available
reason	• Call control supplementary service result reason • Values: – See qaGobiApiTableCallControlReturnReasons.h for return reasons.

8.1023.2 Field Documentation

8.1023.2.1 uint8_t voice_ccSUPSType::reason

8.1023.2.2 uint8_t voice_ccSUPSType::svcType

8.1024 voice_CLIPResp Struct Reference

Data Fields

- uint8_t ActiveStatus
- uint8_t ProvisionStatus

8.1024.1 Detailed Description

This structure contains information about the Calling Line Identification Presentation (CLIP) supplementary service responses.

Parameters

ActiveStatus	• Active status. • Values: – 0x00 - ACTIVE_STATUS_INACTIVE - Inactive – 0x01 - ACTIVE_STATUS_ACTIVE - Active – 0xFF - Not Available
ProvisionStatus	• Provisioned status. • Values: – 0x00 - PROVISION_STATUS_NOT_PROVISIONED - Not provisioned – 0x01 - PROVISION_STATUS_PROVISIONED - Provisioned – 0xFF - Not Available

8.1024.2 Field Documentation

8.1024.2.1 uint8_t voice_CLIPResp::ActiveStatus

8.1024.2.2 uint8_t voice_CLIPResp::ProvisionStatus

8.1025 voice_CLIRResp Struct Reference

Data Fields

- uint8_t ActiveStatus
- uint8_t ProvisionStatus

8.1025.1 Detailed Description

This structure contains information about the Calling Line Identification Restriction (CLIR) supplementary service responses.

Parameters

ActiveStatus	• Active status. • Values: – 0x00 - ACTIVE_STATUS_INACTIVE - Inactive – 0x01 - ACTIVE_STATUS_ACTIVE - Active – 0xFF - Not Available
ProvisionStatus	• Provisioned status. • Values: – 0x00 - PROVISION_STATUS_NOT_PROVISIONED - Not provisioned – 0x01 - PROVISION_STATUS_PROVISIONED_PERMANENT - Permanently provisioned – 0x02 - PROVISION_STATUS_PRESENTATION_RESTRICTED - Restricted presentation – 0x03 - PROVISION_STATUS_PRESENTATION_ALLOWED - Allowed presentation – 0xFF - Not Available

8.1025.2 Field Documentation

8.1025.2.1 uint8_t voice_CLIRResp::ActiveStatus

8.1025.2.2 uint8_t voice_CLIRResp::ProvisionStatus

8.1026 voice_CNAPResp Struct Reference

Data Fields

- uint8_t ActiveStatus
- uint8_t ProvisionStatus

8.1026.1 Detailed Description

This structure contains information about the Calling Name Presentation (CNAP) supplementary service responses.

Parameters

ActiveStatus	• Active status. • Values: – 0x00 - ACTIVE_STATUS_INACTIVE - Inactive – 0x01 - ACTIVE_STATUS_ACTIVE - Active – 0xFF - Not Available
ProvisionStatus	• Provisioned status. • Values: – 0x00 - PROVISION_STATUS_NOT_PROVISIONED - Not provisioned – 0x01 - PROVISION_STATUS_PROVISIONED - Provisioned – 0xFF - Not Available

8.1026.2 Field Documentation

8.1026.2.1 uint8_t voice_CNAPResp::ActiveStatus

8.1026.2.2 uint8_t voice_CNAPResp::ProvisionStatus

8.1027 voice_COLPResp Struct Reference

Data Fields

- uint8_t ActiveStatus
- uint8_t ProvisionStatus

8.1027.1 Detailed Description

This structure contains information about the Connected Line Identification Presentation (COLP) supplementary service responses.

Parameters

ActiveStatus	• Active status. • Values: – 0x00 - ACTIVE_STATUS_INACTIVE - Inactive – 0x01 - ACTIVE_STATUS_ACTIVE - Active – 0xFF - Not Available
ProvisionStatus	• Provisioned status. • Values: – 0x00 - PROVISION_STATUS_NOT_PROVISIONED - Not provisioned – 0x01 - PROVISION_STATUS_PROVISIONED - Provisioned – 0xFF - Not Available

8.1027.2 Field Documentation

8.1027.2.1 uint8_t voice_COLPResp::ActiveStatus

8.1027.2.2 uint8_t voice_COLPResp::ProvisionStatus

8.1028 voice_COLRResp Struct Reference

Data Fields

- uint8_t ActiveStatus
- uint8_t ProvisionStatus

8.1028.1 Detailed Description

This structure contains information about the Connected Line Identification Restriction (COLR) supplementary service responses.

Parameters

ActiveStatus	• Active status. • Values: – 0x00 - ACTIVE_STATUS_INACTIVE - Inactive – 0x01 - ACTIVE_STATUS_ACTIVE - Active – 0xFF - Not Available
ProvisionStatus	• Provisioned status. • Values: – 0x00 - PROVISION_STATUS_NOT_PROVISIONED - Not provisioned – 0x01 - PROVISION_STATUS_PROVISIONED - Provisioned – 0xFF - Not Available

8.1028.2 Field Documentation

8.1028.2.1 uint8_t voice_COLRResp::ActiveStatus

8.1028.2.2 uint8_t voice_COLRResp::ProvisionStatus

8.1029 voice_connectNumInfo Struct Reference

Data Fields

- uint8_t numPresInd
- uint8_t screeningInd
- uint8_t numType
- uint8_t numPlan
- uint8_t callerIDLen
- uint8_t callerID [81]

8.1029.1 Detailed Description

This structure contains information about the numbers connected to a device. It contains information such as number type, eg International or Local.

Parameters

numPresInd	• Presentation indicator – 0x00 - PRESENTATION_ALLOWED - Allowed presentation – 0x01 - PRESENTATION_RESTRICTED - Restricted presentation – 0x02 - PRESENTATION_NUM_UNAVAILABLE - Unavailable presentation – 0x04 - PRESENTATION_PAYPHONE - Payphone presentation (GSM/UMTS specific) – 0xFF - Not Available

screeningInd	• Screening indicator. – 0x00 - QMI_VOICE_SI_USER_PROVIDED_NOT_SCREENED - Provided user is not screened – 0x01 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_PASSED - Provided user passed verification – 0x02 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_FAILED - Provided user failed verification – 0x03 - QMI_VOICE_SI_NETWORK_PROVIDED - Provided network – 0xFF - Not Available
numType	• Number type. – 0x00 - QMI_VOICE_NUM_TYPE_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_TYPE_INTERNATIONAL - International – 0x02 - QMI_VOICE_NUM_TYPE_NATIONAL - National – 0x03 - QMI_VOICE_NUM_TYPE_NETWORK_SPECIFIC - Network-specific – 0x04 - QMI_VOICE_NUM_TYPE_SUBSCRIBER - Subscriber – 0x05 - QMI_VOICE_NUM_TYPE_RESERVED - Reserved – 0x06 - QMI_VOICE_NUM_TYPE_ABBREVIATED - Abbreviated – 0x07 - QMI_VOICE_NUM_TYPE_RESERVED_EXTENSION - Reserved extension – 0xFF - Not Available
numPlan	• Number plan. – 0x00 - QMI_VOICE_NUM_PLAN_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_PLAN_ISDN - ISDN – 0x03 - QMI_VOICE_NUM_PLAN_DATA - Data – 0x04 - QMI_VOICE_NUM_PLAN_TELEX - Telex – 0x08 - QMI_VOICE_NUM_PLAN_NATIONAL - National – 0x09 - QMI_VOICE_NUM_PLAN_PRIVATE - Private – 0x0B - QMI_VOICE_NUM_PLAN_RESERVED_CTS - Reserved cordless telephony system – 0x0F - QMI_VOICE_NUM_PLAN_RESERVED_EXTENSION - Reserved extension – 0xFF - Not Available
callerIDLen	• Provides the length of caller ID which follow. • If zero(0) then no further information exists.
callerID[MAX_VOICE_CALL_NO_LEN]	• callerID of numLen length, NULL terminated.

8.1029.2 Field Documentation

8.1029.2.1 uint8_t voice_connectNumInfo::callerID[81]

8.1029.2.2 uint8_t voice_connectNumInfo::callerIDLen

8.1029.2.3 uint8_t voice_connectNumInfo::numPlan

8.1029.2.4 uint8_t voice_connectNumInfo::numPresInd

8.1029.2.5 uint8_t voice_connectNumInfo::numType

8.1029.2.6 uint8_t voice_connectNumInfo::screeningInd

8.1030 voice_CUGInfo Struct Reference

Data Fields

- uint16_t CUGIndex
- uint8_t SuppPrefCUG
- uint8_t SuppOA

8.1030.1 Detailed Description

This structure contains Closed User Group Information

Parameters

CUGIndex	• Range 0x00... 0x7FFF
SuppPrefCUG	• Suppress preferential CUG – 0x00 - FALSE – 0x01 - TRUE
SuppOA	• Suppress OA subscription option – 0x00 - FALSE – 0x01 - TRUE

8.1030.2 Field Documentation

8.1030.2.1 uint16_t voice_CUGInfo::CUGIndex

8.1030.2.2 uint8_t voice_CUGInfo::SuppOA

8.1030.2.3 uint8_t voice_CUGInfo::SuppPrefCUG

8.1031 voice_curAMRConfig Struct Reference

Data Fields

- uint8_t gsmAmrStat
- uint8_t wcdmaAmrStat

8.1031.1 Detailed Description

This structure contains the Current Adaptive Multi Rate Configuration Information.

Parameters

gsmAmrStat	• GSM AMR Status – 0x00 - Disable – 0x01 - Enable – 0xFF - Not Available
wcdmaAmrStat	• WCDMA AMR Status • One or a combination of the following bitmask values: – Bit 0 - AMR codec advertised is not supported – Bit 1 - Controls WCDMA AMR wideband – Bit 2 - Controls GSM half rate AMR – Bit 3 - Controls GSM AMR wideband – Bit 4 - Controls GSM AMR narrowband • 0xFF, if not available

8.1031.2 Field Documentation

8.1031.2.1 uint8_t voice_curAMRConfig::gsmAmrStat

8.1031.2.2 uint8_t voice_curAMRConfig::wcdmaAmrStat

8.1032 voice_diagInfo Struct Reference

Data Fields

- uint8_t diagInfoLen
- uint8_t diagnosticInfo [255]

8.1032.1 Detailed Description

This structure contains Diagnostic Information

Parameters

diagInfoLen	• Provides the length of information which follow. • If zero(0) then no further information exists.
diagnosticInfo[MAX_VOICE_DESCRIPTION_LENGTH]	• Diagnostic information.

8.1032.2 Field Documentation

8.1032.2.1 uint8_t voice_diagInfo::diagInfoLen

8.1032.2.2 uint8_t voice_diagInfo::diagnosticInfo[255]

8.1033 voice_DTMFInfo Struct Reference

Data Fields

- uint8_t callID
- uint8_t DTMFEvent
- uint8_t digitCnt
- uint8_t digitBuff [255]

8.1033.1 Detailed Description

This structure contains information about the DTMF (Dual Tone Multi-Frequency).

Parameters

callID	• Call identifier for the current call.
DTMFEvent	• DTMF event – 0x00 - DTMF_EVENT_REV_BURST - Sends a CDMA-burst DTMF – 0x01 - DTMF_EVENT_REV_START_CONT - Starts a continuous DTMF tone – 0x03 - DTMF_EVENT_REV_STOP_CONT - Stops a continuous DTMF tone – 0x05 - DTMF_EVENT_FWD_BURST - Received a CDMA-burst DTMF message – 0x06 - DTMF_EVENT_FWD_START_CONT - Received a start-continuous DTMF tone order – 0x07 - DTMF_EVENT_FWD_STOP_CONT - Received a stop-continuous DTMF tone order
digitCnt	• Number of set of following element i.e. digitBuff.
digitBuff[MAX_VOICE_DESCRIPTION_LENGTH]	• DTMF digit buffer in ASCII string which is NULL terminated

8.1033.2 Field Documentation

8.1033.2.1 uint8_t voice_DTMFInfo::callID

8.1033.2.2 uint8_t voice_DTMFInfo::digitBuff[255]

8.1033.2.3 uint8_t voice_DTMFInfo::digitCnt

8.1033.2.4 uint8_t voice_DTMFInfo::DTMFEvent

8.1034 voice_DTMFLengths Struct Reference

Data Fields

- uint8_t DTMFPulseWidth
- uint8_t DTMFInterdigitInterval

8.1034.1 Detailed Description

This structure contains Voice Burst DTMF pulse length information

Parameters

DTMFPulse-Width	• DTMF pulse width. Values: – 0x00 - DTMF_ONLENGTH_95MS - 95 ms – 0x01 - DTMF_ONLENGTH_150MS - 150 ms – 0x02 - DTMF_ONLENGTH_200MS - 200 ms – 0x03 - DTMF_ONLENGTH_250MS - 250 ms – 0x04 - DTMF_ONLENGTH_300MS - 300 ms – 0x05 - DTMF_ONLENGTH_350MS - 350 ms – 0x06 - DTMF_ONLENGTH_SMS SMS Tx special pulse width
DTMFInterdigit-Interval	• DTMF interdigit interval Values: – 0x00 - DTMF_OFFLENGTH_60MS - 60 ms – 0x01 - DTMF_OFFLENGTH_100MS - 100 ms – 0x02 - DTMF_OFFLENGTH_150MS - 150 ms – 0x03 - DTMF_OFFLENGTH_200MS - 200 ms

8.1034.2 Field Documentation

8.1034.2.1 uint8_t voice_DTMFLengths::DTMFInterdigitInterval

8.1034.2.2 uint8_t voice_DTMFLengths::DTMFPulseWidth

8.1035 voice_ECTNum Struct Reference

Data Fields

- uint8_t ECTCallState
- uint8_t presentationInd
- uint8_t number [81]

8.1035.1 Detailed Description

Contains the parameters passed for Explicit Communication Transfer by the device.

Parameters

ECTCallState	• ECT call state: – 0x00 - ECT_CALL_STATE_NONE - None – 0x01 - ECT_CALL_STATE_ALERTING - Alerting – 0x02 - ECT_CALL_STATE_ACTIVE - Active

presentationInd	• Presentation indicator – 0x00 - presentationAllowedAddress – 0x01 - presentationRestricted – 0x02 - numberNotAvailable – 0x04 - presentationRestrictedAddress
number	• Number in ASCII characters terminated by NULL

8.1035.2 Field Documentation

8.1035.2.1 uint8_t voice_ECTNum::ECTCallState

8.1035.2.2 uint8_t voice_ECTNum::number[81]

8.1035.2.3 uint8_t voice_ECTNum::presentationInd

8.1036 voice_extDispRecInfo Struct Reference

Data Fields

- uint8_t dispType
- uint8_t extDispInfoLen
- uint8_t extDispInfo [255]

8.1036.1 Detailed Description

This structure contains Line Control Information

Parameters

dispType	• Values are per [S1, Table 3.7.5.16-1].
extDispInfoLen	• Number of sets of the following elements: – ext_display_info
extDispInfo	• Extended display information buffer containing the display record; refer to [S1, Section 3.7.5.16] for the format information of the buffer contents.

8.1036.2 Field Documentation

8.1036.2.1 uint8_t voice_extDispRecInfo::dispType

8.1036.2.2 uint8_t voice_extDispRecInfo::extDispInfo[255]

8.1036.2.3 uint8_t voice_extDispRecInfo::extDispInfoLen

8.1037 voice_getAllCallInformation Struct Reference

Data Fields

- voice_callInfo CallInfo
- uint8_t isEmpty
- uint8_t ALS

8.1037.1 Detailed Description

This structure contains information related to call state change.

Parameters

CallInfo	• See voice_callInfo for more information.
isEmpty	• Multiparty indicator. – 0x00 - False – 0x01 - True
ALS	• Alternate Line Service line indicator. • Feature for supporting two different phone numbers on the same mobile device. – 0x00 - ALS_LINE1 - Line 1 (default) – 0x01 - ALS_LINE2 - Line 2

8.1037.2 Field Documentation

8.1037.2.1 uint8_t voice_getAllCallInformation::ALS

8.1037.2.2 voice_callInfo voice_getAllCallInformation::CallInfo

8.1037.2.3 uint8_t voice_getAllCallInformation::isEmpty

8.1038 voice_getAllCallRmtPtyName Struct Reference

Data Fields

- uint8_t callID
- voice_remotePartyName RemotePartyName

8.1038.1 Detailed Description

This structure contains information for All Call Remote Party Names

Parameters

callID	• Unique call identifier for the call.
RemoteParty-Name	• See voice_remotePartyName for more information.

8.1038.2 Field Documentation

8.1038.2.1 uint8_t voice_getAllCallRmtPtyName::callID

8.1038.2.2 voice_remotePartyName voice_getAllCallRmtPtyName::RemotePartyName

8.1039 voice_getAllCallRmtPtyNum Struct Reference

Data Fields

- uint8_t callID
- voice_remotePartyNum RemotePartyNum

8.1039.1 Detailed Description

This structure contains information for All Call Remote Party Numbers

Parameters

callID	• Unique call identifier for the call.
RemoteParty-Num	• See voice_remotePartyNum for more information.

8.1039.2 Field Documentation

8.1039.2.1 uint8_t voice_getAllCallRmtPtyNum::callID

8.1039.2.2 voice_remotePartyNum voice_getAllCallRmtPtyNum::RemotePartyNum

8.1040 voice_getCallFWExtInfo Struct Reference

Data Fields

- uint8_t numInstances
- voice_callFWExtInfo CallFWExtInfo [20]

8.1040.1 Detailed Description

This structure contains an array of Call Forwarded Extended Information.

Parameters

numInstances	• Number of callFWExtInfo that follow. • If zero(0) then no further information exists.
CallFWExtInfo[VOICE_MAX_NO_OF_CALLS]	• Array of CallFWExtInfo. – See voice_callFWExtInfo for more information.

8.1040.2 Field Documentation

8.1040.2.1 voice_callFWExtInfo voice_getCallFWExtInfo::CallFWExtInfo[20]

8.1040.2.2 uint8_t voice_getCallFWExtInfo::numInstances

8.1041 voice_getCallFWInfo Struct Reference

Data Fields

- uint8_t numInstances
- voice_callFWInfo CallFWInfo [20]

8.1041.1 Detailed Description

This structure contains an array of Call Forwarded Information.

Parameters

numInstances	• Number of callFWInfo that follow. • If zero(0) then no further information exists.
CallFWInfo[VOICE_MAX_NO_OF_CALLS]	• Array of callFWInfo. – See voice_callFWInfo for more information.

8.1041.2 Field Documentation

8.1041.2.1 voice_callFWInfo voice_getCallFWInfo::CallFWInfo[20]

8.1041.2.2 uint8_t voice_getCallFWInfo::numInstances

8.1042 voice_lineCtrlInfo Struct Reference

Data Fields

- uint8_t polarityIncluded
- uint8_t toggleMode
- uint8_t revPolarity
- uint8_t pwrDenialTime

8.1042.1 Detailed Description

This structure contains Line Control Information

Parameters

polarityIncluded	• Included Polarity; Boolean Value
toggleMode	• Toggle mode; Boolean Value
revPolarity	• Reverse Polarity; Boolean Value
pwrDenialTime	• Power denial time; refer to [S1, Section 3.7.5.15 Line Control] for valid values

8.1042.2 Field Documentation

8.1042.2.1 uint8_t voice_lineCtrlInfo::polarityIncluded

8.1042.2.2 uint8_t voice_lineCtrlInfo::pwrDenialTime

8.1042.2.3 uint8_t voice_lineCtrlInfo::revPolarity

8.1042.2.4 uint8_t voice_lineCtrlInfo::toggleMode

8.1043 voice_newPwdData Struct Reference

Data Fields

- uint8_t newPwd [4]
- uint8_t newPwdAgain [4]

8.1043.1 Detailed Description

This structure contains New Password Data.

Parameters

newPwd[BARRING_PASSWORD_LENGTH]	• New password. – Password consists of 4 ASCII digits. – Range: 0000 to 9999.
newPwdAgain[BARRING_PASSWORD_LENGTH]	• New password again. – Password consists of 4 ASCII digits. – Range: 0000 to 9999.

8.1043.2 Field Documentation

8.1043.2.1 uint8_t voice_newPwdData::newPwd[4]

8.1043.2.2 uint8_t voice_newPwdData::newPwdAgain[4]

8.1044 voice_NSSAudioCtrl Struct Reference

Data Fields

- uint8_t upLink
- uint8_t downLink

8.1044.1 Detailed Description

This structure contains National Supplementary Services - Audio Control Information

Parameters

upLink	• Values as per[S24, 4.10 Reservation response].
downLink	• Values as per[S24, 4.10 Reservation response].

8.1044.2 Field Documentation

8.1044.2.1 uint8_t voice_NSSAudioCtrl::downLink

8.1044.2.2 uint8_t voice_NSSAudioCtrl::upLink

8.1045 voice_peerNumberInfo Struct Reference

Data Fields

- uint8_t callID
- uint8_t numPI
- uint8_t numSI
- uint8_t numType
- uint8_t numPlan
- uint8_t numLen
- uint8_t number [81]

8.1045.1 Detailed Description

This structure contains information for Connected Peer Numbers.

Parameters

callID	• Unique call identifier for the call.

numPI	• Number presentation indicator. – 0x00 - PRESENTATION_ALLOWED - Allowed presentation – 0x01 - PRESENTATION_RESTRICTED - Restricted presentation – 0x02 - PRESENTATION_NUM_UNAVAILABLE - Unavailable presentation – 0x04 - PRESENTATION_PAYPHONE - Payphone presentation (GSM/UMTS specific) – 0xFF - Not Available
numSI	• Number screening indicator. – 0x00 - QMI_VOICE_SI_USER_PROVIDED_NOT_SCREENED - Provided user is not screened – 0x01 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_PASSED - Provided user passed verification – 0x02 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_FAILED - Provided user failed verification – 0x03 - QMI_VOICE_SI_NETWORK_PROVIDED - Provided network
numType	• Number type. – 0x00 - QMI_VOICE_NUM_TYPE_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_TYPE_INTERNATIONAL - International – 0x02 - QMI_VOICE_NUM_TYPE_NATIONAL - National – 0x03 - QMI_VOICE_NUM_TYPE_NETWORK_SPECIFIC - Network-specific – 0x04 - QMI_VOICE_NUM_TYPE_SUBSCRIBER - Subscriber – 0x05 - QMI_VOICE_NUM_TYPE_RESERVED - Reserved – 0x06 - QMI_VOICE_NUM_TYPE_ABBREVIATED - Abbreviated – 0x07 - QMI_VOICE_NUM_TYPE_RESERVED_EXTENSION - Reserved extension
numPlan	• Number plan. – 0x00 - QMI_VOICE_NUM_PLAN_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_PLAN_ISDN - ISDN – 0x03 - QMI_VOICE_NUM_PLAN_DATA - Data – 0x04 - QMI_VOICE_NUM_PLAN_TELEX - Telex – 0x08 - QMI_VOICE_NUM_PLAN_NATIONAL - National – 0x09 - QMI_VOICE_NUM_PLAN_PRIVATE - Private – 0x0B - QMI_VOICE_NUM_PLAN_RESERVED_CTS - Reserved cordless telephony system – 0x0F - QMI_VOICE_NUM_PLAN_RESERVED_EXTENSION - Reserved extension
numLen	• Provides the length of number which follow.
number[MAX_VOICE_CALL_NO_LEN]	• number of numLen length, NULL terminated.

8.1045.2 Field Documentation

8.1045.2.1 uint8_t voice_peerNumberInfo::callID

8.1045.2.2 uint8_t voice_peerNumberInfo::number[81]

8.1045.2.3 uint8_t voice_peerNumberInfo::numLen

8.1045.2.4 uint8_t voice_peerNumberInfo::numPI

8.1045.2.5 uint8_t voice_peerNumberInfo::numPlan

8.1045.2.6 uint8_t voice_peerNumberInfo::numSI

8.1045.2.7 uint8_t voice_peerNumberInfo::numType

8.1046 voice_prefVoiceSO Struct Reference

Data Fields

- uint8_t namID
- uint8_t evrcCapability
- uint16_t homePageVoiceSO
- uint16_t homeOrigVoiceSO
- uint16_t roamOrigVoiceSO

8.1046.1 Detailed Description

This structure contains information about the Preferred Voice Service Options.

Parameters

namID	• Index of the NAM(Number Assignment Module) to be configured. • Range 0 to 3. • Some modems support only 1 or 2 NAMs. • 0xFF,if not available.
evrcCapability	• EVRC capability. • Values: – 0x00 - Disable – 0x01 - Enable – 0xFF - Not Available

homePageVoiceSO	• Home page voice SO; most preferred CDMA SO to be requested from the network when receiving an incoming (MT) voice call within the home network. • Values: – 0x0000 - VOICE_SO_WILD - Any service option – 0x0001 - VOICE_SO_IS_96A - IS-96A – 0x0003 - VOICE_SO_EVRC - EVRC – 0x0011 - VOICE_SO_13K_IS733 - 13K_IS733 – 0x0038 - VOICE_SO_SELECTABLE_MODE_VOCODER - Selectable mode vocoder – 0x0044 - VOICE_SO_4GV_NARR0W_BAND - 4GV narrowband – 0x0046 - VOICE_SO_4GV_WIDE_BAND - 4GV wideband – 0x8000 - VOICE_SO_13K - 13K – 0x8001 - VOICE_SO_IS_96 - IS-96 – 0x8023 - VOICE_SO_WVRC - WVRC – 0xFFFF - Not Available
homeOrigVoiceSO	• Home origination voice SO; most preferred CDMA SO to be requested from the network when receiving an incoming (MT) voice call within the home network. • Values: – 0x0000 - VOICE_SO_WILD - Any service option – 0x0001 - VOICE_SO_IS_96A - IS-96A – 0x0003 - VOICE_SO_EVRC - EVRC – 0x0011 - VOICE_SO_13K_IS733 - 13K_IS733 – 0x0038 - VOICE_SO_SELECTABLE_MODE_VOCODER - Selectable mode vocoder – 0x0044 - VOICE_SO_4GV_NARR0W_BAND - 4GV narrowband – 0x0046 - VOICE_SO_4GV_WIDE_BAND - 4GV wideband – 0x8000 - VOICE_SO_13K - 13K – 0x8001 - VOICE_SO_IS_96 - IS-96 – 0x8023 - VOICE_SO_WVRC - WVRC – 0xFFFF - Not Available
roamOrigVoiceSO	• Roaming origination voice SO; most preferred CDMA SO to be requested from the network when receiving an incoming (MT) voice call within the home network. • Values: – 0x0000 - VOICE_SO_WILD - Any service option – 0x0001 - VOICE_SO_IS_96A - IS-96A – 0x0003 - VOICE_SO_EVRC - EVRC – 0x0011 - VOICE_SO_13K_IS733 - 13K_IS733 – 0x0038 - VOICE_SO_SELECTABLE_MODE_VOCODER - Selectable mode vocoder – 0x0044 - VOICE_SO_4GV_NARR0W_BAND - 4GV narrowband – 0x0046 - VOICE_SO_4GV_WIDE_BAND - 4GV wideband – 0x8000 - VOICE_SO_13K - 13K – 0x8001 - VOICE_SO_IS_96 - IS-96 – 0x8023 - VOICE_SO_WVRC - WVRC – 0xFFFF - Not Available

8.1046.2 Field Documentation

8.1046.2.1 uint8_t voice_prefVoiceSO::evrcCapability

8.1046.2.2 uint16_t voice_prefVoiceSO::homeOrigVoiceSO

8.1046.2.3 uint16_t voice_prefVoiceSO::homePageVoiceSO

8.1046.2.4 uint8_t voice_prefVoiceSO::namID

8.1046.2.5 uint16_t voice_prefVoiceSO::roamOrigVoiceSO

8.1047 voice_redirNumInfo Struct Reference

Data Fields

- uint8_t PI
- uint8_t SI
- uint8_t numType
- uint8_t numPlan
- uint8_t reason
- uint8_t numLen
- uint8_t number [255]

8.1047.1 Detailed Description

This structure contains Redirecting Number Information

Parameters

PI	• Presentation indicator; refer to [S1, Table 2.7.4.4-1] for valid values.
SI	• Number of sets of following elements – Caller Id
SI	• Number screening indicator. • Values: – 0x00 - QMI_VOICE_SI_USER_PROVIDED_NOT_SCREENED - Provided user is not screened – 0x01 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_PASSED - Provided user passed verification – 0x02 - QMI_VOICE_SI_USER_PROVIDED_VERIFIED_FAILED - Provided user failed verification – 0x03 - QMI_VOICE_SI_NETWORK_PROVIDED - Provided network

numType	• Number type. • Values: – 0x00 - QMI_VOICE_NUM_TYPE_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_TYPE_INTERNATIONAL - International – 0x02 - QMI_VOICE_NUM_TYPE_NATIONAL - National – 0x03 - QMI_VOICE_NUM_TYPE_NETWORK_SPECIFIC - Network-specific – 0x04 - QMI_VOICE_NUM_TYPE_SUBSCRIBER - Subscriber – 0x05 - QMI_VOICE_NUM_TYPE_RESERVED - Reserved – 0x06 - QMI_VOICE_NUM_TYPE_ABBREVIATED - Abbreviated – 0x07 - QMI_VOICE_NUM_TYPE_RESERVED_EXTENSION - Reserved extension
numPlan	• Number plan. • Values: – 0x00 - QMI_VOICE_NUM_PLAN_UNKNOWN - Unknown – 0x01 - QMI_VOICE_NUM_PLAN_ISDN - ISDN – 0x03 - QMI_VOICE_NUM_PLAN_DATA - Data – 0x04 - QMI_VOICE_NUM_PLAN_TELEX - Telex – 0x08 - QMI_VOICE_NUM_PLAN_NATIONAL - National – 0x09 - QMI_VOICE_NUM_PLAN_PRIVATE - Private – 0x0B - QMI_VOICE_NUM_PLAN_RESERVED_CTS - Reserved cordless telephony system – 0x0F - QMI_VOICE_NUM_PLAN_RESERVED_EXTENSION - Reserved extension
reason	-Redirecting reason; refer to [S1, Table 3.7.5.11-1] for valid values
numLen	• Provides the length of number which follow.
number[255]	• number of numLen length, NULL terminated.

8.1047.2 Field Documentation

8.1047.2.1 uint8_t voice_redirNumInfo::number[255]

8.1047.2.2 uint8_t voice_redirNumInfo::numLen

8.1047.2.3 uint8_t voice_redirNumInfo::numPlan

8.1047.2.4 uint8_t voice_redirNumInfo::numType

8.1047.2.5 uint8_t voice_redirNumInfo::PI

8.1047.2.6 uint8_t voice_redirNumInfo::reason

8.1047.2.7 uint8_t voice_redirNumInfo::SI

8.1048 voice_remotePartyName Struct Reference

Data Fields

- uint8_t namePI
- uint8_t codingScheme
- uint8_t nameLen
- uint8_t callerName [255]

8.1048.1 Detailed Description

This structure contains information about the names that are dialed from the device or from which a call is received on the device.

Parameters

namePI	• Name presentation indicator. – 0x00 - PRESENTATION_NAME_PRESENTATION_ALLOWED - Allowed presentation – 0x01 - PRESENTATION_NAME_PRESENTATION_RESTRICTED - Restricted presentation – 0x02 - PRESENTATION_NAME_UNAVAILABLE - Unavailable presentation – 0x03 - PRESENTATION_NAME_NAME_PRESENTATION_RESTRICTED - Restricted name presentation – 0xFF - Not Available
codingScheme	• Refer to Table10 qaGobiApiTableCodingScheme.h for coding schemes • 0xFF - Not Available
nameLen	• Provides the length of name which follow. • If zero(0) then no further information exists.
callerName[MAX_VOICE_DESCRIPTION_LENGTH]	• Name in ASCII, NULL ending.

8.1048.2 Field Documentation

8.1048.2.1 uint8_t voice_remotePartyName::callerName[255]

8.1048.2.2 uint8_t voice_remotePartyName::codingScheme

8.1048.2.3 uint8_t voice_remotePartyName::nameLen

8.1048.2.4 uint8_t voice_remotePartyName::namePI

8.1049 voice_remotePartyNum Struct Reference

Data Fields

- uint8_t presentationInd
- uint8_t numLen
- uint8_t remPartyNumber [81]

8.1049.1 Detailed Description

This structure contains information about the numbers that are dialed from the device or from which a call is received on the device.

Parameters

presentationInd	• Presentation indicator. – 0x00 - PRESENTATION_ALLOWED - Allowed presentation – 0x01 - PRESENTATION_RESTRICTED - Restricted presentation – 0x02 - PRESENTATION_NUM_UNAVAILABLE - Unavailable presentation – 0x04 - PRESENTATION_PAYPHONE - Payphone presentation (GSM/UMTS specific) – 0xFF - Not Available
numLen	• Provides the length of number which follow. • If zero(0) then no further information exists.
remParty-Number[MAX_-CALL_NO_LEN]	• Array of numbers in ASCII, NULL ending.

8.1049.2 Field Documentation

8.1049.2.1 uint8_t voice_remotePartyNum::numLen

8.1049.2.2 uint8_t voice_remotePartyNum::presentationInd

8.1049.2.3 uint8_t voice_remotePartyNum::remPartyNumber[81]

8.1050 voice_roamTimer Struct Reference

Data Fields

- uint8_t namID
- uint32_t roamTimerValue

8.1050.1 Detailed Description

This structure contains information about the Roam Timer.

Parameters

namID	• Index of the NAM(Number Assignment Module) to be configured. • Range 0 to 3. • Some modems support only 1 or 2 NAMs. • 0xFF,if not available.
roamTimerValue	• Time in minutes. • Cumulative air time is slammed. • 0xFFFFFFFF,if not available.

8.1050.2 Field Documentation

8.1050.2.1 uint8_t voice_roamTimer::namID

8.1050.2.2 uint32_t voice_roamTimer::roamTimerValue

8.1051 voice_signalInfo Struct Reference

Data Fields

- uint8_t signalType
- uint8_t alertPitch
- uint8_t signal

8.1051.1 Detailed Description

This structure contains Signal Information

Parameters

signalType	• Call identifier for the call.
alertPitch	• Signal Information
signal	• Caller ID Information

8.1051.2 Field Documentation

8.1051.2.1 uint8_t voice_signalInfo::alertPitch

8.1051.2.2 uint8_t voice_signalInfo::signal

8.1051.2.3 uint8_t voice_signalInfo::signalType

8.1052 voice_SUPSInfo Struct Reference

Data Fields

- uint8_t svcType
- uint8_t isModByCC

8.1052.1 Detailed Description

This structure contains information about the Supplementary Services.

Parameters

svcType	• Service type. – 0x01 - SERVICE_TYPE_ACTIVATE - Activate – 0x02 - SERVICE_TYPE_DEACTIVATE - Deactivate – 0x03 - SERVICE_TYPE_REGISTER - Register – 0x04 - SERVICE_TYPE_ERASE - Erase – 0x05 - SERVICE_TYPE_INTERROGATE - Interrogate – 0x06 - SERVICE_TYPE_REGISTER_PASSWORD - Register password – 0x07 - SERVICE_TYPE_USSD - USSD
isModByCC	• Indicates whether the supplementary service data is modified by the card (SIM/USIM) as part of the call control: – 0 - False – 1 - True

8.1052.2 Field Documentation

8.1052.2.1 uint8_t voice_SUPSInfo::isModByCC

8.1052.2.2 uint8_t voice_SUPSInfo::svcType

8.1053 voice_USSDNotificationNetworkInfo Struct Reference

Data Fields

- uint8_t tlvPresent
- struct voice_USSInfo networkInfo

8.1053.1 Detailed Description

Structure for storing the USS info present in USSDNotification callback.

Parameters

tlvPresent	Values: • 0 - Not present • 1 - Tlv is present

NetworkInfo	• USS Data from Network (See structure voice_USSInfo) • NULL pointer - Invalid data.

8.1053.2 Field Documentation

8.1053.2.1 struct voice_USSInfo voice_USSDNotificationNetworkInfo::networkInfo

8.1053.2.2 uint8_t voice_USSDNotificationNetworkInfo::tlvPresent

8.1054 voice_USSInfo Struct Reference

Data Fields

- uint8_t ussDCS
- uint8_t ussLen
- uint8_t ussData [182]

8.1054.1 Detailed Description

This structure contains USS Information

Parameters

ussDCS	• 1 - ASCII coding scheme • 2 - 8-BIT coding scheme • 3 - UCS2
ussLen	• Range 1 to 182
ussData	• Data encoded as per the DCS

8.1054.2 Field Documentation

8.1054.2.1 uint8_t voice_USSInfo::ussData[182]

8.1054.2.2 uint8_t voice_USSInfo::ussDCS

8.1054.2.3 uint8_t voice_USSInfo::ussLen

8.1055 voice_UUSInfo Struct Reference

Data Fields

- uint8_t UUSType
- uint8_t UUSDcs

- uint8_t UUSDatalen
- uint8_t UUSData [255]

8.1055.1 Detailed Description

This structure contains User to User Signaling Service Information.

Parameters

UUSType	• UUS type values are: – 0x00 - UUS_DATA – 0x01 - UUS_TYPE1_IMPLICIT – 0x02 - UUS_TYPE1_REQUIRED – 0x03 - UUS_TYPE1_NOT_REQUIRED – 0x04 - UUS_TYPE2_REQUIRED – 0x05 - UUS_TYPE2_NOT_REQUIRED – 0x06 - UUS_TYPE3_REQUIRED – 0x07 - UUS_TYPE3_NOT_REQUIRED – 0xFF - Not Available
UUSDcs	• UUS data coding scheme values are: – 0x01 - UUS_DCS_USP – 0x02 - UUS_DCS_OHLP – 0x03 - UUS_DCS_X244 – 0x04 - UUS_DCS_SMCF – 0x05 - UUS_DCS_IA5 – 0x06 - UUS_DCS_RV12RD – 0x07 - UUS_DCS_Q931UNCCM – 0xFF - Not Available
UUSDatalen	• Number of sets of the following elements. – UUSData • If zero(0) then no further information exists.
UUSData[MAX_VOICE_DESCRIPTION_LENGTH]	• UUS data encoded as per coding scheme

8.1055.2 Field Documentation

8.1055.2.1 uint8_t voice_UUSInfo::UUSData[255]

8.1055.2.2 uint8_t voice_UUSInfo::UUSDatalen

8.1055.2.3 uint8_t voice_UUSInfo::UUSDcs

8.1055.2.4 uint8_t voice_UUSInfo::UUSType

8.1056 wds_channelRate Struct Reference

Data Fields

- uint32_t CurrChanTxRate
- uint32_t CurrChanRxRate

8.1056.1 Detailed Description

This structure contains Channel Rate

Parameters

CurrChanTxRate	• Max channel Tx rate in bits per second
CurrChanRx-Rate	• Max channel Rx rate in bits per second

8.1056.2 Field Documentation

8.1056.2.1 uint32_t wds_channelRate::CurrChanRxRate

8.1056.2.2 uint32_t wds_channelRate::CurrChanTxRate

8.1057 wds_ChannelRateTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- wds_channelRate ChannelRate

8.1057.1 Detailed Description

This structure stores information about channel rate TLV.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
ChannelRate	• see wds_channelRate for more info

8.1057.2 Field Documentation

8.1057.2.1 wds_channelRate wds_ChannelRateTlv::ChannelRate

8.1057.2.2 uint8_t wds_ChannelRateTlv::TlvPresent

8.1058 wds_ConnStatusTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t MDMConnStatus

8.1058.1 Detailed Description

This structure stores information about modem connection status TLV.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
MDMConn-Status	-Modem connecton status • 0x01 - disconnected • 0x02 - connected

8.1058.2 Field Documentation

8.1058.2.1 uint8_t wds_ConnStatusTlv::MDMConnStatus

8.1058.2.2 uint8_t wds_ConnStatusTlv::TlvPresent

8.1059 wds_currNetworkInfo Struct Reference

Data Fields

- uint8_t NetworkType
- uint32_t RATMask
- uint32_t SOMask

8.1059.1 Detailed Description

Network information structure

Parameters

NetworkType	• Values: – 0 - 3GPP – 1 - 3GPP2
RATMask	• RAT Mask
SOMask	• SO Mask

8.1059.2 Field Documentation

8.1059.2.1 uint8_t wds_currNetworkInfo::NetworkType

8.1059.2.2 uint32_t wds_currNetworkInfo::RATMask

8.1059.2.3 uint32_t wds_currNetworkInfo::SOMask

8.1060 wds_DataBearTechTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t DataBearerTech

8.1060.1 Detailed Description

This structure hold parameters about data bearer technology TLV.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
DataBearerTech	• Data bear technology – 0x01 - cdma2000 1X – 0x02 - cdma2000 HRPD (1xEV-DO) – 0x03 - GSM – 0x04 - UMTS – 0x05 - cdma200 HRPD (1xEV-DO RevA) – 0x06 - EDGE – 0x07 - HSDPA and WCDMA – 0x08 - WCDMA and HSUPA – 0x09 - HSDPA and HSUPA – 0x0A - LTE – 0x0B - cdma2000 EHRPD – 0x0C - HSDPA+ and WCDMA – 0x0D - HSDPA+ and HSUPA – 0x0E - DC_HSDPA+ and WCDMA – 0x0F - DC_HSDPA+ and HSUPA – 0x10 - HSDPA+ and 64QAM – 0x11 - HSDPA+, 64QAM and HSUPA – 0x12 - TDSCDMA – 0x13 - TDSCDMA and HSDPA – 0xFF - Unknown

8.1060.2 Field Documentation

8.1060.2.1 uint8_t wds_DataBearTechTlv::DataBearerTech

8.1060.2.2 uint8_t wds_DataBearTechTlv::TlvPresent

8.1061 wds_DataULongLongTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t ullData

8.1061.1 Detailed Description

This structure contains Data unsigned long long TLV data.

Parameters

TlvPresent	a flag indicates whether TLV presented or not
ullData	unsigend long long data in 64bit

8.1061.2 Field Documentation

8.1061.2.1 uint8_t wds_DataULongLongTlv::TlvPresent

8.1061.2.2 uint64_t wds_DataULongLongTlv::ullData

8.1062 wds_DataULongTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t ulData

8.1062.1 Detailed Description

This structure contains Data unsigned long TLV data.

Parameters

TlvPresent	a flag indicates whether TLV presented or not
ulData	unsigend long data in 32bit

8.1062.2 Field Documentation

8.1062.2.1 uint8_t wds_DataULongTlv::TlvPresent

8.1062.2.2 uint32_t wds_DataULongTlv::ulData

8.1063 wds_DHCPLeaseOptTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t numOpt

- wds_DHCPOpt optList [30]
- uint8_t optListData [2048]

8.1063.1 Detailed Description

DHCP lease option information

Parameters

TlvPresent	a flag indicates whether TLV presented or not
numOpt	number of sets of wds_DHCPOpt
optList	option list
optListData	option list data

8.1063.2 Field Documentation

8.1063.2.1 uint8_t wds_DHCPLeaseOptTlv::numOpt

8.1063.2.2 wds_DHCPOpt wds_DHCPLeaseOptTlv::optList[30]

8.1063.2.3 uint8_t wds_DHCPLeaseOptTlv::optListData[2048]

8.1063.2.4 uint8_t wds_DHCPLeaseOptTlv::TlvPresent

8.1064 wds_DHCPLeaseStateTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t leaseState

8.1064.1 Detailed Description

DHCP lease state information

Parameters

TlvPresent	a flag indicates whether TLV presented or not
leaseState	lease state • 0 - active, newly acquired • 1 - active, renewed • 2 - active, renewing • 3 - active, rebinding • 4 - inactive, expired • 5 - inactive, renew refused • 6 - inactive, rebind refused • 7 - inactive, other

8.1064.2 Field Documentation

8.1064.2.1 uint8_t wds_DHCPLeaseStateTlv::leaseState

8.1064.2.2 uint8_t wds_DHCPLeaseStateTlv::TlvPresent

8.1065 wds_DHCPOpt Struct Reference

Data Fields

- uint8_t optCode
- uint8_t optValLen
- uint8_t * pOptVal

8.1065.1 Detailed Description

DHCP option code information

Parameters

optCode	option code • values: – 0 - 255
optValLen	length of option code • values: – 0 - 255
pOptVal	option value

8.1065.2 Field Documentation

8.1065.2.1 uint8_t wds_DHCPOpt::optCode

8.1065.2.2 uint8_t wds_DHCPOpt::optValLen

8.1065.2.3 uint8_t* wds_DHCPOpt::pOptVal

8.1066 wds_DHCPProfileIdTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t profileType
- uint8_t profileId

8.1066.1 Detailed Description

DHCP profile id TLV information

Parameters

TlvPresent	a flag indicates whether TLV presented or not
profileType	identifying the type of the profile • 0 - 3GPP

profileId	index identifying the profile • 1-24 valid for 3GPP profile type (9x30 and onwards)

8.1066.2 Field Documentation

8.1066.2.1 uint8_t wds_DHCPProfileIdTlv::profileId

8.1066.2.2 uint8_t wds_DHCPProfileIdTlv::profileType

8.1066.2.3 uint8_t wds_DHCPProfileIdTlv::TlvPresent

8.1067 wds_DHCPv4HWConfig Struct Reference

Data Fields

- uint8_t hwType
- uint8_t chaddrLen
- uint8_t chaddr [16]

8.1067.1 Detailed Description

WDS SWI DHCPv4 HW Config Structure.

Parameters

hwType	• HW Type 1 - Ethernet 20 - Serial
chaddrlen	• chaddrlen
chaddr	• chaddr. Max size 16 bytes

8.1067.2 Field Documentation

8.1067.2.1 uint8_t wds_DHCPv4HWConfig::chaddr[16]

8.1067.2.2 uint8_t wds_DHCPv4HWConfig::chaddrLen

8.1067.2.3 uint8_t wds_DHCPv4HWConfig::hwType

8.1068 wds_DHCPv4Option Struct Reference

Data Fields

- uint8_t optCode
- uint8_t optValLen
- uint8_t optVal [255]

8.1068.1 Detailed Description

WDS SWI DHCPv4 Option Structure

Parameters

optCode	• Option code – 0 - 255
optValLen	• Option value length – 0 - 255
optVal	• Option value

8.1068.2 Field Documentation

8.1068.2.1 uint8_t wds_DHCPv4Option::optCode

8.1068.2.2 uint8_t wds_DHCPv4Option::optVal[255]

8.1068.2.3 uint8_t wds_DHCPv4Option::optValLen

8.1069 wds_DHCPv4OptionList Struct Reference

Data Fields

- uint8_t numOpt
- wds_DHCPv4Option * pOptList

8.1069.1 Detailed Description

WDS SWI DHCPv4 Option List Structure

Parameters

numOpt	• number of options – 0 - 255
pOptList	• pointer to list of DHCP Options

8.1069.2 Field Documentation

8.1069.2.1 uint8_t wds_DHCPv4OptionList::numOpt

8.1069.2.2 wds_DHCPv4Option* wds_DHCPv4OptionList::pOptList

8.1070 wds_DHCPv4ProfileId Struct Reference

Data Fields

- uint8_t profileType
- uint8_t profileId

8.1070.1 Detailed Description

WDS SWI DHCPv4 Profile Identifier Structure

Parameters

profileType	• 0 for 3GPP
profileId	• 1 to 24 for 3GPP profile

8.1070.2 Field Documentation

8.1070.2.1 uint8_t wds_DHCPv4ProfileId::profileId

8.1070.2.2 uint8_t wds_DHCPv4ProfileId::profileType

8.1071 wds_Domain Struct Reference

Data Fields

- uint16_t domainLen
- uint8_t domainName [256]

8.1071.1 Detailed Description

This structure contains the DomainName Information

Parameters

domainLen	• length of the recieved Domain name
domainName	• Domain name(Max 256 characters)

8.1071.2 Field Documentation

8.1071.2.1 uint16_t wds_Domain::domainLen

8.1071.2.2 uint8_t wds_Domain::domainName[256]

8.1072 wds_DomainNameList Struct Reference

Data Fields

- uint8_t numInstances
- struct wds_Domain domain [10]

8.1072.1 Detailed Description

This structure contains the DomainNameList Information

Parameters

numInstances	• Number of Domain name receieved
domain	• Domain name information(Max 10 Domain names)

Note

Data invalid when numInstances equal 0xff.

8.1072.2 Field Documentation

8.1072.2.1 struct wds_Domain wds_DomainNameList::domain[10]

8.1072.2.2 uint8_t wds_DomainNameList::numInstances

8.1073 wds_DormStatTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint8_t DormancyStat

8.1073.1 Detailed Description

This structure stores information about dormancy status TLV.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
DormancyStat	-Dormancy status • 0x01 - Traffic channel dormant • 0x02 - Traffic channel active

8.1073.2 Field Documentation

8.1073.2.1 uint8_t wds_DormStatTlv::DormancyStat

8.1073.2.2 uint8_t wds_DormStatTlv::TlvPresent

8.1074 wds_GPRSQoS Struct Reference

Data Fields

- uint32_t precedenceClass
- uint32_t delayClass
- uint32_t reliabilityClass
- uint32_t peakThroughputClass
- uint32_t meanThroughputClass

8.1074.1 Detailed Description

This structure contains the GPRS Quality Of Service Information

Parameters

precedence-Class	• Precedence class
delayClass	• Delay class
reliabilityClass	• Reliability class
peak-Throughput-Class	• Peak throughput class
mean-Throughput-Class	• Mean throughput class

Note

Data invalid when all parameters are equal to 0xffffffff.

8.1074.2 Field Documentation

8.1074.2.1 uint32_t wds_GPRSQoS::delayClass

8.1074.2.2 uint32_t wds_GPRSQoS::meanThroughputClass

8.1074.2.3 uint32_t wds_GPRSQoS::peakThroughputClass

8.1074.2.4 uint32_t wds_GPRSQoS::precedenceClass

8.1074.2.5 uint32_t wds_GPRSQoS::reliabilityClass

8.1075 wds_IPv4AdTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint32_t IPv4Addr

8.1075.1 Detailed Description

IPv4 address TLV information

Parameters

TlvPresent	a flag indicates whether TLV presented or not
IPv4Addr	IPv4 address

8.1075.2 Field Documentation

8.1075.2.1 uint32_t wds_IPv4AdTlv::IPv4Addr

8.1075.2.2 uint8_t wds_IPv4AdTlv::TlvPresent

8.1076 wds_IPV6AddressInfo Struct Reference

Data Fields

- uint8_t IPV6PrefixLen
- uint16_t IPAddressV6 [8]

8.1076.1 Detailed Description

This structure contains the IPV6 Address Information

Parameters

IPV6PrefixLen	• Length of the received IPv6 address in no. of bits; can take value between 0 and 128 – 0xFF - Not Available
IPAddressV6	• IPv6 address(in network byte order); This is an 8-element array of 16 bit numbers, each of which is in big endian format.

8.1076.2 Field Documentation

8.1076.2.1 uint16_t wds_IPV6AddressInfo::IPAddressV6[8]

8.1076.2.2 uint8_t wds_IPV6AddressInfo::IPV6PrefixLen

8.1077 wds_IPV6GWAddressInfo Struct Reference

Data Fields

- uint8_t gwV6PrefixLen

- uint16_t gwAddressV6 [8]

8.1077.1 Detailed Description

This structure contains the IPV6 Gateway Address Information

Parameters

gwV6PrefixLen	• Length of the received IPv6 Gateway address in no. of bits; can take value between 0 and 128
IPAddressV6	• IPv6 Gateway address(in network byte order); This is an 8-element array of 16 bit numbers, each of which is in big endian format.

Note

Data invalid when IPV6PrefixLen equal 0xff.

8.1077.2 Field Documentation

8.1077.2.1 uint16_t wds_IPV6GWAddressInfo::gwAddressV6[8]

8.1077.2.2 uint8_t wds_IPV6GWAddressInfo::gwV6PrefixLen

8.1078 wds_LastMdmCallEndRsnTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint16_t CallEndReason

8.1078.1 Detailed Description

This structure stores information about modem last call end reason TLV.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
CallEndReason	-Modem call end reason • See qaGobiApiTableCallEndReasons.h for Call End Reason

8.1078.2 Field Documentation

8.1078.2.1 uint16_t wds_LastMdmCallEndRsnTlv::CallEndReason

8.1078.2.2 uint8_t wds_LastMdmCallEndRsnTlv::TlvPresent

8.1079 wds_PCSCFFQDNAddress Struct Reference

Data Fields

- uint16_t fqdnLen
- uint8_t fqdnAddr [256]

8.1079.1 Detailed Description

This structure contains the PCSCFFQDNAddress Information

Parameters

fqdnLen	• length of the received FQDN address
fqdnAddr	• FQDN address(Max 256 characters)

8.1079.2 Field Documentation

8.1079.2.1 uint8_t wds_PCSCFFQDNAddress::fqdnAddr[256]

8.1079.2.2 uint16_t wds_PCSCFFQDNAddress::fqdnLen

8.1080 wds_PCSCFFQDNAddressList Struct Reference

Data Fields

- uint8_t numInstances
- struct wds_PCSCFFQDNAddress pcsfFQDNAddress [10]

8.1080.1 Detailed Description

This structure contains the PCSCFFQDNAddressList Information

Parameters

numInstances	• Number of FQDN addresses received
pcsfFQDN-Address	• FQDN address information(Max 10 addresses)

Note

Data invalid when numInstances equal 0xff.

8.1080.2 Field Documentation

8.1080.2.1 uint8_t wds_PCSCFFQDNAddressList::numInstances

8.1080.2.2 struct wds_PCSCFFQDNAddress wds_PCSCFFQDNAddressList::pcsfFQDNAddress[10]

8.1081 wds_PCSCFIPv4ServerAddressList Struct Reference

Data Fields

- uint8_t numInstances
- uint32_t pscsfIPv4Addr [64]

8.1081.1 Detailed Description

This structure contains the PCSCFIPv4ServerAddressList Information

Parameters

numInstances	• number of address following
pscsfIPv4Addr	• P-CSCF IPv4 server addresses(Max 16 address, 4 bytes each)

Note

Data invalid when numInstances equal 0xff and pscsfIPv4Addr equal to 0xffffffff.

8.1081.2 Field Documentation

8.1081.2.1 uint8_t wds_PCSCFIPv4ServerAddressList::numInstances

8.1081.2.2 uint32_t wds_PCSCFIPv4ServerAddressList::pscsfIPv4Addr[64]

8.1082 wds_ProfileIdentifier Struct Reference

Data Fields

- uint8_t profileType
- uint8_t profileIndex

8.1082.1 Detailed Description

This structure contains the Profile Identifier Information

Parameters

profileType	• Identifies the type of profile 0x00 = 3GPP
profileIndex	• Index of profile whose settings were loaded prior to session parameter negotiation for the current call. If this TLV is not present, data call parameters are based on device default settings for each parameter

Note

Data invalid when all parameters are equal to 0xff.

8.1082.2 Field Documentation

8.1082.2.1 uint8_t wds_ProfileIdentifier::profileIndex

8.1082.2.2 uint8_t wds_ProfileIdentifier::profileType

8.1083 wds_profileInfo Union Reference

Data Fields

- LibPackprofile_3GPP SlqsProfile3GPP
- LibPackprofile_3GPP2 SlqsProfile3GPP2

8.1083.1 Detailed Description

This union consist of profile_3GPP and profile_3GPP2 out of which one will be used to create profile.

Parameters

SlqsProfile3GPP	3GPP profile See LibPackprofile_3GPP
SlqsProfile3GP-P2	3GPP2 profile See LibPackprofile_3GPP2

8.1083.2 Field Documentation

8.1083.2.1 LibPackprofile_3GPP wds_profileInfo::SlqsProfile3GPP

8.1083.2.2 LibPackprofile_3GPP2 wds_profileInfo::SlqsProfile3GPP2

8.1084 wds_RXBytesOKTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t RxByteOKCnt

8.1084.1 Detailed Description

This structure stores information about Rx Bytes OK TLV.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
RxByteOKCnt	-Number of bytes received without error

8.1084.2 Field Documentation

8.1084.2.1 uint64_t wds_RXBytesOKTlv::RxByteOKCnt

8.1084.2.2 uint8_t wds_RXBytesOKTlv::TlvPresent

8.1085 wds_transferStatInd Struct Reference

Data Fields

- uint8_t StatsPeriod
- uint32_t StatsMask

8.1085.1 Detailed Description

This structure contains the transfer statistic indication information

Parameters

StatsPeriod	Field Period between transfer statistic reports. • 0 - Do not report. • 1 - Other - Period between reports (in seconds).
StatsMask	requested statistic bit mask. • 0x00000040 - Tx bytes OK • 0x00000080 - Rx bytes OK

8.1085.2 Field Documentation

8.1085.2.1 uint32_t wds_transferStatInd::StatsMask

8.1085.2.2 uint8_t wds_transferStatInd::StatsPeriod

8.1086 wds_TrStatInd Struct Reference

Data Fields

- uint8_t statsPeriod
- uint32_t statsMask

8.1086.1 Detailed Description

This structure contains the information about the Transfer Statistics Indicator parameters.

Parameters

statsPeriod	• Period between transfer statistics reports. – 0 - Do not report – Other - Period between reports (seconds)

statsMask	• Requested statistic bit mask. – 0x00000001 - Tx packets OK – 0x00000002 - Rx packets OK – 0x00000004 - Tx packet errors – 0x00000008 - Rx packet errors – 0x00000010 - Tx overflows – 0x00000020 - Rx overflows – 0x00000040 - Tx bytes OK – 0x00000080 - Rx bytes OK • Each bit set causes the corresponding optional information to be sent in SLQSWdsEventReport-CallBack. • All unlisted bits are reserved for future use and must be set to zero.

8.1086.2 Field Documentation

8.1086.2.1 uint32_t wds_TrStatInd::statsMask

8.1086.2.2 uint8_t wds_TrStatInd::statsPeriod

8.1087 wds_TXBytesOKTlv Struct Reference

Data Fields

- uint8_t TlvPresent
- uint64_t TxByteOKCnt

8.1087.1 Detailed Description

This structure stores information about Tx Bytes OK TLV.

Parameters

TlvPresent	• value is 1 if this TLV is present in indication, otherwise 0
TxByteOKCnt	• Number of bytes transmitted without error

8.1087.2 Field Documentation

8.1087.2.1 uint8_t wds_TXBytesOKTlv::TlvPresent

8.1087.2.2 uint64_t wds_TXBytesOKTlv::TxByteOKCnt

8.1088 wds_UMTSMinQoS Struct Reference

Data Fields

- uint8_t trafficClass
- uint32_t maxUplinkBitrate
- uint32_t maxDownlinkBitrate
- uint32_t grntUplinkBitrate
- uint32_t grntDownlinkBitrate
- uint8_t qosDeliveryOrder
- uint32_t maxSDUSize
- uint8_t sduErrorRatio
- uint8_t resBerRatio
- uint8_t deliveryErrSDU
- uint32_t transferDelay
- uint32_t trafficPriority

8.1088.1 Detailed Description

This structure contains the UMTS Quality Of Service Information

Parameters

trafficClass	• 0x00 - Subscribed • 0x01 - Conversational • 0x02 - Streaming • 0x03 - Interactive • 0x04 - Background
maxUplinkBitrate	• Maximum uplink bit rate in bits/sec
maxDownlink-Bitrate	• Maximum downlink bit rate in bits/sec
grntUplinkBitrate	• Guaranteed uplink bit rate in bits/sec
grntDownlink-Bitrate	• Guaranteed downlink bit rate in bits/sec
qosDelivery-Order	- Qos delivery order • 0x00 - Subscribe • 0x01 - Delivery order on • 0x02 - Delivery order off
maxSDUSize	• Maximum SDU size

sduErrorRatio	- SDU error ratio • Target value for fraction of SDUs lost or detected as erroneous. • 0x00 - Subscribe • 0x01 - 1∗10^(-2) • 0x02 - 7∗10^(-3) • 0x03 - 1∗10^(-3) • 0x04 - 1∗10^(-4) • 0x05 - 1∗10^(-5) • 0x06 - 1∗10^(-6) • 0x07 - 1∗10^(-1)
resBerRatio	- Residual bit error ratio • Target value for undetected bit error ratio in in the delivered SDUs. • 0x00 - Subscribe • 0x01 - 5∗10^(-2) • 0x02 - 1∗10^(-2) • 0x03 - 5∗10^(-3) • 0x04 - 4∗10^(-3) • 0x05 - 1∗10^(-3) • 0x06 - 1∗10^(-4) • 0x07 - 1∗10^(-5) • 0x08 - 1∗10^(-6) • 0x09 - 1∗10^(-8)
deliveryErrSDU	- delivery of erroneous SDUs • Indicates whether SDUs detected as erroneous shall be delivered or not. • 0x00 - Subscribe • 0x01 - 5∗10^(-2) • 0x02 - 1∗10^(-2) • 0x03 - 5∗10^(-3) • 0x04 - 4∗10^(-3) • 0x05 - 1∗10^(-3) • 0x06 - 1∗10^(-4) • 0x07 - 1∗10^(-5) • 0x08 - 1∗10^(-6) • 0x09 - 1∗10^(-8)
transferDelay	- Transfer delay (ms) • Indicates the targeted time between a request to transfer an SDU at one SAP to its delivery at the other SAP in milliseconds.
trafficPriority	- Transfer handling priority • Specifies the relative importance for handling of SDUs that belong to the UMTS bearer, compared to the SDUs of other bearers.

8.1088.2 Field Documentation

8.1088.2.1 uint8_t wds_UMTSMinQoS::deliveryErrSDU

8.1088.2.2 uint32_t wds_UMTSMinQoS::grntDownlinkBitrate

8.1088.2.3 uint32_t wds_UMTSMinQoS::grntUplinkBitrate

8.1088.2.4 uint32_t wds_UMTSMinQoS::maxDownlinkBitrate

8.1088.2.5 uint32_t wds_UMTSMinQoS::maxSDUSize

8.1088.2.6 uint32_t wds_UMTSMinQoS::maxUplinkBitrate

8.1088.2.7 uint8_t wds_UMTSMinQoS::qosDeliveryOrder

8.1088.2.8 uint8_t wds_UMTSMinQoS::resBerRatio

8.1088.2.9 uint8_t wds_UMTSMinQoS::sduErrorRatio

8.1088.2.10 uint8_t wds_UMTSMinQoS::trafficClass

8.1088.2.11 uint32_t wds_UMTSMinQoS::trafficPriority

8.1088.2.12 uint32_t wds_UMTSMinQoS::transferDelay

8.1089 wdsDhcpv4HwConfig Struct Reference

Data Fields

- uint8_t hwType
- uint8_t chaddrLen
- uint8_t chaddr [16]

8.1089.1 Detailed Description

Structure contain DHCP V4 Hardware Configuration.

Parameters

hwType	DHCP HW Type, examples: • 0 - Ethernet • 20 - Serial
chaddrLen	Length of chaddr field, examples: • 6 for Ethernet MAC address
chaddr	Client hardware address

8.1089.2 Field Documentation

8.1089.2.1 uint8_t wdsDhcpv4HwConfig::chaddr[16]

8.1089.2.2 uint8_t wdsDhcpv4HwConfig::chaddrLen

8.1089.2.3 uint8_t wdsDhcpv4HwConfig::hwType

8.1090 wdsDhcpv4Option Struct Reference

Data Fields

- uint8_t optCode
- uint8_t optValLen
- uint8_t optVal [255]

8.1090.1 Detailed Description

This structure contains DHCP V4 Option information.

Parameters

optCode	Option code • 0 - 255
optValLen	Option value length • 0 - 255
optVal	Option Value

8.1090.2 Field Documentation

8.1090.2.1 uint8_t wdsDhcpv4Option::optCode

8.1090.2.2 uint8_t wdsDhcpv4Option::optVal[255]

8.1090.2.3 uint8_t wdsDhcpv4Option::optValLen

8.1091 wdsDhcpv4OptionList Struct Reference

Data Fields

- uint8_t numOpt
- wdsDhcpv4Option * pOptList

8.1091.1 Detailed Description

Structure contain DHCP V4 Option List

Parameters

numOpt	number of options • 0 - 255
pOptList	pointer to list of DHCP Options • See wdsDhcpv4Option

8.1091.2 Field Documentation

8.1091.2.1 uint8_t wdsDhcpv4OptionList::numOpt

8.1091.2.2 wdsDhcpv4Option* wdsDhcpv4OptionList::pOptList

8.1092 wdsDhcpv4ProfileId Struct Reference

Data Fields

- uint8_t profileType
- uint8_t profileId

8.1092.1 Detailed Description

This structure contains DHCP v4 ProfielID Information.

Parameters

profileType	profile type • 0 - 3GPP
profileId	profile index • index identifiying the profile 1-24 valid for 3GPP profile type (EM74xx and onwards)

8.1092.2 Field Documentation

8.1092.2.1 uint8_t wdsDhcpv4ProfileId::profileId

8.1092.2.2 uint8_t wdsDhcpv4ProfileId::profileType

Chapter 9

File Documentation

9.1 apdoxypages.c File Reference

Contains the module declaration for the Doxygen output. Also contains the content of the main page and related pages.

Namespaces

- Tables

9.1.1 Detailed Description

Contains the module declaration for the Doxygen output. Also contains the content of the main page and related pages.

9.2 audio.h File Reference

Data Structures

- struct pack_audio_SLQSGetAudioProfile_t
- struct unpack_audio_SLQSGetAudioProfile_t
- struct pack_audio_SLQSSetAudioProfile_t
- struct pack_audio_SLQSGetAudioPathConfig_t
- struct audio_TXPCMIIRFltr
- struct audio_RXPCMIIRFltr
- struct audio_RXAGCList
- struct audio_RXAVCList
- struct audio_TXAGCList
- struct unpack_audio_SLQSGetAudioPathConfig_t
- struct pack_audio_SLQSSetAudioPathConfig_t
- struct pack_audio_SLQSGetAudioVolTLBConfig_t
- struct unpack_audio_SLQSGetAudioVolTLBConfig_t
- struct pack_audio_SLQSSetAudioVolTLBConfig_t
- struct unpack_audio_SLQSSetAudioVolTLBConfig_t

Functions

- int pack_audio_SLQSGetAudioProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSGetAudioProfile_t *pReqParam)
- int unpack_audio_SLQSGetAudioProfile (uint8_t *pResp, uint16_t respLen, unpack_audio_SLQSGetAudioProfile_t *pOutput)
- int pack_audio_SLQSSetAudioProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSSetAudioProfile_t *pReqParam)
- int unpack_audio_SLQSSetAudioProfile (uint8_t *pResp, uint16_t respLen)
- int pack_audio_SLQSGetAudioPathConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSGetAudioPathConfig_t *pReqParam)
- int unpack_audio_SLQSGetAudioPathConfig (uint8_t *pResp, uint16_t respLen, unpack_audio_SLQSGetAudioPathConfig_t *pOutput)
- int pack_audio_SLQSSetAudioPathConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSSetAudioPathConfig_t *pReqParam)
- int unpack_audio_SLQSSetAudioPathConfig (uint8_t *pResp, uint16_t respLen)
- int pack_audio_SLQSGetAudioVolTLBConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSGetAudioVolTLBConfig_t *pReqParam)
- int unpack_audio_SLQSGetAudioVolTLBConfig (uint8_t *pResp, uint16_t respLen, unpack_audio_SLQSGetAudioVolTLBConfig_t *pOutput)
- int pack_audio_SLQSSetAudioVolTLBConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_audio_SLQSSetAudioVolTLBConfig_t *pReqParam)
- int unpack_audio_SLQSSetAudioVolTLBConfig (uint8_t *pResp, uint16_t respLen, unpack_audio_SLQSSetAudioVolTLBConfig_t *pOutput)

9.2.1 Function Documentation

9.2.1.1 int pack_audio_SLQSGetAudioPathConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSGetAudioPathConfig_t * *pReqParam*)

Gets the audio path configuration parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.2 int pack_audio_SLQSGetAudioProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSGetAudioProfile_t * *pReqParam*)

Gets get the profile content of the requested audio generator. pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.3 int pack_audio_SLQSGetAudioVolTLBConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSGetAudioVolTLBConfig_t * *pReqParam*)

Gets the audio VolTLB configuration parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.4 int pack_audio_SLQSSetAudioPathConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSSetAudioPathConfig_t * *pReqParam*)

sets the audio path configuration parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.5 int pack_audio_SLQSSetAudioProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSSetAudioProfile_t * *pReqParam*)

sets an audio profile pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.6 int pack_audio_SLQSSetAudioVoITLBConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_audio_SLQSSetAudioVoITLBConfig_t * *pReqParam*)

Sets the audio VoITLB configuration parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: SL9090

9.2.1.7 int unpack_audio_SLQSGetAudioPathConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_audio_SLQSGetAudioPathConfig_t * *pOutput*)

Gets the audio path configuration parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.2.1.8 int unpack_audio_SLQSGetAudioProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_audio_SLQSGetAudioProfile_t * *pOutput*)

Gets get the profile content of the requested audio generator unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.2.1.9 int unpack_audio_SLQSGetAudioVoITLBConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_audio_SLQSGetAudioVoITLBConfig_t * *pOutput*)

Gets the audio VoITLB configuration parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.2.1.10 int unpack_audio_SLQSSetAudioPathConfig (uint8_t * *pResp*, uint16_t *respLen*)

sets the audio path configuration parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.2.1.11 int unpack_audio_SLQSSetAudioProfile (uint8_t * *pResp*, uint16_t *respLen*)

sets an audio profile unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.2.1.12 int unpack_audio_SLQSSetAudioVoITLBConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_audio_SLQSSetAudioVoITLBConfig_t * *pOutput*)

Sets the audio VoITLB configuration parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3 cat.h File Reference

Data Structures

- struct pack_cat_SetCATEventCallback_t
- struct unpack_cat_SetCATEventCallback_t
- struct cat_EventIDDataTlv
- struct cat_AlPhaIdentifierTlv
- struct cat_EventListTlv
- struct cat_RefreshTlv
- struct cat_EndProactiveSessionTlv
- union cat_currentCatEvent
- struct cat_commonEventTlv
- struct unpack_cat_SetCatEventCallback_ind_t
- struct pack_cat_CATSendEnvelopeCommand_t
- struct pack_cat_CATSendTerminalResponse_t

Macros

- #define CAT_EVENT_DATA_MAX_LENGTH 255
- #define CAN_COMMON_EVENT_TLV_NUMBER 11

Typedefs

- typedef unpack_result_t unpack_cat_CATSendEnvelopeCommand_t
- typedef unpack_result_t unpack_cat_CATSendTerminalResponse_t

Functions

- int pack_cat_SetCATEventCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_cat_SetCATEventCallback_t *reqArg)
- int unpack_cat_SetCATEventCallback (uint8_t *pResp, uint16_t respLen, unpack_cat_SetCATEventCallback_t *pOutput)
- int unpack_cat_SetCatEventCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_cat_SetCatEventCallback_ind_t *pOutput)
- int pack_cat_CATSendEnvelopeCommand (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_cat_CATSendEnvelopeCommand_t *reqArg)
- int unpack_cat_CATSendEnvelopeCommand (uint8_t *pResp, uint16_t respLen, unpack_cat_CATSendEnvelopeCommand_t *pOutput)
- int pack_cat_CATSendTerminalResponse (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_cat_CATSendTerminalResponse_t *reqArg)
- int unpack_cat_CATSendTerminalResponse (uint8_t *pResp, uint16_t respLen, unpack_cat_CATSendTerminalResponse_t *pOutput)

9.3.1 Macro Definition Documentation

9.3.1.1 #define CAN_COMMON_EVENT_TLV_NUMBER 11

9.3.1.2 #define CAT_EVENT_DATA_MAX_LENGTH 255

9.3.2 Typedef Documentation

9.3.2.1 typedef unpack_result_t unpack_cat_CATSendEnvelopeCommand_t

9.3.2.2 typedef unpack_result_t unpack_cat_CATSendTerminalResponse_t

9.3.3 Function Documentation

9.3.3.1 int pack_cat_CATSendEnvelopeCommand (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_cat_CATSendEnvelopeCommand_t * *reqArg*)

Sends the envelope command to the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.3.2 int pack_cat_CATSendTerminalResponse (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_cat_CATSendTerminalResponse_t * *reqArg*)

Sends the terminal response to the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter •

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.3.3 int pack_cat_SetCATEventCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_cat_SetCATEventCallback_t * *reqArg*)

Enables/disables the CAT event callback pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.3.4 int unpack_cat_CATSendEnvelopeCommand (uint8_t * *pResp*, uint16_t *respLen*, unpack_cat_CATSendEnvelopeCommand_t * *pOutput*)

Sends the envelope command to the device unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.3.5 int unpack_cat_CATSendTerminalResponse (uint8_t * *pResp*, uint16_t *respLen*, unpack_cat_CATSendTerminalResponse_t * *pOutput*)

Sends the terminal response to the device unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.3.6 int unpack_cat_SetCATEventCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_cat_SetCATEventCallback_t * *pOutput*)

Enables/disables the CAT event callback unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.3.3.7 int unpack_cat_SetCatEventCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_cat_SetCatEvent-Callback_ind_t * *pOutput*)

CAT event indication unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.4 common.h File Reference

Data Structures

- struct pack_qmi_t
- struct unpack_qmi_t
- struct unpack_result_t

Macros

- #define SDU_HDR_LEN (3)

- #define MINREQBKLEN (2048)
- #define MSGID_AND_LEN (4)
- #define MSGID_DONT_CARE (0xffff)
- #define UNUSEDPARAM(x) (void)x
- #define DEAULT_LOC_TIMEOUT_IN_SEC 2
- #define SDK_VALIDATE_INPUT_PACK_PARAM(pCtx, pBuf, pLen)
- #define SDK_VALIDATE_INPUT_PACK_PARAM_AND_FILL_XID(pCtx, pBuf, pLen)
- #define SDK_VALIDATE_INPUT_UNPACK_PARAM(pResp, respLen, pOutput)
- #define SWI_INIT_UNPACK_RESULT_VALUE {0, SWI_UINT256_INT_VALUE}

Typedefs

- typedef void(∗ logger)(uint8_t lvl, const char ∗buff)

Enumerations

- enum eLOG_LEVEL {
  eLOG_INFO,
  eLOG_DEBUG,
  eLOG_WARN,
  eLOG_FATAL }
- enum eTimeout {
  eTIMEOUT_2_S = 2000,
  eTIMEOUT_5_S = 5000,
  eTIMEOUT_8_S = 8000,
  eTIMEOUT_10_S = 10000,
  eTIMEOUT_20_S = 20000,
  eTIMEOUT_30_S = 30000,
  eTIMEOUT_60_S = 60000,
  eTIMEOUT_300_S = 300000,
  eTIMEOUT_DEFAULT = eTIMEOUT_8_S }
- enum eQMI_SVC {
  eCTL,
  eWDS,
  eDMS,
  eNAS =3,
  eQOS,
  eSMS =5,
  ePDS =0x06,
  eVOICE =0x09,
  eCAT =0x0A,
  eUIM =0x0B,
  eLOC =0x10,
  eSAR =0x11,
  eIMS =0x12,
  eTMD =0x18,
  eIMSA =0x21,
  eRMS =225,
  eSWIOMA =240,
  eAUDIO =241,
  eSWIM2MCMD =243,
  eSWIM2MCMD_AVC2 =0xfd,
  eSWIOMAEXT =244,
  eSWIAUDIO = 245,
  eSWILOC =246,
  eSWIDMS =254 }

- enum msgtype {
  eREQ =0,
  eRSP =2,
  eIND =4 }

Functions

- uint16_t helper_get_xid (uint8_t *qmi_resp)
- uint16_t helper_get_error_code (uint8_t *qmi_resp)
- char * helper_get_error_reason (uint16_t retVal)
- const char * helper_get_resp_ctx (uint8_t svc, uint8_t *pbuf, uint32_t len, unpack_qmi_t *pCtx)
- const char * helper_get_req_str (uint8_t svc, uint8_t *req, uint32_t len)
- unsigned unpack_result_code_only (uint8_t *pMdmResp)
- int helper_set_log_func (logger *func)
- void liteqmi_log (uint8_t lvl, const char *fmt,...)
- int helper_set_log_lvl (uint8_t lvl)
- void fill_sdu_hdr (pack_qmi_t *pCtx, uint8_t *pReqBuf)
- void fill_pack_ctx (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, uint8_t svc, int timeout)
- char * get_version ()
- char * liteqmi_GetVersion ()
- void liteqmi_helper_decode7bitAsciiEncString (uint8_t *encoded_str, uint8_t encoded_len, uint8_t *decoded_str)
- int helper_isBootLoader_DebugEnabled (const char *szPath, const char *pQsn)

Variables

- logger * glog
- uint8_t gloglvl

9.4.1 Macro Definition Documentation

9.4.1.1 #define DEAULT_LOC_TIMEOUT_IN_SEC 2

9.4.1.2 #define MINREQBKLEN (2048)

9.4.1.3 #define MSGID_AND_LEN (4)

9.4.1.4 #define MSGID_DONT_CARE (0xffff)

9.4.1.5 #define SDK_VALIDATE_INPUT_PACK_PARAM(*pCtx, pBuf, pLen*)

Value:

```
if ((pCtx == NULL) || (pBuf == NULL) || (pLen == NULL) ) \
        {\
        liteqmi_log(eLOG_DEBUG,"[  pack] %s parameter NULL\n",__func__); \
        return eQCWWAN_ERR_INVALID_ARG; \
        }
```

9.4.1.6 #define SDK_VALIDATE_INPUT_PACK_PARAM_AND_FILL_XID(*pCtx, pBuf, pLen*)

Value:

```
if ((pCtx == NULL) || (pBuf == NULL) || (pLen == NULL) ) \
        {\
        liteqmi_log(eLOG_DEBUG,"[  pack] %s parameter NULL\n",__func__); \
        return eQCWWAN_ERR_INVALID_ARG; \
        } \
    if (pCtx->xid == 0) \
       return eQCWWAN_ERR_INVALID_XID; \
    pBuf[0] = eREQ; \
    pBuf[1] = pCtx->xid & 0xff; \
    pBuf[2] = pCtx->xid >> 8;
```

9.4.1.7 #define SDK_VALIDATE_INPUT_UNPACK_PARAM(*pResp, respLen, pOutput*)

Value:

```
if ((pResp == NULL) || (respLen == 0) || (pOutput == NULL) ) \
        {\
        liteqmi_log(eLOG_DEBUG,"[ unpack] %s parameter NULL or invalid\n",
      __func__); \
        return eQCWWAN_ERR_INVALID_ARG; \
        }
```

9.4.1.8 #define SDU_HDR_LEN (3)

9.4.1.9 #define SWI_INIT_UNPACK_RESULT_VALUE {0, SWI_UINT256_INT_VALUE}

9.4.1.10 #define UNUSEDPARAM(*x*) (void)x

9.4.2 Typedef Documentation

9.4.2.1 typedef void(∗ logger)(uint8_t lvl, const char ∗buff)

9.4.3 Enumeration Type Documentation

9.4.3.1 enum eLOG_LEVEL

log levels

Enumerator

eLOG_INFO

eLOG_DEBUG

eLOG_WARN

eLOG_FATAL

9.4.3.2 enum eQMI_SVC

qmi service

Enumerator

eCTL

eWDS

eDMS

eNAS
eQOS
eSMS
ePDS
eVOICE
eCAT
eUIM
eLOC
eSAR
eIMS
eTMD
eIMSA
eRMS
eSWIOMA
eAUDIO
eSWIM2MCMD
eSWIM2MCMD_AVC2
eSWIOMAEXT
eSWIAUDIO
eSWILOC
eSWIDMS

9.4.3.3 enum eTimeout

eTimeout

Enumerator

eTIMEOUT_2_S
eTIMEOUT_5_S
eTIMEOUT_8_S
eTIMEOUT_10_S
eTIMEOUT_20_S
eTIMEOUT_30_S
eTIMEOUT_60_S
eTIMEOUT_300_S
eTIMEOUT_DEFAULT

9.4.3.4 enum msgtype

qmi message type

Enumerator

eREQ
eRSP
eIND

9.4.4 Function Documentation

9.4.4.1 void fill_pack_ctx (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen,* uint8_t *svc,* int *timeout*)

9.4.4.2 void fill_sdu_hdr (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf*)

9.4.4.3 char* get_version ( )

Returns

version string

9.4.4.4 uint16_t helper_get_error_code (uint8_t * *qmi_resp*)

9.4.4.5 char* helper_get_error_reason (uint16_t *retVal*)

9.4.4.6 const char* helper_get_req_str (uint8_t *svc,* uint8_t * *req,* uint32_t *len*)

extract msgid string from modem req

Parameters

in	*svc*	qmi service
in	*req*	qmi request
in	*len*	request length

Returns

qmi message string

9.4.4.7 const char* helper_get_resp_ctx (uint8_t *svc,* uint8_t * *pbuf,* uint32_t *len,* unpack_qmi_t * *pCtx*)

extract msgid/xid/type from modem reply

Parameters

in	*svc*	qmi service
in	*pbuf*	qmi response/indication
in	*len*	response/indication length
out	*pCtx*	unpacked context

Returns

qmi message string

9.4.4.8 uint16_t helper_get_xid (uint8_t * *qmi_resp*)

9.4.4.9 int helper_isBootLoader_DebugEnabled (const char * *szPath,* const char * *pQsn*)

Parameters

in	*szPath*	the full path of the provided bootloader or firmware file
in	*pQsn*	the QSN of a specific module user wants to check, it is a 4 bytes hex value without the prefix 0X. It can be retrieved by AT command AT!ENTERCND="<password>", AT!SECBOOTCFG?, the first parameter of the response of AT!SECBOOTCFG?.

Returns

values listed below

- -1 bootloader is not debug enabled
- 0 unbale to retrieve the bootloader debug info
- 1 bootloader is debug enabled for the provided QSN
- 4 either szPath or pQsn is invalid (NULL)
- 18 invalid file

9.4.4.10 int helper_set_log_func (logger * *func*)

set log function

9.4.4.11 int helper_set_log_lvl (uint8_t *lvl*)

set log level

9.4.4.12 char* liteqmi_GetVersion ( )

Returns

version string

9.4.4.13 void liteqmi_helper_decode7bitAsciiEncString (uint8_t * *encoded_str,* uint8_t *encoded_len,* uint8_t * *decoded_str*)

decode 7bit encoded string

Parameters

in	*encoded_str*	7 bit encoded ASCII
in	*encoded_len*	encoded length
out	*decoded_str*	decoded ASCII string

9.4.4.14 void liteqmi_log (uint8_t *lvl,* const char * *fmt,* ...)

9.4.4.15 unsigned unpack_result_code_only (uint8_t * *pMdmResp*)

common handler for unpacking response with TLV type 0x02 only

9.4.5 Variable Documentation

9.4.5.1 logger* glog

9.4.5.2 uint8_t gloglvl

9.5 dms.h File Reference

Data Structures

- struct unpack_dms_GetModelID_t

- struct unpack_dms_GetIMSI_t
- struct unpack_dms_GetFirmwareInfo_t
- struct unpack_dms_GetPower_t
- struct unpack_dms_GetSerialNumbers_t
- struct unpack_dms_GetHardwareRevision_t
- struct unpack_dms_SLQSGetBandCapability_t
- struct unpack_dms_GetDeviceCapabilities_t
- struct unpack_dms_GetFirmwareRevisions_t
- struct unpack_dms_GetFirmwareRevision_t
- struct unpack_dms_GetDeviceSerialNumbers_t
- struct unpack_dms_GetPRLVersion_t
- struct unpack_dms_GetNetworkTime_t
- struct unpack_dms_GetVoiceNumber_t
- struct unpack_dms_GetDeviceHardwareRev_t
- struct unpack_dms_GetFSN_t
- struct unpack_dms_GetDeviceCap_t
- struct pack_dms_SetPower_t
- struct unpack_dms_SetPower_t
- struct unpack_dms_GetBandCapability_t
- struct unpack_dms_GetUSBComp_t
- struct pack_dms_SetUSBComp_t
- struct unpack_dms_SetUSBComp_t
- struct pack_dms_SetCustFeature_t
- struct unpack_dms_SetCustFeature_t
- struct unpack_dms_GetCustFeature_t
- struct unpack_dms_SetFirmwarePreference_t
- struct unpack_dms_GetCrashAction_t
- struct pack_dms_SetCrashAction_t
- struct unpack_dms_SetCrashAction_t
- struct unpack_dms_GetDeviceMfr_t
- struct pack_dms_SetEventReport_t
- struct unpack_dms_SetEventReport_t
- struct dms_OperatingModeTlv
- struct dms_ActivationStatusTlv
- struct unpack_dms_SetEventReport_ind_t
- struct pack_dms_UIMGetICCID_t
- struct unpack_dms_UIMGetICCID_t
- struct pack_dms_SetCustFeaturesV2_t
- struct unpack_dms_SetCustFeaturesV2_t
- struct pack_dms_GetCustFeaturesV2_t
- struct DMSgetCustomInput
- struct DMScustSettingInfo
- struct DMScustSettingList
- struct DMSgetCustomFeatureV2
- struct unpack_dms_GetCustFeaturesV2_t
- struct unpack_dms_GetActivationState_t
- struct image_info_t
- struct unpack_dms_SLQSSwiGetFirmwareCurr_t
- struct pack_dms_SLQSSwiSetDyingGaspCfg_t
- struct unpack_dms_SLQSSwiSetDyingGaspCfg_t
- struct unpack_dms_SLQSSwiClearDyingGaspStatistics_t
- struct packgetDyingGaspStatistics
- struct unpack_dms_SLQSSwiGetDyingGaspStatistics_t
- struct packgetDyingGaspCfg
- struct unpack_dms_SLQSSwiGetDyingGaspCfg_t

- struct unpack_dms_SLQSDmsSwiGetResetInfo_t
- struct unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t
- struct pack_dms_SLQSDmsSwiIndicationRegister_t
- struct unpack_dms_SLQSDmsSwiIndicationRegister_t
- struct unpack_dms_SLQSSwiGetFwUpdateStatus_t
- struct unpack_dms_GetManufacturer_t
- struct unpack_dms_GetOfflineReason_t
- struct pack_dms_SetActivationStatusCallback_t
- struct unpack_dms_SetActivationStatusCallback_t
- struct pack_dms_UIMSetPINProtection_t
- struct unpack_dms_UIMSetPINProtection_t
- struct pack_dms_UIMUnblockPIN_t
- struct pack_dms_UIMVerifyPIN_t
- struct pack_dms_UIMChangePIN_t
- struct pack_dms_UIMGetControlKeyStatus_t
- struct unpack_dms_UIMGetControlKeyStatus_t
- struct unpack_dms_UIMGetPINStatus_t
- struct pack_dms_UIMSetControlKeyProtection_t
- struct unpack_dms_UIMSetControlKeyProtection_t
- struct pack_dms_UIMUnblockControlKey_t
- struct unpack_dms_UIMUnblockControlKey_t
- struct pack_dms_ResetToFactoryDefaults_t
- struct unpack_dms_ResetToFactoryDefaults_t
- struct pack_dms_ActivateAutomatic_t
- struct eriDataparams
- struct unpack_dms_SLQSGetERIFile_t
- struct unpack_dms_SLQSUIMGetState_t
- struct pack_dms_SLQSSwiGetCrashInfo_t
- struct crashInformation
- struct crashInfoParams
- struct unpack_dms_SLQSSwiGetCrashInfo_t
- struct unpack_dms_SLQSSwiGetHostDevInfo_t
- struct pack_dms_SLQSSwiSetHostDevInfo_t
- struct unpack_dms_SLQSSwiSetHostDevInfo_t
- struct unpack_dms_SLQSSwiGetOSInfo_t
- struct pack_dms_SLQSSwiSetOSInfo_t
- struct unpack_dms_SLQSSwiSetOSInfo_t
- struct unpack_dms_SLQSSwiGetSerialNoExt_t
- struct unpack_dms_SLQSDmsSwiGetPCInfo_t
- struct dms_PSMEnableStateTlv
- struct dms_PSMDurationThresholdTlv
- struct dms_PSMDurationDueToOOSTlv
- struct dms_PSMRandomizationWindowTlv
- struct dms_PSMActiveTimerTlv
- struct dms_PSMPeriodicUpdateTimerTlv
- struct dms_PSMEarlyWakeupTimeTlv
- struct unpack_dms_SLQSGetPowerSaveModeConfig_t
- struct pack_dms_SLQSSetPowerSaveModeConfig_t
- struct unpack_dms_SLQSSetPowerSaveModeConfig_t
- struct pack_dms_SetIndicationRegister_t
- struct unpack_dms_SetIndicationRegister_t
- struct dms_PSMEnableStateIndTlv
- struct dms_PSMActiveTimerIndTlv
- struct dms_PSMPeriodicUpdateTimerIndTlv
- struct unpack_dms_PSMCfgChange_ind_t

- struct pack_dms_SwiSetEventReport_t
- struct unpack_dms_SwiSetEventReport_t
- struct dms_TemperatureTlv
- struct dms_VoltageTlv
- struct dms_UimStatusTlv
- struct unpack_dms_SwiEventReportCallBack_ind_t
- struct pack_dms_SwiUimSelect_t
- struct unpack_dms_SwiUimSelect_t
- struct dms_UimAutoSwitchActSlotTlv
- struct unpack_dms_SLQSDmsSwiGetUimSelection_t

Macros

- #define DMS_UINT8_MAX_STRING_SZ 255
- #define DMS_MAX_CUST_ID_LEN 64
- #define DMS_MAX_CUST_VALUE_LEN 8
- #define DMS_IMGDETAILS_LEN 16
- #define DMS_MAX_FWUPDATE_LOG_STR_SZ 255
- #define DMS_MAX_FWUPDATE_REF_STR_SZ 15
- #define DMS_VALID_FSN_LEN 14
- #define DMS_MAX_RADIO_IFCS_SIZE 64
- #define DMS_SLQSFWINFO_MODELID_SZ 20
- #define DMS_SLQSFWINFO_BOOTVERSION_SZ 85
- #define DMS_SLQSFWINFO_APPVERSION_SZ 85
- #define DMS_SLQSFWINFO_SKU_SZ 15
- #define DMS_SLQSFWINFO_PACKAGEID_SZ 85
- #define DMS_SLQSFWINFO_CARRIER_SZ 20
- #define DMS_SLQSFWINFO_PRIVERSION_SZ 16
- #define DMS_SLQSFWINFO_CUR_CARR_NAME 17
- #define DMS_SLQSFWINFO_CUR_CARR_REV 13
- #define MAX_BUILD_ID_LEN 255
- #define UNIQUE_ID_LEN 16
- #define SLQS_MAX_DYING_GASP_CFG_SMS_CONTENT_LENGTH 160
- #define SLQS_MAX_DYING_GASP_CFG_SMS_NUMBER_LENGTH 20
- #define SPC_SIZE 6
- #define CK_MAX_SIZE 8
- #define ACT_CODE_MAX_SIZE 81
- #define ERI_DATA_MAX_SIZE 1024
- #define MEID_MAX_SIZE 8
- #define DMS_PM_ONLINE 0x00 /∗ Online ∗/
- #define DMS_PM_LOW 0x01 /∗ Low Power ∗/
- #define DMS_PM_FACTORY 0x02 /∗ Factory Test Mode ∗/
- #define DMS_PM_OFFLINE 0x03 /∗ Offline ∗/
- #define DMS_PM_RESET 0x04 /∗ Reset ∗/
- #define DMS_PM_SHUT_DOWN 0x05 /∗ Shut Down ∗/
- #define DMS_PM_PERSISTENT_LOW 0x06 /∗ Persistent Low Power ∗/
- #define DMS_SET_REPORT_ENABLE 1
- #define DMS_SET_REPORT_DISABLE 0
- #define DMS_SWI_SET_IND_ENABLE 1
- #define DMS_SWI_SET_IND_DISABLE 0
- #define DMS_SET_REG_IND_ENABLE 1
- #define DMS_SET_REG_IND_DISABLE 0
- #define DMS_SET_REG_IND_NO_CHANGE 2

Functions

- int pack_dms_GetIMSI (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetIMSI (uint8_t *pResp, uint16_t respLen, unpack_dms_GetIMSI_t *pOutput)
- int pack_dms_GetModelID (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetModelID (uint8_t *pResp, uint16_t respLen, unpack_dms_GetModelID_t *pOutput)
- int pack_dms_GetFirmwareInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetFirmwareInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_GetFirmwareInfo_t *pOutput)
- int pack_dms_GetPower (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetPower (uint8_t *pResp, uint16_t respLen, unpack_dms_GetPower_t *pOutput)
- int pack_dms_GetSerialNumbers (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetSerialNumbers (uint8_t *pResp, uint16_t respLen, unpack_dms_GetSerialNumbers_t *pOutput)
- int pack_dms_GetHardwareRevision (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetHardwareRevision (uint8_t *pResp, uint16_t respLen, unpack_dms_GetHardwareRevision_t *pOutput)
- int pack_dms_SLQSGetBandCapability (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_SLQSGetBandCapability (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSGetBandCapability_t *pOutput)
- int pack_dms_GetDeviceCapabilities (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetDeviceCapabilities (uint8_t *pResp, uint16_t respLen, unpack_dms_GetDeviceCapabilities_t *pOutput)
- int pack_dms_GetFirmwareRevisions (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetFirmwareRevisions (uint8_t *pResp, uint16_t respLen, unpack_dms_GetFirmwareRevisions_t *pOutput)
- int pack_dms_GetFirmwareRevision (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetFirmwareRevision (uint8_t *pResp, uint16_t respLen, unpack_dms_GetFirmwareRevision_t *pOutput)
- int pack_dms_GetDeviceSerialNumbers (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetDeviceSerialNumbers (uint8_t *pResp, uint16_t respLen, unpack_dms_GetDeviceSerialNumbers_t *pOutput)
- int pack_dms_GetPRLVersion (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetPRLVersion (uint8_t *pResp, uint16_t respLen, unpack_dms_GetPRLVersion_t *pOutput)
- int pack_dms_GetNetworkTime (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetNetworkTime (uint8_t *pResp, uint16_t respLen, unpack_dms_GetNetworkTime_t *pOutput)
- int pack_dms_GetVoiceNumber (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetVoiceNumber (uint8_t *pResp, uint16_t respLen, unpack_dms_GetVoiceNumber_t *pOutput)
- int pack_dms_GetDeviceHardwareRev (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetDeviceHardwareRev (uint8_t *pResp, uint16_t respLen, unpack_dms_GetDeviceHardwareRev_t *pOutput)
- int pack_dms_GetFSN (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetFSN (uint8_t *pResp, uint16_t respLen, unpack_dms_GetFSN_t *pOutput)
- int pack_dms_GetDeviceCap (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetDeviceCap (uint8_t *pResp, uint16_t respLen, unpack_dms_GetDeviceCap_t *pOutput)
- int pack_dms_SetPower (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetPower_t *reqArg)
- int unpack_dms_SetPower (uint8_t *pResp, uint16_t respLen, unpack_dms_SetPower_t *pOutput)
- int pack_dms_GetBandCapability (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetBandCapability (uint8_t *pResp, uint16_t respLen, unpack_dms_GetBandCapability_t *pOutput)
- int pack_dms_GetUSBComp (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetUSBComp (uint8_t *pResp, uint16_t respLen, unpack_dms_GetUSBComp_t *pOutput)

- int pack_dms_SetUSBComp (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetUSBComp_t *reqArg)
- int unpack_dms_SetUSBComp (uint8_t *pResp, uint16_t respLen, unpack_dms_SetUSBComp_t *pOutput)
- int pack_dms_SetCustFeature (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetCustFeature_t *reqArg)
- int unpack_dms_SetCustFeature (uint8_t *pResp, uint16_t respLen, unpack_dms_SetCustFeature_t *pOutput)
- int pack_dms_GetCustFeature (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetCustFeature (uint8_t *pResp, uint16_t respLen, unpack_dms_GetCustFeature_t *pOutput)
- int pack_dms_SetFirmwarePreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_SetFirmwarePreference (uint8_t *pResp, uint16_t respLen, unpack_dms_SetFirmwarePreference_t *pOutput)
- int pack_dms_GetCrashAction (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetCrashAction (uint8_t *pResp, uint16_t respLen, unpack_dms_GetCrashAction_t *pOutput)
- int pack_dms_SetCrashAction (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetCrashAction_t reqArg)
- int unpack_dms_SetCrashAction (uint8_t *pResp, uint16_t respLen, unpack_dms_SetCrashAction_t *pOutput)
- int pack_dms_GetDeviceMfr (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_GetDeviceMfr (uint8_t *pResp, uint16_t respLen, unpack_dms_GetDeviceMfr_t *pOutput)
- int pack_dms_SetEventReport (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetEventReport_t *reqArg)
- int unpack_dms_SetEventReport (uint8_t *pResp, uint16_t respLen, unpack_dms_SetEventReport_t *pOutput)
- int unpack_dms_SetEventReport_ind (uint8_t *pResp, uint16_t respLen, unpack_dms_SetEventReport_ind_t *pOutput)
- int pack_dms_UIMGetICCID (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMGetICCID_t *reqArg)
- int unpack_dms_UIMGetICCID (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMGetICCID_t *pOutput)
- int pack_dms_SetCustFeaturesV2 (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetCustFeaturesV2_t *reqArg)
- int unpack_dms_SetCustFeaturesV2 (uint8_t *pResp, uint16_t respLen, unpack_dms_SetCustFeaturesV2_t *pOutput)
- int pack_dms_GetCustFeaturesV2 (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_GetCustFeaturesV2_t *reqArg)
- int unpack_dms_GetCustFeaturesV2 (uint8_t *pResp, uint16_t respLen, unpack_dms_GetCustFeaturesV2_t *pOutput)
- int pack_dms_GetActivationState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_GetActivationState (uint8_t *pResp, uint16_t respLen, unpack_dms_GetActivationState_t *pOutput)
- int pack_dms_SLQSSwiGetFirmwareCurr (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetFirmwareCurr (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetFirmwareCurr_t *pOutput)
- int pack_dms_SLQSSwiSetDyingGaspCfg (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SLQSSwiSetDyingGaspCfg_t *reqArg)
- int unpack_dms_SLQSSwiSetDyingGaspCfg (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiSetDyingGaspCfg_t *pOutput)
- int pack_dms_SLQSSwiClearDyingGaspStatistics (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiClearDyingGaspStatistics (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiClearDyingGaspStatistics_t *pOutput)
- int pack_dms_SLQSSwiGetDyingGaspStatistics (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetDyingGaspStatistics (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetDyingGaspStatistics_t *pOutput)
- int pack_dms_SLQSSwiGetDyingGaspCfg (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)

- int unpack_dms_SLQSSwiGetDyingGaspCfg (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetDyingGaspCfg_t *pOutput)
- int pack_dms_SLQSDmsSwiGetResetInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSDmsSwiGetResetInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSDmsSwiGetResetInfo_t *pOutput)
- int unpack_dms_SLQSDmsSwiGetResetInfo_Ind (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t *pOutput)
- int pack_dms_SLQSDmsSwiIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SLQSDmsSwiIndicationRegister_t *reqArg)
- int unpack_dms_SLQSDmsSwiIndicationRegister (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSDmsSwiIndicationRegister_t *pOutput)
- int pack_dms_SLQSSwiGetFwUpdateStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetFwUpdateStatus (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetFwUpdateStatus_t *pOutput)
- int pack_dms_GetManufacturer (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_GetManufacturer (uint8_t *pResp, uint16_t respLen, unpack_dms_GetManufacturer_t *pOutput)
- int pack_dms_GetOfflineReason (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_GetOfflineReason (uint8_t *pResp, uint16_t respLen, unpack_dms_GetOfflineReason_t *pOutput)
- int pack_dms_SetActivationStatusCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetActivationStatusCallback_t *reqArg)
- int unpack_dms_SetActivationStatusCallback (uint8_t *pResp, uint16_t respLen, unpack_dms_SetActivationStatusCallback_t *pOutput)
- int pack_dms_UIMSetPINProtection (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMSetPINProtection_t *pReq)
- int unpack_dms_UIMSetPINProtection (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMSetPINProtection_t *pOutput)
- int pack_dms_UIMUnblockPIN (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMUnblockPIN_t *pReq)
- int unpack_dms_UIMUnblockPIN (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMSetPINProtection_t *pOutput)
- int pack_dms_UIMVerifyPIN (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMVerifyPIN_t *pReq)
- int unpack_dms_UIMVerifyPIN (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMSetPINProtection_t *pOutput)
- int pack_dms_UIMChangePIN (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMChangePIN_t *pReq)
- int unpack_dms_UIMChangePIN (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMSetPINProtection_t *pOutput)
- int pack_dms_UIMGetControlKeyStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMGetControlKeyStatus_t *pReq)
- int unpack_dms_UIMGetControlKeyStatus (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMGetControlKeyStatus_t *pOutput)
- int pack_dms_UIMGetPINStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_UIMGetPINStatus (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMGetPINStatus_t *pOutput)
- int pack_dms_UIMSetControlKeyProtection (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMSetControlKeyProtection_t *pReq)
- int unpack_dms_UIMSetControlKeyProtection (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMSetControlKeyProtection_t *pOutput)
- int pack_dms_UIMUnblockControlKey (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_UIMUnblockControlKey_t *pReq)
- int unpack_dms_UIMUnblockControlKey (uint8_t *pResp, uint16_t respLen, unpack_dms_UIMUnblockControlKey_t *pOutput)

- int pack_dms_ResetToFactoryDefaults (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_ResetToFactoryDefaults_t *pReq)
- int unpack_dms_ResetToFactoryDefaults (uint8_t *pResp, uint16_t respLen, unpack_dms_ResetToFactoryDefaults_t *pOutput)
- int pack_dms_ValidateSPC (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_ResetToFactoryDefaults_t *pReq)
- int unpack_dms_ValidateSPC (uint8_t *pResp, uint16_t respLen, unpack_dms_ResetToFactoryDefaults_t *pOutput)
- int pack_dms_ActivateAutomatic (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_ActivateAutomatic_t *pReq)
- int unpack_dms_ActivateAutomatic (uint8_t *pResp, uint16_t respLen, unpack_dms_ResetToFactoryDefaults_t *pOutput)
- int pack_dms_SLQSGetERIFile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSGetERIFile (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSGetERIFile_t *pOutput)
- int pack_dms_SLQSUIMGetState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSUIMGetState (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSUIMGetState_t *pOutput)
- int pack_dms_SLQSSwiGetCrashInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SLQSSwiGetCrashInfo_t *pReq)
- int unpack_dms_SLQSSwiGetCrashInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetCrashInfo_t *pOutput)
- int pack_dms_SLQSSwiGetHostDevInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetHostDevInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetHostDevInfo_t *pOutput)
- int pack_dms_SLQSSwiSetHostDevInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SLQSSwiSetHostDevInfo_t *pReq)
- int unpack_dms_SLQSSwiSetHostDevInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiSetHostDevInfo_t *pOutput)
- int pack_dms_SLQSSwiGetOSInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetOSInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetOSInfo_t *pOutput)
- int pack_dms_SLQSSwiSetOSInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SLQSSwiSetOSInfo_t *pReq)
- int unpack_dms_SLQSSwiSetOSInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiSetOSInfo_t *pOutput)
- int pack_dms_SLQSSwiGetSerialNoExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_dms_SLQSSwiGetSerialNoExt (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSwiGetSerialNoExt_t *pOutput)
- int pack_dms_SLQSDmsSwiGetPCInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_SLQSDmsSwiGetPCInfo (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSDmsSwiGetPCInfo_t *pOutput)
- int pack_dms_SLQSGetPowerSaveModeConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_SLQSGetPowerSaveModeConfig (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSGetPowerSaveModeConfig_t *pOutput)
- int pack_dms_SLQSSetPowerSaveModeConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SLQSSetPowerSaveModeConfig_t *reqArg)
- int unpack_dms_SLQSSetPowerSaveModeConfig (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSSetPowerSaveModeConfig_t *pOutput)
- int pack_dms_SetIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SetIndicationRegister_t *reqArg)
- int unpack_dms_SetIndicationRegister (uint8_t *pResp, uint16_t respLen, unpack_dms_SetIndicationRegister_t *pOutput)
- int unpack_dms_PSMCfgChange_ind (uint8_t *pResp, uint16_t respLen, unpack_dms_PSMCfgChange_ind_t *pOutput)

- int pack_dms_SwiSetEventReport (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SwiSetEventReport_t *reqArg)
- int unpack_dms_SwiSetEventReport (uint8_t *pResp, uint16_t respLen, unpack_dms_SwiSetEventReport_t *pOutput)
- int unpack_dms_SwiEventReportCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_dms_SwiEventReportCallBack_ind_t *pOutput)
- int pack_dms_SwiUimSelect (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_dms_SwiUimSelect_t *reqArg)
- int unpack_dms_SwiUimSelect (uint8_t *pResp, uint16_t respLen, unpack_dms_SwiUimSelect_t *pOutput)
- int pack_dms_SLQSDmsSwiGetUimSelection (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_dms_SLQSDmsSwiGetUimSelection (uint8_t *pResp, uint16_t respLen, unpack_dms_SLQSDmsSwiGetUimSelection_t *pOutput)

9.5.1 Macro Definition Documentation

9.5.1.1 #define ACT_CODE_MAX_SIZE 81

9.5.1.2 #define CK_MAX_SIZE 8

9.5.1.3 #define DMS_IMGDETAILS_LEN 16

9.5.1.4 #define DMS_MAX_CUST_ID_LEN 64

9.5.1.5 #define DMS_MAX_CUST_VALUE_LEN 8

9.5.1.6 #define DMS_MAX_FWUPDATE_LOG_STR_SZ 255

9.5.1.7 #define DMS_MAX_FWUPDATE_REF_STR_SZ 15

9.5.1.8 #define DMS_MAX_RADIO_IFCS_SIZE 64

9.5.1.9 #define DMS_PM_FACTORY 0x02 /* Factory Test Mode */

9.5.1.10 #define DMS_PM_LOW 0x01 /* Low Power */

9.5.1.11 #define DMS_PM_OFFLINE 0x03 /* Offline */

9.5.1.12 #define DMS_PM_ONLINE 0x00 /* Online */

9.5.1.13 #define DMS_PM_PERSISTENT_LOW 0x06 /* Persistent Low Power */

9.5.1.14 #define DMS_PM_RESET 0x04 /* Reset */

9.5.1.15 #define DMS_PM_SHUT_DOWN 0x05 /* Shut Down */

9.5.1.16 #define DMS_SET_REG_IND_DISABLE 0

9.5.1.17 #define DMS_SET_REG_IND_ENABLE 1

9.5.1.18 #define DMS_SET_REG_IND_NO_CHANGE 2

9.5.1.19 #define DMS_SET_REPORT_DISABLE 0

9.5.1.20 #define DMS_SET_REPORT_ENABLE 1

9.5.1.21 #define DMS_SLQSFWINFO_APPVERSION_SZ 85

9.5.1.22 #define DMS_SLQSFWINFO_BOOTVERSION_SZ 85

9.5.1.23 #define DMS_SLQSFWINFO_CARRIER_SZ 20

9.5.1.24 #define DMS_SLQSFWINFO_CUR_CARR_NAME 17

9.5.1.25 #define DMS_SLQSFWINFO_CUR_CARR_REV 13

9.5.1.26 #define DMS_SLQSFWINFO_MODELID_SZ 20

9.5.1.27 #define DMS_SLQSFWINFO_PACKAGEID_SZ 85

9.5.1.28 #define DMS_SLQSFWINFO_PRIVERSION_SZ 16

9.5.1.29 #define DMS_SLQSFWINFO_SKU_SZ 15

9.5.1.30 #define DMS_SWI_SET_IND_DISABLE 0

9.5.1.31 #define DMS_SWI_SET_IND_ENABLE 1

9.5.1.32 #define DMS_UINT8_MAX_STRING_SZ 255

9.5.1.33 #define DMS_VALID_FSN_LEN 14

9.5.1.34 #define ERI_DATA_MAX_SIZE 1024

9.5.1.35 #define MAX_BUILD_ID_LEN 255

9.5.1.36 #define MEID_MAX_SIZE 8

9.5.1.37 #define SLQS_MAX_DYING_GASP_CFG_SMS_CONTENT_LENGTH 160

9.5.1.38 #define SLQS_MAX_DYING_GASP_CFG_SMS_NUMBER_LENGTH 20

9.5.1.39 #define SPC_SIZE 6

9.5.1.40 #define UNIQUE_ID_LEN 16

9.5.2 Function Documentation

9.5.2.1 int pack_dms_ActivateAutomatic (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_ActivateAutomatic_t * *pReq*)

Requests the device to perform automatic service activation pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.2 int pack_dms_GetActivationState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get Activation State pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

This is only supported for 3GPP2 devices.

9.5.2.3 int pack_dms_GetBandCapability (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Band Capability pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.4 int pack_dms_GetCrashAction (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Crash Action pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.5 int pack_dms_GetCustFeature (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Custom Feature pack. This API is deprecated for EM74xx/MC74xx, please use pack_dms_GetCustFeatures-V2() instead for EM74xx/MC74xx.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.6 int pack_dms_GetCustFeaturesV2 (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_GetCustFeaturesV2_t * *reqArg*)

Get Custom Feature pack This function queries the modem for a list of supported features. This function is for firmware version 2.0 and newer. Currently supported Customization features:

- GPIOSARENABLE
- GPSSEL
- IMSWITCHHIDE
- IPV6ENABLE
- WAKEHOSTEN

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.7 int pack_dms_GetDeviceCap (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Device Capabilities pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.8 int pack_dms_GetDeviceCapabilities (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get device capability pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.9 int pack_dms_GetDeviceHardwareRev (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Hardware Revision of the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.10 int pack_dms_GetDeviceMfr (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Device Manufacture Name pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.11 int pack_dms_GetDeviceSerialNumbers (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Device Serial Number pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.12 int pack_dms_GetFirmwareInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get firmware info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.13 int pack_dms_GetFirmwareRevision (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Firmware Revision pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.14 int pack_dms_GetFirmwareRevisions (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Firmware Revisions pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.15 int pack_dms_GetFSN (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get FSN pack. This API get the Factory Sequence Number of the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.16 int pack_dms_GetHardwareRevision (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get hardware revision of the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.17 int pack_dms_GetIMSI (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get IMSI pack. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_-xx_xx and all EM74xx firmware versions. Please use pack_uim_ReadTransparent()(EF ID: 3F00 7F20 6F07 for 2G card and 3F00 7FFF 6F07 for 3G card) instead for new firmware versions and new modules.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.18 int pack_dms_GetManufacturer (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get device manufacturer information pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.19 int pack_dms_GetModelID (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get model id pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.20 int pack_dms_GetNetworkTime (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Network Time pack Returns the current time of the device based on the value supported by the network.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.21 int pack_dms_GetOfflineReason (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get operating mode offline reason pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.22 int pack_dms_GetPower (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get operating mode of the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.23 int pack_dms_GetPRLVersion (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get PRL Versions pack. Return version of the active Preferred Roaming List (PRL) in use by the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.24 int pack_dms_GetSerialNumbers (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get serial numbers pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.25 int pack_dms_GetUSBComp (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get USB Comp pack This API queries the modem's USB interface configuration and supported configuration parameters.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.26 int pack_dms_GetVoiceNumber (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Voice Number pack. Returns the voice number in use by the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.27 int pack_dms_ResetToFactoryDefaults (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_ResetToFactoryDefaults_t * *pReq*)

Resets to default factory settings of the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.28 int pack_dms_SetActivationStatusCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetActivationStatusCallback_t * *reqArg*)

Set activation status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.29 int pack_dms_SetCrashAction (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetCrashAction_t *reqArg*)

Set Crash Action pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.30 int pack_dms_SetCustFeature (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetCustFeature_t * *reqArg*)

Set Custom Feature pack. This API is deprecated for EM74xx/MC74xx, please use pack_dms_SetCustFeatures-V2() instead for EM74xx/MC74xx.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.31 int pack_dms_SetCustFeaturesV2 (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetCustFeaturesV2_t * *reqArg*)

Set Cust Features pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.32 int pack_dms_SetEventReport (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetEventReport_t * *reqArg*)

Set Event Report pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.33 int pack_dms_SetFirmwarePreference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Set Firmware Preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.34 int pack_dms_SetIndicationRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetIndicationRegister_t * *reqArg*)

Set Indication register pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.35 int pack_dms_SetPower (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetPower_t * *reqArg*)

Set Power pack Sets the operating mode of the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.36 int pack_dms_SetUSBComp (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SetUSBComp_t * *reqArg*)

Set USB Comp pack This API is used to change the modem's USB interface configuration thus allowing a device to have multiple USB compositions. Devices will, by default, be configured to support a minimal set of interfaces to reduce end user modem installation time. Developers and some customers, however, require access to a custom set of interfaces. A reset is required for any change in the USB composition to take effect.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.37 int pack_dms_SLQSDmsSwiGetPCInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get device power control status information pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.38 int pack_dms_SLQSDmsSwiGetResetInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get reset info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.39 int pack_dms_SLQSDmsSwiGetUimSelection (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get device UIM Selection information pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.40 int pack_dms_SLQSDmsSwiIndicationRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SLQSDmsSwiIndicationRegister_t * *reqArg*)

Set the registration state for different indication pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

support EM/MC74xx onwards

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.41 int pack_dms_SLQSGetBandCapability (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get band capability of the device pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.42 int pack_dms_SLQSGetERIFile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To set UIM Get ERI file pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.43 int pack_dms_SLQSGetPowerSaveModeConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Power Save Mode (PSM) configuration parameter pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter(NULL)

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.44 int pack_dms_SLQSSetPowerSaveModeConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SLQSSetPowerSaveModeConfig_t * *reqArg*)

Sets the Power Save Mode (PSM) configuration parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.45 int pack_dms_SLQSSwiClearDyingGaspStatistics (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Clear Dying GASP Statistics pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.46 int pack_dms_SLQSSwiGetCrashInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SLQSSwiGetCrashInfo_t * *pReq*)

To Get the Crash Information from the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.47 int pack_dms_SLQSSwiGetDyingGaspCfg (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get Dying GASP Config pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.48 int pack_dms_SLQSSwiGetDyingGaspStatistics (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get Dying GASP Statistics pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.49 int pack_dms_SLQSSwiGetFirmwareCurr (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get currently active image pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.50 int pack_dms_SLQSSwiGetFwUpdateStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get Firmware Update status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.51 int pack_dms_SLQSSwiGetHostDevInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get host dev information pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.52 int pack_dms_SLQSSwiGetOSInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To Get Host OS Info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.53 int pack_dms_SLQSSwiGetSerialNoExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get serial number extension pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.54 int pack_dms_SLQSSwiSetDyingGaspCfg (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SLQSSwiSetDyingGaspCfg_t * *reqArg*)

Set Dying GASP Config pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.55 int pack_dms_SLQSSwiSetHostDevInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SLQSSwiSetHostDevInfo_t * *pReq*)

To set Host Dev Info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.56 int pack_dms_SLQSSwiSetOSInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SLQSSwiSetOSInfo_t * *pReq*)

To set Host OS Info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.57 int pack_dms_SLQSUIMGetState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Returns the UIM state pack. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use API unpack_uim_GetCardStatus/ unpack_uim_GetCardStatus for new firmware versions and new modules

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.58 int pack_dms_SwiSetEventReport (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SwiSetEventReport_t * *reqArg*)

Sets the DMS swi event report parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.59 int pack_dms_SwiUimSelect (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_SwiUimSelect_t * *reqArg*)

Sets the DMS swi UIM Select parameters pack. A reset is required for any change in the UIM selection to take effect.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.60 int pack_dms_UIMChangePIN (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMChangePIN_t * *pReq*)

To set UIM change PIN pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.61 int pack_dms_UIMGetControlKeyStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMGetControlKeyStatus_t * *pReq*)

To set UIM Get Control Key Status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.62 int pack_dms_UIMGetICCID (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMGetICCID_t * *reqArg*)

Packs the UIMGetICCID response message to a user-provided response structure. This API is deprecated on MC73xx/EM73xx modules. Since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use pack_uim_ReadTransparent()(EF ID: 3F00 2FE2) instead for new firmware versions and new modules.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.63 int pack_dms_UIMGetPINStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To set UIM Get PIN Status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.64 int pack_dms_UIMSetControlKeyProtection (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMSetControlKeyProtection_t * *pReq*)

To set UIM Set Control Key Protection pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.65 int pack_dms_UIMSetPINProtection (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMSetPINProtection_t * *pReq*)

To set UIM PIN protection pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.66 int pack_dms_UIMUnblockControlKey (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMUnblockControlKey_t * *pReq*)

To set UIM Unblock Control Key pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.67 int pack_dms_UIMUnblockPIN (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMUnblockPIN_t * *pReq*)

To set UIM unblock PIN pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.68 int pack_dms_UIMVerifyPIN (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_UIMVerifyPIN_t * *pReq*)

To set UIM verify PIN pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.69 int pack_dms_ValidateSPC (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_dms_ResetToFactoryDefaults_t * *pReq*)

Requests the device to perform automatic service activation pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*pReq*	requeset parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.70 int unpack_dms_ActivateAutomatic (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_ResetToFactory-Defaults_t * *pOutput*)

Requests the device to perform automatic service activation unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.71 int unpack_dms_GetActivationState (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetActivationState_t * *pOutput*)

Get Activation State unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

This is only supported for 3GPP2 devices.

9.5.2.72 int unpack_dms_GetBandCapability (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetBandCapability_t * *pOutput*)

Get Band Capabilities unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.73 int unpack_dms_GetCrashAction (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetCrashAction_t * *pOutput*)

Get Crash Action unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.74 int unpack_dms_GetCustFeature (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetCustFeature_t * *pOutput*)

Get Custom Feature unpack. This API is deprecated for EM74xx/MC74xx, please use unpack_dms_GetCustFeaturesV2() instead for EM74xx/MC74xx.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.75 int unpack_dms_GetCustFeaturesV2 (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetCustFeaturesV2_t * *pOutput*)

Get Custom Feature unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.76 int unpack_dms_GetDeviceCap (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetDeviceCap_t * *pOutput*)

Get Device Capabilities unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.77 int unpack_dms_GetDeviceCapabilities (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetDeviceCapabilities_t * *pOutput*)

Get device capability unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.78 int unpack_dms_GetDeviceHardwareRev (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetDeviceHardwareRev_t * *pOutput*)

Get Hardware Revision of the device unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.79 int unpack_dms_GetDeviceMfr (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetDeviceMfr_t * *pOutput*)

Get Device Manufacture Name unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.80 int unpack_dms_GetDeviceSerialNumbers (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetDeviceSerialNumbers_t * *pOutput*)

Get Device Serial Number unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.81 int unpack_dms_GetFirmwareInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetFirmwareInfo_t * *pOutput*)

Get firmware info unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.82 int unpack_dms_GetFirmwareRevision (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetFirmwareRevision_t * *pOutput*)

Get Firmware Revision unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.83 int unpack_dms_GetFirmwareRevisions (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetFirmwareRevisions_t * *pOutput*)

Get Firmware Revisions unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.84 int unpack_dms_GetFSN (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetFSN_t * *pOutput*)

Get FSN unpack This API get the Factory Sequence Number of the device.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.85 int unpack_dms_GetHardwareRevision (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetHardwareRevision_t * *pOutput*)

Get hardware revision of the device unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.86 int unpack_dms_GetIMSI (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetIMSI_t * *pOutput*)

Get IMSI unpack. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx-_xx_xx and all EM74xx firmware versions. Please use unpack_uim_ReadTransparent()(EF ID: 3F00 7F20 6F07 for 2G card and 3F00 7FFF 6F07 for 3G card) instead for new firmware versions and new modules.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.87 int unpack_dms_GetManufacturer (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetManufacturer_t * *pOutput*)

To get device manufacturer information unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.88 int unpack_dms_GetModelID (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetModelID_t * *pOutput*)

Get model id unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.89 int unpack_dms_GetNetworkTime (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetNetworkTime_t * *pOutput*)

Get Network Time unpack. Returns the current time of the device based on the value supported by the network.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.90 int unpack_dms_GetOfflineReason (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetOfflineReason_t * *pOutput*)

To get operating mode offline reason unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.91 int unpack_dms_GetPower (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetPower_t * *pOutput*)

Get operating mode of the device unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.92 int unpack_dms_GetPRLVersion (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetPRLVersion_t * *pOutput*)

Get PRL Versions unpack Return version of the active Preferred Roaming List (PRL) in use by the device.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.93 int unpack_dms_GetSerialNumbers (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetSerialNumbers_t * *pOutput*)

Get serial numbers unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.94 int unpack_dms_GetUSBComp (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetUSBComp_t * *pOutput*)

Get USB Comp unpack This API queries the modem's USB interface configuration and supported configuration parameters.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.95 int unpack_dms_GetVoiceNumber (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_GetVoiceNumber_t * *pOutput*)

Get Voice Number unpack Returns the voice number in use by the device.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.96 int unpack_dms_PSMCfgChange_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_PSMCfgChange_ind_t * *pOutput*)

PSM Configuration change Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.97 int unpack_dms_ResetToFactoryDefaults (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_ResetToFactory-Defaults_t * *pOutput*)

Resets to default factory settings of the device unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.98 int unpack_dms_SetActivationStatusCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetActivationStatusCallback_t * *pOutput*)

Set Activation status unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.99 int unpack_dms_SetCrashAction (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetCrashAction_t * *pOutput*)

Set Crash Action unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response. Not used

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.100 int unpack_dms_SetCustFeature (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetCustFeature_t * *pOutput*)

Set Custom Feature unpack. This API is deprecated for EM74xx/MC74xx, please use unpack_dms_SetCustFeaturesV2() instead for EM74xx/MC74xx.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.101 int unpack_dms_SetCustFeaturesV2 (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetCustFeaturesV2_t * *pOutput*)

Set Cust features unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.102 int unpack_dms_SetEventReport (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetEventReport_t * *pOutput*)

Set Event Report unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.103 int unpack_dms_SetEventReport_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetEventReport_ind_t * *pOutput*)

Event Report Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.104 int unpack_dms_SetFirmwarePreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetFirmwarePreference_t * *pOutput*)

Set Firmware Preference unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.105 int unpack_dms_SetIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetIndicationRegister_t * *pOutput*)

Set Indication register unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.106 int unpack_dms_SetPower (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetPower_t * *pOutput*)

Set Power unpack. Sets the operating mode of the device.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.107 int unpack_dms_SetUSBComp (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SetUSBComp_t * *pOutput*)

Set USB Comp unpack This API is used to change the modem's USB interface configuration thus allowing a device to have multiple USB compositions. Devices will, by default, be configured to support a minimal set of interfaces to reduce end user modem installation time. Developers and some customers, however, require access to a custom set of interfaces. A reset is required for any change in the USB composition to take effect.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.108 int unpack_dms_SLQSDmsSwiGetPCInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSDmsSwiGetPCInfo_t * *pOutput*)

Get device power control status information unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.109 int unpack_dms_SLQSDmsSwiGetResetInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSDmsSwiGetResetInfo_t * *pOutput*)

To get reset info unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.110 int unpack_dms_SLQSDmsSwiGetResetInfo_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t * *pOutput*)

DMS reset info Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

support EM/MC74xx onwards

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.111 int unpack_dms_SLQSDmsSwiGetUimSelection (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSDmsSwiGetUimSelection_t * *pOutput*)

Get device UIM selection information unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.112 int unpack_dms_SLQSDmsSwiIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSDmsSwiIndicationRegister_t * *pOutput*)

Set the registration state for different indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

support EM/MC74xx onwards

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.113 int unpack_dms_SLQSGetBandCapability (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSGetBandCapability_t * *pOutput*)

Get band capability of the device unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.114 int unpack_dms_SLQSGetERIFile (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSGetERIFile_t * *pOutput*)

To get UIM Get ERI file unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.115 int unpack_dms_SLQSGetPowerSaveModeConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSGetPowerSaveModeConfig_t * *pOutput*)

Get Power Save Mode (PSM) configuration parameter unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.116 int unpack_dms_SLQSSetPowerSaveModeConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSetPowerSaveModeConfig_t * *pOutput*)

Sets the Power Save Mode (PSM) configuration parameters unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.117 int unpack_dms_SLQSSwiClearDyingGaspStatistics (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiClearDyingGaspStatistics_t * *pOutput*)

Clear Dying GASP Statistics unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.118 int unpack_dms_SLQSSwiGetCrashInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetCrashInfo_t * *pOutput*)

To Get the Crash Information from the device unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.119 int unpack_dms_SLQSSwiGetDyingGaspCfg (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetDyingGaspCfg_t * *pOutput*)

Get Dying GASP Config unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.120 int unpack_dms_SLQSSwiGetDyingGaspStatistics (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetDyingGaspStatistics_t * *pOutput*)

Get Dying GASP Statistics unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.121 int unpack_dms_SLQSSwiGetFirmwareCurr (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetFirmwareCurr_t * *pOutput*)

Get currently active image unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.122 int unpack_dms_SLQSSwiGetFwUpdateStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetFwUpdateStatus_t * *pOutput*)

To get Firmware Update status unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.123 int unpack_dms_SLQSSwiGetHostDevInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetHostDevInfo_t * *pOutput*)

To get host dev information unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.124 int unpack_dms_SLQSSwiGetOSInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetOSInfo_t * *pOutput*)

To get Host OS Info unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.125 int unpack_dms_SLQSSwiGetSerialNoExt (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiGetSerialNoExt_t * *pOutput*)

To get serial number extension unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.126 int unpack_dms_SLQSSwiSetDyingGaspCfg (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiSetDyingGaspCfg_t * *pOutput*)

Set Dying GASP Config unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.127 int unpack_dms_SLQSSwiSetHostDevInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiSetHostDevInfo_t * *pOutput*)

To set Host Dev Info unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.128 int unpack_dms_SLQSSwiSetOSInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSSwiSetOSInfo_t * *pOutput*)

To set Host OS Info unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.129 int unpack_dms_SLQSUIMGetState (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SLQSUIMGetState_t * *pOutput*)

Returns the UIM state unpack. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use API unpack_uim_GetCardStatus / unpack_uim_GetCardStatus for new firmware versions and new modules

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.130 int unpack_dms_SwiEventReportCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SwiEventReportCallBack_ind_t * *pOutput*)

unpack for DMS swi event report indication

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.131 int unpack_dms_SwiSetEventReport (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SwiSetEventReport_t * *pOutput*)

Sets the swi event report parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.132 int unpack_dms_SwiUimSelect (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_SwiUimSelect_t * *pOutput*)

Sets the DMS swi UIM Select parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.133 int unpack_dms_UIMChangePIN (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMSetPINProtection_t * *pOutput*)

To get UIM change PIN unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.134 int unpack_dms_UIMGetControlKeyStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMGetControlKeyStatus_t * *pOutput*)

To get UIM Get ControlKeyStatus unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.135 int unpack_dms_UIMGetICCID (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMGetICCID_t * *pOutput*)

Unpacks the UIMGetICCID response message to a user-provided response structure.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.136 int unpack_dms_UIMGetPINStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMGetPINStatus_t * *pOutput*)

To get UIM Get PIN Status unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.137 int unpack_dms_UIMSetControlKeyProtection (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMSetControlKeyProtection_t * *pOutput*)

To get UIM Set Control Key Protection unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.138 int unpack_dms_UIMSetPINProtection (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMSetPINProtection_t * *pOutput*)

To get UIM Set PIN protection unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.139 int unpack_dms_UIMUnblockControlKey (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMUnblockControlKey_t * *pOutput*)

To get UIM Unblock Control Key unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.140 int unpack_dms_UIMUnblockPIN (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMSetPINProtection_t * *pOutput*)

To get UIM unblock PIN unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.141 int unpack_dms_UIMVerifyPIN (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_UIMSetPINProtection_t * *pOutput*)

To get UIM verify PIN unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.5.2.142 int unpack_dms_ValidateSPC (uint8_t * *pResp*, uint16_t *respLen*, unpack_dms_ResetToFactoryDefaults_t * *pOutput*)

Requests the device to perform automatic service activation unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.6 fms.h File Reference

Data Structures

- struct CarrierImage_t
- struct pack_fms_GetImagesPreference_t
- struct FMSImageElement
- struct FMSPrefImageList
- struct unpack_fms_GetImagesPreference_t
- struct pack_fms_GetStoredImages_t
- struct FMSImageIdElement
- struct FMSImageIDEntries
- struct FMSImageList
- struct unpack_fms_GetStoredImages_t
- struct pack_fms_SetImagesPreference_t
- struct unpack_fms_SetImagesPreference_t

Macros

- #define FMS_GOBI_MBN_IMG_ID_SIZE 16
- #define LITE_TOTAL_IMAGE_ID_STRING_SIZE 100
- #define FMS_GOBI_MBN_IMG_ID_STR_LEN LITE_TOTAL_IMAGE_ID_STRING_SIZE
- #define FMS_GOBI_MBN_BUILD_ID_STR_LEN LITE_TOTAL_IMAGE_ID_STRING_SIZE
- #define FMS_GOBI_LISTENTRIES_MAX 2
- #define FMS_MAX_IMAGE_PREFERENCE_IMAGE_SIZE 255
- #define FMS_MAX_IMAGE_ID_ELEMENT 50
- #define FMS_IMAGE_ID_MAX_ENTRIES 2
- #define FMS_FW_PRI_BUILD_MATCH_LEN 11
- #define FMS_IMAGE_ID_IMG_ID_LEN 16
- #define FMS_IMAGE_ID_BUILD_ID_LEN 32
- #define FMS_IMAGE_ID_PRI_IMGTYPE 0x01

Functions

- int pack_fms_GetImagesPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_fms_GetImagesPreference_t *reqArg)
- int unpack_fms_GetImagesPreference (uint8_t *pResp, uint16_t respLen, unpack_fms_GetImagesPreference_t *pOutput)
- int pack_fms_GetStoredImages (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_fms_GetStoredImages_t *reqArg)
- int unpack_fms_GetStoredImages (uint8_t *pResp, uint16_t respLen, unpack_fms_GetStoredImages_t *pOutput)
- int pack_fms_SetImagesPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_fms_SetImagesPreference_t *reqArg)
- int unpack_fms_SetImagesPreference (uint8_t *pResp, uint16_t respLen, unpack_fms_SetImagesPreference_t *pOutput)
- uint32_t GetValidFwPriCombinations (FMSImageList *pStoredImageList, uint32_t *pValidCombinationSize, CarrierImage_t *pValidCombinations)

9.6.1 Macro Definition Documentation

9.6.1.1 #define FMS_FW_PRI_BUILD_MATCH_LEN 11

9.6.1.2 #define FMS_GOBI_LISTENTRIES_MAX 2

9.6.1.3 #define FMS_GOBI_MBN_BUILD_ID_STR_LEN LITE_TOTAL_IMAGE_ID_STRING_SIZE

9.6.1.4 #define FMS_GOBI_MBN_IMG_ID_SIZE 16

9.6.1.5 #define FMS_GOBI_MBN_IMG_ID_STR_LEN LITE_TOTAL_IMAGE_ID_STRING_SIZE

9.6.1.6 #define FMS_IMAGE_ID_BUILD_ID_LEN 32

9.6.1.7 #define FMS_IMAGE_ID_IMG_ID_LEN 16

9.6.1.8 #define FMS_IMAGE_ID_MAX_ENTRIES 2

9.6.1.9 #define FMS_IMAGE_ID_PRI_IMGTYPE 0x01

9.6.1.10 #define FMS_MAX_IMAGE_ID_ELEMENT 50

9.6.1.11 #define FMS_MAX_IMAGE_PREFERENCE_IMAGE_SIZE 255

9.6.1.12 #define LITE_TOTAL_IMAGE_ID_STRING_SIZE 100

9.6.2 Function Documentation

9.6.2.1 uint32_t GetValidFwPriCombinations (FMSImageList * *pStoredImageList*, uint32_t * *pValidCombinationSize*, CarrierImage_t * *pValidCombinations*)

This API distills valid Firmware/PRI combinations from GetStoredImages result

Parameters

in	*pStoredImage-List*	• image list returned from GetStoredImages • See FMSImageList
in,out	*pValid-CombinationSize*	• number of combination passed in and returned
out	*pValid-Combinations*	• valid combinations returned • See CarrierImage_t

Returns

- eQCWWAN_ERR_INVALID_ARG - Invalid parameters
- eQCWWAN_ERR_BUFFER_SZ - No enough element to store combinatons returned

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.6.2.2 int pack_fms_GetImagesPreference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_fms_GetImagesPreference_t * *reqArg*)

Get Images Preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

9.6.2.3 int pack_fms_GetStoredImages (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_fms_GetStoredImages_t * *reqArg*)

Get Images Preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

9.6.2.4 int pack_fms_SetImagesPreference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_fms_SetImagesPreference_t * *reqArg*)

Set Images Preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

9.6.2.5 int unpack_fms_GetImagesPreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_fms_GetImagesPreference_t * *pOutput*)

Get Images Preference unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

9.6.2.6 int unpack_fms_GetStoredImages (uint8_t * *pResp*, uint16_t *respLen*, unpack_fms_GetStoredImages_t * *pOutput*)

Get Images Preference unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

9.6.2.7 int unpack_fms_SetImagesPreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_fms_SetImagesPreference_t * *pOutput*)

Set Images Preference unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

9.7 ims.h File Reference

Data Structures

- struct pack_ims_SLQSSetSIPConfig_t
- struct unpack_ims_SLQSSetSIPConfig_t
- struct pack_ims_SLQSSetRegMgrConfig_t
- struct unpack_ims_SLQSSetRegMgrConfig_t
- struct pack_ims_SLQSSetIMSSMSConfig_t
- struct unpack_ims_SLQSSetIMSSMSConfig_t
- struct pack_ims_SLQSSetIMSUserConfig_t
- struct unpack_ims_SLQSSetIMSUserConfig_t
- struct pack_ims_SLQSSetIMSVoIPConfig_t
- struct unpack_ims_SLQSSetIMSVoIPConfig_t
- struct unpack_ims_SLQSGetSIPConfig_t
- struct unpack_ims_SLQSGetRegMgrConfig_t
- struct unpack_ims_SLQSGetIMSSMSConfig_t
- struct unpack_ims_SLQSGetIMSUserConfig_t
- struct unpack_ims_SLQSGetIMSVoIPConfig_t
- struct pack_ims_SLQSImsConfigIndicationRegister_t
- struct ims_PCSCFPortInfo
- struct ims_CSCFPortNameInfo
- struct ims_IMSTestModeInfo
- struct unpack_ims_SLQSRegMgrCfgCallBack_ind_t
- struct ims_SIPPortInfo
- struct ims_SIPRegnTmrInfo
- struct ims_SubscrTmrInfo
- struct ims_TmrT1Info
- struct ims_TmrT2Info
- struct ims_TmrTfInfo
- struct ims_SigCompEnInfo
- struct unpack_ims_SLQSSIPCfgCallBack_ind_t
- struct ims_SMSFmtInfo
- struct ims_SMSoIPNwInfo
- struct ims_PhCtxtURIInfo
- struct unpack_ims_SLQSSMSCfgCallBack_ind_t
- struct ims_IMSDomainInfo

- struct unpack_ims_SLQSUserCfgCallBack_ind_t
- struct ims_SessDurInfo
- struct ims_MinSessExpInfo
- struct ims_EnabAMRWBInfo
- struct ims_EnabSCRAMRInfo
- struct ims_EnabSCRAMRWBInfo
- struct ims_AMRModeInfo
- struct ims_AMRWBModeInfo
- struct ims_AMROctAlgnInfo
- struct ims_AMRWBOctAlgnInfo
- struct ims_RngTmrInfo
- struct ims_RngBkTmrInfo
- struct ims_RTPRTCPInactTmrDurInfo
- struct unpack_ims_SLQSVoIPCfgCallBack_ind_t

Macros

- #define MAX_NAME_LEN 255

Typedefs

- typedef unpack_result_t unpack_ims_SLQSImsConfigIndicationRegister_t

Functions

- int pack_ims_SLQSSetSIPConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSSetSIPConfig_t *pReqParam)
- int unpack_ims_SLQSSetSIPConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSetSIPConfig_t *pOutput)
- int pack_ims_SLQSSetRegMgrConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSSetRegMgrConfig_t *pReqParam)
- int unpack_ims_SLQSSetRegMgrConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSetRegMgrConfig_t *pOutput)
- int pack_ims_SLQSSetIMSSMSConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSSetIMSSMSConfig_t *pReqParam)
- int unpack_ims_SLQSSetIMSSMSConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSetIMSSMSConfig_t *pOutput)
- int pack_ims_SLQSSetIMSUserConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSSetIMSUserConfig_t *pReqParam)
- int unpack_ims_SLQSSetIMSUserConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSetIMSUserConfig_t *pOutput)
- int pack_ims_SLQSSetIMSVoIPConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSSetIMSVoIPConfig_t *pReqParam)
- int unpack_ims_SLQSSetIMSVoIPConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSetIMSVoIPConfig_t *pOutput)
- int pack_ims_SLQSGetSIPConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_ims_SLQSGetSIPConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSGetSIPConfig_t *pOutput)
- int pack_ims_SLQSGetRegMgrConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_ims_SLQSGetRegMgrConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSGetRegMgrConfig_t *pOutput)
- int pack_ims_SLQSGetIMSSMSConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_ims_SLQSGetIMSSMSConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSGetIMSSMSConfig_t *pOutput)

- int pack_ims_SLQSGetIMSUserConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_ims_SLQSGetIMSUserConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSGetIMSUserConfig_t *pOutput)
- int pack_ims_SLQSGetIMSVoIPConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_ims_SLQSGetIMSVoIPConfig (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSGetIMSVoIPConfig_t *pOutput)
- int pack_ims_SLQSImsConfigIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_ims_SLQSImsConfigIndicationRegister_t *pReqParam)
- int unpack_ims_SLQSImsConfigIndicationRegister (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSImsConfigIndicationRegister_t *pOutput)
- int unpack_ims_SLQSRegMgrCfgCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSRegMgrCfgCallBack_ind_t *pOutput)
- int unpack_ims_SLQSSIPCfgCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSIPCfgCallBack_ind_t *pOutput)
- int unpack_ims_SLQSSMSCfgCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSSMSCfgCallBack_ind_t *pOutput)
- int unpack_ims_SLQSUserCfgCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSUserCfgCallBack_ind_t *pOutput)
- int unpack_ims_SLQSVoIPCfgCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_ims_SLQSVoIPCfgCallBack_ind_t *pOutput)

9.7.1 Macro Definition Documentation

9.7.1.1 #define MAX_NAME_LEN 255

9.7.2 Typedef Documentation

9.7.2.1 typedef unpack_result_t unpack_ims_SLQSImsConfigIndicationRegister_t

9.7.3 Function Documentation

9.7.3.1 int pack_ims_SLQSGetIMSSMSConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Retrieves the SMS configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.3.2 int pack_ims_SLQSGetIMSUserConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Retrieves the IMS User configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.3.3 int pack_ims_SLQSGetIMSVoIPConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Retrieves the IMS VoIP configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.3.4 int pack_ims_SLQSGetRegMgrConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Retrieves the Session Initiation Protocol(SIP) configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.3.5 int pack_ims_SLQSGetSIPConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Retrieves the Session Initiation Protocol(SIP) configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.3.6 int pack_ims_SLQSImsConfigIndicationRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_ims_SLQSImsConfigIndicationRegister_t * *pReqParam*)

Sets the registration state for different QMI_IMS indications for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

```
- This function is used by a device to register/deregister for different
  QMI IMS indications.
- The device's registration state variables that control registration
  for indications will be modified to reflect the settings indicated in the
  request message.
- At least one optional parameter must be present in the request.
```

9.7.3.7 int pack_ims_SLQSSetIMSSMSConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_ims_SLQSSetIMSSMSConfig_t * *pReqParam*)

Sets the IMS SMS configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.3.8 int pack_ims_SLQSSetIMSUserConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_ims_SLQSSetIMSUserConfig_t * *pReqParam*)

Sets the IMS user configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.3.9 int pack_ims_SLQSSetIMSVoIPConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_ims_SLQSSetIMSVoIPConfig_t * *pReqParam*)

Sets the IMS Voice over Internet Protocol (VoIP) configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.3.10 int pack_ims_SLQSSetRegMgrConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_ims_SLQSSetRegMgrConfig_t * *pReqParam*)

Sets the IMS registration manager configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.3.11 int pack_ims_SLQSSetSIPConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_ims_SLQSSetSIPConfig_t * *pReqParam*)

Sets the IMS Session Initiation Protocol(SIP) configuration parameters for the requesting control point pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC73xx, MC74xx and EM74xx

9.7.3.12 int unpack_ims_SLQSGetIMSSMSConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSGetIMSSMSConfig_t * *pOutput*)

Retrieves the SMS configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.13 int unpack_ims_SLQSGetIMSUserConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSGetIMSUserConfig_t * *pOutput*)

Retrieves the IMS User configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.14 int unpack_ims_SLQSGetIMSVoIPConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSGetIMSVoIP-Config_t * *pOutput*)

Retrieves the IMS VoIP configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.15 int unpack_ims_SLQSGetRegMgrConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSGetRegMgr-Config_t * *pOutput*)

Retrieves the Session Initiation Protocol(SIP) configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.16 int unpack_ims_SLQSGetSIPConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSGetSIPConfig_t * *pOutput*)

Retrieves the Session Initiation Protocol(SIP) configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.17 int unpack_ims_SLQSImsConfigIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSImsConfigIndicationRegister_t * *pOutput*)

Sets the registration state for different QMI_IMS indications for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.18 int unpack_ims_SLQSRegMgrCfgCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSRegMgrCfgCallBack_ind_t * *pOutput*)

Unpack indication about IMS registration manager configuration

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.19 int unpack_ims_SLQSSetIMSSMSConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSetIMSSMSConfig_t * *pOutput*)

Sets the IMS SMS configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.20 int unpack_ims_SLQSSetIMSUserConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSetIMSUserConfig_t * *pOutput*)

Sets the IMS user configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.21 int unpack_ims_SLQSSetIMSVoIPConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSetIMSVoIPConfig_t * *pOutput*)

Sets the IMS Voice over Internet Protocol (VoIP) configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.22 int unpack_ims_SLQSSetRegMgrConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSetRegMgrConfig_t * *pOutput*)

Sets the IMS registration manager configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.23 int unpack_ims_SLQSSetSIPConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSetSIPConfig_t * *pOutput*)

Sets the IMS Session Initiation Protocol(SIP) configuration parameters for the requesting control point unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.24 int unpack_ims_SLQSSIPCfgCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSIPCfgCallBack_ind_t * *pOutput*)

Unpack indication about SIP configuration info

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.25 int unpack_ims_SLQSSMSCfgCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSSMSCfgCallBack_ind_t * *pOutput*)

Unpack indication about SMS configuration info for IMS

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.26 int unpack_ims_SLQSUserCfgCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSUserCfgCallBack_ind_t * *pOutput*)

Unpack indication about User configuration info for IMS

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.7.3.27 int unpack_ims_SLQSVoIPCfgCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_ims_SLQSVoIPCfgCallBack_ind_t * *pOutput*)

Unpack indication about VOIP configuration info

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8 imsa.h File Reference

Data Structures

- struct pack_imsa_SLQSRegisterIMSAIndication_t
- struct unpack_imsa_SLQSGetIMSARegStatus_t
- struct unpack_imsa_SLQSGetIMSAServiceStatus_t

- struct imsa_SmsSvcStatusInfo
- struct imsa_SmsRatInfo
- struct imsa_VoipSvcStatusInfo
- struct imsa_VoipRatInfo
- struct imsa_VtSvcStatusInfo
- struct imsa_VtRatInfo
- struct imsa_UtSvcStatusInfo
- struct imsa_UtRatInfo
- struct unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t
- struct imsa_IMSRegStatusInfo
- struct imsa_IMSRegStatusErrorCodeInfo
- struct imsa_NewIMSRegStatusInfo
- struct unpack_imsa_SLQSImsaRegStatusCallBack_ind_t
- struct imsa_RatHandoverStatusInfo
- struct unpack_imsa_SLQSImsaRatStatusCallBack_ind_t
- struct imsa_IMSFailErrCodeTlv
- struct unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t

Macros

- #define MAX_ERROR_CODE_LEN 256

Typedefs

- typedef unpack_result_t unpack_imsa_SLQSRegisterIMSAIndication_t

Functions

- int pack_imsa_SLQSRegisterIMSAIndication (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_imsa_SLQSRegisterIMSAIndication_t *reqParam)
- int unpack_imsa_SLQSRegisterIMSAIndication (uint8_t *pResp, uint16_t respLen, unpack_imsa_SLQSRegisterIMSAIndication_t *pOutput)
- int pack_imsa_SLQSGetIMSARegStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_imsa_SLQSGetIMSARegStatus (uint8_t *pResp, uint16_t respLen, unpack_imsa_SLQSGetIMSARegStatus_t *pOutput)
- int pack_imsa_SLQSGetIMSAServiceStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_imsa_SLQSGetIMSAServiceStatus (uint8_t *pResp, uint16_t respLen, unpack_imsa_SLQSGetIMSAServiceStatus_t *pOutput)
- int unpack_imsa_SLQSImsaSvcStatusCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t *pOutput)
- int unpack_imsa_SLQSImsaRegStatusCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_imsa_SLQSImsaRegStatusCallBack_ind_t *pOutput)
- int unpack_imsa_SLQSImsaRatStatusCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_imsa_SLQSImsaRatStatusCallBack_ind_t *pOutput)
- int unpack_imsa_SLQSImsaPdpStatusCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t *pOutput)

9.8.1 Macro Definition Documentation

9.8.1.1 #define MAX_ERROR_CODE_LEN 256

9.8.2 Typedef Documentation

9.8.2.1 typedef unpack_result_t unpack_imsa_SLQSRegisterIMSAIndication_t

9.8.3 Function Documentation

9.8.3.1 int pack_imsa_SLQSGetIMSARegStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack Get IMSA Registration Status command.

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.3.2 int pack_imsa_SLQSGetIMSAServiceStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack Get IMSA Service Status command

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.3.3 int pack_imsa_SLQSRegisterIMSAIndication (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_imsa_SLQSRegisterIMSAIndication_t * *reqParam*)

Function to pack Register IMSA Indication command

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[IN] • See pack_imsa_SLQSRegisterIMSAIndication_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.3.4 int unpack_imsa_SLQSGetIMSARegStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_imsa_SLQSGetIMSA-RegStatus_t * *pOutput*)

Function to unpack Get IMSA Registration Status response from modem. *

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem
pOutput	[OUT] • See unpack_imsa_SLQSGetIMSARegStatus_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.3.5 int unpack_imsa_SLQSGetIMSAServiceStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_imsa_SLQSGetIMSAServiceStatus_t * *pOutput*)

Function to unpack Get IMSA Service Status response from modem

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem
pOutput	[OUT] • See unpack_imsa_SLQSGetIMSAServiceStatus_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.3.6 int unpack_imsa_SLQSImsaPdpStatusCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t * *pOutput*)

Unpack indication about IMSA PDP status info

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.3.7 int unpack_imsa_SLQSImsaRatStatusCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_imsa_SLQSImsaRatStatusCallBack_ind_t * *pOutput*)

Unpack indication about IMSA RAT status info

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.3.8 int unpack_imsa_SLQSImsaRegStatusCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_imsa_SLQSImsaRegStatusCallBack_ind_t * *pOutput*)

Unpack indication about IMSA registration status info

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.3.9 int unpack_imsa_SLQSImsaSvcStatusCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t * *pOutput*)

Unpack indication about IMSA service status info

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.8.3.10 int unpack_imsa_SLQSRegisterIMSAIndication (uint8_t * *pResp*, uint16_t *respLen*, unpack_imsa_SLQSRegisterIMSAIndication_t * *pOutput*)

Function to unpack Register IMSA Indication response from modem

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem
pOutput	[OUT] • See unpack_imsa_SLQSRegisterIMSAIndication_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.9 lite-fw.h File Reference

Data Structures

- struct _litefw_FirmwareInfo_

Macros

- #define IMG_MASK_MDM (1<<0)
- #define IMG_MASK_PRI (1<<1)
- #define IMG_MASK_CLEAR (0x000)
- #define IMG_MASK_GENERIC (0xFFFF)
- #define LITEFW_CARRIER_PACKAGE_SKU "9999999"
- #define LITEFW_SKU_STRING_LENGTH 7
- #define FIRMWARE_INFO_STRING_SIZE 20
- #define NULL_TERMINATOR_CHAR_SIZE 1
- #define libSDP_GetVersion litefw_GetVersion
- #define libSDP_CalculateImageMask litefw_CalculateImageMask
- #define libSDP_getFileType litefw_getFileType
- #define libSDP_ExtractFirmwareParametersByPath litefw_ExtractFirmwareParametersByPath
- #define libSDP_GetModelFamily litefw_GetModelFamily
- #define libSDP_CheckValidFirmwareInfo litefw_CheckValidFirmwareInfo
- #define libSDP_BuildImagesPreferenceRequest litefw_BuildImagesPreferenceRequest
- #define libSDP_DownloadFW litefw_DownloadFW

- #define libsdp_set_log_func litefw_set_log_func
- #define libsdp_SetReadBlockSize litefw_SetReadBlockSize
- #define LIBSDP_CARRIER_PACKAGE_SKU LITEFW_CARRIER_PACKAGE_SKU
- #define LIBSDP_SKU_STRING_LENGTH LITEFW_SKU_STRING_LENGTH

Typedefs

- typedef struct _litefw_FirmwareInfo_ litefw_FirmwareInfo
- typedef void(∗ litefwlogger)(uint8_t lvl, const char ∗buff)
- typedef litefw_FirmwareInfo libSDP_FirmwareInfo
- typedef litefwlogger libsdplogger

Enumerations

- enum litefw_fwdwl_error_codes {
  eSDP_FWDWL_SUCCESS = 0,
  eSDP_FWDWL_ERR_GENERAL = 100,
  eSDP_FWDWL_ERR_SDK,
  eSDP_FWDWL_ERR_SET_CBK,
  eSDP_FWDWL_ERR_PATH_TOO_LONG,
  eSDP_FWDWL_ERR_PATH_NOT_SPECIFIED,
  eSDP_FWDWL_ERR_FW_UPGRADE,
  eSDP_FWDWL_ERR_INVALID_DEV,
  eSDP_FWDWL_ERR_INVALID_PATH,
  eSDP_FWDWL_ERR_TIMEOUT,
  eSDP_FWDWL_ERR_FAIL,
  eSDP_FWDWL_ERR_PRI_FAIL,
  eSDP_FWDWL_ERR_FW_VERSION_FAIL,
  eSDP_FWDWL_ERR_SDP_TIMEOUT,
  eFIREHOSE_ERR_SECBOOT_INVALID_CERT_CHAIN,
  eSDP_FWDWL_ERR_END }
- enum litefw_Fw_Type {
  eFW_TYPE_MBN_GOBI,
  eFW_TYPE_MBN,
  eFW_TYPE_CWE,
  eFW_TYPE_NVU,
  eFW_TYPE_SPK,
  eFW_TYPE_INVALID,
  eFW_TYPE_CWE_NVU }
- enum litefw_Models {
  eModel_Unknown =-1,
  eModel_9X15 =0,
  eModel_WP9X15 =1,
  eModel_9X30 =2,
  eModel_9x07 =3,
  eModel_9x06 =4 }
- enum litefw_QDL_MODEs {
  eQDL_MODE_Unknown =-1,
  eQDL_MODE_INIT =0,
  eQDL_MODE_TTYUSB =1,
  eQDL_MODE_UART0 =2 }
- enum litefw_QDL_FLOW_CONTROLs {
  eQDL_HW_FLOW_Unknown =-1,
  eQDL_HW_FLOW_INIT =0,
  eQDL_HW_FLOW_ENABLE =1,
  eQDL_HW_FLOW_DISABLE =2 }

Functions

- void litefw_logsenable (int log_en)
- int litefw_ExtractFirmwareParametersByPath (char *pImagePath, litefw_FirmwareInfo *info)
- int litefw_BuildImagesPreferenceRequest (litefw_FirmwareInfo info, pack_fms_SetImagesPreference_t *pack)
- int litefw_CalculateImageMask (unpack_fms_SetImagesPreference_t SetPrefRspFromModem)
- int litefw_getFileType (char *szPath)
- unsigned int litefw_DownloadFW (char *pImagePath, char *szTTYPath, int iFWImageType, int image_mask, int iModelFamily)
- int litefw_GetModelFamily (char *pModelString)
- int litefw_CheckValidFirmwareInfo (litefw_FirmwareInfo info)
- char * litefw_GetVersion ()
- int litefw_set_log_func (litefwlogger *func)
- void litefw_SetReadBlockSize (unsigned long lBlockSize)
- int litefw_switch_9x07_to_downloadmode (char *szTTYPath)
- int litefw_switch_to_BootHoldMode (char *szTTYPath)
- int litefw_SetQTLDownloadMode (int iMode)
- int litefw_GetQTLDownloadMode ()
- int litefw_SetQTLHWFlowControl (int iMode)
- int litefw_GetQTLHWFlowControl ()

9.9.1 Detailed Description

Filename: lite-fw.h

Purpose: Global definitions used inside the SDK

Copyright: © 2016 Sierra Wireless Inc., all rights reserved

9.9.2 Macro Definition Documentation

9.9.2.1 #define FIRMWARE_INFO_STRING_SIZE 20

9.9.2.2 #define IMG_MASK_CLEAR (0x000)

9.9.2.3 #define IMG_MASK_GENERIC (0xFFFF)

9.9.2.4 #define IMG_MASK_MDM (1<<0)

9.9.2.5 #define IMG_MASK_PRI (1<<1)

9.9.2.6 #define libSDP_BuildImagesPreferenceRequest litefw_BuildImagesPreferenceRequest

9.9.2.7 #define libSDP_CalculateImageMask litefw_CalculateImageMask

9.9.2.8 #define LIBSDP_CARRIER_PACKAGE_SKU LITEFW_CARRIER_PACKAGE_SKU

9.9.2.9 #define libSDP_CheckValidFirmwareInfo litefw_CheckValidFirmwareInfo

9.9.2.10 #define libSDP_DownloadFW litefw_DownloadFW

9.9.2.11 #define libSDP_ExtractFirmwareParametersByPath litefw_ExtractFirmwareParametersByPath

9.9.2.12 #define libSDP_getFileType litefw_getFileType

9.9.2.13 #define libSDP_GetModelFamily litefw_GetModelFamily

9.9.2.14 #define libSDP_GetVersion litefw_GetVersion

9.9.2.15 #define libsdp_set_log_func litefw_set_log_func

9.9.2.16 #define libsdp_SetReadBlockSize litefw_SetReadBlockSize

9.9.2.17 #define LIBSDP_SKU_STRING_LENGTH LITEFW_SKU_STRING_LENGTH

9.9.2.18 #define LITEFW_CARRIER_PACKAGE_SKU "9999999"

9.9.2.19 #define LITEFW_SKU_STRING_LENGTH 7

9.9.2.20 #define NULL_TERMINATOR_CHAR_SIZE 1

9.9.3 Typedef Documentation

9.9.3.1 typedef litefw_FirmwareInfo libSDP_FirmwareInfo

9.9.3.2 typedef litefwlogger libsdplogger

9.9.3.3 typedef struct _litefw_FirmwareInfo_ litefw_FirmwareInfo

This structure contains information of the response parameters associated with a Read Transparent API.

Parameters

szModelid_str	• Model Name String
szFwversion_str	• Firmware Version String.
szSku_str	• SKU String.
szPackageid_str	• Package ID String.
szCarrier_str	• Carrier String.
szCarrier-Priversion_str	• Carrier PRI Version String.

9.9.3.4 typedef void(∗ litefwlogger)(uint8_t lvl, const char ∗buff)

This Custom Log prototype.

Parameters

in	*lvl*	• Log level.

in	*buff*	• Log String.

Returns

none

9.9.4 Enumeration Type Documentation

9.9.4.1 enum litefw_Fw_Type

Enumerator

eFW_TYPE_MBN_GOBI

eFW_TYPE_MBN

eFW_TYPE_CWE

eFW_TYPE_NVU

eFW_TYPE_SPK

eFW_TYPE_INVALID

eFW_TYPE_CWE_NVU

9.9.4.2 enum litefw_fwdwl_error_codes

Enumerator

eSDP_FWDWL_SUCCESS

eSDP_FWDWL_ERR_GENERAL

eSDP_FWDWL_ERR_SDK

eSDP_FWDWL_ERR_SET_CBK

eSDP_FWDWL_ERR_PATH_TOO_LONG

eSDP_FWDWL_ERR_PATH_NOT_SPECIFIED

eSDP_FWDWL_ERR_FW_UPGRADE

eSDP_FWDWL_ERR_INVALID_DEV

eSDP_FWDWL_ERR_INVALID_PATH

eSDP_FWDWL_ERR_TIMEOUT

eSDP_FWDWL_ERR_FAIL

eSDP_FWDWL_ERR_PRI_FAIL

eSDP_FWDWL_ERR_FW_VERSION_FAIL

eSDP_FWDWL_ERR_SDP_TIMEOUT

eFIREHOSE_ERR_SECBOOT_INVALID_CERT_CHAIN

eSDP_FWDWL_ERR_END

9.9.4.3 enum litefw_Models

Enumerator

eModel_Unknown

eModel_9X15

eModel_WP9X15

eModel_9X30

eModel_9x07

eModel_9x06

9.9.4.4 enum litefw_QDL_FLOW_CONTROLs

Enumerator

eQDL_HW_FLOW_Unknown

eQDL_HW_FLOW_INIT

eQDL_HW_FLOW_ENABLE

eQDL_HW_FLOW_DISABLE

9.9.4.5 enum litefw_QDL_MODEs

Enumerator

eQDL_MODE_Unknown

eQDL_MODE_INIT

eQDL_MODE_TTYUSB

eQDL_MODE_UART0

9.9.5 Function Documentation

9.9.5.1 int litefw_BuildImagesPreferenceRequest (litefw_FirmwareInfo *info*, pack_fms_SetImagesPreference_t * *pack*)

This API Build Image Preference Request Using Firmware Information.

Parameters

in	*info*	• See litefw_FirmwareInfo for more information.
out	*pack*	• See pack_fms_SetImagesPreference_t for more information.

Returns

0 on success, litefw_fwdwl_error_codes error value otherwise

See Also

See litefw_fwdwl_error_codes for error values

9.9.5.2 int litefw_CalculateImageMask (unpack_fms_SetImagesPreference_t *SetPrefRspFromModem*)

This API Calculate Image Mask for Firmware Download.

Parameters

in	*SetPrefRsp-FromModem*	• See unpack_fms_SetImagesPreference_t for more information.

Returns

Image Mask

- IMG_MASK_MDM | IMG_MASK_PRI

9.9.5.3 int litefw_CheckValidFirmwareInfo (litefw_FirmwareInfo *info*)

This API Check Valid Firmware Information to build Image Prefernce Request.

Parameters

in	*info*	• See litefw_FirmwareInfo for more information.

Returns

0 on success, -1 error value otherwise

9.9.5.4 unsigned int litefw_DownloadFW (char * *pImagePath*, char * *szTTYPath*, int *iFWImageType*, int *image_mask*, int *iModelFamily*)

This API Download Firmware.

Parameters

in	*pImagePath*	• Firmware Folder Path.
in	*szTTYPath*	• QDL Device Path.
in	*iFWImageType*	• Firmware Type. • See litefw_Fw_Type
in	*image_mask*	• Image Mask. – IMG_MASK_MDM | IMG_MASK_PRI
in	*iModelFamily*	• Modem Family. • See litefw_Models

Returns

0 on success, litefw_fwdwl_error_codes error value otherwise

See Also

See litefw_fwdwl_error_codes for error values

9.9.5.5 int litefw_ExtractFirmwareParametersByPath (char * *pImagePath,* litefw_FirmwareInfo * *info*)

This API Extrace Firmware Parameters From Path.

Parameters

in	*pImagePath*	• Firmware Folder Path.
out	*info*	• See litefw_FirmwareInfo for more information.

Returns

0 on success, litefw_fwdwl_error_codes error value otherwise

See Also

See litefw_fwdwl_error_codes for error values

9.9.5.6 int litefw_getFileType (char * *szPath*)

This API Get File Type By Path

Parameters

in	*szPath*	• See litefw_FirmwareInfo for more information.

Returns

eFW_TYPE_INVALID on error, litefw_Fw_Type value otherwise

See Also

See litefw_Fw_Type for values

9.9.5.7 int litefw_GetModelFamily (char * *pModelString*)

This API Get Model Famliy from a model string.

Parameters

in	*pModelString*	• Model String.

Returns

eModel_Unknown on Error, litefw_Models value otherwise

See Also

See litefw_Models for values

9.9.5.8 int litefw_GetQTLDownloadMode ( )

This API Get QDL port donwload mode.

Returns

eQDL_MODE_Unknown on Error, litefw_QDL_MODEs value otherwise

9.9.5.9 int litefw_GetQTLHWFlowControl ( )

This API Get QDL port Hardware flow control.

Returns

eQDL_HW_FLOW_Unknown on Error, litefw_QDL_FLOW_CONTROLs value otherwise

9.9.5.10 char* litefw_GetVersion ( )

This API Get Lib SDP Version.

Returns

Version String

9.9.5.11 void litefw_logsenable (int *log_en*)

This function enable/disable lite firmware debug logs.

Parameters

in	*log_en*	• Logs enable/disable flag.

9.9.5.12 int litefw_set_log_func (litefwlogger * *func*)

This API Set Custom Log function.

Parameters

in	*func*	• See litefwlogger for more information.

Returns

none

9.9.5.13 int litefw_SetQTLDownloadMode (int *iMode*)

This API set QDL port donwload mode.

Parameters

in	*iMode*	• QDL Download Mode. – litefw_QDL_MODEs

Returns

0 on success, -1 error value otherwise

9.9.5.14 int litefw_SetQTLHWFlowControl (int *iMode*)

This API Set QDL port Hardware flow control.

Parameters

in	*iMode*	• litefw_QDL_FLOW_CONTROLs

Returns

0 on success, -1 error value otherwise

9.9.5.15 void litefw_SetReadBlockSize (unsigned long *lBlockSize*)

This API Set Read BlockSize.

Parameters

in	*lBlockSize*	• Firmware Read Block Size.

Returns

none

9.9.5.16 int litefw_switch_9x07_to_downloadmode (char * *szTTYPath*)

This API switch 9x07 modem to download mode.

Parameters

in	*szTTYPath*	• QDL Device Path.

Returns

0 on success, -1 error value otherwise

9.9.5.17 int litefw_switch_to_BootHoldMode (char * *szTTYPath*)

This API switch modem to boot hold modem via QDL port.

Parameters

in	*szTTYPath*	• QDL Device Path.

Returns

0 on success, -1 error value otherwise

9.10 loc.h File Reference

Data Structures

- struct loc_LocApplicationInfo
- struct loc_SV
- struct loc_SVInfo
- struct loc_GnssData
- struct loc_CellDb
- struct loc_ClkInfo
- struct loc_BdsSV
- struct loc_BdsSVInfo
- struct pack_loc_EventRegister_t
- struct unpack_loc_EventRegister_t
- struct pack_loc_SetExtPowerState_t
- struct unpack_loc_SetExtPowerState_t
- struct pack_loc_Start_t
- struct unpack_loc_Start_t
- struct pack_loc_Stop_t
- struct unpack_loc_Stop_t
- struct pack_loc_SetOperationMode_t
- struct unpack_loc_SetOperationMode_t
- struct pack_loc_Delete_Assist_Data_t
- struct unpack_loc_Delete_Assist_Data_t
- struct loc_precisionDilution
- struct loc_sensorDataUsage
- struct loc_svUsedforFix
- struct loc_gpsTime
- struct unpack_loc_PositionRpt_Ind_t
- struct unpack_loc_EngineState_Ind_t

- struct unpack_loc_SetExtPowerConfig_Ind_t
- struct unpack_loc_SLQSLOCGetBestAvailPos_t
- struct pack_loc_SLQSLOCGetBestAvailPos_t
- struct unpack_loc_BestAvailPos_Ind_t
- struct unpack_loc_SetOperationMode_Ind_t
- struct unpack_loc_DeleteAssistData_Ind_t
- struct loc_satelliteInfo
- struct unpack_loc_GnssSvInfo_Ind_t
- struct pack_loc_SLQSLOCInjectUTCTime_t
- struct altSrcInfo_t
- struct pack_loc_SLQSLOCInjectPosition_t
- struct pack_loc_SLQSLOCSetCradleMountConfig_t
- struct sensorData_t
- struct tempData_t
- struct pack_loc_SLQSLOCInjectSensorData_t
- struct unpack_loc_EventNMEA_Ind_t
- struct pack_loc_SLQSLOCGetServer_t
- struct loc_IPv4Info
- struct loc_IPv6Info
- struct loc_urlAddr
- struct unpack_loc_GetServer_Ind_t
- struct unpack_loc_CradleMountCallback_Ind_t
- struct unpack_loc_EventTimeSyncCallback_Ind_t
- struct unpack_loc_InjectTimeSyncDataCallback_Ind_t
- struct unpack_loc_InjectSensorDataCallback_Ind_t
- struct loc_accelAcceptReady
- struct loc_gyroAcceptReady
- struct loc_accelTempAcceptReady
- struct loc_gyroTempAcceptReady
- struct unpack_loc_SensorStreamingCallback_Ind_t
- struct unpack_loc_InjectUTCTimeCallback_Ind_t
- struct unpack_loc_InjectPositionCallback_Ind_t
- struct loc_IPv4Config
- struct loc_IPv6Config
- struct loc_URLAddrInfo
- struct pack_loc_SLQSLOCSetServer_t
- struct unpack_loc_SetServer_Ind_t

Macros

- #define LOC_UINT8_MAX_STRING_SZ 255
- #define LOCEVENTMASKPOSITIONREPORT 0x00000001
- #define LOCEVENTMASKGNSSSVINFO 0x00000002
- #define LOCEVENTMASKNMEA 0x00000004
- #define LOCEVENTMASKNINOTIFYVERIFYREQ 0x00000008
- #define LOCEVENTMASKINJECTTIMEREQ 0x00000010
- #define LOCEVENTMASKINJECTPREDICTEDORBITSREQ 0x00000020
- #define LOCEVENTMASKINJECTPOSITIONREQ 0x00000040
- #define LOCEVENTMASKENGINESTATE 0x00000080
- #define LOCEVENTMASKFIXSESSIONSTATE 0x00000100
- #define LOCEVENTMASKWIFIREQ 0x00000200
- #define LOCEVENTMASKSENSORSTREAMINGREADYSTATUS 0x00000400
- #define LOCEVENTMASKTIMESYNCREQ 0x00000800
- #define LOCEVENTMASKSETSPISTREAMINGREPORT 0x00001000

- #define LOCEVENTMASKLOCATIONSERVERCONNECTIONREQ 0x00002000
- #define LOCEVENTMASKNIGEOFENCENOTIFICATION 0x00004000
- #define LOCEVENTMASKGEOFENCEGENALERT 0x00008000
- #define LOCEVENTMASKGEOFENCEBREACHNOTIFICATION 0x00010000
- #define LOCEVENTMASKPEDOMETERCONTROL 0x00020000
- #define LOCEVENTMASKMOTIONDATACONTROL 0x00040000
- #define LOCEVENTMASKBATCHFULLNOTIFICATION 0x00080000
- #define LOCEVENTMASKLIVEBATCHEDPOSITIONREPORT 0x00100000
- #define LOCEVENTMASKINJECTWIFIAPDATAREQ 0x00200000
- #define LOCEVENTMASKGEOFENCEBATCHBREACHNOTIFICATION 0x00400000
- #define LOCEVENTMASKVEHICLEDATAREADYSTATUS 0x00800000
- #define LOCEVENTMASKGNSSMEASUREMENTREPORT 0x01000000
- #define LOCEVENTMASKINVALIDVALUE 0xFFFFFFFF
- #define MAX_SENSOR_DATA_LEN 64
- #define MAX_TEMP_DATA_LEN 64
- #define MAX_LOC_NMEA_STR_LEN 201

Typedefs

- typedef unpack_result_t unpack_loc_SLQSLOCInjectUTCTime_t
- typedef unpack_result_t unpack_loc_SLQSLOCInjectPosition_t
- typedef unpack_result_t unpack_loc_SLQSLOCSetCradleMountConfig_t
- typedef unpack_result_t unpack_loc_SLQSLOCInjectSensorData_t
- typedef unpack_result_t unpack_loc_SLQSLOCGetServer_t

Enumerations

- enum {
  eQMI_LOC_SESS_STATUS_SUCCESS =0,
  eQMI_LOC_SESS_STATUS_IN_PROGRESS =1,
  eQMI_LOC_SESS_STATUS_FAILURE =2,
  eQMI_LOC_SESS_STATUS_TIMEOUT =3 }

Functions

- int pack_loc_EventRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_EventRegister_t *reqArg)
- int unpack_loc_EventRegister (uint8_t *pResp, uint16_t respLen, unpack_loc_EventRegister_t *pOutput)
- int pack_loc_SetExtPowerState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SetExtPowerState_t *reqArg)
- int unpack_loc_SetExtPowerState (uint8_t *pResp, uint16_t respLen, unpack_loc_SetExtPowerState_t *pOutput)
- int pack_loc_Start (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_Start_t *reqArg)
- int unpack_loc_Start (uint8_t *pResp, uint16_t respLen, unpack_loc_Start_t *pOutput)
- int pack_loc_Stop (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_Stop_t *reqArg)
- int unpack_loc_Stop (uint8_t *pResp, uint16_t respLen, unpack_loc_Stop_t *pOutput)
- int pack_loc_SetOperationMode (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SetOperationMode_t *reqArg)
- int unpack_loc_SetOperationMode (uint8_t *pResp, uint16_t respLen, unpack_loc_SetOperationMode_t *pOutput)
- int pack_loc_DeleteAssistData (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_Delete_Assist_Data_t *reqArg)
- int unpack_loc_DeleteAssistData (uint8_t *pResp, uint16_t respLen, unpack_loc_Delete_Assist_Data_t *pOutput)

- int unpack_loc_PositionRpt_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_PositionRpt_Ind_t *pOutput)
- int unpack_loc_EngineState_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_EngineState_Ind_t *pOutput)
- int unpack_loc_SetExtPowerConfig_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_SetExtPowerConfig_Ind_t *pOutput)
- int pack_loc_SLQSLOCGetBestAvailPos (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCGetBestAvailPos_t *reqArg)
- int unpack_loc_SLQSLOCGetBestAvailPos (uint8_t *pResp, uint16_t respLen, unpack_loc_SLQSLOCGetBestAvailPos_t *pOutput)
- int unpack_loc_BestAvailPos_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_BestAvailPos_Ind_t *pOutput)
- int unpack_loc_SetOperationMode_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_SetOperationMode_Ind_t *pOutput)
- int unpack_loc_DeleteAssistData_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_DeleteAssistData_Ind_t *pOutput)
- int unpack_loc_GnssSvInfo_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_GnssSvInfo_Ind_t *pOutput)
- int pack_loc_SLQSLOCInjectUTCTime (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCInjectUTCTime_t *reqArg)
- int unpack_loc_SLQSLOCInjectUTCTime (uint8_t *pResp, uint16_t respLen, unpack_loc_SLQSLOCInjectUTCTime_t *pOutput)
- int pack_loc_SLQSLOCInjectPosition (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCInjectPosition_t *reqArg)
- int unpack_loc_SLQSLOCInjectPosition (uint8_t *pResp, uint16_t respLen, unpack_loc_SLQSLOCInjectPosition_t *pOutput)
- int pack_loc_SLQSLOCSetCradleMountConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCSetCradleMountConfig_t *reqArg)
- int unpack_loc_SLQSLOCSetCradleMountConfig (uint8_t *pResp, uint16_t respLen, unpack_loc_SLQSLOCSetCradleMountConfig_t *pOutput)
- int pack_loc_SLQSLOCInjectSensorData (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCInjectSensorData_t *reqArg)
- int unpack_loc_SLQSLOCInjectSensorData (uint8_t *pResp, uint16_t respLen, unpack_loc_SLQSLOCInjectSensorData_t *pOutput)
- int unpack_loc_EventNMEA_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_EventNMEA_Ind_t *pOutput)
- int pack_loc_SLQSLOCGetServer (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCGetServer_t *reqArg)
- int unpack_loc_SLQSLOCGetServer (uint8_t *pResp, uint16_t respLen, unpack_loc_SLQSLOCGetServer_t *pOutput)
- int unpack_loc_GetServer_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_GetServer_Ind_t *pOutput)
- int unpack_loc_CradleMountCallback_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_CradleMountCallback_Ind_t *pOutput)
- int unpack_loc_EventTimeSyncCallback_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_EventTimeSyncCallback_Ind_t *pOutput)
- int unpack_loc_InjectTimeSyncDataCallback_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_InjectTimeSyncDataCallback_Ind_t *pOutput)
- int unpack_loc_InjectSensorDataCallback_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_InjectSensorDataCallback_Ind_t *pOutput)
- int unpack_loc_SensorStreamingCallback_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_SensorStreamingCallback_Ind_t *pOutput)
- int unpack_loc_InjectUTCTimeCallback_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_InjectUTCTimeCallback_Ind_t *pOutput)
- int unpack_loc_InjectPositionCallback_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_InjectPositionCallback_Ind_t *pOutput)
- int pack_loc_SLQSLOCSetServer (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_loc_SLQSLOCSetServer_t *reqArg)
- int unpack_loc_SLQSLOCSetServer (uint8_t *pResp, uint16_t respLen)
- int unpack_loc_SetServer_Ind (uint8_t *pResp, uint16_t respLen, unpack_loc_SetServer_Ind_t *pOutput)

9.10.1 Macro Definition Documentation

9.10.1.1 #define LOC_UINT8_MAX_STRING_SZ 255

9.10.1.2 #define LOCEVENTMASKBATCHFULLNOTIFICATION 0x00080000

The control point must enable this mask to receive notification when a batch is full. The location engine sends this event to notify of Batch Full for ongoing batching session.

9.10.1.3 #define LOCEVENTMASKENGINESTATE 0x00000080

The control point must enable this mask to receive engine state report event indications.

9.10.1.4 #define LOCEVENTMASKFIXSESSIONSTATE 0x00000100

The control point must enable this mask to receive fix session status report event indications.

9.10.1.5 #define LOCEVENTMASKGEOFENCEBATCHBREACHNOTIFICATION 0x00400000

The control point must enable this mask to receive notifications when a Geofence is breached. These events are generated when a UE enters or leaves the perimeter of a Geofence. This breach notification is for multiple Geofences. Breaches from multiple Geofences are all batched and sent in the same notification.

9.10.1.6 #define LOCEVENTMASKGEOFENCEBREACHNOTIFICATION 0x00010000

The control point must enable this mask to receive notifications when a Geofence is breached. These events are generated when a UE enters or leaves the perimeter of a Geofence. This breach report is for a single Geofence.

9.10.1.7 #define LOCEVENTMASKGEOFENCEGENALERT 0x00008000

The control point must enable this mask to receive Geofence alerts. These alerts are generated to inform the client of the changes that may affect a Geofence, for example, if GPS is turned off or if the network is unavailable.

9.10.1.8 #define LOCEVENTMASKGNSSMEASUREMENTREPORT 0x01000000

The control point must enable this mask to receive system clock and satellite measurement report events (system clock, SV time, Doppler, etc.). Reports are generated only for the GNSS satellite constellations that are enabled using QMI_LOC_SET_GNSS_ CONSTELL_REPORT_CONFIG(Not yet supported).

9.10.1.9 #define LOCEVENTMASKGNSSSVINFO 0x00000002

The control point must enable this mask to receive satellite report event indications. These reports are sent at a 1 Hz rate.

9.10.1.10 #define LOCEVENTMASKINJECTPOSITIONREQ 0x00000040

The control point must enable this mask to receive position injection request event indications.

9.10.1.11 #define LOCEVENTMASKINJECTPREDICTEDORBITSREQ 0x00000020

The control point must enable this mask to receive predicted orbits request event indications.

9.10.1.12 #define LOCEVENTMASKINJECTTIMEREQ 0x00000010

The control point must enable this mask to receive time injection request event indications.

9.10.1.13 #define LOCEVENTMASKINJECTWIFIAPDATAREQ 0x00200000

The control point must enable this mask to receive Wi-Fi Access Point (AP) data inject request event indications.

9.10.1.14 #define LOCEVENTMASKINVALIDVALUE 0xFFFFFFFF

Invalid Event Mask

9.10.1.15 #define LOCEVENTMASKLIVEBATCHEDPOSITIONREPORT 0x00100000

The control point must enable this mask to receive position report indications along with an ongoing batching session. The location engine sends this event to notify the batched position report while a batching session is ongoing.

9.10.1.16 #define LOCEVENTMASKLOCATIONSERVERCONNECTIONREQ 0x00002000

The control point must enable this mask to receive location server requests. These requests are generated when the service wishes to establish a connection with a location server.

9.10.1.17 #define LOCEVENTMASKMOTIONDATACONTROL 0x00040000

The control point must enable this mask to register for motion data control requests from the location engine. The location engine sends this event to control the injection of motion data.

9.10.1.18 #define LOCEVENTMASKNIGEOFENCENOTIFICATION 0x00004000

The control point must enable this mask to receive notifications related to network-initiated Geofences. These events notify the client when a network-initiated Geofence is added, deleted, or edited.

9.10.1.19 #define LOCEVENTMASKNINOTIFYVERIFYREQ 0x00000008

The control point must enable this mask to receive NI Notify/Verify request event indications.

9.10.1.20 #define LOCEVENTMASKNMEA 0x00000004

The control point must enable this mask to receive NMEA reports for position and satellites in view. The report is at a 1 Hz rate.

9.10.1.21 #define LOCEVENTMASKPEDOMETERCONTROL 0x00020000

The control point must enable this mask to register for pedometer control requests from the location engine. The location engine sends this event to control the injection of pedometer reports.

9.10.1.22 #define LOCEVENTMASKPOSITIONREPORT 0x00000001

The control point must enable this mask to receive position report event indications.

9.10.1.23 #define LOCEVENTMASKSENSORSTREAMINGREADYSTATUS 0x00000400

The control point must enable this mask to receive notifications from the location engine indicating its readiness to accept data from the sensors (accelerometer, gyroscope, etc.).

9.10.1.24 #define LOCEVENTMASKSETSPISTREAMINGREPORT 0x00001000

The control point must enable this mask to receive Stationary Position Indicator (SPI) streaming report indications.

9.10.1.25 #define LOCEVENTMASKTIMESYNCREQ 0x00000800

The control point must enable this mask to receive time sync requests from the GPS engine. Time sync enables the GPS engine to synchronize its clock with the sensor processor's clock.

9.10.1.26 #define LOCEVENTMASKVEHICLEDATAREADYSTATUS 0x00800000

The control point must enable this mask to receive notifications from the location engine indicating its readiness to accept vehicle data (vehicle accelerometer, vehicle angular rate, vehicle odometry, etc.).

9.10.1.27 #define LOCEVENTMASKWIFIREQ 0x00000200

The control point must enable this mask to receive Wi-Fi position request event indications.

9.10.1.28 #define MAX_LOC_NMEA_STR_LEN 201

9.10.1.29 #define MAX_SENSOR_DATA_LEN 64

9.10.1.30 #define MAX_TEMP_DATA_LEN 64

9.10.2 Typedef Documentation

9.10.2.1 typedef unpack_result_t unpack_loc_SLQSLOCGetServer_t

9.10.2.2 typedef unpack_result_t unpack_loc_SLQSLOCInjectPosition_t

9.10.2.3 typedef unpack_result_t unpack_loc_SLQSLOCInjectSensorData_t

9.10.2.4 typedef unpack_result_t unpack_loc_SLQSLOCInjectUTCTime_t

9.10.2.5 typedef unpack_result_t unpack_loc_SLQSLOCSetCradleMountConfig_t

9.10.3 Enumeration Type Documentation

9.10.3.1 anonymous enum

Enumerator

eQMI_LOC_SESS_STATUS_SUCCESS

eQMI_LOC_SESS_STATUS_IN_PROGRESS

eQMI_LOC_SESS_STATUS_FAILURE

eQMI_LOC_SESS_STATUS_TIMEOUT

9.10.4 Function Documentation

9.10.4.1 int pack_loc_DeleteAssistData (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_loc_Delete_Assist_Data_t * reqArg)

Delete Assistant Data pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.2 int pack_loc_EventRegister (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_loc_EventRegister_t * reqArg)

Event Register pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.3 int pack_loc_SetExtPowerState (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_loc_SetExtPowerState_t * reqArg)

Set Ext Power State pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.4 int pack_loc_SetOperationMode (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SetOperationMode_t * *reqArg*)

Set Operation Mode pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.5 int pack_loc_SLQSLOCGetBestAvailPos (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCGetBestAvailPos_t * *reqArg*)

Get Best Avail position pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.6 int pack_loc_SLQSLOCGetServer (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCGetServer_t * *reqArg*)

Pack get server.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

The request is acknowledged through the response, but the SUCCESS/FAILURE status is sent through unpack_loc_GetServer_Ind callback If successful, the callback also contains the A-GPS server address.

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.7 int pack_loc_SLQSLOCInjectPosition (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCInjectPosition_t * *reqArg*)

Pack inject position.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.8 int pack_loc_SLQSLOCInjectSensorData (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCInjectSensorData_t * *reqArg*)

Pack inject sensor data.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.9 int pack_loc_SLQSLOCInjectUTCTime (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCInjectUTCTime_t * *reqArg*)

Pack inject UTC time.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.10 int pack_loc_SLQSLOCSetCradleMountConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCSetCradleMountConfig_t * *reqArg*)

Pack set cradle mount configure.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.11 int pack_loc_SLQSLOCSetServer (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_SLQSLOCSetServer_t * *reqArg*)

Pack Set server.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

If multiple types of addresses are specified in the request, the IPv4 address takes precedence over the IPv6 address and the IPv6 address takes precedence over the URL address.The request is acknowledged through the response, but the SUCCESS/FAILURE status is sent through unpack_loc_SetServer_Ind callback

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.12 int pack_loc_Start (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_Start_t * *reqArg*)

LOC Start pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.13 int pack_loc_Stop (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_loc_Stop_t * *reqArg*)

Loc Stop pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.14 int unpack_loc_BestAvailPos_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_BestAvailPos_Ind_t * *pOutput*)

Loc Best Avial position Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.15 int unpack_loc_CradleMountCallback_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_CradleMountCallback_Ind_t * *pOutput*)

Unpack the Cradle Mount Indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.16 int unpack_loc_DeleteAssistData (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_Delete_Assist_Data_t * *pOutput*)

Delete Assistant Data unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.17 int unpack_loc_DeleteAssistData_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_DeleteAssistData_Ind_t * *pOutput*)

Unpack the status of delete the location engine assistance data

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.18 int unpack_loc_EngineState_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_EngineState_Ind_t * *pOutput*)

Loc Engine State Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.19 int unpack_loc_EventNMEA_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_EventNMEA_Ind_t * *pOutput*)

Unpack the NMEA Event Indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.20 int unpack_loc_EventRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_EventRegister_t * *pOutput*)

Event Register unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.21 int unpack_loc_EventTimeSyncCallback_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_EventTimeSyncCallback_Ind_t * *pOutput*)

Unpack the Event Time Sync indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.22 int unpack_loc_GetServer_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_GetServer_Ind_t * *pOutput*)

Unpack the Get Server Indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.23 int unpack_loc_GnssSvInfo_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_GnssSvInfo_Ind_t * *pOutput*)

Unpack the GNSS SV Info Indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.24 int unpack_loc_InjectPositionCallback_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_InjectPositionCallback_Ind_t * *pOutput*)

Unpack the Inject position indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.25 int unpack_loc_InjectSensorDataCallback_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_InjectSensorDataCallback_Ind_t * *pOutput*)

Unpack the inject sensor data indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.26 int unpack_loc_InjectTimeSyncDataCallback_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_InjectTimeSyncDataCallback_Ind_t * *pOutput*)

Unpack the inject time sync data indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.27 int unpack_loc_InjectUTCTimeCallback_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_InjectUTCTimeCallback_Ind_t * *pOutput*)

Unpack the Inject UTC time indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.28 int unpack_loc_PositionRpt_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_PositionRpt_Ind_t * *pOutput*)

Loc Position Report Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.29 int unpack_loc_SensorStreamingCallback_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SensorStreamingCallback_Ind_t * *pOutput*)

Unpack the Sensor streaming status indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.30 int unpack_loc_SetExtPowerConfig_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SetExtPowerConfig_Ind_t * *pOutput*)

Loc Set External Power Configure Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.31 int unpack_loc_SetExtPowerState (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SetExtPowerState_t * *pOutput*)

Set Ext Power State unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.32 int unpack_loc_SetOperationMode (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SetOperationMode_t * *pOutput*)

Set Operation Mode unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.33 int unpack_loc_SetOperationMode_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SetOperationMode_Ind_t * *pOutput*)

Unpack the engine to use the specified operation mode.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.34 int unpack_loc_SetServer_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SetServer_Ind_t * *pOutput*)

Unpack the Set Server Indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.35 int unpack_loc_SLQSLOCGetBestAvailPos (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SLQSLOCGetBestAvailPos_t * *pOutput*)

Get Best Avail position unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.36 int unpack_loc_SLQSLOCGetServer (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SLQSLOCGetServer_t * *pOutput*)

Unpack get server.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.37 int unpack_loc_SLQSLOCInjectPosition (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SLQSLOCInject-Position_t * *pOutput*)

Unpack inject position.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.38 int unpack_loc_SLQSLOCInjectSensorData (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SLQSLOCInjectSensorData_t * *pOutput*)

Unpack inject sensor data.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.39 int unpack_loc_SLQSLOCInjectUTCTime (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SLQSLOCInjectUTCTime_t * *pOutput*)

Unpack inject UTC time.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.40 int unpack_loc_SLQSLOCSetCradleMountConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_SLQSLOCSetCradleMountConfig_t * *pOutput*)

Unpack set cradle mount configure.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.41 int unpack_loc_SLQSLOCSetServer (uint8_t * *pResp*, uint16_t *respLen*)

Unpack set server.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.42 int unpack_loc_Start (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_Start_t * *pOutput*)

Loc Start unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.10.4.43 int unpack_loc_Stop (uint8_t * *pResp*, uint16_t *respLen*, unpack_loc_Stop_t * *pOutput*)

Loc Stop unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11 nas.h File Reference

Data Structures

- struct unpack_nas_GetSignalStrengths_t
- struct unpack_nas_SLQSGetSysSelectionPref_t
- struct nas_netSelectionPref
- struct nas_acqOrderPref
- struct nas_CSGID
- struct pack_nas_SLQSSetSysSelectionPref_t
- struct nas_lteBandPrefExt
- struct nas_ciotAcqOrderPref
- struct nas_nr5gBandPref
- struct pack_nas_SLQSSetSysSelectionPrefExt_t
- struct pack_nas_SLQSSetBandPreference_t
- struct pack_nas_SLQSNasIndicationRegisterExt_t
- struct RFBandInfoElements
- struct unpack_nas_GetRFInfo_t
- struct cdmaSSInfo
- struct hdrSSInfo
- struct lteSSInfo
- struct tdscdmaSigInfoExt
- struct unpack_nas_SLQSNasGetSigInfo_t
- struct unpack_nas_SLQSNasSigInfoCallback_ind_t
- struct unpack_nas_GetHomeNetwork_t
- struct nas_SrvStatusInfo
- struct nas_GSMSrvStatusInfo
- struct nas_sysInfoCommon
- struct nas_CDMASysInfo
- struct nas_HDRSysInfo
- struct nas_GSMSysInfo
- struct nas_WCDMASysInfo
- struct nas_LTESysInfo
- struct nas_AddCDMASysInfo
- struct nas_AddSysInfo
- struct nas_CallBarringSysInfo
- struct unpack_nas_SLQSGetSysInfo_t
- struct unpack_nas_SLQSSysInfoCallback_ind_t
- struct unpack_nas_GetServingNetwork_t
- struct unpack_nas_GetServingNetworkCapabilities_t
- struct nas_QmiNas3GppNetworkInfo
- struct nas_QmiNas3GppNetworkRAT
- struct nas_QmisNasPcsDigit
- struct nas_QmisNasSlqsNasPCICellInfo
- struct nas_QmisNasSlqsNasPCIInfo
- struct unpack_nas_PerformNetworkScan_t

- struct unpack_nas_SLQSSwiGetLteCQI_t
- struct nas_CommInfo
- struct nas_LTEInfo
- struct unpack_nas_SLQSNasSwiModemStatus_t
- struct nas_servSystem
- struct nas_dataSrvCapabilities
- struct nas_currentPLMN
- struct nas_roamIndList
- struct nas_qaQmi3Gpp2TimeZone
- struct nas_detailSvcInfo
- struct nas_CDMASysInfoExt
- struct nas_callBarStatus
- struct unpack_nas_SLQSGetServingSystem_t
- struct nas_rxSignalStrengthListElement
- struct nas_ecioListElement
- struct nas_errorRateListElement
- struct nas_rsrqInformation
- struct nas_lteSnrinformation
- struct nas_lteRsrpinformation
- struct unpack_nas_SLQSGetSignalStrength_t
- struct nas_SLQSSignalStrengthsIndReq
- struct pack_nas_SLQSSetSignalStrengthsCallback_t
- struct nas_SLQSSignalStrengthsInformation
- struct nas_RejectReasonTlv
- struct nas_SignalStrengthTlv
- struct nas_RFInfoTlv
- struct nas_SLQSSignalStrengthsTlv
- struct unpack_nas_SetEventReportInd_t
- struct unpack_nas_GetCDMANetworkParameters_t
- struct unpack_nas_GetANAAAAuthenticationStatus_t
- struct unpack_nas_GetACCOLC_t
- struct pack_nas_SetACCOLC_t
- struct nas_CDMARSSIThresh
- struct nas_CDMAECIOThresh
- struct nas_HDRRSSIThresh
- struct nas_HDRECIOThresh
- struct nas_HDRSINRThreshold
- struct nas_HDRIOThresh
- struct nas_GSMRSSIThresh
- struct nas_WCDMARSSIThresh
- struct nas_WCDMAECIOThresh
- struct nas_LTERSSIThresh
- struct nas_LTESNRThreshold
- struct nas_LTERSRQThresh
- struct nas_LTERSRPThresh
- struct nas_LTESigRptConfig
- struct nas_TDSCDMARSCPThresh
- struct nas_TDSCDMARSSIThresh
- struct nas_TDSCDMAECIOThresh
- struct nas_TDSCDMASINRThresh
- struct pack_nas_SLQSNasConfigSigInfo2_t
- struct unpack_nas_SetDataCapabilitiesCallback_ind_t
- struct unpack_nas_GetNetworkPreference_t
- struct pack_nas_SetNetworkPreference_t
- struct unpack_nas_SetNetworkPreference_t

- struct unpack_nas_SetRoamingIndicatorCallback_ind_t
- struct NASServingSystemInfo
- struct unpack_nas_SetServingSystemCallback_ind_t
- struct NASPhyCaAggScellIndType
- struct NASPhyCaAggScellDlBw
- struct NASPhyCaAggScellInfo
- struct NASPhyCaAggPcellInfo
- struct NASPhyCaAggScellIndex
- struct NasGetLTECphyCaInfo
- struct unpack_nas_SlqsGetLTECphyCAInfo_t
- struct NASEmergencyModeTlv
- struct NASModePreferenceTlv
- struct NASBandPreferenceTlv
- struct NASPRLPreferenceTlv
- struct NASRoamPreferenceTlv
- struct NASLTEBandPreferenceTlv
- struct NASNetSelPreferenceTlv
- struct NASServDomainPrefTlv
- struct NASGWAcqOrderPrefTlv
- struct NASAcqOrderPrefTlv
- struct NASRatDisabledMaskTlv
- struct NASCiotLteOpModePrefTlv
- struct NASLteM1BandPrefTlv
- struct NASLteNB1BandPrefTlv
- struct NASCiotAcqOrderPrefTlv
- struct NASNr5gBandPrefTlv
- struct NASQmiCbkNasSystemSelPrefInd
- struct unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t
- struct NASOTAMessageTlv
- struct NASLteNasReleaseInfoTlv
- struct NASTimeInfoTlv
- struct NASQmiCbkNasSwiOTAMessageInd
- struct unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t
- struct nas_MNRInfo
- struct pack_nas_SLQSInitiateNetworkRegistration_t
- struct pack_nas_SLQSNasSwiIndicationRegister_t
- struct pack_nas_SLQSGetPLMNName_t
- struct unpack_nas_SLQSGetPLMNName_t
- struct nas_nmrCellInfo
- struct nas_GERANInfo
- struct nas_geranInstInfo
- struct nas_UMTSinstInfo
- struct nas_UMTSInfo
- struct nas_CDMAInfo
- struct nas_cellParams
- struct nas_LTEInfoIntrafreq
- struct nas_infoInterFreq
- struct nas_LTEInfoInterfreq
- struct nas_gsmCellInfo
- struct nas_lteGsmCellInfo
- struct nas_LTEInfoNeighboringGSM
- struct nas_wcdmaCellInfo
- struct nas_lteWcdmaCellInfo
- struct nas_LTEInfoNeighboringWCDMA
- struct nas_umtsLTENbrCell

- struct nas_WCDMAInfoLTENeighborCell
- struct unpack_nas_SLQSNasGetCellLocationInfo_t
- struct nas_timeInfo
- struct unpack_nas_SLQSGetNetworkTime_t
- struct nas_UniversalTime
- struct unpack_nas_SLQSNasNetworkTimeCallBack_ind_t
- struct nas_PhyCaAggScellIndType
- struct nas_PhyCaAggScellDlBw
- struct nas_PhyCaAggScellInfo
- struct nas_PhyCaAggPcellInfo
- struct nas_PhyCaAggScellIndex
- struct unpack_nas_SetNasLTECphyCaIndCallback_ind_t
- struct nas_RxSigInfo
- struct nas_SccRxInfo
- struct unpack_nas_SLQSSwiGetLteSccRxInfo_t
- struct unpack_nas_SLQSNasTimerCallback_ind_t
- struct pack_nas_InitiateDomainAttach_t
- struct pack_nas_SetCDMANetworkParameters_t
- struct unpack_nas_SLQSNasGetHDRColorCode_t
- struct pack_nas_SLQSNasGetTxRxInfo_t
- struct nas_rxInfo
- struct nas_txInfo
- struct unpack_nas_SLQSNasGetTxRxInfo_t
- struct nas_OperatorPLMNData
- struct nas_operatorPLMNList
- struct nas_serviceProviderName
- struct nas_PLMNNetworkNameData
- struct nas_PLMNNetworkName
- struct nas_operatorNameString
- struct unpack_nas_SLQSGetOperatorNameData_t
- struct pack_nas_SLQSNasGet3GPP2Subscription_t
- struct nas_namName
- struct nas_dirNum
- struct nas_sidNid
- struct nas_homeSIDNID
- struct nas_minBasedIMSI
- struct nas_trueIMSI
- struct nas_CDMAChannel
- struct unpack_nas_SLQSNasGet3GPP2Subscription_t
- struct nas_protocolSubtypeElement
- struct unpack_nas_SLQSSwiGetHDRPersonality_t
- struct unpack_nas_SLQSSwiGetHDRProtSubtype_t
- struct pack_nas_SLQSSwiPSDetach_t
- struct unpack_nas_SLQSGetErrorRate_t
- struct nas_DRCParams
- struct nas_PilotSetParams
- struct nas_PilotSetData
- struct unpack_nas_SLQSSwiGetHRPDStats_t
- struct nas_ActPilotPNElement
- struct nas_NetworkStat1x
- struct nas_NetworkStatEVDO
- struct nas_DeviceConfigDetail
- struct nas_DataStatusDetail
- struct unpack_nas_SLQSSwiNetworkDebug_t
- struct nas_RSSIThresh

- struct nas_ECIOThresh
- struct nas_HDRSINRThresh
- struct nas_LTESNRThresh
- struct nas_IOThresh
- struct nas_RSRQThresh
- struct nas_RSRPThresh
- struct nas_LTESigRptCfg
- struct nas_TDSCDMASINRCONFThresh
- struct pack_nas_SLQSConfigSigInfo_t
- struct unpack_nas_GetHomeNetwork3GPP2_t
- struct nas_wcdmaUARFCN
- struct nas_lteEARFCN
- struct nas_ltePCI
- struct pack_nas_SLQSNASSwiSetChannelLock_t
- struct unpack_nas_SLQSNASSwiGetChannelLock_t
- struct unpack_nas_SLQSNASGeteDRXParams_t
- struct pack_nas_SLQSNASGeteDRXParamsExt_t
- struct unpack_nas_SLQSNASGeteDRXParamsExt_t
- struct pack_nas_SLQSNASSeteDRXParams_t
- struct nas_HDRPersonality_Ind_Data
- struct unpack_nas_SLQSSwiHDRPersonalityCallback_Ind_t
- struct nas_RankIndicatorTlv
- struct unpack_nas_SLQSSwiRandIndicatorCallback_Ind_t
- struct nas_RFBandInfoElements
- struct nas_RfDedicatedBandInfoElements
- struct nas_RfBandInfoExtFormatElements
- struct nas_RfBandwidthInfoElements
- struct nas_RfBandInfoList
- struct nas_RfDedicatedBandInfo
- struct nas_RfBandInfoExtFormat
- struct nas_RfBandwidthInfo
- struct nas_LTEOperationMode
- struct unpack_nas_SLQSNasGetRFInfo_t
- struct nas_EmerModeTlv
- struct nas_ModePrefTlv
- struct nas_BandPrefTlv
- struct nas_PRLPrefTlv
- struct nas_RoamPrefTlv
- struct nas_LTEBandPrefTlv
- struct nas_NetSelPrefTlv
- struct nas_SrvDomainPrefTlv
- struct nas_GWAcqOrderPrefTlv
- struct nas_AcqOrderPrefTlv
- struct nas_RatDisabledMaskTlv
- struct nas_CiotLteOpModePrefTlv
- struct nas_LteM1BandPrefTlv
- struct nas_LteNb1BandPrefTlv
- struct nas_CiotAcqOrderPrefTlv
- struct nas_BandPrefInfoTlv
- struct unpack_nas_SLQSGetSysSelectionPrefExt_t
- struct pack_nas_PerformNetworkScanPCI_t
- struct nas_EdrxEnableType
- struct nas_EdrxCycleLength
- struct nas_EdrxPagingTimeWindow
- struct nas_EdrxRatType

- struct nas_EdrxCiotLteMode
- struct unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t
- struct nas_CsgId
- struct nas_PlmnID
- struct nas_LteOpMode
- struct unpack_nas_SLQSNasNetworkRejectCallback_Ind_t
- struct nas_ForbiddenNetworks3GPP
- struct unpack_nas_SLQSNASGetForbiddenNetworks_t

Macros

- #define NAS_OTA_MESSAGE_MAX_BUF_SIZE 2048
- #define NAS_MAX_NUM_NETWORKS 30
- #define NAS_MAX_DESCRIPTION_LENGTH 255
- #define NAS_PLMN_LENGTH 3
- #define NAS_MAX_SCC_RX_INFO_INSTANCES 255
- #define NAS_NAM_NAME_LENGTH 12
- #define NAS_IMSI_M_S1_LENGTH 7
- #define NAS_IMSI_M_S2_LENGTH 3
- #define NAS_SERVING_SYSTEM_INFO_MAX_RADIO_INTERFACE_LIST 255
- #define NAS_MAX_SLQS_NAS_PCI_INFO_PLMN_LENGTH 255
- #define NAS_MAX_SLQS_NAS_PCI_INFO_LENGTH 255
- #define NAS_MCC_MNC_INST_LENGTH 255

Typedefs

- typedef unpack_result_t unpack_nas_SLQSSetSysSelectionPref_t
- typedef unpack_result_t unpack_nas_SLQSSetSysSelectionPrefExt_t
- typedef unpack_result_t unpack_nas_SLQSSetBandPreference_t
- typedef unpack_result_t unpack_nas_SLQSNasIndicationRegisterExt_t
- typedef unpack_result_t unpack_nas_SLQSSetSignalStrengthsCallback_t
- typedef unpack_result_t unpack_nas_SetRFInfoCallback_t
- typedef unpack_result_t unpack_nas_SetLURejectCallback_t
- typedef unpack_result_t unpack_nas_SetACCOLC_t
- typedef unpack_result_t unpack_nas_SLQSNasConfigSigInfo2_t
- typedef unpack_result_t unpack_nas_SLQSInitiateNetworkRegistration_t
- typedef unpack_result_t unpack_nas_SLQSNasSwiIndicationRegister_t
- typedef unpack_result_t unpack_nas_InitiateDomainAttach_t
- typedef unpack_result_t unpack_nas_SetCDMANetworkParameters_t
- typedef unpack_result_t unpack_nas_SLQSSwiPSDetach_t
- typedef unpack_result_t unpack_nas_SLQSConfigSigInfo_t
- typedef unpack_result_t unpack_nas_SLQSNASSwiSetChannelLock_t
- typedef unpack_result_t unpack_nas_SLQSNASSeteDRXParams_t
- typedef nas_BandPrefInfoTlv nas_NR5gBandPrefTlv
- typedef nas_BandPrefInfoTlv nas_LTEBandPrefExtTlv

Enumerations

- enum LITEQMI_NAS_LTE_CPHY_SCELL_STATE {
  eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_DECONFIGURED =0x00,
  eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED =0x01,
  eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED =0x02 }
- enum LITEQMI_NAS_LTE_CPHY_CA_BW_NRB {
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_6 =0x00,
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_15 =0x01,
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_25 =0x02,
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_50 =0x03,
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_75 =0x04,
  eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_100 =0x05 }
- enum NAS_LTE_CPHY_CA_BW_NRB_LITE {
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_6 =0x00,
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_15 =0x01,
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_25 =0x02,
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_50 =0x03,
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_75 =0x04,
  eNAS_LTE_CPHY_CA_BW_NRB_LITE_100 =0x05 }
- enum NAS_LTE_CPHY_SCELL_STATE_LITE {
  eNAS_LTE_CPHY_SCELL_STATE_DECONFIGURED_LITE =0x00,
  eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED_LITE =0x01,
  eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED_LITE =0x02 }
- enum LITE_TYPE_OF_SERVICE_DOMAIN {
  LITE_SYS_SRV_DOMAIN_NO_SRV = 0x00,
  LITE_SYS_SRV_DOMAIN_CS_ONLY = 0x01,
  LITE_SYS_SRV_DOMAIN_PS_ONLY = 0x02,
  LITE_SYS_SRV_DOMAIN_CS_PS = 0x03,
  LITE_SYS_SRV_DOMAIN_CAMPED = 0x04 }

Functions

- int unpack_nas_GetSignalStrengths (uint8_t *pResp, uint16_t respLen, unpack_nas_GetSignalStrengths_t *pOutput)
- int pack_nas_GetSignalStrengths (pack_qmi_t *pCtx, uint8_t *pReq, uint16_t *pLen)
- int pack_nas_SLQSGetSysSelectionPref (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetSysSelectionPref (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetSysSelectionPref_t *pOutput)
- int pack_nas_SLQSSetSysSelectionPref (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSSetSysSelectionPref_t *pReqParam)
- int unpack_nas_SLQSSetSysSelectionPref (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSetSysSelectionPref_t *pOutput)
- int pack_nas_SLQSSetSysSelectionPrefExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSSetSysSelectionPrefExt_t *pReqParam)
- int unpack_nas_SLQSSetSysSelectionPrefExt (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSetSysSelectionPrefExt_t *pOutput)
- int pack_nas_SLQSSetBandPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSSetBandPreference_t *pReqParam)
- int unpack_nas_SLQSSetBandPreference (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSetBandPreference_t *pOutput)
- int pack_nas_SLQSNasIndicationRegisterExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNasIndicationRegisterExt_t *pReqParam)
- int unpack_nas_SLQSNasIndicationRegisterExt (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasIndicationRegisterExt_t *pOutput)
- int pack_nas_GetRFInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)

- int unpack_nas_GetRFInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_GetRFInfo_t *pOutput)
- int pack_nas_SLQSNasGetSigInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNasGetSigInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasGetSigInfo_t *pOutput)
- int unpack_valid_nas_SLQSNasGetSigInfo (uint8_t *pResp, uint8_t u8Info)
- int unpack_nas_SLQSNasSigInfoCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasSigInfoCallback_ind_t *pOutput)
- int unpack_nas_GetHomeNetwork (uint8_t *pResp, uint16_t respLen, unpack_nas_GetHomeNetwork_t *pOutput)
- int pack_nas_GetHomeNetwork (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int pack_nas_SLQSGetSysInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetSysInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetSysInfo_t *pOutput)
- int unpack_nas_SLQSNasSysInfoCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSysInfoCallback_ind_t *pOutput)
- int pack_nas_GetServingNetwork (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetServingNetwork (uint8_t *pResp, uint16_t respLen, unpack_nas_GetServingNetwork_t *pOutput)
- int pack_nas_GetServingNetworkCapabilities (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetServingNetworkCapabilities (uint8_t *pResp, uint16_t respLen, unpack_nas_GetServingNetworkCapabilities_t *pOutput)
- int pack_nas_PerformNetworkScan (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_PerformNetworkScan (uint8_t *pResp, uint16_t respLen, unpack_nas_PerformNetworkScan_t *pOutput)
- int pack_nas_SLQSSwiGetLteCQI (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSSwiGetLteCQI (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiGetLteCQI_t *pOutput)
- int pack_nas_SLQSNasSwiModemStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNasSwiModemStatus (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasSwiModemStatus_t *pOutput)
- int pack_nas_SLQSGetServingSystem (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetServingSystem (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetServingSystem_t *pOutput)
- int unpack_valid_nas_SLQSGetServingSystem (uint8_t *pResp, uint8_t u8Info)
- int pack_nas_SLQSGetSignalStrength (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, uint16_t reqMask)
- int unpack_nas_SLQSGetSignalStrength (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetSignalStrength_t *pOutput)
- int unpack_valid_nas_SLQSGetSignalStrength (uint8_t *pResp, uint8_t u8Info)
- int pack_nas_SLQSSetSignalStrengthsCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSSetSignalStrengthsCallback_t *pReqParam)
- int unpack_nas_SLQSSetSignalStrengthsCallback (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSetSignalStrengthsCallback_t *pOutput)
- int pack_nas_SetRFInfoCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, uint8_t *pBenable)
- int unpack_nas_SetRFInfoCallback (uint8_t *pResp, uint16_t respLen, unpack_nas_SetRFInfoCallback_t *pOutput)
- int pack_nas_SetLURejectCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, uint8_t *pBenable)
- int unpack_nas_SetLURejectCallback (uint8_t *pResp, uint16_t respLen, unpack_nas_SetLURejectCallback_t *pOutput)
- int unpack_nas_SetEventReportInd (uint8_t *pResp, uint16_t respLen, unpack_nas_SetEventReportInd_t *pOutput)
- int pack_nas_GetCDMANetworkParameters (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetCDMANetworkParameters (uint8_t *pResp, uint16_t respLen, unpack_nas_GetCDMANetworkParameters_t *pOutput)
- int unpack_valid_nas_GetCDMANetworkParameters (uint8_t *pResp, uint8_t u8Info)

- int pack_nas_GetANAAAAuthenticationStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetANAAAAuthenticationStatus (uint8_t *pResp, uint16_t respLen, unpack_nas_GetANAAAAuthenticationStatus_t *pOutput)
- int pack_nas_GetACCOLC (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetACCOLC (uint8_t *pResp, uint16_t respLen, unpack_nas_GetACCOLC_t *pOutput)
- int pack_nas_SetACCOLC (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SetACCOLC_t reqParam)
- int unpack_nas_SetACCOLC (uint8_t *pResp, uint16_t respLen, unpack_nas_SetACCOLC_t *pOutput)
- int pack_nas_SLQSNasConfigSigInfo2 (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNasConfigSigInfo2_t *pReqParam)
- int unpack_nas_SLQSNasConfigSigInfo2 (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasConfigSigInfo2_t *pOutput)
- int unpack_nas_SetDataCapabilitiesCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SetDataCapabilitiesCallback_ind_t *pOutput)
- int pack_nas_GetNetworkPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetNetworkPreference (uint8_t *pResp, uint16_t respLen, unpack_nas_GetNetworkPreference_t *pOutput)
- int pack_nas_SetNetworkPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SetNetworkPreference_t *reqArg)
- int unpack_nas_SetNetworkPreference (uint8_t *pResp, uint16_t respLen, unpack_nas_SetNetworkPreference_t *pOutput)
- int unpack_nas_SetRoamingIndicatorCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SetRoamingIndicatorCallback_ind_t *pOutput)
- int unpack_nas_SetServingSystemCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SetServingSystemCallback_ind_t *pOutput)
- int pack_nas_SlqsGetLTECphyCAInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SlqsGetLTECphyCAInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SlqsGetLTECphyCAInfo_t *pOutput)
- int unpack_nas_SLQSSetSysSelectionPrefCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t *pOutput)
- int unpack_nas_SLQSNasSwiOTAMessageCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t *pOutput)
- int pack_nas_SLQSInitiateNetworkRegistration (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSInitiateNetworkRegistration_t *pReqParam)
- int unpack_nas_SLQSInitiateNetworkRegistration (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSInitiateNetworkRegistration_t *pOutput)
- int pack_nas_SLQSNasSwiIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNasSwiIndicationRegister_t *pReqParam)
- int unpack_nas_SLQSNasSwiIndicationRegister (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasSwiIndicationRegister_t *pOutput)
- int pack_nas_SLQSGetPLMNName (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSGetPLMNName_t *reqArg)
- int unpack_nas_SLQSGetPLMNName (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetPLMNName_t *pOutput)
- int pack_nas_SLQSNasGetCellLocationInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNasGetCellLocationInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasGetCellLocationInfo_t *pOutput)
- int pack_nas_SLQSGetNetworkTime (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetNetworkTime (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetNetworkTime_t *pOutput)
- int unpack_nas_SLQSNasNetworkTimeCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasNetworkTimeCallBack_ind_t *pOutput)
- int unpack_nas_SetNasLTECphyCaIndCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SetNasLTECphyCaIndCallback_ind_t *pOutput)
- int pack_nas_SLQSSwiGetLteSccRxInfo (pack_qmi_t *pCtx, uint8_t *pReq, uint16_t *pLen)

- int unpack_nas_SLQSSwiGetLteSccRxInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiGetLteSccRxInfo_t *pOutput)
- int unpack_nas_SLQSNasTimerCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasTimerCallback_ind_t *pOutput)
- int pack_nas_InitiateDomainAttach (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_InitiateDomainAttach_t *pReqParam)
- int unpack_nas_InitiateDomainAttach (uint8_t *pResp, uint16_t respLen, unpack_nas_InitiateDomainAttach_t *pOutput)
- int pack_nas_SetCDMANetworkParameters (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SetCDMANetworkParameters_t *pReqParam)
- int unpack_nas_SetCDMANetworkParameters (uint8_t *pResp, uint16_t respLen, unpack_nas_SetCDMANetworkParameters_t *pOutput)
- int pack_nas_SLQSNasGetHDRColorCode (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNasGetHDRColorCode (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasGetHDRColorCode_t *pOutput)
- int pack_nas_SLQSNasGetTxRxInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNasGetTxRxInfo_t *reqArg)
- int unpack_nas_SLQSNasGetTxRxInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasGetTxRxInfo_t *pOutput)
- int pack_nas_SLQSGetOperatorNameData (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetOperatorNameData (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetOperatorNameData_t *pOutput)
- int pack_nas_SLQSNasGet3GPP2Subscription (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNasGet3GPP2Subscription_t *reqArg)
- int unpack_nas_SLQSNasGet3GPP2Subscription (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasGet3GPP2Subscription_t *pOutput)
- int pack_nas_SLQSSwiGetHDRPersonality (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSSwiGetHDRPersonality (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiGetHDRPersonality_t *pOutput)
- int pack_nas_SLQSSwiGetHDRProtSubtype (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSSwiGetHDRProtSubtype (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiGetHDRProtSubtype_t *pOutput)
- int pack_nas_SLQSSwiPSDetach (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSSwiPSDetach_t *pReqParam)
- int unpack_nas_SLQSSwiPSDetach (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiPSDetach_t *pOutput)
- int pack_nas_SLQSGetErrorRate (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetErrorRate (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGetErrorRate_t *pOutput)
- int pack_nas_SLQSSwiGetHRPDStats (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSSwiGetHRPDStats (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiGetHRPDStats_t *pOutput)
- int pack_nas_SLQSSwiNetworkDebug (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSSwiNetworkDebug (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSSwiNetworkDebug_t *pOutput)
- int pack_nas_SLQSConfigSigInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSConfigSigInfo_t *pReqParam)
- int unpack_nas_SLQSConfigSigInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSConfigSigInfo_t *pOutput)
- int pack_nas_GetHomeNetwork3GPP2 (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_GetHomeNetwork3GPP2 (uint8_t *pResp, uint16_t respLen, unpack_nas_GetHomeNetwork3GPP2_t *pOutput)
- int pack_nas_SLQSNASSwiSetChannelLock (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_SLQSNASSwiSetChannelLock_t *pReqParam)
- int unpack_nas_SLQSNASSwiSetChannelLock (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNASSwiSetChannelLock_t *pOutput)

- int pack_nas_SLQSNASSwiGetChannelLock (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNASSwiGetChannelLock (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNAS-SwiGetChannelLock_t *pOutput)
- int pack_nas_SLQSNASGeteDRXParams (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNASGeteDRXParams (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNAS-GeteDRXParams_t *pOutput)
- int pack_nas_SLQSNASGeteDRXParamsExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_-nas_SLQSNASGeteDRXParamsExt_t *pReqParam)
- int unpack_nas_SLQSNASGeteDRXParamsExt (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNAS-GeteDRXParamsExt_t *pOutput)
- int pack_nas_SLQSNASSeteDRXParams (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas-_SLQSNASSeteDRXParams_t *pReqParam)
- int unpack_nas_SLQSNASSeteDRXParams (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNAS-SeteDRXParams_t *pOutput)
- int unpack_nas_SLQSSwiHDRPersonalityCallback_Ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SL-QSSwiHDRPersonalityCallback_Ind_t *pOutput)
- int unpack_nas_SLQSSwiRandIndicatorCallback_Ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQ-SSwiRandIndicatorCallback_Ind_t *pOutput)
- int pack_nas_SLQSNasGetRFInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNasGetRFInfo (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSNasGetRFInfo_t *pOutput)
- int pack_nas_SLQSGetSysSelectionPrefExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSGetSysSelectionPrefExt (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSGet-SysSelectionPrefExt_t *pOutput)
- int pack_nas_PerformNetworkScanPCI (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_nas_-PerformNetworkScanPCI_t *pReqParam)
- int unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind (uint8_t *pResp, uint16_t respLen, unpack_nas_S-LQSNasEdrxChangeInfoCallBack_Ind_t *pOutput)
- int unpack_nas_SLQSNasNetworkRejectCallback_Ind (uint8_t *pResp, uint16_t respLen, unpack_nas_SL-QSNasNetworkRejectCallback_Ind_t *pOutput)
- int pack_nas_SLQSNASGetForbiddenNetworks (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_nas_SLQSNASGetForbiddenNetworks (uint8_t *pResp, uint16_t respLen, unpack_nas_SLQSN-ASGetForbiddenNetworks_t *pOutput)

9.11.1 Macro Definition Documentation

9.11.1.1 #define NAS_IMSI_M_S1_LENGTH 7

9.11.1.2 #define NAS_IMSI_M_S2_LENGTH 3

9.11.1.3 #define NAS_MAX_DESCRIPTION_LENGTH 255

9.11.1.4 #define NAS_MAX_NUM_NETWORKS 30

9.11.1.5 #define NAS_MAX_SCC_RX_INFO_INSTANCES 255

9.11.1.6 #define NAS_MAX_SLQS_NAS_PCI_INFO_LENGTH 255

9.11.1.7 #define NAS_MAX_SLQS_NAS_PCI_INFO_PLMN_LENGTH 255

9.11.1.8 #define NAS_MCC_MNC_INST_LENGTH 255

9.11.1.9 #define NAS_NAM_NAME_LENGTH 12

9.11.1.10 #define NAS_OTA_MESSAGE_MAX_BUF_SIZE 2048

9.11.1.11 #define NAS_PLMN_LENGTH 3

9.11.1.12 #define NAS_SERVING_SYSTEM_INFO_MAX_RADIO_INTERFACE_LIST 255

9.11.2 Typedef Documentation

9.11.2.1 typedef nas_BandPrefInfoTlv nas_LTEBandPrefExtTlv

Contain the LTE Band Preference Extended.

- See nas_BandPrefInfoTlv for more information.

9.11.2.2 typedef nas_BandPrefInfoTlv nas_NR5gBandPrefTlv

Contain the NR5G Band Preference.

- See nas_BandPrefInfoTlv for more information.

9.11.2.3 typedef unpack_result_t unpack_nas_InitiateDomainAttach_t

9.11.2.4 typedef unpack_result_t unpack_nas_SetACCOLC_t

9.11.2.5 typedef unpack_result_t unpack_nas_SetCDMANetworkParameters_t

9.11.2.6 typedef unpack_result_t unpack_nas_SetLURejectCallback_t

9.11.2.7 typedef unpack_result_t unpack_nas_SetRFInfoCallback_t

9.11.2.8 typedef unpack_result_t unpack_nas_SLQSConfigSigInfo_t

9.11.2.9 typedef unpack_result_t unpack_nas_SLQSInitiateNetworkRegistration_t

9.11.2.10 typedef unpack_result_t unpack_nas_SLQSNasConfigSigInfo2_t

9.11.2.11 typedef unpack_result_t unpack_nas_SLQSNasIndicationRegisterExt_t

9.11.2.12 typedef unpack_result_t unpack_nas_SLQSNASSeteDRXParams_t

9.11.2.13 typedef unpack_result_t unpack_nas_SLQSNasSwiIndicationRegister_t

9.11.2.14 typedef unpack_result_t unpack_nas_SLQSNASSwiSetChannelLock_t

9.11.2.15 typedef unpack_result_t unpack_nas_SLQSSetBandPreference_t

9.11.2.16 typedef unpack_result_t unpack_nas_SLQSSetSignalStrengthsCallback_t

9.11.2.17 typedef unpack_result_t unpack_nas_SLQSSetSysSelectionPref_t

9.11.2.18 typedef unpack_result_t unpack_nas_SLQSSetSysSelectionPrefExt_t

9.11.2.19 typedef unpack_result_t unpack_nas_SLQSSwiPSDetach_t

9.11.3 Enumeration Type Documentation

9.11.3.1 enum LITE_TYPE_OF_SERVICE_DOMAIN

Enumerator

LITE_SYS_SRV_DOMAIN_NO_SRV

LITE_SYS_SRV_DOMAIN_CS_ONLY

LITE_SYS_SRV_DOMAIN_PS_ONLY

LITE_SYS_SRV_DOMAIN_CS_PS

LITE_SYS_SRV_DOMAIN_CAMPED

9.11.3.2 enum LITEQMI_NAS_LTE_CPHY_CA_BW_NRB

Enumerator

eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_6

eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_15

eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_25

eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_50

eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_75

eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_100

9.11.3.3 enum LITEQMI_NAS_LTE_CPHY_SCELL_STATE

Enumerator

eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_DECONFIGURED

eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED

eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED

9.11.3.4 enum NAS_LTE_CPHY_CA_BW_NRB_LITE

Enumerator

eNAS_LTE_CPHY_CA_BW_NRB_LITE_6

eNAS_LTE_CPHY_CA_BW_NRB_LITE_15

eNAS_LTE_CPHY_CA_BW_NRB_LITE_25

eNAS_LTE_CPHY_CA_BW_NRB_LITE_50

eNAS_LTE_CPHY_CA_BW_NRB_LITE_75

eNAS_LTE_CPHY_CA_BW_NRB_LITE_100

9.11.3.5 enum NAS_LTE_CPHY_SCELL_STATE_LITE

Enumerator

eNAS_LTE_CPHY_SCELL_STATE_DECONFIGURED_LITE

eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED_LITE

eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED_LITE

9.11.4 Function Documentation

9.11.4.1 int pack_nas_GetACCOLC (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Retrieves information about the access overload class (ACCOLC) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.2 int pack_nas_GetANAAAAuthenticationStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

AN-AAA authentication status of the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.3 int pack_nas_GetCDMANetworkParameters (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get CDMA Network Parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.4 int pack_nas_GetHomeNetwork (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

get home network pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.5 int pack_nas_GetHomeNetwork3GPP2 (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Get Home Network 3GPP2 Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.6 int pack_nas_GetNetworkPreference (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Gets the network registration preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

9.11.4.7 int pack_nas_GetRFInfo (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

get rf info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.8 int pack_nas_GetServingNetwork (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack provides information about the system that provides service to the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.9 int pack_nas_GetServingNetworkCapabilities (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack returns information regarding the data capabilities of the system that currently provides service to the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.10 int pack_nas_GetSignalStrengths (pack_qmi_t * *pCtx*, uint8_t * *pReq*, uint16_t * *pLen*)

get signal strengths pack. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15-C_05_xx_xx_xx and all EM74xx firmware versions. Please use pack_nas_SLQSNasGetSigInfo() for new firmware versions and new modules

Parameters

in,out	*pCtx*	qmi request context
out	*pReq*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.11 int pack_nas_InitiateDomainAttach (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_InitiateDomainAttach_t * *pReqParam*)

Initiates a domain attach/detach of the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.12 int pack_nas_PerformNetworkScan (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack performs scan for available networks and scans for RAT info as well.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.13 int pack_nas_PerformNetworkScanPCI (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_PerformNetworkScanPCI_t * *pReqParam*)

Pack performs scan for available networks and scans for LTE RAT info (specific Network or Scan Type).

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Device Supported: MC75xx, EM75xx and WP76xx.

9.11.4.14 int pack_nas_SetACCOLC (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SetACCOLC_t *reqParam*)

Pack Sets the access overload class (ACCOLC)

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.15 int pack_nas_SetCDMANetworkParameters (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SetCDMANetworkParameters_t * *pReqParam*)

CDMA Network Parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.16 int pack_nas_SetLURejectCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, uint8_t * *pBenable*)

Pack set registration reject Callback

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pBenable*	0/1 value to disable/enable indication respectively

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.17 int pack_nas_SetNetworkPreference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SetNetworkPreference_t * *reqArg*)

Sets the network registration preference. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use pack_nas_SLQSSetSysSelection-Pref() for new firmware versions and new modules

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

9.11.4.18 int pack_nas_SetRFInfoCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, uint8_t * *pBenable*)

Pack Set RF Band Information callback.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pBenable*	0/1 value to disable/enable indication respectively

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.19 int pack_nas_SLQSConfigSigInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSConfigSigInfo_t * *pReqParam*)

Config Sig Info Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.20 int pack_nas_SLQSGetErrorRate (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get Error Rate Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.21 int pack_nas_SlqsGetLTECphyCAInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack get carrier aggregation event information.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

9.11.4.22 int pack_nas_SLQSGetNetworkTime (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack Get Network Time.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.23 int pack_nas_SLQSGetOperatorNameData (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Operator Name Data Parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.24 int pack_nas_SLQSGetPLMNName (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSGetPLMNName_t * *reqArg*)

Pack get operator name for specificed network.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.25 int pack_nas_SLQSGetServingSystem (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack queries information regarding the system that currently provides service.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.26 int pack_nas_SLQSGetSignalStrength (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, uint16_t *reqMask*)

Queries the current signal strength as measured by the device. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use pack_nas_SLQS-NasGetSigInfo() for new firmware versions and new modules

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqMask*	request mask for fetching extra signal info

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.27 int pack_nas_SLQSGetSysInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack get system information.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.28 int pack_nas_SLQSGetSysSelectionPref (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Queries the different system selection preferences of the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.29 int pack_nas_SLQSGetSysSelectionPrefExt (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Queries the different system selection preferences of the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.30 int pack_nas_SLQSInitiateNetworkRegistration (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_nas_SLQSInitiateNetworkRegistration_t * pReqParam)

Pack initiates a network registration.This API is deprecated on MC73xx/EM73xx modules since firmware version S-WI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use pack_nas_SLQSSetSysSelectionPrefExt() instead for new firmware versions and new modules.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.31 int pack_nas_SLQSNasConfigSigInfo2 (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSNasConfigSigInfo2_t * *pReqParam*)

Pack sets the signal strength reporting thresholds

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.32 int pack_nas_SLQSNasGet3GPP2Subscription (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSNasGet3GPP2Subscription_t * *reqArg*)

3GPP2 Subscription Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.33 int pack_nas_SLQSNasGetCellLocationInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack retrieves cell location-related information.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.34 int pack_nas_SLQSNASGeteDRXParams (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get eDRX Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.35 int pack_nas_SLQSNASGeteDRXParamsExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSNASGeteDRXParamsExt_t * *pReqParam*)

Get eDRX Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.36 int pack_nas_SLQSNASGetForbiddenNetworks (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get forbidden networks pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.37 int pack_nas_SLQSNasGetHDRColorCode (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

HDR Color Code Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.38 int pack_nas_SLQSNasGetRFInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets radio band/channel information pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.39 int pack_nas_SLQSNasGetSigInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get sig info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.40 int pack_nas_SLQSNasGetTxRxInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSNasGetTxRxInfo_t * *reqArg*)

Get Tx Rx Info Parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.41 int pack_nas_SLQSNasIndicationRegisterExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSNasIndicationRegisterExt_t * *pReqParam*)

Pack used to Registers/De-registers for different NAS (Network access service) indications.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

This function is used by a control point to register/deregister for different QMI_NAS indications. The control point's registration state variables, controlling registration for indications, are modified to reflect the settings indicated in the parameters that are present in the request message. At least one optional parameter must be present in the request.

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.42 int pack_nas_SLQSNASSeteDRXParams (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_nas_SLQSNASSeteDRXParams_t * pReqParam)

Set eDRX Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.43 int pack_nas_SLQSNASSwiGetChannelLock (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Get Channel Lock Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.44 int pack_nas_SLQSNasSwiIndicationRegister (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_nas_SLQSNasSwiIndicationRegister_t * pReqParam)

Pack sets the registration state for different QMI_NAS SWI indications.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.45 int pack_nas_SLQSNasSwiModemStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

This function requests the device to return the current status of modem.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.46 int pack_nas_SLQSNASSwiSetChannelLock (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSNASSwiSetChannelLock_t * *pReqParam*)

Set Channel Lock Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.47 int pack_nas_SLQSSetBandPreference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSSetBandPreference_t * *pReqParam*)

Pack sets the different system selection preferences of the device.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.48 int pack_nas_SLQSSetSignalStrengthsCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSSetSignalStrengthsCallback_t * *pReqParam*)

Pack set signal strength thresholds callback.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request prarmeters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.49 int pack_nas_SLQSSetSysSelectionPref (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSSetSysSelectionPref_t * *pReqParam*)

Sets the different system selection preferences of the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.50 int pack_nas_SLQSSetSysSelectionPrefExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSSetSysSelectionPrefExt_t * *pReqParam*)

Sets the different system selection preferences of the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.51 int pack_nas_SLQSSwiGetHDRPersonality (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

HDR Personality Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.52 int pack_nas_SLQSSwiGetHDRProtSubtype (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

HDR Protocol Sub type Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.53 int pack_nas_SLQSSwiGetHRPDStats (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

HRPD Stats Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.54 int pack_nas_SLQSSwiGetLteCQI (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack fetch CQI parameters for LTE data session.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.55 int pack_nas_SLQSSwiGetLteSccRxInfo (pack_qmi_t * *pCtx*, uint8_t * *pReq*, uint16_t * *pLen*)

get LTE Secondary carrier Rx signal level information pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReq*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.56 int pack_nas_SLQSSwiNetworkDebug (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Network Debug Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.57 int pack_nas_SLQSSwiPSDetach (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_nas_SLQSSwiPSDetach_t * *pReqParam*)

PS Connection Detach Parameters pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request Parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.58 int unpack_nas_GetACCOLC (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetACCOLC_t * *pOutput*)

Retrieves information about the access overload class (ACCOLC) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.59 int unpack_nas_GetANAAAAuthenticationStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetANAAAAuthenticationStatus_t * *pOutput*)

AN-AAA authentication status of the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.60 int unpack_nas_GetCDMANetworkParameters (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetCDMANetworkParameters_t * *pOutput*)

Get CDMA Network Parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	qmi output parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.61 int unpack_nas_GetHomeNetwork (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetHomeNetwork_t * *pOutput*)

Retrieves information about the home network of the device unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.62 int unpack_nas_GetHomeNetwork3GPP2 (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetHomeNetwork3GPP2_t * *pOutput*)

Get Home Network 3GPP2 Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.63 int unpack_nas_GetNetworkPreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetNetwork-Preference_t * *pOutput*)

Gets the network registration preference unpack

Parameters

in	*pResp*	qmi resp from modem
in	*respLen*	qmi resp length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.64 int unpack_nas_GetRFInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetRFInfo_t * *pOutput*)

get rf info unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.65 int unpack_nas_GetServingNetwork (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetServingNetwork_t * *pOutput*)

Unpack provides information about the system that provides service to the device. This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use API unpack_nas_SLQSGetSysInfo() for new firmware versions and new modules

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.66 int unpack_nas_GetServingNetworkCapabilities (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetServingNetworkCapabilities_t * *pOutput*)

Unpack returns information regarding the data capabilities of the system that currently provides service to the device.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.67 int unpack_nas_GetSignalStrengths (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_GetSignalStrengths_t * *pOutput*)

Returns the available signal strengths (in dBm) as measured by the device in an array. This will also provides the corresponding radio interfaces in an array. This API is deprecated on MC73xx/EM73xx modules since firmware

version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use unpack_nas_SLQSNasGetSigInfo() for new firmware versions and new modules

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.68 int unpack_nas_InitiateDomainAttach (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_InitiateDomainAttach_t * *pOutput*)

Initiates a domain attach/detach of the device unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.69 int unpack_nas_PerformNetworkScan (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_PerformNetworkScan_t * *pOutput*)

Unpack performs scan for available networks and scans for RAT info as well.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.70 int unpack_nas_SetACCOLC (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetACCOLC_t * *pOutput*)

Unpack Sets the access overload class (ACCOLC)

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.71 int unpack_nas_SetCDMANetworkParameters (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetCDMANetworkParameters_t * *pOutput*)

CDMA Network Parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.72 int unpack_nas_SetDataCapabilitiesCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetDataCapabilitiesCallback_ind_t * *pOutput*)

Data Capabilities indication unpack

Parameters

in	*pResp*	qmi indication from modem
in	*respLen*	qmi indication length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.73 int unpack_nas_SetEventReportInd (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetEventReportInd_t * *pOutput*)

Unpack set event report indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.74 int unpack_nas_SetLURejectCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetLURejectCallback_t * *pOutput*)

Unpack set registration reject Callback

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.75 int unpack_nas_SetNasLTECphyCaIndCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetNasLTECphyCaIndCallback_ind_t * *pOutput*)

Unpack set LTE PHY CA indication callback.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	sig info indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.76 int unpack_nas_SetNetworkPreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetNetwork-Preference_t * *pOutput*)

Sets the network registration preference unpack

Parameters

in	*pResp*	qmi resp from modem
in	*respLen*	qmi resp length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.77 int unpack_nas_SetRFInfoCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetRFInfoCallback_t * *pOutput*)

Unack Set RF Band Information callback.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.78 int unpack_nas_SetRoamingIndicatorCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetRoamingIndicatorCallback_ind_t * *pOutput*)

Roaming indication unpack

Parameters

in	*pResp*	qmi indication from modem
in	*respLen*	qmi indication length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.79 int unpack_nas_SetServingSystemCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SetServingSystemCallback_ind_t * *pOutput*)

Set Serving system indication unpack

Parameters

in	*pResp*	qmi indication from modem
in	*respLen*	qmi indication length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.80 int unpack_nas_SLQSConfigSigInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSConfigSigInfo_t * *pOutput*)

Config Sig Info Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.81 int unpack_nas_SLQSGetErrorRate (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetErrorRate_t * *pOutput*)

Get Error Rate Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.82 int unpack_nas_SlqsGetLTECphyCAInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SlqsGetLTECphyCAInfo_t * *pOutput*)

Unack get carrier aggregation event information.

Parameters

in	*pResp*	qmi resp from modem
in	*respLen*	qmi resp length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.83 int unpack_nas_SLQSGetNetworkTime (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetNetworkTime_t * *pOutput*)

Unpack get network time.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.84 int unpack_nas_SLQSGetOperatorNameData (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetOperatorNameData_t * *pOutput*)

Operator Name Data Parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.85 int unpack_nas_SLQSGetPLMNName (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetPLMNName_t * *pOutput*)

unpack get operator name for specificed network.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.86 int unpack_nas_SLQSGetServingSystem (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetServingSystem_t * *pOutput*)

Unack queries information regarding the system that currently provides service.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.87 int unpack_nas_SLQSGetSignalStrength (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetSignalStrength_t * *pOutput*)

Unpack get signal strength.This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use unpack_nas_SLQSNasGetSigInfo() for new firmware versions and new modules

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.88 int unpack_nas_SLQSGetSysInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetSysInfo_t * *pOutput*)

Provides the system information. This API is preferred when trying to get the service status info and serving system info. The function unpack_nas_SLQSGetServingSystem_t() reports similar NAS information, but it is deprecated. Please refer to the header description of unpack_nas_SLQSGetServingSystem_t() for more information.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

This API queries current serving system information, including registration information and system property. The registration information for all RATs specified in the mode capability setting are included regardless of registration status. The RAT-specific system property are included only for RATs that are specified in the mode capability setting and which are not in either No Service or Power Save modes.

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.89 int unpack_nas_SLQSGetSysSelectionPref (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetSysSelectionPref_t * *pOutput*)

Queries the different system selection preferences of the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.90 int unpack_nas_SLQSGetSysSelectionPrefExt (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSGetSysSelectionPrefExt_t * *pOutput*)

Queries the different system selection preferences of the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.91 int unpack_nas_SLQSInitiateNetworkRegistration (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSInitiateNetworkRegistration_t * *pOutput*)

Unpack initiates a network registration.This API is deprecated on MC73xx/EM73xx modules since firmware version SWI9X15C_05_xx_xx_xx and all EM74xx firmware versions. Please use unpack_nas_SLQSSetSysSelectionPrefExt() instead for new firmware versions and new modules.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.92 int unpack_nas_SLQSNasConfigSigInfo2 (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasConfigSigInfo2_t * *pOutput*)

Unpack sets the signal strength reporting thresholds

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.93 int unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t * *pOutput*)

unpack nas eDRX change Info indication

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.94 int unpack_nas_SLQSNasGet3GPP2Subscription (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasGet3GPP2Subscription_t * *pOutput*)

3GPP2 Subscription Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.95 int unpack_nas_SLQSNasGetCellLocationInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasGetCellLocationInfo_t * *pOutput*)

Unpack retrieves cell location-related information.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.96 int unpack_nas_SLQSNASGeteDRXParams (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNASGeteDRXParams_t * *pOutput*)

Get eDRX Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.97 int unpack_nas_SLQSNASGeteDRXParamsExt (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNASGeteDRXParamsExt_t * *pOutput*)

Get eDRX Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.98 int unpack_nas_SLQSNASGetForbiddenNetworks (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNASGetForbiddenNetworks_t * *pOutput*)

Get forbidden networks unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.99 int unpack_nas_SLQSNasGetHDRColorCode (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasGetHDRColorCode_t * *pOutput*)

HDR Color Code Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.100 int unpack_nas_SLQSNasGetRFInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasGetRFInfo_t * *pOutput*)

Gets radio band/channel information unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.101 int unpack_nas_SLQSNasGetSigInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasGetSigInfo_t * *pOutput*)

get sig info unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

This command queries the signal strength information for currently active RATs. Information is reported only if the corresponding RATs have signal strength values to be reported. If no signal strength information is available for any RAT, the response message contains only the mandatory response message

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.102 int unpack_nas_SLQSNasGetTxRxInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasGetTxRxInfo_t * *pOutput*)

Get Tx Rx Info Parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.103 int unpack_nas_SLQSNasIndicationRegisterExt (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasIndicationRegisterExt_t * *pOutput*)

Unpack used to Registers/De-registers for different NAS (Network access service) indications.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.104 int unpack_nas_SLQSNasNetworkRejectCallback_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasNetworkRejectCallback_Ind_t * *pOutput*)

unpack nas Network Reject Callback indication

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.105 int unpack_nas_SLQSNasNetworkTimeCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasNetworkTimeCallBack_ind_t * *pOutput*)

Unpack Network time callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	sig info indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.106 int unpack_nas_SLQSNASSeteDRXParams (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNASSeteDRXParams_t * *pOutput*)

Set eDRX Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.107 int unpack_nas_SLQSNasSigInfoCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasSigInfoCallback_ind_t * *pOutput*)

Unpack Signal Information callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	sig info indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.108 int unpack_nas_SLQSNASSwiGetChannelLock (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNASSwiGetChannelLock_t * *pOutput*)

Get Channel Lock Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.109 int unpack_nas_SLQSNasSwiIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasSwiIndicationRegister_t * *pOutput*)

unpack sets the registration state for different QMI_NAS SWI indications.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.110 int unpack_nas_SLQSNasSwiModemStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasSwiModemStatus_t * *pOutput*)

This function requests the device to return the current status of modem.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.111 int unpack_nas_SLQSNasSwiOTAMessageCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t * *pOutput*)

OTA message indication unpack

Parameters

in	*pResp*	qmi indication from modem
in	*respLen*	qmi indication length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.112 int unpack_nas_SLQSNASSwiSetChannelLock (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNASSwiSetChannelLock_t * *pOutput*)

Set Channel Lock Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.113 int unpack_nas_SLQSNasSysInfoCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSysInfoCallback_ind_t * *pOutput*)

Unpack system information callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.114 int unpack_nas_SLQSNasTimerCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSNasTimerCallback_ind_t * *pOutput*)

Unpack timer callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	network timer indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.115 int unpack_nas_SLQSSetBandPreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSetBandPreference_t * *pOutput*)

Unpack sets the different system selection preferences of the device.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

9.11.4.116 int unpack_nas_SLQSSetSignalStrengthsCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSetSignalStrengthsCallback_t * *pOutput*)

Unpack set signal strength thresholds callback.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.117 int unpack_nas_SLQSSetSysSelectionPref (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSetSysSelectionPref_t * *pOutput*)

Sets the different system selection preferences of the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.118 int unpack_nas_SLQSSetSysSelectionPrefCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t * *pOutput*)

System Selection Preference indication unpack

Parameters

in	*pResp*	qmi indication from modem
in	*respLen*	qmi indication length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.119 int unpack_nas_SLQSSetSysSelectionPrefExt (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSetSysSelectionPrefExt_t * *pOutput*)

Sets the different system selection preferences of the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.120 int unpack_nas_SLQSSwiGetHDRPersonality (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiGetHDRPersonality_t * *pOutput*)

HDR Personality Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.121 int unpack_nas_SLQSSwiGetHDRProtSubtype (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiGetHDRProtSubtype_t * *pOutput*)

HDR Protocol Sub type Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.122 int unpack_nas_SLQSSwiGetHRPDStats (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiGetHRPDStats_t * *pOutput*)

HRPD Stats Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.123 int unpack_nas_SLQSSwiGetLteCQI (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiGetLteCQI_t * *pOutput*)

Unack fetch CQI parameters for LTE data session.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.124 int unpack_nas_SLQSSwiGetLteSccRxInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiGetLteSccRxInfo_t * *pOutput*)

get LTE Secondary carrier Rx signal level information unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.125 int unpack_nas_SLQSSwiHDRPersonalityCallback_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiHDRPersonalityCallback_Ind_t * *pOutput*)

unpack nas SWI Hdr Personality indication

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.126 int unpack_nas_SLQSSwiNetworkDebug (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiNetworkDebug_t * *pOutput*)

Network Debug Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.127 int unpack_nas_SLQSSwiPSDetach (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiPSDetach_t * *pOutput*)

PS Connection Detach Parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.128 int unpack_nas_SLQSSwiRandIndicatorCallback_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_nas_SLQSSwiRandIndicatorCallback_Ind_t * *pOutput*)

unpack nas SWI Rank indicator indication

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.129 int unpack_valid_nas_GetCDMANetworkParameters (uint8_t * *pResp*, uint8_t *u8Info*)

valid CDMA Network Parameters

Parameters

in	*pResp*	qmi response from modem
in	*u8Info*	value to check unpack_nas_GetCDMANetworkParameters_t param valid. • 0 - SCI • 1 - SCM • 2 - RegHomeSID, RegForeignSID and RegForeignNID • 3 - ForceRev0 • 4 - CustomSCP, Protocol ,Broadcast and Application • 5 - Roaming

Returns

eQCWWAN_ERR_NONE on signal info valid, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.130 int unpack_valid_nas_SLQSGetServingSystem (uint8_t * *pResp*, uint8_t *u8Info*)

valid queries information regarding the system that currently provides service

Parameters

in	*pResp*	qmi response from modem
in	*u8Info*	value to check unpack_nas_SLQSGetServingSystem_t param valid. • 0 - RoamIndicatorVal • 1 - DataSrvCapabilities • 2 - CurrentPLMN • 3 - SystemID and NetworkID • 4 - BaseStationID, BaseStationLatitude and BasestationLongitude • 5 - RoamingIndicatorList • 6 - DefaultRoamInd • 7 - Gpp2TimeZone • 8 - CDMA_P_Rev • 9 - GppTimeZone • 10 - GppNetworkDSTAdjustment • 11 - Lac • 12 - CellID • 13 - ConcSvcInfo • 14 - PRLInd • 15 - DTMInd • 16 - DetailedSvcInfo • 17 - CDMASystemInfoExt • 18 - HdrPersonality • 19 - TrackAreaCode • 20 - CallBarStatus

Returns

eQCWWAN_ERR_NONE on signal info valid, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.131 int unpack_valid_nas_SLQSGetSignalStrength (uint8_t * *pResp*, uint8_t *u8Info*)

valid queries information regarding the system that currently provides service

Parameters

in	*pResp*	qmi response from modem
in	*u8Info*	value to check unpack_nas_SLQSGetSignalStrength_t param valid. • 0 - rxSignalStrengthList and rxSignalStrengthListLen • 1 - ecioList and ecioListLen • 2 - Io • 3 - sinr • 4 - errorRateListLen, errorRateList • 5 - rsrqInfo • 6 - ltesnr • 7 - ltersrp

Returns

eQCWWAN_ERR_NONE on signal info valid, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.11.4.132 int unpack_valid_nas_SLQSNasGetSigInfo (uint8_t * *pResp*, uint8_t *u8Info*)

valid get sig info

Parameters

in	*pResp*	qmi response from modem
in	*u8Info*	value to check unpack_nas_SLQSNasGetSigInfo_t param valid. • 0 - CDMASSInfo • 1 - HDRSSInfo. • 2 - GSMSSInfo. • 3 - WCDMASSInfo. • 4 - LTESSInfo.

Returns

eQCWWAN_ERR_NONE on signal info valid, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12 pds.h File Reference

Data Structures

- struct unpack_pds_GetPDSState_t
- struct pack_pds_SetPDSState_t
- struct unpack_pds_GetPDSDefaults_t
- struct pack_pds_SetPDSDefaults_t
- struct unpack_pds_GetPortAutomaticTracking_t
- struct pack_pds_SetPortAutomaticTracking_t
- struct pack_pds_StartPDSTrackingSessionExt_t
- struct pack_pds_PDSInjectTimeReference_t
- struct unpack_pds_GetXTRAAutomaticDownload_t
- struct pack_pds_SetXTRAAutomaticDownload_t
- struct unpack_pds_GetXTRANetwork_t
- struct pack_pds_SetXTRANetwork_t
- struct unpack_pds_GetXTRAValidity_t
- struct unpack_pds_GetServiceAutomaticTracking_t
- struct pack_pds_SetServiceAutomaticTracking_t
- struct pack_pds_ResetPDSData_t
- struct pack_pds_SLQSSetAGPSConfig_t
- struct pack_pds_SLQSPDSInjectAbsoluteTimeReference_t
- struct pack_pds_SLQSGetAGPSConfig_t
- struct unpack_pds_SLQSGetAGPSConfig_t
- struct pack_pds_SLQSPDSInjectPositionData_t
- struct unpack_pds_SLQSGetGPSStateInfo_t
- struct pack_pds_SLQSSetPositionMethodState_t
- struct pack_pds_SetEventReportCallback_t
- struct unpack_pds_SetEventReport_Ind_t
- struct unpack_pds_SetPdsState_Ind_t

Typedefs

- typedef unpack_result_t unpack_pds_SetPDSState_t
- typedef unpack_result_t unpack_pds_SetPDSDefaults_t
- typedef unpack_result_t unpack_pds_SetPortAutomaticTracking_t
- typedef unpack_result_t unpack_pds_StartPDSTrackingSessionExt_t
- typedef unpack_result_t unpack_pds_StopPDSTrackingSession_t
- typedef unpack_result_t unpack_pds_PDSInjectTimeReference_t
- typedef unpack_result_t unpack_pds_SetXTRAAutomaticDownload_t
- typedef unpack_result_t unpack_pds_SetXTRANetwork_t
- typedef unpack_result_t unpack_pds_ForceXTRADownload_t
- typedef unpack_result_t unpack_pds_SetServiceAutomaticTracking_t
- typedef unpack_result_t unpack_pds_ResetPDSData_t
- typedef unpack_result_t unpack_pds_SLQSSetAGPSConfig_t
- typedef unpack_result_t unpack_pds_SLQSPDSInjectAbsoluteTimeReference_t
- typedef unpack_result_t unpack_pds_SLQSPDSInjectPositionData_t
- typedef unpack_result_t unpack_pds_SLQSPDSDeterminePosition_t
- typedef unpack_result_t unpack_pds_SLQSSetPositionMethodState_t
- typedef unpack_result_t unpack_pds_SetEventReportCallback_t

Functions

- int pack_pds_GetPDSState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetPDSState (uint8_t *pResp, uint16_t respLen, unpack_pds_GetPDSState_t *pOutput)
- int pack_pds_SetPDSState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetPDSState_t *pReqParam)
- int unpack_pds_SetPDSState (uint8_t *pResp, uint16_t respLen, unpack_pds_SetPDSState_t *pOutput)
- int pack_pds_GetPDSDefaults (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetPDSDefaults (uint8_t *pResp, uint16_t respLen, unpack_pds_GetPDSDefaults_t *pOutput)
- int pack_pds_SetPDSDefaults (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetPDSDefaults_t *pReqParam)
- int unpack_pds_SetPDSDefaults (uint8_t *pResp, uint16_t respLen, unpack_pds_SetPDSDefaults_t *pOutput)
- int pack_pds_GetPortAutomaticTracking (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetPortAutomaticTracking (uint8_t *pResp, uint16_t respLen, unpack_pds_GetPortAutomaticTracking_t *pOutput)
- int pack_pds_SetPortAutomaticTracking (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetPortAutomaticTracking_t *pReqParam)
- int unpack_pds_SetPortAutomaticTracking (uint8_t *pResp, uint16_t respLen, unpack_pds_SetPortAutomaticTracking_t *pOutput)
- int pack_pds_StartPDSTrackingSessionExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_StartPDSTrackingSessionExt_t *pReqParam)
- int unpack_pds_StartPDSTrackingSessionExt (uint8_t *pResp, uint16_t respLen, unpack_pds_StartPDSTrackingSessionExt_t *pOutput)
- int pack_pds_StopPDSTrackingSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_StopPDSTrackingSession (uint8_t *pResp, uint16_t respLen, unpack_pds_StopPDSTrackingSession_t *pOutput)
- int pack_pds_PDSInjectTimeReference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_PDSInjectTimeReference_t *pReqParam)
- int unpack_pds_PDSInjectTimeReference (uint8_t *pResp, uint16_t respLen, unpack_pds_PDSInjectTimeReference_t *pOutput)
- int pack_pds_GetXTRAAutomaticDownload (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetXTRAAutomaticDownload (uint8_t *pResp, uint16_t respLen, unpack_pds_GetXTRAAutomaticDownload_t *pOutput)
- int pack_pds_SetXTRAAutomaticDownload (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetXTRAAutomaticDownload_t *pReqParam)
- int unpack_pds_SetXTRAAutomaticDownload (uint8_t *pResp, uint16_t respLen, unpack_pds_SetXTRAAutomaticDownload_t *pOutput)
- int pack_pds_GetXTRANetwork (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetXTRANetwork (uint8_t *pResp, uint16_t respLen, unpack_pds_GetXTRANetwork_t *pOutput)
- int pack_pds_SetXTRANetwork (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetXTRANetwork_t *pReqParam)
- int unpack_pds_SetXTRANetwork (uint8_t *pResp, uint16_t respLen, unpack_pds_SetXTRANetwork_t *pOutput)
- int pack_pds_GetXTRAValidity (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetXTRAValidity (uint8_t *pResp, uint16_t respLen, unpack_pds_GetXTRAValidity_t *pOutput)
- int pack_pds_ForceXTRADownload (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_ForceXTRADownload (uint8_t *pResp, uint16_t respLen, unpack_pds_ForceXTRADownload_t *pOutput)
- int pack_pds_GetServiceAutomaticTracking (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_GetServiceAutomaticTracking (uint8_t *pResp, uint16_t respLen, unpack_pds_GetServiceAutomaticTracking_t *pOutput)

- int pack_pds_SetServiceAutomaticTracking (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SetServiceAutomaticTracking_t *pReqParam)
- int unpack_pds_SetServiceAutomaticTracking (uint8_t *pResp, uint16_t respLen, unpack_pds_SetServiceAutomaticTracking_t *pOutput)
- int pack_pds_ResetPDSData (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_ResetPDSData_t *pReqParam)
- int unpack_pds_ResetPDSData (uint8_t *pResp, uint16_t respLen, unpack_pds_ResetPDSData_t *pOutput)
- int pack_pds_SLQSSetAGPSConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SLQSSetAGPSConfig_t *pReqParam)
- int unpack_pds_SLQSSetAGPSConfig (uint8_t *pResp, uint16_t respLen, unpack_pds_SLQSSetAGPSConfig_t *pOutput)
- int pack_pds_SLQSPDSInjectAbsoluteTimeReference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SLQSPDSInjectAbsoluteTimeReference_t *pReqParam)
- int unpack_pds_SLQSPDSInjectAbsoluteTimeReference (uint8_t *pResp, uint16_t respLen, unpack_pds_SLQSPDSInjectAbsoluteTimeReference_t *pOutput)
- int pack_pds_SLQSGetAGPSConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SLQSGetAGPSConfig_t *pReqParam)
- int unpack_pds_SLQSGetAGPSConfig (uint8_t *pResp, uint16_t respLen, unpack_pds_SLQSGetAGPSConfig_t *pOutput)
- int pack_pds_SLQSPDSInjectPositionData (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SLQSPDSInjectPositionData_t *pReqParam)
- int unpack_pds_SLQSPDSInjectPositionData (uint8_t *pResp, uint16_t respLen, unpack_pds_SLQSPDSInjectPositionData_t *pOutput)
- int pack_pds_SLQSPDSDeterminePosition (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_SLQSPDSDeterminePosition (uint8_t *pResp, uint16_t respLen, unpack_pds_SLQSPDSDeterminePosition_t *pOutput)
- int pack_pds_SLQSGetGPSStateInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_pds_SLQSGetGPSStateInfo (uint8_t *pResp, uint16_t respLen, unpack_pds_SLQSGetGPSStateInfo_t *pOutput)
- int pack_pds_SLQSSetPositionMethodState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_pds_SLQSSetPositionMethodState_t *pReqParam)
- int unpack_pds_SLQSSetPositionMethodState (uint8_t *pResp, uint16_t respLen, unpack_pds_SLQSSetPositionMethodState_t *pOutput)
- int pack_pds_SetEventReportCallback (pack_qmi_t *pCtx, uint8_t *pReq, uint16_t *pLen, pack_pds_SetEventReportCallback_t *pReqParam)
- int unpack_pds_SetEventReportCallback (uint8_t *pResp, uint16_t respLen, unpack_pds_SetEventReportCallback_t *pOutput)
- int unpack_pds_SetEventReport_Ind (uint8_t *pResp, uint16_t respLen, unpack_pds_SetEventReport_Ind_t *pOutput)
- int unpack_pds_SetPdsState_Ind (uint8_t *pResp, uint16_t respLen, unpack_pds_SetPdsState_Ind_t *pOutput)

9.12.1 Typedef Documentation

9.12.1.1 typedef unpack_result_t unpack_pds_ForceXTRADownload_t

9.12.1.2 typedef unpack_result_t unpack_pds_PDSInjectTimeReference_t

9.12.1.3 typedef unpack_result_t unpack_pds_ResetPDSData_t

9.12.1.4 typedef unpack_result_t unpack_pds_SetEventReportCallback_t

9.12.1.5 typedef unpack_result_t unpack_pds_SetPDSDefaults_t

9.12.1.6 typedef unpack_result_t unpack_pds_SetPDSState_t

9.12.1.7 typedef unpack_result_t unpack_pds_SetPortAutomaticTracking_t

9.12.1.8 typedef unpack_result_t unpack_pds_SetServiceAutomaticTracking_t

9.12.1.9 typedef unpack_result_t unpack_pds_SetXTRAAutomaticDownload_t

9.12.1.10 typedef unpack_result_t unpack_pds_SetXTRANetwork_t

9.12.1.11 typedef unpack_result_t unpack_pds_SLQSPDSDeterminePosition_t

9.12.1.12 typedef unpack_result_t unpack_pds_SLQSPDSInjectAbsoluteTimeReference_t

9.12.1.13 typedef unpack_result_t unpack_pds_SLQSPDSInjectPositionData_t

9.12.1.14 typedef unpack_result_t unpack_pds_SLQSSetAGPSConfig_t

9.12.1.15 typedef unpack_result_t unpack_pds_SLQSSetPositionMethodState_t

9.12.1.16 typedef unpack_result_t unpack_pds_StartPDSTrackingSessionExt_t

9.12.1.17 typedef unpack_result_t unpack_pds_StopPDSTrackingSession_t

9.12.2 Function Documentation

9.12.2.1 int pack_pds_ForceXTRADownload (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen*)

Forces the XTRA database to be downloaded to the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.2 int pack_pds_GetPDSDefaults (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen*)

Get the default tracking session configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.3 int pack_pds_GetPDSState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get current PDS state pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.4 int pack_pds_GetPortAutomaticTracking (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Returns the automatic tracking configuration for the NMEA COM port pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.5 int pack_pds_GetServiceAutomaticTracking (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

automatic tracking state for the service pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.6 int pack_pds_GetXTRAAutomaticDownload (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

XTRA automatic database download configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.7 int pack_pds_GetXTRANetwork (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

XTRA WWAN network preference parameter pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.8 int pack_pds_GetXTRAValidity (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

XTRA database validity period parameter pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.9 int pack_pds_PDSInjectTimeReference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_PDSInjectTimeReference_t * *pReqParam*)

Inject system time parameters pack.

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.10 int pack_pds_ResetPDSData (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_ResetPDSData_t * *pReqParam*)

Resets the specified PDS data pack.

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.11 int pack_pds_SetEventReportCallback (pack_qmi_t * *pCtx*, uint8_t * *pReq*, uint16_t * *pLen*, pack_pds_SetEventReportCallback_t * *pReqParam*)

Enables/disables the PDS Event report callback function pack.

Parameters

in, out	*pCtx*	qmi request context
out	*pReq*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.12 int pack_pds_SetPDSDefaults (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetPDSDefaults_t * *pReqParam*)

Sets the default tracking session configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.13 int pack_pds_SetPDSState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetPDSState_t * *pReqParam*)

Sets the PDS state pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.14 int pack_pds_SetPortAutomaticTracking (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetPortAutomaticTracking_t * *pReqParam*)

Sets the automatic tracking configuration for the NMEA COM port pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.15 int pack_pds_SetServiceAutomaticTracking (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetServiceAutomaticTracking_t * *pReqParam*)

Sets the automatic tracking state for the service pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.16 int pack_pds_SetXTRAAutomaticDownload (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetXTRAAutomaticDownload_t * *pReqParam*)

Sets the XTRA automatic database download configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.17 int pack_pds_SetXTRANetwork (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SetXTRANetwork_t * *pReqParam*)

Sets the XTRA WWAN network preference pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.18 int pack_pds_SLQSGetAGPSConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SLQSGetAGPSConfig_t * *pReqParam*)

Gets the PDS AGPS (MS-based) configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.19 int pack_pds_SLQSGetGPSStateInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Queries the MSM GPS server for receiver state information pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.20 int pack_pds_SLQSPDSDeterminePosition (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Requests the MSM GPS service to obtain the current position for manually controlled tracking sessions pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.21 int pack_pds_SLQSPDSInjectAbsoluteTimeReference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SLQSPDSInjectAbsoluteTimeReference_t * *pReqParam*)

Injects a absolute time reference into the PDS engine pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.22 int pack_pds_SLQSPDSInjectPositionData (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SLQSPDSInjectPositionData_t * *pReqParam*)

Injects position data into the PDS engine pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.23 int pack_pds_SLQSSetAGPSConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SLQSSetAGPSConfig_t * *pReqParam*)

Sets the PDS AGPS (MS-based) configuration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.24 int pack_pds_SLQSSetPositionMethodState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_SLQSSetPositionMethodState_t * *pReqParam*)

Sets the state of positioning methods for the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.25 int pack_pds_StartPDSTrackingSessionExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_pds_StartPDSTrackingSessionExt_t * *pReqParam*)

Starts a PDS tracking session pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.26 int pack_pds_StopPDSTrackingSession (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Stops a PDS tracking session pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.27 int unpack_pds_ForceXTRADownload (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_ForceXTRADownload_t * *pOutput*)

Forces the XTRA database to be downloaded to the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.28 int unpack_pds_GetPDSDefaults (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetPDSDefaults_t * *pOutput*)

Get the default tracking session configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.29 int unpack_pds_GetPDSState (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetPDSState_t * *pOutput*)

Get current PDS state unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.30 int unpack_pds_GetPortAutomaticTracking (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetPortAutomaticTracking_t * *pOutput*)

Returns the automatic tracking configuration for the NMEA COM port unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.31 int unpack_pds_GetServiceAutomaticTracking (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetServiceAutomaticTracking_t * *pOutput*)

automatic tracking state for the service unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.32 int unpack_pds_GetXTRAAutomaticDownload (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetXTRAAutomaticDownload_t * *pOutput*)

XTRA automatic database download configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.33 int unpack_pds_GetXTRANetwork (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetXTRANetwork_t * *pOutput*)

XTRA WWAN network preference parameter unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.34 int unpack_pds_GetXTRAValidity (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_GetXTRAValidity_t * *pOutput*)

XTRA database validity period parameter unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.35 int unpack_pds_PDSInjectTimeReference (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_PDSInjectTimeReference_t * *pOutput*)

Inject system time parameters unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.36 int unpack_pds_ResetPDSData (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_ResetPDSData_t * *pOutput*)

Resets the specified PDS data unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.37 int unpack_pds_SetEventReport_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SetEventReport_Ind_t * *pOutput*)

PDS Event Report Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.38 int unpack_pds_SetEventReportCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SetEventReportCallback_t * *pOutput*)

Enables/disables the PDS Event report callback function unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.39 int unpack_pds_SetPDSDefaults (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SetPDSDefaults_t * *pOutput*)

Sets the default tracking session configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.40 int unpack_pds_SetPDSState (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SetPDSState_t * *pOutput*)

Sets the PDS state unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.41 int unpack_pds_SetPdsState_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SetPdsState_Ind_t * *pOutput*)

PDS State Indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.42 int unpack_pds_SetPortAutomaticTracking (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SetPortAutomaticTracking_t * *pOutput*)

Sets the automatic tracking configuration for the NMEA COM port unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.43 int unpack_pds_SetServiceAutomaticTracking (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SetServiceAutomaticTracking_t * *pOutput*)

Sets the automatic tracking state for the service unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.44 int unpack_pds_SetXTRAAutomaticDownload (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SetXTRAAutomaticDownload_t * *pOutput*)

Sets the XTRA automatic database download configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.45 int unpack_pds_SetXTRANetwork (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SetXTRANetwork_t * *pOutput*)

Sets the XTRA WWAN network preference unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.46 int unpack_pds_SLQSGetAGPSConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SLQSGetAGPSConfig_t * *pOutput*)

Gets the PDS AGPS (MS-based) configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.47 int unpack_pds_SLQSGetGPSStateInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SLQSGetGPSStateInfo_t * *pOutput*)

Queries the MSM GPS server for receiver state information unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.48 int unpack_pds_SLQSPDSDeterminePosition (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SLQSPDSDeterminePosition_t * *pOutput*)

Requests the MSM GPS service to obtain the current position for manually controlled tracking sessions unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.49 int unpack_pds_SLQSPDSInjectAbsoluteTimeReference (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SLQSPDSInjectAbsoluteTimeReference_t * *pOutput*)

Injects a absolute time reference into the PDS engine unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.50 int unpack_pds_SLQSPDSInjectPositionData (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SLQSPDSInjectPositionData_t * *pOutput*)

Injects position data into the PDS engine unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.51 int unpack_pds_SLQSSetAGPSConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SLQSSetAGPSConfig_t * *pOutput*)

Sets the PDS AGPS (MS-based) configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.52 int unpack_pds_SLQSSetPositionMethodState (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_SLQSSetPositionMethodState_t * *pOutput*)

Sets the state of positioning methods for the device unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.53 int unpack_pds_StartPDSTrackingSessionExt (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_StartPDSTrackingSessionExt_t * *pOutput*)

Starts a PDS tracking session unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.12.2.54 int unpack_pds_StopPDSTrackingSession (uint8_t * *pResp*, uint16_t *respLen*, unpack_pds_StopPDSTrackingSession_t * *pOutput*)

Stops a PDS tracking session unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.13 qaGobiApiTableBandClasses.h File Reference

Network Access Service API Band Classes table.

9.13.1 Detailed Description

Network Access Service API Band Classes table.

9.13.2 Band Classes (Value - Description)

- 0 - CDMA Band Class 0
- 1 - CDMA Band Class 1
- 3 - CDMA Band Class 3
- 4 - CDMA Band Class 4
- 5 - CDMA Band Class 5
- 6 - CDMA Band Class 6
- 7 - CDMA Band Class 7
- 8 - CDMA Band Class 8
- 9 - CDMA Band Class 9
- 10 - CDMA Band Class 10
- 11 - CDMA Band Class 11
- 12 - CDMA Band Class 12
- 13 - CDMA Band Class 13
- 14 - CDMA Band Class 14
- 15 - CDMA Band Class 15
- 16 - CDMA Band Class 16
- 17 - CDMA Band Class 17
- 18 - CDMA Band Class 18
- 19 - CDMA Band Class 19
- 40 - GSM 450
- 41 - GSM 480
- 42 - GSM 750
- 43 - GSM 850

- 44 - GSM 900 (Extended)
- 45 - GSM 900 (Primary)
- 46 - GSM 900 (Railways)
- 47 - GSM 1800
- 48 - GSM 1900
- 80 - WCDMA 2100
- 81 - WCDMA PCS 1900
- 82 - WCDMA DCS 1800
- 83 - WCDMA 1700 (US)
- 84 - WCDMA 850
- 85 - WCDMA 800
- 86 - WCDMA 2600
- 87 - WCDMA 900
- 88 - WCDMA 1700 (Japan)
- 90 - WCDMA 1500 band (Japan)
- 91 - WCDMA 850 band (Japan)
- < Reserved 89, 92-109 for WCDMA band classes>
- 110 - WLAN US 2400 MHz
- 111 - WLAN JAPAN 2400 MHz
- 112 - WLAN EUROPEAN 2400 MHz
- 113 - WLAN FRANCE 2400 MHz
- 114 - WLAN SPAIN 2400 MHz
- 115 - WLAN US 5000 MHz band
- 116 - WLAN JAPAN 5000 MHz
- 117 - WLAN EUROPEAN 5000 MHz
- 118 - WLAN FRANCE 5000 MHz
- 119 - WLAN SPAIN 5000 MHz

9.13.2.1 LTE Bands

- 28 - LTE Band Class 28
- 39 - LTE Band Class 39
- 40 - LTE Band Class 40
- 41 - LTE Band Class 41
- 120 - FDD UL:1920-1980; DL:2110-2170; E-UTRA Operating Band 1
- 121 - FDD UL:1850-1910; DL:1930-1990; E-UTRA Operating Band 2
- 122 - FDD UL:1710-1785; DL:1805-1880; E-UTRA Operating Band 3

- 123 - FDD UL:1710-1755; DL:2110-2155; E-UTRA Operating Band 4
- 124 - FDD UL: 824- 849; DL: 869- 894; E-UTRA Operating Band 5
- 125 - FDD UL: 830- 840; DL: 875- 885; E-UTRA Operating Band 6
- 126 - FDD UL:2500-2570; DL:2620-2690; E-UTRA Operating Band 7
- 127 - FDD UL: 880- 915; DL: 925- 960; E-UTRA Operating Band 8
- 128 - FDD UL:1749.9-1784.9; DL:1844.9-1879.9; E-UTRA Operating Band 9
- 129 - FDD UL:1710-1770; DL:2110-2170; E-UTRA Operating Band 10
- 130 - FDD UL:1427.9-1452.9; DL:1475.9-1500.9; E-UTRA Operating Band 11
- 131 - FDD UL:698-716; DL:728-746; E-UTRA Operating Band 12
- 132 - FDD UL: 777- 787; DL: 746-756; E-UTRA Operating Band 13
- 133 - FDD UL: 788- 798; DL: 758-768; E-UTRA Operating Band 14
- 134 - FDD UL: 704-716; DL: 734-746; E-UTRA Operating Band 17
- 135 - TDD LTE UL: 1900-1920; DL: 1900-1920; E-UTRA Operating Band 33
- 136 - TDD LTE UL: 2010-2025; DL: 2010-2025; E-UTRA Operating Band 34
- 137 - TDD LTE UL: 1850-1910; DL: 1850-1910; E-UTRA Operating Band 35
- 138 - TDD LTE UL: 1930-1990; DL: 1930-1990; E-UTRA Operating Band 36
- 139 - TDD LTE UL: 1910-1930; DL: 1910-1930; E-UTRA Operating Band 37
- 140 - TDD LTE UL: 2570-2620; DL: 2570-2620; E-UTRA Operating Band 38
- 141 - TDD LTE UL: 1880-1920; DL: 1880-1920; E-UTRA Operating Band 39
- 142 - TDD LTE UL: 2300-2400; DL: 2300-2400; E-UTRA Operating Band 40
- 143 - FDD LTE UL: 815-830; DL: 860-875; E-UTRA Operating Band 18
- 144 - FDD LTE UL: 830-845; DL: 875-890; E-UTRA Operating Band 19
- 145 - FDD LTE UL: 832-862; DL: 791-821; E-UTRA Operating Band 20
- 146 - FDD LTE UL: 1447.9-1462.9; DL: 1495.9-1510.9; E-UTRA Operating Band 21
- 147 - FDD LTE UL: 1626.5-1660.5; DL: 1525-1559; E-UTRA Operating Band 24
- 148 - FDD LTE UL: 1850-19195; DL: 1930-1995; E-UTRA Operating Band 25
- 149 - TDD LTE UL: 2496-2690; DL: 2496-2690; E-UTRA Operating Band 41
- 150 - TDD LTE UL: 3400-3600; DL: 3400-3600; E-UTRA Operating Band 42
- 151 - TDD LTE UL: 3600-3800; DL: 3600-3800; E-UTRA Operating Band 43
- 152 - E-UTRA Operating Band 23
- 153 - E-UTRA Operating Band 26
- 154 - E-UTRA Operating Band 32
- 155 - E-UTRA Operating Band 125
- 156 - E-UTRA Operating Band 126
- 157 - E-UTRA Operating Band 127
- 158 - E-UTRA Operating Band 28

- 159 - E-UTRA Operating Band 29
- 160 - E-UTRA Operating Band 30
- 161 - E-UTRA Operating Band 66
- 162 - E-UTRA Operating Band 250
- 163 - E-UTRA Operating Band 46
- 164 - E-UTRA Operating Band 27
- 165 - E-UTRA Operating Band 31
- 166 - E-UTRA Operating Band 71
- 167 - E-UTRA Operating Band 47
- 168 - E-UTRA Operating Band 48
- 200 - TD-SCDMA Band A
- 201 - TD-SCDMA Band B
- 202 - TD-SCDMA Band C
- 203 - TD-SCDMA Band D
- 204 - TD-SCDMA Band E
- 205 - TD-SCDMA Band F
- 250 - NR5G Band 1
- 251 - NR5G Band 2

Copyright: © 2018 Sierra Wireless, Inc. all rights reserved

9.14 qaGobiApiTableCallControlReturnReasons.h File Reference

Call Control Return Reasons table.

9.14.1 Detailed Description

Call Control Return Reasons table.

9.14.2 S1

- 0x01 - QMI_VOICE_REASON_FWD_UNCONDITIONAL - Unconditional call forwarding
- 0x02 - QMI_VOICE_REASON_FWD_MOBILEBUSY - Forward when the mobile is busy
- 0x03 - QMI_VOICE_REASON_FWD_NOREPLY - Forward when there is no reply
- 0x04 - QMI_VOICE_REASON_FWD_UNREACHABLE - Forward when the call is unreachable
- 0x05 - QMI_VOICE_REASON_FWD_ALLFORWARDING - All forwarding
- 0x06 - QMI_VOICE_REASON_FWD_ALLCONDITIONAL - All conditional forwarding
- 0x07 - QMI_VOICE_REASON_BARR_ALLOUTGOING - All outgoing
- 0x08 - QMI_VOICE_REASON_BARR_OUTGOINGINT - Outgoing internal

- 0x09 - QMI_VOICE_REASON_BARR_OUTGOINGINTEXTOHOME - Outgoing external to home
- 0x0A - QMI_VOICE_REASON_BARR_ALLINCOMING - All incoming
- 0x0B - QMI_VOICE_REASON_BARR_INCOMINGROAMING - Roaming incoming
- 0x0C - QMI_VOICE_REASON_BARR_ALLBARRING - All calls are barred
- 0x0D - QMI_VOICE_REASON_BARR_ALLOUTGOINGBARRING - All outgoing calls are barred
- 0x0E - QMI_VOICE_REASON_BARR_ALLINCOMINGBARRING - All incoming calls are barred
- 0x0F - QMI_VOICE_REASON_CALLWAITING - Call waiting
- 0x10 - VOICE_CC_SUPS_RESULT_REASON_CLIP - CLIP
- 0x11 - VOICE_CC_SUPS_RESULT_REASON_CLIR - CLIR
- 0x12 - VOICE_CC_SUPS_RESULT_REASON_COLP - COLP
- 0x13 - VOICE_CC_SUPS_RESULT_REASON_COLR - COLR
- 0x14 - VOICE_CC_SUPS_RESULT_REASON_CNAP - CNAP
- 0xFF - Not Available

Copyright: © 2012 Sierra Wireless, Inc. all rights reserved

9.15 qaGobiApiTableCallEndReasons.h File Reference

Wireless Data Service Call End Reasons.

9.15.1 Detailed Description

Wireless Data Service Call End Reasons.

9.15.2 Call end reason codes (Code - Reason)

9.15.2.1 Technology-agnostic call end reasons

- 1 - Reason unspecified, check the verbose call end reason
- 2 - Client ended the call
- 3 - Device has no service
- 4 - Call ended abnormally
- 5 - Received release from base station; no reason given
- 6 - Access attempt already in progress; SD2.0 only
- 7 - Access failure for reason other than the above
- 8 - Call rejected because of redirection or handoff
- 9 - Call failed because close is in progress
- 10 - Authentication failed, 3GPP equivalent ESM(EPS Session Management) cause code value 29, User authentication failed
- 11 - Call ended because of internal call end. This error code is returned when data call is brought down due to some unknown error, such as not specific to any RAT

- 12 - Call ended because of internal error. This error code is returned when data call is brought down due to some unspecified internal error, such as NULL pointer
- 13 - Internal unknown cause code

9.15.2.2 EVDO CDMA 1xEV-DO

- 500 - Device is CDMA-locked until power cycle
- 501 - Received intercept from base station; origination only
- 502 - Received reorder from base station; origination only
- 503 - Received release from base station; service option reject
- 504 - Received incoming call from base station
- 505 - Received alert stop from base station; incoming only
- 506 - Received end activation; OTASP call only
- 507 - Max access probes transmitted
- 508 - Concurrent service is not supported by base station
- 509 - No response received from base station
- 510 - Call rejected by the base station; CDMA only
- 511 - Concurrent services requested were not compatible; CDMA only
- 512 - Corresponds to CM CALL ORIG ERR ALREADY IN TC
- 513 - Used if Call manager subsystem is ending a GPS call in favor of a user call
- 514 - Used if Call manager subsystem is ending a SMS call in favor of a user call
- 515 - CDMA Only; Device has no service

9.15.2.3 WCDMA/GSM call end reasons

- 1000 - Call origination request failed; WCDMA/GSM Only
- 1001 - Client rejected the incoming call; WCDMA/GSM Only
- 1002 - Device has no UMTS service; WCDMA/GSM Only
- 1003 - Network ended the call, look in cc call; WCDMA/GSM Only
- 1004 - LLC(Logical Link Control) or SNDCP(Sub Network Dependent Convergence Protocol) failure
- 1005 - Insufficient resources, 3GPP equivalent ESM(EPS Session Management) cause code value 26, Insufficient resources
- 1006 - Service option temporarily out of order, 3GPP equivalent ESM(EPS Session Management) cause code value 34, Service option temporarily out of order
- 1007 - PTI already used, 3GPP equivalent ESM(EPS Session Management) cause code value 35, PTI(-Procedure Transaction Identity) already in use
- 1008 - Regular PDP context deactivation, 3GPP equivalent ESM(EPS Session Management) cause code value 36, Regular deactivation
- 1009 - Network failure, 3GPP equivalent ESM(EPS Session Management) cause code value 38, Network failure

- 1010 - Reactivation requested, 3GPP equivalent ESM(EPS Session Management) cause code value 39, Reactivation requested
- 1011 - Protocol error, unspecified, 3GPP equivalent ESM(EPS Session Management) cause code value 111, Protocol error, unspecified
- 1012 - Operator determined barring, 3GPP equivalent ESM(EPS Session Management) cause code value 8, Operator Determined Barring
- 1013 - Unknown or missing Access Point Name (APN), 3GPP equivalent ESM(EPS Session Management) cause code value 27, Missing or unknown APN
- 1014 - Unknown PDP address or PDP type, 3GPP equivalent ESM(EPS Session Management) cause code value 28, Unknown PDN type
- 1015 - Activation rejected by GGSN, 3GPP equivalent ESM(EPS Session Management) cause code value 30, Requested rejected by Serving GW or PDN GW
- 1016 - Activation rejected, unspecified, 3GPP equivalent ESM(EPS Session Management) cause code value 31, Request rejected, unspecified
- 1017 - Service option not supported, 3GPP equivalent ESM(EPS Session Management) cause code value 32, Service option not supported
- 1018 - Requested service option not subscribed, 3GPP equivalent ESM(EPS Session Management) cause code value 33, Requested service option not subscribed
- 1019 - EPS Quality of Service (QoS) not accepted, 3GPP equivalent ESM(EPS Session Management) cause code value 37, EPS QoS not accepted
- 1020 - Semantic error in the TFT operation, 3GPP equivalent ESM(EPS Session Management) cause code value 41, Semantic error in the TFT operation
- 1021 - Syntactical error in the TFT operation, 3GPP equivalent ESM(EPS Session Management) cause code value 42, Syntactical error in the TFT operation
- 1022 - Unknown PDP context, 3GPP equivalent ESM(EPS Session Management) cause code value 43, Invalid EPS bearer identity
- 1023 - Semantic errors in packet filter(s), 3GPP equivalent ESM(EPS Session Management) cause code value 44, Semantic errors in packet filter(s)
- 1024 - Syntactical error in packet filter(s), 3GPP equivalent ESM(EPS Session Management) cause code value 45, Syntactical errors in packet filter(s)
- 1025 - PDP context without TFT already activated, 3GPP equivalent ESM(EPS Session Management) cause code value 46, Unused
- 1026 - Invalid transaction identifier value, 3GPP equivalent ESM(EPS Session Management) cause code value 81, Invalid PTI value
- 1027 - Semantically incorrect message, 3GPP equivalent ESM(EPS Session Management) cause code value 95, Semantically incorrect message
- 1028 - Invalid mandatory information, 3GPP equivalent ESM(EPS Session Management) cause code value 96, Invalid mandatory information
- 1029 - Message type non-existent or not implemented, 3GPP equivalent ESM(EPS Session Management) cause code value 97, Message type non-existent or not implemented
- 1030 - Message not compatible with state, 3GPP equivalent ESM(EPS Session Management) cause code value 98, Message type not compatible with the protocol state
- 1031 - Information element nonexistent or not implemented, 3GPP equivalent ESM(EPS Session Management) cause code value 99, Information element non-existent or not implemented

- 1032 - Conditional information element error, 3GPP equivalent ESM(EPS Session Management) cause code value 100, Conditional IE error
- 1033 - Message not compatible with protocol state, 3GPP equivalent ESM(EPS Session Management) cause code value 101, Message not compatible with the protocol state
- 1034 - APN restriction value incompatible with active PDP context, 3GPP equivalent ESM(EPS Session Management) cause code value 112, APN restriction value incompatible with
  - active EPS bearer context
- 1035 - No GPRS context present
- 1036 - Requested feature not supported, 3GPP equivalent ESM(EPS Session Management) cause code value 40, Feature not supported
- 1037 - Illegal MS, 3GPP equivalent EMM(EPS Mobility Management) cause code value 3, Illegal UE (MS)
- 1038 - Illegal ME, 3GPP equivalent EMM(EPS Mobility Management) cause code value 6, Illegal ME. This error code is sent to the MS if the ME used is not acceptable
  - to the network, e.g. blacklisted
- 1039 - GPRS and non GPRS services not allowed
- 1040 - GPRS services not allowed
- 1041 - MS identity not derived by the network, 3GPP equivalent EMM(EPS Mobility Management) cause code value 9, UE (MS) Identify cannot be derived by the network
- 1042 - Implicitly detached, 3GPP equivalent EMM(EPS Mobility Management) cause code value 10, Implicitly Detached
- 1043 - PLMN not allowed, 3GPP equivalent EMM(EPS Mobility Management) cause code value 11, PLMN not allowed
- 1044 - LA not allowed, this cause is sent to the MS if it requests location updating in a location area where the HPLMN determines that the MS, by subscription, is not allowed to operate.
- 1045 - GPRS services not allowed in PLMN
- 1046 - PDP duplicate
- 1047 - UE radio access technology change
- 1048 - app preempted
- 1049 - Congestion, This cause is sent if the service request or LOCATION UPDATING REQUEST message cannot be actioned because of congestion (e.g. congestion of the MSC or SGSN or GGSN or PDN Gateway; no channel; facility busy/congested etc.).
- 1050 - No PDP context activated
- 1051 - Access class DSAC rejection

9.15.2.4 EVDO CDMA 1xEV-DO

- 1500 - Abort connection setup due to the reception of a Connection Deny message with deny code set to either general or network busy.
- 1501 - Abort connection setup due to the reception of a Connection Deny message with deny code set to either billing or authentication failure.
- 1502 - Change HDR system due to redirection or PRL not preferred
- 1503 - Exit HDR due to redirection or PRL not preferred

- 1504 - No HDR session
- 1505 - Used if Call manager is ending an HDR call origination in favor of a GPS fix
- 1506 - Connection setup timeout
- 1507 - Call manager released HDR call so 1x call can continue

9.15.2.5 call end reason type

- 1 - Mobile IP
- 2 - Internal
- 3 - Call Manager defined
- 6 - 3GPP specification defined
- 7 - PPP
- 8 - EHRPD
- 9 - IPv6

9.15.2.6 Mobile IP call end reasons (Type=1)

- 64 - MIP(Mobile IP) FA(Foreign Agent) ERR REASON UNSPECIFIED, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration with unspecified reason
- 65 - MIP(Mobile IP) FA(Foreign Agent) ERR ADMINISTRATIVELY PROHIBITED, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent administratively prohibited MIP registration
- 66 - MIP(Mobile IP) FA(Foreign Agent) ERR INSUFFICIENT RESOURCES, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to insufficient resources
- 67 - MIP(Mobile IP) FA(Foreign Agent) ERR MOBILE NODE AUTHENTICATION FAILURE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because MN-AAA authenticator was wrong
- 68 - MIP(Mobile IP) FA(Foreign Agent) ERR HA AUTHENTICATION FAILURE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because of home agent authentication failure
- 69 - MIP(Mobile IP) FA(Foreign Agent) ERR REQUESTED LIFETIME TOO LONG, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because requested lifetime is too long
- 70 - MIP(Mobile IP) FA(Foreign Agent) ERR MALFORMED REQUEST, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to malformed request
- 71 - MIP(Mobile IP) FA(Foreign Agent) ERR MALFORMED REPLY, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to malformed reply
- 72 - MIP(Mobile IP) FA(Foreign Agent) ERR ENCAPSULATION UNAVAILABLE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because requested encapsulation is unavailable
- 73 - MIP(Mobile IP) FA(Foreign Agent) ERR VJHC UNAVAILABLE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because VJ Header Compression is unavailable

- 74 - MIP(Mobile IP) FA(Foreign Agent) ERR REVERSE TUNNEL UNAVAILABLE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because reverse tunnel is unavailable
- 75 - MIP(Mobile IP) FA(Foreign Agent) ERR REVERSE TUNNEL IS MANDATORY AND T BIT NOT SET, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because reverse tunnel is mandatory but not requested by device
- 79 - MIP(Mobile IP) FA(Foreign Agent) ERR DELIVERY STYLE NOT SUPPORTED, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration because delivery style is not supported
- 97 - MIP(Mobile IP) FA(Foreign Agent) ERR MISSING NAI, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to missing NAI
- 98 - MIP(Mobile IP) FA(Foreign Agent) ERR MISSING HA, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to missing Home Agent
- 99 - MIP(Mobile IP) FA(Foreign Agent) ERR MISSING HOME ADDR, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to missing Home Address
- 104 - MIP(Mobile IP) FA(Foreign Agent) ERR UNKNOWN CHALLENGE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to unknown challenge
- 105 - MIP(Mobile IP) FA(Foreign Agent) ERR MISSING CHALLENGE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to missing challenge
- 106 - MIP(Mobile IP) FA(Foreign Agent) ERR STALE CHALLENGE, this error code is returned when the data call bring up fails in MIP setup phase since foreign agent rejected MIP registration due to stale challenge
- 128 - MIP(Mobile IP) FA(Home Agent) ERR REASON UNSPECIFIED, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration with unspecified reason
- 129 - MIP(Mobile IP) FA(Home Agent) ERR ADMINISTRATIVELY PROHIBITED, this error code is returned when the data call bring up fails in MIP setup phase since home agent administratively prohibited MIP registration
- 130 - MIP(Mobile IP) FA(Home Agent) ERR INSUFFICIENT RESOURCES, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to insufficient resources
- 131 - MIP(Mobile IP) FA(Home Agent) ERR MOBILE NODE AUTHENTICATION FAILURE, this error code is returned when the data call bring up fails in MIP setup phase since home agent fails authentication because MN-HA authenticator was wrong
- 132 - MIP(Mobile IP) FA(Home Agent) ERR FA AUTHENTICATION FAILURE, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to FA authentication failure
- 133 - MIP(Mobile IP) FA(Home Agent) ERR REGISTRATION ID MISMATCH, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to registration id mismatch
- 134 - MIP(Mobile IP) FA(Home Agent) ERR MALFORMED REQUEST, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to malformed request
- 136 - MIP(Mobile IP) FA(Home Agent) ERR UNKNOWN HA ADDR, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to unknown Home Agent address. This code is returned by a home agent when the mobile node is performing dynamic home agent address resolution as described in RFC 3220 (IP Mobility Support for IPV4) Sections 3.6.1.1 and 3.6.1.2

- 137 - MIP(Mobile IP) FA(Home Agent) ERR REVERSE TUNNEL UNAVAILABLE, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration because reverse tunnel is unavailable
- 138 - MIP(Mobile IP) FA(Home Agent) ERR REVERSE TUNNEL IS MANDATORY AND T BIT NOT SET, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration because reverse tunnel is mandatory but not requested by device
- 139 - MIP(Mobile IP) FA(Home Agent) ERR ENCAPSULATION UNAVAILABLE, this error code is returned when the data call bring up fails in MIP setup phase since home agent rejected MIP registration due to encapsulation unavailable
- 65536 - MIP ERR REASON UNKNOWN

9.15.2.7 Internal call end reasons (Type=2)

- 200 - INTERNAL MIN, internal error table offset value, no meaningful message to the error.
- 201 - INTERNAL ERROR, this error code is returned when data call is brought down due to some unspecified internal error
- 202 - CALL ENDED
- 203 - INTERNAL UNKNOWN CAUSE CODE, this error code is returned when data call is brought down due to some unknown error
- 204 - UNKNOWN CAUSE CODE, this error code is returned when data call is brought down due to some unknown error
- 205 - CLOSE IN PROGRESS
- 206 - NETWORK INITIATED TERMINATION
- 207 - APP PREEMPTED
- 208 - ERR PDN IPV4 CALL DISALLOWED, this error code is returned when V4 PDN is in throttled state due to network providing only V6 address during the previous VSNCP bring up (subs_limited_to_v6). The time for which the IPv4 PDN is throttled is determined by the IPv4 throttling timers maintained in the profile
- 209 - ERR PDN IPV4 CALL THROTTLED, this error code is returned when V4 PDN is in throttled state due to previous VSNCP bring up failure(s). The time for which the IPv4 PDN is throttled is determined by the IPv4 throttling timers maintained in the profile
- 210 - ERR PDN IPV6 CALL DISALLOWED, this error code is returned when V6 PDN is in throttled state due to network providing only V4 address during the previous VSNCP bring up (subs_limited_to_v4). The time for which the IPv6 PDN is throttled is determined by the IPv6 throttling timers maintained in the profile
- 211 - ERR PDN IPV6 CALL THROTTLED, this error code is returned when V6 PDN is in throttled state due to previous VSNCP bring up failure(s). The time for which the IPv6 PDN is throttled is determined by the IPv6 throttling timers maintained in the profile
- 212 - MODEM RESTART
- 213 - PDP PPP NOT SUPPORTED
- 214 - UNPREFERRED RAT, this error code is returned when data call is brought down since the RAT on which the data call is attempted/connected is no longer the preferred RAT
- 215 - PHYS LINK CLOSE IN PROGRESS, this error code is returned when data call bring up is rejected because physical link is in the process of cleanup
- 216 - APN PENDING HANDOVER, this error code is returned when interface bring up is attempted for an APN that is yet to be handed over to target RAT
- 217 - PROFILE BEARER INCOMPATIBLE

- 218 - MMGSDI CARD EVT, this error code is returned when data call is brought down because card got refreshed/removed
- 219 - LPM OR PWR DOWN, this error code is returned when data call is brought down because device is going into lower power mode or powering down
- 220 - APN DISABLED, this error code is returned when APN is disabled in card
- 221 - MPIT EXPIRED, this error code is returned when data call is brought down because maximum PPP inactivity timer expired
- 222 - IPV6 ADDR TRANSFER FAILED
- 223 - TRAT SWAP FAILED
- 224 - EHRPD TO HRPD FALLBACK, this error code is returned when data call is brought down because device falls back from eHRPD to HRPD (not because of OOS on eHRPD but due to operator/spec driven eHRPD to HRPD fallback requirements)
- 225 - MANDATORY APN DISABLED, this error code is returned when any mandatory APN is disabled, and MinApnList Disallow call config item is set to TRUE in device
- 226 - MIP CONFIG FAILURE, this error code is returned when UE is in MIP Only config (QCMIP=2) but MIP config fails on call bring up due to incorrect provisioning
- 227 - INTERNAL_PDN_INACTIVITY_TIMER_EXPIRED, this error code is returned when PDN inactivity timer expired due to no data transmission in a configurable duration of time
- 228 - MAX_V4_CONNECTIONS, this error code is returned when IPv4 data call bring up is rejected because the UE already maintains the allotted maximum number of IPv4 data connections
- 229 - MAX_V6_CONNECTIONS, this error code is returned when IPv6 data call bring up is rejected because the UE already maintains the allotted maximum number of IPv6 data connections
- 230 - APN_MISMATCH, this error code is returned when New PDN bring up is rejected during interface selection because the UE has already allotted the available interfaces for other PDNs
- 231 - IP_VERSION_MISMATCH, this error code is returned when New call bring up is rejected because the existing data call IP type does not match the requested IP type
- 232 - DUN_CALL_DISALLOWED, this error code is returned when DUN call bring up is rejected because the UE is in eHRPD RAT
- 233 - INVALID_PROFILE, this error code is returned when Call bring up was requested with an invalid profile
- 234 - INTERNAL_EPC_NONEPC_TRANSITION, this error code is returned when Data call is rejected or brought down because the UE is in transition between EPC and non-EPC RAT
- 235 - INVALID_PROFILE_ID, this error code is returned when Call bring up was requested with an invalid profile ID
- 236 - INTERNAL_CALL_ALREADY_PRESENT, this error code is returned when a data call with the same policy is already connected or in the process of bring up on another RmNet instance
- 237 - IFACE_IN_USE, this error code is returned when the current IFACE is in use
- 238 - IP_PDP_MISMATCH, this error code is returned when a PPP call is attempted on a PDP profile
- 239 - APN_DISALLOWED_ON_ROAMING, this error code is returned when PDN connection to the APN is disallowed on the roaming network. The DS generates DS_SYS_EVENT_3GPP_ROAMING_DISALLOWED_INFO to inform clients of the APNs that must deregister and disconnect (if the PDN is up) while the UE is on the roaming network. Clients must deregister or disconnect if the APN name corresponding to the client is listed in this system event. Clients can register again if the APN name corresponding to the client is not listed in this system event.

- 240 - APN_PARAM_CHANGE, this error code is returned when Failure to reestablish the PDN with the changed parameters; when APN-related parameters are changed, the PDN associated with the parameters must be brought down and reestablished with the changed parameters
- 241 - IFACE_IN_USE_CFG_MATCH, this error code is returned when the IFACE is already in use with a matching configuration
- 242 - NULL_APN_DISALLOWED, this error code is returned when a PDN is attempted to be brought up with a NULL APN and when a NULL APN is not supported
- 243 - THERMAL_MITIGATION, this error code is returned when the thermal level increases and causes calls to be torn down when normal mode of operation is not allowed
- 244 - SUBS_ID_MISMATCH, this error code is returned when a new call bring up is rejected due to a mismatch between the subs_id in the profile and the subs_id in the ACL policy information
- 245 - DATA_SETTINGS_DISABLED, this error code is returned when the PDN connection to a given APN is disallowed because data is disabled from the device user interface (UI) settings
- 246 - DATA_ROAMING_SETTINGS_DISABLED, this error code is returned when the PDN Connection to a given APN is disallowed because data roaming is disabled from the device UI settings and the UE is roaming
- 247 - APN_FORMAT_INVALID, this error code is returned when the APN specified in the policy does not follow the format specified in the 3GPP Specification
- 248 - DDS_CALL_ABORT, this error code is returned when a DDS switch occurs; the data call is brought down with the DDS abort reason
- 249 - VALIDATION_FAILURE, this error code is returned when a data call is brought down due to an internal validation failure

9.15.2.8 Call Manager defined call end reasons (Type=3)

- 500 - CDMA LOCK, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to device in CDMA locked state
- 501 - INTERCEPT, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since it received an intercept order from the base station
- 502 - REORDER, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) due to receiving a reorder from base station
- 503 - REL SO REJ, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to receiving a release from base station with reason: SO Reject
- 504 - INCOM CALL, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since it received an incoming call from base station
- 505 - ALERT STOP, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to RL/FL fade (or) receiving call release from base stations
- 506 - ACTIVATION, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to channel acquisition failures. This indicates that device has failed acquiring all the channels in the PRL
- 507 - MAX ACCESS PROBE, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) due maximum access probes transmitted
- 508 - CCS NOT SUPPORTED BY BS, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since concurrent service is not supported by base station
- 509 - NO RESPONSE FROM BS, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since there is no response received from base station

- 510 - REJECTED BY BS, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) due to base station rejecting the call
- 511 - INCOMPATIBLE, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since concurrent services requested were not compatible
- 512 - ALREADY IN TC, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since traffic channel is already up for voice calls
- 513 - USER CAL ORIG DURING GPS
- 514 - USER CAL ORIG DURING SMS, this error code is returned when data call is brought down because traffic channel request got rejected since SMS is ongoing
- 515 - NO CDMA SRV, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device does not have CDMA service
- 516 - MC ABORT, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since MC aborted the origination/conversation
- 517 - PSIST NG, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to persistence test failure
- 518 - UIM NOT PRESENT, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to RUIM not present
- 519 - RETRY ORDER, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) due to receiving a retry order from base station
- 520 - ACCESS BLOCK, this error code is returned when data call is brought down because traffic channel rejected/released due to Access blocked by base station
- 521 - ACCESS BLOCK ALL, this error code is returned when data call is brought down because traffic channel rejected due to Access blocked by the base station for all mobile devices
- 522 - IS707B MAX ACC, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) due maximum access probes for IS-707B call
- 523 - THERMAL EMERGENCY, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) to put device in thermal emergency
- 524 - CALL ORIG THROTTLED, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since call origination is throttled by DCTM module
- 535 - USER CALL ORIGINATE DURING VOICE CALL, this error code is returned when data call is brought down because traffic channel got released by CM(Call Manager) in favor of voice call or SMS when concurrent voice and data are not supported
- 1000 - CONFERENCE FAILED
- 1001 - INCOMING REJECTED
- 1002 - NO GATEWAY SERVICE
- 1003 - NO GPRS CONTEXT
- 1004 - ILLEGAL MS, This cause is sent to the MS when the network refuses service to the MS either because an identity of the MS is not acceptable to the network or because the MS does not pass the authentication check, i.e. the SRES received from the MS is different from that generated by the network
- 1005 - ILLEGAL ME, This cause is sent to the MS if the ME used is not acceptable to the network, e.g. blacklisted
- 1006 - GPRS SERVICES AND NON GPRS SERVICES NOT ALLOWED
- 1007 - GPRS SERVICES NOT ALLOWED

- 1008 - MS IDENTITY CANNOT BE DERIVED BY THE NETWORK
- 1009 - IMPLICITLY DETACHED, this error code is sent to the MS either if the network has implicitly detached the MS, e.g. some while after the Mobile reachable timer has expired, or if the GMM context data related to the subscription does not exist in the SGSN e.g. because of a SGSN restart.
- 1010 - PLMN NOT ALLOWED, this error code is sent to the MS if it requests location updating in a PLMN where the MS, by subscription or due to operator determined barring is not allowed to operate
- 1011 - LOCAL AREA NOT ALLOWED
- 1012 - GPRS SERVICES NOT ALLOWED IN THIS PLMN
- 1013 - PDP DUPLICATE
- 1014 - USER EQUIPMENT RADIO ACCESS TECHNOLOGY CHANGE
- 1015 - CONGESTION
- 1016 - NO PDP CONEXT ACTIVATED
- 1017 - ACCESS CLASS DSAC REJECTION
- 1018 - PDP ACTIVATE MAX RETRY FAILED
- 1019 - RAB FAILURE
- 1020 - EPS SERVICE NOT ALLOWED
- 1021 - TRACKING AREA NOT ALLOWED
- 1022 - ROAMING NOT ALLOWED IN THIS TRACKING AREA
- 1023 - NO SUITABLE CELLS IN TRACKING AREA
- 1024 - NOT AUTHORIZED FOR THIS CLOSED SUBSCRIBER GROUP
- 1025 - ESM UNKNOWN EPS BEARER CONTEXT
- 1026 - DRB RELEASED AT RRC
- 1027 - NAS SIG CONN RELEASED
- 1028 - EPS MOBILITY MANAGEMENT DETACHED
- 1029 - EPS MOBILITY MANAGEMENT ATTACH FAILED
- 1030 - EPS MOBILITY MANAGEMENT ATTACH STARTED
- 1031 - LTE NAS SERVICE REQ FAILED
- 1032 - ESM(EPS Session Management) ACTIVE DEDICATED BEARER REACTIVATED BY NW
- 1033 - ESM(EPS Session Management) LOWER LAYER FAILURE
- 1034 - ESM(EPS Session Management) SYNC UP WITH NW
- 1035 - ESM(EPS Session Management) NW ACTIVATED DED BEARER WITH ID OF DEF BEARER
- 1036 - ESM(EPS Session Management) BAD OTA MESSAGE
- 1037 - ESM DS REJECTED THE CALL
- 1038 - ESM(EPS Session Management) CONTEXT TRANSFERRED DUE TO IRAT
- 1039 - DS EXPLICIT DEACT
- 1040 - ESM(EPS Session Management) LOCAL CAUSE NONE
- 1041 - LTE NAS SERVICE REQ FAILED NO THROTTLE

- 1042 - ACL FAILURE, This error code should rarely triggered and reported to the application
- 1043 - LTE NAS SERVICE REQ FAILED DS DISALLOW
- 1044 - EMM(EPS Mobility Management) T3417 EXPIRED
- 1045 - EMM(EPS Mobility Management) T3417 EXT EXPIRED
- 1046 - LRRC(LTE Radio Resource Control) UL DATA CNF FAILURE TXN - Light Radio Resource Controller Uplink data confirmation failure
- 1047 - LRRC(LTE Radio Resource Control) UL DATA CNF FAILURE HO
- 1048 - LRRC(LTE Radio Resource Control) UL DATA CNF FAILURE CONN REL
- 1049 - LRRC(LTE Radio Resource Control) UL DATA CNF FAILURE RLF
- 1050 - LRRC(LTE Radio Resource Control) UL DATA CNF FAILURE CTRL NOT CONN
- 1051 - LRRC(LTE Radio Resource Control) CONN EST FAILURE
- 1052 - LRRC(LTE Radio Resource Control) CONN EST FAILURE ABORTED
- 1053 - LRRC(LTE Radio Resource Control) CONN EST FAILURE ACCESS BARRED
- 1054 - LRRC(LTE Radio Resource Control) CONN EST FAILURE CELL RESEL
- 1055 - LRRC(LTE Radio Resource Control) CONN EST FAILURE CONFIG FAILURE
- 1056 - LRRC(LTE Radio Resource Control) CONN EST FAILURE TIMER EXPIRED
- 1057 - LRRC(LTE Radio Resource Control) CONN EST FAILURE LINK FAILURE
- 1058 - LRRC(LTE Radio Resource Control) CONN EST FAILURE NOT CAMPED
- 1059 - LRRC(LTE Radio Resource Control) CONN EST FAILURE SI FAILURE
- 1060 - LRRC(LTE Radio Resource Control) CONN EST FAILURE CONN REJECT
- 1061 - LRRC(LTE Radio Resource Control) CONN REL NORMAL
- 1062 - LRRC(LTE Radio Resource Control) CONN REL RLF
- 1063 - LRRC(LTE Radio Resource Control) CONN REL CRE FAILURE
- 1064 - LRRC(LTE Radio Resource Control) CONN REL OOS DURING CRE
- 1065 - LRRC(LTE Radio Resource Control) CONN REL ABORTED
- 1066 - LRRC(LTE Radio Resource Control) CONN REL SIB READ ERROR
- 1067 - DETACH WITH REATTACH LTE NW DETACH
- 1068 - DETACH WITH OUT REATTACH LTE NW DETACH
- 1069 - ESM(EPS Session Management) PROC TIME OUT
- 1070 - MESSAGE EXCEED MAX L2 LIMIT
- 1500 - CD GEN OR BUSY, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to the reception of a Connection Deny message with a deny code of general or network busy
- 1501 - CD BILL OR AUTH, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to the reception of a Connection Deny message with a deny code of billing failure or authentication failure
- 1502 - CHG HDR, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since there is a change to HDR system due to redirection or PRL not preferred

- 1503 - EXIT HDR, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device exited HDR due to redirection or PRL not preferred
- 1504 - HDR NO SESSION, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device does not have a HDR session
- 1505 - HDR ORIG DURING GPS FIX, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since it is ending an HDR call origination in favor of a GPS fix
- 1506 - HDR CS TIMEOUT, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since connection setup on HDR system timed out
- 1507 - HDR RELEASED BY CM, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) when it wants to release a HDR call so a 1X call can continue
- 1508 - COLLOC ACQ FAIL, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) when device failed to acquire co-located HDR for origination
- 1509 - OTASP COMMIT IN PROG, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since an OTASP commit is in progress
- 1510 - NO HYBR HDR SRV, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device has no Hybrid HDR service
- 1511 - HDR NO LOCK GRANTED, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since HDR module could not get the RF lock
- 1512 - HOLD OTHER IN PROG, this error code is returned when data call is brought down by CM(Call Manager) because DBM or SMS is in progress
- 1513 - HDR FADE, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since HDR module released the call due to fade
- 1514 - HDR ACC FAIL, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to HDR system Access Failure
- 2000 - CLIENT END, this error code is returned when client ends the data call
- 2001 - NO SRV, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since device has no service
- 2002 - FADE, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device lost the system due to fade
- 2003 - REL NORMAL, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to receiving a release from base station with no reason
- 2004 - ACC IN PROG, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to Access attempt already in progress
- 2005 - ACC FAIL, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) due to Access Failure
- 2006 - REDIR OR HANDOFF, this error code is returned when data call is brought down because device is in the process of redirecting/handing off to a different target system
- 2500 - OFFLINE, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device went offline
- 2501 - EMERGENCY MODE, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since device is operating in Emergency mode
- 2502 - PHONE IN USE, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since device is in use (e.g voice call)

- 2503 - INVALID MODE, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since the device's operational mode is different from the mode requested in the traffic channel bring up
- 2504 - INVALID SIM STATE, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since the SIM was marked by network as invalid for circuit and/or packet service domain
- 2505 - NO COLLOC HDR, this error code is returned when data call is brought down because traffic channel got rejected/released by CM(Call Manager) since there is no collocated HDR
- 2506 - CALL CONTROL REJECTED, this error code is returned when data call is brought down because traffic channel request got rejected by CM(Call Manager) since Call control module rejected the request

9.15.2.9 3GPP specification defined call end reasons (Type=6)

- 8 - OPERATOR DETERMINED BARRING, this reason code is posted by the MME(Mobility Management Entity) to indicate operator has barred the UE
- 25 - LLC SNDCP FAILURE, PDP context deactivation initiated by the MS or by the Network
- 26 - INSUFFICIENT RESOURCES, this reason is posted to indicate that the network cannot provide the requested service due to insufficient resources
- 27 - MISSING OR UNKNOWN APN, the APN was required and not specified or APN could not be resolved. In LTE mode of operation, this is a PDN throttling cause code, meaning the UE may endup throttling further requests to the same APN
- 28 - UNKNOWN PDN TYPE, the reason is posted by the network to indicate that the PDN type was not recognized
- 29 - AUTH FAILED, the reason is posted when authentication fails. In LTE mode of operation, this is a PDN throttling cause code, meaning the UE may end up throttling further requests to the same APN
- 30 - GGSN REJECT, the reason is posted when the request was rejected by Serving GW or PDN GW. In LTE mode of operation, this is a PDN throttling cause code, meaning the UE may end up throttling further requests to the same APN
- 31 - ACTIVATION REJECT, the reason is posted when the request is rejected by the network due to unspecified reasons
- 32 - OPTION NOT SUPPORTED, the reason is posted when UE requested a service not supported by the PLMN
- 33 - OPTION UNSUBSCRIBED, This cause is sent when the MS requests a service option for which it has no subscription
- 34 - OPTION TEMP OOO, service option temporarily out of order, this reason is posted when the network is temporarily out of resources to service the request
- 35 - PTI ALREADY USED, the reason is posted to indicate that PTI (Procedure Transaction Identifier) used in the request is already active via another UE requested procedure
- 36 - REGULAR DEACTIVATION, this reason is posted by the network to initiate a regular release of bearer resources
- 37 - EPS QOS NOT ACCEPTED, this reason is posted by the network to indicate that the QoS requested by the UE could not be accepted
- 38 - NETWORK FAILURE, this reason is posted when an error occurs in the network
- 39 - UMTS REACTIVATION REQ, this reason is posted by the network to request for bearer reactivation. This code may be posted during network congestion

- 40 - FEATURE NOT SUPPORTED, Unsuccessful MBMS context activation requested by the network
- 41 - TFT SEMANTIC ERROR, the reason is posted by the network to indicate semantic error(s) in specifying TFT operation included in the request
- 42 - TFT SYNTAX ERROR, the reason is posted by the network to indicate syntactic error(s) in specifying TFT operation included in the request
- 43 - UNKNOWN PDP CONTEXT, the reason is posted when the bearer identity (or linked bearer identity) in the request is invalid (or inactive)
- 44 - FILTER SEMANTIC ERROR, the reason is posted by the network to indicate semantic error(s) in specifying packet filter(s) associated with a TFT
- 45 - FILTER SYNTAX ERROR, the reason is posted by the network to indicate syntactic error(s) in specifying packet filter(s) associated with a TFT
- 46 - PDP WITHOUT ACTIVE TFT, the reason is posted by the network when UW requested more than one PDP connection without TFT
- 50 - IPV4 ONLY ALLOWED, 3GPP equivalent ESM(EPS Session Management) cause code value 50, PDN type IPv4 only allowed.
- 51 - IPV6 ONLY ALLOWED, 3GPP equivalent ESM(EPS Session Management) cause code value 51, PDN type IPv6 only allowed
- 52 - SINGLE ADDRESS BEARER ONLY, 3GPP equivalent ESM(EPS Session Management) cause code value 52, Single address bearers only allowed. The reason is posted when the network supports single address bearers only, meaning dual IP bearers are not supported
- 53 - ESM INFORMATION NOT RECEIVED, 3GPP equivalent ESM(EPS Session Management) cause code value 53, ESM information not received. The reason is posted by the network to indicate that the PDN connection request was rejected because ESM information was not received
- 54 - PND CONNECTION DOES NOT EXIST, 3GPP equivalent ESM(EPS Session Management) cause code value 54, PDN connection does not exist The reason is posted by the network during handover from a non-3GPP network to indicate that the MME does not have any information regarding the requested PDN connection
- 55 - MULTIPLE CONNECTION TO SAME PDN NOT ALLOWED, 3GPP equivalent ESM(EPS Session Management) cause code value 55, Multiple PDN connections for a given APN not allowed. The reason is posted by the network to indicate that the UE is already connected to the requested APN via another PDN/PDN connection
- 81 - INVALID TRANSACTION ID, the reason is posted by the network to indicate that the PTI used in the request is unassigned or reserved
- 95 - MESSAGE INCORRECT SEMANTIC, the reason is posted by the network to indicate receipt of an invalid message
- 96 - INVALID MANDATORY INFO, the reason is posted by the network to indicate receipt of a message with semantic error in a mandatory information element
- 97 - MESSAGE TYPE UNSUPPORTED, the reason is posted by the network to indicate receipt of a message that is either undefined or defined but not implemented by the equipment sending this ESM cause
- 98 - MSG TYPE NONCOMPATIBLE STATE, the reason is posted by the network to indicate receipt of a message type that cannot be handled in the current network protocol state
- 99 - UNKNOWN INFO ELEMENT, the reason is posted by the network to indicate receipt of a message that includes and information element that is either not defined or defined but not implemented by the equipment sending the ESM cause
- 100 - CONDITIONAL IE ERROR, the reason is posted by the network to indicate receipt of a message that includes a syntactically incorrect information element. This message is ignored by the network.

- 101 - MSG AND PROTOCOL STATE UNCOMPATIBLE, the reason is posted by the network to indicate receipt of a message that cannot be handled in the current network protocol state
- 111 - PROTOCOL ERROR, the reason is posted by the network to indicate a protocol error when no other error applies
- 112 - APN TYPE CONFLICT
- 113 - INVALID PROXY-CALL SESSION CONTROL FUNCTION ADDRESS

9.15.2.10 PPP call end reasons (Type=7)

- 1 - TIMEOUT, this error code is returned when the data call bring up fails in PPP setup due to timeout (For e.g: LCP Conf Ack not received from network)
- 2 - AUTH FAILURE, this error code is returned when the data call bring up fails in PPP setup due to authentication failure
- 3 - OPTION MISMATCH, this error code is returned when the data call bring up fails in PPP setup due option mismatch (e.g: Authentication is required, but not negotiated with network during LCP phase)
- 31 - PAP FAILURE, this error code is returned when the data call bring up fails in PPP setup due to PAP failure
- 32 - CHAP FAILURE, this error code is returned when the data call bring up fails in PPP setup due to CHAP failure
- 33 - CLOSE IN PROGRESS, this error code is returned when the data call bring up fails in PPP setup since PPP is in the process of cleaning the previous PPP session
- -1 - UNKNOWN, this error code is unused

9.15.2.11 EHRPD call end reasons (Type=8)

- 1 - SUBS LIMITED TO V4, this error code is returned when the V6 interface bring up fails because network provided only V4 address for the upcoming PDN
- 2 - SUBS LIMITED TO V6, this error code is returned when the V4 interface bring up fails because network provided only V6 address for the upcoming PDN
- 4 - VSNCP(Vendor Specific Network Control Protocol) TIMEOUT, this error code is returned when the data call bring up fails in VSNCP phase due to VSNCP timeout error
- 5 - VSNCP(Vendor Specific Network Control Protocol) FAILURE, this error code is returned when VSNCP configuration failed during call bring up
- 6 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I GEN ERROR, this error code is returned when the data call bring up fails in VSNCP phase due to general error
- 7 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I UNAUTH APN, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason requested APN is unauthorized
- 8 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I PDN LIMIT EXCEED, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason PDN limit exceeded
- 9 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I NO PDN GW, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason no PDN gateway

- 10 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I PDN GW UNREACH, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason PDN gateway unreachable

- 11 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I PDN GW REJ, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason PDN gateway reject

- 12 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I INSUFF PARAM, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason insufficient parameter

- 13 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I RESOURCE UNAVAIL, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason resource unavailable

- 14 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I ADMIN PROHIBIT, this error code is returned when the data call bring up fails in SNCP phase since network rejected VSNCP config request with reason admin prohibited

- 15 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I PDN ID IN USE, this error code is returned when the data call bring up fails in VSNCP phase because network rejected with reason PDN ID IN USE (or) All existing PDNs are brought down with this end reason because one of the PDN bring up got rejected by network with reason PDN ID IN USE

- 16 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I SUBSCR LIMITATION, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason subscriber limitation

- 17 - VSNCP(Vendor Specific Network Control Protocol) 3GPP2I PDN EXISTS FOR THIS APN, this error code is returned when the data call bring up fails in VSNCP phase since network rejected VSNCP config request with reason PDN exists for this APN

9.15.2.12 IPV6 call end reasons (Type=9)

- 1 - PREFIX UNAVAILABLE, this error code is returned when V6 data call is brought down because device failed to get the prefix from network

- 2 - IPV6 ERR HRPD IPV6 DISABLED, this error code is returned when V6 data call bring up is rejected because IPV6 is disabled in 1X/HRPD mode

- 3 - IPV6 DISABLED, this error code is returned when IPv6 data call bring up is rejected because NV1896 (IPV6 enable) is disabled

Copyright: © 2011-2013 Sierra Wireless, Inc. all rights reserved

9.16 qaGobiApiTableCarrierCodes.h File Reference

Carrier Codes table.

9.16.1 Detailed Description

Carrier Codes table.

9.16.2 Carrier Codes (Number - Carrier)

- 0 - no carrier specified
- 1 - Generic
- 2 - Telstra
- 4 - AT&T
- 5 - Verizon
- 11 - Sprint
- 12 - Telefonica
- 101 - Verizon
- 102 - Sprint
- 103 - Alltel
- 104 - Bell Mobility
- 105 - Telus
- 106 - U.S. Cellular
- 107 - Telstra
- 108 - China Unicom
- 109 - Telecom New Zealand
- 110 - SK Telecom
- 111 - Reliance Communications
- 112 - Tata Communications
- 113 - MetroPCS Communications
- 114 - Leap Wireless
- 115 - KDDI
- 116 - Grupo Iusacell
- 117 - China Telecom
- 118 - Open Mobile Handset
- 176 - Rogers
- 177 - NetIndex
- 178 - DNA
- 179 - Big Pond
- 201 - AT&T
- 202 - Vodafone
- 203 - T-Mobile
- 204 - Orange
- 205 - Telefonica

- 206 - Telecom Italia
- 207 - 3
- 208 - O2
- 209 - SFR
- 210 - Swisscom AG
- 211 - China Mobile
- 212 - Telstra
- 213 - Singapore Telecommunications
- 214 - Reliance Telecommunications
- 215 - Bharti Airtel
- 216 - NTT docomo
- 217 - E Mobile
- 218 - Softbank
- 219 - Korea Telecom Freetel
- 220 - SK Telecom
- 221 - Telenor
- 222 - NetCom Norway
- 223 - TeliaSonera
- 224 - América Móvil
- 225 - Brasil Vivo
- 0xFFFFFFFF - Unknown

Copyright: © 2011-2014 Sierra Wireless, Inc. all rights reserved

9.17 qaGobiApiTableCodingScheme.h File Reference

Data Coding Scheme.

Macros

- #define __GOBI_API_CODING_SCHEME_H__

9.17.1 Detailed Description

Data Coding Scheme.

9.17.2 S1

9.17.2.1 Use of bits 3..0\n\n

- Language using the GSM 7 bit default alphabet Bits 3..0
  indicate the language:
  0000 German
  0001 English
  0010 Italian
  0011 French
  0100 Spanish
  0101 Dutch
  0110 Swedish
  0111 Danish
  1000 Portuguese
  1001 Finnish
  1010 Norwegian
  1011 Greek
  1100 Turkish
  1101 Hungarian
  1110 Polish
  1111 Language unspecified

9.17.3 Coding Group Bits 7..4(0001)

9.17.3.1 use of bits 3..0

- 0000 GSM 7 bit default alphabet; message preceded by language indication.
  The first 3 characters of the message are a two-character representation of the language encoded according to ISO 639 [12], followed by a CR character. The CR character is then followed by 90 characters of text.
- 0001 UCS2; message preceded by language indication
  The message starts with a two GSM 7-bit default alphabet character representation of the language encoded according to ISO 639. This is padded to the octet boundary with two bits set to 0 and then followed by 40 characters of UCS2-encoded message.
  An MS not supporting UCS2 coding will present the two character language identifier followed by improperly interpreted user data.

9.17.4 Coding Group Bits 7..4(0010)

9.17.4.1 use of bits 3..0

- 0000 Czech
  0001 Hebrew
  0010 Arabic

0011 Russian
0100 Icelandic
0101..1111 Reserved for other languages using the GSM 7 bit
default alphabet, with unspecified handling at the MS

9.17.5 Coding Group Bits 7..4(0011)

9.17.5.1 use of bits 3..0

- 0000..1111 Reserved for other languages using the GSM 7 bit
  default alphabet, with unspecified handling at the MS

9.17.6 Coding Group Bits 7..4(01xx)

9.17.6.1 use of bits 3..0

- General Data Coding indication
  - Bits 5..0 indicate the following:
  - Bit 5, if set to 0, indicates the text is uncompressed
  - Bit 5, if set to 1, indicates the text is compressed using the compression algorithm defined in 3GPP TS 23.042
  - Bit 4, if set to 0, indicates that bits 1 to 0 are reserved and have no message class meaning
  - Bit 4, if set to 1, indicates that bits 1 to 0 have a message class meaning: Bit 1 Bit 0 Message Class:
    0 0 Class 0
    0 1 Class 1 Default meaning: ME-specific.
    1 0 Class 2 (U)SIM specific message.
    1 1 Class 3 Default meaning: TE-specific (see 3GPP TS 27.005)
    Bits 3 and 2 indicate the character set being used, as follows:
    Bit 3 Bit 2 Character set:
    0 0 GSM 7 bit default alphabet
    0 1 8 bit data
    1 0 UCS2 (16 bit) [10]
    1 1 Reserved

9.17.7 Coding Group Bits 7..4(1001)

9.17.7.1 Reserved coding groups

- Message with User Data Header (UDH) structure:
  Bit 1 Bit 0 Message Class:
  0 0 Class 0
  0 1 Class 1 Default meaning: ME-specific.
  1 0 Class 2 (U)SIM specific message.
  1 1 Class 3 Default meaning: TE-specific (see 3GPP TS 27.005 [8])
  Bits 3 and 2 indicate the alphabet being used, as follows:
  Bit 3 Bit 2 Alphabet:
  0 0 GSM 7 bit default alphabet
  0 1 8 bit data
  1 0 USC2 (16 bit) [10]
  1 1 Reserved

9.17.8 Coding Group Bits 7..4(1010..1101)

9.17.8.1 Reserved coding groups

9.17.9 Coding Group Bits 7..4(1110)

9.17.9.1 Defined by the WAP Forum

9.17.10 Coding Group Bits 7..4 (1111)

9.17.10.1 Data coding / message handling

- Bit 3 is reserved, set to 0.

  Bit 2 Message coding:

  0 GSM 7 bit default alphabet

  1 8 bit data

  Bit 1 Bit 0 Message Class:

  0 0 No message class.

  0 1 Class 1 user defined.

  1 0 Class 2 user defined.

  1 1 Class 3

  default meaning: TE specific(3GPP TS 27.005)

  Copyright: © 2012 Sierra Wireless, Inc. all rights reserved

9.17.11 Macro Definition Documentation

9.17.11.1 #define __GOBI_API_CODING_SCHEME_H__

9.18 qaGobiApiTableGpsCapabilityCodes.h File Reference

Position Determination Service API GPS Capability Codes.

9.18.1 Detailed Description

Position Determination Service API GPS Capability Codes.

9.18.2 GPS capability (Value - Capability)

- 0 - None
- 1 - Standalone
- 2 - Assisted (including XTRA and implying standalone is also supported)
- 3 - Assisted (without XTRA and implying standalone is also supported)
- 0xFFFFFFFF - Unknown

Copyright: © 2011 Sierra Wireless, Inc. all rights reserved

9.19 qaGobiApiTablePowerModes.h File Reference

Device Management Service API Power Modes table.

9.19.1 Detailed Description

Device Management Service API Power Modes table.

9.19.2 Power Modes (Value - Description)

- 0 - Online (default)
- 1 - Low power (airplane) mode
- 2 - Factory test mode
- 3 - Offline
- 4 - Resetting
- 5 - Power off
- 6 - Persistent low power (airplane) mode
- 7 - Mode - only low power

Valid transitions for Power Modes

- Online to Low Power, Persistent low power, Factory test, Offline or Shut Down
- Low power to online, Persistent low power, Offline, or Shut Down
- Persistent low power to Online, Low power, Offline or Shut down
- Factory test to online
- Offline to Reset

Copyright: © 2011 Sierra Wireless, Inc. all rights reserved

9.20 qaGobiApiTableRadioInterfaces.h File Reference

Network Access Service API Radio Interfaces table.

9.20.1 Detailed Description

Network Access Service API Radio Interfaces table.

9.20.2 Radio interface

9.20.2.1 Technology (Value - Radio Interface Technology)

- 0 - No service
- 1 - CDMA 1xRTT
- 2 - CDMA 1xEV-DO

- 3 - AMPS (Unsupported)
- 4 - GSM
- 5 - UMTS
- 6 - WLAN
- 7 - GPS
- 8 - LTE
- 9 - TD-SCDMA
- 12 - NR5G

Copyright: © 2011 Sierra Wireless, Inc. all rights reserved

9.21 qaGobiApiTableRegionCodes.h File Reference

Region Codes table.

9.21.1 Detailed Description

Region Codes table.

9.21.2 Region Codes (Code - Region)

- 0 - North America
- 1 - Latin America
- 2 - Europe
- 3 - Asia
- 4 - Australia
- 5 - Global
- 0xFFFFFFFF - Unknown

Copyright: © 2011 Sierra Wireless, Inc. all rights reserved

9.22 qaGobiApiTableServiceOptions.h File Reference

Voice Service Options.

9.22.1 Detailed Description

Voice Service Options.

9.22.2 Service Option codes (Code - Reason)

9.22.2.1 Description

- 0x0001 - Basic variable rate voice service (8 kbps)
- 0x0002 - Mobile station loopback (8 kbps)
- 0x0003 - Enhanced variable rate voice service (8 kbps)
- 0x0004 - Asynchronous data service (9.6 kbps)
- 0x0005 - Group 3 facsimile (9.6 kbps)
- 0x0006 - Short message service (rate set 1)
- 0x0007 - Packet data service: Internet or ISO Protocol stack (9.6 kbps)
- 0x0008 - Packet data service: CDPD Protocol stack (9.6 kbps)
- 0x0009 - Mobile station loopback (13 kbps)
- 0x000A - transparent service
- 0x000B - III nontransparent service
- 0x000C - Asynchronous data service (14.4 or 9.6 kbps)
- 0x000D - Group 3 facsimile (14.4 or 9.6 kbps)
- 0x000E - Short message service (rate set 2)
- 0x000F - Packet data service: Internet or ISO Protocol stack (14.4 kbps)
- 0x0010 - Packet data service: CDPD Protocol stack (14.4 kbps)
- 0x0011 - High-rate voice service (13 kbps)
- 0x0012 - Over-the-air parameter administration (rate set 1)
- 0x0013 - Over-the-air parameter administration (rate set 2)
- 0x0014 - Group 3 analog facsimile (rate set 1)
- 0x0015 - Group 3 analog facsimile (rate set 2)
- 0x0016 - High-speed packet data service: Internet or ISO Protocol stack (RS1 forward, RS1 reverse)
- 0x0017 - High-speed packet data service: Internet or ISO Protocol stack (RS1 forward, RS2 reverse)
- 0x0018 - High-speed packet data service: Internet or ISO Protocol stack (RS2 forward, RS1 reverse)
- 0x0019 - High-speed packet data service: Internet or ISO Protocol stack (RS2 forward, RS2 reverse)
- 0x001A - High-speed packet data service: CDPD Protocol stack (RS1 forward, RS1 reverse)
- 0x001B - High-speed packet data service: CDPD Protocol stack (RS1 forward, RS2 reverse)
- 0x001C - High-speed packet data service: CDPD Protocol stack (RS2 forward, RS1 reverse)
- 0x001D - High-speed packet data service: CDPD Protocol stack (RS2 forward, RS2 reverse)
- 0x001E - RATE_SET_1 Supplemental channel loopback test for rate set 1
- 0x001F - RATE_SET_2 Supplemental channel loopback test for rate set 2
- 0x0020 - Test Data Service Option (TDSO)
- 0x0021 - cdma2000 high-speed packet data service, Internet or ISO Protocol stack

- 0x0022 - cdma2000 high-speed packet data service, CDPD Protocol
- 0x0023 - Location services, rate set 1 (9.6 kbps)
- 0x0024 - Location services, rate set 2 (14.4 kbps)
- 0x0025 - ISDN interworking service (64 kbps)
- 0x0026 - GSM voice
- 0x0027 - GSM circuit data
- 0x0028 - GSM packet data
- 0x0029 - GSM short message service
- 0x0036 - Markov Service Option (MSO)
- 0x0037 - Loopback Service Option (LSO)
- 0x0038 - Selectable mode vocoder
- 0x0039 - 32 kbps circuit video conferencing
- 0x003A - CONFERENCING 64 kbps circuit video conferencing
- 0x003B - HRPD packet data service, which when used in paging over the 1X air interface, a page response is not required
- 0x003C - Link Layer Assisted Robust Header Compression (LLA ROHC) - header removal
- 0x003D - LLA ROHC - Header Compression
- 0x003E - Source-controlled Variable-Rate Multimode Wideband (VMR-WB) speech codec rate set 2
- 0x003F - Source-controlled VMR-WB speech codec rate set 1
- 0x0040 - HRPD auxiliary packet data service instance
- 0x0041 - cdma2000/GPRS interworking
- 0x0042 - ISO_PROTOCOL_SO_66 cdma2000 high-speed packet data service, Internet or ISO Protocol stack
- 0x0043 - HRPD packet data IP service where higher layer protocol is IP or ROHC
- 0x0044 - Enhanced variable rate voice service (EVRC-B)
- 0x0045 - HRPD packet data service, which when used in paging over the 1X air interface, a page response is required
- 0x0046 - Enhanced variable rate voice service (EVRC-WB)
- 0x1004 - Asynchronous data service, Revision 1 (9.6 or 14.4 kbps)
- 0x1005 - Group 3 facsimile, Revision 1 (9.6 or 14.4 kbps)
- 0x1007 - Packet data service: Internet or ISO Protocol stack, Revision 1 (9.6 or 14.4 kbps)
- 0x1008 - Packet data service: CDPD Protocol stack, Revision 1 (9.6 or 14.4 kbps)
- 0x7FF8 - Identifies service reference identifier 0
- 0x7FF9 - Identifies service reference identifier 1
- 0x7FFA - Identifies service reference identifier 2
- 0x7FFB - Identifies service reference identifier 3
- 0x7FFC - Identifies service reference identifier 4
- 0x7FFD - Identifies service reference identifier 5

- 0x7FFE - Identifies service reference identifier 6
- 0x7FFF - Identifies service reference identifier 7

Copyright: © 2012 Sierra Wireless, Inc. all rights reserved

9.23 qaGobiApiTableSupServiceInfoClasses.h File Reference

Voice Supplementary Service Information Classes.

9.23.1 Detailed Description

Voice Supplementary Service Information Classes.

9.23.2 Supplementary Service Information Classes (Value - Service Class)

- 0X00 - CLASS_NONE
- 0X01 - CLASS_VOICE
- 0X02 - CLASS_DATA
- 0X04 - CLASS_FAX
- 0X08 - CLASS_SMS
- 0X10 - CLASS_DATACIRCUITSYNC
- 0X20 - CLASS_DATACIRCUITASYNC
- 0X40 - CLASS_PACKETACCESS
- 0X80 - CLASS_PADACCESS

Copyright: © 2012 Sierra Wireless, Inc. all rights reserved

9.24 qaGobiApiTableSwiAudio.h File Reference

Swi Audio related tables.

9.24.1 Detailed Description

Swi Audio related tables.

9.24.2 ACDB Device (Device ID - description)

- 0 - Vehicle HF
- 1 - Handset
- 2 - TTY
- 3 - USB
- 4 - NA

9.24.3 Physical Interface (Device ID - description - Interface parameters)

- 0 - PCM - Mode: 0-slave, 1-master, 2-Auxiliary PCM; Rate: 0-8k, 1-16k; Format: 0-linear, 1-u-law, 2-A-law; Padding: 0-disable, 1-enable; Bits-frame: 0-8BPF, 1-16BPF, 2-32BPF, 3-64BPF, 4-128BPF, 5-256BPF;
- 1 - I2S - None
- 2 - Analog(with internal codec) - None
- 3 - USB - None

Copyright: © 2013 Sierra Wireless, Inc. all rights reserved

9.25 qaGobiApiTableSwiOMADMSessionStatus.h File Reference

Session Status table.

9.25.1 Detailed Description

Session Status table.

9.25.2 OMA DM Session Status (Session Status - Meaning - Usage)

- 0x0000 - Successful - Session succeeded
- 0x0001 - Break - Session succeeded
- 0x0002 - Large Object Handled - Session succeeded
- 0x0003 - No status - Session succeeded
- 0x0004 - No more commands - Session succeeded
- 0x0005 - User cancel - Session cancelled
- 0x0100-0x01FF - General errors
- 0x0200-0x02FF - Syncml errors
- 0x0300-0x03FF - Authentication errors
- 0x0400-0x04FF - Protocol errors
- 0x0500-0x05FF - Tree errors (DM Only)
- 0x0600-0x06FF - Not applicable
- 0x0700-0x07FF - Trigger errors
- 0x0800-0x08FF - FUMO errors
- 0x0900-0x09FF - Communication errors
- 0x0A00-0x0AFF - Parsing errors
- 0x0B00-0x0CFF - Not applicable
- 0x7F00-0x7F12 - Insignia errors
- 0x7F13 - Illegal text - Text received contains illegal characters
- 0x7F14 - Download failure - Failed to download FOTA image

- 0x7F15 - Empty session - Session ran successfully, but no information was updated
- 0x7F16 - Factory reset successful - Factory reset succeeded
- 0x7F17 - Factory reset fail - Factory reset failed

Copyright: © 2017 Sierra Wireless, Inc. all rights reserved

9.26 qaGobiApiTableSwiOMADMUpdateCompleteStatus.h File Reference

Update Complete Status table.

9.26.1 Detailed Description

Update Complete Status table.

9.26.2 OMA DM Update Complete Status (Update Complete Status - Meaning - Usage)

- 200 - Successful - The request has succeeded
- 250-299 - Successful(vendor specified) - successful operation with vendor specified ResultCode
- 400 - Management Client Error - Management Client error - based on User or Device behavior
- 401 - User Cancelled - User chose not to accept the operation when prompted
- 402 - Corrupted Firmware Update Package - Corrupted firmware update package did not store correctly. Detected for example, by mismatch CRCs between actual and expected
- 403 - Firmware UpdatePackage(Device Mismatch) - Wrong firmware update package delivered to device based on current device characteristics
- 404 - Failed Firmware Update Package Validation - Failure to positively validate digital signature of firmware update package
- 405 - Firmware Update Package Not acceptable - firmware update package is not acceptable
- 406 - Alternate Download Authentication Failure - authentication required but authentication failure was encountered when downloading firmware update package
- 407 - Alternate Download Request Timeout - client has encountered a timeout when downloading firmware update package
- 408 - Not Implemented - the device does not support the requested operation
- 409 - Undefined Error - indicates failure not defined by any other error code
- 410 - Firmware Update Failed - firmware update operation failed in device
- 411 - Malformed or Bad URL - the URL provided for alternate download is bad
- 412 - Alternate Download Server Unavailable - the alternate download server is unavailable or does not respond
- 450 - Client Error (OMADM General) - Vendor defined client error
- 451 - Client Error (OMADM SyncML) - Vendor defined client error
- 452 - Client Error (OMADM Auth) - Vendor defined client error
- 453 - Client Error (OMADM Protocol)- Vendor defined client error

- 454 - Client Error (OMADM Tree) - Vendor defined client error
- 455 - Client Error (OMADM DStore) - Vendor defined client error
- 456 - Client Error (OMADM Trigger) - Vendor defined client error
- 457 - Client Error (OMADM Fumo) - Vendor defined client error
- 458 - Client Error (OMADM Comms) - Vendor defined client error
- 459 - Client Error (OMADM Parse) - Vendor defined client error
- 460 - Client Error (OMADM TNDS) - Vendor defined client error
- 461 - Client Error (OMADM SCM) - Vendor defined client error
- 462 - Client Error (OMADM Impl) - Vendor defined client error
- 463-499 - Client Error (Vendor Specified) - client error encountered for operation with vendor specified result code
- 500 - Alternate Download Server Error - Alternate download server error encountered
- 501 - Download fails due to device out of memory - The download fails due to insufficient memory in the device to save the firmware update package
- 502 - Firmware update fails due to device out of memory - The update fails because there isn't sufficient memory to update the device
- 503 - Download fails due to network issues - The download fails due to network/transport level errors
- 550-599 - Alternate Download Server Error (vendor specified)- Alternate download server error encountered for operation with vendor specified result code

Copyright: © 2013 Sierra Wireless, Inc. all rights reserved

9.27 qaGobiApiTableVoiceCallEndReasons.h File Reference

Voice Service Call and supplementary services end reasons.

9.27.1 Detailed Description

Voice Service Call and supplementary services end reasons.

9.27.2 Voice Call and supplementary services end reason codes (Code - Reason)

9.27.2.1 General

- 0 - Phone is offline
- 20 - Phone is CDMA locked until a power cycle; CDMA only
- 21 - Phone has no service, this is for backward compatibility
- 22 - Call has ended abnormally; CDMA only
- 23 - Received intercept from the base station; originating only; CDMA only
- 24 - Received reorder from the base station; originating only; CDMA only
- 25 - Received release from the base station; no reason was given

- 26 - Received release from the base station; SO reject; CDMA only
- 27 - Received incoming call from the base station
- 28 - Received alert stop from the base station; incoming only; CDMA only
- 29 - Client ended the call
- 30 - Received end activation; OTASP call only; CDMA only
- 31 - MC aborted the origination/conversation; CDMA only
- 32 - Maximum access probes were transmitted; CDMA only
- 33 - Persistence test failure; FEATURE_JCDMA only; CDMA only
- 34 - R-UIM is not present
- 35 - Access attempt is already in progress
- 36 - Access failure for a reason other than the above
- 37 - Received retry order; originating only; IS 2000; CDMA only
- 38 - BYBS Concurrent service is not supported by the base station
- 39 - No response was received from the base station
- 40 - Call was rejected by the base station; CDMA only
- 41 - Concurrent services requested were not compatible; CDMA only
- 42 - Access is blocked by the base station; CDMA only
- 43 - Corresponds to CM_CALL_ORIG_ ERR_ALREADY_IN_TC
- 44 - Call is ended because an emergency call is flashed over this call; CDMA only
- 45 - Used if CM is ending a GPS call in preference of a user call
- 46 - Used if CM is ending an SMS call in preference of a user call
- 47 - Used if CM is ending a data call in preference of an emergency call
- 48 - Call was rejected because of a redirection or handoff
- 49 - Access is blocked by the base station for all mobiles; KDDI-specific; CDMA only
- 50 - To support OTASP SPC Error indication
- 51 - Maximum access probes for an IS-707B call; CDMA only
- 52 - Base station reject order
- 53 - Base station retry order
- 54 - Timer T42 is expired
- 55 - Timer T40 is expired
- 56 - Service initialization failure - Traffic Channel Initialization
- 57 - Timer T50m is expired - Traffic Channel Initialization
- 58 - Timer T51m is expired - Traffic Channel Initialization
- 59 - Acknowledgement timeout due to 12 retransmissions
- 60 - Bad forward link or timer T5M is expired
- 61 - Transceiver Resource Manager request failed

- 62 - Timer T41 is expired
- 100 - WCDMA/GSM/TDS only; call end LL cause, Received a reason for ending the call from the lower layer
- 101 - WCDMA/GSM only; Call origination request failed
- 102 - WCDMA/GSM only; client rejected an incoming call
- 103 - WCDMA/GSM only; client rejected a setup indication
- 104 - WCDMA/GSM only; network ended the call
- 105 - WCDMA/GSM only
- 106 - GWM/WCDMA only; phone has no service
- 107 - 1X only; phone has no service
- 108 - Full service is unavailable
- 109 - Indicates resources are not available to handle a new MO/MT PS call

9.27.2.2 service Errors

- 110 - Unknown subscriber
- 111 - Illegal subscriber
- 112 - Bearer service not provisioned
- 113 - Tele service not provisioned
- 114 - Illegal equipment
- 115 - Call barred
- 116 - Illegal ss operation
- 117 - Ss error status
- 118 - Ss not available
- 119 - Ss subscription violation
- 120 - Ss incompatibility
- 121 - Facility not supported
- 122 - Absent subscriber
- 123 - Short term denial
- 124 - Long term denial
- 125 - System failure
- 126 - Data missing
- 127 - Unexpected data value
- 128 - Pwd registration failure
- 129 - Negative pwd check
- 130 - Num of pwd attempts violation
- 131 - Position method failure
- 132 - Unknown alphabet

- 133 - Ussd busy
- 134 - Rejected by user
- 135 - Rejected by network
- 136 - Deflection to served subscriber
- 137 - Special service code
- 138 - Invalid deflected to number
- 139 - Mpty participants exceeded
- 140 - Resources not available

9.27.2.3 control cause values

- 141 - Unassigned number
- 142 - No route to destination
- 143 - Channel unacceptable
- 144 - Operator determined barring
- 145 - Normal call clearing
- 146 - User busy sEE [s3, aNNEX h]
- 147 - No user responding sEE [s3, aNNEX h]
- 148 - User alerting no answer
- 149 - Call rejected sEE [s3, aNNEX h]
- 150 - Number changed sEE [s3, aNNEX h]
- 151 - Preemption sEE [s3, aNNEX h]
- 152 - Destination out of order
- 153 - Invalid number format
- 154 - Facility rejected
- 155 - Resp to status enquiry
- 156 - Normal unspecified
- 157 - No circuit or channel available
- 158 - Network out of order
- 159 - Temporary failure
- 160 - Switching equipment congestion
- 161 - Access information discarded
- 162 - Requested circuit or channel not available
- 163 - Resources unavailable or unspecified
- 164 - Qos unavailable
- 165 - Requested facility not subscribed
- 166 - Incoming calls barred within cug

- 167 - Bearer capability not auth
- 168 - Bearer capability unavailable
- 169 - Service option not available
- 170 - Acm limit exceeded
- 171 - Bearer service not implemented
- 172 - Requested facility not implemented
- 173 - Only digital information bearer available
- 174 - Service or option not implemented
- 175 - Invalid transaction identifier
- 176 - USER NOT MEMBER OF CUG
- 177 - Incompatible destination
- 178 - Invalid transit nw selection
- 179 - Semantically incorrect message
- 180 - Invalid mandatory information
- 181 - Message type non implemented
- 182 - Message type not compatible with protocol statE
- 183 - Information element non existent
- 184 - Conditonal ie error
- 185 - Message not compatible with protocol state
- 186 - Recovery on timer expired
- 187 - Protocol error unspecified
- 188 - Interworking unspecified
- 189 - Outgoing calls barred within cug
- 190 - No cug selection
- 191 - Unknown cug index
- 192 - Cug index incompatible
- 193 - Cug call failure unspecified
- 194 - Clir not subscribed
- 195 - Ccbs possible sEE
- 196 - Ccbs not possible

9.27.2.4 reject causes

- 197 - Imsi unknown in hlr
- 198 - Illegal ms
- 199 - Imsi unknown in vlr
- 200 - Imei not accepted
- 201 - Illegal me sEE
- 202 - Plmn not allowed
- 203 - Location area not allowed
- 204 - Roaming not allowed in this location area
- 205 - No suitable cells in location area
- 206 - Network failure sEE
- 207 - mac failure sEE
- 208 - Synch failure
- 209 - Network congestion
- 210 - GSM authentication unacceptable
- 211 - Service not subscribed
- 212 - Service temporarily out of order
- 213 - Call cannot be identified
- 214 - Incorrect semantics in message
- 215 - Mandatory information invalid
- 216 - Call failed due to other access stratum failures
- 217 - SIM is invalid
- 218 - Invalid call state
- 219 - Access class is blocked
- 220 - No resources are in the protocol stack to allow the call
- 221 - Invalid user data was received

9.27.2.5 reject causes

- 222 - Timer T3230 is expired
- 223 - No cell is available
- 224 - Abort message was received
- 225 - Radio link was lost due to other lower layer causes

9.27.2.6 reject causes

- 226 - Timer T303 is expired
- 227 - CNM MM release is pending

9.27.2.7 stratum reject causes

- 228 - Access stratum RR release indication
- 229 - Access stratum random access failure
- 230 - RRC_REL_IND Access stratum RRC release indication
- 231 - Access stratum close session indication
- 232 - Access stratum open session failure
- 233 - Access stratum low level failure
- 234 - Access stratum low level failure redial is not allowed
- 235 - Access stratum low level immediate retry
- 236 - Access stratum abort radio is unavailable

9.27.2.8 reject causes

- 237 - Service option is not supported

9.27.2.9 IP end reasons

- 300 - Received SIP 400 bad request;waiting for INVITE response
- 301 - Received SIP 400 bad request;waiting for INVITE response
- 302 - Received SIP 404 not found; call failed; called party does not exist
- 303 - Received SIP 415 unsupported media type; call failed; called party does not support media
- 304 - Received SIP 480 temporarily unavailable; call failed; called party is not in the LTE area
- 305 - No network response; call failed
- 306 - No network response; unable to put call on hold
- 307 - Moved to eHRPD; call failed or dropped; not in the LTE area
- 308 - Upgrade/downgrade rejected (200 OK with the current call SDP)
- 309 - Received 403 call forbidden; waiting for INVITE response
- 310 - Generic timeout; did not receive a response from the server or other end
- 311 - Reported on the MO side for generic internal software errors; user can try again if the call still exists
- 312 - Reported on the MT side if the upgrade timer has been cancelled or cannot complete the request for some reason after notifying the user of a re-invite request
- 313 - Call origination is rejected due to a Service-Specific Access Control (SSAC) barring
- 314 - Phone was put in thermal emergency
- 315 - 1XCSFB call ended because of a soft failure
- 316 - 1XCSFB call ended because of a hard failure

Copyright: © 2012 Sierra Wireless, Inc. all rights reserved

9.28 qmerrno.h File Reference

Enumerations

- enum eQCWWANError {
  eQCWWAN_ERR_ENUM_BEGIN = -1,
  eQCWWAN_ERR_NONE,
  eQCWWAN_ERR_GENERAL,
  eQCWWAN_ERR_INTERNAL,
  eQCWWAN_ERR_MEMORY,
  eQCWWAN_ERR_INVALID_ARG,
  eQCWWAN_ERR_BUFFER_SZ,
  eQCWWAN_ERR_NO_DEVICE,
  eQCWWAN_ERR_INVALID_DEVID,
  eQCWWAN_ERR_NO_CONNECTION,
  eQCWWAN_ERR_QMI_IFACE,
  eQCWWAN_ERR_QMI_CONNECT,
  eQCWWAN_ERR_QMI_REQ_SCH,
  eQCWWAN_ERR_QMI_REQ,
  eQCWWAN_ERR_QMI_RSP,
  eQCWWAN_ERR_QMI_REQ_TO,
  eQCWWAN_ERR_QMI_RSP_TO,
  eQCWWAN_ERR_MALFORMED_QMI_RSP,
  eQCWWAN_ERR_INVALID_QMI_RSP,
  eQCWWAN_ERR_INVALID_FILE,
  eQCWWAN_ERR_FILE_OPEN,
  eQCWWAN_ERR_FILE_COPY,
  eQCWWAN_ERR_OFFLINE = 27,
  eQCWWAN_ERR_RESET,
  eQCWWAN_ERR_NO_SIGNAL,
  eQCWWAN_ERR_MULTIPLE_DEVICES,
  eQCWWAN_ERR_DRIVER,
  eQCWWAN_ERR_NO_CANCELABLE_OP,
  eQCWWAN_ERR_CANCEL_OP,
  eQCWWAN_ERR_API_MUTEX_TIMEOUT,
  eQCWWAN_ERR_PDU_GENERATION,
  eQCWWAN_ERR_INVALID_XID,
  eQCWWAN_ERR_MULTIPLE_SMS_UNSUPPORTED,
  eQCWWAN_ERR_ENUM_END,
  eQCWWAN_ERR_QMI_OFFSET = 1000,
  eQCWWAN_ERR_QMI_MALFORMED_MSG = 1001,
  eQCWWAN_ERR_QMI_NO_MEMORY,
  eQCWWAN_ERR_QMI_INTERNAL,
  eQCWWAN_ERR_QMI_ABORTED,
  eQCWWAN_ERR_QMI_CLIENT_IDS_EXHAUSTED,
  eQCWWAN_ERR_QMI_UNABORTABLE_TRANSACTION,
  eQCWWAN_ERR_QMI_INVALID_CLIENT_ID,
  eQCWWAN_ERR_QMI_NO_THRESHOLDS,
  eQCWWAN_ERR_QMI_INVALID_HANDLE,
  eQCWWAN_ERR_QMI_INVALID_PROFILE,
  eQCWWAN_ERR_QMI_INVALID_PINID,
  eQCWWAN_ERR_QMI_INCORRECT_PIN,
  eQCWWAN_ERR_QMI_NO_NETWORK_FOUND,
  eQCWWAN_ERR_QMI_CALL_FAILED,
  eQCWWAN_ERR_QMI_OUT_OF_CALL,
  eQCWWAN_ERR_QMI_NOT_PROVISIONED,
  eQCWWAN_ERR_QMI_MISSING_ARG,
  eQCWWAN_ERR_QMI_ARG_TOO_LONG = 1019,
  eQCWWAN_ERR_QMI_INVALID_TX_ID = 1022,
  eQCWWAN_ERR_QMI_DEVICE_IN_USE,
  eQCWWAN_ERR_QMI_OP_NETWORK_UNSUPPORTED,
  eQCWWAN_ERR_QMI_OP_DEVICE_UNSUPPORTED,
  eQCWWAN_ERR_QMI_NO_EFFECT,
  eQCWWAN_ERR_QMI_NO_FREE_PROFILE,
  eQCWWAN_ERR_QMI_INVALID_PDP_TYPE,
  eQCWWAN_ERR_QMI_INVALID_TECH_PREF,
  eQCWWAN_ERR_QMI_INVALID_PROFILE_TYPE,

eQCWWAN_ERR_QMI_WIDTH = 0xFFFF }
- enum qm_wds_ds_profile_extended_err_codes {
  eWDS_ERR_PROFILE_REG_RESULT_FAIL = 1,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_HNDL,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_OP,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_TYPE,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_NUM,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_IDENT,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_LIB_NOT_INITED,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_LEN_INVALID,
  eWDS_ERR_PROFILE_REG_RESULT_LIST_END,
  eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_SUBS_ID,
  eWDS_ERR_PROFILE_REG_INVAL_PROFILE_FAMILY,
  eWDS_ERR_PROFILE_REG_3GPP_INVAL_PROFILE_FAMILY = 1001,
  eWDS_ERR_PROFILE_REG_3GPP_ACCESS_ERR,
  eWDS_ERR_PROFILE_REG_3GPP_CONTEXT_NOT_DEFINED,
  eWDS_ERR_PROFILE_REG_3GPP_VALID_FLAG_NOT_SET,
  eWDS_ERR_PROFILE_REG_3GPP_READ_ONLY_FLAG_SET,
  eWDS_ERR_PROFILE_REG_3GPP_ERR_OUT_OF_PROFILES,
  eWDS_ERR_PROFILE_REG_3GPP2_ERR_INVALID_IDENT_FOR_PROFILE = 1101,
  eWDS_ERR_PROFILE_REG_END }

9.28.1 Enumeration Type Documentation

9.28.1.1 enum eQCWWANError

QMI Error Code Enumeration

Enumerator

eQCWWAN_ERR_ENUM_BEGIN

eQCWWAN_ERR_NONE 00 - Success

eQCWWAN_ERR_GENERAL 01 - General error

eQCWWAN_ERR_INTERNAL 02 - Internal error

eQCWWAN_ERR_MEMORY 03 - Memory error

eQCWWAN_ERR_INVALID_ARG 04 - Invalid argument

eQCWWAN_ERR_BUFFER_SZ 05 - Buffer too small

eQCWWAN_ERR_NO_DEVICE 06 - Unable to detect WWAN device

eQCWWAN_ERR_INVALID_DEVID 07 - Invalid WWAN device ID

eQCWWAN_ERR_NO_CONNECTION 08 - No connection to WWAN device

eQCWWAN_ERR_QMI_IFACE 09 - Unable to obtain QMI interace

eQCWWAN_ERR_QMI_CONNECT 10 - Unable to connect to QMI interface

eQCWWAN_ERR_QMI_REQ_SCH 11 - Unable to schedule QMI request

eQCWWAN_ERR_QMI_REQ 12 - Error sending QMI request

eQCWWAN_ERR_QMI_RSP 13 - Error receiving QMI response

eQCWWAN_ERR_QMI_REQ_TO 14 - Timeout while sending QMI request

eQCWWAN_ERR_QMI_RSP_TO 15 - Timeout while receiving QMI response

eQCWWAN_ERR_MALFORMED_QMI_RSP 16 - Malformed QMI response received

eQCWWAN_ERR_INVALID_QMI_RSP 17 - Invalid QMI response received

eQCWWAN_ERR_INVALID_FILE 18 - Invalid file path

eQCWWAN_ERR_FILE_OPEN 19 - Unable to open file

eQCWWAN_ERR_FILE_COPY 20 - Unable to copy file

eQCWWAN_ERR_OFFLINE 27 - Unable to set WWAN device offline

eQCWWAN_ERR_RESET 28 - Unable to reset WWAN device

eQCWWAN_ERR_NO_SIGNAL 29 - No available signal

eQCWWAN_ERR_MULTIPLE_DEVICES 30 - Multiple WWAN devices detected

eQCWWAN_ERR_DRIVER 31 - Error interfacing to driver

eQCWWAN_ERR_NO_CANCELABLE_OP 32 - No cancelable operation is pending

eQCWWAN_ERR_CANCEL_OP 33- Error canceling outstanding operation

eQCWWAN_ERR_API_MUTEX_TIMEOUT 34- api mutex lock timeout

eQCWWAN_ERR_PDU_GENERATION 35- PDU generation error

eQCWWAN_ERR_INVALID_XID 36- Invalid transaction id

eQCWWAN_ERR_MULTIPLE_SMS_UNSUPPORTED 37- Unsupported multiple SMS

eQCWWAN_ERR_ENUM_END End of SLQS SDK specific error codes

eQCWWAN_ERR_QMI_OFFSET 1000 - This is not an error code but the offset from which mapped QMI error codes start from

eQCWWAN_ERR_QMI_MALFORMED_MSG 1001 - Malformed or Corrupted QMI msg

eQCWWAN_ERR_QMI_NO_MEMORY 1002 - Device could not allocate memory for QMI Resp

eQCWWAN_ERR_QMI_INTERNAL 1003 - Unexpected error occurred during processing

eQCWWAN_ERR_QMI_ABORTED 1004 - Processing aborted

eQCWWAN_ERR_QMI_CLIENT_IDS_EXHAUSTED 1005 - QMI client IDs have been exhausted

eQCWWAN_ERR_QMI_UNABORTABLE_TRANSACTION 1006 - Unable to abort QMI transaction

eQCWWAN_ERR_QMI_INVALID_CLIENT_ID 1007 - Invalid QMI client ID

eQCWWAN_ERR_QMI_NO_THRESHOLDS 1008 - No thresholds were provided

eQCWWAN_ERR_QMI_INVALID_HANDLE 1009 - Invalid Handle provided in the QMI request

eQCWWAN_ERR_QMI_INVALID_PROFILE 1010 - Profile specified is invalid

eQCWWAN_ERR_QMI_INVALID_PINID 1011 - Invalid PIN ID specified

eQCWWAN_ERR_QMI_INCORRECT_PIN 1012 - Incorrect PIN ID specified

eQCWWAN_ERR_QMI_NO_NETWORK_FOUND 1013 - No network found

eQCWWAN_ERR_QMI_CALL_FAILED 1014 - Call failed

eQCWWAN_ERR_QMI_OUT_OF_CALL 1015 - Device is not in a call

eQCWWAN_ERR_QMI_NOT_PROVISIONED 1016 - Requested information element not provisioned on device

eQCWWAN_ERR_QMI_MISSING_ARG 1017 - Mandatory QMI TLV not provided

eQCWWAN_ERR_QMI_ARG_TOO_LONG 1019 - Arg passed in QMI TLV larger than available storage in device

eQCWWAN_ERR_QMI_INVALID_TX_ID 1022 - Invalid TX ID specified

eQCWWAN_ERR_QMI_DEVICE_IN_USE 1023 - Device currently in a call

eQCWWAN_ERR_QMI_OP_NETWORK_UNSUPPORTED 1024 - The selected operation is not supported by the network

eQCWWAN_ERR_QMI_OP_DEVICE_UNSUPPORTED 1025 - The selected operation is not supported by the device

eQCWWAN_ERR_QMI_NO_EFFECT 1026 - Requested operation would have no effect

eQCWWAN_ERR_QMI_NO_FREE_PROFILE 1027 - No space for a profile is available

eQCWWAN_ERR_QMI_INVALID_PDP_TYPE 1028 - Invalid PDP type specified

eQCWWAN_ERR_QMI_INVALID_TECH_PREF 1029 - Invalid technology preference specified

eQCWWAN_ERR_QMI_INVALID_PROFILE_TYPE 1030 - Invalid profile type specified

eQCWWAN_ERR_QMI_INVALID_SERVICE_TYPE 1031 - Invalid service type specified

eQCWWAN_ERR_QMI_INVALID_REGISTER_ACTION 1032 - Invalid register action specified

eQCWWAN_ERR_QMI_INVALID_PS_ATTACH_ACTION 1033 - Invalid PS attach/detach action specified

eQCWWAN_ERR_QMI_AUTHENTICATION_FAILED 1034 - Authentication of supplied information element failed

eQCWWAN_ERR_QMI_PIN_BLOCKED 1035 - PIN is blocked; an unblock operation needs to be issued

eQCWWAN_ERR_QMI_PIN_PERM_BLOCKED 1036 - PIN is permanently blocked; the UIM is unusable

eQCWWAN_ERR_QMI_SIM_NOT_INITIALIZED 1037 - UIM initialization has not completed

eQCWWAN_ERR_QMI_MAX_QOS_REQUESTS_IN_USE 1038 - Max QOS requests are used

eQCWWAN_ERR_QMI_INCORRECT_FLOW_FILTER 1039 - The Flow filter is incorrect

eQCWWAN_ERR_QMI_NETWORK_QOS_UNAWARE 1040 - Network unaware of the QOS requested

eQCWWAN_ERR_QMI_INVALID_ID 1041 - Invalid QOS ID

eQCWWAN_ERR_QMI_INVALID_QOS_ID 1041 - Invalid QOS ID

eQCWWAN_ERR_QMI_REQUESTED_NUM_UNSUPPORTED 1042 - The request number is not supported

eQCWWAN_ERR_QMI_INTERFACE_NOT_FOUND 1043 - Unable to find the interface

eQCWWAN_ERR_QMI_FLOW_SUSPENDED 1044- Flow suspended

eQCWWAN_ERR_QMI_INVALID_DATA_FORMAT 1045 - Data format is invalid

eQCWWAN_ERR_QMI_GENERAL 1046 - General error

eQCWWAN_ERR_QMI_UNKNOWN 1047 - Unknown error

eQCWWAN_ERR_QMI_INVALID_ARG 1048 - A specified argument is invalid

eQCWWAN_ERR_QMI_INVALID_INDEX 1049 - A specified index is invalid

eQCWWAN_ERR_QMI_NO_ENTRY 1050 - No information element exists at specified memory designation

eQCWWAN_ERR_QMI_DEVICE_STORAGE_FULL 1051 - The memory storage specified in the request is full

eQCWWAN_ERR_QMI_DEVICE_NOT_READY 1052 - Device not in a ready state

eQCWWAN_ERR_QMI_NETWORK_NOT_READY 1053 - Network not in a ready state

eQCWWAN_ERR_QMI_CAUSE_CODE 1054 - Error provided in SMS cause code

eQCWWAN_ERR_QMI_MESSAGE_NOT_SENT 1055 - The message could not be sent

eQCWWAN_ERR_QMI_MESSAGE_DELIVERY_FAILURE 1056 - The message could not be delivered

eQCWWAN_ERR_QMI_INVALID_MESSAGE_ID 1057 - The message ID specified for the message is invalid

eQCWWAN_ERR_QMI_ENCODING 1058 - The message is not encoded properly

eQCWWAN_ERR_QMI_AUTHENTICATION_LOCK 1059 - Maximum number of authentication failures has been reached

eQCWWAN_ERR_QMI_INVALID_TRANSITION 1060 - Operating mode transition from the current mode is invalid

eQCWWAN_ERR_QMI_NOT_A_MCAST_IFACE 1061 - The intercace is not muticast

eQCWWAN_ERR_QMI_MAX_MCAST_REQUESTS_IN_USE 1062 - Maximum requests in use

eQCWWAN_ERR_QMI_INVALID_MCAST_HANDLE 1063 - Invalid muticast handle

eQCWWAN_ERR_QMI_INVALID_IP_FAMILY_PREF 1064 - Invalid IP family preference

eQCWWAN_ERR_QMI_SESSION_INACTIVE 1065 - No tracking session has been started

eQCWWAN_ERR_QMI_SESSION_INVALID 1066 - Current session does not allow this operation

eQCWWAN_ERR_QMI_SESSION_OWNERSHIP 1067 - Current tracking session not started by this QMI control point

eQCWWAN_ERR_QMI_INSUFFICIENT_RESOURCES 1068 - Device GPS service resources insufficient for request

eQCWWAN_ERR_QMI_DISABLED 1069 - Support for QMI message is disabled

eQCWWAN_ERR_QMI_INVALID_OPERATION 1070 - Invalid operation specified

eQCWWAN_ERR_QMI_INVALID_QMI_CMD 1071 - Invalid/unknown QMI command specified

eQCWWAN_ERR_QMI_TPDU_TYPE 1072 - Message contains TPDU type that cannot be read as raw message

eQCWWAN_ERR_QMI_SMSC_ADDR 1073 - The SMSC address specified is invalid

eQCWWAN_ERR_QMI_INFO_UNAVAILABLE 1074 - Information element is unavailable at this point

eQCWWAN_ERR_QMI_SEGMENT_TOO_LONG 1075 - Segment size too large

eQCWWAN_ERR_QMI_SEGMENT_ORDER 1076 - Segment order is incorrect

eQCWWAN_ERR_QMI_BUNDLING_NOT_SUPPORTED 1077 - Bundling not supported

eQCWWAN_ERR_QMI_OP_PARTIAL_FAILURE 1078 - The operation failed partially

eQCWWAN_ERR_QMI_POLICY_MISMATCH 1079 - Policy mismatch

eQCWWAN_ERR_QMI_SIM_FILE_NOT_FOUND 1080 - SIM file not found

eQCWWAN_ERR_QMI_EXTENDED_INTERNAL 1081 - Extended internal error

eQCWWAN_ERR_QMI_ACCESS_DENIED 1082 - Access to a required entity is not available

eQCWWAN_ERR_QMI_HARDWARE_RESTRICTED 1083 - Selected operating mode is invalid with current hardware setting

eQCWWAN_ERR_QMI_ACK_NOT_SENT 1084 - ACK not sent

eQCWWAN_ERR_QMI_INJECT_TIMEOUT 1084 - Inject a timeout for the request

eQCWWAN_ERR_QMI_INCOMPATIBLE_STATE 1090 - Incompatible state

eQCWWAN_ERR_QMI_FDN_RESTRICT 1091 - FDN Restrict

eQCWWAN_ERR_QMI_SUPS_FAILURE_CAUSE 1092 - SUPS failure cause

eQCWWAN_ERR_QMI_NO_RADIO 1093 - No Radio

eQCWWAN_ERR_QMI_NOT_SUPPORTED 1094 - Not Supported

eQCWWAN_ERR_QMI_NO_SUBSCRIPTION 1095 - No Subscription

eQCWWAN_ERR_QMI_CARD_CALL_CONTROL_FAILED 1096 - Card call control failed

eQCWWAN_ERR_QMI_NETWORK_ABORTED 1097 - Network Aborted

eQCWWAN_ERR_QMI_MSG_BLOCKED 1098 - Open Error

eQCWWAN_ERR_QMI_MAX Error - End of QMI specific defines

eQCWWAN_ERR_SWICM_START **Vendor defines - Connection Manager error codes**

eQCWWAN_ERR_SWICM_NOT_IMPLEMENTED 0xE001 - The API is yet to be implemented

eQCWWAN_ERR_SWICM_QMI_SVC_NOT_SUPPORTED 0xE002 - The service is not supported

eQCWWAN_ERR_SWICM_QMI_CLNT_NOT_SUPPORTED 0xE003 - The client is not supported

eQCWWAN_ERR_SWICM_TIMEOUT 0xE004 - API Timeout

eQCWWAN_ERR_SWICM_SOCKET_IN_USE 0xE005 - The communication socket is in use

eQCWWAN_ERR_SWICM_AM_VERS_ERROR 0xE006 - SLQS API and SDK version mismatch

eQCWWAN_ERR_SWICM_FAILED_TO_KILL_SDK_PROCESS 0xE007 - Failed to kill SDK process

eQCWWAN_ERR_SWICM_CALL_IN_PROGRESS 0xE008 - Call in progress

eQCWWAN_ERR_SWICM_V4DWN_V6DWN 0xE009 - IPV4 and IPV6 is down

eQCWWAN_ERR_SWICM_V4DWN_V6UP 0xE00A - IPV4 is down and IPV6 is up

eQCWWAN_ERR_SWICM_V4UP_V6DWN 0xE00B - IPV4 is up and IPV6 is down

eQCWWAN_ERR_SWICM_V4UP_V6UP 0xE00C - IPV4 and IPV6 is up

eQCWWAN_ERR_SWICM_INVALID_SESSION_ID 0xE00D - Invalid V4 Session ID

eQCWWAN_ERR_SWICM_INVALID_V4_SESSION_ID 0xE00E - Invalid V4 Session ID

eQCWWAN_ERR_SWICM_INVALID_V6_SESSION_ID 0xE00F - Invalid V6 Session ID

eQCWWAN_ERR_SWICM_SM_NO_AVAILABLE_SESSIONS 0xE010 - No available Session Manager slots for additional data sessions

eQCWWAN_ERR_SWICM_END 0xE011 - End of connection manager specific codes

eQCWWAN_ERR_SWISMS_START **Vendor defines - SMS Error codes**

eQCWWAN_ERR_SWISMS_MSG_LEN_TOO_LONG 0xE101 - SMS message length is long

eQCWWAN_ERR_SWISMS_MSG_CORRUPTED 0xE102 - The SMS message is corrupted (encoding wrong)

eQCWWAN_ERR_SWISMS_SMSC_NUM_CORRUPTED 0xE103 - The SMS number is corrupted (incorrect number)

eQCWWAN_ERR_SWISMS_BEARER_DATA_NOT_FOUND 0xE104 - The SMS bearer data is not available

eQCWWAN_ERR_SWISM_END

eQCWWAN_ERR_SWIIM_START **Vendor defines - Image Management error codes**

eQCWWAN_ERR_SWIIM_INVALID_PATH 0xE801 - Invalid directory path

eQCWWAN_ERR_SWIIM_OPENING_DIR 0xE802 - Unable to open the directory

eQCWWAN_ERR_SWIIM_FILE_NOT_FOUND 0xE803 - No Firmware image present in the path

eQCWWAN_ERR_SWIIM_OPENING_FILE 0xE804 - Unable to open the file

eQCWWAN_ERR_SWIIM_CORRUPTED_FW_IMAGE 0xE805 - Firmware image is corrupted

eQCWWAN_ERR_SWIIM_FIRMWARE_NOT_DOWNLOADED 0xE806 - No Firmware image download needed

eQCWWAN_ERR_SWIIM_FW_UPDATE_FAIL 0xE807 - Firmware update failed

eQCWWAN_ERR_SWIIM_FW_PREFERENCE_MISMATCH 0xE808 - Update success but pri/fw preference mismatch

eQCWWAN_ERR_SWIIM_FW_UPDATE_SUCCESS 0xE809 - Update successful

eQCWWAN_ERR_SWIIM_FW_ENTER_DOWNLOAD_MODE 0xE80A - Enter Download Mode

eQCWWAN_ERR_SWIIM_FW_FLASH_COMPLETE 0xE80B - File transfer to modem complete

eQCWWAN_ERR_SWIIM_FW_WAIT_FOR_REBOOT 0xE80C - Wait for modem to reboot

eQCWWAN_ERR_SWIIM_INVALID_CRASH_STATE 0xE80D - Invalid Crash State for Firmware Download

eQCWWAN_ERR_SWIIM_FW_SAME_AS_CURRENT_ACTIVE_IMAGE 0xE80E - Same as current active image

eQCWWAN_ERR_SWIIM_FW_INVALID_SLOT_INDEX 0xE80F - invalid slot index

eQCWWAN_ERR_SWIIM_FW_SECBOOT_IMAGE_NOT_SIGNED

eQCWWAN_ERR_SWIIM_FW_SECBOOT_INVALID_CERT_CHAIN

eQCWWAN_ERR_SWIIM_END

eQCWWAN_ERR_SWIDCS_START **Vendor defines - Device Connectivity error codes**

eQCWWAN_ERR_SWIDCS_IOCTL_ERR 0xE901 - IO Control error

eQCWWAN_ERR_SWIDCS_FILEIO_ERR 0xE902 - file open/read/write error

eQCWWAN_ERR_SWIDCS_DEVNODE_NOT_FOUND 0xE903 - The device is not found

eQCWWAN_ERR_SWIDCS_APP_DISCONNECTED 0xE904 - Application is disconnected from SDK

eQCWWAN_ERR_SWIDCS_END

eQCWWAN_ERR_QMI_CAT_START **QMI errors related to CAT**

eQCWWAN_ERR_QMI_EVENT_REG_FAILED 62441 - CAT event registration failed

eQCWWAN_ERR_QMI_INVALID_TERMINAL_RSP 62442 - Invalid terminal response

eQCWWAN_ERR_QMI_INVALID_ENVELOPE_CMD 62443 - Invalid envelope command

eQCWWAN_ERR_QMI_CARD_BUSY_RSP 62444 - Card busy response for envelope command

eQCWWAN_ERR_QMI_ENVELOPE_CMD_FAILURE 62445 - Envelope command failure

eQCWWAN_ERR_QMI_CAT_END

eQCWWAN_ERR_NULL_TLV

eQCWWAN_ERR_QMI_WIDTH 0xFFFF - Not an error, represent the end of QMI errors

9.28.1.2 enum qm_wds_ds_profile_extended_err_codes

WDS DS profile extented error codes

Enumerator

eWDS_ERR_PROFILE_REG_RESULT_FAIL 1 - General Failure

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_HNDL 2 - The request contains an invalid profile handle

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_OP 3 - An invalid operation was requested.

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_TYPE 4 - The request contains an invalid technology type

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_NUM 5 - The request contains an invalid profile number

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_IDENT 6 - The request contains an invalid profile identifier

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL 7 - The request contains an invalid argument other than profile number and profile identifier received.

eWDS_ERR_PROFILE_REG_RESULT_ERR_LIB_NOT_INITED 8 - Profile registry has not been initialized yet

eWDS_ERR_PROFILE_REG_RESULT_ERR_LEN_INVALID 9 - The request contains a parameter with invalid length.

eWDS_ERR_PROFILE_REG_RESULT_LIST_END 10 - End of the profile list was reached while searching for the requested profile.

eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_SUBS_ID 11 - The request contains an invalid subscrition identifier.

eWDS_ERR_PROFILE_REG_INVAL_PROFILE_FAMILY 12 - The request contains an invalid profile family.

eWDS_ERR_PROFILE_REG_3GPP_INVAL_PROFILE_FAMILY 1001 - The request contains an invalid 3GPP profile family.

eWDS_ERR_PROFILE_REG_3GPP_ACCESS_ERR 1002 - An error was encountered while accessing the 3GPP profiles.

eWDS_ERR_PROFILE_REG_3GPP_CONTEXT_NOT_DEFINED 1003 - The given 3GPP profile doesn't have a valid context.

eWDS_ERR_PROFILE_REG_3GPP_VALID_FLAG_NOT_SET 1004 - The given 3GPP profile is marked invalid.

eWDS_ERR_PROFILE_REG_3GPP_READ_ONLY_FLAG_SET 1005 - The given 3GPP profile is marked read-only.

eWDS_ERR_PROFILE_REG_3GPP_ERR_OUT_OF_PROFILES 1006 - Creation of a new 3GPP profile failed because the limit of 16 profiles has already been reached.

eWDS_ERR_PROFILE_REG_3GPP2_ERR_INVALID_IDENT_FOR_PROFILE 1101 - An invalid profile identifier was received as part of the 3GPP2 profile modification request.

eWDS_ERR_PROFILE_REG_END

9.29 qos.h File Reference

Data Structures

- struct unpack_qos_SLQSQosGetNetworkStatus_t
- struct pack_qos_SLQSQosSwiReadApnExtraParams_t
- struct unpack_qos_SLQSQosSwiReadApnExtraParams_t

- struct pack_qos_SLQSQosSwiReadDataStats_t
- struct unpack_QosFlowStat_t
- struct unpack_qos_SLQSQosSwiReadDataStats_t
- struct unpack_qos_SLQSSetQosNWStatusCallback_ind_t
- struct unpack_qos_SLQSSetQosStatusCallback_ind_t
- struct unpack_qos_SLQSSetQosPriEventCallback_ind_t
- struct pack_qos_SLQSSetQosEventCallback_t
- struct unpack_qos_SLQSSetQosEventCallback_t
- struct unpack_qos_QosFlowInfoState_t
- struct unpack_qos_dataRate_t
- struct unpack_qos_tokenBucket_t
- struct unpack_qos_pktErrRate_t
- struct unpack_qos_swiQosFlow_t
- struct unpack_qos_IPv4Addr_t
- struct unpack_qos_Tos_t
- struct unpack_qos_IPv6Addr_t
- struct unpack_qos_IPv6TrafCls_t
- struct unpack_qos_Port_t
- struct unpack_qos_swiQosFilter_t
- struct unpack_qos_QosFlowInfo_t
- struct unpack_qos_SLQSSetQosEventCallback_ind_t
- struct qos_BindDataPortPeripheralEndPointID_t
- struct qos_BindDataPortMuxID_t
- struct qos_BindDataPortSIODataPort_t
- struct pack_qos_BindDataPort_t
- struct unpack_qos_BindDataPort_t

Macros

- #define LITEQMI_MAX_QOS_FLOW_PER_APN_STATS 10
- #define LITEQMI_MAX_QOS_FILTERS 25
- #define LITEQMI_MAX_QOS_FLOWS 8

Functions

- int pack_qos_SLQSQosGetNetworkStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_qos_SLQSQosGetNetworkStatus (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSQosGetNetworkStatus_t *pOutput)
- int pack_qos_SLQSQosSwiReadApnExtraParams (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_qos_SLQSQosSwiReadApnExtraParams_t reqParam)
- int unpack_qos_SLQSQosSwiReadApnExtraParams (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSQosSwiReadApnExtraParams_t *pOutput)
- int pack_qos_SLQSQosSwiReadDataStats (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_qos_SLQSQosSwiReadDataStats_t reqParam)
- int unpack_qos_SLQSQosSwiReadDataStats (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSQosSwiReadDataStats_t *pOutput)
- int unpack_qos_SLQSSetQosNWStatusCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSSetQosNWStatusCallback_ind_t *pOutput)
- int unpack_qos_SLQSSetQosStatusCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSSetQosStatusCallback_ind_t *pOutput)
- int unpack_qos_SLQSSetQosPriEventCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSSetQosPriEventCallback_ind_t *pOutput)
- int pack_qos_SLQSSetQosEventCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_qos_SLQSSetQosEventCallback_t reqParam)

- int unpack_qos_SLQSSetQosEventCallback (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSSetQosEventCallback_t *pOutput)
- int unpack_qos_SLQSSetQosEventCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_qos_SLQSSetQosEventCallback_ind_t *pOutput)
- int pack_qos_BindDataPort (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_qos_BindDataPort_t req)
- int unpack_qos_BindDataPort (uint8_t *pResp, uint16_t respLen, unpack_qos_BindDataPort_t *pOutput)

9.29.1 Macro Definition Documentation

9.29.1.1 #define LITEQMI_MAX_QOS_FILTERS 25

9.29.1.2 #define LITEQMI_MAX_QOS_FLOW_PER_APN_STATS 10

9.29.1.3 #define LITEQMI_MAX_QOS_FLOWS 8

9.29.2 Function Documentation

9.29.2.1 int pack_qos_BindDataPort (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_qos_BindDataPort_t *req*)

Function to pack command to Binds a control point to a data port. This maps to PkQmiQosBindDataPort

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*req*	• See pack_qos_BindDataPort_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Timeout: 2 seconds

9.29.2.2 int pack_qos_SLQSQosGetNetworkStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack command to retrieve QoS status of the network. This maps to SLQSQosGetNetworkStatus

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Timeout: 2 seconds
- Technology Supported: CDMA
- PDN Specific: No

9.29.2.3 int pack_qos_SLQSQosSwiReadApnExtraParams (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_qos_SLQSQosSwiReadApnExtraParams_t *reqParam*)

Function to pack QMI command to query extra APN parameters This maps to SLQSQosSwiReadApnExtraParams

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_qos_SLQSQosSwiReadApnExtraParams_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Timeout: 2 seconds
  - PDN Specific: Yes

9.29.2.4 int pack_qos_SLQSQosSwiReadDataStats (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_qos_SLQSQosSwiReadDataStats_t *reqParam*)

Function to pack QMI command to query APN data statistics This maps to SLQSQosSwiReadDataStats

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_qos_SLQSQosSwiReadDataStats_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Timeout: 2 seconds
  - PDN Specific: Yes

9.29.2.5 int pack_qos_SLQSSetQosEventCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_qos_SLQSSetQosEventCallback_t *reqParam*)

Function to pack QMI command to enable QoS event indications This maps to SLQSSetQosEventCallback

Parameters

out	*pCtx*	• See pack_qmi_t for more information

in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_qos_SLQSSetQosEventCallback_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Timeout: 2 seconds
  - PDN Specific: Yes

9.29.2.6 int unpack_qos_BindDataPort (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_BindDataPort_t * *pOutput*)

Function to unpack the response to Binds a control point to a data port. This maps to UpkQmiQosBindDataPort

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_BindDataPort_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.29.2.7 int unpack_qos_SLQSQosGetNetworkStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSQosGetNetworkStatus_t * *pOutput*)

Function to unpack the response to get NW QoS status command This maps to SLQSQosGetNetworkStatus

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSQosGetNetworkStatus_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.29.2.8 int unpack_qos_SLQSQosSwiReadApnExtraParams (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSQosSwiReadApnExtraParams_t * *pOutput*)

Function to unpack the response to get NW QoS status command This maps to SLQSQosSwiReadApnExtraParams

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSQosSwiReadApnExtraParams_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.29.2.9 int unpack_qos_SLQSQosSwiReadDataStats (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSQosSwiReadDataStats_t * *pOutput*)

Function to unpack APN data statistics response This maps to SLQSQosSwiReadDataStats

Parameters

in	*pResp*	• Response from modem

in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSQosSwiReadDataStats_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.29.2.10 int unpack_qos_SLQSSetQosEventCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSSetQosEventCallback_t * *pOutput*)

Function to unpack enable QoS event indications command's response This maps to SLQSSetQosEventCallback

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSSetQosEventCallback_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.29.2.11 int unpack_qos_SLQSSetQosEventCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSSetQosEventCallback_ind_t * *pOutput*)

Function to unpack QoS event indications This maps to SLQSSetQosEventCallback

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem

out	*pOutput*	• See unpack_qos_SLQSSetQosEventCallback_ind_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- This is a broadcast notification that is sent to the registered QoS service
- No explicit function to register for this indication is needed
- Please use eQMI_QOS_NETWORK_STATUS_IND indication to identify this event from QOS service read function

9.29.2.12 int unpack_qos_SLQSSetQosNWStatusCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSSetQosNWStatusCallback_ind_t * *pOutput*)

Function to unpack QoS NW status indication. This maps to SLQSSetQosNWStatusCallback

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSSetQosNWStatusCallback_ind_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Technology Supported: CDMA
- This is a broadcast notification that is sent to the registered QoS service
- No explicit function to register for this indication is needed
- Please use eQMI_QOS_NETWORK_STATUS_IND indication to identify this event from QOS service read function

9.29.2.13 int unpack_qos_SLQSSetQosPriEventCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSSetQosPriEventCallback_ind_t * *pOutput*)

Function to unpack QoS primary flow events. This maps to SLQSSetQosPriEventCallback

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSSetQosPriEventCallback_ind_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- This is a broadcast notification that is sent to the registered QoS service
- No explicit function to register for this indication is needed
- Please use eQMI_QOS_PRIMARY_QOS_EVENT_IND indication to identify this event from QOS service read function
- This is only generated when the primary flow is modified by the host

9.29.2.14 int unpack_qos_SLQSSetQosStatusCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_qos_SLQSSetQosStatusCallback_ind_t * *pOutput*)

Function to unpack QoS status indications. This maps to SLQSSetQosStatusCallback

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pOutput*	• See unpack_qos_SLQSSetQosStatusCallback_ind_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- This is a broadcast notification that is sent to the registered QoS service
- No explicit function to register for this indication is needed
- Please use eQMI_QOS_FLOW_STATUS_IND indication to identify this event from QOS service read function

9.30 rms.h File Reference

Data Structures

- struct unpack_rms_GetSMSWake_t
- struct pack_rms_SetSMSWake_t
- struct unpack_rms_SetSMSWake_t

Macros

- #define __LITEQMI_RMS_H__

Functions

- int pack_rms_GetSMSWake (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_rms_GetSMSWake (uint8_t *pResp, uint16_t respLen, unpack_rms_GetSMSWake_t *pOutput)
- int pack_rms_SetSMSWake (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_rms_SetSMSWake_t *reqArg)
- int unpack_rms_SetSMSWake (uint8_t *pResp, uint16_t respLen, unpack_rms_SetSMSWake_t *pOutput)

9.30.1 Macro Definition Documentation

9.30.1.1 #define __LITEQMI_RMS_H__

9.30.2 Function Documentation

9.30.2.1 int pack_rms_GetSMSWake (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get SMS Wake pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.30.2.2 int pack_rms_SetSMSWake (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_rms_SetSMSWake_t * *reqArg*)

Set SMS Wake pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.30.2.3 int unpack_rms_GetSMSWake (uint8_t * *pResp*, uint16_t *respLen*, unpack_rms_GetSMSWake_t * *pOutput*)

Get SMS Wake unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.30.2.4 int unpack_rms_SetSMSWake (uint8_t * *pResp*, uint16_t *respLen*, unpack_rms_SetSMSWake_t * *pOutput*)

Set SMS Wake unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.31 sar.h File Reference

Data Structures

- struct unpack_sar_SLQSGetRfSarState_t
- struct pack_sar_SLQSSetRfSarState_t

Typedefs

- typedef unpack_result_t unpack_sar_SLQSSetRfSarState_t

Functions

- int pack_sar_SLQSGetRfSarState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sar_SLQSGetRfSarState (uint8_t *pResp, uint16_t respLen, unpack_sar_SLQSGetRfSarState_t *pOutput)
- int pack_sar_SLQSSetRfSarState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sar_SLQSSetRfSarState_t *reqArg)
- int unpack_sar_SLQSSetRfSarState (uint8_t *pResp, uint16_t respLen, unpack_sar_SLQSSetRfSarState_t *pOutput)

9.31.1 Typedef Documentation

9.31.1.1 typedef unpack_result_t unpack_sar_SLQSSetRfSarState_t

9.31.2 Function Documentation

9.31.2.1 int pack_sar_SLQSGetRfSarState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the specified RF SAR state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.31.2.2 int pack_sar_SLQSSetRfSarState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sar_SLQSSetRfSarState_t * *reqArg*)

Sets the specified RF SAR state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.31.2.3 int unpack_sar_SLQSGetRfSarState (uint8_t * *pResp*, uint16_t *respLen*, unpack_sar_SLQSGetRfSarState_t * *pOutput*)

Gets the specified RF SAR state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.31.2.4 int unpack_sar_SLQSSetRfSarState (uint8_t * *pResp*, uint16_t *respLen*, unpack_sar_SLQSSetRfSarState_t * *pOutput*)

Sets the specified RF SAR state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32 sms.h File Reference

Data Structures

- struct pack_sms_SLQSGetSMS_t
- struct unpack_sms_SLQSGetSMS_t
- struct pack_sms_SLQSGetSMSList_t
- struct qmiSmsMessageList
- struct unpack_sms_SLQSGetSMSList_t
- struct pack_sms_SLQSModifySMSStatus_t
- struct unpack_sms_SLQSModifySMSStatus_t
- struct pack_sms_SLQSDeleteSMS_t
- struct unpack_sms_SLQSDeleteSMS_t
- struct pack_sms_SendSMS_t
- struct unpack_sms_SendSMS_t
- struct pack_sms_SetNewSMSCallback_t
- struct unpack_sms_SetNewSMSCallback_t
- struct sMSMTMessageInfo
- struct newMTMessageTlv
- struct sMSTransferRouteMTMessageInfo
- struct transferRouteMessageTlv
- struct sMSMessageModeInfo
- struct messageModeTlv
- struct sMSEtwsMessageInfo
- struct sMSEtwsMessageTlv
- struct sMSEtwsPlmnInfo
- struct eTWSPLMNInfoTlv
- struct sMSCAddressInfo
- struct sMSCAddressTlv
- struct sMSOnIMSInfo
- struct sMSOnIMSTlv
- struct unpack_sms_SetNewSMSCallback_ind_t
- struct unpack_sms_SLQSWmsMemoryFullCallBack_ind_t
- struct unpack_sms_GetSMSCAddress_t
- struct pack_sms_SetSMSCAddress_t
- struct unpack_sms_SetSMSCAddress_t
- struct pack_sms_SaveSMS_t
- struct unpack_sms_SaveSMS_t
- struct sms_BroadcastConfig
- struct sms_qaQmi3GPPBroadcastCfgInfo
- struct sms_CDMABroadcastConfig
- struct sms_qaQmi3GPP2BroadcastCfgInfo
- struct unpack_sms_SLQSGetSmsBroadcastConfig_t
- struct pack_sms_SLQSGetSmsBroadcastConfig_t
- struct pack_sms_SLQSSetSmsBroadcastConfig_t
- struct unpack_sms_SLQSSetSmsBroadcastConfig_t
- struct pack_sms_SLQSSetSmsBroadcastActivation_t
- struct unpack_sms_SLQSSetSmsBroadcastActivation_t
- struct sms_transLayerInfo
- struct sms_getTransLayerInfo

- struct unpack_sms_SLQSGetTransLayerInfo_t
- struct sms_getTransNWRegInfo
- struct unpack_sms_SLQSGetTransNWRegInfo_t
- struct sms_getIndicationReg
- struct unpack_sms_SLQSGetIndicationRegister_t
- struct sms_setIndicationReg
- struct pack_sms_SLQSSetIndicationRegister_t
- struct unpack_sms_SLQSSetIndicationRegister_t
- struct sms_routeEntry
- struct sms_setRoutesReq
- struct pack_sms_SLQSSmsSetRoutes_t
- struct unpack_sms_SLQSSmsSetRoutes_t
- struct sms_msgProtocolResp
- struct unpack_sms_SLQSSmsGetMessageProtocol_t
- struct sms_maxStorageSizeReq
- struct sms_maxStorageSizeResp
- struct pack_sms_SLQSSmsGetMaxStorageSize_t
- struct unpack_sms_SLQSSmsGetMaxStorageSize_t
- struct sms_messageWaitingInfoContent
- struct sms_getMsgWaitingInfo
- struct unpack_sms_SLQSGetMessageWaiting_t
- struct sms_sendAsyncsmsParams
- struct pack_sms_SLQSSendAsyncSMS_t
- struct unpack_sms_SLQSSendAsyncSMS_t
- struct pack_sms_SLQSSetSmsStorage_t
- struct unpack_sms_SLQSSetSmsStorage_t
- struct unpack_sms_SLQSSwiGetSMSStorage_t
- struct unpack_sms_SLQSTransLayerInfoCallback_ind_t
- struct unpack_sms_SLQSNWRegInfoCallback_ind_t
- struct unpack_sms_SLQSWmsMessageWaitingCallBack_ind_t
- struct unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t

Macros

- #define MAX_SMS_MESSAGE_SIZE 2048
- #define MAX_SMS_LIST_SIZE 255
- #define MAX_MS_TRANSFER_ROUTE_MSG 256
- #define MAX_MSE_TWS_MSG 1254
- #define MAX_MSC_ADDRESS_SIZE 256
- #define MAX_CDMA_ENC_MO_TXT_MSG_SIZE 255
- #define SMSC_TYPE_LEN 0x03
- #define SMS_CONFIG_LEN 0x05
- #define SMS_MAX_SMS_ROUTES 0x0A
- #define SMS_NUM_OF_SET 0xFF

Enumerations

- enum eqmiCbkSetStatus {
  LITEQMI_QMI_CBK_PARAM_RESET = 0,
  LITEQMI_QMI_CBK_PARAM_SET = 1,
  LITEQMI_QMI_CBK_PARAM_NOCHANGE }

Functions

- int pack_sms_SLQSGetSMS (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSGetSMS_t *reqParam)
- int unpack_sms_SLQSGetSMS (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetSMS_t *pOutput)
- int pack_sms_SLQSGetSMSList (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSGetSMSList_t *reqParam)
- int unpack_sms_SLQSGetSMSList (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetSMSList_t *pOutput)
- int pack_sms_SLQSModifySMSStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSModifySMSStatus_t *reqParam)
- int unpack_sms_SLQSModifySMSStatus (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSModifySMSStatus_t *pOutput)
- int pack_sms_SLQSDeleteSMS (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSDeleteSMS_t *reqParam)
- int unpack_sms_SLQSDeleteSMS (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSDeleteSMS_t *pOutput)
- int pack_sms_SendSMS (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SendSMS_t *reqParam)
- int unpack_sms_SendSMS (uint8_t *pResp, uint16_t respLen, unpack_sms_SendSMS_t *pOutput)
- int pack_sms_SetNewSMSCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SetNewSMSCallback_t reqParam)
- int unpack_sms_SetNewSMSCallback (uint8_t *pResp, uint16_t respLen, unpack_sms_SetNewSMSCallback_t *Output)
- int unpack_sms_SetNewSMSCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_sms_SetNewSMSCallback_ind_t *pOutput)
- int unpack_sms_SLQSWmsMemoryFullCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSWmsMemoryFullCallBack_ind_t *pOutput)
- int pack_sms_GetSMSCAddress (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_GetSMSCAddress (uint8_t *pResp, uint16_t respLen, unpack_sms_GetSMSCAddress_t *pOutput)
- int pack_sms_SetSMSCAddress (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SetSMSCAddress_t *reqParam)
- int unpack_sms_SetSMSCAddress (uint8_t *pResp, uint16_t respLen, unpack_sms_SetSMSCAddress_t *pOutput)
- int pack_sms_SaveSMS (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SaveSMS_t *reqParam)
- int unpack_sms_SaveSMS (uint8_t *pResp, uint16_t respLen, unpack_sms_SaveSMS_t *pOutput)
- int pack_sms_SLQSGetSmsBroadcastConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSGetSmsBroadcastConfig_t *reqParam)
- int unpack_sms_SLQSGetSmsBroadcastConfig (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetSmsBroadcastConfig_t *pOutput)
- int pack_sms_SLQSSetSmsBroadcastConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSetSmsBroadcastConfig_t *reqParam)
- int unpack_sms_SLQSSetSmsBroadcastConfig (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSetSmsBroadcastConfig_t *pOutput)
- int pack_sms_SLQSSetSmsBroadcastActivation (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSetSmsBroadcastActivation_t *reqParam)
- int unpack_sms_SLQSSetSmsBroadcastActivation (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSetSmsBroadcastActivation_t *pOutput)
- int pack_sms_SLQSGetTransLayerInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_SLQSGetTransLayerInfo (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetTransLayerInfo_t *pOutput)
- int pack_sms_SLQSGetTransNWRegInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_SLQSGetTransNWRegInfo (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetTransNWRegInfo_t *pOutput)

- int pack_sms_SLQSGetIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_SLQSGetIndicationRegister (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetIndicationRegister_t *pOutput)
- int pack_sms_SLQSSetIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSetIndicationRegister_t *reqParam)
- int unpack_sms_SLQSSetIndicationRegister (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSetIndicationRegister_t *pOutput)
- int pack_sms_SLQSSmsSetRoutes (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSmsSetRoutes_t *reqParam)
- int unpack_sms_SLQSSmsSetRoutes (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSmsSetRoutes_t *pOutput)
- int pack_sms_SLQSSmsGetMessageProtocol (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_SLQSSmsGetMessageProtocol (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSmsGetMessageProtocol_t *pOutput)
- int pack_sms_SLQSSmsGetMaxStorageSize (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSmsGetMaxStorageSize_t *reqParam)
- int unpack_sms_SLQSSmsGetMaxStorageSize (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSmsGetMaxStorageSize_t *pOutput)
- int pack_sms_SLQSGetMessageWaiting (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_SLQSGetMessageWaiting (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSGetMessageWaiting_t *pOutput)
- int pack_sms_SLQSSendAsyncSMS (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSendAsyncSMS_t *reqParam)
- int unpack_sms_SLQSSendAsyncSMS (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSendAsyncSMS_t *pOutput)
- int pack_sms_SLQSSetSmsStorage (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_sms_SLQSSetSmsStorage_t *reqParam)
- int unpack_sms_SLQSSetSmsStorage (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSetSmsStorage_t *pOutput)
- int pack_sms_SLQSSwiGetSMSStorage (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_sms_SLQSSwiGetSMSStorage (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSSwiGetSMSStorage_t *pOutput)
- int unpack_sms_SLQSTransLayerInfoCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSTransLayerInfoCallback_ind_t *pOutput)
- int unpack_sms_SLQSNWRegInfoCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSNWRegInfoCallback_ind_t *pOutput)
- int unpack_sms_SLQSWmsMessageWaitingCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSWmsMessageWaitingCallBack_ind_t *pOutput)
- int unpack_sms_SLQSWmsAsyncRawSendCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t *pOutput)

9.32.1 Macro Definition Documentation

9.32.1.1 #define MAX_CDMA_ENC_MO_TXT_MSG_SIZE 255

9.32.1.2 #define MAX_MS_TRANSFER_ROUTE_MSG 256

9.32.1.3 #define MAX_MSC_ADDRESS_SIZE 256

9.32.1.4 #define MAX_MSE_TWS_MSG 1254

9.32.1.5 #define MAX_SMS_LIST_SIZE 255

9.32.1.6 #define MAX_SMS_MESSAGE_SIZE 2048

9.32.1.7 #define SMS_CONFIG_LEN 0x05

9.32.1.8 #define SMS_MAX_SMS_ROUTES 0x0A

9.32.1.9 #define SMS_NUM_OF_SET 0xFF

9.32.1.10 #define SMSC_TYPE_LEN 0x03

9.32.2 Enumeration Type Documentation

9.32.2.1 enum eqmiCbkSetStatus

Enumerator

LITEQMI_QMI_CBK_PARAM_RESET

LITEQMI_QMI_CBK_PARAM_SET

LITEQMI_QMI_CBK_PARAM_NOCHANGE

9.32.3 Function Documentation

9.32.3.1 int pack_sms_GetSMSCAddress (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the SMS center address pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.2 int pack_sms_SaveSMS (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SaveSMS_t * *reqParam*)

Saves an SMS message to device memory pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.3 int pack_sms_SendSMS (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SendSMS_t * *reqParam*)

send sms list pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.4 int pack_sms_SetNewSMSCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SetNewSMSCallback_t *reqParam*)

set new sms callback pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.5 int pack_sms_SetSMSCAddress (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SetSMSCAddress_t * *reqParam*)

Set the SMS center address pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.6 int pack_sms_SLQSDeleteSMS (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSDeleteSMS_t * *reqParam*)

delete sms pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.7 int pack_sms_SLQSGetIndicationRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets registration state of different WMS indications pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.8 int pack_sms_SLQSGetMessageWaiting (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the message waiting information pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.9 int pack_sms_SLQSGetSMS (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSGetSMS_t * *reqParam*)

get sms pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.10 int pack_sms_SLQSGetSmsBroadcastConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSGetSmsBroadcastConfig_t * *reqParam*)

Provides Information about the SMS BroadcastConfiguration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.11 int pack_sms_SLQSGetSMSList (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSGetSMSList_t * *reqParam*)

get sms list pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.12 int pack_sms_SLQSGetTransLayerInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets information about the transport layer pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.13 int pack_sms_SLQSGetTransNWRegInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets transport layer network registration info pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.14 int pack_sms_SLQSModifySMSStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSModifySMSStatus_t * *reqParam*)

modify sms status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.15 int pack_sms_SLQSSendAsyncSMS (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSendAsyncSMS_t * *reqParam*)

Sends an SMS message for immediate over-the-air transmission pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.16 int pack_sms_SLQSSetIndicationRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSetIndicationRegister_t * *reqParam*)

Sets the registration state of different WMS indications pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.17 int pack_sms_SLQSSetSmsBroadcastActivation (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSetSmsBroadcastActivation_t * *reqParam*)

Enables or disables the reception of broadcast SMS messages pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.18 int pack_sms_SLQSSetSmsBroadcastConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSetSmsBroadcastConfig_t * *reqParam*)

Sets the information about the SMS BroadcastConfiguration pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.19 int pack_sms_SLQSSetSmsStorage (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSetSmsStorage_t * *reqParam*)

Sets the SMS Storage on the device pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.20 int pack_sms_SLQSSmsGetMaxStorageSize (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSmsGetMaxStorageSize_t * *reqParam*)

Get the maximum number of messages that can be stored in the specified memory storage. Also it provides the number of slots currently available pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.21 int pack_sms_SLQSSmsGetMessageProtocol (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the message protocol currently in use for the WMS client pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.22 int pack_sms_SLQSSmsSetRoutes (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_sms_SLQSSmsSetRoutes_t * *reqParam*)

Sets the action performed on SMS message receipt for specified message routes. It also specifies the action performed on SMS receipt of status reports pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
	reqParam	packed request

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.23 int pack_sms_SLQSSwiGetSMSStorage (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the current SMS configuration that is applied to all incoming and outgoing messages pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.24 int unpack_sms_GetSMSCAddress (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_GetSMSCAddress_t * *pOutput*)

Gets the SMS center address unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.25 int unpack_sms_SaveSMS (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SaveSMS_t * *pOutput*)

Saves an SMS message to device memory unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.26 int unpack_sms_SendSMS (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SendSMS_t * *pOutput*)

send sms unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.27 int unpack_sms_SetNewSMSCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SetNewSMSCallback_t * *Output*)

set new sms callback unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*Output*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.28 int unpack_sms_SetNewSMSCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SetNewSMSCallback_ind_t * *pOutput*)

set new sms callback indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.29 int unpack_sms_SetSMSCAddress (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SetSMSCAddress_t * *pOutput*)

Set the SMS center address unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.30 int unpack_sms_SLQSDeleteSMS (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSDeleteSMS_t * *pOutput*)

delete sms unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.31 int unpack_sms_SLQSGetIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetIndicationRegister_t * *pOutput*)

Gets registration state of different WMS indications unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.32 int unpack_sms_SLQSGetMessageWaiting (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetMessageWaiting_t * *pOutput*)

Gets the message waiting information unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.33 int unpack_sms_SLQSGetSMS (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetSMS_t * *pOutput*)

get sms unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.34 int unpack_sms_SLQSGetSmsBroadcastConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetSmsBroadcastConfig_t * *pOutput*)

Provides Information about the SMS BroadcastConfiguration unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.35 int unpack_sms_SLQSGetSMSList (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetSMSList_t * *pOutput*)

get sms list unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.36 int unpack_sms_SLQSGetTransLayerInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetTransLayerInfo_t * *pOutput*)

Gets information about the transport layer unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.37 int unpack_sms_SLQSGetTransNWRegInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSGetTransNWRegInfo_t * *pOutput*)

Gets transport layer network registration info unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.38 int unpack_sms_SLQSModifySMSStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSModifySMSStatus_t * *pOutput*)

modify sms status unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.39 int unpack_sms_SLQSNWRegInfoCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSNWRegInfoCallback_ind_t * *pOutput*)

Unpack indication about change in transport layer info

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.40 int unpack_sms_SLQSSendAsyncSMS (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSendAsyncSMS_t * *pOutput*)

Sends an SMS message for immediate over-the-air transmission unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.41 int unpack_sms_SLQSSetIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSetIndicationRegister_t * *pOutput*)

Sets the registration state of different WMS indications unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.42 int unpack_sms_SLQSSetSmsBroadcastActivation (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSetSmsBroadcastActivation_t * *pOutput*)

Enables or disables the reception of broadcast SMS messages unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.43 int unpack_sms_SLQSSetSmsBroadcastConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSetSmsBroadcastConfig_t * *pOutput*)

Sets the information about the SMS BroadcastConfiguration unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.44 int unpack_sms_SLQSSetSmsStorage (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSetSmsStorage_t * *pOutput*)

Sets the SMS Storage on the device unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.45 int unpack_sms_SLQSSmsGetMaxStorageSize (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSmsGetMaxStorageSize_t * *pOutput*)

Get the maximum number of messages that can be stored in the specified memory storage. Also it provides the number of slots currently available unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.46 int unpack_sms_SLQSSmsGetMessageProtocol (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSmsGetMessageProtocol_t * *pOutput*)

Gets the message protocol currently in use for the WMS client unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.47 int unpack_sms_SLQSSmsSetRoutes (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSmsSetRoutes_t * *pOutput*)

Sets the action performed on SMS message receipt for specified message routes. It also specifies the action performed on SMS receipt of status reports unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.48 int unpack_sms_SLQSSwiGetSMSStorage (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSSwiGetSMSStorage_t * *pOutput*)

Gets the current SMS configuration that is applied to all incoming and outgoing messages unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.49 int unpack_sms_SLQSTransLayerInfoCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSTransLayerInfoCallback_ind_t * *pOutput*)

Unpack indication about change in transport layer info

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.50 int unpack_sms_SLQSWmsAsyncRawSendCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t * *pOutput*)

Unpack indication for sms async raw send

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.51 int unpack_sms_SLQSWmsMemoryFullCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSWmsMemoryFullCallBack_ind_t * *pOutput*)

sms full callback indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.32.3.52 int unpack_sms_SLQSWmsMessageWaitingCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_sms_SLQSWmsMessageWaitingCallBack_ind_t * *pOutput*)

Unpack indication for message waiting information

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33 swiaudio.h File Reference

Data Structures

- struct pack_swiaudio_SLQSGetM2MAudioProfile_t
- struct unpack_swiaudio_SLQSGetM2MAudioProfile_t
- struct pack_swiaudio_SLQSSetM2MAudioProfile_t
- struct pack_swiaudio_SLQSGetM2MAudioVolume_t
- struct unpack_swiaudio_SLQSGetM2MAudioVolume_t
- struct pack_swiaudio_SLQSSetM2MAudioVolume_t
- struct swiaudio_PCMparams

- struct pack_swiaudio_SLQSSetM2MAudioAVCFG_t
- struct pack_swiaudio_SLQSSetM2MAudioLPBK_t
- struct pack_swiaudio_SLQSGetM2MSpkrGain_t
- struct unpack_swiaudio_SLQSGetM2MSpkrGain_t
- struct pack_swiaudio_SLQSSetM2MSpkrGain_t
- struct pack_swiaudio_SLQSGetM2MAVMute_t
- struct unpack_swiaudio_SLQSGetM2MAVMute_t
- struct pack_swiaudio_SLQSSetM2MAVMute_t

Macros

- #define SWIAUDIO_MAX_LEN_IFACE_TABLE 255

Typedefs

- typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAudioProfile_t
- typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAudioVolume_t
- typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAudioAVCFG_t
- typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAudioLPBK_t
- typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAudioNVDef_t
- typedef unpack_result_t unpack_swiaudio_SLQSSetM2MSpkrGain_t
- typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAVMute_t

Functions

- int pack_swiaudio_SLQSGetM2MAudioProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSGetM2MAudioProfile_t *pReqParam)
- int unpack_swiaudio_SLQSGetM2MAudioProfile (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSGetM2MAudioProfile_t *pOutput)
- int pack_swiaudio_SLQSSetM2MAudioProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MAudioProfile_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MAudioProfile (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSSetM2MAudioProfile_t *pOutput)
- int pack_swiaudio_SLQSGetM2MAudioVolume (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSGetM2MAudioVolume_t *pReqParam)
- int unpack_swiaudio_SLQSGetM2MAudioVolume (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSGetM2MAudioVolume_t *pOutput)
- int pack_swiaudio_SLQSSetM2MAudioVolume (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MAudioVolume_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MAudioVolume (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSSetM2MAudioVolume_t *pOutput)
- int pack_swiaudio_SLQSSetM2MAudioAVCFG (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MAudioAVCFG_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MAudioAVCFG (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSSetM2MAudioAVCFG_t *pOutput)
- int pack_swiaudio_SLQSSetM2MAudioLPBK (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MAudioLPBK_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MAudioLPBK (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSSetM2MAudioLPBK_t *pOutput)
- int pack_swiaudio_SLQSSetM2MAudioNVDef (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swiaudio_SLQSSetM2MAudioNVDef (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSSetM2MAudioNVDef_t *pOutput)
- int pack_swiaudio_SLQSGetM2MSpkrGain (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSGetM2MSpkrGain_t *pReqParam)

- int unpack_swiaudio_SLQSGetM2MSpkrGain (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSGetM2MSpkrGain_t *pOutput)
- int pack_swiaudio_SLQSSetM2MSpkrGain (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MSpkrGain_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MSpkrGain (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSSetM2MSpkrGain_t *pOutput)
- int pack_swiaudio_SLQSGetM2MAVMute (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSGetM2MAVMute_t *pReqParam)
- int unpack_swiaudio_SLQSGetM2MAVMute (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSGetM2MAVMute_t *pOutput)
- int pack_swiaudio_SLQSSetM2MAVMute (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiaudio_SLQSSetM2MAVMute_t *pReqParam)
- int unpack_swiaudio_SLQSSetM2MAVMute (uint8_t *pResp, uint16_t respLen, unpack_swiaudio_SLQSSetM2MAVMute_t *pOutput)

9.33.1 Macro Definition Documentation

9.33.1.1 #define SWIAUDIO_MAX_LEN_IFACE_TABLE 255

9.33.2 Typedef Documentation

9.33.2.1 typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAudioAVCFG_t

9.33.2.2 typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAudioLPBK_t

9.33.2.3 typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAudioNVDef_t

9.33.2.4 typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAudioProfile_t

9.33.2.5 typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAudioVolume_t

9.33.2.6 typedef unpack_result_t unpack_swiaudio_SLQSSetM2MAVMute_t

9.33.2.7 typedef unpack_result_t unpack_swiaudio_SLQSSetM2MSpkrGain_t

9.33.3 Function Documentation

9.33.3.1 int pack_swiaudio_SLQSGetM2MAudioProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSGetM2MAudioProfile_t * *pReqParam*)

Gets the profile content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.2 int pack_swiaudio_SLQSGetM2MAudioVolume (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSGetM2MAudioVolume_t * *pReqParam*)

Gets the Volume content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.3 int pack_swiaudio_SLQSGetM2MAVMute (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSGetM2MAVMute_t * *pReqParam*)

Gets the AV Mute content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.4 int pack_swiaudio_SLQSGetM2MSpkrGain (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSGetM2MSpkrGain_t * *pReqParam*)

Gets the SPKRGAIN content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.5 int pack_swiaudio_SLQSSetM2MAudioAVCFG (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MAudioAVCFG_t * *pReqParam*)

Sets the AVCFG content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.6 int pack_swiaudio_SLQSSetM2MAudioLPBK (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MAudioLPBK_t * *pReqParam*)

Sets the LPBK content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.7 int pack_swiaudio_SLQSSetM2MAudioNVDef (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Sets the NVDef content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.8 int pack_swiaudio_SLQSSetM2MAudioProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MAudioProfile_t * *pReqParam*)

sets an audio profile content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.9 int pack_swiaudio_SLQSSetM2MAudioVolume (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MAudioVolume_t * *pReqParam*)

Sets the Volume content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.10 int pack_swiaudio_SLQSSetM2MAVMute (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MAVMute_t * *pReqParam*)

Sets the AV Mute content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.11 int pack_swiaudio_SLQSSetM2MSpkrGain (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiaudio_SLQSSetM2MSpkrGain_t * *pReqParam*)

Sets the SPKRGAIN content pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameters

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.12 int unpack_swiaudio_SLQSGetM2MAudioProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSGetM2MAudioProfile_t * *pOutput*)

Gets the profile content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.13 int unpack_swiaudio_SLQSGetM2MAudioVolume (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSGetM2MAudioVolume_t * *pOutput*)

Gets the Volume content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.14 int unpack_swiaudio_SLQSGetM2MAVMute (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSGetM2MAVMute_t * *pOutput*)

Gets the AV Mute content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.15 int unpack_swiaudio_SLQSGetM2MSpkrGain (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSGetM2MSpkrGain_t * *pOutput*)

Gets the SPKRGAIN content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.16 int unpack_swiaudio_SLQSSetM2MAudioAVCFG (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSSetM2MAudioAVCFG_t * *pOutput*)

Sets the AVCFG content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.17 int unpack_swiaudio_SLQSSetM2MAudioLPBK (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSSetM2MAudioLPBK_t * *pOutput*)

Sets the LPBK content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.18 int unpack_swiaudio_SLQSSetM2MAudioNVDef (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSSetM2MAudioNVDef_t * *pOutput*)

Sets the NVDef content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.19 int unpack_swiaudio_SLQSSetM2MAudioProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSSetM2MAudioProfile_t * *pOutput*)

sets an audio profile content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.20 int unpack_swiaudio_SLQSSetM2MAudioVolume (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSSetM2MAudioVolume_t * *pOutput*)

Sets the Volume content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.21 int unpack_swiaudio_SLQSSetM2MAVMute (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSSetM2MAVMute_t * *pOutput*)

Sets the AV Mute content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.33.3.22 int unpack_swiaudio_SLQSSetM2MSpkrGain (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiaudio_SLQSSetM2MSpkrGain_t * *pOutput*)

Sets the SPKRGAIN content unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34 swiavms.h File Reference

Data Structures

- struct pack_swiavms_SLQSAVMSStartSession_t
- struct unpack_swiavms_SLQSAVMSStartSession_t
- struct pack_swiavms_SLQSAVMSStopSession_t
- struct unpack_swiavms_SLQSAVMSStopSession_t
- struct PackSwiAvmsSetSettingsPeriodInfo
- struct PackSwiAvmsSetSettingsAPNInfo
- struct PackSwiAvmsSetSettingsConnectionRetryTimers
- struct pack_swiavms_SLQSAVMSSetSettings_t
- struct unpack_swiavms_SLQSAVMSSetSettings_t
- struct pack_swiavms_SLQSAVMSSetSettings_v2_t
- struct unpack_swiavms_SLQSAVMSSetSettings_v2_t
- struct PackSwiAVMSSettingsAPNInfo
- struct PackSwiAVMSSettingsConnectionRetryTimers
- struct PackSwiAVMSSettingsPeriodsInfo
- struct unpack_swiavms_SLQSAVMSGetSettings_t
- struct unpack_swiavms_SLQSAVMSGetSettings_v2_t
- struct pack_swiavms_SLQSAVMSSendSelection_t
- struct unpack_swiavms_SLQSAVMSSendSelection_t
- struct unpack_swiavms_SLQSAvmsSetEventReport_t
- struct UnpackSwiAvmsEventReportBinaryUpdateSessionInfo
- struct UnpackSwiAvmsEventReportConfig
- struct UnpackSwiAvmsEventReportNotification
- struct UnpackSwiAvmsEventReportConnectionRequest

- struct UnpackSwiAvmsEventReportWAMSParamChange
- struct UnpackSwiAvmsEventReportPackageID
- struct UnpackSwiAvmsEventReportRegStatus
- struct UnpackSwiAvmsEventReportDataSessionStatus
- struct UnpackSwiAvmsEventReportSessionType
- struct UnpackSwiAvmsEventReportHTTPStatus
- struct unpack_swiavms_SLQSAVMSSessionGetInfo_t
- struct unpack_swiavms_SLQSAVMSEventReportInd_t

Macros

- #define LITEQMI_MAX_SWIOMA_STR_LEN 255
- #define LITEQMI_MAX_GET_SETTINGS_AVMS_APN_STRING_LENGTH 49
- #define LITEQMI_MAX_GET_SETTINGS_AVMS_UNAME_STRING_LENGTH 29
- #define LITEQMI_MAX_GET_SETTINGS_AVMS_PWD_STRING_LENGTH 29
- #define MAX_PACK_SWI_AVMS_SET_SETTING_APN_LENGTH 49
- #define MAX_PACK_SWI_AVMS_SET_SETTING_UNAME_LENGTH 29
- #define MAX_PACK_SWI_AVMS_SET_SETTING_PWD_LENGTH 29
- #define MAX_PACK_SWI_AVMS_SET_SETTING_CONNECTION_RETRY_TIMMERS 8
- #define MAX_AVMS_SETTINGS_RETRY_TIMER_NUMBER 8
- #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_VERSION_LENGTH 128
- #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_NAME_LENGTH 128
- #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_DESC_LENGTH 1024
- #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_CONFIG_ALERT_MSG_LENGTH 200

Functions

- int pack_swiavms_SLQSAVMSStartSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiavms_SLQSAVMSStartSession_t reqParam)
- int unpack_swiavms_SLQSAVMSStartSession (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSStartSession_t *pResponse)
- int pack_swiavms_SLQSAVMSStopSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiavms_SLQSAVMSStopSession_t reqParam)
- int unpack_swiavms_SLQSAVMSStopSession (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSStopSession_t *pResponse)
- int unpack_swiavms_SLQSAVMSStopSession_avc2 (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSStopSession_t *pResponse)
- int pack_swiavms_SLQSAVMSSetSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiavms_SLQSAVMSSetSettings_t reqParam)
- int unpack_swiavms_SLQSAVMSSetSettings (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSSetSettings_t *pResponse)
- int pack_swiavms_SLQSAVMSSetSettings_v2 (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiavms_SLQSAVMSSetSettings_v2_t reqParam)
- int unpack_swiavms_SLQSAVMSSetSettings_v2 (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSSetSettings_v2_t *pResponse)
- int pack_swiavms_SLQSAVMSSetSettingsNoAutoRebootField (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiavms_SLQSAVMSSetSettings_t reqParam)
- int pack_swiavms_SLQSAVMSGetSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swiavms_SLQSAVMSGetSettings (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSGetSettings_t *pResponse)
- int pack_swiavms_SLQSAVMSGetSettings_v2 (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)

- int unpack_swiavms_SLQSAVMSGetSettings_v2 (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSGetSettings_v2_t *pResponse)
- int pack_swiavms_SLQSAVMSSendSelection (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiavms_SLQSAVMSSendSelection_t reqParam)
- int unpack_swiavms_SLQSAVMSSendSelection (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSSendSelection_t *pResponse)
- int pack_swiavms_SLQSAvmsSetEventReport (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swiavms_SLQSAvmsSetEventReport (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAvmsSetEventReport_t *pResponse)
- int pack_swiavms_SLQSAVMSSessionGetInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swiavms_SLQSAVMSSessionGetInfo (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSSessionGetInfo_t *pResponse)
- int unpack_swiavms_SLQSAVMSEventReportInd (uint8_t *pResp, uint16_t respLen, unpack_swiavms_SLQSAVMSEventReportInd_t *pResponse)

9.34.1 Macro Definition Documentation

9.34.1.1 #define LITEQMI_MAX_GET_SETTINGS_AVMS_APN_STRING_LENGTH 49

9.34.1.2 #define LITEQMI_MAX_GET_SETTINGS_AVMS_PWD_STRING_LENGTH 29

9.34.1.3 #define LITEQMI_MAX_GET_SETTINGS_AVMS_UNAME_STRING_LENGTH 29

9.34.1.4 #define LITEQMI_MAX_SWIOMA_STR_LEN 255

9.34.1.5 #define MAX_AVMS_SETTINGS_RETRY_TIMER_NUMBER 8

9.34.1.6 #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_DESC_LENGTH 1024

9.34.1.7 #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_NAME_LENGTH 128

9.34.1.8 #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_BINARYUPDATESESSIONINFO_VERSION_LENGTH 128

9.34.1.9 #define MAX_PACK_SWI_AVMS_SESSIONGETINFO_CONFIG_ALERT_MSG_LENGTH 200

9.34.1.10 #define MAX_PACK_SWI_AVMS_SET_SETTING_APN_LENGTH 49

9.34.1.11 #define MAX_PACK_SWI_AVMS_SET_SETTING_CONNECTION_RETRY_TIMMERS 8

9.34.1.12 #define MAX_PACK_SWI_AVMS_SET_SETTING_PWD_LENGTH 29

9.34.1.13 #define MAX_PACK_SWI_AVMS_SET_SETTING_UNAME_LENGTH 29

9.34.2 Function Documentation

9.34.2.1 int pack_swiavms_SLQSAVMSGetSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack AVMS Get settings command This maps to SLQSAVMSSetSettings

Parameters

out	*pCtx*	• See pack_qmi_t for more information

in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.2 int pack_swiavms_SLQSAVMSGetSettings_v2 (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack AVMS Get settings command This maps to SLQSAVMSSetSettings_v2 (For AVC2 service)

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.3 int pack_swiavms_SLQSAVMSSendSelection (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiavms_SLQSAVMSSendSelection_t *reqParam*)

Function to pack AVMS send selection command This maps to SLQSAVMSSendSelection

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_swiavms_SLQSAVMSSendSelection_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.4 int pack_swiavms_SLQSAVMSSessionGetInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack AVMS get session info command This maps to SLQSAVMSSessionGetInfo

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.5 int pack_swiavms_SLQSAvmsSetEventReport (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack AVMS set event report command This maps to SLQSAVMSSetEventReport

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.6 int pack_swiavms_SLQSAVMSSetSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiavms_SLQSAVMSSetSettings_t *reqParam*)

Function to pack AVMS Set settings command This maps to SLQSAVMSSetSettings

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes

in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_swiavms_SLQSAVMSSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.7 int pack_swiavms_SLQSAVMSSetSettings_v2 (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiavms_SLQSAVMSSetSettings_v2_t *reqParam*)

Function to pack AVMS Set settings command This maps to SLQSAVMSSetSettings_v2 (For AVC2 service)

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_swiavms_SLQSAVMSSetSettings_v2_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.8 int pack_swiavms_SLQSAVMSSetSettingsNoAutoRebootField (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiavms_SLQSAVMSSetSettings_t *reqParam*)

Function to pack AVMS Set settings without Auto Reobot field command This maps to SLQSAVMSSetSettings-IgnoreAutoReboot

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_swiavms_SLQSAVMSSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.9 int pack_swiavms_SLQSAVMSStartSession (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiavms_SLQSAVMSStartSession_t *reqParam*)

Function to pack Start AVMS session command This maps to SLQSAVMSStartSession

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_swiavms_SLQSAVMSStartSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.10 int pack_swiavms_SLQSAVMSStopSession (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiavms_SLQSAVMSStopSession_t *reqParam*)

Function to pack cancel AVMS session command This maps to SLQSAVMSStopSession

Parameters

out	*pCtx*	• See pack_qmi_t for more information
in,out	*pReqBuf*	• Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
in,out	*pLen*	• On input, size of pReqBuf • On ouptut, number of bytes actually packed
in	*reqParam*	• See pack_swiavms_SLQSAVMSStopSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 2 seconds

9.34.2.11 int unpack_swiavms_SLQSAVMSEventReportInd (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSEventReportInd_t * *pResponse*)

Function to unpack AVMS event report Indication command This maps to SLQSAVMSSetEventReport

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSEventReportInd_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.12 int unpack_swiavms_SLQSAVMSGetSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSGetSettings_t * *pResponse*)

Function to unpack AVMS set settings command This maps to SLQSAVMSGetSettings

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.13 int unpack_swiavms_SLQSAVMSGetSettings_v2 (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSGetSettings_v2_t * *pResponse*)

Function to unpack AVMS set settings command This maps to SLQSAVMSGetSettings_v2 (For AVC2 service)

Parameters

in	*pResp*	• Response from modem

in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.14 int unpack_swiavms_SLQSAVMSSendSelection (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSSendSelection_t * *pResponse*)

Function to unpack AVMS send selection command This maps to SLQSAVMSSendSelection

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSSendSelection_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.15 int unpack_swiavms_SLQSAVMSSessionGetInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSSessionGetInfo_t * *pResponse*)

Function to unpack AVMS event report Indication command This maps to SLQSAVMSSetEventReport

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem

out	*pResponse*	• See unpack_swiavms_SLQSAVMSSessionGetInfo_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.16 int unpack_swiavms_SLQSAvmsSetEventReport (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAvmsSetEventReport_t * *pResponse*)

Function to unpack AVMS set event report command This maps to SLQSAVMSSetEventReport

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAvmsSetEventReport_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.17 int unpack_swiavms_SLQSAVMSSetSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSSetSettings_t * *pResponse*)

Function to unpack AVMS Set settings command This maps to SLQSAVMSSetSettings

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.18 int unpack_swiavms_SLQSAVMSSetSettings_v2 (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSSetSettings_v2_t * *pResponse*)

Function to unpack AVMS Set settings command This maps to SLQSAVMSSetSettings_v2 (For AVC2 service)

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSSetSettings_v2_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.19 int unpack_swiavms_SLQSAVMSStartSession (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSStartSession_t * *pResponse*)

Function to unpack Start AVMS session response from modem This maps to SLQSAVMSStartSession

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSStartSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.20 int unpack_swiavms_SLQSAVMSStopSession (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSStopSession_t * *pResponse*)

Function to pack stop AVMS session command This maps to SLQSAVMSStopSession

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSStopSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.34.2.21 int unpack_swiavms_SLQSAVMSStopSession_avc2 (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiavms_SLQSAVMSStopSession_t * *pResponse*)

Function to pack stop AVMS session command This maps to SLQSAVMSStopSession Note: this targets WP760x as the stop response doesn't contains mandatory session_type(0x01) TLV

Parameters

in	*pResp*	• Response from modem
in	*respLen*	• Length of pResp from modem
out	*pResponse*	• See unpack_swiavms_SLQSAVMSStopSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.35 SwiDataTypes.h File Reference

SWI data types.

Data Structures

- struct qmTlvResult

Macros

- #define SWI_API
- #define QMI_NO_LTE_FW_SUPPORT 0
- #define QMI_TLV_PLACEHOLDER 0x8F
- #define UNUSEDPARAM(x) (void)x
- #define MEMSET_STATIC_OUTPUT_STRUCT(OUTPUT_PARA, STRUCT_OF_OUTPUT_PARA) memset(O-UTPUT_PARA,0,sizeof(STRUCT_OF_OUTPUT_PARA));\

Typedefs

- typedef unsigned int ULONG
- typedef unsigned long long ULONGLONG
- typedef signed char INT8
- typedef unsigned char BYTE
- typedef char CHAR
- typedef unsigned short WORD
- typedef unsigned short USHORT
- typedef const char * LPCSTR
- typedef int BOOL
- typedef signed short SHORT
- typedef signed int INT32
- typedef float FLOAT
- typedef unsigned short qmuint16
- typedef unsigned long qmulong

9.35.1 Detailed Description

SWI data types.

9.35.2 Macro Definition Documentation

9.35.2.1 #define MEMSET_STATIC_OUTPUT_STRUCT(*OUTPUT_PARA, STRUCT_OF_OUTPUT_PARA*) memset(OUTPUT_PARA,0,sizeof(STRUCT_OF_OUTPUT_PARA));\

Macro used to memset unpack output paramter. To prevent output parameter is not inititalized.

9.35.2.2 #define QMI_NO_LTE_FW_SUPPORT 0

9.35.2.3 #define QMI_TLV_PLACEHOLDER 0x8F

9.35.2.4 #define SWI_API

9.35.2.5 #define UNUSEDPARAM(*x*) (void)x

Macro used to avoid “unused variable” compiler warnings generated due to the inclusion of the "-Wextra" flag in our make files.

9.35.3 Typedef Documentation

9.35.3.1 typedef int BOOL

9.35.3.2 typedef unsigned char BYTE

9.35.3.3 typedef char CHAR

9.35.3.4 typedef float FLOAT

9.35.3.5 typedef signed int INT32

9.35.3.6 typedef signed char INT8

9.35.3.7 typedef const char* LPCSTR

9.35.3.8 typedef unsigned short qmuint16

9.35.3.9 typedef unsigned long qmulong

9.35.3.10 typedef signed short SHORT

9.35.3.11 typedef unsigned int ULONG

9.35.3.12 typedef unsigned long long ULONGLONG

9.35.3.13 typedef unsigned short USHORT

9.35.3.14 typedef unsigned short WORD

9.36 swidms.h File Reference

Data Structures

- struct unpack_swidms_SLQSSwiDmsGetUsbNetNum_t
- struct pack_swidms_SLQSSwiDmsSetUsbNetNum_t
- struct pack_swidms_SLQSSwiDmsSetMTU_t
- struct unpack_swidms_SLQSSwiDmsSetMTU_t
- struct swidms_mtuSize3gppTlv
- struct swidms_hrpdMTUSizeTlv
- struct swidms_ehrpdMTUSizeTlv
- struct swidms_usbMTUSizeTlv
- struct unpack_swidms_SLQSSwiDmsGetMTU_t
- struct swidms_intfaceCfgTlv

- struct swidms_supportedIntBitmaskTlv
- struct unpack_swidms_SLQSSwiDmsGetUsbComp_t
- struct pack_swidms_SLQSSwiDmsSetUsbComp_t
- struct unpack_swidms_SLQSSwiDmsSetUsbComp_t

Typedefs

- typedef unpack_result_t unpack_swidms_SLQSSwiDmsSetUsbNetNum_t

Functions

- int pack_swidms_SLQSSwiDmsGetUsbNetNum (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swidms_SLQSSwiDmsGetUsbNetNum (uint8_t *pResp, uint16_t respLen, unpack_swidms_SLQSSwiDmsGetUsbNetNum_t *pOutput)
- int pack_swidms_SLQSSwiDmsSetUsbNetNum (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swidms_SLQSSwiDmsSetUsbNetNum_t *pReqParam)
- int unpack_swidms_SLQSSwiDmsSetUsbNetNum (uint8_t *pResp, uint16_t respLen, unpack_swidms_SLQSSwiDmsSetUsbNetNum_t *pOutput)
- int pack_swidms_SLQSSwiDmsSetMTU (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swidms_SLQSSwiDmsSetMTU_t *reqArg)
- int unpack_swidms_SLQSSwiDmsSetMTU (uint8_t *pResp, uint16_t respLen, unpack_swidms_SLQSSwiDmsSetMTU_t *pOutput)
- int pack_swidms_SLQSSwiDmsGetMTU (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swidms_SLQSSwiDmsGetMTU (uint8_t *pResp, uint16_t respLen, unpack_swidms_SLQSSwiDmsGetMTU_t *pOutput)
- int pack_swidms_SLQSSwiDmsGetUsbComp (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swidms_SLQSSwiDmsGetUsbComp (uint8_t *pResp, uint16_t respLen, unpack_swidms_SLQSSwiDmsGetUsbComp_t *pOutput)
- int pack_swidms_SLQSSwiDmsSetUsbComp (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swidms_SLQSSwiDmsSetUsbComp_t *reqArg)
- int unpack_swidms_SLQSSwiDmsSetUsbComp (uint8_t *pResp, uint16_t respLen, unpack_swidms_SLQSSwiDmsSetUsbComp_t *pOutput)

9.36.1 Typedef Documentation

9.36.1.1 typedef unpack_result_t unpack_swidms_SLQSSwiDmsSetUsbNetNum_t

9.36.2 Function Documentation

9.36.2.1 int pack_swidms_SLQSSwiDmsGetMTU (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get the preferred MTU Size of the 3GPP, HRPD, EHRPD and USB descriptor Interfaces pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.2.2 int pack_swidms_SLQSSwiDmsGetUsbComp (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the usb interface composition pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.2.3 int pack_swidms_SLQSSwiDmsGetUsbNetNum (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

pack function to get usb net numbers for QMAP configuration

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.2.4 int pack_swidms_SLQSSwiDmsSetMTU (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swidms_SLQSSwiDmsSetMTU_t * *reqArg*)

Sets the preferred MTU size for 3GPP, HRPD, EHRPD Interfaces pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.2.5 int pack_swidms_SLQSSwiDmsSetUsbComp (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swidms_SLQSSwiDmsSetUsbComp_t * *reqArg*)

Sets the usb interface config value pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values. This setting will be effective after modem reboot

9.36.2.6 int pack_swidms_SLQSSwiDmsSetUsbNetNum (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swidms_SLQSSwiDmsSetUsbNetNum_t * *pReqParam*)

pack function to set usb net numbers for QMAP configuration

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request params

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.2.7 int unpack_swidms_SLQSSwiDmsGetMTU (uint8_t * *pResp*, uint16_t *respLen*, unpack_swidms_SLQSSwiDmsGetMTU_t * *pOutput*)

Get the MTU Size of the 3GPP, HRPD, EHRPD and USB descriptor Interfaces unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.2.8 int unpack_swidms_SLQSSwiDmsGetUsbComp (uint8_t * *pResp*, uint16_t *respLen*, unpack_swidms_SLQSSwiDmsGetUsbComp_t * *pOutput*)

Gets the usb interface composition unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.2.9 int unpack_swidms_SLQSSwiDmsGetUsbNetNum (uint8_t * *pResp*, uint16_t *respLen*, unpack_swidms_SLQSSwiDmsGetUsbNetNum_t * *pOutput*)

unpack function to get usb net numbers for QMAP configuration

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.2.10 int unpack_swidms_SLQSSwiDmsSetMTU (uint8_t * *pResp*, uint16_t *respLen*, unpack_swidms_SLQSSwiDmsSetMTU_t * *pOutput*)

Sets preferred MTU size for 3GPP, HRPD, EHRPD Interfaces unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.36.2.11 int unpack_swidms_SLQSSwiDmsSetUsbComp (uint8_t * *pResp*, uint16_t *respLen*, unpack_swidms_SLQSSwiDmsSetUsbComp_t * *pOutput*)

Sets the usb interface config value unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values. This setting will be effective after modem reboot

9.36.2.12 int unpack_swidms_SLQSSwiDmsSetUsbNetNum (uint8_t * *pResp*, uint16_t *respLen*, unpack_swidms_SLQSSwiDmsSetUsbNetNum_t * *pOutput*)

unpack function to set usb net numbers for QMAP configuration

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.37 swiloc.h File Reference

Data Structures

- struct unpack_swiloc_SwiLocGetAutoStart_t
- struct pack_swiloc_SwiLocSetAutoStart_t

Typedefs

- typedef unpack_result_t unpack_swiloc_SwiLocSetAutoStart_t

Functions

- int pack_swiloc_SwiLocGetAutoStart (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swiloc_SwiLocGetAutoStart (uint8_t *pResp, uint16_t respLen, unpack_swiloc_SwiLocGetAutoStart_t *pOutput)
- int pack_swiloc_SwiLocSetAutoStart (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swiloc_SwiLocSetAutoStart_t *reqArg)
- int unpack_swiloc_SwiLocSetAutoStart (uint8_t *pResp, uint16_t respLen, unpack_swiloc_SwiLocSetAutoStart_t *pOutput)

9.37.1 Typedef Documentation

9.37.1.1 typedef unpack_result_t unpack_swiloc_SwiLocSetAutoStart_t

9.37.2 Function Documentation

9.37.2.1 int pack_swiloc_SwiLocGetAutoStart (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Get Auto Start pack

Parameters

in	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.37.2.2 int pack_swiloc_SwiLocSetAutoStart (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swiloc_SwiLocSetAutoStart_t * *reqArg*)

Set Auto Start pack

Parameters

in	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.37.2.3 int unpack_swiloc_SwiLocGetAutoStart (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiloc_SwiLocGetAutoStart_t * *pOutput*)

Get Auto Start unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.37.2.4 int unpack_swiloc_SwiLocSetAutoStart (uint8_t * *pResp*, uint16_t *respLen*, unpack_swiloc_SwiLocSetAutoStart_t * *pOutput*)

Set Auto Start unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.38 swioma.h File Reference

Data Structures

- struct pack_swioma_SLQSOMADMStartSession_t
- struct unpack_swioma_SLQSOMADMStartSession_t
- struct pack_swioma_SLQSOMADMCancelSession_t
- struct unpack_swioma_SLQSOMADMGetSettings_t
- struct pack_swioma_SLQSOMADMSetSettings_t
- struct pack_swioma_SLQSOMADMSendSelection_t
- struct pack_swioma_SLQSOMADMGetSessionInfo_t
- struct unpack_swioma_SLQSOMADMGetSessionInfo_t
- struct unpack_omaDmFotaTlv_t
- struct unpack_omaDmConfigTlv_t
- struct unpack_omaDmNotificationsTlv_t
- struct unpack_swioma_SLQSOMADMAlertCallback_ind_t

Macros

- #define LITEQMI_MAX_SWIOMA_STR_LEN 255

Typedefs

- typedef unpack_result_t unpack_swioma_SLQSOMADMCancelSession_t
- typedef unpack_result_t unpack_swioma_SLQSOMADMSetSettings_t
- typedef unpack_result_t unpack_swioma_SLQSOMADMSendSelection_t
- typedef unpack_result_t unpack_swioma_SLQSOMADMAlertCallback_t

Functions

- int pack_swioma_SLQSOMADMStartSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMStartSession_t reqParam)
- int unpack_swioma_SLQSOMADMStartSession (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMStartSession_t *pOutput)
- int pack_swioma_SLQSOMADMCancelSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMCancelSession_t reqParam)
- int unpack_swioma_SLQSOMADMCancelSession (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMCancelSession_t *pOutput)
- int pack_swioma_SLQSOMADMGetSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swioma_SLQSOMADMGetSettings (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMGetSettings_t *pOutput)
- int pack_swioma_SLQSOMADMSetSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMSetSettings_t reqParam)
- int unpack_swioma_SLQSOMADMSetSettings (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMSetSettings_t *pOutput)
- int pack_swioma_SLQSOMADMSendSelection (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMSendSelection_t reqParam)
- int unpack_swioma_SLQSOMADMSendSelection (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMSendSelection_t *pOutput)
- int pack_swioma_SLQSOMADMGetSessionInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMGetSessionInfo_t reqParam)
- int unpack_swioma_SLQSOMADMGetSessionInfo (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMGetSessionInfo_t *pOutput)
- int pack_swioma_SLQSOMADMAlertCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_swioma_SLQSOMADMAlertCallback (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMAlertCallback_t *pOutput)
- int unpack_swioma_SLQSOMADMAlertCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMAlertCallback_ind_t *pOutput)

9.38.1 Macro Definition Documentation

9.38.1.1 #define LITEQMI_MAX_SWIOMA_STR_LEN 255

9.38.2 Typedef Documentation

9.38.2.1 typedef unpack_result_t unpack_swioma_SLQSOMADMAlertCallback_t

9.38.2.2 typedef unpack_result_t unpack_swioma_SLQSOMADMCancelSession_t

9.38.2.3 typedef unpack_result_t unpack_swioma_SLQSOMADMSendSelection_t

9.38.2.4 typedef unpack_result_t unpack_swioma_SLQSOMADMSetSettings_t

9.38.3 Function Documentation

9.38.3.1 int pack_swioma_SLQSOMADMAlertCallback (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen*)

Function to pack QMI command to enable the SWIOMADM network-initiated alert callback function. This maps to SetSLQSOMADMAlertCallback

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On ouptut, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.38.3.2 int pack_swioma_SLQSOMADMCancelSession (pack_qmi_t * *pCtx,* uint8_t * *pReqBuf,* uint16_t * *pLen,* pack_swioma_SLQSOMADMCancelSession_t *reqParam*)

Function to pack cancel OMA-DM session command This maps to SLQSOMADMCancelSession

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On output, number of bytes actually packed
reqParam	[in] • See pack_swioma_SLQSOMADMCancelSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.38.3.3 int pack_swioma_SLQSOMADMGetSessionInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMGetSessionInfo_t *reqParam*)

Function to pack QMI command to return information related to the current (or previous if no session is active) OMA-DM session. This maps to SLQSOMADMGetSessionInfo

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[in] • See pack_swioma_SLQSOMADMGetSessionInfo_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.38.3.4 int pack_swioma_SLQSOMADMGetSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Function to pack command to retrieve the OMA-DM settings from the device. This maps to SLQSOMADMGetSettings2

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On output, number of bytes actually packed

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.38.3.5 int pack_swioma_SLQSOMADMSendSelection (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMSendSelection_t *reqParam*)

Function to pack OMA-DM send selection command This maps to SLQSOMADMSendSelection2

Parameters

pCtx	[out] • See pack_qmi_t for more information

pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[in] • See pack_swioma_SLQSOMADMSendSelection_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.38.3.6 int pack_swioma_SLQSOMADMSetSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMSetSettings_t *reqParam*)

Function to pack OMA-DM set settings command This maps to SLQSOMADMSetSettings3

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[in] • See pack_swioma_SLQSOMADMSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.38.3.7 int pack_swioma_SLQSOMADMStartSession (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMStartSession_t *reqParam*)

Function to pack Start OMA-DM session command This maps to SLQSOMADMStartSession2

Parameters

pCtx	[out] • See pack_qmi_t for more information
pReqBuf	[in,out] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[in,out] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[in] • See pack_swioma_SLQSOMADMStartSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.38.3.8 int unpack_swioma_SLQSOMADMAlertCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMAlertCallback_t * *pOutput*)

Function to unpack response of QMI command to enable the SWIOMADM network-initiated alert callback function. This maps to SetSLQSOMADMAlertCallback

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem
pOutput	[out] • response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

- Please use eQMI_SWIOMA_EVENT_IND indication to identify this event from SWIOMA service read function

9.38.3.9 int unpack_swioma_SLQSOMADMAlertCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMAlertCallback_ind_t * *pOutput*)

Function to unpack SWIOMADM alert indications This maps to SetSLQSOMADMAlertCallback

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem
pOutput	[out] • See unpack_swioma_SLQSOMADMAlertCallback_ind_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.38.3.10 int unpack_swioma_SLQSOMADMCancelSession (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMCancelSession_t * *pOutput*)

Function to pack cancel OMA-DM session command This maps to SLQSOMADMCancelSession

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem
pOutput	[out] • response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.38.3.11 int unpack_swioma_SLQSOMADMGetSessionInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMGetSessionInfo_t * *pOutput*)

Function to unpack information related to the current (or previous if no session is active) OMA-DM session. This maps to SLQSOMADMGetSessionInfo

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem
pOutput	[out] • See unpack_swioma_SLQSOMADMGetSessionInfo_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.38.3.12 int unpack_swioma_SLQSOMADMGetSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMGetSettings_t * *pOutput*)

Function to unpack OMA-DM get settings response from modem This maps to SLQSOMADMGetSettings2

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem
pOutput	[out] • See unpack_swioma_SLQSOMADMGetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.38.3.13 int unpack_swioma_SLQSOMADMSendSelection (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMSendSelection_t * *pOutput*)

Function to unpack OMA-DM send selection command This maps to SLQSOMADMSendSelection2

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem
pOutput	[out] • response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.38.3.14 int unpack_swioma_SLQSOMADMSetSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMSetSettings_t * *pOutput*)

Function to unpack OMA-DM set settings command This maps to SLQSOMADMSetSettings3

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem
pOutput	[out] • response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.38.3.15 int unpack_swioma_SLQSOMADMStartSession (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMStartSession_t * *pOutput*)

Function to unpack Start OMA-DM session response from modem This maps to SLQSOMADMStartSession2

Parameters

pResp	[in] • Response from modem
respLen	[in] • Length of pResp from modem
pOutput	[out] • See unpack_swioma_SLQSOMADMStartSession_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.39 swiomaext.h File Reference

Data Structures

- struct pack_swioma_SLQSOMADMStartSessionExt_t
- struct pack_swioma_SLQSOMADMCancelSessionExt_t
- struct pack_swioma_SLQSOMADMSetSettingsExt_t
- struct pack_swioma_SLQSOMADMSendSelectionExt_t

Macros

- #define LITEQMI_MAX_SWIOMA_STR_LEN 255

Typedefs

- typedef unpack_result_t unpack_swioma_SLQSOMADMStartSessionExt_t
- typedef unpack_result_t unpack_swioma_SLQSOMADMCancelSessionExt_t
- typedef unpack_result_t unpack_swioma_SLQSOMADMSetSettingsExt_t
- typedef unpack_result_t unpack_swioma_SLQSOMADMSendSelectionExt_t

Functions

- int pack_swioma_SLQSOMADMStartSessionExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMStartSessionExt_t reqParam)
- int unpack_swioma_SLQSOMADMStartSessionExt (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMStartSessionExt_t *pOutput)
- int pack_swioma_SLQSOMADMCancelSessionExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMCancelSessionExt_t reqParam)

- int unpack_swioma_SLQSOMADMCancelSessionExt (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMCancelSessionExt_t *pOutput)
- int pack_swioma_SLQSOMADMSetSettingsExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMSetSettingsExt_t reqParam)
- int unpack_swioma_SLQSOMADMSetSettingsExt (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMSetSettingsExt_t *pOutput)
- int pack_swioma_SLQSOMADMSendSelectionExt (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_swioma_SLQSOMADMSendSelectionExt_t reqParam)
- int unpack_swioma_SLQSOMADMSendSelectionExt (uint8_t *pResp, uint16_t respLen, unpack_swioma_SLQSOMADMSendSelectionExt_t *pOutput)

9.39.1 Macro Definition Documentation

9.39.1.1 #define LITEQMI_MAX_SWIOMA_STR_LEN 255

9.39.2 Typedef Documentation

9.39.2.1 typedef unpack_result_t unpack_swioma_SLQSOMADMCancelSessionExt_t

9.39.2.2 typedef unpack_result_t unpack_swioma_SLQSOMADMSendSelectionExt_t

9.39.2.3 typedef unpack_result_t unpack_swioma_SLQSOMADMSetSettingsExt_t

9.39.2.4 typedef unpack_result_t unpack_swioma_SLQSOMADMStartSessionExt_t

9.39.3 Function Documentation

9.39.3.1 int pack_swioma_SLQSOMADMCancelSessionExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMCancelSessionExt_t *reqParam*)

Function to pack cancel OMA-DM session command This maps to SLQSOMADMCancelSessionExt

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[IN] • See pack_swioma_SLQSOMADMCancelSessionExt_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.39.3.2 int pack_swioma_SLQSOMADMSendSelectionExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMSendSelectionExt_t *reqParam*)

Function to pack OMA-DM send selection command This maps to SLQSOMADMSendSelectionExt

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[IN] • See pack_swioma_SLQSOMADMSendSelectionExt_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.39.3.3 int pack_swioma_SLQSOMADMSetSettingsExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMSetSettingsExt_t *reqParam*)

Function to pack OMA-DM set settings command This maps to SLQSOMADMSetSettingsExt

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes

pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[IN] • See pack_swioma_SLQSOMADMSetSettings_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.39.3.4 int pack_swioma_SLQSOMADMStartSessionExt (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_swioma_SLQSOMADMStartSessionExt_t *reqParam*)

Function to pack Start OMA-DM session command This maps to SLQSOMADMStartSessionExt

Parameters

pCtx	[OUT] • See pack_qmi_t for more information
pReqBuf	[IN/OUT] • Buffer for packed QMI command to be provided by the host application • Minimum expected size is 2048 bytes
pLen	[IN/OUT] • On input, size of pReqBuf • On ouptut, number of bytes actually packed
reqParam	[IN] • See pack_swioma_SLQSOMADMStartSessionExt_t for more information

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

Timeout: 20 seconds

9.39.3.5 int unpack_swioma_SLQSOMADMCancelSessionExt (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMCancelSessionExt_t * *pOutput*)

Function to pack cancel OMA-DM session command This maps to SLQSOMADMCancelSessionExt

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem
pOutput	[OUT] • response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.39.3.6 int unpack_swioma_SLQSOMADMSendSelectionExt (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMSendSelectionExt_t * *pOutput*)

Function to unpack OMA-DM send selection command This maps to SLQSOMADMSendSelectionExt

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem
pOutput	[OUT] • response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.39.3.7 int unpack_swioma_SLQSOMADMSetSettingsExt (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMSetSettingsExt_t * *pOutput*)

Function to unpack OMA-DM set settings command This maps to SLQSOMADMSetSettingsExt

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem
pOutput	[OUT] • response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.39.3.8 int unpack_swioma_SLQSOMADMStartSessionExt (uint8_t * *pResp*, uint16_t *respLen*, unpack_swioma_SLQSOMADMStartSessionExt_t * *pOutput*)

Function to unpack Start OMA-DM session response from modem This maps to SLQSOMADMStartSessionExt

Parameters

pResp	[IN] • Response from modem
respLen	[IN] • Length of pResp from modem
pOutput	[OUT] • response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.40 switype_256bit.h File Reference

Data Structures

- struct swi_uint256_t

Macros

- #define SWI_UINT256_WORD_COUNT 16

- #define SWI_UINT256_BITS_PER_WORD 16
- #define SWI_UINT256_WORD_OFFSET(val) ((val) / SWI_UINT256_BITS_PER_WORD)
- #define SWI_UINT256_BIT_OFFSET(val) ((val) % SWI_UINT256_BITS_PER_WORD)
- #define SWI_UINT256_INT_VALUE {{0}}

Functions

- void swi_uint256_set_bit (swi_uint256_t *pMask, uint8_t bit)
- void swi_uint256_clear_bit (swi_uint256_t *pMask, uint8_t bit)
- uint8_t swi_uint256_get_bit (swi_uint256_t Mask, uint8_t bit)
- void swi_uint256_print_mask (swi_uint256_t mask)

9.40.1 Macro Definition Documentation

9.40.1.1 #define SWI_UINT256_BIT_OFFSET(*val*) ((val) % SWI_UINT256_BITS_PER_WORD)

9.40.1.2 #define SWI_UINT256_BITS_PER_WORD 16

9.40.1.3 #define SWI_UINT256_INT_VALUE {{0}}

9.40.1.4 #define SWI_UINT256_WORD_COUNT 16

9.40.1.5 #define SWI_UINT256_WORD_OFFSET(*val*) ((val) / SWI_UINT256_BITS_PER_WORD)

9.40.2 Function Documentation

9.40.2.1 void swi_uint256_clear_bit (swi_uint256_t * *pMask*, uint8_t *bit*)

Clear relevant bit in provided mask

Parameters

in	*pMask*	Pointer to bitmask
in	*bit*	Bit to clear

9.40.2.2 uint8_t swi_uint256_get_bit (swi_uint256_t *Mask*, uint8_t *bit*)

Get relevant bit from provided mask

Parameters

in	*Mask*	Bit mask
in	*bit*	Bit to extract

Returns

Bit value

- 0 - bit is not set
- 1 - bit is set

9.40.2.3 void swi_uint256_print_mask (swi_uint256_t *mask*)

Print the log mask to syslog. Use only for debugging

Parameters

in	*mask*	Bit mask

9.40.2.4 void swi_uint256_set_bit (swi_uint256_t * *pMask*, uint8_t *bit*)

Set relevant bit in provided mask

Parameters

in	*pMask*	Pointer to bit mask
in	*bit*	Bit to set

9.41 SWIWWANCMAPI.h File Reference

9.42 tmd.h File Reference

Data Structures

- struct tmd_mitigationDevList
- struct unpack_tmd_SLQSTmdGetMitigationDevList_t
- struct pack_tmd_SLQSTmdGetMitigationLvl_t
- struct unpack_tmd_SLQSTmdGetMitigationLvl_t
- struct pack_tmd_SLQSTmdRegNotMitigationLvl_t
- struct unpack_tmd_SLQSTmdRegNotMitigationLvl_t
- struct pack_tmd_SLQSTmdDeRegNotMitigationLvl_t
- struct unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t
- struct unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t

Macros

- #define TMD_MAX_DEV_LIST 255
- #define MAX_MITIGATION_DEV_LIST_LEN 255
- #define MAX_MITIGATION_DEV_ID_LEN 255

Functions

- int pack_tmd_SLQSTmdGetMitigationDevList (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_tmd_SLQSTmdGetMitigationDevList (uint8_t *pResp, uint16_t respLen, unpack_tmd_SLQSTmdGetMitigationDevList_t *pOutput)
- int pack_tmd_SLQSTmdGetMitigationLvl (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_tmd_SLQSTmdGetMitigationLvl_t *reqArg)
- int unpack_tmd_SLQSTmdGetMitigationLvl (uint8_t *pResp, uint16_t respLen, unpack_tmd_SLQSTmdGetMitigationLvl_t *pOutput)
- int pack_tmd_SLQSTmdRegNotMitigationLvl (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_tmd_SLQSTmdRegNotMitigationLvl_t *reqArg)
- int unpack_tmd_SLQSTmdRegNotMitigationLvl (uint8_t *pResp, uint16_t respLen, unpack_tmd_SLQSTmdRegNotMitigationLvl_t *pOutput)
- int pack_tmd_SLQSTmdDeRegNotMitigationLvl (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_tmd_SLQSTmdDeRegNotMitigationLvl_t *reqArg)
- int unpack_tmd_SLQSTmdDeRegNotMitigationLvl (uint8_t *pResp, uint16_t respLen, unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t *pOutput)
- int unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t *pOutput)

9.42.1 Macro Definition Documentation

9.42.1.1 #define MAX_MITIGATION_DEV_ID_LEN 255

9.42.1.2 #define MAX_MITIGATION_DEV_LIST_LEN 255

9.42.1.3 #define TMD_MAX_DEV_LIST 255

9.42.2 Function Documentation

9.42.2.1 int pack_tmd_SLQSTmdDeRegNotMitigationLvl (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_tmd_SLQSTmdDeRegNotMitigationLvl_t * *reqArg*)

To DeRegister notification mitigation level pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*reqArg*	request argument.

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.2.2 int pack_tmd_SLQSTmdGetMitigationDevList (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

To get mitigation device list pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.2.3 int pack_tmd_SLQSTmdGetMitigationLvl (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_tmd_SLQSTmdGetMitigationLvl_t * *reqArg*)

To get mitigation level pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*reqArg*	request argument.

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.2.4 int pack_tmd_SLQSTmdRegNotMitigationLvl (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_tmd_SLQSTmdRegNotMitigationLvl_t * *reqArg*)

To Register notification mitigation level pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
out	*reqArg*	request argument.

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.2.5 int unpack_tmd_SLQSTmdDeRegNotMitigationLvl (uint8_t * *pResp*, uint16_t *respLen*, unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t * *pOutput*)

To De-Register notification mitigation level unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.2.6 int unpack_tmd_SLQSTmdGetMitigationDevList (uint8_t * *pResp*, uint16_t *respLen*, unpack_tmd_SLQSTmdGetMitigationDevList_t * *pOutput*)

To mitigation device list unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.2.7 int unpack_tmd_SLQSTmdGetMitigationLvl (uint8_t * *pResp*, uint16_t *respLen*, unpack_tmd_SLQSTmdGetMitigationLvl_t * *pOutput*)

To get mitigation level unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.2.8 int unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t * *pOutput*)

Mitigiation Level Report Indication unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	indication unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.42.2.9 int unpack_tmd_SLQSTmdRegNotMitigationLvl (uint8_t * *pResp*, uint16_t *respLen*, unpack_tmd_SLQSTmdRegNotMitigationLvl_t * *pOutput*)

To Register notification mitigation level unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43 uim.h File Reference

Data Structures

- struct uim_appStatus
- struct uim_slotInfo
- struct uim_cardStatus
- struct uim_hotSwapStatus
- struct unpack_uim_GetCardStatus_t
- struct uim_encryptedPIN1
- struct uim_remainingRetries
- struct uim_sessionInformation
- struct uim_verifyUIMPIN
- struct uim_unblockUIMPIN
- struct uim_cardResult
- struct uim_setPINProtection
- struct uim_changeUIMPIN
- struct uim_fileInfo
- struct uim_UIMSessionInformation
- struct uim_readTransparentInfo
- struct uim_readResult
- struct pack_uim_VerifyPin_t
- struct unpack_uim_VerifyPin_t
- struct pack_uim_UnblockPin_t
- struct unpack_uim_UnblockPin_t
- struct pack_uim_SetPinProtection_t
- struct unpack_uim_SetPinProtection_t
- struct pack_uim_ChangePin_t
- struct unpack_uim_ChangePin_t
- struct pack_uim_ReadTransparent_t
- struct unpack_uim_ReadTransparent_t

- struct pack_uim_SLQSUIMEventRegister_t
- struct unpack_uim_SLQSUIMEventRegister_t
- struct appStats
- struct slotInf
- struct unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t
- struct slot_t
- struct slots_t
- struct unpack_uim_SLQSUIMGetSlotsStatus_t
- struct pack_uim_SLQSUIMSwitchSlot_t
- struct unpack_uim_SetUimSlotStatusChangeCallback_ind_t
- struct pack_uim_SLQSUIMPowerUp_t
- struct pack_uim_SLQSUIMPowerDown_t
- struct pack_uim_SLQSUIMRefreshOK_t
- struct uim_registerRefresh
- struct pack_uim_SLQSUIMRefreshRegister_t
- struct pack_uim_SLQSUIMRefreshComplete_t
- struct uim_refreshevent
- struct pack_uim_SLQSUIMRefreshGetLastEvent_t
- struct unpack_uim_SLQSUIMRefreshGetLastEvent_t
- struct pack_uim_SLQSUIMGetFileAttributes_t
- struct uim_fileAttributes
- struct unpack_uim_SLQSUIMGetFileAttributes_t
- struct uim_depersonalizationInformation
- struct pack_uim_SLQSUIMDepersonalization_t
- struct unpack_uim_SLQSUIMDepersonalization_t
- struct uim_authenticationData
- struct pack_uim_SLQSUIMAuthenticate_t
- struct uim_authenticateResult
- struct unpack_uim_SLQSUIMAuthenticate_t
- struct uim_personalizationStatus
- struct pack_uim_SLQSUIMGetConfiguration_t
- struct unpack_uim_SLQSUIMGetConfiguration_t
- struct unpack_uim_SLQSUIMRefreshCallback_Ind_t

Macros

- #define UIM_UINT8_MAX_STRING_SZ 255
- #define UIM_MAX_DESCRIPTION_LENGTH 255
- #define UIM_MAX_NO_OF_SLOTS 5
- #define UIM_MAX_NO_OF_APPLICATIONS 10
- #define MAX_NO_OF_SLOTS 5
- #define MAX_NO_OF_APPLICATIONS 10
- #define MAX_DESCRIPTION_LENGTH 255
- #define MAX_SLOTS_STATUS 255
- #define MAX_ICCID_LENGTH 255
- #define UIM_MAX_CONTENT_LENGTH 1024
- #define UIM_MAX_ACTIVE_PERS_FEATURES 12

Typedefs

- typedef unpack_result_t unpack_uim_SLQSUIMSwitchSlot_t
- typedef unpack_result_t unpack_uim_SLQSUIMPowerUp_t
- typedef unpack_result_t unpack_uim_SLQSUIMPowerDown_t
- typedef unpack_result_t unpack_uim_SLQSUIMReset_t
- typedef unpack_result_t unpack_uim_SLQSUIMRefreshOK_t
- typedef unpack_result_t unpack_uim_SLQSUIMRefreshRegister_t
- typedef unpack_result_t unpack_uim_SLQSUIMRefreshComplete_t

Functions

- int pack_uim_GetCardStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, void *reqArg)
- int unpack_uim_GetCardStatus (uint8_t *pResp, uint16_t respLen, unpack_uim_GetCardStatus_t *pOutput)
- int pack_uim_VerifyPin (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_VerifyPin_t *reqArg)
- int unpack_uim_VerifyPin (uint8_t *pResp, uint16_t respLen, unpack_uim_VerifyPin_t *pOutput)
- int pack_uim_UnblockPin (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_UnblockPin_t *reqArg)
- int unpack_uim_UnblockPin (uint8_t *pResp, uint16_t respLen, unpack_uim_UnblockPin_t *pOutput)
- int pack_uim_SetPinProtection (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SetPinProtection_t *reqArg)
- int unpack_uim_SetPinProtection (uint8_t *pResp, uint16_t respLen, unpack_uim_SetPinProtection_t *pOutput)
- int pack_uim_ChangePin (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_ChangePin_t *reqArg)
- int unpack_uim_ChangePin (uint8_t *pResp, uint16_t respLen, unpack_uim_ChangePin_t *pOutput)
- int pack_uim_ReadTransparent (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_ReadTransparent_t *reqArg)
- int unpack_uim_ReadTransparent (uint8_t *pResp, uint16_t respLen, unpack_uim_ReadTransparent_t *pOutput)
- int pack_uim_SLQSUIMEventRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMEventRegister_t *reqArg)
- int unpack_uim_SLQSUIMEventRegister (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMEventRegister_t *pOutput)
- int unpack_uim_SLQSUIMSetStatusChangeCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t *pOutput)
- int pack_uim_SLQSUIMGetSlotsStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_uim_SLQSUIMGetSlotsStatus (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMGetSlotsStatus_t *pOutput)
- int pack_uim_SLQSUIMSwitchSlot (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMSwitchSlot_t *reqArg)
- int unpack_uim_SLQSUIMSwitchSlot (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMSwitchSlot_t *pOutput)
- int unpack_uim_SetUimSlotStatusChangeCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_uim_SetUimSlotStatusChangeCallback_ind_t *pOutput)
- int pack_uim_SLQSUIMPowerUp (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMPowerUp_t *reqArg)
- int unpack_uim_SLQSUIMPowerUp (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMPowerUp_t *pOutput)
- int pack_uim_SLQSUIMPowerDown (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMPowerDown_t *reqArg)
- int unpack_uim_SLQSUIMPowerDown (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMPowerDown_t *pOutput)
- int pack_uim_SLQSUIMReset (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_uim_SLQSUIMReset (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMReset_t *pOutput)
- int pack_uim_SLQSUIMRefreshOK (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMRefreshOK_t *reqArg)
- int unpack_uim_SLQSUIMRefreshOK (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMRefreshOK_t *pOutput)
- int pack_uim_SLQSUIMRefreshRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMRefreshRegister_t *reqArg)
- int unpack_uim_SLQSUIMRefreshRegister (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMRefreshRegister_t *pOutput)
- int pack_uim_SLQSUIMRefreshComplete (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMRefreshComplete_t *reqArg)

- int unpack_uim_SLQSUIMRefreshComplete (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMRefreshComplete_t *pOutput)
- int pack_uim_SLQSUIMRefreshGetLastEvent (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMRefreshGetLastEvent_t *reqArg)
- int unpack_uim_SLQSUIMRefreshGetLastEvent (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMRefreshGetLastEvent_t *pOutput)
- int pack_uim_SLQSUIMGetFileAttributes (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMGetFileAttributes_t *reqArg)
- int unpack_uim_SLQSUIMGetFileAttributes (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMGetFileAttributes_t *pOutput)
- int pack_uim_SLQSUIMDepersonalization (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMDepersonalization_t *reqArg)
- int unpack_uim_SLQSUIMDepersonalization (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMDepersonalization_t *pOutput)
- int pack_uim_SLQSUIMAuthenticate (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMAuthenticate_t *reqArg)
- int unpack_uim_SLQSUIMAuthenticate (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMAuthenticate_t *pOutput)
- int pack_uim_SLQSUIMGetConfiguration (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_uim_SLQSUIMGetConfiguration_t *reqArg)
- int unpack_uim_SLQSUIMGetConfiguration (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMGetConfiguration_t *pOutput)
- int unpack_uim_SLQSUIMRefreshCallback_Ind (uint8_t *pResp, uint16_t respLen, unpack_uim_SLQSUIMRefreshCallback_Ind_t *pOutput)

9.43.1 Macro Definition Documentation

9.43.1.1 #define MAX_DESCRIPTION_LENGTH 255

9.43.1.2 #define MAX_ICCID_LENGTH 255

9.43.1.3 #define MAX_NO_OF_APPLICATIONS 10

9.43.1.4 #define MAX_NO_OF_SLOTS 5

9.43.1.5 #define MAX_SLOTS_STATUS 255

9.43.1.6 #define UIM_MAX_ACTIVE_PERS_FEATURES 12

9.43.1.7 #define UIM_MAX_CONTENT_LENGTH 1024

9.43.1.8 #define UIM_MAX_DESCRIPTION_LENGTH 255

9.43.1.9 #define UIM_MAX_NO_OF_APPLICATIONS 10

9.43.1.10 #define UIM_MAX_NO_OF_SLOTS 5

9.43.1.11 #define UIM_UINT8_MAX_STRING_SZ 255

9.43.2 Typedef Documentation

9.43.2.1 typedef unpack_result_t unpack_uim_SLQSUIMPowerDown_t

9.43.2.2 typedef unpack_result_t unpack_uim_SLQSUIMPowerUp_t

9.43.2.3 typedef unpack_result_t unpack_uim_SLQSUIMRefreshComplete_t

9.43.2.4 typedef unpack_result_t unpack_uim_SLQSUIMRefreshOK_t

9.43.2.5 typedef unpack_result_t unpack_uim_SLQSUIMRefreshRegister_t

9.43.2.6 typedef unpack_result_t unpack_uim_SLQSUIMReset_t

9.43.2.7 typedef unpack_result_t unpack_uim_SLQSUIMSwitchSlot_t

9.43.3 Function Documentation

9.43.3.1 int pack_uim_ChangePin (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_ChangePin_t * *reqArg*)

Change Pin pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.2 int pack_uim_GetCardStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, void * *reqArg*)

Get Card Status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.3 int pack_uim_ReadTransparent (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_ReadTransparent_t * *reqArg*)

SLQS ReadTransparent pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.4 int pack_uim_SetPinProtection (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SetPinProtection_t * *reqArg*)

Set Pin Protection pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.5 int pack_uim_SLQSUIMAuthenticate (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMAuthenticate_t * *reqArg*)

Send a security command to the card pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.6 int pack_uim_SLQSUIMDepersonalization (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMDepersonalization_t * *reqArg*)

De-activates or unblocks the personalization on the phone pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.7 int pack_uim_SLQSUIMEventRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMEventRegister_t * *reqArg*)

UIM Status Change callback enable pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.8 int pack_uim_SLQSUIMGetConfiguration (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMGetConfiguration_t * *reqArg*)

Gets the modem configuration for the UIM module pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.9 int pack_uim_SLQSUIMGetFileAttributes (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMGetFileAttributes_t * *reqArg*)

Retrieves the file attributes for any EF(Elementary File) or DF(Dedicated File) in the card and provides access by the path pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.10 int pack_uim_SLQSUIMGetSlotsStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Pack get slots status.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.11 int pack_uim_SLQSUIMPowerDown (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMPowerDown_t * *reqArg*)

Powers down the card pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.12 int pack_uim_SLQSUIMPowerUp (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMPowerUp_t * *reqArg*)

Powers up the card pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.13 int pack_uim_SLQSUIMRefreshComplete (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMRefreshComplete_t * *reqArg*)

Enables the terminal response to be sent to the card When the client finished Refresh procedure pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.14 int pack_uim_SLQSUIMRefreshGetLastEvent (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMRefreshGetLastEvent_t * *reqArg*)

Retrieve the last refresh event pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.15 int pack_uim_SLQSUIMRefreshOK (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMRefreshOK_t * *reqArg*)

Enables the client to indicate whether it is OK to start the Refresh procedure pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.16 int pack_uim_SLQSUIMRefreshRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMRefreshRegister_t * *reqArg*)

Registers for file change notifications triggered by the card pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.17 int pack_uim_SLQSUIMReset (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Resets the issuing control points state kept by the service pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.18 int pack_uim_SLQSUIMSwitchSlot (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_SLQSUIMSwitchSlot_t * *reqArg*)

switch slot pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.19 int pack_uim_UnblockPin (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_UnblockPin_t * *reqArg*)

Unblock Pin pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.20 int pack_uim_VerifyPin (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_uim_VerifyPin_t * *reqArg*)

Verify Pin Status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.21 int unpack_uim_ChangePin (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_ChangePin_t * *pOutput*)

Change Pin unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.22 int unpack_uim_GetCardStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_GetCardStatus_t * *pOutput*)

Get Card Status unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.23 int unpack_uim_ReadTransparent (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_ReadTransparent_t * *pOutput*)

SLQS ReadTransparent unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.24 int unpack_uim_SetPinProtection (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SetPinProtection_t * *pOutput*)

Set Pin Protection unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.25 int unpack_uim_SetUimSlotStatusChangeCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SetUimSlotStatusChangeCallback_ind_t * *pOutput*)

UIM Slot Status Change indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

use pack_uim_SLQSUIMEventRegister to subscribe

9.43.3.26 int unpack_uim_SLQSUIMAuthenticate (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMAuthenticate_t * *pOutput*)

Unpack the status code received from the card when card responded to the read request

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.27 int unpack_uim_SLQSUIMDepersonalization (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMDepersonalization_t * *pOutput*)

De-activates or unblocks the personalization on the phone unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.28 int unpack_uim_SLQSUIMEventRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMEvent-Register_t * *pOutput*)

UIM Status Change callback enable unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.29 int unpack_uim_SLQSUIMGetConfiguration (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMGetConfiguration_t * *pOutput*)

Gets the modem configuration for the UIM module unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.30 int unpack_uim_SLQSUIMGetFileAttributes (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMGetFileAttributes_t * *pOutput*)

Retrieves the file attributes for any EF(Elementary File) or DF(Dedicated File) in the card and provides access by the path unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.31 int unpack_uim_SLQSUIMGetSlotsStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMGetSlotsStatus_t * *pOutput*)

get slot status unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.32 int unpack_uim_SLQSUIMPowerDown (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMPowerDown_t * *pOutput*)

Powers down the card unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.33 int unpack_uim_SLQSUIMPowerUp (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMPowerUp_t * *pOutput*)

Powers up the card unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.34 int unpack_uim_SLQSUIMRefreshCallback_Ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMRefreshCallback_Ind_t * *pOutput*)

Unpack UIM refresh event indication.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.35 int unpack_uim_SLQSUIMRefreshComplete (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMRefreshComplete_t * *pOutput*)

Enables the terminal response to be sent to the card When the client finished Refresh procedure unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.36 int unpack_uim_SLQSUIMRefreshGetLastEvent (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMRefreshGetLastEvent_t * *pOutput*)

Retrieve the last refresh event unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.37 int unpack_uim_SLQSUIMRefreshOK (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMRefreshOK_t * *pOutput*)

Enables the client to indicate whether it is OK to start the Refresh procedure unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.38 int unpack_uim_SLQSUIMRefreshRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMRefreshRegister_t * *pOutput*)

Registers for file change notifications triggered by the card unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.39 int unpack_uim_SLQSUIMReset (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMReset_t * *pOutput*)

Resets the issuing control points state kept by the service unpack.

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.40 int unpack_uim_SLQSUIMSetStatusChangeCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t * *pOutput*)

UIM Status Change indication unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

use pack_uim_SLQSUIMEventRegister to subscribe

9.43.3.41 int unpack_uim_SLQSUIMSwitchSlot (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_SLQSUIMSwitchSlot_t * *pOutput*)

switch slot unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.42 int unpack_uim_UnblockPin (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_UnblockPin_t * *pOutput*)

Unblock Pin unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.43.3.43 int unpack_uim_VerifyPin (uint8_t * *pResp*, uint16_t *respLen*, unpack_uim_VerifyPin_t * *pOutput*)

Verify Pin unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44 voice.h File Reference

Data Structures

- struct voice_USSInfo
- struct pack_voice_OriginateUSSD_t
- struct pack_voice_AnswerUSSD_t
- struct voice_UUSInfo
- struct voice_CUGInfo
- struct voice_calledPartySubAdd
- struct pack_voice_SLQSVoiceDialCall_t
- struct voice_alphaIDInfo
- struct voice_ccSUPSType
- struct unpack_voice_SLQSVoiceDialCall_t
- struct pack_voice_SLQSVoiceEndCall_t
- struct unpack_voice_SLQSVoiceEndCall_t
- struct voice_callFwdTypeAndPlan
- struct pack_voice_SLQSVoiceSetSUPSService_t
- struct unpack_voice_SLQSVoiceSetSUPSService_t
- struct voice_airTimer
- struct voice_roamTimer
- struct voice_prefVoiceSO
- struct pack_voice_SLQSVoiceSetConfig_t
- struct unpack_voice_SLQSVoiceSetConfig_t
- struct pack_voice_SLQSVoiceAnswerCall_t
- struct unpack_voice_SLQSVoiceAnswerCall_t
- struct voice_CLIRResp
- struct unpack_voice_SLQSVoiceGetCLIR_t
- struct voice_CLIPResp
- struct unpack_voice_SLQSVoiceGetCLIP_t
- struct pack_voice_SLQSVoiceGetCallWaiting_t
- struct unpack_voice_SLQSVoiceGetCallWaiting_t
- struct pack_voice_SLQSVoiceGetCallBarring_t
- struct unpack_voice_SLQSVoiceGetCallBarring_t
- struct pack_voice_SLQSVoiceGetCallForwardingStatus_t
- struct voice_callFWInfo
- struct voice_callFWExtInfo
- struct voice_getCallFWInfo
- struct voice_getCallFWExtInfo
- struct unpack_voice_SLQSVoiceGetCallForwardingStatus_t
- struct pack_voice_SLQSVoiceSetCallBarringPassword_t
- struct unpack_voice_SLQSVoiceSetCallBarringPassword_t
- struct pack_voice_SLQSVoiceGetCallInfo_t
- struct voice_callInfo
- struct voice_remotePartyNum
- struct voice_remotePartyName
- struct voice_connectNumInfo
- struct voice_diagInfo
- struct unpack_voice_SLQSVoiceGetCallInfo_t
- struct voice_getAllCallInformation
- struct voice_getAllCallRmtPtyNum
- struct voice_getAllCallRmtPtyName
- struct voice_allCallsUUSInfo
- struct voice_allCallsAlphaIDInfo
- struct voice_allCallsDiagInfo
- struct voice_peerNumberInfo
- struct voice_arrCallInfo

- struct voice_arrRemotePartyNum
- struct voice_arrRemotePartyName
- struct voice_arrAlertingType
- struct voice_arrUUSInfo
- struct voice_arrSvcOption
- struct voice_arrCallEndReason
- struct voice_arrAlphaID
- struct voice_arrConnectPartyNum
- struct voice_arrDiagInfo
- struct voice_arrCalledPartyNum
- struct voice_arrRedirPartyNum
- struct voice_arrAlertingPattern
- struct unpack_voice_SLQSVoiceGetAllCallInfo_t
- struct pack_voice_SLQSVoiceManageCalls_t
- struct unpack_voice_SLQSVoiceManageCalls_t
- struct voice_burstDTMFInfo
- struct voice_DTMFLengths
- struct pack_voice_SLQSVoiceBurstDTMF_t
- struct unpack_voice_SLQSVoiceBurstDTMF_t
- struct pack_voice_SLQSVoiceStartContDTMF_t
- struct unpack_voice_SLQSVoiceStartContDTMF_t
- struct pack_voice_SLQSVoiceStopContDTMF_t
- struct unpack_voice_SLQSVoiceStopContDTMF_t
- struct pack_voice_SLQSVoiceSendFlash_t
- struct unpack_voice_SLQSVoiceSendFlash_t
- struct pack_voice_SLQSVoiceSetPreferredPrivacy_t
- struct pack_voice_SLQSVoiceIndicationRegister_t
- struct pack_voice_SLQSVoiceGetConfig_t
- struct voice_curAMRConfig
- struct unpack_voice_SLQSVoiceGetConfig_t
- struct pack_voice_SLQSVoiceOrigUSSDNoWait_t
- struct pack_voice_SLQSVoiceBindSubscription_t
- struct pack_voice_SLQSVoiceALSSetLineSwitching_t
- struct pack_voice_SLQSVoiceALSSelectLine_t
- struct voice_COLPResp
- struct unpack_voice_SLQSVoiceGetCOLP_t
- struct voice_COLRResp
- struct unpack_voice_SLQSVoiceGetCOLR_t
- struct voice_CNAPResp
- struct unpack_voice_SLQSVoiceGetCNAP_t
- struct pack_voice_SLQSOriginateUSSD_t
- struct unpack_voice_SLQSOriginateUSSD_t
- struct voice_USSDNotificationNetworkInfo
- struct unpack_voice_USSDNotificationCallback_ind_t
- struct voice_SUPSInfo
- struct voice_newPwdData
- struct unpack_voice_SLQSVoiceSUPSCallback_ind_t
- struct unpack_voice_allCallStatusCallback_ind_t
- struct unpack_voice_voicePrivacyChangeCallback_ind_t
- struct voice_DTMFInfo
- struct unpack_voice_DTMFEventCallback_ind_t
- struct voice_ECTNum
- struct unpack_voice_SUPSNotificationCallback_ind_t
- struct unpack_voice_OTASPStatusCallback_ind_t
- struct voice_signalInfo

- struct voice_callerIDInfo
- struct voice_callingPartyInfo
- struct voice_calledPartyInfo
- struct voice_redirNumInfo
- struct voice_NSSAudioCtrl
- struct voice_lineCtrlInfo
- struct voice_extDispRecInfo
- struct unpack_voice_VoiceInfoRecCallback_ind_t

Macros

- #define MAXVOICEUSSDLENGTH 182
- #define MAX_VOICE_CALL_NO_LEN 81
- #define MAX_VOICE_DESCRIPTION_LENGTH 255
- #define VOICE_MAX_NO_OF_CALLS 20
- #define BARRING_PASSWORD_LENGTH 4

Typedefs

- typedef unpack_result_t unpack_voice_OriginateUSSD_t
- typedef unpack_result_t unpack_voice_AnswerUSSD_t
- typedef unpack_result_t unpack_voice_CancelUSSD_t
- typedef unpack_result_t unpack_voice_SLQSVoiceSetPreferredPrivacy_t
- typedef unpack_result_t unpack_voice_SLQSVoiceIndicationRegister_t
- typedef unpack_result_t unpack_voice_SLQSVoiceOrigUSSDNoWait_t
- typedef unpack_result_t unpack_voice_SLQSVoiceBindSubscription_t
- typedef unpack_result_t unpack_voice_SLQSVoiceALSSetLineSwitching_t
- typedef unpack_result_t unpack_voice_SLQSVoiceALSSelectLine_t

Enumerations

- enum liteServiceClassInformation {
  LITE_VOICE_SUPS_SRV_CLASS_NONE = 0x00,
  LITE_VOICE_SUPS_SRV_CLASS_VOICE = 0x01,
  LITE_VOICE_SUPS_SRV_CLASS_DATA = 0x02,
  LITE_VOICE_SUPS_SRV_CLASS_FAX = 0x04,
  LITE_VOICE_SUPS_SRV_CLASS_SMS = 0x08,
  LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITSYNC = 0x10,
  LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITASYNC = 0x20,
  LITE_VOICE_SUPS_SRV_CLASS_PACKETACCESS = 0x40,
  LITE_VOICE_SUPS_SRV_CLASS_PADACCESS = 0x80 }

Functions

- int pack_voice_OriginateUSSD (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_OriginateUSSD_t *reqArg)
- int unpack_voice_OriginateUSSD (uint8_t *pResp, uint16_t respLen, unpack_voice_OriginateUSSD_t *pOutput)
- int pack_voice_AnswerUSSD (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_AnswerUSSD_t *reqArg)
- int unpack_voice_AnswerUSSD (uint8_t *pResp, uint16_t respLen, unpack_voice_AnswerUSSD_t *pOutput)
- int pack_voice_CancelUSSD (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_CancelUSSD (uint8_t *pResp, uint16_t respLen, unpack_voice_CancelUSSD_t *pOutput)

- int pack_voice_SLQSVoiceDialCall (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceDialCall_t *pReq)
- int unpack_voice_SLQSVoiceDialCall (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceDialCall_t *pOutput)
- int pack_voice_SLQSVoiceEndCall (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceEndCall_t *pReq)
- int unpack_voice_SLQSVoiceEndCall (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceEndCall_t *pOutput)
- int pack_voice_SLQSVoiceSetSUPSService (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceSetSUPSService_t *pReq)
- int unpack_voice_SLQSVoiceSetSUPSService (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceSetSUPSService_t *pOutput)
- int pack_voice_SLQSVoiceSetConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceSetConfig_t *pReq)
- int unpack_voice_SLQSVoiceSetConfig (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceSetConfig_t *pOutput)
- int pack_voice_SLQSVoiceAnswerCall (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceAnswerCall_t *pReq)
- int unpack_voice_SLQSVoiceAnswerCall (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceAnswerCall_t *pOutput)
- int pack_voice_SLQSVoiceGetCLIR (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetCLIR (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCLIR_t *pOutput)
- int pack_voice_SLQSVoiceGetCLIP (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetCLIP (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCLIP_t *pOutput)
- int pack_voice_SLQSVoiceGetCallWaiting (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceGetCallWaiting_t *pReq)
- int unpack_voice_SLQSVoiceGetCallWaiting (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCallWaiting_t *pOutput)
- int pack_voice_SLQSVoiceGetCallBarring (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceGetCallBarring_t *pReq)
- int unpack_voice_SLQSVoiceGetCallBarring (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCallBarring_t *pOutput)
- int pack_voice_SLQSVoiceGetCallForwardingStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceGetCallForwardingStatus_t *pReq)
- int unpack_voice_SLQSVoiceGetCallForwardingStatus (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCallForwardingStatus_t *pOutput)
- int pack_voice_SLQSVoiceSetCallBarringPassword (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceSetCallBarringPassword_t *pReq)
- int unpack_voice_SLQSVoiceSetCallBarringPassword (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceSetCallBarringPassword_t *pOutput)
- int pack_voice_SLQSVoiceGetCallInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceGetCallInfo_t *pReq)
- int unpack_voice_SLQSVoiceGetCallInfo (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCallInfo_t *pOutput)
- int pack_voice_SLQSVoiceGetAllCallInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetAllCallInfo (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetAllCallInfo_t *pOutput)
- int pack_voice_SLQSVoiceManageCalls (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceManageCalls_t *pReq)
- int unpack_voice_SLQSVoiceManageCalls (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceManageCalls_t *pOutput)
- int pack_voice_SLQSVoiceBurstDTMF (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceBurstDTMF_t *pReq)
- int unpack_voice_SLQSVoiceBurstDTMF (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceBurstDTMF_t *pOutput)

- int pack_voice_SLQSVoiceStartContDTMF (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceStartContDTMF_t *pReq)
- int unpack_voice_SLQSVoiceStartContDTMF (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceStartContDTMF_t *pOutput)
- int pack_voice_SLQSVoiceStopContDTMF (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceStopContDTMF_t *pReq)
- int unpack_voice_SLQSVoiceStopContDTMF (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceStopContDTMF_t *pOutput)
- int pack_voice_SLQSVoiceSendFlash (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceSendFlash_t *pReq)
- int unpack_voice_SLQSVoiceSendFlash (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceSendFlash_t *pOutput)
- int pack_voice_SLQSVoiceSetPreferredPrivacy (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceSetPreferredPrivacy_t *reqArg)
- int unpack_voice_SLQSVoiceSetPreferredPrivacy (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceSetPreferredPrivacy_t *pOutput)
- int pack_voice_SLQSVoiceIndicationRegister (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceIndicationRegister_t *reqArg)
- int unpack_voice_SLQSVoiceIndicationRegister (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceIndicationRegister_t *pOutput)
- int pack_voice_SLQSVoiceGetConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceGetConfig_t *reqArg)
- int unpack_voice_SLQSVoiceGetConfig (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetConfig_t *pOutput)
- int pack_voice_SLQSVoiceOrigUSSDNoWait (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceOrigUSSDNoWait_t *reqArg)
- int unpack_voice_SLQSVoiceOrigUSSDNoWait (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceOrigUSSDNoWait_t *pOutput)
- int pack_voice_SLQSVoiceBindSubscription (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceBindSubscription_t *reqArg)
- int unpack_voice_SLQSVoiceBindSubscription (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceBindSubscription_t *pOutput)
- int pack_voice_SLQSVoiceALSSetLineSwitching (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceALSSetLineSwitching_t *reqArg)
- int unpack_voice_SLQSVoiceALSSetLineSwitching (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceALSSetLineSwitching_t *pOutput)
- int pack_voice_SLQSVoiceALSSelectLine (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSVoiceALSSelectLine_t *reqArg)
- int unpack_voice_SLQSVoiceALSSelectLine (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceALSSelectLine_t *pOutput)
- int pack_voice_SLQSVoiceGetCOLP (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetCOLP (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCOLP_t *pOutput)
- int pack_voice_SLQSVoiceGetCOLR (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetCOLR (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCOLR_t *pOutput)
- int pack_voice_SLQSVoiceGetCNAP (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_voice_SLQSVoiceGetCNAP (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceGetCNAP_t *pOutput)
- int pack_voice_SLQSOriginateUSSD (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_voice_SLQSOriginateUSSD_t *reqArg)
- int unpack_voice_SLQSOriginateUSSD (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSOriginateUSSD_t *pOutput)
- int unpack_voice_USSDNotificationCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_voice_USSDNotificationCallback_ind_t *pOutput)
- int unpack_voice_SLQSVoiceSUPSCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_voice_SLQSVoiceSUPSCallback_ind_t *pOutput)

- int unpack_voice_allCallStatusCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_voice_allCallStatusCallback_ind_t *pOutput)
- int unpack_voice_voicePrivacyChangeCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_voice_voicePrivacyChangeCallback_ind_t *pOutput)
- int unpack_voice_DTMFEventCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_voice_DTMFEventCallback_ind_t *pOutput)
- int unpack_voice_SUPSNotificationCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_voice_SUPSNotificationCallback_ind_t *pOutput)
- int unpack_voice_OTASPStatusCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_voice_OTASPStatusCallback_ind_t *pOutput)
- int unpack_voice_VoiceInfoRecCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_voice_VoiceInfoRecCallback_ind_t *pOutput)

9.44.1 Detailed Description

9.44.2 S1

- 3GPP Mobile Radio Interface Layer 3 Specification : Core Network Protocols; Stage 3 (Release 7)
- 3GPP TS 24.008 V7.0.0 (2005-06)

9.44.3 Macro Definition Documentation

9.44.3.1 #define BARRING_PASSWORD_LENGTH 4

9.44.3.2 #define MAX_VOICE_CALL_NO_LEN 81

9.44.3.3 #define MAX_VOICE_DESCRIPTION_LENGTH 255

9.44.3.4 #define MAXVOICEUSSDLENGTH 182

9.44.3.5 #define VOICE_MAX_NO_OF_CALLS 20

9.44.4 Typedef Documentation

9.44.4.1 typedef unpack_result_t unpack_voice_AnswerUSSD_t

9.44.4.2 typedef unpack_result_t unpack_voice_CancelUSSD_t

9.44.4.3 typedef unpack_result_t unpack_voice_OriginateUSSD_t

9.44.4.4 typedef unpack_result_t unpack_voice_SLQSVoiceALSSelectLine_t

9.44.4.5 typedef unpack_result_t unpack_voice_SLQSVoiceALSSetLineSwitching_t

9.44.4.6 typedef unpack_result_t unpack_voice_SLQSVoiceBindSubscription_t

9.44.4.7 typedef unpack_result_t unpack_voice_SLQSVoiceIndicationRegister_t

9.44.4.8 typedef unpack_result_t unpack_voice_SLQSVoiceOrigUSSDNoWait_t

9.44.4.9 typedef unpack_result_t unpack_voice_SLQSVoiceSetPreferredPrivacy_t

9.44.5 Enumeration Type Documentation

9.44.5.1 enum liteServiceClassInformation

Service Class information

Enumerator

LITE_VOICE_SUPS_SRV_CLASS_NONE

LITE_VOICE_SUPS_SRV_CLASS_VOICE

LITE_VOICE_SUPS_SRV_CLASS_DATA

LITE_VOICE_SUPS_SRV_CLASS_FAX

LITE_VOICE_SUPS_SRV_CLASS_SMS

LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITSYNC

LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITASYNC

LITE_VOICE_SUPS_SRV_CLASS_PACKETACCESS

LITE_VOICE_SUPS_SRV_CLASS_PADACCESS

9.44.6 Function Documentation

9.44.6.1 int pack_voice_AnswerUSSD (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_AnswerUSSD_t * *reqArg*)

Responds to a USSD request from the network pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.2 int pack_voice_CancelUSSD (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Cancels an in-progress USSD operation pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.3 int pack_voice_OriginateUSSD (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_OriginateUSSD_t * *reqArg*)

Initiates a USSD operation pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.4 int pack_voice_SLQSOriginateUSSD (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSOriginateUSSD_t * *reqArg*)

Initiates a USSD session pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.5 int pack_voice_SLQSVoiceALSSelectLine (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceALSSelectLine_t * *reqArg*)

allows the user to select the preferred line pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.6 int pack_voice_SLQSVoiceALSSetLineSwitching (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceALSSetLineSwitching_t * *reqArg*)

sets the line switch setting on the card pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.7 int pack_voice_SLQSVoiceAnswerCall (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceAnswerCall_t * *pReq*)

Answers an incoming voice call pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.8 int pack_voice_SLQSVoiceBindSubscription (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceBindSubscription_t * *reqArg*)

binds a subscription type to a specific voice client ID pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.9 int pack_voice_SLQSVoiceBurstDTMF (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceBurstDTMF_t * *pReq*)

Sends a burst Dual-Tone Multi frequency (DTMF) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.10 int pack_voice_SLQSVoiceDialCall (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceDialCall_t * *pReq*)

Originates a voice call (MO call) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.11 int pack_voice_SLQSVoiceEndCall (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_voice_SLQSVoiceEndCall_t * pReq)

Ends a voice call pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.12 int pack_voice_SLQSVoiceGetAllCallInfo (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

information associated with all the calls originating or terminating pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.13 int pack_voice_SLQSVoiceGetCallBarring (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_voice_SLQSVoiceGetCallBarring_t * pReq)

Status of Call Barring Supplementary Service pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.14 int pack_voice_SLQSVoiceGetCallForwardingStatus (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceGetCallForwardingStatus_t * *pReq*)

Status of Call Forwarding Supplementary Service pack

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.15 int pack_voice_SLQSVoiceGetCallInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceGetCallInfo_t * *pReq*)

information associated with a call pack

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.16 int pack_voice_SLQSVoiceGetCallWaiting (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceGetCallWaiting_t * *pReq*)

Status of Call Waiting Supplementary Service pack

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.17 int pack_voice_SLQSVoiceGetCLIP (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

status of the Calling Line Identification Presentation (CLIP) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.18 int pack_voice_SLQSVoiceGetCLIR (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

status of the Calling Line Identification Restriction (CLIR) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.19 int pack_voice_SLQSVoiceGetCNAP (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

status of the Calling Name Presentation(CNAP) pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.20 int pack_voice_SLQSVoiceGetCOLP (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

status of the Connected Line Identification Presentation pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.21 int pack_voice_SLQSVoiceGetCOLR (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

status of the Connected Line Identification Restriction pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.22 int pack_voice_SLQSVoiceGetConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceGetConfig_t * *reqArg*)

retrieves various configuration parameters that control the modem behavior pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.23 int pack_voice_SLQSVoiceIndicationRegister (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceIndicationRegister_t * *reqArg*)

Sets the registration state for different QMI_VOICE indications pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.24 int pack_voice_SLQSVoiceManageCalls (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceManageCalls_t * *pReq*)

Manages the calls by using the supplementary service pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.25 int pack_voice_SLQSVoiceOrigUSSDNoWait (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceOrigUSSDNoWait_t * *reqArg*)

initiates a USSD operation No Wait pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.26 int pack_voice_SLQSVoiceSendFlash (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceSendFlash_t * *pReq*)

sends a simple flash message pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.27 int pack_voice_SLQSVoiceSetCallBarringPassword (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceSetCallBarringPassword_t * *pReq*)

Sets a Call Barring Password pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.28 int pack_voice_SLQSVoiceSetConfig (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_voice_SLQSVoiceSetConfig_t * pReq)

configuration parameters that control the modem behavior pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.29 int pack_voice_SLQSVoiceSetPreferredPrivacy (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_voice_SLQSVoiceSetPreferredPrivacy_t * reqArg)

sets the voice privacy preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.30 int pack_voice_SLQSVoiceSetSUPSService (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_voice_SLQSVoiceSetSUPSService_t * pReq)

call-independent supplementary services pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.31 int pack_voice_SLQSVoiceStartContDTMF (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceStartContDTMF_t * *pReq*)

Starts a continuous DTMF pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.32 int pack_voice_SLQSVoiceStopContDTMF (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_voice_SLQSVoiceStopContDTMF_t * *pReq*)

Stops a continuous DTMF pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.33 int unpack_voice_allCallStatusCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_allCallStatusCallback_ind_t * *pOutput*)

Unpack all call status callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	all call status callback unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.34 int unpack_voice_AnswerUSSD (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_AnswerUSSD_t * *pOutput*)

Responds to a USSD request from the network unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.35 int unpack_voice_CancelUSSD (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_CancelUSSD_t * *pOutput*)

Cancels an in-progress USSD operation unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.36 int unpack_voice_DTMFEventCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_DTMFEventCallback_ind_t * *pOutput*)

Unpack DTMF event callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	DTMF event callback unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.37 int unpack_voice_OriginateUSSD (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_OriginateUSSD_t * *pOutput*)

Initiates a USSD operation unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.38 int unpack_voice_OTASPStatusCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_OTASPStatusCallback_ind_t * *pOutput*)

Unpack voice OTASP status callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	voice OTASP status callback unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.39 int unpack_voice_SLQSOriginateUSSD (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSOriginateUSSD_t * *pOutput*)

Initiates a USSD session unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.40 int unpack_voice_SLQSVoiceALSSelectLine (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceALSSelectLine_t * *pOutput*)

allows the user to select the preferred line unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.41 int unpack_voice_SLQSVoiceALSSetLineSwitching (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceALSSetLineSwitching_t * *pOutput*)

sets the line switch setting on the card unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.42 int unpack_voice_SLQSVoiceAnswerCall (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceAnswerCall_t * *pOutput*)

Answers an incoming voice call unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.43 int unpack_voice_SLQSVoiceBindSubscription (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceBindSubscription_t * *pOutput*)

binds a subscription type to a specific voice client ID unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.44 int unpack_voice_SLQSVoiceBurstDTMF (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceBurstDTMF_t * *pOutput*)

Sends a burst Dual-Tone Multi frequency (DTMF) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.45 int unpack_voice_SLQSVoiceDialCall (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceDialCall_t * *pOutput*)

Originates a voice call (MO call) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.46 int unpack_voice_SLQSVoiceEndCall (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceEndCall_t * *pOutput*)

Ends a voice call unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.47 int unpack_voice_SLQSVoiceGetAllCallInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetAllCallInfo_t * *pOutput*)

information associated with all the calls originating or terminating unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.48 int unpack_voice_SLQSVoiceGetCallBarring (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCallBarring_t * *pOutput*)

Status of Call Barring Supplementary Service unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.49 int unpack_voice_SLQSVoiceGetCallForwardingStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCallForwardingStatus_t * *pOutput*)

Status of Call Forwarding Supplementary Service unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.50 int unpack_voice_SLQSVoiceGetCallInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCallInfo_t * *pOutput*)

information associated with a call unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.51 int unpack_voice_SLQSVoiceGetCallWaiting (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCallWaiting_t * *pOutput*)

Status of Call Waiting Supplementary Service unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.52 int unpack_voice_SLQSVoiceGetCLIP (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCLIP_t * *pOutput*)

status of the Calling Line Identification Presentation (CLIP) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.53 int unpack_voice_SLQSVoiceGetCLIR (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCLIR_t * *pOutput*)

status of the Calling Line Identification Restriction (CLIR) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.54 int unpack_voice_SLQSVoiceGetCNAP (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCNAP_t * *pOutput*)

status of the Calling Name Presentation(CNAP) unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.55 int unpack_voice_SLQSVoiceGetCOLP (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCOLP_t * *pOutput*)

status of the Connected Line Identification Presentation unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.56 int unpack_voice_SLQSVoiceGetCOLR (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetCOLR_t * *pOutput*)

status of the Connected Line Identification Restriction unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.57 int unpack_voice_SLQSVoiceGetConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceGetConfig_t * *pOutput*)

retrieves various configuration parameters that control the modem behavior unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.58 int unpack_voice_SLQSVoiceIndicationRegister (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceIndicationRegister_t * *pOutput*)

Sets the registration state for different QMI_VOICE indications unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.59 int unpack_voice_SLQSVoiceManageCalls (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceManageCalls_t * *pOutput*)

Manages the calls by using the supplementary service unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.60 int unpack_voice_SLQSVoiceOrigUSSDNoWait (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceOrigUSSDNoWait_t * *pOutput*)

initiates a USSD operation No Wait unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.61 int unpack_voice_SLQSVoiceSendFlash (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceSendFlash_t * *pOutput*)

sends a simple flash message unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.62 int unpack_voice_SLQSVoiceSetCallBarringPassword (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceSetCallBarringPassword_t * *pOutput*)

Sets a Call Barring Password unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.63 int unpack_voice_SLQSVoiceSetConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceSetConfig_t * *pOutput*)

configuration parameters that control the modem behavior unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.64 int unpack_voice_SLQSVoiceSetPreferredPrivacy (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceSetPreferredPrivacy_t * *pOutput*)

sets the voice privacy preference unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.65 int unpack_voice_SLQSVoiceSetSUPSService (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceSetSUPSService_t * *pOutput*)

call-independent supplementary services unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.66 int unpack_voice_SLQSVoiceStartContDTMF (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceStartContDTMF_t * *pOutput*)

Starts a continuous DTMF unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.67 int unpack_voice_SLQSVoiceStopContDTMF (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceStopContDTMF_t * *pOutput*)

Stops a continuous DTMF unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

Note

return eQCWWAN_ERR_NULL_TLV then callID value is invalid.

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.68 int unpack_voice_SLQSVoiceSUPSCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SLQSVoiceSUPSCallback_ind_t * *pOutput*)

Unpack voice sups callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	voice susp callback unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.69 int unpack_voice_SUPSNotificationCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_SUPSNotificationCallback_ind_t * *pOutput*)

Unpack SUPS notification callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	SUPS notification callback unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.70 int unpack_voice_USSDNotificationCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_USSDNotificationCallback_ind_t * *pOutput*)

Unpack USSD notification callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	USSD notification unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.71 int unpack_voice_VoiceInfoRecCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_VoiceInfoRecCallback_ind_t * *pOutput*)

Unpack SUPS notification callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	SUPS notification callback unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.44.6.72 int unpack_voice_voicePrivacyChangeCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_voice_voicePrivacyChangeCallback_ind_t * *pOutput*)

Unpack voice privacy change callback indication.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	voice privacy change callback unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45 wds.h File Reference

Data Structures

- struct LibPackQosClassID
- struct LibPackTFTIDParams
- struct LibPackGPRSRequestedQoS
- struct LibPackUMTSQoS
- struct LibPackUMTSReqQoSSigInd
- struct pack_wds_SLQSStartDataSession_t
- struct unpack_wds_SLQSStartDataSession_t
- struct unpack_wds_SLQSSetPacketSrvStatusCallback_t
- struct pack_wds_SLQSStopDataSession_t
- struct wds_ProfileIdentifier
- struct wds_GPRSQoS
- struct wds_PCSCFIPv4ServerAddressList

- struct wds_PCSCFFQDNAddress
- struct wds_PCSCFFQDNAddressList
- struct wds_Domain
- struct wds_DomainNameList
- struct wds_IPV6AddressInfo
- struct wds_IPV6GWAddressInfo
- struct unpack_wds_SLQSGetRuntimeSettings_t
- struct wds_currNetworkInfo
- struct unpack_wds_SLQSSetWdsEventCallback_ind_t
- struct pack_wds_SLQSSetWdsEventCallback_t
- struct pack_wds_SLQSGetRuntimeSettings_t
- struct wds_UMTSMinQoS
- struct LibPackprofile_3GPP
- struct LibPackprofile_3GPP2
- union wds_profileInfo
- struct pack_wds_SLQSCreateProfile_t
- struct PackCreateProfileOut
- struct unpack_wds_SLQSCreateProfile_t
- struct pack_wds_SLQSModifyProfile_t
- struct unpack_wds_SLQSModifyProfile_t
- struct pack_wds_SLQSGetProfileSettings_t
- struct LibpackProfile3GPP
- struct LibpackProfile3GPP2
- union unpackWdsProfileParam
- struct UnPackGetProfileSettingOut
- struct unpack_wds_SLQSGetProfileSettings_t
- struct unpack_wds_GetSessionState_t
- struct pack_wds_GetDefaultProfile_t
- struct unpack_wds_GetDefaultProfile_t
- struct unpack_wds_GetConnectionRate_t
- struct pack_wds_GetPacketStatus_t
- struct unpack_wds_GetPacketStatus_t
- struct unpack_wds_GetSessionDuration_t
- struct pack_wds_GetSessionDuration_t
- struct unpack_wds_GetDormancyState_t
- struct pack_wds_GetDormancyState_t
- struct pack_wds_SLQSDeleteProfile_t
- struct unpack_wds_SLQSDeleteProfile_t
- struct pack_wds_SetDefaultProfile_t
- struct unpack_wds_SLQSGet3GPPConfigItem_t
- struct pack_wds_SLQSSet3GPPConfigItem_t
- struct unpack_wds_GetMobileIP_t
- struct pack_wds_GetMobileIP_t
- struct pack_wds_GetMobileIPProfile_t
- struct unpack_wds_GetMobileIPProfile_t
- struct currNetworkInfo
- struct unpack_wds_SLQSGetCurrDataSystemStat_t
- struct pack_wds_SLQSGetCurrDataSystemStat_t
- struct unpack_wds_GetLastMobileIPError_t
- struct pack_wds_GetLastMobileIPError_t
- struct rmTrasnferStaticsReq
- struct pack_wds_RMSetTransferStatistics_t
- struct unpack_wds_RMSetTransferStatistics_t
- struct pack_wds_SetMobileIPProfile_t
- struct unpack_wds_SetMobileIPProfile_t

- struct pack_wds_SLQSWdsSwiPDPRuntimeSettings_t
- struct ipv6AddressInfo
- struct unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t
- struct wds_transferStatInd
- struct pack_wds_SLQSGetDUNCallInfo_t
- struct connectionStatus
- struct dunchannelRate
- struct unpack_wds_SLQSGetDUNCallInfo_t
- struct qmiWDSDataBearerTechnology
- struct unpack_wds_SLQSGetDataBearerTechnology_t
- struct pack_wds_SLQSGetDataBearerTechnology_t
- struct pack_wds_SLQSSetIPFamilyPreference_t
- struct unpack_wds_SLQSSetIPFamilyPreference_t
- struct pack_wds_SetDefaultProfileNum_t
- struct pack_wds_GetDefaultProfileNum_t
- struct unpack_wds_GetDefaultProfileNum_t
- struct wdsDhcpv4ProfileId
- struct wdsDhcpv4HwConfig
- struct wdsDhcpv4Option
- struct wdsDhcpv4OptionList
- struct pack_wds_SLQSSGetDHCPv4ClientConfig_t
- struct unpack_wds_SLQSSGetDHCPv4ClientConfig_t
- struct pack_wds_GetPacketStatistics_t
- struct unpack_wds_GetPacketStatistics_t
- struct unpack_wds_GetByteTotals_t
- struct unpack_wds_SLQSGetCurrentChannelRate_t
- struct unpack_wds_SLQSSGetLoopback_t
- struct pack_wds_SLQSSSetLoopback_t
- struct wds_DataULongTlv
- struct wds_DataULongLongTlv
- struct unpack_RMTransferStatistics_ind_t
- struct pack_wds_DHCPv4ClientLeaseChange_t
- struct wds_DHCPProfileIdTlv
- struct wds_DHCPLeaseStateTlv
- struct wds_IPv4AdTlv
- struct wds_DHCPOpt
- struct wds_DHCPLeaseOptTlv
- struct unpack_wds_DHCPv4ClientLease_ind_t
- struct pack_wds_SetMobileIP_t
- struct pack_wds_SetMobileIPParameters_t
- struct pack_wds_SetAutoconnect_t
- struct unpack_wds_GetAutoconnect_t
- struct wds_TrStatInd
- struct pack_wds_SLQSWdsSetEventReport_t
- struct wds_DHCPv4ProfileId
- struct wds_DHCPv4HWConfig
- struct wds_DHCPv4Option
- struct wds_DHCPv4OptionList
- struct pack_wds_SLQSSSetDHCPv4ClientConfig_t
- struct unpack_wds_GetDataBearerTechnology_t
- struct wds_ConnStatusTlv
- struct wds_LastMdmCallEndRsnTlv
- struct wds_TXBytesOKTlv
- struct wds_RXBytesOKTlv
- struct wds_DormStatTlv

- struct wds_DataBearTechTlv
- struct wds_channelRate
- struct wds_ChannelRateTlv
- struct unpack_wds_SLQSDUNCallInfoCallBack_ind_t

Macros

- #define IPV6_ADDRESS_ARRAY_SIZE 8
- #define MAX_WDS_3GPP_CONF_LTE_ATTACH_PROFILE_LIST_SIZE 24
- #define PACK_WDS_IPV4 4
- #define PACK_WDS_IPV6 6
- #define BYT_STAT_STAT_MASK 0X000000C0
- #define WDS_DHCP_MAX_NUM_OPTIONS 30
- #define WDS_DHCP_OPTION_DATA_BUF_SIZE 2048 /∗ current max size of raw message in SDK process is 2048 ∗/
- #define WDS_TFTID_SOURCE_IP_SIZE 8
- #define WDS_PROFILE_3GPP 0
- #define WDS_PROFILE_3GPP2 1

Typedefs

- typedef unpack_result_t unpack_wds_SLQSStopDataSession_t
- typedef unpack_result_t unpack_wds_SLQSSetWdsEventCallback_t
- typedef union unpackWdsProfileParam UnpackQmiProfileInfo
- typedef unpack_result_t unpack_wds_SetDefaultProfile_t
- typedef unpack_result_t unpack_wds_SLQSSet3GPPConfigItem_t
- typedef unpack_result_t unpack_wds_SetDefaultProfileNum_t
- typedef unpack_result_t unpack_wds_SLQSSSetLoopback_t
- typedef unpack_result_t unpack_wds_DHCPv4ClientLeaseChange_t
- typedef unpack_result_t unpack_wds_SetMobileIP_t
- typedef unpack_result_t unpack_wds_SetMobileIPParameters_t
- typedef unpack_result_t unpack_wds_SetAutoconnect_t
- typedef unpack_result_t unpack_wds_SLQSWdsSetEventReport_t
- typedef unpack_result_t unpack_wds_SLQSWdsGoDormant_t
- typedef unpack_result_t unpack_wds_SLQSWdsGoActive_t
- typedef unpack_result_t unpack_wds_SLQSResetPacketStatics_t
- typedef unpack_result_t unpack_wds_SLQSSSetDHCPv4ClientConfig_t
- typedef unpack_result_t unpack_wds_SetMuxID_t

Enumerations

- enum liteQmiDataBearerMasks {
  QMI_LITE_WDS_CURRENT_CALL_DB_MASK = 0x01,
  QMI_LITE_WDS_LAST_CALL_DB_MASK = 0x02 }

Functions

- int pack_wds_SLQSStartDataSession (pack_qmi_t ∗pCtx, uint8_t ∗pReqBuf, uint16_t ∗pLen, pack_wds_SLQSStartDataSession_t ∗reqArg)
- int unpack_wds_SLQSStartDataSession (uint8_t ∗pResp, uint16_t respLen, unpack_wds_SLQSStartDataSession_t ∗pOutput)
- int unpack_wds_SLQSSetPacketSrvStatusCallback (uint8_t ∗pResp, uint16_t respLen, unpack_wds_SLQSSetPacketSrvStatusCallback_t ∗pOutput)

- int pack_wds_SLQSStopDataSession (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSStopDataSession_t *reqArg)
- int unpack_wds_SLQSStopDataSession (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSStopDataSession_t *pOutput)
- int unpack_wds_SLQSGetRuntimeSettings (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetRuntimeSettings_t *pOutput)
- int unpack_wds_SLQSSetWdsEventCallback_ind (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSetWdsEventCallback_ind_t *pOutput)
- int unpack_wds_SLQSSetWdsEventCallback (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSetWdsEventCallback_t *pOutput)
- int pack_wds_SLQSSetWdsEventCallback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSetWdsEventCallback_t *reqArg)
- int pack_wds_SLQSGetRuntimeSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSGetRuntimeSettings_t *reqArg)
- int pack_wds_SLQSCreateProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSCreateProfile_t *reqArg)
- int unpack_wds_SLQSCreateProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSCreateProfile_t *pOutput)
- int pack_wds_SLQSModifyProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSModifyProfile_t *reqArg)
- int unpack_wds_SLQSModifyProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSModifyProfile_t *pOutput)
- int pack_wds_SLQSGetProfileSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSGetProfileSettings_t *reqArg)
- int unpack_wds_SLQSGetProfileSettings (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetProfileSettings_t *pOutput)
- int pack_wds_GetSessionState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_GetSessionState (uint8_t *pResp, uint16_t respLen, unpack_wds_GetSessionState_t *pOutput)
- int pack_wds_GetDefaultProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetDefaultProfile_t *reqParam)
- int unpack_wds_GetDefaultProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_GetDefaultProfile_t *pOutput)
- int pack_wds_GetConnectionRate (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_GetConnectionRate (uint8_t *pResp, uint16_t respLen, unpack_wds_GetConnectionRate_t *pOutput)
- int pack_wds_GetPacketStatus (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetPacketStatus_t *reqParam)
- int unpack_wds_GetPacketStatus (uint8_t *pResp, uint16_t respLen, unpack_wds_GetPacketStatus_t *pOutput)
- int pack_wds_GetSessionDuration (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetSessionDuration_t *reqParam)
- int unpack_wds_GetSessionDuration (uint8_t *pResp, uint16_t respLen, unpack_wds_GetSessionDuration_t *pOutput)
- int pack_wds_GetDormancyState (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetDormancyState_t *reqParam)
- int unpack_wds_GetDormancyState (uint8_t *pResp, uint16_t respLen, unpack_wds_GetDormancyState_t *pOutput)
- int pack_wds_SLQSDeleteProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSDeleteProfile_t *reqParam)
- int unpack_wds_SLQSDeleteProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSDeleteProfile_t *pOutput)
- int pack_wds_SetDefaultProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetDefaultProfile_t *reqParam)
- int unpack_wds_SetDefaultProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_SetDefaultProfile_t *pOutput)

- int pack_wds_SLQSGet3GPPConfigItem (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSGet3GPPConfigItem (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGet3GPPConfigItem_t *pOutput)
- int pack_wds_SLQSSet3GPPConfigItem (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSet3GPPConfigItem_t *reqParam)
- int unpack_wds_SLQSSet3GPPConfigItem (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSet3GPPConfigItem_t *pOutput)
- int pack_wds_GetMobileIP (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetMobileIP_t *pReqParam)
- int unpack_wds_GetMobileIP (uint8_t *pResp, uint16_t respLen, unpack_wds_GetMobileIP_t *pOutput)
- int pack_wds_GetMobileIPProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetMobileIPProfile_t *reqParam)
- int unpack_wds_GetMobileIPProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_GetMobileIPProfile_t *pOutput)
- int pack_wds_SLQSGetCurrDataSystemStat (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSGetCurrDataSystemStat_t *pReqParam)
- int unpack_wds_SLQSGetCurrDataSystemStat (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetCurrDataSystemStat_t *pOutput)
- int pack_wds_GetLastMobileIPError (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetLastMobileIPError_t *pReqParam)
- int unpack_wds_GetLastMobileIPError (uint8_t *pResp, uint16_t respLen, unpack_wds_GetLastMobileIPError_t *pOutput)
- int pack_wds_RMSetTransferStatistics (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_RMSetTransferStatistics_t *reqParam)
- int unpack_wds_RMSetTransferStatistics (uint8_t *pResp, uint16_t respLen, unpack_wds_RMSetTransferStatistics_t *pOutput)
- int pack_wds_SetMobileIPProfile (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetMobileIPProfile_t *reqParam)
- int unpack_wds_SetMobileIPProfile (uint8_t *pResp, uint16_t respLen, unpack_wds_SetMobileIPProfile_t *pOutput)
- int pack_wds_SLQSWdsSwiPDPRuntimeSettings (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSWdsSwiPDPRuntimeSettings_t *reqParam)
- int unpack_wds_SLQSWdsSwiPDPRuntimeSettings (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t *pOutput)
- int pack_wds_SLQSGetDUNCallInfo (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSGetDUNCallInfo_t *reqParam)
- int unpack_wds_SLQSGetDUNCallInfo (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetDUNCallInfo_t *pOutput)
- int pack_wds_SLQSGetDataBearerTechnology (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSGetDataBearerTechnology_t *pReqParam)
- int unpack_wds_SLQSGetDataBearerTechnology (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetDataBearerTechnology_t *pOutput)
- int pack_wds_SLQSSetIPFamilyPreference (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSetIPFamilyPreference_t *pReqParam)
- int unpack_wds_SLQSSetIPFamilyPreference (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSetIPFamilyPreference_t *pOutput)
- int pack_wds_SetDefaultProfileNum (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetDefaultProfileNum_t *pReqParam)
- int unpack_wds_SetDefaultProfileNum (uint8_t *pResp, uint16_t respLen, unpack_wds_SetDefaultProfileNum_t *pOutput)
- int pack_wds_GetDefaultProfileNum (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetDefaultProfileNum_t *pReqParam)
- int unpack_wds_GetDefaultProfileNum (uint8_t *pResp, uint16_t respLen, unpack_wds_GetDefaultProfileNum_t *pOutput)
- int pack_wds_SLQSSGetDHCPv4ClientConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSGetDHCPv4ClientConfig_t *pReq)

- int unpack_wds_SLQSSGetDHCPv4ClientConfig (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSGetDHCPv4ClientConfig_t *pOutput)
- int pack_wds_GetPacketStatistics (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_GetPacketStatistics_t *pReq)
- int unpack_wds_GetPacketStatistics (uint8_t *pResp, uint16_t respLen, unpack_wds_GetPacketStatistics_t *pOutput)
- int pack_wds_GetByteTotals (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_GetByteTotals (uint8_t *pResp, uint16_t respLen, unpack_wds_GetByteTotals_t *pOutput)
- int pack_wds_SLQSGetCurrentChannelRate (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSGetCurrentChannelRate (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSGetCurrentChannelRate_t *pOutput)
- int pack_wds_SLQSSGetLoopback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSSGetLoopback (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSGetLoopback_t *pOutput)
- int pack_wds_SLQSSSetLoopback (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSSetLoopback_t *reqArg)
- int unpack_wds_SLQSSSetLoopback (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSSetLoopback_t *pOutput)
- int unpack_wds_RMTransferStatistics_ind (uint8_t *pResp, uint16_t respLen, unpack_RMTransferStatistics_ind_t *pOutput)
- int pack_wds_DHCPv4ClientLeaseChange (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_DHCPv4ClientLeaseChange_t *reqArg)
- int unpack_wds_DHCPv4ClientLeaseChange (uint8_t *pResp, uint16_t respLen, unpack_wds_DHCPv4ClientLeaseChange_t *pOutput)
- int unpack_wds_DHCPv4ClientLease_ind (uint8_t *pResp, uint16_t respLen, unpack_wds_DHCPv4ClientLease_ind_t *pOutput)
- int pack_wds_SetMobileIP (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetMobileIP_t *reqArg)
- int unpack_wds_SetMobileIP (uint8_t *pResp, uint16_t respLen, unpack_wds_SetMobileIP_t *pOutput)
- int pack_wds_SetMobileIPParameters (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetMobileIPParameters_t *reqArg)
- int unpack_wds_SetMobileIPParameters (uint8_t *pResp, uint16_t respLen, unpack_wds_SetMobileIPParameters_t *pOutput)
- int pack_wds_SetAutoconnect (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SetAutoconnect_t *reqArg)
- int unpack_wds_SetAutoconnect (uint8_t *pResp, uint16_t respLen, unpack_wds_SetAutoconnect_t *pOutput)
- int pack_wds_GetAutoconnect (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_GetAutoconnect (uint8_t *pResp, uint16_t respLen, unpack_wds_GetAutoconnect_t *pOutput)
- int pack_wds_SLQSWdsSetEventReport (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSWdsSetEventReport_t *reqArg)
- int unpack_wds_SLQSWdsSetEventReport (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSWdsSetEventReport_t *pOutput)
- int pack_wds_SLQSWdsGoDormant (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSWdsGoDormant (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSWdsGoDormant_t *pOutput)
- int pack_wds_SLQSWdsGoActive (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSWdsGoActive (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSWdsGoActive_t *pOutput)
- int pack_wds_SLQSResetPacketStatics (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_SLQSResetPacketStatics (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSResetPacketStatics_t *pOutput)
- int pack_wds_SLQSSSetDHCPv4ClientConfig (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, pack_wds_SLQSSSetDHCPv4ClientConfig_t *reqArg)

- int unpack_wds_SLQSSSetDHCPv4ClientConfig (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSSSetDHCPv4ClientConfig_t *pOutput)
- int pack_wds_GetDataBearerTechnology (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen)
- int unpack_wds_GetDataBearerTechnology (uint8_t *pResp, uint16_t respLen, unpack_wds_GetDataBearerTechnology_t *pOutput)
- int pack_wds_SetMuxID (pack_qmi_t *pCtx, uint8_t *pReqBuf, uint16_t *pLen, uint8_t *pMuxID)
- int unpack_wds_SetMuxID (uint8_t *pResp, uint16_t respLen, unpack_wds_SetMuxID_t *pOutput)
- int unpack_wds_SLQSDUNCallInfoCallBack_ind (uint8_t *pResp, uint16_t respLen, unpack_wds_SLQSDUNCallInfoCallBack_ind_t *pOutput)

9.45.1 Detailed Description

9.45.2 SO Mask

- SO mask to indicate the service option or type of application.
  - An SO mask value of zero indicates that this field is ignored.
  - Values:
    - 0x00 - DONT_CARE
  - CDMA 1X SO mask:
    - 0x01 - CDMA_1X_IS95
    - 0x02 - CDMA_1X_IS2000
    - 0x04 - CDMA_1X_IS2000_REL_A
  - CDMA EV-DO Rev 0 SO mask:
    - 0x01 - DPA
  - CDMA EV-DO Rev A SO mask:
    - 0x01 - DPA
    - 0x02 - MFPA
    - 0x04 - EMPA
    - 0x08 - EMPA_EHRPD
  - CDMA EV-DO Rev B SO mask:
    - 0x01 - DPA
    - 0x02 - MFPA
    - 0x04 - EMPA
    - 0x08 - EMPA_EHRPD
    - 0x10 - MMPA
    - 0x20 - MMPA_EHRPD

9.45.3 RAT Mask

- RAT mask to indicate the type of technology. A RAT mask value of zero indicates that this field is ignored.
  Values:
  - 0x00 - DONT_CARE
  - 0x8000 - NULL_BEARER

- CDMA RAT mask:
  - 0x01 - CDMA_1X
  - 0x02 - EVDO_REV0
  - 0x04 - EVDO_REVA

  - 0x08 - EVDO_REVB
  - 0x10 - EHRPD
  - 0x20 - FMC

- UMTS RAT mask:
  - 0x01 - WCDMA
  - 0x02 - GPRS
  - 0x04 - HSDPA
  - 0x08 - HSUPA
  - 0x10 - EDGE
  - 0x20 - LTE
  - 0x40 - HSDPA+
  - 0x80 - DC_HSDPA+
  - 0x100 - 64_QAM
  - 0x200 - TD-SCDMA

9.45.4 Macro Definition Documentation

9.45.4.1 #define BYT_STAT_STAT_MASK 0X000000C0

9.45.4.2 #define IPV6_ADDRESS_ARRAY_SIZE 8

9.45.4.3 #define MAX_WDS_3GPP_CONF_LTE_ATTACH_PROFILE_LIST_SIZE 24

9.45.4.4 #define PACK_WDS_IPV4 4

9.45.4.5 #define PACK_WDS_IPV6 6

9.45.4.6 #define WDS_DHCP_MAX_NUM_OPTIONS 30

9.45.4.7 #define WDS_DHCP_OPTION_DATA_BUF_SIZE 2048 /∗ current max size of raw message in SDK process is 2048 ∗/

9.45.4.8 #define WDS_PROFILE_3GPP 0

9.45.4.9 #define WDS_PROFILE_3GPP2 1

9.45.4.10 #define WDS_TFTID_SOURCE_IP_SIZE 8

9.45.5 Typedef Documentation

9.45.5.1 typedef unpack_result_t unpack_wds_DHCPv4ClientLeaseChange_t

9.45.5.2 typedef unpack_result_t unpack_wds_SetAutoconnect_t

9.45.5.3 typedef unpack_result_t unpack_wds_SetDefaultProfile_t

9.45.5.4 typedef unpack_result_t unpack_wds_SetDefaultProfileNum_t

9.45.5.5 typedef unpack_result_t unpack_wds_SetMobileIP_t

9.45.5.6 typedef unpack_result_t unpack_wds_SetMobileIPParameters_t

9.45.5.7 typedef unpack_result_t unpack_wds_SetMuxID_t

9.45.5.8 typedef unpack_result_t unpack_wds_SLQSResetPacketStatics_t

9.45.5.9 typedef unpack_result_t unpack_wds_SLQSSet3GPPConfigItem_t

9.45.5.10 typedef unpack_result_t unpack_wds_SLQSSetWdsEventCallback_t

9.45.5.11 typedef unpack_result_t unpack_wds_SLQSSSetDHCPv4ClientConfig_t

9.45.5.12 typedef unpack_result_t unpack_wds_SLQSSSetLoopback_t

9.45.5.13 typedef unpack_result_t unpack_wds_SLQSStopDataSession_t

9.45.5.14 typedef unpack_result_t unpack_wds_SLQSWdsGoActive_t

9.45.5.15 typedef unpack_result_t unpack_wds_SLQSWdsGoDormant_t

9.45.5.16 typedef unpack_result_t unpack_wds_SLQSWdsSetEventReport_t

9.45.5.17 typedef union unpackWdsProfileParam UnpackQmiProfileInfo

This union WdsProfileParam consists of Profile3GPP and Profile3GPP2 out of which one will be used to create profile.

Parameters

SlqsProfile3GPP	3GPP profile • See LibpackProfile3GPP
SlqsProfile3GP-P2	3GPP2 profile • See LibpackProfile3GPP2

9.45.6 Enumeration Type Documentation

9.45.6.1 enum liteQmiDataBearerMasks

Bit mask values to indicate the presence of data bearer information for the current and last data calls

Enumerator

QMI_LITE_WDS_CURRENT_CALL_DB_MASK

QMI_LITE_WDS_LAST_CALL_DB_MASK

9.45.7 Function Documentation

9.45.7.1 int pack_wds_DHCPv4ClientLeaseChange (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_DHCPv4ClientLeaseChange_t * *reqArg*)

DHCPv4 lease state changes pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.2 int pack_wds_GetAutoconnect (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets auto connect data session setting pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.3 int pack_wds_GetByteTotals (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get Rx/Tx byte counts since the start of the last packet data session pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.4 int pack_wds_GetConnectionRate (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get connection rate pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.45.7.5 int pack_wds_GetDataBearerTechnology (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get current data bearer technology pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.6 int pack_wds_GetDefaultProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetDefaultProfile_t * *reqParam*)

get default profile pack.

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.7 int pack_wds_GetDefaultProfileNum (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetDefaultProfileNum_t * *pReqParam*)

get default profile number pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.8 int pack_wds_GetDormancyState (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetDormancyState_t * *reqParam*)

get dormancy state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.45.7.9 int pack_wds_GetLastMobileIPError (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetLastMobileIPError_t * *pReqParam*)

get current data system pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.45.7.10 int pack_wds_GetMobileIP (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetMobileIP_t * *pReqParam*)

get mobile ip mode pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.45.7.11 int pack_wds_GetMobileIPProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetMobileIPProfile_t * *reqParam*)

get mobile ip profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.12 int pack_wds_GetPacketStatistics (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_GetPacketStatistics_t * *pReq*)

gets current packet transfer counter values pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.13 int pack_wds_GetPacketStatus (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_wds_GetPacketStatus_t * reqParam)

get packet status pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.14 int pack_wds_GetSessionDuration (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_wds_GetSessionDuration_t * reqParam)

get session duration pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.45.7.15 int pack_wds_GetSessionState (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

get session state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.16 int pack_wds_RMSetTransferStatistics (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_RMSetTransferStatistics_t * *reqParam*)

RM set transfer statistics pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Note

PDN Specific: No

9.45.7.17 int pack_wds_SetAutoconnect (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetAutoconnect_t * *reqArg*)

Auto connect data session parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.18 int pack_wds_SetDefaultProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetDefaultProfile_t * *reqParam*)

set default profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.19 int pack_wds_SetDefaultProfileNum (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetDefaultProfileNum_t * *pReqParam*)

set default profile number pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.20 int pack_wds_SetMobileIP (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetMobileIP_t * *reqArg*)

Sets the current mobile IP setting pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.21 int pack_wds_SetMobileIPParameters (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetMobileIPParameters_t * *reqArg*)

Sets the specified mobile IP parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.22 int pack_wds_SetMobileIPProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SetMobileIPProfile_t * *reqParam*)

set mobile ip profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.23 int pack_wds_SetMuxID (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, uint8_t * *pMuxID*)

Set MUX ID pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pMuxID*	MUX ID. • 0x80 to 0x88

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.24 int pack_wds_SLQSCreateProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSCreateProfile_t * *reqArg*)

Create Profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.25 int pack_wds_SLQSDeleteProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSDeleteProfile_t * *reqParam*)

delete stored profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.26 int pack_wds_SLQSGet3GPPConfigItem (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get 3Gpp config items pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.27 int pack_wds_SLQSGetCurrDataSystemStat (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSGetCurrDataSystemStat_t * *pReqParam*)

get current data system pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.28 int pack_wds_SLQSGetCurrentChannelRate (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get current Tx/Rx channel bitrate of the current packet data pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.29 int pack_wds_SLQSGetDataBearerTechnology (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSGetDataBearerTechnology_t * *pReqParam*)

get data bearer technology pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.30 int pack_wds_SLQSGetDUNCallInfo (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSGetDUNCallInfo_t * *reqParam*)

get dun call info pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.31 int pack_wds_SLQSGetProfileSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSGetProfileSettings_t * *reqArg*)

Get Profile Settings pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.32 int pack_wds_SLQSGetRuntimeSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSGetRuntimeSettings_t * *reqArg*)

get runtime settings pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.33 int pack_wds_SLQSModifyProfile (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSModifyProfile_t * *reqArg*)

Modify Profile pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.34 int pack_wds_SLQSResetPacketStatics (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Reset packet data transfer statistics pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.35 int pack_wds_SLQSSet3GPPConfigItem (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSSet3GPPConfigItem_t * *reqParam*)

set 3Gpp config items pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.36 int pack_wds_SLQSSetIPFamilyPreference (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSSetIPFamilyPreference_t * *pReqParam*)

Set IP Family Preference pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.37 int pack_wds_SLQSSetWdsEventCallback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSSetWdsEventCallback_t *reqArg*)

set event callback pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: No

9.45.7.38 int pack_wds_SLQSSGetDHCPv4ClientConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSSGetDHCPv4ClientConfig_t * *pReq*)

get DHCPv4 Client Config pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*pReq*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.39 int pack_wds_SLQSSGetLoopback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

get the value of loopback mode and multiplier pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.40 int pack_wds_SLQSSSetDHCPv4ClientConfig (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSSSetDHCPv4ClientConfig_t * *reqArg*)

Gets the DHCP Client V4 Configuration pack

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

see qmerrno.h for eQCWWAN_xxx error values

9.45.7.41 int pack_wds_SLQSSSetLoopback (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSSSetLoopback_t * *reqArg*)

Enable/disable Data Loopback Mode and set the value of loopback multiplier pack

Parameters

in, out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.42 int pack_wds_SLQSStartDataSession (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_wds_SLQSStartDataSession_t * reqArg)

Start data session

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.43 int pack_wds_SLQSStopDataSession (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen, pack_wds_SLQSStopDataSession_t * reqArg)

stop data session pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.44 int pack_wds_SLQSWdsGoActive (pack_qmi_t * pCtx, uint8_t * pReqBuf, uint16_t * pLen)

Gets the device into Active state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.45 int pack_wds_SLQSWdsGoDormant (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*)

Gets the device into dormant state pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.46 int pack_wds_SLQSWdsSetEventReport (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSWdsSetEventReport_t * *reqArg*)

Sets the event report parameters pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqArg*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.47 int pack_wds_SLQSWdsSwiPDPRuntimeSettings (pack_qmi_t * *pCtx*, uint8_t * *pReqBuf*, uint16_t * *pLen*, pack_wds_SLQSWdsSwiPDPRuntimeSettings_t * *reqParam*)

swi pdp runtime settings pack

Parameters

in,out	*pCtx*	qmi request context
out	*pReqBuf*	qmi request buffer
out	*pLen*	qmi request length
in	*reqParam*	request parameter

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Note

PDN Specific: Yes

9.45.7.48 int unpack_wds_DHCPv4ClientLease_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_DHCPv4ClientLease_ind_t * *pOutput*)

DHCP lease state has changed indication unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.49 int unpack_wds_DHCPv4ClientLeaseChange (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_DHCPv4ClientLeaseChange_t * *pOutput*)

DHCPv4 lease state changes unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.50 int unpack_wds_GetAutoconnect (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetAutoconnect_t * *pOutput*)

Gets auto connect data session setting unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.51 int unpack_wds_GetByteTotals (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetByteTotals_t * *pOutput*)

get Rx/Tx byte counts since the start of the last packet data session unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.52 int unpack_wds_GetConnectionRate (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetConnectionRate_t * *pOutput*)

get connection rate unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.53 int unpack_wds_GetDataBearerTechnology (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetDataBearerTechnology_t * *pOutput*)

get current data bearer technology unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.54 int unpack_wds_GetDefaultProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetDefaultProfile_t * *pOutput*)

get default profile unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.55 int unpack_wds_GetDefaultProfileNum (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetDefaultProfileNum_t * *pOutput*)

get default profile number unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.56 int unpack_wds_GetDormancyState (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetDormancyState_t * *pOutput*)

get dormancy state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.57 int unpack_wds_GetLastMobileIPError (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetLastMobileIPError_t * *pOutput*)

get current data system unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.58 int unpack_wds_GetMobileIP (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetMobileIP_t * *pOutput*)

get mobile ip mode unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.59 int unpack_wds_GetMobileIPProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetMobileIPProfile_t * *pOutput*)

get mobile ip profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.60 int unpack_wds_GetPacketStatistics (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetPacketStatistics_t * *pOutput*)

gets current packet transfer counter values unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.61 int unpack_wds_GetPacketStatus (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetPacketStatus_t * *pOutput*)

get packet status unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.62 int unpack_wds_GetSessionDuration (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetSessionDuration_t * *pOutput*)

get session duration unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.63 int unpack_wds_GetSessionState (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_GetSessionState_t * *pOutput*)

get session state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.64 int unpack_wds_RMSetTransferStatistics (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_RMSetTransferStatistics_t * *pOutput*)

RM set transfer statistics unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.65 int unpack_wds_RMTransferStatistics_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_RMTransferStatistics_ind_t * *pOutput*)

RM transfer statistics indication unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.66 int unpack_wds_SetAutoconnect (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SetAutoconnect_t * *pOutput*)

Auto connect data session parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.67 int unpack_wds_SetDefaultProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SetDefaultProfile_t * *pOutput*)

set default profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.68 int unpack_wds_SetDefaultProfileNum (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SetDefaultProfile-Num_t * *pOutput*)

set default profile number unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.69 int unpack_wds_SetMobileIP (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SetMobileIP_t * *pOutput*)

Sets the current mobile IP setting unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.70 int unpack_wds_SetMobileIPParameters (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SetMobileIP-Parameters_t * *pOutput*)

Sets the specified mobile IP parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.71 int unpack_wds_SetMobileIPProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SetMobileIPProfile_t * *pOutput*)

set mobile ip profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.72 int unpack_wds_SetMuxID (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SetMuxID_t * *pOutput*)

Set MUX ID unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.73 int unpack_wds_SLQSCreateProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSCreateProfile_t * *pOutput*)

Create Profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response structure to fill

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.74 int unpack_wds_SLQSDeleteProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSDeleteProfile_t * *pOutput*)

delete stored profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.75 int unpack_wds_SLQSDUNCallInfoCallBack_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSDUNCallInfoCallBack_ind_t * *pOutput*)

unpack DUN call info indication

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.76 int unpack_wds_SLQSGet3GPPConfigItem (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGet3GPPConfigItem_t * *pOutput*)

get 3GPP config items unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.77 int unpack_wds_SLQSGetCurrDataSystemStat (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetCurrDataSystemStat_t * *pOutput*)

get current data system unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.78 int unpack_wds_SLQSGetCurrentChannelRate (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetCurrentChannelRate_t * *pOutput*)

get current Tx/Rx channel bitrate of the current packet data unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.79 int unpack_wds_SLQSGetDataBearerTechnology (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetDataBearerTechnology_t * *pOutput*)

get data bearer technology unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.80 int unpack_wds_SLQSGetDUNCallInfo (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetDUNCallInfo_t * *pOutput*)

get dun call info unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.81 int unpack_wds_SLQSGetProfileSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetProfileSettings_t * *pOutput*)

get session state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response structure to fill

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.82 int unpack_wds_SLQSGetRuntimeSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSGetRuntimeSettings_t * *pOutput*)

get runtime settings unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.83 int unpack_wds_SLQSModifyProfile (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSModifyProfile_t * *pOutput*)

Modify Profile unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response structure to fill

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.84 int unpack_wds_SLQSResetPacketStatics (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSResetPacketStatics_t * *pOutput*)

Reset packet data transfer statistics unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.85 int unpack_wds_SLQSSet3GPPConfigItem (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSet3GPPConfigItem_t * *pOutput*)

set 3GPP config items unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

9.45.7.86 int unpack_wds_SLQSSetIPFamilyPreference (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSetIPFamilyPreference_t * *pOutput*)

Set IP Family Preference unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.87 int unpack_wds_SLQSSetPacketSrvStatusCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSetPacketSrvStatusCallback_t * *pOutput*)

set packet srv status callback unpack

Parameters

in	*pResp*	qmi response
in	*respLen*	length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.88 int unpack_wds_SLQSSetWdsEventCallback (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSetWdsEventCallback_t * *pOutput*)

set event callback unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.89 int unpack_wds_SLQSSetWdsEventCallback_ind (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSetWdsEventCallback_ind_t * *pOutput*)

set event callback unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.90 int unpack_wds_SLQSSGetDHCPv4ClientConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSGetDHCPv4ClientConfig_t * *pOutput*)

get DHCPv4 Client Config unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.91 int unpack_wds_SLQSSGetLoopback (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSGetLoopback_t * *pOutput*)

get the value of loopback mode and multiplier unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.92 int unpack_wds_SLQSSSetDHCPv4ClientConfig (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSSetDHCPv4ClientConfig_t * *pOutput*)

Gets the DHCP Client V4 Configuration unpack.

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.93 int unpack_wds_SLQSSSetLoopback (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSSSetLoopback_t * *pOutput*)

Enable/disable Data Loopback Mode and set the value of loopback multiplier unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.94 int unpack_wds_SLQSStartDataSession (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSStartDataSession_t * *pOutput*)

start data session unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.95 int unpack_wds_SLQSStopDataSession (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSStopDataSession_t * *pOutput*)

stop data session unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.96 int unpack_wds_SLQSWdsGoActive (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSWdsGoActive_t * *pOutput*)

Gets the device into Active state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.97 int unpack_wds_SLQSWdsGoDormant (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSWdsGoDormant_t * *pOutput*)

Gets the device into dormant state unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.98 int unpack_wds_SLQSWdsSetEventReport (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSWdsSetEventReport_t * *pOutput*)

Sets the event report parameters unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	unpacked response

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

9.45.7.99 int unpack_wds_SLQSWdsSwiPDPRuntimeSettings (uint8_t * *pResp*, uint16_t *respLen*, unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t * *pOutput*)

get current data system unpack

Parameters

in	*pResp*	qmi response from modem
in	*respLen*	qmi response length
out	*pOutput*	response unpacked

Returns

eQCWWAN_ERR_NONE on success, eQCWWAN_xxx error value otherwise

See Also

See qmerrno.h for eQCWWAN_xxx error values

Index

_3gppRelease
    unpack_wds_SLQSGet3GPPConfigItem_t, 935
_litefw_FirmwareInfo_, 33
    szCarrier_str, 33
    szCarrierPriversion_str, 34
    szFwversion_str, 34
    szModelid_str, 34
    szPackageid_str, 34
    szSku_str, 34

AAASPI
    unpack_wds_GetMobileIPProfile_t, 925
AAAState
    unpack_wds_GetMobileIPProfile_t, 925
ACT_CODE_MAX_SIZE
    dms.h, 1064
ALS
    voice_getAllCallInformation, 1002
AMSSString
    unpack_dms_GetFirmwareRevision_t, 587
    unpack_dms_GetFirmwareRevisions_t, 588
AMTlv
    unpack_ims_SLQSVoIPCfgCallBack_ind_t, 654
AOATlv
    unpack_ims_SLQSVoIPCfgCallBack_ind_t, 654
AOPTlv
    NASQmiCbkNasSystemSelPrefInd, 304
APNName
    unpack_wds_SLQSGetRuntimeSettings_t, 945
AWMTlv
    unpack_ims_SLQSVoIPCfgCallBack_ind_t, 654
AWOATlv
    unpack_ims_SLQSVoIPCfgCallBack_ind_t, 654
accelTemp
    pack_loc_SLQSLOCInjectSensorData_t, 355
acceleroData
    pack_loc_SLQSLOCInjectSensorData_t, 355
acceleroTimeSrc
    pack_loc_SLQSLOCInjectSensorData_t, 355
AccessMac
    nas_protocolSubtypeElement, 240
accoIc
    pack_nas_SetACCOLC_t, 361
accuracy
    pack_pds_SetPDSDefaults_t, 401
ackIndicator
    sMSTransferRouteMTMessageInfo, 533
acqOrdeLen
    nas_acqOrderPref, 143
    nas_AcqOrderPrefTlv, 143
AcqOrderLen
    NASAcqOrderPrefTlv, 290
AcqOrderPref
    NASAcqOrderPrefTlv, 290
acroamsetting
    pack_wds_SetAutoconnect_t, 480
acsetting
    pack_wds_SetAutoconnect_t, 480
actCode
    pack_dms_ActivateAutomatic_t, 317
ActSetCnt
    nas_NetworkStat1x, 223
ActSetPilotPN
    nas_ActPilotPNElement, 144
ActSetPilotPNStrength
    nas_ActPilotPNElement, 144
action
    pack_nas_InitiateDomainAttach_t, 360
activated_ind
    sms_qaQmi3GPP2BroadcastCfgInfo, 522
    sms_qaQmi3GPPBroadcastCfgInfo, 522
activationState
    pack_dms_SetActivationStatusCallback_t, 318
activationStatus
    dms_ActivationStatusTlv, 52
ActivationStatusTlv
    unpack_dms_SetEventReport_ind_t, 603
activeBand
    nas_RfBandInfoExtFormatElements, 249
activeBandClass
    nas_RFBandInfoElements, 248
    nas_RFInfoTlv, 254
    RFBandInfoElements, 509
activeChannel
    nas_RFBandInfoElements, 248
    nas_RfBandInfoExtFormatElements, 249
    nas_RFInfoTlv, 254
    RFBandInfoElements, 509
activeInd
    sms_messageWaitingInfoContent, 520
ActiveStatus
    voice_CLIPResp, 992
    voice_CLIRResp, 993
    voice_CNAPResp, 994
    voice_COLPResp, 994
    voice_COLRResp, 995
ActiveTechPref
    unpack_nas_GetNetworkPreference_t, 700
ActiveTimer

unpack_dms_PSMCfgChange_ind_t, 600
activeTimer
dms_PSMActiveTimerTlv, 54
ActiveTimerInd
dms_PSMActiveTimerIndTlv, 54
addr
unpack_qos_IPv4Addr_t, 785
unpack_qos_IPv6Addr_t, 786
address
loc_IPv4Info, 132
loc_IPv6Info, 133
loc_urlAddr, 140
unpack_wds_GetMobileIPProfile_t, 925
addressSize
unpack_sms_GetSMSCAddress_t, 810
aid
uim_refreshevent, 558
uim_sessionInformation, 560
uim_UIMSessionInformation, 564
aidLength
appStats, 37
uim_appStatus, 543
uim_refreshevent, 558
uim_sessionInformation, 560
uim_UIMSessionInformation, 564
aidVal
appStats, 37
uim_appStatus, 543
aidingIndicatorMask
loc_sensorDataUsage, 138
airTimerValue
voice_airTimer, 970
alertPitch
voice_signalInfo, 1014
alertingPattern
voice_arrAlertingPattern, 973
AlertingType
voice_arrAlertingType, 974
alertmsg
unpack_omaDmConfigTlv_t, 767
alertmsglength
unpack_omaDmConfigTlv_t, 767
allCallsAlphaIDInfoArr
voice_arrAlphaID, 974
AllCallsUUSInfo
voice_arrUUSInfo, 980
alphaDcs
voice_alphaIDInfo, 972
AlphaID
cat_AlPhaIdentifierTlv, 45
AlphaIDInfo
voice_allCallsAlphaIDInfo, 970
alphaIDLen
unpack_sms_SLQSWmsAsyncRawSendCallBack-_ind_t, 827
AlphaIDLength
cat_AlPhaIdentifierTlv, 45
alphaLen
voice_alphaIDInfo, 972
alphaText
voice_alphaIDInfo, 972
altSrcInfo_t, 34
coverage, 35
linkage, 35
source, 35
Altitude
unpack_pds_SLQSGetGPSStateInfo_t, 782
altitudeAssumed
unpack_loc_GnssSvInfo_Ind_t, 676
altitudeSrcInfo
pack_loc_SLQSLOCInjectPosition_t, 353
altitudeWrtEllipsoid
pack_loc_SLQSLOCInjectPosition_t, 353
altitudeWrtMeanSeaLevel
pack_loc_SLQSLOCInjectPosition_t, 353
ambr_dl
unpack_qos_SLQSQosSwiReadApnExtraParams-_t, 791
ambr_dl_ext
unpack_qos_SLQSQosSwiReadApnExtraParams-_t, 791
ambr_dl_ext2
unpack_qos_SLQSQosSwiReadApnExtraParams-_t, 791
ambr_ul
unpack_qos_SLQSQosSwiReadApnExtraParams-_t, 791
ambr_ul_ext
unpack_qos_SLQSQosSwiReadApnExtraParams-_t, 791
ambr_ul_ext2
unpack_qos_SLQSQosSwiReadApnExtraParams-_t, 791
amrMode
ims_AMRModeInfo, 71
amrOctAlgn
ims_AMROctAlgnInfo, 72
amrWBEnable
ims_EnabAMRWBInfo, 74
amrWBMode
ims_AMRWBModeInfo, 73
amrWBOctAlgn
ims_AMRWBOctAlgnInfo, 73
amssSize
unpack_dms_GetFirmwareRevision_t, 587
unpack_dms_GetFirmwareRevisions_t, 588
apdoxypages.c, 1041
apnId
pack_qos_SLQSQosSwiReadApnExtraParams_t, 411
pack_qos_SLQSQosSwiReadDataStats_t, 411
unpack_qos_SLQSQosSwiReadApnExtraParams-_t, 791
unpack_qos_SLQSQosSwiReadDataStats_t, 793
apnName

unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 959
apnname
unpack_wds_GetDefaultProfile_t, 920
apnsize
unpack_wds_GetDefaultProfile_t, 920
appNameLength
loc_LocApplicationInfo, 134
appProviderLength
loc_LocApplicationInfo, 134
appState
appStats, 37
uim_appStatus, 543
appStats, 35
aidLength, 37
aidVal, 37
appState, 37
appType, 37
persoFeature, 37
persoRetries, 37
persoState, 37
persoUnblockRetries, 37
pin1Retries, 38
pin1State, 38
pin2Retries, 38
pin2State, 38
puk1Retries, 38
puk2Retries, 38
univPin, 38
AppStatus
slotInf, 514
uim_slotInfo, 563
appType
appStats, 37
uim_appStatus, 543
appVersionLength
loc_LocApplicationInfo, 134
appVersionValid
loc_LocApplicationInfo, 134
Application
unpack_nas_GetCDMANetworkParameters_t, 695
appversion_str
unpack_dms_GetFirmwareInfo_t, 585
arfcn
nas_GERANInfo, 177
nas_gsmCellInfo, 179
arrCallInfomation
unpack_voice_allCallStatusCallback_ind_t, 870
arrfileInfo
uim_refreshevent, 558
uim_registerRefresh, 559
audio.h, 1041
pack_audio_SLQSGetAudioPathConfig, 1042
pack_audio_SLQSGetAudioProfile, 1042
pack_audio_SLQSGetAudioVolTLBConfig, 1043
pack_audio_SLQSSetAudioPathConfig, 1043
pack_audio_SLQSSetAudioProfile, 1044
pack_audio_SLQSSetAudioVolTLBConfig, 1044
unpack_audio_SLQSGetAudioPathConfig, 1045
unpack_audio_SLQSGetAudioProfile, 1045
unpack_audio_SLQSGetAudioVolTLBConfig, 1045
unpack_audio_SLQSSetAudioPathConfig, 1046
unpack_audio_SLQSSetAudioProfile, 1046
unpack_audio_SLQSSetAudioVolTLBConfig, 1046
audio_RXAGCList, 38
pRXAIG, 38
pRXComprSlope, 39
pRXComprThres, 39
pRXExpSlope, 39
pRXExpThres, 39
pRXStaticGain, 39
audio_RXAVCList, 39
pAVRXAVCHeadroom, 39
pAVRXAVCSens, 39
audio_RXPCMIIRFltr, 39
pFlag, 41
pStage0Val, 41
pStage1Val, 41
pStage2Val, 41
pStage3Val, 41
pStage4Val, 41
pStageCnt, 41
audio_TXAGCList, 41
pTXAIG, 41
pTXComprSlope, 42
pTXComprThres, 42
pTXExpSlope, 42
pTXExpThres, 42
pTXStaticGain, 42
audio_TXPCMIIRFltr, 42
pFlag, 43
pStage0Val, 43
pStage1Val, 43
pStage2Val, 43
pStage3Val, 43
pStage4Val, 43
pStageCnt, 43
auth
unpack_wds_GetDefaultProfile_t, 920
authData
pack_uim_SLQSUIMAuthenticate_t, 448
AuthProt
nas_protocolSubtypeElement, 240
Authentication
unpack_wds_SLQSGetRuntimeSettings_t, 945
authentication
pack_wds_SetDefaultProfile_t, 481
AutoConnect
pack_swiavms_SLQSAVMSSetSettings_t, 431
pack_swiavms_SLQSAVMSSetSettings_v2_t, 432
unpack_swiavms_SLQSAVMSGetSettings_t, 835
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
AutoReboot
pack_swiavms_SLQSAVMSSetSettings_t, 431
unpack_swiavms_SLQSAVMSGetSettings_t, 835

Autosdm
unpack_swioma_SLQSOMADMGetSettings_t, 852
avgPeriod
nas_LTESigRptCfg, 211
nas_LTESigRptConfig, 212
azimuth
loc_satelliteInfo, 137

bAPNLength
PackSwiAvmsSetSettingsAPNInfo, 503
PackSwiAVMSSettingsAPNInfo, 504
bAuto
pack_pds_SetPortAutomaticTracking_t, 402
pack_pds_SetServiceAutomaticTracking_t, 402
bBinaryType
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 961
bEnable
pack_dms_UIMSetPINProtection_t, 332
pack_nas_SLQSSetSignalStrengthsCallback_t, 382
bEnabled
pack_pds_SetXTRAAutomaticDownload_t, 403
bForceDownload
pack_fms_SetImagesPreference_t, 336
bICCID
slot_t, 512
bICCIDLength
slot_t, 512
bLogicalSlot
pack_uim_SLQSUIMSwitchSlot_t, 454
slot_t, 512
bNotification
UnpackSwiAvmsEventReportNotification, 966
bNumberOfPhySlots
unpack_uim_SetUimSlotStatusChangeCallback_-ind_t, 861
BOOL
SwiDataTypes.h, 1359
BPTlv
NASQmiCbkNasSystemSelPrefInd, 304
bPWDLength
PackSwiAvmsSetSettingsAPNInfo, 503
PackSwiAVMSSettingsAPNInfo, 504
bPackageID
UnpackSwiAvmsEventReportPackageID, 967
bRegStatus
UnpackSwiAvmsEventReportRegStatus, 967
bResetStatistics
rmTrasnferStaticsReq, 510
bSerity
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 961
bState
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 961
UnpackSwiAvmsEventReportConfig, 962
bType
UnpackSwiAvmsEventReportDataSessionStatus, 964
UnpackSwiAvmsEventReportSessionType, 968
bUnameLength
PackSwiAvmsSetSettingsAPNInfo, 503
PackSwiAVMSSettingsAPNInfo, 505
bUserInputRequest
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 961
UnpackSwiAvmsEventReportConfig, 962
UnpackSwiAvmsEventReportConnectionRequest, 963
BYT_STAT_STAT_MASK
wds.h, 1446
BYTE
SwiDataTypes.h, 1359
band
nas_LTEInfo, 198
band1900
nas_gsmCellInfo, 179
band_pref
NASBandPreferenceTlv, 290
BandCapability
unpack_dms_GetBandCapability_t, 574
bandCapability
unpack_dms_SLQSGetBandCapability_t, 617
BandPref
nas_BandPrefTlv, 148
bandPref
pack_nas_SLQSSetBandPreference_t, 381
bandwidth
nas_LTEInfo, 198
nas_RfBandwidthInfoElements, 251
baseId
nas_CDMAInfo, 151
nas_CDMASysInfo, 155
baseLat
nas_CDMAInfo, 151
nas_CDMASysInfo, 155
baseLong
nas_CDMAInfo, 151
nas_CDMASysInfo, 155
BasestationID
unpack_nas_SLQSGetServingSystem_t, 722
BasestationLatitude
unpack_nas_SLQSGetServingSystem_t, 722
BasestationLongitude
unpack_nas_SLQSGetServingSystem_t, 722
batchPerSec
loc_accelAcceptReady, 123
loc_accelTempAcceptReady, 124
loc_gyroAcceptReady, 130
loc_gyroTempAcceptReady, 131
BearerID
unpack_qos_QosFlowInfo_t, 788
bearerID
unpack_wds_SLQSSetPacketSrvStatusCallback_-t, 948

bearerId
unpack_QosFlowStat_t, 806
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 959
bits_129_192
nas_BandPrefInfoTlv, 146
nas_lteBandPrefExt, 193
nas_nr5gBandPref, 227
bits_193_256
nas_BandPrefInfoTlv, 146
nas_lteBandPrefExt, 193
nas_nr5gBandPref, 227
bits_1_64
nas_BandPrefInfoTlv, 146
nas_lteBandPrefExt, 193
nas_nr5gBandPref, 227
bits_65_128
nas_BandPrefInfoTlv, 146
nas_lteBandPrefExt, 193
nas_nr5gBandPref, 227
bootSize
unpack_dms_GetFirmwareRevisions_t, 588
BootString
unpack_dms_GetFirmwareRevisions_t, 588
bootversion_str
unpack_dms_GetFirmwareInfo_t, 585
Broadcast
unpack_nas_GetCDMANetworkParameters_t, 695
broadcastActivate
pack_sms_SLQSSetSmsBroadcastActivation_t, 420
broadcastConfig
sms_qaQmi3GPPBroadcastCfgInfo, 522
bsInfoValid
nas_CDMASysInfo, 155
bsPRev
nas_CDMASysInfo, 155
bsPRevValid
nas_CDMASysInfo, 155
bsic
nas_GERANInfo, 177
bsicId
nas_gsmCellInfo, 179
bucketSz
unpack_qos_tokenBucket_t, 804
buildID
FMSImageIdElement, 67
image_info_t, 71
buildIDLen
image_info_t, 71
buildIDLength
FMSImageIdElement, 67
buildId
FMSImageElement, 66
buildIdLength
FMSImageElement, 66
BurstDTMFInfo
pack_voice_SLQSVoiceBurstDTMF_t, 460
ByteLoopbackMode
unpack_wds_SLQSSGetLoopback_t, 956
ByteLoopbackMultiplier
unpack_wds_SLQSSGetLoopback_t, 956

CCETlv
unpack_cat_SetCatEventCallback_ind_t, 570
CDMA_P_Rev
unpack_nas_SLQSGetServingSystem_t, 722
CDMABroadcastConfig
sms_qaQmi3GPP2BroadcastCfgInfo, 522
CDMAECIOThreshListLen
nas_CDMAECIOThresh, 150
CDMARSSIThreshListLen
nas_CDMARSSIThresh, 152
CDMASSInfo
unpack_nas_SLQSNasGetSigInfo_t, 746
CDMASystemInfoExt
unpack_nas_SLQSGetServingSystem_t, 722
CHAR
SwiDataTypes.h, 1359
CK_MAX_SIZE
dms.h, 1064
CQIValueCW0
unpack_nas_SLQSSwiGetLteCQI_t, 760
CQIValueCW1
unpack_nas_SLQSSwiGetLteCQI_t, 760
CRTlv
unpack_wds_SLQSDUNCallInfoCallBack_ind_t, 934
CSDomain
unpack_nas_GetServingNetwork_t, 703
CSTlv
unpack_wds_SLQSDUNCallInfoCallBack_ind_t, 934
CUGIndex
voice_CUGInfo, 997
CallBarStatus
unpack_nas_SLQSGetServingSystem_t, 722
callDuration
unpack_wds_GetSessionDuration_t, 930
CallEndReason
wds_LastMdmCallEndRsnTlv, 1030
callEndReason
unpack_wds_SLQSGetDUNCallInfo_t, 941
voice_arrCallEndReason, 975
CallFWExtInfo
voice_getCallFWExtInfo, 1004
CallFWInfo
voice_getCallFWInfo, 1004
callID
pack_voice_SLQSVoiceGetCallInfo_t, 464
pack_voice_SLQSVoiceStopContDTMF_t, 475
unpack_voice_OTASPStatusCallback_ind_t, 873
unpack_voice_SLQSVoiceStopContDTMF_t, 905
unpack_voice_SUPSNotificationCallback_ind_t, 910
unpack_voice_VoiceInfoRecCallback_ind_t, 913

unpack_voice_voicePrivacyChangeCallback_ind_t, 914
voice_allCallsAlphaIDInfo, 970
voice_allCallsDiagInfo, 971
voice_allCallsUUSInfo, 971
voice_arrAlertingPattern, 973
voice_arrAlertingType, 974
voice_arrCallEndReason, 975
voice_arrSvcOption, 979
voice_callInfo, 989
voice_DTMFInfo, 999
voice_getAllCallRmtPtyName, 1003
voice_getAllCallRmtPtyNum, 1003
voice_peerNumberInfo, 1007
callNumber
pack_voice_SLQSVoiceDialCall_t, 461
callState
voice_callInfo, 989
callType
voice_callInfo, 989
CalledPartyNum
voice_arrCalledPartyNum, 975
callerID
voice_callerIDInfo, 984
voice_connectNumInfo, 996
callerIDLen
voice_callerIDInfo, 984
voice_connectNumInfo, 996
callerName
voice_remotePartyName, 1012
Callinfo
voice_getAllCallInformation, 1002
cardState
slotInf, 514
uim_slotInfo, 563
carrier
unpack_dms_SLQSSwiGetFirmwareCurr_t, 623
carrier_str
unpack_dms_GetFirmwareInfo_t, 585
CarrierImage_t, 43
m_FwBuildId, 44
m_FwImageId, 44
m_PriBuildId, 44
m_PriImageId, 45
m_nCarrierId, 44
m_nFolderId, 44
m_nStorage, 44
cat.h, 1047
pack_cat_CATSendEnvelopeCommand, 1048
pack_cat_CATSendTerminalResponse, 1048
pack_cat_SetCATEventCallback, 1048
unpack_cat_CATSendEnvelopeCommand, 1049
unpack_cat_CATSendEnvelopeCommand_t, 1048
unpack_cat_CATSendTerminalResponse, 1049
unpack_cat_CATSendTerminalResponse_t, 1048
unpack_cat_SetCATEventCallback, 1050
unpack_cat_SetCatEventCallback_ind, 1050
cat_AlPhaIdentifierTlv, 45
AlphaID, 45
AlphaIDLength, 45
ReferenceID, 45
cat_EndProactiveSessionTlv, 47
EndProactiveSession, 47
cat_EventIDDataTlv, 47
Data, 47
DataLength, 47
ReferenceID, 47
cat_EventListTlv, 47
SetupEventList, 48
cat_RefreshTlv, 48
RefreshMode, 48
RefreshStage, 48
cat_commonEventTlv, 45
CatEvent, 46
EventID, 46
EventLength, 46
TlvPresent, 46
cat_currentCatEvent, 46
CatAlphaIdtfr, 46
CatEndPS, 46
CatEvIDData, 46
CatEventLst, 46
CatRefresh, 46
CatAlphaIdtfr
cat_currentCatEvent, 46
CatEndPS
cat_currentCatEvent, 46
CatEvIDData
cat_currentCatEvent, 46
CatEvent
cat_commonEventTlv, 46
CatEventLst
cat_currentCatEvent, 46
CatRefresh
cat_currentCatEvent, 46
causeCode
unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t, 827
ccsSupported
nas_CDMASysInfo, 155
ccsSupportedValid
nas_CDMASysInfo, 155
cdmaSSInfo, 48
ecio, 49
rssi, 49
cdmaSysIdValid
nas_CDMASysInfo, 155
cell_resel_priority
nas_infoInterFreq, 191
cellBroadcastCap
nas_AddSysInfo, 145
CellID
unpack_nas_SLQSGetServingSystem_t, 722
cellID
nas_GERANInfo, 177
nas_QmisNasSlqsNasPCICellInfo, 244

nas_UMTSInfo, 280
cellId
nas_GSMSysInfo, 183
nas_LTESysInfo, 216
nas_WCDMASysInfo, 288
cellIdValid
nas_gsmCellInfo, 179
nas_GSMSysInfo, 183
nas_LTESysInfo, 216
nas_WCDMASysInfo, 289
cellInterFreqParams
nas_infoInterFreq, 191
cellIsTDD
nas_umtsLTENbrCell, 282
CellParams
nas_LTEInfoIntrafreq, 201
cellReselPriority
nas_lteGsmCellInfo, 196
nas_LTEInfoIntrafreq, 201
nas_lteWcdmaCellInfo, 217
cells_len
nas_infoInterFreq, 191
nas_lteGsmCellInfo, 196
cellsLen
nas_LTEInfoIntrafreq, 201
nas_lteWcdmaCellInfo, 217
CfgValue
pack_swidms_SLQSSwiDmsSetUsbComp_t, 435
swidms_intfaceCfgTlv, 536
chaddr
wds_DHCPv4HWConfig, 1024
wdsDhcpv4HwConfig, 1038
chaddrLen
wds_DHCPv4HWConfig, 1024
wdsDhcpv4HwConfig, 1038
changePIN
pack_uim_ChangePin_t, 445
ChannelRate
wds_ChannelRateTlv, 1018
channelRate
unpack_wds_SLQSGetDUNCallInfo_t, 941
Chipset
nas_DeviceConfigDetail, 168
CiotAOPTlv
NASQmiCbkNasSystemSelPrefInd, 304
CiotAcqOrderLen
NASCiotAcqOrderPrefTlv, 291
ciotAcqOrderLen
nas_ciotAcqOrderPref, 158
nas_CiotAcqOrderPrefTlv, 159
CiotAcqOrderPref
NASCiotAcqOrderPrefTlv, 291
CiotLteOpModePref
NASCiotLteOpModePrefTlv, 291
ciotLteOpModePref
nas_CiotLteOpModePrefTlv, 159
CiotOpMPTlv
NASQmiCbkNasSystemSelPrefInd, 304
ckLen
uim_depersonalizationInformation, 549
ckVal
uim_depersonalizationInformation, 549
clear
pack_dms_SLQSSwiGetCrashInfo_t, 326
cmdID
pack_cat_CATSendEnvelopeCommand_t, 315
codingScheme
nas_PLMNNetworkNameData, 238
voice_remotePartyName, 1012
common.h
eAUDIO, 1054
eCAT, 1054
eCTL, 1053
eDMS, 1053
eIMS, 1054
eIMSA, 1054
eIND, 1054
eLOC, 1054
eLOG_DEBUG, 1053
eLOG_FATAL, 1053
eLOG_INFO, 1053
eLOG_WARN, 1053
eNAS, 1053
ePDS, 1054
eQOS, 1054
eREQ, 1054
eRMS, 1054
eRSP, 1054
eSAR, 1054
eSMS, 1054
eSWIAUDIO, 1054
eSWIDMS, 1054
eSWILOC, 1054
eSWIM2MCMD, 1054
eSWIM2MCMD_AVC2, 1054
eSWIOMA, 1054
eSWIOMAEXT, 1054
eTIMEOUT_10_S, 1054
eTIMEOUT_20_S, 1054
eTIMEOUT_2_S, 1054
eTIMEOUT_300_S, 1054
eTIMEOUT_30_S, 1054
eTIMEOUT_5_S, 1054
eTIMEOUT_60_S, 1054
eTIMEOUT_8_S, 1054
eTIMEOUT_DEFAULT, 1054
eTMD, 1054
eUIM, 1054
eVOICE, 1054
eWDS, 1053
common.h, 1050
eLOG_LEVEL, 1053
eQMI_SVC, 1053
eTimeout, 1054
fill_pack_ctx, 1055
fill_sdu_hdr, 1055

get_version, 1055
glog, 1056
gloglvl, 1056
helper_get_error_code, 1055
helper_get_error_reason, 1055
helper_get_req_str, 1055
helper_get_resp_ctx, 1055
helper_get_xid, 1055
helper_isBootLoader_DebugEnabled, 1055
helper_set_log_func, 1056
helper_set_log_lvl, 1056
liteqmi_GetVersion, 1056
liteqmi_helper_decode7bitAsciiEncString, 1056
liteqmi_log, 1056
logger, 1053
MINREQBKLEN, 1052
MSGID_AND_LEN, 1052
MSGID_DONT_CARE, 1052
msgtype, 1054
SDU_HDR_LEN, 1053
UNUSEDPARAM, 1053
unpack_result_code_only, 1056
commonInfo
unpack_nas_SLQSNasSwiModemStatus_t, 754
ConcSvcInfo
unpack_nas_SLQSGetServingSystem_t, 723
confidence
pack_loc_SLQSLOCSetCradleMountConfig_t, 357
conn_status
unpack_wds_SLQSSetPacketSrvStatusCallback_t, 948
ConnectedPartyNum
voice_arrConnectPartyNum, 977
connectionStatus, 49
MDMCallDuration, 49
MDMConnStatus, 49
unpack_wds_GetSessionState_t, 930
unpack_wds_SLQSGetDUNCallInfo_t, 941
content
uim_authenticateResult, 544
uim_readResult, 556
contentLen
uim_authenticateResult, 544
uim_readResult, 556
context
uim_authenticationData, 545
contextId
pack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 500
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 959
contextType
pack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 500
ControlMac
nas_protocolSubtypeElement, 240
count0
nas_RankIndicatorTlv, 246
count1
nas_RankIndicatorTlv, 246
countryInitials
nas_PLMNNetworkNameData, 238
coverage
altSrcInfo_t, 35
cpich_ecno
nas_wcdmaCellInfo, 284
cpich_rscp
nas_wcdmaCellInfo, 284
cradleMountConfigStatus
unpack_loc_CradleMountCallback_Ind_t, 669
crashAction
pack_dms_SetCrashAction_t, 319
crashData
crashInformation, 51
crashId
crashInformation, 51
crashInfo
crashInfoParams, 50
crashInfoParam
unpack_dms_SLQSSwiGetCrashInfo_t, 621
crashInfoParams, 50
crashInfo, 50
crashStatus, 50
crashInformation, 50
crashData, 51
crashId, 51
crashString, 51
crashStrlen, 51
gcdumpString, 51
gcdumpStrlen, 51
numCrashes, 51
crashStatus
crashInfoParams, 50
crashString
crashInformation, 51
crashStrlen
crashInformation, 51
csAttachState
nas_servSystem, 264
NASServingSystemInfo, 307
csBarStatus
nas_CallBarringSysInfo, 148
nas_callBarStatus, 149
cscfPortName
ims_CSCFPortNameInfo, 74
csgId
nas_CsgId, 162
cur_carr_name
unpack_dms_GetFirmwareInfo_t, 586
cur_carr_rev
unpack_dms_GetFirmwareInfo_t, 586
curDataBearerTechnology
unpack_wds_SLQSGetDataBearerTechnology_t, 938
curProfile
pack_wds_SLQSModifyProfile_t, 492

UnPackGetProfileSettingOut, 960
CurrChanRxRate
dunchannelRate, 64
wds_channelRate, 1018
CurrChanTxRate
dunchannelRate, 64
wds_channelRate, 1018
currDBTechAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 953
currNWInfo
unpack_wds_SLQSSetWdsEventCallback_ind_t, 953
currNetworkInfo, 51
NetworkType, 52
RATMask, 52
SOMask, 52
unpack_wds_SLQSGetCurrDataSystemStat_t, 936
current_channel_rx_rate
unpack_wds_SLQSGetCurrentChannelRate_t, 938
current_channel_tx_rate
unpack_wds_SLQSGetCurrentChannelRate_t, 938
CurrentCfgType
swidms_intfaceCfgTlv, 536
currentChannelRXRate
unpack_wds_GetConnectionRate_t, 917
currentChannelTXRate
unpack_wds_GetConnectionRate_t, 917
currentDataBearer
pack_wds_SLQSSetWdsEventCallback_t, 495
currentNetwork
qmiWDSDataBearerTechnology, 507
CurrentPLMN
unpack_nas_SLQSGetServingSystem_t, 723
CurrentmitigationLvl
unpack_tmd_SLQSTmdGetMitigationLvl_t, 855
cust_attr
DMScustSettingInfo, 62
cust_id
DMScustSettingInfo, 62
DMSgetCustomInput, 64
pack_dms_GetCustFeaturesV2_t, 317
pack_dms_SetCustFeaturesV2_t, 322
cust_value
DMScustSettingInfo, 62
pack_dms_SetCustFeaturesV2_t, 322
custSetting
DMScustSettingList, 62
CustomSCP
unpack_nas_GetCDMANetworkParameters_t, 695
CwtMute
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 829
unpack_swiaudio_SLQSGetM2MAVMute_t, 831
cycleLength
nas_EdrxCycleLength, 171

DBTTlv
unpack_wds_SLQSDUNCallInfoCallBack_ind_t, 934
dBTechAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 953
dBTechExtRatValue
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
dBTechExtSoMask
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
dBTechnology
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
dBtechExtAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 953
dBtechnologyExt
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
DHCPRelayEnabled
pack_dms_SetCustFeature_t, 321
unpack_dms_GetCustFeature_t, 577
DHCPv4LeaseOptTlv
unpack_wds_DHCPv4ClientLease_ind_t, 915
DHCPv4LeaseStateTlv
unpack_wds_DHCPv4ClientLease_ind_t, 915
dLatitude
unpack_pds_SetEventReport_Ind_t, 776
dLongitude
unpack_pds_SetEventReport_Ind_t, 776
DMS_IMGDETAILS_LEN
dms.h, 1064
DMS_PM_FACTORY
dms.h, 1064
DMS_PM_LOW
dms.h, 1064
DMS_PM_OFFLINE
dms.h, 1064
DMS_PM_ONLINE
dms.h, 1064
DMS_PM_RESET
dms.h, 1064
DMS_PM_SHUT_DOWN
dms.h, 1064
DMS_VALID_FSN_LEN
dms.h, 1065
DMScustSettingInfo, 61
cust_attr, 62
cust_id, 62
cust_value, 62
id_length, 62
value_length, 62
DMScustSettingList, 62
custSetting, 62
list_type, 62

num_instances, 62
DMSgetCustomFeatureV2, 63
pCustSettingInfo, 63
pCustSettingList, 63
pGetCustomInput, 63
DMSgetCustomInput, 63
cust_id, 64
list_type, 64
DRCCover
nas_DRCParams, 169
DRCValue
nas_DRCParams, 169
DSTIv
unpack_wds_SLQSDUNCallInfoCallBack_ind_t, 934
DTMFEvent
voice_DTMFInfo, 999
DTMFInformation
unpack_voice_DTMFEventCallback_ind_t, 871
DTMFInterdigitInterval
voice_DTMFLengths, 1000
DTMFPulseWidth
voice_DTMFLengths, 1000
DTMFdigit
pack_voice_SLQSVoiceStartContDTMF_t, 475
DTMInd
unpack_nas_SLQSGetServingSystem_t, 723
Data
cat_EventIDDataTlv, 47
data
sMSCAddressInfo, 528
sMSEtwsMessageInfo, 529
sMSTransferRouteMTMessageInfo, 533
uim_authenticationData, 545
data_buf
NASOTAMessageTlv, 297
data_len
NASOTAMessageTlv, 297
dataBearer
pack_wds_SLQSSetWdsEventCallback_t, 495
dataBearerMask
unpack_wds_SLQSGetDataBearerTechnology_t, 938
DataBearerTech
wds_DataBearTechTlv, 1020
dataBearerTech
unpack_wds_SLQSGetDUNCallInfo_t, 941
dataBearerTechExt
pack_wds_SLQSSetWdsEventCallback_t, 495
dataCapabilities
nas_dataSrvCapabilities, 164
dataCapabilitiesLen
nas_dataSrvCapabilities, 164
DataCaps
unpack_nas_GetServingNetwork_t, 703
unpack_nas_GetServingNetworkCapabilities_t, 705
dataCaps
unpack_nas_SetDataCapabilitiesCallback_ind_t, 708
DataCapsLen
unpack_nas_GetServingNetwork_t, 703
unpack_nas_GetServingNetworkCapabilities_t, 705
dataCapsSize
unpack_nas_SetDataCapabilitiesCallback_ind_t, 708
dataLen
pack_cat_CATSendEnvelopeCommand_t, 315
pack_cat_CATSendTerminalResponse_t, 316
uim_authenticationData, 545
DataLength
cat_EventIDDataTlv, 47
DataRate
unpack_qos_swiQosFlow_t, 803
dataRateMax
unpack_qos_dataRate_t, 785
dataServiceCaCapability
unpack_dms_GetDeviceCapabilities_t, 580
DataServiceCapability
unpack_dms_GetDeviceCap_t, 579
DataSrvCapabilities
unpack_nas_SLQSGetServingSystem_t, 723
dataSysStatAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 953
dataSystemStatus
pack_wds_SLQSSetWdsEventCallback_t, 495
Date
unpack_swioma_SLQSOMADMGetSessionInfo_t, 850
DateLength
unpack_swioma_SLQSOMADMGetSessionInfo_t, 850
day
nas_timeInfo, 277
nas_UniversalTime, 283
dayLtSavingAdj
nas_timeInfo, 277
dayOfWeek
nas_timeInfo, 277
nas_UniversalTime, 283
daylightSavings
nas_qaQmi3Gpp2TimeZone, 241
dedicatedBand
nas_RfDedicatedBandInfoElements, 253
defaultPDNEnabled
unpack_wds_SLQSGet3GPPConfigItem_t, 935
DefaultRoamInd
unpack_nas_SLQSGetServingSystem_t, 723
delayClass
LibPackGPRSRequestedQoS, 92
wds_GPRSQoS, 1028
deliveryErrSDU
LibPackUMTSQoS, 121
wds_UMTSMinQoS, 1037

depersonilisationInfo
pack_uim_SLQSUIMDepersonalization_t, 449
description
unpack_omaDmFotaTlv_t, 768
descriptionlength
unpack_omaDmFotaTlv_t, 768
Desription
nas_QmiNas3GppNetworkInfo, 242
destPortRangeEnd
LibPackTFTIDParams, 119
destPortRangeStart
LibPackTFTIDParams, 119
DetailedSvcInfo
unpack_nas_SLQSGetServingSystem_t, 723
DevCrashState
unpack_dms_GetCrashAction_t, 574
Device
pack_swiaudio_SLQSSetM2MAudioAVCFG_t, 425
DeviceError
qmTlvResult, 507
deviceID
unpack_tmd_SLQSTmdMitigationLvlRptCallback_-
ind_t, 856
deviceIdLen
unpack_tmd_SLQSTmdMitigationLvlRptCallback_-
ind_t, 856
DeviceResult
qmTlvResult, 507
DiagInfo
voice_allCallsDiagInfo, 971
voice_arrDiagInfo, 977
diagInfoLen
voice_diagInfo, 998
diagnosticInfo
voice_diagInfo, 998
digitBuff
voice_DTMFInfo, 999
digitCnt
voice_burstDTMFInfo, 981
voice_DTMFInfo, 999
dirNum
nas_dirNum, 168
dirNumLen
nas_dirNum, 168
direction
voice_callInfo, 989
DisableIMSI
pack_dms_SetCustFeature_t, 321
unpack_dms_GetCustFeature_t, 577
dispType
voice_extDispRecInfo, 1001
displayCondition
nas_serviceProviderName, 262
dl_bw_value
nas_PhyCaAggPcellInfo, 229
nas_PhyCaAggScellDlBw, 230
nas_PhyCaAggScellInfo, 234
NASPhyCaAggPcellInfo, 298
NASPhyCaAggScellDlBw, 299
NASPhyCaAggScellInfo, 301
dms.h, 1056
ACT_CODE_MAX_SIZE, 1064
CK_MAX_SIZE, 1064
DMS_IMGDETAILS_LEN, 1064
DMS_PM_FACTORY, 1064
DMS_PM_LOW, 1064
DMS_PM_OFFLINE, 1064
DMS_PM_ONLINE, 1064
DMS_PM_RESET, 1064
DMS_PM_SHUT_DOWN, 1064
DMS_VALID_FSN_LEN, 1065
ERI_DATA_MAX_SIZE, 1065
MAX_BUILD_ID_LEN, 1065
MEID_MAX_SIZE, 1065
pack_dms_ActivateAutomatic, 1065
pack_dms_GetActivationState, 1066
pack_dms_GetBandCapability, 1066
pack_dms_GetCrashAction, 1066
pack_dms_GetCustFeature, 1067
pack_dms_GetCustFeaturesV2, 1067
pack_dms_GetDeviceCap, 1067
pack_dms_GetDeviceCapabilities, 1068
pack_dms_GetDeviceHardwareRev, 1068
pack_dms_GetDeviceMfr, 1069
pack_dms_GetDeviceSerialNumbers, 1069
pack_dms_GetFSN, 1070
pack_dms_GetFirmwareInfo, 1069
pack_dms_GetFirmwareRevision, 1070
pack_dms_GetFirmwareRevisions, 1070
pack_dms_GetHardwareRevision, 1071
pack_dms_GetIMSI, 1071
pack_dms_GetManufacturer, 1071
pack_dms_GetModelID, 1072
pack_dms_GetNetworkTime, 1072
pack_dms_GetOfflineReason, 1072
pack_dms_GetPRLVersion, 1073
pack_dms_GetPower, 1073
pack_dms_GetSerialNumbers, 1073
pack_dms_GetUSBComp, 1074
pack_dms_GetVoiceNumber, 1074
pack_dms_ResetToFactoryDefaults, 1074
pack_dms_SLQSDmsSwiGetPCInfo, 1078
pack_dms_SLQSDmsSwiGetResetInfo, 1079
pack_dms_SLQSDmsSwiGetUimSelection, 1079
pack_dms_SLQSDmsSwiIndicationRegister, 1079
pack_dms_SLQSGetBandCapability, 1080
pack_dms_SLQSGetERIFile, 1080
pack_dms_SLQSGetPowerSaveModeConfig, 1080
pack_dms_SLQSSetPowerSaveModeConfig, 1081
pack_dms_SLQSSwiClearDyingGaspStatistics,
1081
pack_dms_SLQSSwiGetCrashInfo, 1082
pack_dms_SLQSSwiGetDyingGaspCfg, 1082
pack_dms_SLQSSwiGetDyingGaspStatistics,
1082
pack_dms_SLQSSwiGetFirmwareCurr, 1083

pack_dms_SLQSSwiGetFwUpdateStatus, 1083
pack_dms_SLQSSwiGetHostDevInfo, 1083
pack_dms_SLQSSwiGetOSInfo, 1084
pack_dms_SLQSSwiGetSerialNoExt, 1084
pack_dms_SLQSSwiSetDyingGaspCfg, 1084
pack_dms_SLQSSwiSetHostDevInfo, 1085
pack_dms_SLQSSwiSetOSInfo, 1085
pack_dms_SLQSUIMGetState, 1085
pack_dms_SetActivationStatusCallback, 1075
pack_dms_SetCrashAction, 1075
pack_dms_SetCustFeature, 1076
pack_dms_SetCustFeaturesV2, 1076
pack_dms_SetEventReport, 1076
pack_dms_SetFirmwarePreference, 1077
pack_dms_SetIndicationRegister, 1077
pack_dms_SetPower, 1077
pack_dms_SetUSBComp, 1078
pack_dms_SwiSetEventReport, 1086
pack_dms_SwiUimSelect, 1086
pack_dms_UIMChangePIN, 1086
pack_dms_UIMGetControlKeyStatus, 1087
pack_dms_UIMGetICCID, 1087
pack_dms_UIMGetPINStatus, 1088
pack_dms_UIMSetControlKeyProtection, 1088
pack_dms_UIMSetPINProtection, 1088
pack_dms_UIMUnblockControlKey, 1089
pack_dms_UIMUnblockPIN, 1089
pack_dms_UIMVerifyPIN, 1089
pack_dms_ValidateSPC, 1090
SPC_SIZE, 1065
UNIQUE_ID_LEN, 1065
unpack_dms_ActivateAutomatic, 1090
unpack_dms_GetActivationState, 1091
unpack_dms_GetBandCapability, 1091
unpack_dms_GetCrashAction, 1091
unpack_dms_GetCustFeature, 1092
unpack_dms_GetCustFeaturesV2, 1092
unpack_dms_GetDeviceCap, 1092
unpack_dms_GetDeviceCapabilities, 1093
unpack_dms_GetDeviceHardwareRev, 1093
unpack_dms_GetDeviceMfr, 1093
unpack_dms_GetDeviceSerialNumbers, 1094
unpack_dms_GetFSN, 1095
unpack_dms_GetFirmwareInfo, 1094
unpack_dms_GetFirmwareRevision, 1094
unpack_dms_GetFirmwareRevisions, 1095
unpack_dms_GetHardwareRevision, 1095
unpack_dms_GetIMSI, 1096
unpack_dms_GetManufacturer, 1096
unpack_dms_GetModelID, 1096
unpack_dms_GetNetworkTime, 1097
unpack_dms_GetOfflineReason, 1097
unpack_dms_GetPRLVersion, 1098
unpack_dms_GetPower, 1097
unpack_dms_GetSerialNumbers, 1098
unpack_dms_GetUSBComp, 1098
unpack_dms_GetVoiceNumber, 1099
unpack_dms_PSMCfgChange_ind, 1099
unpack_dms_ResetToFactoryDefaults, 1099
unpack_dms_SLQSDmsSwiGetPCInfo, 1103
unpack_dms_SLQSDmsSwiGetResetInfo, 1104
unpack_dms_SLQSDmsSwiGetResetInfo_Ind, 1104
unpack_dms_SLQSDmsSwiGetUimSelection, 1104
unpack_dms_SLQSDmsSwiIndicationRegister, 1105
unpack_dms_SLQSGetBandCapability, 1105
unpack_dms_SLQSGetERIFile, 1105
unpack_dms_SLQSGetPowerSaveModeConfig, 1106
unpack_dms_SLQSSetPowerSaveModeConfig, 1106
unpack_dms_SLQSSwiClearDyingGaspStatistics, 1107
unpack_dms_SLQSSwiGetCrashInfo, 1107
unpack_dms_SLQSSwiGetDyingGaspCfg, 1107
unpack_dms_SLQSSwiGetDyingGaspStatistics, 1108
unpack_dms_SLQSSwiGetFirmwareCurr, 1108
unpack_dms_SLQSSwiGetFwUpdateStatus, 1108
unpack_dms_SLQSSwiGetHostDevInfo, 1109
unpack_dms_SLQSSwiGetOSInfo, 1109
unpack_dms_SLQSSwiGetSerialNoExt, 1109
unpack_dms_SLQSSwiSetDyingGaspCfg, 1110
unpack_dms_SLQSSwiSetHostDevInfo, 1110
unpack_dms_SLQSSwiSetOSInfo, 1110
unpack_dms_SLQSUIMGetState, 1111
unpack_dms_SetActivationStatusCallback, 1100
unpack_dms_SetCrashAction, 1100
unpack_dms_SetCustFeature, 1100
unpack_dms_SetCustFeaturesV2, 1101
unpack_dms_SetEventReport, 1101
unpack_dms_SetEventReport_ind, 1101
unpack_dms_SetFirmwarePreference, 1102
unpack_dms_SetIndicationRegister, 1102
unpack_dms_SetPower, 1103
unpack_dms_SetUSBComp, 1103
unpack_dms_SwiEventReportCallBack_ind, 1111
unpack_dms_SwiSetEventReport, 1111
unpack_dms_SwiUimSelect, 1112
unpack_dms_UIMChangePIN, 1112
unpack_dms_UIMGetControlKeyStatus, 1112
unpack_dms_UIMGetICCID, 1113
unpack_dms_UIMGetPINStatus, 1113
unpack_dms_UIMSetControlKeyProtection, 1113
unpack_dms_UIMSetPINProtection, 1114
unpack_dms_UIMUnblockControlKey, 1114
unpack_dms_UIMUnblockPIN, 1114
unpack_dms_UIMVerifyPIN, 1115
unpack_dms_ValidateSPC, 1115
dms_ActivationStatusTlv, 52
activationStatus, 52
TlvPresent, 52
dms_OperatingModeTlv, 52
operatingMode, 53

TlvPresent, 53
dms_PSMActiveTimerIndTlv, 53
ActiveTimerInd, 54
TlvPresent, 54
dms_PSMActiveTimerTlv, 54
activeTimer, 54
TlvPresent, 54
dms_PSMDurationDueToOOSTlv, 54
durationDueToOOS, 55
TlvPresent, 55
dms_PSMDurationThresholdTlv, 55
durationThreshold, 55
TlvPresent, 55
dms_PSMEarlyWakeupTimeTlv, 55
earlyWakeupTime, 56
TlvPresent, 56
dms_PSMEnableStateIndTlv, 56
EnableStateInd, 56
TlvPresent, 56
dms_PSMEnableStateTlv, 56
enableState, 57
TlvPresent, 57
dms_PSMPeriodicUpdateTimerIndTlv, 57
PeriodicUpdateTimerInd, 57
TlvPresent, 57
dms_PSMPeriodicUpdateTimerTlv, 57
periodicUpdateTimer, 58
TlvPresent, 58
dms_PSMRandomizationWindowTlv, 58
randomizationWindow, 58
TlvPresent, 58
dms_TemperatureTlv, 58
TempStat, 59
Temperature, 59
TlvPresent, 59
dms_UimAutoSwitchActSlotTlv, 59
TlvPresent, 59
uimAutoSwitchActSlot, 59
dms_UimStatusTlv, 60
event, 60
intf, 60
TlvPresent, 60
dms_VoltageTlv, 60
TlvPresent, 61
VoltStat, 61
Voltage, 61
domain
wds_DomainNameList, 1027
domainLen
wds_Domain, 1026
DomainList
unpack_wds_SLQSGetRuntimeSettings_t, 945
domainName
wds_Domain, 1026
DormancyStat
wds_DormStatTlv, 1027
dormancyStatAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
dormancyState
unpack_wds_GetDormancyState_t, 922
dormancyStatus
pack_wds_SLQSSetWdsEventCallback_t, 495
unpack_wds_SLQSGetDUNCallInfo_t, 941
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
downLink
voice_NSSAudioCtrl, 1006
dtmSupp
nas_GSMSysInfo, 183
dtmSuppValid
nas_GSMSysInfo, 183
dunchannelRate, 64
CurrChanRxRate, 64
CurrChanTxRate, 64
MaxChanRxRate, 64
MaxChanTxRate, 64
Duration
pack_nas_SetNetworkPreference_t, 364
unpack_nas_GetNetworkPreference_t, 700
durationDueToOOS
dms_PSMDurationDueToOOSTlv, 55
durationThreshold
dms_PSMDurationThresholdTlv, 55

eAUDIO
common.h, 1054
eCAT
common.h, 1054
eCTL
common.h, 1053
eDMS
common.h, 1053
eFIREHOSE_ERR_SECBOOT_INVALID_CERT_CHAIN
lite-fw.h, 1141
eFW_TYPE_CWE
lite-fw.h, 1141
eFW_TYPE_CWE_NVU
lite-fw.h, 1141
eFW_TYPE_INVALID
lite-fw.h, 1141
eFW_TYPE_MBN
lite-fw.h, 1141
eFW_TYPE_MBN_GOBI
lite-fw.h, 1141
eFW_TYPE_NVU
lite-fw.h, 1141
eFW_TYPE_SPK
lite-fw.h, 1141
eIMS
common.h, 1054
eIMSA
common.h, 1054
eIND
common.h, 1054

eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_100
nas.h, 1181
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_15
nas.h, 1181
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_25
nas.h, 1181
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_50
nas.h, 1181
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_6
nas.h, 1181
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_75
nas.h, 1181
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED
nas.h, 1181
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED
nas.h, 1181
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_DECONFIGURED
nas.h, 1181
eLOC
common.h, 1054
eLOG_DEBUG
common.h, 1053
eLOG_FATAL
common.h, 1053
eLOG_INFO
common.h, 1053
eLOG_WARN
common.h, 1053
eModel_9X15
lite-fw.h, 1142
eModel_9X30
lite-fw.h, 1142
eModel_9x06
lite-fw.h, 1142
eModel_9x07
lite-fw.h, 1142
eModel_Unknown
lite-fw.h, 1142
eModel_WP9X15
lite-fw.h, 1142
eNAS
common.h, 1053
eNAS_LTE_CPHY_CA_BW_NRB_LITE_100
nas.h, 1181
eNAS_LTE_CPHY_CA_BW_NRB_LITE_15
nas.h, 1181
eNAS_LTE_CPHY_CA_BW_NRB_LITE_25
nas.h, 1181
eNAS_LTE_CPHY_CA_BW_NRB_LITE_50
nas.h, 1181
eNAS_LTE_CPHY_CA_BW_NRB_LITE_6
nas.h, 1181
eNAS_LTE_CPHY_CA_BW_NRB_LITE_75
nas.h, 1181
eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED_LITE
nas.h, 1181
eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED_LITE
nas.h, 1181
eNAS_LTE_CPHY_SCELL_STATE_DECONFIGURED_LITE
nas.h, 1181
ePDS
common.h, 1054
eQCWWAN_ERR_API_MUTEX_TIMEOUT
qmerrno.h, 1294
eQCWWAN_ERR_BUFFER_SZ
qmerrno.h, 1293
eQCWWAN_ERR_CANCEL_OP
qmerrno.h, 1294
eQCWWAN_ERR_DRIVER
qmerrno.h, 1294
eQCWWAN_ERR_ENUM_BEGIN
qmerrno.h, 1293
eQCWWAN_ERR_ENUM_END
qmerrno.h, 1294
eQCWWAN_ERR_FILE_COPY
qmerrno.h, 1293
eQCWWAN_ERR_FILE_OPEN
qmerrno.h, 1293
eQCWWAN_ERR_GENERAL
qmerrno.h, 1293
eQCWWAN_ERR_INTERNAL
qmerrno.h, 1293
eQCWWAN_ERR_INVALID_ARG
qmerrno.h, 1293
eQCWWAN_ERR_INVALID_DEVID
qmerrno.h, 1293
eQCWWAN_ERR_INVALID_FILE
qmerrno.h, 1293
eQCWWAN_ERR_INVALID_QMI_RSP
qmerrno.h, 1293
eQCWWAN_ERR_INVALID_XID
qmerrno.h, 1294
eQCWWAN_ERR_MALFORMED_QMI_RSP
qmerrno.h, 1293
eQCWWAN_ERR_MEMORY
qmerrno.h, 1293
eQCWWAN_ERR_MULTIPLE_DEVICES
qmerrno.h, 1294
eQCWWAN_ERR_MULTIPLE_SMS_UNSUPPORTED
qmerrno.h, 1294
eQCWWAN_ERR_NO_CANCELABLE_OP
qmerrno.h, 1294
eQCWWAN_ERR_NO_CONNECTION
qmerrno.h, 1293
eQCWWAN_ERR_NO_DEVICE
qmerrno.h, 1293
eQCWWAN_ERR_NO_SIGNAL
qmerrno.h, 1294
eQCWWAN_ERR_NONE

qmerrno.h, 1293
eQCWWAN_ERR_NULL_TLV
qmerrno.h, 1297
eQCWWAN_ERR_OFFLINE
qmerrno.h, 1294
eQCWWAN_ERR_PDU_GENERATION
qmerrno.h, 1294
eQCWWAN_ERR_QMI_ABORTED
qmerrno.h, 1294
eQCWWAN_ERR_QMI_ACCESS_DENIED
qmerrno.h, 1296
eQCWWAN_ERR_QMI_ACK_NOT_SENT
qmerrno.h, 1296
eQCWWAN_ERR_QMI_ARG_TOO_LONG
qmerrno.h, 1294
eQCWWAN_ERR_QMI_AUTHENTICATION_FAILED
qmerrno.h, 1295
eQCWWAN_ERR_QMI_AUTHENTICATION_LOCK
qmerrno.h, 1295
eQCWWAN_ERR_QMI_BUNDLING_NOT_SUPPORTED
qmerrno.h, 1296
eQCWWAN_ERR_QMI_CALL_FAILED
qmerrno.h, 1294
eQCWWAN_ERR_QMI_CARD_BUSY_RSP
qmerrno.h, 1297
eQCWWAN_ERR_QMI_CARD_CALL_CONTROL_FAILED
qmerrno.h, 1296
eQCWWAN_ERR_QMI_CAT_END
qmerrno.h, 1297
eQCWWAN_ERR_QMI_CAT_START
qmerrno.h, 1297
eQCWWAN_ERR_QMI_CAUSE_CODE
qmerrno.h, 1295
eQCWWAN_ERR_QMI_CLIENT_IDS_EXHAUSTED
qmerrno.h, 1294
eQCWWAN_ERR_QMI_CONNECT
qmerrno.h, 1293
eQCWWAN_ERR_QMI_DEVICE_IN_USE
qmerrno.h, 1294
eQCWWAN_ERR_QMI_DEVICE_NOT_READY
qmerrno.h, 1295
eQCWWAN_ERR_QMI_DEVICE_STORAGE_FULL
qmerrno.h, 1295
eQCWWAN_ERR_QMI_DISABLED
qmerrno.h, 1295
eQCWWAN_ERR_QMI_ENCODING
qmerrno.h, 1295
eQCWWAN_ERR_QMI_ENVELOPE_CMD_FAILURE
qmerrno.h, 1297
eQCWWAN_ERR_QMI_EVENT_REG_FAILED
qmerrno.h, 1297
eQCWWAN_ERR_QMI_EXTENDED_INTERNAL
qmerrno.h, 1296
eQCWWAN_ERR_QMI_FDN_RESTRICT
qmerrno.h, 1296
eQCWWAN_ERR_QMI_FLOW_SUSPENDED
qmerrno.h, 1295
eQCWWAN_ERR_QMI_GENERAL
qmerrno.h, 1295
eQCWWAN_ERR_QMI_HARDWARE_RESTRICTED
qmerrno.h, 1296
eQCWWAN_ERR_QMI_IFACE
qmerrno.h, 1293
eQCWWAN_ERR_QMI_INCOMPATIBLE_STATE
qmerrno.h, 1296
eQCWWAN_ERR_QMI_INCORRECT_FLOW_FILTER
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INCORRECT_PIN
qmerrno.h, 1294
eQCWWAN_ERR_QMI_INFO_UNAVAILABLE
qmerrno.h, 1296
eQCWWAN_ERR_QMI_INJECT_TIMEOUT
qmerrno.h, 1296
eQCWWAN_ERR_QMI_INSUFFICIENT_RESOURCES
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INTERFACE_NOT_FOUND
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INTERNAL
qmerrno.h, 1294
eQCWWAN_ERR_QMI_INVALID_ARG
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INVALID_CLIENT_ID
qmerrno.h, 1294
eQCWWAN_ERR_QMI_INVALID_DATA_FORMAT
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INVALID_ENVELOPE_CMD
qmerrno.h, 1297
eQCWWAN_ERR_QMI_INVALID_HANDLE
qmerrno.h, 1294
eQCWWAN_ERR_QMI_INVALID_ID
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INVALID_INDEX
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INVALID_IP_FAMILY_PREF
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INVALID_MCAST_HANDLE
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INVALID_MESSAGE_ID
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INVALID_OPERATION
qmerrno.h, 1296
eQCWWAN_ERR_QMI_INVALID_PDP_TYPE
qmerrno.h, 1294
eQCWWAN_ERR_QMI_INVALID_PINID
qmerrno.h, 1294
eQCWWAN_ERR_QMI_INVALID_PROFILE
qmerrno.h, 1294
eQCWWAN_ERR_QMI_INVALID_PROFILE_TYPE
qmerrno.h, 1294
eQCWWAN_ERR_QMI_INVALID_PS_ATTACH_ACTION
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INVALID_QMI_CMD

qmerrno.h, 1296
eQCWWAN_ERR_QMI_INVALID_QOS_ID
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INVALID_REGISTER_ACTIO-
N
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INVALID_SERVICE_TYPE
qmerrno.h, 1294
eQCWWAN_ERR_QMI_INVALID_TECH_PREF
qmerrno.h, 1294
eQCWWAN_ERR_QMI_INVALID_TERMINAL_RSP
qmerrno.h, 1297
eQCWWAN_ERR_QMI_INVALID_TRANSITION
qmerrno.h, 1295
eQCWWAN_ERR_QMI_INVALID_TX_ID
qmerrno.h, 1294
eQCWWAN_ERR_QMI_MALFORMED_MSG
qmerrno.h, 1294
eQCWWAN_ERR_QMI_MAX
qmerrno.h, 1296
eQCWWAN_ERR_QMI_MAX_MCAST_REQUESTS_I-
N_USE
qmerrno.h, 1295
eQCWWAN_ERR_QMI_MAX_QOS_REQUESTS_IN_-
USE
qmerrno.h, 1295
eQCWWAN_ERR_QMI_MESSAGE_DELIVERY_FAIL-
URE
qmerrno.h, 1295
eQCWWAN_ERR_QMI_MESSAGE_NOT_SENT
qmerrno.h, 1295
eQCWWAN_ERR_QMI_MISSING_ARG
qmerrno.h, 1294
eQCWWAN_ERR_QMI_MSG_BLOCKED
qmerrno.h, 1296
eQCWWAN_ERR_QMI_NETWORK_ABORTED
qmerrno.h, 1296
eQCWWAN_ERR_QMI_NETWORK_NOT_READY
qmerrno.h, 1295
eQCWWAN_ERR_QMI_NETWORK_QOS_UNAWARE
qmerrno.h, 1295
eQCWWAN_ERR_QMI_NO_EFFECT
qmerrno.h, 1294
eQCWWAN_ERR_QMI_NO_ENTRY
qmerrno.h, 1295
eQCWWAN_ERR_QMI_NO_FREE_PROFILE
qmerrno.h, 1294
eQCWWAN_ERR_QMI_NO_MEMORY
qmerrno.h, 1294
eQCWWAN_ERR_QMI_NO_NETWORK_FOUND
qmerrno.h, 1294
eQCWWAN_ERR_QMI_NO_RADIO
qmerrno.h, 1296
eQCWWAN_ERR_QMI_NO_SUBSCRIPTION
qmerrno.h, 1296
eQCWWAN_ERR_QMI_NO_THRESHOLDS
qmerrno.h, 1294
eQCWWAN_ERR_QMI_NOT_A_MCAST_IFACE
qmerrno.h, 1295
eQCWWAN_ERR_QMI_NOT_PROVISIONED
qmerrno.h, 1294
eQCWWAN_ERR_QMI_NOT_SUPPORTED
qmerrno.h, 1296
eQCWWAN_ERR_QMI_OFFSET
qmerrno.h, 1294
eQCWWAN_ERR_QMI_OP_DEVICE_UNSUPPORTE-
D
qmerrno.h, 1294
eQCWWAN_ERR_QMI_OP_NETWORK_UNSUPPOR-
TED
qmerrno.h, 1294
eQCWWAN_ERR_QMI_OP_PARTIAL_FAILURE
qmerrno.h, 1296
eQCWWAN_ERR_QMI_OUT_OF_CALL
qmerrno.h, 1294
eQCWWAN_ERR_QMI_PIN_BLOCKED
qmerrno.h, 1295
eQCWWAN_ERR_QMI_PIN_PERM_BLOCKED
qmerrno.h, 1295
eQCWWAN_ERR_QMI_POLICY_MISMATCH
qmerrno.h, 1296
eQCWWAN_ERR_QMI_REQ
qmerrno.h, 1293
eQCWWAN_ERR_QMI_REQ_SCH
qmerrno.h, 1293
eQCWWAN_ERR_QMI_REQ_TO
qmerrno.h, 1293
eQCWWAN_ERR_QMI_REQUESTED_NUM_UNSUP-
PORTED
qmerrno.h, 1295
eQCWWAN_ERR_QMI_RSP
qmerrno.h, 1293
eQCWWAN_ERR_QMI_RSP_TO
qmerrno.h, 1293
eQCWWAN_ERR_QMI_SEGMENT_ORDER
qmerrno.h, 1296
eQCWWAN_ERR_QMI_SEGMENT_TOO_LONG
qmerrno.h, 1296
eQCWWAN_ERR_QMI_SESSION_INACTIVE
qmerrno.h, 1295
eQCWWAN_ERR_QMI_SESSION_INVALID
qmerrno.h, 1295
eQCWWAN_ERR_QMI_SESSION_OWNERSHIP
qmerrno.h, 1295
eQCWWAN_ERR_QMI_SIM_FILE_NOT_FOUND
qmerrno.h, 1296
eQCWWAN_ERR_QMI_SIM_NOT_INITIALIZED
qmerrno.h, 1295
eQCWWAN_ERR_QMI_SMSC_ADDR
qmerrno.h, 1296
eQCWWAN_ERR_QMI_SUPS_FAILURE_CAUSE
qmerrno.h, 1296
eQCWWAN_ERR_QMI_TPDU_TYPE
qmerrno.h, 1296
eQCWWAN_ERR_QMI_UNABORTABLE_TRANSACT-
ION

qmerrno.h, 1294
eQCWWAN_ERR_QMI_UNKNOWN
qmerrno.h, 1295
eQCWWAN_ERR_QMI_WIDTH
qmerrno.h, 1297
eQCWWAN_ERR_RESET
qmerrno.h, 1294
eQCWWAN_ERR_SWICM_AM_VERS_ERROR
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_CALL_IN_PROGRESS
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_END
qmerrno.h, 1297
eQCWWAN_ERR_SWICM_FAILED_TO_KILL_SDK_-PROCESS
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_INVALID_SESSION_ID
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_INVALID_V4_SESSION_I-D
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_INVALID_V6_SESSION_I-D
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_NOT_IMPLEMENTED
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_QMI_CLNT_NOT_SUPPO-RTED
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_QMI_SVC_NOT_SUPPO-RTED
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_SM_NO_AVAILABLE_SE-SSIONS
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_SOCKET_IN_USE
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_START
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_TIMEOUT
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_V4DWN_V6DWN
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_V4DWN_V6UP
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_V4UP_V6DWN
qmerrno.h, 1296
eQCWWAN_ERR_SWICM_V4UP_V6UP
qmerrno.h, 1296
eQCWWAN_ERR_SWIDCS_APP_DISCONNECTED
qmerrno.h, 1297
eQCWWAN_ERR_SWIDCS_DEVNODE_NOT_FOUN-D
qmerrno.h, 1297
eQCWWAN_ERR_SWIDCS_END
qmerrno.h, 1297
eQCWWAN_ERR_SWIDCS_FILEIO_ERR
qmerrno.h, 1297
eQCWWAN_ERR_SWIDCS_IOCTL_ERR
qmerrno.h, 1297
eQCWWAN_ERR_SWIDCS_START
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_CORRUPTED_FW_IMAGE
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_END
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FILE_NOT_FOUND
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FIRMWARE_NOT_DOWN-LOADED
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FW_ENTER_DOWNLOAD-_MODE
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FW_FLASH_COMPLETE
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FW_INVALID_SLOT_INDE-X
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FW_PREFERENCE_MISM-ATCH
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FW_SAME_AS_CURRENT-_ACTIVE_IMAGE
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FW_SECBOOT_IMAGE_N-OT_SIGNED
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FW_SECBOOT_INVALID_-CERT_CHAIN
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FW_UPDATE_FAIL
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FW_UPDATE_SUCCESS
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_FW_WAIT_FOR_REBOOT
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_INVALID_CRASH_STATE
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_INVALID_PATH
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_OPENING_DIR
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_OPENING_FILE
qmerrno.h, 1297
eQCWWAN_ERR_SWIIM_START
qmerrno.h, 1297
eQCWWAN_ERR_SWISM_END
qmerrno.h, 1297
eQCWWAN_ERR_SWISMS_BEARER_DATA_NOT_F-OUND
qmerrno.h, 1297
eQCWWAN_ERR_SWISMS_MSG_CORRUPTED
qmerrno.h, 1297
eQCWWAN_ERR_SWISMS_MSG_LEN_TOO_LONG
qmerrno.h, 1297

eQCWWAN_ERR_SWISMS_SMSC_NUM_CORRUPTED
qmerrno.h, 1297
eQCWWAN_ERR_SWISMS_START
qmerrno.h, 1297
eQDL_HW_FLOW_DISABLE
lite-fw.h, 1142
eQDL_HW_FLOW_ENABLE
lite-fw.h, 1142
eQDL_HW_FLOW_INIT
lite-fw.h, 1142
eQDL_HW_FLOW_Unknown
lite-fw.h, 1142
eQDL_MODE_INIT
lite-fw.h, 1142
eQDL_MODE_TTYUSB
lite-fw.h, 1142
eQDL_MODE_UART0
lite-fw.h, 1142
eQDL_MODE_Unknown
lite-fw.h, 1142
eQMI_LOC_SESS_STATUS_FAILURE
loc.h, 1153
eQMI_LOC_SESS_STATUS_IN_PROGRESS
loc.h, 1153
eQMI_LOC_SESS_STATUS_SUCCESS
loc.h, 1153
eQMI_LOC_SESS_STATUS_TIMEOUT
loc.h, 1153
eQOS
common.h, 1054
eREQ
common.h, 1054
eRMS
common.h, 1054
eRSP
common.h, 1054
eSAR
common.h, 1054
eSDP_FWDWL_ERR_END
lite-fw.h, 1141
eSDP_FWDWL_ERR_FAIL
lite-fw.h, 1141
eSDP_FWDWL_ERR_FW_UPGRADE
lite-fw.h, 1141
eSDP_FWDWL_ERR_FW_VERSION_FAIL
lite-fw.h, 1141
eSDP_FWDWL_ERR_GENERAL
lite-fw.h, 1141
eSDP_FWDWL_ERR_INVALID_DEV
lite-fw.h, 1141
eSDP_FWDWL_ERR_INVALID_PATH
lite-fw.h, 1141
eSDP_FWDWL_ERR_PATH_NOT_SPECIFIED
lite-fw.h, 1141
eSDP_FWDWL_ERR_PATH_TOO_LONG
lite-fw.h, 1141
eSDP_FWDWL_ERR_PRI_FAIL
lite-fw.h, 1141
eSDP_FWDWL_ERR_SDK
lite-fw.h, 1141
eSDP_FWDWL_ERR_SDP_TIMEOUT
lite-fw.h, 1141
eSDP_FWDWL_ERR_SET_CBK
lite-fw.h, 1141
eSDP_FWDWL_ERR_TIMEOUT
lite-fw.h, 1141
eSDP_FWDWL_SUCCESS
lite-fw.h, 1141
eSMS
common.h, 1054
eSWIAUDIO
common.h, 1054
eSWIDMS
common.h, 1054
eSWILOC
common.h, 1054
eSWIM2MCMD
common.h, 1054
eSWIM2MCMD_AVC2
common.h, 1054
eSWIOMA
common.h, 1054
eSWIOMAEXT
common.h, 1054
eTIMEOUT_10_S
common.h, 1054
eTIMEOUT_20_S
common.h, 1054
eTIMEOUT_2_S
common.h, 1054
eTIMEOUT_300_S
common.h, 1054
eTIMEOUT_30_S
common.h, 1054
eTIMEOUT_5_S
common.h, 1054
eTIMEOUT_60_S
common.h, 1054
eTIMEOUT_8_S
common.h, 1054
eTIMEOUT_DEFAULT
common.h, 1054
eTMD
common.h, 1054
eUIM
common.h, 1054
eVOICE
common.h, 1054
eWDS
common.h, 1053
eWDS_ERR_PROFILE_REG_3GPP2_ERR_INVALID_IDENT_FOR_PROFILE
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_3GPP_ACCESS_ERR
qmerrno.h, 1298

eWDS_ERR_PROFILE_REG_3GPP_CONTEXT_NOT_DEFINED
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_3GPP_ERR_OUT_OF_PROFILES
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_3GPP_INVAL_PROFILE_FAMILY
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_3GPP_READ_ONLY_FLAG_SET
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_3GPP_VALID_FLAG_NOT_SET
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_END
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_INVAL_PROFILE_FAMILY
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_HNDL
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_IDENT
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_OP
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_NUM
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_TYPE
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_SUBS_ID
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_LEN_INVALID
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_LIB_NOT_INITED
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_RESULT_FAIL
qmerrno.h, 1298
eWDS_ERR_PROFILE_REG_RESULT_LIST_END
qmerrno.h, 1298
EAWTlv
unpack_ims_SLQSVoIPCfgCallBack_ind_t, 655
ECIOThresListLen
nas_ECIOThresh, 170
ECTCallState
voice_ECTNum, 1001
eLOG_LEVEL
common.h, 1053
EMTlv
NASQmiCbkNasSystemSelPrefInd, 304
eQCWWANError
qmerrno.h, 1293
eQMI_SVC
common.h, 1053
ERI_DATA_MAX_SIZE
dms.h, 1065
ESATlv
unpack_ims_SLQSVoIPCfgCallBack_ind_t, 655
ESAWTlv
unpack_ims_SLQSVoIPCfgCallBack_ind_t, 655
ESNString
unpack_dms_GetDeviceSerialNumbers_t, 584
ETWSPLMNInfo
eTWSPLMNInfoTlv, 65
eTWSPLMNInfoTlv, 65
ETWSPLMNInfo, 65
TlvPresent, 65
ETWSPLMNTlv
unpack_sms_SetNewSMSCallback_ind_t, 812
ETWSTlv
unpack_sms_SetNewSMSCallback_ind_t, 813
eTimeout
common.h, 1054
eValid
LibPackTFTIDParams, 119
EarMute
pack_audio_SLQSSetAudioProfile_t, 313
pack_swiaudio_SLQSSetM2MAVMute_t, 428
unpack_audio_SLQSGetAudioProfile_t, 568
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 829
unpack_swiaudio_SLQSGetM2MAVMute_t, 831
earfcn
nas_infoInterFreq, 191
nas_LTEInfoIntrafreq, 201
nas_ltePCI, 208
nas_umtsLTENbrCell, 282
earfcn0
nas_lteEARFCN, 195
earfcn1
nas_lteEARFCN, 195
earlyWakeupTime
dms_PSMEarlyWakeupTimeTlv, 56
ecio
cdmaSSInfo, 49
hdrSSInfo, 70
nas_ecioListElement, 169
nas_rxInfo, 259
nas_UMTSInfo, 280
tdscdmaSigInfoExt, 538
ecioDelta
nas_SLQSSignalStrengthsIndReq, 266
ecioInfo
nas_SLQSSignalStrengthsInformation, 268
ecioList
unpack_nas_SLQSGetSignalStrength_t, 725

ecioListLen
unpack_nas_SLQSGetSignalStrength_t, 725
ecioThresholdList
nas_SLQSSignalStrengthsIndReq, 266
ecioThresholdListLen
nas_SLQSSignalStrengthsIndReq, 266
edrxCiotLteModeTlv
unpack_nas_SLQSNasEdrxChangeInfoCallBack_-Ind_t, 738
edrxCycleLengthTlv
unpack_nas_SLQSNasEdrxChangeInfoCallBack_-Ind_t, 738
edrxEnableTypeTlv
unpack_nas_SLQSNasEdrxChangeInfoCallBack_-Ind_t, 738
edrxEnabled
nas_EdrxEnableType, 172
edrxPagingTimeWindowTlv
unpack_nas_SLQSNasEdrxChangeInfoCallBack_-Ind_t, 738
edrxPtw
nas_EdrxPagingTimeWindow, 172
edrxRatType
nas_EdrxRatType, 173
edrxRatTypeTlv
unpack_nas_SLQSNasEdrxChangeInfoCallBack_-Ind_t, 738
egprsSupp
nas_GSMSysInfo, 183
egprsSuppValid
nas_GSMSysInfo, 183
ehrpdMTUSize
swidms_ehrpdMTUSizeTlv, 534
elevation
loc_satelliteInfo, 137
EmerMode
nas_EmerModeTlv, 174
NASEmergencyModeTlv, 292
emmConnState
nas_LTEInfo, 198
emmState
nas_LTEInfo, 198
emmSubState
nas_LTEInfo, 198
Enable
pack_swiaudio_SLQSSetM2MAudioLPBK_t, 425
enable
pack_pds_SetPDSState_t, 401
pack_qos_SLQSSetQosEventCallback_t, 412
EnableState
unpack_dms_PSMCfgChange_ind_t, 600
enableState
dms_PSMEnableStateTlv, 57
EnableStateInd
dms_PSMEnableStateIndTlv, 56
enabled
pack_rms_SetSMSWake_t, 412
unpack_rms_GetSMSWake_t, 807
unpack_wds_GetMobileIPProfile_t, 925
EnabledStatus
unpack_pds_SetPdsState_Ind_t, 777
EncryptProt
nas_protocolSubtypeElement, 240
EncryptedPIN1
pack_uim_ChangePin_t, 445
pack_uim_SetPinProtection_t, 447
pack_uim_UnblockPin_t, 455
EndPointType
qos_BindDataPortPeripheralEndPointID_t, 508
EndProactiveSession
cat_EndProactiveSessionTlv, 47
EngineState
unpack_pds_SLQSGetGPSStateInfo_t, 782
engineState
unpack_loc_EngineState_Ind_t, 672
eqmiCbkSetStatus
sms.h, 1316
eriData
eriDataparams, 65
eriDataLen
eriDataparams, 65
eriDataparams, 64
eriData, 65
eriDataLen, 65
eriFile
unpack_dms_SLQSGetERIFile_t, 618
error
unpack_wds_GetLastMobileIPError_t, 922
errorClass
unpack_sms_SLQSWmsAsyncRawSendCallBack-_ind_t, 827
ErrorCode
imsa_IMSRegStatusErrorCodeInfo, 85
ErrorCodeData
imsa_RatHandoverStatusInfo, 87
ErrorCodeLen
imsa_RatHandoverStatusInfo, 87
errorMask
unpack_cat_SetCATEventCallback_t, 571
errorRate
nas_errorRateListElement, 175
errorRateInfo
nas_SLQSSignalStrengthsInformation, 268
errorRateList
unpack_nas_SLQSGetSignalStrength_t, 725
errorRateListLen
unpack_nas_SLQSGetSignalStrength_t, 725
errorState
slotInf, 514
uim_slotInfo, 563
esn
unpack_dms_GetSerialNumbers_t, 596
esnSize
unpack_dms_GetDeviceSerialNumbers_t, 584
EspSpi
unpack_qos_swiQosFilter_t, 799

EtwsMessageInfo
sMSEtwsMessageTlv, 530
event
dms_UimStatusTlv, 60
unpack_qos_SLQSSetQosPriEventCallback_ind_t, 795
unpack_qos_SLQSSetQosStatusCallback_ind_t, 796
event_Index
unpack_cat_SetCatEventCallback_ind_t, 570
EventID
cat_commonEventTlv, 46
EventLength
cat_commonEventTlv, 46
eventMask
pack_cat_SetCATEventCallback_t, 316
pack_uim_SLQSUIMEventRegister_t, 449
unpack_uim_SLQSUIMEventRegister_t, 863
eventRegister
pack_loc_EventRegister_t, 347
eventType
unpack_swioma_SLQSOMADMAlertCallback_ind_t, 848
evrcCapability
voice_prefVoiceSO, 1010
executingImage
FMSImageIDEntries, 68
exponent
unpack_qos_pktErrRate_t, 787
extBit
voice_calledPartySubAdd, 983
extDispInfo
voice_extDispRecInfo, 1001
extDispInfoLen
voice_extDispRecInfo, 1001
ExtErrorCode
PackCreateProfileOut, 501
extPowerState
pack_loc_SetExtPowerState_t, 347
extendedErrorCode
unpack_wds_SLQSDeleteProfile_t, 932

FLOAT
SwiDataTypes.h, 1359
FMSImageElement, 65
buildId, 66
buildIdLength, 66
imageId, 66
imageType, 66
FMSImageIDEntries, 67
executingImage, 68
imageIDElement, 68
imageIDSize, 68
imageType, 68
maxImages, 68
FMSImageIdElement, 66
buildID, 67
buildIDLength, 67
failureCount, 67
imageID, 67
storageIndex, 67
FMSImageList, 68
imageIDEntries, 68
listSize, 68
FMSPrefImageList, 69
listEntries, 69
listSize, 69
FOTAUpdate
pack_swioma_SLQSOMADMSetSettings_t, 441
pack_swioma_SLQSOMADMSetSettingsExt_t, 442
unpack_swioma_SLQSOMADMGetSettings_t, 852
FOTAdownload
pack_swioma_SLQSOMADMSetSettings_t, 441
pack_swioma_SLQSOMADMSetSettingsExt_t, 442
unpack_swioma_SLQSOMADMGetSettings_t, 852
FUMOEnable
pack_swioma_SLQSOMADMSetSettingsExt_t, 442
facility
pack_dms_UIMGetControlKeyStatus_t, 331
pack_dms_UIMSetControlKeyProtection_t, 332
pack_dms_UIMUnblockControlKey_t, 333
facilityCk
pack_dms_UIMSetControlKeyProtection_t, 332
pack_dms_UIMUnblockControlKey_t, 333
facilityState
pack_dms_UIMSetControlKeyProtection_t, 332
unpack_dms_UIMGetControlKeyStatus_t, 632
FailErrCode
unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t, 659
failureCount
FMSImageIdElement, 67
family
pack_wds_GetDefaultProfileNum_t, 476
pack_wds_SetDefaultProfileNum_t, 482
feature
uim_depersonalizationInformation, 549
uim_personalizationStatus, 555
fileID
uim_fileAttributes, 553
uim_fileInfo, 554
fileIndex
pack_uim_ReadTransparent_t, 446
pack_uim_SLQSUIMGetFileAttributes_t, 450
fileSize
uim_fileAttributes, 553
fileType
uim_fileAttributes, 553
fill_pack_ctx
common.h, 1055
fill_sdu_hdr
common.h, 1055
filterId
LibPackTFTIDParams, 119

fix_rate
pack_swiloc_SwiLocSetAutoStart_t, 437
unpack_swiloc_SwiLocGetAutoStart_t, 847
fix_rate_reported
unpack_swiloc_SwiLocGetAutoStart_t, 847
fix_type
pack_swiloc_SwiLocSetAutoStart_t, 437
unpack_swiloc_SwiLocGetAutoStart_t, 847
fix_type_reported
unpack_swiloc_SwiLocGetAutoStart_t, 847
fixAccuracy
pack_pds_StartPDSTrackingSessionExt_t, 409
fixCount
pack_pds_StartPDSTrackingSessionExt_t, 409
fixInterval
pack_pds_StartPDSTrackingSessionExt_t, 409
fixTimeout
pack_pds_StartPDSTrackingSessionExt_t, 409
flags
sensorData_t, 511
flowLabel
LibPackTFTIDParams, 119
fms.h, 1116
GetValidFwPriCombinations, 1117
pack_fms_GetImagesPreference, 1117
pack_fms_GetStoredImages, 1118
pack_fms_SetImagesPreference, 1118
unpack_fms_GetImagesPreference, 1118
unpack_fms_GetStoredImages, 1118
unpack_fms_SetImagesPreference, 1119
Forbidden
nas_QmiNas3GppNetworkInfo, 242
forbiddenNwInstLen
nas_ForbiddenNetworks3GPP, 176
forceFlag
pack_pds_SLQSPDSInjectAbsoluteTimeReference-_t, 404
ForceRev0
unpack_nas_GetCDMANetworkParameters_t, 695
format
sMSTransferRouteMTMessageInfo, 533
ForwardMac
nas_protocolSubtypeElement, 240
fqdnAddr
wds_PCSCFFQDNAddress, 1031
fqdnLen
wds_PCSCFFQDNAddress, 1031
freeSlots
sms_maxStorageSizeResp, 520
freq
nas_PhyCaAggPcellInfo, 229
nas_PhyCaAggScellIndType, 231
nas_PhyCaAggScellInfo, 234
nas_QmisNasSlqsNasPCICellInfo, 244
NASPhyCaAggPcellInfo, 298
NASPhyCaAggScellIndType, 300
NASPhyCaAggScellInfo, 301
freqsLen
nas_LTEInfoInterfreq, 199
nas_LTEInfoNeighboringGSM, 202
nas_LTEInfoNeighboringWCDMA, 203
fromServiceId
sms_BroadcastConfig, 515
function
pack_swiloc_SwiLocSetAutoStart_t, 437
unpack_swiloc_SwiLocGetAutoStart_t, 847
function_reported
unpack_swiloc_SwiLocGetAutoStart_t, 847
FwAutoCheck
unpack_swioma_SLQSOMADMGetSettings_t, 852
FwAutoSDM
unpack_swiavms_SLQSAVMSGetSettings_t, 835
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
FwAvailability
unpack_swioma_SLQSOMADMStartSession_t, 853
FwPromptUpdate
unpack_swiavms_SLQSAVMSGetSettings_t, 836
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
FwPromptdownload
unpack_swiavms_SLQSAVMSGetSettings_t, 835
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
fwdloadsize
unpack_omaDmFotaTlv_t, 768
fwloadComplete
unpack_omaDmFotaTlv_t, 768
fwvers
unpack_dms_SLQSSwiGetFirmwareCurr_t, 623

gDlBitRate
LibPackQosClassID, 117
GPRSGrantedQoS
unpack_wds_SLQSGetRuntimeSettings_t, 945
GPSLPM
pack_dms_SetCustFeature_t, 321
unpack_dms_GetCustFeature_t, 577
GPSSel
pack_dms_SetCustFeature_t, 321
unpack_dms_GetCustFeature_t, 577
GSMRSSIThreshListLen
nas_GSMRSSIThresh, 180
GSMSSInfo
unpack_nas_SLQSNasGetSigInfo_t, 746
gUlBitRate
LibPackQosClassID, 117
GWAOPTlv
NASQmiCbkNasSystemSelPrefInd, 304
GWAcqOrderPref
nas_GWAcqOrderPrefTlv, 184
NASGWAcqOrderPrefTlv, 293
GWAddressV4
unpack_wds_SLQSGetRuntimeSettings_t, 945
gcdumpString
crashInformation, 51

gcdumpStrlen
crashInformation, 51
Generator
pack_audio_SLQSGetAudioProfile_t, 310
pack_audio_SLQSGetAudioVolTLBConfig_t, 310
pack_audio_SLQSSetAudioProfile_t, 313
pack_audio_SLQSSetAudioVolTLBConfig_t, 314
pack_swiaudio_SLQSGetM2MAudioVolume_t, 423
pack_swiaudio_SLQSSetM2MAudioVolume_t, 427
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 829
geoSysIdx
nas_AddCDMASysInfo, 145
nas_AddSysInfo, 145
geranArfcn
nas_geranInstInfo, 178
geranBsicBcc
nas_geranInstInfo, 178
geranBsicNcc
nas_geranInstInfo, 178
geranInst
nas_UMTSInfo, 280
GeranInstInfo
nas_UMTSInfo, 280
geranRssi
nas_geranInstInfo, 178
get_version
common.h, 1055
getAllCallInfo
voice_arrCallInfo, 976
GetAllCallRmtPtyName
voice_arrRemotePartyName, 978
GetCustomFeatureV2
unpack_dms_GetCustFeaturesV2_t, 578
GetValidFwPriCombinations
fms.h, 1117
glo_almanac_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
glo_ephemeris_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
glo_health_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
glo_visible_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
GlobalCellID
nas_QmisNasSlqsNasPCICellInfo, 244
globalCellId
nas_LTEInfoIntrafreq, 201
glog
common.h, 1056
gloglvl
common.h, 1056
gnssSvId
loc_satelliteInfo, 137
gnssSvUsedList
loc_svUsedforFix, 140
gnssSvUsedList_len
loc_svUsedforFix, 140
Gpp2TimeZone
unpack_nas_SLQSGetServingSystem_t, 723
GppNetworkDSTAdjustment
unpack_nas_SLQSGetServingSystem_t, 723
GppTimeZone
unpack_nas_SLQSGetServingSystem_t, 723
gps_almanac_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
gps_ephemeris_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
gps_health_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
gps_visible_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
GpsEnable
pack_dms_SetCustFeature_t, 321
unpack_dms_GetCustFeature_t, 577
gpsTimeOfWeekMs
loc_gpsTime, 129
gpsWeek
loc_gpsTime, 129
grntDownlinkBitrate
LibPackUMTSQoS, 121
wds_UMTSMinQoS, 1037
grntUplinkBitrate
LibPackUMTSQoS, 121
wds_UMTSMinQoS, 1038
gsmAmrStat
voice_curAMRConfig, 998
GsmCellInfo
nas_lteGsmCellInfo, 196
gsmUmtsDl
pack_nas_SLQSNasSwiIndicationRegister_t, 379
gsmUmtsUl
pack_nas_SLQSNasSwiIndicationRegister_t, 379
guaranteedRate
unpack_qos_dataRate_t, 785
gwAddressV6
wds_IPV6GWAddressInfo, 1030
gwV6PrefixLen
wds_IPV6GWAddressInfo, 1030
gyroData
pack_loc_SLQSLOCInjectSensorData_t, 355
gyroTemp
pack_loc_SLQSLOCInjectSensorData_t, 355
gyroTimeSrc
pack_loc_SLQSLOCInjectSensorData_t, 356

HASPI
unpack_wds_GetMobileIPProfile_t, 925
HAState
unpack_wds_GetMobileIPProfile_t, 925
HDOP
loc_precisionDilution, 135
HDRECIOThreshListLen
nas_HDRECIOThresh, 185
HDRIOThreshListLen
nas_HDRIOThresh, 185
HDRRSSIThreshListLen

nas_HDRRSSIThresh, 186
HDRSINRThresListLen
nas_HDRSINRThresh, 187
HDRSINRThreshListLen
nas_HDRSINRThreshold, 188
HDRSSInfo
unpack_nas_SLQSNasGetSigInfo_t, 746
HWVersion
nas_DeviceConfigDetail, 168
HardwareControlledMode
unpack_dms_GetPower_t, 594
has_LpmFlag
unpack_dms_SLQSDmsSwiGetPCInfo_t, 608
has_PdpStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 344
has_PersistentLpm
unpack_dms_SLQSDmsSwiGetPCInfo_t, 608
has_PositionDataNMEA
unpack_pds_SetEventReport_Ind_t, 776
has_PowerOffMode
unpack_dms_SLQSDmsSwiGetPCInfo_t, 608
has_RatHandoverStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 344
has_RegStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 344
has_ServiceStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 344
has_SessionStatus
unpack_pds_SetEventReport_Ind_t, 776
has_Wdisable
unpack_dms_SLQSDmsSwiGetPCInfo_t, 608
has_accelTemp
pack_loc_SLQSLOCInjectSensorData_t, 356
has_acceleroTimeSrc
pack_loc_SLQSLOCInjectSensorData_t, 356
has_accleroData
pack_loc_SLQSLOCInjectSensorData_t, 356
has_altitudeSrcInfo
pack_loc_SLQSLOCInjectPosition_t, 353
has_altitudeWrtEllipsoid
pack_loc_SLQSLOCInjectPosition_t, 353
has_altitudeWrtMeanSeaLevel
pack_loc_SLQSLOCInjectPosition_t, 353
has_confidence
pack_loc_SLQSLOCSetCradleMountConfig_t, 357
has_dLatitude
unpack_pds_SetEventReport_Ind_t, 776
has_dLongitude
unpack_pds_SetEventReport_Ind_t, 776
has_gyroData
pack_loc_SLQSLOCInjectSensorData_t, 356
has_gyroTemp
pack_loc_SLQSLOCInjectSensorData_t, 356
has_gyroTimeSrc
pack_loc_SLQSLOCInjectSensorData_t, 356
has_horConfidence
pack_loc_SLQSLOCInjectPosition_t, 353
has_horReliability
pack_loc_SLQSLOCInjectPosition_t, 353
has_horUncCircular
pack_loc_SLQSLOCInjectPosition_t, 353
has_latitude
pack_loc_SLQSLOCInjectPosition_t, 353
has_longitude
pack_loc_SLQSLOCInjectPosition_t, 353
has_opaqueId
pack_loc_SLQSLOCInjectSensorData_t, 356
has_posSrc
unpack_pds_SetEventReport_Ind_t, 776
has_positionSrc
pack_loc_SLQSLOCInjectPosition_t, 353
has_rawHorConfidence
pack_loc_SLQSLOCInjectPosition_t, 353
has_rawHorUncCircular
pack_loc_SLQSLOCInjectPosition_t, 353
has_serverAddrTypeMask
pack_loc_SLQSLOCGetServer_t, 349
has_timestampAge
pack_loc_SLQSLOCInjectPosition_t, 353
has_timestampUtc
pack_loc_SLQSLOCInjectPosition_t, 353
has_vertConfidence
pack_loc_SLQSLOCInjectPosition_t, 353
has_vertRelicability
pack_loc_SLQSLOCInjectPosition_t, 353
has_vertUnc
pack_loc_SLQSLOCInjectPosition_t, 354
hdrActiveProt
nas_HDRSysInfo, 190
hdrActiveProtValid
nas_HDRSysInfo, 190
hdrHybrid
nas_detailSvcInfo, 167
HdrPersonality
unpack_nas_SLQSGetServingSystem_t, 723
hdrPersonality
nas_HDRSysInfo, 190
NASServingSystemInfo, 307
hdrPersonalityValid
nas_HDRSysInfo, 190
hdrSSInfo, 69
ecio, 70
io, 70
rssi, 70
sinr, 70
hdrSrvStatus
nas_detailSvcInfo, 167
healthStatus
loc_satelliteInfo, 137
helper_get_error_code
common.h, 1055
helper_get_error_reason
common.h, 1055
helper_get_req_str
common.h, 1055
helper_get_resp_ctx

common.h, 1055
helper_get_xid
common.h, 1055
helper_isBootLoader_DebugEnabled
common.h, 1055
helper_set_log_func
common.h, 1056
helper_set_log_lvl
common.h, 1056
homeOrigVoiceSO
voice_prefVoiceSO, 1010
homePageVoiceSO
voice_prefVoiceSO, 1010
horConfidence
pack_loc_SLQSLOCInjectPosition_t, 354
horReliability
pack_loc_SLQSLOCInjectPosition_t, 354
horUncCircular
pack_loc_SLQSLOCInjectPosition_t, 354
HorizontalUncertainty
unpack_pds_SLQSGetGPSStateInfo_t, 783
hotSwap
uim_hotSwapStatus, 554
hotSwapLength
uim_hotSwapStatus, 554
hour
nas_timeInfo, 277
nas_UniversalTime, 283
hrpdMTUSize
swidms_hrpdMTUSizeTlv, 535
hsCallStatus
nas_WCDMASysInfo, 289
hsCallStatusValid
nas_WCDMASysInfo, 289
hsInd
nas_WCDMASysInfo, 289
hsIndValid
nas_WCDMASysInfo, 289
hwType
wds_DHCPv4HWConfig, 1024
wdsDhcpv4HwConfig, 1038
hwVer
unpack_dms_GetHardwareRevision_t, 589

IDTlv
unpack_ims_SLQSUserCfgCallBack_ind_t, 653
iFaceTab
swiaudio_PCMparams, 534
iFaceTabLen
swiaudio_PCMparams, 534
iLTEbandValue
nas_PhyCaAggPcellInfo, 229
nas_PhyCaAggScellInfo, 234
NASPhyCaAggPcellInfo, 298
NASPhyCaAggScellInfo, 301
IMCNflag
unpack_wds_SLQSGetRuntimeSettings_t, 945
IMEIString
unpack_dms_GetDeviceSerialNumbers_t, 584
IMG_MASK_CLEAR
lite-fw.h, 1139
IMG_MASK_GENERIC
lite-fw.h, 1139
IMG_MASK_MDM
lite-fw.h, 1139
IMG_MASK_PRI
lite-fw.h, 1139
IMSInfo
sMSOnIMSTlv, 532
IMSRegistration
unpack_imsa_SLQSImsaRegStatusCallBack_ind_t, 660
IMSRegistrationError
unpack_imsa_SLQSImsaRegStatusCallBack_ind_t, 660
IMSTlv
unpack_sms_SetNewSMSCallback_ind_t, 813
INT32
SwiDataTypes.h, 1359
INT8
SwiDataTypes.h, 1359
IOThresListLen
nas_IOThresh, 192
IPAddress
nas_DataStatusDetail, 165
IPAddressV6
ipv6AddressInfo, 91
wds_IPV6AddressInfo, 1029
IPFamSupport
pack_dms_SetCustFeature_t, 321
unpack_dms_GetCustFeature_t, 577
IPFamilyPreference
pack_wds_SLQSSetIPFamilyPreference_t, 494
unpack_wds_SLQSGetRuntimeSettings_t, 945
IPSECSPI
LibPackTFTIDParams, 119
IPV6AddrInfo
unpack_wds_SLQSGetRuntimeSettings_t, 945
IPV6GWAddrInfo
unpack_wds_SLQSGetRuntimeSettings_t, 945
IPV6PrefixLen
ipv6AddressInfo, 92
wds_IPV6AddressInfo, 1029
IPv4
unpack_wds_SLQSGetRuntimeSettings_t, 945
IPv4Addr
loc_IPv4Config, 131
wds_IPv4AdTlv, 1029
IPv4AddrTlv
unpack_wds_DHCPv4ClientLease_ind_t, 915
IPv4DstAddr
unpack_qos_swiQosFilter_t, 799
IPv4Port
loc_IPv4Config, 131
IPv4SrcAddr
unpack_qos_swiQosFilter_t, 799
IPv4Tos

unpack_qos_swiQosFilter_t, 799
IPv6Addr
loc_IPv6Config, 132
IPv6DstAddr
unpack_qos_swiQosFilter_t, 799
IPv6Label
unpack_qos_swiQosFilter_t, 799
IPv6Port
loc_IPv6Config, 132
IPv6SrcAddr
unpack_qos_swiQosFilter_t, 799
IPv6TrafCls
unpack_qos_swiQosFilter_t, 799
Id
unpack_qos_swiQosFilter_t, 799
id
loc_BdsSV, 124
loc_SV, 139
nas_CSGID, 162
pack_dms_UIMChangePIN_t, 330
pack_dms_UIMSetPINProtection_t, 332
pack_dms_UIMUnblockPIN_t, 334
pack_dms_UIMVerifyPIN_t, 334
unpack_qos_QosFlowInfoState_t, 789
unpack_qos_SLQSSetQosStatusCallback_ind_t, 796
id_length
DMScustSettingInfo, 62
IdleState
nas_protocolSubtypeElement, 240
IfaceID
qos_BindDataPortPeripheralEndPointID_t, 508
image_info_t, 70
buildID, 71
buildIDLen, 71
imageType, 71
uniqueID, 71
imageID
FMSImageIdElement, 67
imageIDElement
FMSImageIDEntries, 68
imageIDEntries
FMSImageList, 68
imageIDSize
FMSImageIDEntries, 68
imageId
FMSImageElement, 66
imageList
unpack_fms_GetStoredImages_t, 638
ImageListSize
unpack_fms_GetImagesPreference_t, 638
imageListSize
pack_fms_SetImagesPreference_t, 336
imageType
FMSImageElement, 66
FMSImageIDEntries, 68
image_info_t, 71
ImageTypes
unpack_fms_SetImagesPreference_t, 639
ImageTypesSize
unpack_fms_SetImagesPreference_t, 639
imagelistSize
unpack_fms_GetStoredImages_t, 638
imei_no
unpack_dms_GetSerialNumbers_t, 596
imeiSize
unpack_dms_GetDeviceSerialNumbers_t, 584
imeiSvnSize
unpack_dms_GetDeviceSerialNumbers_t, 584
ImeiSvnString
unpack_dms_GetDeviceSerialNumbers_t, 584
imeisv_svn
unpack_dms_GetSerialNumbers_t, 596
imgType
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 625
ims.h, 1119
MAX_NAME_LEN, 1121
pack_ims_SLQSGetIMSSMSConfig, 1121
pack_ims_SLQSGetIMSUserConfig, 1121
pack_ims_SLQSGetIMSVoIPConfig, 1122
pack_ims_SLQSGetRegMgrConfig, 1122
pack_ims_SLQSGetSIPConfig, 1123
pack_ims_SLQSImsConfigIndicationRegister, 1123
pack_ims_SLQSSetIMSSMSConfig, 1124
pack_ims_SLQSSetIMSUserConfig, 1124
pack_ims_SLQSSetIMSVoIPConfig, 1125
pack_ims_SLQSSetRegMgrConfig, 1125
pack_ims_SLQSSetSIPConfig, 1125
unpack_ims_SLQSGetIMSSMSConfig, 1126
unpack_ims_SLQSGetIMSUserConfig, 1126
unpack_ims_SLQSGetIMSVoIPConfig, 1127
unpack_ims_SLQSGetRegMgrConfig, 1127
unpack_ims_SLQSGetSIPConfig, 1127
unpack_ims_SLQSImsConfigIndicationRegister, 1128
unpack_ims_SLQSImsConfigIndicationRegister_t, 1121
unpack_ims_SLQSRegMgrCfgCallBack_ind, 1128
unpack_ims_SLQSSIPCfgCallBack_ind, 1130
unpack_ims_SLQSSMSCfgCallBack_ind, 1130
unpack_ims_SLQSSetIMSSMSConfig, 1128
unpack_ims_SLQSSetIMSUserConfig, 1129
unpack_ims_SLQSSetIMSVoIPConfig, 1129
unpack_ims_SLQSSetRegMgrConfig, 1129
unpack_ims_SLQSSetSIPConfig, 1130
unpack_ims_SLQSUserCfgCallBack_ind, 1131
unpack_ims_SLQSVoIPCfgCallBack_ind, 1131
ims_AMRModeInfo, 71
amrMode, 71
TlvPresent, 72
ims_AMROctAlgnInfo, 72
amrOctAlgn, 72
TlvPresent, 72
ims_AMRWBModeInfo, 72
amrWBMode, 73

TlvPresent, 73
ims_AMRWBOctAlgnInfo, 73
amrWBOctAlgn, 73
TlvPresent, 73
ims_CSCFPortNameInfo, 73
cscfPortName, 74
TlvPresent, 74
ims_EnabAMRWBInfo, 74
amrWBEnable, 74
TlvPresent, 74
ims_EnabSCRAMRInfo, 74
scrAmrEnable, 75
TlvPresent, 75
ims_EnabSCRAMRWBInfo, 75
scrAmrWBEnable, 75
TlvPresent, 75
ims_IMSDomainInfo, 75
imsDomainName, 76
TlvPresent, 76
ims_IMSTestModeInfo, 76
imsTestMode, 76
TlvPresent, 76
ims_MinSessExpInfo, 76
minSessExp, 77
TlvPresent, 77
ims_PCSCFPortInfo, 77
priCSCFPort, 77
TlvPresent, 77
ims_PhCtxtURIInfo, 77
PhCtxtURI, 77
TlvPresent, 78
ims_RTPRTCPInactTmrDurInfo, 79
InactTmr, 79
TlvPresent, 79
ims_RngBkTmrInfo, 78
RingBkTmr, 78
TlvPresent, 78
ims_RngTmrInfo, 78
RingTmr, 78
TlvPresent, 79
ims_SIPPortInfo, 80
SIPLocalPort, 80
TlvPresent, 80
ims_SIPRegnTmrInfo, 81
TlvPresent, 81
tmrSIPRegn, 81
ims_SMSFmtInfo, 81
smsFormat, 81
TlvPresent, 81
ims_SMSoIPNwInfo, 82
smsoIPNW, 82
TlvPresent, 82
ims_SessDurInfo, 79
sessExp, 79
TlvPresent, 80
ims_SigCompEnInfo, 80
SigCompEn, 80
TlvPresent, 80
ims_SubscrTmrInfo, 82
subscrTmr, 82
TlvPresent, 82
ims_TmrT1Info, 82
TlvPresent, 83
tmrT1, 83
ims_TmrT2Info, 83
TlvPresent, 83
tmrT2, 83
ims_TmrTfInfo, 83
TlvPresent, 84
tmrTf, 84
imsDomainName
ims_IMSDomainInfo, 76
ImsFailErrCode
imsa_IMSFailErrCodeTlv, 84
ImsRegErrCode
unpack_imsa_SLQSGetIMSARegStatus_t, 656
imsRegState
nas_CommInfo, 161
ImsRegStatus
imsa_NewIMSRegStatusInfo, 86
unpack_imsa_SLQSGetIMSARegStatus_t, 656
ImsRegistered
imsa_IMSRegStatusInfo, 85
imsTestMode
ims_IMSTestModeInfo, 76
imsa.h, 1131
MAX_ERROR_CODE_LEN, 1133
pack_imsa_SLQSGetIMSARegStatus, 1133
pack_imsa_SLQSGetIMSAServiceStatus, 1133
pack_imsa_SLQSRegisterIMSAIndication, 1134
unpack_imsa_SLQSGetIMSARegStatus, 1134
unpack_imsa_SLQSGetIMSAServiceStatus, 1135
unpack_imsa_SLQSImsaPdpStatusCallBack_ind, 1135
unpack_imsa_SLQSImsaRatStatusCallBack_ind, 1135
unpack_imsa_SLQSImsaRegStatusCallBack_ind, 1136
unpack_imsa_SLQSImsaSvcStatusCallBack_ind, 1136
unpack_imsa_SLQSRegisterIMSAIndication, 1137
unpack_imsa_SLQSRegisterIMSAIndication_t, 1133
imsa_IMSFailErrCodeTlv, 84
ImsFailErrCode, 84
TlvPresent, 84
imsa_IMSRegStatusErrorCodeInfo, 84
ErrorCode, 85
TlvPresent, 85
imsa_IMSRegStatusInfo, 85
ImsRegistered, 85
TlvPresent, 85
imsa_NewIMSRegStatusInfo, 86
ImsRegStatus, 86
TlvPresent, 86
imsa_RatHandoverStatusInfo, 86

ErrorCodeData, 87
ErrorCodeLen, 87
RatHandoverStatus, 87
SourceRAT, 87
TargetRAT, 87
TlvPresent, 87
imsa_SmsRatInfo, 87
SmsRatVal, 87
TlvPresent, 88
imsa_SmsSvcStatusInfo, 88
SmsSvcStatus, 88
TlvPresent, 88
imsa_UtRatInfo, 88
TlvPresent, 89
UtRatVal, 89
imsa_UtSvcStatusInfo, 89
TlvPresent, 89
UtSvcStatus, 89
imsa_VoipRatInfo, 89
TlvPresent, 90
VoipRatVal, 90
imsa_VoipSvcStatusInfo, 90
TlvPresent, 90
VoipSvcStatus, 90
imsa_VtRatInfo, 90
TlvPresent, 91
VtRatVal, 91
imsa_VtSvcStatusInfo, 91
TlvPresent, 91
VtSvcStatus, 91
imsi
unpack_dms_GetIMSI_t, 590
imsi_11_12
nas_CDMASysInfoExt, 156
imsiM1112
nas_minBasedIMSI, 218
imsiMS1
nas_minBasedIMSI, 218
imsiMS2
nas_minBasedIMSI, 218
imsiT1112
nas_trueIMSI, 278
imsiTS1
nas_trueIMSI, 278
imsiTS2
nas_trueIMSI, 278
imsiTaddrNum
nas_trueIMSI, 278
InUse
nas_QmiNas3GppNetworkInfo, 242
InactTmr
ims_RTPRTCPInactTmrDurInfo, 79
includes_pcs_digit
nas_QmisNasPcsDigit, 244
index
pack_wds_GetMobileIPProfile_t, 478
pack_wds_SetDefaultProfileNum_t, 482
pack_wds_SetMobileIPProfile_t, 485
unpack_qos_swiQosFilter_t, 799
unpack_qos_swiQosFlow_t, 803
unpack_wds_GetDefaultProfileNum_t, 921
index1xPri
uim_cardStatus, 547
index1xSec
uim_cardStatus, 547
indexGwPri
uim_cardStatus, 547
indexGwSec
uim_cardStatus, 547
Info
unpack_nas_SLQSNasSwiOTAMessageCallback-_ind_t, 755
unpack_nas_SLQSSetSysSelectionPrefCallBack-_ind_t, 756
InfoInterfreq
nas_LTEInfoInterfreq, 199
injectEnable
loc_accelAcceptReady, 123
loc_accelTempAcceptReady, 124
loc_gyroAcceptReady, 130
loc_gyroTempAcceptReady, 131
injectSensorDataStatus
unpack_loc_InjectSensorDataCallback_Ind_t, 678
injectTimeSyncStatus
unpack_loc_InjectTimeSyncDataCallback_Ind_t, 679
insNmrCellInfo
nas_GERANInfo, 177
instancesSize
unpack_nas_GetRFInfo_t, 701
interval
pack_pds_SetPDSDefaults_t, 401
pack_pds_SetXTRAAutomaticDownload_t, 403
pack_wds_SLQSSetWdsEventCallback_t, 495
intf
dms_UimStatusTlv, 60
Io
unpack_nas_SLQSGetSignalStrength_t, 725
io
hdrSSInfo, 70
nas_SLQSSignalStrengthsInformation, 268
ioDelta
nas_SLQSSignalStrengthsIndReq, 267
Iono_valid
unpack_pds_SLQSGetGPSStateInfo_t, 783
ipAddress
pack_wds_SetDefaultProfile_t, 482
ipFamily
unpack_wds_SLQSSetPacketSrvStatusCallback_-t, 949
ipVersion
LibPackTFTIDParams, 119
ipaddr
unpack_wds_GetDefaultProfile_t, 920
ipaddrv6
unpack_wds_GetDefaultProfile_t, 921

ipv4Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 959
ipv4GWAddress
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 959
ipv6Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 959
ipv6AddressInfo, 91
IPAddressV6, 91
IPV6PrefixLen, 92
ipv6GWAddress
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 959
is856SysId
nas_HDRSysInfo, 190
is856SysIdValid
nas_HDRSysInfo, 190
is_DataRate_Available
unpack_qos_swiQosFlow_t, 803
is_EspSpi_Available
unpack_qos_swiQosFilter_t, 799
is_IPv4DstAddr_Available
unpack_qos_swiQosFilter_t, 799
is_IPv4SrcAddr_Available
unpack_qos_swiQosFilter_t, 799
is_IPv4Tos_Available
unpack_qos_swiQosFilter_t, 799
is_IPv6DstAddr_Available
unpack_qos_swiQosFilter_t, 799
is_IPv6Label_Available
unpack_qos_swiQosFilter_t, 799
is_IPv6SrcAddr_Available
unpack_qos_swiQosFilter_t, 799
is_IPv6TrafCls_Available
unpack_qos_swiQosFilter_t, 799
is_Id_Available
unpack_qos_swiQosFilter_t, 799
is_Jitter_Available
unpack_qos_swiQosFlow_t, 803
is_Latency_Available
unpack_qos_swiQosFlow_t, 803
is_LteBandCapability_Available
unpack_dms_SLQSGetBandCapability_t, 617
is_LteQci_Available
unpack_qos_swiQosFlow_t, 803
is_MaxAllowedPktSz_Available
unpack_qos_swiQosFlow_t, 803
is_MinPolicedPktSz_Available
unpack_qos_swiQosFlow_t, 803
is_NxtHdrProto_Available
unpack_qos_swiQosFilter_t, 799
is_PktErrRate_Available
unpack_qos_swiQosFlow_t, 803
is_Precedence_Available
unpack_qos_swiQosFilter_t, 799
is_ProfileId3GPP2_Available
unpack_qos_swiQosFlow_t, 803
is_RxQFlowGranted_Available
unpack_qos_QosFlowInfo_t, 788
is_TCPDstPort_Available
unpack_qos_swiQosFilter_t, 799
is_TCPSrcPort_Available
unpack_qos_swiQosFilter_t, 799
is_TdsBandCapability_Available
unpack_dms_SLQSGetBandCapability_t, 617
is_TokenBucket_Available
unpack_qos_swiQosFlow_t, 803
is_TrafficClass_Available
unpack_qos_swiQosFlow_t, 803
is_TranDstPort_Available
unpack_qos_swiQosFilter_t, 800
is_TranSrcPort_Available
unpack_qos_swiQosFilter_t, 800
is_TxQFlowGranted_Available
unpack_qos_QosFlowInfo_t, 788
is_UDPDstPort_Available
unpack_qos_swiQosFilter_t, 800
is_UDPSrcPort_Available
unpack_qos_swiQosFilter_t, 800
is_val_3GPP2Pri_Available
unpack_qos_swiQosFlow_t, 803
is_val_3GPPImCn_Available
unpack_qos_swiQosFlow_t, 803
is_val_3GPPResResidualBER_Available
unpack_qos_swiQosFlow_t, 803
is_val_3GPPSigInd_Available
unpack_qos_swiQosFlow_t, 803
is_val_3GPPTraHdlPri_Available
unpack_qos_swiQosFlow_t, 803
isEmpty
voice_getAllCallInformation, 1002
isInTraffic
nas_txInfo, 278
isModByCC
voice_SUPSInfo, 1015
isNewFlow
unpack_qos_QosFlowInfoState_t, 789
isPrefDataPath
nas_GSMSrvStatusInfo, 181
nas_SrvStatusInfo, 270
isRadioTuned
nas_rxInfo, 259
nas_RxSigInfo, 260
isSysForbidden
nas_detailSvcInfo, 167
nas_sysInfoCommon, 272
isSysForbiddenValid
nas_sysInfoCommon, 272
isSysPrlMatch
nas_CDMASysInfo, 155
nas_HDRSysInfo, 190
isSysPrlMatchValid
nas_CDMASysInfo, 155
nas_HDRSysInfo, 190

IsVoiceEnabled
pack_dms_SetCustFeature_t, 321
unpack_dms_GetCustFeature_t, 577
Item
pack_audio_SLQSGetAudioPathConfig_t, 309
pack_audio_SLQSGetAudioVolTLBConfig_t, 310
pack_audio_SLQSSetAudioVolTLBConfig_t, 314

Jitter
unpack_qos_swiQosFlow_t, 803

KeyExchange
nas_protocolSubtypeElement, 240

LITE_SYS_SRV_DOMAIN_CAMPED
nas.h, 1181
LITE_SYS_SRV_DOMAIN_CS_ONLY
nas.h, 1181
LITE_SYS_SRV_DOMAIN_CS_PS
nas.h, 1181
LITE_SYS_SRV_DOMAIN_NO_SRV
nas.h, 1181
LITE_SYS_SRV_DOMAIN_PS_ONLY
nas.h, 1181
LITE_VOICE_SUPS_SRV_CLASS_DATA
voice.h, 1413
LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITAS-
YNC
voice.h, 1413
LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITSY-
NC
voice.h, 1413
LITE_VOICE_SUPS_SRV_CLASS_FAX
voice.h, 1413
LITE_VOICE_SUPS_SRV_CLASS_NONE
voice.h, 1413
LITE_VOICE_SUPS_SRV_CLASS_PACKETACCESS
voice.h, 1413
LITE_VOICE_SUPS_SRV_CLASS_PADACCESS
voice.h, 1413
LITE_VOICE_SUPS_SRV_CLASS_SMS
voice.h, 1413
LITE_VOICE_SUPS_SRV_CLASS_VOICE
voice.h, 1413
LITEQMI_QMI_CBK_PARAM_NOCHANGE
sms.h, 1316
LITEQMI_QMI_CBK_PARAM_RESET
sms.h, 1316
LITEQMI_QMI_CBK_PARAM_SET
sms.h, 1316
LBPTlv
NASQmiCbkNasSystemSelPrefInd, 304
LMCERTlv
unpack_wds_SLQSDUNCallInfoCallBack_ind_t,
934
LOCEVENTMASKGNSSSVINFO
loc.h, 1151
LOCEVENTMASKNMEA
loc.h, 1152
LOCEVENTMASKWIFIREQ
loc.h, 1153
LPCSTR
SwiDataTypes.h, 1359
LTEAttachProfile
unpack_wds_SLQSGet3GPPConfigItem_t, 935
LTEAttachProfileList
unpack_wds_SLQSGet3GPPConfigItem_t, 936
LTEAttachProfileListLen
pack_wds_SLQSSet3GPPConfigItem_t, 493
unpack_wds_SLQSGet3GPPConfigItem_t, 936
LTEBandPref
nas_LTEBandPrefTlv, 194
NASLTEBandPreferenceTlv, 294
LTECphyCaInfo
unpack_nas_SlqsGetLTECphyCAInfo_t, 714
LTERSRPThreshListLen
nas_LTERSRPThresh, 209
LTERSRQThreshListLen
nas_LTERSRQThresh, 210
LTERSSIThreshListLen
nas_LTERSSIThresh, 210
LTESNRThresListLen
nas_LTESNRThresh, 213
LTESNRThreshListLen
nas_LTESNRThreshold, 214
LTESSInfo
unpack_nas_SLQSNasGetSigInfo_t, 746
LTEWCDMACellInfo
nas_LTEInfoNeighboringWCDMA, 203
Lac
unpack_nas_SLQSGetServingSystem_t, 723
lac
nas_GERANInfo, 177
nas_GSMSysInfo, 183
nas_LTESysInfo, 216
nas_UMTSInfo, 280
nas_WCDMASysInfo, 289
lac1
nas_OperatorPLMNData, 228
lac2
nas_OperatorPLMNData, 228
lacValid
nas_GSMSysInfo, 183
nas_LTESysInfo, 216
nas_WCDMASysInfo, 289
language
sms_CDMABroadcastConfig, 516
lastCallDataBearerTech
unpack_wds_SLQSGetDUNCallInfo_t, 941
lastCallDataBearerTechnology
unpack_wds_SLQSGetDataBearerTechnology_t,
939
lastCallRXOKBytesCnt
unpack_wds_SLQSGetDUNCallInfo_t, 941
lastCallTXOKBytesCnt
unpack_wds_SLQSGetDUNCallInfo_t, 941
LastErrCode

nas_DataStatusDetail, 165
Latency
unpack_qos_swiQosFlow_t, 803
Latitude
unpack_pds_SLQSGetGPSStateInfo_t, 783
latitude
pack_loc_SLQSLOCInjectPosition_t, 354
leapSeconds
nas_qaQmi3Gpp2TimeZone, 241
leaseState
wds_DHCPLeaseStateTlv, 1022
len
loc_BdsSVInfo, 125
loc_SVInfo, 139
unpack_nas_GetSignalStrengths_t, 705
length
sMSCAddressInfo, 528
sMSEtwsMessageInfo, 529
sMSTransferRouteMTMessageInfo, 533
uim_readTransparentInfo, 556
Level
pack_swiaudio_SLQSSetM2MAudioVolume_t, 427
unpack_swiaudio_SLQSGetM2MAudioVolume_t, 830
LibPackGPRSRequestedQoS, 92
delayClass, 92
meanThroughputClass, 92
peakThroughputClass, 92
precedenceClass, 92
reliabilityClass, 92
LibPackQosClassID, 116
gDlBitRate, 117
gUlBitRate, 117
maxDlBitRate, 117
maxUlBitRate, 117
QCI, 117
LibPackTFTIDParams, 117
destPortRangeEnd, 119
destPortRangeStart, 119
eValid, 119
filterId, 119
flowLabel, 119
IPSECSPI, 119
ipVersion, 119
nextHeader, 119
pSourceIP, 119
sourceIPMask, 119
srcPortRangeEnd, 119
srcPortRangeStart, 119
tosMask, 119
LibPackUMTSQoS, 119
deliveryErrSDU, 121
grntDownlinkBitrate, 121
grntUplinkBitrate, 121
maxDownlinkBitrate, 121
maxSDUSize, 121
maxUplinkBitrate, 121
qosDeliveryOrder, 121
resBerRatio, 122
sduErrorRatio, 122
trafficClass, 122
trafficPriority, 122
transferDelay, 122
LibPackUMTSReqQoSSigInd, 122
SigInd, 122
UMTSReqQoS, 122
LibPackprofile_3GPP, 105
pAPNClass, 110
pAPNDisabledFlag, 110
pAPNName, 110
pAPNnameSize, 110
pAddrAllocPref, 110
pAuthenticationPref, 110
pGPRSMinimumQoS, 110
pGPRSRequestedQos, 110
pIPv4AddrPref, 110
pIPv6AddPref, 110
pImCnFlag, 110
pPDNInactivTimeout, 110
pPDPtype, 111
pPassword, 110
pPasswordSize, 110
pPcscfAddrUsingDhcp, 110
pPcscfAddrUsingPCO, 110
pPdpAccessConFlag, 110
pPdpContext, 110
pPdpDataCompType, 110
pPdpHdrCompType, 110
pPriDNSIPv4AddPref, 111
pPriDNSIPv6addpref, 111
pPrimaryID, 111
pProfilename, 111
pProfilenameSize, 111
pQosClassID, 111
pSecDNSIPv4AddPref, 111
pSecDNSIPv6addpref, 111
pSecondaryFlag, 111
pSupportEmergencyCalls, 111
pTFTID1Params, 111
pTFTID2Params, 111
pUMTSMinQoS, 111
pUMTSMinQosSigInd, 111
pUMTSReqQoS, 111
pUMTSReqQoSSigInd, 111
pUsername, 111
pUsernameSize, 111
LibPackprofile_3GPP2, 111
pAPNClass3GPP2, 115
pAPNEnabled3GPP2, 115
pAllowLinger, 115
pApnString, 115
pApnStringSize, 115
pAppPriority, 116
pAppType, 116
pAuthPassword, 116
pAuthPassword_tSize, 116

pAuthProtocol, 116
pAuthRetryCount, 116
pAuthTimeout, 116
pDataMode, 116
pDataRate, 116
pIpcpAckTimeout, 116
pIpcpCreqRetryCount, 116
pIsPcscfAddressNedded, 116
pLcpAckTimeout, 116
pLcpCreqRetryCount, 116
pNegoDnsSrvrPref, 116
pPDNInactivTimeout3GPP2, 116
pPdnType, 116
pPppSessCloseTimer1x, 116
pPppSessCloseTimerDO, 116
pPriV6DnsAddress, 116
pPrimaryV4DnsAddress, 116
pRATType, 116
pSecV6DnsAddress, 116
pSecondaryV4DnsAddress, 116
pUserId, 116
pUserIdSize, 116
libSDP_BuildImagesPreferenceRequest
lite-fw.h, 1139
libSDP_CalculateImageMask
lite-fw.h, 1139
libSDP_CheckValidFirmwareInfo
lite-fw.h, 1139
libSDP_DownloadFW
lite-fw.h, 1139
libSDP_ExtractFirmwareParametersByPath
lite-fw.h, 1139
libSDP_FirmwareInfo
lite-fw.h, 1140
libSDP_GetModelFamily
lite-fw.h, 1139
libSDP_GetVersion
lite-fw.h, 1140
libSDP_getFileType
lite-fw.h, 1139
LibpackProfile3GPP, 92
pAPNClass, 98
pAPNDisabledFlag, 98
pAPNName, 98
pAPNnameSize, 98
pAddrAllocPref, 98
pAuthenticationPref, 98
pGPRSMinimumQoS, 98
pGPRSRequestedQos, 98
pIPv4AddrPref, 98
pIPv6AddPref, 98
pImCnFlag, 98
pPDNInactivTimeout, 98
pPDPtype, 99
pPassword, 98
pPasswordSize, 98
pPcscfAddrUsingDhcp, 98
pPcscfAddrUsingPCO, 98
pPdpAccessConFlag, 98
pPdpContext, 98
pPdpDataCompType, 98
pPdpHdrCompType, 99
pPriDNSIPv4AddPref, 99
pPriDNSIPv6addpref, 99
pPrimaryID, 99
pProfilename, 99
pProfilenameSize, 99
pQosClassID, 99
pSecDNSIPv4AddPref, 99
pSecDNSIPv6addpref, 99
pSecondaryFlag, 99
pSupportEmergencyCalls, 99
pTFTID1Params, 99
pTFTID2Params, 99
pUMTSMinQoS, 99
pUMTSMinQosSigInd, 99
pUMTSReqQoS, 99
pUMTSReqQoSSigInd, 99
pUsername, 99
pUsernameSize, 99
LibpackProfile3GPP2, 99
pAPNClass3GPP2, 104
pAPNEnabled3GPP2, 104
pAllowLinger, 104
pApnString, 104
pApnStringSize, 104
pAppPriority, 104
pAppType, 104
pAuthPassword, 104
pAuthPasswordSize, 104
pAuthProtocol, 104
pAuthRetryCount, 104
pAuthTimeout, 104
pDataMode, 104
pDataRate, 105
pIpcpAckTimeout, 105
pIpcpCreqRetryCount, 105
pIsPcscfAddressNedded, 105
pLcpAckTimeout, 105
pLcpCreqRetryCount, 105
pNegoDnsSrvrPref, 105
pPDNInactivTimeout3GPP2, 105
pPdnType, 105
pPppSessCloseTimer1x, 105
pPppSessCloseTimerDO, 105
pPriV6DnsAddress, 105
pPrimaryV4DnsAddress, 105
pRATType, 105
pSecV6DnsAddress, 105
pSecondaryV4DnsAddress, 105
pUserId, 105
pUserIdSize, 105
libsdp_SetReadBlockSize
lite-fw.h, 1140
libsdp_set_log_func
lite-fw.h, 1140

libsdplogger
lite-fw.h, 1140
lineValue
pack_voice_SLQSVoiceALSSelectLine_t, 458
linkage
altSrcInfo_t, 35
list_type
DMScustSettingList, 62
DMSgetCustomInput, 64
pack_dms_GetCustFeaturesV2_t, 317
listEntries
FMSPrefImageList, 69
listSize
FMSImageList, 68
FMSPrefImageList, 69
lite-fw.h
eFIREHOSE_ERR_SECBOOT_INVALID_CERT_-CHAIN, 1141
eFW_TYPE_CWE, 1141
eFW_TYPE_CWE_NVU, 1141
eFW_TYPE_INVALID, 1141
eFW_TYPE_MBN, 1141
eFW_TYPE_MBN_GOBI, 1141
eFW_TYPE_NVU, 1141
eFW_TYPE_SPK, 1141
eModel_9X15, 1142
eModel_9X30, 1142
eModel_9x06, 1142
eModel_9x07, 1142
eModel_Unknown, 1142
eModel_WP9X15, 1142
eQDL_HW_FLOW_DISABLE, 1142
eQDL_HW_FLOW_ENABLE, 1142
eQDL_HW_FLOW_INIT, 1142
eQDL_HW_FLOW_Unknown, 1142
eQDL_MODE_INIT, 1142
eQDL_MODE_TTYUSB, 1142
eQDL_MODE_UART0, 1142
eQDL_MODE_Unknown, 1142
eSDP_FWDWL_ERR_END, 1141
eSDP_FWDWL_ERR_FAIL, 1141
eSDP_FWDWL_ERR_FW_UPGRADE, 1141
eSDP_FWDWL_ERR_FW_VERSION_FAIL, 1141
eSDP_FWDWL_ERR_GENERAL, 1141
eSDP_FWDWL_ERR_INVALID_DEV, 1141
eSDP_FWDWL_ERR_INVALID_PATH, 1141
eSDP_FWDWL_ERR_PATH_NOT_SPECIFIED, 1141
eSDP_FWDWL_ERR_PATH_TOO_LONG, 1141
eSDP_FWDWL_ERR_PRI_FAIL, 1141
eSDP_FWDWL_ERR_SDK, 1141
eSDP_FWDWL_ERR_SDP_TIMEOUT, 1141
eSDP_FWDWL_ERR_SET_CBK, 1141
eSDP_FWDWL_ERR_TIMEOUT, 1141
eSDP_FWDWL_SUCCESS, 1141
lite-fw.h, 1137
IMG_MASK_CLEAR, 1139
IMG_MASK_GENERIC, 1139
IMG_MASK_MDM, 1139
IMG_MASK_PRI, 1139
libSDP_BuildImagesPreferenceRequest, 1139
libSDP_CalculateImageMask, 1139
libSDP_CheckValidFirmwareInfo, 1139
libSDP_DownloadFW, 1139
libSDP_ExtractFirmwareParametersByPath, 1139
libSDP_FirmwareInfo, 1140
libSDP_GetModelFamily, 1139
libSDP_GetVersion, 1140
libSDP_getFileType, 1139
libsdp_SetReadBlockSize, 1140
libsdp_set_log_func, 1140
libsdplogger, 1140
litefw_BuildImagesPreferenceRequest, 1142
litefw_CalculateImageMask, 1142
litefw_CheckValidFirmwareInfo, 1143
litefw_DownloadFW, 1143
litefw_ExtractFirmwareParametersByPath, 1144
litefw_FirmwareInfo, 1140
litefw_Fw_Type, 1141
litefw_GetModelFamily, 1144
litefw_GetQTLDownloadMode, 1145
litefw_GetQTLHWFlowControl, 1145
litefw_GetVersion, 1145
litefw_Models, 1141
litefw_QDL_FLOW_CONTROLs, 1142
litefw_QDL_MODEs, 1142
litefw_SetQTLDownloadMode, 1146
litefw_SetQTLHWFlowControl, 1146
litefw_SetReadBlockSize, 1146
litefw_fwdwl_error_codes, 1141
litefw_getFileType, 1144
litefw_logsenable, 1145
litefw_set_log_func, 1145
litefw_switch_9x07_to_downloadmode, 1146
litefw_switch_to_BootHoldMode, 1147
litefwlogger, 1140
liteQmiDataBearerMasks
wds.h, 1447
liteServiceClassInformation
voice.h, 1412
litefw_BuildImagesPreferenceRequest
lite-fw.h, 1142
litefw_CalculateImageMask
lite-fw.h, 1142
litefw_CheckValidFirmwareInfo
lite-fw.h, 1143
litefw_DownloadFW
lite-fw.h, 1143
litefw_ExtractFirmwareParametersByPath
lite-fw.h, 1144
litefw_FirmwareInfo
lite-fw.h, 1140
litefw_Fw_Type
lite-fw.h, 1141
litefw_GetModelFamily
lite-fw.h, 1144

litefw_GetQTLDownloadMode
lite-fw.h, 1145
litefw_GetQTLHWFlowControl
lite-fw.h, 1145
litefw_GetVersion
lite-fw.h, 1145
litefw_Models
lite-fw.h, 1141
litefw_QDL_FLOW_CONTROLs
lite-fw.h, 1142
litefw_QDL_MODEs
lite-fw.h, 1142
litefw_SetQTLDownloadMode
lite-fw.h, 1146
litefw_SetQTLHWFlowControl
lite-fw.h, 1146
litefw_SetReadBlockSize
lite-fw.h, 1146
litefw_fwdwl_error_codes
lite-fw.h, 1141
litefw_getFileType
lite-fw.h, 1144
litefw_logsenable
lite-fw.h, 1145
litefw_set_log_func
lite-fw.h, 1145
litefw_switch_9x07_to_downloadmode
lite-fw.h, 1146
litefw_switch_to_BootHoldMode
lite-fw.h, 1147
litefwlogger
lite-fw.h, 1140
liteqmi_GetVersion
common.h, 1056
liteqmi_helper_decode7bitAsciiEncString
common.h, 1056
liteqmi_log
common.h, 1056
loc.h
eQMI_LOC_SESS_STATUS_FAILURE, 1153
eQMI_LOC_SESS_STATUS_IN_PROGRESS, 1153
eQMI_LOC_SESS_STATUS_SUCCESS, 1153
eQMI_LOC_SESS_STATUS_TIMEOUT, 1153
loc.h, 1147
LOCEVENTMASKNMEA, 1152
LOCEVENTMASKWIFIREQ, 1153
MAX_TEMP_DATA_LEN, 1153
pack_loc_DeleteAssistData, 1154
pack_loc_EventRegister, 1154
pack_loc_SLQSLOCGetBestAvailPos, 1155
pack_loc_SLQSLOCGetServer, 1155
pack_loc_SLQSLOCInjectPosition, 1156
pack_loc_SLQSLOCInjectSensorData, 1156
pack_loc_SLQSLOCInjectUTCTime, 1157
pack_loc_SLQSLOCSetCradleMountConfig, 1157
pack_loc_SLQSLOCSetServer, 1157
pack_loc_SetExtPowerState, 1154
pack_loc_SetOperationMode, 1155
pack_loc_Start, 1158
pack_loc_Stop, 1158
unpack_loc_BestAvailPos_Ind, 1159
unpack_loc_CradleMountCallback_Ind, 1159
unpack_loc_DeleteAssistData, 1159
unpack_loc_DeleteAssistData_Ind, 1160
unpack_loc_EngineState_Ind, 1160
unpack_loc_EventNMEA_Ind, 1160
unpack_loc_EventRegister, 1161
unpack_loc_EventTimeSyncCallback_Ind, 1161
unpack_loc_GetServer_Ind, 1161
unpack_loc_GnssSvInfo_Ind, 1162
unpack_loc_InjectPositionCallback_Ind, 1162
unpack_loc_InjectSensorDataCallback_Ind, 1162
unpack_loc_InjectTimeSyncDataCallback_Ind, 1163
unpack_loc_InjectUTCTimeCallback_Ind, 1163
unpack_loc_PositionRpt_Ind, 1163
unpack_loc_SLQSLOCGetBestAvailPos, 1166
unpack_loc_SLQSLOCGetServer, 1166
unpack_loc_SLQSLOCGetServer_t, 1153
unpack_loc_SLQSLOCInjectPosition, 1166
unpack_loc_SLQSLOCInjectPosition_t, 1153
unpack_loc_SLQSLOCInjectSensorData, 1167
unpack_loc_SLQSLOCInjectSensorData_t, 1153
unpack_loc_SLQSLOCInjectUTCTime, 1167
unpack_loc_SLQSLOCInjectUTCTime_t, 1153
unpack_loc_SLQSLOCSetCradleMountConfig, 1167
unpack_loc_SLQSLOCSetCradleMountConfig_t, 1153
unpack_loc_SLQSLOCSetServer, 1168
unpack_loc_SensorStreamingCallback_Ind, 1164
unpack_loc_SetExtPowerConfig_Ind, 1164
unpack_loc_SetExtPowerState, 1164
unpack_loc_SetOperationMode, 1165
unpack_loc_SetOperationMode_Ind, 1165
unpack_loc_SetServer_Ind, 1165
unpack_loc_Start, 1168
unpack_loc_Stop, 1168
loc_BdsSV, 124
id, 124
mask, 124
loc_BdsSVInfo, 124
len, 125
pSV, 125
loc_CellDb, 125
mask, 126
loc_ClkInfo, 126
mask, 127
loc_GnssData, 127
mask, 128
loc_IPv4Config, 131
IPv4Addr, 131
IPv4Port, 131
loc_IPv4Info, 131
address, 132

port, 132
TlvPresent, 132
loc_IPv6Config, 132
IPv6Addr, 132
IPv6Port, 132
loc_IPv6Info, 132
address, 133
port, 133
TlvPresent, 133
loc_LocApplicationInfo, 133
appNameLength, 134
appProviderLength, 134
appVersionLength, 134
appVersionValid, 134
pAppName, 134
pAppProvider, 134
pAppVersion, 134
loc_SV, 138
id, 139
mask, 139
system, 139
loc_SVInfo, 139
len, 139
pSV, 139
loc_URLAddrInfo, 140
urlAddr, 141
loc_accelAcceptReady, 122
batchPerSec, 123
injectEnable, 123
samplesPerBatch, 123
loc_accelTempAcceptReady, 123
batchPerSec, 124
injectEnable, 124
samplesPerBatch, 124
loc_gpsTime, 129
gpsTimeOfWeekMs, 129
gpsWeek, 129
loc_gyroAcceptReady, 129
batchPerSec, 130
injectEnable, 130
samplesPerBatch, 130
loc_gyroTempAcceptReady, 130
batchPerSec, 131
injectEnable, 131
samplesPerBatch, 131
loc_precisionDilution, 134
HDOP, 135
PDOP, 135
VDOP, 135
loc_satelliteInfo, 135
azimuth, 137
elevation, 137
gnssSvId, 137
healthStatus, 137
snr, 137
svInfoMask, 137
svListLen, 137
svStatus, 137
system, 137
validMask, 137
loc_sensorDataUsage, 137
aidingIndicatorMask, 138
usageMask, 138
loc_svUsedforFix, 139
gnssSvUsedList, 140
gnssSvUsedList_len, 140
loc_urlAddr, 140
address, 140
TlvPresent, 140
localTimeOffset
nas_qaQmi3Gpp2TimeZone, 241
logString
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 625
logger
common.h, 1053
longName
nas_PLMNNetworkNameData, 238
unpack_nas_SLQSGetPLMNName_t, 718
longNameCI
unpack_nas_SLQSGetPLMNName_t, 718
longNameEn
unpack_nas_SLQSGetPLMNName_t, 718
longNameLen
nas_PLMNNetworkNameData, 238
unpack_nas_SLQSGetPLMNName_t, 718
longNameSB
unpack_nas_SLQSGetPLMNName_t, 718
longNameSpareBits
nas_PLMNNetworkNameData, 238
Longitude
unpack_pds_SLQSGetGPSStateInfo_t, 783
longitude
pack_loc_SLQSLOCInjectPosition_t, 354
loopbackMode
pack_wds_SLQSSSetLoopback_t, 496
loopbackMultiplier
pack_wds_SLQSSSetLoopback_t, 496
LpmFlag
unpack_dms_SLQSDmsSwiGetPCInfo_t, 609
LteBandCapability
unpack_dms_SLQSGetBandCapability_t, 617
lteEmmDl
pack_nas_SLQSNasSwiIndicationRegister_t, 379
lteEmmUl
pack_nas_SLQSNasSwiIndicationRegister_t, 379
lteEsmDl
pack_nas_SLQSNasSwiIndicationRegister_t, 379
lteEsmUl
pack_nas_SLQSNasSwiIndicationRegister_t, 379
LteGsmCellInfo
nas_LTEInfoNeighboringGSM, 202
LteM1BandPref
NASLteM1BandPrefTlv, 294
lteM1BandPref
nas_LteM1BandPrefTlv, 204
LteNB1BandPref

NASLteNB1BandPrefTlv, 295
lteNb1BandPref
nas_LteNb1BandPrefTlv, 206
lteOpMode
nas_EdrxCiotLteMode, 171
nas_LteOpMode, 208
LteQci
unpack_qos_swiQosFlow_t, 804
lteRsrpDelta
nas_SLQSSignalStrengthsIndReq, 267
lteRsrpinfo
nas_SLQSSignalStrengthsInformation, 268
lteSSInfo, 141
rsrp, 141
rsrq, 142
rssi, 142
snr, 142
lteSnrDelta
nas_SLQSSignalStrengthsIndReq, 267
lteSnrinfo
nas_SLQSSignalStrengthsInformation, 268
ltersrp
unpack_nas_SLQSGetSignalStrength_t, 726
ltesnr
unpack_nas_SLQSGetSignalStrength_t, 726
lvl
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t, 856

M1BandPTlv
NASQmiCbkNasSystemSelPrefInd, 304
m_FwBuildId
CarrierImage_t, 44
m_FwImageId
CarrierImage_t, 44
m_PriBuildId
CarrierImage_t, 44
m_PriImageId
CarrierImage_t, 45
m_nCarrierId
CarrierImage_t, 44
m_nFolderId
CarrierImage_t, 44
m_nStorage
CarrierImage_t, 44
MACIndex
nas_NetworkStatEVDO, 225
MAX_BUILD_ID_LEN
dms.h, 1065
MAX_ERROR_CODE_LEN
imsa.h, 1133
MAX_ICCID_LENGTH
uim.h, 1390
MAX_MSE_TWS_MSG
sms.h, 1315
MAX_NAME_LEN
ims.h, 1121
MAX_NO_OF_SLOTS
uim.h, 1390
MAX_SENSOR_DATA_LEN
loc.h, 1153
MAX_SLOTS_STATUS
uim.h, 1390
MAX_SMS_LIST_SIZE
sms.h, 1315
MAX_TEMP_DATA_LEN
loc.h, 1153
MAXVOICEUSSDLENGTH
voice.h, 1412
MCC
nas_CDMASysInfo, 155
nas_CDMASysInfoExt, 156
nas_currentPLMN, 163
nas_ForbiddenNetworks3GPP, 176
nas_GSMSysInfo, 183
nas_LTESysInfo, 216
nas_QmiNas3GppNetworkInfo, 242
nas_QmiNas3GppNetworkRAT, 243
nas_QmisNasPcsDigit, 244
nas_WCDMASysInfo, 289
unpack_nas_GetServingNetwork_t, 703
MDMCallDuration
connectionStatus, 49
MDMConnStatus
connectionStatus, 49
wds_ConnStatusTlv, 1019
MEID_MAX_SIZE
dms.h, 1065
MEIDString
unpack_dms_GetDeviceSerialNumbers_t, 584
MIN
unpack_dms_GetVoiceNumber_t, 599
MINREQBKLEN
common.h, 1052
MMTlv
unpack_sms_SetNewSMSCallback_ind_t, 813
MNC
nas_CDMASysInfo, 155
nas_currentPLMN, 163
nas_ForbiddenNetworks3GPP, 176
nas_GSMSysInfo, 183
nas_LTESysInfo, 216
nas_QmiNas3GppNetworkInfo, 242
nas_QmiNas3GppNetworkRAT, 243
nas_QmisNasPcsDigit, 244
nas_WCDMASysInfo, 289
unpack_nas_GetServingNetwork_t, 703
MPTlv
NASQmiCbkNasSystemSelPrefInd, 304
MSETlv
unpack_ims_SLQSVoIPCfgCallBack_ind_t, 655
MSGID_AND_LEN
common.h, 1052
MSGID_DONT_CARE
common.h, 1052
MTMessageInfo
newMTMessageTlv, 308

MTUSize
pack_swidms_SLQSSwiDmsSetMTU_t, 434
MTUSize3gpp
swidms_mtuSize3gppTlv, 537
manString
pack_dms_SLQSSwiSetHostDevInfo_t, 327
unpack_dms_SLQSSwiGetHostDevInfo_t, 626
manufacturer
unpack_dms_GetManufacturer_t, 590
Mask
pack_wds_SLQSGetDUNCallInfo_t, 489
mask
loc_BdsSV, 124
loc_CellDb, 126
loc_ClkInfo, 127
loc_GnssData, 128
loc_SV, 139
unpack_qos_IPv6TrafCls_t, 786
unpack_qos_Tos_t, 805
max
PackSwiAVMSSettingsPeriodsInfo, 506
max_channel_rx_rate
unpack_wds_SLQSGetCurrentChannelRate_t, 938
max_channel_tx_rate
unpack_wds_SLQSGetCurrentChannelRate_t, 938
max_dist
pack_swiloc_SwiLocSetAutoStart_t, 437
unpack_swiloc_SwiLocGetAutoStart_t, 847
max_dist_reported
unpack_swiloc_SwiLocGetAutoStart_t, 847
max_time
pack_swiloc_SwiLocSetAutoStart_t, 437
unpack_swiloc_SwiLocGetAutoStart_t, 847
max_time_reported
unpack_swiloc_SwiLocGetAutoStart_t, 847
MaxAllowedPktSz
unpack_qos_swiQosFlow_t, 804
MaxChanRxRate
dunchannelRate, 64
MaxChanTxRate
dunchannelRate, 64
maxChannelRXRate
unpack_wds_GetConnectionRate_t, 917
maxChannelTXRate
unpack_wds_GetConnectionRate_t, 917
maxDlBitRate
LibPackQosClassID, 117
maxDownlinkBitrate
LibPackUMTSQoS, 121
wds_UMTSMinQoS, 1038
maxImages
FMSImageIDEntries, 68
maxMitigationLevel
tmd_mitigationDevList, 540
MaxRXChannelRate
unpack_dms_GetDeviceCap_t, 579
maxRxChannelRate
unpack_dms_GetDeviceCapabilities_t, 581
maxSDUSize
LibPackUMTSQoS, 121
wds_UMTSMinQoS, 1038
maxStorageSize
sms_maxStorageSizeResp, 520
MaxTXChannelRate
unpack_dms_GetDeviceCap_t, 579
maxTxChannelRate
unpack_dms_GetDeviceCapabilities_t, 581
maxUlBitRate
LibPackQosClassID, 117
maxUplinkBitrate
LibPackUMTSQoS, 121
wds_UMTSMinQoS, 1038
mcc
nas_CSGID, 162
nas_MNRInfo, 219
nas_netSelectionPref, 221
nas_OperatorPLMNData, 228
nas_PlmnID, 236
pack_nas_SLQSGetPLMNName_t, 366
unpack_nas_GetHomeNetwork_t, 699
mccM
nas_minBasedIMSI, 218
mccT
nas_trueIMSI, 278
mdmCallDurationActive
unpack_wds_SLQSGetDUNCallInfo_t, 942
meanThroughputClass
LibPackGPRSRequestedQoS, 92
wds_GPRSQoS, 1028
meid
unpack_dms_GetSerialNumbers_t, 596
meidSize
unpack_dms_GetDeviceSerialNumbers_t, 584
meidString
unpack_dms_SLQSSwiGetSerialNoExt_t, 627
message
unpack_sms_SLQSGetSMS_t, 816
message_type
NASOTAMessageTlv, 297
messageClass
sms_routeEntry, 523
messageFailureCode
unpack_sms_SendSMS_t, 811
messageFormat
pack_sms_SaveSMS_t, 414
pack_sms_SendSMS_t, 414
sms_sendAsyncsmsParams, 525
unpack_sms_SLQSGetSMS_t, 816
messageID
unpack_sms_SendSMS_t, 811
unpack_sms_SLQSWmsAsyncRawSendCallBack-_ind_t, 827
messageIndex
pack_sms_SLQSGetSMS_t, 417

pack_sms_SLQSModifySMSStatus_t, 419
qmiSmsMessageList, 506
sMSMTMessageInfo, 531
messageList
unpack_sms_SLQSGetSMSList_t, 818
messageListSize
unpack_sms_SLQSGetSMSList_t, 818
messageMode
sMSMessageModeInfo, 531
unpack_sms_SLQSWmsMemoryFullCallBack_ind_t, 828
MessageModeInfo
messageModeTlv, 142
messageModeTlv, 142
MessageModeInfo, 142
TlvPresent, 142
messageSize
pack_sms_SaveSMS_t, 414
pack_sms_SendSMS_t, 414
sms_sendAsyncsmsParams, 525
unpack_sms_SLQSGetSMS_t, 816
messageTag
pack_sms_SLQSModifySMSStatus_t, 419
qmiSmsMessageList, 506
unpack_sms_SLQSGetSMS_t, 816
messageType
sms_routeEntry, 523
MicMute
pack_audio_SLQSSetAudioProfile_t, 313
pack_swiaudio_SLQSSetM2MAVMute_t, 428
unpack_audio_SLQSGetAudioProfile_t, 569
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 829
unpack_swiaudio_SLQSGetM2MAVMute_t, 831
min
PackSwiAVMSSettingsPeriodsInfo, 506
MinPolicedPktSz
unpack_qos_swiQosFlow_t, 804
minSessExp
ims_MinSessExpInfo, 77
minSize
unpack_dms_GetVoiceNumber_t, 599
minute
nas_timeInfo, 277
nas_UniversalTime, 283
mipMode
unpack_wds_GetMobileIP_t, 923
mipStatus
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
mipstatAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
mitigationDevID
pack_tmd_SLQSTmdDeRegNotMitigationLvl_t, 443
pack_tmd_SLQSTmdGetMitigationLvl_t, 444
pack_tmd_SLQSTmdRegNotMitigationLvl_t, 444
mitigationDevIDLen
pack_tmd_SLQSTmdDeRegNotMitigationLvl_t, 443
pack_tmd_SLQSTmdGetMitigationLvl_t, 444
pack_tmd_SLQSTmdRegNotMitigationLvl_t, 444
mitigationDevId
tmd_mitigationDevList, 540
mitigationDevIdLen
tmd_mitigationDevList, 540
MitigationDevList
unpack_tmd_SLQSTmdGetMitigationDevList_t, 854
MitigationDevListLen
unpack_tmd_SLQSTmdGetMitigationDevList_t, 854
mnc
nas_CSGID, 162
nas_MNRInfo, 219
nas_netSelectionPref, 221
nas_OperatorPLMNData, 228
nas_PlmnID, 236
pack_nas_SLQSGetPLMNName_t, 366
unpack_nas_GetHomeNetwork_t, 699
mncPcsDigits
nas_CSGID, 162
mobileCountryCode
sMSEtwsPlmnInfo, 530
mobileIP
pack_wds_SLQSSetWdsEventCallback_t, 495
mobileNetworkCode
sMSEtwsPlmnInfo, 530
mode
pack_dms_SetEventReport_t, 322
pack_dms_SetPower_t, 324
pack_loc_SetOperationMode_t, 348
pack_sms_SLQSGetSmsBroadcastConfig_t, 417
pack_sms_SLQSSetSmsBroadcastActivation_t, 420
pack_sms_SLQSSetSmsBroadcastConfig_t, 421
pack_wds_SetMobileIP_t, 483
uim_refreshevent, 558
voice_callInfo, 989
ModePref
nas_ModePrefTlv, 219
NASModePreferenceTlv, 296
modelString
pack_dms_SLQSSwiSetHostDevInfo_t, 327
unpack_dms_SLQSSwiGetHostDevInfo_t, 626
modelid
unpack_dms_GetModelID_t, 591
modelid_str
unpack_dms_GetFirmwareInfo_t, 586
modemMode
nas_CommInfo, 161
modemindex
pack_fms_SetImagesPreference_t, 336
month
nas_timeInfo, 277

nas_UniversalTime, 283
msgCount
sms_messageWaitingInfoContent, 520
msgDelFailureCause
unpack_sms_SLQSWmsAsyncRawSendCallBack-_ind_t, 827
msgDelFailureType
unpack_sms_SLQSWmsAsyncRawSendCallBack-_ind_t, 827
msgProtocol
sms_msgProtocolResp, 521
msgType
sms_messageWaitingInfoContent, 520
msgWaitInfo
sms_getMsgWaitingInfo, 517
unpack_sms_SLQSWmsMessageWaitingCall-Back_ind_t, 828
msgid
pack_qmi_t, 410
unpack_qmi_t, 784
msgtype
common.h, 1054
Mtu
unpack_wds_SLQSGetRuntimeSettings_t, 945
MultDisc
nas_protocolSubtypeElement, 240
multiplier
unpack_qos_pktErrRate_t, 787
MuxID
qos_BindDataPortMuxID_t, 508

NAI
unpack_wds_GetMobileIPProfile_t, 925
NAS_NAM_NAME_LENGTH
nas.h, 1179
NAS_PLMN_LENGTH
nas.h, 1179
NASAcqOrderPrefTlv, 290
AcqOrderLen, 290
AcqOrderPref, 290
TlvPresent, 290
NASBandPreferenceTlv, 290
band_pref, 290
TlvPresent, 290
NASCiotAcqOrderPrefTlv, 291
CiotAcqOrderLen, 291
CiotAcqOrderPref, 291
TlvPresent, 291
NASCiotLteOpModePrefTlv, 291
CiotLteOpModePref, 291
TlvPresent, 291
NASEmergencyModeTlv, 291
EmerMode, 292
TlvPresent, 292
NASGWAcqOrderPrefTlv, 293
GWAcqOrderPref, 293
TlvPresent, 293
NASLTEBandPreferenceTlv, 293
LTEBandPref, 294
TlvPresent, 294
NASLteM1BandPrefTlv, 294
LteM1BandPref, 294
TlvPresent, 294
NASLteNB1BandPrefTlv, 295
LteNB1BandPref, 295
TlvPresent, 295
NASLteNasReleaseInfoTlv, 294
nas_major, 295
nas_minor, 295
nas_release, 295
TlvPresent, 295
NASModePreferenceTlv, 295
ModePref, 296
TlvPresent, 296
NASNetSelPreferenceTlv, 296
NetSelPref, 296
TlvPresent, 296
NASNr5gBandPrefTlv, 296
Nr5gBandPrefbits1_64, 297
Nr5gBandPrefbits_129_192, 297
Nr5gBandPrefbits_193_256, 297
Nr5gBandPrefbits_65_128, 297
TlvPresent, 297
NASOTAMessageTlv, 297
data_buf, 297
data_len, 297
message_type, 297
TlvPresent, 297
NASPRLPreferenceTlv, 301
PRLPref, 302
TlvPresent, 302
NASPhyCaAggPcellInfo, 298
dl_bw_value, 298
freq, 298
iLTEbandValue, 298
pci, 298
TlvPresent, 298
NASPhyCaAggScellDlBw, 298
dl_bw_value, 299
TlvPresent, 299
NASPhyCaAggScellIndType, 299
freq, 300
pci, 300
scell_state, 300
TlvPresent, 300
NASPhyCaAggScellIndex, 299
scell_idx, 299
TlvPresent, 299
NASPhyCaAggScellInfo, 300
dl_bw_value, 301
freq, 301
iLTEbandValue, 301
pci, 301
scell_state, 301
TlvPresent, 301
NASQmiCbkNasSwiOTAMessageInd, 302
nasRelInfoTlv, 302

otaMsgTlv, 302
timeTlv, 302
NASQmiCbkNasSystemSelPrefInd, 302
AOPTlv, 304
BPTlv, 304
CiotAOPTlv, 304
CiotOpMPTlv, 304
EMTlv, 304
GWAOPTlv, 304
LBPTlv, 304
M1BandPTlv, 304
MPTlv, 304
NB1BandPTlv, 304
NR5gBandPTlv, 304
NSPTlv, 304
PRLPTlv, 304
RPTlv, 305
RatDMTlv, 305
SDPTlv, 305
NASRatDisabledMaskTlv, 305
RatDisabledMask, 305
TlvPresent, 305
NASRoamPreferenceTlv, 305
RoamPref, 305
TlvPresent, 305
NASServDomainPrefTlv, 306
SrvDomainPref, 306
TlvPresent, 306
NASServingSystemInfo, 306
csAttachState, 307
hdrPersonality, 307
psAttachState, 307
radioInterfaceList, 307
radioInterfaceNo, 307
registrationState, 307
selectedNetwork, 307
NASTimeInfoTlv, 307
time, 308
TlvPresent, 308
NB1BandPTlv
NASQmiCbkNasSystemSelPrefInd, 304
NMEAData
unpack_loc_EventNMEA_Ind_t, 672
NR5gBandPTlv
NASQmiCbkNasSystemSelPrefInd, 304
NSPTlv
NASQmiCbkNasSystemSelPrefInd, 304
nUsbNetNum
pack_swidms_SLQSSwiDmsSetUsbNetNum_t, 435
NWQoSStatus
unpack_qos_SLQSQosGetNetworkStatus_t, 790
NWRegStat
unpack_sms_SLQSNWRegInfoCallback_ind_t, 820
naiSize
unpack_wds_GetMobileIPProfile_t, 925
namID
pack_nas_SLQSNasGet3GPP2Subscription_t, 372
voice_airTimer, 970
voice_prefVoiceSO, 1010
voice_roamTimer, 1014
namName
nas_namName, 220
namNameLen
nas_namName, 220
Name
unpack_nas_GetServingNetwork_t, 703
name
unpack_nas_GetHomeNetwork_t, 699
unpack_wds_GetDefaultProfile_t, 921
nameLen
voice_remotePartyName, 1012
namePI
voice_remotePartyName, 1012
nameSize
unpack_nas_GetHomeNetwork3GPP2_t, 697
unpack_nas_GetServingNetwork_t, 704
nameString
pack_dms_SLQSSwiSetOSInfo_t, 328
unpack_dms_SLQSSwiGetOSInfo_t, 627
namelength
unpack_omaDmFotaTlv_t, 768
namesize
unpack_wds_GetDefaultProfile_t, 921
nas.h
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_100, 1181
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_15, 1181
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_25, 1181
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_50, 1181
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_6, 1181
eLITEQMI_NAS_LTE_CPHY_CA_BW_NRB_75, 1181
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED, 1181
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED, 1181
eLITEQMI_NAS_LTE_CPHY_SCELL_STATE_DECONFIGURED, 1181
eNAS_LTE_CPHY_CA_BW_NRB_LITE_100, 1181
eNAS_LTE_CPHY_CA_BW_NRB_LITE_15, 1181
eNAS_LTE_CPHY_CA_BW_NRB_LITE_25, 1181
eNAS_LTE_CPHY_CA_BW_NRB_LITE_50, 1181
eNAS_LTE_CPHY_CA_BW_NRB_LITE_6, 1181
eNAS_LTE_CPHY_CA_BW_NRB_LITE_75, 1181
eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_ACTIVATED_LITE, 1181
eNAS_LTE_CPHY_SCELL_STATE_CONFIGURED_DEACTIVATED_LITE, 1181

eNAS_LTE_CPHY_SCELL_STATE_DECONFIGURED_LITE, 1181
LITE_SYS_SRV_DOMAIN_CAMPED, 1181
LITE_SYS_SRV_DOMAIN_CS_ONLY, 1181
LITE_SYS_SRV_DOMAIN_CS_PS, 1181
LITE_SYS_SRV_DOMAIN_NO_SRV, 1181
LITE_SYS_SRV_DOMAIN_PS_ONLY, 1181
nas.h, 1169
NAS_PLMN_LENGTH, 1179
nas_LTEBandPrefExtTlv, 1180
nas_NR5gBandPrefTlv, 1180
pack_nas_GetACCOLC, 1182
pack_nas_GetANAAAAuthenticationStatus, 1182
pack_nas_GetCDMANetworkParameters, 1182
pack_nas_GetHomeNetwork, 1182
pack_nas_GetHomeNetwork3GPP2, 1183
pack_nas_GetNetworkPreference, 1183
pack_nas_GetRFInfo, 1183
pack_nas_GetServingNetwork, 1184
pack_nas_GetServingNetworkCapabilities, 1184
pack_nas_GetSignalStrengths, 1184
pack_nas_InitiateDomainAttach, 1185
pack_nas_PerformNetworkScan, 1185
pack_nas_PerformNetworkScanPCI, 1185
pack_nas_SLQSConfigSigInfo, 1187
pack_nas_SLQSGetErrorRate, 1188
pack_nas_SLQSGetNetworkTime, 1188
pack_nas_SLQSGetOperatorNameData, 1189
pack_nas_SLQSGetPLMNName, 1189
pack_nas_SLQSGetServingSystem, 1189
pack_nas_SLQSGetSignalStrength, 1190
pack_nas_SLQSGetSysInfo, 1190
pack_nas_SLQSGetSysSelectionPref, 1190
pack_nas_SLQSGetSysSelectionPrefExt, 1191
pack_nas_SLQSInitiateNetworkRegistration, 1191
pack_nas_SLQSNASGetForbiddenNetworks, 1193
pack_nas_SLQSNASGeteDRXParams, 1193
pack_nas_SLQSNASGeteDRXParamsExt, 1193
pack_nas_SLQSNASSeteDRXParams, 1195
pack_nas_SLQSNASSwiGetChannelLock, 1196
pack_nas_SLQSNASSwiSetChannelLock, 1197
pack_nas_SLQSNasConfigSigInfo2, 1192
pack_nas_SLQSNasGet3GPP2Subscription, 1192
pack_nas_SLQSNasGetCellLocationInfo, 1192
pack_nas_SLQSNasGetHDRColorCode, 1194
pack_nas_SLQSNasGetRFInfo, 1194
pack_nas_SLQSNasGetSigInfo, 1194
pack_nas_SLQSNasGetTxRxInfo, 1195
pack_nas_SLQSNasIndicationRegisterExt, 1195
pack_nas_SLQSNasSwiIndicationRegister, 1196
pack_nas_SLQSNasSwiModemStatus, 1197
pack_nas_SLQSSetBandPreference, 1197
pack_nas_SLQSSetSignalStrengthsCallback, 1198
pack_nas_SLQSSetSysSelectionPref, 1198
pack_nas_SLQSSetSysSelectionPrefExt, 1198
pack_nas_SLQSSwiGetHDRPersonality, 1199
pack_nas_SLQSSwiGetHDRProtSubtype, 1199
pack_nas_SLQSSwiGetHRPDStats, 1199
pack_nas_SLQSSwiGetLteCQI, 1200
pack_nas_SLQSSwiGetLteSccRxInfo, 1200
pack_nas_SLQSSwiNetworkDebug, 1200
pack_nas_SLQSSwiPSDetach, 1201
pack_nas_SetACCOLC, 1186
pack_nas_SetCDMANetworkParameters, 1186
pack_nas_SetLURejectCallback, 1187
pack_nas_SetNetworkPreference, 1187
pack_nas_SetRFInfoCallback, 1187
pack_nas_SlqsGetLTECphyCAInfo, 1188
unpack_nas_GetACCOLC, 1201
unpack_nas_GetANAAAAuthenticationStatus, 1201
unpack_nas_GetCDMANetworkParameters, 1202
unpack_nas_GetHomeNetwork, 1202
unpack_nas_GetHomeNetwork3GPP2, 1203
unpack_nas_GetNetworkPreference, 1203
unpack_nas_GetRFInfo, 1203
unpack_nas_GetServingNetwork, 1204
unpack_nas_GetServingNetworkCapabilities, 1204
unpack_nas_GetSignalStrengths, 1204
unpack_nas_InitiateDomainAttach, 1205
unpack_nas_InitiateDomainAttach_t, 1180
unpack_nas_PerformNetworkScan, 1205
unpack_nas_SLQSConfigSigInfo, 1209
unpack_nas_SLQSConfigSigInfo_t, 1180
unpack_nas_SLQSGetErrorRate, 1209
unpack_nas_SLQSGetNetworkTime, 1210
unpack_nas_SLQSGetOperatorNameData, 1210
unpack_nas_SLQSGetPLMNName, 1211
unpack_nas_SLQSGetServingSystem, 1211
unpack_nas_SLQSGetSignalStrength, 1211
unpack_nas_SLQSGetSysInfo, 1212
unpack_nas_SLQSGetSysSelectionPref, 1212
unpack_nas_SLQSGetSysSelectionPrefExt, 1213
unpack_nas_SLQSInitiateNetworkRegistration, 1213
unpack_nas_SLQSInitiateNetworkRegistration_t, 1180
unpack_nas_SLQSNASGetForbiddenNetworks, 1216
unpack_nas_SLQSNASGeteDRXParams, 1215
unpack_nas_SLQSNASGeteDRXParamsExt, 1215
unpack_nas_SLQSNASSeteDRXParams, 1219
unpack_nas_SLQSNASSeteDRXParams_t, 1180
unpack_nas_SLQSNASSwiGetChannelLock, 1219
unpack_nas_SLQSNASSwiSetChannelLock, 1221
unpack_nas_SLQSNASSwiSetChannelLock_t, 1180
unpack_nas_SLQSNasConfigSigInfo2, 1213
unpack_nas_SLQSNasConfigSigInfo2_t, 1180
unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind, 1214
unpack_nas_SLQSNasGet3GPP2Subscription, 1214

unpack_nas_SLQSNasGetCellLocationInfo, 1214
unpack_nas_SLQSNasGetHDRColorCode, 1216
unpack_nas_SLQSNasGetRFInfo, 1216
unpack_nas_SLQSNasGetSigInfo, 1217
unpack_nas_SLQSNasGetTxRxInfo, 1217
unpack_nas_SLQSNasIndicationRegisterExt, 1217
unpack_nas_SLQSNasIndicationRegisterExt_t, 1180
unpack_nas_SLQSNasNetworkRejectCallback_Ind, 1218
unpack_nas_SLQSNasNetworkTimeCallBack_ind, 1218
unpack_nas_SLQSNasSigInfoCallback_ind, 1219
unpack_nas_SLQSNasSwiIndicationRegister, 1220
unpack_nas_SLQSNasSwiIndicationRegister_t, 1180
unpack_nas_SLQSNasSwiModemStatus, 1220
unpack_nas_SLQSNasSwiOTAMessageCallback_ind, 1220
unpack_nas_SLQSNasSysInfoCallback_ind, 1221
unpack_nas_SLQSNasTimerCallback_ind, 1221
unpack_nas_SLQSSetBandPreference, 1222
unpack_nas_SLQSSetBandPreference_t, 1180
unpack_nas_SLQSSetSignalStrengthsCallback, 1222
unpack_nas_SLQSSetSignalStrengthsCallback_t, 1180
unpack_nas_SLQSSetSysSelectionPref, 1222
unpack_nas_SLQSSetSysSelectionPref_t, 1180
unpack_nas_SLQSSetSysSelectionPrefCallBack_ind, 1223
unpack_nas_SLQSSetSysSelectionPrefExt, 1223
unpack_nas_SLQSSetSysSelectionPrefExt_t, 1180
unpack_nas_SLQSSwiGetHDRPersonality, 1223
unpack_nas_SLQSSwiGetHDRProtSubtype, 1224
unpack_nas_SLQSSwiGetHRPDStats, 1224
unpack_nas_SLQSSwiGetLteCQI, 1224
unpack_nas_SLQSSwiGetLteSccRxInfo, 1225
unpack_nas_SLQSSwiHDRPersonalityCallback_Ind, 1225
unpack_nas_SLQSSwiNetworkDebug, 1225
unpack_nas_SLQSSwiPSDetach, 1226
unpack_nas_SLQSSwiPSDetach_t, 1180
unpack_nas_SLQSSwiRandIndicatorCallback_Ind, 1226
unpack_nas_SetACCOLC, 1205
unpack_nas_SetACCOLC_t, 1180
unpack_nas_SetCDMANetworkParameters, 1206
unpack_nas_SetCDMANetworkParameters_t, 1180
unpack_nas_SetDataCapabilitiesCallback_ind, 1206
unpack_nas_SetEventReportInd, 1206
unpack_nas_SetLURejectCallback, 1207
unpack_nas_SetLURejectCallback_t, 1180
unpack_nas_SetNasLTECphyCaIndCallback_ind, 1207
unpack_nas_SetNetworkPreference, 1208
unpack_nas_SetRFInfoCallback, 1208
unpack_nas_SetRFInfoCallback_t, 1180
unpack_nas_SetRoamingIndicatorCallback_ind, 1208
unpack_nas_SetServingSystemCallback_ind, 1209
unpack_nas_SlqsGetLTECphyCAInfo, 1210
unpack_valid_nas_GetCDMANetworkParameters, 1226
unpack_valid_nas_SLQSGetServingSystem, 1227
unpack_valid_nas_SLQSGetSignalStrength, 1228
unpack_valid_nas_SLQSNasGetSigInfo, 1228
nas_AcqOrderPrefTlv, 143
acqOrdeLen, 143
pAcqOrder, 143
TlvPresent, 144
nas_ActPilotPNElement, 144
ActSetPilotPN, 144
ActSetPilotPNStrength, 144
nas_AddCDMASysInfo, 144
geoSysIdx, 145
regPrd, 145
nas_AddSysInfo, 145
cellBroadcastCap, 145
geoSysIdx, 145
nas_BandPrefInfoTlv, 145
bits_129_192, 146
bits_193_256, 146
bits_1_64, 146
bits_65_128, 146
TlvPresent, 146
nas_BandPrefTlv, 146
BandPref, 148
TlvPresent, 148
nas_CDMAChannel, 149
priChA, 150
priChB, 150
secChA, 150
secChB, 150
nas_CDMAECIOThresh, 150
CDMAECIOThreshListLen, 150
pCDMAECIOThreshList, 150
nas_CDMAInfo, 151
baseId, 151
baseLat, 151
baseLong, 151
nid, 151
refpn, 152
sid, 152
nas_CDMARSSIThresh, 152
CDMARSSIThreshListLen, 152
pCDMARSSIThreshList, 152
nas_CDMASysInfo, 152
baseId, 155
baseLat, 155

baseLong, 155
bsInfoValid, 155
bsPRev, 155
bsPRevValid, 155
ccsSupported, 155
ccsSupportedValid, 155
cdmaSysIdValid, 155
isSysPrlMatch, 155
isSysPrlMatchValid, 155
MCC, 155
MNC, 155
networkID, 155
networkIdValid, 155
pRevInUse, 156
pRevInUseValid, 156
packetZone, 156
packetZoneValid, 156
sysInfoCDMA, 156
systemID, 156
nas_CDMASysInfoExt, 156
imsi_11_12, 156
MCC, 156
nas_CSGID, 161
id, 162
mcc, 162
mnc, 162
mncPcsDigits, 162
rat, 162
nas_CallBarringSysInfo, 148
csBarStatus, 148
psBarStatus, 148
nas_CiotAcqOrderPrefTlv, 158
ciotAcqOrderLen, 159
pCiotAcqOrder, 159
TlvPresent, 159
nas_CiotLteOpModePrefTlv, 159
ciotLteOpModePref, 159
TlvPresent, 159
nas_CommInfo, 159
imsRegState, 161
modemMode, 161
psState, 161
systemMode, 161
temperature, 161
nas_CsgId, 162
csgId, 162
TlvPresent, 162
nas_DRCParams, 168
DRCCover, 169
DRCValue, 169
nas_DataStatusDetail, 164
IPAddress, 165
LastErrCode, 165
nas_DeviceConfigDetail, 167
Chipset, 168
HWVersion, 168
QLIC, 168
Technology, 168
nas_ECIOThresh, 170
ECIOThresListLen, 170
pECIOThresList, 170
nas_EdrxCiotLteMode, 170
lteOpMode, 171
TlvPresent, 171
nas_EdrxCycleLength, 171
cycleLength, 171
TlvPresent, 171
nas_EdrxEnableType, 171
edrxEnabled, 172
TlvPresent, 172
nas_EdrxPagingTimeWindow, 172
edrxPtw, 172
TlvPresent, 172
nas_EdrxRatType, 172
edrxRatType, 173
TlvPresent, 173
nas_EmerModeTlv, 173
EmerMode, 174
TlvPresent, 174
nas_ForbiddenNetworks3GPP, 175
forbiddenNwInstLen, 176
MCC, 176
MNC, 176
TlvPresent, 176
nas_GERANInfo, 176
arfcn, 177
bsic, 177
cellID, 177
insNmrCellInfo, 177
lac, 177
nmrInst, 177
plmn, 177
rxLev, 177
timingAdvance, 177
nas_GSMRSSIThresh, 179
GSMRSSIThreshListLen, 180
pGSMRSSIThreshList, 180
nas_GSMSrvStatusInfo, 180
isPrefDataPath, 181
srvStatus, 181
trueSrvStatus, 181
nas_GSMSysInfo, 181
cellId, 183
cellIdValid, 183
dtmSupp, 183
dtmSuppValid, 183
egprsSupp, 183
egprsSuppValid, 183
lac, 183
lacValid, 183
MCC, 183
MNC, 183
networkIdValid, 183
regRejectInfoValid, 183
rejCause, 183
rejectSrvDomain, 184

sysInfoGSM, 184
nas_GWAcqOrderPrefTlv, 184
GWAcqOrderPref, 184
TlvPresent, 184
nas_HDRECIOThresh, 184
HDRECIOThreshListLen, 185
pHDRECIOThreshList, 185
nas_HDRIOThresh, 185
HDRIOThreshListLen, 185
pHDRIOThreshList, 185
nas_HDRPersonality_Ind_Data, 185
pCurrentPersonality, 186
pPersonalityListLength, 186
pProtocolSubtypeElement, 186
nas_HDRRSSIThresh, 186
HDRRSSIThreshListLen, 186
pHDRRSSIThreshList, 186
nas_HDRSINRThresh, 187
HDRSINRThresListLen, 187
pHDRSINRThresList, 187
nas_HDRSINRThreshold, 187
HDRSINRThreshListLen, 188
pHDRSINRThreshList, 188
nas_HDRSysInfo, 188
hdrActiveProt, 190
hdrActiveProtValid, 190
hdrPersonality, 190
hdrPersonalityValid, 190
is856SysId, 190
is856SysIdValid, 190
isSysPrlMatch, 190
isSysPrlMatchValid, 190
sysInfoHDR, 190
nas_IOThresh, 192
IOThresListLen, 192
pIOThresList, 192
nas_LTEBandPrefExtTlv
nas.h, 1180
nas_LTEBandPrefTlv, 193
LTEBandPref, 194
TlvPresent, 195
nas_LTEInfo, 196
band, 198
bandwidth, 198
emmConnState, 198
emmState, 198
emmSubState, 198
RXChan, 198
TXChan, 198
nas_LTEInfoInterfreq, 199
freqsLen, 199
InfoInterfreq, 199
ueInIdle, 199
nas_LTEInfoIntrafreq, 199
CellParams, 201
cellReselPriority, 201
cellsLen, 201
earfcn, 201
globalCellId, 201
plmn, 201
sIntraSearch, 201
sNonIntraSearch, 201
servingCellId, 201
tac, 201
threshServingLow, 201
ueInIdle, 201
nas_LTEInfoNeighboringGSM, 201
freqsLen, 202
LteGsmCellInfo, 202
ueInIdle, 202
nas_LTEInfoNeighboringWCDMA, 202
freqsLen, 203
ueInIdle, 203
nas_LTEOperationMode, 207
pLTEOperationMode, 207
TlvPresent, 207
nas_LTERSRPThresh, 209
LTERSRPThreshListLen, 209
pLTERSRPThreshList, 209
nas_LTERSRQThresh, 209
LTERSRQThreshListLen, 210
pLTERSRQThreshList, 210
nas_LTERSSIThresh, 210
LTERSSIThreshListLen, 210
pLTERSSIThreshList, 210
nas_LTESNRThresh, 213
LTESNRThresListLen, 213
pLTESNRThresList, 213
nas_LTESNRThreshold, 213
LTESNRThreshListLen, 214
pLTESNRThreshList, 214
nas_LTESigRptCfg, 210
avgPeriod, 211
rptRate, 211
nas_LTESigRptConfig, 211
avgPeriod, 212
rptRate, 212
nas_LTESysInfo, 214
cellId, 216
cellIdValid, 216
lac, 216
lacValid, 216
MCC, 216
MNC, 216
networkIdValid, 216
regRejectInfoValid, 216
rejCause, 216
rejectSrvDomain, 216
sysInfoLTE, 216
tac, 216
tacValid, 216
nas_LteM1BandPrefTlv, 203
lteM1BandPref, 204
TlvPresent, 205
nas_LteNb1BandPrefTlv, 205
lteNb1BandPref, 206

TlvPresent, 207
nas_LteOpMode, 207
lteOpMode, 208
TlvPresent, 208
nas_MNRInfo, 218
mcc, 219
mnc, 219
rat, 219
nas_ModePrefTlv, 219
ModePref, 219
TlvPresent, 219
nas_NR5gBandPrefTlv
nas.h, 1180
nas_NetSelPrefTlv, 221
NetSelPref, 221
TlvPresent, 221
nas_NetworkStat1x, 221
ActSetCnt, 223
NeighborSetCnt, 223
pActPilotPNElements, 223
pNeighborSetPilotPN, 223
RX_EC_IO, 223
RX_PWR, 223
SO, 223
State, 223
TX_PWR, 223
nas_NetworkStatEVDO, 223
MACIndex, 225
PER, 225
pSectorID, 225
PilotEnergy, 225
RX_PWR, 225
SNR, 225
SectorIDLen, 225
State, 225
nas_OperatorPLMNData, 227
lac1, 228
lac2, 228
mcc, 228
mnc, 228
PLMNRecID, 228
nas_PLMNNetworkName, 236
numInstance, 236
PLMNNetName, 236
nas_PLMNNetworkNameData, 236
codingScheme, 238
countryInitials, 238
longName, 238
longNameLen, 238
longNameSpareBits, 238
shortName, 238
shortNameLen, 238
shortNameSpareBits, 238
nas_PRLPrefTlv, 238
PRLPref, 239
TlvPresent, 239
nas_PhyCaAggPcellInfo, 229
dl_bw_value, 229
freq, 229
iLTEbandValue, 229
pci, 229
TlvPresent, 229
nas_PhyCaAggScellDlBw, 230
dl_bw_value, 230
TlvPresent, 230
nas_PhyCaAggScellIndType, 231
freq, 231
pci, 231
scell_state, 231
TlvPresent, 231
nas_PhyCaAggScellIndex, 230
scell_idx, 230
TlvPresent, 230
nas_PhyCaAggScellInfo, 231
dl_bw_value, 234
freq, 234
iLTEbandValue, 234
pci, 234
scell_state, 234
TlvPresent, 234
nas_PilotSetData, 234
NumPilots, 234
pPilotSetInfo, 234
nas_PilotSetParams, 235
PilotPN, 235
PilotStrength, 235
PilotType, 235
nas_PlmnID, 235
mcc, 236
mnc, 236
pcsDigit, 236
TlvPresent, 236
nas_QmiNas3GppNetworkInfo, 241
Desription, 242
Forbidden, 242
InUse, 242
MCC, 242
MNC, 242
Preferred, 242
Roaming, 242
nas_QmiNas3GppNetworkRAT, 242
MCC, 243
MNC, 243
RAT, 243
nas_QmisNasPcsDigit, 243
includes_pcs_digit, 244
MCC, 244
MNC, 244
nas_QmisNasSlqsNasPCICellInfo, 244
cellID, 244
freq, 244
GlobalCellID, 244
nasQmisNasPcsDigit, 244
PlmnLen, 244
nas_QmisNasSlqsNasPCIInfo, 245
nasQmisNasSlqsNasPCICellInfo, 245

PCICellInfoLen, 245
rsrp, 245
rsrpRx0, 245
rsrpRx1, 245
rsrq, 246
rsrqRx0, 246
rsrqRx1, 246
nas_RFBandInfoElements, 247
activeBandClass, 248
activeChannel, 248
radioInterface, 248
nas_RFInfoTlv, 253
activeBandClass, 254
activeChannel, 254
radioInterface, 254
radioInterfaceSize, 254
TlvPresent, 254
nas_RSRPThresh, 255
pRSRPThresList, 256
RSRPThresListLen, 256
nas_RSRQThresh, 256
pRSRQThresList, 257
RSRQThresListLen, 257
nas_RSSIThresh, 257
pRSSIThresList, 258
RSSIThresListLen, 258
nas_RankIndicatorTlv, 246
count0, 246
count1, 246
TlvPresent, 246
nas_RatDisabledMaskTlv, 246
ratDisabledMask, 247
TlvPresent, 247
nas_RejectReasonTlv, 247
rejectCause, 247
serviceDomain, 247
TlvPresent, 247
nas_RfBandInfoExtFormat, 248
pInstancesSize, 249
pRfBandInfoExtFormatParam, 249
TlvPresent, 249
nas_RfBandInfoExtFormatElements, 249
activeBand, 249
activeChannel, 249
radioInterface, 249
nas_RfBandInfoList, 250
pInstanceSize, 250
pRFBandInfoParam, 250
nas_RfBandwidthInfo, 250
pInstancesSize, 251
pRfBandwidthInfoParam, 251
TlvPresent, 251
nas_RfBandwidthInfoElements, 251
bandwidth, 251
radioInterface, 251
nas_RfDedicatedBandInfo, 252
pInstancesSize, 252
pRfDedicatedBandInfoParam, 252
TlvPresent, 252
nas_RfDedicatedBandInfoElements, 252
dedicatedBand, 253
radioInterface, 253
nas_RoamPrefTlv, 255
RoamPref, 255
TlvPresent, 255
nas_RxSigInfo, 259
isRadioTuned, 260
rsrp, 260
rxChainIndex, 260
rxPower, 260
nas_SLQSSignalStrengthsIndReq, 265
ecioDelta, 266
ecioThresholdList, 266
ecioThresholdListLen, 266
ioDelta, 267
lteRsrpDelta, 267
lteSnrDelta, 267
rsrqDelta, 267
rxSignalStrengthDelta, 267
sinrDelta, 267
sinrThresholdList, 267
sinrThresholdListLen, 267
nas_SLQSSignalStrengthsInformation, 267
ecioInfo, 268
errorRateInfo, 268
io, 268
lteRsrpinfo, 268
lteSnrinfo, 268
rsrqInfo, 268
rxSignalStrengthInfo, 268
sinr, 268
nas_SLQSSignalStrengthsTlv, 268
sSLQSSignalStrengthsInfo, 269
TlvPresent, 269
nas_SccRxInfo, 261
numInstances, 262
rsrq, 262
sigInfo, 262
snr, 262
TlvPresent, 262
nas_SignalStrengthTlv, 265
radioInterface, 265
signalStrength, 265
TlvPresent, 265
nas_SrvDomainPrefTlv, 269
SrvDomainPref, 269
TlvPresent, 269
nas_SrvStatusInfo, 269
isPrefDataPath, 270
srvStatus, 270
nas_TDSCDMAECIOThresh, 273
nas_TDSCDMARSCPThresh, 273
nas_TDSCDMARSSIThresh, 274
nas_TDSCDMASINRCONFThresh, 274
nas_TDSCDMASINRThresh, 275
nas_UMTSInfo, 278

cellID, 280
ecio, 280
geranInst, 280
GeranInstInfo, 280
lac, 280
plmn, 280
psc, 280
rscp, 280
UMTSInstInfo, 280
uarfcn, 280
umtsInst, 280
nas_UMTSinstInfo, 280
umtsEcio, 281
umtsPsc, 281
umtsRscp, 281
umtsUarfcn, 281
nas_UniversalTime, 282
day, 283
dayOfWeek, 283
hour, 283
minute, 283
month, 283
second, 283
year, 283
nas_WCDMAECIOThresh, 284
nas_WCDMAInfoLTENeighborCell, 284
umtsLTENbrCellLen, 285
wcdmaRRCState, 285
nas_WCDMARSSIThresh, 285
nas_WCDMASysInfo, 286
cellId, 288
cellIdValid, 289
hsCallStatus, 289
hsCallStatusValid, 289
hsInd, 289
hsIndValid, 289
lac, 289
lacValid, 289
MCC, 289
MNC, 289
networkIdValid, 289
psc, 289
pscValid, 289
regRejectInfoValid, 289
rejCause, 289
rejectSrvDomain, 289
sysInfoWCDMA, 289
nas_acqOrderPref, 142
acqOrdeLen, 143
pAcqOrder, 143
nas_callBarStatus, 148
csBarStatus, 149
psBarStatus, 149
nas_cellParams, 156
pci, 157
rsrp, 157
rsrq, 157
rssi, 157
srxlev, 157
nas_ciotAcqOrderPref, 157
ciotAcqOrderLen, 158
pCiotAcqOrder, 158
nas_currentPLMN, 162
MCC, 163
MNC, 163
netDescr, 163
netDescrLength, 163
nas_dataSrvCapabilities, 163
dataCapabilities, 164
dataCapabilitiesLen, 164
nas_detailSvcInfo, 166
hdrHybrid, 167
hdrSrvStatus, 167
isSysForbidden, 167
srvCapability, 167
srvStatus, 167
nas_dirNum, 168
dirNum, 168
dirNumLen, 168
nas_ecioListElement, 169
ecio, 169
radioIf, 170
nas_errorRateListElement, 174
errorRate, 175
radioIf, 175
nas_geranInstInfo, 177
geranArfcn, 178
geranBsicBcc, 178
geranBsicNcc, 178
geranRssi, 178
nas_gsmCellInfo, 178
arfcn, 179
band1900, 179
bsicId, 179
cellIdValid, 179
rssi, 179
srxlev, 179
nas_homeSIDNID, 190
numInstances, 190
SidNid, 190
nas_infoInterFreq, 190
cell_resel_priority, 191
cellInterFreqParams, 191
cells_len, 191
earfcn, 191
threshXHigh, 191
threshXLow, 192
nas_lteBandPrefExt, 192
bits_129_192, 193
bits_193_256, 193
bits_1_64, 193
bits_65_128, 193
nas_lteEARFCN, 195
earfcn0, 195
earfcn1, 195
status, 195

nas_lteGsmCellInfo, 195
cellReselPriority, 196
cells_len, 196
GsmCellInfo, 196
nccPermitted, 196
threshGsmHigh, 196
threshGsmLow, 196
nas_ltePCI, 208
earfcn, 208
pci, 208
status, 208
nas_lteRsrpinformation, 208
rsrplevel, 209
nas_lteSnrinformation, 212
snrlevel, 213
nas_lteWcdmaCellInfo, 216
cellReselPriority, 217
cellsLen, 217
threshXhigh, 217
threshXlow, 217
uarfcn, 217
WCDMACellInfo, 217
nas_major
NASLteNasReleaseInfoTlv, 295
nas_minBasedIMSI, 217
imsiM1112, 218
imsiMS1, 218
imsiMS2, 218
mccM, 218
nas_minor
NASLteNasReleaseInfoTlv, 295
nas_namName, 219
namName, 220
namNameLen, 220
nas_netSelectionPref, 220
mcc, 221
mnc, 221
netReg, 221
nas_nmrCellInfo, 225
nmrArfcn, 226
nmrBsic, 226
nmrCellID, 226
nmrLac, 226
nmrPlmn, 226
nmrRxLev, 226
nas_nr5gBandPref, 226
bits_129_192, 227
bits_193_256, 227
bits_1_64, 227
bits_65_128, 227
nas_operatorNameString, 227
PLMNName, 227
nas_operatorPLMNList, 228
numInstance, 229
PLMNData, 229
nas_protocolSubtypeElement, 239
AccessMac, 240
AuthProt, 240
ControlMac, 240
EncryptProt, 240
ForwardMac, 240
IdleState, 240
KeyExchange, 240
MultDisc, 240
PhysicalLayer, 240
ReverseMac, 240
SecProt, 240
VirtStream, 240
nas_qaQmi3Gpp2TimeZone, 240
daylightSavings, 241
leapSeconds, 241
localTimeOffset, 241
nas_release
NASLteNasReleaseInfoTlv, 295
nas_roamIndList, 254
numInstances, 254
radioInterface, 255
roamIndicator, 255
nas_rsrqInformation, 256
radioIf, 256
rsrq, 256
nas_rxInfo, 258
ecio, 259
isRadioTuned, 259
phase, 259
rscp, 259
rsrp, 259
rxPower, 259
nas_rxSignalStrengthListElement, 260
radioIf, 261
rxSignalStrength, 261
nas_servSystem, 263
csAttachState, 264
numRadioInterfaces, 264
psAttachState, 264
radioInterface, 264
regState, 264
selNetwork, 264
nas_serviceProviderName, 262
displayCondition, 262
spn, 262
spnLength, 262
nas_sidNid, 264
nid, 264
sid, 264
nas_sysInfoCommon, 270
isSysForbidden, 272
isSysForbiddenValid, 272
roamStatus, 272
roamStatusValid, 272
srvCapability, 272
srvCapabilityValid, 272
srvDomain, 272
srvDomainValid, 272
nas_timeInfo, 275
day, 277

dayLtSavingAdj, 277
dayOfWeek, 277
hour, 277
minute, 277
month, 277
radioInterface, 277
second, 277
timeZone, 277
TlvPresent, 277
year, 277
nas_trueIMSI, 277
imsiT1112, 278
imsiTS1, 278
imsiTS2, 278
imsiTaddrNum, 278
mccT, 278
nas_txInfo, 278
isInTraffic, 278
txPower, 278
nas_umtsLTENbrCell, 281
cellIsTDD, 282
earfcn, 282
pci, 282
rsrp, 282
rsrq, 282
srxlev, 282
nas_wcdmaCellInfo, 283
cpich_ecno, 284
cpich_rscp, 284
psc, 284
srxlev, 284
nas_wcdmaUARFCN, 289
status, 290
uarfcn, 290
NasGetLTECphyCaInfo, 292
PhyCaAggPcellInfo, 293
PhyCaAggScellDlBw, 293
PhyCaAggScellIndType, 293
PhyCaAggScellIndex, 293
PhyCaAggScellInfo, 293
nasQmisNasPcsDigit
nas_QmisNasSlqsNasPCICellInfo, 244
nasQmisNasSlqsNasPCICellInfo
nas_QmisNasSlqsNasPCIInfo, 245
nasRelInfoTlv
NASQmiCbkNasSwiOTAMessageInd, 302
nccPermitted
nas_lteGsmCellInfo, 196
NeighborSetCnt
nas_NetworkStat1x, 223
netDescr
nas_currentPLMN, 163
netDescrLength
nas_currentPLMN, 163
netInfoLen
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
netReg
nas_netSelectionPref, 221
NetSelPref
nas_NetSelPrefTlv, 221
NASNetSelPreferenceTlv, 296
NetworkID
unpack_nas_SLQSGetServingSystem_t, 723
networkID
nas_CDMASysInfo, 155
networkIdValid
nas_CDMASysInfo, 155
nas_GSMSysInfo, 183
nas_LTESysInfo, 216
nas_WCDMASysInfo, 289
networkInfo
voice_USSDNotificationNetworkInfo, 1016
networkInfoLen
unpack_wds_SLQSGetCurrDataSystemStat_t, 936
NetworkType
currNetworkInfo, 52
wds_currNetworkInfo, 1020
NewIMSRegistration
unpack_imsa_SLQSImsaRegStatusCallBack_ind_t, 660
NewImsRegStatus
unpack_imsa_SLQSGetIMSARegStatus_t, 656
NewMMTlv
unpack_sms_SetNewSMSCallback_ind_t, 813
newMTMessageTlv, 308
MTMessageInfo, 308
TlvPresent, 308
newPINLen
uim_unblockUIMPIN, 564
newPINVal
uim_unblockUIMPIN, 564
newPasswd
pack_voice_SLQSVoiceSetCallBarringPassword_t, 470
newPasswdAgain
pack_voice_SLQSVoiceSetCallBarringPassword_t, 470
newPin
pack_dms_UIMUnblockPIN_t, 334
newPwd
voice_newPwdData, 1006
newPwdAgain
voice_newPwdData, 1006
newValue
pack_dms_UIMChangePIN_t, 330
nextHeader
LibPackTFTIDParams, 119
nid
nas_CDMAInfo, 151
nas_sidNid, 264
unpack_nas_GetHomeNetwork_t, 699
nmrArfcn
nas_nmrCellInfo, 226
nmrBsic

nas_nmrCellInfo, 226
nmrCellID
nas_nmrCellInfo, 226
nmrInst
nas_GERANInfo, 177
nmrLac
nas_nmrCellInfo, 226
nmrPlmn
nas_nmrCellInfo, 226
nmrRxLev
nas_nmrCellInfo, 226
noReplyTimer
voice_callFWExtInfo, 986
voice_callFWInfo, 987
notifType
unpack_voice_SUPSNotificationCallback_ind_t, 910
notification
unpack_omaDmNotificationsTlv_t, 770
notification_Type
unpack_voice_USSDNotificationCallback_ind_t, 910
notificationType
sMSEtwsMessageInfo, 529
notused
unpack_dms_SetCrashAction_t, 602
Nr5gBandPrefbits1_64
NASNr5gBandPrefTlv, 297
Nr5gBandPrefbits_129_192
NASNr5gBandPrefTlv, 297
Nr5gBandPrefbits_193_256
NASNr5gBandPrefTlv, 297
Nr5gBandPrefbits_65_128
NASNr5gBandPrefTlv, 297
num_instances
DMScustSettingList, 62
sms_qaQmi3GPP2BroadcastCfgInfo, 522
sms_qaQmi3GPPBroadcastCfgInfo, 522
numApp
slotInf, 514
uim_slotInfo, 563
numCrashes
crashInformation, 51
numEntries
unpack_dms_SLQSSwiGetFirmwareCurr_t, 623
numFeatures
uim_personalizationStatus, 555
numFiles
uim_registerRefresh, 559
NumFlows
unpack_qos_SLQSSetQosEventCallback_ind_t, 793
numInstance
nas_operatorPLMNList, 229
nas_PLMNNetworkName, 236
numInstances
nas_homeSIDNID, 190
nas_roamIndList, 254
nas_SccRxInfo, 262
sms_getMsgWaitingInfo, 517
unpack_sms_SLQSWmsMessageWaitingCallBack_ind_t, 828
voice_arrAlertingPattern, 973
voice_arrAlertingType, 974
voice_arrAlphaID, 974
voice_arrCalledPartyNum, 975
voice_arrCallEndReason, 976
voice_arrCallInfo, 976
voice_arrConnectPartyNum, 977
voice_arrDiagInfo, 977
voice_arrRedirPartyNum, 978
voice_arrRemotePartyName, 978
voice_arrRemotePartyNum, 979
voice_arrSvcOption, 979
voice_arrUUSInfo, 980
voice_getCallFWExtInfo, 1004
voice_getCallFWInfo, 1004
wds_DomainNameList, 1027
wds_PCSCFFQDNAddressList, 1031
wds_PCSCFIPv4ServerAddressList, 1032
numLen
voice_calledPartyInfo, 982
voice_callFWExtInfo, 986
voice_callFWInfo, 988
voice_callingPartyInfo, 991
voice_peerNumberInfo, 1008
voice_redirNumInfo, 1011
voice_remotePartyNum, 1013
numOfFiles
uim_refreshevent, 558
numOfRoutes
sms_setRoutesReq, 527
numOpt
wds_DHCPLeaseOptTlv, 1022
wds_DHCPv4OptionList, 1025
wdsDhcpv4OptionList, 1039
numPI
voice_peerNumberInfo, 1008
NumPilots
nas_PilotSetData, 234
numPlan
voice_calledPartyInfo, 982
voice_callFWExtInfo, 987
voice_callingPartyInfo, 991
voice_connectNumInfo, 996
voice_peerNumberInfo, 1008
voice_redirNumInfo, 1011
numPresInd
voice_connectNumInfo, 996
numQosFlow
unpack_qos_SLQSQosSwiReadDataStats_t, 793
numRadioInterfaces
nas_servSystem, 264
NumRxFilters
unpack_qos_QosFlowInfo_t, 788
numSI

voice_peerNumberInfo, 1008
numSlot
uim_cardStatus, 547
NumSupUSBComps
unpack_dms_GetUSBComp_t, 598
NumTxFilters
unpack_qos_QosFlowInfo_t, 788
numType
voice_calledPartyInfo, 982
voice_callFWExtInfo, 987
voice_callingPartyInfo, 991
voice_connectNumInfo, 997
voice_peerNumberInfo, 1008
voice_redirNumInfo, 1011
number
voice_calledPartyInfo, 982
voice_callFWExtInfo, 986
voice_callFWInfo, 987
voice_callingPartyInfo, 991
voice_ECTNum, 1001
voice_peerNumberInfo, 1008
voice_redirNumInfo, 1011
numberPlan
voice_callFwdTypeAndPlan, 985
numberType
voice_callFwdTypeAndPlan, 985
NxtHdrProto
unpack_qos_swiQosFilter_t, 800

OKtoRefresh
pack_uim_SLQSUIMRefreshOK_t, 453
OMADMEnable
pack_swioma_SLQSOMADMSetSettingsExt_t, 442
OMADMEnabled
unpack_swiavms_SLQSAVMSGetSettings_t, 836
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
unpack_swioma_SLQSOMADMGetSettings_t, 853
OMADMLogEnable
pack_swioma_SLQSOMADMSetSettingsExt_t, 442
OTASPStatus
unpack_voice_OTASPStatusCallback_ind_t, 873
oddEvenInd
voice_calledPartySubAdd, 983
OfflineReason
unpack_dms_GetPower_t, 594
offset
uim_readTransparentInfo, 556
oldPINLen
uim_changeUIMPIN, 548
oldPINVal
uim_changeUIMPIN, 548
oldPasswd
pack_voice_SLQSVoiceSetCallBarringPassword_t, 470
oldValue
pack_dms_UIMChangePIN_t, 330
opMode
unpack_dms_SLQSDmsSwiGetPCInfo_t, 609
opaqueId
pack_loc_SLQSLOCInjectSensorData_t, 356
operatingMode
dms_OperatingModeTlv, 53
OperatingModeTlv
unpack_dms_SetEventReport_ind_t, 603
operation
pack_pds_SetPDSDefaults_t, 401
uim_depersonalizationInformation, 549
OperationMode
unpack_dms_GetPower_t, 594
optCode
wds_DHCPOpt, 1023
wds_DHCPv4Option, 1025
wdsDhcpv4Option, 1039
optList
wds_DHCPLeaseOptTlv, 1022
optListData
wds_DHCPLeaseOptTlv, 1022
optVal
wds_DHCPv4Option, 1025
wdsDhcpv4Option, 1039
optValLen
wds_DHCPOpt, 1023
wds_DHCPv4Option, 1025
wdsDhcpv4Option, 1039
otaMsgTlv
NASQmiCbkNasSwiOTAMessageInd, 302

p1Status
unpack_dms_UIMGetPINStatus_t, 635
p1UnblockRetriesLeft
unpack_dms_UIMGetPINStatus_t, 635
p1VerifyRetriesLeft
unpack_dms_UIMGetPINStatus_t, 635
p2Status
unpack_dms_UIMGetPINStatus_t, 635
p2UnblockRetriesLeft
unpack_dms_UIMGetPINStatus_t, 635
p2VerifyRetriesLeft
unpack_dms_UIMGetPINStatus_t, 635
p3GPP2TimeInfo
unpack_nas_SLQSGetNetworkTime_t, 714
p3GPPTimeInfo
unpack_nas_SLQSGetNetworkTime_t, 714
p3GppNetworkInfoInstances
unpack_nas_PerformNetworkScan_t, 707
p3GppNetworkInstanceSize
unpack_nas_PerformNetworkScan_t, 707
p3gppRelease
pack_wds_SLQSSet3GPPConfigItem_t, 493
pAAASPI
pack_wds_SetMobileIPProfile_t, 486
PACK_WDS_IPV4
wds.h, 1446
PACK_WDS_IPV6
wds.h, 1446

pAMRStatus
pack_voice_SLQSVoiceGetConfig_t, 466
pAPN
PackSwiAVMSSettingsAPNInfo, 505
pAPNClass
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pAPNClass3GPP2
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 115
pAPNDisabledFlag
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pAPNEnabled3GPP2
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 115
pAPNInfo
pack_swiavms_SLQSAVMSSetSettings_t, 431
pack_swiavms_SLQSAVMSSetSettings_v2_t, 433
unpack_swiavms_SLQSAVMSGetSettings_t, 836
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
pAPNName
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pAPNnameSize
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pAVRXAVCHeadroom
audio_RXAVCList, 39
pAVRXAVCSens
audio_RXAVCList, 39
pAccelAcceptReady
unpack_loc_SensorStreamingCallback_Ind_t, 687
pAccelSamplesAccepted
unpack_loc_InjectSensorDataCallback_Ind_t, 678
pAccelTempAcceptReady
unpack_loc_SensorStreamingCallback_Ind_t, 687
pAccelTempSamplesAccepted
unpack_loc_InjectSensorDataCallback_Ind_t, 678
pAccoIc
unpack_nas_GetACCOLC_t, 692
pAccuracy
unpack_pds_GetPDSDefaults_t, 770
pAcqOrder
nas_acqOrderPref, 143
nas_AcqOrderPrefTlv, 143
pAcqOrderPref
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPrefExt_t, 736
pActPilotPNElements
nas_NetworkStat1x, 223
pActiveTimer
pack_dms_SLQSSetPowerSaveModeConfig_t, 326
unpack_dms_SLQSGetPowerSaveModeConfig_t, 619
pAddCDMASysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
pAddGSMSysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
pAddHDRSysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
pAddLTESysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
pAddWCDMASysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
pAddrAllocPref
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pAddress
pack_wds_SetMobileIPProfile_t, 486
pAirTimer
pack_voice_SLQSVoiceGetConfig_t, 466
pAirTimerCnt
unpack_voice_SLQSVoiceGetConfig_t, 898
pAirTimerConfig
pack_voice_SLQSVoiceSetConfig_t, 472
pAirTimerStatus
unpack_voice_SLQSVoiceSetConfig_t, 902
pAlertType
unpack_voice_SLQSVoiceGetCallInfo_t, 887
pAlertingPattern
unpack_voice_SLQSVoiceGetCallInfo_t, 887
pAllowLinger
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 115
pAlphaID
unpack_sms_SLQSWmsAsyncRawSendCallBack-_ind_t, 827
pAlphaIDInfo
unpack_voice_SLQSOriginateUSSD_t, 875
unpack_voice_SLQSVoiceDialCall_t, 877
unpack_voice_SLQSVoiceGetCallBarring_t, 883
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 884
unpack_voice_SLQSVoiceGetCallInfo_t, 887
unpack_voice_SLQSVoiceGetCallWaiting_t, 889
unpack_voice_SLQSVoiceGetCLIP_t, 890
unpack_voice_SLQSVoiceGetCLIR_t, 892
unpack_voice_SLQSVoiceGetCNAP_t, 893
unpack_voice_SLQSVoiceGetCOLP_t, 895
unpack_voice_SLQSVoiceGetCOLR_t, 896
unpack_voice_SLQSVoiceSetCallBarringPassword-_t, 901
unpack_voice_SLQSVoiceSetSUPSService_t, 904
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 907
pAltitudeAssumed
unpack_loc_PositionRpt_Ind_t, 685

pAltitudeWrtEllipsoid
pack_pds_SLQSPDSInjectPositionData_t, 406
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pAltitudeWrtMeanSeaLevel
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pAltitudeWrtSealevel
pack_pds_SLQSPDSInjectPositionData_t, 406
pAmrMode
pack_ims_SLQSSetIMSVoIPConfig_t, 341
unpack_ims_SLQSGetIMSVoIPConfig_t, 643
pAmrOctetAligned
pack_ims_SLQSSetIMSVoIPConfig_t, 341
unpack_ims_SLQSGetIMSVoIPConfig_t, 643
pAmrWBMode
pack_ims_SLQSSetIMSVoIPConfig_t, 341
unpack_ims_SLQSGetIMSVoIPConfig_t, 643
pAmrWBOctetAligned
pack_ims_SLQSSetIMSVoIPConfig_t, 341
unpack_ims_SLQSGetIMSVoIPConfig_t, 644
pAmrWbEnable
pack_ims_SLQSSetIMSVoIPConfig_t, 341
unpack_ims_SLQSGetIMSVoIPConfig_t, 643
pApnString
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 115
pApnStringSize
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 115
pApnname
pack_wds_SetDefaultProfile_t, 482
pAppName
loc_LocApplicationInfo, 134
pAppPriority
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 116
pAppProvider
loc_LocApplicationInfo, 134
pAppSubType
unpack_nas_SLQSSwiGetHDRProtSubtype_t, 758
pAppType
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 116
pAppVersion
loc_LocApplicationInfo, 134
pApplication
pack_nas_SetCDMANetworkParameters_t, 362
pApplicationInfo
pack_loc_Start_t, 359
pArrAlertingPattern
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrAlertingType
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrAlphaID
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrCallEndReason
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrCallInfo
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrCalledPartyNum
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrConnectPartyNum
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrDiagInfo
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrRedirPartyNum
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrRemotePartyName
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrRemotePartyNum
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrSvcOption
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pArrUUSInfo
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
pAuth
pack_wds_SLQSStartDataSession_t, 497
pAuthPassword
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 116
pAuthPassword_tSize
LibPackprofile_3GPP2, 116
pAuthPasswordSize
LibpackProfile3GPP2, 104
pAuthProtocol
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 116
pAuthRetryCount
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 116
pAuthStatus
unpack_nas_GetANAAAAuthenticationStatus_t, 693
pAuthTimeout
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 116
pAuthenticateResult
unpack_uim_SLQSUIMAuthenticate_t, 861
pAuthenticationPref
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pAutoAnsStatus
unpack_voice_SLQSVoiceSetConfig_t, 902
pAutoAnswer

pack_voice_SLQSVoiceGetConfig_t, 466
pack_voice_SLQSVoiceSetConfig_t, 472
pAutoAnswerStat
unpack_voice_SLQSVoiceGetConfig_t, 898
pAutoReboot
pack_swiavms_SLQSAVMSSetSettings_v2_t, 433
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
pAutoSelection
unpack_uim_SLQSUIMGetConfiguration_t, 864
pAutosdm
pack_swioma_SLQSOMADMSetSettings_t, 441
pBandPref
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPref_t, 734
unpack_nas_SLQSGetSysSelectionPrefExt_t, 736
pBdsSVInfo
pack_loc_Delete_Assist_Data_t, 345
pBinaryUpdateSessionInfo
unpack_swiavms_SLQSAVMSEventReportInd_t, 833
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 839
pBroadcast
pack_nas_SetCDMANetworkParameters_t, 363
pBroadcastConfig
pack_sms_SLQSSetSmsBroadcastConfig_t, 421
unpack_sms_SLQSGetSmsBroadcastConfig_t, 817
pBurstDTMFLengths
pack_voice_SLQSVoiceBurstDTMF_t, 460
pCCResType
unpack_voice_SLQSVoiceGetCallBarring_t, 883
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 884
unpack_voice_SLQSVoiceGetCallWaiting_t, 889
unpack_voice_SLQSVoiceGetCLIP_t, 890
unpack_voice_SLQSVoiceGetCLIR_t, 892
unpack_voice_SLQSVoiceGetCNAP_t, 893
unpack_voice_SLQSVoiceGetCOLP_t, 895
unpack_voice_SLQSVoiceGetCOLR_t, 896
unpack_voice_SLQSVoiceSetCallBarringPassword-_t, 901
pCCResultType
unpack_voice_SLQSVoiceDialCall_t, 877
unpack_voice_SLQSVoiceSetSUPSService_t, 904
pCCSUPSType
unpack_voice_SLQSVoiceDialCall_t, 877
unpack_voice_SLQSVoiceGetCallBarring_t, 883
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 884
unpack_voice_SLQSVoiceGetCallWaiting_t, 889
unpack_voice_SLQSVoiceGetCLIP_t, 890
unpack_voice_SLQSVoiceGetCLIR_t, 892
unpack_voice_SLQSVoiceGetCNAP_t, 893
unpack_voice_SLQSVoiceGetCOLP_t, 895
unpack_voice_SLQSVoiceGetCOLR_t, 896
unpack_voice_SLQSVoiceSetCallBarringPassword-_t, 901
unpack_voice_SLQSVoiceSetSUPSService_t, 904
pCCSuppsType
unpack_voice_SLQSOriginateUSSD_t, 875
pCDMABroadcastConfig
pack_sms_SLQSSetSmsBroadcastConfig_t, 421
unpack_sms_SLQSGetSmsBroadcastConfig_t, 817
pCDMAChannel
unpack_nas_SLQSNasGet3GPP2Subscription_t, 739
pCDMAECIODelta
pack_nas_SLQSNasConfigSigInfo2_t, 370
pCDMAECIOThresh
pack_nas_SLQSNasConfigSigInfo2_t, 370
pCDMAECIOThreshList
nas_CDMAECIOThresh, 150
pCDMAFrameErrRate
unpack_nas_SLQSGetErrorRate_t, 713
pCDMAInfo
unpack_nas_SLQSNasGetCellLocationInfo_t, 741
pCDMARSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 370
pCDMARSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 370
pCDMARSSIThreshList
nas_CDMARSSIThresh, 152
pCDMASigInfo
unpack_nas_SLQSNasSigInfoCallback_ind_t, 752
pCDMASrvStatusInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
pCDMASysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
PCICellInfoLen
nas_QmisNasSlqsNasPCIInfo, 245
pCLIPResp
unpack_voice_SLQSVoiceGetCLIP_t, 890
pCLIPstatus
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pCLIRCause
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pCLIRResp
unpack_voice_SLQSVoiceGetCLIR_t, 892
pCLIRType
pack_voice_SLQSVoiceDialCall_t, 461
pCLIRstatus
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pCNAPResp
unpack_voice_SLQSVoiceGetCNAP_t, 893
pCNAPstatus
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pCOLPResp

unpack_voice_SLQSVoiceGetCOLP_t, 895
pCOLPstatus
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pCOLRResp
unpack_voice_SLQSVoiceGetCOLR_t, 896
pCOLRstatus
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
PCSCFAddrPCO
unpack_wds_SLQSGetRuntimeSettings_t, 945
PCSCFFQDNAddrList
unpack_wds_SLQSGetRuntimeSettings_t, 945
pCSCFPortName
pack_ims_SLQSSetRegMgrConfig_t, 342
pCSCFPortNameLen
pack_ims_SLQSSetRegMgrConfig_t, 342
pCSGID
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
PCTlv
unpack_ims_SLQSRegMgrCfgCallBack_ind_t, 647
pCUGIndex
unpack_voice_SUPSNotificationCallback_ind_t, 910
pCUGInfo
pack_voice_SLQSVoiceDialCall_t, 461
PCURTlv
unpack_ims_SLQSSMSCfgCallBack_ind_t, 652
pCallBarPasswd
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 907
pCallBarringPasswd
pack_voice_SLQSVoiceSetSUPSService_t, 474
pCallFWNum
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pCallFWTimerVal
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pCallForwardingNumber
pack_voice_SLQSVoiceSetSUPSService_t, 474
pCallFwdInfo
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 907
pCallFwdTypeAndPlan
pack_voice_SLQSVoiceSetSUPSService_t, 474
pCallID
pack_voice_SLQSVoiceManageCalls_t, 468
pack_voice_SLQSVoiceSendFlash_t, 469
pack_voice_SLQSVoiceStartContDTMF_t, 475
unpack_voice_SLQSVoiceBurstDTMF_t, 876
unpack_voice_SLQSVoiceDialCall_t, 877
unpack_voice_SLQSVoiceGetCallBarring_t, 883
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 884
unpack_voice_SLQSVoiceGetCallWaiting_t, 889
unpack_voice_SLQSVoiceGetCLIP_t, 890
unpack_voice_SLQSVoiceGetCLIR_t, 892
unpack_voice_SLQSVoiceGetCNAP_t, 893
unpack_voice_SLQSVoiceGetCOLP_t, 895
unpack_voice_SLQSVoiceGetCOLR_t, 896
unpack_voice_SLQSVoiceSendFlash_t, 899
unpack_voice_SLQSVoiceSetCallBarringPassword-_t, 901
unpack_voice_SLQSVoiceSetSUPSService_t, 904
unpack_voice_SLQSVoiceStartContDTMF_t, 904
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
voice_burstDTMFInfo, 981
pCallId
pack_voice_SLQSVoiceAnswerCall_t, 459
pack_voice_SLQSVoiceEndCall_t, 462
unpack_voice_SLQSOriginateUSSD_t, 875
unpack_voice_SLQSVoiceAnswerCall_t, 876
unpack_voice_SLQSVoiceEndCall_t, 878
pCallInfo
unpack_voice_SLQSVoiceGetCallInfo_t, 887
pCallPartySubAdd
pack_voice_SLQSVoiceDialCall_t, 461
pCallType
pack_voice_SLQSVoiceDialCall_t, 461
pCallWaitInd
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pCalledPartyInfo
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pCallerIDInfo
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pCallerNameInfo
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pCallingPartyInfo
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pCampedCiotLteOpMode
unpack_nas_SLQSGetSysInfo_t, 729
pCardResult
unpack_uim_ReadTransparent_t, 859
unpack_uim_SLQSUIMAuthenticate_t, 862
unpack_uim_SLQSUIMGetFileAttributes_t, 864
pCardStatus
unpack_uim_GetCardStatus_t, 858
unpack_uim_SLQSUIMSetStatusChangeCall-Back_ind_t, 867
pCcResultType
unpack_voice_SLQSOriginateUSSD_t, 875
pCellDataMask
pack_pds_ResetPDSData_t, 399
pCellDb
pack_loc_Delete_Assist_Data_t, 345
pChangeDuration
pack_nas_SLQSInitiateNetworkRegistration_t, 367
pChgDuration
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
pCiotAcqOrder
nas_ciotAcqOrderPref, 158
nas_CiotAcqOrderPrefTlv, 159

pCiotAcqOrderPref
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPrefExt_t, 736
pCiotLteOpMode
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
pCiotLteOpModePref
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPrefExt_t, 736
pClientPerformOperationFlag
pack_swiavms_SLQSAVMSSendSelection_t, 429
pClkInfo
pack_loc_Delete_Assist_Data_t, 345
pCodecSTGain
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pColorCode
unpack_nas_SLQSNasGetHDRColorCode_t, 744
pConfig
unpack_swiavms_SLQSAVMSEventReportInd_t, 833
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 839
pConfigAltitudeAssumed
pack_loc_Start_t, 359
pConfigurationMask
pack_uim_SLQSUIMGetConfiguration_t, 449
pConnectNumInfo
unpack_voice_SLQSVoiceGetCallInfo_t, 887
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pConnectionRequest
unpack_swiavms_SLQSAVMSEventReportInd_t, 833
pConnectionRetryTimers
pack_swiavms_SLQSAVMSSetSettings_t, 431
pack_swiavms_SLQSAVMSSetSettings_v2_t, 433
unpack_swiavms_SLQSAVMSGetSettings_t, 836
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
pCreateProfileOut
unpack_wds_SLQSCreateProfile_t, 932
pCsgId
unpack_nas_SLQSNasNetworkRejectCallback_-Ind_t, 750
pCurAMRConfig
unpack_voice_SLQSVoiceGetConfig_t, 898
pCurPrefVoiceSO
unpack_voice_SLQSVoiceGetConfig_t, 898
pCurProfile
pack_wds_SLQSCreateProfile_t, 487
pCurVoiceDomainPref
unpack_voice_SLQSVoiceGetConfig_t, 898
pCurVoicePrivacyPref
unpack_voice_SLQSVoiceGetConfig_t, 898
pCurrChannelRateInd
pack_wds_SLQSWdsSetEventReport_t, 499
pCurrDataBearerTechInd
pack_wds_SLQSWdsSetEventReport_t, 499
pCurrImgInfo
unpack_dms_SLQSSwiGetFirmwareCurr_t, 623
pCurrPrefDataSysInd
pack_wds_SLQSWdsSetEventReport_t, 499
pCurrTTYMode
unpack_voice_SLQSVoiceGetConfig_t, 898
pCurrentPersonality
nas_HDRPersonality_Ind_Data, 186
unpack_nas_SLQSSwiGetHDRPersonality_t, 757
pCurrentPrsnlty
unpack_nas_SLQSSwiGetHDRProtSubtype_t, 758
pCustSettingInfo
DMSgetCustomFeatureV2, 63
pCustSettingList
DMSgetCustomFeatureV2, 63
pCustomSCP
pack_nas_SetCDMANetworkParameters_t, 363
pCwtMute
pack_swiaudio_SLQSSetM2MAudioProfile_t, 426
pack_swiaudio_SLQSSetM2MAVMute_t, 428
pCycleLen
pack_nas_SLQSNASSeteDRXParams_t, 377
unpack_nas_SLQSNASGeteDRXParams_t, 742
unpack_nas_SLQSNASGeteDRXParamsExt_t, 743
pDDTMInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
PDOP
loc_precisionDilution, 135
PDPType
unpack_wds_SLQSGetRuntimeSettings_t, 945
pDRCParams
unpack_nas_SLQSSwiGetHRPDStats_t, 759
pDTMFTXGain
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pData
pack_cat_CATSendEnvelopeCommand_t, 315
pack_cat_CATSendTerminalResponse_t, 316
pDataBearer
unpack_wds_GetDataBearerTechnology_t, 918
pDataBearerTechInd
pack_wds_SLQSWdsSetEventReport_t, 499
pDataCallStatusChangeInd
pack_wds_SLQSWdsSetEventReport_t, 499
pDataMode
LibpackProfile3GPP2, 104
LibPackprofile_3GPP2, 116
pDataRate
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pDataSessionStatus
unpack_swiavms_SLQSAVMSEventReportInd_t, 833
pDataSrc
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pDataStatusDetail
unpack_nas_SLQSSwiNetworkDebug_t, 762

pDataSystemStatusChangeInd
pack_wds_SLQSWdsSetEventReport_t, 499
pDayltSavAdj
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t, 751
pDefaultPDNEnabled
pack_wds_SLQSSet3GPPConfigItem_t, 493
pDeferTime
pack_swiavms_SLQSAVMSSendSelection_t, 429
pack_swioma_SLQSOMADMSendSelection_t, 439
pDestSMSContent
pack_dms_SLQSSwiSetDyingGaspCfg_t, 327
packgetDyingGaspCfg, 501
pDestSMSNum
pack_dms_SLQSSwiSetDyingGaspCfg_t, 327
packgetDyingGaspCfg, 501
pDetachAction
pack_nas_SLQSSwiPSDetach_t, 398
pDeviceConfigDetail
unpack_nas_SLQSSwiNetworkDebug_t, 762
pDiagInfo
unpack_voice_SLQSVoiceGetCallInfo_t, 887
pDigitBuff
voice_burstDTMFInfo, 981
pDirNum
unpack_nas_SLQSNasGet3GPP2Subscription_t, 739
pDispInfo
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pDormancyStatusInd
pack_wds_SLQSWdsSetEventReport_t, 500
pDualStandByPrefInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pDuration
unpack_pds_GetXTRAValidity_t, 775
pDurationDueToOOS
unpack_dms_SLQSGetPowerSaveModeConfig_t, 619
pDurationThreshold
unpack_dms_SLQSGetPowerSaveModeConfig_t, 619
pECIOThresList
nas_ECIOThresh, 170
pECIOThresh
pack_nas_SLQSConfigSigInfo_t, 365
pECMode
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pECTNum
unpack_voice_SUPSNotificationCallback_ind_t, 910
PER
nas_NetworkStatEVDO, 225
pEVDOPageMonPerChangeInd
pack_wds_SLQSWdsSetEventReport_t, 500
pEarMute
pack_swiaudio_SLQSSetM2MAudioProfile_t, 426
pEarlyWakeupTime
unpack_dms_SLQSGetPowerSaveModeConfig_t, 619
pEdrxChangeInfoInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pEdrxCiotLteMode
pack_nas_SLQSNASSeteDRXParams_t, 377
pEdrxEnable
pack_nas_SLQSNASSeteDRXParams_t, 378
unpack_nas_SLQSNASGeteDRXParams_t, 742
unpack_nas_SLQSNASGeteDRXParamsExt_t, 743
pEdrxRAT
pack_nas_SLQSNASGeteDRXParamsExt_t, 373
unpack_nas_SLQSNASGeteDRXParamsExt_t, 743
pEdrxRatType
pack_nas_SLQSNASSeteDRXParams_t, 378
pEhrpdMTUSize
unpack_swidms_SLQSSwiDmsGetMTU_t, 843
pEmerMode
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPref_t, 734
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pEmergencyCategory
pack_voice_SLQSVoiceDialCall_t, 461
pEnableNotification
pack_wds_DHCPv4ClientLeaseChange_t, 476
pEnabled
pack_wds_SetMobileIPProfile_t, 486
pEnabledStatus
unpack_pds_GetPDSState_t, 771
pEncryptData
pack_uim_ReadTransparent_t, 446
pEncryptedData
unpack_uim_ReadTransparent_t, 859
pEncryptedPIN1
pack_uim_VerifyPin_t, 456
unpack_uim_ChangePin_t, 857
unpack_uim_SetPinProtection_t, 860
unpack_uim_UnblockPin_t, 867
unpack_uim_VerifyPin_t, 868
pErrorRateInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pExtDispInfo
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pExtDispRecInfo
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pExtErrCode
UnPackGetProfileSettingOut, 960
pExtErrorCode
unpack_wds_SLQSModifyProfile_t, 946
pFailCause
unpack_voice_SLQSVoiceGetCallBarring_t, 883
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 884
unpack_voice_SLQSVoiceGetCallWaiting_t, 889

unpack_voice_SLQSVoiceGetCLIP_t, 891
unpack_voice_SLQSVoiceGetCLIR_t, 892
unpack_voice_SLQSVoiceGetCNAP_t, 893
unpack_voice_SLQSVoiceGetCOLP_t, 895
unpack_voice_SLQSVoiceGetCOLR_t, 896
unpack_voice_SLQSVoiceManageCalls_t, 899
unpack_voice_SLQSVoiceSetCallBarringPassword_t, 901
unpack_voice_SLQSVoiceSetSUPSService_t, 904
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pFailureReason
unpack_wds_SLQSStartDataSession_t, 956
pFileAttributes
unpack_uim_SLQSUIMGetFileAttributes_t, 864
pFixId
unpack_loc_PositionRpt_Ind_t, 685
pFlag
audio_RXPCMIIRFltr, 41
audio_TXPCMIIRFltr, 43
pFlashPayLd
pack_voice_SLQSVoiceSendFlash_t, 469
pFlashType
pack_voice_SLQSVoiceSendFlash_t, 469
pFollowOnDC
sms_sendAsyncsmsParams, 525
pForbiddenNetworks3GPP
unpack_nas_SLQSNASGetForbiddenNetworks_t, 744
pForceOnDC
sms_sendAsyncsmsParams, 525
pForceRev0
pack_nas_SetCDMANetworkParameters_t, 363
pFwAutoCheck
pack_swioma_SLQSOMADMSetSettings_t, 441
pFwAutoSDM
pack_swiavms_SLQSAVMSSetSettings_t, 431
pack_swiavms_SLQSAVMSSetSettings_v2_t, 433
pGERANInfo
unpack_nas_SLQSNasGetCellLocationInfo_t, 741
pGPRSMinimumQoS
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pGPRSRequestedQos
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pGPSDataMask
pack_pds_ResetPDSData_t, 400
pGPSWeek
unpack_pds_GetXTRAValidity_t, 775
pGPSWeekOffset
unpack_pds_GetXTRAValidity_t, 775
pGSMBER
unpack_nas_SLQSGetErrorRate_t, 713
pGSMCallBarringSysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
pGSMCipherDomainSysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
pGSMRSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 370
pGSMRSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 370
pGSMRSSIThreshList
nas_GSMRSSIThresh, 180
pGSMSigInfo
unpack_nas_SLQSNasSigInfoCallback_ind_t, 752
pGSMSrvStatusInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
pGSMSysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
pGWAcqOrderPref
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPref_t, 734
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pGenerator
pack_swiaudio_SLQSGetM2MAudioProfile_t, 423
pack_swiaudio_SLQSSetM2MAudioProfile_t, 426
pGetCallFWExtInfo
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 885
pGetCallFWInfo
unpack_voice_SLQSVoiceGetCallForwarding-Status_t, 885
pGetCustomInput
DMSgetCustomFeatureV2, 63
pGetDyingGaspCfg
unpack_dms_SLQSSwiGetDyingGaspCfg_t, 622
pGetDyingGaspStatistics
unpack_dms_SLQSSwiGetDyingGaspStatistics_t, 622
pGetIndicationRegInfo
unpack_sms_SLQSGetIndicationRegister_t, 815
pGetMsgWaitingInfoResp
unpack_sms_SLQSGetMessageWaiting_t, 815
pGetTransLayerInfo
unpack_sms_SLQSGetTransLayerInfo_t, 818
pGetTransNWRegInfo
unpack_sms_SLQSGetTransNWRegInfo_t, 819
pGnssData
pack_loc_Delete_Assist_Data_t, 345
pGpsTime
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pGyroAcceptReady
unpack_loc_SensorStreamingCallback_Ind_t, 687
pGyroSamplesAccepted
unpack_loc_InjectSensorDataCallback_Ind_t, 678
pGyroTempAcceptReady
unpack_loc_SensorStreamingCallback_Ind_t, 687
pGyroTempSamplesAccepted
unpack_loc_InjectSensorDataCallback_Ind_t, 678

pHA2002bis
pack_wds_SetMobileIPParameters_t, 484
pHAAuthenticator
pack_wds_SetMobileIPParameters_t, 484
pHASPI
pack_wds_SetMobileIPProfile_t, 486
pHDRECIODelta
pack_nas_SLQSNasConfigSigInfo2_t, 370
pHDRECIOThresh
pack_nas_SLQSNasConfigSigInfo2_t, 370
pHDRECIOThreshList
nas_HDRECIOThresh, 185
pHDRIODelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pHDRIOThresh
pack_nas_SLQSNasConfigSigInfo2_t, 371
pHDRIOThreshList
nas_HDRIOThresh, 185
pHDRNewUATIAssInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pHDRPackErrRate
unpack_nas_SLQSGetErrorRate_t, 713
pHDRPersInd
unpack_nas_SLQSSwiHDRPersonalityCallback_-Ind_t, 761
pHDRRSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pHDRRSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 371
pHDRRSSIThreshList
nas_HDRRSSIThresh, 186
pHDRSINRDelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pHDRSINRThresList
nas_HDRSINRThresh, 187
pHDRSINRThresh
pack_nas_SLQSConfigSigInfo_t, 365
pack_nas_SLQSNasConfigSigInfo2_t, 371
pHDRSINRThreshList
nas_HDRSINRThreshold, 188
pHDRSessionCloseInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pHDRSigInfo
unpack_nas_SLQSNasSigInfoCallback_ind_t, 752
pHDRSrvStatusInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 765
pHDRSysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 766
pHTTPStatus
unpack_swiavms_SLQSAVMSEventReportInd_t, 833
pHaltSubscription
unpack_uim_SLQSUIMGetConfiguration_t, 864
pHeading
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pHeadingUnc
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pHomeSIDNID
unpack_nas_SLQSNasGet3GPP2Subscription_t, 739
pHorCirConf
unpack_loc_BestAvailPos_Ind_t, 668
pHorConfidence
unpack_loc_PositionRpt_Ind_t, 685
pHorEllpConf
unpack_loc_BestAvailPos_Ind_t, 668
pHorReliability
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pHorUncCircular
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pHorUncEllipseOrientAzimuth
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pHorUncEllipseSemiMajor
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pHorUncEllipseSemiMinor
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pHorizontalAccuracyLvl
pack_loc_Start_t, 359
pHorizontalConfidence
pack_pds_SLQSPDSInjectPositionData_t, 406
pHorizontalUncCircular
pack_pds_SLQSPDSInjectPositionData_t, 406
pHotSwapStatus
unpack_uim_GetCardStatus_t, 858
pHrpdMTUSize
unpack_swidms_SLQSSwiDmsGetMTU_t, 843
pHwConfig
pack_wds_SLQSSSetDHCPv4ClientConfig_t, 496
unpack_wds_SLQSSGetDHCPv4ClientConfig_t, 955
PI
voice_calledPartyInfo, 982
voice_callerIDInfo, 984
voice_callFWExtInfo, 987
voice_callingPartyInfo, 991
voice_redirNumInfo, 1011
PIFACEId
pack_swiaudio_SLQSSetM2MAudioAVCFG_t, 425
pIMSDomain
pack_ims_SLQSSetIMSUserConfig_t, 338
unpack_ims_SLQSGetIMSUserConfig_t, 641
pIMSDomainLen
pack_ims_SLQSSetIMSUserConfig_t, 338
unpack_ims_SLQSGetIMSUserConfig_t, 641
pIMSTestMode
pack_ims_SLQSSetRegMgrConfig_t, 342
unpack_ims_SLQSGetRegMgrConfig_t, 645

pIOThresList
nas_IOThresh, 192
pIOThresh
pack_nas_SLQSConfigSigInfo_t, 365
pIPv4AddrInfo
unpack_loc_GetServer_Ind_t, 675
pIPv4AddrPref
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pIPv4Config
pack_loc_SLQSLOCSetServer_t, 358
pIPv6AddPref
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pIPv6AddrInfo
unpack_loc_GetServer_Ind_t, 675
pIPv6Config
pack_loc_SLQSLOCSetServer_t, 358
pIgnoreHotSwapSwitch
pack_uim_SLQSUIMPowerUp_t, 451
pImCnFlag
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pImageList
pack_fms_SetImagesPreference_t, 336
unpack_fms_GetImagesPreference_t, 638
pIndicationToken
pack_uim_ChangePin_t, 445
pack_uim_ReadTransparent_t, 446
pack_uim_SetPinProtection_t, 447
pack_uim_SLQSUIMAuthenticate_t, 448
pack_uim_SLQSUIMGetFileAttributes_t, 450
pack_uim_UnblockPin_t, 455
pack_uim_VerifyPin_t, 456
unpack_uim_ChangePin_t, 857
unpack_uim_ReadTransparent_t, 859
unpack_uim_SetPinProtection_t, 860
unpack_uim_SLQSUIMAuthenticate_t, 862
unpack_uim_SLQSUIMGetFileAttributes_t, 864
unpack_uim_UnblockPin_t, 868
unpack_uim_VerifyPin_t, 868
pInfo
pack_voice_AnswerUSSD_t, 457
pack_voice_OriginateUSSD_t, 457
pInstanceSize
nas_RfBandInfoList, 250
pInstancesSize
nas_RfBandInfoExtFormat, 249
nas_RfBandwidthInfo, 251
nas_RfDedicatedBandInfo, 252
pInterfaceCfg
unpack_swidms_SLQSSwiDmsGetUsbComp_t, 844
pIntermediateReportState
pack_loc_Start_t, 359
pInterval
unpack_pds_GetPDSDefaults_t, 770
unpack_pds_GetXTRAAutomaticDownload_t, 773
pIpcpAckTimeout
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pIpcpCreqRetryCount
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pIsPcscfAddressNedded
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pKeyReferenceID
pack_uim_ChangePin_t, 445
pack_uim_SetPinProtection_t, 447
pack_uim_UnblockPin_t, 455
pack_uim_VerifyPin_t, 456
PLMNData
nas_operatorPLMNList, 229
PLMNName
nas_operatorNameString, 227
PLMNNetName
nas_PLMNNetworkName, 236
PLMNRecID
nas_OperatorPLMNData, 228
pLTEAttachProfile
pack_wds_SLQSSet3GPPConfigItem_t, 493
pLTEAttachProfileList
pack_wds_SLQSSet3GPPConfigItem_t, 493
pLTEBandPref
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPref_t, 734
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pLTEBandPrefExt
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pLTECphyCa
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pLTEInfo
unpack_nas_SLQSNasSwiModemStatus_t, 754
pLTEInfoInterfreq
unpack_nas_SLQSNasGetCellLocationInfo_t, 741
pLTEInfoIntrafreq
unpack_nas_SLQSNasGetCellLocationInfo_t, 741
pLTEInfoNeighboringGSM
unpack_nas_SLQSNasGetCellLocationInfo_t, 741
pLTEInfoNeighboringWCDMA
unpack_nas_SLQSNasGetCellLocationInfo_t, 741
pLTEOperationMode
nas_LTEOperationMode, 207
unpack_nas_SLQSNasGetRFInfo_t, 745
pLTERSRPDelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pLTERSRPThresh
pack_nas_SLQSNasConfigSigInfo2_t, 371
pLTERSRPThreshList
nas_LTERSRPThresh, 209
pLTERSRQDelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pLTERSRQThresh

pack_nas_SLQSNasConfigSigInfo2_t, 371
pLTERSRQThreshList
nas_LTERSRQThresh, 210
pLTERSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pLTERSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 371
pLTERSSIThreshList
nas_LTERSSIThresh, 210
pLTESNRDelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pLTESNRThresList
nas_LTESNRThresh, 213
pLTESNRThresh
pack_nas_SLQSConfigSigInfo_t, 365
pack_nas_SLQSNasConfigSigInfo2_t, 371
pLTESNRThreshList
nas_LTESNRThreshold, 214
pLTESigInfo
unpack_nas_SLQSNasSigInfoCallback_ind_t, 752
pLTESigRptCfg
pack_nas_SLQSConfigSigInfo_t, 365
pLTESigRptConfig
pack_nas_SLQSNasConfigSigInfo2_t, 371
pLTESrvStatusInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 766
pLTESysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 766
pLTEVoiceSupportSysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 766
pLatitude
pack_pds_SLQSPDSInjectPositionData_t, 406
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pLcpAckTimeout
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pLcpCreqRetryCount
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pLeapSeconds
unpack_loc_PositionRpt_Ind_t, 685
pLineCtrlInfo
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pLinktimer
pack_sms_SendSMS_t, 414
sms_sendAsyncsmsParams, 525
pLongitude
pack_pds_SLQSPDSInjectPositionData_t, 406
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pLteEARFCN
pack_nas_SLQSNASSwiSetChannelLock_t, 379
unpack_nas_SLQSNASSwiGetChannelLock_t, 753
pLteM1BandPref
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pLteNb1BandPref
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pLteOpMode
pack_nas_SLQSNASGeteDRXParamsExt_t, 373
unpack_nas_SLQSNASGeteDRXParamsExt_t, 743
unpack_nas_SLQSNasNetworkRejectCallback_-Ind_t, 750
pLtePCI
pack_nas_SLQSNASSwiSetChannelLock_t, 379
unpack_nas_SLQSNASSwiGetChannelLock_t, 753
pMCC
unpack_nas_GetHomeNetwork3GPP2_t, 697
pMICGainSelect
unpack_audio_SLQSGetAudioPathConfig_t, 567
pMIPStatusInd
pack_wds_SLQSWdsSetEventReport_t, 500
pMNAAA
pack_wds_SetMobileIPProfile_t, 486
pMNC
unpack_nas_GetHomeNetwork3GPP2_t, 697
pMNCIncPCSDigStat
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
pMNHA
pack_wds_SetMobileIPProfile_t, 486
pMNRInfo
pack_nas_SLQSInitiateNetworkRegistration_t, 367
pMTUSize3gpp
unpack_swidms_SLQSSwiDmsGetMTU_t, 843
pMagneticDeviation
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 685
pManagedRoamingInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pMaxStorageSizeReq
pack_sms_SLQSSmsGetMaxStorageSize_t, 422
pMaxStorageSizeResp
unpack_sms_SLQSSmsGetMaxStorageSize_t, 823
pMessage
pack_sms_SaveSMS_t, 414
pack_sms_SendSMS_t, 415
sms_sendAsyncsmsParams, 525
pMessageIndex
pack_sms_SLQSDeleteSMS_t, 416
unpack_sms_SaveSMS_t, 811
pMessageMode
pack_sms_SLQSDeleteSMS_t, 416
pack_sms_SLQSGetSMS_t, 417
pack_sms_SLQSGetSMSList_t, 418
pack_sms_SLQSModifySMSStatus_t, 419
sms_maxStorageSizeReq, 519

pMessageProtocol
unpack_sms_SLQSSmsGetMessageProtocol_t, 823
pMessageTag
pack_sms_SLQSDeleteSMS_t, 416
pMicMute
pack_swiaudio_SLQSSetM2MAudioProfile_t, 426
pMinBasedIMSI
unpack_nas_SLQSNasGet3GPP2Subscription_t, 739
pMinIntervalTime
pack_loc_Start_t, 359
pMinSessionExpiryTimer
pack_ims_SLQSSetIMSVoIPConfig_t, 341
unpack_ims_SLQSGetIMSVoIPConfig_t, 644
pMncPcsDigitStatus
pack_nas_SLQSInitiateNetworkRegistration_t, 367
pMncPcsStatus
pack_nas_SLQSGetPLMNName_t, 366
pMode
pack_wds_SetMobileIPParameters_t, 484
pModePref
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPref_t, 734
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pMuxID
pack_qos_BindDataPort_t, 411
pNAI
pack_wds_SetMobileIPProfile_t, 486
pNAMNameInfo
unpack_nas_SLQSNasGet3GPP2Subscription_t, 739
pNID
unpack_nas_GetHomeNetwork3GPP2_t, 697
pNITZInformation
unpack_nas_SLQSGetOperatorNameData_t, 715
pNSEnable
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pNSSAudioCtrl
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pNSSRelease
unpack_voice_VoiceInfoRecCallback_ind_t, 913
PNTlv
unpack_ims_SLQSRegMgrCfgCallBack_ind_t, 647
pNamID
pack_voice_SLQSVoiceGetConfig_t, 466
pName
pack_wds_SetDefaultProfile_t, 482
unpack_nas_GetHomeNetwork3GPP2_t, 697
pNegoDnsSrvrPref
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pNeighborSetPilotPN
nas_NetworkStat1x, 223
pNetSelPref
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPref_t, 734
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pNetworkMode
pack_pds_SLQSGetAGPSConfig_t, 404
pack_pds_SLQSSetAGPSConfig_t, 407
pNetworkRejectInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pNetworkStat1x
unpack_nas_SLQSSwiNetworkDebug_t, 762
pNetworkStatEVDO
unpack_nas_SLQSSwiNetworkDebug_t, 762
pNetworkTimeInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pNetworkType
pack_nas_PerformNetworkScanPCI_t, 361
pNewPwdData
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pNotifStore
pack_swiavms_SLQSAVMSSetSettings_t, 431
pack_swiavms_SLQSAVMSSetSettings_v2_t, 433
pNotification
unpack_swiavms_SLQSAVMSEventReportInd_t, 833
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 840
pNotificationStore
unpack_swiavms_SLQSAVMSGetSettings_t, 836
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
pNr5gBandPref
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pNumberOfPhySlot
unpack_uim_SLQSUIMGetSlotsStatus_t, 865
pNw2DescDisp
unpack_nas_GetHomeNetwork3GPP2_t, 697
pNw2DescEnc
unpack_nas_GetHomeNetwork3GPP2_t, 698
pNw2DescLen
unpack_nas_GetHomeNetwork3GPP2_t, 698
pNw2MCC
unpack_nas_GetHomeNetwork3GPP2_t, 698
pNw2MNC
unpack_nas_GetHomeNetwork3GPP2_t, 698
pNw2Name
unpack_nas_GetHomeNetwork3GPP2_t, 698
pOTASPStatus
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
unpack_voice_SLQSVoiceGetCallInfo_t, 887
pObjectVer
unpack_nas_SLQSSwiNetworkDebug_t, 762
pOffLength
unpack_voice_DTMFEventCallback_ind_t, 871
pOnLength
unpack_voice_DTMFEventCallback_ind_t, 871
pOpaqueIdentifier

unpack_loc_InjectSensorDataCallback_Ind_t, 678
pOperation
unpack_pds_GetPDSDefaults_t, 770
pOperatorNameString
unpack_nas_SLQSGetOperatorNameData_t, 715
pOperatorPLMNList
unpack_nas_SLQSGetOperatorNameData_t, 715
pOptList
wds_DHCPv4OptionList, 1025
wdsDhcpv4OptionList, 1040
pOptVal
wds_DHCPOpt, 1023
pPCIInfo
unpack_nas_PerformNetworkScan_t, 707
pPCMParams
pack_swiaudio_SLQSSetM2MAudioAVCFG_t, 425
pPCSCFPort
unpack_ims_SLQSGetRegMgrConfig_t, 645
pPCSInstance
unpack_nas_PerformNetworkScan_t, 707
pPCSInstanceSize
unpack_nas_PerformNetworkScan_t, 707
pPDNInactivTimeout
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pPDNInactivTimeout3GPP2
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pPDPtype
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pPLMNNetworkName
unpack_nas_SLQSGetOperatorNameData_t, 715
pPRLPref
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 397
unpack_nas_SLQSGetSysSelectionPref_t, 734
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pPWD
PackSwiAVMSSettingsAPNInfo, 505
pPackageID
pack_swiavms_SLQSAVMSSendSelection_t, 429
unpack_swiavms_SLQSAVMSEventReportInd_t, 833
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 840
pPagingTimeWindow
pack_nas_SLQSNASSeteDRXParams_t, 378
unpack_nas_SLQSNASGeteDRXParams_t, 742
unpack_nas_SLQSNASGeteDRXParamsExt_t, 743
pPass
pack_wds_SLQSStartDataSession_t, 497
pPassword
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pack_wds_SetDefaultProfile_t, 482
pPasswordSize
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pPcscfAddrUsingDhcp
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pPcscfAddrUsingPCO
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pPdnType
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pPdpAccessConFlag
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pPdpContext
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pPdpDataCompType
LibpackProfile3GPP, 98
LibPackprofile_3GPP, 110
pPdpHdrCompType
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 110
pPeriodInfo
pack_swiavms_SLQSAVMSSetSettings_t, 431
pack_swiavms_SLQSAVMSSetSettings_v2_t, 433
pPeriodicUpdateTimer
pack_dms_SLQSSetPowerSaveModeConfig_t, 326
unpack_dms_SLQSGetPowerSaveModeConfig_t, 619
pPeripheralEndPointID
pack_qos_BindDataPort_t, 411
pPeroidsInfo
unpack_swiavms_SLQSAVMSGetSettings_t, 836
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
pPersonalityListLength
nas_HDRPersonality_Ind_Data, 186
unpack_nas_SLQSSwiGetHDRPersonality_t, 757
unpack_nas_SLQSSwiGetHDRProtSubtype_t, 758
pPersonalizationStatus
unpack_uim_SLQSUIMGetConfiguration_t, 864
pPhoneCtxtURI
pack_ims_SLQSSetIMSSMSConfig_t, 338
unpack_ims_SLQSGetIMSSMSConfig_t, 640
pPhoneCtxtURILen
pack_ims_SLQSSetIMSSMSConfig_t, 338
unpack_ims_SLQSGetIMSSMSConfig_t, 640
pPilotSetData
unpack_nas_SLQSSwiGetHRPDStats_t, 759
pPilotSetInfo
nas_PilotSetData, 234
pPlmnId
unpack_nas_SLQSNasNetworkRejectCallback_Ind_t, 750
pPollingTimer
pack_swiavms_SLQSAVMSSetSettings_t, 431

pack_swiavms_SLQSAVMSSetSettings_v2_t, 433
unpack_swiavms_SLQSAVMSGetSettings_t, 836
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
pPositionSource
pack_pds_SLQSPDSInjectPositionData_t, 406
pPppSessCloseTimer1x
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pPppSessCloseTimerDO
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pPrecisionDilution
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 686
pPrefVoiceDomain
pack_voice_SLQSVoiceSetConfig_t, 472
pPrefVoicePrivacy
pack_voice_SLQSVoiceGetConfig_t, 466
pPrefVoiceSO
pack_voice_SLQSVoiceGetConfig_t, 466
pack_voice_SLQSVoiceSetConfig_t, 472
pPrefVoiceSOStatus
unpack_voice_SLQSVoiceSetConfig_t, 902
pPreference
unpack_pds_GetXTRANetwork_t, 774
pPriCSCFPort
pack_ims_SLQSSetRegMgrConfig_t, 342
pPriCSCFPortName
unpack_ims_SLQSGetRegMgrConfig_t, 645
pPriCSCFPortNameLen
unpack_ims_SLQSGetRegMgrConfig_t, 645
pPriDNSIPv4AddPref
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pPriDNSIPv6addpref
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pPriV6DnsAddress
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pPrimaryHA
pack_wds_SetMobileIPProfile_t, 486
pPrimaryID
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pPrimaryV4DnsAddress
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pProfileID
unpack_wds_SLQSCreateProfile_t, 932
pProfileId
pack_wds_SLQSCreateProfile_t, 487
pack_wds_SLQSModifyProfile_t, 492
pack_wds_SLQSSGetDHCPv4ClientConfig_t, 495
pack_wds_SLQSSSetDHCPv4ClientConfig_t, 496
pProfileList
pack_wds_SLQSSet3GPPConfigItem_t, 493
pProfileSettings
unpack_wds_SLQSGetProfileSettings_t, 942
pProfileType
pack_wds_SLQSCreateProfile_t, 487
pack_wds_SLQSModifyProfile_t, 492
pProfilename
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pProfilenameSize
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pProtoSubTypElmnt
unpack_nas_SLQSSwiGetHDRProtSubtype_t, 758
pProtocol
pack_nas_SetCDMANetworkParameters_t, 363
pProtocolSubtypeElement
nas_HDRPersonality_Ind_Data, 186
unpack_nas_SLQSSwiGetHDRPersonality_t, 757
pPsmEnableState
pack_dms_SLQSSetPowerSaveModeConfig_t, 326
unpack_dms_SLQSGetPowerSaveModeConfig_t, 619
pQosClassID
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pRAT
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 398
pRATINstance
unpack_nas_PerformNetworkScan_t, 707
pRATInstanceSize
unpack_nas_PerformNetworkScan_t, 707
pRATType
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pRFBandInfoParam
nas_RfBandInfoList, 250
PRIString
unpack_dms_GetFirmwareRevision_t, 587
unpack_dms_GetFirmwareRevisions_t, 588
PRLEnable
pack_swioma_SLQSOMADMSetSettingsExt_t, 442
PRLInd
unpack_nas_SLQSGetServingSystem_t, 723
PRLPTlv
NASQmiCbkNasSystemSelPrefInd, 304
PRLPref
nas_PRLPrefTlv, 239
NASPRLPreferenceTlv, 302
pRSRPThresList
nas_RSRPThresh, 256
pRSRPThresh
pack_nas_SLQSConfigSigInfo_t, 365
pRSRQThresList
nas_RSRQThresh, 257
pRSRQThresh

pack_nas_SLQSConfigSigInfo_t, 365
pRSSIThresList
nas_RSSIThresh, 258
pRSSIThresh
pack_nas_SLQSConfigSigInfo_t, 365
pRTPRTCPInactTimer
pack_ims_SLQSSetIMSVoIPConfig_t, 341
unpack_ims_SLQSGetIMSVoIPConfig_t, 644
pRXAGCList
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pRXAIG
audio_RXAGCList, 38
pRXAVCAGCSwitch
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pRXAVCList
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pRXChain0Info
unpack_nas_SLQSNasGetTxRxInfo_t, 747
pRXChain1Info
unpack_nas_SLQSNasGetTxRxInfo_t, 747
pRXComprSlope
audio_RXAGCList, 39
pRXComprThres
audio_RXAGCList, 39
pRXDroppedCount
unpack_wds_GetPacketStatistics_t, 927
pRXExpSlope
audio_RXAGCList, 39
pRXExpThres
audio_RXAGCList, 39
pRXOKBytesLastCall
unpack_wds_GetPacketStatistics_t, 927
pRXOkBytesCount
unpack_wds_GetPacketStatistics_t, 927
pRXPCMIIRFltr
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pRXPacketErrors
unpack_wds_GetPacketStatistics_t, 927
pRXPacketOverflows
unpack_wds_GetPacketStatistics_t, 927
pRXPacketSuccesses
unpack_wds_GetPacketStatistics_t, 927
pRXStaticGain
audio_RXAGCList, 39
pRXTotalBytes
unpack_wds_GetByteTotals_t, 916
pRadioInterface
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t, 751
pRandomizationWindow
unpack_dms_SLQSGetPowerSaveModeConfig_t, 619
pRankIndicatorInd
pack_nas_SLQSNasSwiIndicationRegister_t, 379
pRatDisabledMask
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pReRegPeriod
pack_wds_SetMobileIPParameters_t, 484
pReRegTraffic
pack_wds_SetMobileIPParameters_t, 484
pReadResult
unpack_uim_ReadTransparent_t, 859
pReason
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pReasonMask
unpack_dms_GetOfflineReason_t, 593
pRecurrenceType
pack_loc_Start_t, 359
pRedirNumInfo
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pRefreshEvent
unpack_uim_SLQSUIMRefreshGetLastEvent_t, 866
pRegCallStatInfoEvt
sms_getIndicationReg, 517
sms_setIndicationReg, 526
pRegDTMFEvents
pack_voice_SLQSVoiceIndicationRegister_t, 467
pRegInd
sms_getTransLayerInfo, 518
pRegMgrConfigEvents
pack_ims_SLQSImsConfigIndicationRegister_t, 337
pRegStatus
sms_getTransNWRegInfo, 518
unpack_swiavms_SLQSAVMSEventReportInd_t, 833
pRegTransLayerInfoEvt
sms_getIndicationReg, 517
sms_setIndicationReg, 526
pRegTransNWRegInfoEvt
sms_getIndicationReg, 517
sms_setIndicationReg, 526
pRegVoicePrivacyEvents
pack_voice_SLQSVoiceIndicationRegister_t, 467
pRejectReason
pack_swiavms_SLQSAVMSSendSelection_t, 429
pack_swioma_SLQSOMADMSendSelection_t, 439
pRemainingRetries
unpack_uim_ChangePin_t, 857
unpack_uim_SetPinProtection_t, 860
unpack_uim_SLQSUIMDepersonalization_t, 862
unpack_uim_UnblockPin_t, 868
unpack_uim_VerifyPin_t, 868
pRemotePartyName
unpack_voice_SLQSVoiceGetCallInfo_t, 887
pRemotePartyNum
unpack_voice_SLQSVoiceGetCallInfo_t, 887
pReportChannelRate
pack_wds_SLQSGetDUNCallInfo_t, 489

pReportConnStatus
pack_wds_SLQSGetDUNCallInfo_t, 489
pReportDataBearerTech
pack_wds_SLQSGetDUNCallInfo_t, 489
pReportDormStatus
pack_wds_SLQSGetDUNCallInfo_t, 489
pReqSettings
pack_wds_SLQSGetRuntimeSettings_t, 491
pRequestOptionList
pack_wds_SLQSSSetDHCPv4ClientConfig_t, 496
unpack_wds_SLQSSGetDHCPv4ClientConfig_t, 955
pRequestedTag
pack_sms_SLQSGetSMSList_t, 418
pRetryInterval
pack_wds_SetMobileIPParameters_t, 484
pRetryLimit
pack_wds_SetMobileIPParameters_t, 484
pRetryMessage
sms_sendAsyncsmsParams, 525
pRetryMessageId
sms_sendAsyncsmsParams, 525
pRevInUse
nas_CDMASysInfo, 156
pRevInUseValid
nas_CDMASysInfo, 156
pRevTunneling
pack_wds_SetMobileIPProfile_t, 486
pRfBandInfoExtFormat
unpack_nas_SLQSNasGetRFInfo_t, 745
pRfBandInfoExtFormatParam
nas_RfBandInfoExtFormat, 249
pRfBandwidthInfo
unpack_nas_SLQSNasGetRFInfo_t, 745
pRfBandwidthInfoParam
nas_RfBandwidthInfo, 251
pRfDedicatedBandInfo
unpack_nas_SLQSNasGetRFInfo_t, 745
pRfDedicatedBandInfoParam
nas_RfDedicatedBandInfo, 252
pRingBackTimer
pack_ims_SLQSSetIMSVoIPConfig_t, 341
unpack_ims_SLQSGetIMSVoIPConfig_t, 644
pRingingTimer
pack_ims_SLQSSetIMSVoIPConfig_t, 341
unpack_ims_SLQSGetIMSVoIPConfig_t, 644
pRoamPref
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 398
unpack_nas_SLQSGetSysSelectionPref_t, 734
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pRoamTimer
pack_voice_SLQSVoiceGetConfig_t, 466
pRoamTimerCnt
unpack_voice_SLQSVoiceGetConfig_t, 898
pRoamTimerConfig
pack_voice_SLQSVoiceSetConfig_t, 472
pRoamTimerStatus
unpack_voice_SLQSVoiceSetConfig_t, 902
pRoaming
pack_nas_SetCDMANetworkParameters_t, 363
pRscp
unpack_nas_SLQSNasSigInfoCallback_ind_t, 752
PSDomain
unpack_nas_GetServingNetwork_t, 704
pSID
unpack_nas_GetHomeNetwork3GPP2_t, 698
pSIODataPort
pack_qos_BindDataPort_t, 411
pSIPConfigEvents
pack_ims_SLQSImsConfigIndicationRegister_t, 337
pSIPLocalPort
pack_ims_SLQSSetSIPConfig_t, 343
unpack_ims_SLQSGetSIPConfig_t, 646
PSMCfgChangeInfo
pack_dms_SetIndicationRegister_t, 323
pSMSAttemptedFlag
packgetDyingGaspStatistics, 502
pSMSCAddress
pack_sms_SetSMSCAddress_t, 415
unpack_sms_GetSMSCAddress_t, 810
pSMSCType
pack_sms_SetSMSCAddress_t, 415
unpack_sms_GetSMSCAddress_t, 810
pSMSConfigEvents
pack_ims_SLQSImsConfigIndicationRegister_t, 337
pSMSFormat
pack_ims_SLQSSetIMSSMSConfig_t, 338
unpack_ims_SLQSGetIMSSMSConfig_t, 640
pSMSOverIPNwInd
pack_ims_SLQSSetIMSSMSConfig_t, 338
unpack_ims_SLQSGetIMSSMSConfig_t, 640
PSMStatus
pack_dms_SetIndicationRegister_t, 323
pSPC
pack_nas_SetCDMANetworkParameters_t, 363
pack_wds_SetMobileIPParameters_t, 484
pSV
loc_BdsSVInfo, 125
loc_SVInfo, 139
pSVInfo
pack_loc_Delete_Assist_Data_t, 345
pSarRFState
unpack_sar_SLQSGetRfSarState_t, 809
pSatelliteInfo
unpack_loc_GnssSvInfo_Ind_t, 676
pScanResult
unpack_nas_PerformNetworkScan_t, 707
pScanType
pack_nas_PerformNetworkScanPCI_t, 361
pSccRxInfo
unpack_nas_SLQSSwiGetLteSccRxInfo_t, 760
pScrAmrEnable
pack_ims_SLQSSetIMSVoIPConfig_t, 341

unpack_ims_SLQSGetIMSVoIPConfig_t, 644
pScrAmrWbEnable
pack_ims_SLQSSetIMSVoIPConfig_t, 341
unpack_ims_SLQSGetIMSVoIPConfig_t, 644
pSecDNSIPv4AddPref
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pSecDNSIPv6addpref
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pSecV6DnsAddress
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pSecondaryFlag
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pSecondaryHA
pack_wds_SetMobileIPProfile_t, 486
pSecondaryV4DnsAddress
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pSectorID
nas_NetworkStatEVDO, 225
pSendSmsParams
pack_sms_SLQSSendAsyncSMS_t, 419
pSensorDataUsage
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 686
pServerAddress
pack_pds_SLQSSetAGPSConfig_t, 407
unpack_pds_SLQSGetAGPSConfig_t, 778
pServerPort
pack_pds_SLQSSetAGPSConfig_t, 407
unpack_pds_SLQSGetAGPSConfig_t, 778
pServerURL
pack_pds_SLQSSetAGPSConfig_t, 407
unpack_pds_SLQSGetAGPSConfig_t, 778
pServerURLLength
pack_pds_SLQSSetAGPSConfig_t, 407
unpack_pds_SLQSGetAGPSConfig_t, 778
pServiceClass
pack_voice_SLQSVoiceSetSUPSService_t, 474
pServiceOption
sms_sendAsyncsmsParams, 525
pServingSystemInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pSessionExpiryTimer
pack_ims_SLQSSetIMSVoIPConfig_t, 341
unpack_ims_SLQSGetIMSVoIPConfig_t, 644
pSessionType
unpack_swiavms_SLQSAVMSEventReportInd_t, 833
pSetIndicationRegReq
pack_sms_SLQSSetIndicationRegister_t, 420
pSetRoutesReq
pack_sms_SLQSSmsSetRoutes_t, 422
pSettingResp
unpack_ims_SLQSGetIMSSMSConfig_t, 640
unpack_ims_SLQSGetIMSUserConfig_t, 641
unpack_ims_SLQSGetIMSVoIPConfig_t, 644
unpack_ims_SLQSGetRegMgrConfig_t, 645
unpack_ims_SLQSGetSIPConfig_t, 646
unpack_ims_SLQSSetIMSSMSConfig_t, 648
unpack_ims_SLQSSetIMSUserConfig_t, 648
unpack_ims_SLQSSetIMSVoIPConfig_t, 649
unpack_ims_SLQSSetRegMgrConfig_t, 649
unpack_ims_SLQSSetSIPConfig_t, 650
pSigCompEnabled
pack_ims_SLQSSetSIPConfig_t, 342
unpack_ims_SLQSGetSIPConfig_t, 646
pSigIndReq
pack_nas_SLQSSetSignalStrengthsCallback_t, 382
pSignalInfo
unpack_voice_VoiceInfoRecCallback_ind_t, 913
pSignalStrengthInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pSmsOnIms
sms_sendAsyncsmsParams, 525
pSmsStorage
unpack_sms_SLQSSwiGetSMSStorage_t, 824
pSourceIP
LibPackTFTIDParams, 119
pSpeedHorizontal
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 686
pSpeedUnc
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 686
pSpeedVertical
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 686
pSpeedVerticalUnc
unpack_loc_BestAvailPos_Ind_t, 668
pSrvDomainPref
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 398
unpack_nas_SLQSGetSysSelectionPref_t, 734
unpack_nas_SLQSGetSysSelectionPrefExt_t, 737
pSrvOpt
unpack_voice_SLQSVoiceGetCallInfo_t, 887
pSrvRegRestriction
pack_nas_SLQSSetSysSelectionPref_t, 387
pack_nas_SLQSSetSysSelectionPrefExt_t, 398
pSrvcProviderName
unpack_nas_SLQSGetOperatorNameData_t, 715
pStage0Val
audio_RXPCMIIRFltr, 41
audio_TXPCMIIRFltr, 43
pStage1Val
audio_RXPCMIIRFltr, 41
audio_TXPCMIIRFltr, 43
pStage2Val
audio_RXPCMIIRFltr, 41
audio_TXPCMIIRFltr, 43
pStage3Val

audio_RXPCMIIRFltr, 41
audio_TXPCMIIRFltr, 43
pStage4Val
audio_RXPCMIIRFltr, 41
audio_TXPCMIIRFltr, 43
pStageCnt
audio_RXPCMIIRFltr, 41
audio_TXPCMIIRFltr, 43
pStatMask
pack_wds_GetPacketStatistics_t, 478
pSubscribeTimer
pack_ims_SLQSSetSIPConfig_t, 343
unpack_ims_SLQSGetSIPConfig_t, 646
pSubscriptionInfoInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pSupportEmergencyCalls
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pSupportedBitmasks
unpack_swidms_SLQSSwiDmsGetUsbComp_t, 844
pSuppressSysInfoInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pSuppsNotifEvents
pack_voice_SLQSVoiceIndicationRegister_t, 467
pSvUsedforFix
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 686
pSvcClass
pack_voice_SLQSVoiceGetCallBarring_t, 463
pack_voice_SLQSVoiceGetCallForwardingStatus-_t, 464
pack_voice_SLQSVoiceGetCallWaiting_t, 465
unpack_voice_SLQSVoiceGetCallBarring_t, 883
unpack_voice_SLQSVoiceGetCallWaiting_t, 889
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pSvcType
pack_voice_SLQSVoiceDialCall_t, 462
pSysInfoInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pSysInfoNoChange
unpack_nas_SLQSSysInfoCallback_ind_t, 766
pSystemSelectionInd
pack_nas_SLQSNasIndicationRegisterExt_t, 376
pTDSCDMAECIODelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pTDSCDMAECIOThresh
pack_nas_SLQSNasConfigSigInfo2_t, 371
pTDSCDMAECIOThreshList
nas_TDSCDMAECIOThresh, 273
pTDSCDMARSCPDelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pTDSCDMARSCPThresh
pack_nas_SLQSNasConfigSigInfo2_t, 371
pTDSCDMARSCPThreshList
nas_TDSCDMARSCPThresh, 273
pTDSCDMARSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pTDSCDMARSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 371
pTDSCDMARSSIThreshList
nas_TDSCDMARSSIThresh, 274
pTDSCDMASINRDelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pTDSCDMASINRThresh
pack_nas_SLQSNasConfigSigInfo2_t, 371
pTDSCDMASINRThreshList
nas_TDSCDMASINRThresh, 275
pTDSCDMASigInfoExt
unpack_nas_SLQSNasSigInfoCallback_ind_t, 752
pTFTID1Params
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pTFTID2Params
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pTTYConfigStatus
unpack_voice_SLQSVoiceSetConfig_t, 902
pTTYMode
pack_voice_SLQSVoiceGetConfig_t, 466
pack_voice_SLQSVoiceSetConfig_t, 472
pTXAGCList
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pTXAIG
audio_TXAGCList, 41
pTXAVCSwitch
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pTXComprSlope
audio_TXAGCList, 42
pTXComprThres
audio_TXAGCList, 42
pTXDroppedCount
unpack_wds_GetPacketStatistics_t, 927
pTXExpSlope
audio_TXAGCList, 42
pTXExpThres
audio_TXAGCList, 42
pTXGain
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pTXInfo
unpack_nas_SLQSNasGetTxRxInfo_t, 747
pTXOKBytesLastCall
unpack_wds_GetPacketStatistics_t, 927
pTXOkBytesCount
unpack_wds_GetPacketStatistics_t, 927
pTXPCMIIRFltr
pack_audio_SLQSSetAudioPathConfig_t, 312
unpack_audio_SLQSGetAudioPathConfig_t, 567
pTXPacketErrors
unpack_wds_GetPacketStatistics_t, 927
pTXPacketOverflows
unpack_wds_GetPacketStatistics_t, 927

pTXPacketSuccesses
unpack_wds_GetPacketStatistics_t, 927
pTXStaticGain
audio_TXAGCList, 42
pTXTotalBytes
unpack_wds_GetByteTotals_t, 916
pTdscdmaBandPref
pack_nas_SLQSSetSysSelectionPref_t, 388
pack_nas_SLQSSetSysSelectionPrefExt_t, 398
pTech
pack_wds_SLQSStartDataSession_t, 497
pTechnologyMask
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 686
pTempReport
pack_dms_SwiSetEventReport_t, 329
pTimeSrc
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 686
pTimeStamp
pack_pds_SLQSPDSInjectPositionData_t, 406
packgetDyingGaspStatistics, 502
pTimeType
pack_pds_SLQSPDSInjectPositionData_t, 406
pTimeUnc
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 686
pTimeZone
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t, 751
pTimeout
unpack_pds_GetPDSDefaults_t, 771
pTimer
pack_nas_SLQSNasSwiIndicationRegister_t, 379
pTimerSIPReg
pack_ims_SLQSSetSIPConfig_t, 343
unpack_ims_SLQSGetSIPConfig_t, 646
pTimerT1
pack_ims_SLQSSetSIPConfig_t, 343
unpack_ims_SLQSGetSIPConfig_t, 646
pTimerT2
pack_ims_SLQSSetSIPConfig_t, 343
unpack_ims_SLQSGetSIPConfig_t, 646
pTimerTf
pack_ims_SLQSSetSIPConfig_t, 343
unpack_ims_SLQSGetSIPConfig_t, 646
pTimerVal
pack_voice_SLQSVoiceSetSUPSService_t, 474
pTimestampUtc
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 686
pTrackingStatus
unpack_pds_GetPDSState_t, 771
pTransLayerInfo
sms_getTransLayerInfo, 518
unpack_sms_SLQSTransLayerInfoCallback_ind_t, 825
pTransferStatInd
pack_wds_SLQSGetDUNCallInfo_t, 489
pack_wds_SLQSWdsSetEventReport_t, 500
pTransferStatusReport
sms_setRoutesReq, 527
pTrueIMSI
unpack_nas_SLQSNasGet3GPP2Subscription_t, 739
pUATI
unpack_nas_SLQSSwiGetHRPDStats_t, 759
pUIMStatusReport
pack_dms_SwiSetEventReport_t, 329
pUMTSCellID
unpack_nas_SLQSNasGetCellLocationInfo_t, 741
pUMTSInfo
unpack_nas_SLQSNasGetCellLocationInfo_t, 741
pUMTSMinQoS
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pUMTSMinQosSigInd
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pUMTSReqQoS
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pUMTSReqQoSSigInd
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pURL
unpack_loc_GetServer_Ind_t, 675
pURLAddr
pack_loc_SLQSLOCSetServer_t, 358
pUSSDInfo
unpack_voice_SLQSOriginateUSSD_t, 875
pUSSInfo
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
pUUSInFo
pack_voice_SLQSVoiceDialCall_t, 462
pUUSInfo
unpack_voice_SLQSVoiceGetCallInfo_t, 888
pUimAutoSwitchActSlot
unpack_dms_SLQSDmsSwiGetUimSelection_t, 612
pUimSlotsStatus
unpack_uim_SLQSUIMGetSlotsStatus_t, 865
pUname
PackSwiAVMSSettingsAPNInfo, 505
pUsbMTUSize
unpack_swidms_SLQSSwiDmsGetMTU_t, 843
pUser
pack_wds_SLQSStartDataSession_t, 497
pUserConfigEvents
pack_ims_SLQSImsConfigIndicationRegister_t, 337
pUserData
sms_sendAsyncsmsParams, 525
pUserId
LibpackProfile3GPP2, 105

LibPackprofile_3GPP2, 116
pUserIdSize
LibpackProfile3GPP2, 105
LibPackprofile_3GPP2, 116
pUsername
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pack_wds_SetDefaultProfile_t, 482
pUsernameSize
LibpackProfile3GPP, 99
LibPackprofile_3GPP, 111
pVerboseFailReasonType
unpack_wds_SLQSStartDataSession_t, 957
pVerboseFailureReason
unpack_wds_SLQSStartDataSession_t, 957
pVertConfidence
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_PositionRpt_Ind_t, 686
pVertReliability
unpack_loc_BestAvailPos_Ind_t, 669
unpack_loc_PositionRpt_Ind_t, 686
pVertUnc
unpack_loc_BestAvailPos_Ind_t, 669
unpack_loc_PositionRpt_Ind_t, 686
pVerticalConfidence
pack_pds_SLQSPDSInjectPositionData_t, 406
pVerticalUnc
pack_pds_SLQSPDSInjectPositionData_t, 406
pVoIPConfigEvents
pack_ims_SLQSImsConfigIndicationRegister_t, 337
pVoiceDomainPref
pack_voice_SLQSVoiceGetConfig_t, 466
pVoiceDomainPrefStatus
unpack_voice_SLQSVoiceSetConfig_t, 902
pVoicePrivacy
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
unpack_voice_SLQSVoiceGetCallInfo_t, 888
pVoltReport
pack_dms_SwiSetEventReport_t, 329
pVolume
pack_swiaudio_SLQSSetM2MAudioProfile_t, 426
pWAMSParaChanged
unpack_swiavms_SLQSAVMSEventReportInd_t, 833
pWCDMABER
unpack_nas_SLQSGetErrorRate_t, 713
pWCDMACallBarringSysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 766
pWCDMACipherDomainSysInfo
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSSysInfoCallback_ind_t, 766
pWCDMAECIODelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pWCDMAECIOThresh
pack_nas_SLQSNasConfigSigInfo2_t, 371
pWCDMAECIOThreshList
nas_WCDMAECIOThresh, 284
pWCDMAInfoLTENeighborCell
unpack_nas_SLQSNasGetCellLocationInfo_t, 741
pWCDMARSSIDelta
pack_nas_SLQSNasConfigSigInfo2_t, 371
pWCDMARSSIThresh
pack_nas_SLQSNasConfigSigInfo2_t, 371
pWCDMARSSIThreshList
nas_WCDMARSSIThresh, 286
pWCDMASigInfo
unpack_nas_SLQSNasSigInfoCallback_ind_t, 753
pWCDMASrvStatusInfo
unpack_nas_SLQSGetSysInfo_t, 730
unpack_nas_SLQSSysInfoCallback_ind_t, 766
pWCDMASysInfo
unpack_nas_SLQSGetSysInfo_t, 730
unpack_nas_SLQSSysInfoCallback_ind_t, 766
pWcdmaUARFCN
pack_nas_SLQSNASSwiSetChannelLock_t, 380
unpack_nas_SLQSNASSwiGetChannelLock_t, 753
pWifiState
pack_pds_SLQSSetPositionMethodState_t, 408
pXid
unpack_loc_BestAvailPos_Ind_t, 669
pXtraDataState
pack_pds_SLQSSetPositionMethodState_t, 408
pXtraTimeState
pack_pds_SLQSSetPositionMethodState_t, 408
pack_audio_SLQSGetAudioPathConfig
audio.h, 1042
pack_audio_SLQSGetAudioPathConfig_t, 308
Item, 309
Profile, 309
pack_audio_SLQSGetAudioProfile
audio.h, 1042
pack_audio_SLQSGetAudioProfile_t, 309
Generator, 310
pack_audio_SLQSGetAudioVolTLBConfig
audio.h, 1043
pack_audio_SLQSGetAudioVolTLBConfig_t, 310
Generator, 310
Item, 310
Profile, 310
Volume, 310
pack_audio_SLQSSetAudioPathConfig
audio.h, 1043
pack_audio_SLQSSetAudioPathConfig_t, 310
pCodecSTGain, 312
pECMode, 312
pNSEnable, 312
pRXAGCList, 312
pRXAVCList, 312
pTXAGCList, 312
pTXAVCSwitch, 312
pTXGain, 312
Profile, 312
pack_audio_SLQSSetAudioProfile

audio.h, 1044
pack_audio_SLQSSetAudioProfile_t, 312
EarMute, 313
Generator, 313
MicMute, 313
Profile, 313
Volume, 313
pack_audio_SLQSSetAudioVolTLBConfig
audio.h, 1044
pack_audio_SLQSSetAudioVolTLBConfig_t, 314
Generator, 314
Item, 314
Profile, 314
VolValue, 314
Volume, 314
pack_cat_CATSendEnvelopeCommand
cat.h, 1048
pack_cat_CATSendEnvelopeCommand_t, 314
cmdID, 315
dataLen, 315
pData, 315
pack_cat_CATSendTerminalResponse
cat.h, 1048
pack_cat_CATSendTerminalResponse_t, 315
dataLen, 316
pData, 316
refID, 316
pack_cat_SetCATEventCallback
cat.h, 1048
pack_cat_SetCATEventCallback_t, 316
eventMask, 316
pack_dms_ActivateAutomatic
dms.h, 1065
pack_dms_ActivateAutomatic_t, 317
actCode, 317
pack_dms_GetActivationState
dms.h, 1066
pack_dms_GetBandCapability
dms.h, 1066
pack_dms_GetCrashAction
dms.h, 1066
pack_dms_GetCustFeature
dms.h, 1067
pack_dms_GetCustFeaturesV2
dms.h, 1067
pack_dms_GetCustFeaturesV2_t, 317
cust_id, 317
list_type, 317
Tlvresult, 317
pack_dms_GetDeviceCap
dms.h, 1067
pack_dms_GetDeviceCapabilities
dms.h, 1068
pack_dms_GetDeviceHardwareRev
dms.h, 1068
pack_dms_GetDeviceMfr
dms.h, 1069
pack_dms_GetDeviceSerialNumbers
dms.h, 1069
pack_dms_GetFSN
dms.h, 1070
pack_dms_GetFirmwareInfo
dms.h, 1069
pack_dms_GetFirmwareRevision
dms.h, 1070
pack_dms_GetFirmwareRevisions
dms.h, 1070
pack_dms_GetHardwareRevision
dms.h, 1071
pack_dms_GetIMSI
dms.h, 1071
pack_dms_GetManufacturer
dms.h, 1071
pack_dms_GetModelID
dms.h, 1072
pack_dms_GetNetworkTime
dms.h, 1072
pack_dms_GetOfflineReason
dms.h, 1072
pack_dms_GetPRLVersion
dms.h, 1073
pack_dms_GetPower
dms.h, 1073
pack_dms_GetSerialNumbers
dms.h, 1073
pack_dms_GetUSBComp
dms.h, 1074
pack_dms_GetVoiceNumber
dms.h, 1074
pack_dms_ResetToFactoryDefaults
dms.h, 1074
pack_dms_ResetToFactoryDefaults_t, 318
spc, 318
pack_dms_SLQSDmsSwiGetPCInfo
dms.h, 1078
pack_dms_SLQSDmsSwiGetResetInfo
dms.h, 1079
pack_dms_SLQSDmsSwiGetUimSelection
dms.h, 1079
pack_dms_SLQSDmsSwiIndicationRegister
dms.h, 1079
pack_dms_SLQSDmsSwiIndicationRegister_t, 325
resetInfoInd, 325
pack_dms_SLQSGetBandCapability
dms.h, 1080
pack_dms_SLQSGetERIFile
dms.h, 1080
pack_dms_SLQSGetPowerSaveModeConfig
dms.h, 1080
pack_dms_SLQSSetPowerSaveModeConfig
dms.h, 1081
pack_dms_SLQSSetPowerSaveModeConfig_t, 325
pActiveTimer, 326
pPeriodicUpdateTimer, 326
pPsmEnableState, 326
pack_dms_SLQSSwiClearDyingGaspStatistics

dms.h, 1081
pack_dms_SLQSSwiGetCrashInfo
dms.h, 1082
pack_dms_SLQSSwiGetCrashInfo_t, 326
clear, 326
pack_dms_SLQSSwiGetDyingGaspCfg
dms.h, 1082
pack_dms_SLQSSwiGetDyingGaspStatistics
dms.h, 1082
pack_dms_SLQSSwiGetFirmwareCurr
dms.h, 1083
pack_dms_SLQSSwiGetFwUpdateStatus
dms.h, 1083
pack_dms_SLQSSwiGetHostDevInfo
dms.h, 1083
pack_dms_SLQSSwiGetOSInfo
dms.h, 1084
pack_dms_SLQSSwiGetSerialNoExt
dms.h, 1084
pack_dms_SLQSSwiSetDyingGaspCfg
dms.h, 1084
pack_dms_SLQSSwiSetDyingGaspCfg_t, 326
pDestSMSContent, 327
pDestSMSNum, 327
pack_dms_SLQSSwiSetHostDevInfo
dms.h, 1085
pack_dms_SLQSSwiSetHostDevInfo_t, 327
manString, 327
modelString, 327
plasmaIDString, 328
swVerString, 328
pack_dms_SLQSSwiSetOSInfo
dms.h, 1085
pack_dms_SLQSSwiSetOSInfo_t, 328
nameString, 328
versionString, 328
pack_dms_SLQSUIMGetState
dms.h, 1085
pack_dms_SetActivationStatusCallback
dms.h, 1075
pack_dms_SetActivationStatusCallback_t, 318
activationState, 318
pack_dms_SetCrashAction
dms.h, 1075
pack_dms_SetCrashAction_t, 318
crashAction, 319
pack_dms_SetCustFeature
dms.h, 1076
pack_dms_SetCustFeature_t, 319
DHCPRelayEnabled, 321
DisableIMSI, 321
GPSLPM, 321
GPSSel, 321
GpsEnable, 321
IPFamSupport, 321
IsVoiceEnabled, 321
RMAutoConnect, 321
SMSSupport, 321
pack_dms_SetCustFeaturesV2
dms.h, 1076
pack_dms_SetCustFeaturesV2_t, 321
cust_id, 322
cust_value, 322
Tlvresult, 322
value_length, 322
pack_dms_SetEventReport
dms.h, 1076
pack_dms_SetEventReport_t, 322
mode, 322
pack_dms_SetFirmwarePreference
dms.h, 1077
pack_dms_SetIndicationRegister
dms.h, 1077
pack_dms_SetIndicationRegister_t, 322
PSMCfgChangeInfo, 323
PSMStatus, 323
RptIMSCapability, 323
pack_dms_SetPower
dms.h, 1077
pack_dms_SetPower_t, 323
mode, 324
Tlvresult, 324
pack_dms_SetUSBComp
dms.h, 1078
pack_dms_SetUSBComp_t, 324
Tlvresult, 324
USBComp, 324
pack_dms_SwiSetEventReport
dms.h, 1086
pack_dms_SwiSetEventReport_t, 328
pTempReport, 329
pUIMStatusReport, 329
pVoltReport, 329
pack_dms_SwiUimSelect
dms.h, 1086
pack_dms_SwiUimSelect_t, 329
uim_select, 329
pack_dms_UIMChangePIN
dms.h, 1086
pack_dms_UIMChangePIN_t, 329
id, 330
newValue, 330
oldValue, 330
pack_dms_UIMGetControlKeyStatus
dms.h, 1087
pack_dms_UIMGetControlKeyStatus_t, 330
facility, 331
pack_dms_UIMGetICCID
dms.h, 1087
pack_dms_UIMGetICCID_t, 331
ParamPresenceMask, 331
Tlvresult, 331
pack_dms_UIMGetPINStatus
dms.h, 1088
pack_dms_UIMSetControlKeyProtection
dms.h, 1088

pack_dms_UIMSetControlKeyProtection_t, 331
facility, 332
facilityCk, 332
facilityState, 332
pack_dms_UIMSetPINProtection
dms.h, 1088
pack_dms_UIMSetPINProtection_t, 332
bEnable, 332
id, 332
value, 332
pack_dms_UIMUnblockControlKey
dms.h, 1089
pack_dms_UIMUnblockControlKey_t, 333
facility, 333
facilityCk, 333
pack_dms_UIMUnblockPIN
dms.h, 1089
pack_dms_UIMUnblockPIN_t, 333
id, 334
newPin, 334
pukValue, 334
pack_dms_UIMVerifyPIN
dms.h, 1089
pack_dms_UIMVerifyPIN_t, 334
id, 334
value, 334
pack_dms_ValidateSPC
dms.h, 1090
pack_fms_GetImagesPreference
fms.h, 1117
pack_fms_GetImagesPreference_t, 334
Tlvresult, 335
pack_fms_GetStoredImages
fms.h, 1118
pack_fms_GetStoredImages_t, 335
Tlvresult, 335
pack_fms_SetImagesPreference
fms.h, 1118
pack_fms_SetImagesPreference_t, 335
bForceDownload, 336
imageListSize, 336
modemindex, 336
pImageList, 336
Tlvresult, 336
pack_ims_SLQSGetIMSSMSConfig
ims.h, 1121
pack_ims_SLQSGetIMSUserConfig
ims.h, 1121
pack_ims_SLQSGetIMSVoIPConfig
ims.h, 1122
pack_ims_SLQSGetRegMgrConfig
ims.h, 1122
pack_ims_SLQSGetSIPConfig
ims.h, 1123
pack_ims_SLQSImsConfigIndicationRegister
ims.h, 1123
pack_ims_SLQSImsConfigIndicationRegister_t, 336
pRegMgrConfigEvents, 337
pSIPConfigEvents, 337
pSMSConfigEvents, 337
pUserConfigEvents, 337
pVoIPConfigEvents, 337
pack_ims_SLQSSetIMSSMSConfig
ims.h, 1124
pack_ims_SLQSSetIMSSMSConfig_t, 337
pack_ims_SLQSSetIMSUserConfig
ims.h, 1124
pack_ims_SLQSSetIMSUserConfig_t, 338
pIMSDomain, 338
pack_ims_SLQSSetIMSVoIPConfig
ims.h, 1125
pack_ims_SLQSSetIMSVoIPConfig_t, 339
pAmrMode, 341
pRingingTimer, 341
pack_ims_SLQSSetRegMgrConfig
ims.h, 1125
pack_ims_SLQSSetRegMgrConfig_t, 341
pCSCFPortName, 342
pIMSTestMode, 342
pPriCSCFPort, 342
pack_ims_SLQSSetSIPConfig
ims.h, 1125
pack_ims_SLQSSetSIPConfig_t, 342
pSIPLocalPort, 343
pSigCompEnabled, 342
pSubscribeTimer, 343
pTimerSIPReg, 343
pTimerT1, 343
pTimerT2, 343
pTimerTf, 343
pack_imsa_SLQSGetIMSARegStatus
imsa.h, 1133
pack_imsa_SLQSGetIMSAServiceStatus
imsa.h, 1133
pack_imsa_SLQSRegisterIMSAIndication
imsa.h, 1134
pack_imsa_SLQSRegisterIMSAIndication_t, 343
PdpStatusConfig, 344
RatHandoverStatusConfig, 344
RegStatusConfig, 344
ServiceStatusConfig, 344
pack_loc_Delete_Assist_Data_t, 344
pBdsSVInfo, 345
pCellDb, 345
pClkInfo, 345
pGnssData, 345
pSVInfo, 345
Tlvresult, 345
pack_loc_DeleteAssistData
loc.h, 1154
pack_loc_EventRegister
loc.h, 1154
pack_loc_EventRegister_t, 345
eventRegister, 347
Tlvresult, 347
pack_loc_SLQSLOCGetBestAvailPos

loc.h, 1155
pack_loc_SLQSLOCGetBestAvailPos_t, 348
Tlvresult, 348
xid, 348
pack_loc_SLQSLOCGetServer
loc.h, 1155
pack_loc_SLQSLOCGetServer_t, 349
has_serverAddrTypeMask, 349
serverAddrTypeMask, 349
serverType, 349
pack_loc_SLQSLOCInjectPosition
loc.h, 1156
pack_loc_SLQSLOCInjectPosition_t, 349
altitudeSrcInfo, 353
altitudeWrtEllipsoid, 353
altitudeWrtMeanSeaLevel, 353
has_altitudeSrcInfo, 353
has_altitudeWrtEllipsoid, 353
has_horConfidence, 353
has_horReliability, 353
has_horUncCircular, 353
has_latitude, 353
has_longitude, 353
has_positionSrc, 353
has_rawHorConfidence, 353
has_rawHorUncCircular, 353
has_timestampAge, 353
has_timestampUtc, 353
has_vertConfidence, 353
has_vertRelicability, 353
has_vertUnc, 354
horConfidence, 354
horReliability, 354
horUncCircular, 354
latitude, 354
longitude, 354
positionSrc, 354
rawHorConfidence, 354
rawHorUncCircular, 354
timestampAge, 354
timestampUtc, 354
vertConfidence, 354
vertReliability, 354
vertUnc, 354
pack_loc_SLQSLOCInjectSensorData
loc.h, 1156
pack_loc_SLQSLOCInjectSensorData_t, 354
accelTemp, 355
acceleroData, 355
acceleroTimeSrc, 355
gyroData, 355
gyroTemp, 355
gyroTimeSrc, 356
has_accelTemp, 356
has_acceleroTimeSrc, 356
has_accleroData, 356
has_gyroData, 356
has_gyroTemp, 356
has_gyroTimeSrc, 356
has_opaqueId, 356
opaqueId, 356
pack_loc_SLQSLOCInjectUTCTime
loc.h, 1157
pack_loc_SLQSLOCInjectUTCTime_t, 356
timeMsec, 356
timeUncMsec, 356
pack_loc_SLQSLOCSetCradleMountConfig
loc.h, 1157
pack_loc_SLQSLOCSetCradleMountConfig_t, 356
confidence, 357
has_confidence, 357
state, 357
pack_loc_SLQSLOCSetServer
loc.h, 1157
pack_loc_SLQSLOCSetServer_t, 357
pIPv4Config, 358
pIPv6Config, 358
pURLAddr, 358
serverType, 358
pack_loc_SetExtPowerState
loc.h, 1154
pack_loc_SetExtPowerState_t, 347
extPowerState, 347
Tlvresult, 347
pack_loc_SetOperationMode
loc.h, 1155
pack_loc_SetOperationMode_t, 347
mode, 348
Tlvresult, 348
pack_loc_Start
loc.h, 1158
pack_loc_Start_t, 358
pApplicationInfo, 359
pConfigAltitudeAssumed, 359
pHorizontalAccuracyLvl, 359
pIntermediateReportState, 359
pMinIntervalTime, 359
pRecurrenceType, 359
SessionId, 360
Tlvresult, 360
pack_loc_Stop
loc.h, 1158
pack_loc_Stop_t, 360
SessionId, 360
Tlvresult, 360
pack_nas_GetACCOLC
nas.h, 1182
pack_nas_GetANAAAAuthenticationStatus
nas.h, 1182
pack_nas_GetCDMANetworkParameters
nas.h, 1182
pack_nas_GetHomeNetwork
nas.h, 1182
pack_nas_GetHomeNetwork3GPP2
nas.h, 1183
pack_nas_GetNetworkPreference

nas.h, 1183
pack_nas_GetRFInfo
nas.h, 1183
pack_nas_GetServingNetwork
nas.h, 1184
pack_nas_GetServingNetworkCapabilities
nas.h, 1184
pack_nas_GetSignalStrengths
nas.h, 1184
pack_nas_InitiateDomainAttach
nas.h, 1185
pack_nas_InitiateDomainAttach_t, 360
action, 360
pack_nas_PerformNetworkScan
nas.h, 1185
pack_nas_PerformNetworkScanPCI
nas.h, 1185
pack_nas_PerformNetworkScanPCI_t, 361
pNetworkType, 361
pScanType, 361
pack_nas_SLQSConfigSigInfo
nas.h, 1187
pack_nas_SLQSConfigSigInfo_t, 364
pECIOThresh, 365
pIOThresh, 365
pLTESNRThresh, 365
pLTESigRptCfg, 365
pRSRPThresh, 365
pRSRQThresh, 365
pRSSIThresh, 365
pack_nas_SLQSGetErrorRate
nas.h, 1188
pack_nas_SLQSGetNetworkTime
nas.h, 1188
pack_nas_SLQSGetOperatorNameData
nas.h, 1189
pack_nas_SLQSGetPLMNName
nas.h, 1189
pack_nas_SLQSGetPLMNName_t, 365
mcc, 366
mnc, 366
pMncPcsStatus, 366
pack_nas_SLQSGetServingSystem
nas.h, 1189
pack_nas_SLQSGetSignalStrength
nas.h, 1190
pack_nas_SLQSGetSysInfo
nas.h, 1190
pack_nas_SLQSGetSysSelectionPref
nas.h, 1190
pack_nas_SLQSGetSysSelectionPrefExt
nas.h, 1191
pack_nas_SLQSInitiateNetworkRegistration
nas.h, 1191
pack_nas_SLQSInitiateNetworkRegistration_t, 366
pChangeDuration, 367
pMNRInfo, 367
pMncPcsDigitStatus, 367
regAction, 367
pack_nas_SLQSNASGetForbiddenNetworks
nas.h, 1193
pack_nas_SLQSNASGeteDRXParams
nas.h, 1193
pack_nas_SLQSNASGeteDRXParamsExt
nas.h, 1193
pack_nas_SLQSNASGeteDRXParamsExt_t, 372
pack_nas_SLQSNASSeteDRXParams
nas.h, 1195
pack_nas_SLQSNASSeteDRXParams_t, 376
pCycleLen, 377
pEdrxEnable, 378
pack_nas_SLQSNASSwiGetChannelLock
nas.h, 1196
pack_nas_SLQSNASSwiSetChannelLock
nas.h, 1197
pack_nas_SLQSNASSwiSetChannelLock_t, 379
pack_nas_SLQSNasConfigSigInfo2
nas.h, 1192
pack_nas_SLQSNasConfigSigInfo2_t, 367
pHDRIODelta, 371
pHDRIOThresh, 371
pLTESigRptConfig, 371
pack_nas_SLQSNasGet3GPP2Subscription
nas.h, 1192
pack_nas_SLQSNasGet3GPP2Subscription_t, 372
namID, 372
pack_nas_SLQSNasGetCellLocationInfo
nas.h, 1192
pack_nas_SLQSNasGetHDRColorCode
nas.h, 1194
pack_nas_SLQSNasGetRFInfo
nas.h, 1194
pack_nas_SLQSNasGetSigInfo
nas.h, 1194
pack_nas_SLQSNasGetTxRxInfo
nas.h, 1195
pack_nas_SLQSNasGetTxRxInfo_t, 373
radio_if, 373
pack_nas_SLQSNasIndicationRegisterExt
nas.h, 1195
pack_nas_SLQSNasIndicationRegisterExt_t, 373
pDDTMInd, 376
pDualStandByPrefInd, 376
pEdrxChangeInfoInd, 376
pErrorRateInd, 376
pHDRSessionCloseInd, 376
pLTECphyCa, 376
pManagedRoamingInd, 376
pNetworkRejectInd, 376
pNetworkTimeInd, 376
pServingSystemInd, 376
pSignalStrengthInd, 376
pSubscriptionInfoInd, 376
pSuppressSysInfoInd, 376
pSysInfoInd, 376
pSystemSelectionInd, 376

pack_nas_SLQSNasSwiIndicationRegister
nas.h, 1196
pack_nas_SLQSNasSwiIndicationRegister_t, 378
gsmUmtsDl, 379
gsmUmtsUl, 379
lteEmmDl, 379
lteEmmUl, 379
lteEsmDl, 379
lteEsmUl, 379
pRankIndicatorInd, 379
pTimer, 379
pack_nas_SLQSNasSwiModemStatus
nas.h, 1197
pack_nas_SLQSSetBandPreference
nas.h, 1197
pack_nas_SLQSSetBandPreference_t, 380
bandPref, 381
pack_nas_SLQSSetSignalStrengthsCallback
nas.h, 1198
pack_nas_SLQSSetSignalStrengthsCallback_t, 382
bEnable, 382
pSigIndReq, 382
pack_nas_SLQSSetSysSelectionPref
nas.h, 1198
pack_nas_SLQSSetSysSelectionPref_t, 382
pAcqOrderPref, 387
pBandPref, 387
pCSGID, 387
pChgDuration, 387
pEmerMode, 387
pGWAcqOrderPref, 387
pLTEBandPref, 387
pModePref, 387
pNetSelPref, 387
pPRLPref, 387
pRAT, 387
pRoamPref, 387
pSrvDomainPref, 387
pSrvRegRestriction, 387
pTdscdmaBandPref, 388
pack_nas_SLQSSetSysSelectionPrefExt
nas.h, 1198
pack_nas_SLQSSetSysSelectionPrefExt_t, 388
pAcqOrderPref, 397
pBandPref, 397
pCSGID, 397
pChgDuration, 397
pCiotAcqOrderPref, 397
pCiotLteOpMode, 397
pCiotLteOpModePref, 397
pEmerMode, 397
pGWAcqOrderPref, 397
pLTEBandPref, 397
pLteM1BandPref, 397
pLteNb1BandPref, 397
pModePref, 397
pNetSelPref, 397
pNr5gBandPref, 397
pPRLPref, 397
pRAT, 398
pRoamPref, 398
pSrvDomainPref, 398
pSrvRegRestriction, 398
pTdscdmaBandPref, 398
pack_nas_SLQSSwiGetHDRPersonality
nas.h, 1199
pack_nas_SLQSSwiGetHDRProtSubtype
nas.h, 1199
pack_nas_SLQSSwiGetHRPDStats
nas.h, 1199
pack_nas_SLQSSwiGetLteCQI
nas.h, 1200
pack_nas_SLQSSwiGetLteSccRxInfo
nas.h, 1200
pack_nas_SLQSSwiNetworkDebug
nas.h, 1200
pack_nas_SLQSSwiPSDetach
nas.h, 1201
pack_nas_SLQSSwiPSDetach_t, 398
pDetachAction, 398
pack_nas_SetACCOLC
nas.h, 1186
pack_nas_SetACCOLC_t, 361
accolc, 361
spc, 361
pack_nas_SetCDMANetworkParameters
nas.h, 1186
pack_nas_SetCDMANetworkParameters_t, 361
pApplication, 362
pBroadcast, 363
pCustomSCP, 363
pForceRev0, 363
pProtocol, 363
pRoaming, 363
pSPC, 363
pack_nas_SetLURejectCallback
nas.h, 1187
pack_nas_SetNetworkPreference
nas.h, 1187
pack_nas_SetNetworkPreference_t, 363
Duration, 364
TechnologyPref, 364
Tlvresult, 364
pack_nas_SetRFInfoCallback
nas.h, 1187
pack_nas_SlqsGetLTECphyCAInfo
nas.h, 1188
pack_pds_ForceXTRADownload
pds.h, 1232
pack_pds_GetPDSDefaults
pds.h, 1232
pack_pds_GetPDSState
pds.h, 1233
pack_pds_GetPortAutomaticTracking
pds.h, 1233
pack_pds_GetServiceAutomaticTracking

pds.h, 1233
pack_pds_GetXTRAAutomaticDownload
pds.h, 1234
pack_pds_GetXTRANetwork
pds.h, 1234
pack_pds_GetXTRAValidity
pds.h, 1234
pack_pds_PDSInjectTimeReference
pds.h, 1235
pack_pds_PDSInjectTimeReference_t, 398
systemDiscontinuities, 399
systemTime, 399
pack_pds_ResetPDSData
pds.h, 1235
pack_pds_ResetPDSData_t, 399
pCellDataMask, 399
pGPSDataMask, 400
pack_pds_SLQSGetAGPSConfig
pds.h, 1238
pack_pds_SLQSGetAGPSConfig_t, 403
pNetworkMode, 404
pack_pds_SLQSGetGPSStateInfo
pds.h, 1238
pack_pds_SLQSPDSDeterminePosition
pds.h, 1239
pack_pds_SLQSPDSInjectAbsoluteTimeReference
pds.h, 1239
pack_pds_SLQSPDSInjectAbsoluteTimeReference_t, 404
forceFlag, 404
timeBase, 404
timeMsec, 404
timeUncMsec, 405
pack_pds_SLQSPDSInjectPositionData
pds.h, 1239
pack_pds_SLQSPDSInjectPositionData_t, 405
pAltitudeWrtEllipsoid, 406
pAltitudeWrtSealevel, 406
pHorizontalConfidence, 406
pHorizontalUncCircular, 406
pLatitude, 406
pLongitude, 406
pPositionSource, 406
pTimeStamp, 406
pTimeType, 406
pVerticalConfidence, 406
pVerticalUnc, 406
pack_pds_SLQSSetAGPSConfig
pds.h, 1240
pack_pds_SLQSSetAGPSConfig_t, 407
pNetworkMode, 407
pServerAddress, 407
pServerPort, 407
pServerURL, 407
pack_pds_SLQSSetPositionMethodState
pds.h, 1240
pack_pds_SLQSSetPositionMethodState_t, 407
pWifiState, 408
pXtraDataState, 408
pXtraTimeState, 408
pack_pds_SetEventReportCallback
pds.h, 1235
pack_pds_SetEventReportCallback_t, 400
posDataNmea, 400
rptPosData, 400
pack_pds_SetPDSDefaults
pds.h, 1236
pack_pds_SetPDSDefaults_t, 400
accuracy, 401
interval, 401
operation, 401
timeout, 401
pack_pds_SetPDSState
pds.h, 1236
pack_pds_SetPDSState_t, 401
enable, 401
pack_pds_SetPortAutomaticTracking
pds.h, 1236
pack_pds_SetPortAutomaticTracking_t, 401
bAuto, 402
pack_pds_SetServiceAutomaticTracking
pds.h, 1237
pack_pds_SetServiceAutomaticTracking_t, 402
bAuto, 402
pack_pds_SetXTRAAutomaticDownload
pds.h, 1237
pack_pds_SetXTRAAutomaticDownload_t, 402
bEnabled, 403
interval, 403
pack_pds_SetXTRANetwork
pds.h, 1237
pack_pds_SetXTRANetwork_t, 403
preference, 403
pack_pds_StartPDSTrackingSessionExt
pds.h, 1240
pack_pds_StartPDSTrackingSessionExt_t, 408
fixAccuracy, 409
fixCount, 409
fixInterval, 409
fixTimeout, 409
sessionControl, 409
sessionOperation, 409
sessionServerOption, 409
sessionType, 409
pack_pds_StopPDSTrackingSession
pds.h, 1241
pack_qmi_t, 409
msgid, 410
svc, 410
timeout, 410
xid, 410
pack_qos_BindDataPort
qos.h, 1300
pack_qos_BindDataPort_t, 410
pMuxID, 411
pPeripheralEndPointID, 411

pSIODataPort, 411
pack_qos_SLQSQosGetNetworkStatus
qos.h, 1300
pack_qos_SLQSQosSwiReadApnExtraParams
qos.h, 1301
pack_qos_SLQSQosSwiReadApnExtraParams_t, 411
apnId, 411
pack_qos_SLQSQosSwiReadDataStats
qos.h, 1302
pack_qos_SLQSQosSwiReadDataStats_t, 411
apnId, 411
pack_qos_SLQSSetQosEventCallback
qos.h, 1302
pack_qos_SLQSSetQosEventCallback_t, 411
enable, 412
pack_rms_GetSMSWake
rms.h, 1308
pack_rms_SetSMSWake
rms.h, 1309
pack_rms_SetSMSWake_t, 412
enabled, 412
wake_mask, 412
pack_sar_SLQSGetRfSarState
sar.h, 1310
pack_sar_SLQSSetRfSarState
sar.h, 1310
pack_sar_SLQSSetRfSarState_t, 412
RfSarState, 413
pack_sms_GetSMSCAddress
sms.h, 1316
pack_sms_SLQSDeleteSMS
sms.h, 1318
pack_sms_SLQSDeleteSMS_t, 415
pMessageIndex, 416
pMessageMode, 416
pMessageTag, 416
storageType, 416
pack_sms_SLQSGetIndicationRegister
sms.h, 1318
pack_sms_SLQSGetMessageWaiting
sms.h, 1318
pack_sms_SLQSGetSMS
sms.h, 1319
pack_sms_SLQSGetSMS_t, 416
messageIndex, 417
pMessageMode, 417
storageType, 417
pack_sms_SLQSGetSMSList
sms.h, 1319
pack_sms_SLQSGetSMSList_t, 417
pMessageMode, 418
pRequestedTag, 418
storageType, 418
pack_sms_SLQSGetSmsBroadcastConfig
sms.h, 1319
pack_sms_SLQSGetSmsBroadcastConfig_t, 417
mode, 417
pack_sms_SLQSGetTransLayerInfo
sms.h, 1320
pack_sms_SLQSGetTransNWRegInfo
sms.h, 1320
pack_sms_SLQSModifySMSStatus
sms.h, 1320
pack_sms_SLQSModifySMSStatus_t, 418
messageIndex, 419
messageTag, 419
pMessageMode, 419
storageType, 419
pack_sms_SLQSSendAsyncSMS
sms.h, 1321
pack_sms_SLQSSendAsyncSMS_t, 419
pSendSmsParams, 419
pack_sms_SLQSSetIndicationRegister
sms.h, 1321
pack_sms_SLQSSetIndicationRegister_t, 419
pSetIndicationRegReq, 420
pack_sms_SLQSSetSmsBroadcastActivation
sms.h, 1321
pack_sms_SLQSSetSmsBroadcastActivation_t, 420
broadcastActivate, 420
mode, 420
pack_sms_SLQSSetSmsBroadcastConfig
sms.h, 1322
pack_sms_SLQSSetSmsBroadcastConfig_t, 420
mode, 421
pBroadcastConfig, 421
pCDMABroadcastConfig, 421
pack_sms_SLQSSetSmsStorage
sms.h, 1322
pack_sms_SLQSSetSmsStorage_t, 421
smsStorage, 421
pack_sms_SLQSSmsGetMaxStorageSize
sms.h, 1323
pack_sms_SLQSSmsGetMaxStorageSize_t, 422
pMaxStorageSizeReq, 422
pack_sms_SLQSSmsGetMessageProtocol
sms.h, 1323
pack_sms_SLQSSmsSetRoutes
sms.h, 1323
pack_sms_SLQSSmsSetRoutes_t, 422
pSetRoutesReq, 422
pack_sms_SLQSSwiGetSMSStorage
sms.h, 1324
pack_sms_SaveSMS
sms.h, 1316
pack_sms_SaveSMS_t, 413
messageFormat, 414
messageSize, 414
pMessage, 414
storageType, 414
pack_sms_SendSMS
sms.h, 1317
pack_sms_SendSMS_t, 414
messageFormat, 414
messageSize, 414
pLinktimer, 414

pMessage, 415
pack_sms_SetNewSMSCallback
sms.h, 1317
pack_sms_SetNewSMSCallback_t, 415
status, 415
pack_sms_SetSMSCAddress
sms.h, 1317
pack_sms_SetSMSCAddress_t, 415
pSMSCAddress, 415
pSMSCType, 415
pack_swiaudio_SLQSGetM2MAVMute
swiaudio.h, 1337
pack_swiaudio_SLQSGetM2MAVMute_t, 423
Profile, 424
pack_swiaudio_SLQSGetM2MAudioProfile
swiaudio.h, 1336
pack_swiaudio_SLQSGetM2MAudioProfile_t, 422
pGenerator, 423
pack_swiaudio_SLQSGetM2MAudioVolume
swiaudio.h, 1336
pack_swiaudio_SLQSGetM2MAudioVolume_t, 423
Generator, 423
Profile, 423
pack_swiaudio_SLQSGetM2MSpkrGain
swiaudio.h, 1337
pack_swiaudio_SLQSGetM2MSpkrGain_t, 424
Profile, 424
pack_swiaudio_SLQSSetM2MAVMute
swiaudio.h, 1339
pack_swiaudio_SLQSSetM2MAVMute_t, 427
EarMute, 428
MicMute, 428
pCwtMute, 428
Profile, 428
pack_swiaudio_SLQSSetM2MAudioAVCFG
swiaudio.h, 1338
pack_swiaudio_SLQSSetM2MAudioAVCFG_t, 424
Device, 425
Profile, 425
pack_swiaudio_SLQSSetM2MAudioLPBK
swiaudio.h, 1338
pack_swiaudio_SLQSSetM2MAudioLPBK_t, 425
Enable, 425
pack_swiaudio_SLQSSetM2MAudioNVDef
swiaudio.h, 1338
pack_swiaudio_SLQSSetM2MAudioProfile
swiaudio.h, 1339
pack_swiaudio_SLQSSetM2MAudioProfile_t, 425
pCwtMute, 426
pEarMute, 426
pGenerator, 426
pMicMute, 426
pVolume, 426
Profile, 426
pack_swiaudio_SLQSSetM2MAudioVolume
swiaudio.h, 1339
pack_swiaudio_SLQSSetM2MAudioVolume_t, 427
Generator, 427
Level, 427
Profile, 427
pack_swiaudio_SLQSSetM2MSpkrGain
swiaudio.h, 1340
pack_swiaudio_SLQSSetM2MSpkrGain_t, 428
Profile, 428
Value, 428
pack_swiavms_SLQSAVMSGetSettings
swiavms.h, 1346
pack_swiavms_SLQSAVMSGetSettings_v2
swiavms.h, 1347
pack_swiavms_SLQSAVMSSendSelection
swiavms.h, 1347
pack_swiavms_SLQSAVMSSendSelection_t, 429
pDeferTime, 429
pPackageID, 429
pRejectReason, 429
selection, 429
pack_swiavms_SLQSAVMSSessionGetInfo
swiavms.h, 1348
pack_swiavms_SLQSAVMSSetSettings
swiavms.h, 1349
pack_swiavms_SLQSAVMSSetSettings_t, 429
AutoConnect, 431
AutoReboot, 431
pAPNInfo, 431
pConnectionRetryTimers, 431
pNotifStore, 431
pPeriodInfo, 431
pPollingTimer, 431
PromptFwDownload, 431
PromptFwUpdate, 431
pack_swiavms_SLQSAVMSSetSettings_v2
swiavms.h, 1350
pack_swiavms_SLQSAVMSSetSettings_v2_t, 431
AutoConnect, 432
pAutoReboot, 433
pNotifStore, 433
pPeriodInfo, 433
pPollingTimer, 433
PromptFwDownload, 433
PromptFwUpdate, 433
pack_swiavms_SLQSAVMSSetSettingsNoAutoReboot-
Field
swiavms.h, 1350
pack_swiavms_SLQSAVMSStartSession
swiavms.h, 1351
pack_swiavms_SLQSAVMSStartSession_t, 433
sessionType, 433
pack_swiavms_SLQSAVMSStopSession
swiavms.h, 1352
pack_swiavms_SLQSAVMSStopSession_t, 433
sessionType, 434
pack_swiavms_SLQSAvmsSetEventReport
swiavms.h, 1349
pack_swidms_SLQSSwiDmsGetMTU
swidms.h, 1360
pack_swidms_SLQSSwiDmsGetUsbComp

swidms.h, 1361
pack_swidms_SLQSSwiDmsGetUsbNetNum
swidms.h, 1361
pack_swidms_SLQSSwiDmsSetMTU
swidms.h, 1361
pack_swidms_SLQSSwiDmsSetMTU_t, 434
MTUSize, 434
pack_swidms_SLQSSwiDmsSetUsbComp
swidms.h, 1362
pack_swidms_SLQSSwiDmsSetUsbComp_t, 434
CfgValue, 435
pack_swidms_SLQSSwiDmsSetUsbNetNum
swidms.h, 1362
pack_swidms_SLQSSwiDmsSetUsbNetNum_t, 435
nUsbNetNum, 435
pack_swiloc_SwiLocGetAutoStart
swiloc.h, 1365
pack_swiloc_SwiLocSetAutoStart
swiloc.h, 1365
pack_swiloc_SwiLocSetAutoStart_t, 436
fix_rate, 437
fix_type, 437
function, 437
max_dist, 437
max_time, 437
set_fix_rate, 437
set_fix_type, 437
set_function, 437
set_max_dist, 437
set_max_time, 437
pack_swioma_SLQSOMADMAlertCallback
swioma.h, 1368
pack_swioma_SLQSOMADMCancelSession
swioma.h, 1368
pack_swioma_SLQSOMADMCancelSession_t, 437
sessionType, 438
pack_swioma_SLQSOMADMCancelSessionExt
swiomaext.h, 1377
pack_swioma_SLQSOMADMCancelSessionExt_t, 438
sessionType, 438
pack_swioma_SLQSOMADMGetSessionInfo
swioma.h, 1369
pack_swioma_SLQSOMADMGetSessionInfo_t, 438
SessionType, 439
pack_swioma_SLQSOMADMGetSettings
swioma.h, 1370
pack_swioma_SLQSOMADMSendSelection
swioma.h, 1370
pack_swioma_SLQSOMADMSendSelection_t, 439
pDeferTime, 439
pRejectReason, 439
selection, 439
pack_swioma_SLQSOMADMSendSelectionExt
swiomaext.h, 1378
pack_swioma_SLQSOMADMSendSelectionExt_t, 439
selection, 440
pack_swioma_SLQSOMADMSetSettings
swioma.h, 1371
pack_swioma_SLQSOMADMSetSettings_t, 440
FOTAdownload, 441
pAutosdm, 441
pFwAutoCheck, 441
pack_swioma_SLQSOMADMSetSettingsExt
swiomaext.h, 1378
pack_swioma_SLQSOMADMSetSettingsExt_t, 441
pack_swioma_SLQSOMADMStartSession
swioma.h, 1372
pack_swioma_SLQSOMADMStartSession_t, 442
sessionType, 442
pack_swioma_SLQSOMADMStartSessionExt
swiomaext.h, 1379
pack_swioma_SLQSOMADMStartSessionExt_t, 442
sessionType, 443
pack_tmd_SLQSTmdDeRegNotMitigationLvl
tmd.h, 1384
pack_tmd_SLQSTmdDeRegNotMitigationLvl_t, 443
mitigationDevID, 443
mitigationDevIDLen, 443
pack_tmd_SLQSTmdGetMitigationDevList
tmd.h, 1384
pack_tmd_SLQSTmdGetMitigationLvl
tmd.h, 1384
pack_tmd_SLQSTmdGetMitigationLvl_t, 443
mitigationDevID, 444
mitigationDevIDLen, 444
pack_tmd_SLQSTmdRegNotMitigationLvl
tmd.h, 1385
pack_tmd_SLQSTmdRegNotMitigationLvl_t, 444
mitigationDevID, 444
mitigationDevIDLen, 444
pack_uim_ChangePin
uim.h, 1391
pack_uim_ChangePin_t, 444
changePIN, 445
EncryptedPIN1, 445
pIndicationToken, 445
pKeyReferenceID, 445
sessionInfo, 445
Tlvresult, 445
pack_uim_GetCardStatus
uim.h, 1391
pack_uim_ReadTransparent
uim.h, 1391
pack_uim_ReadTransparent_t, 445
fileIndex, 446
pEncryptData, 446
pIndicationToken, 446
readTransparent, 446
sessionInfo, 446
Tlvresult, 446
pack_uim_SLQSUIMAuthenticate
uim.h, 1392
pack_uim_SLQSUIMAuthenticate_t, 448
authData, 448
pIndicationToken, 448
sessionInfo, 448

pack_uim_SLQSUIMDepersonalization
uim.h, 1392
pack_uim_SLQSUIMDepersonalization_t, 448
depersonilisationInfo, 449
pack_uim_SLQSUIMEventRegister
uim.h, 1393
pack_uim_SLQSUIMEventRegister_t, 449
eventMask, 449
pack_uim_SLQSUIMGetConfiguration
uim.h, 1393
pack_uim_SLQSUIMGetConfiguration_t, 449
pConfigurationMask, 449
pack_uim_SLQSUIMGetFileAttributes
uim.h, 1394
pack_uim_SLQSUIMGetFileAttributes_t, 450
fileIndex, 450
pIndicationToken, 450
sessionInfo, 450
pack_uim_SLQSUIMGetSlotsStatus
uim.h, 1394
pack_uim_SLQSUIMPowerDown
uim.h, 1394
pack_uim_SLQSUIMPowerDown_t, 450
slot, 451
pack_uim_SLQSUIMPowerUp
uim.h, 1395
pack_uim_SLQSUIMPowerUp_t, 451
pIgnoreHotSwapSwitch, 451
slot, 451
pack_uim_SLQSUIMRefreshComplete
uim.h, 1395
pack_uim_SLQSUIMRefreshComplete_t, 451
refreshComplete, 452
sessionInfo, 452
pack_uim_SLQSUIMRefreshGetLastEvent
uim.h, 1395
pack_uim_SLQSUIMRefreshGetLastEvent_t, 452
sessionInfo, 452
pack_uim_SLQSUIMRefreshOK
uim.h, 1396
pack_uim_SLQSUIMRefreshOK_t, 452
OKtoRefresh, 453
sessionInfo, 453
pack_uim_SLQSUIMRefreshRegister
uim.h, 1396
pack_uim_SLQSUIMRefreshRegister_t, 453
regRefresh, 453
sessionInfo, 453
pack_uim_SLQSUIMReset
uim.h, 1397
pack_uim_SLQSUIMSwitchSlot
uim.h, 1397
pack_uim_SLQSUIMSwitchSlot_t, 453
bLogicalSlot, 454
ulPhysicalSlot, 454
pack_uim_SetPinProtection
uim.h, 1392
pack_uim_SetPinProtection_t, 447
EncryptedPIN1, 447
pIndicationToken, 447
pKeyReferenceID, 447
pinProtection, 447
sessionInfo, 447
Tlvresult, 447
pack_uim_UnblockPin
uim.h, 1397
pack_uim_UnblockPin_t, 454
EncryptedPIN1, 455
pIndicationToken, 455
pKeyReferenceID, 455
pinProtection, 455
sessionInfo, 455
Tlvresult, 455
pack_uim_VerifyPin
uim.h, 1398
pack_uim_VerifyPin_t, 455
pEncryptedPIN1, 456
pIndicationToken, 456
pKeyReferenceID, 456
sessionInfo, 456
Tlvresult, 456
verifyPIN, 456
pack_voice_AnswerUSSD
voice.h, 1413
pack_voice_AnswerUSSD_t, 456
pInfo, 457
pack_voice_CancelUSSD
voice.h, 1413
pack_voice_OriginateUSSD
voice.h, 1414
pack_voice_OriginateUSSD_t, 457
pInfo, 457
pack_voice_SLQSOriginateUSSD
voice.h, 1414
pack_voice_SLQSOriginateUSSD_t, 457
ussDCS, 458
ussData, 458
ussLen, 458
pack_voice_SLQSVoiceALSSelectLine
voice.h, 1414
pack_voice_SLQSVoiceALSSelectLine_t, 458
lineValue, 458
pack_voice_SLQSVoiceALSSetLineSwitching
voice.h, 1415
pack_voice_SLQSVoiceALSSetLineSwitching_t, 458
switchOption, 458
pack_voice_SLQSVoiceAnswerCall
voice.h, 1415
pack_voice_SLQSVoiceAnswerCall_t, 459
pCallId, 459
pack_voice_SLQSVoiceBindSubscription
voice.h, 1415
pack_voice_SLQSVoiceBindSubscription_t, 459
subsType, 459
pack_voice_SLQSVoiceBurstDTMF
voice.h, 1416

pack_voice_SLQSVoiceBurstDTMF_t, 459
pack_voice_SLQSVoiceDialCall
voice.h, 1416
pack_voice_SLQSVoiceDialCall_t, 460
callNumber, 461
pCLIRType, 461
pCUGInfo, 461
pCallPartySubAdd, 461
pCallType, 461
pEmergencyCategory, 461
pSvcType, 462
pUUSInFo, 462
pack_voice_SLQSVoiceEndCall
voice.h, 1416
pack_voice_SLQSVoiceEndCall_t, 462
pCallId, 462
pack_voice_SLQSVoiceGetAllCallInfo
voice.h, 1417
pack_voice_SLQSVoiceGetCLIP
voice.h, 1419
pack_voice_SLQSVoiceGetCLIR
voice.h, 1419
pack_voice_SLQSVoiceGetCNAP
voice.h, 1419
pack_voice_SLQSVoiceGetCOLP
voice.h, 1420
pack_voice_SLQSVoiceGetCOLR
voice.h, 1420
pack_voice_SLQSVoiceGetCallBarring
voice.h, 1417
pack_voice_SLQSVoiceGetCallBarring_t, 462
pSvcClass, 463
reason, 463
pack_voice_SLQSVoiceGetCallForwardingStatus
voice.h, 1418
pack_voice_SLQSVoiceGetCallForwardingStatus_t, 463
pSvcClass, 464
Reason, 464
pack_voice_SLQSVoiceGetCallInfo
voice.h, 1418
pack_voice_SLQSVoiceGetCallInfo_t, 464
callID, 464
pack_voice_SLQSVoiceGetCallWaiting
voice.h, 1418
pack_voice_SLQSVoiceGetCallWaiting_t, 464
pSvcClass, 465
pack_voice_SLQSVoiceGetConfig
voice.h, 1420
pack_voice_SLQSVoiceGetConfig_t, 465
pAMRStatus, 466
pAirTimer, 466
pAutoAnswer, 466
pNamID, 466
pPrefVoicePrivacy, 466
pPrefVoiceSO, 466
pRoamTimer, 466
pTTYMode, 466
pVoiceDomainPref, 466
pack_voice_SLQSVoiceIndicationRegister
voice.h, 1421
pack_voice_SLQSVoiceIndicationRegister_t, 467
pRegDTMFEvents, 467
pRegVoicePrivacyEvents, 467
pSuppsNotifEvents, 467
pack_voice_SLQSVoiceManageCalls
voice.h, 1421
pack_voice_SLQSVoiceManageCalls_t, 467
pCallID, 468
SUPSType, 468
pack_voice_SLQSVoiceOrigUSSDNoWait
voice.h, 1421
pack_voice_SLQSVoiceOrigUSSDNoWait_t, 468
pack_voice_SLQSVoiceSendFlash
voice.h, 1422
pack_voice_SLQSVoiceSendFlash_t, 469
pCallID, 469
pFlashPayLd, 469
pFlashType, 469
pack_voice_SLQSVoiceSetCallBarringPassword
voice.h, 1422
pack_voice_SLQSVoiceSetCallBarringPassword_t, 469
newPasswd, 470
newPasswdAgain, 470
oldPasswd, 470
Reason, 470
pack_voice_SLQSVoiceSetConfig
voice.h, 1422
pack_voice_SLQSVoiceSetConfig_t, 470
pAirTimerConfig, 472
pAutoAnswer, 472
pPrefVoiceDomain, 472
pPrefVoiceSO, 472
pRoamTimerConfig, 472
pTTYMode, 472
pack_voice_SLQSVoiceSetPreferredPrivacy
voice.h, 1423
pack_voice_SLQSVoiceSetPreferredPrivacy_t, 472
privacyPref, 472
pack_voice_SLQSVoiceSetSUPSService
voice.h, 1423
pack_voice_SLQSVoiceSetSUPSService_t, 472
pCallBarringPasswd, 474
pCallForwardingNumber, 474
pServiceClass, 474
pTimerVal, 474
reason, 474
voiceSvc, 474
pack_voice_SLQSVoiceStartContDTMF
voice.h, 1424
pack_voice_SLQSVoiceStartContDTMF_t, 474
DTMFdigit, 475
pCallID, 475
pack_voice_SLQSVoiceStopContDTMF
voice.h, 1424
pack_voice_SLQSVoiceStopContDTMF_t, 475
callID, 475

pack_wds_DHCPv4ClientLeaseChange
wds.h, 1447
pack_wds_DHCPv4ClientLeaseChange_t, 475
pEnableNotification, 476
pack_wds_GetAutoconnect
wds.h, 1448
pack_wds_GetByteTotals
wds.h, 1448
pack_wds_GetConnectionRate
wds.h, 1449
pack_wds_GetDataBearerTechnology
wds.h, 1449
pack_wds_GetDefaultProfile
wds.h, 1449
pack_wds_GetDefaultProfile_t, 476
profiletype, 476
pack_wds_GetDefaultProfileNum
wds.h, 1450
pack_wds_GetDefaultProfileNum_t, 476
family, 476
type, 476
pack_wds_GetDormancyState
wds.h, 1450
pack_wds_GetDormancyState_t, 477
pack_wds_GetLastMobileIPError
wds.h, 1451
pack_wds_GetLastMobileIPError_t, 477
pack_wds_GetMobileIP
wds.h, 1451
pack_wds_GetMobileIP_t, 477
pack_wds_GetMobileIPProfile
wds.h, 1452
pack_wds_GetMobileIPProfile_t, 477
index, 478
pack_wds_GetPacketStatistics
wds.h, 1452
pack_wds_GetPacketStatistics_t, 478
pStatMask, 478
pack_wds_GetPacketStatus
wds.h, 1452
pack_wds_GetPacketStatus_t, 478
statmask, 479
pack_wds_GetSessionDuration
wds.h, 1453
pack_wds_GetSessionDuration_t, 479
pack_wds_GetSessionState
wds.h, 1453
pack_wds_RMSetTransferStatistics
wds.h, 1454
pack_wds_RMSetTransferStatistics_t, 479
RmTrasnferStaticsReq, 479
pack_wds_SLQSCreateProfile
wds.h, 1457
pack_wds_SLQSCreateProfile_t, 486
pCurProfile, 487
pProfileId, 487
pProfileType, 487
pack_wds_SLQSDeleteProfile
wds.h, 1457
pack_wds_SLQSDeleteProfile_t, 487
profileIndex, 487
profileType, 487
pack_wds_SLQSGet3GPPConfigItem
wds.h, 1458
pack_wds_SLQSGetCurrDataSystemStat
wds.h, 1458
pack_wds_SLQSGetCurrDataSystemStat_t, 487
pack_wds_SLQSGetCurrentChannelRate
wds.h, 1459
pack_wds_SLQSGetDUNCallInfo
wds.h, 1460
pack_wds_SLQSGetDUNCallInfo_t, 488
Mask, 489
pReportChannelRate, 489
pReportConnStatus, 489
pReportDataBearerTech, 489
pReportDormStatus, 489
pTransferStatInd, 489
pack_wds_SLQSGetDataBearerTechnology
wds.h, 1459
pack_wds_SLQSGetDataBearerTechnology_t, 488
pack_wds_SLQSGetProfileSettings
wds.h, 1460
pack_wds_SLQSGetProfileSettings_t, 489
ProfileId, 490
ProfileType, 490
pack_wds_SLQSGetRuntimeSettings
wds.h, 1460
pack_wds_SLQSGetRuntimeSettings_t, 490
pReqSettings, 491
pack_wds_SLQSModifyProfile
wds.h, 1461
pack_wds_SLQSModifyProfile_t, 491
curProfile, 492
pProfileId, 492
pProfileType, 492
pack_wds_SLQSResetPacketStatics
wds.h, 1461
pack_wds_SLQSSGetDHCPv4ClientConfig
wds.h, 1463
pack_wds_SLQSSGetDHCPv4ClientConfig_t, 495
pProfileId, 495
pack_wds_SLQSSGetLoopback
wds.h, 1463
pack_wds_SLQSSSetDHCPv4ClientConfig
wds.h, 1464
pack_wds_SLQSSSetDHCPv4ClientConfig_t, 495
pHwConfig, 496
pProfileId, 496
pack_wds_SLQSSSetLoopback
wds.h, 1464
pack_wds_SLQSSSetLoopback_t, 496
loopbackMode, 496
loopbackMultiplier, 496
pack_wds_SLQSSet3GPPConfigItem
wds.h, 1462

pack_wds_SLQSSet3GPPConfigItem_t, 492
p3gppRelease, 493
pProfileList, 493
pack_wds_SLQSSetIPFamilyPreference
wds.h, 1462
pack_wds_SLQSSetIPFamilyPreference_t, 494
IPFamilyPreference, 494
pack_wds_SLQSSetWdsEventCallback
wds.h, 1462
pack_wds_SLQSSetWdsEventCallback_t, 494
currentDataBearer, 495
dataBearer, 495
dataBearerTechExt, 495
dataSystemStatus, 495
dormancyStatus, 495
interval, 495
mobileIP, 495
transferStats, 495
pack_wds_SLQSStartDataSession
wds.h, 1464
pack_wds_SLQSStartDataSession_t, 496
pAuth, 497
pPass, 497
pTech, 497
pUser, 497
pprofileid3gpp, 497
pprofileid3gpp2, 497
pack_wds_SLQSStopDataSession
wds.h, 1465
pack_wds_SLQSStopDataSession_t, 498
psid, 498
pack_wds_SLQSWdsGoActive
wds.h, 1465
pack_wds_SLQSWdsGoDormant
wds.h, 1466
pack_wds_SLQSWdsSetEventReport
wds.h, 1466
pack_wds_SLQSWdsSetEventReport_t, 498
pCurrChannelRateInd, 499
pCurrDataBearerTechInd, 499
pCurrPrefDataSysInd, 499
pDataBearerTechInd, 499
pDataCallStatusChangeInd, 499
pDataSystemStatusChangeInd, 499
pDormancyStatusInd, 500
pMIPStatusInd, 500
pTransferStatInd, 500
pack_wds_SLQSWdsSwiPDPRuntimeSettings
wds.h, 1467
pack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 500
contextId, 500
contextType, 500
pack_wds_SetAutoconnect
wds.h, 1454
pack_wds_SetAutoconnect_t, 480
acroamsetting, 480
acsetting, 480
pack_wds_SetDefaultProfile
wds.h, 1454
pack_wds_SetDefaultProfile_t, 480
authentication, 481
ipAddress, 482
pApnname, 482
pName, 482
pPassword, 482
pUsername, 482
pdpType, 482
primaryDNS, 482
profileType, 482
secondaryDNS, 482
pack_wds_SetDefaultProfileNum
wds.h, 1455
pack_wds_SetDefaultProfileNum_t, 482
family, 482
index, 482
type, 482
pack_wds_SetMobileIP
wds.h, 1455
pack_wds_SetMobileIP_t, 483
mode, 483
pack_wds_SetMobileIPParameters
wds.h, 1456
pack_wds_SetMobileIPParameters_t, 483
pHA2002bis, 484
pHAAuthenticator, 484
pMode, 484
pReRegPeriod, 484
pReRegTraffic, 484
pRetryInterval, 484
pRetryLimit, 484
pSPC, 484
pack_wds_SetMobileIPProfile
wds.h, 1456
pack_wds_SetMobileIPProfile_t, 484
index, 485
pAAASPI, 486
pAddress, 486
pEnabled, 486
pHASPI, 486
pMNAAA, 486
pMNHA, 486
pNAI, 486
pPrimaryHA, 486
pRevTunneling, 486
pSecondaryHA, 486
spc, 486
pack_wds_SetMuxID
wds.h, 1457
PackCreateProfileOut, 500
ExtErrorCode, 501
ProfileIndex, 501
ProfileType, 501
PackSwiAVMSSettingsAPNInfo, 504
bAPNLength, 504
bPWDLength, 504
bUnameLength, 505

pAPN, 505
pPWD, 505
pUname, 505
PackSwiAVMSSettingsConnectionRetryTimers, 505
Timers, 505
PackSwiAVMSSettingsPeriodsInfo, 506
max, 506
min, 506
PackSwiAvmsSetSettingsAPNInfo, 502
bAPNLength, 503
bPWDLength, 503
bUnameLength, 503
szAPN, 503
szPWD, 503
szUname, 503
PackSwiAvmsSetSettingsConnectionRetryTimers, 503
Timers, 503
PackSwiAvmsSetSettingsPeriodInfo, 504
ulMax, 504
ulMin, 504
package_name
unpack_omaDmFotaTlv_t, 768
packageid_str
unpack_dms_GetFirmwareInfo_t, 586
packetZone
nas_CDMASysInfo, 156
packetZoneValid
nas_CDMASysInfo, 156
packgetDyingGaspCfg, 501
pDestSMSContent, 501
pDestSMSNum, 501
packgetDyingGaspStatistics, 501
pSMSAttemptedFlag, 502
pTimeStamp, 502
ParamPresenceMask
pack_dms_UIMGetICCID_t, 331
unpack_audio_SLQSGetAudioPathConfig_t, 567
unpack_audio_SLQSGetAudioProfile_t, 569
unpack_audio_SLQSGetAudioVolTLBConfig_t, 569
unpack_audio_SLQSSetAudioVolTLBConfig_t, 570
unpack_cat_SetCatEventCallback_ind_t, 570
unpack_cat_SetCATEventCallback_t, 571
unpack_dms_GetActivationState_t, 572
unpack_dms_GetBandCapability_t, 574
unpack_dms_GetCrashAction_t, 574
unpack_dms_GetCustFeature_t, 577
unpack_dms_GetCustFeaturesV2_t, 578
unpack_dms_GetDeviceCap_t, 579
unpack_dms_GetDeviceCapabilities_t, 581
unpack_dms_GetDeviceHardwareRev_t, 581
unpack_dms_GetDeviceMfr_t, 582
unpack_dms_GetDeviceSerialNumbers_t, 584
unpack_dms_GetFirmwareInfo_t, 586
unpack_dms_GetFirmwareRevision_t, 587
unpack_dms_GetFirmwareRevisions_t, 588
unpack_dms_GetFSN_t, 589
unpack_dms_GetHardwareRevision_t, 589
unpack_dms_GetIMSI_t, 590
unpack_dms_GetManufacturer_t, 590
unpack_dms_GetModelID_t, 591
unpack_dms_GetNetworkTime_t, 592
unpack_dms_GetOfflineReason_t, 593
unpack_dms_GetPower_t, 594
unpack_dms_GetPRLVersion_t, 595
unpack_dms_GetSerialNumbers_t, 596
unpack_dms_GetUSBComp_t, 598
unpack_dms_GetVoiceNumber_t, 599
unpack_dms_PSMCfgChange_ind_t, 600
unpack_dms_ResetToFactoryDefaults_t, 601
unpack_dms_SetActivationStatusCallback_t, 601
unpack_dms_SetCrashAction_t, 602
unpack_dms_SetCustFeature_t, 602
unpack_dms_SetCustFeaturesV2_t, 603
unpack_dms_SetEventReport_ind_t, 604
unpack_dms_SetEventReport_t, 604
unpack_dms_SetFirmwarePreference_t, 605
unpack_dms_SetIndicationRegister_t, 605
unpack_dms_SetPower_t, 606
unpack_dms_SetUSBComp_t, 606
unpack_dms_SLQSDmsSwiGetPCInfo_t, 609
unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t, 610
unpack_dms_SLQSDmsSwiGetResetInfo_t, 611
unpack_dms_SLQSDmsSwiGetUimSelection_t, 612
unpack_dms_SLQSDmsSwiIndicationRegister_t, 613
unpack_dms_SLQSGetBandCapability_t, 617
unpack_dms_SLQSGetERIFile_t, 618
unpack_dms_SLQSGetPowerSaveModeConfig_t, 619
unpack_dms_SLQSSetPowerSaveModeConfig_t, 620
unpack_dms_SLQSSwiClearDyingGaspStatistics-_t, 620
unpack_dms_SLQSSwiGetCrashInfo_t, 621
unpack_dms_SLQSSwiGetDyingGaspCfg_t, 622
unpack_dms_SLQSSwiGetDyingGaspStatistics_t, 622
unpack_dms_SLQSSwiGetFirmwareCurr_t, 623
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 625
unpack_dms_SLQSSwiGetHostDevInfo_t, 626
unpack_dms_SLQSSwiGetOSInfo_t, 627
unpack_dms_SLQSSwiGetSerialNoExt_t, 627
unpack_dms_SLQSSwiSetDyingGaspCfg_t, 628
unpack_dms_SLQSSwiSetHostDevInfo_t, 628
unpack_dms_SLQSSwiSetOSInfo_t, 629
unpack_dms_SLQSUIMGetState_t, 630
unpack_dms_SwiEventReportCallBack_ind_t, 630
unpack_dms_SwiSetEventReport_t, 631
unpack_dms_SwiUimSelect_t, 631
unpack_dms_UIMGetControlKeyStatus_t, 632
unpack_dms_UIMGetICCID_t, 633
unpack_dms_UIMGetPINStatus_t, 635

unpack_dms_UIMSetControlKeyProtection_t, 635
unpack_dms_UIMSetPINProtection_t, 636
unpack_dms_UIMUnblockControlKey_t, 637
unpack_fms_GetImagesPreference_t, 638
unpack_fms_GetStoredImages_t, 638
unpack_fms_SetImagesPreference_t, 639
unpack_ims_SLQSGetIMSSMSConfig_t, 640
unpack_ims_SLQSGetIMSUserConfig_t, 641
unpack_ims_SLQSGetIMSVoIPConfig_t, 644
unpack_ims_SLQSGetRegMgrConfig_t, 645
unpack_ims_SLQSGetSIPConfig_t, 646
unpack_ims_SLQSRegMgrCfgCallBack_ind_t, 647
unpack_ims_SLQSSetIMSSMSConfig_t, 648
unpack_ims_SLQSSetIMSUserConfig_t, 648
unpack_ims_SLQSSetIMSVoIPConfig_t, 649
unpack_ims_SLQSSetRegMgrConfig_t, 649
unpack_ims_SLQSSetSIPConfig_t, 650
unpack_ims_SLQSSIPCfgCallBack_ind_t, 651
unpack_ims_SLQSSMSCfgCallBack_ind_t, 652
unpack_ims_SLQSUserCfgCallBack_ind_t, 653
unpack_ims_SLQSVoIPCfgCallBack_ind_t, 655
unpack_imsa_SLQSGetIMSARegStatus_t, 656
unpack_imsa_SLQSGetIMSAServiceStatus_t, 658
unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t, 659
unpack_imsa_SLQSImsaRatStatusCallBack_ind_t, 660
unpack_imsa_SLQSImsaRegStatusCallBack_ind_t, 660
unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t, 662
unpack_loc_BestAvailPos_Ind_t, 668
unpack_loc_CradleMountCallback_Ind_t, 669
unpack_loc_Delete_Assist_Data_t, 670
unpack_loc_DeleteAssistData_Ind_t, 671
unpack_loc_EngineState_Ind_t, 672
unpack_loc_EventNMEA_Ind_t, 672
unpack_loc_EventRegister_t, 673
unpack_loc_EventTimeSyncCallback_Ind_t, 673
unpack_loc_GetServer_Ind_t, 675
unpack_loc_GnssSvInfo_Ind_t, 676
unpack_loc_InjectPositionCallback_Ind_t, 676
unpack_loc_InjectSensorDataCallback_Ind_t, 678
unpack_loc_InjectTimeSyncDataCallback_Ind_t, 679
unpack_loc_InjectUTCTimeCallback_Ind_t, 679
unpack_loc_PositionRpt_Ind_t, 685
unpack_loc_SensorStreamingCallback_Ind_t, 687
unpack_loc_SetExtPowerConfig_Ind_t, 688
unpack_loc_SetExtPowerState_t, 688
unpack_loc_SetOperationMode_Ind_t, 689
unpack_loc_SetOperationMode_t, 690
unpack_loc_SLQSLOCGetBestAvailPos_t, 691
unpack_loc_Start_t, 691
unpack_loc_Stop_t, 692
unpack_nas_GetACCOLC_t, 692
unpack_nas_GetANAAAAuthenticationStatus_t, 693
unpack_nas_GetCDMANetworkParameters_t, 695
unpack_nas_GetHomeNetwork3GPP2_t, 697
unpack_nas_GetHomeNetwork_t, 699
unpack_nas_GetNetworkPreference_t, 700
unpack_nas_GetRFInfo_t, 701
unpack_nas_GetServingNetwork_t, 704
unpack_nas_GetServingNetworkCapabilities_t, 705
unpack_nas_GetSignalStrengths_t, 705
unpack_nas_PerformNetworkScan_t, 707
unpack_nas_SetDataCapabilitiesCallback_ind_t, 708
unpack_nas_SetEventReportInd_t, 709
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 710
unpack_nas_SetNetworkPreference_t, 710
unpack_nas_SetRoamingIndicatorCallback_ind_t, 711
unpack_nas_SetServingSystemCallback_ind_t, 712
unpack_nas_SLQSGetErrorRate_t, 713
unpack_nas_SlqsGetLTECphyCAInfo_t, 714
unpack_nas_SLQSGetNetworkTime_t, 714
unpack_nas_SLQSGetOperatorNameData_t, 715
unpack_nas_SLQSGetPLMNName_t, 718
unpack_nas_SLQSGetServingSystem_t, 723
unpack_nas_SLQSGetSignalStrength_t, 726
unpack_nas_SLQSGetSysInfo_t, 729
unpack_nas_SLQSGetSysSelectionPref_t, 734
unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t, 738
unpack_nas_SLQSNasGet3GPP2Subscription_t, 739
unpack_nas_SLQSNasGetCellLocationInfo_t, 740
unpack_nas_SLQSNASGeteDRXParams_t, 742
unpack_nas_SLQSNASGeteDRXParamsExt_t, 743
unpack_nas_SLQSNASGetForbiddenNetworks_t, 744
unpack_nas_SLQSNasGetHDRColorCode_t, 744
unpack_nas_SLQSNasGetSigInfo_t, 746
unpack_nas_SLQSNasGetTxRxInfo_t, 747
unpack_nas_SLQSNasNetworkRejectCallback_Ind_t, 750
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t, 751
unpack_nas_SLQSNasSigInfoCallback_ind_t, 752
unpack_nas_SLQSNASSwiGetChannelLock_t, 753
unpack_nas_SLQSNasSwiModemStatus_t, 754
unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t, 755
unpack_nas_SLQSNasTimerCallback_ind_t, 755
unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t, 756
unpack_nas_SLQSSwiGetHDRPersonality_t, 757
unpack_nas_SLQSSwiGetHDRProtSubtype_t, 758
unpack_nas_SLQSSwiGetHRPDStats_t, 759

unpack_nas_SLQSSwiGetLteCQI_t, 760
unpack_nas_SLQSSwiGetLteSccRxInfo_t, 760
unpack_nas_SLQSSwiHDRPersonalityCallback_-Ind_t, 761
unpack_nas_SLQSSwiNetworkDebug_t, 762
unpack_nas_SLQSSwiRandIndicatorCallback_-Ind_t, 762
unpack_nas_SLQSSysInfoCallback_ind_t, 765
unpack_pds_GetPDSDefaults_t, 770
unpack_pds_GetPDSState_t, 771
unpack_pds_GetPortAutomaticTracking_t, 772
unpack_pds_GetServiceAutomaticTracking_t, 772
unpack_pds_GetXTRAAutomaticDownload_t, 773
unpack_pds_GetXTRANetwork_t, 774
unpack_pds_GetXTRAValidity_t, 774
unpack_pds_SetEventReport_Ind_t, 776
unpack_pds_SetPdsState_Ind_t, 777
unpack_pds_SLQSGetAGPSConfig_t, 778
unpack_pds_SLQSGetGPSStateInfo_t, 783
unpack_qos_BindDataPort_t, 784
unpack_qos_SLQSQosGetNetworkStatus_t, 790
unpack_qos_SLQSQosSwiReadApnExtraParams-_t, 791
unpack_qos_SLQSQosSwiReadDataStats_t, 793
unpack_qos_SLQSSetQosEventCallback_ind_t, 793
unpack_qos_SLQSSetQosEventCallback_t, 794
unpack_qos_SLQSSetQosNWStatusCallback_ind-_t, 794
unpack_qos_SLQSSetQosPriEventCallback_ind_-t, 795
unpack_qos_SLQSSetQosStatusCallback_ind_t, 796
unpack_result_t, 806
unpack_rms_GetSMSWake_t, 807
unpack_rms_SetSMSWake_t, 807
unpack_RMTransferStatistics_ind_t, 808
unpack_sar_SLQSGetRfSarState_t, 809
unpack_sms_GetSMSCAddress_t, 810
unpack_sms_SaveSMS_t, 811
unpack_sms_SendSMS_t, 811
unpack_sms_SetNewSMSCallback_ind_t, 813
unpack_sms_SetNewSMSCallback_t, 813
unpack_sms_SetSMSCAddress_t, 814
unpack_sms_SLQSDeleteSMS_t, 814
unpack_sms_SLQSGetIndicationRegister_t, 815
unpack_sms_SLQSGetMessageWaiting_t, 815
unpack_sms_SLQSGetSMS_t, 816
unpack_sms_SLQSGetSmsBroadcastConfig_t, 817
unpack_sms_SLQSGetSMSList_t, 818
unpack_sms_SLQSGetTransLayerInfo_t, 818
unpack_sms_SLQSGetTransNWRegInfo_t, 819
unpack_sms_SLQSModifySMSStatus_t, 819
unpack_sms_SLQSNWRegInfoCallback_ind_t, 820
unpack_sms_SLQSSendAsyncSMS_t, 820
unpack_sms_SLQSSetIndicationRegister_t, 821
unpack_sms_SLQSSetSmsBroadcastActivation_t, 821
unpack_sms_SLQSSetSmsBroadcastConfig_t, 822
unpack_sms_SLQSSetSmsStorage_t, 822
unpack_sms_SLQSSmsGetMaxStorageSize_t, 822
unpack_sms_SLQSSmsGetMessageProtocol_t, 823
unpack_sms_SLQSSmsSetRoutes_t, 823
unpack_sms_SLQSSwiGetSMSStorage_t, 824
unpack_sms_SLQSTransLayerInfoCallback_ind_t, 825
unpack_sms_SLQSWmsAsyncRawSendCallBack-_ind_t, 827
unpack_sms_SLQSWmsMemoryFullCallBack_ind-_t, 828
unpack_sms_SLQSWmsMessageWaitingCall-Back_ind_t, 828
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 830
unpack_swiaudio_SLQSGetM2MAudioVolume_t, 830
unpack_swiaudio_SLQSGetM2MAVMute_t, 831
unpack_swiaudio_SLQSGetM2MSpkrGain_t, 832
unpack_swiavms_SLQSAVMSEventReportInd_t, 833
unpack_swiavms_SLQSAVMSGetSettings_t, 836
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
unpack_swiavms_SLQSAVMSSendSelection_t, 839
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 839
unpack_swiavms_SLQSAvmsSetEventReport_t, 840
unpack_swiavms_SLQSAVMSSetSettings_t, 840
unpack_swiavms_SLQSAVMSSetSettings_v2_t, 841
unpack_swiavms_SLQSAVMSStartSession_t, 841
unpack_swiavms_SLQSAVMSStopSession_t, 842
unpack_swidms_SLQSSwiDmsGetMTU_t, 843
unpack_swidms_SLQSSwiDmsGetUsbComp_t, 843
unpack_swidms_SLQSSwiDmsGetUsbNetNum_t, 844
unpack_swidms_SLQSSwiDmsSetMTU_t, 845
unpack_swidms_SLQSSwiDmsSetUsbComp_t, 845
unpack_swiloc_SwiLocGetAutoStart_t, 847
unpack_swioma_SLQSOMADMAlertCallback_ind-_t, 848
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
unpack_swioma_SLQSOMADMGetSettings_t, 853
unpack_swioma_SLQSOMADMStartSession_t, 853

unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t, 854
unpack_tmd_SLQSTmdGetMitigationDevList_t, 855
unpack_tmd_SLQSTmdGetMitigationLvl_t, 855
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t, 856
unpack_tmd_SLQSTmdRegNotMitigationLvl_t, 857
unpack_uim_ChangePin_t, 857
unpack_uim_GetCardStatus_t, 858
unpack_uim_ReadTransparent_t, 859
unpack_uim_SetPinProtection_t, 860
unpack_uim_SetUimSlotStatusChangeCallback_ind_t, 861
unpack_uim_SLQSUIMAuthenticate_t, 861
unpack_uim_SLQSUIMDepersonalization_t, 862
unpack_uim_SLQSUIMEventRegister_t, 863
unpack_uim_SLQSUIMGetConfiguration_t, 863
unpack_uim_SLQSUIMGetFileAttributes_t, 864
unpack_uim_SLQSUIMGetSlotsStatus_t, 865
unpack_uim_SLQSUIMRefreshCallback_Ind_t, 866
unpack_uim_SLQSUIMRefreshGetLastEvent_t, 866
unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t, 867
unpack_uim_UnblockPin_t, 867
unpack_uim_VerifyPin_t, 868
unpack_voice_allCallStatusCallback_ind_t, 870
unpack_voice_DTMFEventCallback_ind_t, 871
unpack_voice_OTASPStatusCallback_ind_t, 873
unpack_voice_SLQSOriginateUSSD_t, 875
unpack_voice_SLQSVoiceAnswerCall_t, 876
unpack_voice_SLQSVoiceBurstDTMF_t, 876
unpack_voice_SLQSVoiceDialCall_t, 877
unpack_voice_SLQSVoiceEndCall_t, 878
unpack_voice_SLQSVoiceGetAllCallInfo_t, 881
unpack_voice_SLQSVoiceGetCallBarring_t, 883
unpack_voice_SLQSVoiceGetCallForwardingStatus_t, 884
unpack_voice_SLQSVoiceGetCallInfo_t, 887
unpack_voice_SLQSVoiceGetCallWaiting_t, 889
unpack_voice_SLQSVoiceGetCLIP_t, 890
unpack_voice_SLQSVoiceGetCLIR_t, 892
unpack_voice_SLQSVoiceGetCNAP_t, 893
unpack_voice_SLQSVoiceGetCOLP_t, 895
unpack_voice_SLQSVoiceGetCOLR_t, 896
unpack_voice_SLQSVoiceGetConfig_t, 898
unpack_voice_SLQSVoiceManageCalls_t, 899
unpack_voice_SLQSVoiceSendFlash_t, 899
unpack_voice_SLQSVoiceSetCallBarringPassword_t, 901
unpack_voice_SLQSVoiceSetConfig_t, 902
unpack_voice_SLQSVoiceSetSUPSService_t, 904
unpack_voice_SLQSVoiceStartContDTMF_t, 904
unpack_voice_SLQSVoiceStopContDTMF_t, 905
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 907
unpack_voice_SUPSNotificationCallback_ind_t, 910
unpack_voice_USSDNotificationCallback_ind_t, 910
unpack_voice_VoiceInfoRecCallback_ind_t, 913
unpack_voice_voicePrivacyChangeCallback_ind_t, 914
unpack_wds_DHCPv4ClientLease_ind_t, 915
unpack_wds_GetAutoconnect_t, 915
unpack_wds_GetByteTotals_t, 916
unpack_wds_GetConnectionRate_t, 917
unpack_wds_GetDataBearerTechnology_t, 918
unpack_wds_GetDefaultProfile_t, 921
unpack_wds_GetDefaultProfileNum_t, 921
unpack_wds_GetDormancyState_t, 922
unpack_wds_GetLastMobileIPError_t, 923
unpack_wds_GetMobileIP_t, 923
unpack_wds_GetMobileIPProfile_t, 925
unpack_wds_GetPacketStatistics_t, 927
unpack_wds_GetPacketStatus_t, 929
unpack_wds_GetSessionDuration_t, 930
unpack_wds_GetSessionState_t, 930
unpack_wds_RMSetTransferStatistics_t, 931
unpack_wds_SetMobileIPProfile_t, 931
unpack_wds_SLQSCreateProfile_t, 932
unpack_wds_SLQSDeleteProfile_t, 932
unpack_wds_SLQSDUNCallInfoCallBack_ind_t, 934
unpack_wds_SLQSGet3GPPConfigItem_t, 936
unpack_wds_SLQSGetCurrDataSystemStat_t, 936
unpack_wds_SLQSGetCurrentChannelRate_t, 938
unpack_wds_SLQSGetDataBearerTechnology_t, 939
unpack_wds_SLQSGetDUNCallInfo_t, 942
unpack_wds_SLQSGetProfileSettings_t, 942
unpack_wds_SLQSGetRuntimeSettings_t, 945
unpack_wds_SLQSModifyProfile_t, 946
unpack_wds_SLQSSetIPFamilyPreference_t, 947
unpack_wds_SLQSSetPacketSrvStatusCallback_t, 949
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
unpack_wds_SLQSSGetDHCPv4ClientConfig_t, 955
unpack_wds_SLQSSGetLoopback_t, 956
unpack_wds_SLQSStartDataSession_t, 956
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 959
path
uim_fileInfo, 554
pathLen
uim_fileInfo, 554
pbAuto
unpack_pds_GetPortAutomaticTracking_t, 772

unpack_pds_GetServiceAutomaticTracking_t, 772
pbEnabled
unpack_pds_GetXTRAAutomaticDownload_t, 773
pbPlatform
unpack_dms_GetOfflineReason_t, 593
pci
nas_cellParams, 157
nas_ltePCI, 208
nas_PhyCaAggPcellInfo, 229
nas_PhyCaAggScellIndType, 231
nas_PhyCaAggScellInfo, 234
nas_umtsLTENbrCell, 282
NASPhyCaAggPcellInfo, 298
NASPhyCaAggScellIndType, 300
NASPhyCaAggScellInfo, 301
pcsDigit
nas_PlmnID, 236
pcsfFQDNAddress
wds_PCSCFFQDNAddressList, 1031
PdpConnState
unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t, 659
PdpStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 344
pdpType
pack_wds_SetDefaultProfile_t, 482
pdptype
unpack_wds_GetDefaultProfile_t, 921
pds.h, 1229
pack_pds_ForceXTRADownload, 1232
pack_pds_GetPDSDefaults, 1232
pack_pds_GetPDSState, 1233
pack_pds_GetPortAutomaticTracking, 1233
pack_pds_GetServiceAutomaticTracking, 1233
pack_pds_GetXTRAAutomaticDownload, 1234
pack_pds_GetXTRANetwork, 1234
pack_pds_GetXTRAValidity, 1234
pack_pds_PDSInjectTimeReference, 1235
pack_pds_ResetPDSData, 1235
pack_pds_SLQSGetAGPSConfig, 1238
pack_pds_SLQSGetGPSStateInfo, 1238
pack_pds_SLQSPDSDeterminePosition, 1239
pack_pds_SLQSPDSInjectAbsoluteTimeReference, 1239
pack_pds_SLQSPDSInjectPositionData, 1239
pack_pds_SLQSSetAGPSConfig, 1240
pack_pds_SLQSSetPositionMethodState, 1240
pack_pds_SetEventReportCallback, 1235
pack_pds_SetPDSDefaults, 1236
pack_pds_SetPDSState, 1236
pack_pds_SetPortAutomaticTracking, 1236
pack_pds_SetServiceAutomaticTracking, 1237
pack_pds_SetXTRAAutomaticDownload, 1237
pack_pds_SetXTRANetwork, 1237
pack_pds_StartPDSTrackingSessionExt, 1240
pack_pds_StopPDSTrackingSession, 1241
unpack_pds_ForceXTRADownload, 1241
unpack_pds_ForceXTRADownload_t, 1231
unpack_pds_GetPDSDefaults, 1241
unpack_pds_GetPDSState, 1242
unpack_pds_GetPortAutomaticTracking, 1242
unpack_pds_GetServiceAutomaticTracking, 1242
unpack_pds_GetXTRAAutomaticDownload, 1243
unpack_pds_GetXTRANetwork, 1243
unpack_pds_GetXTRAValidity, 1244
unpack_pds_PDSInjectTimeReference, 1244
unpack_pds_PDSInjectTimeReference_t, 1231
unpack_pds_ResetPDSData, 1244
unpack_pds_ResetPDSData_t, 1231
unpack_pds_SLQSGetAGPSConfig, 1248
unpack_pds_SLQSGetGPSStateInfo, 1248
unpack_pds_SLQSPDSDeterminePosition, 1248
unpack_pds_SLQSPDSDeterminePosition_t, 1232
unpack_pds_SLQSPDSInjectAbsoluteTimeReference, 1249
unpack_pds_SLQSPDSInjectAbsoluteTimeReference_t, 1232
unpack_pds_SLQSPDSInjectPositionData, 1249
unpack_pds_SLQSPDSInjectPositionData_t, 1232
unpack_pds_SLQSSetAGPSConfig, 1249
unpack_pds_SLQSSetAGPSConfig_t, 1232
unpack_pds_SLQSSetPositionMethodState, 1250
unpack_pds_SLQSSetPositionMethodState_t, 1232
unpack_pds_SetEventReport_Ind, 1245
unpack_pds_SetEventReportCallback, 1245
unpack_pds_SetEventReportCallback_t, 1231
unpack_pds_SetPDSDefaults, 1245
unpack_pds_SetPDSDefaults_t, 1231
unpack_pds_SetPDSState, 1246
unpack_pds_SetPDSState_t, 1231
unpack_pds_SetPdsState_Ind, 1246
unpack_pds_SetPortAutomaticTracking, 1246
unpack_pds_SetPortAutomaticTracking_t, 1231
unpack_pds_SetServiceAutomaticTracking, 1247
unpack_pds_SetServiceAutomaticTracking_t, 1232
unpack_pds_SetXTRAAutomaticDownload, 1247
unpack_pds_SetXTRAAutomaticDownload_t, 1232
unpack_pds_SetXTRANetwork, 1247
unpack_pds_SetXTRANetwork_t, 1232
unpack_pds_StartPDSTrackingSessionExt, 1250
unpack_pds_StartPDSTrackingSessionExt_t, 1232
unpack_pds_StopPDSTrackingSession, 1250
unpack_pds_StopPDSTrackingSession_t, 1232
peakRate
unpack_qos_tokenBucket_t, 804
peakThroughputClass
LibPackGPRSRequestedQoS, 92
wds_GPRSQoS, 1028
PeriodicUpdateTimer
unpack_dms_PSMCfgChange_ind_t, 600
periodicUpdateTimer
dms_PSMPeriodicUpdateTimerTlv, 58
PeriodicUpdateTimerInd
dms_PSMPeriodicUpdateTimerIndTlv, 57
PersistentLpm

unpack_dms_SLQSDmsSwiGetPCInfo_t, 609
PersistentTechPref
unpack_nas_GetNetworkPreference_t, 700
persoFeature
appStats, 37
uim_appStatus, 543
persoRetries
appStats, 37
uim_appStatus, 543
persoState
appStats, 37
uim_appStatus, 543
persoUnblockRetries
appStats, 37
uim_appStatus, 543
pfailureCause
unpack_voice_SLQSOriginateUSSD_t, 875
PhCtxtURI
ims_PhCtxtURIInfo, 77
phase
nas_rxInfo, 259
PhyCaAggPcellInfo
NasGetLTECphyCaInfo, 293
PhyCaAggScellDlBw
NasGetLTECphyCaInfo, 293
PhyCaAggScellIndType
NasGetLTECphyCaInfo, 293
PhyCaAggScellIndex
NasGetLTECphyCaInfo, 293
PhyCaAggScellInfo
NasGetLTECphyCaInfo, 293
PhysicalLayer
nas_protocolSubtypeElement, 240
PilotEnergy
nas_NetworkStatEVDO, 225
PilotPN
nas_PilotSetParams, 235
PilotStrength
nas_PilotSetParams, 235
PilotType
nas_PilotSetParams, 235
pin1Len
uim_encryptedPIN1, 550
pin1Retries
appStats, 38
uim_appStatus, 543
pin1State
appStats, 38
uim_appStatus, 543
pin1Val
uim_encryptedPIN1, 550
pin2Retries
appStats, 38
uim_appStatus, 543
pin2State
appStats, 38
uim_appStatus, 544
pinID
uim_changeUIMPIN, 548
uim_setPINProtection, 561
uim_unblockUIMPIN, 564
uim_verifyUIMPIN, 565
pinLen
uim_changeUIMPIN, 548
uim_verifyUIMPIN, 565
pinLength
uim_setPINProtection, 561
pinOperation
uim_setPINProtection, 561
pinProtection
pack_uim_SetPinProtection_t, 447
pack_uim_UnblockPin_t, 455
pinVal
uim_changeUIMPIN, 548
uim_verifyUIMPIN, 565
pinValue
uim_setPINProtection, 561
PkgDescLength
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
PkgDescription
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
PkgName
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
PkgNameLength
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
pkgver
unpack_dms_SLQSSwiGetFirmwareCurr_t, 623
PktErrRate
unpack_qos_swiQosFlow_t, 804
plasmaIDString
pack_dms_SLQSSwiSetHostDevInfo_t, 328
unpack_dms_SLQSSwiGetHostDevInfo_t, 626
plmn
nas_GERANInfo, 177
nas_LTEInfoIntrafreq, 201
nas_UMTSInfo, 280
PlmnLen
nas_QmisNasSlqsNasPCICellInfo, 244
polarityIncluded
voice_lineCtrlInfo, 1005
port
loc_IPv4Info, 132
loc_IPv6Info, 133
unpack_qos_Port_t, 787
posDataNmea
pack_pds_SetEventReportCallback_t, 400
posSrc
unpack_pds_SetEventReport_Ind_t, 777
PositionDataNMEA
unpack_pds_SetEventReport_Ind_t, 776
positionSrc
pack_loc_SLQSLOCInjectPosition_t, 354

PowerOffMode
unpack_dms_SLQSDmsSwiGetPCInfo_t, 609
pprofileid3gpp
pack_wds_SLQSStartDataSession_t, 497
pprofileid3gpp2
pack_wds_SLQSStartDataSession_t, 497
prDNSIPv4Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 959
prDNSIPv6Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 959
prPCSCFIPv4Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 959
prPCSCFIPv6Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings-_t, 959
Precedence
unpack_qos_swiQosFilter_t, 800
precedenceClass
LibPackGPRSRequestedQoS, 92
wds_GPRSQoS, 1028
prefNetwork
unpack_wds_SLQSGetCurrDataSystemStat_t, 937
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
preference
pack_pds_SetXTRANetwork_t, 403
Preferred
nas_QmiNas3GppNetworkInfo, 242
prefixLen
unpack_qos_IPv6Addr_t, 786
presentationInd
voice_ECTNum, 1001
voice_remotePartyNum, 1013
priCSCFPort
ims_PCSCFPortInfo, 77
priChA
nas_CDMAChannel, 150
priChB
nas_CDMAChannel, 150
priSize
unpack_dms_GetFirmwareRevisions_t, 588
pridns
unpack_wds_GetDefaultProfile_t, 921
pridnsv6
unpack_wds_GetDefaultProfile_t, 921
primaryDNS
pack_wds_SetDefaultProfile_t, 482
PrimaryDNSV4
unpack_wds_SLQSGetRuntimeSettings_t, 945
PrimaryDNSV6
unpack_wds_SLQSGetRuntimeSettings_t, 945
primaryHA
unpack_wds_GetMobileIPProfile_t, 925
privacyPref
pack_voice_SLQSVoiceSetPreferredPrivacy_t, 472
priver
unpack_dms_SLQSSwiGetFirmwareCurr_t, 623
priversion_str
unpack_dms_GetFirmwareInfo_t, 586
Profile
pack_audio_SLQSGetAudioPathConfig_t, 309
pack_audio_SLQSGetAudioVolTLBConfig_t, 310
pack_audio_SLQSSetAudioPathConfig_t, 312
pack_audio_SLQSSetAudioProfile_t, 313
pack_audio_SLQSSetAudioVolTLBConfig_t, 314
pack_swiaudio_SLQSGetM2MAudioVolume_t, 423
pack_swiaudio_SLQSGetM2MAVMute_t, 424
pack_swiaudio_SLQSGetM2MSpkrGain_t, 424
pack_swiaudio_SLQSSetM2MAudioAVCFG_t, 425
pack_swiaudio_SLQSSetM2MAudioProfile_t, 426
pack_swiaudio_SLQSSetM2MAudioVolume_t, 427
pack_swiaudio_SLQSSetM2MAVMute_t, 428
pack_swiaudio_SLQSSetM2MSpkrGain_t, 428
unpack_audio_SLQSGetAudioProfile_t, 569
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 830
ProfileID
unpack_wds_SLQSGetRuntimeSettings_t, 945
ProfileId
pack_wds_SLQSGetProfileSettings_t, 490
profileId
wds_DHCPProfileIdTlv, 1024
wds_DHCPv4ProfileId, 1026
wdsDhcpv4ProfileId, 1040
ProfileId3GPP2
unpack_qos_swiQosFlow_t, 804
ProfileIdTlv
unpack_wds_DHCPv4ClientLease_ind_t, 915
ProfileIndex
PackCreateProfileOut, 501
profileIndex
pack_wds_SLQSDeleteProfile_t, 487
wds_ProfileIdentifier, 1033
profileList
unpack_wds_SLQSGet3GPPConfigItem_t, 936
ProfileName
unpack_wds_SLQSGetRuntimeSettings_t, 945
ProfileType
pack_wds_SLQSGetProfileSettings_t, 490
PackCreateProfileOut, 501
unpack_wds_SLQSGetProfileSettings_t, 942
profileType
pack_wds_SetDefaultProfile_t, 482
pack_wds_SLQSDeleteProfile_t, 487
wds_DHCPProfileIdTlv, 1024
wds_DHCPv4ProfileId, 1026
wds_ProfileIdentifier, 1033
wdsDhcpv4ProfileId, 1040
profiletype
pack_wds_GetDefaultProfile_t, 476
PromptFwDownload

pack_swiavms_SLQSAVMSSetSettings_t, 431
pack_swiavms_SLQSAVMSSetSettings_v2_t, 433
PromptFwUpdate
pack_swiavms_SLQSAVMSSetSettings_t, 431
pack_swiavms_SLQSAVMSSetSettings_v2_t, 433
Protocol
unpack_nas_GetCDMANetworkParameters_t, 695
ProvisionStatus
voice_CLIPResp, 992
voice_CLIRResp, 993
voice_CNAPResp, 994
voice_COLPResp, 994
voice_COLRResp, 995
psAttachState
nas_servSystem, 264
NASServingSystemInfo, 307
psBarStatus
nas_CallBarringSysInfo, 148
nas_callBarStatus, 149
psState
nas_CommInfo, 161
psc
nas_UMTSInfo, 280
nas_wcdmaCellInfo, 284
nas_WCDMASysInfo, 289
pscValid
nas_WCDMASysInfo, 289
pscsfIPv4Addr
wds_PCSCFIPv4ServerAddressList, 1032
psetting
unpack_wds_GetAutoconnect_t, 915
psid
pack_wds_SLQSStopDataSession_t, 498
unpack_wds_SLQSStartDataSession_t, 956
puk1Retries
appStats, 38
uim_appStatus, 544
puk2Retries
appStats, 38
uim_appStatus, 544
pukLen
uim_unblockUIMPIN, 564
pukVal
uim_unblockUIMPIN, 565
pukValue
pack_dms_UIMUnblockPIN_t, 334
pwrDenialTime
voice_lineCtrlInfo, 1005

QMI_LITE_WDS_CURRENT_CALL_DB_MASK
wds.h, 1447
QMI_LITE_WDS_LAST_CALL_DB_MASK
wds.h, 1447
QCI
LibPackQosClassID, 117
QFlowState
unpack_qos_QosFlowInfo_t, 788
QLIC
nas_DeviceConfigDetail, 168
QMI pack/unpack (lite-qmi), 29
qaGobiApiTableBandClasses.h, 1251
qaGobiApiTableCallControlReturnReasons.h, 1254
qaGobiApiTableCallEndReasons.h, 1255
qaGobiApiTableCarrierCodes.h, 1271
qaGobiApiTableCodingScheme.h, 1273
qaGobiApiTableGpsCapabilityCodes.h, 1276
qaGobiApiTablePowerModes.h, 1277
qaGobiApiTableRadioInterfaces.h, 1277
qaGobiApiTableRegionCodes.h, 1278
qaGobiApiTableServiceOptions.h, 1278
qaGobiApiTableSupServiceInfoClasses.h, 1281
qaGobiApiTableSwiAudio.h, 1281
qaGobiApiTableSwiOMADMSessionStatus.h, 1282
qaGobiApiTableSwiOMADMUpdateCompleteStatus.h, 1283
qaGobiApiTableVoiceCallEndReasons.h, 1284
qm_wds_ds_profile_extended_err_codes
qmerrno.h, 1297
qmTlvResult, 507
DeviceError, 507
DeviceResult, 507
TlvPresenceMask, 507
TlvResultCode, 507
qmerrno.h
eQCWWAN_ERR_API_MUTEX_TIMEOUT, 1294
eQCWWAN_ERR_BUFFER_SZ, 1293
eQCWWAN_ERR_CANCEL_OP, 1294
eQCWWAN_ERR_DRIVER, 1294
eQCWWAN_ERR_ENUM_BEGIN, 1293
eQCWWAN_ERR_ENUM_END, 1294
eQCWWAN_ERR_FILE_COPY, 1293
eQCWWAN_ERR_FILE_OPEN, 1293
eQCWWAN_ERR_GENERAL, 1293
eQCWWAN_ERR_INTERNAL, 1293
eQCWWAN_ERR_INVALID_ARG, 1293
eQCWWAN_ERR_INVALID_DEVID, 1293
eQCWWAN_ERR_INVALID_FILE, 1293
eQCWWAN_ERR_INVALID_QMI_RSP, 1293
eQCWWAN_ERR_INVALID_XID, 1294
eQCWWAN_ERR_MALFORMED_QMI_RSP, 1293
eQCWWAN_ERR_MEMORY, 1293
eQCWWAN_ERR_MULTIPLE_DEVICES, 1294
eQCWWAN_ERR_MULTIPLE_SMS_UNSUPPORTED, 1294
eQCWWAN_ERR_NO_CANCELABLE_OP, 1294
eQCWWAN_ERR_NO_CONNECTION, 1293
eQCWWAN_ERR_NO_DEVICE, 1293
eQCWWAN_ERR_NO_SIGNAL, 1294
eQCWWAN_ERR_NONE, 1293
eQCWWAN_ERR_NULL_TLV, 1297
eQCWWAN_ERR_OFFLINE, 1294
eQCWWAN_ERR_PDU_GENERATION, 1294
eQCWWAN_ERR_QMI_ABORTED, 1294
eQCWWAN_ERR_QMI_ACCESS_DENIED, 1296
eQCWWAN_ERR_QMI_ACK_NOT_SENT, 1296
eQCWWAN_ERR_QMI_ARG_TOO_LONG, 1294

eQCWWAN_ERR_QMI_AUTHENTICATION_FAILED, 1295
eQCWWAN_ERR_QMI_AUTHENTICATION_LOCK, 1295
eQCWWAN_ERR_QMI_BUNDLING_NOT_SUPPORTED, 1296
eQCWWAN_ERR_QMI_CALL_FAILED, 1294
eQCWWAN_ERR_QMI_CARD_BUSY_RSP, 1297
eQCWWAN_ERR_QMI_CARD_CALL_CONTROL_FAILED, 1296
eQCWWAN_ERR_QMI_CAT_END, 1297
eQCWWAN_ERR_QMI_CAT_START, 1297
eQCWWAN_ERR_QMI_CAUSE_CODE, 1295
eQCWWAN_ERR_QMI_CLIENT_IDS_EXHAUSTED, 1294
eQCWWAN_ERR_QMI_CONNECT, 1293
eQCWWAN_ERR_QMI_DEVICE_IN_USE, 1294
eQCWWAN_ERR_QMI_DEVICE_NOT_READY, 1295
eQCWWAN_ERR_QMI_DEVICE_STORAGE_FULL, 1295
eQCWWAN_ERR_QMI_DISABLED, 1295
eQCWWAN_ERR_QMI_ENCODING, 1295
eQCWWAN_ERR_QMI_ENVELOPE_CMD_FAILURE, 1297
eQCWWAN_ERR_QMI_EVENT_REG_FAILED, 1297
eQCWWAN_ERR_QMI_EXTENDED_INTERNAL, 1296
eQCWWAN_ERR_QMI_FDN_RESTRICT, 1296
eQCWWAN_ERR_QMI_FLOW_SUSPENDED, 1295
eQCWWAN_ERR_QMI_GENERAL, 1295
eQCWWAN_ERR_QMI_HARDWARE_RESTRICTED, 1296
eQCWWAN_ERR_QMI_IFACE, 1293
eQCWWAN_ERR_QMI_INCOMPATIBLE_STATE, 1296
eQCWWAN_ERR_QMI_INCORRECT_FLOW_FILTER, 1295
eQCWWAN_ERR_QMI_INCORRECT_PIN, 1294
eQCWWAN_ERR_QMI_INFO_UNAVAILABLE, 1296
eQCWWAN_ERR_QMI_INJECT_TIMEOUT, 1296
eQCWWAN_ERR_QMI_INSUFFICIENT_RESOURCES, 1295
eQCWWAN_ERR_QMI_INTERFACE_NOT_FOUND, 1295
eQCWWAN_ERR_QMI_INTERNAL, 1294
eQCWWAN_ERR_QMI_INVALID_ARG, 1295
eQCWWAN_ERR_QMI_INVALID_CLIENT_ID, 1294
eQCWWAN_ERR_QMI_INVALID_DATA_FORMAT, 1295
eQCWWAN_ERR_QMI_INVALID_ENVELOPE_CMD, 1297
eQCWWAN_ERR_QMI_INVALID_HANDLE, 1294
eQCWWAN_ERR_QMI_INVALID_ID, 1295
eQCWWAN_ERR_QMI_INVALID_INDEX, 1295
eQCWWAN_ERR_QMI_INVALID_IP_FAMILY_PREF, 1295
eQCWWAN_ERR_QMI_INVALID_MCAST_HANDLE, 1295
eQCWWAN_ERR_QMI_INVALID_MESSAGE_ID, 1295
eQCWWAN_ERR_QMI_INVALID_OPERATION, 1296
eQCWWAN_ERR_QMI_INVALID_PDP_TYPE, 1294
eQCWWAN_ERR_QMI_INVALID_PINID, 1294
eQCWWAN_ERR_QMI_INVALID_PROFILE, 1294
eQCWWAN_ERR_QMI_INVALID_PROFILE_TYPE, 1294
eQCWWAN_ERR_QMI_INVALID_PS_ATTACH_ACTION, 1295
eQCWWAN_ERR_QMI_INVALID_QMI_CMD, 1296
eQCWWAN_ERR_QMI_INVALID_QOS_ID, 1295
eQCWWAN_ERR_QMI_INVALID_REGISTER_ACTION, 1295
eQCWWAN_ERR_QMI_INVALID_SERVICE_TYPE, 1294
eQCWWAN_ERR_QMI_INVALID_TECH_PREF, 1294
eQCWWAN_ERR_QMI_INVALID_TERMINAL_RSP, 1297
eQCWWAN_ERR_QMI_INVALID_TRANSITION, 1295
eQCWWAN_ERR_QMI_INVALID_TX_ID, 1294
eQCWWAN_ERR_QMI_MALFORMED_MSG, 1294
eQCWWAN_ERR_QMI_MAX, 1296
eQCWWAN_ERR_QMI_MAX_MCAST_REQUESTS_IN_USE, 1295
eQCWWAN_ERR_QMI_MAX_QOS_REQUESTS_IN_USE, 1295
eQCWWAN_ERR_QMI_MESSAGE_DELIVERY_FAILURE, 1295
eQCWWAN_ERR_QMI_MESSAGE_NOT_SENT, 1295
eQCWWAN_ERR_QMI_MISSING_ARG, 1294
eQCWWAN_ERR_QMI_MSG_BLOCKED, 1296
eQCWWAN_ERR_QMI_NETWORK_ABORTED, 1296
eQCWWAN_ERR_QMI_NETWORK_NOT_READY, 1295
eQCWWAN_ERR_QMI_NETWORK_QOS_UNAWARE, 1295
eQCWWAN_ERR_QMI_NO_EFFECT, 1294
eQCWWAN_ERR_QMI_NO_ENTRY, 1295
eQCWWAN_ERR_QMI_NO_FREE_PROFILE, 1294
eQCWWAN_ERR_QMI_NO_MEMORY, 1294
eQCWWAN_ERR_QMI_NO_NETWORK_FOUND, 1294
eQCWWAN_ERR_QMI_NO_RADIO, 1296

eQCWWAN_ERR_QMI_NO_SUBSCRIPTION, 1296
eQCWWAN_ERR_QMI_NO_THRESHOLDS, 1294
eQCWWAN_ERR_QMI_NOT_A_MCAST_IFACE, 1295
eQCWWAN_ERR_QMI_NOT_PROVISIONED, 1294
eQCWWAN_ERR_QMI_NOT_SUPPORTED, 1296
eQCWWAN_ERR_QMI_OFFSET, 1294
eQCWWAN_ERR_QMI_OP_DEVICE_UNSUPPORTED, 1294
eQCWWAN_ERR_QMI_OP_NETWORK_UNSUPPORTED, 1294
eQCWWAN_ERR_QMI_OP_PARTIAL_FAILURE, 1296
eQCWWAN_ERR_QMI_OUT_OF_CALL, 1294
eQCWWAN_ERR_QMI_PIN_BLOCKED, 1295
eQCWWAN_ERR_QMI_PIN_PERM_BLOCKED, 1295
eQCWWAN_ERR_QMI_POLICY_MISMATCH, 1296
eQCWWAN_ERR_QMI_REQ, 1293
eQCWWAN_ERR_QMI_REQ_SCH, 1293
eQCWWAN_ERR_QMI_REQ_TO, 1293
eQCWWAN_ERR_QMI_REQUESTED_NUM_UNSUPPORTED, 1295
eQCWWAN_ERR_QMI_RSP, 1293
eQCWWAN_ERR_QMI_RSP_TO, 1293
eQCWWAN_ERR_QMI_SEGMENT_ORDER, 1296
eQCWWAN_ERR_QMI_SEGMENT_TOO_LONG, 1296
eQCWWAN_ERR_QMI_SESSION_INACTIVE, 1295
eQCWWAN_ERR_QMI_SESSION_INVALID, 1295
eQCWWAN_ERR_QMI_SESSION_OWNERSHIP, 1295
eQCWWAN_ERR_QMI_SIM_FILE_NOT_FOUND, 1296
eQCWWAN_ERR_QMI_SIM_NOT_INITIALIZED, 1295
eQCWWAN_ERR_QMI_SMSC_ADDR, 1296
eQCWWAN_ERR_QMI_SUPS_FAILURE_CAUSE, 1296
eQCWWAN_ERR_QMI_TPDU_TYPE, 1296
eQCWWAN_ERR_QMI_UNABORTABLE_TRANSACTION, 1294
eQCWWAN_ERR_QMI_UNKNOWN, 1295
eQCWWAN_ERR_QMI_WIDTH, 1297
eQCWWAN_ERR_RESET, 1294
eQCWWAN_ERR_SWICM_AM_VERS_ERROR, 1296
eQCWWAN_ERR_SWICM_CALL_IN_PROGRESS, 1296
eQCWWAN_ERR_SWICM_END, 1297
eQCWWAN_ERR_SWICM_FAILED_TO_KILL_SDK_PROCESS, 1296
eQCWWAN_ERR_SWICM_INVALID_SESSION_ID, 1296
eQCWWAN_ERR_SWICM_INVALID_V4_SESSION_ID, 1296
eQCWWAN_ERR_SWICM_INVALID_V6_SESSION_ID, 1296
eQCWWAN_ERR_SWICM_NOT_IMPLEMENTED, 1296
eQCWWAN_ERR_SWICM_QMI_CLNT_NOT_SUPPORTED, 1296
eQCWWAN_ERR_SWICM_QMI_SVC_NOT_SUPPORTED, 1296
eQCWWAN_ERR_SWICM_SM_NO_AVAILABLE_SESSIONS, 1296
eQCWWAN_ERR_SWICM_SOCKET_IN_USE, 1296
eQCWWAN_ERR_SWICM_START, 1296
eQCWWAN_ERR_SWICM_TIMEOUT, 1296
eQCWWAN_ERR_SWICM_V4DWN_V6DWN, 1296
eQCWWAN_ERR_SWICM_V4DWN_V6UP, 1296
eQCWWAN_ERR_SWICM_V4UP_V6DWN, 1296
eQCWWAN_ERR_SWICM_V4UP_V6UP, 1296
eQCWWAN_ERR_SWIDCS_APP_DISCONNECTED, 1297
eQCWWAN_ERR_SWIDCS_DEVNODE_NOT_FOUND, 1297
eQCWWAN_ERR_SWIDCS_END, 1297
eQCWWAN_ERR_SWIDCS_FILEIO_ERR, 1297
eQCWWAN_ERR_SWIDCS_IOCTL_ERR, 1297
eQCWWAN_ERR_SWIDCS_START, 1297
eQCWWAN_ERR_SWIIM_CORRUPTED_FW_IMAGE, 1297
eQCWWAN_ERR_SWIIM_END, 1297
eQCWWAN_ERR_SWIIM_FILE_NOT_FOUND, 1297
eQCWWAN_ERR_SWIIM_FIRMWARE_NOT_DOWNLOADED, 1297
eQCWWAN_ERR_SWIIM_FW_ENTER_DOWNLOAD_MODE, 1297
eQCWWAN_ERR_SWIIM_FW_FLASH_COMPLETE, 1297
eQCWWAN_ERR_SWIIM_FW_INVALID_SLOT_INDEX, 1297
eQCWWAN_ERR_SWIIM_FW_PREFERENCE_MISMATCH, 1297
eQCWWAN_ERR_SWIIM_FW_SAME_AS_CURRENT_ACTIVE_IMAGE, 1297
eQCWWAN_ERR_SWIIM_FW_SECBOOT_IMAGE_NOT_SIGNED, 1297
eQCWWAN_ERR_SWIIM_FW_SECBOOT_INVALID_CERT_CHAIN, 1297
eQCWWAN_ERR_SWIIM_FW_UPDATE_FAIL, 1297
eQCWWAN_ERR_SWIIM_FW_UPDATE_SUCCESS, 1297

eQCWWAN_ERR_SWIIM_FW_WAIT_FOR_REBOOT, 1297
eQCWWAN_ERR_SWIIM_INVALID_CRASH_STATE, 1297
eQCWWAN_ERR_SWIIM_INVALID_PATH, 1297
eQCWWAN_ERR_SWIIM_OPENING_DIR, 1297
eQCWWAN_ERR_SWIIM_OPENING_FILE, 1297
eQCWWAN_ERR_SWIIM_START, 1297
eQCWWAN_ERR_SWISM_END, 1297
eQCWWAN_ERR_SWISMS_BEARER_DATA_NOT_FOUND, 1297
eQCWWAN_ERR_SWISMS_MSG_CORRUPTED, 1297
eQCWWAN_ERR_SWISMS_MSG_LEN_TOO_LONG, 1297
eQCWWAN_ERR_SWISMS_SMSC_NUM_CORRUPTED, 1297
eQCWWAN_ERR_SWISMS_START, 1297
eWDS_ERR_PROFILE_REG_3GPP2_ERR_INVALID_IDENT_FOR_PROFILE, 1298
eWDS_ERR_PROFILE_REG_3GPP_ACCESS_ERR, 1298
eWDS_ERR_PROFILE_REG_3GPP_CONTEXT_NOT_DEFINED, 1298
eWDS_ERR_PROFILE_REG_3GPP_ERR_OUT_OF_PROFILES, 1298
eWDS_ERR_PROFILE_REG_3GPP_INVAL_PROFILE_FAMILY, 1298
eWDS_ERR_PROFILE_REG_3GPP_READ_ONLY_FLAG_SET, 1298
eWDS_ERR_PROFILE_REG_3GPP_VALID_FLAG_NOT_SET, 1298
eWDS_ERR_PROFILE_REG_END, 1298
eWDS_ERR_PROFILE_REG_INVAL_PROFILE_FAMILY, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_HNDL, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_IDENT, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_OP, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_NUM, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_PROFILE_TYPE, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_INVAL_SUBS_ID, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_LEN_INVALID, 1298
eWDS_ERR_PROFILE_REG_RESULT_ERR_LIB_NOT_INITED, 1298
eWDS_ERR_PROFILE_REG_RESULT_FAIL, 1298
eWDS_ERR_PROFILE_REG_RESULT_LIST_END, 1298
qmerrno.h, 1291
eQCWWANError, 1293
qm_wds_ds_profile_extended_err_codes, 1297
qmiSmsMessageList, 506
messageIndex, 506
messageTag, 506
qmiWDSDataBearerTechnology, 506
currentNetwork, 507
ratMask, 507
soMask, 507
qmuint16
SwiDataTypes.h, 1359
qmulong
SwiDataTypes.h, 1359
qos.h, 1298
pack_qos_BindDataPort, 1300
pack_qos_SLQSQosGetNetworkStatus, 1300
pack_qos_SLQSQosSwiReadApnExtraParams, 1301
pack_qos_SLQSQosSwiReadDataStats, 1302
pack_qos_SLQSSetQosEventCallback, 1302
unpack_qos_BindDataPort, 1303
unpack_qos_SLQSQosGetNetworkStatus, 1303
unpack_qos_SLQSQosSwiReadApnExtraParams, 1304
unpack_qos_SLQSQosSwiReadDataStats, 1304
unpack_qos_SLQSSetQosEventCallback, 1305
unpack_qos_SLQSSetQosEventCallback_ind, 1305
unpack_qos_SLQSSetQosNWStatusCallback_ind, 1306
unpack_qos_SLQSSetQosPriEventCallback_ind, 1306
unpack_qos_SLQSSetQosStatusCallback_ind, 1307
qos_BindDataPortMuxID_t, 507
MuxID, 508
qos_BindDataPortPeripheralEndPointID_t, 508
EndPointType, 508
IfaceID, 508
qos_BindDataPortSIODataPort_t, 508
SIODataPort, 509
qosDeliveryOrder
LibPackUMTSQoS, 121
wds_UMTSMinQoS, 1038
qosFlow
unpack_qos_SLQSQosSwiReadDataStats_t, 793
QosFlowInfo
unpack_qos_SLQSSetQosEventCallback_ind_t, 794

RAN
unpack_nas_GetServingNetwork_t, 704
RAT
nas_QmiNas3GppNetworkRAT, 243
RATMask
currNetworkInfo, 52
wds_currNetworkInfo, 1020
RBTTlv
unpack_ims_SLQSVoIPCfgCallBack_ind_t, 655

RFBandInfoElements, 509
activeBandClass, 509
activeChannel, 509
radioInterface, 509
unpack_nas_GetRFInfo_t, 701
RFTlv
unpack_nas_SetEventReportInd_t, 709
RMAutoConnect
pack_dms_SetCustFeature_t, 321
unpack_dms_GetCustFeature_t, 577
RPCause
unpack_sms_SLQSWmsAsyncRawSendCallBack-_ind_t, 827
RPTlv
NASQmiCbkNasSystemSelPrefInd, 305
RRTlv
unpack_nas_SetEventReportInd_t, 709
RSRPThresListLen
nas_RSRPThresh, 256
RSRQThresListLen
nas_RSRQThresh, 257
RSSIThresListLen
nas_RSSIThresh, 258
RTIDTlv
unpack_ims_SLQSVoIPCfgCallBack_ind_t, 655
RTTlv
unpack_ims_SLQSVoIPCfgCallBack_ind_t, 655
RX_EC_IO
nas_NetworkStat1x, 223
RX_PWR
nas_NetworkStat1x, 223
nas_NetworkStatEVDO, 225
RXBOTlv
unpack_wds_SLQSDUNCallInfoCallBack_ind_t, 934
RXChan
nas_LTEInfo, 198
rXDroppedCount
unpack_wds_GetPacketStatus_t, 929
rXOKBytesLastCall
unpack_wds_GetPacketStatus_t, 929
rXOkBytesCount
unpack_wds_GetPacketStatus_t, 929
rXPacketErrors
unpack_wds_GetPacketStatus_t, 929
rXPacketOverflows
unpack_wds_GetPacketStatus_t, 929
rXPacketSuccesses
unpack_wds_GetPacketStatus_t, 929
radio
unpack_nas_GetSignalStrengths_t, 705
radio_if
pack_nas_SLQSNasGetTxRxInfo_t, 373
radioIf
nas_ecioListElement, 170
nas_errorRateListElement, 175
nas_rsrqInformation, 256
nas_rxSignalStrengthListElement, 261
unpack_nas_SLQSNasNetworkRejectCallback_-Ind_t, 750
RadioIfaces
unpack_dms_GetDeviceCap_t, 579
unpack_dms_GetDeviceCapabilities_t, 581
unpack_nas_GetServingNetwork_t, 704
RadioIfacesSize
unpack_dms_GetDeviceCap_t, 579
unpack_nas_GetServingNetwork_t, 704
radioIfacesSize
unpack_dms_GetDeviceCapabilities_t, 581
radioInterface
nas_RFBandInfoElements, 248
nas_RfBandInfoExtFormatElements, 249
nas_RfBandwidthInfoElements, 251
nas_RfDedicatedBandInfoElements, 253
nas_RFInfoTlv, 254
nas_roamIndList, 255
nas_servSystem, 264
nas_SignalStrengthTlv, 265
nas_timeInfo, 277
RFBandInfoElements, 509
radioInterfaceList
NASServingSystemInfo, 307
radioInterfaceNo
NASServingSystemInfo, 307
radioInterfaceSize
nas_RFInfoTlv, 254
randomizationWindow
dms_PSMRandomizationWindowTlv, 58
range
unpack_qos_Port_t, 787
rankIndicatorTlv
unpack_nas_SLQSSwiRandIndicatorCallback_-Ind_t, 762
rat
nas_CSGID, 162
nas_MNRInfo, 219
RatDMTlv
NASQmiCbkNasSystemSelPrefInd, 305
RatDisabledMask
NASRatDisabledMaskTlv, 305
ratDisabledMask
nas_RatDisabledMaskTlv, 247
RatHandover
unpack_imsa_SLQSImsaRatStatusCallBack_ind_-t, 660
RatHandoverStatus
imsa_RatHandoverStatusInfo, 87
RatHandoverStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 344
ratMask
qmiWDSDataBearerTechnology, 507
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
rawHorConfidence
pack_loc_SLQSLOCInjectPosition_t, 354
rawHorUncCircular

pack_loc_SLQSLOCInjectPosition_t, 354
rawLen
uim_fileAttributes, 553
rawValue
uim_fileAttributes, 553
readTransparent
pack_uim_ReadTransparent_t, 446
Reason
pack_voice_SLQSVoiceGetCallForwardingStatus-_t, 464
pack_voice_SLQSVoiceSetCallBarringPassword_t, 470
reason
pack_voice_SLQSVoiceGetCallBarring_t, 463
pack_voice_SLQSVoiceSetSUPSService_t, 474
unpack_qos_SLQSSetQosStatusCallback_ind_t, 796
voice_ccSUPSType, 991
voice_redirNumInfo, 1011
receiptAction
sms_routeEntry, 523
reconfigReqd
unpack_wds_SLQSSetPacketSrvStatusCallback_-t, 949
recordCount
uim_fileAttributes, 553
recordSize
uim_fileAttributes, 553
RedirPartyNum
voice_arrRedirPartyNum, 978
refData
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 625
refID
pack_cat_CATSendTerminalResponse_t, 316
refString
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 625
ReferenceID
cat_AlPhaIdentifierTlv, 45
cat_EventIDDataTlv, 47
refpn
nas_CDMAInfo, 152
refreshComplete
pack_uim_SLQSUIMRefreshComplete_t, 452
refreshEvent
unpack_uim_SLQSUIMRefreshCallback_Ind_t, 866
RefreshMode
cat_RefreshTlv, 48
RefreshStage
cat_RefreshTlv, 48
regAction
pack_nas_SLQSInitiateNetworkRegistration_t, 367
RegForeignNID
unpack_nas_GetCDMANetworkParameters_t, 695
RegForeignSID
unpack_nas_GetCDMANetworkParameters_t, 695
RegHomeSID
unpack_nas_GetCDMANetworkParameters_t, 695
regInd
unpack_sms_SLQSTransLayerInfoCallback_ind_t, 825
regPrd
nas_AddCDMASysInfo, 145
regRefresh
pack_uim_SLQSUIMRefreshRegister_t, 453
regRejectInfoValid
nas_GSMSysInfo, 183
nas_LTESysInfo, 216
nas_WCDMASysInfo, 289
regState
nas_servSystem, 264
RegStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 344
registerFlag
uim_registerRefresh, 559
RegistrationState
unpack_nas_GetServingNetwork_t, 704
registrationState
NASServingSystemInfo, 307
rejCause
nas_GSMSysInfo, 183
nas_LTESysInfo, 216
nas_WCDMASysInfo, 289
rejectCause
nas_RejectReasonTlv, 247
unpack_nas_SLQSNasNetworkRejectCallback_-Ind_t, 750
rejectSrvDomain
nas_GSMSysInfo, 184
nas_LTESysInfo, 216
nas_WCDMASysInfo, 289
reliabilityClass
LibPackGPRSRequestedQoS, 92
wds_GPRSQoS, 1028
remPartyNumber
voice_remotePartyNum, 1013
RemotePartyName
voice_getAllCallRmtPtyName, 1003
RemotePartyNum
voice_getAllCallRmtPtyNum, 1003
ReqMitigationLvl
unpack_tmd_SLQSTmdGetMitigationLvl_t, 855
resBerRatio
LibPackUMTSQoS, 122
wds_UMTSMinQoS, 1038
ResCode
unpack_audio_SLQSGetAudioVolTLBConfig_t, 569
unpack_audio_SLQSSetAudioVolTLBConfig_t, 570
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 625
resetInfoInd
pack_dms_SLQSDmsSwiIndicationRegister_t, 325
resultcode
unpack_swiavms_SLQSAVMSEventReportInd_t, 833

unpack_swiavms_SLQSAVMSGetSettings_t, 836
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 838
unpack_swiavms_SLQSAVMSSendSelection_t, 839
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 840
unpack_swiavms_SLQSAvmsSetEventReport_t, 840
unpack_swiavms_SLQSAVMSSetSettings_t, 840
unpack_swiavms_SLQSAVMSSetSettings_v2_t, 841
unpack_swiavms_SLQSAVMSStartSession_t, 841
unpack_swiavms_SLQSAVMSStopSession_t, 842
RetryCount
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
revPolarity
voice_lineCtrlInfo, 1005
revTunneling
unpack_wds_GetMobileIPProfile_t, 925
ReverseMac
nas_protocolSubtypeElement, 240
RfSarState
pack_sar_SLQSSetRfSarState_t, 413
rfbandInfoList
unpack_nas_SLQSNasGetRFInfo_t, 745
RingBkTmr
ims_RngBkTmrInfo, 78
RingTmr
ims_RngTmrInfo, 78
RmTrasnferStaticsReq
pack_wds_RMSetTransferStatistics_t, 479
rmTrasnferStaticsReq, 509
bResetStatistics, 510
ulMask, 510
rms.h, 1308
pack_rms_GetSMSWake, 1308
pack_rms_SetSMSWake, 1309
unpack_rms_GetSMSWake, 1309
unpack_rms_SetSMSWake, 1309
RmtPtyNum
voice_arrRemotePartyNum, 979
roamIndicator
nas_roamIndList, 255
RoamIndicatorVal
unpack_nas_SLQSGetServingSystem_t, 723
roamOrigVoiceSO
voice_prefVoiceSO, 1010
RoamPref
nas_RoamPrefTlv, 255
NASRoamPreferenceTlv, 305
roamStatus
nas_sysInfoCommon, 272
roamStatusValid
nas_sysInfoCommon, 272
roamTimerValue
voice_roamTimer, 1014
Roaming
nas_QmiNas3GppNetworkInfo, 242
unpack_nas_GetCDMANetworkParameters_t, 695
unpack_nas_GetServingNetwork_t, 704
roaming
unpack_nas_SetRoamingIndicatorCallback_ind_t, 711
RoamingIndicatorList
unpack_nas_SLQSGetServingSystem_t, 723
routeList
sms_setRoutesReq, 527
routeStorage
sms_routeEntry, 523
RptIMSCapability
pack_dms_SetIndicationRegister_t, 323
rptPosData
pack_pds_SetEventReportCallback_t, 400
rptRate
nas_LTESigRptCfg, 211
nas_LTESigRptConfig, 212
rscp
nas_rxInfo, 259
nas_UMTSInfo, 280
tdscdmaSigInfoExt, 538
rsrp
lteSSInfo, 141
nas_cellParams, 157
nas_QmisNasSlqsNasPCIInfo, 245
nas_rxInfo, 259
nas_RxSigInfo, 260
nas_umtsLTENbrCell, 282
rsrpRx0
nas_QmisNasSlqsNasPCIInfo, 245
rsrpRx1
nas_QmisNasSlqsNasPCIInfo, 245
rsrplevel
nas_lteRsrpinformation, 209
rsrq
lteSSInfo, 142
nas_cellParams, 157
nas_QmisNasSlqsNasPCIInfo, 246
nas_rsrqInformation, 256
nas_SccRxInfo, 262
nas_umtsLTENbrCell, 282
rsrqDelta
nas_SLQSSignalStrengthsIndReq, 267
rsrqInfo
nas_SLQSSignalStrengthsInformation, 268
unpack_nas_SLQSGetSignalStrength_t, 726
rsrqRx0
nas_QmisNasSlqsNasPCIInfo, 246
rsrqRx1
nas_QmisNasSlqsNasPCIInfo, 246
rssi
cdmaSSInfo, 49
hdrSSInfo, 70
lteSSInfo, 142
nas_cellParams, 157

nas_gsmCellInfo, 179
tdscdmaSigInfoExt, 538
unpack_nas_GetSignalStrengths_t, 705
rx_bytes
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
rx_pkts
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
RxByteOKCnt
wds_RXBytesOKTlv, 1033
rxChainIndex
nas_RxSigInfo, 260
RxDropConutTlv
unpack_RMTransferStatistics_ind_t, 808
rxLev
nas_GERANInfo, 177
rxOKBytesCount
unpack_wds_SLQSGetDUNCallInfo_t, 942
RxOkByteCountTlv
unpack_RMTransferStatistics_ind_t, 808
RxOkConutTlv
unpack_RMTransferStatistics_ind_t, 808
rxPower
nas_rxInfo, 259
nas_RxSigInfo, 260
RxQFilter
unpack_qos_QosFlowInfo_t, 788
RxQFlowGranted
unpack_qos_QosFlowInfo_t, 789
rxSignalStrength
nas_rxSignalStrengthListElement, 261
rxSignalStrengthDelta
nas_SLQSSignalStrengthsIndReq, 267
rxSignalStrengthInfo
nas_SLQSSignalStrengthsInformation, 268
rxSignalStrengthList
unpack_nas_SLQSGetSignalStrength_t, 726
rxSignalStrengthListLen
unpack_nas_SLQSGetSignalStrength_t, 726

SCI
unpack_nas_GetCDMANetworkParameters_t, 695
SCM
unpack_nas_GetCDMANetworkParameters_t, 695
SCTlv
unpack_ims_SLQSSIPCfgCallBack_ind_t, 651
SDPTlv
NASQmiCbkNasSystemSelPrefInd, 305
SDTlv
unpack_ims_SLQSVoIPCfgCallBack_ind_t, 655
SDU_HDR_LEN
common.h, 1053
SFTlv
unpack_ims_SLQSSMSCfgCallBack_ind_t, 652
SHORT
SwiDataTypes.h, 1359
SI
voice_calledPartyInfo, 982
voice_callFWExtInfo, 987
voice_callingPartyInfo, 991
voice_redirNumInfo, 1011
SINTlv
unpack_ims_SLQSSMSCfgCallBack_ind_t, 652
SIODataPort
qos_BindDataPortSIODataPort_t, 509
SIPLocalPort
ims_SIPPortInfo, 80
sIntraSearch
nas_LTEInfoIntrafreq, 201
SLQSSSTlv
unpack_nas_SetEventReportInd_t, 709
SMS_CONFIG_LEN
sms.h, 1315
SMS_MAX_SMS_ROUTES
sms.h, 1316
SMS_NUM_OF_SET
sms.h, 1316
SMSC_TYPE_LEN
sms.h, 1316
sMSCAddressInfo, 528
data, 528
length, 528
sMSCAddressTlv, 528
SMSCInfo, 528
TlvPresent, 529
SMSCInfo
sMSCAddressTlv, 528
SMSCTlv
unpack_sms_SetNewSMSCallback_ind_t, 813
sMSEtwsMessageInfo, 529
data, 529
length, 529
notificationType, 529
sMSEtwsMessageTlv, 529
EtwsMessageInfo, 530
TlvPresent, 530
sMSEtwsPlmnInfo, 530
mobileCountryCode, 530
mobileNetworkCode, 530
sMSMTMessageInfo, 531
messageIndex, 531
storageType, 531
sMSMessageModeInfo, 530
messageMode, 531
sMSOnIMSInfo, 531
smsOnIMS, 531
sMSOnIMSTlv, 532
IMSInfo, 532
TlvPresent, 532
SMSSupport
pack_dms_SetCustFeature_t, 321
unpack_dms_GetCustFeature_t, 577
sMSTransferRouteMTMessageInfo, 532
ackIndicator, 533
data, 533
format, 533

length, 533
transactionID, 533
SNR
nas_NetworkStatEVDO, 225
sNonIntraSearch
nas_LTEInfoIntrafreq, 201
SO
nas_NetworkStat1x, 223
SOMask
currNetworkInfo, 52
wds_currNetworkInfo, 1020
SPC_SIZE
dms.h, 1065
SPTlv
unpack_ims_SLQSSIPCfgCallBack_ind_t, 651
sPhyCaAggPcellInfo
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 710
sPhyCaAggScellDlBw
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 710
sPhyCaAggScellIndType
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 710
sPhyCaAggScellIndex
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 710
sPhyCaAggScellInfo
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 710
SRTlv
unpack_ims_SLQSSIPCfgCallBack_ind_t, 651
SSInfo
unpack_nas_SetServingSystemCallback_ind_t, 712
sSLQSSignalStrengthsInfo
nas_SLQSSignalStrengthsTlv, 269
SSTlv
unpack_nas_SetEventReportInd_t, 709
STTlv
unpack_ims_SLQSSIPCfgCallBack_ind_t, 651
SUPSInformation
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 908
SUPSType
pack_voice_SLQSVoiceManageCalls_t, 468
SWI_API
SwiDataTypes.h, 1359
SWIWWANCMAPI.h, 1383
samplesPerBatch
loc_accelAcceptReady, 123
loc_accelTempAcceptReady, 124
loc_gyroAcceptReady, 130
loc_gyroTempAcceptReady, 131
sar.h, 1310
pack_sar_SLQSGetRfSarState, 1310
pack_sar_SLQSSetRfSarState, 1310
unpack_sar_SLQSGetRfSarState, 1311
unpack_sar_SLQSSetRfSarState, 1311
unpack_sar_SLQSSetRfSarState_t, 1310
sbas_almanac_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
sbas_ephemeris_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
sbas_health_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
sbas_visible_sv_msk
unpack_pds_SLQSGetGPSStateInfo_t, 783
scell_idx
nas_PhyCaAggScellIndex, 230
NASPhyCaAggScellIndex, 299
scell_state
nas_PhyCaAggScellIndType, 231
nas_PhyCaAggScellInfo, 234
NASPhyCaAggScellIndType, 300
NASPhyCaAggScellInfo, 301
scrAmrEnable
ims_EnabSCRAMRInfo, 75
scrAmrWBEnable
ims_EnabSCRAMRWBInfo, 75
screeningInd
voice_connectNumInfo, 997
sduErrorRatio
LibPackUMTSQoS, 122
wds_UMTSMinQoS, 1038
seDNSIPv4Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 959
seDNSIPv6Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 959
sePCSCFIPv4Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 959
sePCSCFIPv6Address
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 959
secActivate
uim_fileAttributes, 553
secActivateMask
uim_fileAttributes, 553
secChA
nas_CDMAChannel, 150
secChB
nas_CDMAChannel, 150
secDeactivate
uim_fileAttributes, 553
secDeactivateMask
uim_fileAttributes, 553
secIncrease
uim_fileAttributes, 553
secIncreaseMask
uim_fileAttributes, 553
SecProt
nas_protocolSubtypeElement, 240
secRead

uim_fileAttributes, 553
secReadMask
uim_fileAttributes, 553
secWrite
uim_fileAttributes, 553
secWriteMask
uim_fileAttributes, 553
secdns
unpack_wds_GetDefaultProfile_t, 921
secdnsv6
unpack_wds_GetDefaultProfile_t, 921
second
nas_timeInfo, 277
nas_UniversalTime, 283
secondaryDNS
pack_wds_SetDefaultProfile_t, 482
SecondaryDNSV4
unpack_wds_SLQSGetRuntimeSettings_t, 945
SecondaryDNSV6
unpack_wds_SLQSGetRuntimeSettings_t, 945
secondaryHA
unpack_wds_GetMobileIPProfile_t, 925
SectorIDLen
nas_NetworkStatEVDO, 225
selNetwork
nas_servSystem, 264
selected
sms_BroadcastConfig, 515
sms_CDMABroadcastConfig, 516
selectedNetwork
NASServingSystemInfo, 307
selection
pack_swiavms_SLQSAVMSSendSelection_t, 429
pack_swioma_SLQSOMADMSendSelection_t, 439
pack_swioma_SLQSOMADMSendSelectionExt_t, 440
sendStatus
unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t, 827
sensorData_t, 510
flags, 511
sensorDataLen, 511
timeOfFirstSample, 511
timeOffset, 511
xAxis, 511
yAxis, 511
zAxis, 511
sensorDataLen
sensorData_t, 511
ServerAddrList
unpack_wds_SLQSGetRuntimeSettings_t, 945
serverAddrTypeMask
pack_loc_SLQSLOCGetServer_t, 349
serverStatus
unpack_loc_GetServer_Ind_t, 675
unpack_loc_SetServer_Ind_t, 690
serverType
pack_loc_SLQSLOCGetServer_t, 349
pack_loc_SLQSLOCSetServer_t, 358
unpack_loc_GetServer_Ind_t, 675
serviceCategory
sms_CDMABroadcastConfig, 516
serviceDomain
nas_RejectReasonTlv, 247
unpack_nas_SLQSNasNetworkRejectCallback_Ind_t, 750
ServiceStatusConfig
pack_imsa_SLQSRegisterIMSAIndication_t, 344
servingCellId
nas_LTEInfoIntrafreq, 201
ServingSystem
unpack_nas_SLQSGetServingSystem_t, 723
sessExp
ims_SessDurInfo, 79
sessionControl
pack_pds_StartPDSTrackingSessionExt_t, 409
sessionEndReason
unpack_wds_SLQSSetPacketSrvStatusCallback_t, 949
SessionId
pack_loc_Start_t, 360
pack_loc_Stop_t, 360
sessionId
unpack_loc_PositionRpt_Ind_t, 686
sessionInfo
pack_uim_ChangePin_t, 445
pack_uim_ReadTransparent_t, 446
pack_uim_SetPinProtection_t, 447
pack_uim_SLQSUIMAuthenticate_t, 448
pack_uim_SLQSUIMGetFileAttributes_t, 450
pack_uim_SLQSUIMRefreshComplete_t, 452
pack_uim_SLQSUIMRefreshGetLastEvent_t, 452
pack_uim_SLQSUIMRefreshOK_t, 453
pack_uim_SLQSUIMRefreshRegister_t, 453
pack_uim_UnblockPin_t, 455
pack_uim_VerifyPin_t, 456
SessionInfoConfig
unpack_swioma_SLQSOMADMAlertCallback_ind_t, 848
SessionInfoFota
unpack_swioma_SLQSOMADMAlertCallback_ind_t, 848
SessionInfoNotification
unpack_swioma_SLQSOMADMAlertCallback_ind_t, 848
sessionOperation
pack_pds_StartPDSTrackingSessionExt_t, 409
sessionResponse
unpack_swiavms_SLQSAVMSStartSession_t, 842
sessionServerOption
pack_pds_StartPDSTrackingSessionExt_t, 409
SessionState
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
SessionStatus

unpack_pds_SetEventReport_Ind_t, 777
sessionStatus
unpack_loc_PositionRpt_Ind_t, 686
unpack_omaDmNotificationsTlv_t, 770
SessionType
pack_swioma_SLQSOMADMGetSessionInfo_t, 439
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
sessionType
pack_pds_StartPDSTrackingSessionExt_t, 409
pack_swiavms_SLQSAVMSStartSession_t, 433
pack_swiavms_SLQSAVMSStopSession_t, 434
pack_swioma_SLQSOMADMCancelSession_t, 438
pack_swioma_SLQSOMADMCancelSessionExt_t, 438
pack_swioma_SLQSOMADMStartSession_t, 442
pack_swioma_SLQSOMADMStartSessionExt_t, 443
uim_refreshevent, 558
uim_sessionInformation, 560
uim_UIMSessionInformation, 564
unpack_omaDmFotaTlv_t, 768
set_fix_rate
pack_swiloc_SwiLocSetAutoStart_t, 437
set_fix_type
pack_swiloc_SwiLocSetAutoStart_t, 437
set_function
pack_swiloc_SwiLocSetAutoStart_t, 437
set_max_dist
pack_swiloc_SwiLocSetAutoStart_t, 437
set_max_time
pack_swiloc_SwiLocSetAutoStart_t, 437
SetupEventList
cat_EventListTlv, 48
Severity
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
severity
unpack_omaDmFotaTlv_t, 768
shortName
nas_PLMNNetworkNameData, 238
unpack_nas_SLQSGetPLMNName_t, 718
shortNameCI
unpack_nas_SLQSGetPLMNName_t, 718
shortNameEn
unpack_nas_SLQSGetPLMNName_t, 718
shortNameLen
nas_PLMNNetworkNameData, 238
unpack_nas_SLQSGetPLMNName_t, 718
shortNameSB
unpack_nas_SLQSGetPLMNName_t, 718
shortNameSpareBits
nas_PLMNNetworkNameData, 238
sid
nas_CDMAInfo, 152
nas_sidNid, 264
unpack_nas_GetHomeNetwork_t, 699
SidNid
nas_homeSIDNID, 190
SigCompEn
ims_SigCompEnInfo, 80
SigInd
LibPackUMTSReqQoSSigInd, 122
sigInfo
nas_SccRxInfo, 262
signal
voice_signalInfo, 1014
signalStrength
nas_SignalStrengthTlv, 265
signalStrengthReqMask
unpack_nas_SLQSGetSignalStrength_t, 726
signalType
voice_signalInfo, 1014
SimCapability
unpack_dms_GetDeviceCap_t, 579
simCapability
unpack_dms_GetDeviceCapabilities_t, 581
sinr
hdrSSInfo, 70
nas_SLQSSignalStrengthsInformation, 268
tdscdmaSigInfoExt, 538
unpack_nas_SLQSGetSignalStrength_t, 726
sinrDelta
nas_SLQSSignalStrengthsIndReq, 267
sinrThresholdList
nas_SLQSSignalStrengthsIndReq, 267
sinrThresholdListLen
nas_SLQSSignalStrengthsIndReq, 267
sku_str
unpack_dms_GetFirmwareInfo_t, 586
slot
pack_uim_SLQSUIMPowerDown_t, 451
pack_uim_SLQSUIMPowerUp_t, 451
slot_t, 512
bICCID, 512
bICCIDLength, 512
bLogicalSlot, 512
uPhyCardStatus, 512
uPhySlotStatus, 512
slotInf, 513
AppStatus, 514
cardState, 514
errorState, 514
numApp, 514
upinRetries, 514
upinState, 514
upukRetries, 514
SlotInfo
uim_cardStatus, 547
slots_t, 514
uimSlotStatus, 515
slotsstatusChange
unpack_uim_SetUimSlotStatusChangeCallback_ind_t, 861

SlqsProfile3GPP
unpackWdsProfileParam, 969
wds_profileInfo, 1033
SlqsProfile3GPP2
unpackWdsProfileParam, 969
wds_profileInfo, 1033
sms.h
LITEQMI_QMI_CBK_PARAM_NOCHANGE, 1316
LITEQMI_QMI_CBK_PARAM_RESET, 1316
LITEQMI_QMI_CBK_PARAM_SET, 1316
sms.h, 1312
eqmiCbkSetStatus, 1316
MAX_MSE_TWS_MSG, 1315
MAX_SMS_LIST_SIZE, 1315
pack_sms_GetSMSCAddress, 1316
pack_sms_SLQSDeleteSMS, 1318
pack_sms_SLQSGetIndicationRegister, 1318
pack_sms_SLQSGetMessageWaiting, 1318
pack_sms_SLQSGetSMS, 1319
pack_sms_SLQSGetSMSList, 1319
pack_sms_SLQSGetSmsBroadcastConfig, 1319
pack_sms_SLQSGetTransLayerInfo, 1320
pack_sms_SLQSGetTransNWRegInfo, 1320
pack_sms_SLQSModifySMSStatus, 1320
pack_sms_SLQSSendAsyncSMS, 1321
pack_sms_SLQSSetIndicationRegister, 1321
pack_sms_SLQSSetSmsBroadcastActivation, 1321
pack_sms_SLQSSetSmsBroadcastConfig, 1322
pack_sms_SLQSSetSmsStorage, 1322
pack_sms_SLQSSmsGetMaxStorageSize, 1323
pack_sms_SLQSSmsGetMessageProtocol, 1323
pack_sms_SLQSSmsSetRoutes, 1323
pack_sms_SLQSSwiGetSMSStorage, 1324
pack_sms_SaveSMS, 1316
pack_sms_SendSMS, 1317
pack_sms_SetNewSMSCallback, 1317
pack_sms_SetSMSCAddress, 1317
SMS_CONFIG_LEN, 1315
SMS_MAX_SMS_ROUTES, 1316
SMS_NUM_OF_SET, 1316
SMSC_TYPE_LEN, 1316
unpack_sms_GetSMSCAddress, 1324
unpack_sms_SLQSDeleteSMS, 1326
unpack_sms_SLQSGetIndicationRegister, 1326
unpack_sms_SLQSGetMessageWaiting, 1327
unpack_sms_SLQSGetSMS, 1327
unpack_sms_SLQSGetSMSList, 1328
unpack_sms_SLQSGetSmsBroadcastConfig, 1327
unpack_sms_SLQSGetTransLayerInfo, 1328
unpack_sms_SLQSGetTransNWRegInfo, 1329
unpack_sms_SLQSModifySMSStatus, 1329
unpack_sms_SLQSNWRegInfoCallback_ind, 1329
unpack_sms_SLQSSendAsyncSMS, 1330
unpack_sms_SLQSSetIndicationRegister, 1330
unpack_sms_SLQSSetSmsBroadcastActivation, 1330
unpack_sms_SLQSSetSmsBroadcastConfig, 1331
unpack_sms_SLQSSetSmsStorage, 1331
unpack_sms_SLQSSmsGetMaxStorageSize, 1331
unpack_sms_SLQSSmsGetMessageProtocol, 1332
unpack_sms_SLQSSmsSetRoutes, 1332
unpack_sms_SLQSSwiGetSMSStorage, 1332
unpack_sms_SLQSTransLayerInfoCallback_ind, 1333
unpack_sms_SLQSWmsAsyncRawSendCallBack-_ind, 1333
unpack_sms_SLQSWmsMemoryFullCallBack_ind, 1334
unpack_sms_SLQSWmsMessageWaitingCall-Back_ind, 1334
unpack_sms_SaveSMS, 1324
unpack_sms_SendSMS, 1325
unpack_sms_SetNewSMSCallback, 1325
unpack_sms_SetNewSMSCallback_ind, 1325
unpack_sms_SetSMSCAddress, 1326
sms_BroadcastConfig, 515
fromServiceId, 515
selected, 515
toServiceId, 515
sms_CDMABroadcastConfig, 515
language, 516
selected, 516
serviceCategory, 516
sms_getIndicationReg, 516
pRegCallStatInfoEvt, 517
pRegTransLayerInfoEvt, 517
pRegTransNWRegInfoEvt, 517
sms_getMsgWaitingInfo, 517
msgWaitInfo, 517
numInstances, 517
sms_getTransLayerInfo, 517
pRegInd, 518
pTransLayerInfo, 518
sms_getTransNWRegInfo, 518
pRegStatus, 518
sms_maxStorageSizeReq, 519
pMessageMode, 519
storageType, 519
sms_maxStorageSizeResp, 519
freeSlots, 520
maxStorageSize, 520
sms_messageWaitingInfoContent, 520
activeInd, 520
msgCount, 520
msgType, 520
sms_msgProtocolResp, 521
msgProtocol, 521
sms_qaQmi3GPP2BroadcastCfgInfo, 521
activated_ind, 522
CDMABroadcastConfig, 522
num_instances, 522
sms_qaQmi3GPPBroadcastCfgInfo, 522
activated_ind, 522

broadcastConfig, 522
num_instances, 522
sms_routeEntry, 522
messageClass, 523
messageType, 523
receiptAction, 523
routeStorage, 523
sms_sendAsyncsmsParams, 523
messageFormat, 525
messageSize, 525
pFollowOnDC, 525
pForceOnDC, 525
pLinktimer, 525
pMessage, 525
pRetryMessage, 525
pRetryMessageId, 525
pServiceOption, 525
pSmsOnIms, 525
pUserData, 525
sms_setIndicationReg, 526
pRegCallStatInfoEvt, 526
pRegTransLayerInfoEvt, 526
pRegTransNWRegInfoEvt, 526
sms_setRoutesReq, 526
numOfRoutes, 527
pTransferStatusReport, 527
routeList, 527
sms_transLayerInfo, 527
TransCap, 527
TransType, 528
smsFormat
ims_SMSFmtInfo, 81
smsOnIMS
sMSOnIMSInfo, 531
SmsRat
unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t, 662
SmsRatVal
imsa_SmsRatInfo, 87
SmsService
unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t, 662
SmsServiceRat
unpack_imsa_SLQSGetIMSAServiceStatus_t, 658
SmsServiceStatus
unpack_imsa_SLQSGetIMSAServiceStatus_t, 658
smsStorage
pack_sms_SLQSSetSmsStorage_t, 421
SmsSvcStatus
imsa_SmsSvcStatusInfo, 88
smsoIPNW
ims_SMSoIPNwInfo, 82
snr
loc_satelliteInfo, 137
lteSSInfo, 142
nas_SccRxInfo, 262
snrlevel
nas_lteSnrinformation, 213
soMask
qmiWDSDataBearerTechnology, 507
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
Source
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
source
altSrcInfo_t, 35
unpack_dms_GetNetworkTime_t, 592
unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t, 610
unpack_dms_SLQSDmsSwiGetResetInfo_t, 611
sourceIPMask
LibPackTFTIDParams, 119
SourceLength
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
SourceRAT
imsa_RatHandoverStatusInfo, 87
spc
pack_dms_ResetToFactoryDefaults_t, 318
pack_nas_SetACCOLC_t, 361
pack_wds_SetMobileIPProfile_t, 486
spn
nas_serviceProviderName, 262
unpack_nas_SLQSGetPLMNName_t, 718
spnEncoding
unpack_nas_SLQSGetPLMNName_t, 718
spnLength
nas_serviceProviderName, 262
unpack_nas_SLQSGetPLMNName_t, 719
srcPortRangeEnd
LibPackTFTIDParams, 119
srcPortRangeStart
LibPackTFTIDParams, 119
srvCapability
nas_detailSvcInfo, 167
nas_sysInfoCommon, 272
srvCapabilityValid
nas_sysInfoCommon, 272
srvDomain
nas_sysInfoCommon, 272
SrvDomainPref
nas_SrvDomainPrefTlv, 269
NASServDomainPrefTlv, 306
srvDomainValid
nas_sysInfoCommon, 272
srvOption
voice_arrSvcOption, 979
srvStatus
nas_detailSvcInfo, 167
nas_GSMSrvStatusInfo, 181
nas_SrvStatusInfo, 270
srxlev
nas_cellParams, 157
nas_gsmCellInfo, 179
nas_umtsLTENbrCell, 282

nas_wcdmaCellInfo, 284
stage
uim_refreshevent, 558
State
nas_NetworkStat1x, 223
nas_NetworkStatEVDO, 225
state
pack_loc_SLQSLOCSetCradleMountConfig_t, 357
unpack_dms_GetActivationState_t, 572
unpack_dms_SLQSUIMGetState_t, 630
unpack_omaDmConfigTlv_t, 767
unpack_omaDmFotaTlv_t, 769
unpack_qos_QosFlowInfoState_t, 789
statmask
pack_wds_GetPacketStatus_t, 479
StatsMask
wds_transferStatInd, 1034
statsMask
wds_TrStatInd, 1035
StatsPeriod
wds_transferStatInd, 1034
statsPeriod
wds_TrStatInd, 1035
Status
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
status
nas_lteEARFCN, 195
nas_ltePCI, 208
nas_wcdmaUARFCN, 290
pack_sms_SetNewSMSCallback_t, 415
unpack_loc_BestAvailPos_Ind_t, 669
unpack_loc_DeleteAssistData_Ind_t, 671
unpack_loc_InjectPositionCallback_Ind_t, 676
unpack_loc_InjectUTCTimeCallback_Ind_t, 679
unpack_loc_SetExtPowerConfig_Ind_t, 688
unpack_loc_SetOperationMode_Ind_t, 689
unpack_qos_SLQSSetQosNWStatusCallback_ind_t, 794
unpack_qos_SLQSSetQosStatusCallback_ind_t, 796
storageIndex
FMSImageIdElement, 67
storageType
pack_sms_SaveSMS_t, 414
pack_sms_SLQSDeleteSMS_t, 416
pack_sms_SLQSGetSMS_t, 417
pack_sms_SLQSGetSMSList_t, 418
pack_sms_SLQSModifySMSStatus_t, 419
sms_maxStorageSizeReq, 519
sMSMTMessageInfo, 531
unpack_sms_SLQSWmsMemoryFullCallBack_ind_t, 828
Streaming Download Protocol (lite-fw), 30
String
unpack_dms_GetDeviceHardwareRev_t, 581
unpack_dms_GetDeviceMfr_t, 582
unpack_dms_GetFSN_t, 589
unpack_dms_UIMGetICCID_t, 633
stringSize
unpack_dms_GetDeviceHardwareRev_t, 581
unpack_dms_GetDeviceMfr_t, 582
unpack_dms_UIMGetICCID_t, 633
subAddr
voice_calledPartySubAdd, 983
subAddrLen
voice_calledPartySubAdd, 983
subAddrType
voice_calledPartySubAdd, 983
subnetMask
unpack_qos_IPv4Addr_t, 785
SubnetMaskV4
unpack_wds_SLQSGetRuntimeSettings_t, 945
subsType
pack_voice_SLQSVoiceBindSubscription_t, 459
subscrTmr
ims_SubscrTmrInfo, 82
SupUSBComps
unpack_dms_GetUSBComp_t, 598
SuppOA
voice_CUGInfo, 997
SuppPrefCUG
voice_CUGInfo, 997
svInfoMask
loc_satelliteInfo, 137
svListLen
loc_satelliteInfo, 137
svStatus
loc_satelliteInfo, 137
svc
pack_qmi_t, 410
SvcClass
voice_callFWExtInfo, 987
voice_callFWInfo, 988
SvcStatus
voice_callFWExtInfo, 987
voice_callFWInfo, 988
svcType
voice_ccSUPSType, 992
voice_SUPSInfo, 1015
sw1
uim_cardResult, 546
sw2
uim_cardResult, 546
swVerString
pack_dms_SLQSSwiSetHostDevInfo_t, 328
unpack_dms_SLQSSwiGetHostDevInfo_t, 626
swi_uint256_clear_bit
switype_256bit.h, 1382
swi_uint256_get_bit
switype_256bit.h, 1382
swi_uint256_print_mask
switype_256bit.h, 1382
swi_uint256_set_bit
switype_256bit.h, 1383
swi_uint256_t, 533

word, 533
SwiDataTypes.h, 1358
BOOL, 1359
BYTE, 1359
CHAR, 1359
FLOAT, 1359
INT32, 1359
INT8, 1359
LPCSTR, 1359
qmuint16, 1359
qmulong, 1359
SHORT, 1359
SWI_API, 1359
ULONG, 1359
ULONGLONG, 1359
UNUSEDPARAM, 1359
USHORT, 1359
WORD, 1359
swiaudio.h, 1334
pack_swiaudio_SLQSGetM2MAVMute, 1337
pack_swiaudio_SLQSGetM2MAudioProfile, 1336
pack_swiaudio_SLQSGetM2MAudioVolume, 1336
pack_swiaudio_SLQSGetM2MSpkrGain, 1337
pack_swiaudio_SLQSSetM2MAVMute, 1339
pack_swiaudio_SLQSSetM2MAudioAVCFG, 1338
pack_swiaudio_SLQSSetM2MAudioLPBK, 1338
pack_swiaudio_SLQSSetM2MAudioNVDef, 1338
pack_swiaudio_SLQSSetM2MAudioProfile, 1339
pack_swiaudio_SLQSSetM2MAudioVolume, 1339
pack_swiaudio_SLQSSetM2MSpkrGain, 1340
unpack_swiaudio_SLQSGetM2MAVMute, 1341
unpack_swiaudio_SLQSGetM2MAudioProfile, 1340
unpack_swiaudio_SLQSGetM2MAudioVolume, 1341
unpack_swiaudio_SLQSGetM2MSpkrGain, 1341
unpack_swiaudio_SLQSSetM2MAVMute, 1343
unpack_swiaudio_SLQSSetM2MAVMute_t, 1336
unpack_swiaudio_SLQSSetM2MAudioAVCFG, 1342
unpack_swiaudio_SLQSSetM2MAudioAVCFG_t, 1336
unpack_swiaudio_SLQSSetM2MAudioLPBK, 1342
unpack_swiaudio_SLQSSetM2MAudioLPBK_t, 1336
unpack_swiaudio_SLQSSetM2MAudioNVDef, 1342
unpack_swiaudio_SLQSSetM2MAudioNVDef_t, 1336
unpack_swiaudio_SLQSSetM2MAudioProfile, 1343
unpack_swiaudio_SLQSSetM2MAudioProfile_t, 1336
unpack_swiaudio_SLQSSetM2MAudioVolume, 1343
unpack_swiaudio_SLQSSetM2MAudioVolume_t, 1336
unpack_swiaudio_SLQSSetM2MSpkrGain, 1344
unpack_swiaudio_SLQSSetM2MSpkrGain_t, 1336
swiaudio_PCMparams, 533
iFaceTab, 534
iFaceTabLen, 534
swiavms.h, 1344
pack_swiavms_SLQSAVMSGetSettings, 1346
pack_swiavms_SLQSAVMSGetSettings_v2, 1347
pack_swiavms_SLQSAVMSSendSelection, 1347
pack_swiavms_SLQSAVMSSessionGetInfo, 1348
pack_swiavms_SLQSAVMSSetSettings, 1349
pack_swiavms_SLQSAVMSSetSettings_v2, 1350
pack_swiavms_SLQSAVMSSetSettingsNoAuto-RebootField, 1350
pack_swiavms_SLQSAVMSStartSession, 1351
pack_swiavms_SLQSAVMSStopSession, 1352
pack_swiavms_SLQSAvmsSetEventReport, 1349
unpack_swiavms_SLQSAVMSEventReportInd, 1352
unpack_swiavms_SLQSAVMSGetSettings, 1353
unpack_swiavms_SLQSAVMSGetSettings_v2, 1353
unpack_swiavms_SLQSAVMSSendSelection, 1354
unpack_swiavms_SLQSAVMSSessionGetInfo, 1354
unpack_swiavms_SLQSAVMSSetSettings, 1355
unpack_swiavms_SLQSAVMSSetSettings_v2, 1356
unpack_swiavms_SLQSAVMSStartSession, 1356
unpack_swiavms_SLQSAVMSStopSession, 1357
unpack_swiavms_SLQSAVMSStopSession_avc2, 1357
unpack_swiavms_SLQSAvmsSetEventReport, 1355
swidms.h, 1359
pack_swidms_SLQSSwiDmsGetMTU, 1360
pack_swidms_SLQSSwiDmsGetUsbComp, 1361
pack_swidms_SLQSSwiDmsGetUsbNetNum, 1361
pack_swidms_SLQSSwiDmsSetMTU, 1361
pack_swidms_SLQSSwiDmsSetUsbComp, 1362
pack_swidms_SLQSSwiDmsSetUsbNetNum, 1362
unpack_swidms_SLQSSwiDmsGetMTU, 1362
unpack_swidms_SLQSSwiDmsGetUsbComp, 1363
unpack_swidms_SLQSSwiDmsGetUsbNetNum, 1363
unpack_swidms_SLQSSwiDmsSetMTU, 1363
unpack_swidms_SLQSSwiDmsSetUsbComp, 1364
unpack_swidms_SLQSSwiDmsSetUsbNetNum, 1364
unpack_swidms_SLQSSwiDmsSetUsbNetNum_t, 1360
swidms_ehrpdMTUSizeTlv, 534
ehrpdMTUSize, 534
TlvPresent, 534

swidms_hrpdMTUSizeTlv, 534
hrpdMTUSize, 535
TlvPresent, 535
swidms_intfaceCfgTlv, 535
CfgValue, 536
CurrentCfgType, 536
TlvPresent, 536
swidms_mtuSize3gppTlv, 536
MTUSize3gpp, 537
TlvPresent, 537
swidms_supportedIntBitmaskTlv, 537
TlvPresent, 537
ValidBitmasks, 537
swidms_usbMTUSizeTlv, 537
TlvPresent, 538
UsbMTUSize, 538
swiloc.h, 1365
pack_swiloc_SwiLocGetAutoStart, 1365
pack_swiloc_SwiLocSetAutoStart, 1365
unpack_swiloc_SwiLocGetAutoStart, 1366
unpack_swiloc_SwiLocSetAutoStart, 1366
unpack_swiloc_SwiLocSetAutoStart_t, 1365
swioma.h, 1366
pack_swioma_SLQSOMADMAlertCallback, 1368
pack_swioma_SLQSOMADMCancelSession, 1368
pack_swioma_SLQSOMADMGetSessionInfo, 1369
pack_swioma_SLQSOMADMGetSettings, 1370
pack_swioma_SLQSOMADMSendSelection, 1370
pack_swioma_SLQSOMADMSetSettings, 1371
pack_swioma_SLQSOMADMStartSession, 1372
unpack_swioma_SLQSOMADMAlertCallback, 1372
unpack_swioma_SLQSOMADMAlertCallback_ind, 1373
unpack_swioma_SLQSOMADMAlertCallback_t, 1368
unpack_swioma_SLQSOMADMCancelSession, 1373
unpack_swioma_SLQSOMADMCancelSession_t, 1368
unpack_swioma_SLQSOMADMGetSessionInfo, 1374
unpack_swioma_SLQSOMADMGetSettings, 1374
unpack_swioma_SLQSOMADMSendSelection, 1375
unpack_swioma_SLQSOMADMSendSelection_t, 1368
unpack_swioma_SLQSOMADMSetSettings, 1375
unpack_swioma_SLQSOMADMSetSettings_t, 1368
unpack_swioma_SLQSOMADMStartSession, 1375
swiomaext.h, 1376
pack_swioma_SLQSOMADMCancelSessionExt, 1377
pack_swioma_SLQSOMADMSendSelectionExt, 1378
pack_swioma_SLQSOMADMSetSettingsExt, 1378
pack_swioma_SLQSOMADMStartSessionExt, 1379
unpack_swioma_SLQSOMADMCancelSessionExt, 1379
unpack_swioma_SLQSOMADMCancelSessionExt_t, 1377
unpack_swioma_SLQSOMADMSendSelectionExt, 1380
unpack_swioma_SLQSOMADMSendSelectionExt_t, 1377
unpack_swioma_SLQSOMADMSetSettingsExt, 1380
unpack_swioma_SLQSOMADMSetSettingsExt_t, 1377
unpack_swioma_SLQSOMADMStartSessionExt, 1381
unpack_swioma_SLQSOMADMStartSessionExt_t, 1377
switchOption
pack_voice_SLQSVoiceALSSetLineSwitching_t, 458
switype_256bit.h, 1381
swi_uint256_clear_bit, 1382
swi_uint256_get_bit, 1382
swi_uint256_print_mask, 1382
swi_uint256_set_bit, 1383
sysInfoCDMA
nas_CDMASysInfo, 156
sysInfoGSM
nas_GSMSysInfo, 184
sysInfoHDR
nas_HDRSysInfo, 190
sysInfoLTE
nas_LTESysInfo, 216
sysInfoWCDMA
nas_WCDMASysInfo, 289
system
loc_satelliteInfo, 137
loc_SV, 139
systemDiscontinuities
pack_pds_PDSInjectTimeReference_t, 399
SystemID
unpack_nas_SLQSGetServingSystem_t, 723
systemID
nas_CDMASysInfo, 156
systemMode
nas_CommInfo, 161
systemTime
pack_pds_PDSInjectTimeReference_t, 399
szAPN
PackSwiAvmsSetSettingsAPNInfo, 503
szAlertMsg
UnpackSwiAvmsEventReportConfig, 962
szCarrier_str
_litefw_FirmwareInfo_, 33
szCarrierPriversion_str
_litefw_FirmwareInfo_, 34

szDescription
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 961
szFwversion_str
_litefw_FirmwareInfo_, 34
szModelid_str
_litefw_FirmwareInfo_, 34
szName
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 961
szPWD
PackSwiAvmsSetSettingsAPNInfo, 503
szPackageid_str
_litefw_FirmwareInfo_, 34
szSku_str
_litefw_FirmwareInfo_, 34
szUname
PackSwiAvmsSetSettingsAPNInfo, 503
szVersion
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 961

t3396_apn
unpack_nas_SLQSNasTimerCallback_ind_t, 755
t3396_plmn_id
unpack_nas_SLQSNasTimerCallback_ind_t, 755
t3396_val
unpack_nas_SLQSNasTimerCallback_ind_t, 755
TCPDstPort
unpack_qos_swiQosFilter_t, 800
TCPSrcPort
unpack_qos_swiQosFilter_t, 800
TDSCDMAECIOThreshListLen
nas_TDSCDMAECIOThresh, 273
TDSCDMARSCPThreshListLen
nas_TDSCDMARSCPThresh, 273
TDSCDMARSSIThreshListLen
nas_TDSCDMARSSIThresh, 274
TDSCDMASINRThreshListLen
nas_TDSCDMASINRThresh, 275
TMD_MAX_DEV_LIST
tmd.h, 1384
TMTlv
unpack_ims_SLQSRegMgrCfgCallBack_ind_t, 647
TPCause
unpack_sms_SLQSWmsAsyncRawSendCallBack-_ind_t, 827
TRMessageTlv
unpack_sms_SetNewSMSCallback_ind_t, 813
TT1Tlv
unpack_ims_SLQSSIPCfgCallBack_ind_t, 651
TT2Tlv
unpack_ims_SLQSSIPCfgCallBack_ind_t, 651
TTfTlv
unpack_ims_SLQSSIPCfgCallBack_ind_t, 651
TX_PWR
nas_NetworkStat1x, 223
TXBOTlv
unpack_wds_SLQSDUNCallInfoCallBack_ind_t, 934
TXChan
nas_LTEInfo, 198
tXDroppedCount
unpack_wds_GetPacketStatus_t, 929
tXOKBytesLastCall
unpack_wds_GetPacketStatus_t, 929
tXOkBytesCount
unpack_wds_GetPacketStatus_t, 929
tXPacketErrors
unpack_wds_GetPacketStatus_t, 929
tXPacketOverflows
unpack_wds_GetPacketStatus_t, 929
tXPacketSuccesses
unpack_wds_GetPacketStatus_t, 929
Tables, 31
tac
nas_LTEInfoIntrafreq, 201
nas_LTESysInfo, 216
tacValid
nas_LTESysInfo, 216
TargetRAT
imsa_RatHandoverStatusInfo, 87
TdsBandCapability
unpack_dms_SLQSGetBandCapability_t, 617
tdscdmaSigInfoExt, 538
ecio, 538
rscp, 538
rssi, 538
sinr, 538
techName
unpack_wds_SLQSSetPacketSrvStatusCallback_-t, 949
Technology
nas_DeviceConfigDetail, 168
unpack_wds_SLQSGetRuntimeSettings_t, 945
TechnologyPref
pack_nas_SetNetworkPreference_t, 364
tempData_t, 538
temperature, 539
temperatureDataLen, 539
timeOfFirstSample, 539
timeOffset, 539
timeSource, 539
TempStat
dms_TemperatureTlv, 59
TempTlv
unpack_dms_SwiEventReportCallBack_ind_t, 630
Temperature
dms_TemperatureTlv, 59
temperature
nas_CommInfo, 161
tempData_t, 539
temperatureDataLen
tempData_t, 539
threshGsmHigh
nas_lteGsmCellInfo, 196

threshGsmLow
nas_lteGsmCellInfo, 196
threshServingLow
nas_LTEInfoIntrafreq, 201
threshXHigh
nas_infoInterFreq, 191
threshXLow
nas_infoInterFreq, 192
threshXhigh
nas_lteWcdmaCellInfo, 217
threshXlow
nas_lteWcdmaCellInfo, 217
Time
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
time
NASTimeInfoTlv, 308
Time_uncert_ms
unpack_pds_SLQSGetGPSStateInfo_t, 783
timeBase
pack_pds_SLQSPDSInjectAbsoluteTimeReference_t, 404
TimeLength
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
timeMsec
pack_loc_SLQSLOCInjectUTCTime_t, 356
pack_pds_SLQSPDSInjectAbsoluteTimeReference_t, 404
timeOfFirstSample
sensorData_t, 511
tempData_t, 539
timeOffset
sensorData_t, 511
tempData_t, 539
timeSource
tempData_t, 539
TimeStmp_gps_week
unpack_pds_SLQSGetGPSStateInfo_t, 783
TimeStmp_tow_ms
unpack_pds_SLQSGetGPSStateInfo_t, 783
timeSyncRefCounter
unpack_loc_EventTimeSyncCallback_Ind_t, 673
timeTlv
NASQmiCbkNasSwiOTAMessageInd, 302
timeUncMsec
pack_loc_SLQSLOCInjectUTCTime_t, 356
pack_pds_SLQSPDSInjectAbsoluteTimeReference_t, 405
timeZone
nas_timeInfo, 277
timeout
pack_pds_SetPDSDefaults_t, 401
pack_qmi_t, 410
Timers
PackSwiAvmsSetSettingsConnectionRetryTimers, 503
PackSwiAVMSSettingsConnectionRetryTimers, 505
timestamp
unpack_dms_GetNetworkTime_t, 592
timestampAge
pack_loc_SLQSLOCInjectPosition_t, 354
timestampUtc
pack_loc_SLQSLOCInjectPosition_t, 354
timingAdvance
nas_GERANInfo, 177
TlvPresenceMask
qmTlvResult, 507
TlvPresent
cat_commonEventTlv, 46
dms_ActivationStatusTlv, 52
dms_OperatingModeTlv, 53
dms_PSMActiveTimerIndTlv, 54
dms_PSMActiveTimerTlv, 54
dms_PSMDurationDueToOOSTlv, 55
dms_PSMDurationThresholdTlv, 55
dms_PSMEarlyWakeupTimeTlv, 56
dms_PSMEnableStateIndTlv, 56
dms_PSMEnableStateTlv, 57
dms_PSMPeriodicUpdateTimerIndTlv, 57
dms_PSMPeriodicUpdateTimerTlv, 58
dms_PSMRandomizationWindowTlv, 58
dms_TemperatureTlv, 59
dms_UimAutoSwitchActSlotTlv, 59
dms_UimStatusTlv, 60
dms_VoltageTlv, 61
eTWSPLMNInfoTlv, 65
ims_AMRModeInfo, 72
ims_AMROctAlgnInfo, 72
ims_AMRWBModeInfo, 73
ims_AMRWBOctAlgnInfo, 73
ims_CSCFPortNameInfo, 74
ims_EnabAMRWBInfo, 74
ims_EnabSCRAMRInfo, 75
ims_EnabSCRAMRWBInfo, 75
ims_IMSDomainInfo, 76
ims_IMSTestModeInfo, 76
ims_MinSessExpInfo, 77
ims_PCSCFPortInfo, 77
ims_PhCtxtURIInfo, 78
ims_RngBkTmrInfo, 78
ims_RngTmrInfo, 79
ims_RTPRTCPInactTmrDurInfo, 79
ims_SessDurInfo, 80
ims_SigCompEnInfo, 80
ims_SIPPortInfo, 80
ims_SIPRegnTmrInfo, 81
ims_SMSFmtInfo, 81
ims_SMSoIPNwInfo, 82
ims_SubscrTmrInfo, 82
ims_TmrT1Info, 83
ims_TmrT2Info, 83
ims_TmrTfInfo, 84
imsa_IMSFailErrCodeTlv, 84

imsa_IMSRegStatusErrorCodeInfo, 85
imsa_IMSRegStatusInfo, 85
imsa_NewIMSRegStatusInfo, 86
imsa_RatHandoverStatusInfo, 87
imsa_SmsRatInfo, 88
imsa_SmsSvcStatusInfo, 88
imsa_UtRatInfo, 89
imsa_UtSvcStatusInfo, 89
imsa_VoipRatInfo, 90
imsa_VoipSvcStatusInfo, 90
imsa_VtRatInfo, 91
imsa_VtSvcStatusInfo, 91
loc_IPv4Info, 132
loc_IPv6Info, 133
loc_urlAddr, 140
messageModeTlv, 142
nas_AcqOrderPrefTlv, 144
nas_BandPrefInfoTlv, 146
nas_BandPrefTlv, 148
nas_CiotAcqOrderPrefTlv, 159
nas_CiotLteOpModePrefTlv, 159
nas_CsgId, 162
nas_EdrxCiotLteMode, 171
nas_EdrxCycleLength, 171
nas_EdrxEnableType, 172
nas_EdrxPagingTimeWindow, 172
nas_EdrxRatType, 173
nas_EmerModeTlv, 174
nas_ForbiddenNetworks3GPP, 176
nas_GWAcqOrderPrefTlv, 184
nas_LTEBandPrefTlv, 195
nas_LteM1BandPrefTlv, 205
nas_LteNb1BandPrefTlv, 207
nas_LTEOperationMode, 207
nas_LteOpMode, 208
nas_ModePrefTlv, 219
nas_NetSelPrefTlv, 221
nas_PhyCaAggPcellInfo, 229
nas_PhyCaAggScellDlBw, 230
nas_PhyCaAggScellIndex, 230
nas_PhyCaAggScellIndType, 231
nas_PhyCaAggScellInfo, 234
nas_PlmnID, 236
nas_PRLPrefTlv, 239
nas_RankIndicatorTlv, 246
nas_RatDisabledMaskTlv, 247
nas_RejectReasonTlv, 247
nas_RfBandInfoExtFormat, 249
nas_RfBandwidthInfo, 251
nas_RfDedicatedBandInfo, 252
nas_RFInfoTlv, 254
nas_RoamPrefTlv, 255
nas_SccRxInfo, 262
nas_SignalStrengthTlv, 265
nas_SLQSSignalStrengthsTlv, 269
nas_SrvDomainPrefTlv, 269
nas_timeInfo, 277
NASAcqOrderPrefTlv, 290
NASBandPreferenceTlv, 290
NASCiotAcqOrderPrefTlv, 291
NASCiotLteOpModePrefTlv, 291
NASEmergencyModeTlv, 292
NASGWAcqOrderPrefTlv, 293
NASLTEBandPreferenceTlv, 294
NASLteM1BandPrefTlv, 294
NASLteNasReleaseInfoTlv, 295
NASLteNB1BandPrefTlv, 295
NASModePreferenceTlv, 296
NASNetSelPreferenceTlv, 296
NASNr5gBandPrefTlv, 297
NASOTAMessageTlv, 297
NASPhyCaAggPcellInfo, 298
NASPhyCaAggScellDlBw, 299
NASPhyCaAggScellIndex, 299
NASPhyCaAggScellIndType, 300
NASPhyCaAggScellInfo, 301
NASPRLPreferenceTlv, 302
NASRatDisabledMaskTlv, 305
NASRoamPreferenceTlv, 305
NASServDomainPrefTlv, 306
NASTimeInfoTlv, 308
newMTMessageTlv, 308
sMSCAddressTlv, 529
sMSEtwsMessageTlv, 530
sMSOnIMSTlv, 532
swidms_ehrpdMTUSizeTlv, 534
swidms_hrpdMTUSizeTlv, 535
swidms_intfaceCfgTlv, 536
swidms_mtuSize3gppTlv, 537
swidms_supportedIntBitmaskTlv, 537
swidms_usbMTUSizeTlv, 538
transferRouteMessageTlv, 541
unpack_pds_SetPdsState_Ind_t, 777
unpack_uim_SLQSUIMRefreshCallback_Ind_t, 866
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 961
UnpackSwiAvmsEventReportConfig, 963
UnpackSwiAvmsEventReportConnectionRequest, 963
UnpackSwiAvmsEventReportDataSessionStatus, 964
UnpackSwiAvmsEventReportHTTPStatus, 965
UnpackSwiAvmsEventReportNotification, 967
UnpackSwiAvmsEventReportPackageID, 967
UnpackSwiAvmsEventReportRegStatus, 967
UnpackSwiAvmsEventReportSessionType, 968
UnpackSwiAvmsEventReportWAMSParam-Change, 969
wds_ChannelRateTlv, 1018
wds_ConnStatusTlv, 1019
wds_DataBearTechTlv, 1020
wds_DataULongLongTlv, 1021
wds_DataULongTlv, 1021
wds_DHCPLeaseOptTlv, 1022
wds_DHCPLeaseStateTlv, 1022

wds_DHCPProfileIdTlv, 1024
wds_DormStatTlv, 1028
wds_IPv4AdTlv, 1029
wds_LastMdmCallEndRsnTlv, 1030
wds_RXBytesOKTlv, 1034
wds_TXBytesOKTlv, 1035
tlvPresent
voice_USSDNotificationNetworkInfo, 1016
TlvResultCode
qmTlvResult, 507
Tlvresult
pack_dms_GetCustFeaturesV2_t, 317
pack_dms_SetCustFeaturesV2_t, 322
pack_dms_SetPower_t, 324
pack_dms_SetUSBComp_t, 324
pack_dms_UIMGetICCID_t, 331
pack_fms_GetImagesPreference_t, 335
pack_fms_GetStoredImages_t, 335
pack_fms_SetImagesPreference_t, 336
pack_loc_Delete_Assist_Data_t, 345
pack_loc_EventRegister_t, 347
pack_loc_SetExtPowerState_t, 347
pack_loc_SetOperationMode_t, 348
pack_loc_SLQSLOCGetBestAvailPos_t, 348
pack_loc_Start_t, 360
pack_loc_Stop_t, 360
pack_nas_SetNetworkPreference_t, 364
pack_uim_ChangePin_t, 445
pack_uim_ReadTransparent_t, 446
pack_uim_SetPinProtection_t, 447
pack_uim_UnblockPin_t, 455
pack_uim_VerifyPin_t, 456
unpack_cat_SetCATEventCallback_t, 571
unpack_dms_GetBandCapability_t, 574
unpack_dms_GetCrashAction_t, 575
unpack_dms_GetCustFeature_t, 577
unpack_dms_GetCustFeaturesV2_t, 578
unpack_dms_GetDeviceCap_t, 579
unpack_dms_GetDeviceHardwareRev_t, 581
unpack_dms_GetDeviceMfr_t, 582
unpack_dms_GetDeviceSerialNumbers_t, 584
unpack_dms_GetFirmwareInfo_t, 586
unpack_dms_GetFirmwareRevision_t, 587
unpack_dms_GetFirmwareRevisions_t, 588
unpack_dms_GetFSN_t, 589
unpack_dms_GetIMSI_t, 590
unpack_dms_GetManufacturer_t, 590
unpack_dms_GetModelID_t, 591
unpack_dms_GetNetworkTime_t, 592
unpack_dms_GetOfflineReason_t, 593
unpack_dms_GetPower_t, 594
unpack_dms_GetPRLVersion_t, 595
unpack_dms_GetUSBComp_t, 598
unpack_dms_GetVoiceNumber_t, 599
unpack_dms_PSMCfgChange_ind_t, 600
unpack_dms_ResetToFactoryDefaults_t, 601
unpack_dms_SetActivationStatusCallback_t, 601
unpack_dms_SetCustFeature_t, 602
unpack_dms_SetCustFeaturesV2_t, 603
unpack_dms_SetEventReport_ind_t, 604
unpack_dms_SetEventReport_t, 604
unpack_dms_SetFirmwarePreference_t, 605
unpack_dms_SetIndicationRegister_t, 605
unpack_dms_SetPower_t, 606
unpack_dms_SetUSBComp_t, 606
unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t, 610
unpack_dms_SLQSDmsSwiGetResetInfo_t, 611
unpack_dms_SLQSDmsSwiIndicationRegister_t, 613
unpack_dms_SLQSGetERIFile_t, 618
unpack_dms_SLQSSetPowerSaveModeConfig_t, 620
unpack_dms_SLQSSwiClearDyingGaspStatistics-_t, 620
unpack_dms_SLQSSwiGetCrashInfo_t, 621
unpack_dms_SLQSSwiGetDyingGaspCfg_t, 622
unpack_dms_SLQSSwiGetDyingGaspStatistics_t, 622
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 625
unpack_dms_SLQSSwiGetHostDevInfo_t, 626
unpack_dms_SLQSSwiGetOSInfo_t, 627
unpack_dms_SLQSSwiGetSerialNoExt_t, 628
unpack_dms_SLQSSwiSetDyingGaspCfg_t, 628
unpack_dms_SLQSSwiSetHostDevInfo_t, 629
unpack_dms_SLQSSwiSetOSInfo_t, 629
unpack_dms_SLQSUIMGetState_t, 630
unpack_dms_SwiSetEventReport_t, 631
unpack_dms_SwiUimSelect_t, 631
unpack_dms_UIMGetControlKeyStatus_t, 632
unpack_dms_UIMGetICCID_t, 633
unpack_dms_UIMGetPINStatus_t, 635
unpack_dms_UIMSetControlKeyProtection_t, 635
unpack_dms_UIMSetPINProtection_t, 636
unpack_dms_UIMUnblockControlKey_t, 637
unpack_fms_GetImagesPreference_t, 638
unpack_fms_GetStoredImages_t, 638
unpack_fms_SetImagesPreference_t, 639
unpack_loc_BestAvailPos_Ind_t, 669
unpack_loc_Delete_Assist_Data_t, 670
unpack_loc_DeleteAssistData_Ind_t, 671
unpack_loc_EngineState_Ind_t, 672
unpack_loc_EventNMEA_Ind_t, 672
unpack_loc_EventRegister_t, 673
unpack_loc_GetServer_Ind_t, 675
unpack_loc_GnssSvInfo_Ind_t, 676
unpack_loc_PositionRpt_Ind_t, 686
unpack_loc_SetExtPowerConfig_Ind_t, 688
unpack_loc_SetExtPowerState_t, 688
unpack_loc_SetOperationMode_Ind_t, 689
unpack_loc_SetOperationMode_t, 690
unpack_loc_SetServer_Ind_t, 690
unpack_loc_SLQSLOCGetBestAvailPos_t, 691
unpack_loc_Start_t, 691
unpack_loc_Stop_t, 692
unpack_nas_GetNetworkPreference_t, 700

unpack_nas_SetNetworkPreference_t, 711
unpack_nas_SetServingSystemCallback_ind_t, 712
unpack_nas_SlqsGetLTECphyCAInfo_t, 714
unpack_nas_SLQSNasGetRFInfo_t, 745
unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t, 755
unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t, 756
unpack_result_t, 806
unpack_swidms_SLQSSwiDmsSetMTU_t, 845
unpack_swidms_SLQSSwiDmsSetUsbComp_t, 845
unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t, 854
unpack_tmd_SLQSTmdGetMitigationDevList_t, 855
unpack_tmd_SLQSTmdGetMitigationLvl_t, 855
unpack_tmd_SLQSTmdRegNotMitigationLvl_t, 857
unpack_uim_ChangePin_t, 858
unpack_uim_GetCardStatus_t, 858
unpack_uim_ReadTransparent_t, 859
unpack_uim_SetPinProtection_t, 860
unpack_uim_UnblockPin_t, 868
unpack_uim_VerifyPin_t, 868
unpack_wds_SLQSCreateProfile_t, 932
unpack_wds_SLQSGetProfileSettings_t, 942
unpack_wds_SLQSSetIPFamilyPreference_t, 947

tmd.h, 1383
pack_tmd_SLQSTmdDeRegNotMitigationLvl, 1384
pack_tmd_SLQSTmdGetMitigationDevList, 1384
pack_tmd_SLQSTmdGetMitigationLvl, 1384
pack_tmd_SLQSTmdRegNotMitigationLvl, 1385
TMD_MAX_DEV_LIST, 1384
unpack_tmd_SLQSTmdDeRegNotMitigationLvl, 1385
unpack_tmd_SLQSTmdGetMitigationDevList, 1385
unpack_tmd_SLQSTmdGetMitigationLvl, 1386
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind, 1386
unpack_tmd_SLQSTmdRegNotMitigationLvl, 1387

tmd_mitigationDevList, 540
maxMitigationLevel, 540
mitigationDevId, 540
mitigationDevIdLen, 540

tmrSIPRegn
ims_SIPRegnTmrInfo, 81

tmrT1
ims_TmrT1Info, 83

tmrT2
ims_TmrT2Info, 83

tmrTf
ims_TmrTfInfo, 84

toServiceId
sms_BroadcastConfig, 515

toggleMode
voice_lineCtrlInfo, 1005

TokenBucket
unpack_qos_swiQosFlow_t, 804

tokenRate
unpack_qos_tokenBucket_t, 804

tosMask
LibPackTFTIDParams, 119

total_rx_bytes
unpack_qos_SLQSQosSwiReadDataStats_t, 793

total_rx_pkt
unpack_qos_SLQSQosSwiReadDataStats_t, 793

total_tx_bytes
unpack_qos_SLQSQosSwiReadDataStats_t, 793

total_tx_bytes_drp
unpack_qos_SLQSQosSwiReadDataStats_t, 793

total_tx_pkt
unpack_qos_SLQSQosSwiReadDataStats_t, 793

total_tx_pkt_drp
unpack_qos_SLQSQosSwiReadDataStats_t, 793

TrackAreaCode
unpack_nas_SLQSGetServingSystem_t, 723

TrackingStatus
unpack_pds_SetPdsState_Ind_t, 777

TrafficClass
unpack_qos_swiQosFlow_t, 804

trafficClass
LibPackUMTSQoS, 122
wds_UMTSMinQoS, 1038

trafficPriority
LibPackUMTSQoS, 122
wds_UMTSMinQoS, 1038

TranDstPort
unpack_qos_swiQosFilter_t, 800

TranSrcPort
unpack_qos_swiQosFilter_t, 800

TransCap
sms_transLayerInfo, 527

TransType
sms_transLayerInfo, 528

transactionID
sMSTransferRouteMTMessageInfo, 533

transferDelay
LibPackUMTSQoS, 122
wds_UMTSMinQoS, 1038

TransferRouteMTMessageInfo
transferRouteMessageTlv, 541

transferRouteMessageTlv, 540
TlvPresent, 541
TransferRouteMTMessageInfo, 541

transferStats
pack_wds_SLQSSetWdsEventCallback_t, 495

trueSrvStatus
nas_GSMSrvStatusInfo, 181

tx_bytes
unpack_QosFlowStat_t, 806
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954

tx_bytes_drp

unpack_QosFlowStat_t, 806
tx_pkt
unpack_QosFlowStat_t, 806
tx_pkt_drp
unpack_QosFlowStat_t, 806
tx_pkts
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
TxByteOKCnt
wds_TXBytesOKTlv, 1035
TxDropConutTlv
unpack_RMTransferStatistics_ind_t, 808
txOKBytesCount
unpack_wds_SLQSGetDUNCallInfo_t, 942
TxOkByteCountTlv
unpack_RMTransferStatistics_ind_t, 808
TxOkConutTlv
unpack_RMTransferStatistics_ind_t, 808
txPower
nas_txInfo, 278
TxQFilter
unpack_qos_QosFlowInfo_t, 789
TxQFlowGranted
unpack_qos_QosFlowInfo_t, 789
type
pack_wds_GetDefaultProfileNum_t, 476
pack_wds_SetDefaultProfileNum_t, 482
unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t, 610
unpack_dms_SLQSDmsSwiGetResetInfo_t, 611
unpack_qmi_t, 784
typeSize
unpack_sms_GetSMSCAddress_t, 810

u16PRLVersion
unpack_dms_GetPRLVersion_t, 595
u8PRLPreference
unpack_dms_GetPRLVersion_t, 595
UDPDstPort
unpack_qos_swiQosFilter_t, 800
UDPSrcPort
unpack_qos_swiQosFilter_t, 800
ULONG
SwiDataTypes.h, 1359
ULONGLONG
SwiDataTypes.h, 1359
UMTSGrantedQoS
unpack_wds_SLQSGetRuntimeSettings_t, 946
UMTSInstInfo
nas_UMTSInfo, 280
UMTSLTENbrCell
nas_WCDMAInfoLTENeighborCell, 285
UMTSReqQoS
LibPackUMTSReqQoSSigInd, 122
UNIQUE_ID_LEN
dms.h, 1065
UNUSEDPARAM
common.h, 1053
SwiDataTypes.h, 1359
uPhyCardStatus
slot_t, 512
uPhySlotStatus
slot_t, 512
USBComp
pack_dms_SetUSBComp_t, 324
unpack_dms_GetUSBComp_t, 598
USHORT
SwiDataTypes.h, 1359
USSDNotificationNetworkInfo
unpack_voice_USSDNotificationCallback_ind_t, 910
USSInformation
pack_voice_SLQSVoiceOrigUSSDNoWait_t, 469
UUSData
voice_UUSInfo, 1017
UUSDatalen
voice_UUSInfo, 1017
UUSDcs
voice_UUSInfo, 1017
UUSType
voice_UUSInfo, 1017
uarfcn
nas_lteWcdmaCellInfo, 217
nas_UMTSInfo, 280
nas_wcdmaUARFCN, 290
ueInIdle
nas_LTEInfoInterfreq, 199
nas_LTEInfoIntrafreq, 201
nas_LTEInfoNeighboringGSM, 202
nas_LTEInfoNeighboringWCDMA, 203
uim.h, 1387
MAX_ICCID_LENGTH, 1390
MAX_NO_OF_SLOTS, 1390
MAX_SLOTS_STATUS, 1390
pack_uim_ChangePin, 1391
pack_uim_GetCardStatus, 1391
pack_uim_ReadTransparent, 1391
pack_uim_SLQSUIMAuthenticate, 1392
pack_uim_SLQSUIMDepersonalization, 1392
pack_uim_SLQSUIMEventRegister, 1393
pack_uim_SLQSUIMGetConfiguration, 1393
pack_uim_SLQSUIMGetFileAttributes, 1394
pack_uim_SLQSUIMGetSlotsStatus, 1394
pack_uim_SLQSUIMPowerDown, 1394
pack_uim_SLQSUIMPowerUp, 1395
pack_uim_SLQSUIMRefreshComplete, 1395
pack_uim_SLQSUIMRefreshGetLastEvent, 1395
pack_uim_SLQSUIMRefreshOK, 1396
pack_uim_SLQSUIMRefreshRegister, 1396
pack_uim_SLQSUIMReset, 1397
pack_uim_SLQSUIMSwitchSlot, 1397
pack_uim_SetPinProtection, 1392
pack_uim_UnblockPin, 1397
pack_uim_VerifyPin, 1398
unpack_uim_ChangePin, 1398
unpack_uim_GetCardStatus, 1398
unpack_uim_ReadTransparent, 1399

unpack_uim_SLQSUIMAuthenticate, 1400
unpack_uim_SLQSUIMDepersonalization, 1400
unpack_uim_SLQSUIMEventRegister, 1401
unpack_uim_SLQSUIMGetConfiguration, 1401
unpack_uim_SLQSUIMGetFileAttributes, 1401
unpack_uim_SLQSUIMGetSlotsStatus, 1402
unpack_uim_SLQSUIMPowerDown, 1402
unpack_uim_SLQSUIMPowerDown_t, 1390
unpack_uim_SLQSUIMPowerUp, 1402
unpack_uim_SLQSUIMPowerUp_t, 1390
unpack_uim_SLQSUIMRefreshCallback_Ind, 1403
unpack_uim_SLQSUIMRefreshComplete, 1403
unpack_uim_SLQSUIMRefreshComplete_t, 1390
unpack_uim_SLQSUIMRefreshGetLastEvent, 1404
unpack_uim_SLQSUIMRefreshOK, 1404
unpack_uim_SLQSUIMRefreshOK_t, 1391
unpack_uim_SLQSUIMRefreshRegister, 1404
unpack_uim_SLQSUIMRefreshRegister_t, 1391
unpack_uim_SLQSUIMReset, 1405
unpack_uim_SLQSUIMReset_t, 1391
unpack_uim_SLQSUIMSetStatusChangeCallBack_ind, 1405
unpack_uim_SLQSUIMSwitchSlot, 1405
unpack_uim_SLQSUIMSwitchSlot_t, 1391
unpack_uim_SetPinProtection, 1399
unpack_uim_SetUimSlotStatusChangeCallback_ind, 1400
unpack_uim_UnblockPin, 1406
unpack_uim_VerifyPin, 1406
uim_UIMSessionInformation, 563
aid, 564
aidLength, 564
sessionType, 564
uim_appStatus, 541
aidLength, 543
aidVal, 543
appState, 543
appType, 543
persoFeature, 543
persoRetries, 543
persoState, 543
persoUnblockRetries, 543
pin1Retries, 543
pin1State, 543
pin2Retries, 543
pin2State, 544
puk1Retries, 544
puk2Retries, 544
univPin, 544
uim_authenticateResult, 544
content, 544
contentLen, 544
uim_authenticationData, 544
context, 545
data, 545
dataLen, 545
uim_cardResult, 545
sw1, 546
sw2, 546
uim_cardStatus, 546
index1xPri, 547
index1xSec, 547
indexGwPri, 547
indexGwSec, 547
numSlot, 547
SlotInfo, 547
uim_changeUIMPIN, 547
oldPINLen, 548
oldPINVal, 548
pinID, 548
pinLen, 548
pinVal, 548
uim_depersonalizationInformation, 548
ckLen, 549
ckVal, 549
feature, 549
operation, 549
uim_encryptedPIN1, 549
pin1Len, 550
pin1Val, 550
uim_fileAttributes, 550
fileID, 553
fileSize, 553
fileType, 553
rawLen, 553
rawValue, 553
recordCount, 553
recordSize, 553
secActivate, 553
secActivateMask, 553
secDeactivate, 553
secDeactivateMask, 553
secIncrease, 553
secIncreaseMask, 553
secRead, 553
secReadMask, 553
secWrite, 553
secWriteMask, 553
uim_fileInfo, 553
fileID, 554
path, 554
pathLen, 554
uim_hotSwapStatus, 554
hotSwap, 554
hotSwapLength, 554
uim_personalizationStatus, 554
feature, 555
numFeatures, 555
unblockLeft, 555
verifyLeft, 555
uim_readResult, 555
content, 556
contentLen, 556
uim_readTransparentInfo, 556
length, 556

offset, 556
uim_refreshevent, 556
aid, 558
aidLength, 558
arrfileInfo, 558
mode, 558
numOfFiles, 558
sessionType, 558
stage, 558
uim_registerRefresh, 558
arrfileInfo, 559
numFiles, 559
registerFlag, 559
voteForInit, 559
uim_remainingRetries, 559
unblockLeft, 559
verifyLeft, 559
uim_select
pack_dms_SwiUimSelect_t, 329
uim_sessionInformation, 560
aid, 560
aidLength, 560
sessionType, 560
uim_setPINProtection, 560
pinID, 561
pinLength, 561
pinOperation, 561
pinValue, 561
uim_slotInfo, 561
AppStatus, 563
cardState, 563
errorState, 563
numApp, 563
upinRetries, 563
upinState, 563
upukRetries, 563
uim_unblockUIMPIN, 564
newPINLen, 564
newPINVal, 564
pinID, 564
pukLen, 564
pukVal, 565
uim_verifyUIMPIN, 565
pinID, 565
pinLen, 565
pinVal, 565
uimAutoSwitchActSlot
dms_UimAutoSwitchActSlotTlv, 59
uimSelect
unpack_dms_SLQSDmsSwiGetUimSelection_t, 612
uimSlotStatus
slots_t, 515
UimStatusTlv
unpack_dms_SwiEventReportCallBack_ind_t, 630
ulData
wds_DataULongTlv, 1021
ulMask
rmTrasnferStaticsReq, 510
ulMax
PackSwiAvmsSetSettingsPeriodInfo, 504
ulMin
PackSwiAvmsSetSettingsPeriodInfo, 504
ulPhysicalSlot
pack_uim_SLQSUIMSwitchSlot_t, 454
ulPkgDownloadComplete
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 961
ulPkgDownloadSize
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 962
ullData
wds_DataULongLongTlv, 1021
umtsEcio
nas_UMTSinstInfo, 281
umtsInst
nas_UMTSInfo, 280
umtsLTENbrCellLen
nas_WCDMAInfoLTENeighborCell, 285
umtsPsc
nas_UMTSinstInfo, 281
umtsRscp
nas_UMTSinstInfo, 281
umtsUarfcn
nas_UMTSinstInfo, 281
UnPackGetProfileSettingOut, 959
curProfile, 960
pExtErrCode, 960
unblockLeft
uim_personalizationStatus, 555
uim_remainingRetries, 559
unblockRetriesLeft
unpack_dms_UIMGetControlKeyStatus_t, 632
unpack_dms_UIMSetPINProtection_t, 636
unpack_dms_UIMUnblockControlKey_t, 637
uniqueID
image_info_t, 71
univPin
appStats, 38
uim_appStatus, 544
universalTime
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t, 751
unpack_QosFlowStat_t, 805
bearerId, 806
tx_bytes, 806
tx_bytes_drp, 806
tx_pkt, 806
tx_pkt_drp, 806
unpack_RMTransferStatistics_ind_t, 807
ParamPresenceMask, 808
RxDropConutTlv, 808
RxOkByteCountTlv, 808
RxOkConutTlv, 808
TxDropConutTlv, 808
TxOkByteCountTlv, 808

TxOkConutTlv, 808
unpack_audio_SLQSGetAudioPathConfig
audio.h, 1045
unpack_audio_SLQSGetAudioPathConfig_t, 565
pCodecSTGain, 567
pECMode, 567
pMICGainSelect, 567
pNSEnable, 567
pRXAGCList, 567
pRXAVCList, 567
pTXAGCList, 567
pTXAVCSwitch, 567
pTXGain, 567
ParamPresenceMask, 567
unpack_audio_SLQSGetAudioProfile
audio.h, 1045
unpack_audio_SLQSGetAudioProfile_t, 568
EarMute, 568
MicMute, 569
ParamPresenceMask, 569
Profile, 569
Volume, 569
unpack_audio_SLQSGetAudioVolTLBConfig
audio.h, 1045
unpack_audio_SLQSGetAudioVolTLBConfig_t, 569
ParamPresenceMask, 569
ResCode, 569
unpack_audio_SLQSSetAudioPathConfig
audio.h, 1046
unpack_audio_SLQSSetAudioProfile
audio.h, 1046
unpack_audio_SLQSSetAudioVolTLBConfig
audio.h, 1046
unpack_audio_SLQSSetAudioVolTLBConfig_t, 569
ParamPresenceMask, 570
ResCode, 570
unpack_cat_CATSendEnvelopeCommand
cat.h, 1049
unpack_cat_CATSendEnvelopeCommand_t
cat.h, 1048
unpack_cat_CATSendTerminalResponse
cat.h, 1049
unpack_cat_CATSendTerminalResponse_t
cat.h, 1048
unpack_cat_SetCATEventCallback
cat.h, 1050
unpack_cat_SetCATEventCallback_t, 570
errorMask, 571
ParamPresenceMask, 571
Tlvresult, 571
unpack_cat_SetCatEventCallback_ind
cat.h, 1050
unpack_cat_SetCatEventCallback_ind_t, 570
CCETlv, 570
event_Index, 570
ParamPresenceMask, 570
unpack_dms_ActivateAutomatic
dms.h, 1090
unpack_dms_GetActivationState
dms.h, 1091
unpack_dms_GetActivationState_t, 571
ParamPresenceMask, 572
state, 572
unpack_dms_GetBandCapability
dms.h, 1091
unpack_dms_GetBandCapability_t, 572
BandCapability, 574
ParamPresenceMask, 574
Tlvresult, 574
unpack_dms_GetCrashAction
dms.h, 1091
unpack_dms_GetCrashAction_t, 574
DevCrashState, 574
ParamPresenceMask, 574
Tlvresult, 575
unpack_dms_GetCustFeature
dms.h, 1092
unpack_dms_GetCustFeature_t, 575
DHCPRelayEnabled, 577
DisableIMSI, 577
GPSLPM, 577
GPSSel, 577
GpsEnable, 577
IPFamSupport, 577
IsVoiceEnabled, 577
ParamPresenceMask, 577
RMAutoConnect, 577
SMSSupport, 577
Tlvresult, 577
unpack_dms_GetCustFeaturesV2
dms.h, 1092
unpack_dms_GetCustFeaturesV2_t, 577
GetCustomFeatureV2, 578
ParamPresenceMask, 578
Tlvresult, 578
unpack_dms_GetDeviceCap
dms.h, 1092
unpack_dms_GetDeviceCap_t, 578
DataServiceCapability, 579
MaxRXChannelRate, 579
MaxTXChannelRate, 579
ParamPresenceMask, 579
RadioIfaces, 579
RadioIfacesSize, 579
SimCapability, 579
Tlvresult, 579
unpack_dms_GetDeviceCapabilities
dms.h, 1093
unpack_dms_GetDeviceCapabilities_t, 579
dataServiceCaCapability, 580
maxRxChannelRate, 581
maxTxChannelRate, 581
ParamPresenceMask, 581
RadioIfaces, 581
radioIfacesSize, 581
simCapability, 581

unpack_dms_GetDeviceHardwareRev
dms.h, 1093
unpack_dms_GetDeviceHardwareRev_t, 581
ParamPresenceMask, 581
String, 581
stringSize, 581
Tlvresult, 581
unpack_dms_GetDeviceMfr
dms.h, 1093
unpack_dms_GetDeviceMfr_t, 582
ParamPresenceMask, 582
String, 582
stringSize, 582
Tlvresult, 582
unpack_dms_GetDeviceSerialNumbers
dms.h, 1094
unpack_dms_GetDeviceSerialNumbers_t, 582
ESNString, 584
esnSize, 584
IMEIString, 584
imeiSize, 584
imeiSvnSize, 584
ImeiSvnString, 584
MEIDString, 584
meidSize, 584
ParamPresenceMask, 584
Tlvresult, 584
unpack_dms_GetFSN
dms.h, 1095
unpack_dms_GetFSN_t, 588
ParamPresenceMask, 589
String, 589
Tlvresult, 589
unpack_dms_GetFirmwareInfo
dms.h, 1094
unpack_dms_GetFirmwareInfo_t, 584
appversion_str, 585
bootversion_str, 585
carrier_str, 585
cur_carr_name, 586
cur_carr_rev, 586
modelid_str, 586
packageid_str, 586
ParamPresenceMask, 586
priversion_str, 586
sku_str, 586
Tlvresult, 586
unpack_dms_GetFirmwareRevision
dms.h, 1094
unpack_dms_GetFirmwareRevision_t, 586
AMSSString, 587
amssSize, 587
PRIString, 587
ParamPresenceMask, 587
Tlvresult, 587
unpack_dms_GetFirmwareRevisions
dms.h, 1095
unpack_dms_GetFirmwareRevisions_t, 587
AMSSString, 588
amssSize, 588
bootSize, 588
BootString, 588
PRIString, 588
ParamPresenceMask, 588
priSize, 588
Tlvresult, 588
unpack_dms_GetHardwareRevision
dms.h, 1095
unpack_dms_GetHardwareRevision_t, 589
hwVer, 589
ParamPresenceMask, 589
unpack_dms_GetIMSI
dms.h, 1096
unpack_dms_GetIMSI_t, 589
imsi, 590
ParamPresenceMask, 590
Tlvresult, 590
unpack_dms_GetManufacturer
dms.h, 1096
unpack_dms_GetManufacturer_t, 590
manufacturer, 590
ParamPresenceMask, 590
Tlvresult, 590
unpack_dms_GetModelID
dms.h, 1096
unpack_dms_GetModelID_t, 591
modelid, 591
ParamPresenceMask, 591
Tlvresult, 591
unpack_dms_GetNetworkTime
dms.h, 1097
unpack_dms_GetNetworkTime_t, 591
ParamPresenceMask, 592
source, 592
timestamp, 592
Tlvresult, 592
unpack_dms_GetOfflineReason
dms.h, 1097
unpack_dms_GetOfflineReason_t, 592
pReasonMask, 593
ParamPresenceMask, 593
pbPlatform, 593
Tlvresult, 593
unpack_dms_GetPRLVersion
dms.h, 1098
unpack_dms_GetPRLVersion_t, 594
ParamPresenceMask, 595
Tlvresult, 595
u16PRLVersion, 595
u8PRLPreference, 595
unpack_dms_GetPower
dms.h, 1097
unpack_dms_GetPower_t, 593
HardwareControlledMode, 594
OfflineReason, 594
OperationMode, 594

ParamPresenceMask, 594
Tlvresult, 594
unpack_dms_GetSerialNumbers
dms.h, 1098
unpack_dms_GetSerialNumbers_t, 595
esn, 596
imei_no, 596
imeisv_svn, 596
meid, 596
ParamPresenceMask, 596
unpack_dms_GetUSBComp
dms.h, 1098
unpack_dms_GetUSBComp_t, 596
NumSupUSBComps, 598
ParamPresenceMask, 598
SupUSBComps, 598
Tlvresult, 598
USBComp, 598
unpack_dms_GetVoiceNumber
dms.h, 1099
unpack_dms_GetVoiceNumber_t, 598
MIN, 599
minSize, 599
ParamPresenceMask, 599
Tlvresult, 599
VoiceNumber, 599
voiceNumberSize, 599
unpack_dms_PSMCfgChange_ind
dms.h, 1099
unpack_dms_PSMCfgChange_ind_t, 600
ActiveTimer, 600
EnableState, 600
ParamPresenceMask, 600
PeriodicUpdateTimer, 600
Tlvresult, 600
unpack_dms_ResetToFactoryDefaults
dms.h, 1099
unpack_dms_ResetToFactoryDefaults_t, 600
ParamPresenceMask, 601
Tlvresult, 601
unpack_dms_SLQSDmsSwiGetPCInfo
dms.h, 1103
unpack_dms_SLQSDmsSwiGetPCInfo_t, 606
has_LpmFlag, 608
has_PersistentLpm, 608
has_Wdisable, 608
LpmFlag, 609
opMode, 609
ParamPresenceMask, 609
PersistentLpm, 609
PowerOffMode, 609
Wdisable, 609
unpack_dms_SLQSDmsSwiGetResetInfo
dms.h, 1104
unpack_dms_SLQSDmsSwiGetResetInfo_Ind
dms.h, 1104
unpack_dms_SLQSDmsSwiGetResetInfo_Ind_t, 609
ParamPresenceMask, 610
source, 610
Tlvresult, 610
type, 610
unpack_dms_SLQSDmsSwiGetResetInfo_t, 610
ParamPresenceMask, 611
source, 611
Tlvresult, 611
type, 611
unpack_dms_SLQSDmsSwiGetUimSelection
dms.h, 1104
unpack_dms_SLQSDmsSwiGetUimSelection_t, 611
pUimAutoSwitchActSlot, 612
ParamPresenceMask, 612
uimSelect, 612
unpack_dms_SLQSDmsSwiIndicationRegister
dms.h, 1105
unpack_dms_SLQSDmsSwiIndicationRegister_t, 612
ParamPresenceMask, 613
Tlvresult, 613
unpack_dms_SLQSGetBandCapability
dms.h, 1105
unpack_dms_SLQSGetBandCapability_t, 613
bandCapability, 617
LteBandCapability, 617
ParamPresenceMask, 617
TdsBandCapability, 617
unpack_dms_SLQSGetERIFile
dms.h, 1105
unpack_dms_SLQSGetERIFile_t, 617
eriFile, 618
ParamPresenceMask, 618
Tlvresult, 618
unpack_dms_SLQSGetPowerSaveModeConfig
dms.h, 1106
unpack_dms_SLQSGetPowerSaveModeConfig_t, 618
pActiveTimer, 619
pDurationThreshold, 619
pEarlyWakeupTime, 619
pPeriodicUpdateTimer, 619
pPsmEnableState, 619
pRandomizationWindow, 619
ParamPresenceMask, 619
unpack_dms_SLQSSetPowerSaveModeConfig
dms.h, 1106
unpack_dms_SLQSSetPowerSaveModeConfig_t, 619
ParamPresenceMask, 620
Tlvresult, 620
unpack_dms_SLQSSwiClearDyingGaspStatistics
dms.h, 1107
unpack_dms_SLQSSwiClearDyingGaspStatistics_t, 620
ParamPresenceMask, 620
Tlvresult, 620
unpack_dms_SLQSSwiGetCrashInfo
dms.h, 1107
unpack_dms_SLQSSwiGetCrashInfo_t, 620
crashInfoParam, 621
ParamPresenceMask, 621

Tlvresult, 621
unpack_dms_SLQSSwiGetDyingGaspCfg
dms.h, 1107
unpack_dms_SLQSSwiGetDyingGaspCfg_t, 621
pGetDyingGaspCfg, 622
ParamPresenceMask, 622
Tlvresult, 622
unpack_dms_SLQSSwiGetDyingGaspStatistics
dms.h, 1108
unpack_dms_SLQSSwiGetDyingGaspStatistics_t, 622
pGetDyingGaspStatistics, 622
ParamPresenceMask, 622
Tlvresult, 622
unpack_dms_SLQSSwiGetFirmwareCurr
dms.h, 1108
unpack_dms_SLQSSwiGetFirmwareCurr_t, 622
carrier, 623
fwvers, 623
numEntries, 623
pCurrImgInfo, 623
ParamPresenceMask, 623
pkgver, 623
priver, 623
unpack_dms_SLQSSwiGetFwUpdateStatus
dms.h, 1108
unpack_dms_SLQSSwiGetFwUpdateStatus_t, 623
imgType, 625
logString, 625
ParamPresenceMask, 625
refData, 625
refString, 625
ResCode, 625
Tlvresult, 625
unpack_dms_SLQSSwiGetHostDevInfo
dms.h, 1109
unpack_dms_SLQSSwiGetHostDevInfo_t, 625
manString, 626
modelString, 626
ParamPresenceMask, 626
plasmaIDString, 626
swVerString, 626
Tlvresult, 626
unpack_dms_SLQSSwiGetOSInfo
dms.h, 1109
unpack_dms_SLQSSwiGetOSInfo_t, 626
nameString, 627
ParamPresenceMask, 627
Tlvresult, 627
versionString, 627
unpack_dms_SLQSSwiGetSerialNoExt
dms.h, 1109
unpack_dms_SLQSSwiGetSerialNoExt_t, 627
meidString, 627
ParamPresenceMask, 627
Tlvresult, 628
unpack_dms_SLQSSwiSetDyingGaspCfg
dms.h, 1110
unpack_dms_SLQSSwiSetDyingGaspCfg_t, 628
ParamPresenceMask, 628
Tlvresult, 628
unpack_dms_SLQSSwiSetHostDevInfo
dms.h, 1110
unpack_dms_SLQSSwiSetHostDevInfo_t, 628
ParamPresenceMask, 628
Tlvresult, 629
unpack_dms_SLQSSwiSetOSInfo
dms.h, 1110
unpack_dms_SLQSSwiSetOSInfo_t, 629
ParamPresenceMask, 629
Tlvresult, 629
unpack_dms_SLQSUIMGetState
dms.h, 1111
unpack_dms_SLQSUIMGetState_t, 629
ParamPresenceMask, 630
state, 630
Tlvresult, 630
unpack_dms_SetActivationStatusCallback
dms.h, 1100
unpack_dms_SetActivationStatusCallback_t, 601
ParamPresenceMask, 601
Tlvresult, 601
unpack_dms_SetCrashAction
dms.h, 1100
unpack_dms_SetCrashAction_t, 601
notused, 602
ParamPresenceMask, 602
unpack_dms_SetCustFeature
dms.h, 1100
unpack_dms_SetCustFeature_t, 602
ParamPresenceMask, 602
Tlvresult, 602
unpack_dms_SetCustFeaturesV2
dms.h, 1101
unpack_dms_SetCustFeaturesV2_t, 602
ParamPresenceMask, 603
Tlvresult, 603
unpack_dms_SetEventReport
dms.h, 1101
unpack_dms_SetEventReport_ind
dms.h, 1101
unpack_dms_SetEventReport_ind_t, 603
ActivationStatusTlv, 603
OperatingModeTlv, 603
ParamPresenceMask, 604
Tlvresult, 604
unpack_dms_SetEventReport_t, 604
ParamPresenceMask, 604
Tlvresult, 604
unpack_dms_SetFirmwarePreference
dms.h, 1102
unpack_dms_SetFirmwarePreference_t, 604
ParamPresenceMask, 605
Tlvresult, 605
unpack_dms_SetIndicationRegister
dms.h, 1102
unpack_dms_SetIndicationRegister_t, 605

ParamPresenceMask, 605
Tlvresult, 605
unpack_dms_SetPower
dms.h, 1103
unpack_dms_SetPower_t, 605
ParamPresenceMask, 606
Tlvresult, 606
unpack_dms_SetUSBComp
dms.h, 1103
unpack_dms_SetUSBComp_t, 606
ParamPresenceMask, 606
Tlvresult, 606
unpack_dms_SwiEventReportCallBack_ind
dms.h, 1111
unpack_dms_SwiEventReportCallBack_ind_t, 630
ParamPresenceMask, 630
TempTlv, 630
UimStatusTlv, 630
VoltTlv, 630
unpack_dms_SwiSetEventReport
dms.h, 1111
unpack_dms_SwiSetEventReport_t, 631
ParamPresenceMask, 631
Tlvresult, 631
unpack_dms_SwiUimSelect
dms.h, 1112
unpack_dms_SwiUimSelect_t, 631
ParamPresenceMask, 631
Tlvresult, 631
unpack_dms_UIMChangePIN
dms.h, 1112
unpack_dms_UIMGetControlKeyStatus
dms.h, 1112
unpack_dms_UIMGetControlKeyStatus_t, 632
facilityState, 632
ParamPresenceMask, 632
Tlvresult, 632
unblockRetriesLeft, 632
verifyRetriesLeft, 632
unpack_dms_UIMGetICCID
dms.h, 1113
unpack_dms_UIMGetICCID_t, 633
ParamPresenceMask, 633
String, 633
stringSize, 633
Tlvresult, 633
unpack_dms_UIMGetPINStatus
dms.h, 1113
unpack_dms_UIMGetPINStatus_t, 633
p1Status, 635
p1UnblockRetriesLeft, 635
p1VerifyRetriesLeft, 635
p2Status, 635
p2UnblockRetriesLeft, 635
p2VerifyRetriesLeft, 635
ParamPresenceMask, 635
Tlvresult, 635
unpack_dms_UIMSetControlKeyProtection
dms.h, 1113
unpack_dms_UIMSetControlKeyProtection_t, 635
ParamPresenceMask, 635
Tlvresult, 635
verifyRetriesLeft, 636
unpack_dms_UIMSetPINProtection
dms.h, 1114
unpack_dms_UIMSetPINProtection_t, 636
ParamPresenceMask, 636
Tlvresult, 636
unblockRetriesLeft, 636
verifyRetriesLeft, 636
unpack_dms_UIMUnblockControlKey
dms.h, 1114
unpack_dms_UIMUnblockControlKey_t, 636
ParamPresenceMask, 637
Tlvresult, 637
unblockRetriesLeft, 637
unpack_dms_UIMUnblockPIN
dms.h, 1114
unpack_dms_UIMVerifyPIN
dms.h, 1115
unpack_dms_ValidateSPC
dms.h, 1115
unpack_fms_GetImagesPreference
fms.h, 1118
unpack_fms_GetImagesPreference_t, 637
ImageListSize, 638
pImageList, 638
ParamPresenceMask, 638
Tlvresult, 638
unpack_fms_GetStoredImages
fms.h, 1118
unpack_fms_GetStoredImages_t, 638
imageList, 638
imagelistSize, 638
ParamPresenceMask, 638
Tlvresult, 638
unpack_fms_SetImagesPreference
fms.h, 1119
unpack_fms_SetImagesPreference_t, 638
ImageTypes, 639
ImageTypesSize, 639
ParamPresenceMask, 639
Tlvresult, 639
unpack_ims_SLQSGetIMSSMSConfig
ims.h, 1126
unpack_ims_SLQSGetIMSSMSConfig_t, 639
pSettingResp, 640
ParamPresenceMask, 640
unpack_ims_SLQSGetIMSUserConfig
ims.h, 1126
unpack_ims_SLQSGetIMSUserConfig_t, 640
pIMSDomain, 641
pSettingResp, 641
ParamPresenceMask, 641
unpack_ims_SLQSGetIMSVoIPConfig
ims.h, 1127

unpack_ims_SLQSGetIMSVoIPConfig_t, 641
pAmrMode, 643
pRingingTimer, 644
pSettingResp, 644
ParamPresenceMask, 644
unpack_ims_SLQSGetRegMgrConfig
ims.h, 1127
unpack_ims_SLQSGetRegMgrConfig_t, 644
pIMSTestMode, 645
pPCSCFPort, 645
pSettingResp, 645
ParamPresenceMask, 645
unpack_ims_SLQSGetSIPConfig
ims.h, 1127
unpack_ims_SLQSGetSIPConfig_t, 645
pSIPLocalPort, 646
pSettingResp, 646
pSigCompEnabled, 646
pSubscribeTimer, 646
pTimerSIPReg, 646
pTimerT1, 646
pTimerT2, 646
pTimerTf, 646
ParamPresenceMask, 646
unpack_ims_SLQSImsConfigIndicationRegister
ims.h, 1128
unpack_ims_SLQSImsConfigIndicationRegister_t
ims.h, 1121
unpack_ims_SLQSRegMgrCfgCallBack_ind
ims.h, 1128
unpack_ims_SLQSRegMgrCfgCallBack_ind_t, 646
PCTlv, 647
PNTlv, 647
ParamPresenceMask, 647
TMTlv, 647
unpack_ims_SLQSSIPCfgCallBack_ind
ims.h, 1130
unpack_ims_SLQSSIPCfgCallBack_ind_t, 650
ParamPresenceMask, 651
SCTlv, 651
SPTlv, 651
SRTlv, 651
STTlv, 651
TT1Tlv, 651
TT2Tlv, 651
TTfTlv, 651
unpack_ims_SLQSSMSCfgCallBack_ind
ims.h, 1130
unpack_ims_SLQSSMSCfgCallBack_ind_t, 651
ParamPresenceMask, 652
SFTlv, 652
unpack_ims_SLQSSetIMSSMSConfig
ims.h, 1128
unpack_ims_SLQSSetIMSSMSConfig_t, 647
pSettingResp, 648
ParamPresenceMask, 648
unpack_ims_SLQSSetIMSUserConfig
ims.h, 1129
unpack_ims_SLQSSetIMSUserConfig_t, 648
pSettingResp, 648
ParamPresenceMask, 648
unpack_ims_SLQSSetIMSVoIPConfig
ims.h, 1129
unpack_ims_SLQSSetIMSVoIPConfig_t, 648
pSettingResp, 649
ParamPresenceMask, 649
unpack_ims_SLQSSetRegMgrConfig
ims.h, 1129
unpack_ims_SLQSSetRegMgrConfig_t, 649
pSettingResp, 649
ParamPresenceMask, 649
unpack_ims_SLQSSetSIPConfig
ims.h, 1130
unpack_ims_SLQSSetSIPConfig_t, 649
pSettingResp, 650
ParamPresenceMask, 650
unpack_ims_SLQSUserCfgCallBack_ind
ims.h, 1131
unpack_ims_SLQSUserCfgCallBack_ind_t, 652
IDTlv, 653
ParamPresenceMask, 653
unpack_ims_SLQSVoIPCfgCallBack_ind
ims.h, 1131
unpack_ims_SLQSVoIPCfgCallBack_ind_t, 653
AMTlv, 654
ParamPresenceMask, 655
RTTlv, 655
SDTlv, 655
unpack_imsa_SLQSGetIMSARegStatus
imsa.h, 1134
unpack_imsa_SLQSGetIMSARegStatus_t, 655
ImsRegErrCode, 656
ImsRegStatus, 656
NewImsRegStatus, 656
ParamPresenceMask, 656
unpack_imsa_SLQSGetIMSAServiceStatus
imsa.h, 1135
unpack_imsa_SLQSGetIMSAServiceStatus_t, 656
ParamPresenceMask, 658
SmsServiceRat, 658
SmsServiceStatus, 658
UtServiceRat, 658
UtServiceStatus, 658
VoipServiceRat, 658
VoipServiceStatus, 658
VsServiceRat, 658
VsServiceStatus, 658
VtServiceRat, 658
VtServiceStatus, 658
unpack_imsa_SLQSImsaPdpStatusCallBack_ind
imsa.h, 1135
unpack_imsa_SLQSImsaPdpStatusCallBack_ind_t, 658
FailErrCode, 659
ParamPresenceMask, 659
PdpConnState, 659
unpack_imsa_SLQSImsaRatStatusCallBack_ind

imsa.h, 1135
unpack_imsa_SLQSImsaRatStatusCallBack_ind_t, 659
ParamPresenceMask, 660
RatHandover, 660
unpack_imsa_SLQSImsaRegStatusCallBack_ind
imsa.h, 1136
unpack_imsa_SLQSImsaRegStatusCallBack_ind_t, 660
IMSRegistration, 660
ParamPresenceMask, 660
unpack_imsa_SLQSImsaSvcStatusCallBack_ind
imsa.h, 1136
unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t, 661
ParamPresenceMask, 662
SmsRat, 662
SmsService, 662
UtRat, 662
UtService, 662
VoipRat, 662
VoipService, 662
VtRat, 662
VtService, 662
unpack_imsa_SLQSRegisterIMSAIndication
imsa.h, 1137
unpack_imsa_SLQSRegisterIMSAIndication_t
imsa.h, 1133
unpack_loc_BestAvailPos_Ind
loc.h, 1159
unpack_loc_BestAvailPos_Ind_t, 662
pAltitudeWrtEllipsoid, 668
pAltitudeWrtMeanSeaLevel, 668
pGpsTime, 668
pHeading, 668
pHeadingUnc, 668
pHorCirConf, 668
pHorEllpConf, 668
pHorReliability, 668
pHorUncCircular, 668
pHorUncEllipseOrientAzimuth, 668
pHorUncEllipseSemiMajor, 668
pHorUncEllipseSemiMinor, 668
pLatitude, 668
pLongitude, 668
pMagneticDeviation, 668
pPrecisionDilution, 668
pSensorDataUsage, 668
pSpeedHorizontal, 668
pSpeedUnc, 668
pSpeedVertical, 668
pSpeedVerticalUnc, 668
pSvUsedforFix, 668
pTechnologyMask, 668
pTimeSrc, 668
pTimeUnc, 668
pTimestampUtc, 668
pVertConfidence, 668
pVertReliability, 669
pVertUnc, 669
pXid, 669
ParamPresenceMask, 668
status, 669
Tlvresult, 669
unpack_loc_CradleMountCallback_Ind
loc.h, 1159
unpack_loc_CradleMountCallback_Ind_t, 669
cradleMountConfigStatus, 669
ParamPresenceMask, 669
unpack_loc_Delete_Assist_Data_t, 669
ParamPresenceMask, 670
Tlvresult, 670
unpack_loc_DeleteAssistData
loc.h, 1159
unpack_loc_DeleteAssistData_Ind
loc.h, 1160
unpack_loc_DeleteAssistData_Ind_t, 670
ParamPresenceMask, 671
status, 671
Tlvresult, 671
unpack_loc_EngineState_Ind
loc.h, 1160
unpack_loc_EngineState_Ind_t, 671
engineState, 672
ParamPresenceMask, 672
Tlvresult, 672
unpack_loc_EventNMEA_Ind
loc.h, 1160
unpack_loc_EventNMEA_Ind_t, 672
NMEAData, 672
ParamPresenceMask, 672
Tlvresult, 672
unpack_loc_EventRegister
loc.h, 1161
unpack_loc_EventRegister_t, 673
ParamPresenceMask, 673
Tlvresult, 673
unpack_loc_EventTimeSyncCallback_Ind
loc.h, 1161
unpack_loc_EventTimeSyncCallback_Ind_t, 673
ParamPresenceMask, 673
timeSyncRefCounter, 673
unpack_loc_GetServer_Ind
loc.h, 1161
unpack_loc_GetServer_Ind_t, 673
pIPv4AddrInfo, 675
pIPv6AddrInfo, 675
pURL, 675
ParamPresenceMask, 675
serverStatus, 675
serverType, 675
Tlvresult, 675
unpack_loc_GnssSvInfo_Ind
loc.h, 1162
unpack_loc_GnssSvInfo_Ind_t, 675
altitudeAssumed, 676
pSatelliteInfo, 676
ParamPresenceMask, 676

Tlvresult, 676
unpack_loc_InjectPositionCallback_Ind
loc.h, 1162
unpack_loc_InjectPositionCallback_Ind_t, 676
ParamPresenceMask, 676
status, 676
unpack_loc_InjectSensorDataCallback_Ind
loc.h, 1162
unpack_loc_InjectSensorDataCallback_Ind_t, 676
injectSensorDataStatus, 678
pAccelSamplesAccepted, 678
pAccelTempSamplesAccepted, 678
pGyroSamplesAccepted, 678
pGyroTempSamplesAccepted, 678
pOpaqueIdentifier, 678
ParamPresenceMask, 678
unpack_loc_InjectTimeSyncDataCallback_Ind
loc.h, 1163
unpack_loc_InjectTimeSyncDataCallback_Ind_t, 678
injectTimeSyncStatus, 679
ParamPresenceMask, 679
unpack_loc_InjectUTCTimeCallback_Ind
loc.h, 1163
unpack_loc_InjectUTCTimeCallback_Ind_t, 679
ParamPresenceMask, 679
status, 679
unpack_loc_PositionRpt_Ind
loc.h, 1163
unpack_loc_PositionRpt_Ind_t, 679
pAltitudeAssumed, 685
pAltitudeWrtEllipsoid, 685
pAltitudeWrtMeanSeaLevel, 685
pFixId, 685
pGpsTime, 685
pHeading, 685
pHeadingUnc, 685
pHorConfidence, 685
pHorReliability, 685
pHorUncCircular, 685
pHorUncEllipseOrientAzimuth, 685
pHorUncEllipseSemiMajor, 685
pHorUncEllipseSemiMinor, 685
pLatitude, 685
pLeapSeconds, 685
pLongitude, 685
pMagneticDeviation, 685
pPrecisionDilution, 686
pSensorDataUsage, 686
pSpeedHorizontal, 686
pSpeedUnc, 686
pSpeedVertical, 686
pSvUsedforFix, 686
pTechnologyMask, 686
pTimeSrc, 686
pTimeUnc, 686
pTimestampUtc, 686
pVertConfidence, 686
pVertReliability, 686
pVertUnc, 686
ParamPresenceMask, 685
sessionId, 686
sessionStatus, 686
Tlvresult, 686
unpack_loc_SLQSLOCGetBestAvailPos
loc.h, 1166
unpack_loc_SLQSLOCGetBestAvailPos_t, 691
ParamPresenceMask, 691
Tlvresult, 691
unpack_loc_SLQSLOCGetServer
loc.h, 1166
unpack_loc_SLQSLOCGetServer_t
loc.h, 1153
unpack_loc_SLQSLOCInjectPosition
loc.h, 1166
unpack_loc_SLQSLOCInjectPosition_t
loc.h, 1153
unpack_loc_SLQSLOCInjectSensorData
loc.h, 1167
unpack_loc_SLQSLOCInjectSensorData_t
loc.h, 1153
unpack_loc_SLQSLOCInjectUTCTime
loc.h, 1167
unpack_loc_SLQSLOCInjectUTCTime_t
loc.h, 1153
unpack_loc_SLQSLOCSetCradleMountConfig
loc.h, 1167
unpack_loc_SLQSLOCSetCradleMountConfig_t
loc.h, 1153
unpack_loc_SLQSLOCSetServer
loc.h, 1168
unpack_loc_SensorStreamingCallback_Ind
loc.h, 1164
unpack_loc_SensorStreamingCallback_Ind_t, 686
pAccelAcceptReady, 687
pAccelTempAcceptReady, 687
pGyroAcceptReady, 687
pGyroTempAcceptReady, 687
ParamPresenceMask, 687
unpack_loc_SetExtPowerConfig_Ind
loc.h, 1164
unpack_loc_SetExtPowerConfig_Ind_t, 687
ParamPresenceMask, 688
status, 688
Tlvresult, 688
unpack_loc_SetExtPowerState
loc.h, 1164
unpack_loc_SetExtPowerState_t, 688
ParamPresenceMask, 688
Tlvresult, 688
unpack_loc_SetOperationMode
loc.h, 1165
unpack_loc_SetOperationMode_Ind
loc.h, 1165
unpack_loc_SetOperationMode_Ind_t, 689
ParamPresenceMask, 689
status, 689

Tlvresult, 689
unpack_loc_SetOperationMode_t, 689
ParamPresenceMask, 690
Tlvresult, 690
unpack_loc_SetServer_Ind
loc.h, 1165
unpack_loc_SetServer_Ind_t, 690
serverStatus, 690
Tlvresult, 690
unpack_loc_Start
loc.h, 1168
unpack_loc_Start_t, 691
ParamPresenceMask, 691
Tlvresult, 691
unpack_loc_Stop
loc.h, 1168
unpack_loc_Stop_t, 691
ParamPresenceMask, 692
Tlvresult, 692
unpack_nas_GetACCOLC
nas.h, 1201
unpack_nas_GetACCOLC_t, 692
pAccolc, 692
ParamPresenceMask, 692
unpack_nas_GetANAAAAuthenticationStatus
nas.h, 1201
unpack_nas_GetANAAAAuthenticationStatus_t, 692
pAuthStatus, 693
ParamPresenceMask, 693
unpack_nas_GetCDMANetworkParameters
nas.h, 1202
unpack_nas_GetCDMANetworkParameters_t, 693
Application, 695
Broadcast, 695
CustomSCP, 695
ForceRev0, 695
ParamPresenceMask, 695
Protocol, 695
RegForeignNID, 695
RegForeignSID, 695
RegHomeSID, 695
Roaming, 695
SCI, 695
SCM, 695
unpack_nas_GetHomeNetwork
nas.h, 1202
unpack_nas_GetHomeNetwork3GPP2
nas.h, 1203
unpack_nas_GetHomeNetwork3GPP2_t, 695
nameSize, 697
pMCC, 697
pMNC, 697
pNID, 697
pName, 697
pNw2DescDisp, 697
pNw2DescEnc, 698
pNw2DescLen, 698
pNw2MCC, 698
pNw2MNC, 698
pNw2Name, 698
pSID, 698
ParamPresenceMask, 697
unpack_nas_GetHomeNetwork_t, 698
mcc, 699
mnc, 699
name, 699
nid, 699
ParamPresenceMask, 699
sid, 699
unpack_nas_GetNetworkPreference
nas.h, 1203
unpack_nas_GetNetworkPreference_t, 699
ActiveTechPref, 700
Duration, 700
ParamPresenceMask, 700
PersistentTechPref, 700
Tlvresult, 700
unpack_nas_GetRFInfo
nas.h, 1203
unpack_nas_GetRFInfo_t, 700
instancesSize, 701
ParamPresenceMask, 701
RFBandInfoElements, 701
unpack_nas_GetServingNetwork
nas.h, 1204
unpack_nas_GetServingNetwork_t, 701
CSDomain, 703
DataCaps, 703
DataCapsLen, 703
MCC, 703
MNC, 703
Name, 703
nameSize, 704
PSDomain, 704
ParamPresenceMask, 704
RAN, 704
RadioIfaces, 704
RadioIfacesSize, 704
RegistrationState, 704
Roaming, 704
unpack_nas_GetServingNetworkCapabilities
nas.h, 1204
unpack_nas_GetServingNetworkCapabilities_t, 704
DataCaps, 705
DataCapsLen, 705
ParamPresenceMask, 705
unpack_nas_GetSignalStrengths
nas.h, 1204
unpack_nas_GetSignalStrengths_t, 705
len, 705
ParamPresenceMask, 705
radio, 705
rssi, 705
unpack_nas_InitiateDomainAttach
nas.h, 1205
unpack_nas_InitiateDomainAttach_t

nas.h, 1180
unpack_nas_PerformNetworkScan
nas.h, 1205
unpack_nas_PerformNetworkScan_t, 706
p3GppNetworkInfoInstances, 707
p3GppNetworkInstanceSize, 707
pPCIInfo, 707
pPCSInstance, 707
pPCSInstanceSize, 707
pRATINstance, 707
pRATInstanceSize, 707
pScanResult, 707
ParamPresenceMask, 707
unpack_nas_SLQSConfigSigInfo
nas.h, 1209
unpack_nas_SLQSConfigSigInfo_t
nas.h, 1180
unpack_nas_SLQSGetErrorRate
nas.h, 1209
unpack_nas_SLQSGetErrorRate_t, 712
pCDMAFrameErrRate, 713
pGSMBER, 713
pHDRPackErrRate, 713
pWCDMABER, 713
ParamPresenceMask, 713
unpack_nas_SLQSGetNetworkTime
nas.h, 1210
unpack_nas_SLQSGetNetworkTime_t, 714
p3GPP2TimeInfo, 714
p3GPPTimeInfo, 714
ParamPresenceMask, 714
unpack_nas_SLQSGetOperatorNameData
nas.h, 1210
unpack_nas_SLQSGetOperatorNameData_t, 714
pNITZInformation, 715
pOperatorNameString, 715
pOperatorPLMNList, 715
pPLMNNetworkName, 715
pSrvcProviderName, 715
ParamPresenceMask, 715
unpack_nas_SLQSGetPLMNName
nas.h, 1211
unpack_nas_SLQSGetPLMNName_t, 716
longName, 718
longNameCI, 718
longNameEn, 718
longNameLen, 718
longNameSB, 718
ParamPresenceMask, 718
shortName, 718
shortNameCI, 718
shortNameEn, 718
shortNameLen, 718
shortNameSB, 718
spn, 718
spnEncoding, 718
spnLength, 719
unpack_nas_SLQSGetServingSystem
nas.h, 1211
unpack_nas_SLQSGetServingSystem_t, 719
BasestationID, 722
BasestationLatitude, 722
BasestationLongitude, 722
CDMASystemInfoExt, 722
CallBarStatus, 722
CellID, 722
ConcSvcInfo, 723
CurrentPLMN, 723
DTMInd, 723
DataSrvCapabilities, 723
DefaultRoamInd, 723
DetailedSvcInfo, 723
Gpp2TimeZone, 723
GppNetworkDSTAdjustment, 723
GppTimeZone, 723
HdrPersonality, 723
Lac, 723
NetworkID, 723
PRLInd, 723
ParamPresenceMask, 723
RoamIndicatorVal, 723
RoamingIndicatorList, 723
ServingSystem, 723
SystemID, 723
TrackAreaCode, 723
unpack_nas_SLQSGetSignalStrength
nas.h, 1211
unpack_nas_SLQSGetSignalStrength_t, 723
ecioList, 725
ecioListLen, 725
errorRateList, 725
errorRateListLen, 725
Io, 725
ltersrp, 726
ltesnr, 726
ParamPresenceMask, 726
rsrqInfo, 726
rxSignalStrengthList, 726
rxSignalStrengthListLen, 726
signalStrengthReqMask, 726
sinr, 726
unpack_nas_SLQSGetSysInfo
nas.h, 1212
unpack_nas_SLQSGetSysInfo_t, 726
pAddCDMASysInfo, 729
pAddGSMSysInfo, 729
pAddHDRSysInfo, 729
pAddLTESysInfo, 729
pCDMASrvStatusInfo, 729
pCDMASysInfo, 729
pCampedCiotLteOpMode, 729
pGSMCallBarringSysInfo, 729
pGSMCipherDomainSysInfo, 729
pGSMSrvStatusInfo, 729
pGSMSysInfo, 729
pHDRSrvStatusInfo, 729

pHDRSysInfo, 729
pLTESrvStatusInfo, 729
pLTESysInfo, 729
pLTEVoiceSupportSysInfo, 729
pWCDMASysInfo, 730
ParamPresenceMask, 729
unpack_nas_SLQSGetSysSelectionPref
nas.h, 1212
unpack_nas_SLQSGetSysSelectionPref_t, 730
pBandPref, 734
pEmerMode, 734
pGWAcqOrderPref, 734
pLTEBandPref, 734
pModePref, 734
pNetSelPref, 734
pPRLPref, 734
pRoamPref, 734
pSrvDomainPref, 734
ParamPresenceMask, 734
unpack_nas_SLQSGetSysSelectionPrefExt
nas.h, 1213
unpack_nas_SLQSGetSysSelectionPrefExt_t, 734
pAcqOrderPref, 736
pBandPref, 736
pCiotAcqOrderPref, 736
pCiotLteOpModePref, 736
pEmerMode, 737
pGWAcqOrderPref, 737
pLTEBandPref, 737
pLteM1BandPref, 737
pLteNb1BandPref, 737
pModePref, 737
pNetSelPref, 737
pNr5gBandPref, 737
pPRLPref, 737
pRatDisabledMask, 737
pRoamPref, 737
pSrvDomainPref, 737
unpack_nas_SLQSInitiateNetworkRegistration
nas.h, 1213
unpack_nas_SLQSInitiateNetworkRegistration_t
nas.h, 1180
unpack_nas_SLQSNASGetForbiddenNetworks
nas.h, 1216
unpack_nas_SLQSNASGetForbiddenNetworks_t, 743
ParamPresenceMask, 744
unpack_nas_SLQSNASGeteDRXParams
nas.h, 1215
unpack_nas_SLQSNASGeteDRXParams_t, 741
pCycleLen, 742
pEdrxEnable, 742
ParamPresenceMask, 742
unpack_nas_SLQSNASGeteDRXParamsExt
nas.h, 1215
unpack_nas_SLQSNASGeteDRXParamsExt_t, 742
unpack_nas_SLQSNASSeteDRXParams
nas.h, 1219
unpack_nas_SLQSNASSeteDRXParams_t
nas.h, 1180
unpack_nas_SLQSNASSwiGetChannelLock
nas.h, 1219
unpack_nas_SLQSNASSwiGetChannelLock_t, 753
ParamPresenceMask, 753
unpack_nas_SLQSNASSwiSetChannelLock
nas.h, 1221
unpack_nas_SLQSNASSwiSetChannelLock_t
nas.h, 1180
unpack_nas_SLQSNasConfigSigInfo2
nas.h, 1213
unpack_nas_SLQSNasConfigSigInfo2_t
nas.h, 1180
unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind
nas.h, 1214
unpack_nas_SLQSNasEdrxChangeInfoCallBack_Ind_t, 737
unpack_nas_SLQSNasGet3GPP2Subscription
nas.h, 1214
unpack_nas_SLQSNasGet3GPP2Subscription_t, 738
pDirNum, 739
ParamPresenceMask, 739
unpack_nas_SLQSNasGetCellLocationInfo
nas.h, 1214
unpack_nas_SLQSNasGetCellLocationInfo_t, 739
pCDMAInfo, 741
pLTEInfoInterfreq, 741
pLTEInfoIntrafreq, 741
pUMTSInfo, 741
ParamPresenceMask, 740
unpack_nas_SLQSNasGetHDRColorCode
nas.h, 1216
unpack_nas_SLQSNasGetHDRColorCode_t, 744
pColorCode, 744
ParamPresenceMask, 744
unpack_nas_SLQSNasGetRFInfo
nas.h, 1216
unpack_nas_SLQSNasGetRFInfo_t, 744
pLTEOperationMode, 745
pRfBandInfoExtFormat, 745
pRfBandwidthInfo, 745
pRfDedicatedBandInfo, 745
rfbandInfoList, 745
Tlvresult, 745
unpack_nas_SLQSNasGetSigInfo
nas.h, 1217
unpack_nas_SLQSNasGetSigInfo_t, 745
CDMASSInfo, 746
GSMSSInfo, 746
HDRSSInfo, 746
LTESSInfo, 746
ParamPresenceMask, 746
unpack_nas_SLQSNasGetTxRxInfo
nas.h, 1217
unpack_nas_SLQSNasGetTxRxInfo_t, 746
pRXChain0Info, 747
pRXChain1Info, 747
pTXInfo, 747

ParamPresenceMask, 747
unpack_nas_SLQSNasIndicationRegisterExt
nas.h, 1217
unpack_nas_SLQSNasIndicationRegisterExt_t
nas.h, 1180
unpack_nas_SLQSNasNetworkRejectCallback_Ind
nas.h, 1218
unpack_nas_SLQSNasNetworkRejectCallback_Ind_t, 747
pCsgId, 750
pLteOpMode, 750
pPlmnId, 750
ParamPresenceMask, 750
radioIf, 750
rejectCause, 750
serviceDomain, 750
unpack_nas_SLQSNasNetworkTimeCallBack_ind
nas.h, 1218
unpack_nas_SLQSNasNetworkTimeCallBack_ind_t, 750
pDayltSavAdj, 751
pRadioInterface, 751
pTimeZone, 751
ParamPresenceMask, 751
universalTime, 751
unpack_nas_SLQSNasSigInfoCallback_ind
nas.h, 1219
unpack_nas_SLQSNasSigInfoCallback_ind_t, 751
pRscp, 752
ParamPresenceMask, 752
unpack_nas_SLQSNasSwiIndicationRegister
nas.h, 1220
unpack_nas_SLQSNasSwiIndicationRegister_t
nas.h, 1180
unpack_nas_SLQSNasSwiModemStatus
nas.h, 1220
unpack_nas_SLQSNasSwiModemStatus_t, 753
commonInfo, 754
pLTEInfo, 754
ParamPresenceMask, 754
unpack_nas_SLQSNasSwiOTAMessageCallback_ind
nas.h, 1220
unpack_nas_SLQSNasSwiOTAMessageCallback_ind_t, 754
Info, 755
Tlvresult, 755
unpack_nas_SLQSNasSysInfoCallback_ind
nas.h, 1221
unpack_nas_SLQSNasTimerCallback_ind
nas.h, 1221
unpack_nas_SLQSNasTimerCallback_ind_t, 755
ParamPresenceMask, 755
t3396_apn, 755
t3396_plmn_id, 755
t3396_val, 755
unpack_nas_SLQSSetBandPreference
nas.h, 1222
unpack_nas_SLQSSetBandPreference_t
nas.h, 1180
unpack_nas_SLQSSetSignalStrengthsCallback
nas.h, 1222
unpack_nas_SLQSSetSignalStrengthsCallback_t
nas.h, 1180
unpack_nas_SLQSSetSysSelectionPref
nas.h, 1222
unpack_nas_SLQSSetSysSelectionPref_t
nas.h, 1180
unpack_nas_SLQSSetSysSelectionPrefCallBack_ind
nas.h, 1223
unpack_nas_SLQSSetSysSelectionPrefCallBack_ind_t, 755
Info, 756
Tlvresult, 756
unpack_nas_SLQSSetSysSelectionPrefExt
nas.h, 1223
unpack_nas_SLQSSetSysSelectionPrefExt_t
nas.h, 1180
unpack_nas_SLQSSwiGetHDRPersonality
nas.h, 1223
unpack_nas_SLQSSwiGetHDRPersonality_t, 756
pCurrentPersonality, 757
pPersonalityListLength, 757
pProtocolSubtypeElement, 757
ParamPresenceMask, 757
unpack_nas_SLQSSwiGetHDRProtSubtype
nas.h, 1224
unpack_nas_SLQSSwiGetHDRProtSubtype_t, 757
pAppSubType, 758
pCurrentPrsnlty, 758
pPersonalityListLength, 758
ParamPresenceMask, 758
unpack_nas_SLQSSwiGetHRPDStats
nas.h, 1224
unpack_nas_SLQSSwiGetHRPDStats_t, 758
pPilotSetData, 759
pUATI, 759
ParamPresenceMask, 759
unpack_nas_SLQSSwiGetLteCQI
nas.h, 1224
unpack_nas_SLQSSwiGetLteCQI_t, 759
ParamPresenceMask, 760
ValidityCW0, 760
ValidityCW1, 760
unpack_nas_SLQSSwiGetLteSccRxInfo
nas.h, 1225
unpack_nas_SLQSSwiGetLteSccRxInfo_t, 760
pSccRxInfo, 760
ParamPresenceMask, 760
unpack_nas_SLQSSwiHDRPersonalityCallback_Ind
nas.h, 1225
unpack_nas_SLQSSwiHDRPersonalityCallback_Ind_t, 760
unpack_nas_SLQSSwiNetworkDebug
nas.h, 1225
unpack_nas_SLQSSwiNetworkDebug_t, 761
pDataStatusDetail, 762

pDeviceConfigDetail, 762
pNetworkStat1x, 762
pNetworkStatEVDO, 762
pObjectVer, 762
ParamPresenceMask, 762
unpack_nas_SLQSSwiPSDetach
nas.h, 1226
unpack_nas_SLQSSwiPSDetach_t
nas.h, 1180
unpack_nas_SLQSSwiRandIndicatorCallback_Ind
nas.h, 1226
unpack_nas_SLQSSwiRandIndicatorCallback_Ind_t, 762
ParamPresenceMask, 762
rankIndicatorTlv, 762
unpack_nas_SLQSSysInfoCallback_ind_t, 762
pGSMSysInfo, 765
pHDRSysInfo, 766
pLTESysInfo, 766
pSysInfoNoChange, 766
ParamPresenceMask, 765
unpack_nas_SetACCOLC
nas.h, 1205
unpack_nas_SetACCOLC_t
nas.h, 1180
unpack_nas_SetCDMANetworkParameters
nas.h, 1206
unpack_nas_SetCDMANetworkParameters_t
nas.h, 1180
unpack_nas_SetDataCapabilitiesCallback_ind
nas.h, 1206
unpack_nas_SetDataCapabilitiesCallback_ind_t, 707
dataCaps, 708
dataCapsSize, 708
ParamPresenceMask, 708
unpack_nas_SetEventReportInd
nas.h, 1206
unpack_nas_SetEventReportInd_t, 708
ParamPresenceMask, 709
RFTlv, 709
RRTlv, 709
SLQSSSTlv, 709
SSTlv, 709
unpack_nas_SetLURejectCallback
nas.h, 1207
unpack_nas_SetLURejectCallback_t
nas.h, 1180
unpack_nas_SetNasLTECphyCaIndCallback_ind
nas.h, 1207
unpack_nas_SetNasLTECphyCaIndCallback_ind_t, 709
ParamPresenceMask, 710
unpack_nas_SetNetworkPreference
nas.h, 1208
unpack_nas_SetNetworkPreference_t, 710
ParamPresenceMask, 710
Tlvresult, 711
unpack_nas_SetRFInfoCallback
nas.h, 1208
unpack_nas_SetRFInfoCallback_t
nas.h, 1180
unpack_nas_SetRoamingIndicatorCallback_ind
nas.h, 1208
unpack_nas_SetRoamingIndicatorCallback_ind_t, 711
ParamPresenceMask, 711
roaming, 711
unpack_nas_SetServingSystemCallback_ind
nas.h, 1209
unpack_nas_SetServingSystemCallback_ind_t, 711
ParamPresenceMask, 712
SSInfo, 712
Tlvresult, 712
unpack_nas_SlqsGetLTECphyCAInfo
nas.h, 1210
unpack_nas_SlqsGetLTECphyCAInfo_t, 713
LTECphyCaInfo, 714
ParamPresenceMask, 714
Tlvresult, 714
unpack_omaDmConfigTlv_t, 766
alertmsg, 767
alertmsglength, 767
state, 767
userInputReq, 767
userInputTimeout, 767
unpack_omaDmFotaTlv_t, 767
description, 768
descriptionlength, 768
fwdloadsize, 768
fwloadComplete, 768
namelength, 768
package_name, 768
sessionType, 768
severity, 768
state, 769
updateCompleteStatus, 769
userInputReq, 769
userInputTimeout, 769
version, 769
versionlength, 769
unpack_omaDmNotificationsTlv_t, 769
notification, 770
sessionStatus, 770
unpack_pds_ForceXTRADownload
pds.h, 1241
unpack_pds_ForceXTRADownload_t
pds.h, 1231
unpack_pds_GetPDSDefaults
pds.h, 1241
unpack_pds_GetPDSDefaults_t, 770
pAccuracy, 770
pInterval, 770
pOperation, 770
pTimeout, 771
ParamPresenceMask, 770
unpack_pds_GetPDSState
pds.h, 1242
unpack_pds_GetPDSState_t, 771

pEnabledStatus, 771
pTrackingStatus, 771
ParamPresenceMask, 771
unpack_pds_GetPortAutomaticTracking
pds.h, 1242
unpack_pds_GetPortAutomaticTracking_t, 771
ParamPresenceMask, 772
pbAuto, 772
unpack_pds_GetServiceAutomaticTracking
pds.h, 1242
unpack_pds_GetServiceAutomaticTracking_t, 772
ParamPresenceMask, 772
pbAuto, 772
unpack_pds_GetXTRAAutomaticDownload
pds.h, 1243
unpack_pds_GetXTRAAutomaticDownload_t, 773
pInterval, 773
ParamPresenceMask, 773
pbEnabled, 773
unpack_pds_GetXTRANetwork
pds.h, 1243
unpack_pds_GetXTRANetwork_t, 773
pPreference, 774
ParamPresenceMask, 774
unpack_pds_GetXTRAValidity
pds.h, 1244
unpack_pds_GetXTRAValidity_t, 774
pDuration, 775
pGPSWeek, 775
pGPSWeekOffset, 775
ParamPresenceMask, 774
unpack_pds_PDSInjectTimeReference
pds.h, 1244
unpack_pds_PDSInjectTimeReference_t
pds.h, 1231
unpack_pds_ResetPDSData
pds.h, 1244
unpack_pds_ResetPDSData_t
pds.h, 1231
unpack_pds_SLQSGetAGPSConfig
pds.h, 1248
unpack_pds_SLQSGetAGPSConfig_t, 777
pServerAddress, 778
pServerPort, 778
pServerURL, 778
ParamPresenceMask, 778
unpack_pds_SLQSGetGPSStateInfo
pds.h, 1248
unpack_pds_SLQSGetGPSStateInfo_t, 778
Altitude, 782
EngineState, 782
HorizontalUncertainty, 783
Iono_valid, 783
Latitude, 783
Longitude, 783
ParamPresenceMask, 783
Time_uncert_ms, 783
ValidMask, 783
VerticalUncertainty, 783
unpack_pds_SLQSPDSDeterminePosition
pds.h, 1248
unpack_pds_SLQSPDSDeterminePosition_t
pds.h, 1232
unpack_pds_SLQSPDSInjectAbsoluteTimeReference
pds.h, 1249
unpack_pds_SLQSPDSInjectAbsoluteTimeReference_t
pds.h, 1232
unpack_pds_SLQSPDSInjectPositionData
pds.h, 1249
unpack_pds_SLQSPDSInjectPositionData_t
pds.h, 1232
unpack_pds_SLQSSetAGPSConfig
pds.h, 1249
unpack_pds_SLQSSetAGPSConfig_t
pds.h, 1232
unpack_pds_SLQSSetPositionMethodState
pds.h, 1250
unpack_pds_SLQSSetPositionMethodState_t
pds.h, 1232
unpack_pds_SetEventReport_Ind
pds.h, 1245
unpack_pds_SetEventReport_Ind_t, 775
dLatitude, 776
dLongitude, 776
has_PositionDataNMEA, 776
has_SessionStatus, 776
has_dLatitude, 776
has_dLongitude, 776
has_posSrc, 776
ParamPresenceMask, 776
posSrc, 777
PositionDataNMEA, 776
SessionStatus, 777
unpack_pds_SetEventReportCallback
pds.h, 1245
unpack_pds_SetEventReportCallback_t
pds.h, 1231
unpack_pds_SetPDSDefaults
pds.h, 1245
unpack_pds_SetPDSDefaults_t
pds.h, 1231
unpack_pds_SetPDSState
pds.h, 1246
unpack_pds_SetPDSState_t
pds.h, 1231
unpack_pds_SetPdsState_Ind
pds.h, 1246
unpack_pds_SetPdsState_Ind_t, 777
EnabledStatus, 777
ParamPresenceMask, 777
TlvPresent, 777
TrackingStatus, 777
unpack_pds_SetPortAutomaticTracking
pds.h, 1246
unpack_pds_SetPortAutomaticTracking_t
pds.h, 1231

unpack_pds_SetServiceAutomaticTracking
pds.h, 1247
unpack_pds_SetServiceAutomaticTracking_t
pds.h, 1232
unpack_pds_SetXTRAAutomaticDownload
pds.h, 1247
unpack_pds_SetXTRAAutomaticDownload_t
pds.h, 1232
unpack_pds_SetXTRANetwork
pds.h, 1247
unpack_pds_SetXTRANetwork_t
pds.h, 1232
unpack_pds_StartPDSTrackingSessionExt
pds.h, 1250
unpack_pds_StartPDSTrackingSessionExt_t
pds.h, 1232
unpack_pds_StopPDSTrackingSession
pds.h, 1250
unpack_pds_StopPDSTrackingSession_t
pds.h, 1232
unpack_qmi_t, 783
msgid, 784
type, 784
xid, 784
unpack_qos_BindDataPort
qos.h, 1303
unpack_qos_BindDataPort_t, 784
ParamPresenceMask, 784
unpack_qos_IPv4Addr_t, 785
addr, 785
subnetMask, 785
unpack_qos_IPv6Addr_t, 785
addr, 786
prefixLen, 786
unpack_qos_IPv6TrafCls_t, 786
mask, 786
val, 786
unpack_qos_Port_t, 787
port, 787
range, 787
unpack_qos_QosFlowInfo_t, 787
BearerID, 788
is_RxQFlowGranted_Available, 788
is_TxQFlowGranted_Available, 788
NumRxFilters, 788
NumTxFilters, 788
QFlowState, 788
RxQFilter, 788
RxQFlowGranted, 789
TxQFilter, 789
TxQFlowGranted, 789
unpack_qos_QosFlowInfoState_t, 789
id, 789
isNewFlow, 789
state, 789
unpack_qos_SLQSQosGetNetworkStatus
qos.h, 1303
unpack_qos_SLQSQosGetNetworkStatus_t, 789
NWQoSStatus, 790
ParamPresenceMask, 790
unpack_qos_SLQSQosSwiReadApnExtraParams
qos.h, 1304
unpack_qos_SLQSQosSwiReadApnExtraParams_t, 790
ambr_dl, 791
ambr_dl_ext, 791
ambr_dl_ext2, 791
ambr_ul, 791
ambr_ul_ext, 791
ambr_ul_ext2, 791
apnId, 791
ParamPresenceMask, 791
unpack_qos_SLQSQosSwiReadDataStats
qos.h, 1304
unpack_qos_SLQSQosSwiReadDataStats_t, 791
apnId, 793
numQosFlow, 793
ParamPresenceMask, 793
qosFlow, 793
total_rx_bytes, 793
total_rx_pkt, 793
total_tx_bytes, 793
total_tx_pkt, 793
unpack_qos_SLQSSetQosEventCallback
qos.h, 1305
unpack_qos_SLQSSetQosEventCallback_ind
qos.h, 1305
unpack_qos_SLQSSetQosEventCallback_ind_t, 793
NumFlows, 793
ParamPresenceMask, 793
QosFlowInfo, 794
unpack_qos_SLQSSetQosEventCallback_t, 794
ParamPresenceMask, 794
unpack_qos_SLQSSetQosNWStatusCallback_ind
qos.h, 1306
unpack_qos_SLQSSetQosNWStatusCallback_ind_t, 794
status, 794
unpack_qos_SLQSSetQosPriEventCallback_ind
qos.h, 1306
unpack_qos_SLQSSetQosPriEventCallback_ind_t, 795
event, 795
ParamPresenceMask, 795
unpack_qos_SLQSSetQosStatusCallback_ind
qos.h, 1307
unpack_qos_SLQSSetQosStatusCallback_ind_t, 795
event, 796
id, 796
ParamPresenceMask, 796
reason, 796
status, 796
unpack_qos_Tos_t, 805
mask, 805
val, 805
unpack_qos_dataRate_t, 784
dataRateMax, 785

guaranteedRate, 785
unpack_qos_pktErrRate_t, 786
exponent, 787
multiplier, 787
unpack_qos_swiQosFilter_t, 797
EspSpi, 799
IPv4DstAddr, 799
IPv4SrcAddr, 799
IPv4Tos, 799
IPv6DstAddr, 799
IPv6Label, 799
IPv6SrcAddr, 799
IPv6TrafCls, 799
Id, 799
index, 799
is_EspSpi_Available, 799
is_IPv4DstAddr_Available, 799
is_IPv4SrcAddr_Available, 799
is_IPv4Tos_Available, 799
is_IPv6DstAddr_Available, 799
is_IPv6Label_Available, 799
is_IPv6SrcAddr_Available, 799
is_IPv6TrafCls_Available, 799
is_Id_Available, 799
is_NxtHdrProto_Available, 799
is_Precedence_Available, 799
is_TCPDstPort_Available, 799
is_TCPSrcPort_Available, 799
is_TranDstPort_Available, 800
is_TranSrcPort_Available, 800
is_UDPDstPort_Available, 800
is_UDPSrcPort_Available, 800
NxtHdrProto, 800
Precedence, 800
TCPDstPort, 800
TCPSrcPort, 800
TranDstPort, 800
TranSrcPort, 800
UDPDstPort, 800
UDPSrcPort, 800
version, 800
unpack_qos_swiQosFlow_t, 800
DataRate, 803
index, 803
is_DataRate_Available, 803
is_Jitter_Available, 803
is_Latency_Available, 803
is_LteQci_Available, 803
is_MaxAllowedPktSz_Available, 803
is_MinPolicedPktSz_Available, 803
is_PktErrRate_Available, 803
is_ProfileId3GPP2_Available, 803
is_TokenBucket_Available, 803
is_TrafficClass_Available, 803
is_val_3GPP2Pri_Available, 803
is_val_3GPPImCn_Available, 803
is_val_3GPPSigInd_Available, 803
Jitter, 803
Latency, 803
LteQci, 804
MaxAllowedPktSz, 804
MinPolicedPktSz, 804
PktErrRate, 804
ProfileId3GPP2, 804
TokenBucket, 804
TrafficClass, 804
val_3GPP2Pri, 804
val_3GPPImCn, 804
val_3GPPResResidualBER, 804
val_3GPPSigInd, 804
val_3GPPTraHdlPri, 804
unpack_qos_tokenBucket_t, 804
bucketSz, 804
peakRate, 804
tokenRate, 804
unpack_result_code_only
common.h, 1056
unpack_result_t, 806
ParamPresenceMask, 806
Tlvresult, 806
unpack_rms_GetSMSWake
rms.h, 1309
unpack_rms_GetSMSWake_t, 806
enabled, 807
ParamPresenceMask, 807
wake_mask, 807
unpack_rms_SetSMSWake
rms.h, 1309
unpack_rms_SetSMSWake_t, 807
ParamPresenceMask, 807
unpack_sar_SLQSGetRfSarState
sar.h, 1311
unpack_sar_SLQSGetRfSarState_t, 809
pSarRFState, 809
ParamPresenceMask, 809
unpack_sar_SLQSSetRfSarState
sar.h, 1311
unpack_sar_SLQSSetRfSarState_t
sar.h, 1310
unpack_sms_GetSMSCAddress
sms.h, 1324
unpack_sms_GetSMSCAddress_t, 809
addressSize, 810
pSMSCAddress, 810
pSMSCType, 810
ParamPresenceMask, 810
typeSize, 810
unpack_sms_SLQSDeleteSMS
sms.h, 1326
unpack_sms_SLQSDeleteSMS_t, 814
ParamPresenceMask, 814
unpack_sms_SLQSGetIndicationRegister
sms.h, 1326
unpack_sms_SLQSGetIndicationRegister_t, 814
pGetIndicationRegInfo, 815
ParamPresenceMask, 815

unpack_sms_SLQSGetMessageWaiting
sms.h, 1327
unpack_sms_SLQSGetMessageWaiting_t, 815
pGetMsgWaitingInfoResp, 815
ParamPresenceMask, 815
unpack_sms_SLQSGetSMS
sms.h, 1327
unpack_sms_SLQSGetSMS_t, 815
message, 816
messageFormat, 816
messageSize, 816
messageTag, 816
ParamPresenceMask, 816
unpack_sms_SLQSGetSMSList
sms.h, 1328
unpack_sms_SLQSGetSMSList_t, 817
messageList, 818
messageListSize, 818
ParamPresenceMask, 818
unpack_sms_SLQSGetSmsBroadcastConfig
sms.h, 1327
unpack_sms_SLQSGetSmsBroadcastConfig_t, 816
pBroadcastConfig, 817
pCDMABroadcastConfig, 817
ParamPresenceMask, 817
unpack_sms_SLQSGetTransLayerInfo
sms.h, 1328
unpack_sms_SLQSGetTransLayerInfo_t, 818
pGetTransLayerInfo, 818
ParamPresenceMask, 818
unpack_sms_SLQSGetTransNWRegInfo
sms.h, 1329
unpack_sms_SLQSGetTransNWRegInfo_t, 818
ParamPresenceMask, 819
unpack_sms_SLQSModifySMSStatus
sms.h, 1329
unpack_sms_SLQSModifySMSStatus_t, 819
ParamPresenceMask, 819
unpack_sms_SLQSNWRegInfoCallback_ind
sms.h, 1329
unpack_sms_SLQSNWRegInfoCallback_ind_t, 819
NWRegStat, 820
ParamPresenceMask, 820
unpack_sms_SLQSSendAsyncSMS
sms.h, 1330
unpack_sms_SLQSSendAsyncSMS_t, 820
ParamPresenceMask, 820
unpack_sms_SLQSSetIndicationRegister
sms.h, 1330
unpack_sms_SLQSSetIndicationRegister_t, 820
ParamPresenceMask, 821
unpack_sms_SLQSSetSmsBroadcastActivation
sms.h, 1330
unpack_sms_SLQSSetSmsBroadcastActivation_t, 821
ParamPresenceMask, 821
unpack_sms_SLQSSetSmsBroadcastConfig
sms.h, 1331
unpack_sms_SLQSSetSmsBroadcastConfig_t, 821
ParamPresenceMask, 822
unpack_sms_SLQSSetSmsStorage
sms.h, 1331
unpack_sms_SLQSSetSmsStorage_t, 822
ParamPresenceMask, 822
unpack_sms_SLQSSmsGetMaxStorageSize
sms.h, 1331
unpack_sms_SLQSSmsGetMaxStorageSize_t, 822
pMaxStorageSizeResp, 823
ParamPresenceMask, 822
unpack_sms_SLQSSmsGetMessageProtocol
sms.h, 1332
unpack_sms_SLQSSmsGetMessageProtocol_t, 823
pMessageProtocol, 823
ParamPresenceMask, 823
unpack_sms_SLQSSmsSetRoutes
sms.h, 1332
unpack_sms_SLQSSmsSetRoutes_t, 823
ParamPresenceMask, 823
unpack_sms_SLQSSwiGetSMSStorage
sms.h, 1332
unpack_sms_SLQSSwiGetSMSStorage_t, 824
pSmsStorage, 824
ParamPresenceMask, 824
unpack_sms_SLQSTransLayerInfoCallback_ind
sms.h, 1333
unpack_sms_SLQSTransLayerInfoCallback_ind_t, 824
pTransLayerInfo, 825
ParamPresenceMask, 825
regInd, 825
unpack_sms_SLQSWmsAsyncRawSendCallBack_ind
sms.h, 1333
unpack_sms_SLQSWmsAsyncRawSendCallBack_ind_t, 825
causeCode, 827
errorClass, 827
messageID, 827
RPCause, 827
sendStatus, 827
TPCause, 827
userData, 827
unpack_sms_SLQSWmsMemoryFullCallBack_ind
sms.h, 1334
unpack_sms_SLQSWmsMemoryFullCallBack_ind_t, 827
messageMode, 828
ParamPresenceMask, 828
storageType, 828
unpack_sms_SLQSWmsMessageWaitingCallBack_ind
sms.h, 1334
unpack_sms_SLQSWmsMessageWaitingCallBack_ind_t, 828
msgWaitInfo, 828
numInstances, 828
ParamPresenceMask, 828
unpack_sms_SaveSMS
sms.h, 1324
unpack_sms_SaveSMS_t, 810

pMessageIndex, 811
ParamPresenceMask, 811
unpack_sms_SendSMS
sms.h, 1325
unpack_sms_SendSMS_t, 811
messageFailureCode, 811
messageID, 811
ParamPresenceMask, 811
unpack_sms_SetNewSMSCallback
sms.h, 1325
unpack_sms_SetNewSMSCallback_ind
sms.h, 1325
unpack_sms_SetNewSMSCallback_ind_t, 811
ETWSTlv, 813
IMSTlv, 813
MMTlv, 813
NewMMTlv, 813
ParamPresenceMask, 813
SMSCTlv, 813
TRMessageTlv, 813
unpack_sms_SetNewSMSCallback_t, 813
ParamPresenceMask, 813
unpack_sms_SetSMSCAddress
sms.h, 1326
unpack_sms_SetSMSCAddress_t, 813
ParamPresenceMask, 814
unpack_swiaudio_SLQSGetM2MAVMute
swiaudio.h, 1341
unpack_swiaudio_SLQSGetM2MAVMute_t, 830
CwtMute, 831
EarMute, 831
MicMute, 831
ParamPresenceMask, 831
unpack_swiaudio_SLQSGetM2MAudioProfile
swiaudio.h, 1340
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 828
CwtMute, 829
EarMute, 829
Generator, 829
MicMute, 829
ParamPresenceMask, 830
Profile, 830
Volume, 830
unpack_swiaudio_SLQSGetM2MAudioVolume
swiaudio.h, 1341
unpack_swiaudio_SLQSGetM2MAudioVolume_t, 830
Level, 830
ParamPresenceMask, 830
unpack_swiaudio_SLQSGetM2MSpkrGain
swiaudio.h, 1341
unpack_swiaudio_SLQSGetM2MSpkrGain_t, 831
ParamPresenceMask, 832
Value, 832
unpack_swiaudio_SLQSSetM2MAVMute
swiaudio.h, 1343
unpack_swiaudio_SLQSSetM2MAVMute_t
swiaudio.h, 1336
unpack_swiaudio_SLQSSetM2MAudioAVCFG
swiaudio.h, 1342
unpack_swiaudio_SLQSSetM2MAudioAVCFG_t
swiaudio.h, 1336
unpack_swiaudio_SLQSSetM2MAudioLPBK
swiaudio.h, 1342
unpack_swiaudio_SLQSSetM2MAudioLPBK_t
swiaudio.h, 1336
unpack_swiaudio_SLQSSetM2MAudioNVDef
swiaudio.h, 1342
unpack_swiaudio_SLQSSetM2MAudioNVDef_t
swiaudio.h, 1336
unpack_swiaudio_SLQSSetM2MAudioProfile
swiaudio.h, 1343
unpack_swiaudio_SLQSSetM2MAudioProfile_t
swiaudio.h, 1336
unpack_swiaudio_SLQSSetM2MAudioVolume
swiaudio.h, 1343
unpack_swiaudio_SLQSSetM2MAudioVolume_t
swiaudio.h, 1336
unpack_swiaudio_SLQSSetM2MSpkrGain
swiaudio.h, 1344
unpack_swiaudio_SLQSSetM2MSpkrGain_t
swiaudio.h, 1336
unpack_swiavms_SLQSAVMSEventReportInd
swiavms.h, 1352
unpack_swiavms_SLQSAVMSEventReportInd_t, 832
pConfig, 833
pConnectionRequest, 833
pDataSessionStatus, 833
pNotification, 833
pPackageID, 833
pRegStatus, 833
pSessionType, 833
ParamPresenceMask, 833
resultcode, 833
unpack_swiavms_SLQSAVMSGetSettings
swiavms.h, 1353
unpack_swiavms_SLQSAVMSGetSettings_t, 833
AutoConnect, 835
AutoReboot, 835
FwAutoSDM, 835
FwPromptUpdate, 836
FwPromptdownload, 835
pAPNInfo, 836
pConnectionRetryTimers, 836
pNotificationStore, 836
pPeroidsInfo, 836
pPollingTimer, 836
ParamPresenceMask, 836
resultcode, 836
unpack_swiavms_SLQSAVMSGetSettings_v2
swiavms.h, 1353
unpack_swiavms_SLQSAVMSGetSettings_v2_t, 836
AutoConnect, 838
FwPromptUpdate, 838
FwPromptdownload, 838
pAutoReboot, 838
pNotificationStore, 838

pPeroidsInfo, 838
pPollingTimer, 838
ParamPresenceMask, 838
resultcode, 838
unpack_swiavms_SLQSAVMSSendSelection
swiavms.h, 1354
unpack_swiavms_SLQSAVMSSendSelection_t, 838
ParamPresenceMask, 839
resultcode, 839
unpack_swiavms_SLQSAVMSSessionGetInfo
swiavms.h, 1354
unpack_swiavms_SLQSAVMSSessionGetInfo_t, 839
pConfig, 839
pNotification, 840
pPackageID, 840
ParamPresenceMask, 839
resultcode, 840
unpack_swiavms_SLQSAVMSSetSettings
swiavms.h, 1355
unpack_swiavms_SLQSAVMSSetSettings_t, 840
ParamPresenceMask, 840
resultcode, 840
unpack_swiavms_SLQSAVMSSetSettings_v2
swiavms.h, 1356
unpack_swiavms_SLQSAVMSSetSettings_v2_t, 841
ParamPresenceMask, 841
resultcode, 841
unpack_swiavms_SLQSAVMSStartSession
swiavms.h, 1356
unpack_swiavms_SLQSAVMSStartSession_t, 841
ParamPresenceMask, 841
resultcode, 841
sessionResponse, 842
unpack_swiavms_SLQSAVMSStopSession
swiavms.h, 1357
unpack_swiavms_SLQSAVMSStopSession_avc2
swiavms.h, 1357
unpack_swiavms_SLQSAVMSStopSession_t, 842
ParamPresenceMask, 842
resultcode, 842
unpack_swiavms_SLQSAvmsSetEventReport
swiavms.h, 1355
unpack_swiavms_SLQSAvmsSetEventReport_t, 840
ParamPresenceMask, 840
resultcode, 840
unpack_swidms_SLQSSwiDmsGetMTU
swidms.h, 1362
unpack_swidms_SLQSSwiDmsGetMTU_t, 842
pMTUSize3gpp, 843
ParamPresenceMask, 843
unpack_swidms_SLQSSwiDmsGetUsbComp
swidms.h, 1363
unpack_swidms_SLQSSwiDmsGetUsbComp_t, 843
pInterfaceCfg, 844
pSupportedBitmasks, 844
ParamPresenceMask, 843
unpack_swidms_SLQSSwiDmsGetUsbNetNum
swidms.h, 1363
unpack_swidms_SLQSSwiDmsGetUsbNetNum_t, 844
ParamPresenceMask, 844
usbNetNum, 844
unpack_swidms_SLQSSwiDmsSetMTU
swidms.h, 1363
unpack_swidms_SLQSSwiDmsSetMTU_t, 844
ParamPresenceMask, 845
Tlvresult, 845
unpack_swidms_SLQSSwiDmsSetUsbComp
swidms.h, 1364
unpack_swidms_SLQSSwiDmsSetUsbComp_t, 845
ParamPresenceMask, 845
Tlvresult, 845
unpack_swidms_SLQSSwiDmsSetUsbNetNum
swidms.h, 1364
unpack_swidms_SLQSSwiDmsSetUsbNetNum_t
swidms.h, 1360
unpack_swiloc_SwiLocGetAutoStart
swiloc.h, 1366
unpack_swiloc_SwiLocGetAutoStart_t, 845
fix_rate, 847
fix_rate_reported, 847
fix_type, 847
fix_type_reported, 847
function, 847
function_reported, 847
max_dist, 847
max_dist_reported, 847
max_time, 847
max_time_reported, 847
ParamPresenceMask, 847
unpack_swiloc_SwiLocSetAutoStart
swiloc.h, 1366
unpack_swiloc_SwiLocSetAutoStart_t
swiloc.h, 1365
unpack_swioma_SLQSOMADMAlertCallback
swioma.h, 1372
unpack_swioma_SLQSOMADMAlertCallback_ind
swioma.h, 1373
unpack_swioma_SLQSOMADMAlertCallback_ind_t, 847
eventType, 848
unpack_swioma_SLQSOMADMAlertCallback_t
swioma.h, 1368
unpack_swioma_SLQSOMADMCancelSession
swioma.h, 1373
unpack_swioma_SLQSOMADMCancelSession_t
swioma.h, 1368
unpack_swioma_SLQSOMADMCancelSessionExt
swiomaext.h, 1379
unpack_swioma_SLQSOMADMCancelSessionExt_t
swiomaext.h, 1377
unpack_swioma_SLQSOMADMGetSessionInfo
swioma.h, 1374
unpack_swioma_SLQSOMADMGetSessionInfo_t, 848
Date, 850
DateLength, 850
ParamPresenceMask, 851

PkgDescLength, 851
PkgDescription, 851
PkgName, 851
PkgNameLength, 851
RetryCount, 851
SessionState, 851
SessionType, 851
Severity, 851
Source, 851
SourceLength, 851
Status, 851
Time, 851
TimeLength, 851
UpdateCompleteStatus, 851
unpack_swioma_SLQSOMADMGetSettings
swioma.h, 1374
unpack_swioma_SLQSOMADMGetSettings_t, 851
Autosdm, 852
FOTAdownload, 852
FwAutoCheck, 852
ParamPresenceMask, 853
unpack_swioma_SLQSOMADMSendSelection
swioma.h, 1375
unpack_swioma_SLQSOMADMSendSelection_t
swioma.h, 1368
unpack_swioma_SLQSOMADMSendSelectionExt
swiomaext.h, 1380
unpack_swioma_SLQSOMADMSendSelectionExt_t
swiomaext.h, 1377
unpack_swioma_SLQSOMADMSetSettings
swioma.h, 1375
unpack_swioma_SLQSOMADMSetSettings_t
swioma.h, 1368
unpack_swioma_SLQSOMADMSetSettingsExt
swiomaext.h, 1380
unpack_swioma_SLQSOMADMSetSettingsExt_t
swiomaext.h, 1377
unpack_swioma_SLQSOMADMStartSession
swioma.h, 1375
unpack_swioma_SLQSOMADMStartSession_t, 853
FwAvailability, 853
ParamPresenceMask, 853
unpack_swioma_SLQSOMADMStartSessionExt
swiomaext.h, 1381
unpack_swioma_SLQSOMADMStartSessionExt_t
swiomaext.h, 1377
unpack_tmd_SLQSTmdDeRegNotMitigationLvl
tmd.h, 1385
unpack_tmd_SLQSTmdDeRegNotMitigationLvl_t, 853
ParamPresenceMask, 854
Tlvresult, 854
unpack_tmd_SLQSTmdGetMitigationDevList
tmd.h, 1385
unpack_tmd_SLQSTmdGetMitigationDevList_t, 854
MitigationDevList, 854
MitigationDevListLen, 854
ParamPresenceMask, 855
Tlvresult, 855
unpack_tmd_SLQSTmdGetMitigationLvl
tmd.h, 1386
unpack_tmd_SLQSTmdGetMitigationLvl_t, 855
CurrentmitigationLvl, 855
ParamPresenceMask, 855
ReqMitigationLvl, 855
Tlvresult, 855
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind
tmd.h, 1386
unpack_tmd_SLQSTmdMitigationLvlRptCallback_ind_t,
855
deviceID, 856
deviceIdLen, 856
lvl, 856
ParamPresenceMask, 856
unpack_tmd_SLQSTmdRegNotMitigationLvl
tmd.h, 1387
unpack_tmd_SLQSTmdRegNotMitigationLvl_t, 856
ParamPresenceMask, 857
Tlvresult, 857
unpack_uim_ChangePin
uim.h, 1398
unpack_uim_ChangePin_t, 857
pEncryptedPIN1, 857
pIndicationToken, 857
pRemainingRetries, 857
ParamPresenceMask, 857
Tlvresult, 858
unpack_uim_GetCardStatus
uim.h, 1398
unpack_uim_GetCardStatus_t, 858
pCardStatus, 858
pHotSwapStatus, 858
ParamPresenceMask, 858
Tlvresult, 858
unpack_uim_ReadTransparent
uim.h, 1399
unpack_uim_ReadTransparent_t, 858
pCardResult, 859
pEncryptedData, 859
pIndicationToken, 859
pReadResult, 859
ParamPresenceMask, 859
Tlvresult, 859
unpack_uim_SLQSUIMAuthenticate
uim.h, 1400
unpack_uim_SLQSUIMAuthenticate_t, 861
pAuthenticateResult, 861
pCardResult, 862
pIndicationToken, 862
ParamPresenceMask, 861
unpack_uim_SLQSUIMDepersonalization
uim.h, 1400
unpack_uim_SLQSUIMDepersonalization_t, 862
pRemainingRetries, 862
ParamPresenceMask, 862
unpack_uim_SLQSUIMEventRegister
uim.h, 1401

unpack_uim_SLQSUIMEventRegister_t, 862
eventMask, 863
ParamPresenceMask, 863
unpack_uim_SLQSUIMGetConfiguration
uim.h, 1401
unpack_uim_SLQSUIMGetConfiguration_t, 863
pAutoSelection, 864
pHaltSubscription, 864
pPersonalizationStatus, 864
ParamPresenceMask, 863
unpack_uim_SLQSUIMGetFileAttributes
uim.h, 1401
unpack_uim_SLQSUIMGetFileAttributes_t, 864
pCardResult, 864
pFileAttributes, 864
pIndicationToken, 864
ParamPresenceMask, 864
unpack_uim_SLQSUIMGetSlotsStatus
uim.h, 1402
unpack_uim_SLQSUIMGetSlotsStatus_t, 864
pNumberOfPhySlot, 865
pUimSlotsStatus, 865
ParamPresenceMask, 865
unpack_uim_SLQSUIMPowerDown
uim.h, 1402
unpack_uim_SLQSUIMPowerDown_t
uim.h, 1390
unpack_uim_SLQSUIMPowerUp
uim.h, 1402
unpack_uim_SLQSUIMPowerUp_t
uim.h, 1390
unpack_uim_SLQSUIMRefreshCallback_Ind
uim.h, 1403
unpack_uim_SLQSUIMRefreshCallback_Ind_t, 865
ParamPresenceMask, 866
refreshEvent, 866
TlvPresent, 866
unpack_uim_SLQSUIMRefreshComplete
uim.h, 1403
unpack_uim_SLQSUIMRefreshComplete_t
uim.h, 1390
unpack_uim_SLQSUIMRefreshGetLastEvent
uim.h, 1404
unpack_uim_SLQSUIMRefreshGetLastEvent_t, 866
pRefreshEvent, 866
ParamPresenceMask, 866
unpack_uim_SLQSUIMRefreshOK
uim.h, 1404
unpack_uim_SLQSUIMRefreshOK_t
uim.h, 1391
unpack_uim_SLQSUIMRefreshRegister
uim.h, 1404
unpack_uim_SLQSUIMRefreshRegister_t
uim.h, 1391
unpack_uim_SLQSUIMReset
uim.h, 1405
unpack_uim_SLQSUIMReset_t
uim.h, 1391
unpack_uim_SLQSUIMSetStatusChangeCallBack_ind
uim.h, 1405
unpack_uim_SLQSUIMSetStatusChangeCallBack_ind_t, 866
unpack_uim_SLQSUIMSwitchSlot
uim.h, 1405
unpack_uim_SLQSUIMSwitchSlot_t
uim.h, 1391
unpack_uim_SetPinProtection
uim.h, 1399
unpack_uim_SetPinProtection_t, 859
pEncryptedPIN1, 860
pIndicationToken, 860
pRemainingRetries, 860
ParamPresenceMask, 860
Tlvresult, 860
unpack_uim_SetUimSlotStatusChangeCallback_ind
uim.h, 1400
unpack_uim_SetUimSlotStatusChangeCallback_ind_t, 860
bNumberOfPhySlots, 861
ParamPresenceMask, 861
slotsstatusChange, 861
unpack_uim_UnblockPin
uim.h, 1406
unpack_uim_UnblockPin_t, 867
pEncryptedPIN1, 867
pIndicationToken, 868
pRemainingRetries, 868
ParamPresenceMask, 867
Tlvresult, 868
unpack_uim_VerifyPin
uim.h, 1406
unpack_uim_VerifyPin_t, 868
pEncryptedPIN1, 868
pIndicationToken, 868
pRemainingRetries, 868
ParamPresenceMask, 868
Tlvresult, 868
unpack_valid_nas_GetCDMANetworkParameters
nas.h, 1226
unpack_valid_nas_SLQSGetServingSystem
nas.h, 1227
unpack_valid_nas_SLQSGetSignalStrength
nas.h, 1228
unpack_valid_nas_SLQSNasGetSigInfo
nas.h, 1228
unpack_voice_AnswerUSSD
voice.h, 1425
unpack_voice_AnswerUSSD_t
voice.h, 1412
unpack_voice_CancelUSSD
voice.h, 1425
unpack_voice_CancelUSSD_t
voice.h, 1412
unpack_voice_DTMFEventCallback_ind
voice.h, 1425
unpack_voice_DTMFEventCallback_ind_t, 871

DTMFInformation, 871
pOffLength, 871
pOnLength, 871
ParamPresenceMask, 871
unpack_voice_OTASPStatusCallback_ind
voice.h, 1426
unpack_voice_OTASPStatusCallback_ind_t, 872
callID, 873
OTASPStatus, 873
ParamPresenceMask, 873
unpack_voice_OriginateUSSD
voice.h, 1426
unpack_voice_OriginateUSSD_t
voice.h, 1412
unpack_voice_SLQSOriginateUSSD
voice.h, 1426
unpack_voice_SLQSOriginateUSSD_t, 873
pAlphaIDInfo, 875
pCCSuppsType, 875
pCallId, 875
pCcResultType, 875
pUSSDInfo, 875
ParamPresenceMask, 875
pfailureCause, 875
unpack_voice_SLQSVoiceALSSelectLine
voice.h, 1427
unpack_voice_SLQSVoiceALSSelectLine_t
voice.h, 1412
unpack_voice_SLQSVoiceALSSetLineSwitching
voice.h, 1427
unpack_voice_SLQSVoiceALSSetLineSwitching_t
voice.h, 1412
unpack_voice_SLQSVoiceAnswerCall
voice.h, 1428
unpack_voice_SLQSVoiceAnswerCall_t, 875
pCallId, 876
ParamPresenceMask, 876
unpack_voice_SLQSVoiceBindSubscription
voice.h, 1428
unpack_voice_SLQSVoiceBindSubscription_t
voice.h, 1412
unpack_voice_SLQSVoiceBurstDTMF
voice.h, 1428
unpack_voice_SLQSVoiceBurstDTMF_t, 876
pCallID, 876
ParamPresenceMask, 876
unpack_voice_SLQSVoiceDialCall
voice.h, 1429
unpack_voice_SLQSVoiceDialCall_t, 876
pAlphaIDInfo, 877
pCCResultType, 877
pCCSUPSType, 877
pCallID, 877
ParamPresenceMask, 877
unpack_voice_SLQSVoiceEndCall
voice.h, 1429
unpack_voice_SLQSVoiceEndCall_t, 877
pCallId, 878
ParamPresenceMask, 878
unpack_voice_SLQSVoiceGetAllCallInfo
voice.h, 1429
unpack_voice_SLQSVoiceGetAllCallInfo_t, 878
pArrAlertingPattern, 881
pArrAlertingType, 881
pArrAlphaID, 881
pArrCallEndReason, 881
pArrCallInfo, 881
pArrCalledPartyNum, 881
pArrConnectPartyNum, 881
pArrDiagInfo, 881
pArrRedirPartyNum, 881
pArrRemotePartyName, 881
pArrRemotePartyNum, 881
pArrSvcOption, 881
pArrUUSInfo, 881
pVoicePrivacy, 881
ParamPresenceMask, 881
unpack_voice_SLQSVoiceGetCLIP
voice.h, 1431
unpack_voice_SLQSVoiceGetCLIP_t, 889
pAlphaIDInfo, 890
pCCResType, 890
pCallID, 890
pFailCause, 891
ParamPresenceMask, 890
unpack_voice_SLQSVoiceGetCLIR
voice.h, 1431
unpack_voice_SLQSVoiceGetCLIR_t, 891
pAlphaIDInfo, 892
pCCResType, 892
pCallID, 892
pFailCause, 892
ParamPresenceMask, 892
unpack_voice_SLQSVoiceGetCNAP
voice.h, 1432
unpack_voice_SLQSVoiceGetCNAP_t, 892
pAlphaIDInfo, 893
pCCResType, 893
pCallID, 893
pFailCause, 893
ParamPresenceMask, 893
unpack_voice_SLQSVoiceGetCOLP
voice.h, 1432
unpack_voice_SLQSVoiceGetCOLP_t, 894
pAlphaIDInfo, 895
pCCResType, 895
pCallID, 895
pFailCause, 895
ParamPresenceMask, 895
unpack_voice_SLQSVoiceGetCOLR
voice.h, 1432
unpack_voice_SLQSVoiceGetCOLR_t, 895
pAlphaIDInfo, 896
pCCResType, 896
pCallID, 896
pFailCause, 896

ParamPresenceMask, 896
unpack_voice_SLQSVoiceGetCallBarring
voice.h, 1430
unpack_voice_SLQSVoiceGetCallBarring_t, 882
pAlphaIDInfo, 883
pCCResType, 883
pCallID, 883
pFailCause, 883
pSvcClass, 883
ParamPresenceMask, 883
unpack_voice_SLQSVoiceGetCallForwardingStatus
voice.h, 1430
unpack_voice_SLQSVoiceGetCallForwardingStatus_t, 883
pAlphaIDInfo, 884
pCCResType, 884
pCallID, 884
pFailCause, 884
ParamPresenceMask, 884
unpack_voice_SLQSVoiceGetCallInfo
voice.h, 1430
unpack_voice_SLQSVoiceGetCallInfo_t, 885
pAlertType, 887
pAlertingPattern, 887
pAlphaIDInfo, 887
pCallInfo, 887
pConnectNumInfo, 887
pDiagInfo, 887
pOTASPStatus, 887
pRemotePartyName, 887
pRemotePartyNum, 887
pSrvOpt, 887
pUUSInfo, 888
pVoicePrivacy, 888
ParamPresenceMask, 887
unpack_voice_SLQSVoiceGetCallWaiting
voice.h, 1431
unpack_voice_SLQSVoiceGetCallWaiting_t, 888
pAlphaIDInfo, 889
pCCResType, 889
pCallID, 889
pFailCause, 889
pSvcClass, 889
ParamPresenceMask, 889
unpack_voice_SLQSVoiceGetConfig
voice.h, 1433
unpack_voice_SLQSVoiceGetConfig_t, 896
pAirTimerCnt, 898
pAutoAnswerStat, 898
pCurAMRConfig, 898
pCurPrefVoiceSO, 898
pCurVoiceDomainPref, 898
pCurVoicePrivacyPref, 898
pCurrTTYMode, 898
pRoamTimerCnt, 898
ParamPresenceMask, 898
unpack_voice_SLQSVoiceIndicationRegister
voice.h, 1433
unpack_voice_SLQSVoiceIndicationRegister_t
voice.h, 1412
unpack_voice_SLQSVoiceManageCalls
voice.h, 1433
unpack_voice_SLQSVoiceManageCalls_t, 898
pFailCause, 899
ParamPresenceMask, 899
unpack_voice_SLQSVoiceOrigUSSDNoWait
voice.h, 1434
unpack_voice_SLQSVoiceOrigUSSDNoWait_t
voice.h, 1412
unpack_voice_SLQSVoiceSUPSCallback_ind
voice.h, 1436
unpack_voice_SLQSVoiceSUPSCallback_ind_t, 905
pDataSrc, 908
pFailCause, 908
pReason, 908
pSvcClass, 908
ParamPresenceMask, 907
unpack_voice_SLQSVoiceSendFlash
voice.h, 1434
unpack_voice_SLQSVoiceSendFlash_t, 899
pCallID, 899
ParamPresenceMask, 899
unpack_voice_SLQSVoiceSetCallBarringPassword
voice.h, 1434
unpack_voice_SLQSVoiceSetCallBarringPassword_t, 900
pAlphaIDInfo, 901
pCCResType, 901
pCallID, 901
pFailCause, 901
ParamPresenceMask, 901
unpack_voice_SLQSVoiceSetConfig
voice.h, 1435
unpack_voice_SLQSVoiceSetConfig_t, 901
pAirTimerStatus, 902
pAutoAnsStatus, 902
pPrefVoiceSOStatus, 902
pRoamTimerStatus, 902
pTTYConfigStatus, 902
pVoiceDomainPrefStatus, 902
ParamPresenceMask, 902
unpack_voice_SLQSVoiceSetPreferredPrivacy
voice.h, 1435
unpack_voice_SLQSVoiceSetPreferredPrivacy_t
voice.h, 1412
unpack_voice_SLQSVoiceSetSUPSService
voice.h, 1435
unpack_voice_SLQSVoiceSetSUPSService_t, 903
pCallID, 904
pFailCause, 904
ParamPresenceMask, 904
unpack_voice_SLQSVoiceStartContDTMF
voice.h, 1436
unpack_voice_SLQSVoiceStartContDTMF_t, 904
pCallID, 904
ParamPresenceMask, 904

unpack_voice_SLQSVoiceStopContDTMF
voice.h, 1436
unpack_voice_SLQSVoiceStopContDTMF_t, 904
callID, 905
ParamPresenceMask, 905
unpack_voice_SUPSNotificationCallback_ind
voice.h, 1437
unpack_voice_SUPSNotificationCallback_ind_t, 908
callID, 910
notifType, 910
pCUGIndex, 910
pECTNum, 910
ParamPresenceMask, 910
unpack_voice_USSDNotificationCallback_ind
voice.h, 1437
unpack_voice_USSDNotificationCallback_ind_t, 910
notification_Type, 910
ParamPresenceMask, 910
unpack_voice_VoiceInfoRecCallback_ind
voice.h, 1437
unpack_voice_VoiceInfoRecCallback_ind_t, 910
callID, 913
pCLIRCause, 913
pCallWaitInd, 913
pCalledPartyInfo, 913
pCallerIDInfo, 913
pCallerNameInfo, 913
pCallingPartyInfo, 913
pConnectNumInfo, 913
pDispInfo, 913
pExtDispInfo, 913
pExtDispRecInfo, 913
pLineCtrlInfo, 913
pNSSAudioCtrl, 913
pNSSRelease, 913
pRedirNumInfo, 913
pSignalInfo, 913
ParamPresenceMask, 913
unpack_voice_allCallStatusCallback_ind
voice.h, 1424
unpack_voice_allCallStatusCallback_ind_t, 869
arrCallInfomation, 870
pArrAlertingPattern, 870
pArrAlertingType, 870
pArrAlphaID, 870
pArrCallEndReason, 870
pArrCalledPartyNum, 870
pArrConnectPartyNum, 870
pArrDiagInfo, 870
pArrRedirPartyNum, 870
pArrRemotePartyName, 870
pArrRemotePartyNum, 870
pArrSvcOption, 870
ParamPresenceMask, 870
unpack_voice_voicePrivacyChangeCallback_ind
voice.h, 1438
unpack_voice_voicePrivacyChangeCallback_ind_t, 913
callID, 914
ParamPresenceMask, 914
voicePrivacy, 914
unpack_wds_DHCPv4ClientLease_ind
wds.h, 1467
unpack_wds_DHCPv4ClientLease_ind_t, 914
DHCPv4LeaseOptTlv, 915
DHCPv4LeaseStateTlv, 915
IPv4AddrTlv, 915
ParamPresenceMask, 915
ProfileIdTlv, 915
unpack_wds_DHCPv4ClientLeaseChange
wds.h, 1467
unpack_wds_DHCPv4ClientLeaseChange_t
wds.h, 1446
unpack_wds_GetAutoconnect
wds.h, 1468
unpack_wds_GetAutoconnect_t, 915
ParamPresenceMask, 915
psetting, 915
unpack_wds_GetByteTotals
wds.h, 1468
unpack_wds_GetByteTotals_t, 915
pRXTotalBytes, 916
pTXTotalBytes, 916
ParamPresenceMask, 916
unpack_wds_GetConnectionRate
wds.h, 1468
unpack_wds_GetConnectionRate_t, 916
currentChannelRXRate, 917
currentChannelTXRate, 917
maxChannelRXRate, 917
maxChannelTXRate, 917
ParamPresenceMask, 917
unpack_wds_GetDataBearerTechnology
wds.h, 1469
unpack_wds_GetDataBearerTechnology_t, 917
pDataBearer, 918
ParamPresenceMask, 918
unpack_wds_GetDefaultProfile
wds.h, 1469
unpack_wds_GetDefaultProfile_t, 918
apnname, 920
apnsize, 920
auth, 920
ipaddr, 920
ipaddrv6, 921
name, 921
namesize, 921
ParamPresenceMask, 921
pdptype, 921
pridns, 921
pridnsv6, 921
secdns, 921
secdnsv6, 921
username, 921
usersize, 921
unpack_wds_GetDefaultProfileNum
wds.h, 1469

unpack_wds_GetDefaultProfileNum_t, 921
index, 921
ParamPresenceMask, 921
unpack_wds_GetDormancyState
wds.h, 1470
unpack_wds_GetDormancyState_t, 921
dormancyState, 922
ParamPresenceMask, 922
unpack_wds_GetLastMobileIPError
wds.h, 1470
unpack_wds_GetLastMobileIPError_t, 922
error, 922
ParamPresenceMask, 923
unpack_wds_GetMobileIP
wds.h, 1471
unpack_wds_GetMobileIP_t, 923
mipMode, 923
ParamPresenceMask, 923
unpack_wds_GetMobileIPProfile
wds.h, 1471
unpack_wds_GetMobileIPProfile_t, 923
AAASPI, 925
AAAState, 925
address, 925
enabled, 925
HASPI, 925
HAState, 925
NAI, 925
naiSize, 925
ParamPresenceMask, 925
primaryHA, 925
revTunneling, 925
secondaryHA, 925
unpack_wds_GetPacketStatistics
wds.h, 1471
unpack_wds_GetPacketStatistics_t, 925
pRXDroppedCount, 927
pRXOKBytesLastCall, 927
pRXOkBytesCount, 927
pRXPacketErrors, 927
pRXPacketOverflows, 927
pRXPacketSuccesses, 927
pTXDroppedCount, 927
pTXOKBytesLastCall, 927
pTXOkBytesCount, 927
pTXPacketErrors, 927
pTXPacketOverflows, 927
pTXPacketSuccesses, 927
ParamPresenceMask, 927
unpack_wds_GetPacketStatus
wds.h, 1472
unpack_wds_GetPacketStatus_t, 927
ParamPresenceMask, 929
rXDroppedCount, 929
rXOKBytesLastCall, 929
rXOkBytesCount, 929
rXPacketErrors, 929
rXPacketOverflows, 929
rXPacketSuccesses, 929
tXDroppedCount, 929
tXOKBytesLastCall, 929
tXOkBytesCount, 929
tXPacketErrors, 929
tXPacketOverflows, 929
tXPacketSuccesses, 929
unpack_wds_GetSessionDuration
wds.h, 1472
unpack_wds_GetSessionDuration_t, 929
callDuration, 930
ParamPresenceMask, 930
unpack_wds_GetSessionState
wds.h, 1472
unpack_wds_GetSessionState_t, 930
connectionStatus, 930
ParamPresenceMask, 930
unpack_wds_RMSetTransferStatistics
wds.h, 1473
unpack_wds_RMSetTransferStatistics_t, 930
ParamPresenceMask, 931
unpack_wds_RMTransferStatistics_ind
wds.h, 1473
unpack_wds_SLQSCreateProfile
wds.h, 1476
unpack_wds_SLQSCreateProfile_t, 931
pCreateProfileOut, 932
pProfileID, 932
ParamPresenceMask, 932
Tlvresult, 932
unpack_wds_SLQSDUNCallInfoCallBack_ind
wds.h, 1476
unpack_wds_SLQSDUNCallInfoCallBack_ind_t, 933
unpack_wds_SLQSDeleteProfile
wds.h, 1476
unpack_wds_SLQSDeleteProfile_t, 932
extendedErrorCode, 932
ParamPresenceMask, 932
unpack_wds_SLQSGet3GPPConfigItem
wds.h, 1477
unpack_wds_SLQSGet3GPPConfigItem_t, 934
_3gppRelease, 935
defaultPDNEnabled, 935
LTEAttachProfile, 935
ParamPresenceMask, 936
profileList, 936
unpack_wds_SLQSGetCurrDataSystemStat
wds.h, 1477
unpack_wds_SLQSGetCurrDataSystemStat_t, 936
currNetworkInfo, 936
networkInfoLen, 936
ParamPresenceMask, 936
prefNetwork, 937
unpack_wds_SLQSGetCurrentChannelRate
wds.h, 1477
unpack_wds_SLQSGetCurrentChannelRate_t, 937
max_channel_rx_rate, 938
max_channel_tx_rate, 938

ParamPresenceMask, 938
unpack_wds_SLQSGetDUNCallInfo
wds.h, 1478
unpack_wds_SLQSGetDUNCallInfo_t, 939
callEndReason, 941
channelRate, 941
connectionStatus, 941
dataBearerTech, 941
dormancyStatus, 941
lastCallDataBearerTech, 941
mdmCallDurationActive, 942
ParamPresenceMask, 942
rxOKBytesCount, 942
txOKBytesCount, 942
unpack_wds_SLQSGetDataBearerTechnology
wds.h, 1478
unpack_wds_SLQSGetDataBearerTechnology_t, 938
curDataBearerTechnology, 938
dataBearerMask, 938
lastCallDataBearerTechnology, 939
ParamPresenceMask, 939
unpack_wds_SLQSGetProfileSettings
wds.h, 1478
unpack_wds_SLQSGetProfileSettings_t, 942
pProfileSettings, 942
ParamPresenceMask, 942
ProfileType, 942
Tlvresult, 942
unpack_wds_SLQSGetRuntimeSettings
wds.h, 1479
unpack_wds_SLQSGetRuntimeSettings_t, 942
APNName, 945
Authentication, 945
DomainList, 945
GPRSGrantedQoS, 945
GWAddressV4, 945
IMCNflag, 945
IPFamilyPreference, 945
IPV6AddrInfo, 945
IPV6GWAddrInfo, 945
IPv4, 945
Mtu, 945
PDPType, 945
ParamPresenceMask, 945
PrimaryDNSV4, 945
PrimaryDNSV6, 945
ProfileID, 945
ProfileName, 945
SecondaryDNSV4, 945
SecondaryDNSV6, 945
ServerAddrList, 945
SubnetMaskV4, 945
Technology, 945
UMTSGrantedQoS, 946
Username, 946
unpack_wds_SLQSModifyProfile
wds.h, 1479
unpack_wds_SLQSModifyProfile_t, 946
pExtErrorCode, 946
ParamPresenceMask, 946
unpack_wds_SLQSResetPacketStatics
wds.h, 1479
unpack_wds_SLQSResetPacketStatics_t
wds.h, 1447
unpack_wds_SLQSSGetDHCPv4ClientConfig
wds.h, 1481
unpack_wds_SLQSSGetDHCPv4ClientConfig_t, 954
pHwConfig, 955
ParamPresenceMask, 955
unpack_wds_SLQSSGetLoopback
wds.h, 1482
unpack_wds_SLQSSGetLoopback_t, 955
ByteLoopbackMode, 956
ByteLoopbackMultiplier, 956
ParamPresenceMask, 956
unpack_wds_SLQSSSetDHCPv4ClientConfig
wds.h, 1482
unpack_wds_SLQSSSetDHCPv4ClientConfig_t
wds.h, 1447
unpack_wds_SLQSSSetLoopback
wds.h, 1482
unpack_wds_SLQSSSetLoopback_t
wds.h, 1447
unpack_wds_SLQSSet3GPPConfigItem
wds.h, 1480
unpack_wds_SLQSSet3GPPConfigItem_t
wds.h, 1447
unpack_wds_SLQSSetIPFamilyPreference
wds.h, 1480
unpack_wds_SLQSSetIPFamilyPreference_t, 946
ParamPresenceMask, 947
Tlvresult, 947
unpack_wds_SLQSSetPacketSrvStatusCallback
wds.h, 1480
unpack_wds_SLQSSetPacketSrvStatusCallback_t, 947
bearerID, 948
conn_status, 948
ipFamily, 949
ParamPresenceMask, 949
reconfigReqd, 949
sessionEndReason, 949
techName, 949
verboseSessnEndReason, 949
verboseSessnEndReasonType, 949
unpack_wds_SLQSSetWdsEventCallback
wds.h, 1481
unpack_wds_SLQSSetWdsEventCallback_ind
wds.h, 1481
unpack_wds_SLQSSetWdsEventCallback_ind_t, 949
currDBTechAvail, 953
currNWInfo, 953
dBTechAvail, 953
dBTechnology, 954
dBtechExtAvail, 953
dBtechnologyExt, 954
dataSysStatAvail, 953

dormancyStatAvail, 954
dormancyStatus, 954
mipStatus, 954
mipstatAvail, 954
netInfoLen, 954
ParamPresenceMask, 954
prefNetwork, 954
ratMask, 954
rx_bytes, 954
rx_pkts, 954
soMask, 954
tx_bytes, 954
tx_pkts, 954
xferStatAvail, 954
unpack_wds_SLQSSetWdsEventCallback_t
wds.h, 1447
unpack_wds_SLQSStartDataSession
wds.h, 1483
unpack_wds_SLQSStartDataSession_t, 956
pFailureReason, 956
pVerboseFailReasonType, 957
pVerboseFailureReason, 957
ParamPresenceMask, 956
psid, 956
unpack_wds_SLQSStopDataSession
wds.h, 1483
unpack_wds_SLQSStopDataSession_t
wds.h, 1447
unpack_wds_SLQSWdsGoActive
wds.h, 1483
unpack_wds_SLQSWdsGoActive_t
wds.h, 1447
unpack_wds_SLQSWdsGoDormant
wds.h, 1484
unpack_wds_SLQSWdsGoDormant_t
wds.h, 1447
unpack_wds_SLQSWdsSetEventReport
wds.h, 1484
unpack_wds_SLQSWdsSetEventReport_t
wds.h, 1447
unpack_wds_SLQSWdsSwiPDPRuntimeSettings
wds.h, 1484
unpack_wds_SLQSWdsSwiPDPRuntimeSettings_t, 957
apnName, 959
bearerId, 959
contextId, 959
ipv4Address, 959
ipv4GWAddress, 959
ipv6Address, 959
ipv6GWAddress, 959
ParamPresenceMask, 959
unpack_wds_SetAutoconnect
wds.h, 1473
unpack_wds_SetAutoconnect_t
wds.h, 1446
unpack_wds_SetDefaultProfile
wds.h, 1474
unpack_wds_SetDefaultProfile_t
wds.h, 1446
unpack_wds_SetDefaultProfileNum
wds.h, 1474
unpack_wds_SetDefaultProfileNum_t
wds.h, 1446
unpack_wds_SetMobileIP
wds.h, 1474
unpack_wds_SetMobileIP_t
wds.h, 1446
unpack_wds_SetMobileIPParameters
wds.h, 1475
unpack_wds_SetMobileIPParameters_t
wds.h, 1446
unpack_wds_SetMobileIPProfile
wds.h, 1475
unpack_wds_SetMobileIPProfile_t, 931
ParamPresenceMask, 931
unpack_wds_SetMuxID
wds.h, 1475
unpack_wds_SetMuxID_t
wds.h, 1446
UnpackQmiProfileInfo
wds.h, 1447
UnpackSwiAvmsEventReportBinaryUpdateSessionInfo, 960
bBinaryType, 961
bSerity, 961
bState, 961
bUserInputRequest, 961
szDescription, 961
szName, 961
szVersion, 961
TlvPresent, 961
ulPkgDownloadComplete, 961
ulPkgDownloadSize, 962
wDescriptionLength, 962
wNameLength, 962
wUpdateCompeteStatus, 962
wUserInputTimeout, 962
wVersionLength, 962
UnpackSwiAvmsEventReportConfig, 962
bState, 962
bUserInputRequest, 962
szAlertMsg, 962
TlvPresent, 963
wAlertMsgLength, 963
wUserInputTimeout, 963
UnpackSwiAvmsEventReportConnectionRequest, 963
bUserInputRequest, 963
TlvPresent, 963
wUserInputTimeout, 963
UnpackSwiAvmsEventReportDataSessionStatus, 963
bType, 964
TlvPresent, 964
wErrorCode, 964
UnpackSwiAvmsEventReportHTTPStatus, 964
TlvPresent, 965

wHTTPStatus, 965
UnpackSwiAvmsEventReportNotification, 966
bNotification, 966
TlvPresent, 967
wSessionStatus, 967
UnpackSwiAvmsEventReportPackageID, 967
bPackageID, 967
TlvPresent, 967
UnpackSwiAvmsEventReportRegStatus, 967
bRegStatus, 967
TlvPresent, 967
UnpackSwiAvmsEventReportSessionType, 968
bType, 968
TlvPresent, 968
UnpackSwiAvmsEventReportWAMSParamChange, 968
TlvPresent, 969
wWamsChangeMask, 969
unpackWdsProfileParam, 969
SlqsProfile3GPP, 969
SlqsProfile3GPP2, 969
upLink
voice_NSSAudioCtrl, 1006
UpdateCompleteStatus
unpack_swioma_SLQSOMADMGetSessionInfo_t, 851
updateCompleteStatus
unpack_omaDmFotaTlv_t, 769
upinRetries
slotInf, 514
uim_slotInfo, 563
upinState
slotInf, 514
uim_slotInfo, 563
upukRetries
slotInf, 514
uim_slotInfo, 563
urlAddr
loc_URLAddrInfo, 141
usageMask
loc_sensorDataUsage, 138
UsbMTUSize
swidms_usbMTUSizeTlv, 538
usbNetNum
unpack_swidms_SLQSSwiDmsGetUsbNetNum_t, 844
userData
unpack_sms_SLQSWmsAsyncRawSendCallBack-_ind_t, 827
userInputReq
unpack_omaDmConfigTlv_t, 767
unpack_omaDmFotaTlv_t, 769
userInputTimeout
unpack_omaDmConfigTlv_t, 767
unpack_omaDmFotaTlv_t, 769
Username
unpack_wds_SLQSGetRuntimeSettings_t, 946
username
unpack_wds_GetDefaultProfile_t, 921
usersize
unpack_wds_GetDefaultProfile_t, 921
ussDCS
pack_voice_SLQSOriginateUSSD_t, 458
voice_USSInfo, 1016
ussData
pack_voice_SLQSOriginateUSSD_t, 458
voice_USSInfo, 1016
ussLen
pack_voice_SLQSOriginateUSSD_t, 458
voice_USSInfo, 1016
UtRat
unpack_imsa_SLQSImsaSvcStatusCallBack_ind_-t, 662
UtRatVal
imsa_UtRatInfo, 89
UtService
unpack_imsa_SLQSImsaSvcStatusCallBack_ind_-t, 662
UtServiceRat
unpack_imsa_SLQSGetIMSAServiceStatus_t, 658
UtServiceStatus
unpack_imsa_SLQSGetIMSAServiceStatus_t, 658
UtSvcStatus
imsa_UtSvcStatusInfo, 89
uusInfo
voice_allCallsUUSInfo, 971

VDOP
loc_precisionDilution, 135
val
unpack_qos_IPv6TrafCls_t, 786
unpack_qos_Tos_t, 805
val_3GPP2Pri
unpack_qos_swiQosFlow_t, 804
val_3GPPImCn
unpack_qos_swiQosFlow_t, 804
val_3GPPResResidualBER
unpack_qos_swiQosFlow_t, 804
val_3GPPSigInd
unpack_qos_swiQosFlow_t, 804
val_3GPPTraHdlPri
unpack_qos_swiQosFlow_t, 804
ValidBitmasks
swidms_supportedIntBitmaskTlv, 537
ValidMask
unpack_pds_SLQSGetGPSStateInfo_t, 783
validMask
loc_satelliteInfo, 137
ValidityCW0
unpack_nas_SLQSSwiGetLteCQI_t, 760
ValidityCW1
unpack_nas_SLQSSwiGetLteCQI_t, 760
Value
pack_swiaudio_SLQSSetM2MSpkrGain_t, 428
unpack_swiaudio_SLQSGetM2MSpkrGain_t, 832
value
pack_dms_UIMSetPINProtection_t, 332
pack_dms_UIMVerifyPIN_t, 334

value_length
DMScustSettingInfo, 62
pack_dms_SetCustFeaturesV2_t, 322
verboseSessnEndReason
unpack_wds_SLQSSetPacketSrvStatusCallback_t, 949
verboseSessnEndReasonType
unpack_wds_SLQSSetPacketSrvStatusCallback_t, 949
verifyLeft
uim_personalizationStatus, 555
uim_remainingRetries, 559
verifyPIN
pack_uim_VerifyPin_t, 456
verifyRetriesLeft
unpack_dms_UIMGetControlKeyStatus_t, 632
unpack_dms_UIMSetControlKeyProtection_t, 636
unpack_dms_UIMSetPINProtection_t, 636
version
unpack_omaDmFotaTlv_t, 769
unpack_qos_swiQosFilter_t, 800
versionString
pack_dms_SLQSSwiSetOSInfo_t, 328
unpack_dms_SLQSSwiGetOSInfo_t, 627
versionlength
unpack_omaDmFotaTlv_t, 769
vertConfidence
pack_loc_SLQSLOCInjectPosition_t, 354
vertReliability
pack_loc_SLQSLOCInjectPosition_t, 354
vertUnc
pack_loc_SLQSLOCInjectPosition_t, 354
VerticalUncertainty
unpack_pds_SLQSGetGPSStateInfo_t, 783
VirtStream
nas_protocolSubtypeElement, 240
voice.h
LITE_VOICE_SUPS_SRV_CLASS_DATA, 1413
LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITASYNC, 1413
LITE_VOICE_SUPS_SRV_CLASS_DATACIRCUITSYNC, 1413
LITE_VOICE_SUPS_SRV_CLASS_FAX, 1413
LITE_VOICE_SUPS_SRV_CLASS_NONE, 1413
LITE_VOICE_SUPS_SRV_CLASS_PACKETACCESS, 1413
LITE_VOICE_SUPS_SRV_CLASS_PADACCESS, 1413
LITE_VOICE_SUPS_SRV_CLASS_SMS, 1413
LITE_VOICE_SUPS_SRV_CLASS_VOICE, 1413
voice.h, 1406
liteServiceClassInformation, 1412
MAXVOICEUSSDLENGTH, 1412
pack_voice_AnswerUSSD, 1413
pack_voice_CancelUSSD, 1413
pack_voice_OriginateUSSD, 1414
pack_voice_SLQSOriginateUSSD, 1414
pack_voice_SLQSVoiceALSSelectLine, 1414
pack_voice_SLQSVoiceALSSetLineSwitching, 1415
pack_voice_SLQSVoiceAnswerCall, 1415
pack_voice_SLQSVoiceBindSubscription, 1415
pack_voice_SLQSVoiceBurstDTMF, 1416
pack_voice_SLQSVoiceDialCall, 1416
pack_voice_SLQSVoiceEndCall, 1416
pack_voice_SLQSVoiceGetAllCallInfo, 1417
pack_voice_SLQSVoiceGetCLIP, 1419
pack_voice_SLQSVoiceGetCLIR, 1419
pack_voice_SLQSVoiceGetCNAP, 1419
pack_voice_SLQSVoiceGetCOLP, 1420
pack_voice_SLQSVoiceGetCOLR, 1420
pack_voice_SLQSVoiceGetCallBarring, 1417
pack_voice_SLQSVoiceGetCallForwardingStatus, 1418
pack_voice_SLQSVoiceGetCallInfo, 1418
pack_voice_SLQSVoiceGetCallWaiting, 1418
pack_voice_SLQSVoiceGetConfig, 1420
pack_voice_SLQSVoiceIndicationRegister, 1421
pack_voice_SLQSVoiceManageCalls, 1421
pack_voice_SLQSVoiceOrigUSSDNoWait, 1421
pack_voice_SLQSVoiceSendFlash, 1422
pack_voice_SLQSVoiceSetCallBarringPassword, 1422
pack_voice_SLQSVoiceSetConfig, 1422
pack_voice_SLQSVoiceSetPreferredPrivacy, 1423
pack_voice_SLQSVoiceSetSUPSService, 1423
pack_voice_SLQSVoiceStartContDTMF, 1424
pack_voice_SLQSVoiceStopContDTMF, 1424
unpack_voice_AnswerUSSD, 1425
unpack_voice_AnswerUSSD_t, 1412
unpack_voice_CancelUSSD, 1425
unpack_voice_CancelUSSD_t, 1412
unpack_voice_DTMFEventCallback_ind, 1425
unpack_voice_OTASPStatusCallback_ind, 1426
unpack_voice_OriginateUSSD, 1426
unpack_voice_OriginateUSSD_t, 1412
unpack_voice_SLQSOriginateUSSD, 1426
unpack_voice_SLQSVoiceALSSelectLine, 1427
unpack_voice_SLQSVoiceALSSelectLine_t, 1412
unpack_voice_SLQSVoiceALSSetLineSwitching, 1427
unpack_voice_SLQSVoiceALSSetLineSwitching_t, 1412
unpack_voice_SLQSVoiceAnswerCall, 1428
unpack_voice_SLQSVoiceBindSubscription, 1428
unpack_voice_SLQSVoiceBindSubscription_t, 1412
unpack_voice_SLQSVoiceBurstDTMF, 1428
unpack_voice_SLQSVoiceDialCall, 1429
unpack_voice_SLQSVoiceEndCall, 1429
unpack_voice_SLQSVoiceGetAllCallInfo, 1429
unpack_voice_SLQSVoiceGetCLIP, 1431
unpack_voice_SLQSVoiceGetCLIR, 1431
unpack_voice_SLQSVoiceGetCNAP, 1432
unpack_voice_SLQSVoiceGetCOLP, 1432
unpack_voice_SLQSVoiceGetCOLR, 1432

unpack_voice_SLQSVoiceGetCallBarring, 1430
unpack_voice_SLQSVoiceGetCallForwarding-Status, 1430
unpack_voice_SLQSVoiceGetCallInfo, 1430
unpack_voice_SLQSVoiceGetCallWaiting, 1431
unpack_voice_SLQSVoiceGetConfig, 1433
unpack_voice_SLQSVoiceIndicationRegister, 1433
unpack_voice_SLQSVoiceIndicationRegister_t, 1412
unpack_voice_SLQSVoiceManageCalls, 1433
unpack_voice_SLQSVoiceOrigUSSDNoWait, 1434
unpack_voice_SLQSVoiceOrigUSSDNoWait_t, 1412
unpack_voice_SLQSVoiceSUPSCallback_ind, 1436
unpack_voice_SLQSVoiceSendFlash, 1434
unpack_voice_SLQSVoiceSetCallBarringPassword, 1434
unpack_voice_SLQSVoiceSetConfig, 1435
unpack_voice_SLQSVoiceSetPreferredPrivacy, 1435
unpack_voice_SLQSVoiceSetPreferredPrivacy_t, 1412
unpack_voice_SLQSVoiceSetSUPSService, 1435
unpack_voice_SLQSVoiceStartContDTMF, 1436
unpack_voice_SLQSVoiceStopContDTMF, 1436
unpack_voice_SUPSNotificationCallback_ind, 1437
unpack_voice_USSDNotificationCallback_ind, 1437
unpack_voice_VoiceInfoRecCallback_ind, 1437
unpack_voice_allCallStatusCallback_ind, 1424
unpack_voice_voicePrivacyChangeCallback_ind, 1438
voice_CLIPResp, 992
ActiveStatus, 992
ProvisionStatus, 992
voice_CLIRResp, 992
ActiveStatus, 993
ProvisionStatus, 993
voice_CNAPResp, 993
ActiveStatus, 994
ProvisionStatus, 994
voice_COLPResp, 994
ActiveStatus, 994
ProvisionStatus, 994
voice_COLRResp, 994
ActiveStatus, 995
ProvisionStatus, 995
voice_CUGInfo, 997
CUGIndex, 997
SuppOA, 997
SuppPrefCUG, 997
voice_DTMFInfo, 999
callID, 999
DTMFEvent, 999
digitBuff, 999
digitCnt, 999
voice_DTMFLengths, 999
DTMFInterdigitInterval, 1000
DTMFPulseWidth, 1000
voice_ECTNum, 1000
ECTCallState, 1001
number, 1001
presentationInd, 1001
voice_NSSAudioCtrl, 1006
downLink, 1006
upLink, 1006
voice_SUPSInfo, 1015
isModByCC, 1015
svcType, 1015
voice_USSDNotificationNetworkInfo, 1015
networkInfo, 1016
tlvPresent, 1016
voice_USSInfo, 1016
ussDCS, 1016
ussData, 1016
ussLen, 1016
voice_UUSInfo, 1016
UUSData, 1017
UUSDatalen, 1017
UUSDcs, 1017
UUSType, 1017
voice_airTimer, 969
airTimerValue, 970
namID, 970
voice_allCallsAlphaIDInfo, 970
AlphaIDInfo, 970
callID, 970
voice_allCallsDiagInfo, 970
callID, 971
DiagInfo, 971
voice_allCallsUUSInfo, 971
callID, 971
uusInfo, 971
voice_alphaIDInfo, 971
alphaDcs, 972
alphaLen, 972
alphaText, 972
voice_arrAlertingPattern, 972
alertingPattern, 973
callID, 973
numInstances, 973
voice_arrAlertingType, 973
AlertingType, 974
callID, 974
numInstances, 974
voice_arrAlphaID, 974
allCallsAlphaIDInfoArr, 974
numInstances, 974
voice_arrCallEndReason, 975
callEndReason, 975
callID, 975
numInstances, 976
voice_arrCallInfo, 976
getAllCallInfo, 976

numInstances, 976
voice_arrCalledPartyNum, 974
CalledPartyNum, 975
numInstances, 975
voice_arrConnectPartyNum, 976
ConnectedPartyNum, 977
numInstances, 977
voice_arrDiagInfo, 977
DiagInfo, 977
numInstances, 977
voice_arrRedirPartyNum, 977
numInstances, 978
RedirPartyNum, 978
voice_arrRemotePartyName, 978
GetAllCallRmtPtyName, 978
numInstances, 978
voice_arrRemotePartyNum, 978
numInstances, 979
RmtPtyNum, 979
voice_arrSvcOption, 979
callID, 979
numInstances, 979
srvOption, 979
voice_arrUUSInfo, 979
AllCallsUUSInfo, 980
numInstances, 980
voice_burstDTMFInfo, 980
digitCnt, 981
pCallID, 981
pDigitBuff, 981
voice_callFWExtInfo, 985
noReplyTimer, 986
numLen, 986
numPlan, 987
numType, 987
number, 986
PI, 987
SI, 987
SvcClass, 987
SvcStatus, 987
voice_callFWInfo, 987
noReplyTimer, 987
numLen, 988
number, 987
SvcClass, 988
SvcStatus, 988
voice_callFwdTypeAndPlan, 984
numberPlan, 985
numberType, 985
voice_callInfo, 988
callID, 989
callState, 989
callType, 989
direction, 989
mode, 989
voice_calledPartyInfo, 981
numLen, 982
numPlan, 982
numType, 982
number, 982
PI, 982
SI, 982
voice_calledPartySubAdd, 982
extBit, 983
oddEvenInd, 983
subAddr, 983
subAddrLen, 983
subAddrType, 983
voice_callerIDInfo, 983
callerID, 984
callerIDLen, 984
PI, 984
voice_callingPartyInfo, 989
numLen, 991
numPlan, 991
numType, 991
number, 991
PI, 991
SI, 991
voice_ccSUPSType, 991
reason, 991
svcType, 992
voice_connectNumInfo, 995
callerID, 996
callerIDLen, 996
numPlan, 996
numPresInd, 996
numType, 997
screeningInd, 997
voice_curAMRConfig, 997
gsmAmrStat, 998
wcdmaAmrStat, 998
voice_diagInfo, 998
diagInfoLen, 998
diagnosticInfo, 998
voice_extDispRecInfo, 1001
dispType, 1001
extDispInfo, 1001
extDispInfoLen, 1001
voice_getAllCallInformation, 1002
ALS, 1002
Callinfo, 1002
isEmpty, 1002
voice_getAllCallRmtPtyName, 1002
callID, 1003
RemotePartyName, 1003
voice_getAllCallRmtPtyNum, 1003
callID, 1003
RemotePartyNum, 1003
voice_getCallFWExtInfo, 1003
CallFWExtInfo, 1004
numInstances, 1004
voice_getCallFWInfo, 1004
CallFWInfo, 1004
numInstances, 1004
voice_lineCtrlInfo, 1004

polarityIncluded, 1005
pwrDenialTime, 1005
revPolarity, 1005
toggleMode, 1005
voice_newPwdData, 1005
newPwd, 1006
newPwdAgain, 1006
voice_peerNumberInfo, 1006
callID, 1007
numLen, 1008
numPI, 1008
numPlan, 1008
numSI, 1008
numType, 1008
number, 1008
voice_prefVoiceSO, 1008
evrcCapability, 1010
homeOrigVoiceSO, 1010
homePageVoiceSO, 1010
namID, 1010
roamOrigVoiceSO, 1010
voice_redirNumInfo, 1010
numLen, 1011
numPlan, 1011
numType, 1011
number, 1011
PI, 1011
reason, 1011
SI, 1011
voice_remotePartyName, 1012
callerName, 1012
codingScheme, 1012
nameLen, 1012
namePI, 1012
voice_remotePartyNum, 1012
numLen, 1013
presentationInd, 1013
remPartyNumber, 1013
voice_roamTimer, 1013
namID, 1014
roamTimerValue, 1014
voice_signalInfo, 1014
alertPitch, 1014
signal, 1014
signalType, 1014
VoiceNumber
unpack_dms_GetVoiceNumber_t, 599
voiceNumberSize
unpack_dms_GetVoiceNumber_t, 599
voicePrivacy
unpack_voice_voicePrivacyChangeCallback_ind_t, 914
voiceSvc
pack_voice_SLQSVoiceSetSUPSService_t, 474
VoipRat
unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t, 662
VoipRatVal
imsa_VoipRatInfo, 90
VoipService
unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t, 662
VoipServiceRat
unpack_imsa_SLQSGetIMSAServiceStatus_t, 658
VoipServiceStatus
unpack_imsa_SLQSGetIMSAServiceStatus_t, 658
VoipSvcStatus
imsa_VoipSvcStatusInfo, 90
VolValue
pack_audio_SLQSSetAudioVolTLBConfig_t, 314
VoltStat
dms_VoltageTlv, 61
VoltTlv
unpack_dms_SwiEventReportCallBack_ind_t, 630
Voltage
dms_VoltageTlv, 61
Volume
pack_audio_SLQSGetAudioVolTLBConfig_t, 310
pack_audio_SLQSSetAudioProfile_t, 313
pack_audio_SLQSSetAudioVolTLBConfig_t, 314
unpack_audio_SLQSGetAudioProfile_t, 569
unpack_swiaudio_SLQSGetM2MAudioProfile_t, 830
voteForInit
uim_registerRefresh, 559
VsServiceRat
unpack_imsa_SLQSGetIMSAServiceStatus_t, 658
VsServiceStatus
unpack_imsa_SLQSGetIMSAServiceStatus_t, 658
VtRat
unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t, 662
VtRatVal
imsa_VtRatInfo, 91
VtService
unpack_imsa_SLQSImsaSvcStatusCallBack_ind_t, 662
VtServiceRat
unpack_imsa_SLQSGetIMSAServiceStatus_t, 658
VtServiceStatus
unpack_imsa_SLQSGetIMSAServiceStatus_t, 658
VtSvcStatus
imsa_VtSvcStatusInfo, 91

wAlertMsgLength
UnpackSwiAvmsEventReportConfig, 963
WCDMACellInfo
nas_lteWcdmaCellInfo, 217
WCDMAECIOThreshListLen
nas_WCDMAECIOThresh, 284
WCDMARSSIThreshListLen
nas_WCDMARSSIThresh, 286
WCDMASSInfo
unpack_nas_SLQSNasGetSigInfo_t, 746
WDS_PROFILE_3GPP
wds.h, 1446
WDS_PROFILE_3GPP2

wds.h, 1446
wDescriptionLength
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 962
wErrorCode
UnpackSwiAvmsEventReportDataSessionStatus, 964
wHTTPStatus
UnpackSwiAvmsEventReportHTTPStatus, 965
wNameLength
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 962
WORD
SwiDataTypes.h, 1359
wSessionStatus
UnpackSwiAvmsEventReportNotification, 967
wUpdateCompeteStatus
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 962
wUserInputTimeout
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 962
UnpackSwiAvmsEventReportConfig, 963
UnpackSwiAvmsEventReportConnectionRequest, 963
wVersionLength
UnpackSwiAvmsEventReportBinaryUpdate-SessionInfo, 962
wWamsChangeMask
UnpackSwiAvmsEventReportWAMSParam-Change, 969
wake_mask
pack_rms_SetSMSWake_t, 412
unpack_rms_GetSMSWake_t, 807
wcdmaAmrStat
voice_curAMRConfig, 998
wcdmaRRCState
nas_WCDMAInfoLTENeighborCell, 285
Wdisable
unpack_dms_SLQSDmsSwiGetPCInfo_t, 609
wds.h
QMI_LITE_WDS_CURRENT_CALL_DB_MASK, 1447
QMI_LITE_WDS_LAST_CALL_DB_MASK, 1447
wds.h, 1438
BYT_STAT_STAT_MASK, 1446
liteQmiDataBearerMasks, 1447
PACK_WDS_IPV4, 1446
PACK_WDS_IPV6, 1446
pack_wds_DHCPv4ClientLeaseChange, 1447
pack_wds_GetAutoconnect, 1448
pack_wds_GetByteTotals, 1448
pack_wds_GetConnectionRate, 1449
pack_wds_GetDataBearerTechnology, 1449
pack_wds_GetDefaultProfile, 1449
pack_wds_GetDefaultProfileNum, 1450
pack_wds_GetDormancyState, 1450
pack_wds_GetLastMobileIPError, 1451
pack_wds_GetMobileIP, 1451
pack_wds_GetMobileIPProfile, 1452
pack_wds_GetPacketStatistics, 1452
pack_wds_GetPacketStatus, 1452
pack_wds_GetSessionDuration, 1453
pack_wds_GetSessionState, 1453
pack_wds_RMSetTransferStatistics, 1454
pack_wds_SLQSCreateProfile, 1457
pack_wds_SLQSDeleteProfile, 1457
pack_wds_SLQSGet3GPPConfigItem, 1458
pack_wds_SLQSGetCurrDataSystemStat, 1458
pack_wds_SLQSGetCurrentChannelRate, 1459
pack_wds_SLQSGetDUNCallInfo, 1460
pack_wds_SLQSGetDataBearerTechnology, 1459
pack_wds_SLQSGetProfileSettings, 1460
pack_wds_SLQSGetRuntimeSettings, 1460
pack_wds_SLQSModifyProfile, 1461
pack_wds_SLQSResetPacketStatics, 1461
pack_wds_SLQSSGetDHCPv4ClientConfig, 1463
pack_wds_SLQSSGetLoopback, 1463
pack_wds_SLQSSSetDHCPv4ClientConfig, 1464
pack_wds_SLQSSSetLoopback, 1464
pack_wds_SLQSSet3GPPConfigItem, 1462
pack_wds_SLQSSetIPFamilyPreference, 1462
pack_wds_SLQSSetWdsEventCallback, 1462
pack_wds_SLQSStartDataSession, 1464
pack_wds_SLQSStopDataSession, 1465
pack_wds_SLQSWdsGoActive, 1465
pack_wds_SLQSWdsGoDormant, 1466
pack_wds_SLQSWdsSetEventReport, 1466
pack_wds_SLQSWdsSwiPDPRuntimeSettings, 1467
pack_wds_SetAutoconnect, 1454
pack_wds_SetDefaultProfile, 1454
pack_wds_SetDefaultProfileNum, 1455
pack_wds_SetMobileIP, 1455
pack_wds_SetMobileIPParameters, 1456
pack_wds_SetMobileIPProfile, 1456
pack_wds_SetMuxID, 1457
unpack_wds_DHCPv4ClientLease_ind, 1467
unpack_wds_DHCPv4ClientLeaseChange, 1467
unpack_wds_DHCPv4ClientLeaseChange_t, 1446
unpack_wds_GetAutoconnect, 1468
unpack_wds_GetByteTotals, 1468
unpack_wds_GetConnectionRate, 1468
unpack_wds_GetDataBearerTechnology, 1469
unpack_wds_GetDefaultProfile, 1469
unpack_wds_GetDefaultProfileNum, 1469
unpack_wds_GetDormancyState, 1470
unpack_wds_GetLastMobileIPError, 1470
unpack_wds_GetMobileIP, 1471
unpack_wds_GetMobileIPProfile, 1471
unpack_wds_GetPacketStatistics, 1471
unpack_wds_GetPacketStatus, 1472
unpack_wds_GetSessionDuration, 1472
unpack_wds_GetSessionState, 1472
unpack_wds_RMSetTransferStatistics, 1473
unpack_wds_RMTransferStatistics_ind, 1473

unpack_wds_SLQSCreateProfile, 1476
unpack_wds_SLQSDUNCallInfoCallBack_ind, 1476
unpack_wds_SLQSDeleteProfile, 1476
unpack_wds_SLQSGet3GPPConfigItem, 1477
unpack_wds_SLQSGetCurrDataSystemStat, 1477
unpack_wds_SLQSGetCurrentChannelRate, 1477
unpack_wds_SLQSGetDUNCallInfo, 1478
unpack_wds_SLQSGetDataBearerTechnology, 1478
unpack_wds_SLQSGetProfileSettings, 1478
unpack_wds_SLQSGetRuntimeSettings, 1479
unpack_wds_SLQSModifyProfile, 1479
unpack_wds_SLQSResetPacketStatics, 1479
unpack_wds_SLQSResetPacketStatics_t, 1447
unpack_wds_SLQSSGetDHCPv4ClientConfig, 1481
unpack_wds_SLQSSGetLoopback, 1482
unpack_wds_SLQSSSetDHCPv4ClientConfig, 1482
unpack_wds_SLQSSSetDHCPv4ClientConfig_t, 1447
unpack_wds_SLQSSSetLoopback, 1482
unpack_wds_SLQSSSetLoopback_t, 1447
unpack_wds_SLQSSet3GPPConfigItem, 1480
unpack_wds_SLQSSet3GPPConfigItem_t, 1447
unpack_wds_SLQSSetIPFamilyPreference, 1480
unpack_wds_SLQSSetPacketSrvStatusCallback, 1480
unpack_wds_SLQSSetWdsEventCallback, 1481
unpack_wds_SLQSSetWdsEventCallback_ind, 1481
unpack_wds_SLQSSetWdsEventCallback_t, 1447
unpack_wds_SLQSStartDataSession, 1483
unpack_wds_SLQSStopDataSession, 1483
unpack_wds_SLQSStopDataSession_t, 1447
unpack_wds_SLQSWdsGoActive, 1483
unpack_wds_SLQSWdsGoActive_t, 1447
unpack_wds_SLQSWdsGoDormant, 1484
unpack_wds_SLQSWdsGoDormant_t, 1447
unpack_wds_SLQSWdsSetEventReport, 1484
unpack_wds_SLQSWdsSetEventReport_t, 1447
unpack_wds_SLQSWdsSwiPDPRuntimeSettings, 1484
unpack_wds_SetAutoconnect, 1473
unpack_wds_SetAutoconnect_t, 1446
unpack_wds_SetDefaultProfile, 1474
unpack_wds_SetDefaultProfile_t, 1446
unpack_wds_SetDefaultProfileNum, 1474
unpack_wds_SetDefaultProfileNum_t, 1446
unpack_wds_SetMobileIP, 1474
unpack_wds_SetMobileIP_t, 1446
unpack_wds_SetMobileIPParameters, 1475
unpack_wds_SetMobileIPParameters_t, 1446
unpack_wds_SetMobileIPProfile, 1475
unpack_wds_SetMuxID, 1475
unpack_wds_SetMuxID_t, 1446
UnpackQmiProfileInfo, 1447
WDS_PROFILE_3GPP, 1446
WDS_PROFILE_3GPP2, 1446
wds_ChannelRateTlv, 1018
ChannelRate, 1018
TlvPresent, 1018
wds_ConnStatusTlv, 1019
MDMConnStatus, 1019
TlvPresent, 1019
wds_DHCPLeaseOptTlv, 1021
numOpt, 1022
optList, 1022
optListData, 1022
TlvPresent, 1022
wds_DHCPLeaseStateTlv, 1022
leaseState, 1022
TlvPresent, 1022
wds_DHCPOpt, 1023
optCode, 1023
optValLen, 1023
pOptVal, 1023
wds_DHCPProfileIdTlv, 1023
profileId, 1024
profileType, 1024
TlvPresent, 1024
wds_DHCPv4HWConfig, 1024
chaddr, 1024
chaddrLen, 1024
hwType, 1024
wds_DHCPv4Option, 1024
optCode, 1025
optVal, 1025
optValLen, 1025
wds_DHCPv4OptionList, 1025
numOpt, 1025
pOptList, 1025
wds_DHCPv4ProfileId, 1026
profileId, 1026
profileType, 1026
wds_DataBearTechTlv, 1020
DataBearerTech, 1020
TlvPresent, 1020
wds_DataULongLongTlv, 1021
TlvPresent, 1021
ullData, 1021
wds_DataULongTlv, 1021
TlvPresent, 1021
ulData, 1021
wds_Domain, 1026
domainLen, 1026
domainName, 1026
wds_DomainNameList, 1027
domain, 1027
numInstances, 1027
wds_DormStatTlv, 1027
DormancyStat, 1027
TlvPresent, 1028
wds_GPRSQoS, 1028
delayClass, 1028

meanThroughputClass, 1028
peakThroughputClass, 1028
precedenceClass, 1028
reliabilityClass, 1028
wds_IPV6AddressInfo, 1029
IPAddressV6, 1029
IPV6PrefixLen, 1029
wds_IPV6GWAddressInfo, 1029
gwAddressV6, 1030
gwV6PrefixLen, 1030
wds_IPv4AdTlv, 1028
IPv4Addr, 1029
TlvPresent, 1029
wds_LastMdmCallEndRsnTlv, 1030
CallEndReason, 1030
TlvPresent, 1030
wds_PCSCFFQDNAddress, 1031
fqdnAddr, 1031
fqdnLen, 1031
wds_PCSCFFQDNAddressList, 1031
numInstances, 1031
pcsfFQDNAddress, 1031
wds_PCSCFIPv4ServerAddressList, 1032
numInstances, 1032
pscsfIPv4Addr, 1032
wds_ProfileIdentifier, 1032
profileIndex, 1033
profileType, 1033
wds_RXBytesOKTlv, 1033
RxByteOKCnt, 1033
TlvPresent, 1034
wds_TXBytesOKTlv, 1035
TlvPresent, 1035
TxByteOKCnt, 1035
wds_TrStatInd, 1034
statsMask, 1035
statsPeriod, 1035
wds_UMTSMinQoS, 1035
deliveryErrSDU, 1037
grntDownlinkBitrate, 1037
grntUplinkBitrate, 1038
maxDownlinkBitrate, 1038
maxSDUSize, 1038
maxUplinkBitrate, 1038
qosDeliveryOrder, 1038
resBerRatio, 1038
sduErrorRatio, 1038
trafficClass, 1038
trafficPriority, 1038
transferDelay, 1038
wds_channelRate, 1018
CurrChanRxRate, 1018
CurrChanTxRate, 1018
wds_currNetworkInfo, 1019
NetworkType, 1020
RATMask, 1020
SOMask, 1020
wds_profileInfo, 1033
SlqsProfile3GPP, 1033
SlqsProfile3GPP2, 1033
wds_transferStatInd, 1034
StatsMask, 1034
StatsPeriod, 1034
wdsDhcpv4HwConfig, 1038
chaddr, 1038
chaddrLen, 1038
hwType, 1038
wdsDhcpv4Option, 1039
optCode, 1039
optVal, 1039
optValLen, 1039
wdsDhcpv4OptionList, 1039
numOpt, 1039
pOptList, 1040
wdsDhcpv4ProfileId, 1040
profileId, 1040
profileType, 1040
word
swi_uint256_t, 533

xAxis
sensorData_t, 511
xferStatAvail
unpack_wds_SLQSSetWdsEventCallback_ind_t, 954
xid
pack_loc_SLQSLOCGetBestAvailPos_t, 348
pack_qmi_t, 410
unpack_qmi_t, 784
xtra_start_gps_minutes
unpack_pds_SLQSGetGPSStateInfo_t, 783
xtra_start_gps_week
unpack_pds_SLQSGetGPSStateInfo_t, 783
xtra_valid_duration_hours
unpack_pds_SLQSGetGPSStateInfo_t, 783

yAxis
sensorData_t, 511
year
nas_timeInfo, 277
nas_UniversalTime, 283

zAxis
sensorData_t, 511