

TiGR 350R

ENGLISH



SIERRA
WIRELESS®

You have just purchased a Sierra Wireless phone, we congratulate you; it is recommended that you read this handbook carefully in order to use your phone efficiently and in the best conditions.

Your phone can be used internationally in the various networks (R-GSM, GSM 900MHz and DCS 1800MHz) depending on the roaming arrangements with your operator.

We remind you that this phone is approved to meet European standards.

WARNING

Ensure that your SIM card is a 3 V SIM type that is compatible with your phone. Inserting an incompatible card will be indicated by a message when your phone is switched on. Contact your operator.

Your phone is identified by its IMEI number. Write this number down, and do not keep it with your phone, because you may be asked for it in the event of your phone being stolen, in order to prevent it from being used, even with a different SIM card. In order to display the IMEI on your phone's screen, type: *#06#.

Sierra Wireless is a registered trademark.

AT® is a registered trademark of Hayes Microcomputer Products Inc.

Hayes® is a registered trademark of Hayes Microcomputer Products Inc.

T9 is protected by one or more of the following US patents: 5,818,437, 5,953,541, 5,187,480, 5,945,928, 6,011,554 and other patents are being applied for worldwide.

Java™ and all Java™ based trademarks and logos are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

The WAP navigator and the softwares included are the exclusive property of Openwave. For this reason, it is forbidden to modify, translate, disassemble or even decompile all or part of these softwares.

Wellphone™ and SmartCom™ are registered trademarks owned by SmartCom SARL France.

The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc.

Contents

Menus	9
Your phone package	11
Description	12
Navigation principles	14
Initial screen	15
Activating your phone	16
Information on the SIM card	16
First use: installing the SIM card and the battery	17
Removing the battery	17
Getting started	18
PIN number	18
Setting time and date	19
Network	19
First call	19
Calling voicemail	20
Receiving a call	20
Switching off	20
Using your phone	21
Freeing the antenna	21
Increase the efficiency of your phone	21
Charging the battery	22
Phonebook	23
Using the phonebook	23
Storing a new contact	23
Calling a contact	23
Contact options	24

Modify contact	24
Send message	24
Send by	24
Copy to SIM	24
My numbers	24
Mailing list	24
Memory	25
Delete/Delete all	25
Set as my card/Business card	25
Exchange	25
Contacts synchronisation with a computer	25
List choice	25
Identity	26
Dialling help	26
Quick dialling	26
Manage FID	26
Registration	26
Deregistration	27
Interrogation	27
Changing the current identity	27
Deregister All	27
Synchronising identities	28
Group Calls	29
Initiating a Broadcast Call	29
Initiating a Group Call	29
Initiating an Emergency Call	29
Joining an Ongoing group	30
Terminating a Broadcast Call	30
Terminating a Group Call	30
Terminating an Emergency Call	30
Messages	31
Compose SMS	31
Compose MMS	34

Receiving messages.....	35
Inbox	35
Outbox	35
Sentbox.....	36
Drafts	36
Templates	36
Status report	36
Sending a message	36
Recipient	37
Alias	37
New status message.....	37
Options	37
Memory.....	38
Calling Voice Mail	38
Mailing list	38
WAP	39
The WAP Menu	39
Configuring WAP parameters	40
WAP Logging on.....	41
Downloading objects.....	41
WAP Logging off.....	42
GPRS.....	42
Applications.....	43
ToDo	43
ToDo menu	43
ToDo actions menu.....	43
Sending a vCal	44
Receiving a vCal	44
Data exchange with a PC	44
Calculator.....	45
Converter	45
Alarm	46
Timer.....	46

Organizer	47
Calendar menu	47
Settings	48
Customise (PIN2)	48
Sounds	48
Security	49
WAP settings	51
Call forward	51
Display numbers	52
Voicemail	52
Blacklist	52
Local info	52
Activate Menu	52
Call waiting	53
Calls	53
View last calls	53
Counters	53
Networks	53
Multimedia	54
My Pictures	54
My Sounds	54
Memory	55
Languages	55
Energy saving	55
Contacts	55
Shortcuts	55
Automatic update	56
Short code dialling	56
Date / Time	56
Set Date/Time	56
Automatic update	57
Display	57
Time zone	57
Daylight savings	57

Help	57
Connectivity.....	58
Bluetooth.....	58
Serial speed.....	59
Car kit	59
SyncML.....	59
Technical features.....	60
Care and safety information.....	62
SAR	62
Advice for limiting exposure to radiofrequency (RF) fields	62
Safety.....	63
Environment.....	64
Warranty.....	65
End User Licence Agreement (EULA), for the software	69
Java™	73
Troubleshooting.....	78
Index.....	83

Menus



WAP



Applications

- ToDo
- Services
- Calculator
- Converter
- Alarm
- Timer



Messages

- Compose
- Inbox
- Outbox
- Sentbox
- Drafts
- Templates
- Status report
- Options
- Memory
- Call Voice Mail
- Mailing list



Identity

- Dialling Help
- Quick dial.
- Manage FID
 - Registration
 - Deregistration
 - Interrogation
 - Change ID
 - Dereg All.
- Synchronise



Group calls

- Initiate
- Ongoing calls
- Group status



Organizer

- See month
- See week
- See today
- See date
- Calendar menu
- Help



Connectivity

- Bluetooth
- Serial Speed
- Car kit
- SyncML



Settings

- Customise (PIN2)
 - Sounds
 - Security
 - WAP settings
 - Call Forward
 - Display number
 - Voicemail
 - Blacklist
 - Local info.
 - Activate Menu
 - Call waiting
- Calls
 - View last calls
 - Counters
 - Help
- Networks
- Multimedia
 - My Pictures

- My Sounds
- Memory
- Help
- Languages
- Energy saving
- Contacts
- Shortcuts
- Date/Time
 - Set Date/Time
 - Automatic upda.
 - Display
 - Time zone
 - Daylight savings
- Help




Phonebook

- Contacts menu

Your phone package

When you open the box, check that all items are present:

- 1 - Phone
- 2 - Charger
- 3 - Battery
- 4 - User guide



Description

Emergency call



Hold down: Switch on/off

In a call context: Reject a call - hang up

In menus: Return to initial screen



During a call: Activate/Deactivate hands-free mode (**WARNING:** in this mode do not bring the phone up to your ear)

In call context: Call - receiving a call



Right programmable key:

In initial screen: access to certain functions (shortcuts)

In menus: Access to the selection shown on screen in the tab (*)



Left programmable key:

In initial screen: access to certain functions (shortcuts)

In menus: Access to the selection shown on screen in the tab (*)



The four-directional navigation stick allows you to:

- Move the cursor on the screen by pushing the stick toward the corresponding direction
- Confirm your selection by pressing **[OK]**
- In initial screen: long press leftwards/rightwards: access to Phonebook

Note: when the   icons appear on the screen, the function is related to the navigation stick



Press briefly and [OK]: activate or deactivate keypad locking



Hold down: *In initial screen:* Silent mode

In call reception mode: Short press stops ring tone

In ring tone setting mode: Activate / deactivate ring tone


When composing a message:

Short press: switches from one input mode to another (T9, ABC, 123)

Long press: upper case/lower case

2 to 9 A long press on the keys **2** to **9** directly displays the phonebook.

(*) In this manual, when a function is chosen by pressing on this key, square brackets are used (e.g.: **[Save]**).



Navigation principles

These basic principles bring a great intuitiveness to your phone.

Validate by pressing the  key or the **OK** key.

Cancel by pressing the  key.

The thumbnails at the bottom of the screen refer to the   keys.

In the menus, a title bar reminds you of the previous level.

From the home page, pressing the navigation stick displays the icons of the main menus.

When pressing the navigation stick followed by a figure, you can display a menu directly. For instance, pressing the navigation stick then **8** displays the Phonebook.

The  key is used to go from a menu to a sub-menu.

The  key is used to go from a sub-menu to a menu.

The  key (press briefly) is used to go back to the initial screen (current function is abandoned).

In some menus there is a **Help** menu () which informs you on the various functions of the sub-menus.

Initial screen

The initial screen may contain the following information:

1 - The title bar icons:

	Battery
	Calls forwarded
	Call (establishing the call)
	Call (hands free)
	Message (reception of a message, message memory full)
	FAX communication
	DATA communication
	Silent mode
	Message in answering machine
	WAP (@) communication
	GPRS
	Region zone
	Roaming
	Only emergency call is possible
	Keypad locking
	Secured WAP registration
	Secured WAP registration symbol with certificate
	Signal strength level (5 bars).
	Manual network selection.
	Access group call or broadcast.

2 - Date and time, in digital mode

3 - Network provider


4 - Thumbnail centred on bottom line:

The main « Menu » thumbnail shows that the menu can be accessed by pressing the navigation stick. The following information may also be displayed: « 1 message received » or « 1 call ».

It can be deleted by pressing  key briefly.

Activating your phone

Information on the SIM card



To use your phone, you need a card called SIM card. It contains personal information that you can modify:


- Secret codes (PIN(s): Personal Identification Numbers), these codes allow you to protect access to your SIM card and phone
- Phonebook
- Messages
- How special services work.

Your phone is compatible with the SIM 3V cards.

WARNING

This card must be handled and stored with care in order not to be damaged. If you should lose your SIM card, contact your network provider or your SMC (Services Marketing Company) immediately.
Please keep your SIM card out of reach of young children.

First use: installing the SIM card and the battery




- 1 Slide the SIM card, with cut corner as shown on the phone, into the card holder with fold face down.
- 2 Place the battery by positioning first the top of it, as shown on the battery.

Removing the battery

Proceed as follows to remove the battery (in case of replacement of the SIM card, for instance):

- Turn the phone back. Press on the back of the battery at the level of the latch and lift the battery.



Getting started

You are now ready to use your phone for the first time.

Switch on the phone by pressing the  key. A short display appears.

When you switch on your phone for the first time, you must configure it with various settings that will remain by default until you choose to modify them.

After entering your PIN code and the date and time, make your choice for the following settings: time zone, daylight savings, skin, wallpaper, screensaver, ring tone, volume, vibrate and voicemail number.

If there are contacts saved in your SIM card, you are invited, if you wish, to copy them in the phone contacts memory.

PIN number

This is your SIM's secret code.

If access to the SIM card is protected, the device prompts you to enter the PIN number:

Enter the code between 4 and 8 digits given to you when the SIM card was issued. These digits do not appear on the screen for security reasons.

Press **[OK]** or the navigation stick to validate.

If your phone indicates that the SIM is missing, press the  key to switch off your phone and check that the SIM card is correctly installed.

WARNING

If a wrong PIN number is entered three times in succession, your SIM card is blocked. You must then:

- Enter the PUK (Personal Unblocking Key) code provided by your operator, and validate.
- Enter your PIN number and validate.
- Enter your PIN number again and validate. For this, follow the following sequence : **05*PUK*PIN*PIN#

After 5 or 10 failed attempts (depending on the type of SIM card), the SIM card is definitely locked. You must then contact your operator or your SMC to obtain a new card.

Setting time and date

When you use your phone for the first time, you need to set the date and time.

In due course, when the battery is completely discharged, or if it has been removed, you will be prompted systematically to confirm date and time.

Setting the date:

Set the date by entering it directly in numerical form or by using the navigation stick to increase or decrease the default values. Use the navigation stick to access the next (or last) data input field.

Once the date is correct, press the  key to validate.

Setting the time:

Same procedure as for setting the date.

Network

From now on the phone hunts for a network on which it can make calls. If it finds one, it displays the name of the network on the screen. You are then ready to send or receive a call.

If the network icon appears, calls are possible on your operator's network.

If the letter R and a network name are displayed, calls are possible on the network of a different operator.

If the letter E is displayed without any network name, only the emergency services are accessible (ambulance, police, fire brigade).

If the network icon flashes, the phone is in permanent search mode. There is no network available. The signal strength indicator received allows you to display the quality of reception. If it indicates less than three bars, search for better reception in order to call in good conditions.

First call

Dial the number of your correspondent.

Press the  key.

During the call, the call in progress icon flashes on screen and tones may indicate the establishment of the call.

Once communication has been established, the call icon stops flashing.

You can adjust the sound level (volume) using the navigation stick.

At the end of the conversation press the  key to hang up.

Calling voicemail

In the initial screen, press and hold down the **1**key.

International call

Press **0** (hold down) to display « + », then dial the country code without waiting for the dial tone, then the number of the called party.

Emergency services

Depending on the operators you can obtain the emergency service with or without SIM card or when the keypad is locked. It is enough to be in an area served by a network.

To obtain the international emergency service, dial **112** then press the  key.

Receiving a call

When you receive a call, the number of your correspondent is displayed when it is presented by the network.

Press the  key or the  key to answer, and speak.

To refuse the call, press the  key or the  key.

To stop the ring tone or the vibrate, without refusing the call, press the  key.

Hands-free mode

During a call, press the  key to switch into hands-free mode and confirm with the **OK** key.

WARNING: in this mode do not bring the phone up to your ear.

All the numbers corresponding to incoming and outgoing calls are logged in the list of recent calls.

When a call is on hand, pressing **[Options]** allows you to have access to different functions: switching to hands-free mode, holding a call, switching to mute mode, ending the call, displaying menus.

Pressing **[Mute ON]** allows you to switch off the sound temporarily when you do not want that your correspondent listens when you want to speak to other people.


Switching off

Press the  key (long press).

The end message is displayed. The phone switches off.

Using your phone

Freeing the antenna



The antenna is integrated in your phone, under the back cover at the top.

Avoid putting your fingers on this area when the phone is switched ON.

If your fingers obstruct the antenna, the phone may have to operate with a higher power level than usual; decreasing its efficiency quickly. It could also affect the quality of your communications.

Non ionising radiation

To obtain maximum satisfaction from your phone, use it in a vertical position. Your personal safety can only be improved by doing so.



Increase the efficiency of your phone

- Don't press the keys when not necessary: each keypress activates the backlight, and uses much power.
- Don't obstruct the antenna with your fingers.

Charging the battery



Your phone is powered by a rechargeable battery. A new battery must be charged for 4 hours at least before being used for the first time. It reaches its optimum capacity after a few cycles of use.

When your battery has been discharged, the phone displays the state (empty battery icon flashes). In this case recharge your battery for at least 15 minutes before making any calls in order not to be cut off in the middle of a call.

To recharge the battery:

Connect the charger to a socket.

Plug the end of the cable into the side connector of the phone.

The phone is then charging up. The battery icon is scrolling up and down to indicate that it is charging. When the battery is fully charged, the charging stops on its own. Disconnect the cable.

When charging, the battery may warm up, this phenomenon is normal.

WARNING

There is danger of explosion if the battery is placed in an incorrectly way or if it is exposed to fire.

Do not short circuit it.

The battery does not have any part that you can change.

Do not try to open the battery casing.

Use only the appropriate chargers and batteries as shown in the phone manufacturer's catalogue.

The use of other types of chargers or batteries may be dangerous or invalidate the warranty.

The temperature range for charging the batterie is 0 °C to + 40 °C.

Used batteries must be disposed of in the appropriate places.

We advise you to take the battery out if you plan not to use the phone for extended periods.

You are strongly advised not to connect your phone to the charger if it doesn't contain a battery.

The charger is a safety step-down transformer, it is forbidden to modify, alter or replace it by another component (power supply plug, etc).

If the battery has entirely discharged, the phone cannot start. Plug the phone to the charger. The phone will switch on after a few minutes of charge. You can use the phone again when the Start option is displayed on the screen.



Using the phonebook

Enter the **Phonebook** menu, the contacts list is displayed if you already get some (otherwise, go to **Storing a new contact**). When a contact is selected, an icon is displayed in the title bar:



contact stored in the SIM card



contact stored in the phone



contact stored in the Fixed Dialling. See **PIN2 number** and **Fixed dialling** in **Security** Menu for more details about this activation.

You can search for a contact quickly by typing the first letters (up to three). You can display it by pressing **OK**.

Storing a new contact

- Display the Phonebook, press [**Options**] then select **Add phone contact** or **Add SIM contact**.
- Enter the last name and press the navigator.
- Enter the number and press the navigator (**OK**).

Note: you can fill other fields if you store the contact in the phone memory (email, address, ringtone, photo, etc.).

- Press [**Save**] to store it.

Calling a contact

Several ways:

- Select a contact. Press  to start the call.
- Select a contact, press **OK**, his number is displayed, press [**Call**] to start the call.
- Direct call from the idle screen (only for the contacts stored in the SIM card memory): type the number with which the contact was saved then * (example : 21 *) or the number then #, the number is displayed, confirm.

Contact options

To display the various options, select a contact and press **[Options]**.

Modify contact

Modify what you want and validate then select **Save** once the modifications completed.

Send message

To send a SMS or a MMS to a contact (see chapter **Messages**).

Send by

To send a contact details by MMS, SMS, Bluetooth (see chapters **Messages** and **Connectivity**).

Copy to SIM

This allows you to copy your phonebook contacts from one memory to the other. Only the name and the first phone number will be copied.

My numbers

You can create the entries corresponding to your own numbers in order to consult them when necessary. Select **My numbers** and validate. Enter the different details and validate.

Mailing list

A mailing list allows you to send a same message to several recipients at the same time.

- Select **Mailing Lists** and press the navigation stick. The phone asks you to confirm the creation of a new list.
- Select the list type (SMS or MMS) and press the navigation stick.
- Enter a name and press the navigation stick.
- Then, on a list press **[Options]**. Select **Add contact** each time you want to add a contact in the list.

Memory

Select **SIM** or **Telephone** and validate.

Telephone: the screen displays the amount of memory used. The memory capacity is shared between the phonebook and various other features. If you lack memory, check if you can free some space.

SIM: available memory only for contacts.

Delete/Delete all

This allows you to delete the contact selected or all the contacts.

Set as my card/Business card

The details of a contact stored in the phone memory can be saved in a business card.

- Select a contact and press [**Options**].
- Select **Set as my card** and [**OK**]. The details are saved as **Business card**. Then you can read it, modify it or send it by SMS, MMS.

Exchange

You can synchronize your phonebook with your archives stored in your operator's network depending on the options offered by your operator.

The local synchronisation with your computer is only computer originated, from Wellphone software (in option); you have only to activate Bluetooth, or configure your USB connection in your phone.

Contacts synchronisation with a computer

Install Wellphone, software provided on CD (in option), and click on DIRECTSYNC: you can synchronise your contacts stored in the phone memory with those of your Lotus Notes™ or Microsoft Outlook™ bases.

List choice

This menu allows you to select the default phonebook (phone, SIM and Phone or SIM) displayed when the phone switches on.



Dialling help

This menu provides assistance with calling an Functional Identity (FID).

Working from the **Identity** menu, select the **Dialling help** menu and [Enter].

Successively enter and validate the call type (CT), the user identification number (UIN) and the function code (FC) of the identity that you want to call. Validate by pressing OK.

Quick dialling

This menu is a shortcut for calling a stream FID.

Working from the **Identity** menu, select the **Quick dial.** menu and press [Enter].

The mobile phone will recover the start of your current FID. Key in the function code (FC) for your correspondent and validate it. This enables you to avoid entering the start of the FID (call type + user identification number).

To call a correspondent with an FID that does not have the same type of call or user identification number, use the **Dialling Help** menu.

Manage FID

Registration

This menu allows you to save an FID.

Working from the **Identity** menu, select the **Manage FID** menu and then **Registration** and [Enter].

Successively enter and validate the network's international code (RAC), the call type (CT), the user identification number (UIN) and the function code (FC) for the FID that you want to save. Validate by pressing OK.

The FID saved becomes your current FID and will be displayed on the welcome screen.

Deregistration

This menu allows you to erase an FID.

Working from the **Identity** menu, select the **Manage FID** menu and then **Deregistration** and [Enter].

Select the FID to be erased and validate this by pressing **OK** (the current FID will appear in red).

Interrogation

This menu allows you to interrogate the telephone number assigned to an FID.

Working from the **Identity** menu, select the **Manage FID** menu, then **Interrogation** and [Enter].

Successively enter and validate the network's international code (RAC), the call type (CT), the user identification number (UIN) and the function code (FC). Validate by pressing **OK**.

You will obtain the telephone number (MSISDN) associated with the FID you have queried.

Changing the current identity

This menu allows you to change your current FID.

The current FID will appear on your mobile phone's welcome screen and on your correspondent's screen when you make a call.

Working from the **Identity** menu, select the **Manage FID** menu, then **Change ID** and [Enter]. The current FID will appear in red.

Select the FID that you want to have as the current FID and validate it by pressing **OK**.

The new current FID will appear on the welcome screen and will be displayed to your correspondent.

Deregister All

This menu enables you to delete all identities.

From the **Identity** menu, select the **Manage FID** menu, then the **Dereg. all** option, and [Enter].

Confirm deletion by clicking on **OK**.

Synchronising identities

This menu allows you to synchronise FIDs with the network.

It is possible that some of your FIDs may be out of synch with the network – for example after a forced deregistration. In this case, the current FID displayed on the welcome screen will flash.

Working from the **Identity** menu, select the **Synchronise** menu and **[Enter]**.

The FIDs no longer assigned to you will then be erased automatically.

Group Calls



This menu allows you to initiate and connect to a group call or a broadcast call.

You can also gain access to a list of the most recent numbers used.

Initiating a Broadcast Call

In the **Group Calls** menu, select the **Initiate** menu and validate.

Select the **Broadcast** option. The mobile phone will display the broadcast call numbers (GID) that you can set up. Choose a GID and press **[Call]**.

As the person who initiated the broadcast call, you are the only one who can speak.

This is indicated by the icon . The group's other users cannot speak, as indicated by the icon .

Initiating a Group Call

In the **Group Calls** menu, select the **Initiate** menu and validate.

Select the **Group** option. The mobile phone will display the group call numbers (GID) that you can set up. Choose a GID and press **[Call]**.

Before speaking, you must ask permission by pressing the **PTT** (Push-To-Talk) button. Permission is granted by the network to only one user at a time.

If you are granted permission, your mobile phone will display the  icon, indicating that you can speak. When you do not have permission to speak, you become one of the group's listeners and your mobile phone will display the  icon.

Initiating an Emergency Call

Working from any menu, at anytime press on .

Once the call has been initiated, the emergency call works like a group call.

The mobile will request confirmation in order to initiate the emergency call. Confirm by pressing yes.

Once the call has been initiated, the emergency call works like a group call.

Joining an Ongoing group

In the **Group Calls** menu, select the **Ongoing calls** menu and validate.

The mobile phone will display a list of group and broadcast calls in progress at that moment in your region. Select a call and press **[Join]**.

Group status

This menu allows you to choose the group or broadcast call number to be activated for making or receiving group or broadcast calls.

From the **Call menu**, select the **Group status** menu, then the broadcast or group option.

Use the arrows to activate or deactivate the required broadcast or group number, and confirm.

Terminating a Broadcast Call

Press  or  to terminate a Broadcast Call.

If you initiated the call, it will close, and the call will be hung up on the network, with all users being disconnected from it.

If you did not initiate the call, you alone quit the call and the other users can still take part in it.

Terminating a Group Call

Press  or  to terminate a Group Call.

If you did not initiate the call, you alone quit the call and the other users can still take part in it.

If you initiated the call, the mobile phone will give you two options: Quit or Close. If you select Close, the call will be hung up on the network, with all users being disconnected from it. If you select Quit, you alone quit the call and the other users can still take part in it. After having quit, you can still close the group if you rejoin it: speak at least once and then select Close when the option appears.

Terminating an Emergency Call

Press  or  to terminate an Emergency Call.

If you did not initiate the call, you cannot quit the call.

If you initiated the call, you can only Close the call. The call will be hung up on the network, with all users being disconnected from it.

Messages



From this menu, you are able to send SMS and MMS. MMS is a Multimedia Message Service, which allows you to enclose audio files, images and others rich contents to your messages; these messages can even be composed of several slides. MMS are differently invoiced than SMS are. Please contact your network provider to get more information on their cost.

This menu has been compiled in collaboration with magic4™.

magic4

Compose SMS

On the **Messages** menu, please select the **Compose** menu and validate. Choose the **SMS** option.

The language used is the one selected on the display of the phone (if the language selected is not compatible with the Easy Message T9™, the English language will be automatically selected).

When typing a text, a counter showing the number of characters deducted is displayed at the top of the screen. This counter is not displayed if an icon or sound is inserted into the SMS.

When the text has been entered, **[Options]** is used to access the functions offered:

- **Send** is used to send the message by entering the correspondent's number or selecting it in the phonebook
- **ABC mode** (see page 33)
- **123 mode** (see page 33)
- **T9 mode** (see page 32)
- **Save** is used to save a draft in memory
- **Save as Template**: allows you to keep as a template a message in order to use it again.
- **Cancel** is used to delete all text entered and quit
- **Activate/Deactivate Zoom** is used to modify size of characters
- **Activate/Deactivate Silent** is used to activate or not the keypad beep when typing the text
- **Formatting** is used to enrich a text
- **Insert** to insert an image or sound into your message (see page 34).

The Easy Message T9™ mode helps you to easily write your short messages.



Using T9 options

Press once the key corresponding to the letter chosen and compose the word by continuing to press the keys corresponding to the various letters without paying attention to the display: the word is highlighted.

If you agree on the word proposed on the screen, press the **O**key to validate it (the **O**key inserts a space), and go on writing the next word.

However, the same sequence of keys pressed can correspond to several words, existing on the dictionary. If the word that appears is not the word you expected, press the navigation stick to scroll through the words corresponding to this key sequence.

Once you agree on the word proposed on the screen, press the **O**key to validate it (the **O**key inserts a space), and go on writing the next word.

If the word you are expected is not proposed, please add characters until you get the message **Add a word?** Press **Yes** and validate if the word displayed suits you or modify this word before adding it in the dictionary.

When composing a message:

-  **key:**
Deletes last letter
-  **key:**
Message options
-  **key (short press):**
Access to symbol table
-  **key (long press):**
Upper case

Input modes

In the input screen, the  key is used to access other input modes. The mode in which you type the text is displayed at the right top of the screen. A short press of the  key switches from one mode to another.

The **ABC mode** is used to write words that do not exist in the dictionary. To get a particular character, please press the corresponding key several times: the characters will scroll down on your screen.

Mode 123 is used to add numbers.

Insert mode is used to add symbols, animations, call group icons and tunes. Images and sounds can be of two types: pre-defined or customized. Pre-defined images and sounds are smaller, especially suited to exchanging messages.

Upper case

A long press of the  key will display the next letter in upper case ( icon).

Punctuation characters

Punctuation characters are obtained thanks to key **1** (except in **123** mode), or with the help of **Insert** mode (fast access by briefly pressing the  key).

Accented characters

Accented characters are generated automatically in T9 mode.

In ABC mode accented characters are available by pressing the key supporting the non-accented character in succession.

Compose MMS

On the **Messages** menu, please choose the **Compose** menu and validate. Select the **MMS** option.

When the text has been entered, **[Options]** is used to access the functions offered:

- **Insert** to insert multimedia objects such as images, animations, sounds into your message.
- **ABC mode** (see page 33)
- **T9 mode** (see page 32)
- **123 mode** (see page 33)
- **Cancel** is used to delete all text entered and quit
- **Slide** to compose a slideshow of the multimedia objects.
- **Preview...** to see a presentation of the multimedia objects.

Saving the message

Select **Save**. It is saved in the **Drafts** menu.

Select **Save as Template**. It is saved in the **Templates** menu.

Sending the message

- Once the text entered, press the navigation stick or press **[Options]** and select **Send**.
- Enter the receiver's number (or take it in your phonebook pressing **Contacts**) and press the navigation stick.
You can enter an e-mail address.

Note: It is possible that the voice message format (.amr) is not supported by some PC. See your PC provider.

WARNING: some message sendings may fail if the message content is too big.

In the recipient screen, before typing the recipient's number, the following options are available:

- **Editor:** this option allows you to modify the text before sending the message.
- **Contacts:** to access the phonebook.
- **ABC/123:** to type either letters or figures.
- **Add mailing list:** this option allows you to select a mailing list to which the message is sent (see chapter **Phonebook**).

Once the number typed, other options are available.

Receiving messages

When you receive a message, the phone plays the ring tone that you selected, and the message icon  comes on the screen of your phone.

If you do not read the messages, this icon remains displayed on the screen. When it flashes, the memory is full.

Receiving icons, backgrounds or tunes can take several seconds. An icon is blinking when the download of your message is in progress.

Note that you have two different possibilities for receiving MMS: automatically or manually; if « manual mode » is activated, then you will receive only a notification in your Inbox, meaning that a MMS is available on the MMS Server; select Retrieve in the options when you want to retrieve the MMS from the server.

For more details about automatic and retrieval modes, see « Options » on page 37.

Please contact your network provider to get more information on icons, backgrounds or tunes downloading.

Received messages are stored in the SIM card or in the phone until you choose to delete them.

Inbox

On the **Messages** menu, please choose the **Inbox** menu and **[Select]**.

Each message shows the presence of any attachments, the time and date the message was received and its size.

Messages are listed in chronological order, the latest one being displayed first.

The quantity of Not Read and Not Retrieved messages is shown. Not Retrieved and Not Read messages are shown in bold.

Select a message and press the navigation stick. Choose one of the options given.

Enclosures (pictures or sounds), which you receive, can be extracted in order to be used later on (stored...).

You can consult them in the corresponding menus (WAP bookmarks in **WAP**, ring tones in **Help**, wallpapers in **Languages**).

Outbox

This menu displays the messages that have not been sent. You can therefore send them again.

Sentbox

The **Sentbox** menu is used to store all your sent messages if you activated the option **Store sent msgs** in the **Options** menu (see page 37).

Too many messages saved will quickly fill up the available memory and no further messages will be received.

For each message, its characteristics (shown with an icon) and the time (or date) of sending are displayed on the screen.

Select a message and press the navigation stick.

Choose one of the options given: Read, Modify, Forward, Delete, Delete all.

Drafts

When you store a composed message, it is stored among the drafts.

On the **Messages** menu, please choose the **Drafts** menu and press the navigation stick.

Select a message and press **[Options]**. The options are: Modify, View, Details, Delete, Delete all.

If you select a message and press the navigation stick, you can modify it.

If you want to send it, select **Modify** then press **[Options]** and select **Send**.

Templates

When composing a message, if you selected the **Save as Template** option, the template is saved in this menu.

The same options as for the drafts are available for the templates.

Status report

This menu allows to send status messages to a center of destination. These preset messages contain a model giving the state of the user as well as the identifier of the mobile.

The message can be modified before each sending and it is also possible to create new ones.

Sending a message

In the **Messages** menu, select **Status messages**.

Choose a message to send and confirm by pressing **OK**.

The message can be modified, confirm by pressing **OK** then send.

Recipient

The status message recipient corresponds to the number entered in the **Recipient** menu, accessible via **Messages** then **Status messages** menu.

Alias

The ID (or Alias) is added by the mobile at the end of the status message. To modify the ID, in the **Messages** menu, select the **Status messages** menu then choose **Alias**.

Enter the name (max. 15 characters) then confirm.

If this field is blank, the ID will contain the mobile's IMEI.

Note: the mobile automatically adds the ID to the status message before it is sent. The status message text must not exceed 145 characters.

New status message

In the **Messages** menu, select the **Status messages** menu then choose **New status**.

Enter the text which appears in the status messages list (title) and insert a line feed.

Enter the rest of the status message.

These messages, and those saved beforehand, are stored in the mobile and appear in the Status messages menu.

Options

Several sending options are offered.

On the **Messages** menu, please choose **Options** and **[Select]**.

Choose one of the options given: SMS or MMS.

The SMS sending options are: message centre number, store sent message, acknowledgment, period of validity (during that period, the network provider will try to send the message), message format.

The MMS options are:

- **Store sent msgs:** (it is highly recommended that you keep this function deactivated, in order to avoid a full memory),
- **Priority:** selection of a priority to send a message.
- **Request delivery report:** request of a delivery report when sending a message.
- **Period of validity:** during that period, the network provider will try to send the message.

Advanced settings

- **Send delivery report:** sending a delivery report when receiving a message.
- **MMS ignore:** if you want to deactivate the reception of any MMS in your phone.
- **MMS server:** to select another MMS provider, or set the parameters of a new MMS provider.
- **Display Bcc:** if you want to activate/deactivate this display.
- **Sender visibility:** you choose to display or not your phone number on the receiver's phone screen, with that message.
- **Maximal Size:** if you want to activate/deactivate the option of maximum size supported for the MMS.

Memory

You may know the memory available for saving messages.

On the **Messages** menu, please select the **Memory** option and **[Select]**.

Choose one of the options given: SMS or MMS.

The SMS screen displays the memory available either on the SIM card or on the phone.

The MMS screen displays how much memory is used in Kbytes.

Calling Voice Mail

This function allows you to call your voicemail.

On the **Messages** menu, please select the **Call Voice Mail** option and **[Select]**.

Note: if your voicemail number has not been entered yet, you must enter it in the menu **Settings/Calls/Voicemail**.

This number depends on the operator.

Mailing list

This menu displays the mailing lists created in the phonebook.

To display the different options, press **[Options]**.

- **Add mailing list:** allows you to create a new mailing list.
- **Modify name:** allows you to modify the mailing list name.
- **Add contact:** allows you to add a contact to the mailing list.
- **Properties:** allows you to see the type of mailing list and the number of contacts.
- **Delete:** allows you to delete an entry.
- **Delete all:** allows you to delete the mailing list.
- **Send message:** allows you to compose and send a message to the contacts of the mailing list.



WAP (Wireless Application Protocol): a protocol that translates the Internet language into WML and HTML languages that can be read by a phone. The WAP function allows you to log onto certain Internet sites. You can log onto sites that allow you to download ringtones, icons, animated screensavers, Java™ applications to your phone.

The WAP Menu

The WAP navigator is under licence:



RSA Data Security

The WAP navigator and the softwares included are the exclusive property of Openwave. For this reason, it is forbidden to modify, translate, disassemble or even decompile all or part of these softwares.

The **Services** menu, a dropdown menu, can be accessed at all times when navigating through WAP pages pressing the  key.

It contains the following sub menus:

Previous: this menu allows you to come back to the previous screen.

Welcome: logs onto the home page (carries the name of your access provider)

Bookmarks: is used to save in a phonebook the names and addresses of Internet sites in order to make the access easy.

You can receive bookmarks from messages and add them to this list (see chapter on SMS).

You can also send messages by SMS: select a bookmark, press [**Options**], then select **Send by message**.

Go to URL: this menu allows you to input an Internet address directly.

Inbox: this menu allows you to check the messages sent by the Internet site.

Save objects: is used to save a WAP site items.

Snapshots: takes a snapshot of the currently displayed page.

Save Page: saves the currently displayed page.

History: backward and forward navigation of the pages displayed are kept in memory.

Reload: refreshes the current page.

Reset cache: clears the stored information on previous connections.

Advanced....: choose one of the following advanced settings

- Settings
- Show URL
- Disconnect
- Security (is used to access information on making WAP connections secure).
- Delete Cookies
- View Title Region

About....: information on the browser.

Exit: returns to the phone's home page.

Configuring WAP parameters

Select the **Advanced...** menu, then the **Settings** menu.

Profiles is used to select or modify your access provider's logon parameters or configure the parameters of other access providers.

The active profile is preceded with a star.

The **Menu** is used to add a new profile or to display the memory size available.

Configuration of GSM and GPRS parameters:

All information to be entered in the parameters are provided by your operator or access provider.

On a profile in the list, press **[Options]**, select **Modify**. The different parameters are: Provider title, Home page, Preferred connections (see next page), GSM parameters and GPRS parameters (see next page).

Preferred connections:

- GSM if not GPRS (by default): the logon to WAP services uses the GPRS as a priority. However, in the event of unavailability of the GPRS network, the GSM network is used to establish the link.
- GPRS: the logon to WAP services uses the GPRS network exclusively.
- GSM: the logon to WAP services uses the GSM network exclusively.

GSM parameters:

- Login
- Password
- IP address of WAP gateway
- Port type (secure or insecure)
- Dial-up number
- Mode (digital, analog or automatic)

GPRS parameters:

- Login
- Password
- IP address of WAP gateway
- Port type (secure or insecure)
- APN: if no APN has been defined, press **[Options]** then the APN menu. Select or add an APN.

Once all the settings have been entered, you can activate the chosen access provider. Select him from the list. Validate your choice.

Linger timer is used to choose the time after which the call is automatically disconnected if you have forgotten to log off from a service.

WAP Logging on

The connection to a WAP service on the GPRS network is not cut if an incoming call is received. You can answer the call.

Using the **Welcome** menu, you can log onto your access provider's WAP site by pressing the  key.

If you are logging onto the GSM or GPRS network, the @ symbol flashes, the metering of the cost of the call starts as soon as it stops flashing.

Downloading objects

Some WAP sites allow you to download ringtones, icons, animated screensavers, games or Java™ applications. Once downloaded, they are stored in your phone's memory. You can then save them in your phone (same operation as used for downloading using messages).

WAP Logging off

To log off, press the  key. The logoff happens automatically after a few seconds of inactivity if you forget to log off. This period is defined by the linger time setting.

GPRS

A flashing icon indicates that the phone is logging onto a GPRS network.

A non-flashing icon indicates that the GPRS network is available; if the icon is dark, it indicates that the phone is logged onto the GPRS network.

As long as the phone is logged onto the GPRS network, the phone can not send or receive any group call any more even emergency call.

This icon is not displayed if the GPRS network is not available or if the SIM card inserted in your phone does not include the GPRS service. It may also disappear when accessing WAP services if the connection uses the GSM network instead of the GPRS network.

Applications



ToDo

ToDo menu

This menu allows you to add ToDo's, access category-based Todo management and delete all the ToDo's.

On the **Applications** menu, please select **ToDo** and press **[OK]**.

Select one of the actions in the list with the navigation stick and validate.

- **Add Written ToDo/Add Vocal ToDo:** allows you to add ToDo of the text or voice type. Fill in the different items. Save the ToDo.
- **Categories:** allows you to see the different ToDo categories, assign a specific ring tone to each individual ToDo, know the number of ToDo's in each category and see them.
- **Memory:** allows you to view the memory used by the different functions of your ToDo.
- **Synchronize:** allows you to synchronise a ToDo with a computer.

ToDo actions menu

This menu allows you to do all the actions possible on any ToDo.

On the **Applications** menu, please select **ToDo**.

To display a ToDo, select it in the list and press the navigation stick.

To display the different options, press **[Options]**.

- **Modify ToDo:** allows you to modify the ToDo properties.
- **Delete:** allows you to delete the ToDo.
- **Send By:** allows you to send the Vcalendar corresponding to the task by MMS, Bluetooth.

Sending a vCal

A Todo task contains a task of your timetable that can be sent through a vCalendar.

You can send vCals to another phone using MMS.

On the task list (Todo main menu), please select a task and in the Todo task actions menu list select **Send By**.

Please select your contact information (phone number or Email address) before confirming.

If you receive a call while you are sending a vCal, the call will have precedence.

Receiving a vCal

By MMS, you receive a message you have to open to extract the vCal. You cannot add the event to your diary until you have saved it.

You can assign a different beep to each Todo task.

You can also assign a different ring tone to each Todo task category.

Data exchange with a PC

Working from a PC, you can save/edit contacts, events and tasks stored in your phone.

To do this, you will need to connect your phone to the PC by means of a suitable data cable.

Next, you will have to install the Wellphone software optionally supplied with your phone. This software will also enable you to save your contacts, events and tasks by means of copy/paste.

Working from a PC, you can save/edit pictures and ring tones not copyrighted stored in your phone.

To do this, you will need to connect your phone to the PC by means of a suitable data cable.

Next, you will have to install the "My Pictures and Sounds" software (available from www.mobilemediacorner.com site).

Note: If a call comes in during an exchange of data with your PC, the link will be interrupted and will have to be manually re-started.

Services

Calculator

This menu allows you to use your phone as a calculator.

On the **Applications** menu, please select the **Calculator** menu and [OK].

Use the navigation stick to make calculations:

- **Upwards:** Add
- **Downwards:** Subtract
- **Rightwards:** Multiply
- **Leftwards:** Divide

The following keys are used for:

-  : Equals or convert
-  : Delete
-  : Decimal point.

*If no calculations are being run, pressing [Convert] allows you to use the value in the **converter** directly.*

Converter

This menu allows you to convert one currency to another.

On the **Applications** menu, please select the **Converter** menu and [OK].

Enter a value and move the navigation stick upwards to convert from one currency to another, or downwards to convert back.

Pressing [Options] allows you to use the following options:

Rapid exchange

If the Rapid exchange is activated, the converter will work in the initial screen by entering the desired numbers and pressing the navigation stick to convert.

Exchange rate

Enter the exchange rate corresponding to the chosen currency.

Currency

Enter the two types of currency to be converted.

Go to calculator

This option allows you to use immediately the value converted in the **calculator**.

Alarm

This menu allows you to set and activate the alarm.

On the **Applications** menu, please select the **Alarm** menu and [OK].

Activate or **Deactivate** the alarm and validate.

Set the wake-up time by entering the numbers directly and validate.



The alarm icon appears on the initial screen.

The alarm works even when the phone is switched off.

Timer

This menu is used to set and activate the timer.

On the **Applications** menu, please select the **Timer** menu and [OK].

Activate or **Deactivate** the alarm and validate.

Set the duration (hours/minutes) by entering the numbers directly and validate.



The alarm icon appears on the initial screen.

Organizer



This menu gives you access to your diary and get to a day, week, month or specific date. It lets you add events, access the global actions for all the events and manage them by event category.

Calendar menu

This menu lets you add events, manage events by category, see the available memory and delete all the events.

From the **Organizer** menu, select the **Calendar menu**.

- **Add Written Event/Add Vocal Event:** allows you to add events of the text or voice type. Fill in the different items. Save the event.
- **Delete:** allows you to schedule the deletion of events that took place more than one day, week or month ago.
- **Memory:** allows you to view the memory capacity used by the different functions of your diary.
- **Delete all:** allows you to delete all the events from your diary.
- **Categories:** allows you to see the different event categories, assign a specific ring tone to each individual category, know the number of events in each category and see them.
- **Synchronize:** you can synchronize your organizer with your archives stored in your operator's network depending on the options offered by your operator.
The local synchronisation with your computer is only computer originated, from Wellphone software (optional); you have only to activate Bluetooth, or configure your USB connection in your phone.

The other menus are:

- **See month:** allows you to access events on a month-by-month basis.
- **See week:** allows you to access events on a week-by-week basis.
- **See today:** allows you to access the events for the current day and the actions possible on any event (see, modify, delete and send).
- **See date:** allows you to access events at a specific date.



Customise (PIN2)

This menu allows you to customise your phone.

Sounds

Volume and ring tone

This menu allows you to allocate a ring tone to different functions.

On the **Sounds** menu, please select the **Ring tones** menu and [Select].

Select the function on which you want to choose a ring tone.

Select the ring tone from the proposed list and validate.

Note: in the list, there are the phone default ring tones and also the ring tones downloaded in **Multimedia/My Sounds**.

Adjust the volume using the navigation stick and validate.

You can deactivate the sound by pressing the  key.

Vibrate

This menu allows you to activate the vibrate mode for calls.

On the **Sounds** menu, please select the **Vibrate** menu and [Select].

Select the vibrate mode from the proposed choices and validate.

Sound profile

This function is used to rapidly change the different mobile volumes (receiver, beep tone, hands free kit, ring tone).

This function can be accessed via the side volume buttons.

To change the volumes, set the receiver, beep tone and ring tone levels to Automatic.

Silent mode

This menu allows you to switch to Silent mode.

On the **Sounds** menu, please select **Silent mode** and [Select].

Activate or **deactivate** Silent mode and validate.

Silent mode can also be accessed via the initial screen by holding down the  key.

 *When the phone is in silent mode, the relevant icon appears on the initial screen.*

In this mode, the ring tone will not function, except for the alarm clock.

Note: if you have activated the silent mode, it does not remain after switching off your phone.

Beeps

This menu allows you to activate a beep for the battery, the keypad or the network.

On the **Sounds** menu, please select the **Beeps** menu and **[Select]**.

Select the type of beep you want to allocate from the proposed choices and validate. Activate or deactivate the beep and validate.

If you select keypad beeps, different options are given.

Recorder

These menu allows you to record you own melody.

On the **Sounds** menu, please select the **Recorder** menu and **[Select]**.

Pressing **[Start]** record your melody or your voice by means of the microphone then save it.

Give it a name and validate. The new tone is saved in the list of ringtones and in **Multimedia/My Sounds**.

If you select the recorder by means of a programmable key, the sound is saved in the **Applications/ToDo** menu.

Security

This menu allows you to configure your phone's security settings.

Keypad locking

This menu allows you to lock the keypad to avoid unwanted key presses.

On the **Security** menu, please select the **Keypad locking** menu and **[Select]**.

Select **Activate** or **deactivate** and validate.

 The lock icon appears on the initial screen.

*This function is also available in the initial screen pressing the  key and the  key or the **OK** key.*

PIN number

This menu allows you to activate and modify your phone's PIN.

On the **Security** menu, please select the **PIN number** menu and **[Select]**.

To modify the PIN, select **Modify PIN** and **[Select]**.

Enter old PIN and validate.

Enter new PIN twice and validate.

To activate or deactivate the PIN, select the **Control PIN** menu and **[Select]**.

Enter PIN and validate.

Select **Activate** or **Deactivate** and validate.

PIN2 number

You have a second PIN number to allow you to access certain functions.*

** These functions may or may not be available depending on your SIM card.*

Proceed as above in order to activate, deactivate or modify PIN number 2 of your phone.

Phone code

The Phone code menu allows you to activate the phone code so that it is requested and checked whenever the phone is switched on if a different SIM card is used. This code is automatically linked to the SIM card installed when the phone is activated, for example to protect the phone if stolen.

To activate or deactivate the phone code, select the **Phone code** menu and validate.

Enter 0000 (the factory code, by default) and validate.

Select **Activate** or **Deactivate** and validate.

To modify the phone code, select **Modify** and validate.

Enter old phone code and validate.

Enter new phone code and validate.

Enter phone code again to confirm it and validate.

Confidentiality

The Confidentiality function is used to delete last call numbers, messages, organiser events or short code dialed number when a new SIM card is inserted into the phone.

This menu allows the activation of automatic deletion, after power off/on, for messages and/or calls stored in the phone.

On the **Security** menu, please select the **Confidentiality** menu and [Select].

Select Calls, Messages, Organizer or Short code dialing. Select **Activate** or **Deactivate** and validate.

Operator

This menu allows you to modify the call barring.

On the **Security** menu, please select the **Operator** menu and [Select].

Access to this service depends on your type of subscription.

Call barring

Call barring can be applied to ALL calls (incoming and outgoing), to all incoming calls when you are away from your home country (if roaming available).

This menu allows you to block the sending or reception of certain calls.

Before you can use this service, a password will be provided by your operator when you take out your subscription.

On the **Security** menu, please select the **Call barring** menu and **[Select]**.

Select **Activate** or **Deactivate** and validate.

Access to this service depends on your subscription type.

Fixed dialling

This menu allows you to restrict the outgoing calls. The availability of this menu depends on your SIM.

On the **Security** menu, please select the **Fixed dialling** menu and **[Select]**.

Enter PIN2 number and validate.

Select **Activate** or **Deactivate** and validate.

Proceed as for any other phonebook.

When activating this function, only the numbers stored in the phonebook can be called.

This phonebook is linked to the SIM card, and its size depends on the card's capacity.

Cost

This menu allows you to control the cost of your calls (). (Operator-dependent service).*

On the **Security** menu, please select the **Cost** menu and validate.

The **Cost** menu (*) lets you check the cost of the last call you made and of all the calls you made since you last deleted them.

The **Delete costs** menu (*) lets you delete the cost of your last call and reset the cost counter after entering your PIN 2 code.

(*) WARNING

Depending on how the networks and associated subscription cards are configured, some functions may be unavailable (these are marked out with *).

WAP settings

This menu allows you to set various parameters needed for WAP connection.

On the **Settings** menu, please select **WAP settings** and **[Select]**.

You can add or modify URL addresses.

Call forward

Depending on your subscription, this service allows you to forward incoming calls to a different number or to the voice mailbox.

On the **Calls** menu, please select the **Call forward** menu and **[Select]**.

Choose the type of forwarding you want from the options available.

Display numbers

This menu allows you to modify the status of the display number function.

On the **Customise** menu, please select the **Display number** menu and **[Select]**.

Select one of the options given: Anonymous mode, My number, Callers' number.

Anonymous mode

You have the facility to mask your number on the phone of the person you are calling.

- **Preset:** network default mode.
- **Yes:** you choose to active anonymous mode and then not to display your number.
- **No:** you choose not to activate anonymous mode and then to display your number.

Voicemail

This function is used to record your answer phone number.

This number will be used during a call to the voice mailbox using the programmable keys.

On the **Customise** menu, please select the **Voicemail** menu and **[Select]**.

Enter your answer phone number and validate.

Blacklist

The blacklist is used to limit failures on automatic calls (calls generated by the automatic redial function or by applications: data, fax for example).

On the **Customise** menu, please select the **Blacklist** menu and **[Select]**.

When several automatic calls failed with a number (number busy or unknown), this number is put in the blacklist and no automatic call will be done with this number any more until you delete it from the blacklist.

Note: this function does not apply to the calls performed manually.

Local info.

This menu is used to activate reception of local information broadcast by the network.

You can choose whether you want to receive this information or not (please contact your network provider).

On the Messages menu, please select the **Local info.** menu and **Select**.

Activate Menu

The menu allows optional automatic Activation of the Customise menu when the appliance is switched on.

Working from the **Customise** menu, choose the **Select** option in the **Activate Customise** menu.

Activate or de-Activate the menu using the PIN2 code, and confirm.

Call waiting

(Operator-dependent service) During a call, you may be informed that a caller is trying to reach you: you hear a special tone. The caller's identity is displayed on the screen (name or number).

On the **Customize** menu, please select the **Call waiting** menu and **[Select]**.

You can **activate**, **deactivate**, or consult the **status** of the call waiting service in order to check if it is active or not.

During a call, if a second caller tries to contact you, the screen displays the call warning.

Calls

The Calls menu allows you to manage all the calls functions (view last calls, counters, call waiting, etc.).

View last calls

This menu allows you to access the list of last numbers used.

On the **Calls** menu, please select the **View last calls** menu and **[Select]**.

For every phone call are displayed on the screen:

- its characteristics (shown with an icon),
- the time (or date),
- its duration.

Select a call from the list and validate.

Select one of the options given: Call, Store in your phonebook, Send a message, Delete, Delete all.

You can also make the call by pressing the  key.

Fast access to the list of calls from the initial screen: press the  key.

Counters

This menu allows you to consult the duration of the up calls.

It can also be used to check the volume of data exchanged in GPRS.

On the **Calls** menu, please select the **Counters** menu and **[Select]**.

Networks

This menu allows you to configure network preferences.

On the **Settings** menu, please select the **Networks** menu and **[Select]**.

Choose **Selection** to activate (automatically or manually) one of the networks accessible in the area in which you are located.

Choose **Preferred** to view all the pre-registered networks.

Multimedia

All downloaded objects are stored in the **Multimedia** menu.

My Pictures

This menu gives you access to the pictures you have downloaded.

On the **Multimedia** menu, please select the **My Pictures** menu and **[Select]**.

Select **[Options]** allows you to delete all the pictures.

On a picture selected, you can press **[Options]** to have access to these various options:

- **Send By:** makes it possible to transmit a picture (NB: you may not send any copyrighted picture).
- **Use as:** allows you to use the picture as a wallpaper or screen saver.
- **Rename:** allows you to rename a picture.
- **Properties:** properties of the picture selected.
- **Delete:** allows you to delete a picture.
- **Delete all:** allows you to delete all pictures.

You can import or export pictures to or from a computer using My Pictures And Sounds (MPAS), available from www.mobilemediacorner.com.

My Sounds

This menu gives you access to the sounds you have downloaded or recorded.

On the **Multimedia** menu, please select the **My Sounds** menu and **[Select]**.

Select **[Options]** allows you to delete all the sounds or to record a new sound.

To display the different options, press **[Options]**.

- **Send By:** allows you to send a sound by MMS or Bluetooth.
- **Use as:** allows you to add a sound to the ring tones list.
- **Rename:** allows you to rename a sound.
- **Properties:** properties of the sound selected.
- **Delete:** allows you to delete a sound.
- **Delete all:** to delete all the sounds.
- **New Sound:** allows you to record a new sound.

You can import or export sounds to or from a computer using My Pictures And Sounds (MPAS), available from www.mobilemediacorner.com.

Memory

This menu indicates the memory size used by the different features of your phone.

On the **Multimedia** menu, please select the **Memory** menu and **[Select]**.

Use the navigation stick to select the different features using memory. You can see the memory capacity used by each individual feature.

Languages

This menu allows you to choose your phone's display language.

On the **Settings** menu, please select the **Languages** menu and **[Select]**.

Select your language and validate.

If you select **Automatic**, the language used will be the one relative to your SIM card.

Energy saving

On the **Settings** menu, please select the **Energy saving** menu and **[Select]**.

Two options are available to choose from for the backlight:

- Screen only: only the screen is lit up.
- Full backlight: both the screen and the keypad are lit up.

Note: in any case, after a certain time of inactivity, the backlight will be automatically turned off to save battery life.

After a longer period of inactivity, the screen will enter an economy mode where the time is displayed. To quit this sleep mode and resume backlight, press the  key.

Contacts

This menu allows you to select the way to sort contacts in the phonebook (by name or first name) and the filter applied on the contacts list display (SIM contacts, phone memory or both).

Select one of the options given.

Shortcuts

This menu allows you to customize of your phone to make it as convenient as possible for you to use.

This menu allows you to allocate functions to the programmable keys:   .

It exists 3 types of programmable keys :

- Programmable keys : white, yellow, green, blue and Left Key.
- Digital keys (0-9)

Automatic update

On the **Settings** menu, please select the **Shortcuts** menu and **[Select]**.

Select the key that you wish to modify and validate.

Choose the function that you want to allocate to this key and validate.

Short code dialling

This menu allows you to attribute a specific contact to each digital key of the keyboard (0 to 9) in order to quickly dial the contact number. This contact can be chosen in the Phonebook or in the group list.

To initiate this call, in the welcome screen, you just have to press the relevant digital key(0 to 9) then the  key.

In the **Shortcuts** menu, select **Numeric keys** and **[Enter]**

Choose the digital key between 0 and 9 you want to attribute a shortcut and press OK. If a number or a group call is already attributed, the shortcut is written below the key number, otherwise (Inactive) is written.

Once the key is selected, choose the shortcut between

contact in Phonebook (PTP choice),

group call (VGCS choice),

broadcast call (VBS choice)

then press **Validate**.

Date / Time

Set Date/Time

This menu allows you to set the date and time of your phone.

On the **Date / Time** menu, please select **Set Date/Time** and **[Select]**.

Date: set the date by entering it directly in digital form or by using the navigation stick.

Use the navigation stick to access the next (or previous) entry field.

Once the date is correct, validate it.

Time: same procedure as for setting the date.

Automatic update

This menu allows you to choose manual or automatic updating of date and time (after switch off of your phone or when going abroad for instance) (service depending on the operator).

From the **Date / Time** menu, please select **Automatic upda.** and **[Select]**.

Please select Automatic, Manual or On demand and press **[Select]**.

Display

This menu allows you to select the date and time display type.

On the **Date / Time** menu, please select **Display** and **[Select]**.

In the list that appears, select the desired display type between:

- Digital,
- None,

by using the navigation stick and validate.

Time zone

This menu allows you to change time in relation to the GMT time.

On the **Date / Time** menu, please select **Time zone** and **[Select]**.

Choose the time of the country desired by calculating the time from the GMT time.

Daylight savings

This menu allows you to set your phone to the summer/winter time.

On the **Date / Time** menu, please select **Daylight savings** and **[Select]**. Select 1 h, 2 h **Summer time** or **Winter time** depending on the season, and validate.

Help

This menu allows you to activate or deactivate the display of the help in the phone.



You can exchange with other devices (PC, mobile phones, personal assistants, printers, etc.) various data: pictures, sounds, photos, To Do tasks, organiser events, contacts, etc.

Data exchange can be done through:

- USB cable,
- a Bluetooth connection.

If you want to exchange objects between the phone memory and a PC, you must install the Wellphone software provided on CD (optional): select Multimedia to open, from the PC, the phone files explorer.

To save contacts, events or tasks, the Wellphone software, provided on the CD with your phone (optional), must be installed on a PC.

You can read more details about Phonebook or Calendar in chapters **Phonebook** and **Organizer**.

Note: If a call comes in during an exchange of data with your PC, the link will be interrupted and will have to be manually re-started.

Bluetooth

This menu allows you to set your phone Bluetooth connection in order to communicate with other devices equipped with Bluetooth: for example, an audio connection with a pedestrian kit, a car kit or a data connection with a PC.

Bluetooth is a free wireless connection, with a 10 metre maximum range.

Paired devices: allows you to search for devices which may connect with Bluetooth link with your phone (for instance: headset).

Mode: allows you to activate the phone Bluetooth connection.

- Off: Bluetooth connection impossible.
- On and hidden: your phone is not detected by the other devices but the phone detects the other devices.
- On and visible: your phone can be detected by another device.

My Bluetooth name: allows you to assign a name to your phone for the Bluetooth connection. This name is displayed on the devices connected.

Serial speed

This menu enables you to select the speed to be used for data exchanges via your phone's serial port. Except for specific requirements, it is advisable to stick to the default setting: **Automatic**.

Car kit

This menu allows you to configure the options of the phone with a pedestrian kit or a car kit (Automatic response, Switch off, Kit volume).

SyncML

You can synchronize your phonebook, your organizer or your ToDos with your archives stored in your operator's network depending on the options offered by your operator.

The local synchronisation with your computer is only computer originated, from Wellphone software (optional); you have only to activate Bluetooth, or configure your USB connection in your phone.

Technical features

Weight: 230g

Size: 142 x 60 x 36 mm

Original battery: Lithium ion 2600mAh

Battery life calls/standby: up to 7h30/450h (these values are theoretical ones and given for information only)

Multimedia objects supported:

- Audio formats: wave
- Graphic formats: wbmp, bmp, png, gif, animated gif, jpeg

Size of memory available for messages: up to 200 SMS

Size of memory available for the phonenook and the multimedia objects: 3.0 MB

Maximum size of each message:

- SMS < 160 characters
- MMS < 100 kB for outgoing, 100 kB for incoming messages (depends on the phone configuration and on the operator reservations)

Using temperature: from - 10 °C to + 55 °C.

Charging temperature: from 0 °C to + 40 °C.

CE Conformance Document

CE marking attests to the conformity of this product to the basic requirements of directive 1999/5 /EC of the European Parliament and Council on radio equipment and telecommunications terminal equipment, as regards the safety and health of users and radio-wave interference. In addition, it effectively uses the spectrum allocated to terrestrial/space radio communication resources so as to avoid harmful interference.

The compliance statement may be requested from the following address:

Sierra Wireless SA
5, boulevard Gallieni
92442 Issy-les-Moulineaux Cedex - FRANCE

Care and safety information

SAR

THIS MODEL MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves recommended by international guidelines. These guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health.

The guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2 W/kg and the highest SAR value for this device when tested at the ear was 1.25 W/kg (*). As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this user guide (**).

As SAR is measured utilizing the devices highest transmitting power the actual SAR of this device while operating is typically below that indicated above. This is due to automatic changes to the power level of the device to ensure it only uses the minimum level required to reach the network.

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure then you can do so by limiting the length of calls or using a 'hands-free' device to keep the mobile phone away from the head and body. Additional Information can be found on the websites of the World Health Organization (<http://www.who.int/emf>).

Advice for limiting exposure to radiofrequency (RF) fields

For individuals concerned about limiting their exposure to RF fields, the World Health Organization (WHO) provides the following advice:

Precautionary measures: Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If individuals are concerned, they might choose to limit their own or their children's' RF exposure by limiting the length of calls, or using "hands-free" devices to keep mobile phones away from the head and body.

Further information on this subject can be obtained from the WHO home page <http://www.who.int/peh-emf> WHO Fact sheet 193: June 2000.

(*) The tests are carried out in accordance with international guidelines for testing.

(**) Please see the Safety section about body worn operation.

Safety

Never attempt to disassemble your phone. You alone are responsible for how you use your phone and any consequences of its use.

As a general rule, always switch off your phone wherever the use of a phone is prohibited.

Use of your phone is subject to safety measures designed to protect users and their environment.

Do not use your phone in damp areas (bathroom, swimming pool...). Protect it from liquids and other moisture.

Do not expose your phone to extreme temperatures lower than -10°C and higher than $+55^{\circ}\text{C}$.

The physicochemical processes created by chargers impose temperature limits when charging the battery. Your phone automatically protects the batteries in extreme temperatures.

Do not leave your phone within the reach of small children (certain removable parts may be accidentally ingested).

Electrical safety

Only use the chargers listed in the manufacturer's catalogue. Using any other charger may be dangerous; it would also invalidate your warranty. Line voltage must be exactly the one indicated on the charger's serial plate. The charger must be used near the phone and must be easily reachable.

Aircraft safety

When travelling by plane, you will need to switch your phone off when so instructed by the cabin crew or the warning signs.

Using a mobile phone may be dangerous to the operation of the aircraft and may disrupt the phone network.

Its use is illegal and you could be prosecuted or banned from using cellular networks in the future if you do not abide by these regulations.

Explosive materials

Please comply with warning signs at petrol station asking you to switch your phone off. You will need to comply with radio equipment usage restrictions in places such as chemical plants, fuel depots and at any location where blasting operations are under way.

Electronic equipment

To avoid the risk of demagnetisation, do not let electronic devices close to your phone for a long time.

Electronic medical equipment

Your phone is a radio transmitter which may interfere with electronic medical equipment or implants, such as hearing aids, pacemakers, insulin pumps, etc. It is recommended that a minimum separation of 15 cm be maintained between the phone and an implant. Your doctor or the manufacturers of such equipment will be able to give you any advice you may need in this area.

Hospitals

Always make sure that your phone is switched off in hospitals when so instructed by warning signs or by medical staff.

Road safety

Do not use your phone when driving. In order to give your full attention to driving, stop and park safely before making a call. You must comply with any current legislation.

Distance of operation

This phone model has been tested and meets radiofrequency exposure guidelines when used as follows:

- against the ear: place or receive a phone call and hold the phone as you would a wireline telephone,
- body worn: when transmitting, place the phone in a carry accessory that contains no metal and positions the phone a minimum of 2.5 cm from your body. Use of other accessories may not ensure compliance with radiofrequency exposure guidelines. If you do not use a body worn accessory and are not holding the phone at the ear, position the phone a minimum of 2.5 cm from your body,
- data operation: when using a data feature, position the phone a minimum of 2.5 cm from your body for the whole duration of the data transmission.

Environment

Packaging

To facilitate the recycling of packaging materials, please obey the sorting rules instituted locally for this type of waste.

Batteries

Spent batteries must be deposited at the designated collection points.

The product



The crossed-out waste bin mark affixed to the product means that it belongs to the family of electrical and electronic equipment.

To promote the recycling and recovery of waste electrical and electronic equipment (WEEE) and at the same time safeguard the environment, European regulations require you to obey the sorting rules instituted locally for this type of waste.

Warranty

You must always use your phone for the purpose for which it was designed, under normal operating conditions. Sierra Wireless SA declines all responsibility for any use outside of the scope of its designed purpose and for any consequences of this use.

The software program developed by Sierra Wireless SA remains the exclusive property of Sierra Wireless SA. It is therefore highly prohibited to modify, translate, de-compile or disassemble this software program or any part thereof.

Usage precautions

Your phone allows you to download ring tones, icons and animated screensavers. Some of these items may contain data that may cause malfunctions of your phone or data losses (virus for example).

For this reason, Sierra Wireless SA rejects all responsibility concerning (1) the reception of downloaded data or losses of the said data, (2) the impact on the operation of the phone and (3) damages resulting from receiving the said downloaded data or loss of said data. In addition, Sierra Wireless SA states that a failure caused by receiving downloaded data that do not comply with the specifications set by Sierra Wireless SA is excluded from the warranty. Consequently, the diagnosis and repair of a phone infected by the said downloaded data will be at the expense of the customer.

Any content that you download to your phone may be protected by copyright belonging to third parties and consequently you may not have the right to use this content or its use may be restricted. Consequently it is up to you to ensure that you have permission, such as under the terms of a license agreement, to use any content that you download. Furthermore, Sierra Wireless SA does not guarantee the accuracy nor the quality of any content that you download. You alone are responsible for the content that you download to your mobile phone and how you use it. Sierra Wireless SA cannot be held responsible for this content nor for its use.

It is your responsibility to ensure compliance, at your own expense, with the laws and regulations applicable in the country where you use your phone.

Warranty conditions

Whenever you wish to make use of the warranty, please contact your vendor and present him with the purchasing paperwork that he gave you.

If a fault occurs, he will advise you.

1.

The new phone (excluding consumables), including new accessories bundled with the phone, are guaranteed by Sierra Wireless SA, parts and labour (apart from travel) against any manufacturing fault for a period of twelve (12) months with effect from the sale of the phone to the customer, on presentation of the paperwork stating the purchase date of the phone.

Phones that have been repaired or replaced as standard during the warranty period stated above are guaranteed (parts and labour) until the later of these two dates:

Expiry of the guarantee period of twelve (12) months stated above or three (3) months with effect from the date of support provided by Sierra Wireless SA.

Your legal rights under the terms of applicable national law as well as your rights in relation to your retailer, as set out in the sales contract, remain applicable and are not in any way affected by this guarantee.

In any disputes, the phone is covered by the legal warranty against the consequences of faults or hidden defects in compliance with articles 1641 and subsequent of the French civil code.

2.

All faulty phones under warranty will be replaced or repaired free of charge at Sierra Wireless SA' option (with the exclusion of repair of any other damage), once it has been specified that the work required for the application of the warranty will be done in a workshop and that the return costs (transport and insurance) of the phone to the address to be indicated to it by the Sierra Wireless SA after-sales service, whose phone number will appear on the delivery note, will be charged to the customer.

Subject to essential legal provisions, Sierra Wireless SA does not accept any warranty, explicit or implicit, other than the warranty provided expressly in this chapter, nor shall Sierra Wireless SA accept responsibility for any immaterial and/or indirect damages (such as loss of orders, loss of profit or any other financial or commercial damage) under the warranty or not.

3.

The acceptance of a phone under warranty demands that a purchase document that is legible and without modification, stating vendor's name and address, date and place of purchase, type of phone and IMEI, are attached to the warranty, and that the information on the phone identification label is legible and that this label or any other seal has not been tampered with.

The warranty applies in normal conditions of use.

Prior to sending the phone for repair, it is the customer's responsibility to backup at his expense the customized data stored in the phone (phonebook, settings, wallpapers). A list of backup facilities can be provided by Sierra Wireless SA on request. The responsibility of Sierra Wireless SA cannot be invoked if damage occurs to customer files, programs or data. The information or operating elements and the contents of files will not be re-installed in any case in the event of loss.

Sierra Wireless SA may decide, at its option, to repair the phone with new or reconditioned parts, replace the phone with a new phone or, in any dispute, a phone in good working condition. During its work Sierra Wireless SA reserves the facility to make, where necessary, any technical modifications to the phone where these modifications do not adversely affect its initial purpose.

Faulty parts to be replaced during a repair under warranty will become the property of Sierra Wireless SA.

The phone repair and standstill time during the warranty period may not lead to an extension of the warranty period as stated

in article 1 above, provided no other vital provisions have been agreed.

The application of the warranty is subject to the full payment of the sums due for the phone when the request for support is made.

4.

The following are excluded from the warranty:

Breakdowns or malfunctions due to non-compliance with the installation and use instructions, to an external cause of the phone (shock, lightning, fire, vandalism, malice, water damage of any type, contact with various liquids or any harmful agent, unsuitable electric current...), to modifications of the phone made without the written consent of Sierra Wireless SA, to a servicing fault, as described in the documentation supplied with the phone, to lack of supervision or care, to poor environmental conditions of the phone (especially temperature and hygrometry, effects of variations in electric voltage, interference from the mains network or earth) or even due to a repair, a call-out (opening or trying to open the phone) or to servicing done by personnel not approved by Sierra Wireless SA.

Damage resulting from inadequate packaging and/or poor packing of the phone sent back to Sierra Wireless SA.

Normal wear and tear of the phone and accessories.

Communication problems linked with a poor environment, especially:

Problems accessing and/or logging onto the Internet, such as breakdowns of the access network, the failure of the subscriber's or his correspondent's line, transmission fault (poor geographic coverage by radio transmitters, interference, disturbance, failure or poor quality of phone lines...), a fault inherent to the local network (cabling, file server, user phone) and/or transmission network fault (interference, disturbance, failure or poor quality of the network...).

Change of parameters of the cellular network made after the phone was sold.

Supply of new software versions.

Current servicing work: delivery of consumables, installation or replacement of these consumables...

Call-outs for phone or software modified or added without the written consent of Sierra Wireless SA.

Faults or disruptions resulting from the use of products or accessories not compatible with the phone.

Phones returned to Sierra Wireless SA without having complied with the return procedure specific to the phone covered by this warranty.

The opening or closing of a SIM operator key and call-outs resulting in the non-operation of the phone resulting from the opening or closing of SIM operator key done without the agreement of the original operator.

5.

In the cases of warranty exclusion and of expiry of the warranty period, Sierra Wireless SA shall draw up an estimate to be given to the customer for acceptance before any call-out. The repair and carriage costs (there and back) given in the accepted estimate will be charged to the customer.

These provisions are valid unless a special written agreement has been made with the customer. If one of the provisions turns out to infringe a legally essential rule that consumers could have the benefit of under the national legislation, this provision will not be applied, but all other provisions will remain valid.

End User Licence Agreement (EULA), for the software

CONTEXT AND ACCEPTATION OF THE AGREEMENT

You have acquired a Mobile Phone device ("DEVICE"), manufactured by Sierra Wireless SA, that includes software either developed by Sierra Wireless SA itself or licensed third party Software suppliers ("SOFTWARE COMPANIES") to Sierra Wireless SA with the rights to sub-license it to the purchaser of the device. Those installed software products whatever their company of origin, and wherever the name of the company of origin is indicated of not in the DEVICE documentation, as well as associated media, printed materials, and "online" or electronic documentation ("SOFTWARE") are protected by international intellectual property laws and treaties. The SOFTWARE is licensed, not sold. All rights reserved.

IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT ("EULA"), DO NOT USE THE DEVICE OR COPY THE SOFTWARE. INSTEAD, PROMPTLY CONTACT SIERRA WIRELESS SA FOR INSTRUCTIONS ON RETURN OF THE UNUSED DEVICE(S) FOR A REFUND. ANY USE OF THE SOFTWARE, INCLUDING BUT NOT LIMITED TO USE ON THE DEVICE, WILL CONSTITUTE YOUR AGREEMENT TO THIS EULA (OR RATIFICATION OF ANY PREVIOUS CONSENT).

SOFTWARE includes software already installed on the DEVICE ("DEVICE Software") and Software contained on the CD-ROM disk ("Companion CD"), if any is supplied with the product.

GRANT OF SOFTWARE LICENCE

This EULA grants you the following licence:

DEVICE Software. You may use the DEVICE Software as installed on the DEVICE. All or certain portions of the DEVICE Software may be inoperable if you do not have and maintain a service account with an appropriate Mobile Operator, or if the Mobile Operator's network facilities are not operating or configured to operate with the DEVICE software.

COMPANION CD. If any is supplied, additional software for your personal computer is included with your DEVICE. You may install and use the software component(s) contained in the Companion CD only in accordance with the terms of the printed or online end user license agreement(s) provided with such component(s). In the absence of an end user license agreement for particular component(s) of the Companion CD, you may install and use only one (1) copy of such component(s) on the DEVICE or a single computer with which you use the DEVICE.

Security Updates. The SOFTWARE may include digital rights management technology. If SOFTWARE does contain digital rights management technology, content providers are using the digital rights management technology ("DRM") contained in the SOFTWARE to protect the integrity of their content ("Secure Content") so that their intellectual property, including copyright, in such content is not misappropriated. Owners of such Secure Content ("Secure Content Owners") may, from time to time, request manufacturers or SOFTWARE SUPPLIERS to provide security related updates to the DRM components

of the SOFTWARE ("Security Updates") that may affect your ability to copy, display and/or play Secure Content through the SOFTWARE or third party applications that utilise the DRM.

You therefore agree that, if you elect to download a licence from the Internet which enables your use of Secure Content, Suppliers may, in conjunction with such licence, also download onto your DEVICE such Security Updates that a Secure Content Owner has requested that SOFTWARE SUPPLIERS distribute. Sierra Wireless SA and SOFTWARE SUPPLIERS will not retrieve any personally identifiable information, or any other information, from your DEVICE by downloading such Security Updates.

DESCRIPTION OF OTHER RIGHTS AND LIMITATIONS

COPYRIGHT. All title and intellectual property rights in and to the SOFTWARE (including but not limited to any images, photographs, animations, video, audio, music, text and "applets," incorporated into the SOFTWARE), the accompanying printed materials, and any copies of the SOFTWARE, are owned by Sierra Wireless SA or the SOFTWARE SUPPLIERS. You may not copy the printed materials accompanying the SOFTWARE. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE is the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants you no rights to use such content. All rights not specifically granted under this EULA are reserved by Sierra Wireless SA and the SOFTWARE SUPPLIERS

Limitations on Reverse Engineering, Decompilation and Disassembly. You may not reverse engineer, decompile, or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation.

Single DEVICE. The DEVICE Software is licensed with the DEVICE as a single integrated product. The DEVICE Software installed in the memory of the DEVICE may only be used as part of the DEVICE.

Single EULA. The package for the DEVICE may contain multiple versions of this EULA, such as multiple translations and/or multiple media versions (e.g., in the user documentation and in the software). Even if you receive multiple versions of the EULA, you are licensed to use only one (1) copy of the DEVICE Software.

Software Transfer. You may not permanently transfer any of your rights under this EULA with regard to the DEVICE Software or Companion CD, except as permitted by the applicable Mobile Operator. In the event that the Mobile Operator permits such transfer, you may permanently transfer all of your rights under this EULA only as part of a sale or transfer of the DEVICE, provided you retain no copies, you transfer all of the SOFTWARE (including all component parts, the media and printed materials, any upgrades, this EULA and, if applicable, the Certificate(s) of Authenticity), and the recipient agrees to the terms of this EULA. If the SOFTWARE is an upgrade, any transfer must include all prior versions of the SOFTWARE.

Software Rental. You may not rent or lease the SOFTWARE.

Speech/Handwriting Recognition. If the SOFTWARE includes speech and/or handwriting recognition component(s), you should understand that speech and handwriting recognition are inherently statistical processes; that recognition errors are inherent in the processes; and that errors can occur in the component's recognition of your handwriting or speech, and the final conversion into text. Neither Sierra Wireless SA nor its suppliers shall be liable for any damages arising out of errors in the speech and handwriting recognition processes.

NOTICE REGARDING THE MPEG-4 VISUAL STANDARD. The SOFTWARE may include MPEG-4 visual decoding technology. MPEG LA, L.L.C. requires the following notice:

USE OF THIS SOFTWARE IN ANY MANNER THAT COMPLIES WITH THE MPEG-4 VISUAL STANDARD IS PROHIBITED, EXCEPT FOR USE DIRECTLY RELATED TO (A) DATA OR INFORMATION (i) GENERATED BY AND OBTAINED WITHOUT CHARGE FROM A CONSUMER NOT THEREBY ENGAGED IN A BUSINESS ENTERPRISE, AND (ii) FOR PERSONAL USE ONLY; AND (B) OTHER USES SPECIFICALLY AND SEPARATELY LICENSED BY MPEG LA, L.L.C.

If you have questions regarding this Notice, please contact MPEG LA, L.L.C., 250 Steele Street, Suite 300, Denver, Colorado 80206; Telephone 303 331.1880; FAX 303 331.1879

Termination. Without prejudice to any other rights, Sierra Wireless SA may terminate this EULA if you fail to comply with the terms and conditions of this EULA. In such event, you must destroy all copies of the SOFTWARE and all of its component parts.

Consent to Use of Data. You agree that SOFTWARE SUPPLIERS may collect and use technical information gathered in any manner as part of product support services related to the SOFTWARE. SOFTWARE SUPPLIERS may use this information solely to improve their products or to provide customised services or technologies to you. SOFTWARE SUPPLIERS may disclose this information to others, but not in a form that personally identifies you.

Internet Gaming/Update Features. If the SOFTWARE provides, and you choose to utilise, the Internet gaming or update features within the SOFTWARE, it is necessary to use certain computer system, hardware, and software information to implement the features. By using these features, you explicitly authorise SOFTWARE SUPPLIERS to use this information solely to improve their products or to provide customised services or technologies to you. SOFTWARE SUPPLIERS may disclose this information to others, but not in a form that personally identifies you.

Internet-Based Services Components. The SOFTWARE may contain components that enable and facilitate the use of certain Internet-based services. You acknowledge and agree that SOFTWARE SUPPLIERS may automatically check the version of the SOFTWARE and/or its components that you are utilising and may provide upgrades or supplements to the SOFTWARE that may be automatically downloaded to your Device.

Links to Third Party Sites. The SOFTWARE may provide you with the ability to link to third party sites through the use of the SOFTWARE. The third party sites are not under the control of Sierra Wireless SA. Neither Sierra Wireless SA nor its affiliates are responsible for (i) the contents of any third party sites, any links contained in third party sites, or any changes or updates to third party sites, or (ii) webcasting or any other form of transmission received from any third party sites. If the SOFTWARE provides links to third party sites, those links are provided to you only as a convenience, and the inclusion of

any link does not imply an endorsement of the third party site by Sierra Wireless SA or its affiliates.

Additional Software/Services. The SOFTWARE may permit Sierra Wireless SA to provide or make available to you SOFTWARE updates, supplements, add-on components, or Internet-based services components of the SOFTWARE after the date you obtain your initial copy of the SOFTWARE ("Supplemental Components").

If Sierra Wireless SA provides or makes available to you Supplemental Components and no other EULA terms are provided along with the Supplemental Components, then the terms of this EULA shall apply.

Sierra Wireless SA reserves the right to discontinue any Internet-based services provided to you or made available to you through the use of the SOFTWARE.

EXPORT RESTRICTIONS. You acknowledge that SOFTWARE is subject to U.S. export jurisdiction. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use and destination restrictions issued by U.S. and other governments.

UPGRADES AND RECOVERY MEDIA

- **DEVICE Software.** If the DEVICE Software is provided by Sierra Wireless SA separate from the DEVICE on media such as a ROM chip, CD ROM disk(s) or via web download or other means, and is labelled "For Upgrade Purposes Only", you may install one copy of such DEVICE Software onto the DEVICE as a replacement copy for the existing DEVICE Software and use it in accordance with this EULA, including any additional EULA terms accompanying the upgrade DEVICE Software.
- **COMPANION CD.** If any Companion CD component(s) is provided by Sierra Wireless SA separate from the DEVICE on CD ROM disk(s) or via web download or other means, and labelled "For Upgrade Purposes Only", you may (i) install and use one copy of such component(s) on the computer(s) you use to exchange data with the DEVICE as a replacement copy for the existing Companion CD component(s).

RESPONSIBILITIES

SUPPORT AND INFORMATION Should you have any questions concerning this EULA, or if you desire to contact Sierra Wireless SA for any other reason, please refer to the address provided in the documentation for the DEVICE.

NO LIABILITY FOR CERTAIN DAMAGES. EXCEPT AS PROHIBITED BY LAW, SIERRA WIRELESS SA SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE.

FOR APPLICABLE LIMITED WARRANTIES AND SPECIAL PROVISIONS PERTAINING TO YOUR PARTICULAR JURISDICTION, PLEASE REFER TO YOUR WARRANTY BOOKLET INCLUDED WITH THIS PACKAGE OR PROVIDED WITH THE SOFTWARE PRINTED MATERIALS.

You are the owner of a Sierra Wireless mobile phone which gives you the ability to download applications and games to be executed on your phone thanks to the built-in Java™ engine.

However, receiving applications from everywhere implies some basic knowledge of the possible effects of such download.

Thank you for spending a few minutes reading these pages: this will prevent you from performing action without measuring the consequences.

WARNING: When running a Java™ application, you may be prompted to grant access to protected features. These features are protected because using them could incur you cost, or involve your personal data. Read the security popup message carefully, to understand what feature is requested, and decide whether it is legitimate for the application to perform it. In case of doubt, don't hesitate to refuse access by selecting the "No" button!

The security configuration menu is an expert feature! You must know exactly what you are doing before attempting to change security parameters of a MIDlet. Misunderstanding changes may render MIDlet non functional and/or lead to higher risks for your private data or impact your airtime consumption. Any changes in the security configuration are done under your responsibility. In no case shall Sierra Wireless SA and/or your network provider be liable for any damages deriving from or arising out of such changes in the security configuration.

You must be aware that applications downloaded to your phone could cause the phone to perform actions for which you will be billed, like making calls and sending SMS. Depending on your operator's billing policy, you may also be charged to download the application because of airtime consumption.

Security considerations

Java™ MIDP technology is an efficient way to provide powerful applications in mobile phones. It allows use, by "over the air" downloaded applications or games, of the great features built-in in a mobile phone (SMS sending and receiving, multimedia playback and recording, network access...).

All these MIDP 2.0 features cannot be simply exposed to any MIDlet installed in the handset: a careful access control system is implemented in the device to protect your private data and airtime consumption.

Access controls are gathered in 9 security groups:

- Network access (GPRS/GSM data airtime consumption, HTTP/web connections...)
- Auto invocation (MIDlet can wake up at a given time or when receiving a SMS)

- Phone call (ability to initiate a phone call)
- Local connectivity (serial interfaces use by the MIDlet)
- Messaging receive (SMS, SMS-CB interception by a MIDlet)
- Messaging sending (SMS sending by a MIDlet)
- Read User data (Subscriber identity, Phonebook, Agenda read access from a MIDlet)
- Write User data (New phonebook or agenda entry)
- Multimedia recording (ability to control camera or microphone from a MIDlet)

According to the security status of an installed MIDlet (see below), each of these security groups has one among 5 possible authorizations levels (listed from the more restrictive to the more permissive):

- Never
The security group completely prevents access to the protected features.
- Per use
Each time MIDlet tries to use protected feature, user is prompted to grant access.
- Per session
First time a MIDlet uses a protected function, user is prompted to grant access like in "Per use" authorization but access is granted until the MIDlet terminates.
- Single confirmation
The first time in the whole MIDlet life a MIDlet uses a protected feature, user is prompted to grant access. It remains valid until the MIDlet is removed from the handset.
- Always
The security group unconditionally grants access to protected features.

A MIDlet has a security status which is either "uncertified", or else "certified".

An "uncertified" status means that the source of the MIDlet could not be verified by the mobile phone at installation time. As far as the phone knows, the MIDlet could have been written by anyone.

A "certified" status means that the MIDlet was digitally signed by a known party, whose name is displayed by the mobile phone. This means that the mobile phone successfully authenticated the named party as the source of the MIDlet.

Security permissions are different for "uncertified" or "certified" MIDlets, and may be different for different sorts of named parties. Usually "uncertified" security permissions are more restrictive than "certified" ones.

Security configuration menu

When a MIDlet is installed in the mobile phone, default security authorizations are applied.

This default security configuration may be altered through the "Settings/Security" menu of an installed MIDlet.

Once in the "Security" menu, the security status of the MIDlet is displayed (see "Security considerations" paragraph above).

If you do not want to enter the security menu, simply select "Back" button.

You can proceed by selecting "Ok" button.

The menu displayed allows you to increase or decrease permissions currently applied to the current MIDlet for each of the security groups.

When you set a more permissive authorization to a security group than the current value, mobile phone asks you to confirm your increased risk exposure.

The maximum risk exposure increase is limited by the security status. Depending of the manufacturing configuration, it means, for example, that "Net Access" security group authorization cannot be set to a permissive value higher than "Session" for an "uncertified" MIDlet ("Single confirmation" and "Always" are unavailable in the security configuration menu) but an operator "certified" MIDlet may have all permission values available without any limitations.



What is Java™?

Java™ is a new technology enabling use of powerful applications in the mobile phone area. Business applications and games are easily downloadable by the end-user on a Java™ featured handset.

Your mobile phone is a MIDP 2.0 compliant Java™ platform which implements WMA (SMS support) and MMAPI (Multimedia support) options, providing an exciting environment to run highly graphical, networked and intuitive MIDP applications.

Such applications may be, for example, a wide range of games and appealing applications like action and logic games, agenda, e-Mail reader, Web browser...

What is a MIDlet?

A Java™ application or a game designed to run in a mobile phone is named a MIDlet (MIDP applet).

A MIDlet is usually made of 2 files:

- The JAD file
- The JAR file

JAD file stands for Java™ Application Descriptor. It is a small file describing the content of a JAR file (version, vendor name, size...) and displayed by the mobile phone. **JAD file size is usually less than 2 kilo-bytes large.**

JAR file stands for Java™ Archive. It refers to the application data themselves (program, images, sound). **A JAR file may be up to 200 kilo-bytes large.**

Note: In rare circumstances, MIDlet vendors may provide no JAD file and the MIDlet is the JAR file alone. In such a case it is your only responsibility to evaluate the risk to download the JAR file without possibility of consulting the JAD file.

Downloading a MIDlet (Java™ game or application)

MIDlets are easily downloaded in the mobile phone through the Games or Applications menus or through the WAP browser.

In almost all cases, you will first receive a JAD file which will be displayed on the screen.

Much care must be given in examining the content of the file as explained further.

When you select a JAD file, your mobile phone downloads it, displays data contained and prompts you to acknowledge the JAR file download.

The popup displays information below:

- Name of the MIDlet
- Version
- Size (JAR file size)
- Vendor name
- Security status (**IMPORTANT:** see "Security considerations" paragraph below)
- JAR file URL.

If you do not want to download the main data (JAR file), you shall refuse to acknowledge further airtime consumption by selecting "Cancel" (JAR file is not downloaded).

If you agree on the MIDlet installation, just select "Ok". The MIDlet is installed with security levels set to default values associated with its security status.

Before downloading an application, such a message may appear: "Your handset cannot identify the application, please be sure of the source of the application before installing the application".

You shall read carefully the next two paragraphs to fully understand Java™ MIDP security concerns.

Trademarks

Java™ and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Disclaimer

As explained hereabove, some downloaded items may contain data or may induce actions which may cause malfunctioning of your mobile phone or loss or corruption of data or abnormal increase of your airtime consumption.

YOU EXPRESSLY ACKNOWLEDGE THAT THE DOWNLOAD OF ANY APPLICATIONS INCLUDING JAVA APPLICATIONS OR GAMES IS DONE UNDER YOUR EXCLUSIVE RESPONSIBILITY. IN NO EVENT SHALL SIERRA WIRELESS SA, YOUR NETWORK SERVICE PROVIDER OR THEIR AFFILIATES BE LIABLE FOR ANY LOST PROFITS OR COSTS OF PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES, LOSS OF PROFITS, INTERRUPTION OF BUSINESS, LOSS OF DATA OR FOR ANY SPECIAL, INDIRECT, INCIDENTAL, ECONOMIC, OR CONSEQUENTIAL DAMAGES ARISING UNDER CONTRACT, TORT, NEGLIGENCE, OR OTHER THEORY OF LIABILITY RELATING TO THE DOWNLOAD OF ANY APPLICATION BY ANY MEANS, INCLUDING JAVA APPLICATIONS OR GAMES IN SIERRA WIRELESS SA DEVICES. YOU EXPRESSLY ACKNOWLEDGE THAT ANY APPLICATIONS INCLUDING JAVA APPLICATIONS OR GAMES ARE PROVIDED STRICTLY "AS IS". SIERRA WIRELESS SA AND/OR YOUR NETWORK SERVICE PROVIDER EXTEND NO WARRANTY WHATSOEVER THERETO. SIERRA WIRELESS SA AND/OR YOUR NETWORK SERVICE PROVIDER DISCLAIM ANY EXPRESS, IMPLIED OR STATUTORY WARRANTY OF MERCHANTABILITY, FITNESS OF ANY APPLICATIONS INCLUDING JAVA APPLICATIONS OR GAMES FOR A SPECIFIC PURPOSE, SATISFACTORY QUALITY, SECURITY OR OTHERWISE.

Troubleshooting

PROBLEM - SITUATION

ACTIONS

It is impossible to switch the phone on	Remove and replace the battery. If you still cannot switch the phone on, charge the battery: - Put it on charge for at least 15 minutes before switching it back on again. - Check if the battery icon is scrolling up and down. - If so, the phone is charging. - If not, please take the charger out and put it back on again. Please check that the charging icon is scrolling up and down. - If you still cannot switch the phone on, please disconnect the charger, put it back on again and please repeat that manipulation several times. - If the charging icon is still not scrolling up and down, please contact your after-sales services. - When the charging icon has stopped scrolling up and down, the battery is charged.
Battery status unknown	The phone does not recognize the battery. Please check the position of the battery.
LOW BATTERY	This message is displayed when the battery becomes too weak. The phone switches itself off automatically. Put the phone on charge.
SIM not present	Check if the SIM card is present and properly positioned / inserted. Check the condition of the SIM card. If damaged, please go back to the operator's shop for advice. Contact your after-sales service if the message persists.
Incorrect PIN code	An incorrect PIN code has been entered. Be careful! Three incorrect PIN codes will block the SIM Card.

PROBLEM - SITUATION

ACTIONS

SIM BLOCKED

If a wrong PIN number is entered three times in succession, your SIM card is blocked. You must then:

- Enter the PUK (Personal Unblocking Key) code provided by your operator, and validate.
- Enter your PIN number and validate.
- Enter your PIN number again and validate. For this, follow the following sequence : **05*PUK*PIN*PIN#

After 5 or 10 failed attempts (depending on the type of SIM card), the SIM card is definitely locked. You must then contact your operator or your SMC to obtain a new card.

SIM LOCKED-OUT

On network providers' request, the handset can only be used with some types of SIM cards. This message means that the SIM card you are using does not fit with the phone. Take the SIM card out, and switch it back on. If the message **SIM not present** appears on the screen, you will need to check its compatibility next to the place where you bought it. If not, please contact your after-sales service.

No call connection

Check that the number you have dialled is correct.

If the letter R is displayed on the top right corner of the screen, without any network name displayed, only emergency services can be called.

Check the status of your credit.

Check that the SIM Card you are using offers the service you are requesting; check if its validity has not expired.

Check and deactivate the outgoing calls restriction when necessary.

The network could be saturated. Try later.

If the problem persists, please contact your Technical Helpdesk.

PROBLEM - SITUATION

ACTIONS

No receiving calls

Try to make a call in order to check that the phone and the networks are operational.

Check and deactivate the permanent call forwarding (permanent call forwarding icon displayed on the screen).

Check and deactivate the incoming calls restriction when necessary.

If the problem persists, please contact your Technical Helpdesk.

Quality reception when calling

Avoid placing your fingers on the top of the phone, where the aerial is integrated: the phone will have to use full strength to establish a quality transmission.

Impossible to send message

Check that the message centre number is correctly entered.

To do so, please select the menu **Messages**, select **Options**, select **MSG centre n°** and check the number entered. Please contact your network provider to get this number.

No answer phonebox

Check that the SIM card does offer this service.

Program the call to be forwarded to answer phone using the information provided by the operator.

Check that the SIM card used offers this service. Try to make a call to check that phone and network are operational.

Check if the answer phone number is properly configured. To do so, go to the **Settings/Calls** menu, select **Voicemail** and check the number. Otherwise, enter your operator's answer phone centre number.

If answer phone icon flashing

Call the answer phone and listen to the new messages to make it disappear.

In WAP context: SERVER NOT ANSWERING message

Switch off and then switch phone back on.

Logon to home page impossible

In the **WAP** menu, **Clear the cache**.

PROBLEM - SITUATION

Operator name does not appear on screen

How do I (un)lock the keypad?

How do I switch to silent mode?

How do I delete the envelop that appears on the screen? 

How do I delete the answer phone that appears on the screen? 

How do I remove the written message in the initial screen (1 call)?

How do I download ring tones?

How do I free up memory to download my objects (sounds, images)

How do I free up memory to receive new messages?

How do I free up memory to store new contacts in my Phonebook?

ACTIONS

Go into the **Settings** menu, select **Networks**, then **Selection**. Wait until the operator appears, select it and validate.

If the Operator logo is present, activate the display (**Settings/Display/Operator Logo**).

Press the  key, then the  key or the **OK** key.

Hold the  key down unless ring tone sounds, when a short touch is enough.

If you have received a voice mail, please call your voice mailbox and follow the instructions given.

This answer phone means that you have received a voice mail: please call your voice mailbox and listen to it. Please follow the instructions given.

Press the  key to go back to the initial page without messages.

Logon to one of the following site via your computer: www.mobilemediacorner.com. These site offer to send ring tones to your phone in the form of an SMS. You can also logon to your operator's site. Once the SMS has been received, all you have to do is save it: validate the option « Save messages », the tune will then be added to your list. In addition, you can logon to some sites by phone.

Go into the **Multimedia** menu, select **My Pictures** or **My Sounds** then delete some objects.

Manage your Outbox carefully. It is recommended not saving them automatically: too many messages saved will quickly fill up the available memory and no further messages will be received. To delete them, please go into the **Messages** menu, select **Outbox** then delete some messages. Manage your **Inbox** carefully also.

It is highly recommended to manage your Phonebook carefully.

If you have received pictures enclosed to a Vcard, please save or delete them.

PROBLEM - SITUATION

How can I increase the efficiency of my phone?

ACTIONS

The most efficient actions are as follows:

Please keep your phone safely in order to avoid pressing the keys unnecessarily: every time a key is pressed the screen lights up.

Make sure that you don't obstruct the antenna with your fingers when using the phone (see page 21).

Index

A

Activating your phone	16
Alarm	46
Anonymous mode	52

B

Battery	
Charging the battery	22
Installing the battery	17
Beeps	49, 55
Bluetooth	58
Business card	25

C

Calculator	45
Calendar	47
Call barring	50
Call forward	51
Calls	19
Calls (menu)	
Automatic redial	53
Call waiting	56
Counters	53
Group status	53
View last calls	53
Car kit	59
Confidentiality	50
Connectivity	58
Contact	23
Call	23

Delete	25
Mailing list	24
Modify	24
Contacts	18, 58
Converter	45
Cost	51
Currencies	45

D

Date and time	19
Display	55
Display number	52

E

Energy saving	55
---------------	----

F

Fixed dialling	51
----------------	----

G

Getting started	18
GPRS	40, 41, 42
Group Calls	29
GSM	41

H

Hands-free mode	20
Help	14, 57

I			
Icon	15		
Identity	26		
Initial screen	15		
Input modes	33		
IP address	41		
K			
Keypad locking	12, 49		
L			
Languages	55		
Local information	38		
M			
Memory	38, 55		
Menus	9		
Messages			
Compose MMS	34		
Compose SMS	31		
Drafts	36		
Inbox	35		
Outbox	35		
Receiving messages	35		
Sending options	37		
Multimedia (menu)			
Memory	55		
My Pictures	54		
My Sounds	54		
N			
Navigation principles	14		
Network	19		
		Networks	53
		O	
		Operator	50
		Options	37
		Organiser	58
		P	
		Phone code	50
		Phonebook	
		Memory	24
		New contact	23
		Using the phonebook	23
		Photo	58
		Picture	54, 58
		PIN number	49
		PIN2 number	50
		R	
		Recorder	49
		Ring tones	48
		S	
		Safety information	62
		Security	49, 57
		Sentbox	36
		Serial speed	59
		Shortcut keys	57
		Silent mode	48
		SIM card	16, 17
		SMS	31
		Sound	58
		Sounds	48, 54, 57

T

T9	32
Timer	46
ToDo	43
Troubleshooting	78, 79, 80, 81, 82

U

USB cable	58
-----------	----

V

vCal	44
Vibrate	48
Voicemail	52
Volume	48, 55

W

WAP	39, 42
Configuring WAP parameters	40
Downloading objects	41
Services menu	39
WAP logging off	42
WAP logging on	41
WAP settings	51
WAP Settings	51
Warranty	65
Wellphone	58

Y

Your phone package	11
--------------------	----







Sierra Wireless SA
5, boulevard Gallieni
92442 Issy-les-Moulineaux Cedex - France
www.sierrawireless.com